

**RSA6100A Series  
Real-Time Spectrum Analyzers  
Programmer Manual**



077-0249-00

**Tektronix**



**RSA6100A Series  
Real-Time Spectrum Analyzers  
Programmer Manual**

Copyright © Tektronix. All rights reserved. Licensed software products are owned by Tektronix or its subsidiaries or suppliers, and are protected by national copyright laws and international treaty provisions.

Tektronix products are covered by U.S. and foreign patents, issued and pending. Information in this publication supersedes that in all previously published material. Specifications and price change privileges reserved.

TEKTRONIX and TEK are registered trademarks of Tektronix, Inc.

### **Contacting Tektronix**

Tektronix, Inc.  
14200 SW Karl Braun Drive  
P.O. Box 500  
Beaverton, OR 97077  
USA

For product information, sales, service, and technical support:

- In North America, call 1-800-833-9200.
- Worldwide, visit [www.tektronix.com](http://www.tektronix.com) to find contacts in your area.

---

# Table of Contents

Preface .....	iii
Related Documentation .....	iii

## Getting Started

Getting Started .....	1-1
Overview of the Manual .....	1-1
Connecting the Interface .....	1-3
Using the GPIB Port.....	1-4
Setting the GPIB Address.....	1-5
Using TekVISA .....	1-6

## Syntax and Commands

Command Syntax .....	2-1
Backus-Naur Form Definition .....	2-1
SCPI Commands and Queries .....	2-2
IEEE 488.2 Common Commands.....	2-8
Constructed Mnemonics .....	2-8
Command Groups .....	2-9
Measurement Views .....	2-9
Functional Groups .....	2-11
Programming Hints.....	2-12
IEEE Common Commands.....	2-13
Abort Commands .....	2-14
Calculate Commands.....	2-15
Marker Mnemonics.....	2-22
Calibration Commands.....	2-23
Display Commands.....	2-24
Fetch Commands .....	2-33
Initiate Commands .....	2-40
Input Commands.....	2-41
Mass Memory Commands.....	2-42
Specifying the File.....	2-44

Output Commands.....	2-45
Read Commands.....	2-46
Sense Commands.....	2-53
Status Commands.....	2-63
System Commands.....	2-65
Trace Commands.....	2-66
Trace Mnemonics.....	2-69
Trigger commands.....	2-71
Unit Commands.....	2-73
Retrieving Response Message.....	2-74
Command Descriptions.....	2-75

## Status and Events

Status and Events.....	3-1
Status and Event Reporting System.....	3-1
Status Byte.....	3-4
Standard Event Status Block.....	3-6
Operation Status Block.....	3-7
Questionable Status Block.....	3-8
Queues.....	3-10
Status and Event Processing Sequence.....	3-11
Synchronizing Execution.....	3-12
Error Messages and Codes.....	3-14
Command Errors.....	3-14
Execution Errors.....	3-15
Device Specific Errors.....	3-17
Query Errors.....	3-17
Device Errors.....	3-18

## Appendices

Appendix A: Character Charts.....	A-1
Appendix B: GPIB Interface Specification.....	B-1
Interface Functions.....	B-1
Interface Messages.....	B-3
Appendix C: Factory Initialization Settings.....	C-1
Appendix D: SCPI Conformance Information.....	D-1

## Glossary

---

# Preface

This programmer manual covers the RSA6100A Series Real-Time Spectrum Analyzers. It provides information on operating your analyzer using the General Purpose Interface Bus (GPIB).

This manual is composed of the following sections

- *Getting Started* outlines how to use the GPIB interface.
- *Syntax and Commands* defines the syntax used in command descriptions, presents a list of all command subsystems, and presents detailed descriptions of all programming commands.
- *Status and Events* describes how the status and Events Reporting system operates and presents a list of all system errors.
- *Appendices* provides additional information including character charts, GPIB interface specification, and factory initialization settings.

## Related Documentation

- *RSA6100A Series Quick Start User Manual*  
(Tektronix part number 071-1909-XX)  
This manual contains general information about how to put your instrument into service, guides to user interface controls, and application examples.
- *RSA6100A Series Online Help*  
The online help contains detailed information about how to operate the instrument.
- *TekVISA Programmer Manual*  
(Tektronix part number 071-1101-XX)  
This manual is available as a printable PDF file on the Tektronix Web site ([www.tektronix.com](http://www.tektronix.com)). The manual describes TekVISA, the Tektronix implementation of the VISA Application Programming Interface (API). TekVISA is industry-compliant software for writing interoperable instrument drivers in a variety of Application Development Environments (ADEs).





---

# Getting Started



# Getting Started

You can write computer programs that remotely set the analyzer front panel controls or that take measurements and read those measurements for further analysis or storage. To help you get started with programming the analyzer, this section includes the following subsections

- *Overview of the Manual*  
Summarizes each major section of this manual.
- *Connecting the Interface*  
Describes how to physically connect the analyzer to a controller.
- *Using GPIB Ports*  
Describes how to use the GPIB port.
- *Setting the GPIB Address*  
Describes how to set the GPIB parameters from the front panel.
- *Using TekVISA*  
Describes how to use the TekVISA communication protocol.

## Overview of the Manual

The information contained in each major section of this manual is described below.

### Syntax and Commands

*Syntax and Commands*, describes the structure and content of the messages your program sends to the analyzer. The following figure shows command parts as described in the *Command Syntax* subsection.




Figure 1-1: Command parts

Section 2 also describes the effect of each command and provides examples of how you might use it. The *Command Groups* subsection provides lists by functional areas. The commands are listed alphabetically in the *Command Descriptions* section.




Figure 1-2: Functional groupings and an alphabetical list of commands

**Status and Events**

The program may request information from the instrument. The instrument provides information in the form of status and error messages. The following figure illustrates the basic operation of this system. Section 3, *Status and Events*, describes how to get status or event information from the program and details the event and error messages.




Figure 1-3: Event-driven program

## Connecting the Interface

The instrument has a 24-pin GPIB connector on its rear panel, as shown in the following figure. This connector has a D-type shell and conforms to IEEE Std 488.1-1987. Attach an IEEE Std 488.1-1987 GPIB cable (Tektronix part number 012-0991-00) to this connector.




Figure 1-4: GPIB connector (rear panel)

*Appendix B: GPIB Interface Specifications* gives more information on the GPIB configuration of the analyzer. For the other interfaces, refer to the *RSA6100A Series Quick Start User Manual*.

## Using the GPIB Port

The analyzer has Talker/Listener functions through which it can communicate with other devices, as well as the external controller, located on the bus.




Figure 1-5: GPIB connection

### GPIB Requirements

Observe the following rules when you use your analyzer with a GPIB network

- Assign a unique device address to each device on the bus. No two devices can share the same device address.
- Do not connect more than 15 devices to any one bus.
- Connect one device for every 2 m (6 ft) of cable used.
- Do not use more than 20 m (65 ft) of cable to connect devices to a bus.
- Turn on at least 2/3 of the devices on the network while using the network.
- Connect the devices on the network in a star or linear configuration, as shown in the following figure. Do not use loop or parallel configurations.





Figure 1-6: Typical GPIB network configurations


## Setting the GPIB Address

When you use the GPIB port to communicate with an external controller, follow these steps to set the address of the analyzer.

1. From the **Tools** menu, select **Options** to open the Options control panel.



2. Click the **GPIB** tab and set the primary address. Range: 0 to 30 (default: 1)



---

**NOTE.** The GPIB address cannot be initialized by the \*RST command.

---

## Using TekVISA

TekVISA is Tektronix implementation of VISA (Virtual Instrument Software Architecture), an industry-standard communication protocol. VISA provides a common standard for software developers so that software from multiple vendors, such as instrument drivers, can run on the same platform. TekVISA is industry-compliant software, available with selected Tektronix instruments. You can use this software to write (or draw) interoperable instrument drivers in a variety of Application Development Environments (ADEs). It implements a subset of Version 2.2 of the VISA specification for controlling GPIB and serial (RS-232) instrument interfaces locally or remotely via an Ethernet LAN connection.

### Installation

Use an internet browser to access the Tektronix Web site ([www.tektronix.com](http://www.tektronix.com)) and download the current TekVISA to your PC. Unzip the downloaded file in a temporary directory of your choice and run *Setup.exe*.

---

**NOTE.** *The details on TekVISA concepts and operations are explained in the TekVISA Programmer Manual that can be also found on the Tektronix Web site.*

---



---

# Syntax and Commands



---

# Command Syntax

This section contains information on the Standard Commands for Programmable Instruments (SCPI) and IEEE 488.2 Common Commands you can use to program your RSA6106A/RSA6114A analyzer. The information is organized in the following subsections

- Backus-Naur Form Definition
- SCPI Commands and Queries
- IEEE 488.2 Common Commands
- Constructed Mnemonics

## Backus-Naur Form Definition

This manual may describe commands and queries using the Backus-Naur Form (BNF) notation. The following table defines the standard BNF symbols.


**Table 2-1: BNF symbols and meanings**

<b>Symbol</b>	<b>Meaning</b>
< >	Defined element
:=	Is defined as
	Exclusive OR
{ }	Group; one element is required
[ ]	Optional; can be omitted
... .	Previous element(s) may be repeated
( )	Comment

## SCPI Commands and Queries

SCPI is a standard created by a consortium that provides guidelines for remote programming of instruments. These guidelines provide a consistent programming environment for instrument control and data transfer. This environment uses defined programming messages, instrument responses, and data format across all SCPI instruments, regardless of manufacturer. The analyzer uses a command language based on the SCPI standard.

The SCPI language is based on a hierarchical or tree structure as shown in the following figure that represents a subsystem. The top level of the tree is the root node; it is followed by one or more lower-level nodes.



**Figure 2-1: Example of SCPI subsystem hierarchy tree**

You can create commands and queries from these subsystem hierarchy trees. Commands specify actions for the instrument to perform. Queries return measurement data and information about parameter settings.

### Creating Commands

SCPI commands are created by stringing together the nodes of a subsystem hierarchy and separating each node by a colon.

In the figure above, TRIGger is the root node and EVENTt, GATEd, INPut, and SOURce are lower-level nodes. To create a SCPI command, start with the root node TRIGger and move down the tree structure adding nodes until you reach the end of a branch. Most commands and some queries have parameters; you must include a value for these parameters. If you specify a parameter value that is out of range, the parameter will be set to a default value. The command descriptions, list the valid values for all parameters.

For example, TRIGgerEVENTt:SOURce EXTRear is a valid SCPI command created from the hierarchy tree. (See Figure 2-1.)

### Creating Queries

To create a query, start at the root node of a tree structure, move down to the end of a branch, and add a question mark. TRIGgerEVENTt:SOURce? is an example of a valid SCPI query using the hierarchy tree in the figure. (See Figure 2-1.)

## Query Responses

The query causes the analyzer to return information about its status or settings. When a query is sent to the analyzer, only the values are returned. When the returned value is a mnemonic, it is noted in abbreviated format, as shown in the following table.

**Table 2-2: Query response examples**

Query	Response
CALCulate:SPECtrum:MARKer:X	7.50E+9
SENSe:SPECtrum:FFT:WINDow	BH4B

A few queries also initiate an operation action before returning information. For example, the \*CAL? query runs a calibration.

## Parameter Types

Every parameter in the command and query descriptions is of a specified type. The parameters are enclosed in brackets, such as <value>. The parameter type is listed after the parameter and is enclosed in parentheses, for example, (boolean). Some parameter types are defined specifically for the RSA6100A Series command set and some are defined by ANSI/IEEE 488.2-1987 as shown in the following table.

**Table 2-3: Parameter types used in syntax descriptions**

Parameter type	Description	Example
arbitrary block <sup>1</sup>	A specified length of arbitrary data	#512234xxxx . . . where 5 indicates that the following 5 digits (12234) specify the length of the data in bytes; xxxx ... indicates the data
boolean	Boolean numbers or values	ON or 1; OFF or 0
binary	Binary numbers	#B0110
octal	Octal numbers	#Q57, #Q3
hexadecimal <sup>2</sup>	Hexadecimal numbers (0-9, A, B, C, D, E, F)	#HAA, #H1
NR1 <sup>2</sup> numeric	Integers	0, 1, 15, -1
NR2 <sup>2,3</sup> numeric	Decimal numbers	1.2, 3.141516, -6.5
NR3 <sup>2</sup> numeric	Floating point numbers	3.1415E-9, -16.1E5
NRf <sup>2</sup> numeric	Flexible decimal number that may be type NR1, NR2 or NR3	See NR1, NR2, and NR3 examples
string <sup>4</sup>	Alphanumeric characters (must be within quotation marks)	"Testing 1, 2, 3"

<sup>1</sup> Defined in ANSI/IEEE 488.2 as "Definite Length Arbitrary Block Response Data."

<sup>2</sup> An ANSI/IEEE 488.2-1992-defined parameter type.

<sup>3</sup> Some commands and queries will accept an octal or hexadecimal value even though the parameter type is defined as NR1.


<sup>4</sup> Defined in ANSI/IEEE 488.2 as "String Response Data."

**Special Characters**

The Line Feed (LF) character (ASCII 10), and all characters in the range of ASCII 127-255 are defined as special characters. These characters are used in arbitrary block arguments only; using these characters in other parts of any command yields unpredictable results.

**Abbreviating Commands, Queries, and Parameters**

You can abbreviate most SCPI commands, queries, and parameters to an accepted short form. This manual shows these short forms as a combination of upper and lower case letters. The upper case letters indicate the accepted short form of a command. As shown in the following figure, you can create a short form by using only the upper case letters. The accepted short form and the long form are equivalent and request the same action of the instrument.



**Figure 2-2: Example of abbreviating a command**


---

**NOTE.** The numeric suffix of a command or query may be included in either the long form or short form; the analyzer will default to "1" if no suffix is used. In the above figure, the "3" of "MARKer3" indicates that the command is directed to Marker 3.

---


### Chaining Commands and Queries

You can chain several commands or queries together into a single message. To create a chained message, first create a command or query, add a semicolon (;), and then add more commands or queries and semicolons until the message is complete. If the command following a semicolon is a root node, precede it with a colon (:). The following figure illustrates a chained message consisting of several commands and queries. The single chained message should end in a command or query, not a semicolon. Responses to any queries in your message are separated by semicolons.



**Figure 2-3: Example of chaining commands and queries**

If a command or query has the same root and lower-level nodes as the previous command or query, you can omit these nodes. In the following figure, the second command has the same root node (TRIGgerEVENT) as the first command, so these nodes can be omitted.



**Figure 2-4: Example of omitting root and lower-level nodes in a chained message**

**Unit and SI Prefix**

If the decimal numeric argument refers to amplitude, frequency, or time, you can express it using SI units instead of using the scaled explicit point input value format <NR3>. (SI units are units that conform to the Systeme International d'Unites standard.) For example, you can use the input format 200 mV or 1.0 MHz instead of 200.0E-3 or 1.0E+6, respectively, to specify voltage or frequency.

The following table lists the available units.

**Table 2-4: Available units**

Symbol	Meaning
dB	decibel (relative amplitude)
dBm	decibel (absolute amplitude)
DEG	degree (phase)
Hz	hertz (frequency)
PCT	percent (%)
s	second (time)
V	volt

The available SI prefixes are shown in the following table.

**Table 2-5: Available SI prefixes**

SI prefix	Z	A	F	P	N	U	M	K	MA <sup>1</sup>	G	T	PE	EX
Corresponding power	10 <sup>-21</sup>	10 <sup>-18</sup>	10 <sup>-15</sup>	10 <sup>-12</sup>	10 <sup>-9</sup>	10 <sup>-6</sup>	10 <sup>-3</sup>	10 <sup>+3</sup>	10 <sup>+6</sup>	10 <sup>+9</sup>	10 <sup>+12</sup>	10 <sup>+15</sup>	10 <sup>+18</sup>

<sup>1</sup> When the unit is "Hz", "M" may be used instead of "MA" so that the frequency can be represented by "MHz".

You can omit a unit in a command, but you must include the unit when using a SI prefix. For example, frequency of 15 MHz can be described as follows

15.0E6, 1.5E7Hz, 15000000, 15000000Hz, 15MHz, etc.  
("15M" is not allowed.)

Note that you can use either lower or upper case units and prefixes. The following examples have the same result, respectively.

170mhz, 170mHz, 170MHz, etc.  
250mv, 250mV, 250MV, etc.



**General Rules**

Here are three general rules for using SCPI commands, queries, and parameters:

- You can use single (‘ ’) or double (“ ”) quotation marks for quoted strings, but you cannot use both types of quotation marks for the same string.

correct        "This string uses quotation marks correctly."

correct        ‘This string also uses quotation marks correctly.’

incorrect      "This string does not use quotation marks correctly.’

- You can use upper case, lower case, or a mixture of both cases for all commands, queries, and parameters.

SENSE:SPECTRUM:FFT:LENGTH 1024

is the same as

sense:spectrum:fft:length 1024

and

SENSE:spectrum:FFT:length 1024

---

**NOTE.** *Literal strings (quoted) are case sensitive, for example, file names.*

---

- No embedded spaces are allowed between or within nodes.

correct        SENSE:SPECTRUM:FFT:LENGTH 1024

incorrect      SENSE: SPECTRUM: FFT: LEN GTH 1024

## IEEE 488.2 Common Commands

<b>Description</b>	ANSI/IEEE Standard 488.2 defines the codes, formats, protocols, and usage of common commands and queries used on the interface between the controller and the instruments. The analyzer complies with this standard.
<b>Command and Query Structure</b>	<p>The syntax for an IEEE 488.2 common command is an asterisk (*) followed by a command and, optionally, a space and parameter value. The syntax for an IEEE 488.2 common query is an asterisk (*) followed by a query and a question mark. All of the common commands and queries are listed in the last part of the <i>Syntax and Commands</i> section. The following are examples of common commands:</p> <ul style="list-style-type: none"> <li>■ *ESE 16</li> <li>■ *CLS</li> </ul> <p>The following are examples of common queries</p> <ul style="list-style-type: none"> <li>■ *ESR</li> <li>■ *IDN</li> </ul>

## Constructed Mnemonics

Some header mnemonics specify one of a range of mnemonics. For example, a trace mnemonic can be either TRACe1, TRACe2, TRACe3, or TRACe4. You use these mnemonics in the command just as you do any other mnemonic. For example, there is a TRACe1:SPECTrum:FUNCTion command, and there is also a TRACe2:SPECTrum:FUNCTion command. In the command descriptions, this list of choices is abbreviated as TRACe<x>. The value of <x> is the upper range of valid suffixes. If the numeric suffix is omitted, the analyzer uses the default value of "1".

**Table 2-6: Constructed mnemonics**

Symbol	Meaning
MARKer<x>	A marker specifier where <x> = 0, 1, 2, 3, or 4. Refer to <i>Marker Mnemonics</i>
RANGe<x>	A range specifier where <x> = 1 to 20. Refer to <i>[SENSe]:SPURious Subgroup</i> for details.
SPUR<x>	A spurious specifier where <x> = 1 to the number of spurious signals. Refer to <i>FETCh :READ:SPURious Subgroup</i> for details, respectively.
TRACe<x>	A trace specifier where <x> = 0, 1, 2, 3, 4, or 5. Refer to <i>TRACe Commands</i> for details.

---

## Command Groups

This section lists the RSA6100A Series analyzer commands in two ways. It first presents them by functional groups. It then lists them alphabetically. The functional group list starts below. The alphabetical list provides more detail on each command.

The RSA6100A Series analyzers conform to the Standard Commands for Programmable Instruments (SCPI) 1999.0 and IEEE Std 488.2-1987 except where noted.

Items followed by question marks are queries; items without question marks are commands. Some items in this section have a question mark in parentheses ( ) in the command header section; this indicates that the item can be both a command and a query.

For the conventions of notation in this manual, refer to *Command Syntax* and following pages.

## Measurement Views

The measurement views in the RSA6100A Series analyzers are categorized into the following five groups:

- General signal viewing
- General purpose analog demodulation (Option 21 only)
- General purpose digital modulation (Option 21 only)
- RF measurements
- Pulsed RF (Option 20 only)

Each group contains the measurement views as shown in the following table. Each command works in particular measurement view(s) which are specified under the *Conditions* heading in the command descriptions.

---

**NOTE.** *If you send a command for the measurement view that is not displayed on screen, an execution error will occur.*

---

**Table 2-7: Measurement views**

<b>Display group</b>	<b>Measurement view</b>
General signal viewing	Spectrum
	DPX (Digital Phosphor) spectrum
	Amplitude versus Time
	Frequency versus Time
	Phase versus Time
	RF I&Q versus Time
	Spectrogram
General purpose analog demodulation (Option 21 only)	Time overview
	AM
	FM
General purpose digital modulation (Option 21 only)	PM
	Constellation
	Demodulated I&Q vs Time
	EVM versus Time
	Eye diagram
	Frequency deviation vs Time
	Magnitude error versus Time
	Phase error versus Time
	Signal quality
	Symbol table
RF measurements	Trellis diagram
	CCDF
	Channel power and ACPR (Adjacent Channel Power Ratio)
	MCPR (Multiple Carrier Power Ratio)
	Occupied Bandwidth (OBW)
	Phase noise (Option 11 only)
	Spurious
Pulsed RF (Option 20 only)	Pulse statistics
	Pulse table
	Pulse trace

## Functional Groups

All commands are divided into groups as shown in the following table.

**Table 2-8: List of command group**

<b>Command group</b>	<b>Function</b>
IEEE common	Conforms to the IEEE Std 488.2.
ABORt	Resets the trigger system and stops measurements.
CALCulate	Controls the markers and the search operations.
CALibration	Controls the external correction.
DISPlay	Controls the display of measurement results and waveforms.
FETCh	Retrieves the measurements from the last acquired data.
INITiate	Controls data acquisition.
INPut	Controls the characteristics of the signal input.
MMEMory	Provides mass storage capabilities for the analyzer.
OUTPut	Controls the characteristics of the signal output.
READ	Obtains the measurement results with acquiring data.
SENSe	Sets up detailed conditions for each measurement.
STATus	Controls the status and event registers.
SYSTem	Sets or queries system parameters for operation.
TRACe	Controls trace activation and math operations.
TRIGger	Controls triggering.
UNIT	Specifies fundamental units for measurement.

## Programming Hints

Here are some basic tips for using the RSA6100A Series GPIB commands:

- *Selecting a measurement item*  
Use Display commands to select or display the measurement view.  
[Example] `DISPlay:GENeral:MEASview:NEW SPECTrum`  
Displays the spectrum view on the screen.
- *Setting measurement parameters*  
Use Sense commands to set conditions for the measurement session.  
[Example] `SENSe:SPECTrum:FREQUENCY:CENTer 1.5GHZ`  
Sets the center frequency to 1.5 GHz in the spectrum view.
- *Acquiring an input signal*  
Use an Initiate or Abort command to start or stop data acquisition.  
[Example] `INITiate:CONTinuous ON;INITiate:IMMediate`  
Starts data acquisition in the continuous mode.
- *Processing waveforms arithmetically*  
Use Trace commands for math operation on waveforms.  
[Example] `TRACe1:SPECTrum:FUNCTion`  
`AVERage` Averages the spectrum waveform.
- *Measuring with the markers*  
Use Calculate commands to measure some quantity using the markers.  
[Example] `CALCulate:SPECTrum:MARKer1:MAXimum`  
Positions the marker at the highest peak signal on the spectrum.
- *Obtaining the measurement results*  
Use a Fetch or Read command to get the results.  
[Example] `FETCH:SPECTrum:TRACe1`  
Returns the spectrum trace data.
- *Scaling the waveform*  
Use Display commands to change the waveform portion on screen.  
[Example] `DISPlay:IQVTime:Y:SCALE 1.5`  
Sets the vertical range to 1.5 V in the IQ versus Time graph.

Refer to *Appendix C* for the default settings of the commands. (See page 3-1.)

The following sections list the commands by group.

# IEEE Common Commands

The IEEE 488.2 common commands have a "\*" prefix.

**Table 2-9: Status and error commands**

Header	Description
*CAL	Performs an internal self-calibration.
*CLS	Clears status.
*ESE	Sets or queries the bits in the ESER register.
*ESR?	Returns the contents of the SESR register.
*IDN?	Returns the instrument identification code.
*OPC	Synchronizes commands.
*OPT?	Returns a list of options installed in your analyzer.
*RST	Returns the instrument settings to the factory defaults.
*SRE	Sets or queries the bits in the SRER register.
*STB?	Returns the contents of the SBR using the MSS bit.
*TRG	Generates a trigger.
*WAI	Prevents the analyzer from executing further commands.

## Abort Commands

Use the Abort commands to reset the trigger system and to stop measurements.

**Table 2-10: Abort commands**

Header	Description
<a href="#">ABORT</a>	Resets the trigger system and stops measurements.



# Calculate Commands

Use the Calculate commands to control the markers and the search operations.

Table 2-11: Calculate commands

Header	Description
<b>CALCulate basic command subgroup</b>	<b>General marker control</b>
<a href="#">CALCulate:MARKer:ADD</a>	Adds a marker.
<a href="#">CALCulate:MARKer:AOff</a>	Turns off all markers.
<a href="#">CALCulate:MARKer:DELeTe</a>	Deletes the last marker added.
<a href="#">CALCulate:MARKer:DENSity:EXCursion</a>	Sets or queries the minimum excursion of DPX signal density.
<a href="#">CALCulate:MARKer:DENSity:SMOothing</a>	Sets or queries the number of pixels squared for smoothing the density.
<a href="#">CALCulate:MARKer:DENSity:THReshold</a>	Sets or queries the threshold of DPX signal density to detect peaks.
<a href="#">CALCulate:MARKer:MODE</a>	Selects or queries the marker mode.
<a href="#">CALCulate:MARKer:PEAK:EXCursion</a>	Sets or queries the minimum excursion level.
<a href="#">CALCulate:MARKer:PEAK:THReshold</a>	Sets or queries the threshold level to detect peaks.
<a href="#">CALCulate:SEARch:LIMit:FAIL?</a>	Queries whether the waveform cuts across the limit or not.
<a href="#">CALCulate:SEARch:LIMit:MATCh:BEEP[:STATe]</a>	Selects or queries whether to beep when a match occurs.
<a href="#">CALCulate:SEARch:LIMit:MATCh:SACQuire[:STATe]</a>	Selects or queries whether to stop acquiring data on match.
<a href="#">CALCulate:SEARch:LIMit:MATCh:SDATa[:STATe]</a>	Selects or queries whether to save the acquisition data automatically.
<a href="#">CALCulate:SEARch:LIMit:MATCh:SPICture[:STATe]</a>	Selects or queries whether to save the whole screen automatically.
<a href="#">CALCulate:SEARch:LIMit:MATCh:STRace[:STATe]</a>	Selects or queries whether to save the spectrum trace automatically.
<a href="#">CALCulate:SEARch:LIMit:OPERation</a>	Selects or queries the limit operation in the search function.
<a href="#">CALCulate:SEARch:LIMit:OPERation:FEED</a>	Sets or queries the data flow to be fed in the search operation.
<a href="#">CALCulate:SEARch:LIMit:OPERation:MASK:LOAD</a>	Loads the limit mask from a specified file for the search operation.
<a href="#">CALCulate:SEARch:LIMit:OPERation:MASK:STORE</a>	Stores the limit mask to a specified file for the search operation.
<a href="#">CALCulate:SEARch:LIMit:OPERation:SLIMit</a>	Sets or queries the limit value in the search operation.
<a href="#">CALCulate:SEARch:LIMit:REPort:DATA?</a>	Returns the frequency range(s) that satisfy the search condition.
<a href="#">CALCulate:SEARch:LIMit:REPort:POINts?</a>	Returns the number of range(s) that satisfy the search condition.
<a href="#">CALCulate:SEARch:LIMit:STATe</a>	Selects or queries whether to enable or disable the search function.
<b>CALCulate:ACPower subgroup</b>	<b>Channel power and ACPR measurement</b>
<a href="#">CALCulate:ACPower:MARKer&lt;x&gt;:DELTA:X?</a>	Returns the delta marker frequency for the selected marker.
<a href="#">CALCulate:ACPower:MARKer&lt;x&gt;:DELTA:Y?</a>	Returns the delta marker amplitude for the selected marker.
<a href="#">CALCulate:ACPower:MARKer&lt;x&gt;:MAXimum</a>	Moves the marker to the highest peak on the trace.
<a href="#">CALCulate:ACPower:MARKer&lt;x&gt;:PEAK:LEFT</a>	Moves the marker to the next peak to the left on the trace.
<a href="#">CALCulate:ACPower:MARKer&lt;x&gt;:PEAK:RIGHT</a>	Moves the marker to the next peak to the right on the trace.
<a href="#">CALCulate:ACPower:MARKer&lt;x&gt;:X</a>	Sets or queries the horizontal position of the marker.
<a href="#">CALCulate:ACPower:MARKer&lt;x&gt;:Y?</a>	Queries the marker amplitude of the selected marker.

Table 2-11: Calculate commands (cont.)

Header	Description
<b>CALCulate:{AM FM PM} subgroup (Option 21 only)</b>	<b>AM/FM/PM measurement</b>
CALCulate:{AM FM PM}:MARKer<x>:DELTA:X?	Returns the delta marker time for the selected marker.
CALCulate:{AM FM PM}:MARKer<x>:DELTA:Y?	Returns the delta marker amplitude for the selected marker.
CALCulate:{AM FM PM}:MARKer<x>:MAXimum	Moves the marker to the highest peak on the trace.
CALCulate:{AM FM PM}:MARKer<x>:PEAK:HIGHer	Moves the marker to the next peak higher in amplitude.
CALCulate:{AM FM PM}:MARKer<x>:PEAK:LEFT	Moves the marker to the next peak to the left on the trace.
CALCulate:{AM FM PM}:MARKer<x>:PEAK:LOWer	Moves the marker to the next peak lower in amplitude.
CALCulate:{AM FM PM}:MARKer<x>:PEAK:RIGHT	Moves the marker to the next peak to the right on the trace.
CALCulate:{AM FM PM}:MARKer<x>:X	Sets or queries the horizontal position (time) of the marker.
CALCulate:{AM FM PM}:MARKer<x>:Y?	Queries the marker amplitude of the selected marker.
<b>CALCulate:AVTime subgroup</b>	<b>Frequency versus Time measurement</b>
CALCulate:AVTime:MARKer<x>:DELTA:X?	Returns the delta marker time for the selected marker.
CALCulate:AVTime:MARKer<x>:DELTA:Y?	Returns the delta marker amplitude for the selected marker.
CALCulate:AVTime:MARKer<x>:MAXimum	Moves the marker to the highest peak on the trace.
CALCulate:AVTime:MARKer<x>:PEAK:HIGHer	Moves the marker to the next peak higher in amplitude.
CALCulate:AVTime:MARKer<x>:PEAK:LEFT	Moves the marker to the next peak to the left on the trace.
CALCulate:AVTime:MARKer<x>:PEAK:LOWer	Moves the marker to the next peak lower in amplitude.
CALCulate:AVTime:MARKer<x>:PEAK:RIGHT	Moves the marker to the next peak to the right on the trace.
CALCulate:AVTime:MARKer<x>:TRACe	Selects or queries the trace on which the marker is placed.
CALCulate:AVTime:MARKer<x>:X	Sets or queries the horizontal position of the marker.
CALCulate:AVTime:MARKer<x>:Y?	Queries the marker amplitude of the selected marker.
<b>CALCulate:CONSte subgroup (Option 21 only)</b>	<b>Constellation measurement</b>
CALCulate:CONSte:MARKer<x>:DELTA:X[:TIME]?	Returns the delta marker time for the selected marker.
CALCulate:CONSte:MARKer<x>:FDEVIation?	Queries the frequency deviation of the selected marker.
CALCulate:CONSte:MARKer<x>:MAGNitude?	Queries the magnitude readout of the marker.
CALCulate:CONSte:MARKer<x>:MAXimum	Positions the marker at the symbol in the center of the time record.
CALCulate:CONSte:MARKer<x>:PEAK:LEFT	Moves the marker in the time domain to the next lower symbol number.
CALCulate:CONSte:MARKer<x>:PEAK:RIGHT	Moves the marker in the time domain to the next higher symbol number.
CALCulate:CONSte:MARKer<x>:PHASe?	Queries the phase readout of the marker.
CALCulate:CONSte:MARKer<x>:SYMBol?	Queries the symbol readout of the marker.
CALCulate:CONSte:MARKer<x>:VALue?	Queries the value readout of the marker.
CALCulate:CONSte:MARKer<x>:X	Sets or queries the time position of the marker on the trace.
<b>CALCulate:DIQVtime subgroup (Option 21 only)</b>	<b>Demodulated I&amp;Q versus Time measurement</b>
CALCulate:DIQVtime:MARKer<x>:DELTA:X[:TIME]?	Returns the delta marker time for the selected marker.
CALCulate:DIQVtime:MARKer<x>:DELTA:Y?	Returns the delta marker amplitude for the selected marker.
CALCulate:DIQVtime:MARKer<x>:MAXimum	Moves the marker to the highest peak on the trace.
CALCulate:DIQVtime:MARKer<x>:PEAK:HIGHer	Moves the marker to the next peak higher in amplitude.

Table 2-11: Calculate commands (cont.)

Header	Description
CALCulate:DIQVtime:MARKer<x>:PEAK:LEFT	Moves the marker to the next peak to the left on the trace.
CALCulate:DIQVtime:MARKer<x>:PEAK:LOWer	Moves the marker to the next peak lower in amplitude.
CALCulate:DIQVtime:MARKer<x>:PEAK:RIGHT	Moves the marker to the next peak to the right on the trace.
CALCulate:DIQVtime:MARKer<x>:TRACe	Places the selected marker on the Demodulated I&Q versus Time trace.
CALCulate:DIQVtime:MARKer<x>:X[:TIME]	Sets or queries the horizontal position (time) of the marker.
CALCulate:DIQVtime:MARKer<x>:Y?	Queries the marker amplitude of the selected marker.
<b>CALCulate:DPSA subgroup</b>	<b>DPX spectrum measurement</b>
CALCulate:DPSA:MARKer<x>:DELTA:Y?	Returns the delta marker amplitude for the selected marker.
CALCulate:DPSA:MARKer<x>:MAXimum	Moves the marker to the highest peak on the trace.
CALCulate:DPSA:MARKer<x>:PEAK:HIGHer	Moves the marker to the next peak higher in amplitude.
CALCulate:DPSA:MARKer<x>:PEAK:LEFT	Moves the marker to the next peak to the left on the trace.
CALCulate:DPSA:MARKer<x>:PEAK:LOWer	Moves the marker to the next peak lower in amplitude.
CALCulate:DPSA:MARKer<x>:PEAK:RIGHT	Moves the marker to the next peak to the right on the trace.
CALCulate:DPSA:MARKer<x>[:SET]:CENTer	Sets the center frequency to the marker frequency.
CALCulate:DPSA:MARKer<x>:TRACe	Selects or queries the trace to attach the marker to.
CALCulate:DPSA:MARKer<x>:X:AMPLitude	Sets or queries the amplitude position of the marker.
CALCulate:DPSA:MARKer<x>:X[:FREQuency]	Sets or queries the frequency position of the marker.
CALCulate:DPSA:MARKer<x>:Y?	Queries the marker amplitude of the selected marker.
<b>CALCulate:EDiagram subgroup (Option 21 only)</b>	<b>Eye diagram</b>
CALCulate:EDiagram:MARKer<x>:DELTA:X[:TIME]?	Returns the delta marker time for the selected marker.
CALCulate:EDiagram:MARKer<x>:DELTA:Y?	Returns the delta marker amplitude for the selected marker.
CALCulate:EDiagram:MARKer<x>:MAXimum	Moves the marker to the highest peak on the trace.
CALCulate:EDiagram:MARKer<x>:PEAK:HIGHer	Moves the marker to the next peak higher in amplitude.
CALCulate:EDiagram:MARKer<x>:PEAK:LEFT	Moves the marker to the next peak to the left on the trace.
CALCulate:EDiagram:MARKer<x>:PEAK:LOWer	Moves the marker to the next peak lower in amplitude.
CALCulate:EDiagram:MARKer<x>:PEAK:RIGHT	Moves the marker to the next peak to the right on the trace.
CALCulate:EDiagram:MARKer<x>:X[:TIME]	Sets or queries the horizontal position (time) of the marker.
CALCulate:EDiagram:MARKer<x>:TRACe	Places a marker on the I or Q trace in the eye diagram display.
CALCulate:EDiagram:MARKer<x>:Y?	Queries the marker amplitude of the selected marker.
<b>CALCulate:EVM subgroup (Option 21 only)</b>	<b>EVM versus Time measurement</b>
CALCulate:EVM:MARKer<x>:DELTA:X?	Returns the delta marker time for the selected marker.
CALCulate:EVM:MARKer<x>:DELTA:Y?	Returns the delta marker amplitude for the selected marker.
CALCulate:EVM:MARKer<x>:MAXimum	Moves the marker to the highest peak on the trace.
CALCulate:EVM:MARKer<x>:PEAK:HIGHer	Moves the marker to the next peak higher in amplitude.
CALCulate:EVM:MARKer<x>:PEAK:LEFT	Moves the marker to the next peak to the left on the trace.
CALCulate:EVM:MARKer<x>:PEAK:LOWer	Moves the marker to the next peak lower in amplitude.
CALCulate:EVM:MARKer<x>:PEAK:RIGHT	Moves the marker to the next peak to the right on the trace.

Table 2-11: Calculate commands (cont.)

Header	Description
<a href="#">CALCulate:EVM:MARKer&lt;x&gt;:X</a>	Sets or queries the horizontal position of the marker.
<a href="#">CALCulate:EVM:MARKer&lt;x&gt;:Y?</a>	Queries the marker amplitude of the selected marker.
<b>CALCulate:FDVTime subgroup (Option 21 only)</b>	<b>Frequency deviation versus Time measurement</b>
<a href="#">CALCulate:FDVTime:MARKer&lt;x&gt;:DELta:X[:TIME]?</a>	Returns the delta marker time for the selected marker.
<a href="#">CALCulate:FDVTime:MARKer&lt;x&gt;:DELta:Y?</a>	Returns the delta marker frequency for the selected marker.
<a href="#">CALCulate:FDVTime:MARKer&lt;x&gt;:MAXimum</a>	Moves the marker to the highest peak on the trace.
<a href="#">CALCulate:FDVTime:MARKer&lt;x&gt;:PEAK:HIGHer</a>	Moves the marker to the next peak higher in amplitude.
<a href="#">CALCulate:FDVTime:MARKer&lt;x&gt;:PEAK:LEFT</a>	Moves the marker to the next peak to the left on the trace.
<a href="#">CALCulate:FDVTime:MARKer&lt;x&gt;:PEAK:LOWer</a>	Moves the marker to the next peak lower in amplitude.
<a href="#">CALCulate:FDVTime:MARKer&lt;x&gt;:PEAK:RIGHT</a>	Moves the marker to the next peak to the right on the trace.
<a href="#">CALCulate:FDVTime:MARKer&lt;x&gt;:X[:TIME]</a>	Sets or queries the horizontal position (time) of the marker.
<a href="#">CALCulate:FDVTime:MARKer&lt;x&gt;:Y?</a>	Queries the marker amplitude of the selected marker.
<b>CALCulate:FVTime subgroup</b>	<b>Frequency versus Time measurement</b>
<a href="#">CALCulate:FVTime:MARKer&lt;x&gt;:DELta:X?</a>	Returns the delta marker time for the selected marker.
<a href="#">CALCulate:FVTime:MARKer&lt;x&gt;:DELta:Y?</a>	Returns the delta marker frequency for the selected marker.
<a href="#">CALCulate:FVTime:MARKer&lt;x&gt;:MAXimum</a>	Moves the marker to the highest peak on the trace.
<a href="#">CALCulate:FVTime:MARKer&lt;x&gt;:PEAK:HIGHer</a>	Moves the marker to the next peak higher in amplitude.
<a href="#">CALCulate:FVTime:MARKer&lt;x&gt;:PEAK:LEFT</a>	Moves the marker to the next peak to the left on the trace.
<a href="#">CALCulate:FVTime:MARKer&lt;x&gt;:PEAK:LOWer</a>	Moves the marker to the next peak lower in amplitude.
<a href="#">CALCulate:FVTime:MARKer&lt;x&gt;:PEAK:RIGHT</a>	Moves the marker to the next peak to the right on the trace.
<a href="#">CALCulate:FVTime:MARKer&lt;x&gt;:X</a>	Sets or queries the horizontal position of the marker.
<a href="#">CALCulate:FVTime:MARKer&lt;x&gt;:Y?</a>	Queries the marker amplitude of the selected marker.
<b>CALCulate:IQVTime subgroup</b>	<b>RF I&amp;Q versus Time measurement</b>
<a href="#">CALCulate:IQVTime:MARKer&lt;x&gt;:DELta:X?</a>	Returns the delta marker time for the selected marker.
<a href="#">CALCulate:IQVTime:MARKer&lt;x&gt;:DELta:Y?</a>	Returns the delta marker amplitude for the selected marker.
<a href="#">CALCulate:IQVTime:MARKer&lt;x&gt;:MAXimum</a>	Moves the marker to the highest peak on the trace.
<a href="#">CALCulate:IQVTime:MARKer&lt;x&gt;:PEAK:HIGHer</a>	Moves the marker to the next peak higher in amplitude.
<a href="#">CALCulate:IQVTime:MARKer&lt;x&gt;:PEAK:LEFT</a>	Moves the marker to the next peak to the left on the trace.
<a href="#">CALCulate:IQVTime:MARKer&lt;x&gt;:PEAK:LOWer</a>	Moves the marker to the next peak lower in amplitude.
<a href="#">CALCulate:IQVTime:MARKer&lt;x&gt;:PEAK:RIGHT</a>	Moves the marker to the next peak to the right on the trace.
<a href="#">CALCulate:IQVTime:MARKer&lt;x&gt;:TRACe</a>	Selects or queries the trace (I or Q) to place the marker.
<a href="#">CALCulate:IQVTime:MARKer&lt;x&gt;:X</a>	Sets or queries the horizontal position of the marker.
<a href="#">CALCulate:IQVTime:MARKer&lt;x&gt;:Y?</a>	Queries the marker amplitude of the selected marker.
<b>CALCulate:MCPower subgroup</b>	<b>MCPR measurement</b>
<a href="#">CALCulate:MCPower:MARKer&lt;x&gt;:DELta:X?</a>	Returns the delta marker frequency for the selected marker.
<a href="#">CALCulate:MCPower:MARKer&lt;x&gt;:DELta:Y?</a>	Returns the delta marker amplitude for the selected marker.
<a href="#">CALCulate:MCPower:MARKer&lt;x&gt;:MAXimum</a>	Moves the marker to the highest peak on the trace.

Table 2-11: Calculate commands (cont.)

Header	Description
CALCulate:MCPower:MARKer<x>:PEAK:LEFT	Moves the marker to the next peak to the left on the trace.
CALCulate:MCPower:MARKer<x>:PEAK:RIGHT	Moves the marker to the next peak to the right on the trace.
CALCulate:MCPower:MARKer<x>:X	Sets or queries the horizontal position of the marker.
CALCulate:MCPower:MARKer<x>:Y?	Queries the marker amplitude of the selected marker.
<b>CALCulate:MERRor subgroup (Option 21 only)</b>	<b>Magnitude error versus Time measurement</b>
CALCulate:MERRor:MARKer<x>:DELTA:X?	Returns the delta marker time for the selected marker.
CALCulate:MERRor:MARKer<x>:DELTA:Y?	Returns the delta marker amplitude for the selected marker.
CALCulate:MERRor:MARKer<x>:MAXimum	Moves the marker to the highest peak on the trace.
CALCulate:MERRor:MARKer<x>:PEAK:HIGHer	Moves the marker to the next peak higher in amplitude.
CALCulate:MERRor:MARKer<x>:PEAK:LEFT	Moves the marker to the next peak to the left on the trace.
CALCulate:MERRor:MARKer<x>:PEAK:LOWer	Moves the marker to the next peak lower in amplitude.
CALCulate:MERRor:MARKer<x>:PEAK:RIGHT	Moves the marker to the next peak to the right on the trace.
CALCulate:MERRor:MARKer<x>:X	Sets or queries the horizontal position of the marker.
CALCulate:MERRor:MARKer<x>:Y?	Queries the marker amplitude of the selected marker.
<b>CALCulate:OBWidth subgroup</b>	<b>Occupied Bandwidth measurement</b>
CALCulate:OBWidth:MARKer<x>:DELTA:X?	Returns the delta marker frequency for the selected marker.
CALCulate:OBWidth:MARKer<x>:DELTA:Y?	Returns the delta marker amplitude for the selected marker.
CALCulate:OBWidth:MARKer<x>:MAXimum	Moves the marker to the highest peak on the trace.
CALCulate:OBWidth:MARKer<x>:PEAK:HIGHer	Moves the marker to the next peak higher in amplitude.
CALCulate:OBWidth:MARKer<x>:PEAK:LEFT	Moves the marker to the next peak to the left on the trace.
CALCulate:OBWidth:MARKer<x>:PEAK:LOWer	Moves the marker to the next peak lower in amplitude.
CALCulate:OBWidth:MARKer<x>:PEAK:RIGHT	Moves the marker to the next peak to the right on the trace.
CALCulate:OBWidth:MARKer<x>:[SET]:CENTer	Sets the center frequency to the value at the marker position.
CALCulate:OBWidth:MARKer<x>:X	Sets or queries the horizontal position of the marker.
CALCulate:OBWidth:MARKer<x>:Y?	Queries the marker amplitude of the selected marker.
<b>CALCulate:PERRor subgroup (Option 21 only)</b>	<b>Phase error versus Time measurement</b>
CALCulate:PERRor:MARKer<x>:DELTA:X?	Returns the delta marker time for the selected marker.
CALCulate:PERRor:MARKer<x>:DELTA:Y?	Returns the delta marker phase for the selected marker.
CALCulate:PERRor:MARKer<x>:MAXimum	Moves the marker to the highest peak on the trace.
CALCulate:PERRor:MARKer<x>:PEAK:HIGHer	Moves the marker to the next peak higher in amplitude.
CALCulate:PERRor:MARKer<x>:PEAK:LEFT	Moves the marker to the next peak to the left on the trace.
CALCulate:PERRor:MARKer<x>:PEAK:LOWer	Moves the marker to the next peak lower in amplitude.
CALCulate:PERRor:MARKer<x>:PEAK:RIGHT	Moves the marker to the next peak to the right on the trace.
CALCulate:PERRor:MARKer<x>:X	Sets or queries the horizontal position of the marker.
CALCulate:PERRor:MARKer<x>:Y?	Queries the marker amplitude of the selected marker.
<b>CALCulate:PHVTime subgroup</b>	<b>Phase versus Time measurement</b>
CALCulate:PHVTime:MARKer<x>:DELTA:X?	Returns the delta marker time for the selected marker.

Table 2-11: Calculate commands (cont.)

Header	Description
CALCulate:PHVTime:MARKer<x>:DELta:Y?	Returns the delta marker phase for the selected marker.
CALCulate:PHVTime:MARKer<x>:MAXimum	Moves the marker to the highest peak on the trace.
CALCulate:PHVTime:MARKer<x>:PEAK:HIGHER	Moves the marker to the next peak higher in amplitude.
CALCulate:PHVTime:MARKer<x>:PEAK:LEFT	Moves the marker to the next peak to the left on the trace.
CALCulate:PHVTime:MARKer<x>:PEAK:LOWER	Moves the marker to the next peak lower in amplitude.
CALCulate:PHVTime:MARKer<x>:PEAK:RIGHT	Moves the marker to the next peak to the right on the trace.
CALCulate:PHVTime:MARKer<x>:X	Sets or queries the horizontal position of the marker.
CALCulate:PHVTime:MARKer<x>:Y?	Queries the marker amplitude of the selected marker.
<b>CALCulate:PULSe subgroup (Option 20 only)</b>	<b>Pulsed RF measurements</b>
CALCulate:PULSe:STATistics:MARKer<x>:DELta:X?	Returns the delta marker frequency for the selected marker.
CALCulate:PULSe:STATistics:MARKer<x>:DELta:Y?	Returns the delta marker amplitude for the selected marker.
CALCulate:PULSe:STATistics:MARKer<x>:MAXimum	Moves the marker to the highest peak on the statistics trace.
CALCulate:PULSe:STATistics:MARKer<x>:PEAK:HIGHER	Moves the marker to the next peak higher in amplitude.
CALCulate:PULSe:STATistics:MARKer<x>:PEAK:LEFT	Moves the marker to the next peak to the left on the statistics trace.
CALCulate:PULSe:STATistics:MARKer<x>:PEAK:LOWER	Moves the marker to the next peak lower in amplitude.
CALCulate:PULSe:STATistics:MARKer<x>:PEAK:RIGHT	Moves the marker to the next peak to the right on the statistics trace.
CALCulate:PULSe:STATistics:MARKer<x>:X	Sets or queries the horizontal position of the marker.
CALCulate:PULSe:STATistics:MARKer<x>:Y?	Queries the marker amplitude of the selected marker.
CALCulate:PULSe:TRACe:MARKer<x>:DELta:X?	Returns the delta marker time for the selected marker.
CALCulate:PULSe:TRACe:MARKer<x>:DELta:Y?	Returns the delta marker amplitude for the selected marker.
CALCulate:PULSe:TRACe:MARKer<x>:MAXimum	Moves the marker to the highest peak on the pulse trace.
CALCulate:PULSe:TRACe:MARKer<x>:PEAK:HIGHER	Moves the marker to the next peak higher in amplitude.
CALCulate:PULSe:TRACe:MARKer<x>:PEAK:LEFT	Moves the marker to the next peak to the left on the pulse trace.
CALCulate:PULSe:TRACe:MARKer<x>:PEAK:LOWER	Moves the marker to the next peak lower in amplitude.
CALCulate:PULSe:TRACe:MARKer<x>:PEAK:RIGHT	Moves the marker to the next peak to the right on the pulse trace.
CALCulate:PULSe:TRACe:MARKer<x>:X	Sets or queries the horizontal position of the marker.
CALCulate:PULSe:TRACe:MARKer<x>:Y?	Queries the marker amplitude of the selected marker.
<b>CALCulate:SGRam subgroup</b>	<b>Spectrogram measurement</b>
CALCulate:SGRam:MARKer<x>:DELta:X:FREQUENCY?	Returns the delta marker frequency for the selected marker.
CALCulate:SGRam:MARKer<x>:DELta:X[:TIME]?	Returns the delta marker time for the selected marker.
CALCulate:SGRam:MARKer<x>:DELta:Y?	Returns the delta marker amplitude for the selected marker.
CALCulate:SGRam:MARKer<x>:MAXimum	Moves the marker to the highest peak on the trace.
CALCulate:SGRam:MARKer<x>:PEAK:HIGHER	Moves the marker to the next peak higher in amplitude.
CALCulate:SGRam:MARKer<x>:PEAK:LEFT	Moves the marker to the next peak to the left on the trace.
CALCulate:SGRam:MARKer<x>:PEAK:LOWER	Moves the marker to the next peak lower in amplitude.
CALCulate:SGRam:MARKer<x>:PEAK:RIGHT	Moves the marker to the next peak to the right on the trace.
CALCulate:SGRam:MARKer<x>[:SET]:CENTer	Sets the center frequency to the marker frequency.

Table 2-11: Calculate commands (cont.)

Header	Description
CALCulate:SGRam:MARKer<x>:X:FREQuency	Sets or queries the marker frequency.
CALCulate:SGRam:MARKer<x>:X[:TIME]	Sets or queries the marker time.
CALCulate:SGRam:MARKer<x>:Y?	Queries the marker amplitude of the selected marker.
<b>CALCulate:SPECtrum subgroup</b>	<b>Spectrum measurement</b>
CALCulate:SPECtrum:MARKer<x>:DELTA:X?	Returns the delta marker frequency for the selected marker.
CALCulate:SPECtrum:MARKer<x>:DELTA:Y?	Returns the delta marker amplitude for the selected marker.
CALCulate:SPECtrum:MARKer<x>:MAXimum	Moves the marker to the highest peak on the trace.
CALCulate:SPECtrum:MARKer<x>:PEAK:HIGHer	Moves the marker to the next peak higher in amplitude.
CALCulate:SPECtrum:MARKer<x>:PEAK:LEFT	Moves the marker to the next peak to the left on the trace.
CALCulate:SPECtrum:MARKer<x>:PEAK:LOWer	Moves the marker to the next peak lower in amplitude.
CALCulate:SPECtrum:MARKer<x>:PEAK:RIGHT	Moves the marker to the next peak to the right on the trace.
CALCulate:SPECtrum:MARKer<x>[:SET]:CENTer	Sets the center frequency to the marker frequency.
CALCulate:SPECtrum:MARKer<x>:TRACe	Selects or queries the trace on which the marker is placed.
CALCulate:SPECtrum:MARKer<x>:X	Sets or queries the horizontal position of the marker.
CALCulate:SPECtrum:MARKer<x>:Y?	Queries the marker amplitude of the selected marker.
<b>CALCulate:SPURious subgroup</b>	<b>Spurious measurement</b>
CALCulate:SPURious:MARKer<x>:DELTA:X?	Returns the delta marker frequency for the selected marker.
CALCulate:SPURious:MARKer<x>:DELTA:Y?	Returns the delta marker amplitude for the selected marker.
CALCulate:SPURious:MARKer<x>:MAXimum	Moves the marker to the highest peak on the trace.
CALCulate:SPURious:MARKer<x>:PEAK:HIGHer	Moves the marker to the next peak higher in amplitude.
CALCulate:SPURious:MARKer<x>:PEAK:LEFT	Moves the marker to the next peak to the left on the trace.
CALCulate:SPURious:MARKer<x>:PEAK:LOWer	Moves the marker to the next peak lower in amplitude.
CALCulate:SPURious:MARKer<x>:PEAK:RIGHT	Moves the marker to the next peak to the right on the trace.
CALCulate:SPURious:MARKer<x>[:SET]:CENTer	Sets the center frequency to the marker frequency.
CALCulate:SPURious:MARKer<x>:X	Sets or queries the horizontal position of the marker.
CALCulate:SPURious:MARKer<x>:Y?	Queries the marker amplitude of the selected marker.
<b>CALCulate:TDIagram subgroup (Option 21 only)</b>	<b>Trellis diagram</b>
CALCulate:TDIagram:MARKer<x>:DELTA:X[:TIME]?	Returns the delta marker time for the selected marker.
CALCulate:TDIagram:MARKer<x>:DELTA:Y?	Returns the delta marker amplitude for the selected marker.
CALCulate:TDIagram:MARKer<x>:MAXimum	Moves the marker to the highest peak on the trace.
CALCulate:TDIagram:MARKer<x>:PEAK:HIGHer	Moves the marker to the next peak higher in amplitude.
CALCulate:TDIagram:MARKer<x>:PEAK:LEFT	Moves the marker to the next peak to the left on the trace.
CALCulate:TDIagram:MARKer<x>:PEAK:LOWer	Moves the marker to the next peak lower in amplitude.
CALCulate:TDIagram:MARKer<x>:PEAK:RIGHT	Moves the marker to the next peak to the right on the trace.
CALCulate:TDIagram:MARKer<x>:X[:TIME]	Sets or queries the horizontal position (time) of the marker.
CALCulate:TDIagram:MARKer<x>:Y?	Queries the marker amplitude of the selected marker.
<b>CALCulate:TOVerview subgroup</b>	<b>Time overview</b>

Table 2-11: Calculate commands (cont.)

Header	Description
CALCulate:TOVerview:MARKer<x>:DELta:X?	Returns the delta marker time for the selected marker.
CALCulate:TOVerview:MARKer<x>:DELta:Y?	Returns the delta marker amplitude for the selected marker.
CALCulate:TOVerview:MARKer<x>:MAXimum	Moves the marker to the highest peak on the trace.
CALCulate:TOVerview:MARKer<x>:PEAK:HIGHer	Moves the marker to the next peak higher in amplitude.
CALCulate:TOVerview:MARKer<x>:PEAK:LEFT	Moves the marker to the next peak to the left on the trace.
CALCulate:TOVerview:MARKer<x>:PEAK:LOWer	Moves the marker to the next peak lower in amplitude.
CALCulate:TOVerview:MARKer<x>:PEAK:RIGHT	Moves the marker to the next peak to the right on the trace.
CALCulate:TOVerview:MARKer<x>:X	Sets or queries the horizontal position of the marker.
CALCulate:TOVerview:MARKer<x>:Y?	Queries the marker amplitude of the selected marker.

## Marker Mnemonics

Up to five markers can be used. In commands, these are named MARKer<x>, where <x> can be 0, 1, 2, 3, or 4 as shown in the following table.

Table 2-12: Marker mnemonics

Mnemonic	Description
MARKer0	Reference marker (MR)
MARKer1	Marker 1 (M1)
MARKer2	Marker 2 (M2)
MARKer3	Marker 3 (M3)
MARKer4	Marker 4 (M4)

**NOTE.** If you omit the numeric suffix, the marker control defaults to Marker 1.

Before operating the marker, you have to enable it using the CALCulate basic commands.

If you attempt to use a marker other than above in a CALCulate command, the suffix error (error code -130) will occur.



# Calibration Commands

Use the CALibration commands to control the external correction.

**Table 2-13: Calibration commands**

Header	Description
CALibration:ABORT	Aborts any actions related to the alignments in progress.
CALibration:AUTO	Selects or queries whether or not to run alignments automatically.
CALibration:CORRection:EXTernal:EDIT<x>:LABel	Sets or queries the name of the external loss table.
CALibration:CORRection:EXTernal:EDIT<x>:NEW	Creates a new external loss table.
CALibration:CORRection:EXTernal:EDIT<x>:STATe	Sets or queries whether to enable or disable the external loss table.
CALibration:CORRection:EXTernal:GAIN[:MAGNitude]	Sets or queries the external gain value.
CALibration:CORRection:EXTernal:GAIN:STATe	Selects or queries whether to enable or disable the external gain value.
CALibration:CORRection:EXTernal:PROBe:CONNect?	Queries whether the external probe is connected to the analyzer or not.
CALibration:CORRection:EXTernal:PROBe[:MAGNitude]?	Queries the external probe attenuation.
CALibration:CORRection:EXTernal:PROBe:STATe	Determines whether to correct data for the external probe attenuation.
CALibration:CORRection:EXTernal:TYPE	Selects data type to use when applying the external loss table.
INPut:CORRection:EXTernal:EDIT<x>:INTerpolation	Selects or queries the data type to apply the table corrections.

# Display Commands

Use the DISPLAY commands to control the display of measurement waveforms and results on the screen.

**Table 2-14: Display commands**

Header	Description
<b>DISPlay basic command subgroup</b>	<b>General window control</b>
DISPlay:WINDow:ACTive:MEASurement?	Queries the active measurement views.
DISPlay:WINDow:COLor:SCHEME	Selects or queries the color scheme for traces and background.
DISPlay:WINDow:OPTimized:MEASurement?	Queries the measurement views that are optimized.
<b>DISPlay:ACPower subgroup</b>	<b>Channel power and ACPR measurement</b>
DISPlay:ACPower:MARKer:SHOW:STATe	Determines whether to show the readout for the selected marker.
DISPlay:ACPower:PLEVel:SHOW:STATe	Determines whether to show the power levels.
DISPlay:ACPower:RESet:SCALE	Resets the horizontal and vertical scale to the default values.
DISPlay:ACPower:WINDow:TRACe:GRATICule:GRID:STATe	Determines whether to show the graticule grid on screen.
DISPlay:ACPower:X[:SCALE]	Sets or queries the horizontal range.
DISPlay:ACPower:X[:SCALE]:AUTO	Rescales the horizontal axis automatically.
DISPlay:ACPower:X[:SCALE]:OFFSet	Sets or queries the minimum horizontal value (left edge).
DISPlay:ACPower:Y[:SCALE]	Sets or queries the vertical range.
DISPlay:ACPower:Y[:SCALE]:AUTO	Rescales the vertical axis automatically.
DISPlay:ACPower:Y[:SCALE]:OFFSet	Sets or queries the vertical offset.
<b>DISPlay:ADEMod subgroup (Option 21 only)</b>	<b>General purpose analog demodulation measurements</b>
DISPlay:ADEMod:MEASview:DELete	Deletes the measurement view.
DISPlay:ADEMod:MEASview:NEW	Displays a new measurement view.
DISPlay:ADEMod:MEASview:SELect	Selects or queries the measurement view.
<b>DISPlay:{AM FM PM} subgroup (Option 21 only)</b>	<b>AM/FM/PM measurement</b>
DISPlay:{AM FM PM}:MARKer:SHOW:STATe	Determines whether to show the readout for the selected marker.
DISPlay:{AM FM PM}:WINDow:TRACe:GRATICule:GRID:STATe	Determines whether to show the graticule grid on screen.
DISPlay:{AM FM PM}:X:RScale	Rescales the horizontal axis automatically.
DISPlay:{AM FM PM}:X[:SCALE]:AUTO	Sets the horizontal scale automatically.
DISPlay:{AM FM PM}:X[:SCALE]:FULL	Sets or queries the horizontal scale.
DISPlay:{AM FM PM}:X[:SCALE]:OFFSet	Sets or queries the minimum horizontal value (left edge).
DISPlay:{AM FM PM}:Y:RScale	Rescales the vertical axis automatically.
DISPlay:{AM FM PM}:Y[:SCALE]	Sets or queries the vertical scale.
DISPlay:{AM FM PM}:Y[:SCALE]:OFFSet	Sets or queries the vertical offset.
<b>DISPlay:AVTime subgroup</b>	<b>Amplitude versus Time measurement</b>

Table 2-14: Display commands (cont.)

Header	Description
DISPlay:AVTime:LEGenD:STATe	Shows or hides the trace legend in the amplitude versus time view.
DISPlay:AVTime:MARKer:SHOW:STATe	Determines whether to show the readout for the selected marker.
DISPlay:AVTime:RESet	Resets the horizontal and vertical scale to the default values.
DISPlay:AVTime:TRIGger:LEVel:STATe	Determines whether to show the power trigger level line on screen.
DISPlay:AVTime:WINDow:TRACe:GRATicule:GRID:STATe	Determines whether to show the graticule grid on screen.
DISPlay:AVTime:X:RSCale	Rescales the horizontal axis automatically.
DISPlay:AVTime:X[:SCALE]:AUTO	Sets the horizontal scale automatically.
DISPlay:AVTime:X[:SCALE]:AUTO:STATe	Determines whether to set the horizontal scale automatically or manually.
DISPlay:AVTime:X[:SCALE]:FULL	Sets or queries the horizontal scale.
DISPlay:AVTime:X[:SCALE]:MAXimum?	Queries the upper limit of the horizontal scale setting range.
DISPlay:AVTime:X[:SCALE]:MINimum?	Queries the lower limit of the horizontal scale setting range.
DISPlay:AVTime:X[:SCALE]:OFFSet	Sets or queries the minimum horizontal value (left edge).
DISPlay:AVTime:X[:SCALE]:OFFSet:MAXimum?	Queries the upper limit of the horizontal offset setting range.
DISPlay:AVTime:X[:SCALE]:OFFSet:MINimum?	Queries the lower limit of the horizontal offset setting range.
DISPlay:AVTime:Y:RSCale	Rescales the vertical axis automatically.
DISPlay:AVTime:Y[:SCALE]:FULL	Sets or queries the vertical scale.
DISPlay:AVTime:Y[:SCALE]:OFFSet	Sets or queries the vertical offset.
<b>DISPlay:CONSte subgroup (Option 21 only)</b>	<b>Constellation measurement</b>
DISPlay:CONSte:MPHase	Selects or queries the phase multiplication constant for a CPM signal.
DISPlay:CONSte:WINDow:TRACe:GRATicule:GRID:STATe	Selects or queries whether to show the graticule grid on the screen.
<b>DISPlay:DDEMod subgroup (Option 21 only)</b>	<b>General purpose digital modulation measurements</b>
DISPlay:DDEMod:MEASview:DELete	Deletes the measurement view.
DISPlay:DDEMod:MEASview:NEW	Displays a new measurement view.
DISPlay:DDEMod:MEASview:SELect	Selects or queries the measurement view.
DISPlay:DDEMod:RADix	Selects or queries the base of symbols.
DISPlay:DDEMod:X[:SCALE]	Sets or queries the horizontal scale.
DISPlay:DDEMod:X[:SCALE]:AUTO	Sets the horizontal scale automatically.
DISPlay:DDEMod:X[:SCALE]:AUTO:STATe	Determines whether to set the horizontal scale automatically or manually.
DISPlay:DDEMod:X[:SCALE]:MAXimum?	Queries the upper limit of the horizontal scale setting range.
DISPlay:DDEMod:X[:SCALE]:MINimum?	Queries the lower limit of the horizontal scale setting range.
DISPlay:DDEMod:X[:SCALE]:OFFSet	Sets or queries the minimum horizontal value (left edge).
DISPlay:DDEMod:X[:SCALE]:OFFSet:MAXimum?	Queries the upper limit of the horizontal offset setting range.
DISPlay:DDEMod:X[:SCALE]:OFFSet:MINimum?	Queries the lower limit of the horizontal offset setting range.
DISPlay:DDEMod:X[:SCALE]:RESet	Presets the horizontal scale to the default value.

Table 2-14: Display commands (cont.)

Header	Description
<b>DISPlay:DIAGram subgroup (Option 21 only)</b>	<b>Eye/Trellis diagram</b>
DISPlay:DIAGram:X[:SCALe]	Sets or queries the horizontal range.
DISPlay:DIAGram:X[:SCALe]:RESet	Presets the horizontal scale to the default value.
<b>DISPlay:DIQVtime subgroup (Option 21 only)</b>	<b>Demodulated I&amp;Q versus Time measurement</b>
DISPlay:DIQVtime:WINDow:TRACe:GRATICule:GRID:STATe	Selects or queries whether to show the graticule grid on the screen.
DISPlay:DIQVtime:Y[:SCALe]	Sets or queries the vertical scale.
DISPlay:DIQVtime:Y[:SCALe]:AUTO	Sets the vertical scale automatically.
DISPlay:DIQVtime:Y[:SCALe]:OFFSet	Sets or queries the vertical offset (center point of the vertical axis).
<b>DISPlay:DPsA subgroup</b>	<b>DPX spectrum measurement</b>
DISPlay:CCDF:LEGend:STATe	Show or hide the trace legend in the CCDF view.
DISPlay:CCDF:WINDow:TRACe:GRATICule:GRID:STATe	Selects or queries whether to show the graticule grid on the screen.
DISPlay:DPsA:LEGend:STATe	Show or hide the trace legend on the display.
DISPlay:DPsA:WINDow:TRACe:GRATICule:GRID:STATe	Show or hide the graticule grid on the screen.
DISPlay:DPsA:Y[:SCALe]:PDIVision	Sets or queries the vertical scale (per division).
<b>DISPlay:EDIagram subgroup (Option 21 only)</b>	<b>Eye diagram</b>
DISPlay:EDIagram:WINDow:TRACe:GRATICule:GRID:STATe	Selects or queries whether to show the graticule grid on the screen.
DISPlay:EDIagram:Y[:SCALe]	Sets or queries the vertical scale.
DISPlay:EDIagram:Y[:SCALe]:AUTO	Sets the vertical scale automatically.
DISPlay:EDIagram:Y[:SCALe]:OFFSet	Sets or queries the vertical offset (center point of the vertical axis).
<b>DISPlay:EVM subgroup (Option 21 only)</b>	<b>EVM versus Time measurement</b>
DISPlay:FDVTime:WINDow:TRACe:GRATICule:GRID:STATe	Selects or queries whether to show the graticule grid on the screen.
DISPlay:EVM:Y[:SCALe]	Sets or queries the vertical scale.
DISPlay:EVM:Y[:SCALe]:AUTO	Sets the vertical scale automatically.
DISPlay:EVM:Y[:SCALe]:OFFSet	Sets or queries the minimum vertical value (bottom edge).
<b>DISPlay:FDVTime subgroup (Option 21 only)</b>	<b>Frequency deviation versus Time measurement</b>
DISPlay:FDVTime:WINDow:TRACe:GRATICule:GRID:STATe	Selects or queries whether to show the graticule grid on the screen.
DISPlay:FDVTime:Y[:SCALe]	Sets or queries the vertical range of the Frequency deviation versus Time graph.
DISPlay:FDVTime:Y[:SCALe]:AUTO	Sets the vertical scale automatically.
DISPlay:FDVTime:Y[:SCALe]:OFFSet	Sets or queries the vertical offset (center point of the vertical axis).
<b>DISPlay:FVTime subgroup</b>	<b>Frequency versus Time measurement</b>

Table 2-14: Display commands (cont.)

Header	Description
DISPlay:FVTime:WINDow:TRACe:GRATICule:GRID:STATE	Selects or queries whether to show the graticule grid on the screen.
DISPlay:FVTime:X[:SCALe]	Sets or queries the horizontal scale.
DISPlay:FVTime:X[:SCALe]:AUTO	Sets the horizontal scale automatically.
DISPlay:FVTime:X[:SCALe]:AUTO:STATE	Determines whether to set the horizontal scale automatically or manually.
DISPlay:FVTime:X[:SCALe]:MAXimum?	Queries the upper limit of the horizontal scale setting range.
DISPlay:FVTime:X[:SCALe]:MINimum?	Queries the lower limit of the horizontal scale setting range.
DISPlay:FVTime:X[:SCALe]:OFFSet	Sets or queries the minimum horizontal value (left edge).
DISPlay:FVTime:X[:SCALe]:OFFSet:MAXimum?	Queries the upper limit of the horizontal offset setting range.
DISPlay:FVTime:X[:SCALe]:OFFSet:MINimum?	Queries the lower limit of the horizontal offset setting range.
DISPlay:FVTime:Y[:SCALe]	Sets or queries the vertical scale.
DISPlay:FVTime:Y[:SCALe]:AUTO	Sets the vertical scale automatically.
DISPlay:FVTime:Y[:SCALe]:OFFSet	Sets or queries the vertical offset.
<b>DISPlay:GENeral subgroup</b>	<b>General signal viewing</b>
DISPlay:GENeral:MEASview:DELeTe	Deletes the measurement view.
DISPlay:GENeral:MEASview:NEW	Displays a new measurement view.
DISPlay:GENeral:MEASview:SELeCt	Selects or queries the measurement view.
<b>DISPlay:GPRF subgroup</b>	<b>General purpose RF measurements</b>
DISPlay:GPRF:MEASview:DELeTe	Deletes the measurement view.
DISPlay:GPRF:MEASview:NEW	Displays a new measurement view.
DISPlay:GPRF:MEASview:SELeCt	Selects or queries the measurement view.
<b>DISPlay:IQVTime subgroup</b>	<b>RF I&amp;Q versus Time measurement</b>
DISPlay:IQVTime:WINDow:TRACe:GRATICule:GRID:STATE	Selects or queries whether to show the graticule grid on the screen.
DISPlay:IQVTime:X[:SCALe]	Sets or queries the horizontal scale.
DISPlay:IQVTime:X[:SCALe]:AUTO	Sets the horizontal scale automatically.
DISPlay:IQVTime:X[:SCALe]:AUTO:STATE	Determines whether to set the horizontal scale automatically or manually.
DISPlay:IQVTime:X[:SCALe]:MAXimum?	Queries the upper limit of the horizontal scale setting range.
DISPlay:IQVTime:X[:SCALe]:MINimum?	Queries the lower limit of the horizontal scale setting range.
DISPlay:IQVTime:X[:SCALe]:OFFSet	Sets or queries the minimum horizontal value (left edge).
DISPlay:IQVTime:X[:SCALe]:OFFSet:MAXimum?	Queries the upper limit of the horizontal offset setting range.
DISPlay:IQVTime:X[:SCALe]:OFFSet:MINimum?	Queries the lower limit of the horizontal offset setting range.
DISPlay:IQVTime:Y[:SCALe]	Sets or queries the vertical scale.
DISPlay:IQVTime:Y[:SCALe]:AUTO	Sets the vertical scale automatically.
DISPlay:IQVTime:Y[:SCALe]:OFFSet	Sets or queries the vertical offset.
DISPlay:IQVTime:Y[:SCALe]:RESCale	Rescales the vertical scale.
<b>DISPlay:MCPR subgroup</b>	<b>MCPR measurement</b>

**Table 2-14: Display commands (cont.)**

<b>Header</b>	<b>Description</b>
DISPlay:MCPower:MARKer:SHOW:STATe	Determines whether to show the readout for the selected marker.
DISPlay:MCPower:PLEvel:SHOW:STATe	Determines whether to show the power levels.
DISPlay:MCPower:RESet:SCALE	Resets the horizontal and vertical scale to the default values.
DISPlay:MCPower:WINDow:TRACe:GRATICule:GRID:STATe	Determines whether to show the graticule grid on screen.
DISPlay:MCPower:X[:SCALE]	Sets or queries the horizontal range.
DISPlay:MCPower:X[:SCALE]:AUTO	Rescales the horizontal axis automatically.
DISPlay:MCPower:X[:SCALE]:OFFSet	Sets or queries the minimum horizontal value (left edge).
DISPlay:MCPower:Y[:SCALE]	Sets or queries the vertical range.
DISPlay:MCPower:Y[:SCALE]:AUTO	Rescales the vertical axis automatically.
DISPlay:MCPower:Y[:SCALE]:OFFSet	Sets or queries the vertical offset.
<b>DISPlay:MERRor subgroup (Option 21 only)</b>	<b>Magnitude error versus Time measurement</b>
DISPlay:MERRor:Y[:SCALE]	Sets or queries the vertical scale.
DISPlay:MERRor:Y[:SCALE]:AUTO	Sets the vertical scale automatically.
DISPlay:MERRor:Y[:SCALE]:OFFSet	Sets or queries the minimum vertical value (bottom edge).
<b>DISPlay:OBWidth subgroup</b>	<b>Occupied Bandwidth measurement</b>
DISPlay:OBWidth:MARKer:SHOW:STATe	Determines whether to show the readout for the selected marker.
DISPlay:OBWidth:RESet:SCALE	Resets the horizontal and vertical scale to the default values.
DISPlay:OBWidth:SELected:BANDwidth	Selects or queries the bandwidth (OBW or x dB BW) to measure.
DISPlay:OBWidth:WINDow:TRACe:GRATICule:GRID:STATe	Determines whether to show the graticule grid on screen.
DISPlay:OBWidth:X[:SCALE]	Sets or queries the horizontal range.
DISPlay:OBWidth:X[:SCALE]:AUTO	Rescales the horizontal axis automatically.
DISPlay:OBWidth:X[:SCALE]:OFFSet	Sets or queries the minimum horizontal value (left edge).
DISPlay:OBWidth:Y[:SCALE]	Sets or queries the vertical range.
DISPlay:OBWidth:Y[:SCALE]:AUTO	Rescales the vertical axis automatically.
DISPlay:OBWidth:Y[:SCALE]:OFFSet	Sets or queries the vertical offset.
<b>DISPlay:PERRor subgroup (Option 21 only)</b>	<b>Phase error versus Time measurement</b>
DISPlay:PERRor:Y[:SCALE]	Sets or queries the vertical scale.
DISPlay:PERRor:Y[:SCALE]:AUTO	Sets the vertical scale automatically.
DISPlay:PERRor:Y[:SCALE]:OFFSet	Sets or queries the minimum vertical value (bottom edge).
<b>DISPlay:PHVTime subgroup</b>	<b>Phase versus Time measurement</b>
DISPlay:PHVTime:WINDow:TRACe:GRATICule:GRID:STATe	Selects or queries whether to show the graticule grid on the screen.
DISPlay:PHVTime:X[:SCALE]	Sets or queries the horizontal scale.
DISPlay:PHVTime:X[:SCALE]:AUTO	Sets the horizontal scale automatically.
DISPlay:PHVTime:X[:SCALE]:AUTO:STATe	Determines whether to set the horizontal scale automatically or manually.

Table 2-14: Display commands (cont.)

Header	Description
DISPlay:PHVTime:X[:SCALe]:MAXimum?	Queries the upper limit of the horizontal scale setting range.
DISPlay:PHVTime:X[:SCALe]:MINimum?	Queries the lower limit of the horizontal scale setting range.
DISPlay:PHVTime:X[:SCALe]:OFFSet	Sets or queries the minimum horizontal value (left edge).
DISPlay:PHVTime:X[:SCALe]:OFFSet:MAXimum?	Queries the upper limit of the horizontal offset setting range.
DISPlay:PHVTime:X[:SCALe]:OFFSet:MINimum?	Queries the lower limit of the horizontal offset setting range.
DISPlay:PHVTime:Y[:SCALe]	Sets or queries the vertical scale.
DISPlay:PHVTime:Y[:SCALe]:AUTO	Sets the vertical scale automatically.
DISPlay:PHVTime:Y[:SCALe]:AXIS	Selects or queries the vertical axis representation.
DISPlay:PHVTime:Y[:SCALe]:AXIS:REFerence	Sets or queries the reference time for phase.
DISPlay:PHVTime:Y[:SCALe]:OFFSet	Sets or queries the vertical offset.
DISPlay:PHVTime:Y[:SCALe]:REScale	Rescales the vertical scale.
<b>DISPlay:PNOise subgroup (Option 11 only)</b>	<b>Phase noise measurements</b>
DISPlay:PNOise:MARKer:SHOW:STATe	Determines whether to show the readout for the selected marker.
DISPlay:PNOise:RESet:SCALE	Resets the horizontal and vertical scale to the default values.
DISPlay:PNOise:WINDow:TRACe:GRATICule:GRID:STATe	Selects or queries whether to show the graticule grid on the screen.
DISPlay:PNOise:X[:SCALe]:AUTO	Rescales the horizontal axis automatically.
DISPlay:PNOise:X[:SCALe]:START	Sets or queries the start frequency of the graph.
DISPlay:PNOise:X[:SCALe]:STOP	Sets or queries the stop frequency of the graph.
DISPlay:PNOise:Y[:SCALe]	Sets or queries the vertical scale.
DISPlay:PNOise:Y[:SCALe]:AUTO	Rescales the vertical axis automatically.
DISPlay:PNOise:Y[:SCALe]:OFFSet	Sets or queries the vertical offset.
DISPlay:PNOise:Y[:SCALe]:PDIVision	Sets or queries the vertical scale (per division).
<b>DISPlay:PULSe subgroup (Option 20 only)</b>	<b>Pulsed RF measurements</b>
DISPlay:PULSe:MEASview:DELEte	Deletes the measurement view.
DISPlay:PULSe:MEASview:NEW	Displays a new measurement view.
DISPlay:PULSe:MEASview:SELEct	Selects or queries the measurement view.
DISPlay:PULSe:RESult:ATX	Selects or queries whether to show the average transmitted power result.
DISPlay:PULSe:RESult:AVERage	Selects or queries whether to show the average on power result.
DISPlay:PULSe:RESult:DROOp	Selects or queries whether to show the droop in the results table.
DISPlay:PULSe:RESult:DUTPct	Selects or queries whether to show the duty factor (%) result.
DISPlay:PULSe:RESult:DUTRatio	Selects or queries whether to show the duty factor (ratio) result.
DISPlay:PULSe:RESult:FALL	Selects or queries whether to show the fall time in the results table.
DISPlay:PULSe:RESult:FRDeviation	Selects or queries whether to show the frequency deviation result.
DISPlay:PULSe:RESult:MFRerror	Selects or queries whether to show the maximum frequency error result.
DISPlay:PULSe:RESult:MPHerror	Selects or queries whether to show the maximum phase error result.
DISPlay:PULSe:RESult:PHDeviation	Selects or queries whether to show the phase deviation result.

**Table 2-14: Display commands (cont.)**

<b>Header</b>	<b>Description</b>
DISPlay:PULSe:RESult:PPFRequency	Selects or queries whether to show the pulse-pulse frequency result.
DISPlay:PULSe:RESult:PPOWer	Selects or queries whether to show the peak power in the results table.
DISPlay:PULSe:RESult:PPPHase	Selects or queries whether to show the pulse-pulse carrier phase result.
DISPlay:PULSe:RESult:RINTerval	Selects or queries whether to show the repetition interval result.
DISPlay:PULSe:RESult:RIPPLE	Selects or queries whether to show the ripple in the results table.
DISPlay:PULSe:RESult:RISE	Selects or queries whether to show the rise time in the results table.
DISPlay:PULSe:RESult:RMSFreqerror	Selects or queries whether to show the RMS frequency error result.
DISPlay:PULSe:RESult:RMSPherror	Selects or queries whether to show the RMS phase error result.
DISPlay:PULSe:RESult:RRATE	Selects or queries whether to show the repetition rate result.
DISPlay:PULSe:RESult:TIME	Selects or queries whether to show the time in the results table.
DISPlay:PULSe:RESult:WIDTH	Selects or queries whether to show the pulse width in the results table.
DISPlay:PULSe:SElect:NUMBer	Selects or queries the pulse to measure.
DISPlay:PULSe:SElect:RESult	Selects or queries which result is shown in the trace and statistics views.
DISPlay:PULSe:STATistics:MARKer:SHOW:STATe	Selects or queries whether to show the marker readout in the graph.
DISPlay:PULSe:STATistics:PLOT	Selects or queries how to show the statistics graph.
DISPlay:PULSe:STATistics:WINDow:TRACe:GRATICule:GRID:STATe	Selects or queries whether to show the graticule grid in the statistics view.
DISPlay:PULSe:STATistics:X:RSCale	Rescales the horizontal axis of the statistics graph.
DISPlay:PULSe:STATistics:X[:SCALE]:NUMBer	Sets or queries the horizontal scale (the number of pulses per division).
DISPlay:PULSe:STATistics:X[:SCALE]:OFFSet	Sets or queries the minimum horizontal value in the statistics view.
DISPlay:PULSe:STATistics:Y:RSCale	Rescales the vertical axis of the statistics graph.
DISPlay:PULSe:STATistics:Y[:SCALE]:FULL	Sets or queries the vertical full-scale in the statistics view.
DISPlay:PULSe:STATistics:Y[:SCALE]:OFFSet	Sets or queries the vertical offset in the statistics view.
DISPlay:PULSe:STATistics:Y[:SCALE]:STOP?	Queries the minimum vertical value in the statistics view.
DISPlay:PULSe:TRACe:MARKer:SHOW:STATe	Selects or queries whether to show the marker readout in the trace view.
DISPlay:PULSe:TRACe:POINT:SHOW	Selects or queries whether to show the measurement points and lines.
DISPlay:PULSe:TRACe:WINDow:TRACe:GRATICule:GRID:STATe	Selects or queries whether to show the graticule grid in the trace view.
DISPlay:PULSe:TRACe:X:RSCale	Rescales the horizontal axis of the pulse trace view.
DISPlay:PULSe:TRACe:X[:SCALE]	Sets or queries the horizontal full scale in the pulse trace view.
DISPlay:PULSe:TRACe:X[:SCALE]:FULL	Selects or queries the full-scale reference for the horizontal rescale.
DISPlay:PULSe:TRACe:X[:SCALE]:OFFSet	Sets or queries the minimum horizontal value in the pulse trace view.
DISPlay:PULSe:TRACe:X[:SCALE]:PDIVision	Sets or queries the horizontal full scale in the pulse trace view.
DISPlay:PULSe:TRACe:Y:RSCale	Rescales the vertical axis of the pulse trace view.
DISPlay:PULSe:TRACe:Y[:SCALE]:FULL	Sets or queries the vertical full scale in the pulse trace view.
DISPlay:PULSe:TRACe:Y[:SCALE]:OFFSet	Sets or queries the vertical offset in the pulse trace view.
DISPlay:PULSe:TRACe:Y[:SCALE]:STOP?	Queries the minimum vertical value in the pulse trace view.



Table 2-14: Display commands (cont.)

Header	Description
<b>DISPlay:SGRam subgroup</b>	<b>Spectrogram measurement</b>
DISPlay:SGRam:FREQuency:AUTO	Rescales the horizontal (frequency) axis automatically.
DISPlay:SGRam:FREQuency:OFFSet	Sets or queries the horizontal (frequency) offset.
DISPlay:SGRam:FREQuency:SCAlE	Sets or queries the horizontal (frequency) range.
DISPlay:SGRam:TIME:AUTO	Rescales the vertical axis automatically.
DISPlay:SGRam:TIME:OFFSet	Sets or queries the vertical axis (time) offset (bottom line number).
DISPlay:SGRam:TIME:OVERlap	Determines whether or not to allow overlap between adjacent FFT frames.
DISPlay:SGRam:TIME:SCAlE	Sets or queries the vertical scale (the amount of time in each line).
<b>DISPlay:SPEctrum subgroup</b>	<b>Spectrum measurement</b>
DISPlay:SPEctrum:MARKer:NOISe:MODE	Selects or queries whether to enable the marker noise mode.
DISPlay:SPEctrum:FREQuency:AUTO	Rescales the horizontal (frequency) axis automatically.
DISPlay:SPEctrum:FREQuency:OFFSet	Sets or queries the horizontal (frequency) offset.
DISPlay:SPEctrum:FREQuency[:SCAlE]	Sets or queries the horizontal (frequency) range.
DISPlay:SPEctrum:SCAlE:LOG:STATe	Selects or queries whether to set the horizontal axis logarithmic.
DISPlay:SPEctrum:WINDow:TRACe:GRATICule:GRID:STATe	Selects or queries whether to show the graticule grid.
DISPlay:SPEctrum:WINDow:TRACe:LEGend:STATe	Show or hide the trace legend in the Spectrum view.
DISPlay:PNOise:LEGend:STATe	Selects or queries whether to show the trace legend.
DISPlay:SPEctrum:X:LABel	Selects or queries the labels for the horizontal axis.
DISPlay:SPEctrum:Y[:SCAlE]	Sets or queries the vertical range.
DISPlay:SPEctrum:Y[:SCAlE]:AUTO	Rescales the vertical axis automatically.
DISPlay:SPEctrum:Y[:SCAlE]:OFFSet	Sets or queries the vertical offset.
DISPlay:SPEctrum:Y[:SCAlE]:PDIVision	Sets or queries the vertical scale (per division).
DISPlay:SPEctrum:Y[:SCAlE]:RESet	Resets the vertical scale to the default values.
<b>DISPlay:SPURious subgroup</b>	<b>Spurious measurement</b>
DISPlay:SPURious:MARKer:SHOW:STATe	Selects or queries whether to show the readout for the selected marker.
DISPlay:SPURious:RESet:SCAlE	Resets the horizontal and vertical scale to the default values.
DISPlay:SPURious:SCAlE:LOG:STATe	Selects or queries whether to set the horizontal axis logarithmic.
DISPlay:SPURious:SELect:NUMBer	Selects or queries the spurious number.
DISPlay:SPURious:SHOW:LIMit	Selects or queries how to display the limits.
DISPlay:SPURious:WINDow:TRACe:GRATICule:GRID:STATe	Determines whether to show the graticule grid on screen.
DISPlay:SPURious:X[:SCAlE]:AUTO	Rescales the horizontal axis automatically.
DISPlay:SPURious:X[:SCAlE]:START	Sets or queries the minimum horizontal value of the spectrum graph.
DISPlay:SPURious:X[:SCAlE]:STOP	Sets or queries the maximum horizontal value of the spectrum graph.
DISPlay:SPURious:Y[:SCAlE]	Sets or queries the vertical range of the spectrum graph.
DISPlay:SPURious:Y[:SCAlE]:AUTO	Rescales the vertical axis automatically.

**Table 2-14: Display commands (cont.)**

<b>Header</b>	<b>Description</b>
<code>DISPlay:SPURious:Y[:SCALE]:OFFSet</code>	Sets or queries the vertical offset of the spectrum graph.
<b>DISPlay:TDIagram subgroup (Option 21 only)</b>	<b>Trellis diagram</b>
<code>DISPlay:TDIagram:WINDow:TRACe:GRATICule:GRID:STATE</code>	Selects or queries whether to show the graticule grid on the screen.
<code>DISPlay:TDIagram:Y[:SCALE]</code>	Sets or queries the vertical scale.
<code>DISPlay:TDIagram:Y[:SCALE]:AUTO</code>	Sets the vertical scale automatically.
<code>DISPlay:TDIagram:Y[:SCALE]:OFFSet</code>	Sets or queries the vertical offset (center point of the vertical axis).
<b>DISPlay:TOVerview subgroup</b>	<b>Time overview</b>
<code>DISPlay:TOVerview:WINDow:TRACe:GRATICule:GRID:STATE</code>	Selects or queries whether to show the graticule grid in the time overview.
<code>DISPlay:TOVerview:X[:SCALE]</code>	Sets or queries the horizontal scale.
<code>DISPlay:TOVerview:X[:SCALE]:AUTO</code>	Sets the horizontal scale and offset automatically.
<code>DISPlay:TOVerview:X[:SCALE]:OFFSet</code>	Sets or queries the minimum horizontal value (left edge).
<code>DISPlay:TOVerview:Y[:SCALE]</code>	Sets or queries the vertical scale.
<code>DISPlay:TOVerview:Y[:SCALE]:AUTO</code>	Sets the vertical scale and offset automatically.
<code>DISPlay:TOVerview:Y[:SCALE]:OFFSet</code>	Sets or queries the vertical offset.
<code>DISPlay:TOVerview:Y[:SCALE]:RESCale</code>	Rescales the vertical scale.

## Fetch Commands

The FETCh commands retrieve the measurements from the data taken by the latest INITiate command.

To perform a FETCh operation on fresh data, use the READ commands, which acquire a new input signal and fetch the measurement results from that data.

Table 2-15: Fetch commands

Header	Description
<b>FETCh basic command subgroup</b>	<b>General fetch control</b>
<a href="#">FETCh:RFIN:IQ?</a>	Returns time-domain IQ data for a specific acquisition data record.
<a href="#">FETCh:RFIN:IQ:HEADer?</a>	Returns the header information for a specific acquisition data record.
<a href="#">FETCh:RFIN:IQ:SCALe?</a>	Returns the scaling factor contained in the .tiq file header.
<a href="#">FETCh:RFIN:RECOrd:IDS?</a>	Returns the beginning and end ID numbers of acquisition data.
<b>FETCh:ACPower subgroup</b>	<b>Channel power and ACPR measurement</b>
<a href="#">FETCh:ACPower?</a>	Returns the ACPR measurement results.
<a href="#">FETCh:ACPower:CHANnel:POWer?</a>	Returns the average power of the main channel.
<a href="#">FETCh:ACPower:SPECTrum?</a>	Returns spectrum trace data of the ACPR measurement.
<b>FETCh:{AM FM PM} subgroup (Option 21 only)</b>	<b>AM/FM/PM measurement</b>
<a href="#">FETCh:{AM FM PM}?</a>	Returns the trace data.
<a href="#">FETCh:AM:AMINdex?</a>	FIRST Returns the modulation indexdepth.
<a href="#">FETCh:AM:AMNegative?</a>	Returns the negative peak modulation factor (-AM).
<a href="#">FETCh:AM:AMPositive?</a>	Returns the positive peak modulation factor (+AM).
<a href="#">FETCh:AM:RESult?</a>	Returns the AM measurement results.
<a href="#">FETCh:{FM PM}:FERRor?</a>	Returns the frequency error in the Frequency or Phase modulation measurement.
<a href="#">FETCh:FM:PHALf?</a>	Returns the half peak-peak frequency deviation (Pk-Pk/2).
<a href="#">FETCh:FM:PNEGative?</a>	Returns the negative peak frequency deviation (-Pk).
<a href="#">FETCh:FM:PPOSitive?</a>	Returns the positive peak frequency deviation (+Pk).
<a href="#">FETCh:FM:PTPeak?</a>	Returns the peak-peak frequency deviation (Pk-Pk).
<a href="#">FETCh:FM:RESult?</a>	Returns the FM measurement results.
<a href="#">FETCh:FM:RMS?</a>	Returns the RMS frequency deviation.
<a href="#">FETCh:PM:PNEGative?</a>	Returns the negative peak phase deviation (-Pk).
<a href="#">FETCh:PM:PPOSitive?</a>	Returns the positive peak phase deviation (+Pk).
<a href="#">FETCh:PM:PTPeak?</a>	Returns the peak-peak phase deviation (Pk-Pk).
<a href="#">FETCh:PM:RESult?</a>	Returns the PM measurement results.
<a href="#">FETCh:PM:RMS?</a>	Returns the RMS phase deviation.
<b>FETCh:AVTime subgroup</b>	<b>Amplitude versus Time measurement</b>
<a href="#">FETCh:AVTime:AVERage?</a>	Returns the RMS value.

Table 2-15: Fetch commands (cont.)

Header	Description
<a href="#">FETCh:AVTime:{FIRST SECOnd THIRd FOURth}?</a>	Returns the trace data.
<a href="#">FETCh:AVTime:MAXimum?</a>	Returns the maximum value.
<a href="#">FETCh:AVTime:MAXLocation?</a>	Returns the time at the maximum.
<a href="#">FETCh:AVTime:MINimum?</a>	Returns the minimum value.
<a href="#">FETCh:AVTime:MINLocation?</a>	Returns the time at the minimum.
<a href="#">FETCh:AVTime:RESult?</a>	Returns the measurement results.
<b>FETCh:CCDF subgroup</b>	<b>CCDF measurement</b>
<a href="#">FETCh:CCDF?</a>	Returns the CCDF measurement results.
<a href="#">FETCh:CCDF:{FIRST SECOnd THIRd}:X?</a>	Returns the horizontal values of the specified trace.
<a href="#">FETCh:CCDF:{FIRST SECOnd THIRd}:XY?</a>	Returns the horizontal and vertical value pairs of the specified trace.
<a href="#">FETCh:CCDF:{FIRST SECOnd THIRd}:Y?</a>	Returns the vertical values of the specified trace.
<b>FETCh:CONSte subgroup (Option 21 only)</b>	<b>Constellation measurement</b>
<a href="#">FETCh:CONSte:FERRor?</a>	Returns the frequency error in Hz.
<a href="#">FETCh:CONSte:RESults?</a>	Returns the constellation measurement results.
<a href="#">FETCh:CONSte:TRACe?</a>	Returns the constellation trace data.
<b>FETCh:DDEMod subgroup (Option 21 only)</b>	<b>General purpose digital modulation measurements</b>
<a href="#">FETCh:DDEMod:STABle?</a>	Returns the symbol table data.
<a href="#">FETCh:DDEMod:SYNCh:WORD:LENGth?</a>	Returns the length of the synch word in the symbol table.
<a href="#">FETCh:DDEMod:SYNCh:WORD:POSition?</a>	Returns the position of the synch word in the symbol table.
<b>FETCh:DIQVtime subgroup (Option 21 only)</b>	<b>Demodulated I&amp;Q versus Time measurement</b>
<a href="#">FETCh:DIQVtime:FERRor?</a>	Returns the frequency error.
<a href="#">FETCh:DIQVtime:I?</a>	Returns the I versus Time trace data.
<a href="#">FETCh:DIQVtime:Q?</a>	Returns the Q versus Time trace data.
<b>FETCh:DPSA subgroup</b>	<b>DPX spectrum measurement</b>
<a href="#">FETCh:DPSA:RESults:TRACe&lt;x&gt;?</a>	Returns waveform data in the DPX spectrum measurement.
<a href="#">FETCh:DPSA:TRACe:AVERAge?</a>	Returns waveform data of the average trace in the DPX spectrum measurement.
<a href="#">FETCh:DPSA:TRACe:BITMap?</a>	Returns trace waveform data of the bitmap trace.
<a href="#">FETCh:DPSA:TRACe:MATH?</a>	Returns waveform data of the math trace.
<a href="#">FETCh:DPSA:TRACe:MAXimum?</a>	Returns waveform data of the maximum trace.
<a href="#">FETCh:DPSA:TRACe:MINimum?</a>	Returns waveform data of the minimum trace.
<b>FETCh:EDlagram subgroup (Option 21 only)</b>	<b>Eye diagram</b>
<a href="#">FETCh:EDlagram:FDEVIation?</a>	Returns the frequency deviation versus Time trace data.
<a href="#">FETCh:EDlagram:FERRor?</a>	Returns the frequency error.
<a href="#">FETCh:EDlagram:I?</a>	Returns the I versus Time trace data.
<a href="#">FETCh:EDlagram:Q?</a>	Returns the Q versus Time trace data.
<b>FETCh:EVM subgroup (Option 21 only)</b>	<b>EVM versus Time measurement</b>

Table 2-15: Fetch commands (cont.)

Header	Description
FETCh:EVM:FERRor?	Returns the frequency error.
FETCh:EVM:PEAK?	Returns the peak value.
FETCh:EVM:PINDex?	Returns the time at the EVM peak.
FETCh:EVM:RMS?	Returns the RMS value.
FETCh:EVM:TRACe?	Returns the EVM versus Time trace data.
<b>FETCh:FDVTime subgroup (Option 21 only)</b>	<b>Frequency deviation versus Time measurement</b>
FETCh:FDVTime:FERRor?	Returns the frequency error in the Frequency deviation versus Time measurement.
FETCh:{FM PM}:FERRor?	Returns the frequency error.
FETCh:FDVTime:TRACe?	Returns the Frequency deviation versus Time trace data.
<b>FETCh:FVTime subgroup</b>	<b>Frequency versus Time measurement</b>
FETCh:FVTime?	Returns the Frequency versus Time trace data.
FETCh:FVTime:MAXimum?	Returns the maximum value.
FETCh:FVTime:MAXLocation?	Returns the time at which the frequency drift is maximum.
FETCh:FVTime:MINimum?	Returns the minimum value.
FETCh:FVTime:MINLocation?	Returns the time at which the frequency drift is minimum.
FETCh:FVTime:RESult?	Returns the measurement results.
<b>FETCh:IQVTime subgroup</b>	<b>RF I&amp;Q versus Time measurement</b>
FETCh:IQVTime:I?	Returns the I versus Time trace data.
FETCh:IQVTime:MAXimum?	Returns the maximum value.
FETCh:IQVTime:MAXLocation?	Returns the time at which the I or Q level is maximum.
FETCh:IQVTime:MINimum?	Returns the minimum value.
FETCh:IQVTime:MINLocation?	Returns the time at which the I or Q level is minimum.
FETCh:IQVTime:Q?	Returns the Q versus Time trace data.
FETCh:IQVTime:RESult?	Returns the measurement results.
<b>FETCh:MCPower subgroup</b>	<b>MCPR measurement</b>
FETCh:MCPower:ADJacent:CHANnels?	Returns the power of adjacent channels.
FETCh:MCPower:CHANnel:POWer?	Returns the reference power.
FETCh:MCPower:MAIN:CHANnels?	Returns the power of main channels.
FETCh:MCPower:SPECtrum?	Returns spectrum trace data.
<b>FETCh:MERRor subgroup (Option 21 only)</b>	<b>Magnitude error versus Time measurement</b>
FETCh:MERRor:FERRor?	Returns the frequency error.
FETCh:MERRor:PEAK?	Returns the peak value.
FETCh:MERRor:PINDex?	Returns the time at the magnitude error peak.
FETCh:MERRor:RMS?	Returns the RMS value.
FETCh:MERRor:TRACe?	Returns the Magnitude error versus Time trace data.
<b>FETCh:OBWidth subgroup</b>	<b>Occupied Bandwidth measurement</b>

Table 2-15: Fetch commands (cont.)

Header	Description
FETCh:OBWidth:FREQuency:ERRor?	Returns the frequency error.
FETCh:OBWidth:OBWidth:BANDwidth?	Returns the occupied bandwidth.
FETCh:OBWidth:OBWidth:LEFT:FREQuency?	Returns the left (lower) frequency of the occupied bandwidth.
FETCh:OBWidth:OBWidth:LEFT:LEVel?	Returns the level at the left frequency of the occupied bandwidth.
FETCh:OBWidth:OBWidth:POWer?	Returns the reference power in the Occupied Bandwidth measurement.
FETCh:OBWidth:OBWidth:RIGHT:FREQuency?	Returns the right (higher) frequency of the occupied bandwidth.
FETCh:OBWidth:OBWidth:RIGHT:LEVel?	Returns the level at the right frequency of the occupied bandwidth.
FETCh:OBWidth:SPEctrum?	Returns spectrum trace data of the Occupied Bandwidth measurement.
FETCh:OBWidth:XDBBandwidth:BANDwidth?	Returns the x dB bandwidth.
FETCh:OBWidth:XDBBandwidth:LEFT:FREQuency?	Returns the left (lower) frequency of the x dB bandwidth.
FETCh:OBWidth:XDBBandwidth:LEFT:LEVel?	Returns the level at the left frequency of the x dB bandwidth.
FETCh:OBWidth:XDBBandwidth:POWer?	Returns the reference power in the x dB bandwidth measurement.
FETCh:OBWidth:XDBBandwidth:RIGHT:FREQuency?	Returns the right (higher) frequency of the x dB bandwidth.
FETCh:OBWidth:XDBBandwidth:RIGHT:LEVel?	Returns the level at the right frequency of the x dB bandwidth.
<b>FETCh:PERRor subgroup (Option 21 only)</b>	<b>Phase error versus Time measurement</b>
FETCh:PERRor:FERRor?	Returns the frequency error.
FETCh:PERRor:PEAK?	Returns the peak value.
FETCh:PERRor:PINDex?	Returns the time at the phase error peak.
FETCh:PERRor:RMS?	Returns the RMS value.
FETCh:PERRor:TRACe?	Returns the Phase error versus Time trace data.
<b>FETCh:PHVTime subgroup</b>	<b>Phase versus Time measurement</b>
FETCh:PHVTime?	Returns the Phase versus Time trace data.
FETCh:PHVTime:MAXimum?	Returns the maximum value.
FETCh:PHVTime:MAXLocation?	Returns the time at which the phase is maximum.
FETCh:PHVTime:MINimum?	Returns the minimum value.
FETCh:PHVTime:MINLocation?	Returns the time at which the phase is minimum.
FETCh:PHVTime:RESult?	Returns the results.
<b>FETCh:PNOise subgroup (Option 11 only)</b>	<b>Phase noise measurements</b>
FETCh:PNOise:ALL?	Returns all the measurement results.
FETCh:PNOise:CARRier:FERRor?	Returns the carrier frequency error.
FETCh:PNOise:CARRier:POWer?	Returns the carrier power.
FETCh:PNOise:RESidual:FM?	Returns the residual FM.
FETCh:PNOise:RMS:PNOise?	Returns the RMS phase noise.
FETCh:PNOise:SPEctrum<x>:X?	Returns the frequencies of the specified trace.
FETCh:PNOise:SPEctrum<x>:XY?	Returns the frequency and phase noise pairs of the specified trace.
FETCh:PNOise:SPEctrum<x>:Y]?	Returns the phase noise values of the specified trace.
FETCh:PNOise:JITTer?	Returns the jitter.

Table 2-15: Fetch commands (cont.)

Header	Description
<b>FETCh:PULSe subgroup (Option 20 only)</b>	<b>Pulsed RF measurements</b>
FETCh:PULSe[:RESult]:ATX?	Returns the average transmitted power in the results table.
FETCh:PULSe[:RESult]:AVERAge?	Returns the average on power in the results table.
FETCh:PULSe[:RESult]:DROop?	Returns the droop in the results table.
FETCh:PULSe[:RESult]:DUTPct?	Returns the duty factor (%) in the results table.
FETCh:PULSe[:RESult]:DUTRatio?	Returns the duty factor (ratio) in the results table.
FETCh:PULSe[:RESult]:FALL?	Returns the fall time in the results table.
FETCh:PULSe[:RESult]:FRDeviation?	Returns the frequency deviation in the results table.
FETCh:PULSe[:RESult]:MFReqerror?	Returns the maximum frequency error in the results table.
FETCh:PULSe[:RESult]:MPHerror?	Returns the maximum phase error in the results table.
FETCh:PULSe[:RESult]:PHDeviation?	Returns the phase deviation in the results table.
FETCh:PULSe[:RESult]:PPFRequency?	Returns the pulse-pulse carrier frequency in the results table.
FETCh:PULSe[:RESult]:PPOWer?	Returns the peak power in the results table.
FETCh:PULSe[:RESult]:PPPHasE?	Returns the pulse-pulse carrier phase in the results table.
FETCh:PULSe[:RESult]:RINTerval?	Returns the repetition interval in the results table.
FETCh:PULSe[:RESult]:RIPPlE?	Returns the ripple in the results table.
FETCh:PULSe[:RESult]:RISE?	Returns the rise time in the results table.
FETCh:PULSe[:RESult]:RMSFreqerror?	Returns the RMS frequency error in the results table.
FETCh:PULSe[:RESult]:RMSPherror?	Returns the RMS phase error in the results table.
FETCh:PULSe[:RESult]:RRATe?	Returns the repetition rate in the results table.
FETCh:PULSe[:RESult]:TIME?	Returns the time in the results table.
FETCh:PULSe[:RESult]:WIDTh?	Returns the pulse width in the results table.
FETCh:PULSe:STATistics?	Returns the trace data of the pulse statistics measurement.
FETCh:PULSe:STATistics:ATX?	Returns the average transmitted power of the statistics.
FETCh:PULSe:STATistics:AVERAge?	Returns the average on power of the statistics.
FETCh:PULSe:STATistics:DROop?	Returns the droop of the statistics.
FETCh:PULSe:STATistics:DUTPct?	Returns the duty factor (%) of the statistics.
FETCh:PULSe:STATistics:DUTRatio?	Returns the duty factor (ratio) of the statistics.
FETCh:PULSe:STATistics:FALL?	Returns the fall time of the statistics.
FETCh:PULSe:STATistics:FRDeviation?	Returns the frequency deviation of the statistics.
FETCh:PULSe:STATistics:MFReqerror?	Returns the maximum frequency error of the statistics.
FETCh:PULSe:STATistics:MPHerror?	Returns the maximum phase error of the statistics.
FETCh:PULSe:STATistics:PHDeviation?	Returns the phase deviation of the statistics.
FETCh:PULSe:STATistics:PPFRequency?	Returns the pulse-pulse carrier frequency of the statistics.
FETCh:PULSe:STATistics:PPOWer?	Returns the peak power of the statistics.
FETCh:PULSe:STATistics:PPPHasE?	Returns the pulse-pulse carrier phase of the statistics.
FETCh:PULSe:STATistics:RINTerval?	Returns the repetition interval of the statistics.

Table 2-15: Fetch commands (cont.)

Header	Description
FETCh:PULSe:STATistics:RIPple?	Returns the ripple of the statistics.
FETCh:PULSe:STATistics:RISe?	Returns the rise time of the statistics.
FETCh:PULSe:STATistics:RMSFreqerror?	Returns the RMS frequency error of the statistics.
FETCh:PULSe:STATistics:RMSPherror?	Returns the RMS phase error of the statistics.
FETCh:PULSe:STATistics:RRate?	Returns the repetition rate of the statistics.
FETCh:PULSe:STATistics:WIDTh?	Returns the pulse width of the statistics.
FETCh:PULSe:TRACe:X?	Returns the time values of the pulse trace.
FETCh:PULSe:TRACe:XY?	Returns the horizontal (time) and vertical value pairs of the pulse trace.
FETCh:PULSe:TRACe[:Y]?	Returns the vertical values of the pulse trace.
<b>FETCh:SGRam subgroup</b>	<b>Spectrogram measurement</b>
FETCh:SGRam?	Returns the spectrogram trace data.
<b>FETCh:SPECTrum subgroup</b>	<b>Spectrum measurement</b>
FETCh:SPECTrum:TRACe<x>?	Returns the trace data in the Spectrum Analyzer measurement.
<b>FETCh:SPURious subgroup</b>	<b>Spurious measurement</b>
FETCh:SPURious:CARRier:POWer?	Returns the carrier power.
FETCh:SPURious:COUNT?	Returns the number of spurious signals.
FETCh:SPURious:PASS?	Returns the pass/fail limit test result.
FETCh:SPURious:SPECTrum:X?	Returns the frequencies of the spectrum trace.
FETCh:SPURious:SPECTrum:XY?	Returns the frequency and amplitude pairs of the spectrum trace.
FETCh:SPURious:SPECTrum[:Y]?	Returns the amplitudes of the spectrum trace.
FETCh:SPURious:SPUR<x>:AMPLitude:ABSolute?	Returns the absolute amplitude of the specified spurious signal.
FETCh:SPURious:SPUR<x>:AMPLitude:RELative?	Returns the relative amplitude of the specified spurious signal.
FETCh:SPURious:SPUR<x>:FREQUency:ABSolute?	Returns the absolute frequency of the specified spurious signal.
FETCh:SPURious:SPUR<x>:FREQUency:RELative?	Returns the relative frequency of the specified spurious signal.
FETCh:SPURious:SPUR<x>:LIMit:ABSolute?	Returns the absolute amplitude of the limit for a spurious signal.
FETCh:SPURious:SPUR<x>:LIMit:RELative?	Returns the relative amplitude of the limit for a spurious signal.
FETCh:SPURious:SPUR<x>:LIMit:VIOLation?	Returns whether the specified spurious signal exceeds the limit or not.
FETCh:SPURious:SPUR<x>:RANGe?	Returns the frequency range in which the spurious signal occurred.
<b>FETCh:SQUality subgroup (Option 21 only)</b>	<b>Signal quality measurement</b>
FETCh:SQUality:FREQUency:DEVIation?	Returns the frequency deviation.
FETCh:SQUality:FREQUency:DEVIation:TABLE?	Returns the frequency deviation measurement results table.
FETCh:SQUality:FREQUency:ERRor?	Returns the frequency error.
FETCh:SQUality:GAIN:IMBalance?	Returns the gain imbalance.
FETCh:SQUality:ORIGin:OFFSet?	Returns the origin offset.
FETCh:SQUality:PEAK:EVM?	Returns the peak EVM (%).
FETCh:SQUality:PEAK:EVM:DB?	Returns the peak EVM (dB).
FETCh:SQUality:PEAK:EVM:DB:OFFSet?	Returns the peak offset EVM (dB).



Table 2-15: Fetch commands (cont.)

Header	Description
<a href="#">FETCh:SQUality:PEAK:EVM:OFFSet?</a>	Returns the peak offset EVM (%) in the signal quality measurement.
<a href="#">FETCh:SQUality:PEAK:EVM:LOCation?</a>	Returns the time at which the EVM is peak.
<a href="#">FETCh:SQUality:PEAK:EVM:LOCation:OFFSet?</a>	Returns the time at which the offset EVM is peak.
<a href="#">FETCh:SQUality:PEAK:FERRor?</a>	Returns the peak FSK error.
<a href="#">FETCh:SQUality:PEAK:MERRor?</a>	Returns the peak magnitude error (%).
<a href="#">FETCh:SQUality:PEAK:MERRor:DB?</a>	Returns the peak magnitude error (dB).
<a href="#">FETCh:SQUality:PEAK:MERRor:LOCation?</a>	Returns the time at which the magnitude error is peak.
<a href="#">FETCh:SQUality:PEAK:PERRor?</a>	Returns the peak phase error.
<a href="#">FETCh:SQUality:PEAK:PERRor:LOCation?</a>	Returns the time at which the phase error is peak.
<a href="#">FETCh:SQUality:QUADrature:ERRor?</a>	Returns the quadrature error.
<a href="#">FETCh:SQUality:RHO?</a>	Returns the r (waveform quality).
<a href="#">FETCh:SQUality:RMS:EVM?</a>	Returns the RMS EVM (%).
<a href="#">FETCh:SQUality:RMS:EVM:DB?</a>	Returns the RMS EVM (dB).
<a href="#">FETCh:SQUality:RMS:EVM:DB:OFFSet?</a>	Returns the RMS offset EVM (dB).
<a href="#">FETCh:SQUality:RMS:EVM:OFFSet?</a>	Returns the RMS offset EVM (%).
<a href="#">FETCh:SQUality:RMS:FERRor?</a>	Returns the RMS FSK error.
<a href="#">FETCh:SQUality:RMS:MER:DB?</a>	Returns the RMS MER (dB).
<a href="#">FETCh:SQUality:RMS:MERRor?</a>	Returns the RMS magnitude error (%).
<a href="#">FETCh:SQUality:RMS:MERRor:DB?</a>	Returns the RMS magnitude error (dB).
<a href="#">FETCh:SQUality:RMS:PERRor?</a>	Returns the RMS phase error.
<a href="#">FETCh:SQUality:SYMBol:LENGth?</a>	Returns the number of analyzed symbols.
<a href="#">FETCh:SQUality:SYMBol:RATE?</a>	Returns the value of the calculated symbol rate.
<a href="#">FETCh:SQUality:SYMBol:RATE:ERRor?</a>	Returns the value of the symbol rate error.
<b>FETCh:TDIagram subgroup (Option 21 only)</b>	<b>Trellis diagram</b>
<a href="#">FETCh:TDIagram:FERRor?</a>	Returns the frequency error.
<a href="#">FETCh:TDIagram:TRACe?</a>	Returns the Trellis diagram trace data.
<b>FETCh:TOVerview subgroup</b>	<b>Time overview</b>
<a href="#">FETCh:TOVerview?</a>	Returns the trace data.

## Initiate Commands

Use the INITiate commands to control the acquisition of data.

**Table 2-16: Initiate commands**

Header	Description
<a href="#">INITiate:CONTinuous</a>	Selects or queries whether to acquire data continuously.
<a href="#">INITiate:IMMEDIATE</a>	Starts data acquisition.

# Input Commands

Use the INPut commands to control the characteristics of the signal input.

**Table 2-17: Input commands**

Header	Description
<code>INPut:CORRection:EXTeRnal:EDIT&lt;x&gt;:INTeRpolation</code>	Selects or queries the interpolation setting to use with the indicated external gain table.
<code>INPut:CORRection:EXTeRnal:EDIT&lt;x&gt;:NEw</code>	Creates the indicated (x) external loss table.
<code>INPut:CORRection:EXTeRnal:TYPE</code>	Selects or queries the data type to use when applying the external loss table corrections.
<code>INPut[:RF]:ATTenuation</code>	Sets or queries the input attenuation.
<code>INPut[:RF]:ATTenuation:AUTO</code>	Selects or queries whether to set the attenuation automatically.
<code>INPut[:RF]:ATTenuation:MONitor:STATe</code>	Selects or queries whether to enable to monitor attenuator use.
<code>INPut[:RF]:GAIN:STATe</code> (Option 01 only)	Selects or queries whether to enable the internal preamplifier.
<code>INPut:{MLEVel RLEVel}</code>	Sets or queries the reference level.

# Mass Memory Commands

Use the MMEMemory commands to manipulate files on the mass memory devices.

For the trace specifier TRACe<x>, refer to *Trace Mnemonics*. (See page 2-69.)

Table 2-18: Mass memory (MMEMemory) commands

Header	Description
<b>MMEMemory basic command subgroup</b>	<b>General file control</b>
MMEMemory:CALibration:STORe:CORRection:EXTeRnal:EDIT<x>	Stores an external loss table to a specified file.
MMEMemory:LOAD:STATe	Loads the instrument setup from a specified file.
MMEMemory:LOAD:TRACe	Loads the trace data from a specified file.
MMEMemory:STORe:MSState	Stores the measurement parameters in a specified file.
MMEMemory:STORe:RESults	Stores the measurement results including measurement parameters and trace data to a specified file.
MMEMemory:STORe:SCReen	Stores the measurement results in a specified file.
MMEMemory:STORe:STATe	Stores the instrument setup in a specified file.
MMEMemory:STORe:TRACe	Stores trace data in a specified file.
<b>MMEMemory:{AM FM PM} subgroup</b>	<b>AM/FM/PM measurement</b>
MMEMemory:{AM FM PM}:LOAD:TRACe	Loads trace data from the specified file.
MMEMemory:{AM FM PM}:SHOW:TRACe<x>	Enables display of a recalled trace file.
MMEMemory:{AM FM PM}:STORe:TRACe	Stores trace data in the specified file.
<b>MMEMemory:AVTime subgroup</b>	<b>Amplitude versus Time measurement</b>
MMEMemory:CALibration:LOAD:CORRection:EXTeRnal:EDIT<x>	Loads an external loss table from a specified file.
MMEMemory:AVTime:LOAD:TRACe<x>	Loads trace data from the specified file.
MMEMemory:AVTime:SHOW:TRACe<x>	Enables display of a recalled trace file.
MMEMemory:AVTime:STORe:TRACe<x>	Stores trace data in the specified file.
<b>MMEMemory:CCDF subgroup</b>	<b>CCDF measurement</b>
MMEMemory:CCDF:LOAD:TRACe<x>	Loads trace data from the specified file.
MMEMemory:CCDF:SHOW:TRACe<x>	Enables display of a recalled trace file.
MMEMemory:CCDF:STORe:TRACe<x>	Stores trace data in the specified file.
<b>MMEMemory:DDEMod subgroup</b>	<b>DPX spectrum measurement</b>
MMEMemory:DDEMod:LOAD:FILTer:MEASurement:USER<x>	Loads a user-defined measurement filter from the specified file.
MMEMemory:DDEMod:LOAD:FILTer:MEASurement:UOTHer	Loads a user-defined measurement filter from the specified file.
MMEMemory:DDEMod:LOAD:FILTer:REFerence:USER<x>	Loads the specified user-defined reference filter.
MMEMemory:DDEMod:LOAD:FILTer:REFerence:UOTHer	Loads the specified user-defined reference filter

Table 2-18: Mass memory (MMEMory) commands (cont.)

Header	Description
MMEMory:DDEMod:LOAD:SYMBOL:MAP	Loads the specified symbol map filename.
<b>MMEMory:DPsA subgroup</b>	<b>DPX spectrum measurement</b>
MMEMory:DPsA:LOAD:TRACe<x>	Loads trace data from the specified file.
MMEMory:DPsA:SHOW:TRACe<x>	Enables display of a recalled trace file.
MMEMory:DPsA:STORe:TRACe<x>	Stores trace data in the specified file.
<b>MMEMory:FVTime subgroup</b>	<b>Frequency versus Time measurement</b>
MMEMory:FVTime:LOAD:TRACe	Loads trace data from the specified file.
MMEMory:FVTime:SHOW:TRACe<x>	Enables display of a recalled trace file.
MMEMory:FVTime:STORe:TRACe	Stores trace data in the specified file.
<b>MMEMory:IQVTime subgroup</b>	<b>RF I&amp;Q versus Time measurement</b>
MMEMory:IQVTime:LOAD:TRACe:I	Loads I trace data from the specified file.
MMEMory:IQVTime:LOAD:TRACe:Q	Loads Q trace data from the specified file.
MMEMory:IQVTime:SHOW:TRACe:I	Loads trace data from the specified file.
MMEMory:IQVTime:SHOW:TRACe<x>:Q	Enables display of a recalled trace file.
MMEMory:IQVTime:STORe:TRACe:I	Stores I trace data in the specified file.
MMEMory:IQVTime:STORe:TRACe:Q	Stores Q trace data in the specified file.
MMEMory:LOAD:IQ	Loads time-domain IQ waveform into the acquisition memory.
MMEMory:STORe:IQ	Stores time-domain IQ waveform in the acquisition memory to a file.
MMEMory:STORe:IQ:CSV	Stores time-domain IQ waveform to a file in the CSV format.
MMEMory:STORe:IQ:MAT	Stores time-domain IQ waveform to a file in the MATLAB format.
<b>MMEMory:PHVTime subgroup</b>	<b>Phase versus Time measurement</b>
MMEMory:PHVTime:LOAD:TRACe	Loads trace data from the specified file.
MMEMory:PHVTime:SHOW:TRACe	Enables display of a recalled trace file.
MMEMory:PHVTime:STORe:TRACe	Stores trace data in the specified file.
<b>MMEMory:SGRam subgroup</b>	<b>Spurious measurement</b>
MMEMory:SGRam:LOAD:TRACe	Loads the trace data from a specified file.
MMEMory:SGRam:SHOW:TRACe	Enables display of a recalled trace file.
MMEMory:SGRam:STORe:TRACe	Stores the Spectrogram trace data in the specified file.
<b>MMEMory:SPECTrum subgroup</b>	<b>Spectrum measurement</b>
MMEMory:PNOise:LOAD:TRACe<x>	Loads trace data from the specified file.
MMEMory:PNOise:SHOW:TRACe<x>	Enables display of a recalled trace file.
MMEMory:PNOise:STORe:TRACe<x>	Stores trace data in the specified file.
MMEMory:SPECTrum:LOAD:TRACe	Loads the trace data from a specified file.
MMEMory:SPECTrum:SHOW:TRACe<x>	Enables display of a recalled trace file.
MMEMory:SPECTrum:STORe:TRACe<x>	Stores the spectrum trace data in the specified file.
<b>MMEMory:SPURious subgroup</b>	<b>Spurious measurement</b>
MMEMory:SPURious:LOAD:TABLE	Loads the spurious table from the specified file.

**Table 2-18: Mass memory (MMEMory) commands (cont.)**

Header	Description
<a href="#">MMEMory:SPURious:STORe:TABLE</a>	Stores the spurious table in the specified file.
<b>MMEMory:TOVerview subgroup</b>	<b>Spurious measurement</b>
<a href="#">MMEMory:TOVerview:LOAD:TRACe1</a>	Loads the trace data from a specified file.
<a href="#">MMEMory:TOVerview:SHOW:TRACe1</a>	Enables display of a recalled trace file.
<a href="#">MMEMory:TOVerview:STORe:TRACe1</a>	Stores the selected trace data into the specified file.

## Specifying the File

For loading and storing a file, specify the file following these rules

- You can omit the file extension to load and store data. The measurement-specific extension is automatically added.
- You can use the absolute path to specify the file name. For example, specify the *SAMPLE1* file in the *My Documents* folder on the C drive as "C:\My Documents\SAMPLE1".
- If you omit the directory path, the default path is used, which is *C:\Program Files\Tektronix\RSA6100A* initially.

Once a file is saved to a different directory, the new directory will be used as the default for all load and store operations.

# Output Commands

Use the OUTPut commands to control the characteristics of the signal output.

Table 2-19: Output commands

Header		Description
<a href="#">OUTPut:IF:{BANDwidth BWIDTH}</a>	(Option 05 only)	Selects or queries the IF output filter.
<a href="#">OUTPut:IF:STATe]</a>	(Option 05 only)	Selects or queries whether to turn on or off IF output.
<a href="#">OUTPut:IQ:STATe]</a>	(Option 05 only)	Selects or queries whether to turn on or off IQ output.
<a href="#">OUTPut:NOISe]:STATe]</a>		Selects or queries whether to turn on or off 28 V DC power.

## Read Commands

The READ commands acquire an input signal once in the single mode and obtain the measurement results from that data.

To fetch the measurement results from the data currently residing in the memory without acquiring the input signal, use the FETCh commands.

Table 2-20: Read commands

Header	Description
<b>READ:ACPower subgroup</b>	<b>Channel power and ACPR measurement</b>
READ:ACPower?	Returns the ACPR measurement results.
READ:ACPower:CHANnel:POWer?	Returns the average power of the main channel.
READ:ACPower:SPECTrum?	Returns spectrum trace data of the ACPR measurement.
<b>READ:{AM FM PM} subgroup (Option 21 only)</b>	<b>AM/FM/PM measurement</b>
READ:{AM FM PM}?	Returns the trace data.
READ:AM:AMINdex?	Returns the modulation index .
READ:AM:AMNegative?	Returns the negative peak modulation factor (-AM).
READ:AM:AMPositive?	Returns the positive peak modulation factor (+AM).
READ:AM:RESult?	Returns the AM measurement results.
FETCh:AM:AMINdex?	Returns the RMS modulation factor.
READ:FM:PHALf?	Returns the half peak-peak frequency deviation (Pk-Pk/2).
READ:{FM PM}:FERRor?	Returns the frequency error in the Frequency modulation and Phase modulation measurements.
READ:FM:PNEGative?	Returns the negative peak frequency deviation (-Pk).
READ:FM:PPOSitive?	Returns the positive peak frequency deviation (+Pk).
READ:FM:PTPeak?	Returns the peak-peak frequency deviation (Pk-Pk).
READ:FM:RESult?	Returns the FM measurement results.
READ:FM:RMS?	Returns the RMS frequency deviation.
READ:PM:PNEGative?	Returns the negative peak phase deviation (-Pk).
READ:PM:PPOSitive?	Returns the positive peak phase deviation (+Pk).
READ:PM:PTPeak?	Returns the peak-peak phase deviation (Pk-Pk).
READ:PM:RESult?	Returns the PM measurement results.
READ:PM:RMS?	Returns the RMS phase deviation.
<b>READ:AVTime subgroup</b>	<b>Amplitude versus Time measurement</b>
READ:AVTime:AVERage?	Returns the RMS value.
READ:AVTime:{FIRSt SECond THIRd FOURth}?	Returns the trace data.
READ:AVTime:MAXimum?	Returns the maximum value.
READ:AVTime:MAXLocation?	Returns the time at the maximum.
READ:AVTime:MINimum?	Returns the minimum value.



Table 2-20: Read commands (cont.)

Header	Description
READ:AVTime:MINLocation?	Returns the time at the minimum.
READ:AVTime:RESult?	Returns the measurement results.
<b>READ:CCDF subgroup</b>	<b>CCDF measurement</b>
READ:CCDF?	Returns the CCDF measurement results.
READ:CCDF:{FIRST SECond THIRd}:X?	Returns the horizontal values of the specified trace.
READ:CCDF:{FIRST SECond THIRd}:XY?	Returns the horizontal and vertical value pairs of the specified trace.
READ:CCDF:{FIRST SECond THIRd}:Y?	Returns the vertical values of the specified trace.
<b>READ:CONSte subgroup (Option 21 only)</b>	<b>Constellation measurement</b>
READ:CONSte:FERRor?	LAST Returns the frequency error.
READ:CONSte:RESults?	Returns the constellation measurement results.
READ:CONSte:TRACe?	Returns the constellation trace data.
<b>READ:DDEMod subgroup (Option 21 only)</b>	<b>General purpose digital modulation measurements</b>
READ:DDEMod:STABle?	Returns the symbol table data.
<b>READ:DIQVtime subgroup (Option 21 only)</b>	<b>Demodulated I&amp;Q versus Time measurement</b>
READ:DIQVtime:FERRor?	Returns the frequency error.
READ:DIQVtime:I?	Returns the I versus Time trace data.
READ:DIQVtime:Q?	Returns the Q versus Time trace data.
<b>READ:DPSA subgroup</b>	<b>DPX spectrum measurement</b>
READ:DPSA:RESults:TRACe<x>?	Returns waveform data of specified trace.
READ:DPSA:TRACe:AVERage?	Returns waveform data of the average trace.
READ:DPSA:TRACe:BITMap?	Returns trace waveform data of the bitmap trace.
READ:DPSA:TRACe:MATH?	Returns waveform data of the math trace.
READ:DPSA:TRACe:MAXimum?	Returns waveform data of the maximum trace.
READ:DPSA:TRACe:MINimum?	Returns waveform data of the minimum trace.
<b>READ:EDlagram subgroup (Option 21 only)</b>	<b>Eye diagram</b>
READ:EDlagram:FDEVIation?	Returns the frequency deviation versus Time trace data.
READ:EDlagram:FERRor?	Returns the frequency error.
READ:EDlagram:I?	Returns the I versus Time trace data.
READ:EDlagram:Q?	Returns the Q versus Time trace data.
<b>READ:EVM subgroup (Option 21 only)</b>	<b>EVM versus Time measurement</b>
READ:EVM:FERRor?	Returns the frequency error.
READ:EVM:PEAK?	Returns the peak value.
READ:EVM:PINDEX?	Returns the time at the EVM peak.
READ:EVM:RMS?	Returns the RMS value.
READ:EVM:TRACe?	Returns the EVM versus Time trace data.
<b>READ:FDVTime subgroup (Option 21 only)</b>	<b>Frequency deviation versus Time measurement</b>
READ:FDVTime:FERRor?	Returns the frequency error.

Table 2-20: Read commands (cont.)

Header	Description
<a href="#">READ:FDVTime:TRACe?</a>	Returns the Frequency deviation versus Time trace data.
<b>READ:FVTime subgroup</b>	<b>Frequency versus Time measurement</b>
<a href="#">READ:FVTime?</a>	Returns the Frequency versus Time trace data.
<a href="#">READ:FVTime:MAXimum?</a>	Returns the maximum value.
<a href="#">READ:FVTime:MAXLocation?</a>	Returns the time at which the frequency drift is maximum.
<a href="#">READ:FVTime:MINimum?</a>	Returns the minimum value.
<a href="#">READ:FVTime:MINLocation?</a>	Returns the time at which the frequency drift is minimum.
<a href="#">READ:FVTime:RESult?</a>	Returns the measurement results.
<b>READ:IQVTime subgroup</b>	<b>RF I&amp;Q versus Time measurement</b>
<a href="#">READ:IQVTime:I?</a>	Returns the I versus Time trace data.
<a href="#">READ:IQVTime:MAXimum?</a>	Returns the maximum value.
<a href="#">READ:IQVTime:MAXLocation?</a>	Returns the time at which the I or Q level is maximum.
<a href="#">READ:IQVTime:MINimum?</a>	Returns the minimum value.
<a href="#">READ:IQVTime:MINLocation?</a>	Returns the time at which the I or Q level is minimum.
<a href="#">READ:IQVTime:Q?</a>	Returns the Q versus Time trace data.
<a href="#">READ:IQVTime:RESult?</a>	Returns the measurement results.
<b>READ:MCPower subgroup</b>	<b>MCPR measurement</b>
<a href="#">READ:MCPower:ADJacent:CHANnels?</a>	Returns the power of adjacent channels.
<a href="#">READ:MCPower:CHANnel:POWer?</a>	Returns the reference power.
<a href="#">READ:MCPower:MAIN:CHANnels?</a>	Returns the power of main channels.
<a href="#">READ:MCPower:SPECTrum?</a>	Returns spectrum trace data.
<b>READ:MERRor subgroup (Option 21 only)</b>	<b>Magnitude error versus Time measurement</b>
<a href="#">READ:MERRor:FERRor?</a>	Returns the frequency error.
<a href="#">READ:MERRor:PEAK?</a>	Returns the peak value.
<a href="#">READ:MERRor:PINDEX?</a>	Returns the time at the magnitude error peak.
<a href="#">READ:MERRor:RMS?</a>	Returns the RMS value.
<a href="#">READ:MERRor:TRACe?</a>	Returns the Magnitude error versus Time trace data.
<b>READ:PERRor subgroup (Option 21 only)</b>	<b>Phase error versus Time measurement</b>
<a href="#">READ:PERRor:FERRor?</a>	Returns the frequency error.
<a href="#">READ:PERRor:PEAK?</a>	Returns the peak value.
<a href="#">READ:PERRor:PINDEX?</a>	Returns the time at the phase error peak.
<a href="#">READ:PERRor:RMS</a>	Returns the RMS value.
<a href="#">READ:PERRor:TRACe?</a>	Returns the Phase error versus Time trace data.
<b>READ:OBWidth subgroup</b>	<b>Occupied Bandwidth measurement</b>
<a href="#">READ:OBWidth:FREQuency:ERRor?</a>	Returns the frequency error.
<a href="#">READ:OBWidth:OBWidth:BANDwidth?</a>	Returns the occupied bandwidth.
<a href="#">READ:OBWidth:OBWidth:LEFT:FREQuency?</a>	Returns the left (lower) frequency of the occupied bandwidth.

Table 2-20: Read commands (cont.)

Header	Description
READ:OBWidth:OBWidth:LEFT:LEVel?	Returns the level at the left frequency of the occupied bandwidth.
READ:OBWidth:OBWidth:POWer?	Returns the reference power in the Occupied Bandwidth measurement.
READ:OBWidth:OBWidth:RIGHT:FREQuency?	Returns the right (higher) frequency of the occupied bandwidth.
READ:OBWidth:OBWidth:RIGHT:LEVel?	Returns the level at the right frequency of the occupied bandwidth.
READ:OBWidth:SPECtrum?	Returns spectrum trace data of the Occupied Bandwidth measurement.
READ:OBWidth:XDBBandwidth:BANDwidth?	Returns the x dB bandwidth.
READ:OBWidth:XDBBandwidth:LEFT:FREQuency?	Returns the left (lower) frequency of the x dB bandwidth.
READ:OBWidth:XDBBandwidth:LEFT:LEVel?	Returns the level at the left frequency of the x dB bandwidth.
READ:OBWidth:XDBBandwidth:POWer?	Returns the reference power in the x dB bandwidth measurement.
READ:OBWidth:XDBBandwidth:RIGHT:FREQuency?	Returns the right (higher) frequency of the x dB bandwidth.
READ:OBWidth:XDBBandwidth:RIGHT:LEVel?	Returns the level at the right frequency of the x dB bandwidth.
<b>READ:PHVTime subgroup</b>	<b>Phase versus Time measurement</b>
READ:PHVTime?	Returns the Phase versus Time trace data.
READ:PHVTime:MAXimum?	Returns the maximum value.
READ:PHVTime:MAXLocation?	Returns the time at which the phase is maximum.
READ:PHVTime:MINimum?	Returns the minimum value.
READ:PHVTime:MINLocation?	Returns the time at which the phase is minimum.
READ:PHVTime:RESult?	Returns the results.
<b>READ:PNOise subgroup (Option 11 only)</b>	<b>Phase noise measurements</b>
READ:PNOise:ALL?	Returns all the measurement results.
READ:PNOise:CARRier:FERRor?	Returns the carrier frequency error.
READ:PNOise:CARRier:POWer?	Returns the carrier power.
READ:PNOise:RESidual:FM?	Returns the residual FM.
READ:PNOise:RMS:PNOise?	Returns the RMS phase noise.
READ:PNOise:SPECtrum<x>:X?	Returns the frequencies of the specified trace.
READ:PNOise:SPECtrum<x>:XY?	Returns the frequency and phase noise pairs of the specified trace.
READ:PNOise:SPECtrum<x>[:Y]?	Returns the phase noise values of the specified trace.
READ:PNOise:JITTer?	Returns the jitter.
<b>READ:PULSe subgroup (Option 20 only)</b>	<b>Pulsed RF measurements</b>
READ:PULSef:RESultj:ATX?	Returns the average transmitted power in the results table.
READ:PULSef:RESultj:AVERage?	Returns the average on power in the results table.
READ:PULSef:RESultj:DROop?	Returns the droop in the results table.
READ:PULSef:RESultj:DUTPct?	Returns the duty factor (%) in the results table.
READ:PULSef:RESultj:DUTRatio?	Returns the duty factor (ratio) in the results table.
READ:PULSef:RESultj:FALL?	Returns the fall time in the results table.
READ:PULSef:RESultj:FRDeviatiOn?	Returns the frequency deviation in the results table.
READ:PULSef:RESultj:MFRReqerror?	Returns the maximum frequency error in the results table.

Table 2-20: Read commands (cont.)

Header	Description
READ:PULSe[:RESult]:MPHerror?	Returns the maximum phase error in the results table.
READ:PULSe[:RESult]:PHDeviation?	Returns the phase deviation in the results table.
READ:PULSe[:RESult]:PPFRequency?	Returns the pulse-pulse carrier frequency in the results table.
READ:PULSe[:RESult]:PPOWer?	Returns the peak power in the results table.
READ:PULSe[:RESult]:PPPHasE?	Returns the pulse-pulse carrier phase in the results table.
READ:PULSe[:RESult]:RINTerval?	Returns the repetition interval in the results table.
READ:PULSe[:RESult]:RIPPlE?	Returns the ripple in the results table.
READ:PULSe[:RESult]:RISE?	Returns the rise time in the results table.
READ:PULSe[:RESult]:RMSFreqerror?	Returns the RMS frequency error in the results table.
READ:PULSe[:RESult]:RMSPHerror?	Returns the RMS phase error in the results table.
READ:PULSe[:RESult]:RRATe?	Returns the repetition rate in the results table.
READ:PULSe[:RESult]:TIME?	Returns the time in the results table.
READ:PULSe[:RESult]:WIDTh?	Returns the pulse width in the results table.
READ:PULSe:STATistics?	Returns the trace data of the pulse statistics measurement.
READ:PULSe:STATistics:ATX?	Returns the average transmitted power of the statistics.
READ:PULSe:STATistics:AVERage?	Returns the average on power of the statistics.
READ:PULSe:STATistics:DROop?	Returns the droop of the statistics.
READ:PULSe:STATistics:DUTPct?	Returns the duty factor (%) of the statistics.
READ:PULSe:STATistics:DUTRatio?	Returns the duty factor (ratio) of the statistics.
READ:PULSe:STATistics:FALL?	Returns the fall time of the statistics.
READ:PULSe:STATistics:FRDeviation?	Returns the frequency deviation of the statistics.
READ:PULSe:STATistics:MFRReqerror?	Returns the maximum frequency error of the statistics.
READ:PULSe:STATistics:MPHerror?	Returns the maximum phase error of the statistics.
READ:PULSe:STATistics:PHDeviation?	Returns the phase deviation of the statistics.
READ:PULSe:STATistics:PPFRequency?	Returns the pulse-pulse carrier frequency of the statistics.
READ:PULSe:STATistics:PPOWer?	Returns the peak power of the statistics.
READ:PULSe:STATistics:PPPHasE?	Returns the pulse-pulse carrier phase of the statistics.
READ:PULSe:STATistics:RINTerval?	Returns the repetition interval of the statistics.
READ:PULSe:STATistics:RIPPlE?	Returns the ripple of the statistics.
READ:PULSe:STATistics:RISE?	Returns the rise time of the statistics.
READ:PULSe:STATistics:RMSFreqerror?	Returns the RMS frequency error of the statistics.
READ:PULSe:STATistics:RMSPHerror?	Returns the RMS phase error of the statistics.
READ:PULSe:STATistics:RRATE?	Returns the repetition rate of the statistics.
READ:PULSe:STATistics:WIDTh?	Returns the pulse width of the statistics.
READ:PULSe:TRACe:X?	Returns the time values of the pulse trace.
READ:PULSe:TRACe:XY?	Returns the horizontal (time) and vertical value pairs of the pulse trace.
READ:PULSe:TRACe[:Y]?	Returns the vertical values of the pulse trace.

Table 2-20: Read commands (cont.)

Header	Description
<b>READ:SGRam subgroup</b>	<b>Spectrogram measurement</b>
READ:SGRam?	Returns the spectrogram trace data.
<b>READ:SPECTrum subgroup</b>	<b>Spectrum measurement</b>
READ:SPECTrum:TRACe<x>?	Returns the trace data in the Spectrum Analyzer measurement.
<b>READ:SPURious subgroup</b>	<b>Spurious measurement</b>
READ:SPURious:CARRier:POWer?	Returns the carrier power.
READ:SPURious:COUNt?	Returns the number of spurious signals.
READ:SPURious:PASS?	Returns the pass/fail limit test result.
READ:SPURious:SPECTrum:X?	Returns the frequencies of the spectrum trace.
READ:SPURious:SPECTrum:XY?	Returns the frequency and amplitude pairs of the spectrum trace.
READ:SPURious:SPECTrum[:Y]?	Returns the amplitudes of the spectrum trace.
READ:SPURious:SPUR<x>:AMPLitude:ABSolute?	Returns the absolute amplitude of the specified spurious signal.
READ:SPURious:SPUR<x>:AMPLitude:RELative?	Returns the relative amplitude of the specified spurious signal.
READ:SPURious:SPUR<x>:FREQuency:ABSolute?	Returns the absolute frequency of the specified spurious signal.
READ:SPURious:SPUR<x>:FREQuency:RELative?	Returns the relative frequency of the specified spurious signal.
READ:SPURious:SPUR<x>:LIMit:ABSolute?	Returns the absolute amplitude of the limit for a spurious signal.
READ:SPURious:SPUR<x>:LIMit:RELative?	Returns the relative amplitude of the limit for a spurious signal.
READ:SPURious:SPUR<x>:LIMit:VIOLation?	Returns whether the specified spurious signal exceeds the limit or not.
READ:SPURious:SPUR<x>:RANGe?	Returns the frequency range in which the spurious signal occurred.
<b>READ:SQUality subgroup (Option 21 only)</b>	<b>Signal quality measurement</b>
READ:SQUality:FREQuency:DEViation?	Returns the frequency deviation.
READ:SQUality:FREQuency:DEViation:TABLE?	Returns the frequency deviation measurement results table.
READ:SQUality:FREQuency:ERRor?	Returns the frequency error.
READ:SQUality:GAIN:IMBalance?	Returns the gain imbalance.
READ:SQUality:ORIGin:OFFSet?	Returns the origin offset.
READ:SQUality:PEAK:EVM?	Returns the peak EVM (%).
READ:SQUality:PEAK:EVM:DB?	Returns the peak EVM (dB).
READ:SQUality:PEAK:EVM:DB:OFFSet?	Returns the peak offset EVM (dB).
READ:SQUality:PEAK:EVM:LOCation?	Returns the time at which the EVM is peak.
READ:SQUality:PEAK:EVM:LOCation:OFFSet?	Returns the time at which the offset EVM is peak.
READ:SQUality:PEAK:EVM:OFFSet?	Returns the peak offset EVM (%).
READ:SQUality:PEAK:FERRor?	Returns the peak FSK error.
READ:SQUality:PEAK:MERRor?	Returns the peak magnitude error (%).
READ:SQUality:PEAK:MERRor:DB?	Returns the peak magnitude error (dB).
READ:SQUality:PEAK:MERRor:LOCation?	Returns the time at which the magnitude error is peak.
READ:SQUality:PEAK:PERRor?	Returns the peak phase error.
READ:SQUality:PEAK:PERRor:LOCation?	Returns the time at which the phase error is peak.

Table 2-20: Read commands (cont.)

Header	Description
READ:SQUality:QUADrature:ERRor?	Returns the quadrature error.
READ:SQUality:RHO?	Returns the r (waveform quality).
READ:SQUality:RMS:EVM?	Returns the RMS EVM (%).
READ:SQUality:RMS:EVM:DB?	Returns the RMS EVM (dB).
READ:SQUality:RMS:EVM:DB:OFFSet?	Returns the RMS offset EVM (dB).
READ:SQUality:RMS:EVM:OFFSet?	Returns the RMS offset EVM (dB).
READ:SQUality:RMS:FERRor?	Returns the RMS FSK error.
READ:SQUality:RMS:MER:DB?	Returns the RMS MER (dB).
READ:SQUality:RMS:MERRor?	Returns the RMS magnitude error (%).
READ:SQUality:RMS:MERRor:DB?	Returns the RMS magnitude error (dB).
READ:SQUality:RMS:PERRor?	Returns the RMS phase error.
READ:SQUality:SYMBol:LENGth?	Returns the number of analyzed symbols.
READ:SQUality:SYMBol:RATE?	Returns the calculated symbol rate.
READ:SQUality:SYMBol:RATE:ERRor?	LAST Returns the value of the symbol rate error.
<b>READ:TDIagram subgroup (Option 21 only)</b>	<b>Trellis diagram</b>
READ:TDIagram:FERRor?	Returns the frequency error.
READ:TDIagram:TRACe?	Returns the Trellis diagram trace data.
<b>READ:TOVerview subgroup</b>	<b>Time overview</b>
READ:TOVerview?	Returns the trace data.

# Sense Commands

Use the SENSE commands to set up detailed measurement conditions.

Table 2-21: Sense commands

Header	Description
<b>[SENSE] basic command subgroup</b>	<b>General analysis parameter control</b>
[SENSE]:ACQuisition:{BANDwidth BWIDTH}	Sets or queries the acquisition bandwidth.
[SENSE]:ACQuisition:FFRame:ACTual?	Queries the actual number of Fast Frames.
[SENSE]:ACQuisition:FFRame:LIMit	Sets or queries the limit number of Fast Frames.
[SENSE]:ACQuisition:FFRame:STATe	Determines whether to enable or disable the Fast Frame.
[SENSE]:ACQuisition:MEMory:AVAILable:SAMPles?	Returns the amount of acquisition memory available in the instrument.
[SENSE]:ACQuisition:MEMory:CAPacity[:TIME]?	Returns the acquisition memory capacity.
[SENSE]:ACQuisition:MEMory:USED[:PERCent]?	Returns the percentage of the capacity used.
[SENSE]:ACQuisition:MODE	Selects or queries the acquisition mode.
[SENSE]:ACQuisition:SAMPles	Sets or queries the acquisition samples.
[SENSE]:ACQuisition:SEConds	Sets or queries the acquisition length.
[SENSE]:ANALysis:ADVanced:DITHer	Determines whether to enable or disable dithering.
[SENSE]:ANALysis:LENGth	Sets or queries the analysis length.
[SENSE]:ANALysis:LENGth:ACTual?	Queries the actual analysis length.
[SENSE]:ANALysis:LENGth:AUTO	Selects or queries whether to set the analysis length automatically.
[SENSE]:ANALysis:REFerence	Selects or queries the analysis time reference.
[SENSE]:ANALysis:STARt	Sets or queries the analysis offset time.
[SENSE]:ANALysis:STARt:AUTO	Selects or queries whether to set the analysis offset automatically.
[SENSE]:MEASurement:FREQuency	Sets or queries the measurement frequency.
[SENSE]:POWER:UNITs	Selects or queries the unit of power.
[SENSE]:REANalyze	Have all measurements reanalyze the current acquisition record.
[SENSE]:ROSCillator:SOURce	Selects or queries the reference oscillator source.
[SENSE]:SPECtrum:LENGth	Sets or queries the spectrum length.
[SENSE]:SPECtrum:LENGth:ACTual?	Queries the actual spectrum length.
[SENSE]:SPECtrum:LENGth:AUTO	Selects or queries whether to set the spectrum length automatically.
[SENSE]:SPECtrum:STARt	Sets or queries the spectrum offset time.
[SENSE]:SPECtrum:TIME:MODE	Selects or queries whether to set the spectrum time automatically.
[SENSE]:USETtings	Updates the analyzer settings.
<b>[SENSE]:ACPower subgroup</b>	<b>Channel power and ACPR measurement</b>
[SENSE]:ACPower:AVERage	Selects or queries how to average waveform.
[SENSE]:ACPower:AVERage:COUNT	Sets or queries the number of traces for averaging.
[SENSE]:ACPower:{BANDwidth BWIDTH}[:RESolution]	Sets or queries the resolution bandwidth (RBW).

Table 2-21: Sense commands (cont.)

Header	Description
[SENSe]:ACPower:{BANDwidth BWIDth}{:RESolution}:ACTual?	Queries the actual resolution bandwidth (RBW).
[SENSe]:ACPower:{BANDwidth BWIDth}{:RESolution}:AUTO	Selects or queries whether to set the RBW automatically.
[SENSe]:ACPower:{BANDwidth BWIDth}:VIDeo	Sets or queries the video bandwidth (VBW).
[SENSe]:ACPower:{BANDwidth BWIDth}:VIDeo:STATe	Selects or queries whether to enable the video bandwidth (VBW).
[SENSe]:ACPower:CHANnel:{BANDwidth BWIDth}	Sets or queries the channel bandwidth.
[SENSe]:ACPower:CHANnel:FILTer	Selects or queries the adjacent channel filter.
[SENSe]:ACPower:CHANnel:PAIRs	Sets or queries the number of adjacent channel pairs.
[SENSe]:ACPower:CHANnel:SPACing	Sets or queries the channel-to-channel spacing.
[SENSe]:ACPower:CHIPrate	Sets or queries the chip rate.
[SENSe]:ACPower:CLEar:RESults	Restarts the average trace.
[SENSe]:ACPower:FREQuency	Sets or queries the center frequency.
[SENSe]:ACPower:FREQuency:STEP	Sets or queries the frequency step size.
[SENSe]:ACPower:FREQuency:STEP:AUTO	Selects or queries whether to set the frequency step size automatically.
[SENSe]:ACPower:NFLoor:STATe	Selects or queries whether to enable the correction for noise floor.
[SENSe]:ACPower:OPTimize:SPAN	Selects or queries the optimization method.
[SENSe]:ACPower:RRCRolloff	Sets or queries the filter parameter for the Root Raised Cosine filter.
<b>[SENSe]:{AM FM PM} subgroup (Option 21 only)</b>	<b>AM/FM/PM measurement</b>
[SENSe]:{AM FM PM}:{BANDwidth BWIDth}:MEASurement	Sets measurement bandwidth for the AM, FM, or PM demodulation to analyze.
[SENSe]:{AM FM PM}:CLEar:RESults	Clears measurement results.
[SENSe]:{AM FM PM}:{MTPoints MAXTracepoints}	Selects or queries the maximum trace points.
[SENSe]:AM:DETECT:AMPLitude	Selects or queries the carrier amplitude detection method.
[SENSe]:{FM PM}:BURSt:THReshold	Sets or queries the threshold level to detect bursts.
[SENSe]:PM:PHASe:OFFSet:MARKer	Sets or queries the carrier frequency offset.
[SENSe]:{FM PM}:FREQuency:OFFSet	Sets or queries the carrier frequency offset in the FM/PM measurement.
[SENSe]:{FM PM}:FREQuency:OFFSet:MARKer	Sets or queries the frequency offset from selected marker location.
[SENSe]:{FM PM}:FREQuency:SEARch:AUTO	Selects or queries whether to detect the carrier frequency automatically.
[SENSe]:PM:PHASe:OFFSet	Sets or queries the phase offset from the selected marker location.
[SENSe]:PM:PHASe:SEARch:AUTO	Selects or queries whether to detect the phase automatically or manually.
<b>[SENSe]:AVTime subgroup</b>	<b>Amplitude versus Time measurement</b>
[SENSe]:AVTime:{BANDwidth BWIDth}	Sets or queries the time-domain bandwidth filter.
[SENSe]:AVTime:{BANDwidth BWIDth}:ACTual?	Queries the actual resolution bandwidth (RBW).
[SENSe]:AVTime:CLEar:RESults	Restarts multi-trace functions (Average and Max/Min Hold).
[SENSe]:AVTime:MAXTracepoints	Selects or queries the maximum trace points.
[SENSe]:AVTime:METHOD	Selects or queries the method to set the measurement bandwidth.



Table 2-21: Sense commands (cont.)

Header	Description
[SENSe]:AVTime:SPAN	Sets or queries the frequency span.
<b>[SENSe]:CCDF subgroup</b>	<b>CCDF measurement</b>
[SENSe]:CCDF:{BANDwidth BWIDTH}	Sets or queries the CCDF measurement bandwidth.
[SENSe]:CCDF:CLEar	Clears the CCDF accumulator and restarts the measurement.
[SENSe]:CCDF:TIME:TOTal:LENGth	Sets or queries the CCDF measurement time.
[SENSe]:CCDF:TIME:TYPE	Selects or queries how to repeat the CCDF measurement.
<b>[SENSe]:DDEMod subgroup (Option 21 only)</b>	<b>General purpose digital modulation measurements</b>
[SENSe]:DDEMod:ANALysis:LENGth	Sets or queries the analysis length.
[SENSe]:DDEMod:ANALysis:LENGth:ACTual?	Queries the actual analysis length.
[SENSe]:DDEMod:ANALysis:LENGth:AUTO	Selects or queries whether to set the analysis length automatically.
[SENSe]:DDEMod:{BANDwidth BWIDTH}:TINterval	Sets or queries the measurement bandwidth (frequency span).
[SENSe]:DDEMod:{BANDwidth BWIDTH}:TINterval:AUTO	Sets the measurement bandwidth (frequency span) automatically.
[SENSe]:DDEMod:BURSt:DETECT	Selects or queries how to detect bursts.
[SENSe]:DDEMod:BURSt:THReshold	Sets or queries the threshold level to determine a burst.
[SENSe]:DDEMod:CARRier:OFFSet	Sets or queries the carrier frequency offset.
[SENSe]:DDEMod:CARRier:OFFSet:AUTO	Sets or queries whether to detect the carrier frequency automatically.
[SENSe]:DDEMod:FILTer:ALPHA	Sets or queries the filter factor ( $a/BT$ ).
[SENSe]:DDEMod:FILTer:MEASurement	Selects or queries the measurement filter.
[SENSe]:DDEMod:FILTer:REFerence	Selects or queries the reference filter.
[SENSe]:DDEMod:FREQuency:DEVIation	Sets or queries the frequency deviation to determine two states for FSK.
[SENSe]:DDEMod:FREQuency:DEVIation:AUTO	Selects or queries whether to detect the frequency deviation automatically.
[SENSe]:DDEMod:MAGNitude:NORMalize	Selects or queries the method for the magnitude normalization.
[SENSe]:DDEMod:MINDEX	Selects or queries the modulation index for a CPM signal.
[SENSe]:DDEMod:MINDEX:AUTO	Selects or queries whether to detect the modulation index automatically.
[SENSe]:DDEMod:MODulation:TYPE	Selects or queries the modulation type.
[SENSe]:DDEMod:PRESet	Presets the modulation analysis to a communication standard.
[SENSe]:DDEMod:SRATE	Sets or queries the symbol rate.
[SENSe]:DDEMod:SWAP:IQ	Selects or queries whether or not to swap I and Q data.
[SENSe]:DDEMod:SYMBOL:HSSHift	Selects or queries the Q data half-symbol shift for OQPSK and SOQPSK signals.
[SENSe]:DDEMod:SYMBOL:MAP:SOURce?	Specifies or queries the user symbol map file.
[SENSe]:DDEMod:SYMBOL:MAP[:STATE]	Selects or queries whether to use the user symbol map.
[SENSe]:DDEMod:SYMBOL:PLOT:POSITION	Sets or queries the symbol point location on an SOQPSK waveform.
[SENSe]:DDEMod:SYMBOL:POINTS	Sets or queries the number of points per symbol.
[SENSe]:DDEMod:SYMBOL:RATE:SEARCh	Determines whether to enable a symbol rate search.
[SENSe]:DDEMod:SYNCh:WORD	Selects or queries whether to enable the synchronization word.

Table 2-21: Sense commands (cont.)

Header	Description
[SENSe]:DDEMod:SYNCh:WORD:SYMBOL	Sets or queries the synchronization word.
[SENSe]:DDEMod:TIME:UNITS	Selects or queries the fundamental unit of time.
<b>[SENSe]:DPSA subgroup</b>	<b>DPX spectrum measurement</b>
[SENSe]:DPSA:AUDio:DEMod:GAIN	Sets or queries the gain for the audio demodulation.
[SENSe]:DPSA:AUDio:DEMod:RXBWidth	Sets or queries the receiver bandwidth for the audio demodulation.
[SENSe]:DPSA:AUDio:DEMod:RXFRrequency?	Queries the receiver frequency for the audio demodulation.
[SENSe]:DPSA:AUDio:DEMod:STATE	Selects or queries whether to enable or disable the audio demodulation.
[SENSe]:DPSA:AUDio:DEMod:TUNE	Selects or queries how to determine the tuning frequency.
[SENSe]:DPSA:AUDio:DEMod:TYPE	Selects or queries the modulation type for the audio demodulation.
[SENSe]:DPSA:{BANDwidth BWIDth}:ACTual?	Sets or queries the resolution bandwidth (RBW).
[SENSe]:DPSA:{BANDwidth BWIDth}:OPTimization	FIRST Sets or queries the RF & IF Optimization for the Spectrum and Spectrogram displays.
[SENSe]:DPSA:{BANDwidth BWIDth}{:RESolution}:AUTO	Determines whether to set the resolution bandwidth (RBW) automatically or manually in the DPX spectrum measurement.
[SENSe]:DPSA:FREQuency:SPAN:{BANDwidth BWIDth}{:RESolution}:RATio	Selects or queries whether to set the RBW automatically.
[SENSe]:DPSA:CLEar:RESults	Restarts multi-trace functions (Average and Max/Min Hold).
[SENSe]:DPSA:COLor	Selects or queries the color palette of three-dimensional graphs.
[SENSe]:DPSA:COLor:MINimum	Sets or queries the minimum value of the color axis.
[SENSe]:DPSA:COLor:MAXimum	Sets or queries the maximum value of the color axis.
[SENSe]:DPSA:DWELI	Sets or queries the value of the Dwell time for the DPX spectrum measurement.
[SENSe]:DPSA:DWELI:AUTO	Sets the value of the Dwell time automatically.
[SENSe]:DPSA:POINTs:COUNT	Sets or queries the minimum value of the color axis.
[SENSe]:DPSA:FREQuency:CENTer	Sets or queries the center frequency.
[SENSe]:DPSA:FREQuency:SPAN	Sets or queries the frequency span.
[SENSe]:DPSA:FREQuency:START	Sets or queries the measurement start frequency.
[SENSe]:DPSA:FREQuency:STEP	Sets or queries the frequency step size.
[SENSe]:DPSA:FREQuency:STEP:AUTO	Selects or queries whether to set the frequency step size automatically.
[SENSe]:DPSA:FREQuency:STOP	Sets or queries the measurement stop frequency.
<b>[SENSe]:FVTime subgroup</b>	<b>Frequency versus Time measurement</b>
[SENSe]:FVTime:CLEar:RESults	Restarts multi-trace functions (Average and Max/Min Hold).
[SENSe]:FVTime:FREQuency:CENTer	Sets or queries the center frequency.
[SENSe]:FVTime:FREQuency:SPAN	Sets or queries the frequency span.
[SENSe]:FVTime:FREQuency:START	Sets or queries the measurement start frequency.
[SENSe]:FVTime:FREQuency:STEP	Sets or queries the frequency step size.
[SENSe]:FVTime:FREQuency:STEP:AUTO	Selects or queries whether to set the frequency step size automatically.
[SENSe]:FVTime:FREQuency:STOP	Sets or queries the measurement stop frequency.

Table 2-21: Sense commands (cont.)

Header	Description
[SENSe]:FVTime:MAXTracepoints	Selects or queries the maximum trace points.
<b>[SENSe]:IQVTime subgroup</b>	<b>RF I&amp;Q versus Time measurement</b>
[SENSe]:IQVTime:CLEAr:RESuLts	Restarts multi-trace functions (Average and Max/Min Hold).
[SENSe]:IQVTime:FREQUency:CENTer	Sets or queries the center frequency.
[SENSe]:IQVTime:FREQUency:SPAN	Sets or queries the frequency span.
[SENSe]:IQVTime:FREQUency:START	Sets or queries the measurement start frequency.
[SENSe]:IQVTime:FREQUency:STEP	Sets or queries the frequency step size.
[SENSe]:IQVTime:FREQUency:STEP:AUTO	Selects or queries whether to set the frequency step size automatically.
[SENSe]:IQVTime:FREQUency:STOP	Sets or queries the measurement stop frequency.
[SENSe]:IQVTime:MAXTracepoints	Selects or queries the maximum trace points.
<b>[SENSe]:MCPower subgroup</b>	<b>MCPR measurement</b>
[SENSe]:MCPower:AVERAge	Selects or queries how to average waveform.
[SENSe]:MCPower:AVERAge:COUNT	Sets or queries the number of waveforms for average.
[SENSe]:MCPower:{BANDwidth BWIDth}{:RESolution}	Sets or queries the resolution bandwidth (RBW).
[SENSe]:MCPower:{BANDwidth BWIDth}{:RESolution}:ACTual?	Queries the actual resolution bandwidth (RBW).
[SENSe]:MCPower:{BANDwidth BWIDth}{:RESolution}:AUTO	Selects or queries whether to set the RBW automatically.
[SENSe]:MCPower:{BANDwidth BWIDth}:VIDeo	Sets or queries the video bandwidth (VBW).
[SENSe]:MCPower:{BANDwidth BWIDth}:VIDeo:STATe	Selects or queries whether to enable the video bandwidth (VBW).
[SENSe]:MCPower:CHANnel:ADJacent:ADD	Adds a pair of upper and lower adjacent channels.
[SENSe]:MCPower:CHANnel:ADJacent:DELete	Deletes a selected adjacent channel.
[SENSe]:MCPower:CHANnel:FILTer	Selects or queries the measurement filter.
[SENSe]:MCPower:CHANnel:MAIN:{BANDwidth BWIDth}	Sets or queries the frequency bandwidth of the main channels.
[SENSe]:MCPower:CHANnel:MAIN:COUNT	Sets or queries the number of main channels.
[SENSe]:MCPower:CHANnel:MAIN:INACTive	Makes a main channel inactive or queries the inactive main channels.
[SENSe]:MCPower:CHANnel:MAIN:SPACing	Sets or queries the main channel spacing.
[SENSe]:MCPower:CHIPrate	Sets or queries the chip rate.
[SENSe]:MCPower:CLEAr:RESuLts	Restarts the average trace.
[SENSe]:MCPower:FREQUency	Sets or queries the center frequency.
[SENSe]:MCPower:FREQUency:STEP	Sets or queries the frequency step size.
[SENSe]:MCPower:FREQUency:STEP:AUTO	Selects or queries whether to set the frequency step size automatically.
[SENSe]:MCPower:NFLoor:STATe	Selects or queries whether to enable the correction for noise floor.
[SENSe]:MCPower:OPTimize:SPAN	Selects or queries the optimization method.
[SENSe]:MCPower:RCHannels?	Queries the power reference.
[SENSe]:MCPower:RCHannels:MAIN<x>	Sets the power reference to the main channel with the index (<x>).

Table 2-21: Sense commands (cont.)

Header	Description
[SENSe]:MCPower:RCHannels:TOTal	Sets the power reference to the total power of all the active channels.
[SENSe]:MCPower:RRCRolloff	Sets or queries the filter parameter for the Root Raised Cosine filter.
<b>[SENSe]:OBWidth subgroup</b>	<b>Occupied Bandwidth measurement</b>
[SENSe]:OBWidth:AVERAge	Selects or queries whether to enable or disable averaging.
[SENSe]:OBWidth:AVERAge:COUNT	Sets or queries the number of measurements for averaging.
[SENSe]:OBWidth:{BANDwidth BWIDTH}:MEASurement	Sets or queries the measurement bandwidth.
[SENSe]:OBWidth:{BANDwidth BWIDTH}[:RESolution]	Sets or queries the resolution bandwidth (RBW).
[SENSe]:OBWidth:{BANDwidth BWIDTH}[:RESolution]:ACTual?	Queries the actual resolution bandwidth (RBW).
[SENSe]:OBWidth:{BANDwidth BWIDTH}[:RESolution]:AUTO	Selects or queries whether to set the RBW automatically.
[SENSe]:OBWidth:{BANDwidth BWIDTH}:VIDeo	Sets or queries the video bandwidth (VBW).
[SENSe]:OBWidth:{BANDwidth BWIDTH}:VIDeo:STATE	Selects or queries whether to enable the video bandwidth (VBW).
[SENSe]:OBWidth:CLEar:RESults	Restarts the averaging.
[SENSe]:OBWidth:FREQuency:CENTer	Sets or queries the center frequency.
[SENSe]:OBWidth:FREQuency:STEP	Sets or queries the frequency step size.
[SENSe]:OBWidth:FREQuency:STEP:AUTO	Determines whether to set the frequency step size automatically.
[SENSe]:OBWidth:PERCent	Sets or queries the occupied bandwidth percent power.
[SENSe]:OBWidth:XDBLevel	Sets or queries the x dB level.
<b>[SENSe]:PHVTime subgroup</b>	<b>Phase versus Time measurement</b>
[SENSe]:PHVTime:CLEar:RESults	Restarts multi-trace functions (Average and Max/Min Hold).
[SENSe]:PHVTime:FREQuency:CENTer	Sets or queries the center frequency.
[SENSe]:PHVTime:FREQuency:SPAN	Sets or queries the frequency span.
[SENSe]:PHVTime:FREQuency:START	Sets or queries the measurement start frequency.
[SENSe]:PHVTime:FREQuency:STEP	Sets or queries the frequency step size.
[SENSe]:PHVTime:FREQuency:STEP:AUTO	Selects or queries whether to set the frequency step size automatically.
[SENSe]:PHVTime:FREQuency:STOP	Sets or queries the measurement stop frequency.
[SENSe]:PHVTime:MAXTracepoints	Selects or queries the maximum trace points.
<b>[SENSe]:PNOise subgroup (Option 11 only)</b>	<b>Phase noise measurement</b>
[SENSe]:PNOise:AVERAge:COUNT	Sets or queries the number of traces to combine for averaging.
[SENSe]:PNOise:AVERAge:ENABLE	Selects or queries whether to enable or disable averaging trace.
[SENSe]:PNOise:CARRier:FREQuency:TRACk	Selects or queries whether to enable tracking the carrier frequency.
[SENSe]:PNOise:CARRier:THReshold	Sets or queries the threshold level to detect the carrier.
[SENSe]:PNOise:CLEar:RESults	Restarts the average process.
[SENSe]:PNOise:FREQuency:INTegration:OFFSet:START	Sets or queries the start offset frequency for integration.

Table 2-21: Sense commands (cont.)

Header	Description
[SENSe]:PNOise:FREQuency:INTegration:OFFSet:STOP	Sets or queries the stop offset frequency for integration.
[SENSe]:PNOise:FREQuency:PLOT:OFFSet:START	Sets or queries the start offset frequency for plot.
[SENSe]:PNOise:FREQuency:PLOT:OFFSet:STOP	Sets or queries the stop offset frequency for plot.
[SENSe]:PNOise:OPTimization	Selects or queries the method of optimization.
<b>[SENSe]:PULSe subgroup (Option 20 only)</b>	<b>Pulsed RF measurements</b>
[SENSe]:PULSe:ANALyze:LEVel	Selects or queries how to determine the 50% level.
[SENSe]:PULSe:ANALyze:LEVel:FIFTy	Selects or queries how to determine the 50% level.
[SENSe]:PULSe:ANALyze:LEVel:HUNDred	Selects or queries how to determine the 50% level.
[SENSe]:PULSe:ANALyze:MEASurement:TIME:AUTO	Selects or queries whether to set the measurement time automatically.
[SENSe]:PULSe:ANALyze:MEASurement:TIME:START	Sets or queries the measurement start time.
[SENSe]:PULSe:ANALyze:MEASurement:TIME:STOP	Sets or queries the measurement stop time.
[SENSe]:PULSe:ANALyze:PMLocation	Sets or queries the phase measurement location.
[SENSe]:PULSe:ANALyze:POINT:LOCation	Selects or queries the point location method.
[SENSe]:PULSe:ANALyze:RFALl	Selects or queries the threshold levels to measure the rise/fall time.
[SENSe]:PULSe:ANALyze:RIPple	Sets or queries the ripple portion of the pulse top.
[SENSe]:PULSe:CARRier:OFFSet	Sets or queries the carrier frequency offset.
[SENSe]:PULSe:CARRier:SEARCh	Selects or queries how to detect the carrier.
[SENSe]:PULSe:DETECT:MEASurement	Selects or queries whether to set the maximum number of pulses.
[SENSe]:PULSe:DETECT:NUMBer	Sets or queries the maximum number of pulses to detect.
[SENSe]:PULSe:DETECT:POWer[:THRShold]	Sets or queries the power threshold to detect pulses.
[SENSe]:PULSe:DETECT:Time[:THRShold]	Sets or queries the minimum off-time between pulses.
[SENSe]:PULSe:FILTer:{BANDwidth BWIDTH}	Sets or queries the the filter bandwidth for the Gaussian filter.
[SENSe]:PULSe:FILTer:MEASurement	Selects or queries the measurement filter.
[SENSe]:PULSe:FREFerence:AUTO	Determines whether to estimate the frequency reference automatically.
[SENSe]:PULSe:FREFerence:CHIRpbw	Sets or queries the chirp bandwidth.
[SENSe]:PULSe:FREFerence:OFFSet	Sets or queries the frequency reference offset.
[SENSe]:PULSe:MODulation:TYPE	Selects or queries the modulation type.
[SENSe]:PULSe:SIGNAL:TYPE	Selects or queries the signal type.
<b>[SENSe]:SGRam subgroup</b>	<b>Spectrogram measurement</b>
[SENSe]:SGRam:{BANDwidth BWIDTH}:OPTimization	Selects or queries the method of optimizing gain and input bandwidth.
[SENSe]:SGRam:{BANDwidth BWIDTH}:RESolution	Sets or queries the resolution bandwidth (RBW).
[SENSe]:SGRam:{BANDwidth BWIDTH}[:RESolution]:ACTual?	Queries the actual resolution bandwidth (RBW).
[SENSe]:SGRam:{BANDwidth BWIDTH}[:RESolution]:AUTO	Selects or queries whether to set the RBW automatically.
[SENSe]:SGRam:{BANDwidth BWIDTH}[:RESolution]:MODE	Selects or queries whether to enable or disable the RBW processing.

Table 2-21: Sense commands (cont.)

Header	Description
[SENSe]:SGRam:{BANDwidth BWIDth}:VIDeo	Sets or queries the video bandwidth (VBW).
[SENSe]:SGRam:{BANDwidth BWIDth}:VIDeo:STATe	Selects or queries whether to enable the video bandwidth (VBW).
[SENSe]:SGRam:COLor	Selects or queries the color palette of three-dimensional graphs.
[SENSe]:SGRam:COLor:MAXimum	Sets or queries the maximum value of the color axis.
[SENSe]:SGRam:COLor:MINimum	Sets or queries the minimum value of the color axis.
[SENSe]:SGRam:FFT:WINDow	Selects or queries the FFT window.
[SENSe]:SGRam:FILTer[:SHAPE]	Selects or queries the filter shape.
[SENSe]:SGRam:FREQuency:CENTer	Sets or queries the center frequency.
[SENSe]:SGRam:FREQuency:SPAN	Sets or queries the frequency span.
[SENSe]:SGRam:FREQuency:SPAN:BANDwidth[:RESolution]:RATio	Sets or queries the ratio of span to RBW.
[SENSe]:SGRam:FREQuency:SPAN:MAXimum	Sets the frequency range to the maximum real-time span.
[SENSe]:SGRam:FREQuency:START	Sets or queries the measurement start frequency.
[SENSe]:SGRam:FREQuency:STEP	Sets or queries the frequency step size.
[SENSe]:SGRam:FREQuency:STEP:AUTO	Selects or queries whether to set the frequency step size automatically.
[SENSe]:SGRam:FREQuency:STOP	Sets or queries the measurement stop frequency.
<b>[SENSe]:SPECtrum subgroup</b>	<b>Spectrum measurement</b>
[SENSe]:SPECtrum:{BANDwidth BWIDth}:OPTimization	Selects or queries the method of optimizing gain and input bandwidth.
[SENSe]:SPECtrum:{BANDwidth BWIDth}:RESolution]	Sets or queries the resolution bandwidth (RBW).
[SENSe]:SPECtrum:{BANDwidth BWIDth}:RESolution]:ACTual?	Queries the actual resolution bandwidth (RBW).
[SENSe]:SPECtrum:{BANDwidth BWIDth}:RESolution]:AUTO	Selects or queries whether to set the RBW automatically.
[SENSe]:SPECtrum:{BANDwidth BWIDth}:RESolution]:MODE	Selects or queries whether to enable or disable the RBW process.
[SENSe]:SPECtrum:{BANDwidth BWIDth}:VIDeo	Sets or queries the video bandwidth (VBW).
[SENSe]:SPECtrum:{BANDwidth BWIDth}:VIDeo:STATe	Selects or queries whether to enable the video bandwidth (VBW).
[SENSe]:SPECtrum:CLEar:RESults	Restarts multi-trace functions (Average and Max/Min Hold).
[SENSe]:SPECtrum:FFT:WINDow	Selects or queries the FFT window.
[SENSe]:SPECtrum:FILTer[:SHAPE]	Selects or queries the filter shape.
[SENSe]:SPECtrum:FREQuency:CENTer	Sets or queries the center frequency.
[SENSe]:SPECtrum:FREQuency:SPAN	Sets or queries the frequency span.
[SENSe]:SPECtrum:FREQuency:SPAN:BANDwidth[:RESolution]:RATio	Sets or queries the ratio of span to RBW.
[SENSe]:SPECtrum:FREQuency:START	Sets or queries the measurement start frequency.
[SENSe]:SPECtrum:FREQuency:STEP	Sets or queries the frequency step size.

Table 2-21: Sense commands (cont.)

Header	Description
[SENSe]:SPEctrum:FREquency:STEP:AUTO	Selects or queries whether to set the frequency step size automatically.
[SENSe]:SPEctrum:FREquency:STOP	Sets or queries the measurement stop frequency.
[SENSe]:SPEctrum:MAX:SPAN	Sets the frequency span to the maximum span.
[SENSe]:SPEctrum:POINts:COUNT	Sets or queries the number of sample points on the signal spectrum.
<b>[SENSe]:SPURious subgroup</b>	<b>Spurious measurement</b>
[SENSe]:SPURious:CARRier:{BANDwidth BWIDth}	Sets or queries the channel width for the carrier as power reference.
[SENSe]:SPURious:CARRier:{BANDwidth BWIDth}:INtegration	Sets or queries the integration bandwidth to calculate the carrier power.
[SENSe]:SPURious:CARRier:{BANDwidth BWIDth}:RESolution]	Sets or queries the resolution bandwidth to measure the carrier power.
[SENSe]:SPURious:CARRier:{BANDwidth BWIDth}:RESolution]:AUTO	Selects or queries whether to set the resolution bandwidth automatically.
[SENSe]:SPURious:CARRier:DEtECTION	Selects or queries the carrier detection method.
[SENSe]:SPURious:CARRier:FREquency	Sets or queries the carrier frequency.
[SENSe]:SPURious:CARRier:THReshold	Sets or queries the threshold level to detect the carrier.
[SENSe]:SPURious:CLEar:RESults	Restarts multi-trace functions (Average and Max Hold).
[SENSe]:SPURious[:FREquency]:OVERlap?	Queries whether any of the frequency ranges (A to T) overlap.
[SENSe]:SPURious:LIST	Selects or queries how to list the spurious signals.
[SENSe]:SPURious:MODE	Selects or queries the frequency range mode (Multi or Single).
[SENSe]:SPURious:OPTimization	Selects or queries the method of optimization.
[SENSe]:SPURious:POINts:COUNT	Sets or queries the trace point count for the frequency range.
[SENSe]:SPURious:RANGe<x>:BANDwidth:VIDeo	Sets or queries the VBW for the specified frequency range.
[SENSe]:SPURious:RANGe<x>:BANDwidth:VIDeo:STATe	Selects or queries whether to enable the VBW for the frequency range.
[SENSe]:SPURious:RANGe<x>:DEtECTION	Selects or queries the display detector for the frequency range.
[SENSe]:SPURious:RANGe<x>:EXCURsion	Sets or queries the excursion level in the frequency range.
[SENSe]:SPURious:RANGe<x>:FILTer[:SHAPE]	Selects or queries the filter shape for the frequency range.
[SENSe]:SPURious:RANGe<x>:FILTer[:SHAPE]:BANDwidth	Sets or queries the filter bandwidth for the frequency range.
[SENSe]:SPURious:RANGe<x>:FILTer[:SHAPE]:BANDwidth:AUTO	Selects or queries whether to set the filter bandwidth automatically.
[SENSe]:SPURious:RANGe<x>:FREquency:START	Sets or queries the start frequency of the range.
[SENSe]:SPURious:RANGe<x>:FREquency:STOP	Sets or queries the stop frequency of the range.
[SENSe]:SPURious:RANGe<x>:LIMit:ABSolute:START	Sets or queries the absolute start amplitude of the limits for the range.
[SENSe]:SPURious:RANGe<x>:LIMit:ABSolute:STOP	Sets or queries the absolute stop amplitude of the limits for the range.
[SENSe]:SPURious:RANGe<x>:LIMit:MASK	Selects or queries the limit mask function mode for the frequency range.
[SENSe]:SPURious:RANGe<x>:LIMit:RELative:START	Sets or queries the relative start amplitude of the limits for the range.
[SENSe]:SPURious:RANGe<x>:LIMit:RELative:STOP	Sets or queries the relative stop amplitude of the limits for the range.

Table 2-21: Sense commands (cont.)

Header	Description
[SENSe]:SPURious:RANGe<x>:STATe	Selects or queries whether to enable or disable the frequency range.
[SENSe]:SPURious:RANGe<x>:THReshold	Sets or queries the threshold level to detect spurious signals in a range.
[SENSe]:SPURious:REFerence	Selects or queries the power reference.
[SENSe]:SPURious:REFerence:MANual:POWer	Sets or queries the reference power level.
<b>[SENSe]:TOVerview subgroup</b>	<b>Time overview</b>
[SENSe]:TOVerview:FREQuency:CENTer	Sets or queries the center frequency.
[SENSe]:TOVerview:MAXTracepoints	Selects or queries the maximum trace points.
[SENSe]:{AM FM PM};{BANDwidth BWIDth}; MEASurement	
[SENSe]:ANALysis:ADVanced:DITHer:HWARe: STATus?	
[SENSe]:DDEMod:CARRier:OFFSet:AUTO	
[SENSe]:DDEMod:PRESet	
[SENSe]:DDEMod:SYMBol:HSSHift	
[SENSe]:DDEMod:SYMBol:PLOT:POSition	
[SENSe]:DDEMod:SYMBol:RATE:SEARCh	



# Status Commands

Use the STATus commands to control registers defined in the SCPI status reporting structure.

**Table 2-22: Status commands**

Header	Description
STATus:ACPower:EVENTs?	Returns the current events for the ACPR measurement.
STATus:{AM FM PM}:EVENTs?	Returns the current events for the AM/FM/PM measurement.
STATus:AVTime:EVENTs?	Returns the current events for the Amplitude versus Time measurement.
STATus:CCDF:EVENTs?	Returns the current events for the CCDF measurement.
STATus:CONStellation:EVENTs?	Returns the current events for the Constellation measurement.
STATus:DIQTime:EVENTs?	Returns the current events for the Demod I&Q versus Time measurement.
STATus:DPXSA:EVENTs?	Returns the current events for the DPX spectrum measurement.
STATus:EDIagram:EVENTs?	Returns the current events for the Eye diagram measurement.
STATus:EVM:EVENTs?	Returns the current events for the EVM versus Time measurement.
STATus:FDVTime:EVENTs?	Returns the current events for the Freq dev versus Time measurement.
STATus:FVTime:EVENTs?	Returns the current events for the Frequency versus Time measurement.
STATus:IQVTime:EVENTs?	Returns the current events for the RF I&Q versus Time measurement.
STATus:MCPR:EVENTs?	Returns the current events for the MCPR measurement.
STATus:MERRor:EVENTs?	Returns the current events for the Mag error versus Time measurement.
STATus:OBWidth:EVENTs?	Returns the current events for the Occupied Bandwidth measurement.
STATus:OPERation:CONDition?	Queries the contents of the OCR.
STATus:OPERation:ENABle	Sets or queries the mask for the OENR.
STATus:OPERation[:EVENT]?	Queries the contents of the OEVR.
STATus:OPERation:NTRansition	Sets or queries the value of the negative transition filter.
STATus:OPERation:PTRansition	Sets or queries the value of the positive transition filter.
STATus:PERRor:EVENTs?	Returns the current events for the Phase error measurement.
STATus:PHVTime:EVENTs?	Returns the current events for the Phase versus Time measurement.
STATus:PNOise:EVENTs?	Returns the current events for the phase noise measurement.
STATus:PRESet	Presets a status byte.
STATus:PULSe:RESult:EVENTs?	Returns the current events for the pulse table measurement.
STATus:PULSe:STATistics:EVENTs?	Returns the current events for the pulse statistics measurement.
STATus:PULSe:TRACe:EVENTs?	Returns the current events for the pulse trace measurement.
STATus:QUEStionable:CONDition?	Queries the contents of the QCR.
STATus:QUEStionable:ENABle	Sets or queries the mask for the OENR.
STATus:QUEStionable[:EVENT]?	Queries the contents of the QER.
STATus:QUEStionable:NTRansition	Sets or queries the value of the negative transition filter.
STATus:QUEStionable:PTRansition	Sets or queries the value of the positive transition filter.

**Table 2-22: Status commands (cont.)**

<b>Header</b>	<b>Description</b>
<a href="#">STATus:QUESTIONable:CALibration:CONDition?</a>	Queries the contents of the questionable calibration condition register.
<a href="#">STATus:QUESTIONable:CALibration:ENABLE</a>	Sets or queries the mask for the questionable calibration enable register.
<a href="#">STATus:QUESTIONable:CALibration[:EVENT]?</a>	Queries the contents of the questionable calibration event register.
<a href="#">STATus:QUESTIONable:CALibration:NTRansition</a>	Sets or queries the value of the negative transition filter.
<a href="#">STATus:QUESTIONable:CALibration:PTRansition</a>	Sets or queries the value of the positive transition filter.
<a href="#">STATus:QUESTIONable:FREQuency:CONDition?</a>	Queries the contents of the questionable frequency condition register.
<a href="#">STATus:QUESTIONable:FREQuency:ENABLE</a>	Sets or queries the mask for the questionable frequency enable register.
<a href="#">STATus:QUESTIONable:FREQuency[:EVENT]?</a>	Queries the contents of the questionable frequency event register.
<a href="#">STATus:QUESTIONable:FREQuency:NTRansition</a>	Sets or queries the value of the negative transition filter.
<a href="#">STATus:QUESTIONable:FREQuency:PTRansition</a>	Sets or queries the value of the positive transition filter.
<a href="#">STATus:SGRAM:EVENTs?</a>	Returns the current events for the spectrogram measurement.
<a href="#">STATus:SPECTrum:EVENTs?</a>	Returns the current events for the spectrum measurement.
<a href="#">STATus:SPURious:EVENTs?</a>	Returns the current events for the spurious measurement.
<a href="#">STATus:SQUALity:EVENTs?</a>	Returns the current events for the signal quality measurement.
<a href="#">STATus:TDIagram:EVENTs?</a>	Returns the current events for the trellis diagram measurement.

# System Commands

Use the SYSTem commands to set or query system parameters for operation.

**Table 2-23: System commands**

Header	Description
<a href="#">SYSTem:COMMunicate:GPIB[:SELF]:ADDRESS</a>	Sets or queries the GPIB address of the instrument.
<a href="#">SYSTem:DATE</a>	Sets or queries the current date.
<a href="#">SYSTem:ERRor:ALL?</a>	Queries all the error or event information.
<a href="#">SYSTem:ERRor:CODE:ALL?</a>	Queries all the error or event codes.
<a href="#">SYSTem:ERRor:CODE[:NEXT]?</a>	Queries the latest error or event information.
<a href="#">SYSTem:ERRor:COUNT?</a>	Queries the number of errors or events.
<a href="#">SYSTem:ERRor[:NEXT]?</a>	Queries the latest error or event information.
<a href="#">SYSTem:OPTions?</a>	Queries optional information.
<a href="#">SYSTem:PRESet</a>	Presets the analyzer.
<a href="#">SYSTem:TIME</a>	Sets or queries the current time.
<a href="#">SYSTem:VERSion?</a>	Queries the version of the SCPI.

# Trace Commands

Use the TRACe commands to select trace type and to control trace arithmetic.

Table 2-24: Trace commands

Header	Description
<b>TRACe:{AM FM PM} subgroup</b>	<b>AM/FM/PM measurement</b>
TRACe:{AM FM PM}	Determines whether or not to show the trace.
TRACe:{AM FM PM}:DETection	Selects or queries the display detector, the method to be used for decimating traces to fit the available horizontal space on screen.
TRACe<x>:AVTime:DETection	Selects or queries the display detector.
TRACe:{AM FM PM}:FREeze	Selects or queries whether or not to freeze the trace display.
TRACe:{AM FM PM}:FUNCTion	Selects or queries the trace function.
<b>TRACe&lt;x&gt;:AVTime subgroup</b>	<b>Amplitude versus Time measurement</b>
TRACe<x>:AVTime	Selects or queries whether or not to show the specified trace.
TRACe<x>:AVTime:AVERAge:COUNT	Sets or queries the number of traces to combine for averaging.
TRACe<x>:AVTime:AVERAge:RESet	Clears the average data and resets the average counter.
TRACe<x>:AVTime:COUNT	Sets or queries the count for the Max or Min Hold trace.
TRACe<x>:AVTime:COUNT:ENABLE	Selects or queries whether or not to enable the count for Max/Min Hold.
TRACe<x>:AVTime:COUNT:RESet	Clears the Max or Min Hold data and counter, and restarts the process.
TRACe<x>:AVTime:FREeze	Selects or queries whether or not to freeze the display of the trace.
TRACe<x>:AVTime:FUNCTion	Selects or queries the trace function.
TRACe<x>:AVTime:LEFToperand	Selects or queries the left operand for the math trace.
TRACe<x>:AVTime:RIGHToperand	Selects or queries the right operand for the math trace.
TRACe<x>:AVTime:SELection	Selects or queries the trace number to display the readout.
<b>TRACe&lt;x&gt;:CCDF subgroup</b>	<b>CCDF measurement</b>
TRACe<x>:CCDF:FREeze	Selects or queries whether or not to freeze the display of the trace.
TRACe<x>:CCDF:SELection	Selects or queries the trace number to display the readout.
TRACe<x>:CCDF:SHOW	Selects or queries whether to show or hide the trace.
TRACe<x>:CCDF:X	Sets or queries the horizontal position of the measurement pointer.
TRACe<x>:CCDF:Y?	Queries the vertical position (CCDF value) of the measurement pointer.
<b>TRACe:CONStellation subgroup (Option 21 only)</b>	<b>Constellation measurement</b>
TRACe:CONStellation:MODE	Selects or queries how to display the constellation trace.
<b>TRACe:DIQVTime subgroup (Option 21 only)</b>	<b>Demodulated I&amp;Q versus Time measurement</b>
TRACe:DIQVTime:ENABLE:I	Selects or queries whether to show or hide the trace I.
TRACe:DIQVTime:ENABLE:Q	Determines whether to show or hide the Q trace.
TRACe:DIQVTime:SELection:I	Selects the I trace.
TRACe:DIQVTime:SELection:Q	Selects the Q trace.
<b>TRACe&lt;x&gt;:DPSA subgroup</b>	<b>DPX spectrum measurement</b>

Table 2-24: Trace commands (cont.)

Header	Description
TRACe<x>:DPSA	Selects or queries whether or not to show the waveform.
TRACe<x>:DPSA:AVERAge:COUNT	Sets or queries the number of traces to combine for averaging.
TRACe<x>:DPSA:COLor:CURVe	Sets or queries the color intensity.
TRACe<x>:DPSA:COLor:INTensity	Sets or queries the color intensity in the DPX spectrum view.
TRACe<x>:DPSA:COLor:SCALE:AUTO	Automatically adjusts the Max and Min color settings to display the broadest range of colors.
TRACe<x>:DPSA:DETEction	Selects or queries the function.
TRACe<x>:DPSA:DOT:PERsistent	Selects or queries whether to enable or disable the dot persistence.
TRACe<x>:DPSA:DOT:PERsistent:TYPE	Selects or queries the persistence type.
TRACe<x>:DPSA:DOT:PERsistent:VARiable	Sets or queries the length of time that data points are displayed.
TRACe<x>:DPSA:FREeze	Selects or queries whether or not to freeze the display of the trace.
TRACe<x>:DPSA:FUNCTion	Selects or queries the trace function for the in the DPX spectrum view.
TRACe<x>:DPSA:LEFToperand	Selects or queries the left operand for the math trace.
TRACe<x>:DPSA:RIGHToperand	Selects or queries the right operand for the math trace.
TRACe<x>:DPSA:SElect	Selects or queries the trace number to display the readout.
<b>TRACe:EDlagram subgroup (Option 21 only)</b>	<b>Eye diagram</b>
TRACe:EDlagram:ENABle:I	Selects or queries whether to show or hide the trace I.
TRACe:EDlagram:ENABle:Q	Selects or queries whether to show or hide the trace Q.
TRACe:EDlagram:SElect:I	Selects the I trace.
TRACe:EDlagram:SElect:Q	Selects the Q trace.
<b>TRACe:FVTime subgroup</b>	<b>Frequency versus Time measurement</b>
TRACe:FVTime	Selects or queries whether or not to show the trace.
TRACe:FVTime:AVERAge:COUNT	Sets or queries the number of traces to combine for averaging.
TRACe:FVTime:COUNT	Sets or queries the count for the Max or Min Hold trace.
TRACe:FVTime:COUNT:ENABle	Selects or queries whether or not to enable the count for Max/Min Hold.
TRACe:FVTime:COUNT:RESet	Clears the Max or Min Hold data and counter, and restarts the process.
TRACe<x>:FVTime:DETEction	Enables or queries the type of detection for the specified trace.
TRACe:FVTime:FREeze	Selects or queries whether or not to freeze the display of the trace.
TRACe:FVTime:FUNCTion	Selects or queries the trace function.
<b>TRACe:IQVTime subgroup</b>	<b>RF I&amp;Q versus Time measurement</b>
TRACe:IQVTime:AVERAge:COUNT	Sets or queries the number of traces to combine for averaging.
TRACe:IQVTime:COUNT	Sets or queries the count for the Max or Min Hold trace.
TRACe:IQVTime:COUNT:ENABle	Determines whether to enable or disable the count for the Max or Min Hold trace.
TRACe:IQVTime:DETEction	Selects or queries whether or not to enable the count for Max/Min Hold.
TRACe:IQVTime:COUNT:RESet	Clears the Max or Min Hold data and counter, and restarts the process.
TRACe:IQVTime:ENABle:I	Selects or queries whether to show or hide the trace I.

Table 2-24: Trace commands (cont.)

Header	Description
TRACe:IQVTime:ENABle:Q	Selects or queries whether to show or hide the trace Q.
TRACe:IQVTime:FReeze	Selects or queries whether to freeze the IQ traces.
TRACe:IQVTime:FUNCTion	Selects or queries the trace function.
TRACe:IQVTime:SElect:I	Selects or queries whether to choose the I trace.
TRACe:IQVTime:SElect:Q	Selects or queries whether to choose the Q trace.
<b>TRACe:OBWidth subgroup</b>	<b>Occupied Bandwidth measurement</b>
TRACe:OBW:MAXHold	Determines whether to enable or disable the Max Hold trace.
<b>TRACe:PHVTime subgroup</b>	<b>Phase versus Time measurement</b>
TRACe:PHVTime	Selects or queries whether or not to show the trace.
TRACe:PHVTime:AVERage:COUNT	Sets or queries the number of traces to combine for averaging.
TRACe:PHVTime:COUNT	Sets or queries the count for the Max or Min Hold trace.
TRACe:PHVTime:COUNT:ENABle	Selects or queries whether or not to enable the count for Max/Min Hold.
TRACe:PHVTime:COUNT:RESet	Clears the Max or Min Hold data and counter, and restarts the process.
TRACe<x>:PHVTime:DETECTion	Selects or queries the display detector.
TRACe:PHVTime:FReeze	Selects or queries whether to freeze the trace.
TRACe:PHVTime:FUNCTion	Selects or queries the trace function.
<b>TRACe:PNOise subgroup (Option 11 only)</b>	<b>Phase noise measurement</b>
TRACe<x>:PNOise:SElect	Selects a trace or queries the currently selected trace.
TRACe<x>:PNOise:SHOW	Selects or queries whether to show or hide the trace.
TRACe<x>:PNOise:SMOothing:COUNT	Sets or queries the number of data points for smoothing the trace.
TRACe<x>:PNOise:SMOothing:ENABle	Selects or queries whether to enable smoothing the specified trace.
TRACe<x>:PNOise:SMOothing:RESet	Restarts the smoothing process.
<b>TRACe:SGRam subgroup</b>	<b>Spectrogram measurement</b>
TRACe:SGRam:DETECTion	Selects or queries the method to be used for decimating traces to fit the on screen.
TRACe:SGRam:FReeze	Selects or queries whether or not to freeze the spectrogram display.
TRACe:SGRam:FUNCTion	Selects or queries the trace function for the spectrogram.
TRACe:SGRam:FUNCTion:TIME	Sets or queries the number of traces to combine for the trace function.
TRACe:SGRam:SElect:LINE	Selects or queries the number of line to send to the spectrum display.
<b>TRACe&lt;x&gt;:SPECTrum subgroup</b>	<b>Spectrum measurement</b>
TRACe<x>:SPECTrum	Selects or queries whether to show or hide the specified trace.
TRACe<x>:SPECTrum:AVERage:COUNT	Sets or queries the number of traces to combine for averaging.
TRACe<x>:SPECTrum:AVERage:RESet	Clears the average data and resets the average counter.
TRACe<x>:SPECTrum:COUNT	Sets or queries the count for the Max or Min Hold trace.
TRACe<x>:SPECTrum:COUNT:ENABle	Selects or queries whether or not to enable the count for Max/Min Hold.
TRACe<x>:SPECTrum:COUNT:RESet	Clears the Max or Min Hold data and counter, and restarts the process.
TRACe<x>:SPECTrum:DETECTion	Selects or queries the display detector.

Table 2-24: Trace commands (cont.)

Header	Description
TRACe<x>:SPECtrum:FREeze	Selects or queries whether or not to freeze the display of the trace.
TRACe<x>:SPECtrum:FUNction	Selects or queries the trace function.
TRACe<x>:SPECtrum:LEFToperand	Selects or queries the left operand for the math trace.
TRACe<x>:SPECtrum:RIGHToperand	Selects or queries the right operand for the math trace.
TRACe<x>:SPECtrum:SElect	Selects or queries the trace number to display the readout.
<b>TRACe:SPURious subgroup</b>	<b>Spurious measurement</b>
TRACe:SPURious:COUNT	Sets or queries the count for the Max Hold or Average trace.
TRACe:SPURious:COUNT:ENABLE	Selects or queries whether to enable the count for Max Hold or Average.
TRACe:SPURious:COUNT:RESet	Clears Max Hold or Average data and counter, and restarts the process.
TRACe:SPURious:FREeze	Determines whether or not to freeze the display of the trace.
TRACe:SPURious:FUNction	Selects or queries the trace function.
<b>TRACe:TOVerview subgroup</b>	<b>All measurement</b>
TRACe1:TOVerview	Enables display of or queries the display status of the specified trace.
TRACe1:TOVerview:AVERage:COUNT	Sets or queries the number of traces averaged to generate the specified trace.
TRACe1:TOVerview:COUNT	Enables or queries the count set for the specified trace.
TRACe1:TOVerview:COUNT:ENABLE	Enables or queries the Average count for the specified trace.
TRACe1:TOVerview:COUNT:RESet	Selects or queries whether or not to freeze the display of the trace.
TRACe1:TOVerview:DETEction	Enables or queries the type of detection for the specified trace.
TRACe1:TOVerview:FREeze	Enables or queries a halt to acquisition updates for the specified trace.
TRACe1:TOVerview:FUNction	Enables or queries the selected Function for the specified trace.

## Trace Mnemonics

Multiple traces can be used in some measurement displays. The traces are specified by the trace specifier TRACe<x> (<x>=1 to 5) which is defined for each measurement display as follows.

Table 2-25: Trace mnemonics

Measurement display	TRACe1	TRACe2	TRACe3	TRACe4	TRACe5
Amplitude versus Time	Trace 1	Trace 2	Math trace	NA	NA
CCDF	Trace 1	Trace 2	Gaussian curve	NA	NA
DPX spectrum	+Peak trace	-Peak trace	Average trace	Math trace	Bitmap trace
Phase noise	Trace 1	Trace 2	NA	NA	NA
Spectrum	Trace 1	Trace 2	Trace 3	Math trace	Spectrogram

**NOTE.** *Valid traces depend on commands. Refer to each command description.*

---



# Trigger commands

Use the TRIGger commands to set up the trigger system.

**Table 2-26: Trigger commands**

Header	Description
TRIGger:DPSA:SHOW:FRAMES	Selects or queries whether to trigger each segment in the swept mode.
TRIGger:MASK:NEW	Loads a new frequency mask.
TRIGger:MASK:NEW:AUTO	Draws a new frequency mask automatically.
TRIGger:MASK:OPEN	Opens a trigger mask with a specified file.
TRIGger:MASK:SAVE	Saves the current trigger mask to a specified file.
TRIGger[:SEQuence]:ADVanced:HOLDoff	FIRST Sets or queries the trigger holdoff time.
TRIGger[:SEQuence]:ADVanced:SWEep:MODE	Determines whether or not to trigger each segment in the swept acquisition mode.
TRIGger[:SEQuence]:ADVanced:SWEPT:SEGment:ENABLE	Determines whether or not to wait for a trigger for each acquisition in a swept spectrum.
TRIGger[:SEQuence]:EVENT:INPut:DDENsity:AMPLitude	Sets or queries the center vertical level for the density trigger region.
TRIGger[:SEQuence]:EVENT:EXTFront:IMPedance	Selects or queries the impedance of the external trigger input (front).
TRIGger[:SEQuence]:EVENT:EXTFront:LEVel	Sets or queries the trigger level at the external trigger input (front).
TRIGger[:SEQuence]:EVENT:EXTFront:SLOPe	Selects or queries the trigger slope of the external trigger input (front).
TRIGger[:SEQuence]:EVENT:EXTRear:SLOPe	Selects or queries the trigger slope of the external trigger input (rear).
TRIGger[:SEQuence]:EVENT:GATed	Selects or queries the logic for the gated trigger input.
TRIGger[:SEQuence]:EVENT:INPut:FMASK: BANDwidth BWIDTH[:RESolution]:ACTual?	Selects or queries when the trigger occurs in the frequency mask trigger.
TRIGger[:SEQuence]:EVENT:INPut:DDENsity: AMPLitude:TOLerance	Sets or queries the trigger level for the RF input level trigger.
TRIGger[:SEQuence]:EVENT:INPut:RUNT:PULse:HIGH: LEVel	Selects or queries the trigger slope for the RF input level trigger.
TRIGger[:SEQuence]:EVENT:INPut:TDBWidth	Sets or queries the time-domain bandwidth.
TRIGger[:SEQuence]:EVENT:INPut:TDBWidth:ACTual?	Queries the actual time-domain bandwidth.
TRIGger[:SEQuence]:EVENT:INPut:TDBWidth:STATe	Determines whether to set the time-domain bandwidth automatically.
TRIGger[:SEQuence]:EVENT:INPut:TYPE	Selects or queries the trigger type for the source of RF input.
TRIGger[:SEQuence]:EVENT:SOURce	Selects or queries the trigger event source.
TRIGger[:SEQuence]:FORCed	Selects or queries whether to causes a manual trigger.
TRIGger[:SEQuence]:IMMEDIATE	Causes a trigger immediately.
TRIGger[:SEQuence]:EVENT:INPut:DDENsity: FREQuency	Sets or queries the center horizontal level for the density trigger region.
TRIGger[:SEQuence]:EVENT:INPut:DDENsity: FREQuency:TOLerance	Sets or queries the left and right extensions of the density trigger region from the center horizontal level.
TRIGger[:SEQuence]:EVENT:INPut:DDENsity:THReshold	Sets or queries the DPX Density threshold that defines a trigger event.

Table 2-26: Trigger commands (cont.)

Header	Description
TRIGger[:SEquence]:EVENT:INPut:DDENsity:VIOlation	Sets or queries whether a density value higher or lower than the THReshold value defines a trigger event.
TRIGger[:SEquence]:EVENT:INPut:FMASK: {BANDwidth BWIDth};RESolution]	Sets or queries the Resolution Bandwidth value to be used in the spectrum view for the frequency mask trigger.
TRIGger[:SEquence]:EVENT:INPut:FMASK: BANDwidth BWIDth};RESolution]:AUTO	Sets or queries whether to automatically set the Resolution Bandwidth value used in the spectrum view for the frequency mask trigger.
TRIGger[:SEquence]:EVENT:INPut:FMASK:VIOlation	Selects or queries when the analyzer triggers in the frequency mask trigger.
TRIGger[:SEquence]:EVENT:INPut:LEVel	Sets or queries the trigger level for the RF input level trigger.
TRIGger[:SEquence]:EVENT:INPut:RUNT:PULSe	Selects or queries the Runt trigger for a positive or negative going pulse.
TRIGger[:SEquence]:EVENT:INPut:RUNT:PULSe:LOW: LEVel	Sets or queries the lower level (second threshold) to qualify a Runt trigger.
TRIGger[:SEquence]:EVENT:INPut:SLOPe	Selects or queries the trigger slope for the RF input level trigger.
TRIGger[:SEquence]:STATus	Selects or queries the trigger mode (Free Run or Triggered).
TRIGger[:SEquence]:TIME:DELay	Sets or queries the trigger delay time.
TRIGger[:SEquence]:TIME:QUALified	LAST Selects or queries the timing qualification setting for triggers.
TRIGger[:SEquence]:TIME:QUALified:TIME<x>	Selects or queries the trigger mode (Free Run or Triggered).
TRIGger[:SEquence]:ADVanced:HOLDoff:ENABle	Sets or queries the trigger delay time.
TRIGger[:SEquence]:TIME:POSition	Sets or queries the trigger position.

# Unit Commands


Specify fundamental units for measurement.

**Table 2-27: Unit commands**

<b>Header</b>	<b>Description</b>
<a href="#">UNIT:POWer</a>	Selects or queries the unit of power.

## Retrieving Response Message

When receiving a query command from the external controller, the analyzer puts the response message on the Output Queue. This message cannot be retrieved unless you perform retrieval operations through the external controller. (For example, call the IBRD subroutine included in the GPIB software of National Instruments.)



**Figure 2-5: Retrieving response message**

When the Output Queue contains a response message, sending another command from the external controller before retrieving this message deletes it from the queue. The Output Queue always contains the response message to the most recent query command.

You can use the MAV bit of the Status Byte Register (SBR) to check whether the Output Queue contains a response message. For details, refer to *Status Byte Register (SBR)*.

---

# Command Descriptions

## ABORt (No Query Form)

Resets the trigger system and places all trigger sequences in the idle state. Any actions related to the trigger system that are in progress, such as a sweep or acquiring a measurement is also aborted.

To start data acquisition, use the INITiate commands.

<b>Conditions</b>	Measurement views: All
<b>Group</b>	Abort commands
<b>Syntax</b>	ABORt
<b>Related Commands</b>	INITiate:CONTinuous, INITiate[:IMMediate]
<b>Arguments</b>	None
<b>Examples</b>	ABORt resets the trigger system and stops data acquisition.

## \*CAL (Query Only)

Instructs the analyzer to perform an internal self-alignment and return its status.

---

**NOTE.** *The self-alignment can take several minutes to respond. No other commands will be executed until alignment is complete.*

---

<b>Conditions</b>	Measurement views: All
<b>Group</b>	IEEE common commands
<b>Syntax</b>	*CAL
<b>Returns</b>	<NR1>=1 indicates that the alignment was successful. <NR1>=0 indicates that the alignment was unsuccessful.

**Examples** \*CAL performs an internal self-alignment and will return 1 if the alignment is successful.

## CALCulate:ACPower:MARKer<x>:DELTA:X? (Query Only)

Returns the delta marker frequency for the selected marker in the Channel power and ACPR measurement.

The parameter <x> = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

**Conditions** Measurement views: Channel power and ACPR

**Group** Calculate commands

**Syntax** CALCulate:ACPower:MARKer<x>:DELTA:X?

**Related Commands** [CALCulate:MARKer:ADD](#), [CALCulate:ACPower:MARKer<x>:DELTA:Y?](#)

**Returns** <NRf> Delta marker frequency for the selected marker.

**Examples** CALCULATE:ACPOWER:MARKER1:DELTA:X? might return 1.28E+6, indicating that the delta marker frequency is 1.28 MHz.

## CALCulate:ACPower:MARKer<x>:DELTA:Y? (Query Only)

Returns the delta marker amplitude for the selected marker in the Channel power and ACPR measurement.

The parameter <x> = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

**Conditions** Measurement views: Channel power and ACPR

**Group** Calculate commands

**Syntax** CALCulate:ACPower:MARKer<x>:DELTA:Y?

**Related Commands**    [CALCulate:MARKer:ADD](#), [CALCulate:ACPower:MARKer<x>:DELTA:X?](#)

**Returns**    <NRf> Delta marker amplitude for the selected marker.

**Examples**    `CALCULATE:ACPOWER:MARKER1:DELTA:Y?` might return 23.45, indicating that the delta marker amplitude is 23.45 dB.

## **CALCulate:ACPower:MARKer<x>:MAXimum (No Query Form)**

Moves the selected marker to the highest peak on the trace in the Channel power and ACPR measurement.

**Conditions**    Measurement views: Channel power and ACPR

**Group**    Calculate commands

**Syntax**    `CALCulate:ACPower:MARKer<x>:MAXimum`

**Arguments**    None

**Examples**    `CALCULATE:ACPOWER:MARKER1:MAXIMUM` moves Marker 1 (M1) to the highest peak on the trace.

## **CALCulate:ACPower:MARKer<x>:PEAK:LEFT (No Query Form)**

Moves the selected marker to the next peak to the left on the trace in the Channel power and ACPR measurement.

**Conditions**    Measurement views: Channel power and ACPR

**Group**    Calculate commands

**Syntax**    `CALCulate:ACPower:MARKer<x>:PEAK:LEFT`

**Related Commands**    [CALCulate:ACPower:MARKer<x>:PEAK:RIGHT](#)

**Arguments** None

**Examples** CALCULATE:ACPOWER:MARKER1:PEAK:LEFT moves Marker 1 (M1) to the next peak to the left on the trace.

## CALCulate:ACPower:MARKer<x>:PEAK:RIGHT (No Query Form)

Moves the selected marker to the next peak to the right on the trace in the Channel power and ACPR measurement.

**Conditions** Measurement views: Channel power and ACPR

**Group** Calculate commands

**Syntax** CALCulate:ACPower:MARKer<x>:PEAK:RIGHT

**Related Commands** [CALCulate:ACPower:MARKer<x>:PEAK:LEFT](#)

**Arguments** None

**Examples** CALCULATE:ACPOWER:MARKER1:PEAK:RIGHT moves Marker 1 (M1) to the next peak to the right on the trace.

## CALCulate:ACPower:MARKer<x>:X

Sets or queries the horizontal position of the selected marker in the Channel power and ACPR measurement.

**Conditions** Measurement views: Channel power and ACPR

**Group** Calculate commands

**Syntax** CALCulate:ACPower:MARKer<x>:X <value>  
CALCulate:ACPower:MARKer<x>:X?

**Related Commands** [CALCulate:ACPower:MARKer<x>:Y?](#)



**Arguments** `<value> ::= <Nrf>` specifies the horizontal position of the marker.  
 Range: Start to Stop frequency (left to right edge of the horizontal axis).  
 Using an out-of-range value causes an execution error (-222, "Data out of range").

**Examples** `CALCULATE:ACPOWER:MARKER1:X 800MHZ` places Marker 1 (M1) at 800 MHz on the trace.

## CALCulate:ACPower:MARKer<x>:Y? (Query Only)

Queries the marker amplitude of the selected marker in the Channel power and ACPR measurement.

**Conditions** Measurement views: Channel power and ACPR

**Group** Calculate commands

**Syntax** `CALCulate:ACPower:MARKer<x>:Y?`

**Related Commands** [CALCulate:ACPower:MARKer<x>:X](#)

**Arguments** None

**Returns** `<Nrf>` Marker amplitude of the selected marker.

**Examples** `CALCULATE:ACPOWER:MARKER1:Y` might return `-34.28`, indicating Marker 1 (M1) is at -34.28 dBm.

## CALCulate:{AM|FM|PM}:MARKer<x>:DELTA:X? (Query Only)

Returns the delta marker time for the selected marker in the AM/FM/PM measurement.

The parameter `<x>` = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

**Conditions** Measurement views: General purpose analog demodulation

<b>Group</b>	Calculate commands
<b>Syntax</b>	<code>CALCulate:{AM FM PM}:MARKer&lt;x&gt;:DELTA:X?</code>
<b>Related Commands</b>	<a href="#">CALCulate:{AM FM PM}:MARKer&lt;x&gt;:DELTA:Y?</a>
<b>Arguments</b>	None
<b>Returns</b>	<Nrf> Delta marker time for the selected marker.
<b>Examples</b>	<code>CALCULATE:AM:MARKER1:DELTA:X?</code> might return <code>38.0E-6</code> , indicating that the delta marker time is 38.0 $\mu$ s.

### **CALCulate:{AM|FM|PM}:MARKer<x>:DELTA:Y? (Query Only)**

Returns the delta marker amplitude for the selected marker in the AM/FM/PM measurement.

The parameter <x> = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

<b>Conditions</b>	Measurement views: General purpose analog demodulation
<b>Group</b>	Calculate commands
<b>Syntax</b>	<code>CALCulate:{AM FM PM}:MARKer&lt;x&gt;:DELTA:Y?</code>
<b>Related Commands</b>	<a href="#">CALCulate:{AM FM PM}:MARKer&lt;x&gt;:DELTA:X?</a>
<b>Arguments</b>	None
<b>Returns</b>	<Nrf> Delta marker amplitude for the selected marker, indicating the difference of modulation factor in percent (AM), frequency deviation in Hz (FM), or phase deviation in degrees (PM) with the reference marker.

**Examples** `CALCULATE:AM:MARKER1:DELTA:Y?` might return `45.82`, indicating that the delta marker amplitude is the modulation factor difference of 45.82% in the AM measurement.

## **CALCulate:{AM|FM|PM}:MARKer<x>:MAXimum (No Query Form)**

Moves the selected marker to the highest peak on the trace in the AM/FM/PM measurement.

**Conditions** Measurement views: General purpose analog demodulation

**Group** Calculate commands

**Syntax** `CALCulate:{AM|FM|PM}:MARKer<x>:MAXimum`

**Arguments** None

**Examples** `CALCULATE:AM:MARKER1:MAXIMUM` moves Marker 1 (M1) to the highest peak on the AM-demodulated trace.

## **CALCulate:{AM|FM|PM}:MARKer<x>:PEAK:HIGHer (No Query Form)**

Moves the selected marker to the next peak higher in amplitude on the trace in the AM/FM/PM measurement.

**Conditions** Measurement views: General purpose analog demodulation

**Group** Calculate commands

**Syntax** `CALCulate:{AM|FM|PM}:MARKer<x>:PEAK:HIGHer`

**Related Commands** [CALCulate:{AM|FM|PM}:MARKer<x>:PEAK:LOWer](#)

**Arguments** None

**Examples** `CALCULATE:AM:MARKER1:PEAK:HIGHER` moves Marker 1 (M1) to the next peak higher in amplitude on the AM-demodulated trace.

## CALCulate:{AM|FM|PM}:MARKer<x>:PEAK:LEFT (No Query Form)

Moves the selected marker to the next peak to the left on the trace in the AM/FM/PM measurement.

<b>Conditions</b>	Measurement views: General purpose analog demodulation
<b>Group</b>	Calculate commands
<b>Syntax</b>	CALCulate:{AM FM PM}:MARKer<x>:PEAK:LEFT
<b>Related Commands</b>	<a href="#">CALCulate:{AM FM PM}:MARKer&lt;x&gt;:PEAK:RIGHT</a>
<b>Arguments</b>	None
<b>Examples</b>	CALCULATE:AM:MARKER1:PEAK:LEFT moves Marker 1 (M1) to the next peak to the left on the AM-demodulated trace.

## CALCulate:{AM|FM|PM}:MARKer<x>:PEAK:LOWER (No Query Form)

Moves the selected marker to the next peak lower in amplitude on the trace in the AM/FM/PM measurement.

<b>Conditions</b>	Measurement views: General purpose analog demodulation
<b>Group</b>	Calculate commands
<b>Syntax</b>	CALCulate:{AM FM PM}:MARKer<x>:PEAK:LOWER
<b>Related Commands</b>	<a href="#">CALCulate:{AM FM PM}:MARKer&lt;x&gt;:PEAK:HIGHER</a>
<b>Arguments</b>	None
<b>Examples</b>	CALCULATE:AM:MARKER1:PEAK:LOWER moves Marker 1 (M1) to the next peak lower in amplitude on the AM-demodulated trace.

## CALCulate:{AM|FM|PM}:MARKer<x>:PEAK:RIGHT (No Query Form)

Moves the selected marker to the next peak to the right on the trace in the AM/FM/PM measurement.

**Conditions** Measurement views: General purpose analog demodulation

**Group** Calculate commands

**Syntax** CALCulate:{AM|FM|PM}:MARKer<x>:PEAK:RIGHT

**Related Commands** [CALCulate:{AM|FM|PM}:MARKer<x>:PEAK:LEFT](#)

**Arguments** None

**Examples** CALCULATE:AM:MARKER1:PEAK:RIGHT moves Marker 1 (M1) to the next peak to the right on the AM-demodulated trace.

## CALCulate:{AM|FM|PM}:MARKer<x>:X

Sets or queries the horizontal position (time) of the selected marker in the AM/FM/PM measurement.

**Conditions** Measurement views: General purpose analog demodulation

**Group** Calculate commands

**Syntax** CALCulate:{AM|FM|PM}:MARKer<x>:X <value>  
CALCulate:{AM|FM|PM}:MARKer<x>:X?

**Related Commands** [CALCulate:{AM|FM|PM}:MARKer<x>:Y?](#)

**Arguments** <value> ::= <NRf> specifies the horizontal position of the marker.  
Range: (analysis offset) to [(analysis offset) + (analysis length)].

**Examples** CALCULATE:AM:MARKER1:X 1.5us places Marker 1 (M1) at 1.5  $\mu$ s on the AM-demodulated trace.

## CALCulate:{AM|FM|PM}:MARKer<x>:Y? (Query Only)

Queries the marker amplitude of the selected marker in the AM/FM/PM measurement.

<b>Conditions</b>	Measurement views: General purpose analog demodulation
<b>Group</b>	Calculate commands
<b>Syntax</b>	CALCulate:{AM FM PM}:MARKer<x>:Y?
<b>Related Commands</b>	<a href="#">CALCulate:{AM FM PM}:MARKer&lt;x&gt;:X</a>
<b>Arguments</b>	None
<b>Returns</b>	<NRF> Marker amplitude of the selected marker, indicating the modulation factor in percent (AM), frequency deviation in Hz (FM), or phase deviation in degrees (PM) at the marker.
<b>Examples</b>	CALCULATE:AM:MARKER1:Y? might return 23.4, indicating that Marker 1 (M1) reads the modulation factor of 23.4% in the AM measurement.

## CALCulate:AVTime:MARKer<x>:DELTA:X? (Query Only)

Returns the delta marker time for the selected marker in the Amplitude versus Time measurement.

The parameter <x> = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

<b>Conditions</b>	Measurement views: Amplitude versus Time
<b>Group</b>	Calculate commands
<b>Syntax</b>	CALCulate:AVTime:MARKer<x>:DELTA:X?
<b>Related Commands</b>	<a href="#">CALCulate:MARKer:ADD</a> , <a href="#">CALCulate:AVTime:MARKer&lt;x&gt;:DELTA:Y?</a>

**Returns** <Nrf> Delta marker time for the selected marker.

**Examples** CALCULATE:AVTIME:MARKER1:DELTA:X? might return 38.0E-9, indicating that the delta marker time is 38.0 ns.

## CALCulate:AVTime:MARKer<x>:DELTA:Y? (Query Only)

Returns the delta marker amplitude for the selected marker in the Amplitude versus Time measurement.

The parameter <x> = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

**Conditions** Measurement views: Amplitude versus Time

**Group** Calculate commands

**Syntax** CALCulate:AVTime:MARKer<x>:DELTA:Y?

**Related Commands** [CALCulate:MARKer:ADD](#), [CALCulate:AVTime:MARKer<x>:DELTA:X?](#)

**Returns** <Nrf> Delta marker amplitude for the selected marker.

**Examples** CALCULATE:AVTIME:MARKER1:DELTA:Y? might return 23.45, indicating that the delta marker amplitude is 23.45 dB.

## CALCulate:AVTime:MARKer<x>:MAXimum (No Query Form)

Moves the selected marker to the highest peak on the trace in the Amplitude versus Time measurement.

**Conditions** Measurement views: Amplitude versus Time

**Group** Calculate commands

**Syntax** CALCulate:AVTime:MARKer<x>:MAXimum

**Arguments** None

**Examples** CALCULATE:AVTIME:MARKER1:MAXIMUM moves Marker 1 (M1) to the highest peak on the trace.

## CALCulate:AVTime:MARKer<x>:PEAK:HIGHer (No Query Form)

Moves the selected marker to the next peak higher in amplitude on the Amplitude versus Time trace.

**Conditions** Measurement views: Amplitude versus Time

**Group** Calculate commands

**Syntax** CALCulate:AVTime:MARKer<x>:PEAK:HIGHer

**Related Commands** [CALCulate:AVTime:MARKer<x>:PEAK:LOWer](#)

**Arguments** None

**Examples** CALCULATE:AVTIME:MARKER1:PEAK:HIGHER moves Marker 1 (M1) to the next peak higher in amplitude on the trace.

## CALCulate:AVTime:MARKer<x>:PEAK:LEFT (No Query Form)

Moves the selected marker to the next peak to the left on the trace in the Amplitude versus Time measurement.

**Conditions** Measurement views: Amplitude versus Time

**Group** Calculate commands

**Syntax** CALCulate:AVTime:MARKer<x>:PEAK:LEFT

**Related Commands** [CALCulate:AVTime:MARKer<x>:PEAK:RIGHT](#)



**Arguments** None

**Examples** `CALCulate:AVTime:MARKer1:PEAK:LEFT` moves Marker 1 (M1) to the next peak to the left on the trace.

## **CALCulate:AVTime:MARKer<x>:PEAK:LOWer (No Query Form)**

Moves the selected marker to the next peak lower in amplitude on the Amplitude versus Time trace.

**Conditions** Measurement views: Amplitude versus Time

**Group** Calculate commands

**Syntax** `CALCulate:AVTime:MARKer<x>:PEAK:LOWer`

**Related Commands** [CALCulate:AVTime:MARKer<x>:PEAK:HIGHer](#)

**Arguments** None

**Examples** `CALCULATE:AVTIME:MARKER1:PEAK:LOWER` moves Marker 1 (M1) to the next peak lower in amplitude on the trace.

## **CALCulate:AVTime:MARKer<x>:PEAK:RIGHt (No Query Form)**

Moves the selected marker to the next peak to the right on the trace in the Amplitude versus Time measurement.

**Conditions** Measurement views: Amplitude versus Time

**Group** Calculate commands

**Syntax** `CALCulate:AVTime:MARKer<x>:PEAK:RIGHt`

**Related Commands** [CALCulate:AVTime:MARKer<x>:PEAK:LEFT](#)

**Arguments** None

**Examples** CALCULATE:AVTIME:MARKER1:PEAK:RIGHT moves Marker 1 (M1) to the next peak to the right on the trace.

## CALCulate:AVTime:MARKer<x>:TRACe

Selects or queries the trace on which the specified marker is placed in the Amplitude versus Time measurement.

**Conditions** Measurement views: Amplitude versus Time

**Group** Calculate commands

**Syntax** CALCulate:AVTime:MARKer<x>:TRACe { TRACE1 | TRACE2 | TRACE3 | TRACE4 }  
CALCulate:AVTime:MARKer<x>:TRACe?

**Arguments** TRACE1 places the selected marker on Trace 1.  
TRACE2 places the selected marker on Trace 2.  
TRACE3 places the selected marker on Trace 3.  
TRACE4 places the selected marker on Trace 4 (math trace).

**Examples** CALCULATE:AVTIME:MARKER1:TRACE TRACE1 places Marker 1 (M1) on Trace 1.

## CALCulate:AVTime:MARKer<x>:X

Sets or queries the horizontal position of the selected marker in the Amplitude versus Time measurement.

The parameter <x> = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

**Conditions** Measurement views: Amplitude versus Time

**Group** Calculate commands

**Syntax**      `CALCulate:AVTime:MARKer<x>:X <value>`  
`CALCulate:AVTime:MARKer<x>:X?`

**Related Commands**      [CALCulate:AVTime:MARKer<x>:Y?](#)

**Arguments**      `<value> ::= <NRf>` specifies the horizontal position of the marker.  
 Range: (analysis offset) to [(analysis offset) + (analysis length)].

**Examples**      `CALCULATE:AVTIME:MARKER1:X 1.5U` places Marker 1 (M1) at 1.5  $\mu$ s on the trace.

## CALCulate:AVTime:MARKer<x>:Y? (Query Only)

Queries the marker amplitude of the selected marker in the Amplitude versus Time measurement.

The parameter `<x>` = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

**Conditions**      Measurement views: Amplitude versus Time

**Group**      Calculate commands

**Syntax**      `CALCulate:AVTime:MARKer<x>:Y?`

**Related Commands**      [CALCulate:AVTime:MARKer<x>:X](#)

**Arguments**      None

**Returns**      `<NRf>` Marker amplitude of the selected marker.

**Examples**      `CALCULATE:AVTIME:MARKER1:Y?` might return `-2.73`, indicating Marker 1 (M1) is at -2.73 dBm.

## CALCulate:CONSte:MARKer<x>:DELTA:X[:TIME]? (Query Only)

Returns the delta marker time for the selected marker on the constellation trace.

The parameter <x> = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

<b>Conditions</b>	Measurement views: Constellation
<b>Group</b>	Calculate commands
<b>Syntax</b>	CALCulate:CONStE:MARKer<x>:DELTA:X[:TIME]?
<b>Returns</b>	<NRF> Delta marker time for the selected marker. The unit can be changed by the <a href="#">[SENSe]:DDEMod:TIME:UNITs</a> command.
<b>Examples</b>	CALCULATE:CONSTE:MARKER1:DELTA:X:TIME? might return -62.75, indicating that the delta marker time is -62.75 symbols.

## CALCulate:CONStE:MARKer<x>:FDEVIation? (Query Only)

Queries the frequency deviation of the selected marker in the constellation measurement for an FSK modulated signal.

The parameter <x> = 0 to 4. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

<b>Conditions</b>	The command is valid for 2, 4, 8, 16 FSK or C4FM modulated signals.
<b>Group</b>	Calculate commands
<b>Syntax</b>	CALCulate:CONStE:MARKer<x>:FDEVIation?
<b>Related Commands</b>	<a href="#">CALCulate:CONStE:MARKer&lt;x&gt;:MAGNitude?</a> <a href="#">CALCulate:CONStE:MARKer&lt;x&gt;:PHASe?</a>
<b>Arguments</b>	None
<b>Returns</b>	<NRF>The frequency deviation readout for the selected marker.

**Examples**    `CALCulate:CONStE:MARKer1:FDEVIation?` might return `102.824E+3`, indicating the frequency deviation readout of Marker 1 (M1) is 102.824kHz.

## `CALCulate:CONStE:MARKer<x>:MAGNitude?` (Query Only)

Queries the magnitude readout of the selected marker in the constellation measurement.

The parameter `<x>` = 1 to 4; `MARKer0` (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

**Conditions**    Measurement views: Constellation

**Group**    Calculate commands

**Syntax**    `CALCulate:CONStE:MARKer<x>:MAGNitude?`

**Related Commands**    [CALCulate:CONStE:MARKer<x>:X](#)

**Arguments**    None

**Returns**    `<NRf>` The magnitude readout for the selected marker.

**Examples**    `CALCulate:CONStE:MARKer1:MAGNitude?` might return `0.713927`, indicating the magnitude readout of Marker 1 (M1) is 0.713927.

## `CALCulate:CONStE:MARKer<x>:MAXimum` (No Query Form)

Positions the selected marker at the symbol in the center of the time record.

The parameter `<x>` = 1 to 4; `MARKer0` (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

**Conditions**    Measurement views: Constellation

**Group**    Calculate commands

**Syntax**     `CALCulate:CONStE:MARKer<x>:MAXimum`

**Arguments**     None

**Examples**     `CALCulate:CONStE:MARKer1:MAXimum` positions Marker 1 (M1) at the symbol in the center of the time record.

## **CALCulate:CONStE:MARKer<x>:PEAK:LEFT (No Query Form)**

Moves the selected marker in the time domain to the next lower symbol number, relative to the previous marker position.

The parameter <x> = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

**Conditions**     Measurement views: Constellation

**Group**     Calculate commands

**Syntax**     `CALCulate:CONStE:MARKer<x>:PEAK:LEFT`

**Related Commands**     [CALCulate:CONStE:MARKer<x>:PEAK:RIGHT](#)

**Arguments**     None

**Examples**     `CALCulate:CONStE:MARKer1:PEAK:LEFT` moves Marker 1 (M1) in the time domain to the next lower symbol number.

## **CALCulate:CONStE:MARKer<x>:PEAK:RIGHT (No Query Form)**

Moves the selected marker in the time domain to the next higher symbol number, relative to the previous marker position.

The parameter <x> = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

**Conditions**     Measurement views: Constellation

<b>Group</b>	Calculate commands
<b>Syntax</b>	<code>CALCulate:CONStE:MARKer&lt;x&gt;:PEAK:RIGHT</code>
<b>Related Commands</b>	<a href="#">CALCulate:CONStE:MARKer&lt;x&gt;:PEAK:LEFT</a>
<b>Arguments</b>	None
<b>Examples</b>	<code>CALCulate:CONStE:MARKer1:PEAK:RIGHT</code> moves the Marker 1 (M1) in the time domain to the next higher symbol number.

## CALCulate:CONStE:MARKer<x>:PHASe? (Query Only)

Queries the phase readout of the selected marker in the constellation measurement.

The parameter <x> = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

<b>Conditions</b>	Measurement views: Constellation
<b>Group</b>	Calculate commands
<b>Syntax</b>	<code>CALCulate:CONStE:MARKer&lt;x&gt;:PHASe?</code>
<b>Related Commands</b>	<a href="#">CALCulate:CONStE:MARKer&lt;x&gt;:X</a>
<b>Arguments</b>	None
<b>Returns</b>	<NRF> The phase readout for the selected marker.
<b>Examples</b>	<code>CALCulate:CONStE:MARKer1:PHASe</code> might return 35.74, indicating the phase readout of Marker 1 (M1) is 35.74 °.

## CALCulate:CONSte:MARKer<x>:SYMBol? (Query Only)

Queries the symbol readout of the selected marker in the constellation measurement.

The parameter <x> = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

<b>Conditions</b>	Measurement views: Constellation
<b>Group</b>	Calculate commands
<b>Syntax</b>	CALCulate:CONSte:MARKer<x>:SYMBol?
<b>Related Commands</b>	<a href="#">CALCulate:CONSte:MARKer&lt;x&gt;:X</a>
<b>Arguments</b>	None
<b>Returns</b>	<NRF> The symbol readout for the selected marker.
<b>Examples</b>	CALCULATE:CONSTE:MARKER1:SYMBOL? might return 62.00, indicating the symbol readout of Marker 1 (M1) is 62.

## CALCulate:CONSte:MARKer<x>:VALue? (Query Only)

Queries the value readout of the selected marker in the constellation measurement.

The parameter <x> = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

<b>Conditions</b>	Measurement views: Constellation
<b>Group</b>	Calculate commands
<b>Syntax</b>	CALCulate:CONSte:MARKer<x>:VALue?
<b>Related Commands</b>	<a href="#">CALCulate:CONSte:MARKer&lt;x&gt;:X</a>



<b>Arguments</b>	None
<b>Returns</b>	<NRf> The value readout for the selected marker.
<b>Examples</b>	CALCULATE:CONSTE:MARKER1:VALUE? might return 2.00, indicating the value readout of Marker 1 (M1) is 2.

## CALCulate:CONStE:MARKer<x>:X

Sets or queries the time position of the selected marker on the constellation trace.

The parameter <x> = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

<b>Conditions</b>	Measurement views: Constellation
<b>Group</b>	Calculate commands
<b>Syntax</b>	CALCulate:CONStE:MARKer<x>:X <value> CALCulate:CONStE:MARKer<x>:X?
<b>Related Commands</b>	<a href="#">CALCulate:CONStE:MARKer&lt;x&gt;:MAGNitude?</a> , <a href="#">CALCulate:CONStE:MARKer&lt;x&gt;:PHASe?</a> , <a href="#">CALCulate:CONStE:MARKer&lt;x&gt;:SYMBol?</a>
<b>Arguments</b>	<value> ::= <NRf> specifies the time position of the marker. Range: (analysis offset) to [(analysis offset) + (analysis length)].
<b>Examples</b>	CALCULATE:CONSTE:MARKER1:X -1.63875m places the Marker 1 (M1) at -1.63875 ms on the constellation trace.

## CALCulate:DIQVtime:MARKer<x>:DELTA:X[:TIME]? (Query Only)

Returns the delta marker time for the selected marker on the Demodulated I&Q versus Time trace.

The parameter <x> = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

<b>Conditions</b>	Measurement views: Demodulated I&Q versus Time
<b>Group</b>	Calculate commands
<b>Syntax</b>	<code>CALCulate:DIQVtime:MARKer&lt;x&gt;:DELTA:X[:TIME]?</code>
<b>Related Commands</b>	<a href="#">CALCulate:DIQVtime:MARKer&lt;x&gt;:DELTA:Y?</a>
<b>Arguments</b>	None
<b>Returns</b>	<NRF> Delta marker time for the selected marker. Use the <a href="#">[SENSe]:DDEMod:TIME:UNITs</a> command to select the time unit: symbols (default) or seconds.
<b>Examples</b>	<code>CALCULATE:DIQVTIME:MARKER1:DELTA:X:TIME?</code> might return 62.75, indicating that the delta marker time is 62.75 symbols.

## **CALCulate:DIQVtime:MARKer<x>:DELTA:Y? (Query Only)**

Returns the delta marker amplitude for the selected marker on the Demodulated I&Q versus Time trace.

The parameter <x> = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

<b>Conditions</b>	Measurement views: Demodulated I&Q versus Time
<b>Group</b>	Calculate commands
<b>Syntax</b>	<code>CALCulate:DIQVtime:MARKer&lt;x&gt;:DELTA:Y?</code>
<b>Related Commands</b>	<a href="#">CALCulate:DIQVtime:MARKer&lt;x&gt;:DELTA:X[:TIME]?</a>
<b>Arguments</b>	None
<b>Returns</b>	<NRF> Delta marker amplitude for the selected marker in volts.

**Examples**     `CALCULATE:DIQVTIME:MARKER1:DELTA:Y?` might return `-78.24E-3`, indicating that the delta marker amplitude is -78.24 mV.

## **CALCulate:DIQVtime:MARKer<x>:MAXimum (No Query Form)**

Moves the selected marker to the highest peak on the Demodulated I&Q versus Time trace.

The parameter `<x>` = 0 to 4. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

**Conditions**     Measurement views: Demodulated I&Q versus Time

**Group**     Calculate commands

**Syntax**     `CALCulate:DIQVtime:MARKer<x>:MAXimum`

**Arguments**     None

**Examples**     `CALCULATE:DIQVTIME:MARKER1:MAXIMUM` moves Marker 1 (M1) to the highest peak on the trace.

## **CALCulate:DIQVtime:MARKer<x>:PEAK:HIGHer (No Query Form)**

Moves the selected marker to the next peak higher in amplitude on the Demodulated I&Q versus Time trace.

The parameter `<x>` = 0 to 4. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

**Conditions**     Measurement views: Demodulated I&Q versus Time

**Group**     Calculate commands

**Syntax**     `CALCulate:DIQVtime:MARKer<x>:PEAK:HIGHer`

**Related Commands**     [CALCulate:DIQVtime:MARKer<x>:PEAK:LOWer](#)

**Arguments**     None

**Examples**     `CALCULATE:DIQVTIME:MARKER1:PEAK:HIGHER` moves Marker 1 (M1) to the next peak higher in amplitude on the trace.

## **CALCulate:DIQVtime:MARKer<x>:PEAK:LEFT (No Query Form)**

Moves the selected marker to the next peak to the left on the Demodulated I&Q versus Time trace.

The parameter <x> = 0 to 4. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

**Conditions**     Measurement views: Demodulated I&Q versus Time

**Group**            Calculate commands

**Syntax**          `CALCulate:DIQVtime:MARKer<x>:PEAK:LEFT`

**Related Commands**     [CALCulate:DIQVtime:MARKer<x>:PEAK:RIGHT](#)

**Arguments**        None

**Examples**        `CALCULATE:DIQVTIME:MARKER1:PEAK:LEFT` moves Marker 1 (M1) to the next peak to the left on the trace.

## **CALCulate:DIQVtime:MARKer<x>:PEAK:LOWer (No Query Form)**

Moves the selected marker to the next peak lower in amplitude on the Demodulated I&Q versus Time trace.

The parameter <x> = 0 to 4. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

**Conditions**        Measurement views: Demodulated I&Q versus Time

**Group**            Calculate commands

**Syntax**          `CALCulate:DIQVtime:MARKer<x>:PEAK:LOWer`

**Related Commands**     [CALCulate:DIQVtime:MARKer<x>:PEAK:HIGHer](#)

**Arguments** None

**Examples** `CALCULATE:DIQVTIME:MARKER1:PEAK:LOWER` moves Marker 1 (M1) to the next peak lower in amplitude on the trace.

## **CALCulate:DIQVtime:MARKer<x>:PEAK:RIGHT (No Query Form)**

Moves the selected marker to the next peak to the right on the Demodulated I&Q versus Time trace.

The parameter `<x>` = 0 to 4. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

**Conditions** Measurement views: Demodulated I&Q versus Time

**Group** Calculate commands

**Syntax** `CALCulate:DIQVtime:MARKer<x>:PEAK:RIGHT`

**Related Commands** [CALCulate:DIQVtime:MARKer<x>:PEAK:LEFT](#)

**Arguments** None

**Examples** `CALCULATE:DIQVTIME:MARKER1:PEAK:RIGHT` moves Marker 1 (M1) to the next peak to the right on the trace.

## **CALCulate:DIQVtime:MARKer<x>:TRACe**

Places the selected marker on the Demodulated I&Q versus Time trace. The query returns the name of the trace on which the marker resides.

The parameter `<x>` = 0 to 4. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

**Conditions** Measurement views: Demodulated I&Q versus Time

**Group** Calculate commands

**Syntax**      CALCulate:DIQVtime:MARKer<x>:TRACe <Enum>  
 CALCulate:DIQVtime:MARKer<x>:TRACe?

**Related Commands**    [CALCulate:IQVTime:MARKer<x>:TRACe](#)

**Arguments**      <Enum> ::= TRACE1 | TRACE2 specifies which trace to place the marker on. TRACE1 specifies the “I” trace and TRACE2 specifies the “Q” trace.

**Returns**          For I and Q traces, TRACE1 identifies the “I” trace and TRACE2 identifies the “Q” trace.

**Examples**        CALCulate:DIQVtime:MARKer1:TRACe TRACE1 places Marker 1 (M1) on the I trace.

## CALCulate:DIQVtime:MARKer<x>:X[:TIME]

Sets or queries the horizontal position (time) of the selected marker in the Demodulated I&Q versus Time measurement.

The parameter <x> = 0 to 4. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

**Conditions**      Measurement views: Demodulated I&Q versus Time

**Group**            Calculate commands

**Syntax**          CALCulate:DIQVtime:MARKer<x>:X[:TIME] <value>  
 CALCulate:DIQVtime:MARKer<x>:X[:TIME]?

**Related Commands**    [CALCulate:DIQVtime:MARKer<x>:Y?](#)

**Arguments**      <value> ::= <NRf> specifies the horizontal position (time) of the marker. Use the [\[SENSe\]:DDEMod:TIME:UNITs](#) command to select the time unit: symbols (default) or seconds.

**Examples**        CALCULATE:DIQVTIME:MARKER1:X:TIME 38.5 places Marker 1 (M1) at 38.5 symbols on the trace.

## CALCulate:DIQVtime:MARKer<x>:Y? (Query Only)

Queries the marker amplitude of the selected marker in the Demod I&Q versus Time measurement.

The parameter <x> = 0 to 4. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

**Conditions** Measurement views: Demodulated I&Q versus Time

**Group** Calculate commands

**Syntax** CALCulate:DIQVtime:MARKer<x>:Y?

**Related Commands** [CALCulate:DIQVtime:MARKer<x>:X\[:TIME\]](#)

**Arguments** None

**Returns** <NRf> Marker amplitude of the selected marker in volts.

**Examples** CALCulate:DIQVtime:MARKer1:Y? might return 25.803E-3, indicating Marker 1 (M1) is at 25.803 mV.

## CALCulate:DPSA:MARKer<x>:DELTA:X:AMPLitude? (Query Only)

Returns the delta marker amplitude for the selected marker on the DPX spectrum trace.

The parameter <x> = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command and attached to the Bitmap trace using the [CALCulate:DPSA:MARKer<x>:TRACe](#) command.

**Conditions** Measurement views: DPX spectrum DPX spectrum

**Group** Calculate commands

**Syntax** CALCulate:DPSA:MARKer<x>:DELTA:X:AMPLitude?

**Related Commands**    [CALCulate:DPSA:MARKer<x>:X\[:FREQuency\]](#), [CALCulate:DPSA:MARKer<x>:Y?](#)

**Arguments**    None

**Returns**    <NRF> Delta marker amplitude for the selected marker in dB.

**Examples**    `CALCULATE:DPSA:MARKER1:DELTA:X:AMPLITUDE?` might return `35.12`, indicating that the delta marker amplitude is 35.12 dB for Marker 1 (M1).

## **CALCulate:DPSA:MARKer<x>:DELTA:X[:FREQuency]? (Query Only)**

Returns the delta marker frequency for the selected marker on the DPX spectrum trace.

The parameter <x> = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

**Conditions**    Measurement views: DPX spectrum

**Group**    Calculate commands

**Syntax**    `CALCulate:DPSA:MARKer<x>:DELTA:X[:FREQuency]?`

**Related Commands**    [CALCulate:DPSA:MARKer<x>:DELTA:X:AMPLitude?](#), [CALCulate:DPSA:MARKer<x>:DELTA:Y?](#)

**Arguments**    None

**Returns**    <NRF> Delta marker frequency for the selected marker in Hz.

**Examples**    `CALCULATE:DPSA:MARKER1:DELTA:X?` might return `1.28E+6`, indicating that the delta marker frequency is 1.28 MHz for Marker 1 (M1).



## CALCulate:DPSA:MARKer<x>:DELTA:Y? (Query Only)

Returns the delta marker amplitude for the selected marker on the DPX spectrum trace.

The parameter <x> = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

**Conditions** Measurement views: DPX spectrum

**Group** Calculate commands

**Syntax** CALCulate:DPSA:MARKer<x>:DELTA:Y?

**Related Commands** [CALCulate:DPSA:MARKer<x>:DELTA:X\[:FREQUENCY\]?](#)

**Arguments** None

**Returns** <NRf> Delta marker amplitude for the selected marker.

**Examples** CALCULATE:DPSA:MARKER1:DELTA:Y? might return 23.45, indicating that the delta marker amplitude is 23.45 dB.

## CALCulate:DPSA:MARKer<x>:MAXimum (No Query Form)

Moves the selected marker to the highest peak on the DPX spectrum trace.

The parameter <x> = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

**Conditions** Measurement views: DPX spectrum

**Group** Calculate commands

**Syntax** CALCulate:DPSA:MARKer<x>:MAXimum

**Arguments** None

**Examples**     `CALCULATE:DPSA:MARKER1:MAXIMUM` moves Marker 1 (M1) to the highest peak on the trace.

## **CALCulate:DPSA:MARKer<x>:PEAK:HIGHer (No Query Form)**

Moves the selected marker to the next peak higher in amplitude on the DPX spectrum trace.

The parameter <x> = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

**Conditions**     Measurement views: DPX spectrum

**Group**     Calculate commands

**Syntax**     `CALCuLate:DPSA:MARKer<x>:PEAK:HIGHer`

**Related Commands**     [CALCulate:DPSA:MARKer<x>:PEAK:LOWer](#)

**Arguments**     None

**Examples**     `CALCULATE:DPSA:MARKER1:PEAK:HIGHER` moves Marker 1 (M1) to the next peak higher in amplitude on the trace.

## **CALCulate:DPSA:MARKer<x>:PEAK:LEFT (No Query Form)**

Moves the selected marker to the next peak to the left on the DPX spectrum trace.

The parameter <x> = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

**Conditions**     Measurement views: DPX spectrum

**Group**     Calculate commands

**Syntax**     `CALCuLate:DPSA:MARKer<x>:PEAK:LEFT`

**Related Commands**    [CALCulate:DPSA:MARKer<x>:PEAK:RIGHT](#)

**Arguments**    None

**Examples**    CALCULATE:DPSA:MARKER1:PEAK:LEFT moves Marker 1 (M1) to the next peak to the left on the trace.

## CALCulate:DPSA:MARKer<x>:PEAK:LOWer (No Query Form)

Moves the selected marker to the next peak lower in amplitude on the DPX spectrum trace.

The parameter <x> = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

**Conditions**    Measurement views: DPX spectrum

**Group**    Calculate commands

**Syntax**    CALCulate:DPSA:MARKer<x>:PEAK:LOWer

**Related Commands**    [CALCulate:DPSA:MARKer<x>:PEAK:HIGHer](#)

**Arguments**    None

**Examples**    CALCULATE:DPSA:MARKER1:PEAK:LOWER moves Marker 1 (M1) to the next peak lower in amplitude on the trace.

## CALCulate:DPSA:MARKer<x>:PEAK:RIGHT (No Query Form)

Moves the selected marker to the next peak to the right on the DPX spectrum trace.

The parameter <x> = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

**Conditions**    Measurement views: DPX spectrum

<b>Group</b>	Calculate commands
<b>Syntax</b>	<code>CALCulate:DPSA:MARKer&lt;x&gt;:PEAK:RIGHT</code>
<b>Related Commands</b>	<a href="#">CALCulate:DPSA:MARKer&lt;x&gt;:PEAK:LEFT</a>
<b>Arguments</b>	None
<b>Examples</b>	<code>CALCULATE:DPSA:MARKER1:PEAK:RIGHT</code> moves Marker 1 (M1) to the next peak to the right on the trace.

### **CALCulate:DPSA:MARKer<x>[:SET]:CENTER (No Query Form)**

Sets the center frequency to the marker frequency in the DPX spectrum view.

The parameter <x> = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

<b>Conditions</b>	Measurement views: DPX spectrum
<b>Group</b>	Calculate commands
<b>Syntax</b>	<code>CALCulate:DPSA:MARKer&lt;x&gt;[:SET]:CENTER</code>
<b>Arguments</b>	None
<b>Examples</b>	<code>CALCULATE:DPSA:MARKER1:SET:CENTER</code> sets the center frequency to the marker frequency in the DPX spectrum view.

### **CALCulate:DPSA:MARKer<x>:TRACe**

Selects or queries the trace to attach the specified marker to in the DPX spectrum measurement.

The parameter <x> = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

<b>Conditions</b>	Measurement views: DPX spectrum
<b>Group</b>	Calculate commands
<b>Syntax</b>	<code>CALCulate:DPSA:MARKer&lt;x&gt;:TRACe { BITMAP   TRACE1   TRACE2   TRACE3   TRACE4 }</code> <code>CALCulate:DPSA:MARKer&lt;x&gt;:TRACe?</code>
<b>Arguments</b>	<p>BITMAP attaches the specified marker to the Bitmap trace.</p> <p>TRACE1 attaches the specified marker to the +Peak trace.</p> <p>TRACE2 attaches the specified marker to the -Peak trace.</p> <p>TRACE3 attaches the specified marker to the Average trace.</p> <p>TRACE4 attaches the specified marker to the Math trace.</p>
<b>Examples</b>	<code>CALCULATE:DPSA:MARKER1:TRACE TRACE1</code> attaches Marker 1 (M1) to the +Peak trace.

## CALCulate:DPSA:MARKer<x>:X:AMPLitude

Sets or queries the amplitude position of the selected marker in the DPX spectrum view. This command is valid for the marker on the bitmap trace (refer to the [CALCulate:DPSA:MARKer<x>:TRACe](#) command). The frequency position is set by the [CALCulate:DPSA:MARKer<x>:X:FREQuency](#) command.

The parameter <x> = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

<b>Conditions</b>	Measurement views: DPX spectrum
<b>Group</b>	Calculate commands
<b>Syntax</b>	<code>CALCulate:DPSA:MARKer&lt;x&gt;:X:AMPLitude &lt;value&gt;</code> <code>CALCulate:DPSA:MARKer&lt;x&gt;:X:AMPLitude</code>
<b>Arguments</b>	<code>&lt;value&gt; ::= &lt;NRf&gt;</code> specifies the amplitude position of the marker. Range: -100 to 0 dBm.

**Examples**     `CALCULATE:DPSA:MARKER1:X:AMPLITUDE -34.5dBm` places Marker 1 (M1) at -34.5 dBm.

## CALCulate:DPSA:MARKer<x>:X[:FREQUENCY]

Sets or queries the frequency position of the selected marker in the DPX spectrum view.

The parameter <x> = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

**Conditions**     Measurement views: DPX spectrum

**Group**            Calculate commands

**Syntax**           `CALCulate:DPSA:MARKer<x>:X[:FREQUENCY] <value>`  
`CALCulate:DPSA:MARKer<x>:X[:FREQUENCY]?`

**Related Commands**     [CALCulate:DPSA:MARKer<x>:Y?](#)

**Arguments**        `<value>::=<nrf>` specifies the frequency position of the marker.  
Range: Start to Stop frequency (left to right edge of the horizontal axis).  
Using an out-of-range value causes an execution error (-222, "Data out of range").

**Examples**         `CALCULATE:DPSA:MARKER1:X:FREQUENCY 800MHZ` places Marker 1 (M1) at 800 MHz on the trace.

## CALCulate:DPSA:MARKer<x>:Y? (Query Only)

Queries the vertical position of the selected marker in the DPX spectrum view. The data occurrence rate is returned for the bitmap trace, and the amplitude value for the +peak, -peak, average, and math traces. The horizontal position can be set by the [CALCulate:DPSA:MARKer<x>:X:AMPLitude](#) and [CALCulate:DPSA:MARKer<x>:X\[:FREQUENCY\]](#) commands.

The parameter <x> = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

**Conditions**        Measurement views: DPX spectrum

<b>Group</b>	Calculate commands
<b>Syntax</b>	<code>CALCulate:DPSA:MARKer&lt;x&gt;:Y?</code>
<b>Arguments</b>	None
<b>Returns</b>	<p>&lt;Nrf&gt;The value type depends on which trace the marker is placed on (refer to the <a href="#">CALCulate:DPSA:MARKer&lt;x&gt;:TRACe</a> command):</p> <p>The amplitude value is returned in dBm for the marker on the +peak, -peak, average, or math trace. The data occurrence rate is returned in percent (%) for the marker on the bitmap trace.</p>
<b>Examples</b>	<p><code>CALCULATE:DPSA:MARKER1:Y?</code> might return <code>-34.28</code> indicating Marker 1 (M1) is at <code>-34.28</code> dBm when it is placed on the +peak, -peak, average, or math trace.</p> <p><code>CALCULATE:DPSA:MARKER1:Y?</code> might return <code>76.5</code> indicating Marker 1 (M1) is at <code>76.5%</code> when it is placed on the bitmap trace.</p>

## **CALCulate:EDIagram:MARKer<x>:DELTA:X[:TIME]? (Query Only)**

Returns the delta marker time for the selected marker on the eye diagram trace.

The parameter <x> = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

<b>Conditions</b>	Measurement views: Eye diagram
<b>Group</b>	Calculate commands
<b>Syntax</b>	<code>CALCulate:EDIagram:MARKer&lt;x&gt;:DELTA:X[:TIME]?</code>
<b>Related Commands</b>	<a href="#">CALCulate:EDIagram:MARKer&lt;x&gt;:DELTA:Y?</a>
<b>Arguments</b>	None
<b>Returns</b>	<p>&lt;Nrf&gt; Delta marker time for the selected marker.</p> <p>Use the <a href="#">[SENSe]:DDEMod:TIME:UNITs</a> command to select the time unit: symbols (default) or seconds.</p>

**Examples**     `CALCulate:EDIagram:MARKer1:DELTA:X:TIME?` might return `62.75`, indicating that the delta marker time is 62.75 symbols.

## **CALCulate:EDIagram:MARKer<x>:DELTA:Y? (Query Only)**

Returns the delta marker amplitude for the selected marker on the eye diagram trace.

The parameter `<x>` = 1 to 4; `MARKer0` (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

**Conditions**     Measurement views: Eye diagram

**Group**            Calculate commands

**Syntax**          `CALCulate:EDIagram:MARKer<x>:DELTA:Y?`

**Related Commands**     [CALCulate:EDIagram:MARKer<x>:DELTA:X\[:TIME\]?](#)

**Arguments**        None

**Returns**          `<Nrf>` Delta marker amplitude for the selected marker.

**Examples**         `CALCULATE:EDIAGRAM:MARKER1:DELTA:Y?` might return `-1.043`, indicating that the delta marker amplitude is -1.043.

## **CALCulate:EDIagram:MARKer<x>:MAXimum (No Query Form)**

Moves the selected marker to the highest peak on the eye diagram trace.

The parameter `<x>` = 0 to 4. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

**Conditions**        Measurement views: Eye diagram

**Group**            Calculate commands

**Syntax**          `CALCulate:EDIagram:MARKer<x>:MAXimum`



**Arguments** None

**Examples** CALCULATE:EDIAGRAM:MARKER1:MAXIMUM moves Marker 1 (M1) to the highest peak on the trace.

## CALCulate:EDIagram:MARKer<x>:PEAK:HIGHer (No Query Form)

Moves the selected marker to the next peak higher in amplitude on the eye diagram trace.

The parameter <x> = 0 to 4. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

**Conditions** Measurement views: Eye diagram

**Group** Calculate commands

**Syntax** CALCulate:EDIagram:MARKer<x>:PEAK:HIGHer

**Related Commands** [CALCulate:EDIagram:MARKer<x>:PEAK:LOWer](#)

**Arguments** None

**Examples** CALCULATE:EDIAGRAM:MARKER1:PEAK:HIGHER moves Marker 1 (M1) to the next peak higher in amplitude on the trace.

## CALCulate:EDIagram:MARKer<x>:PEAK:LEFT (No Query Form)

Moves the selected marker to the next peak to the left on the eye diagram trace.

The parameter <x> = 0 to 4. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

**Conditions** Measurement views: Eye diagram

**Group** Calculate commands

**Syntax** CALCulate:EDIagram:MARKer<x>:PEAK:LEFT

**Related Commands**    [CALCulate:EDIagram:MARKer<x>:PEAK:RIGHT](#)

**Arguments**    None

**Examples**    CALCULATE:EDIAGRAM:MARKER1:PEAK:LEFT moves Marker 1 (M1) to the next peak to the left on the trace.

## CALCulate:EDIagram:MARKer<x>:PEAK:LOWer (No Query Form)

Moves the selected marker to the next peak lower in amplitude on the eye diagram trace.

The parameter <x> = 0 to 4. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

**Conditions**    Measurement views: Eye diagram

**Group**    Calculate commands

**Syntax**    CALCulate:EDIagram:MARKer<x>:PEAK:LOWer

**Related Commands**    [CALCulate:EDIagram:MARKer<x>:PEAK:HIGHer](#)

**Arguments**    None

**Examples**    CALCULATE:EDIAGRAM:MARKER1:PEAK:LOWER moves Marker 1 (M1) to the next peak lower in amplitude on the trace.

## CALCulate:EDIagram:MARKer<x>:PEAK:RIGHT (No Query Form)

Moves the selected marker to the next peak to the right on the eye diagram trace.

The parameter <x> = 0 to 4. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

**Conditions**    Measurement views: Eye diagram

**Group**    Calculate commands

**Syntax**     `CALCulate:EDIagram:MARKer<x>:PEAK:RIGHT`

**Related Commands**     [CALCulate:EDIagram:MARKer<x>:PEAK:LEFT](#)

**Arguments**     None

**Examples**     `CALCULATE:EDIAGRAM:MARKER1:PEAK:RIGHT` moves Marker 1 (M1) to the next peak to the right on the trace.

## **CALCulate:EDIagram:MARKer<x>:TRACe**

Places the selected marker on the I or Q trace in the eye diagram display. The query returns the name of the trace on which the marker resides. Valid on all modulation types except 2|4|8|16FSK or C4FM.

The parameter `<x>` = 0 to 4. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

**Conditions**     Measurement views: Eye diagram

**Group**     Calculate commands

**Syntax**     `CALCulate:EDIagram:MARKer<x>:TRACe <Enum>`  
`CALCulate:EDIagram:MARKer<x>:TRACe?`

**Related Commands**     [CALCulate:EDIagram:MARKer<x>:X\[:TIME\]](#)

**Arguments**     `<Enum> ::= TRACE1 | TRACE2` specifies which trace to place the marker on. TRACE1 specifies the “I” trace and TRACE2 specifies the “Q” trace.

**Returns**     For I and Q traces, TRACE1 identifies the “I” trace and TRACE2 identifies the “Q” trace.

**Examples**     `CALCulate:EDIagram:MARKer1:TRACe TRACE1` places Marker 1 (M1) on the I trace in an eye diagram.

## CALCulate:EDIagram:MARKer<x>:X[:TIME]

Sets or queries the horizontal position (time) of the selected marker in the eye diagram measurement.

The parameter <x> = 0 to 4. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

**Conditions** Measurement views: Eye diagram

**Group** Calculate commands

**Syntax** CALCulate:EDIagram:MARKer<x>:X[:TIME] <value>  
CALCulate:EDIagram:MARKer<x>:X[:TIME]?

**Related Commands** [CALCulate:EDIagram:MARKer<x>:Y?](#)

**Arguments** <value>: :=<NRf> specifies the horizontal position (time) of the marker. Use the [\[SENSe\]:DDEMod:TIME:UNITs](#) command to select the time unit: symbols (default) or seconds.

**Examples** CALCulate:EDIagram:MARKer1:X:TIME 38.5 places Marker 1 (M1) at 38.5 symbols on the trace.

## CALCulate:EDIagram:MARKer<x>:Y? (Query Only)

Queries the vertical position of the selected marker in the eye diagram measurement.

The parameter <x> = 0 to 4. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

**Conditions** Measurement views: Eye diagram

**Group** Calculate commands

**Syntax** CALCulate:EDIagram:MARKer<x>:Y?

**Related Commands** [CALCulate:EDIagram:MARKer<x>:X\[:TIME\]](#)

<b>Arguments</b>	None
<b>Returns</b>	<Nrf> Vertical position of the selected marker.
<b>Examples</b>	CALCULATE:EDIAGRAM:MARKER1:Y? might return 571.8E-3, indicating Marker 1 (M1) is at 0.5718.

## CALCulate:EVM:MARKer<x>:DELTA:X? (Query Only)

Returns the delta marker time for the selected marker in the EVM versus Time measurement.

The parameter <x> = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

<b>Conditions</b>	Measurement views: EVM versus Time
<b>Group</b>	Calculate commands
<b>Syntax</b>	CALCulate:EVM:MARKer<x>:DELTA:X?

**Related Commands** [CALCulate:EVM:MARKer<x>:DELTA:Y?](#)

<b>Arguments</b>	None
<b>Returns</b>	<Nrf> Delta marker time for the selected marker. The unit can be changed by the <a href="#">[SENSe]:DDEMod:TIME:UNITs</a> command.
<b>Examples</b>	CALCulate:EVM:MARKer1:DELTA:X? might return 9.52, indicating that the delta marker time is 9.52 symbols.

## CALCulate:EVM:MARKer<x>:DELTA:Y? (Query Only)

Returns the delta marker amplitude for the selected marker in the EVM versus Time measurement.

The parameter <x> = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

<b>Conditions</b>	Measurement views: EVM versus Time
<b>Group</b>	Calculate commands
<b>Syntax</b>	CALCulate:EVM:MARKer<x>:DELTA:Y?
<b>Related Commands</b>	<a href="#">CALCulate:EVM:MARKer&lt;x&gt;:DELTA:X?</a>
<b>Arguments</b>	None
<b>Returns</b>	<NRF> Delta marker amplitude for the selected marker in percent (%).
<b>Examples</b>	CALCULATE:EVM:MARKER1:DELTA:Y? might return 1.62, indicating that the delta marker amplitude is 1.62%.

## CALCulate:EVM:MARKer<x>:MAXimum (No Query Form)

Moves the selected marker to the highest peak on the trace in the EVM versus Time measurement.

The parameter <x> = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

<b>Conditions</b>	Measurement views: EVM versus Time
<b>Group</b>	Calculate commands
<b>Syntax</b>	CALCulate:EVM:MARKer<x>:MAXimum
<b>Arguments</b>	None

**Examples**     `CALCULATE:EVM:MARKER1:MAXIMUM` moves Marker 1 (M1) to the highest peak on the trace.

## **CALCulate:EVM:MARKer<x>:PEAK:HIGHer (No Query Form)**

Moves the selected marker to the next peak higher in amplitude on the EVM versus Time trace.

The parameter <x> = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

**Conditions**     Measurement views: EVM versus Time

**Group**     Calculate commands

**Syntax**     `CALCulate:EVM:MARKer<x>:PEAK:HIGHer`

**Related Commands**     [CALCulate:EVM:MARKer<x>:PEAK:LOWer](#)

**Arguments**     None

**Examples**     `CALCULATE:EVM:MARKER1:PEAK:HIGHER` moves Marker 1 (M1) to the next peak higher in amplitude on the trace.

## **CALCulate:EVM:MARKer<x>:PEAK:LEFT (No Query Form)**

Moves the selected marker to the next peak to the left on the trace in the EVM versus Time measurement.

The parameter <x> = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

**Conditions**     Measurement views: EVM versus Time

**Group**     Calculate commands

**Syntax**     `CALCulate:EVM:MARKer<x>:PEAK:LEFT`

<b>Related Commands</b>	<a href="#">CALCulate:EVM:MARKer&lt;x&gt;:PEAK:RIGHT</a>
<b>Arguments</b>	None
<b>Examples</b>	CALCULATE:EVM:MARKER1:PEAK:LEFT moves Marker 1 (M1) to the next peak to the left on the trace.

## CALCulate:EVM:MARKer<x>:PEAK:LOWer (No Query Form)

Moves the selected marker to the next peak lower in amplitude on the EVM versus Time trace.

The parameter <x> = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

<b>Conditions</b>	Measurement views: EVM versus Time
<b>Group</b>	Calculate commands
<b>Syntax</b>	CALCulate:EVM:MARKer<x>:PEAK:LOWer
<b>Related Commands</b>	<a href="#">CALCulate:EVM:MARKer&lt;x&gt;:PEAK:HIGHer</a>
<b>Arguments</b>	None
<b>Examples</b>	CALCULATE:EVM:MARKER1:PEAK:LOWER moves Marker 1 (M1) to the next peak lower in amplitude on the trace.

## CALCulate:EVM:MARKer<x>:PEAK:RIGHT (No Query Form)

Moves the selected marker to the next peak to the right on the trace in the EVM versus Time measurement.

The parameter <x> = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

<b>Conditions</b>	Measurement views: EVM versus Time
-------------------	------------------------------------



<b>Group</b>	Calculate commands
<b>Syntax</b>	<code>CALCulate:EVM:MARKer&lt;x&gt;:PEAK:RIGHT</code>
<b>Related Commands</b>	<a href="#">CALCulate:EVM:MARKer&lt;x&gt;:PEAK:LEFT</a>
<b>Arguments</b>	None
<b>Examples</b>	<code>CALCULATE:EVM:MARKER1:PEAK:RIGHT</code> moves Marker 1 (M1) to the next peak to the right on the trace.

## CALCulate:EVM:MARKer<x>:X

Sets or queries the horizontal position of the selected marker in the EVM versus Time measurement.

The parameter <x> = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

<b>Conditions</b>	Measurement views: EVM versus Time
<b>Group</b>	Calculate commands
<b>Syntax</b>	<code>CALCulate:EVM:MARKer&lt;x&gt;:X &lt;value&gt;</code> <code>CALCulate:EVM:MARKer&lt;x&gt;:X?</code>
<b>Arguments</b>	<value> ::= <NRF> specifies the horizontal position of the marker. Range: (analysis offset) to (analysis offset) + (analysis length). The unit can be changed by the <a href="#">[SENSe]:DDEMod:TIME:UNITs</a> command.
<b>Examples</b>	<code>CALCULATE:EVM:MARKER1:X 1.5us</code> places Marker 1 (M1) at 1.5 $\mu$ s on the trace.

## CALCulate:EVM:MARKer<x>:Y? (Query Only)

Queries the marker amplitude of the selected marker in the EVM versus Time measurement.

<b>Conditions</b>	Measurement views: EVM versus Time
<b>Group</b>	Calculate commands
<b>Syntax</b>	CALCulate:EVM:MARKer<x>:Y?
<b>Related Commands</b>	<a href="#">CALCulate:EVM:MARKer&lt;x&gt;:X</a>
<b>Arguments</b>	None
<b>Returns</b>	<NRF> Marker amplitude of the selected marker in percent (%).
<b>Examples</b>	CALCULATE:EVM:MARKER1:Y? might return 5.34, indicating Marker 1 (M1) is at 5.34%.

## CALCulate:FDVTime:MARKer<x>:DELTA:X[:TIME]? (Query Only)

Returns the delta marker time for the selected marker on the Frequency deviation vs Time trace.

The parameter <x> = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

<b>Conditions</b>	Measurement views: Frequency deviation versus Time
<b>Group</b>	Calculate commands
<b>Syntax</b>	CALCulate:FDVTime:MARKer<x>:DELTA:X[:TIME]?
<b>Related Commands</b>	<a href="#">CALCulate:FDVTime:MARKer&lt;x&gt;:DELTA:Y?</a>
<b>Arguments</b>	None
<b>Returns</b>	<NRF> Delta marker time for the selected marker. Use the <a href="#">[SENSe]:DDEMod:TIME:UNITS</a> command to select the time unit: symbols (default) or seconds.

**Examples**     `CALCULATE:FDVTIME:MARKER1:DELTA:X:TIME?` might return `62.75`, indicating that the delta marker time is 62.75 symbols.

## **CALCulate:FDVTime:MARKer<x>:DELTA:Y? (Query Only)**

Returns the delta marker amplitude for the selected marker on the Frequency deviation vs Time trace.

The parameter `<x>` = 1 to 4; `MARKer0` (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

**Conditions**     Measurement views: Frequency deviation versus Time

**Group**     Calculate commands

**Syntax**     `CALCulate:FDVTime:MARKer<x>:DELTA:Y?`

**Related Commands**     [CALCulate:FDVTime:MARKer<x>:DELTA:X\[:TIME\]?](#)

**Arguments**     None

**Returns**     `<NRf>` Delta marker amplitude for the selected marker in Hz.

**Examples**     `CALCULATE:FDVTIME:MARKER1:DELTA:Y?` might return `-563.7E+3`, indicating that the delta marker amplitude is -563.7 kHz.

## **CALCulate:FDVTime:MARKer<x>:MAXimum (No Query Form)**

Moves the selected marker to the highest peak on the Frequency deviation vs Time trace.

**Conditions**     Measurement views: Frequency deviation versus Time

**Group**     Calculate commands

**Syntax**     `CALCulate:FDVTime:MARKer<x>:MAXimum`

**Arguments** None

**Examples** `CALCULATE:FDVTIME:MARKER1:MAXIMUM` moves Marker 1 (M1) to the highest peak on the trace.

## **CALCulate:FDVTime:MARKer<x>:PEAK:HIGHer (No Query Form)**

Moves the selected marker to the next peak higher in amplitude on the Frequency deviation vs Time trace.

**Conditions** Measurement views: Frequency deviation versus Time

**Group** Calculate commands

**Syntax** `CALCulate:FDVTime:MARKer<x>:PEAK:HIGHer`

**Related Commands** [CALCulate:FDVTime:MARKer<x>:PEAK:LOWer](#)

**Arguments** None

**Examples** `CALCulate:FDVTime:MARKer1:PEAK:HIGHer` moves Marker 1 (M1) to the next peak higher in amplitude on the trace.

## **CALCulate:FDVTime:MARKer<x>:PEAK:LEFT (No Query Form)**

Moves the selected marker to the next peak to the left on the Frequency deviation vs Time trace.

**Conditions** Measurement views: Frequency deviation versus Time

**Group** Calculate commands

**Syntax** `CALCulate:FDVTime:MARKer<x>:PEAK:LEFT`

**Related Commands** [CALCulate:FDVTime:MARKer<x>:PEAK:RIGHT](#)

**Arguments** None

**Examples** CALCULATE:FDVTIME:MARKER1:PEAK:LEFT moves Marker 1 (M1) to the next peak to the left on the trace.

## CALCulate:FDVTime:MARKer<x>:PEAK:LOWer (No Query Form)

Moves the selected marker to the next peak lower in amplitude on the Frequency deviation vs Time trace.

**Conditions** Measurement views: Frequency deviation versus Time

**Group** Calculate commands

**Syntax** CALCulate:FDVTime:MARKer<x>:PEAK:LOWer

**Related Commands** [CALCulate:FDVTime:MARKer<x>:PEAK:HIGHer](#)

**Arguments** None

**Examples** CALCULATE:FDVTIME:MARKER1:PEAK:LOWER moves Marker 1 (M1) to the next peak lower in amplitude on the trace.

## CALCulate:FDVTime:MARKer<x>:PEAK:RIGHT (No Query Form)

Moves the selected marker to the next peak to the right on the trace in the Frequency deviation versus Time measurement.

**Conditions** Measurement views: Frequency deviation versus Time

**Group** Calculate commands

**Syntax** CALCulate:FDVTime:MARKer<x>:PEAK:RIGHT

**Arguments** None

**Examples**     `CALCULATE:FDVTIME:MARKER1:PEAK:RIGHT` moves Marker 1 (M1) to the next peak to the right on the trace.

## **CALCulate:FDVTime:MARKer<x>:X[:TIME]**

Sets or queries the horizontal position (time) of the selected marker in the Frequency deviation versus Time measurement.

**Conditions**     Measurement views: Frequency deviation versus Time

**Group**     Calculate commands

**Syntax**     `CALCulate:FDVTime:MARKer<x>:X[:TIME] <value>`  
`CALCulate:FDVTime:MARKer<x>:X[:TIME]?`

**Related Commands**     [CALCulate:FDVTime:MARKer<x>:Y?](#)

**Arguments**     `<value>::=<Nrf>` specifies the horizontal position of the marker.  
 Range: (analysis offset) to [(analysis offset) + (analysis length)].  
 Use the [\[SENSe\]:DDEMod:TIME:UNITs](#) command to select the time unit: symbols (default) or seconds.

**Examples**     `CALCULATE:FDVTIME:MARKER1:X:TIME 38.5` places Marker 1 (M1) at 38.5 symbols on the trace.

## **CALCulate:FDVTime:MARKer<x>:Y? (Query Only)**

Queries the marker amplitude of the selected marker in the Frequency deviation versus Time measurement.

**Conditions**     Measurement views: Frequency deviation versus Time

**Group**     Calculate commands

**Syntax**     `CALCulate:FDVTime:MARKer<x>:Y?`

**Related Commands**     [CALCulate:FDVTime:MARKer<x>:X\[:TIME\]](#)

<b>Arguments</b>	None
<b>Returns</b>	<NRf> Marker amplitude of the selected marker in Hz.
<b>Examples</b>	CALCULATE:FDVTIME:MARKER1:Y? might return -15.34E+6, indicating Marker 1 (M1) is at -15.34 MHz.

## CALCulate:FVTime:MARKer<x>:DELTA:X? (Query Only)

Returns the delta marker time for the selected marker in the Frequency versus Time measurement.

The parameter <x> = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

<b>Conditions</b>	Measurement views: Frequency versus Time
<b>Group</b>	Calculate commands
<b>Syntax</b>	CALCulate:FVTime:MARKer<x>:DELTA:X?

**Related Commands** [CALCulate:FVTime:MARKer<x>:DELTA:Y?](#)

<b>Arguments</b>	None
<b>Returns</b>	<NRf> Delta marker time for the selected marker.
<b>Examples</b>	CALCULATE:FVTIME:MARKER1:DELTA:X? might return 120.0E-9, indicating that the delta marker time is 120 ns.

## CALCulate:FVTime:MARKer<x>:DELTA:Y? (Query Only)

Returns the delta marker frequency for the selected marker in the Frequency versus Time measurement.

The parameter <x> = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

<b>Conditions</b>	Measurement views: Frequency versus Time
<b>Group</b>	Calculate commands
<b>Syntax</b>	<code>CALCulate:FVTime:MARKer&lt;x&gt;:DELTA:Y?</code>
<b>Related Commands</b>	<a href="#">CALCulate:FVTime:MARKer&lt;x&gt;:DELTA:X?</a>
<b>Arguments</b>	None
<b>Returns</b>	<NRF> Delta marker frequency for the selected marker in Hz.
<b>Examples</b>	<code>CALCULATE:FVTIME:MARKER1:DELTA:Y?</code> might return <code>27.05E+3</code> , indicating that the delta marker frequency is 27.05 kHz.

### **CALCulate:FVTime:MARKer<x>:MAXimum (No Query Form)**

Moves the selected marker to the highest peak on the trace in the Frequency versus Time measurement.

<b>Conditions</b>	Measurement views: Frequency versus Time
<b>Group</b>	Calculate commands
<b>Syntax</b>	<code>CALCulate:FVTime:MARKer&lt;x&gt;:MAXimum</code>
<b>Arguments</b>	None
<b>Examples</b>	<code>CALCULATE:FVTIME:MARKER1:MAXIMUM</code> moves Marker 1 (M1) to the highest peak on the trace.

### **CALCulate:FVTime:MARKer<x>:PEAK:HIGHer (No Query Form)**

Moves the selected marker to the next peak higher in amplitude on the Frequency versus Time trace.



---

<b>Conditions</b>	Measurement views: Frequency versus Time
<b>Group</b>	Calculate commands
<b>Syntax</b>	<code>CALCulate:FVTime:MARKer&lt;x&gt;:PEAK:HIGHer</code>
<b>Related Commands</b>	<a href="#">CALCulate:FVTime:MARKer&lt;x&gt;:PEAK:LOWer</a>
<b>Arguments</b>	None
<b>Examples</b>	<code>CALCULATE:FVTIME:MARKER1:PEAK:HIGHER</code> moves Marker 1 (M1) to the next peak higher in amplitude on the trace.

### **CALCulate:FVTime:MARKer<x>:PEAK:LEFT (No Query Form)**

Moves the selected marker to the next peak to the left on the trace in the Frequency versus Time measurement.

<b>Conditions</b>	Measurement views: Frequency versus Time
<b>Group</b>	Calculate commands
<b>Syntax</b>	<code>CALCulate:FVTime:MARKer&lt;x&gt;:PEAK:LEFT</code>
<b>Related Commands</b>	<a href="#">CALCulate:FVTime:MARKer&lt;x&gt;:PEAK:RIGHT</a>
<b>Arguments</b>	None
<b>Examples</b>	<code>CALCULATE:FVTIME:MARKER1:PEAK:LEFT</code> moves Marker 1 (M1) to the next peak to the left on the trace.

### **CALCulate:FVTime:MARKer<x>:PEAK:LOWer (No Query Form)**

Moves the selected marker to the next peak lower in amplitude on the Frequency versus Time trace.

<b>Conditions</b>	Measurement views: Frequency versus Time
<b>Group</b>	Calculate commands
<b>Syntax</b>	<code>CALCulate:FVTime:MARKer&lt;x&gt;:PEAK:LOWer</code>
<b>Related Commands</b>	<a href="#">CALCulate:FVTime:MARKer&lt;x&gt;:PEAK:HIGHer</a>
<b>Arguments</b>	None
<b>Examples</b>	<code>CALCULATE:FVTIME:MARKER1:PEAK:LOWER</code> moves Marker 1 (M1) to the next peak lower in amplitude on the trace.

## **CALCulate:FVTime:MARKer<x>:PEAK:RIGHT (No Query Form)**

Moves the selected marker to the next peak to the right on the trace in the Frequency versus Time measurement.

<b>Conditions</b>	Measurement views: Frequency versus Time
<b>Group</b>	Calculate commands
<b>Syntax</b>	<code>CALCulate:FVTime:MARKer&lt;x&gt;:PEAK:RIGHT</code>
<b>Related Commands</b>	<a href="#">CALCulate:FVTime:MARKer&lt;x&gt;:PEAK:LEFT</a>
<b>Arguments</b>	None
<b>Examples</b>	<code>CALCULATE:FVTIME:MARKER1:PEAK:RIGHT</code> moves Marker 1 (M1) to the next peak to the right on the trace.

## **CALCulate:FVTime:MARKer<x>:X**

Sets or queries the horizontal position of the selected marker in the Frequency versus Time measurement.

<b>Conditions</b>	Measurement views: Frequency versus Time
<b>Group</b>	Calculate commands
<b>Syntax</b>	CALCulate:FVTime:MARKer<x>:X <value> CALCulate:FVTime:MARKer<x>:X?
<b>Related Commands</b>	<a href="#">CALCulate:FVTime:MARKer&lt;x&gt;:Y?</a>
<b>Arguments</b>	<value> ::= <Nrf> specifies the horizontal position of the marker. Range: (analysis offset) to [(analysis offset) + (analysis length)].
<b>Examples</b>	CALCULATE:FVTIME:MARKER1:X 1.5u places Marker 1 (M1) at 1.5 $\mu$ s on the trace.

## CALCulate:FVTime:MARKer<x>:Y? (Query Only)

Queries the marker amplitude of the selected marker in the Frequency versus Time measurement.

<b>Conditions</b>	Measurement views: Frequency versus Time
<b>Group</b>	Calculate commands
<b>Syntax</b>	CALCulate:FVTime:MARKer<x>:Y?
<b>Related Commands</b>	<a href="#">CALCulate:FVTime:MARKer&lt;x&gt;:X</a>
<b>Arguments</b>	None
<b>Returns</b>	<Nrf> Marker amplitude of the selected marker in Hz.
<b>Examples</b>	CALCULATE:FVTIME:MARKER1:Y? might return -15.34E+6, indicating Marker 1 (M1) is at -15.34 MHz.

## CALCulate:IQVTime:MARKer<x>:DELTA:X? (Query Only)

Returns the delta marker time for the selected marker in the RF I&Q versus Time measurement.

The parameter <x> = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

<b>Conditions</b>	Measurement views: RF I&Q versus Time
<b>Group</b>	Calculate commands
<b>Syntax</b>	CALCulate:IQVTime:MARKer<x>:DELTA:X?
<b>Related Commands</b>	<a href="#">CALCulate:IQVTime:MARKer&lt;x&gt;:DELTA:Y?</a>
<b>Arguments</b>	None
<b>Returns</b>	<NRF> Delta marker time for the selected marker.
<b>Examples</b>	CALCULATE:IQVTIME:MARKER1:DELTA:X? might return 120.0E-9, indicating that the delta marker time is 120 ns.

## CALCulate:IQVTime:MARKer<x>:DELTA:Y? (Query Only)

Returns the delta marker amplitude for the selected marker in the RF I&Q versus Time measurement.

The parameter <x> = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

<b>Conditions</b>	Measurement views: RF I&Q versus Time
<b>Group</b>	Calculate commands
<b>Syntax</b>	CALCulate:IQVTime:MARKer<x>:DELTA:Y?

**Related Commands**    [CALCulate:IQVTime:MARKer<x>:DELTA:X?](#)

**Arguments**    None

**Returns**    <Nrf> Delta marker amplitude for the selected marker in volts.

**Examples**    CALCULATE:IQVTIME:MARKER1:DELTA:Y? might return  $-3.45E-3$ , indicating that the delta marker amplitude is -3.45 mV.

## CALCulate:IQVTime:MARKer<x>:MAXimum (No Query Form)

Moves the selected marker to the highest peak on the trace in the RF I&Q versus Time measurement.

**Conditions**    Measurement views: RF I&Q versus Time

**Group**    Calculate commands

**Syntax**    CALCulate:IQVTime:MARKer<x>:MAXimum

**Arguments**    None

**Examples**    CALCULATE:IQVTIME:MARKER1:MAXIMUM moves Marker 1 (M1) to the highest peak on the trace.

## CALCulate:IQVTime:MARKer<x>:PEAK:HIGHer (No Query Form)

Moves the selected marker to the next peak higher in amplitude on the RF I&Q versus Time trace.

**Conditions**    Measurement views: RF I&Q versus Time

**Group**    Calculate commands

**Syntax**    CALCulate:IQVTime:MARKer<x>:PEAK:HIGHer

**Related Commands**    [CALCulate:IQVTime:MARKer<x>:PEAK:LOWer](#)

**Arguments**    None

**Examples**    CALCULATE:IQVTIME:MARKER1:PEAK:HIGHER moves Marker 1 (M1) to the next peak higher in amplitude on the trace.

## **CALCulate:IQVTime:MARKer<x>:PEAK:LEFT (No Query Form)**

Moves the selected marker to the next peak to the left on the trace in the RF I&Q versus Time measurement.

**Conditions**    Measurement views: RF I&Q versus Time

**Group**    Calculate commands

**Syntax**    CALCulate:IQVTime:MARKer<x>:PEAK:LEFT

**Related Commands**    [CALCulate:IQVTime:MARKer<x>:PEAK:RIGHT](#)

**Arguments**    None

**Examples**    CALCULATE:IQVTIME:MARKER1:PEAK:LEFT moves Marker 1 (M1) to the next peak to the left on the trace.

## **CALCulate:IQVTime:MARKer<x>:PEAK:LOWer (No Query Form)**

Moves the selected marker to the next peak lower in amplitude on the RF I&Q versus Time trace.

**Conditions**    Measurement views: RF I&Q versus Time

**Group**    Calculate commands

**Syntax**    CALCulate:IQVTime:MARKer<x>:PEAK:LOWer

**Related Commands**    [CALCulate:IQVTime:MARKer<x>:PEAK:HIGHer](#)

**Arguments**    None

**Examples**    CALCULATE:IQVTIME:MARKER1:PEAK:LOWER moves Marker 1 (M1) to the next peak lower in amplitude on the trace.

## CALCulate:IQVTime:MARKer<x>:PEAK:RIGHT (No Query Form)

Moves the selected marker to the next peak to the right on the trace in the RF I&Q versus Time measurement.

**Conditions**    Measurement views: RF I&Q versus Time

**Group**    Calculate commands

**Syntax**    CALCulate:IQVTime:MARKer<x>:PEAK:RIGHT

**Related Commands**    [CALCulate:IQVTime:MARKer<x>:PEAK:LEFT](#)

**Arguments**    None

**Examples**    CALCULATE:IQVTIME:MARKER1:PEAK:RIGHT moves Marker 1 (M1) to the next peak to the right on the trace.

## CALCulate:IQVTime:MARKer<x>:TRACe

Places the selected marker on the I or Q trace in the RF I&Q versus Time measurement. The query command returns which trace the selected marker is placed on.

**Conditions**    Measurement views: RF I&Q versus Time

**Group**    Calculate commands

**Syntax**    CALCulate:IQVTime:MARKer<x>:TRACe { TRACE1 | TRACE2 }  
CALCulate:IQVTime:MARKer<x>:TRACe?

**Arguments** TRACE1 places the selected marker on the I trace.  
TRACE2 places the selected marker on the Q trace.

**Examples** CALCULATE:IQVTIME:MARKER1:TRACE TRACE1 places Marker 1 (M1) on the I trace.

## CALCulate:IQVTime:MARKer<x>:X

Sets or queries the horizontal position of the selected marker in the RF I&Q versus Time measurement.

**Conditions** Measurement views: RF I&Q versus Time

**Group** Calculate commands

**Syntax** CALCulate:IQVTime:MARKer<x>:X <value>  
CALCulate:IQVTime:MARKer<x>:X?

**Related Commands** [CALCulate:IQVTime:MARKer<x>:Y?](#)

**Arguments** <value>::=<Nrf> specifies the horizontal position of the marker.  
Range: (analysis offset) to [(analysis offset) + (analysis length)].

**Examples** CALCULATE:IQVTIME:MARKER1:X 1.5us places Marker 1 (M1) at 1.5  $\mu$ s on the trace.

## CALCulate:IQVTime:MARKer<x>:Y? (Query Only)

Queries the marker amplitude of the selected marker in the RF I&Q versus Time measurement.

**Conditions** Measurement views: RF I&Q versus Time

**Group** Calculate commands

**Syntax** CALCulate:IQVTime:MARKer<x>:Y?



---

<b>Related Commands</b>	<a href="#">CALCulate:IQVTime:MARKer&lt;x&gt;:X</a>
<b>Arguments</b>	None
<b>Returns</b>	<NRf> Marker amplitude of the selected marker in volts.
<b>Examples</b>	CALCULATE:IQVTIME:MARKER1:Y? might return 25.803E-3, indicating Marker 1 (M1) is at 25.803 mV.

## CALCulate:MARKer:ADD (No Query Form)

Adds a marker. Every execution of this command adds a marker from MR, then M1 to M4, sequentially.

---

**NOTE.** *If all markers are already turned on, the error message "Cannot add another marker" (execution error -200) is returned.*

---

<b>Conditions</b>	Measurement views: All
<b>Group</b>	Calculate commands
<b>Syntax</b>	CALCulate:MARKer:ADD
<b>Related Commands</b>	<a href="#">CALCulate:MARKer:AOff</a> , <a href="#">CALCulate:MARKer:DElete</a>
<b>Arguments</b>	None
<b>Examples</b>	CALCULATE:MARKER:ADD adds a marker.

## CALCulate:MARKer:AOff (No Query Form)

Turns off all markers.

<b>Conditions</b>	Measurement views: All
<b>Group</b>	Calculate commands

**Syntax**      CALCulate:MARKer:AOff

**Related Commands**    [CALCulate:MARKer:ADD](#), [CALCulate:MARKer:DELeTe](#)

**Arguments**      None

**Examples**      CALCULATE:MARKER:AOff turns off all markers.

## CALCulate:MARKer:DELeTe (No Query Form)

Deletes the last marker added.

---

**NOTE.** *If all markers are turned off, the error message "Cannot delete another marker" (execution error -200) is returned.*

---

**Conditions**      Measurement views: All

**Group**            Calculate commands

**Syntax**          CALCulate:MARKer:DELeTe

**Related Commands**    [CALCulate:MARKer:ADD](#), [CALCulate:MARKer:AOff](#)

**Arguments**      None

**Examples**      CALCULATE:MARKER:DELETE deletes the last marker added.

## CALCulate:MARKer:DENSity:EXCursion

Sets or queries the minimum excursion of DPX signal density, or how far the density (hit count for pixels) must be above the surrounding noise to be detected as a peak. This command is effective for the DPX bitmap trace.

For marker peak up and marker peak down operations, the signal is considered to be a peak if it exceeds the excursion and the threshold set by the CALCulate:MARKer:DENSity:THReshold command.

For marker peak left and marker peak right operations, the signal is considered to be a peak if it first exceeds the amplitude excursion set by `CALCulate:MARKer:PEAK:EXCursion`, the amplitude threshold set by `CALCulate:MARKer:PEAK:THReshold`, the density excursion set by `CALCulate:MARKer:DENSity:EXCursion` and the density threshold set by `CALCulate:MARKer:DENSity:THReshold`.

**Conditions** Measurement views: All

**Group** Calculate commands

**Syntax** `CALCulate:MARKer:DENSity:EXCursion <number>`  
`CALCulate:MARKer:DENSity:EXCursion?`

**Related Commands** [CALCulate:MARKer:DENSity:THReshold](#), [CALCulate:MARKer:PEAK:EXCursion](#), [CALCulate:MARKer:PEAK:THReshold](#)

**Arguments** `<number>::=<NR1>` specifies the minimum excursion density. Range: 0 to 100%.

**Examples** `CALCULATE:MARKER:DENSITY:EXCURSION 30` sets the minimum excursion density to 30.

## CALCulate:MARKer:DENSity:SMOothing

Sets or queries the number of pixels squared for smoothing the DPX signal density. This command is effective for the DPX bitmap trace.

**Conditions** Measurement views: All

**Group** Calculate commands

**Syntax** `CALCulate:MARKer:DENSity:SMOothing <number>`  
`CALCulate:MARKer:DENSity:SMOothing?`

**Arguments** `<number>::=<NR1>` specifies the number of pixels squared for smoothing the DPX signal density. Range: 1 to 20.

**Examples**     `CALCULATE:MARKER:DENSITY:SMOOTHING 5` sets the smoothing number to 5.

## CALCulate:MARKer:DENSity:THReshold

Sets or queries the threshold of DPX signal density above which the density (hit count for pixels) is detected as a peak. This command is effective for the DPX bitmap trace.

**Conditions**     Measurement views: All

**Group**            Calculate commands

**Syntax**           `CALCulate:MARKer:DENSity:THReshold <number>`  
`CALCulate:MARKer:DENSity:THReshold?`

**Related Commands**     [CALCulate:MARKer:DENSity:EXCursion](#)

**Arguments**        `<number> ::= <NR1>` specifies the threshold density for detecting peaks.  
 Range: 0 to 100%.

**Examples**         `CALCULATE:MARKER:DENSITY:THRESHOLD 300` sets the threshold density to 300.

## CALCulate:MARKer:MODE

Selects or queries the marker mode.

**Conditions**        Measurement views: All

**Group**            Calculate commands

**Syntax**           `CALCulate:MARKer:MODE { ABSolute | DELTA }`  
`CALCulate:MARKer:MODE?`

**Arguments**        `ABSolute` selects the absolute marker mode, in which the marker readout indicates the absolute value.

DELTA selects the delta marker mode, in which the marker readout indicates the relative value to the reference marker.

**Examples**    `CALCULATE:MARKER:MODE DELTA` selects the delta marker mode.

## CALCulate:MARKer:PEAK:EXCursion

Sets or queries the minimum excursion level (how far a signal must be above the surrounding noise to be detected as a peak). The signal is considered to be a peak if it exceeds the minimum excursion level and the threshold level set by the [CALCulate:MARKer:PEAK:THReshold](#) command.

**Conditions**    Measurement views: All

**Group**    Calculate commands

**Syntax**    `CALCulate:MARKer:PEAK:EXCursion <value>`  
`CALCulate:MARKer:PEAK:EXCursion?`

**Arguments**    `<value>::=<NRF>` specifies the excursion level. Range: 0 to 100 dB.

**Examples**    `CALCULATE:MARKER:PEAK:EXCURSION 10` sets the excursion level to 10 dB.

## CALCulate:MARKer:PEAK:THReshold

Sets or queries the threshold level above which a signal is detected as a peak.

**Conditions**    Measurement views: All

**Group**    Calculate commands

**Syntax**    `CALCulate:MARKer:PEAK:THReshold <value>`  
`CALCulate:MARKer:PEAK:THReshold?`

**Arguments**    `<value>::=<NRF>` specifies the threshold level for detecting peaks. Range: -170 to +130 dBm.

**Examples**     `CALCULATE:MARKER:PEAK:THRESHOLD -50` sets the threshold level to -50 dBm.

## **CALCulate:MCPower:MARKer<x>:DELTA:X? (Query Only)**

Returns the delta marker frequency for the selected marker in the MCPR measurement.

The parameter <x> = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

**Conditions**     Measurement views: MCPR

**Group**     Calculate commands

**Syntax**     `CALCulate:MCPower:MARKer<x>:DELTA:X?`

**Related Commands**     [CALCulate:MCPower:MARKer<x>:DELTA:Y?](#)

**Arguments**     None

**Returns**     <NRF> Delta marker frequency for the selected marker.

**Examples**     `CALCULATE:MCPOWER:MARKER1:DELTA:X?` might return `1.28E+6`, indicating that the delta marker frequency is 1.28 MHz.

## **CALCulate:MCPower:MARKer<x>:DELTA:Y? (Query Only)**

Returns the delta marker amplitude for the selected marker in the MCPR measurement.

The parameter <x> = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

**Conditions**     Measurement views: MCPR

**Group**     Calculate commands

**Syntax**    `CALCulate:MCPower:MARKer<x>:DELTA:Y?`

**Related Commands**    `CALCulate:MCPower:MARKer<x>:DELTA:X?`

**Arguments**    None

**Returns**    <Nrf> Delta marker amplitude for the selected marker.

**Examples**    `CALCULATE:MCPOWER:MARKER1:DELTA:Y?` might return 23.45, indicating that the delta marker amplitude is 23.45 dB.

## **CALCulate:MCPower:MARKer<x>:MAXimum (No Query Form)**

Moves the selected marker to the highest peak on the trace in the MCPR measurement.

**Conditions**    Measurement views: MCPR

**Group**    Calculate commands

**Syntax**    `CALCulate:MCPower:MARKer<x>:MAXimum`

**Arguments**    None

**Examples**    `CALCULATE:MCPOWER:MARKER1:MAXIMUM` moves Marker 1 (M1) to the highest peak on the trace.

## **CALCulate:MCPower:MARKer<x>:PEAK:LEFT (No Query Form)**

Moves the selected marker to the next peak to the left on the trace in the MCPR measurement.

**Conditions**    Measurement views: MCPR

**Group**    Calculate commands

**Syntax**      `CALCulate:MCPower:MARKer<x>:PEAK:LEFT`

**Related Commands**      [CALCulate:MCPower:MARKer<x>:PEAK:RIGHT](#)

**Arguments**      None

**Examples**      `CALCULATE:MCPOWER:MARKER1:PEAK:LEFT` moves Marker 1 (M1) to the next peak to the left on the trace.

## **CALCulate:MCPower:MARKer<x>:PEAK:RIGHT (No Query Form)**

Moves the selected marker to the next peak to the right on the trace in the MCPR measurement.

**Conditions**      Measurement views: MCPR

**Group**      Calculate commands

**Syntax**      `CALCulate:MCPower:MARKer<x>:PEAK:RIGHT`

**Related Commands**      [CALCulate:MCPower:MARKer<x>:PEAK:LEFT](#)

**Arguments**      None

**Examples**      `CALCULATE:MCPOWER:MARKER1:PEAK:RIGHT` moves Marker 1 (M1) to the next peak to the right on the trace.

## **CALCulate:MCPower:MARKer<x>:X**

Sets or queries the horizontal position of the selected marker in the MCPR measurement.

**Conditions**      Measurement views: MCPR

**Group**      Calculate commands



**Syntax**     `CALCulate:MCPower:MARKer<x>:X <value>`  
`CALCulate:MCPower:MARKer<x>:X?`

**Related Commands**     [CALCulate:MCPower:MARKer<x>:Y?](#)

**Arguments**     `<value> ::= <Nrf>` specifies the horizontal position of the marker.  
 Range: Start to Stop frequency (left to right edge of the horizontal axis).  
 Using an out-of-range value causes an execution error (-222, "Data out of range").

**Examples**     `CALCULATE:MCPOWER:MARKER1:X 800MHZ` places Marker 1 (M1) at 800 MHz on the trace.

## CALCulate:MCPower:MARKer<x>:Y? (Query Only)

Queries the marker amplitude of the selected marker in the MCPR measurement.

**Conditions**     Measurement views: MCPR

**Group**     Calculate commands

**Syntax**     `CALCulate:MCPower:MARKer<x>:Y?`

**Related Commands**     [CALCulate:MCPower:MARKer<x>:X](#)

**Arguments**     None

**Returns**     `<Nrf>` Marker amplitude of the selected marker.

**Examples**     `CALCULATE:MCPOWER:MARKER1:Y?` might return `-34.28`, indicating Marker 1 (M1) is at `-34.28` dBm.

## CALCulate:MERRor:MARKer<x>:DELTA:X? (Query Only)

Returns the delta marker time for the selected marker in the Magnitude error versus Time measurement.

The parameter <x> = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

<b>Conditions</b>	Measurement views: Magnitude error versus Time
<b>Group</b>	Calculate commands
<b>Syntax</b>	CALCulate:MERRor:MARKer<x>:DELTA:X?
<b>Related Commands</b>	<a href="#">CALCulate:MERRor:MARKer&lt;x&gt;:DELTA:Y?</a>
<b>Arguments</b>	None
<b>Returns</b>	<NRf> Delta marker time for the selected marker. The unit can be changed by the <a href="#">[SENSe]:DDEMod:TIME:UNITs</a> command.
<b>Examples</b>	CALCULATE:MERROR:MARKER1:DELTA:X? might return 9.52, indicating that the delta marker time is 9.52 symbols.

## CALCulate:MERRor:MARKer<x>:DELTA:Y? (Query Only)

Returns the delta marker amplitude for the selected marker in the Magnitude error versus Time measurement.

The parameter <x> = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

<b>Conditions</b>	Measurement views: Magnitude error versus Time
<b>Group</b>	Calculate commands
<b>Syntax</b>	CALCulate:MERRor:MARKer<x>:DELTA:Y?
<b>Related Commands</b>	<a href="#">CALCulate:MERRor:MARKer&lt;x&gt;:DELTA:X?</a>

---

<b>Arguments</b>	None
<b>Returns</b>	<Nrf> Delta marker amplitude for the selected marker in percent (%).
<b>Examples</b>	CALCULATE:MERROR:MARKER1:DELTA:Y? might return 3.84, indicating that the delta marker amplitude is 3.84%.

### **CALCulate:MERRor:MARKer<x>:MAXimum (No Query Form)**

Moves the selected marker to the highest peak on the trace in the Magnitude error versus Time measurement.

<b>Conditions</b>	Measurement views: Magnitude error versus Time
<b>Group</b>	Calculate commands
<b>Syntax</b>	CALCulate:MERRor:MARKer<x>:MAXimum
<b>Arguments</b>	None
<b>Examples</b>	CALCULATE:MERROR:MARKER1:MAXIMUM moves Marker 1 (M1) to the highest peak on the trace.

### **CALCulate:MERRor:MARKer<x>:PEAK:HIGHer (No Query Form)**

Moves the selected marker to the next peak higher in amplitude on the Magnitude error versus Time trace.

<b>Conditions</b>	Measurement views: Magnitude error versus Time
<b>Group</b>	Calculate commands
<b>Syntax</b>	CALCulate:MERRor:MARKer<x>:PEAK:HIGHer
<b>Related Commands</b>	<a href="#">CALCulate:MERRor:MARKer&lt;x&gt;:PEAK:LOWer</a>

**Arguments** None

**Examples** CALCULATE:MERROR:MARKER1:PEAK:HIGHER moves Marker 1 (M1) to the next peak higher in amplitude on the trace.

## CALCulate:MERRor:MARKer<x>:PEAK:LEFT (No Query Form)

Moves the selected marker to the next peak to the left on the trace in the Magnitude error versus Time measurement.

**Conditions** Measurement views: Magnitude error versus Time

**Group** Calculate commands

**Syntax** CALCulate:MERRor:MARKer<x>:PEAK:LEFT

**Related Commands** [CALCulate:MERRor:MARKer<x>:PEAK:RIGHT](#)

**Arguments** None

**Examples** CALCULATE:MERROR:MARKER1:PEAK:LEFT moves Marker 1 (M1) to the next peak to the left on the trace.

## CALCulate:MERRor:MARKer<x>:PEAK:LOWer (No Query Form)

Moves the selected marker to the next peak lower in amplitude on the Magnitude error versus Time trace.

**Conditions** Measurement views: Magnitude error versus Time

**Group** Calculate commands

**Syntax** CALCulate:MERRor:MARKer<x>:PEAK:LOWer

**Related Commands** [CALCulate:MERRor:MARKer<x>:PEAK:HIGHer](#)

**Arguments** None

**Examples** `CALCULATE:MERROR:MARKER1:PEAK:LOWER` moves Marker 1 (M1) to the next peak lower in amplitude on the trace.

## **CALCulate:MERRor:MARKer<x>:PEAK:RIGHT (No Query Form)**

Moves the selected marker to the next peak to the right on the trace in the Magnitude error versus Time measurement.

**Conditions** Measurement views: Magnitude error versus Time

**Group** Calculate commands

**Syntax** `CALCulate:MERRor:MARKer<x>:PEAK:RIGHT`

**Related Commands** [CALCulate:MERRor:MARKer<x>:PEAK:LEFT](#)

**Arguments** None

**Examples** `CALCULATE:MERROR:MARKER1:PEAK:RIGHT` moves Marker 1 (M1) to the next peak to the right on the trace.

## **CALCulate:MERRor:MARKer<x>:X**

Sets or queries the horizontal position of the selected marker in the Magnitude error versus Time measurement.

**Conditions** Measurement views: Magnitude error versus Time

**Group** Calculate commands

**Syntax** `CALCulate:MERRor:MARKer<x>:X <value>`  
`CALCulate:MERRor:MARKer<x>:X?`

**Arguments** `<value>::=<Nrf>` specifies the horizontal position of the marker. Range: (analysis offset) to [(analysis offset) + (analysis length)].

The unit can be changed by the [\[SENSe\]:DDEMod:TIME:UNITs](#) command.

**Examples**     `CALCULATE:MERROR:MARKER1:X 1.5u` places Marker 1 (M1) at 1.5  $\mu$ s on the trace.

## CALCulate:MERRor:MARKer<x>:Y? (Query Only)

Queries the marker amplitude of the selected marker in the Magnitude error versus Time measurement.

**Conditions**     Measurement views: Magnitude error versus Time

**Group**     Calculate commands

**Syntax**     `CALCulate:MERRor:MARKer<x>:Y?`

**Related Commands**     [CALCulate:MERRor:MARKer<x>:X](#)

**Arguments**     None

**Returns**     <NRF> Marker amplitude of the selected marker in percent (%).

**Examples**     `CALCULATE:MERROR:MARKER1:Y?` might return 5.34, indicating Marker 1 (M1) is at 5.34%.

## CALCulate:OBWidth:MARKer<x>:DELTA:X? (Query Only)

Returns the delta marker frequency for the selected marker in the Occupied Bandwidth measurement.

The parameter <x> = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

**Conditions**     Measurement views: Occupied Bandwidth

**Group**     Calculate commands

**Syntax**     `CALCulate:OBWidth:MARKer<x>:DELTA:X?`

**Related Commands**     [CALCulate:OBWidth:MARKer<x>:DELTA:Y?](#)

**Arguments**     None

**Returns**     <Nrf> Delta marker frequency for the selected marker.

**Examples**     `CALCULATE:OBWIDTH:MARKER1:DELTA:X?` might return `1.28E+6`, indicating that the delta marker frequency is 1.28 MHz.

## **CALCulate:OBWidth:MARKer<x>:DELTA:Y? (Query Only)**

Returns the delta marker amplitude for the selected marker in the Occupied Bandwidth measurement.

The parameter <x> = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

**Conditions**     Measurement views: Occupied Bandwidth

**Group**     Calculate commands

**Syntax**     `CALCulate:OBWidth:MARKer<x>:DELTA:Y?`

**Related Commands**     [CALCulate:OBWidth:MARKer<x>:DELTA:X?](#)

**Arguments**     None

**Returns**     <Nrf> Delta marker amplitude for the selected marker.

**Examples**     `CALCULATE:OBWIDTH:MARKER1:DELTA:Y?` might return `23.45`, indicating that the delta marker amplitude is 23.45 dB.

## CALCulate:OBWidth:MARKer<x>:MAXimum (No Query Form)

Moves the selected marker to the highest peak on the trace in the Occupied Bandwidth measurement.

**Conditions** Measurement views: Occupied Bandwidth

**Group** Calculate commands

**Syntax** CALCulate:OBWidth:MARKer<x>:MAXimum

**Arguments** None

**Examples** CALCULATE:OBWIDTH:MARKER1:MAXIMUM moves Marker 1 (M1) to the highest peak on the trace.

## CALCulate:OBWidth:MARKer<x>:PEAK:HIGHer (No Query Form)

Moves the selected marker to the next peak higher in amplitude on the Occupied Bandwidth trace.

**Conditions** Measurement views: Occupied Bandwidth

**Group** Calculate commands

**Syntax** CALCulate:OBWidth:MARKer<x>:PEAK:HIGHer

**Related Commands** [CALCulate:OBWidth:MARKer<x>:PEAK:LOWer](#)

**Arguments** None

**Examples** CALCULATE:OBWIDTH:MARKER1:PEAK:HIGHER moves Marker 1 (M1) to the next peak higher in amplitude on the trace.



## CALCulate:OBWidth:MARKer<x>:PEAK:LEFT (No Query Form)

Moves the selected marker to the next peak to the left on the trace in the Occupied Bandwidth measurement.

**Conditions** Measurement views: Occupied Bandwidth

**Group** Calculate commands

**Syntax** CALCulate:OBWidth:MARKer<x>:PEAK:LEFT

**Related Commands** [CALCulate:OBWidth:MARKer<x>:PEAK:RIGHT](#)

**Arguments** None

**Examples** CALCULATE:OBWIDTH:MARKER1:PEAK:LEFT moves Marker 1 (M1) to the next peak to the left on the trace.

## CALCulate:OBWidth:MARKer<x>:PEAK:LOWer (No Query Form)

Moves the selected marker to the next peak lower in amplitude on the Occupied Bandwidth trace.

**Conditions** Measurement views: Occupied Bandwidth

**Group** Calculate commands

**Syntax** CALCulate:OBWidth:MARKer<x>:PEAK:LOWer

**Related Commands** [CALCulate:OBWidth:MARKer<x>:PEAK:HIGHer](#)

**Arguments** None

**Examples** CALCULATE:OBWIDTH:MARKER1:PEAK:LOWER moves Marker 1 (M1) to the next peak lower in amplitude on the trace.

## CALCulate:OBWidth:MARKer<x>:PEAK:RIGHT (No Query Form)

Moves the selected marker to the next peak to the right on the trace in the Occupied Bandwidth measurement.

**Conditions** Measurement views: Occupied Bandwidth

**Group** Calculate commands

**Syntax** CALCulate:OBwidth:MARKer<x>:PEAK:RIGHT

**Related Commands** [CALCulate:OBWidth:MARKer<x>:PEAK:LEFT](#)

**Arguments** None

**Examples** CALCULATE:OBWIDTH:MARKER1:PEAK:RIGHT moves Marker 1 (M1) to the next peak to the right on the trace.

## CALCulate:OBWidth:MARKer<x>[:SET]:CENTER (No Query Form)

Sets the center frequency to the value at the marker position in the Occupied Bandwidth measurement.

**Conditions** Measurement views: Occupied Bandwidth

**Group** Calculate commands

**Syntax** CALCulate:OBwidth:MARKer<x>[:SET]:CENTER

**Arguments** None

**Examples** CALCULATE:OBWIDTH:MARKER1:SET:CENTER sets the center frequency to the value at the Marker 1 position.

## CALCulate:OBWidth:MARKer<x>:X

Sets or queries the horizontal position of the selected marker in the Occupied Bandwidth measurement.

**Conditions** Measurement views: Occupied Bandwidth

**Group** Calculate commands

**Syntax** CALCulate:OBwidth:MARKer<x>:X <value>  
CALCulate:OBwidth:MARKer<x>:X?

**Related Commands** [CALCulate:OBWidth:MARKer<x>:Y?](#)

**Arguments** <value> ::= <NRf> specifies the horizontal position of the marker.  
Range: Start to Stop frequency (left to right edge of the horizontal axis).  
Using an out-of-range value causes an execution error (-222, "Data out of range").

**Examples** CALCULATE:OBWIDTH:MARKER1:X 800MHZ places Marker 1 (M1) at 800 MHz on the trace.

## CALCulate:OBWidth:MARKer<x>:Y? (Query Only)

Queries the marker amplitude of the selected marker in the Occupied Bandwidth measurement.

**Conditions** Measurement views: Occupied Bandwidth

**Group** Calculate commands

**Syntax** CALCulate:OBwidth:MARKer<x>:Y?

**Related Commands** [CALCulate:OBWidth:MARKer<x>:X](#)

**Arguments** None

**Returns** <NRf> Marker amplitude of the selected marker.

**Examples**     `CALCULATE:OBWIDTH:MARKER1:Y?` might return -34.28 indicating Marker 1 (M1) is at -34.28 dBm.

## **CALCulate:PERRor:MARKer<x>:DELTA:X? (Query Only)**

Returns the delta marker time for the selected marker in the Phase error versus Time measurement.

The parameter <x> = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

**Conditions**     Measurement views: Phase error versus Time

**Group**            Calculate commands

**Syntax**           `CALCulate:PERRor:MARKer<x>:DELTA:X?`

**Related Commands**     [CALCulate:PERRor:MARKer<x>:DELTA:Y?](#)

**Arguments**        None

**Returns**           <NRF> Delta marker time for the selected marker.

The unit can be changed by the [\[SENSe\]:DDEMod:TIME:UNITs](#) command.

**Examples**         `CALCULATE:PERROR:MARKER1:DELTA:X?` might return 9.52, indicating that the delta marker time is 9.52 symbols.

## **CALCulate:PERRor:MARKer<x>:DELTA:Y? (Query Only)**

Returns the delta marker phase for the selected marker in the Phase error versus Time measurement.

The parameter <x> = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

**Conditions**        Measurement views: Phase error versus Time

---

<b>Group</b>	Calculate commands
<b>Syntax</b>	<code>CALCulate:PERRor:MARKer&lt;x&gt;:DELTA:Y?</code>
<b>Related Commands</b>	<a href="#">CALCulate:PERRor:MARKer&lt;x&gt;:DELTA:X?</a>
<b>Arguments</b>	None
<b>Returns</b>	<Nrf> Delta marker phase for the selected marker in degrees.
<b>Examples</b>	<code>CALCULATE:PERROR:MARKER1:DELTA:Y?</code> might return <code>-7.93</code> , indicating that the delta marker phase is <code>-7.93 °</code> .

### **CALCulate:PERRor:MARKer<x>:MAXimum (No Query Form)**

Moves the selected marker to the highest peak on the trace in the Phase error versus Time measurement.

<b>Conditions</b>	Measurement views: Phase error versus Time
<b>Group</b>	Calculate commands
<b>Syntax</b>	<code>CALCulate:PERRor:MARKer&lt;x&gt;:MAXimum</code>
<b>Arguments</b>	None
<b>Examples</b>	<code>CALCULATE:PERROR:MARKER1:MAXIMUM</code> moves Marker 1 (M1) to the highest peak on the trace.

### **CALCulate:PERRor:MARKer<x>:PEAK:HIGHer (No Query Form)**

Moves the selected marker to the next peak higher in amplitude on the Phase error versus Time trace.

<b>Conditions</b>	Measurement views: Phase error versus Time
-------------------	--

<b>Group</b>	Calculate commands
<b>Syntax</b>	<code>CALCulate:PERRor:MARKer&lt;x&gt;:PEAK:HIGHer</code>
<b>Related Commands</b>	<a href="#">CALCulate:PERRor:MARKer&lt;x&gt;:PEAK:LOWer</a>
<b>Arguments</b>	None
<b>Examples</b>	<code>CALCULATE:PERROR:MARKER1:PEAK:HIGHER</code> moves Marker 1 (M1) to the next peak higher in amplitude on the trace.

### **CALCulate:PERRor:MARKer<x>:PEAK:LEFT (No Query Form)**

Moves the selected marker to the next peak to the left on the trace in the Phase error versus Time measurement.

<b>Conditions</b>	Measurement views: Phase error versus Time
<b>Group</b>	Calculate commands
<b>Syntax</b>	<code>CALCulate:PERRor:MARKer&lt;x&gt;:PEAK:LEFT</code>
<b>Related Commands</b>	<a href="#">CALCulate:PERRor:MARKer&lt;x&gt;:PEAK:RIGHT</a>
<b>Arguments</b>	None
<b>Examples</b>	<code>CALCULATE:PERROR:MARKER1:PEAK:LEFT</code> moves Marker 1 (M1) to the next peak to the left on the trace.

### **CALCulate:PERRor:MARKer<x>:PEAK:LOWer (No Query Form)**

Moves the selected marker to the next peak lower in amplitude on the Phase error versus Time trace.

<b>Conditions</b>	Measurement views: Phase error versus Time
-------------------	--

<b>Group</b>	Calculate commands
<b>Syntax</b>	<code>CALCulate:PERRor:MARKer&lt;x&gt;:PEAK:LOWer</code>
<b>Related Commands</b>	<a href="#">CALCulate:PERRor:MARKer&lt;x&gt;:PEAK:HIGHer</a>
<b>Arguments</b>	None
<b>Examples</b>	<code>CALCULATE:PERROR:MARKER1:PEAK:LOWER</code> moves Marker 1 (M1) lower in amplitude to the next peak on the trace.

### **CALCulate:PERRor:MARKer<x>:PEAK:RIGHT (No Query Form)**

Moves the selected marker to the next peak to the right on the trace in the Phase error versus Time measurement.

<b>Conditions</b>	Measurement views: Phase error versus Time
<b>Group</b>	Calculate commands
<b>Syntax</b>	<code>CALCulate:PERRor:MARKer&lt;x&gt;:PEAK:RIGHT</code>
<b>Related Commands</b>	<a href="#">CALCulate:PERRor:MARKer&lt;x&gt;:PEAK:LEFT</a>
<b>Arguments</b>	None
<b>Examples</b>	<code>CALCULATE:PERROR:MARKER1:PEAK:RIGHT</code> moves Marker 1 (M1) to the next peak to the right on the trace.

### **CALCulate:PERRor:MARKer<x>:X**

Sets or queries the horizontal position of the selected marker in the Phase error versus Time measurement.

<b>Conditions</b>	Measurement views: Phase error versus Time
-------------------	--

<b>Group</b>	Calculate commands
<b>Syntax</b>	<code>CALCulate:PERRor:MARKer&lt;x&gt;:X &lt;value&gt;</code> <code>CALCulate:PERRor:MARKer&lt;x&gt;:X?</code>
<b>Arguments</b>	<code>&lt;value&gt;::=&lt;NRF&gt;</code> specifies the horizontal position of the marker. Range: (analysis offset) to [(analysis offset) + (analysis length)]. The unit can be changed by the <a href="#">[SENSe]:DDEMod:TIME:UNITs</a> command.
<b>Examples</b>	<code>CALCULATE:PERRor:MARKER1:X 1.5u</code> places Marker 1 (M1) at 1.5 $\mu$ s on the trace.

### **CALCulate:PERRor:MARKer<x>:Y? (Query Only)**

Queries the marker amplitude of the selected marker in the Phase error versus Time measurement.

<b>Conditions</b>	Measurement views: Phase error versus Time
<b>Group</b>	Calculate commands
<b>Syntax</b>	<code>CALCulate:PERRor:MARKer&lt;x&gt;:Y?</code>
<b>Related Commands</b>	<a href="#">CALCulate:PERRor:MARKer&lt;x&gt;:X</a>
<b>Arguments</b>	None
<b>Returns</b>	<code>&lt;NRF&gt;</code> Marker amplitude of the selected marker in degrees.
<b>Examples</b>	<code>CALCULATE:PERRor:MARKER1:Y?</code> might return 21.04, indicating Marker 1 (M1) is at 21.04 $^{\circ}$ .

### **CALCulate:PHVTime:MARKer<x>:DELTA:X? (Query Only)**

Returns the delta marker time for the selected marker in the Phase versus Time measurement.



The parameter <x> = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

<b>Conditions</b>	Measurement views: Phase versus Time
<b>Group</b>	Calculate commands
<b>Syntax</b>	CALCulate:PHVTime:MARKer<x>:DELTA:X?
<b>Related Commands</b>	<a href="#">CALCulate:PHVTime:MARKer&lt;x&gt;:DELTA:Y?</a>
<b>Arguments</b>	None
<b>Returns</b>	<NRf> Delta marker time for the selected marker.
<b>Examples</b>	CALCULATE:PHVTIME:MARKER1:DELTA:X? might return 38.0E-9, indicating that the delta marker time is 38.0 ns.

## CALCulate:PHVTime:MARKer<x>:DELTA:Y? (Query Only)

Returns the delta marker phase for the selected marker in the Phase versus Time measurement.

The parameter <x> = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

<b>Conditions</b>	Measurement views: Phase versus Time
<b>Group</b>	Calculate commands
<b>Syntax</b>	CALCulate:PHVTime:MARKer<x>:DELTA:Y?
<b>Related Commands</b>	<a href="#">CALCulate:PHVTime:MARKer&lt;x&gt;:DELTA:X?</a>
<b>Arguments</b>	None

**Returns** <NRF> Delta marker phase for the selected marker in degrees.

**Examples** CALCULATE:PHVTIME:MARKER1:DELTA:Y? might return 162.38, indicating that the delta marker phase is 162.38 °.

## CALCulate:PHVTime:MARKer<x>:MAXimum (No Query Form)

Moves the selected marker to the highest peak on the trace in the Phase versus Time measurement.

**Conditions** Measurement views: Phase versus Time

**Group** Calculate commands

**Syntax** CALCulate:PHVTime:MARKer<x>:MAXimum

**Arguments** None

**Examples** CALCULATE:PHVTIME:MARKER1:MAXIMUM moves Marker 1 (M1) to the highest peak on the trace.

## CALCulate:PHVTime:MARKer<x>:PEAK:HIGHer (No Query Form)

Moves the selected marker to the next peak higher in amplitude on the Phase versus Time trace.

**Conditions** Measurement views: Phase versus Time

**Group** Calculate commands

**Syntax** CALCulate:PHVTime:MARKer<x>:PEAK:HIGHer

**Related Commands** [CALCulate:PHVTime:MARKer<x>:PEAK:LOWer](#)

**Arguments** None

**Examples**     `CALCULATE:PHVTIME:MARKER1:PEAK:HIGHER` moves Marker 1 (M1) to the next peak higher in amplitude on the trace.

## **CALCulate:PHVTime:MARKer<x>:PEAK:LEFT (No Query Form)**

Moves the selected marker to the next peak to the left on the trace in the Phase versus Time measurement.

**Conditions**     Measurement views: Phase versus Time

**Group**     Calculate commands

**Syntax**     `CALCulate:PHVTime:MARKer<x>:PEAK:LEFT`

**Related Commands**     [CALCulate:PHVTime:MARKer<x>:PEAK:RIGHT](#)

**Arguments**     None

**Examples**     `CALCULATE:PHVTIME:MARKER1:PEAK:LEFT` moves Marker 1 (M1) to the next peak to the left on the trace.

## **CALCulate:PHVTime:MARKer<x>:PEAK:LOWer (No Query Form)**

Moves the selected marker to the next peak lower in amplitude on the Phase versus Time trace.

**Conditions**     Measurement views: Phase versus Time

**Group**     Calculate commands

**Syntax**     `CALCulate:PHVTime:MARKer<x>:PEAK:LOWer`

**Related Commands**     [CALCulate:PHVTime:MARKer<x>:PEAK:HIGHer](#)

**Arguments**     None

**Examples**     `CALCULATE:PHVTIME:MARKER1:PEAK:LOWER` moves Marker 1 (M1) to the next peak lower in amplitude on the trace.

## **CALCulate:PHVTime:MARKer<x>:PEAK:RIGHT (No Query Form)**

Moves the selected marker to the next peak to the right on the trace in the Phase versus Time measurement.

**Conditions**     Measurement views: Phase versus Time

**Group**     Calculate commands

**Syntax**     `CALCulate:PHVTime:MARKer<x>:PEAK:RIGHT`

**Related Commands**     [CALCulate:PHVTime:MARKer<x>:PEAK:LEFT](#)

**Arguments**     None

**Examples**     `CALCULATE:PHVTIME:MARKER1:PEAK:RIGHT` moves Marker 1 (M1) to the next peak to the right on the trace.

## **CALCulate:PHVTime:MARKer<x>:X**

Sets or queries the horizontal position of the selected marker in the Phase versus Time measurement.

**Conditions**     Measurement views: Phase versus Time

**Group**     Calculate commands

**Syntax**     `CALCulate:PHVTime:MARKer<x>:X <value>`  
`CALCulate:PHVTime:MARKer<x>:X?`

**Related Commands**     [CALCulate:PHVTime:MARKer<x>:Y?](#)

**Arguments**     `<value>::=<NRF>` specifies the horizontal position of the marker.  
 Range: (analysis offset) to [(analysis offset) + (analysis length)].

**Examples**    `CALCULATE:PHVTIME:MARKER1:X 1.5US` places Marker 1 (M1) at 1.5  $\mu$ s on the trace.

## **CALCulate:PHVTime:MARKer<x>:Y? (Query Only)**

Queries the marker amplitude of the selected marker in the Phase versus Time measurement.

**Conditions**    Measurement views: Phase versus Time

**Group**    Calculate commands

**Syntax**    `CALCulate:PHVTime:MARKer<x>:Y?`

**Related Commands**    [CALCulate:PHVTime:MARKer<x>:X](#)

**Arguments**    None

**Returns**    <Nrf> Marker amplitude of the selected marker in degrees.

**Examples**    `CALCULATE:PHVTIME:MARKER1:Y?` might return `-18.435`, indicating Marker 1 (M1) is at `-18.435`  $^{\circ}$ .

## **CALCulate:PULSe:STATistics:MARKer<x>:DELTA:X? (Query Only)**

Returns the delta marker frequency for the selected marker on the pulse trace. This command is valid when `DISPlay:PULSe:STATistics:PLOT` is set to FFT.

The parameter <x> = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

**Conditions**    Measurement views: Pulse statistics

**Group**    Calculate commands

**Syntax**    `CALCulate:PULSe:STATistics:MARKer<x>:DELTA:X?`

**Related Commands** [DISPlay:PULSe:STATistics:PLOT](#), [CALCulate:PULSe:STATistics:MARKer<x>:DELTA:Y?](#)

**Returns** <NRF> Delta marker frequency for the selected marker.

**Examples** `CALCULATE:PULSE:STATISTICS:MARKER1:DELTA:X?` might return 614.2, indicating that the delta marker frequency is 614.2 Hz.

## **CALCulate:PULSe:STATistics:MARKer<x>:DELTA:Y? (Query Only)**

Returns the delta marker amplitude for the selected marker on the pulse trace. This command is valid when [DISPlay:PULSe:STATistics:PLOT](#) is set to FFT.

The parameter <x> = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

**Conditions** Measurement views: Pulse statistics

**Group** Calculate commands

**Syntax** `CALCulate:PULSe:STATistics:MARKer<x>:DELTA:Y?`

**Related Commands** [CALCulate:PULSe:STATistics:MARKer<x>:DELTA:X?](#)

**Arguments**

**Returns** <NRF> Delta marker amplitude for the selected marker.

**Examples** `CALCULATE:PULSE:STATISTICS:MARKER1:DELTA:Y?` might return 2.345, indicating that the delta marker amplitude is 2.345 dB.

## **CALCulate:PULSe:STATistics:MARKer<x>:MAXimum (No Query Form)**

Moves the selected marker to the highest peak on the pulse statistics trace. This command is valid when [DISPlay:PULSe:STATistics:PLOT](#) is set to FFT.

**Conditions** Measurement views: Pulse statistics

---

<b>Group</b>	Calculate commands
<b>Syntax</b>	<code>CALCulate:PULSE:STATISTICS:MARKer&lt;x&gt;:MAXimum</code>
<b>Arguments</b>	None
<b>Examples</b>	<code>CALCULATE:PULSE:STATISTICS:MARKER1:MAXIMUM</code> moves Marker 1 (M1) to the highest peak on the trace.

### **CALCulate:PULSE:STATISTICS:MARKer<x>:PEAK:HIGHer (No Query Form)**

Moves the selected marker to the next peak higher in amplitude on the pulse statistics trace. This command is valid when [DISPlay:PULSE:STATISTICS:PLOT](#) is set to FFT.

<b>Conditions</b>	Measurement views: Pulse statistics
<b>Group</b>	Calculate commands
<b>Syntax</b>	<code>CALCulate:PULSE:STATISTICS:MARKer&lt;x&gt;:PEAK:HIGHer</code>
<b>Related Commands</b>	<a href="#">CALCulate:PULSE:STATISTICS:MARKer&lt;x&gt;:PEAK:LOWer</a>
<b>Arguments</b>	None
<b>Examples</b>	<code>CALCULATE:PULSE:STATISTICS:MARKER1:PEAK:HIGHER</code> moves Marker 1 (M1) to the next peak higher in amplitude on the trace.

### **CALCulate:PULSE:STATISTICS:MARKer<x>:PEAK:LEFT (No Query Form)**

Moves the selected marker to the next peak to the left on the pulse statistics trace. This command is valid when [DISPlay:PULSE:STATISTICS:PLOT](#) is set to FFT.

<b>Conditions</b>	Measurement views: Pulse statistics
<b>Group</b>	Calculate commands

**Syntax**      `CALCulate:PULSE:STATISTICS:MARKer<x>:PEAK:LEFT`

**Related Commands**      [CALCulate:PULSE:STATISTICS:MARKer<x>:PEAK:RIGHT](#)

**Arguments**      None

**Examples**      `CALCULATE:PULSE:STATISTICS:MARKER1:PEAK:LEFT` moves Marker 1 (M1) to the next peak to the left on the trace.

### **CALCulate:PULSE:STATISTICS:MARKer<x>:PEAK:LOWer (No Query Form)**

Moves the selected marker to the next peak lower in amplitude on the pulse statistics trace. This command is valid when [DISPlay:PULSE:STATISTICS:PLOT](#) is set to FFT.

**Conditions**      Measurement views: Pulse statistics

**Group**      Calculate commands

**Syntax**      `CALCulate:PULSE:STATISTICS:MARKer<x>:PEAK:LOWer`

**Related Commands**      [CALCulate:PULSE:STATISTICS:MARKer<x>:PEAK:HIGHer](#)

**Arguments**      None

**Examples**      `CALCULATE:PULSE:STATISTICS:MARKER1:PEAK:LOWER` moves Marker 1 (M1) to the next peak lower in amplitude on the trace.

### **CALCulate:PULSE:STATISTICS:MARKer<x>:PEAK:RIGHT (No Query Form)**

Moves the selected marker to the next peak to the right on the pulse statistics trace. This command is valid when [DISPlay:PULSE:STATISTICS:PLOT](#) is set to FFT.

**Conditions**      Measurement views: Pulse statistics

**Group**      Calculate commands



**Syntax**     `CALCulate:PULSE:STATistics:MARKer<x>:PEAK:RIGHT`

**Related Commands**     [CALCulate:PULSE:STATistics:MARKer<x>:PEAK:LEFT](#)

**Arguments**     None

**Examples**     `CALCULATE:PULSE:STATISTICS:MARKER1:PEAK:RIGHT` moves Marker 1 (M1) to the next peak to the right on the trace.

## **CALCulate:PULSE:STATistics:MARKer<x>:X**

Sets or queries the horizontal position of the selected marker in the pulse statistics view. This command is valid when [DISPlay:PULSE:STATistics:PLOT](#) is set to FFT.

**Conditions**     Measurement views: Pulse statistics

**Group**     Calculate commands

**Syntax**     `CALCulate:PULSE:STATistics:MARKer<x>:X <value>`  
`CALCulate:PULSE:STATistics:MARKer<x>:X?`

**Related Commands**     [CALCulate:PULSE:STATistics:MARKer<x>:Y?](#)

**Arguments**     `<value> ::= <NRf>` specifies the horizontal position of the marker.  
 Range: 0 to half of the average repetition rate for all detected pulses in Hz.

**Examples**     `CALCULATE:PULSE:STATISTICS:MARKER1:X 12.5kHz` places Marker 1 (M1) at 12.5 kHz on the trace.

## **CALCulate:PULSE:STATistics:MARKer<x>:Y? (Query Only)**

Queries the marker amplitude of the selected marker in the pulse statistics view. This command is valid when [DISPlay:PULSE:STATistics:PLOT](#) is set to FFT.

**Conditions**     Measurement views: Pulse statistics

<b>Group</b>	Calculate commands
<b>Syntax</b>	CALCulate:PULSe:STATistics:MARKer<x>:Y?
<b>Related Commands</b>	<a href="#">CALCulate:PULSe:STATistics:MARKer&lt;x&gt;:X</a>
<b>Arguments</b>	None
<b>Returns</b>	<NRF> Marker amplitude of the selected marker.
<b>Examples</b>	CALCULATE:PULSE:STATISTICS:MARKER1:Y? might return -28.173, indicating Marker 1 (M1) is at -28.173 dB.

## CALCulate:PULSe:TRACe:MARKer<x>:DELTA:X? (Query Only)

Returns the delta marker time for the selected marker on the pulse trace.

The parameter <x> = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

<b>Conditions</b>	Measurement views: Pulse trace
<b>Group</b>	Calculate commands
<b>Syntax</b>	CALCulate:PULSe:TRACe:MARKer<x>:DELTA:X?
<b>Related Commands</b>	<a href="#">CALCulate:PULSe:TRACe:MARKer&lt;x&gt;:DELTA:Y?</a>
<b>Arguments</b>	None
<b>Returns</b>	<NRF>Delta marker time for the selected marker.
<b>Examples</b>	CALCULATE:PULSE:TRACE:MARKER1:DELTA:X? might return 38.0E-9, indicating that the delta marker time is 38.0 ns.

## CALCulate:PULSe:TRACe:MARKer<x>:DELTA:Y? (Query Only)

Returns the delta marker amplitude for the selected marker on the pulse trace.

The parameter <x> = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

**Conditions** Measurement views: Pulse trace

**Group** Calculate commands

**Syntax** CALCulate:PULSe:TRACe:MARKer<x>:DELTA:Y?

**Related Commands** [CALCulate:PULSe:TRACe:MARKer<x>:DELTA:X?](#)

**Arguments** None

**Returns** <NRf> Delta marker amplitude for the selected marker.

**Examples** CALCULATE:PULSE:TRACE:MARKER1:DELTA:Y? might return 23.45, indicating that the delta marker amplitude is 23.45 dB.

## CALCulate:PULSe:TRACe:MARKer<x>:MAXimum (No Query Form)

Moves the selected marker to the highest peak on the pulse trace.

**Conditions** Measurement views: Pulse trace

**Group** Calculate commands

**Syntax** CALCulate:PULSe:TRACe:MARKer<x>:MAXimum

**Arguments** None

**Examples** CALCULATE:PULSE:TRACE:MARKER1:MAXIMUM moves Marker 1 (M1) to the highest peak on the trace.

## CALCulate:PULSe:TRACe:MARKer<x>:PEAK:HIGHer (No Query Form)

Moves the selected marker to the next peak higher in amplitude on the pulse trace.

**Conditions** Measurement views: Pulse trace

**Group** Calculate commands

**Syntax** CALCulate:PULSe:TRACe:MARKer<x>:PEAK:HIGHer

**Related Commands** [CALCulate:PULSe:TRACe:MARKer<x>:PEAK:LOWer](#)

**Arguments** None

**Examples** CALCULATE:PULSE:TRACE:MARKER1:PEAK:HIGHER moves Marker 1 (M1) to the next peak higher in amplitude on the trace.

## CALCulate:PULSe:TRACe:MARKer<x>:PEAK:LEFT (No Query Form)

Moves the selected marker to the next peak to the left on the pulse trace.

**Conditions** Measurement views: Pulse trace

**Group** Calculate commands

**Syntax** CALCulate:PULSe:TRACe:MARKer<x>:PEAK:LEFT

**Related Commands** [CALCulate:PULSe:TRACe:MARKer<x>:PEAK:RIGHT](#)

**Arguments** None

**Examples** CALCULATE:PULSE:TRACE:MARKER1:PEAK:LEFT moves Marker 1 (M1) to the next peak to the left on the trace.

## CALCulate:PULSe:TRACe:MARKer<x>:PEAK:LOWer (No Query Form)

Moves the selected marker to the next peak lower in amplitude on the pulse trace.

**Conditions** Measurement views: Pulse trace

**Group** Calculate commands

**Syntax** CALCulate:PULSe:TRACe:MARKer<x>:PEAK:LOWer

**Related Commands** [CALCulate:PULSe:TRACe:MARKer<x>:PEAK:HIGHer](#)

**Arguments** None

**Examples** CALCULATE:PULSE:TRACE:MARKER1:PEAK:LOWER moves Marker 1 (M1) to the next peak lower in amplitude on the trace.

## CALCulate:PULSe:TRACe:MARKer<x>:PEAK:RIGHT (No Query Form)

Moves the selected marker to the next peak to the right on the pulse trace.

**Conditions** Measurement views: Pulse trace

**Group** Calculate commands

**Syntax** CALCulate:PULSe:TRACe:MARKer<x>:PEAK:RIGHT

**Related Commands** [CALCulate:PULSe:TRACe:MARKer<x>:PEAK:LEFT](#)

**Arguments** None

**Examples** CALCULATE:PULSE:TRACE:MARKER1:PEAK:RIGHT moves Marker 1 (M1) to the next peak to the right on the trace.

## CALCulate:PULSe:TRACe:MARKer<x>:X

Sets or queries the horizontal position of the selected marker in the pulse trace view.

**Conditions** Measurement views: Pulse trace

**Group** Calculate commands

**Syntax** CALCulate:PULSe:TRACe:MARKer<x>:X <value>  
CALCulate:PULSe:TRACe:MARKer<x>:X?

**Related Commands** [CALCulate:PULSe:TRACe:MARKer<x>:Y?](#)

**Arguments** <value>::=<NRf> specifies the horizontal position of the marker.

---

**NOTE.** To set the horizontal position, the marker must be on the trace of the pulse selected using the [DISPlay:PULSe:SElect:NUMBer](#) command. You cannot put the marker out of the horizontal range of the pulse.

---

**Examples** CALCULATE:PULSE:TRACE:MARKER1:X 1.5us places Marker 1 (M1) at 1.5  $\mu$ s on the trace.

## CALCulate:PULSe:TRACe:MARKer<x>:Y? (Query Only)

Queries the marker amplitude of the selected marker in the pulse trace view.

**Conditions** Measurement views: Pulse trace

**Group** Calculate commands

**Syntax** CALCulate:PULSe:TRACe:MARKer<x>:Y?

**Related Commands** [CALCulate:PULSe:TRACe:MARKer<x>:X](#)

**Arguments** None

**Returns** <Nrf> Marker amplitude of the selected marker.

**Examples** CALCULATE:PULSE:TRACE:MARKER1:Y? might return -28.86, indicating Marker 1 (M1) is at -28.86 dBm.

## CALCulate:SEARch:LIMit:FAIL? (Query Only)

Queries whether the waveform cuts across the limit in the search operation.

**Conditions** Measurement views: All

**Group** Calculate commands

**Syntax** CALCulate:SEARch:LIMit:FAIL?

**Arguments** None

**Returns** { 0 | 1 }

0 represents Pass, indicating that the waveform does not cut across the limit.

1 represents Fail, indicating that the waveform cuts across the limit.

**Examples** CALCULATE:SEARCH:LIMIT:FAIL? might return 1, indicating that the waveform cuts across the limit (Fail).

## CALCulate:SEARch:LIMit:MATCH:BEEP[:STATe]

Determines whether or not to beep on match during run or replay in the search operation.

**Conditions** Measurement views: All

**Group** Calculate commands

**Syntax** CALCulate:SEARch:LIMit:MATCH:BEEP[:STATe] { OFF | ON | 0 | 1 }  
CALCulate:SEARch:LIMit:MATCH:BEEP[:STATe]?

**Arguments** OFF or 0 disables to beep on match.  
ON or 1 enables to beep on match.

**Examples** CALCULATE:SEARCH:LIMIT:MATCH:BEEP:STATE ON enables to beep on match.

## CALCulate:SEARCh:LIMit:MATCH:SACQuire[:STATe]

Determines whether or not to stop acquiring data on match during run or replay in the search operation.

**Conditions** Measurement views: All

**Group** Calculate commands

**Syntax** CALCulate:SEARCh:LIMit:MATCH:SACQuire[:STATe] { OFF | ON | 0 | 1 }  
CALCulate:SEARCh:LIMit:MATCH:SACQuire[:STATe]?

**Arguments** OFF or 0 disables to stop acquiring data on match.  
ON or 1 enables to stop acquiring data on match.

**Examples** CALCULATE:SEARCH:LIMIT:MATCH:SACQUIRE:STATE ON enables to stop acquiring data on match.

## CALCulate:SEARCh:LIMit:MATCH:SDATa[:STATe]

Determines whether or not to save automatically (AutoSave) acquisition data on match during run in the search operation.

**Conditions** Measurement views: All

**Group** Calculate commands

**Syntax** CALCulate:SEARCh:LIMit:MATCH:SDATa[:STATe] { OFF | ON | 0 | 1 }  
CALCulate:SEARCh:LIMit:MATCH:SDATa[:STATe]?



- Arguments** OFF or 0 disables the AutoSave.  
ON or 1 enables to save acquisition data automatically on match.  
The data is saved to a file with the name:  
`<name>-yyyy.mm.dd.hh.mm.ss.sss.tiq`  
Where  
`<name>` is the file name that was last specified.  
yyyy.mm.dd and hh.mm.ss.sss represent date and 24 hour time.  
The file extension is .tiq.  
Example: SAVED-2007.03.20.12.34.567.tiq  
For the directory of file, refer to *Specifying the File* (See page 2-44.) in the MMEMory command section.
- Examples** CALCULATE:SEARCH:LIMIT:MATCH:SDATA:STATE ON enables to save acquisition data automatically on match.

## CALCulate:SEARCh:LIMit:MATCH:SPICture[:STATE]

Determines whether or not to save automatically (AutoSave) the whole screen on match during run in the search operation.

- Conditions** Measurement views: All
- Group** Calculate commands
- Syntax** CALCulate:SEARCh:LIMit:MATCH:SPICture[:STATE] { OFF | ON | 0 | 1 }  
CALCulate:SEARCh:LIMit:MATCH:SPICture[:STATE]?
- Arguments** OFF or 0 disables the AutoSave.  
ON or 1 enables to save the whole screen automatically on match.  
The picture is saved to a file with the name:  
`<name>-yyyy.mm.dd.hh.mm.ss.sss.png`  
Where  
`<name>` is the file name that was last specified.  
yyyy.mm.dd and hh.mm.ss.sss represent date and 24 hour time.  
The file extension is .png.  
Example: SAVED-2007.03.20.12.34.567.png

For the directory of file, refer to *Specifying the File* (See page 2-44.) in the MMEMory command section.

**Examples** CALCULATE:SEARCH:LIMIT:MATCH:SPICTURE:STATE ON enables to save the whole screen automatically on match.

## CALCulate:SEARCh:LIMit:MATCh:STRace[:STATe]

Determines whether or not to save automatically (AutoSave) the spectrum trace on match during run in the search operation.

**Conditions** Measurement views: All

**Group** Calculate commands

**Syntax** CALCulate:SEARCh:LIMit:MATCh:STRace[:STATe] { OFF | ON | 0 | 1 }  
CALCulate:SEARCh:LIMit:MATCh:STRace[:STATe]?

**Arguments** OFF or 0 disables the AutoSave.  
ON or 1 enables to save the spectrum trace automatically on match.  
The trace is saved to a file with the name:

<name>-yyyy.mm.dd.hh.mm.ss.sss.Specan

Where

<name> is the file name that was last specified.

yyyy.mm.dd and hh.mm.ss.sss represent date and 24 hour time.

The file extension is .Specan.

Example: SAVED-2007.03.20.12.34.567.Specan

For the directory of file, refer to *Specifying the File* (See page 2-44.) in the MMEMory command section.

**Examples** CALCULATE:SEARCH:LIMIT:MATCH:STRACE:STATE ON enables to save the spectrum trace automatically on match.

## CALCulate:SEARCh:LIMit:OPERation

Selects or queries the search condition.

**Conditions** Measurement views: All

**Group** Calculate commands

**Syntax** CALCulate:SEARCH:LIMit:OPERation { LT | GT | IMASK | OMASK }  
CALCulate:SEARCH:LIMit:OPERation?

**Related Commands** [CALCulate:SEARCh:LIMit:OPERation:SLIMit](#)

**Arguments** The following table lists the arguments.

#### Search condition

Argument	Meaning
LT	The data is less than the limit value.
GT	The data is greater than the limit value.
IMASK	The data is inside the limit mask.
OMASK	The data is outside the limit mask.

You can select the data using the [CALCulate:SEARCh:LIMit:OPERation:FEED](#) command.

You can set the limit value using the [CALCulate:SEARCh:LIMit:OPERation:SLIMit](#) command.

You can store and load the limit mask using the [CALCulate:SEARCh:LIMit:OPERation:MASK:STORE](#) and [CALCulate:SEARCh:LIMit:OPERation:MASK:LOAD](#) commands.

**Examples** CALCULATE:SEARCH:LIMIT:OPERATION GT selects "the data is greater than the limit value" for the search condition.

## CALCulate:SEARCh:LIMit:OPERation:FEED

Sets or queries the data flow to be fed in the search operation.

**Conditions** Measurement views: All

**Group** Calculate commands

**Syntax**     CALCulate:SEARCH:LIMit:OPERation:FEED <view>,<trace>  
 CALCulate:SEARCH:LIMit:OPERation:FEED?

**Arguments**     <view>::=<string> and <trace>::=<string> are listed in the following table.

**Source data of the search operation**

<view>	<trace>	Meaning
"Spectrum"	"Trace 1" <sup>1</sup>	Trace 1 in the Spectrum view.
	"Trace 2" <sup>1</sup>	Trace 2 in the Spectrum view.
	"Trace 3" <sup>1</sup>	Trace 3 in the Spectrum view.
	"Math Trace"	Math trace in the Spectrum view.
	"Spectrogram Trace"	Spectrogram trace in the Spectrum view.

<sup>1</sup> There is a space character between Trace and the number.

**Examples**     CALCULATE:SEARCH:LIMIT:OPERATION:FEED "Spectrum","Trace 1"  
 selects the Trace 1 in the Spectrum measurement view for the search operation.

CALCULATE:SEARCH:LIMIT:OPERATION:FEED? might return  
 "Spectrum","Math Trace", indicating that the math trace is used as the source data in the search operation.

## CALCulate:SEARch:LIMit:OPERation:MASK:LOAD (No Query Form)

Loads the limit mask from a specified file for the search operation.

**Conditions**     Measurement views: All

**Group**     Calculate commands

**Syntax**     CALCulate:SEARCH:LIMit:OPERation:MASK:LOAD <file\_name>

**Arguments**     <file\_name>::=<string> specifies the file to load the limit mask from. The file extension is .lmt. You can omit the extension.

For the directory of file, refer to *Specifying the File* (See page 2-44.) in the MMEMory command section.

**Examples**     CALCULATE:SEARCH:LIMIT:OPERATION:MASK:LOAD "Limit1" loads the limit mask from the *Limit1.lmt* file.

## CALCulate:SEARch:LIMit:OPERation:MASK:STORE (No Query Form)

Stores the limit mask to a specified file in the search operation.

<b>Conditions</b>	Measurement views: All
<b>Group</b>	Calculate commands
<b>Syntax</b>	CALCulate:SEARch:LIMit:OPERation:MASK:STORE <file_name>
<b>Arguments</b>	<p>&lt;file_name&gt; ::= &lt;string&gt; specifies the file to store the limit mask to. The file extension is .lmt. You can omit the extension.</p> <p>For the directory of file, refer to <i>Specifying the File</i> (See page 2-44.) in the MMEMory command section.</p>
<b>Examples</b>	CALCULATE:SEARCH:LIMIT:OPERATION:MASK:STORE "Limit1" stores the limit mask to the <i>Limit1.lmt</i> file.

## CALCulate:SEARch:LIMit:OPERation:SLIMit

Sets or queries the limit value in the search operation.

<b>Conditions</b>	Measurement views: All
<b>Group</b>	Calculate commands
<b>Syntax</b>	<p>CALCulate:SEARch:LIMit:OPERation:SLIMit &lt;value&gt;</p> <p>CALCulate:SEARch:LIMit:OPERation:SLIMit?</p>
<b>Related Commands</b>	<a href="#">CALCulate:SEARch:LIMit:OPERation</a>
<b>Arguments</b>	<p>&lt;value&gt; ::= &lt;NRF&gt; specifies the limit value in the search operation. Range: -100 to +100 dBm.</p>
<b>Examples</b>	CALCULATE:SEARCH:LIMIT:OPERATION:SLIMIT -20 sets the limit value to -20 dBm.

## CALCulate:SEARch:LIMit:REPort:DATA? (Query Only)

Returns the frequency range(s) that satisfy the search condition.

**Conditions** Measurement views: All

**Group** Calculate commands

**Syntax** CALCulate:SEARch:LIMit:REPort:DATA?

**Arguments** None

**Returns** <num\_range>, <range(1)>, <range(2)>, . . . , <range(n)>

Where

<num\_range> ::= <NR1> is the number of ranges that satisfy the condition.

<range(n)> ::= "<lower\_freq(n)>, <upper\_freq(n)>" (string)

represents the  $n^{\text{th}}$  frequency range that satisfy the search condition in ascending order. <lower\_freq(n)> and <upper\_freq(n)> are the lower and upper frequencies of the range #n, respectively.

**Examples** CALCULATE:SEARCH:LIMIT:REPORT:DATA? might return 2, "1.4800E+9, 1.5001E+9", "1.5002E+9, 1.5200E+9", indicating that the search condition is satisfied in these two ranges 1.48 to 1.5001 GHz and 1.5002 to 1.52 GHz.

## CALCulate:SEARch:LIMit:REPort:POINTs? (Query Only)

Returns the number of frequency range(s) that satisfy the search condition.

**Conditions** Measurement views: All

**Group** Calculate commands

**Syntax** CALCulate:SEARch:LIMit:REPort:POINTs?

**Arguments** None

**Returns** <number> ::= <NR1> represents the number of frequency range(s) that satisfy the search condition.

**Examples** CALCULATE:SEARCH:LIMIT:REPORT:POINTS? might return 5, indicating that five ranges satisfy the search condition.

## CALCulate:SEARch:LIMit:STATe

Determines whether to enable or disable the search function.

**Conditions** Measurement views: All

**Group** Calculate commands

**Syntax** CALCulate:SEARch:LIMit:STATe { OFF | ON | 0 | 1 }  
CALCulate:SEARch:LIMit:STATe?

**Arguments** OFF or 0 disables the search function.

ON or 1 enables the search function.

**Examples** CALCULATE:SEARCH:LIMIT:STATE ON enables the search function.

## CALCulate:SGRam:MARKer<x>:DELTA:X:FREQuency? (Query Only)

Returns the delta marker frequency for the selected marker in the spectrogram.

The parameter <x> = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

**Conditions** Measurement views: Spectrogram

**Group** Calculate commands

**Syntax** CALCulate:SGRam:MARKer<x>:DELTA:X:FREQuency?

**Related Commands** [CALCulate:SGRam:MARKer<x>:DELTA:Y?](#)

<b>Arguments</b>	None
<b>Returns</b>	<NRF> Delta marker frequency for the selected marker.
<b>Examples</b>	CALCULATE:SGRAM:MARKER1:DELTA:X:FREQUENCY? might return 5.95E+6, indicating that the delta marker frequency is 5.95 MHz.

## CALCulate:SGRam:MARKer<x>:DELTA:X[:TIME]? (Query Only)

Returns the delta marker time for the selected marker in the spectrogram.

The parameter <x> = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

<b>Conditions</b>	Measurement views: Spectrogram
<b>Group</b>	Calculate commands
<b>Syntax</b>	CALCulate:SGRam:MARKer<x>:DELTA:X[:TIME]?
<b>Related Commands</b>	<a href="#">CALCulate:SGRam:MARKer&lt;x&gt;:DELTA:Y?</a>
<b>Arguments</b>	None
<b>Returns</b>	<NRF> Delta marker time for the selected marker.
<b>Examples</b>	CALCULATE:SGRAM:MARKER1:DELTA:X:TIME? might return -1.84E-3, indicating that the delta marker time is -1.84 ms.

## CALCulate:SGRam:MARKer<x>:DELTA:Y? (Query Only)

Returns the delta marker amplitude for the selected marker in the spectrogram.

The parameter <x> = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.



---

<b>Conditions</b>	Measurement views: Spectrogram
<b>Group</b>	Calculate commands
<b>Syntax</b>	<code>CALCulate:SGRam:MARKer&lt;x&gt;:DELTA:Y?</code>
<b>Related Commands</b>	<a href="#">CALCulate:SGRam:MARKer&lt;x&gt;:DELTA:X[:TIME]?</a>
<b>Arguments</b>	None
<b>Returns</b>	<NRf> Delta marker amplitude for the selected marker.
<b>Examples</b>	<code>CALCULATE:SGRAM:MARKER1:DELTA:Y?</code> might return <code>-8.45</code> , indicating that the delta marker amplitude is <code>-8.45</code> dB.

## **CALCulate:SGRam:MARKer<x>:MAXimum (No Query Form)**

Moves the selected marker to the highest peak on a line in the spectrogram. The line is selected using the [TRACe:SGRam:SElect:LINE](#) command.

<b>Conditions</b>	Measurement views: Spectrogram
<b>Group</b>	Calculate commands
<b>Syntax</b>	<code>CALCulate:SGRam:MARKer&lt;x&gt;:MAXimum</code>
<b>Arguments</b>	None
<b>Examples</b>	<code>CALCULATE:SGRAM:MARKER1:MAXIMUM</code> moves Marker 1 (M1) to the highest peak on the line.

## **CALCulate:SGRam:MARKer<x>:PEAK:HIGHer (No Query Form)**

Moves the selected marker to the next peak higher in amplitude on a line in the spectrogram. The line is selected using the [TRACe:SGRam:SElect:LINE](#) command.

<b>Conditions</b>	Measurement views: Spectrogram
<b>Group</b>	Calculate commands
<b>Syntax</b>	<code>CALCulate:SGRam:MARKer&lt;x&gt;:PEAK:HIGHer</code>
<b>Related Commands</b>	<a href="#">CALCulate:SGRam:MARKer&lt;x&gt;:PEAK:LOWer</a>
<b>Arguments</b>	None
<b>Examples</b>	<code>CALCULATE:SGRAM:MARKER1:PEAK:HIGHER</code> moves Marker 1 (M1) to the next peak higher in amplitude on the line.

### **CALCulate:SGRam:MARKer<x>:PEAK:LEFT (No Query Form)**

Moves the selected marker to the next peak to the left on a line in the spectrogram. The line is selected using the [TRACe:SGRam:SElect:LINE](#) command.

<b>Conditions</b>	Measurement views: Spectrogram
<b>Group</b>	Calculate commands
<b>Syntax</b>	<code>CALCulate:SGRam:MARKer&lt;x&gt;:PEAK:LEFT</code>
<b>Related Commands</b>	<a href="#">CALCulate:SGRam:MARKer&lt;x&gt;:PEAK:RIGHT</a>
<b>Arguments</b>	None
<b>Examples</b>	<code>CALCULATE:SGRAM:MARKER1:PEAK:LEFT</code> moves Marker 1 (M1) to the next peak to the left on the line.

### **CALCulate:SGRam:MARKer<x>:PEAK:LOWer (No Query Form)**

Moves the selected marker to the next peak lower in amplitude on a line in the spectrogram. The line is selected using the [TRACe:SGRam:SElect:LINE](#) command.

---

<b>Conditions</b>	Measurement views: Spectrogram
<b>Group</b>	Calculate commands
<b>Syntax</b>	<code>CALCulate:SGRam:MARKer&lt;x&gt;:PEAK:LOWer</code>
<b>Related Commands</b>	<a href="#">CALCulate:SGRam:MARKer&lt;x&gt;:PEAK:HIGHer</a>
<b>Arguments</b>	None
<b>Examples</b>	<code>CALCULATE:SGRAM:MARKER1:PEAK:LOWER</code> moves Marker 1 (M1) to the next peak lower in amplitude on the line.

### **CALCulate:SGRam:MARKer<x>:PEAK:RIGHT (No Query Form)**

Moves the selected marker to the next peak to the right on a line in the spectrogram. The line is selected using the [TRACe:SGRam:SElect:LINE](#) command.

<b>Conditions</b>	Measurement views: Spectrogram
<b>Group</b>	Calculate commands
<b>Syntax</b>	<code>CALCulate:SGRam:MARKer&lt;x&gt;:PEAK:RIGHT</code>
<b>Related Commands</b>	<a href="#">CALCulate:SGRam:MARKer&lt;x&gt;:PEAK:LEFT</a>
<b>Arguments</b>	None
<b>Examples</b>	<code>CALCULATE:SGRAM:MARKER1:PEAK:RIGHT</code> moves Marker 1 (M1) to the next peak to the right on the trace.

### **CALCulate:SGRam:MARKer<x>[:SET]:CENTer (No Query Form)**

Sets the center frequency to the marker frequency in the spectrogram.

<b>Conditions</b>	Measurement views: Spectrogram
-------------------	--------------------------------

<b>Group</b>	Calculate commands
<b>Syntax</b>	<code>CALCulate:SGRam:MARKer&lt;x&gt;[:SET]:CENTER</code>
<b>Arguments</b>	None
<b>Examples</b>	<code>CALCULATE:SGRAM:MARKER1:SET:CENTER</code> sets the center frequency to the Marker 1 frequency in the spectrogram.

## **CALCulate:SGRam:MARKer<x>:X:FREQuency**

Sets or queries the marker frequency in the spectrogram.

<b>Conditions</b>	Measurement views: Spectrogram
<b>Group</b>	Calculate commands
<b>Syntax</b>	<code>CALCulate:SGRam:MARKer&lt;x&gt;:X:FREQuency &lt;value&gt;</code> <code>CALCulate:SGRam:MARKer&lt;x&gt;:X:FREQuency?</code>
<b>Related Commands</b>	<a href="#">CALCulate:SGRam:MARKer&lt;x&gt;:Y?</a>
<b>Arguments</b>	<code>&lt;value&gt;::=&lt;Nrf&gt;</code> specifies the marker frequency. Range: (center frequency) ± (span)/2.
<b>Examples</b>	<code>CALCULATE:SGRAM:MARKER1:X 800MHZ</code> places Marker 1 (M1) at 800 MHz on the trace.

## **CALCulate:SGRam:MARKer<x>:X[:TIME]**

Sets or queries the marker time in the spectrogram.

<b>Conditions</b>	Measurement views: Spectrogram
<b>Group</b>	Calculate commands

**Syntax**     `CALCulate:SGRam:MARKer<x>:X[:TIME] <value>`  
`CALCulate:SGRam:MARKer<x>:X[:TIME]?`

**Related Commands**     [CALCulate:SGRam:MARKer<x>:Y?](#)

**Arguments**     `<value>::=<NRF>` specifies the marker time.

**Examples**     `CALCULATE:SGRAM:MARKER1:X:TIME -234.5us` places Marker 1 (M1) at -234.5  $\mu$ s on the trace.

## CALCulate:SGRam:MARKer<x>:Y? (Query Only)

Queries the marker amplitude in the spectrogram.

**Conditions**     Measurement views: Spectrogram

**Group**     Calculate commands

**Syntax**     `CALCulate:SGRam:MARKer<x>:Y?`

**Related Commands**     [CALCulate:SGRam:MARKer<x>:X\[:TIME\]](#)

**Arguments**     None

**Returns**     `<NRF>` Marker amplitude of the selected marker.

**Examples**     `CALCULATE:SGRAM:MARKER1:Y?` might return `-34.28`, indicating Marker 1 (M1) is at -34.28 dBm.

## CALCulate:SPECTrum:MARKer<x>:DELTA:X? (Query Only)

Returns the delta marker frequency for the selected marker on the spectrum trace.

The parameter `<x>` = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

**Conditions**     Measurement views: Spectrum

<b>Group</b>	Calculate commands
<b>Syntax</b>	<code>CALCulate:SPECTrum:MARKer&lt;x&gt;:DELTA:X?</code>
<b>Related Commands</b>	<a href="#">CALCulate:SPECTrum:MARKer&lt;x&gt;:DELTA:Y?</a>
<b>Arguments</b>	None
<b>Returns</b>	<NRF> Delta marker frequency for the selected marker.
<b>Examples</b>	<code>CALCULATE:SPECTRUM:MARKER1:DELTA:X?</code> might return <code>1.28E+6</code> , indicating that the delta marker frequency is 1.28 MHz.

## **CALCulate:SPECTrum:MARKer<x>:DELTA:Y? (Query Only)**

Returns the delta marker amplitude for the selected marker on the spectrum trace.

The parameter <x> = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

<b>Conditions</b>	Measurement views: Spectrum
<b>Group</b>	Calculate commands
<b>Syntax</b>	<code>CALCulate:SPECTrum:MARKer&lt;x&gt;:DELTA:Y?</code>
<b>Related Commands</b>	<a href="#">CALCulate:SPECTrum:MARKer&lt;x&gt;:DELTA:X?</a>
<b>Arguments</b>	None
<b>Returns</b>	<NRF> Delta marker amplitude for the selected marker.
<b>Examples</b>	<code>CALCULATE:SPECTRUM:MARKER1:DELTA:Y?</code> might return <code>23.45</code> , indicating that the delta marker amplitude is 23.45 dB.

## CALCulate:SPECTrum:MARKer<x>:MAXimum (No Query Form)

Moves the selected marker to the highest peak on the spectrum trace.

**Conditions** Measurement views: Spectrum

**Group** Calculate commands

**Syntax** CALCulate:SPECTrum:MARKer<x>:MAXimum

**Arguments** None

**Examples** CALCULATE:SPECTRUM:MARKER1:MAXIMUM moves Marker 1 (M1) to the highest peak on the trace.

## CALCulate:SPECTrum:MARKer<x>:PEAK:HIGHer (No Query Form)

Moves the selected marker to the next peak higher in amplitude on the spectrum trace.

**Conditions** Measurement views: Spectrum

**Group** Calculate commands

**Syntax** CALCulate:SPECTrum:MARKer<x>:PEAK:HIGHer

**Related Commands** [CALCulate:SPECTrum:MARKer<x>:PEAK:LOWer](#)

**Arguments** None

**Examples** CALCULATE:SPECTRUM:MARKER1:PEAK:HIGHER moves Marker 1 (M1) to the next peak higher in amplitude on the trace.

## CALCulate:SPECTrum:MARKer<x>:PEAK:LEFT (No Query Form)

Moves the selected marker to the next peak to the left on the spectrum trace.

<b>Conditions</b>	Measurement views: Spectrum
<b>Group</b>	Calculate commands
<b>Syntax</b>	<code>CALCulate:SPECTrum:MARKer&lt;x&gt;:PEAK:LEFT</code>
<b>Related Commands</b>	<a href="#">CALCulate:SPECTrum:MARKer&lt;x&gt;:PEAK:RIGHT</a>
<b>Arguments</b>	None
<b>Examples</b>	<code>CALCULATE:SPECTRUM:MARKER1:PEAK:LEFT</code> moves Marker 1 (M1) to the next peak to the left on the trace.

### **CALCulate:SPECTrum:MARKer<x>:PEAK:LOWer (No Query Form)**

Moves the selected marker to the next peak lower in amplitude on the spectrum trace.

<b>Conditions</b>	Measurement views: Spectrum
<b>Group</b>	Calculate commands
<b>Syntax</b>	<code>CALCulate:SPECTrum:MARKer&lt;x&gt;:PEAK:LOWer</code>
<b>Related Commands</b>	<a href="#">CALCulate:SPECTrum:MARKer&lt;x&gt;:PEAK:HIGHer</a>
<b>Arguments</b>	None
<b>Examples</b>	<code>CALCULATE:SPECTRUM:MARKER1:PEAK:LOWER</code> moves Marker 1 (M1) to the next peak lower in amplitude on the trace.

### **CALCulate:SPECTrum:MARKer<x>:PEAK:RIGHT (No Query Form)**

Moves the selected marker to the next peak to the right on the spectrum trace.

<b>Conditions</b>	Measurement views: Spectrum
-------------------	-----------------------------



---

<b>Group</b>	Calculate commands
<b>Syntax</b>	<code>CALCulate:SPECTrum:MARKer&lt;x&gt;:PEAK:RIGHT</code>
<b>Related Commands</b>	<a href="#">CALCulate:SPECTrum:MARKer&lt;x&gt;:PEAK:LEFT</a>
<b>Arguments</b>	None
<b>Examples</b>	<code>CALCULATE:SPECTRUM:MARKER1:PEAK:RIGHT</code> moves Marker 1 (M1) to the next peak to the right on the trace.

### **CALCulate:SPECTrum:MARKer<x>[:SET]:CENTer (No Query Form)**

Sets the center frequency to the marker frequency in the spectrum measurement.

<b>Conditions</b>	Measurement views: Spectrum
<b>Group</b>	Calculate commands
<b>Syntax</b>	<code>CALCulate:SPECTrum:MARKer&lt;x&gt;[:SET]:CENTer</code>
<b>Arguments</b>	None
<b>Examples</b>	<code>CALCULATE:SPECTRUM:MARKER1:SET:CENTER</code> sets the center frequency to the marker frequency in the spectrum measurement.

### **CALCulate:SPECTrum:MARKer<x>:TRACe**

Selects or queries the trace on which the specified marker is placed in the spectrum measurement.

<b>Conditions</b>	Measurement views: Spectrum
<b>Group</b>	Calculate commands

**Syntax**    `CALCulate:SPECTrum:MARKer<x>:TRACe { TRACE1 | TRACE2 | TRACE3 | TRACE4 | TRACE5 }`  
`CALCulate:SPECTrum:MARKer<x>:TRACe?`

**Arguments**    TRACE1 places the specified marker on Trace 1.  
TRACE2 places the specified marker on Trace 2.  
TRACE3 places the specified marker on n Trace 3.  
TRACE4 places the specified marker on Trace 4 (math trace).  
TRACE5 places the specified marker on Trace 5 (spectrogram).  
Trace 1 to 3 can be defined as Normal, Average, Max Hold or Min Hold using the [TRACE<x>:SPECTrum:FUNCTion](#) command.

**Examples**    `CALCULATE:SPECTRUM:MARKER1:TRACE` TRACE1 places Marker 1 (M1) on Trace 1.

## **CALCulate:SPECTrum:MARKer<x>:X**

Sets or queries the horizontal position of the selected marker on the spectrum trace.

**Conditions**    Measurement views: Spectrum

**Group**    Calculate commands

**Syntax**    `CALCulate:SPECTrum:MARKer<x>:X <value>`  
`CALCulate:SPECTrum:MARKer<x>:X?`

**Related Commands**    [CALCulate:SPECTrum:MARKer<x>:Y?](#)

**Arguments**    `<value>::=<nrf>` specifies the horizontal position of the marker.  
Range: Start to Stop frequency (left to right edge of the horizontal axis).  
Using an out-of-range value causes an execution error (-222, "Data out of range").

**Examples**    `CALCULATE:SPECTRUM:MARKER1:X 800MHZ` places Marker 1 (M1) at 800 MHz on the spectrum trace.

## CALCulate:SPECTrum:MARKer<x>:Y? (Query Only)

Queries the marker amplitude of the selected marker on the spectrum trace.

**Conditions** Measurement views: Spectrum

**Group** Calculate commands

**Syntax** CALCulate:SPECTrum:MARKer<x>:Y?

**Related Commands** [CALCulate:SPECTrum:MARKer<x>:X](#)

**Arguments** None

**Returns** <NRf> Marker amplitude of the selected marker.

**Examples** CALCULATE:SPECTRUM:MARKER1:Y? might return -34.28, indicating Marker 1 (M1) is at -34.28 dBm.

## CALCulate:SPURious:MARKer<x>:DELTA:X? (Query Only)

Returns the delta marker frequency for the selected marker on the spectrum trace.

The parameter <x> = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

**Conditions** Measurement views: Spurious

**Group** Calculate commands

**Syntax** CALCulate:SPURious:MARKer<x>:DELTA:X?

**Arguments** None

**Returns** <NRf> Delta marker frequency for the selected marker.

**Examples**     `CALCULATE:SPURIOUS:MARKER1:DELTA:X?` might return `1.28E+6`, indicating that the delta marker frequency is 1.28 MHz.

## **CALCulate:SPURious:MARKer<x>:DELTA:Y? (Query Only)**

Returns the delta marker amplitude for the selected marker on the spectrum trace.

The parameter `<x>` = 1 to 4; `MARKer0` (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

**Conditions**     Measurement views: Spurious

**Group**     Calculate commands

**Syntax**     `CALCulate:SPURious:MARKer<x>:DELTA:Y?`

**Arguments**     None

**Returns**     `<NRf>` Delta marker amplitude for the selected marker.

**Examples**     `CALCULATE:SPURIOUS:MARKER1:DELTA:Y?` might return `23.45`, indicating that the delta marker amplitude is 23.45 dB.

## **CALCulate:SPURious:MARKer<x>:MAXimum (No Query Form)**

Moves the selected marker to the highest peak on the spectrum trace.

**Conditions**     Measurement views: Spurious

**Group**     Calculate commands

**Syntax**     `CALCulate:SPURious:MARKer<x>:MAXimum`

**Arguments**     None

**Examples**    `CALCULATE:SPURIOUS:MARKER1:MAXIMUM` moves Marker 1 (M1) to the highest peak on the trace.

## **CALCulate:SPURious:MARKer<x>:PEAK:HIGHer (No Query Form)**

Moves the selected marker to the next peak higher in amplitude on the spectrum trace.

**Conditions**    Measurement views: Spurious

**Group**    Calculate commands

**Syntax**    `CALCulate:SPURious:MARKer<x>:PEAK:HIGHer`

**Arguments**    None

**Examples**    `CALCULATE:SPURIOUS:MARKER1:PEAK:HIGHER` moves Marker 1 (M1) to the next peak higher in amplitude on the trace.

## **CALCulate:SPURious:MARKer<x>:PEAK:LEFT (No Query Form)**

Moves the selected marker to the next peak to the left on the spectrum trace.

**Conditions**    Measurement views: Spurious

**Group**    Calculate commands

**Syntax**    `CALCulate:SPURious:MARKer<x>:PEAK:LEFT`

**Arguments**    None

**Examples**    `CALCULATE:SPURIOUS:MARKER1:PEAK:LEFT` moves Marker 1 (M1) to the next peak to the left on the trace.

## **CALCulate:SPURious:MARKer<x>:PEAK:LOWer (No Query Form)**

Moves the selected marker to the next peak lower in amplitude on the spectrum trace.

**Conditions** Measurement views: Spurious

**Group** Calculate commands

**Syntax** CALCulate:SPURious:MARKer<x>:PEAK:LOWer

**Arguments** None

**Examples** CALCULATE:SPURIOUS:MARKER1:PEAK:LOWER moves Marker 1 (M1) to the next peak lower in amplitude on the trace.

## **CALCulate:SPURious:MARKer<x>:PEAK:RIGHT (No Query Form)**

Moves the selected marker to the next peak to the right on the spectrum trace.

**Conditions** Measurement views: Spurious

**Group** Calculate commands

**Syntax** CALCulate:SPURious:MARKer<x>:PEAK:RIGHT

**Arguments** None

**Examples** CALCULATE:SPURIOUS:MARKER1:PEAK:RIGHT moves Marker 1 (M1) to the next peak to the right on the trace.

## **CALCulate:SPURious:MARKer<x>[:SET]:CENTer (No Query Form)**

Sets the center frequency to the marker frequency in the Spurious measurement.

**Conditions** Measurement views: Spurious

<b>Group</b>	Calculate commands
<b>Syntax</b>	CALCulate:SPURious:MARKer<x>[:SET]:CENTER
<b>Arguments</b>	None
<b>Examples</b>	CALCULATE:SPURIOUS:MARKER1:SET:CENTER sets the center frequency to the value at Marker 1.

## CALCulate:SPURious:MARKer<x>:X

Sets or queries the horizontal position of the selected marker on the spectrum trace.

<b>Conditions</b>	Measurement views: Spurious
<b>Group</b>	Calculate commands
<b>Syntax</b>	CALCulate:SPURious:MARKer<x>:X <value> CALCulate:SPURious:MARKer<x>:X?
<b>Arguments</b>	<value> ::= <NRF> specifies the horizontal position of the marker. Range: Start to Stop frequency (left to right edge of the horizontal axis).  The start and stop frequencies are set using the <a href="#">DISPlay:SPURious:X[:SCALE]:STARt</a> and <a href="#">DISPlay:SPURious:X[:SCALE]:STOP</a> commands.
<b>Examples</b>	CALCULATE:SPURIOUS:MARKER1:X 800MHZ places Marker 1 (M1) at 800 MHz on the spectrum trace.

## CALCulate:SPURious:MARKer<x>:Y? (Query Only)

Queries the marker amplitude of the selected marker on the spectrum trace.

<b>Conditions</b>	Measurement views: Spurious
<b>Group</b>	Calculate commands

**Syntax**     `CALCulate:SPURious:MARKer<x>:Y?`

**Arguments**     None

**Returns**     <NRF> Marker amplitude of the selected marker.

**Examples**     `CALCULATE:SPURIOUS:MARKER1:Y?` might return `-34.28`, indicating Marker 1 (M1) is at `-34.28` dBm.

## **CALCulate:TDIagram:MARKer<x>:DELTA:X[:TIME]? (Query Only)**

Returns the delta marker time for the selected marker on the Trellis diagram trace.

The parameter <x> = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

**Conditions**     Measurement views: Trellis diagram

**Group**     Calculate commands

**Syntax**     `CALCulate:TDIagram:MARKer<x>:DELTA:X[:TIME]?`

**Related Commands**     [CALCulate:TDIagram:MARKer<x>:DELTA:Y?](#)

**Arguments**     None

**Returns**     <NRF> Delta marker time for the selected marker.  
Use the [\[SENSe\]:DDEMod:TIME:UNITs](#) command to select the time unit: symbols (default) or seconds.

**Examples**     `CALCULATE:TDIAGRAM:MARKER1:DELTA:X:TIME?` might return `62.75`, indicating that the delta marker time is `62.75` symbols.

## **CALCulate:TDIagram:MARKer<x>:DELTA:Y? (Query Only)**

Returns the delta marker amplitude for the selected marker on the Trellis diagram trace.



The parameter <x> = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

<b>Conditions</b>	Measurement views: Trellis diagram
<b>Group</b>	Calculate commands
<b>Syntax</b>	<code>CALCulate:TDIagram:MARKer&lt;x&gt;:DELTA:Y?</code>
<b>Related Commands</b>	<a href="#">CALCulate:TDIagram:MARKer&lt;x&gt;:DELTA:X[:TIME]?</a>
<b>Arguments</b>	None
<b>Returns</b>	<NRf> Delta marker amplitude for the selected marker in degrees.
<b>Examples</b>	<code>CALCULATE:TDIAGRAM:MARKER1:DELTA:Y?</code> might return <code>-48.26</code> , indicating that the delta marker amplitude is <code>-48.26°</code> .

## **CALCulate:TDIagram:MARKer<x>:MAXimum (No Query Form)**

Moves the selected marker to the highest peak on the Trellis diagram trace.

<b>Conditions</b>	Measurement views: Trellis diagram
<b>Group</b>	Calculate commands
<b>Syntax</b>	<code>CALCulate:TDIagram:MARKer&lt;x&gt;:MAXimum</code>
<b>Arguments</b>	None
<b>Examples</b>	<code>CALCULATE:TDIAGRAM:MARKER1:MAXIMUM?</code> moves Marker 1 (M1) to the highest peak on the trace.

## CALCulate:TDIagram:MARKer<x>:PEAK:HIGHer (No Query Form)

Moves the selected marker to the next peak higher in amplitude on the Trellis diagram trace.

**Conditions** Measurement views: Trellis diagram

**Group** Calculate commands

**Syntax** CALCulate:TDIagram:MARKer<x>:PEAK:HIGHer

**Related Commands** [CALCulate:TDIagram:MARKer<x>:PEAK:LOWer](#)

**Arguments** None

**Examples** CALCULATE:TDIAGRAM:MARKER1:PEAK:HIGHER moves Marker 1 (M1) to the next peak higher in amplitude on the trace.

## CALCulate:TDIagram:MARKer<x>:PEAK:LEFT (No Query Form)

Moves the selected marker to the next peak to the left on the Trellis diagram trace.

**Conditions** Measurement views: Trellis diagram

**Group** Calculate commands

**Syntax** CALCulate:TDIagram:MARKer<x>:PEAK:LEFT

**Related Commands** [CALCulate:TDIagram:MARKer<x>:PEAK:RIGHT](#)

**Arguments** None

**Examples** CALCULATE:TDIAGRAM:MARKER1:PEAK:LEFT moves Marker 1 (M1) to the next peak to the left on the trace.

## CALCulate:TDIagram:MARKer<x>:PEAK:LOWer (No Query Form)

Moves the selected marker to the next peak lower in amplitude on the Trellis diagram trace.

**Conditions** Measurement views: Trellis diagram

**Group** Calculate commands

**Syntax** CALCulate:TDIagram:MARKer<x>:PEAK:LOWer

**Related Commands** [CALCulate:TDIagram:MARKer<x>:PEAK:HIGHer](#)

**Arguments** None

**Examples** CALCULATE:TDIAGRAM:MARKER1:PEAK:LOWER moves Marker 1 (M1) to the next peak lower in amplitude on the trace.

## CALCulate:TDIagram:MARKer<x>:PEAK:RIGHt (No Query Form)

Moves the selected marker to the next peak to the right on the Trellis diagram trace.

**Conditions** Measurement views: Trellis diagram

**Group** Calculate commands

**Syntax** CALCulate:TDIagram:MARKer<x>:PEAK:RIGHt

**Related Commands** [CALCulate:TDIagram:MARKer<x>:PEAK:LEFT](#)

**Arguments** None

**Examples** CALCULATE:TDIAGRAM:MARKER1:PEAK:RIGHT moves Marker 1 (M1) to the next peak to the right on the trace.

## CALCulate:TDIagram:MARKer<x>:X[:TIME]

Sets or queries the horizontal position (time) of the selected marker in the Trellis diagram measurement.

**Conditions** Measurement views: Trellis diagram

**Group** Calculate commands

**Syntax** CALCulate:TDIagram:MARKer<x>:X[:TIME] <value>  
CALCulate:TDIagram:MARKer<x>:X[:TIME]?

**Related Commands** [CALCulate:TDIagram:MARKer<x>:Y?](#)

**Arguments** <value>::=<NRF> specifies the horizontal position (time) of the marker. Use the [\[SENSe\]:DDEMod:TIME:UNITs](#) command to select the time unit: symbols (default) or seconds.

**Examples** CALCULATE:TDIAGRAM:MARKER1:X:TIME 38.5 places Marker 1 (M1) at 38.5 symbols on the trace.

## CALCulate:TDIagram:MARKer<x>:Y? (Query Only)

Queries the marker amplitude of the selected marker in the Trellis diagram measurement.

**Conditions** Measurement views: Trellis diagram

**Group** Calculate commands

**Syntax** CALCulate:TDIagram:MARKer<x>:Y?

**Related Commands** [CALCulate:TDIagram:MARKer<x>:X\[:TIME\]](#)

**Arguments** None

**Returns** <NRF> Marker amplitude of the selected marker in degrees.

**Examples**    `CALCULATE:TDIAGRAM:MARKER1:Y?` might return `212.3`, indicating Marker 1 (M1) is at `212.3 °`.

## **CALCulate:TOVerview:MARKer<x>:DELTA:X? (Query Only)**

Returns the delta marker time for the selected marker on the time overview trace.

**Conditions**    Measurement views: Time overview

**Group**    Calculate commands

**Syntax**    `CALCulate:TOVerview:MARKer<x>:DELTA:X?`

**Related Commands**    [CALCulate:TOVerview:MARKer<x>:DELTA:Y?](#)

**Arguments**    None

**Returns**    <NRf> Delta marker time for the selected marker.

**Examples**    `CALCULATE:TOVERVIEW:MARKER1:DELTA:X?` might return `38.0E-9`, indicating that the delta marker time is `38.0 ns`.

## **CALCulate:TOVerview:MARKer<x>:DELTA:Y? (Query Only)**

Returns the delta marker amplitude for the selected marker on the time overview trace.

The parameter <x> = 1 to 4; MARKer0 (reference marker) is invalid. The specified marker must be activated using the [CALCulate:MARKer:ADD](#) command.

**Conditions**    Measurement views: Time overview

**Group**    Calculate commands

**Syntax**    `CALCulate:TOVerview:MARKer<x>:DELTA:Y?`

**Related Commands**    [CALCulate:TOVerview:MARKer<x>:DELTA:X?](#)

**Arguments**    None

**Returns**    <NRF> Delta marker amplitude for the selected marker.

**Examples**    CALCULATE:TOVERVIEW:MARKER1:DELTA:Y? might return 23.45, indicating that the delta marker amplitude is 23.45 dB.

### **CALCulate:TOVerview:MARKer<x>:MAXimum (No Query Form)**

Moves the selected marker to the highest peak on the time overview trace.

**Conditions**    Measurement views: Time overview

**Group**    Calculate commands

**Syntax**    CALCulate:TOVerview:MARKer<x>:MAXimum

**Arguments**    None

**Examples**    CALCULATE:TOVERVIEW:MARKER1:MAXIMUM moves Marker 1 (M1) to the highest peak on the trace.

### **CALCulate:TOVerview:MARKer<x>:PEAK:HIGHer (No Query Form)**

Moves the selected marker to the next peak higher in amplitude on the time overview trace.

**Conditions**    Measurement views: Time overview

**Group**    Calculate commands

**Syntax**    CALCulate:TOVerview:MARKer<x>:PEAK:HIGHer

**Related Commands**    [CALCulate:TOVerview:MARKer<x>:PEAK:LOWer](#)

**Arguments** None

**Examples** CALCULATE:TOVIEW:MARKER1:PEAK:HIGHER moves Marker 1 (M1) to the next peak higher in amplitude on the trace.

## CALCulate:TOView:MARKer<x>:PEAK:LEFT (No Query Form)

Moves the selected marker to the next peak to the left on the time overview trace.

**Conditions** Measurement views: Time overview

**Group** Calculate commands

**Syntax** CALCulate:TOView:MARKer<x>:PEAK:LEFT

**Related Commands** [CALCulate:TOView:MARKer<x>:PEAK:RIGHT](#)

**Arguments** None

**Examples** CALCULATE:TOVIEW:MARKER1:PEAK:LEFT moves Marker 1 (M1) to the next peak to the left on the trace.

## CALCulate:TOView:MARKer<x>:PEAK:LOWer (No Query Form)

Moves the selected marker to the next peak lower in amplitude on the time overview trace.

**Conditions** Measurement views: Time overview

**Group** Calculate commands

**Syntax** CALCulate:TOView:MARKer<x>:PEAK:LOWer

**Related Commands** [CALCulate:TOView:MARKer<x>:PEAK:HIGHer](#)

**Arguments** None

**Examples**     `CALCULATE:TOVERVIEW:MARKER1:PEAK:LOWER` moves Marker 1 (M1) to the next peak lower in amplitude on the trace.

## **CALCulate:TOVerview:MARKer<x>:PEAK:RIGHT (No Query Form)**

Moves the selected marker to the next peak to the right on the time overview trace.

**Conditions**     Measurement views: Time overview

**Group**     Calculate commands

**Syntax**     `CALCulate:TOVerview:MARKer<x>:PEAK:RIGHT`

**Related Commands**     [CALCulate:TOVerview:MARKer<x>:PEAK:LEFT](#)

**Arguments**     None

**Examples**     `CALCULATE:TOVERVIEW:MARKER1:PEAK:RIGHT` moves Marker 1 (M1) to the next peak to the right on the trace.

## **CALCulate:TOVerview:MARKer<x>:X**

Sets or queries the horizontal position of the selected marker on the time overview trace.

**Conditions**     Measurement views: Time overview

**Group**     Calculate commands

**Syntax**     `CALCulate:TOVerview:MARKer<x>:X <value>`  
`CALCulate:TOVerview:MARKer<x>:X?`

**Related Commands**     [CALCulate:TOVerview:MARKer<x>:Y?](#)

**Arguments**     `<value>::=<Nrf>` specifies the horizontal position of the marker.  
 Range: (analysis offset) to [(analysis offset) + (analysis length)].



**Examples**     `CALCULATE:TOVERVIEW:MARKER1:X 1.5us` places Marker 1 (M1) at 1.5  $\mu$ s on the trace.

## CALCulate:TOVerview:MARKer<x>:Y? (Query Only)

Queries the marker amplitude of the selected marker in the time overview.

**Conditions**     Measurement views: Time overview

**Group**     Calculate commands

**Syntax**     `CALCulate:TOVerview:MARKer<x>:Y?`

**Related Commands**     [CALCulate:TOVerview:MARKer<x>:X](#)

**Arguments**     None

**Returns**     <NRF> Marker amplitude of the selected marker.

**Examples**     `CALCULATE:TOVERVIEW:MARKER1:Y?` might return `-34.28`, indicating Marker 1 (M1) is at `-34.28` dBm.

## CALibration:ABORt (No Query Form)

Aborts any actions related to the alignments in progress.

**Conditions**     Measurement views: All

**Group**     Calibration commands

**Syntax**     `CALibration:ABORt`

**Arguments**     None

**Examples**     `CALIBRATION:ABORT` aborts any actions related to the alignments in progress.

## CALibration:AUTO

Selects or queries whether or not to run alignments automatically.

**Conditions** Measurement views: All

**Group** Calibration commands

**Syntax** CALibration:AUTO { OFF | ON | 0 | 1 }  
CALibration:AUTO?

**Arguments** OFF or 0 runs alignments on user request.  
Use the \*CAL command to perform alignments.  
ON or 1 runs alignments as needed without user intervention.  
You have to restart measurement if interrupted.

**Examples** CALIBRATION:AUTO ON runs alignments automatically as needed.

## CALibration:CORRection:EXTErnal:EDIT<x>:LABel

Sets or queries the name of the external loss table.

The parameter <x> = 1 to 3 represent the External Loss Table 1 to 3, respectively.

**Conditions** Measurement views: All

**Group** Calibration commands

**Syntax** CALibration:CORRection:EXTErnal:EDIT<x>:LABel <name>  
CALibration:CORRection:EXTErnal:EDIT<x>:LABel?

**Arguments** <name>::=<string> specifies the name of the external loss table.

**Examples** CALIBRATION:CORRECTION:EXTERNAL:EDIT1:LABEL "Sample Table 1"  
names the External Loss Table 1 "Sample Table 1".

## CALibration:CORRection:EXTErnal:EDIT<x>:NEW (No Query Form)

Creates a new external loss table.

The parameter <x> = 1 to 3 represent the External Loss Table 1 to 3, respectively.

<b>Conditions</b>	Measurement views: All
<b>Group</b>	Calibration commands
<b>Syntax</b>	CALibration:CORRection:EXTErnal:EDIT<x>:NEW <freq(1)>,<loss(1)>,<freq(2)>,<loss(2)>,...,<freq(n)>,<loss(n)>
<b>Arguments</b>	<freq(n)>,<loss(n)> specifies a pair of frequency (<NR3> in Hz) and loss (<NR3> in dB) in the external loss table.  The setting range is: Frequency: 0 to 6.2 GHz (RSA6106A)/14 GHz (RSA6114A) Loss: -50 to +80 dB. (A negative value means a gain.)
<b>Examples</b>	CALIBRATION:CORRECTION:EXTERNAL:EDIT1:NEW 1.0E+9,2.2,1.5E+9,2.3 creates the External Loss Table 1 specifying the loss of 2.2 dB and 2.3 dB at the frequency of 1 GHz and 1.5 GHz, respectively.

## CALibration:CORRection:EXTErnal:EDIT<x>:STATE

Determines whether to enable or disable the external loss table.

The parameter <x> = 1 to 3 represent the External Loss Table 1 to 3, respectively.

<b>Conditions</b>	Measurement views: All
<b>Group</b>	Calibration commands
<b>Syntax</b>	CALibration:CORRection:EXTErnal:EDIT<x>:STATE { OFF   ON   0   1 } CALibration:CORRection:EXTErnal:EDIT<x>:STATE?
<b>Arguments</b>	OFF or 0 disables the external loss table.  ON or 1 enables the external loss table.

---

**NOTE.** *You can enable one or more tables at the same time.*

---

**Examples** CALIBRATION:CORRECTION:EXTERNAL:EDIT3:STATE ON enables the External Loss Table 3.

## CALibration:CORRection:EXTErnal:GAIN[:MAGNitude]

Sets or queries the external gain value. It can be enabled or disabled using the [CALibration:CORRection:EXTErnal:GAIN:STATe](#) command.

**Conditions** Measurement views: All

**Group** Calibration commands

**Syntax** CALibration:CORRection:EXTErnal:GAIN[:MAGNitude] <value>  
CALibration:CORRection:EXTErnal:GAIN[:MAGNitude]?

**Arguments** <value>::=<NRF> specifies the external gain value. Range: -50 to +30 dB.

**Examples** CALIBRATION:CORRECTION:EXTERNAL:GAIN:MAGNITUDE -10 sets the external gain to -10 dB.

## CALibration:CORRection:EXTErnal:GAIN:STATe

Determines whether to enable or disable the external gain value.

**Conditions** Measurement views: All

**Group** Calibration commands

**Syntax** CALibration:CORRection:EXTErnal:GAIN:STATe { OFF | ON | 0 | 1 }  
CALibration:CORRection:EXTErnal:GAIN:STATe?

**Related Commands** [CALibration:CORRection:EXTErnal:GAIN\[:MAGNitude\]](#)

<b>Arguments</b>	OFF or 0 disables the external gain value. ON or 1 enables the external gain value.
<b>Examples</b>	CALIBRATION:CORRECTION:EXTERNAL:GAIN:STATE ON enables the external gain value.

## CALibration:CORRection:EXTErnal:PROBe:CONNect? (Query Only)

Queries whether the external probe is connected to the analyzer or not.

<b>Conditions</b>	Measurement views: All
<b>Group</b>	Calibration commands
<b>Syntax</b>	CALibration:CORRection:EXTErnal:PROBe:CONNect?
<b>Arguments</b>	None
<b>Returns</b>	{ 0   1 } 0 indicates that the external probe is not connected to the analyzer. 1 indicates that the external probe is connected to the analyzer.
<b>Examples</b>	CALIBRATION:CORRECTION:EXTERNAL:PROBE:CONNECT? might return ON, indicating that the external probe is connected to the analyzer.

## CALibration:CORRection:EXTErnal:PROBe[:MAGNitude]? (Query Only)

Queries the external probe attenuation.

<b>Conditions</b>	Measurement views: All
<b>Group</b>	Calibration commands
<b>Syntax</b>	CALibration:CORRection:EXTErnal:PROBe[:MAGNitude]?

<b>Arguments</b>	None
<b>Returns</b>	<attenuation>::=<NRF> The probe attenuation value in dB.
<b>Examples</b>	CALIBRATION:CORRECTION:EXTERNAL:PROBE:MAGNITUDE? might return 10, indicating that the probe attenuation is 10 dB.

## CALibration:CORRection:EXTErnal:PROBe:STATe

Determines whether or not to correct data for the external probe attenuation.

<b>Conditions</b>	Measurement views: All
<b>Group</b>	Calibration commands
<b>Syntax</b>	CALibration:CORRection:EXTErnal:PROBe:STATe { OFF   ON   0   1 } CALibration:CORRection:EXTErnal:PROBe:STATe?
<b>Arguments</b>	OFF or 0 does not correct data for the external probe attenuation. ON or 1 corrects data for the external probe attenuation.
<b>Examples</b>	CALIBRATION:CORRECTION:EXTERNAL:PROBE:STATE ON corrects data for the external probe attenuation.

## CALibration:CORRection:EXTErnal:TYPE

Selects or queries the data type to apply the external loss table corrections.

<b>Conditions</b>	Measurement views: All
<b>Group</b>	Calibration commands
<b>Syntax</b>	CALibration:CORRection:EXTErnal:TYPE { TRACE   DATA } CALibration:CORRection:EXTErnal:TYPE
<b>Related Commands</b>	<a href="#">CALibration:CORRection:EXTErnal:GAIN:STATe</a>

**Arguments** TRACe selects traces in the Spectrum, Spectrogram, Spurious, and Amplitude versus Time views. Selecting TRACe disables the CALibration:CORRection:EXTErnal:GAIN:STATe command.

DATA selects all acquired data. Selecting DATA enables the CALibration:CORRection:EXTErnal:GAIN:STATe command.

**Examples** CALIBRATION:CORRECTION:EXTERNAL:TYPE TRACe selects traces to apply the external loss table corrections.

## \*CLS (No Query Form)

Clears the analyzer status data structures. Refer to Section 3, *Status and Events*, for the register information.

The \*CLS command clears the following

- the Event Queue
- the Standard Event Status Register (SESR)
- the Status Byte Register (except the MAV bit; see below)

If the \*CLS command immediately follows an <EOI>, the Output Queue and MAV bit (Status Byte Register bit 4) are also cleared. MAV indicates information is in the output queue. The device clear (DCL) GPIB control message will clear the output queue and thus MAV. \*CLS does not clear the output queue or MAV. (A complete discussion of these registers and bits, and of event handling in general is described in the *Status and Events* section)

\*CLS can suppress a Service Request that is to be generated by an \*OPC. This will happen if a hardcopy output or single sequence acquisition operation is still being processed when the \*CLS command is executed.

**Conditions** Measurement views: All

**Group** IEEE common commands

**Syntax** \*CLS

**Related Commands** \*ESE, \*ESR?, \*SRE, \*STB?

**Arguments** None

**Examples** \*CLS clears the analyzer status data structures.

## DISPlay:ACPower:MARKer:SHOW:STATE

Determines whether to show or hide the readout for the selected marker in the Channel power and ACPR view.

**Conditions** Measurement views: Channel power and ACPR

**Group** Display commands

**Syntax** DISPlay:ACPower:MARKer:SHOW:STATE { OFF | ON | 0 | 1 }  
DISPlay:ACPower:MARKer:SHOW:STATE?

**Arguments** OFF or 0 hides the readout for the selected marker in the graph.  
ON or 1 shows the readout for the selected marker in the graph.

**Examples** DISPLAY:ACPOWER:MARKER:SHOW:STATE ON shows the readout for the selected marker in the graph.

## DISPlay:ACPower:PLEVel:SHOW:STATE

Determines whether to show or hide the power levels in the Channel power and ACPR view.

**Conditions** Measurement views: Channel power and ACPR

**Group** Display commands

**Syntax** DISPlay:ACPower:PLEVel:SHOW:STATE { OFF | ON | 0 | 1 }  
DISPlay:ACPower:PLEVel:SHOW:STATE?

**Arguments** OFF or 0 hides the power levels in the graph.  
ON or 1 shows the power levels in the graph.

**Examples** DISPLAY:ACPOWER:PLEVEL:SHOW:STATE ON shows the power levels in the graph.



## DISPlay:ACPower:RESet:SCALE (No Query Form)

Resets the horizontal and vertical scale to the default values described below in the Channel power and ACPR view.

Vertical offset = Reference level,  
 Vertical scale = 100 dB,  
 Horizontal offset = Center frequency, and  
 Horizontal scale = Default span

<b>Conditions</b>	Measurement views: Channel power and ACPR
<b>Group</b>	Display commands
<b>Syntax</b>	DISP <code>l</code> ay:ACPower:RESet:SCALE
<b>Arguments</b>	None
<b>Examples</b>	DISP <code>l</code> ay:ACPOWER:RESET:SCALE resets the horizontal and vertical scale to the default values.

## DISPlay:ACPower:WINDow:TRACe:GRATICule:GRID:STATe

Determines whether to show or hide the graticule grid on the screen.

<b>Conditions</b>	Measurement views: Channel power and ACPR
<b>Group</b>	Display commands
<b>Syntax</b>	DISP <code>l</code> ay:ACPower:WINDow:TRACe:GRATICule:GRID:STATe { OFF   ON   0   1 } DISP <code>l</code> ay:ACPower:WINDow:TRACe:GRATICule:GRID:STATe?
<b>Arguments</b>	OFF or 0 hides the graticule grid. ON or 1 shows the graticule grid.
<b>Examples</b>	DISP <code>l</code> ay:ACPOWER:WINDOW:TRACE:GRATICULE:GRID:STATE ON shows the graticule grid on the screen.

## DISPlay:ACPower:X[:SCALE]

Sets or queries the horizontal range of the Channel power and ACPR graph.

**Conditions** Measurement views: Channel power and ACPR

**Group** Display commands

**Syntax** DISPlay:ACPower:X[:SCALE] <value>  
DISPlay:ACPower:X[:SCALE]?

**Related Commands** [DISPlay:ACPower:X\[:SCALE\]:OFFSet](#)

**Arguments** <value>::=<Nrf> specifies the horizontal range.  
Range: 10 Hz to 6.2 GHz (RSA6106A) / 14 GHz (RSA6114A).

**Examples** DISPLAY:ACPOWER:X:SCALE 10MHZ sets the horizontal range to 10 MHz.

## DISPlay:ACPower:X[:SCALE]:AUTO (No Query Form)

Rescales the horizontal axis automatically to fit the waveform to the screen in the Channel power and ACPR view.

**Conditions** Measurement views: Channel power and ACPR

**Group** Display commands

**Syntax** DISPlay:ACPower:X[:SCALE]:AUTO

**Arguments** None

**Examples** DISPLAY:ACPOWER:X:SCALE:AUTO rescales the horizontal scale automatically to fit the waveform to the screen.

## DISPlay:ACPower:X[:SCALe]:OFFSet

Sets or queries the minimum horizontal value (left edge) of the Channel power and ACPR graph.

**Conditions** Measurement views: Channel power and ACPR

**Group** Display commands

**Syntax** DISPlay:ACPower:X[:SCALe]:OFFSet <value>  
DISPlay:ACPower:X[:SCALe]:OFFSet?

**Related Commands** [DISPlay:ACPower:X\[:SCALe\]](#)

**Arguments** <value>::=<Nrf> specifies the minimum horizontal value.  
Range: [(center frequency) - (X scale) × 0.9] to [(center frequency) + (X scale) × 0.9]

**Examples** DISPlay:ACPower:X:SCALE:OFFSet 1.45GHz sets the minimum horizontal value to 1.45 GHz in the Channel power and ACPR graph.

## DISPlay:ACPower:Y[:SCALe]

Sets or queries the vertical range of the channel power and ACPR graph.

**Conditions** Measurement views: Channel power and ACPR

**Group** Display commands

**Syntax** DISPlay:ACPower:Y[:SCALe] <value>  
DISPlay:ACPower:Y[:SCALe]?

**Related Commands** [DISPlay:ACPower:Y\[:SCALe\]:OFFSet](#)

**Arguments** <value>::=<Nrf> specifies the vertical range. Range: 0.1 to 200 dB.

**Examples** DISPLAY:ACPOWER:Y:SCALE 100 sets the vertical range to 100 dB in the Channel power and ACPR graph.

## DISPlay:ACPower:Y[:SCALE]:AUTO (No Query Form)

Rescales the vertical axis automatically to fit the waveform to the screen in the Channel power and ACPR view.

**Conditions** Measurement views: Channel power and ACPR

**Group** Display commands

**Syntax** DISPlay:ACPower:Y[:SCALE]:AUTO

**Arguments** None

**Examples** DISPLAY:ACPOWER:Y:SCALE:AUTO rescales the vertical scale automatically to fit the waveform to the screen.

## DISPlay:ACPower:Y[:SCALE]:OFFSet

Sets or queries the vertical offset (the value at the top edge of the vertical axis) in the Channel power and ACPR graph.

**Conditions** Measurement views: Channel power and ACPR

**Group** Display commands

**Syntax** DISPlay:ACPower:Y[:SCALE]:OFFSet <value>  
DISPlay:ACPower:Y[:SCALE]:OFFSet?

**Related Commands** [DISPlay:ACPower:Y\[:SCALE\]](#)

**Arguments** <value>::=<NRF> specifies the vertical offset. Range: -170 to +50 dBm.

**Examples** DISPLAY:ACPOWER:Y:SCALE:OFFSET -12.5 sets the vertical offset to -12.5 dBm in the Channel power and ACPR graph.

## DISPlay:ADEMod:MEASview:DELeTe (No Query Form)

Deletes the measurement view in the general purpose analog demodulation measurements.

**Conditions** Measurement views: General purpose analog demodulation

**Group** Display commands

**Syntax** DISPlay:ADEMod:MEASview:DELeTe { AM | FM | PM }

**Arguments** The following table lists the arguments.

**Table 2-28: Analog demodulation measurement views**

Argument	View
AM	AM measurement (modulation factor versus time)
FM	FM measurement (frequency deviation versus time)
PM	PM measurement (phase deviation versus time)

If you attempt to delete a view that is not displayed on screen, the error (-200, "Execution error; Measurement is not running") will be returned.

**Examples** DISPLAY:ADEMOD:MEASVIEW:DELETE AM deletes the AM measurement view.

## DISPlay:ADEMod:MEASview:NEW (No Query Form)

Displays a new measurement view in the general purpose analog demodulation measurements.

**Conditions** Measurement views: General purpose analog demodulation

**Group** Display commands

**Syntax** DISPlay:ADEMod:MEASview:NEW { AM | FM | PM }

**Arguments** (See Table 2-28 on page 2-219.) If you attempt to open a view that is currently displayed on screen, the error (-200, "Execution error; Measurement is already running") will be returned.

**Examples**     `DISPLAY:AEMOD:MEASVIEW:NEW AM` creates the AM measurement view.

## DISPlay:AEMod:MEASview:SElect

Selects a measurement view on the screen in the general purpose analog demodulation measurements. The query command returns the currently selected view.

Selecting a measurement optimizes it. Other measurements may be optimized as a side effect. Refer to the [DISPlay:WINDow:OPTimized:MEASurement?](#) query.

**Conditions**     Measurement views: General purpose analog demodulation

**Group**     Display commands

**Syntax**     `DISPlay:AEMod:MEASview:SElect { AM | FM | PM }`  
`DISPlay:AEMod:MEASview:SElect?`

**Arguments**     (See Table 2-28 on page 2-219.) If you attempt to select a view that is not displayed on screen, the error (-200, "Execution error; Measurement not running") will be returned.

**Examples**     `DISPLAY:AEMOD:MEASVIEW:SELECT AM` selects the AM measurement view.

## DISPlay:{AM|FM|PM}:MARKer:SHOW:STATe

Determines whether to show or hide the marker readout in the AM/FM/PM measurement view.

**Conditions**     Measurement views: General purpose analog demodulation

**Group**     Display commands

**Syntax**     `DISPlay:{AM|FM|PM}:MARKer:SHOW:STATE { OFF | ON | 0 | 1 }`  
`DISPlay:{AM|FM|PM}:MARKer:SHOW:STATE?`

**Arguments**     OFF or 0 hides the marker readout on the screen.

ON or 1 shows the marker readout on the screen.

**Examples**    `DISPLAY:AM:MARKER:SHOW:STATE ON` shows the marker readout in the AM measurement view.

## **DISPlay:{AM|FM|PM}:WINDow:TRACe:GRATicule:GRID:STATE**

Determines whether to show or hide the graticule grid on the screen.

**Conditions**    Measurement views: General purpose analog demodulation

**Group**    Display commands

**Syntax**    `DISPlay:{AM|FM|PM}:WINDow:TRACe:GRATicule:GRID:STATE { OFF | ON | 0 | 1 }`  
`DISPlay:{AM|FM|PM}:WINDow:TRACe:GRATicule:GRID:STATE?`

**Arguments**    OFF or 0 hides the graticule grid.

ON or 1 shows the graticule grid.

**Examples**    `DISPLAY:AM:WINDOW:TRACE:GRATICULE:GRID:STATE ON` shows the graticule grid on the AM measurement view.

## **DISPlay:{AM|FM|PM}:X:RSCale (No Query Form)**

Rescales the horizontal axis automatically to fit the waveform to the screen in the AM/FM/PM measurement display.

**Conditions**    Measurement views: General purpose analog demodulation

**Group**    Display commands

**Syntax**    `DISPlay:{AM|FM|PM}:X:RSCale`

**Arguments**    None

**Examples**    `DISPLAY:AM:X:RSCALE` rescales the horizontal scale automatically to fit the waveform to the screen.

## DISPlay:{AM|FM|PM}:X[:SCALE]:AUTO (No Query Form)

Sets the horizontal scale automatically to fit the waveform to the screen in the AM/FM/PM measurement display.

<b>Conditions</b>	Measurement views: General purpose analog demodulation
<b>Group</b>	Display commands
<b>Syntax</b>	DISPlay:{AM FM PM}:X[:SCALE]:AUTO
<b>Arguments</b>	None
<b>Examples</b>	DISPLAY:AM:X:SCALE:AUTO sets the horizontal scale automatically to fit the waveform to the screen in the AM/FM/PM measurement display.

## DISPlay:{AM|FM|PM}:X[:SCALE]:FULL

Sets or queries the horizontal scale (full-scale time) of the AM/FM/PM measurement graph.

<b>Conditions</b>	Measurement views: General purpose analog demodulation
<b>Group</b>	Display commands
<b>Syntax</b>	DISPlay:{AM FM PM}:X[:SCALE]:FULL <value> DISPlay:{AM FM PM}:X[:SCALE]:FULL?
<b>Arguments</b>	<value>::=<Nrf> specifies the horizontal scale in full-scale time. Range: 0 to 10 <sup>27</sup> s.
<b>Examples</b>	DISPlay:AM:X:SCALE:FULL 35us sets the horizontal scale to 35 $\mu$ s in the AM measurement.

## DISPlay:{AM|FM|PM}:X[:SCALE]:OFFSet

Sets or queries the minimum horizontal value (left edge) of the AM/FM/PM measurement graph.



<b>Conditions</b>	Measurement views: General purpose analog demodulation
<b>Group</b>	Display commands
<b>Syntax</b>	DISPlay:{AM FM PM}:X[:SCALE]:OFFSet <value> DISPlay:{AM FM PM}:X[:SCALE]:OFFSet?
<b>Arguments</b>	<value>::=<NRf> specifies the minimum horizontal value. Range: $-0.9 \times (\text{horizontal scale})$ to $+0.9 \times (\text{horizontal scale})$
<b>Examples</b>	DISPLAY:AM:X:SCALE:OFFSET 20.075us sets the minimum horizontal value to 20.075 $\mu$ s.

## DISPlay:{AM|FM|PM}:Y:RSCale (No Query Form)

Rescales the vertical axis automatically to fit the waveform to the screen in the AM/FM/PM measurement display.

<b>Conditions</b>	Measurement views: General purpose analog demodulation
<b>Group</b>	Display commands
<b>Syntax</b>	DISPlay:{AM FM PM}:Y:RSCale
<b>Arguments</b>	None
<b>Examples</b>	DISPLAY:AM:Y:RSCALE rescales the vertical scale automatically to fit the waveform to the screen in the AM measurement.

## DISPlay:{AM|FM|PM}:Y[:SCALE]

Sets or queries the vertical range of the AM/FM/PM measurement graph.

<b>Conditions</b>	Measurement views: General purpose analog demodulation
<b>Group</b>	Display commands

**Syntax**     `DISPlay:{AM|FM|PM}:Y[:SCALE] <value>`  
`DISPlay:{AM|FM|PM}:Y[:SCALE]?`

**Arguments**     `<value>::=<Nrf>` specifies the vertical range.  
 The setting range depends on measurements as shown in the following table.

**Setting range**

Measurement	Setting range
AM	1% to 500%
FM	10 Hz to 120 MHz
PM	10° to 400°

**Examples**     `DISPLAY:AM:Y:SCALE 75` sets the vertical range to 75% in the AM measurement graph.

## DISPlay:{AM|FM|PM}:Y[:SCALE]:OFFSet

Sets or queries the vertical offset (center point of the vertical axis) in the AM/FM/PM measurement graph.

**Conditions**     Measurement views: General purpose analog demodulation

**Group**     Display commands

**Syntax**     `DISPlay:{AM|FM|PM}:Y[:SCALE]:OFFSet <value>`  
`DISPlay:{AM|FM|PM}:Y[:SCALE]:OFFSet?`

**Arguments**     `<value>::=<Nrf>` specifies the vertical offset.  
 The setting range depends on measurements as shown in the following table.

**Setting range**

Measurement	Setting range
AM	-500% to +500%
FM	$-(\text{maxVertScale} * (1 + 1.1) * 0.5)$ to $+(\text{maxVertScale} * (1 + 1.1) * 0.5)$
PM	-180° to +180°

**Examples**     `DISPLAY:AM:Y:SCALE:OFFSET -12.5` sets the vertical offset to -12.5% in the AM measurement graph.

## DISPlay:AVTime:LEGend:STATe

Determines whether to show or hide the trace legend in the amplitude versus time view. The legend indicates the trace detection and function on the screen for each displayed trace.

**Conditions** Measurement views: Amplitude versus Time

**Group** Display commands

**Syntax** DISPlay:AVTime:LEGend:STATe { OFF | ON | 0 | 1 }  
DISPlay:AVTime:LEGend:STATe?

**Arguments** OFF or 0 hides the trace legend.  
ON or 1 shows the trace legend.

**Examples** DISPLAY:AVTIME:LEGEND:STATE ON shows the trace legend on the screen.

## DISPlay:AVTime:MARKer:SHOW:STATe

Determines whether to show or hide the readout for the selected marker on the screen in the Amplitude versus Time measurement.

**Conditions** Measurement views: Amplitude versus Time

**Group** Display commands

**Syntax** DISPlay:AVTime:MARKer:SHOW:STATe { OFF | ON | 0 | 1 }  
DISPlay:AVTime:MARKer:SHOW:STATe?

**Arguments** OFF or 0 hides the readout for the selected marker on screen.  
ON or 1 shows the readout for the selected marker on screen.

**Examples** DISPLAY:AVTIME:MARKER:SHOW:STATE ON shows the readout for the selected marker on screen.

## DISPlay:AVTime:RESet (No Query Form)

Resets the horizontal and vertical scale to the default values described below in the Amplitude versus Time view.

Vertical offset = Reference level,  
Vertical scale = 100 dB,  
Horizontal offset = Analysis offset, and  
Horizontal scale = Analysis length

<b>Conditions</b>	Measurement views: Amplitude versus Time
<b>Group</b>	Display commands
<b>Syntax</b>	DISPlay:AVTime:RESet
<b>Arguments</b>	None
<b>Examples</b>	DISPLAY:AVTIME:RESET resets the horizontal and vertical scale to the default values.

## DISPlay:AVTime:TRIGger:LEVel:STATe

Determines whether to show or hide the power trigger level line on the screen in the Amplitude versus Time measurement.

<b>Conditions</b>	Measurement views: Amplitude versus Time
<b>Group</b>	Display commands
<b>Syntax</b>	DISPlay:AVTime:TRIGger:LEVel:STATe { OFF   ON   0   1 } DISPlay:AVTime:TRIGger:LEVel:STATe?
<b>Arguments</b>	OFF or 0 hides the power trigger level line. ON or 1 shows the power trigger level line.
<b>Examples</b>	DISPLAY:AVTIME:TRIGGER:LEVEL:STATE ON shows the power trigger level line on the screen.

## DISPlay:AVTime:WINDow:TRACe:GRATicule:GRID:STATe

Determines whether to show or hide the graticule grid on the screen.

<b>Conditions</b>	Measurement views: Amplitude versus Time
<b>Group</b>	Display commands
<b>Syntax</b>	DISPlay:AVTime:WINDow:TRACe:GRATicule:GRID:STATe { OFF   ON   0   1 } DISPlay:AVTime:WINDow:TRACe:GRATicule:GRID:STATe?
<b>Arguments</b>	OFF or 0 hides the graticule grid. ON or 1 shows the graticule grid.
<b>Examples</b>	DISPLAY:AVTIME:WINDOW:TRACE:GRATICULE:GRID:STATE ON shows the graticule grid on the screen in the Amplitude versus Time view.

## DISPlay:AVTime:X:RSCale (No Query Form)

Rescales the horizontal axis automatically to fit the waveform to the screen in the Amplitude versus Time display.

<b>Conditions</b>	Measurement views: Amplitude versus Time
<b>Group</b>	Display commands
<b>Syntax</b>	DISPlay:AVTime:X:RSCale
<b>Arguments</b>	None
<b>Examples</b>	DISPLAY:AVTIME:X:RSCALE rescales the horizontal scale automatically to fit the waveform to the screen.

## DISPlay:AVTime:X[:SCALE]:AUTO (No Query Form)

Sets the horizontal scale automatically to fit the waveform to the screen in the Amplitude versus Time view. Executing this command sets DISPlay:AVTime:X[:SCALE]:AUTO:STATe ON.

<b>Conditions</b>	Measurement views: Amplitude versus Time
<b>Group</b>	Display commands
<b>Syntax</b>	DISPlay:AVTime:X[:SCALE]:AUTO
<b>Related Commands</b>	<a href="#">DISPlay:AVTime:X[:SCALE]:AUTO:STATe</a>
<b>Arguments</b>	None
<b>Examples</b>	DISPlay:AVTime:X:SCALE:AUTO sets the horizontal scale automatically to fit the waveform to the screen.

## DISPlay:AVTime:X[:SCALE]:AUTO:STATe

Determines whether to set the horizontal scale automatically or manually.

<b>Conditions</b>	Measurement views: Amplitude versus Time
<b>Group</b>	Display commands
<b>Syntax</b>	DISPlay:AVTime:X[:SCALE]:AUTO:STATe { OFF   ON   0   1 } DISPlay:AVTime:X[:SCALE]:AUTO:STATe?
<b>Arguments</b>	<p>OFF or 0 specifies that the horizontal scale is set manually. To set it, use the <a href="#">DISPlay:AVTime:X[:SCALE]:FULL</a> and <a href="#">DISPlay:AVTime:X[:SCALE]:OFFSet</a> commands.</p> <p>ON or 1 specifies that the horizontal scale is set automatically.</p>
<b>Examples</b>	DISPLAY:AVTIME:X:SCALE:AUTO:STATE ON specifies that the horizontal scale is set automatically.

## DISPlay:AVTime:X[:SCALe]:FULL

Sets or queries the horizontal scale (full-scale time) of the Amplitude versus Time graph. Programming a specified scale sets DISPlay:AVTime:X[:SCALe] AUTO:STATe OFF.

<b>Conditions</b>	Measurement views: Amplitude versus Time
<b>Group</b>	Display commands
<b>Syntax</b>	DISPlay:AVTime:X[:SCALe]:FULL <value> DISPlay:AVTime:X[:SCALe]:FULL?
<b>Related Commands</b>	<a href="#">DISPlay:AVTime:X[:SCALe]:AUTO:STATe</a> , <a href="#">DISPlay:AVTime:X[:SCALe]:OFFSet</a>
<b>Arguments</b>	<value>::=<NRf> specifies the horizontal scale in full-scale time. Use the <a href="#">DISPlay:AVTime:X[:SCALe]:MAXimum?</a> and <a href="#">DISPlay:AVTime:X[:SCALe]:MINimum?</a> queries to get the upper and lower limits of the setting range.
<b>Examples</b>	DISPLAY:AVTIME:X:SCALE:FULL 25.6us sets the horizontal scale to 25.6 $\mu$ s.

## DISPlay:AVTime:X[:SCALe]:MAXimum? (Query Only)

Queries the upper limit of the horizontal scale setting range.

<b>Conditions</b>	Measurement views: Amplitude versus Time
<b>Group</b>	Display commands
<b>Syntax</b>	DISPlay:AVTime:X[:SCALe]:MAXimum?
<b>Related Commands</b>	<a href="#">DISPlay:AVTime:X[:SCALe]:FULL</a>
<b>Arguments</b>	None
<b>Returns</b>	<NRf> The upper limit of the horizontal scale setting range.

**Examples**     `DISPLAY:AVTIME:X:SCALE:MAXIMUM?` might return `18.135E-3`, indicating that the upper limit of the horizontal scale setting range is 18.135 ms.

## DISPlay:AVTime:X[:SCALe]:MINimum? (Query Only)

Queries the lower limit of the horizontal scale setting range.

**Conditions**     Measurement views: Amplitude versus Time

**Group**            Display commands

**Syntax**           `DISPlay:AVTime:X[:SCALe]:MINimum?`

**Related Commands**     [DISPlay:AVTime:X\[:SCALe\]:FULL](#)

**Arguments**        None

**Returns**            <NRF> The lower limit of the horizontal scale setting range.

**Examples**     `DISPLAY:AVTIME:X:SCALE:MINIMUM?` might return `10.0E-9`, indicating that the lower limit of the horizontal scale setting range is 10.0 ns.

## DISPlay:AVTime:X[:SCALe]:OFFSet

Sets or queries the minimum horizontal value (left edge) of the Amplitude versus Time graph. Programming a specified offset sets `DISPlay:AVTime:X[:SCALe] AUTO:STATe OFF`.

**Conditions**        Measurement views: Amplitude versus Time

**Group**            Display commands

**Syntax**            `DISPlay:AVTime:X[:SCALe]:OFFSet <value>`  
`DISPlay:AVTime:X[:SCALe]:OFFSet?`

**Related Commands**     [DISPlay:AVTime:X\[:SCALe\]:AUTO:STATe](#), [DISPlay:AVTime:X\[:SCALe\]:FULL](#)



**Arguments** `<value>::=<Nrf>` specifies the minimum horizontal value. Use the [DISPlay:AVTime:X\[:SCALE\]:OFFSet:MAXimum?](#) and [DISPlay:AVTime:X\[:SCALE\]:OFFSet:MINimum?](#) queries to get the upper and lower limits of the setting range.

**Examples** `DISPlay:AVTIME:X:SCALE:OFFSET 800ns` sets the minimum horizontal value to 800 ns in the Amplitude versus Time graph.

## DISPlay:AVTime:X[:SCALE]:OFFSet:MAXimum? (Query Only)

Queries the upper limit of the horizontal offset setting range.

**Conditions** Measurement views: Amplitude versus Time

**Group** Display commands

**Syntax** `DISPlay:AVTime:X[:SCALE]:OFFSet:MAXimum?`

**Related Commands** [DISPlay:AVTime:X\[:SCALE\]:OFFSet](#)

**Arguments** None

**Returns** `<Nrf>` The upper limit of the horizontal offset setting range.

**Examples** `DISPlay:AVTIME:X:SCALE:OFFSET:MAXIMUM?` might return `-1.812E-3`, indicating that the upper limit of the horizontal offset setting range is -1.812 ms.

## DISPlay:AVTime:X[:SCALE]:OFFSet:MINimum? (Query Only)

Queries the lower limit of the horizontal offset setting range.

**Conditions** Measurement views: Amplitude versus Time

**Group** Display commands

**Syntax** `DISPlay:AVTime:X[:SCALE]:OFFSet:MINimum?`

**Related Commands**    [DISPlay:AVTime:X\[:SCALe\]:OFFSet](#)

**Arguments**    None

**Returns**    <NRF> The lower limit of the horizontal offset setting range.

**Examples**    `DISPlay:AVTime:X:SCALE:OFFSET:MINIMUM?` might return `-16.28E-3`, indicating that the lower limit of the horizontal offset setting range is -16.28 ms.

## DISPlay:AVTime:Y:RSCale (No Query Form)

Rescales the vertical axis automatically to fit the waveform to the screen in the Amplitude versus Time display.

**Conditions**    Measurement views: Amplitude versus Time

**Group**    Display commands

**Syntax**    `DISPlay:AVTime:Y:RSCale`

**Arguments**    None

**Examples**    `DISPlay:AVTime:Y:RSCALE` rescales the vertical scale automatically to fit the waveform to the screen.

## DISPlay:AVTime:Y[:SCALe]:FULL

Sets or queries the vertical range of the Amplitude versus Time graph.

**Conditions**    Measurement views: Amplitude versus Time

**Group**    Display commands

**Syntax**    `DISPlay:AVTime:Y[:SCALe]:FULL <value>`  
`DISPlay:AVTime:Y[:SCALe]:FULL?`

---

<b>Related Commands</b>	<a href="#">DISPlay:AVTime:Y[:SCALE]:OFFSet</a>
<b>Arguments</b>	<value> ::= <NRf> specifies the vertical range. Range: 0.1 to 200 dB.
<b>Examples</b>	DISPLAY:AVTIME:Y:SCALE:FULL 100 sets the vertical range to 100 dB in the Amplitude versus Time graph.

## DISPlay:AVTime:Y[:SCALE]:OFFSet

Sets or queries the vertical offset (the value at the top edge of the vertical axis) in the Amplitude versus Time graph.

<b>Conditions</b>	Measurement views: Amplitude versus Time
<b>Group</b>	Display commands
<b>Syntax</b>	DISPlay:AVTime:Y[:SCALE]:OFFSet <value> DISPlay:AVTime:Y[:SCALE]:OFFSet?

<b>Related Commands</b>	<a href="#">DISPlay:AVTime:Y[:SCALE]:FULL</a>
<b>Arguments</b>	<value> ::= <NRf> specifies the vertical offset. Range: -170 to +50 dBm.
<b>Examples</b>	DISPLAY:AVTIME:Y:SCALE:OFFSET -12.5 sets the vertical offset to -12.5 dBm in the Amplitude versus Time graph.

## DISPlay:CCDF:LEGend:STATe

Determines whether to show or hide the trace legend in the CCDF view. The legend indicates the trace detection and function on the screen for each displayed CCDF trace.

<b>Conditions</b>	Measurement views: CCDF
<b>Group</b>	Display commands

**Syntax**     `DISPlay:CCDF:LEGend:STATE { OFF | ON | 0 | 1 }`  
`DISPlay:CCDF:LEGend:STATE?`

**Arguments**     OFF or 0 hides the trace legend.  
                    ON or 1 shows the trace legend.

**Examples**     `DISPLAY:CCDF:LEGEND:STATE ON` shows the trace legend on the screen.

## **DISPlay:CCDF:WINDow:TRACe:GRATICule:GRID:STATE**

Determines whether to show or hide the graticule grid on the screen.

**Conditions**     Measurement views: CCDF

**Group**            Display commands

**Syntax**     `DISPlay:CCDF:WINDow:TRACe:GRATICule:GRID:STATE { OFF | ON`  
`| 0 | 1 }`  
`DISPlay:CCDF:WINDow:TRACe:GRATICule:GRID:STATE?`

**Arguments**     OFF or 0 hides the graticule grid.  
                    ON or 1 shows the graticule grid.

**Examples**     `DISPLAY:CCDF:WINDOW:TRACE:GRATICULE:GRID:STATE ON` shows the graticule grid on the screen in the CCDF view.

## **DISPlay:CONSt:MPHase**

Selects or queries the multiplication constant of the phase multiplication constellation display for a CPM signal. This command is valid when [\[SENSe\]:DDEMod:MODulation:TYPE](#) is set to CPM.

**Conditions**     Measurement views: Constellation

**Group**            Display commands

**Syntax** `DISPlay:CONSte:MPHase { P1 | P2 | P4 | P8 | P16 | P32 }`  
`DISPlay:CONSte:MPHase?`

**Arguments** The following table shows the arguments and phase multiplier.

**Phase multiplication**

Argument	Phase multiplier
P1	1
P2	2
P4	4
P8	8
P16	16
P32	32

**Examples** `DISPLAY:CONSTE:MPHASE P8` sets the phase multiplier to 8.

## DISPlay:CONSte:WINDow:TRACe:GRATicule:GRID:STATe

Determines whether to show or hide the graticule grid on the screen.

**Conditions** Measurement views: Constellation

**Group** Display commands

**Syntax** `DISPlay:CONSte:WINDow:TRACe:GRATicule:GRID:STATe { OFF | ON | 0 | 1 }`  
`DISPlay:CONSte:WINDow:TRACe:GRATicule:GRID:STATe?`

**Arguments** OFF or 0 hides the graticule grid.

ON or 1 shows the graticule grid.

**Examples** `DISPLAY:CONSTE:WINDOW:TRACE:GRATICULE:GRID:STATE ON` shows the graticule grid on the screen.

## DISPlay:DDEMod:MEASview:DELeTe (No Query Form)

Deletes the measurement view in the general purpose digital modulation measurements.

**Conditions** Measurement views: General purpose digital modulation

**Group** Display commands

**Syntax** `DISPlay:DDEMod:MEASview:DELeTe { CONSte | DIQVtime | EDIagram | EVM | FDVTime | MERRor | PERRor | SIGNAqual | STABle | TDIagram }`

**Arguments** The following table lists the arguments. The arguments are the string type.

**Table 2-29: Modulation measurement views**

Argument	View
CONSte	Constellation
DIQVtime	Demodulated I&Q versus Time
EDIagram	Eye diagram
EVM	EVM (Error Vector Magnitude) versus Time
FDVTime	Frequency deviation versus Time
MERRor	Magnitude error versus Time
PERRor	Phase error versus Time
SIGNAqual	Signal quality
STABle	Symbol table
TDIagram	Trellis diagram

If you attempt to delete a view that is not displayed on screen, the error (-200, "Execution error; Measurement not running" will be returned.

**Examples** `DISPlay:DDEMOD:MEASVIEW:DELETE CONSte` deletes the constellation view.

## DISPlay:DDEMod:MEASview:NEW (No Query Form)

Displays a new measurement view in the general purpose digital modulation measurements.

**Conditions** Measurement views: General purpose digital modulation

**Group** Display commands

<b>Syntax</b>	<code>DISPlay:DDEMod:MEASview:NEW { CONSTe   DIQVtime   EDIagram   EVM   FDVTime   MERRor   PERRor   SIGNALqual   STABle   TDIagram }</code>
<b>Arguments</b>	(See Table 2-29 on page 2-236.) If you attempt to open a view that is currently displayed on screen, the error (-200, "Execution error; Measurement is already running") will be returned.
<b>Examples</b>	<code>DISPLAY:DDEMOD:MEASVIEW:NEW CONSTe</code> creates the constellation view.

## DISPlay:DDEMod:MEASview:SElect

Selects a measurement view in the general purpose digital modulation measurements on the screen. The query command returns the currently selected view.

Selecting a measurement optimizes it. Other measurements may be optimized as a side effect. Refer to the [DISPlay:WINDow:OPTimized:MEASurement?](#) query.

<b>Conditions</b>	Measurement views: General purpose digital modulation
<b>Group</b>	Display commands
<b>Syntax</b>	<code>DISPlay:DDEMod:MEASview:SElect { CONSTe   DIQVtime   EDIagram   EVM   FDVTime   MERRor   PERRor   SIGNALqual   STABle   TDIagram }</code> <code>DISPlay:DDEMod:MEASview:SElect?</code>
<b>Arguments</b>	(See Table 2-29 on page 2-236.) If you attempt to select a view that is not displayed on screen, the error (-200, "Execution error; Measurement not running") will be returned.
<b>Examples</b>	<code>DISPLAY:DDEMOD:MEASVIEW:SELECT CONSTe</code> selects the constellation view.

## DISPlay:DDEMod:RADix

Selects or queries the base of symbols. This command is effective in the symbol table.

<b>Conditions</b>	Measurement views: Symbol table
-------------------	---------------------------------

<b>Group</b>	Display commands
<b>Syntax</b>	DISP <code>l</code> ay:DDEMod:RADiX { BINary   HEXadecima <code>l</code> } DISP <code>l</code> ay:DDEMod:RADiX?
<b>Arguments</b>	BINary selects binary notation. HEXadecima <code>l</code> selects hexadecimal notation.
<b>Examples</b>	DISP <code>l</code> AY:DDEMOD:RADIX BINary selects binary notation for the symbol table.

## DISP`l`ay:DDEMod:X[:SCALe]

Sets or queries the horizontal scale (full-scale time) for the time measurements in the general purpose digital modulation analysis. Programming a specified scale sets DISP`l`ay:DDEMod:X[:SCALe]:AUTO:STATe OFF.

<b>Conditions</b>	Measurement views: EVM versus Time, Magnitude error versus Time, Phase error versus Time
<b>Group</b>	Display commands
<b>Syntax</b>	DISP <code>l</code> ay:DDEMod:X[:SCALe] <va <code>l</code> ue> DISP <code>l</code> ay:DDEMod:X[:SCALe]?
<b>Related Commands</b>	<a href="#">DISP<code>l</code>ay:DDEMod:X[:SCALe]:AUTO:STATe</a> , <a href="#">DISP<code>l</code>ay:DDEMod:X[:SCALe]:OFFSet</a>
<b>Arguments</b>	<va <code>l</code> ue>::=<NRf> specifies the horizontal scale in full-scale time. Use the <a href="#">DISP<code>l</code>ay:DDEMod:X[:SCALe]:MAXimum?</a> and <a href="#">DISP<code>l</code>ay:DDEMod:X[:SCALe]:MINimum?</a> queries to get the upper and lower limits of the setting range. The unit can be changed by the <a href="#">[SENSe]:DDEMod:TIME:UNITs</a> command.
<b>Examples</b>	DISP <code>l</code> AY:DDEMOD:X:SCALE 1.5us sets the horizontal scale to 1.5 $\mu$ s.



## DISPlay:DDEMod:X[:SCALE]:AUTO (No Query Form)

Sets the horizontal scale automatically to fit the waveform to the screen in the general purpose digital modulation analysis. Executing this command sets DISPlay:DDEMod:X[:SCALE]:AUTO:STATe ON.

**Conditions** Measurement views: EVM versus Time, Magnitude error versus Time, Phase error versus Time

**Group** Display commands

**Syntax** DISPlay:DDEMod:X[:SCALE]:AUTO

**Related Commands** [DISPlay:DDEMod:X\[:SCALE\]:AUTO:STATe](#)

**Arguments** None

**Examples** DISPLAY:DDEMOD:X:SCALE:AUTO sets the horizontal scale automatically to fit the waveform to the screen.

## DISPlay:DDEMod:X[:SCALE]:AUTO:STATe

Determines whether to set the horizontal scale automatically or manually.

**Conditions** Measurement views: EVM versus Time, Magnitude error versus Time, Phase error versus Time

**Group** Display commands

**Syntax** DISPlay:DDEMod:X[:SCALE]:AUTO:STATe { OFF | ON | 0 | 1 }  
DISPlay:DDEMod:X[:SCALE]:AUTO:STATe?

**Arguments** OFF or 0 specifies that the horizontal scale is set manually. To set it, use the [DISPlay:DDEMod:X\[:SCALE\]](#) and [DISPlay:DDEMod:X\[:SCALE\]:OFFSet](#) commands.

ON or 1 specifies that the horizontal scale is set automatically.

**Examples**     `DISPLAY:DDEMOD:X:SCALE:AUTO:STATE ON` specifies that the horizontal scale is set automatically.

## DISPlay:DDEMod:X[:SCALe]:MAXimum? (Query Only)

Queries the upper limit of the horizontal scale setting range.

**Conditions**     Measurement views: EVM versus Time, Magnitude error versus Time, Phase error versus Time

**Group**     Display commands

**Syntax**     `DISPlay:DDEMod:X[:SCALe]:MAXimum?`

**Arguments**     None

**Returns**     <NRF> The upper limit of the horizontal scale setting range.  
The unit can be changed by the [\[SENSe\]:DDEMod:TIME:UNITs](#) command.

**Examples**     `DISPLAY:DDEMOD:X:SCALE:MAXIMUM?` might return `18.135E-3`, indicating that the upper limit of the horizontal scale setting range is 18.135 ms.

## DISPlay:DDEMod:X[:SCALe]:MINimum? (Query Only)

Queries the lower limit of the horizontal scale setting range.

**Conditions**     Measurement views: EVM versus Time, Magnitude error versus Time, Phase error versus Time

**Group**     Display commands

**Syntax**     `DISPlay:DDEMod:X[:SCALe]:MINimum?`

**Arguments**     None

**Returns**     <NRF> The lower limit of the horizontal scale setting range.  
The unit can be changed by the [\[SENSe\]:DDEMod:TIME:UNITs](#) command.

**Examples** `DISPLAY:DDEMOD:X:SCALE:MINIMUM` might return `10.0E-9`, indicating that the lower limit of the horizontal scale setting range is 10.0 ns.

## DISPlay:DDEMod:X[:SCALe]:OFFSet

Sets or queries the minimum horizontal value (left edge) for the time measurements in the general purpose digital modulation analysis. Programming a specified offset sets `DISPlay:DDEMod:X[:SCALe]:AUTO:STATe` OFF.

**Conditions** Measurement views: EVM versus Time, Magnitude error versus Time, Phase error versus Time

**Group** Display commands

**Syntax** `DISPlay:DDEMod:X[:SCALe]:OFFSet <value>`  
`DISPlay:DDEMod:X[:SCALe]:OFFSet?`

**Related Commands** [DISPlay:DDEMod:X\[:SCALe\]:AUTO:STATe](#), [DISPlay:DDEMod:X\[:SCALe\]](#)

**Arguments** `<value>::=<Nrf>` specifies the minimum horizontal value.

Use the [DISPlay:DDEMod:X\[:SCALe\]:OFFSet:MAXimum?](#) and [DISPlay:DDEMod:X\[:SCALe\]:OFFSet:MINimum?](#) queries to get the upper and lower limits of the setting range.

The unit can be changed by the [\[SENSe\]:DDEMod:TIME:UNITs](#) command.

**Examples** `DISPLAY:DDEMOD:X:SCALE:OFFSET 20.075us` sets the minimum horizontal value to 20.075  $\mu$ s.

## DISPlay:DDEMod:X[:SCALe]:OFFSet:MAXimum? (Query Only)

Queries the upper limit of the horizontal offset setting range.

**Conditions** Measurement views: EVM versus Time, Magnitude error versus Time, Phase error versus Time

**Group** Display commands

**Syntax** `DISPlay:DDEMod:X[:SCALe]:OFFSet:MAXimum?`

<b>Arguments</b>	None
<b>Returns</b>	<NRF> The upper limit of the horizontal offset setting range. The unit can be changed by the <a href="#">[SENSe]:DDEMod:TIME:UNITs</a> command.
<b>Examples</b>	DISPLAY:DDEMOD:X:SCALE:OFFSET:MAXIMUM? might return -1.812E-3, indicating that the upper limit of the horizontal offset setting range is -1.812 ms.

## DISPlay:DDEMod:X[:SCALE]:OFFSet:MINimum? (Query Only)

Queries the lower limit of the horizontal offset setting range.

<b>Conditions</b>	Measurement views: EVM versus Time, Magnitude error versus Time, Phase error versus Time
<b>Group</b>	Display commands
<b>Syntax</b>	DISP <code>l</code> ay:DDEMod:X[:SCALE]:OFFSet:MINimum?
<b>Arguments</b>	None
<b>Returns</b>	<NRF> The lower limit of the horizontal offset setting range. The unit can be changed by the <a href="#">[SENSe]:DDEMod:TIME:UNITs</a> command.
<b>Examples</b>	DISPLAY:DDEMOD:X:SCALE:OFFSET:MINIMUM? might return -16.28E-3, indicating that the lower limit of the horizontal offset setting range is -16.28 ms.

## DISPlay:DDEMod:X[:SCALE]:RESet (No Query Form)

Presets the horizontal scale to the default value for the time measurements in the general purpose digital modulation analysis.

<b>Conditions</b>	Measurement views: EVM versus Time, Magnitude error versus Time, Phase error versus Time
<b>Group</b>	Display commands

---

<b>Syntax</b>	DISP <code>l</code> ay:DDEMod:X[:SCALE]:RESet
<b>Arguments</b>	None
<b>Examples</b>	DISP <code>l</code> ay:DDEMOD:X:SCALE:RESEt presets the horizontal scale to the default value.

## DISP`l`ay:DIAG`r`am:X[:SCALE]

Sets or queries the horizontal range for the eye and trellis diagrams in the general purpose digital modulation analysis.

<b>Conditions</b>	Measurement views: Eye diagram, Trellis diagram
<b>Group</b>	Display commands
<b>Syntax</b>	DISP <code>l</code> ay:DIAG <code>r</code> am:X[:SCALE] <value> DISP <code>l</code> ay:DIAG <code>r</code> am:X[:SCALE]?
<b>Arguments</b>	<value> ::= <NR1> specifies the horizontal range. Range: 1 to 16 symbols.
<b>Examples</b>	DISP <code>l</code> ay:DIAG <code>r</code> am:X:SCALE 3 sets the horizontal range to 3 symbols in the eye and trellis diagrams.

## DISP`l`ay:DIAG`r`am:X[:SCALE]:RESet (No Query Form)

Presets the horizontal scale to the default value for the eye and trellis diagrams in the general purpose digital modulation analysis.

<b>Conditions</b>	Measurement views: Eye diagram, Trellis diagram
<b>Group</b>	Display commands
<b>Syntax</b>	DISP <code>l</code> ay:DIAG <code>r</code> am:X[:SCALE]:RESet
<b>Arguments</b>	None

**Examples**     `DISPLAY:DIAGRAM:X:SCALE:RESET` presets the horizontal scale to the default value for the eye and trellis diagrams.

## **DISPlay:DIQVtime:WINDow:TRACe:GRATICule:GRID:STATe**

Determines whether to show or hide the graticule grid on the screen.

**Conditions**     Measurement views: Demodulated I&Q versus Time

**Group**     Display commands

**Syntax**     `DISPlay:DIQVtime:WINDow:TRACe:GRATICule:GRID:STATE { OFF | ON | 0 | 1 }`  
`DISPlay:DIQVtime:WINDow:TRACe:GRATICule:GRID:STATE?`

**Arguments**     OFF or 0 hides the graticule grid.  
                       ON or 1 shows the graticule grid.

**Examples**     `DISPLAY:DIQVTIME:WINDOW:TRACE:GRATICULE:GRID:STATE ON` shows the graticule grid on the screen in the Demodulated I&Q versus Time view.

## **DISPlay:DIQVtime:Y[:SCALE]**

Sets or queries the vertical range of the Demodulated I&Q versus Time graph.

**Conditions**     Measurement views: Demodulated I&Q versus Time

**Group**     Display commands

**Syntax**     `DISPlay:DIQVtime:Y[:SCALE] <value>`  
`DISPlay:DIQVtime:Y[:SCALE]?`

**Arguments**     `<value>::=<NRF>` specifies the vertical range. Range: 1  $\mu$ V to 10 V.

**Examples**     `DISPLAY:DIQVTIME:Y:SCALE 2.5` sets the vertical range to 2.5 V in the Demodulated I&Q versus Time graph.

## DISPlay:DIQVtime:Y[:SCALe]:AUTO (No Query Form)

Sets the vertical scale automatically to fit the waveform to the screen in the Demodulated I&Q versus Time display.

<b>Conditions</b>	Measurement views: Demodulated I&Q versus Time
<b>Group</b>	Display commands
<b>Syntax</b>	DISPlay:DIQVtime:Y[:SCALe]:AUTO
<b>Arguments</b>	None
<b>Examples</b>	DISPLAY:DIQVTIME:Y:SCALE:AUTO sets the vertical scale automatically to fit the waveform to the screen.

## DISPlay:DIQVtime:Y[:SCALe]:OFFSet

Sets or queries the vertical offset (center point of the vertical axis) of the Demodulated I&Q versus Time graph.

<b>Conditions</b>	Measurement views: Demodulated I&Q versus Time
<b>Group</b>	Display commands
<b>Syntax</b>	DISPlay:DIQVtime:Y[:SCALe]:OFFSet <value> DISPlay:DIQVtime:Y[:SCALe]:OFFSet?
<b>Arguments</b>	<value> ::= <NRF> specifies the vertical offset. Range: -5 to +5 V.
<b>Examples</b>	DISPLAY:DIQVTIME:Y:SCALE:OFFSET -0.5 sets the vertical offset to -0.5 V in the Demodulated I&Q versus Time graph.

## DISPlay:DPSA:LEGend:STATe

Determines whether to show or hide the trace legend on the display. The legend indicates the trace detection and function on the screen for each displayed trace.

<b>Conditions</b>	Measurement views: DPX spectrum
<b>Group</b>	Display commands
<b>Syntax</b>	DISP <code>l</code> ay:DPSA:LEGend:STATe { OFF   ON   0   1 } DISP <code>l</code> ay:DPSA:LEGend:STATe?
<b>Arguments</b>	OFF or 0 hides the trace legend. ON or 1 shows the trace legend.
<b>Examples</b>	DISP <code>l</code> AY:DPSA:LEGEND:STATE ON shows the trace legend on the screen.

## DISP`l`ay:DPSA:WINDow:TRACe:GRATICule:GRID:STATe

Determines whether to show or hide the graticule grid on the screen.

<b>Conditions</b>	Measurement views: DPX spectrum
<b>Group</b>	Display commands
<b>Syntax</b>	DISP <code>l</code> ay:DPSA:WINDow:TRACe:GRATICule:GRID:STATe { OFF   ON   0   1 } DISP <code>l</code> ay:DPSA:WINDow:TRACe:GRATICule:GRID:STATe?
<b>Arguments</b>	OFF or 0 hides the graticule grid. ON or 1 shows the graticule grid.
<b>Examples</b>	DISP <code>l</code> AY:DPSA:WINDOW:TRACE:GRATICULE:GRID:STATE ON shows the graticule grid on the screen in the DPX spectrum view.

## DISP`l`ay:DPSA:Y[:SCALe]:PDIVision

Sets or queries the vertical scale (per division) in the DPX spectrum view.

<b>Conditions</b>	Measurement views: DPX spectrum
-------------------	---------------------------------



<b>Group</b>	Display commands
<b>Syntax</b>	DISP <code>lay:DPSA:Y[:SCALE]:PDIVision</code> <value> DISP <code>lay:DPSA:Y[:SCALE]:PDIVision?</code>
<b>Related Commands</b>	<a href="#">[SENSe]:POWer:UNITs</a>
<b>Arguments</b>	<value> ::= <NRF> specifies the vertical scale (per division). Range: 2 to 20 dB/div.
<b>Examples</b>	SENSE:DPSA:Y:SCALE:PDIVISION 0.5 sets the vertical scale to 0.5 dB/div.

## DISP`lay:EDIagram:WINDow:TRACe:GRATICule:GRID:STATE`

Determines whether to show or hide the graticule grid on the screen in the eye diagram.

<b>Conditions</b>	Measurement views: Eye diagram
<b>Group</b>	Display commands
<b>Syntax</b>	DISP <code>lay:EDIagram:WINDow:TRACe:GRATICule:GRID:STATE</code> { OFF   ON   0   1 } DISP <code>lay:EDIagram:WINDow:TRACe:GRATICule:GRID:STATE?</code>
<b>Arguments</b>	OFF or 0 hides the graticule grid. ON or 1 shows the graticule grid.
<b>Examples</b>	DISPLAY:EDIAGRAM:WINDOW:TRACE:GRATICULE:GRID:STATE ON shows the graticule grid on the screen in the eye diagram.

## DISP`lay:EDIagram:Y[:SCALE]`

Sets or queries the vertical range of the eye diagram.

<b>Conditions</b>	Measurement views: Eye diagram
-------------------	--------------------------------

<b>Group</b>	Display commands
<b>Syntax</b>	DISP <code>lay</code> :EDIagram:Y[:SCALE] <value> DISP <code>lay</code> :EDIagram:Y[:SCALE]?
<b>Arguments</b>	<value>::=<NRF> specifies the vertical range. Range: 1 $\mu$ to 100 (unitless).
<b>Examples</b>	DISP <code>lay</code> :EDIAGRAM:Y:SCALE 2.5 sets the vertical range to 2.5 in the eye diagram.

## DISP`lay`:EDDiagram:Y[:SCALE]:AUTO (No Query Form)

Sets the vertical scale automatically to fit the waveform to the screen in the eye diagram.

<b>Conditions</b>	Measurement views: Eye diagram
<b>Group</b>	Display commands
<b>Syntax</b>	DISP <code>lay</code> :EDIagram:Y[:SCALE]:AUTO
<b>Arguments</b>	None
<b>Examples</b>	DISP <code>lay</code> :EDIAGRAM:Y:SCALE:AUTO sets the vertical scale automatically to fit the waveform to the screen.

## DISP`lay`:EDDiagram:Y[:SCALE]:OFFSet

Sets or queries the vertical offset (center point of the vertical axis) of the eye diagram.

<b>Conditions</b>	Measurement views: Eye diagram
<b>Group</b>	Display commands
<b>Syntax</b>	DISP <code>lay</code> :EDIagram:Y[:SCALE]:OFFSet <value> DISP <code>lay</code> :EDIagram:Y[:SCALE]:OFFSet?

- Arguments** <value> ::= <Nrf> specifies the minimum vertical value.  
Range: -50 to +50 (unitless).
- Examples** DISPLAY:EDIAGRAM:Y:SCALE:OFFSET -0.5 sets the vertical offset to -0.5 in the eye diagram.

## DISPlay:EVM:Y[:SCALE]

Sets or queries the vertical range of the EVM versus Time graph.

- Conditions** Measurement views: EVM versus Time

- Group** Display commands

- Syntax** DISPlay:EVM:Y[:SCALE] <value>  
DISPlay:EVM:Y[:SCALE]?

- Related Commands** [DISPlay:EVM:Y\[:SCALE\]:OFFSet](#)

- Arguments** <value> ::= <Nrf> specifies the vertical range. Range: 1 to 100%.

- Examples** DISPLAY:EVM:Y:SCALE 50 sets the vertical range to 50% in the EVM versus Time graph.

## DISPlay:EVM:Y[:SCALE]:AUTO (No Query Form)

Sets the vertical scale automatically to fit the waveform to the screen in the EVM versus Time display.

- Conditions** Measurement views: EVM versus Time

- Group** Display commands

- Syntax** DISPlay:EVM:Y[:SCALE]:AUTO

- Arguments** None

**Examples**     `DISPLAY:EVM:Y:SCALE:AUTO` sets the vertical scale automatically to fit the waveform to the screen.

## DISPlay:EVM:Y[:SCALE]:OFFSet

Sets or queries the minimum vertical value (bottom edge) of the EVM versus Time graph.

**Conditions**     Measurement views: EVM versus Time

**Group**     Display commands

**Syntax**     `DISPlay:EVM:Y[:SCALE]:OFFSet <value>`  
`DISPlay:EVM:Y[:SCALE]:OFFSet?`

**Related Commands**     [DISPlay:EVM:Y\[:SCALE\]](#)

**Arguments**     `<value>::=<NRF>` specifies the minimum vertical value. Range: -100 to 100%.

**Examples**     `DISPLAY:EVM:Y:SCALE:OFFSET -9.5` sets the minimum vertical value to -9.5% in the EVM versus Time graph.

## DISPlay:FDVTime:WINDow:TRACe:GRATicule:GRID:STATE

Determines whether to show or hide the graticule grid on the screen.

**Conditions**     Measurement views: Frequency deviation versus Time

**Group**     Display commands

**Syntax**     `DISPlay:FDVTime:WINDow:TRACe:GRATicule:GRID:STATE { OFF | ON | 0 | 1 }`  
`DISPlay:FDVTime:WINDow:TRACe:GRATicule:GRID:STATE?`

**Arguments**     OFF or 0 hides the graticule grid.

ON or 1 shows the graticule grid.

**Examples** `DISPLAY:FDVTIME:WINDOW:TRACE:GRATICULE:GRID:STATE ON` shows the graticule grid on the Frequency deviation versus Time view.

## DISPlay:FDVTime:Y[:SCALE]

Sets or queries the vertical range of the Frequency deviation versus Time graph.

**Conditions** Measurement views: Frequency deviation versus Time

**Group** Display commands

**Syntax** `DISPlay:FDVTime:Y[:SCALE] <value>`  
`DISPlay:FDVTime:Y[:SCALE]?`

**Arguments** `<value> ::= <Nrf>` specifies the vertical range. Range: 10 Hz to 120 MHz.

**Examples** `DISPLAY:FDVTIME:Y:SCALE 30MHZ` sets the vertical range to 30 MHz in the Frequency deviation versus Time graph.

## DISPlay:FDVTime:Y[:SCALE]:AUTO (No Query Form)

Sets the vertical scale automatically to fit the waveform to the screen in the Frequency deviation versus Time view.

**Conditions** Measurement views: Frequency deviation versus Time

**Group** Display commands

**Syntax** `DISPlay:FDVTime:Y[:SCALE]:AUTO`

**Arguments** None

**Examples** `DISPLAY:FDVTIME:Y:SCALE:AUTO` sets the vertical scale automatically to fit the waveform to the screen.

## DISPlay:FDVTime:Y[:SCALE]:OFFSet

Sets or queries the vertical offset (center point of the vertical axis) in the Frequency deviation versus Time graph.

<b>Conditions</b>	Measurement views: Frequency deviation versus Time
<b>Group</b>	Display commands
<b>Syntax</b>	DISPlay:FDVTime:Y[:SCALE]:OFFSet <value> DISPlay:FDVTime:Y[:SCALE]:OFFSet?
<b>Arguments</b>	<value>::=<Nrf> specifies the vertical offset. Range: -60 MHz to +60 MHz.
<b>Examples</b>	DISPlay:FDVTime:Y:SCALE:OFFSet -14.5MHz sets the vertical offset to -14.5 MHz in the Frequency deviation versus Time graph.

## DISPlay:FVTime:WINDow:TRACe:GRATICule:GRID:STATe

Determines whether to show or hide the graticule grid on the screen.

<b>Conditions</b>	Measurement views: Frequency versus Time
<b>Group</b>	Display commands
<b>Syntax</b>	DISPlay:FVTime:WINDow:TRACe:GRATICule:GRID:STATe { OFF   ON   0   1 } DISPlay:FVTime:WINDow:TRACe:GRATICule:GRID:STATe?
<b>Arguments</b>	OFF or 0 hides the graticule grid. ON or 1 shows the graticule grid.
<b>Examples</b>	DISPlay:FVTime:WINDow:TRACe:GRATICule:GRID:STATe ON shows the graticule grid on the Frequency versus Time view.

## DISPlay:FVTime:X[:SCALE]

Sets or queries the horizontal scale (full-scale time) of the Frequency versus Time graph. Programming a specified scale sets DISPlay:FVTime:X[:SCALE] AUTO:STATe OFF.

**Conditions** Measurement views: Frequency versus Time

**Group** Display commands

**Syntax** DISPlay:FVTime:X[:SCALE] <value>  
DISPlay:FVTime:X[:SCALE]?

**Related Commands** [DISPlay:FVTime:X\[:SCALE\]:AUTO:STATe](#), [DISPlay:FVTime:X\[:SCALE\]:OFFSet](#)

**Arguments** <value>::={ <NRF> | MAXimum | MINimum } specifies the horizontal scale in full-scale time. MAXimum and MINimum represent the upper and lower limits of the setting range, respectively.

Use the [DISPlay:FVTime:X\[:SCALE\]:MAXimum?](#) and [DISPlay:FVTime:X\[:SCALE\]:MINimum?](#) queries to get the upper and lower limit values of the setting range.

**Examples** DISPLAY:FVTIME:X:SCALE 25.6us sets the horizontal scale to 25.6  $\mu$ s.

## DISPlay:FVTime:X[:SCALE]:AUTO (No Query Form)

Sets the horizontal scale automatically to fit the waveform to the screen in the Frequency versus Time view. Executing this command sets DISPlay:FVTime X[:SCALE]:AUTO:STATe ON.

**Conditions** Measurement views: Frequency versus Time

**Group** Display commands

**Syntax** DISPlay:FVTime:X[:SCALE]:AUTO

**Related Commands** [DISPlay:FVTime:X\[:SCALE\]:AUTO:STATe](#)

<b>Arguments</b>	None
<b>Examples</b>	<code>DISPLAY:FVTIME:X:SCALE:AUTO</code> sets the horizontal scale automatically to fit the waveform to the screen.

## **DISPlay:FVTime:X[:SCALE]:AUTO:STATE**

Determines whether to set the horizontal scale automatically or manually.

<b>Conditions</b>	Measurement views: Frequency versus Time
<b>Group</b>	Display commands
<b>Syntax</b>	<code>DISPlay:FVTime:X[:SCALE]:AUTO:STATE { OFF   ON   0   1 }</code> <code>DISPlay:FVTime:X[:SCALE]:AUTO:STATE?</code>
<b>Arguments</b>	<p>OFF or 0 specifies that the horizontal scale is set manually. To set it, use the <a href="#">DISPlay:FVTime:X[:SCALE]</a> and <a href="#">DISPlay:FVTime:X[:SCALE]:OFFSet</a> commands.</p> <p>ON or 1 specifies that the horizontal scale is set automatically.</p>
<b>Examples</b>	<code>DISPLAY:FVTIME:X:SCALE:AUTO:STATE ON</code> specifies that the horizontal scale is set automatically.

## **DISPlay:FVTime:X[:SCALE]:MAXimum? (Query Only)**

Queries the upper limit of the horizontal scale setting range.

<b>Conditions</b>	Measurement views: Frequency versus Time
<b>Group</b>	Display commands
<b>Syntax</b>	<code>DISPlay:FVTime:X[:SCALE]:MAXimum?</code>
<b>Related Commands</b>	<a href="#">DISPlay:FVTime:X[:SCALE]</a>
<b>Arguments</b>	None



**Returns** <NRf> The upper limit of the horizontal scale setting range.

**Examples** `DISPLAY:FVTIME:X:SCALE:MAXIMUM?` might return `18.135E-3`, indicating that the upper limit of the horizontal scale setting range is 18.135 ms.

## DISPlay:FVTime:X[:SCALe]:MINimum? (Query Only)

Queries the lower limit of the horizontal scale setting range.

**Conditions** Measurement views: Frequency versus Time

**Group** Display commands

**Syntax** `DISPlay:FVTime:X[:SCALe]:MINimum?`

**Related Commands** [DISPlay:FVTime:X\[:SCALe\]](#)

**Arguments** None

**Returns** <NRf> The lower limit of the horizontal scale setting range.

**Examples** `DISPLAY:FVTIME:X:SCALE:MINIMUM?` might return `10.0E-9`, indicating that the lower limit of the horizontal scale setting range is 10.0 ns.

## DISPlay:FVTime:X[:SCALe]:OFFSet

Sets or queries the minimum horizontal value (left edge) of the Frequency versus Time graph. Programming a specified offset sets `DISPlay:FVTime:X[:SCALe] AUTO:STATe OFF`.

**Conditions** Measurement views: Frequency versus Time

**Group** Display commands

**Syntax** `DISPlay:FVTime:X[:SCALe]:OFFSet <value>`  
`DISPlay:FVTime:X[:SCALe]:OFFSet?`

<b>Related Commands</b>	<a href="#">DISPlay:FVTime:X[:SCALE]:AUTO:STATe</a> , <a href="#">DISPlay:FVTime:X[:SCALE]</a>
<b>Arguments</b>	<p>&lt;value&gt;::={ &lt;NRF&gt;   MAXimum   MINimum } specifies the horizontal offset. MAXimum and MINimum represent the upper and lower limits of the setting range, respectively.</p> <p>Use the <a href="#">DISPlay:FVTime:X[:SCALE]:OFFSet:MAXimum?</a> and <a href="#">DISPlay:FVTime:X[:SCALE]:OFFSet:MINimum?</a> queries to get the upper and lower limit values of the setting range.</p>
<b>Examples</b>	<code>DISPlay:FVTime:X[:SCALE]:OFFSet 800ns</code> sets the minimum horizontal value to 800 ns in the Frequency versus Time graph.

### DISPlay:FVTime:X[:SCALE]:OFFSet:MAXimum? (Query Only)

Queries the upper limit of the horizontal offset setting range.

<b>Conditions</b>	Measurement views: Frequency versus Time
<b>Group</b>	Display commands
<b>Syntax</b>	<code>DISPlay:FVTime:X[:SCALE]:OFFSet:MAXimum?</code>
<b>Related Commands</b>	<a href="#">DISPlay:FVTime:X[:SCALE]:OFFSet</a>
<b>Arguments</b>	None
<b>Returns</b>	<NRF> The upper limit of the horizontal offset setting range.
<b>Examples</b>	<code>DISPlay:FVTime:X[:SCALE]:OFFSet:MAXimum?</code> might return <code>-1.812E-3</code> , indicating that the upper limit of the horizontal offset setting range is -1.812 ms.

### DISPlay:FVTime:X[:SCALE]:OFFSet:MINimum? (Query Only)

Queries the lower limit of the horizontal offset setting range.

<b>Conditions</b>	Measurement views: Frequency versus Time
-------------------	--

---

<b>Group</b>	Display commands
<b>Syntax</b>	DISPlay:FVTime:X[:SCALE]:OFFSet:MINimum?
<b>Related Commands</b>	<a href="#">DISPlay:FVTime:X[:SCALE]:OFFSet</a>
<b>Arguments</b>	None
<b>Returns</b>	<NRf> The lower limit of the horizontal offset setting range.
<b>Examples</b>	DISPLAY:FVTIME:X:SCALE:OFFSET:MINIMUM? might return -16.28E-3, indicating that the lower limit of the horizontal offset setting range is -16.28 ms.

## DISPlay:FVTime:Y[:SCALE]

Sets or queries the vertical range of the Frequency versus Time graph.

<b>Conditions</b>	Measurement views: Frequency versus Time
<b>Group</b>	Display commands
<b>Syntax</b>	DISPlay:FVTime:Y[:SCALE] <value> DISPlay:FVTime:Y[:SCALE]?
<b>Related Commands</b>	<a href="#">DISPlay:FVTime:Y[:SCALE]:OFFSet</a>
<b>Arguments</b>	<value>::=<NRf> specifies the vertical range. Range: 10 Hz to 120 MHz.
<b>Examples</b>	DISPlay:FVTime:Y:SCALE 30MHZ sets the vertical range to 30 MHz in the Frequency versus Time graph.

## DISPlay:FVTime:Y[:SCALE]:AUTO (No Query Form)

Sets the vertical scale automatically to fit the waveform to the screen in the Frequency versus Time view.

<b>Conditions</b>	Measurement views: Frequency versus Time
<b>Group</b>	Display commands
<b>Syntax</b>	DISPlay:FVTime:Y[:SCALE]:AUTO
<b>Arguments</b>	None
<b>Examples</b>	DISPLAY:FVTIME:Y:SCALE:AUTO sets the vertical scale automatically to fit the waveform to the screen.

## DISPlay:FVTime:Y[:SCALE]:OFFSet

Sets or queries the vertical offset (the value at the center of the vertical axis) in the Frequency versus Time graph.

<b>Conditions</b>	Measurement views: Frequency versus Time
<b>Group</b>	Display commands
<b>Syntax</b>	DISPlay:FVTime:Y[:SCALE]:OFFSet <value> DISPlay:FVTime:Y[:SCALE]:OFFSet?
<b>Related Commands</b>	<a href="#">DISPlay:FVTime:Y[:SCALE]</a>
<b>Arguments</b>	<value>::=<NRF> specifies the vertical offset. Range: -60 MHz to +60 MHz.
<b>Examples</b>	DISPLAY:FVTIME:Y:SCALE:OFFSET -14.5MHZ sets the vertical offset to -14.5 MHz in the Frequency versus Time graph.

## DISPlay:GENeral:MEASview:DElete (No Query Form)

Deletes a measurement view in the general signal viewing.

<b>Conditions</b>	Measurement views: General signal viewing
-------------------	---

**Group** Display commands

**Syntax** `DISPlay:GENeral:MEASview:DELeTe { SPECTrum | DPSA | AVTime | FVTime | PHVTime | IQVTime | SGRam | TOVerview }`

**Arguments** The following table shows the arguments. The arguments are the string type.

**Table 2-30: General signal viewing views**

Argument	View
SPECTrum	Spectrum
DPSA	DPX (Digital Phosphor) spectrum
AVTime	Amplitude versus Time
FVTime	Frequency versus Time
PHVTime	Phase versus Time
IQVTime	IQ versus Time
SGRam	Spectrogram
TOVerview	Time overview

If you attempt to delete a view that is not displayed on screen, the error (-200, "Execution error; Measurement not running") will be returned.

**Examples** `DISPlay:GENeral:MEASVIEW:DELeTE DPSA` deletes the DPX spectrum view.

## DISPlay:GENeral:MEASview:NEW (No Query Form)

Displays a new measurement view in the general signal viewing.

**Conditions** Measurement views: General signal viewing

**Group** Display commands

**Syntax** `DISPlay:GENeral:MEASview:NEw { SPECTrum | DPSA | AVTime | FVTime | PHVTime | IQVTime | SGRam | TOVerview }`

**Arguments** (See Table 2-30 on page 2-259.) If you attempt to open a view that is currently displayed on screen, the error (-200, "Execution error; Measurement is already running") will be returned.

**Examples**     `DISPLAY:GENERAL:MEASVIEW:NEW DPXA` creates the DPX spectrum view.

## DISPlay:GENeral:MEASview:SElect

Selects a measurement view in the general signal viewing on the screen. The query command returns the currently selected view.

Selecting a measurement optimizes it. Other measurements may be optimized as a side effect. Refer to the [DISPlay:WINDow:OPTimized:MEASurement?](#) query.

**Conditions**     Measurement views: General signal viewing

**Group**            Display commands

**Syntax**           `DISPlay:GENeral:MEASview:SElect { SPECTrum | DPXA | AVTime | FVTime | PHVTime | IQVTime | SGRam | TOVerview }`  
`DISPlay:GENeral:MEASview:SElect?`

**Arguments**       (See Table 2-30 on page 2-259.) If you attempt to select a view that is not displayed on screen, the error (-200, "Execution error; Measurement not running") will be returned.

The time overview (TOVerview) cannot be selected as the primary measurement. If you select it, the error (-200, "Execution error; Time Overview cannot be Primary measurement") will be returned. If you use the `DISPlay:GENeral MEASview:SElect?` query with the time overview as the only measurement active, the error (-200, "Execution error; Analysis selected is not running") will be returned.

**Examples**        `DISPLAY:GENERAL:MEASVIEW:SELECT DPXA` selects the DPX spectrum view.

## DISPlay:GPRF:MEASview:DElete (No Query Form)

Deletes a selected measurement view in the RF measurements.

**Conditions**       Measurement views: RF measurements

**Group**            Display commands

**Syntax** `DISPlay:GPRF:MEASview:DELeTe { CCDF | ACPower | MCPower | OBW | PNOise | SPURious }`

**Arguments** CCDF deletes the CCDF view.  
 ACPower deletes the Channel power and ACPR view.  
 MCPower deletes the MCPR view.  
 OBW deletes the Occupied Bandwidth view.  
 PNOise deletes the Phase Noise view (Option 11 only).  
 SPURious deletes the Spurious view.  
 If you attempt to delete a view that is not displayed on screen, the error (-200, "Execution error; Measurement not running") will be returned.

**Examples** `DISPLAY:GPRF:MEASVIEW:DELETE ACPower` deletes the Channel power and ACPR view.

## DISPlay:GPRF:MEASview:NEW (No Query Form)

Displays a new measurement view in the RF measurements.

**Conditions** Measurement views: RF measurements

**Group** Display commands

**Syntax** `DISPlay:GPRF:MEASview:NEW { CCDF | ACPower | MCPower | OBW | PNOise | SPURious }`

**Arguments** CCDF opens the CCDF view.  
 ACPower opens the Channel power and ACPR view.  
 MCPower opens the MCPR view.  
 OBW opens the Occupied Bandwidth view.  
 PNOise opens the Phase Noise view (Option 11 only).  
 SPURious opens the Spurious view.  
 If you attempt to open a view that is currently displayed on screen, the error (-200, "Execution error; Measurement is already running") will be returned.

**Examples**     `DISPLAY:GPRF:MEASVIEW:NEW ACPower` creates the Channel power and ACPR view.

## DISPlay:GPRF:MEASview:SElect

Selects a measurement view in the RF measurements on the screen. The query command returns the currently selected view.

Selecting a measurement optimizes it. Other measurements may be optimized as a side effect. Refer to the [DISPlay:WINDow:OPTimized:MEASurement?](#) query.

**Conditions**     Measurement views: RF measurements

**Group**     Display commands

**Syntax**     `DISPlay:GPRF:MEASview:SElect { CCDF | ACPower | MCPower |  
OBW | PNOise | SPURious }  
DISPlay:GPRF:MEASview:SElect?`

**Arguments**     `CCDF` selects the CCDF view.  
`ACPower` selects the Channel power and ACPR view.  
`MCPower` selects the MCPR view.  
`OBW` selects the Occupied Bandwidth view.  
`PNOise` selects the Phase Noise view (Option 11 only).  
`SPURious` selects the Spurious view.  
If you attempt to select a view that is not displayed on screen, the error (-200, "Execution error; Measurement not running") will be returned.

**Examples**     `DISPLAY:GPRF:MEASVIEW:SELECT ACPower` selects the Channel power and ACPR view.

## DISPlay:IQVTime:WINDow:TRACe:GRATicule:GRID:STATE

Determines whether to show or hide the graticule grid on the screen.

**Conditions**     Measurement views: RF I&Q versus Time



<b>Group</b>	Display commands
<b>Syntax</b>	DISP <code>l</code> ay:IQVTime:WINDow:TRACe:GRATicule:GRID:STATe { OFF   ON   0   1 } DISP <code>l</code> ay:IQVTime:WINDow:TRACe:GRATicule:GRID:STATe?
<b>Arguments</b>	OFF or 0 hides the graticule grid. ON or 1 shows the graticule grid.
<b>Examples</b>	DISP <code>l</code> AY:IQVTIME:WINDOW:TRACE:GRATICULE:GRID:STATE ON shows the graticule grid on the RF I&Q versus Time view.

## DISP`l`ay:IQVTime:X[:SCALE]

Sets or queries the horizontal scale (full-scale time) of the RF I&Q versus Time graph. Programming a specified scale sets DISP`l`ay:IQVTime:X[:SCALE] AUTO:STATe OFF.

<b>Conditions</b>	Measurement views: RF I&Q versus Time
<b>Group</b>	Display commands
<b>Syntax</b>	DISP <code>l</code> ay:IQVTime:X[:SCALE] <value> DISP <code>l</code> ay:IQVTime:X[:SCALE]?
<b>Related Commands</b>	<a href="#">DISP<code>l</code>ay:IQVTime:X[:SCALE]:AUTO:STATe</a> , <a href="#">DISP<code>l</code>ay:IQVTime:X[:SCALE]:OFFSet</a>
<b>Arguments</b>	<value> ::= { <Nrf>   MAXimum   MINimum } specifies the horizontal scale in full-scale time. MAXimum and MINimum represent the upper and lower limits of the setting range, respectively. Use the <a href="#">DISP<code>l</code>ay:IQVTime:X[:SCALE]:MAXimum?</a> and <a href="#">DISP<code>l</code>ay:IQVTime:X[:SCALE]:MINimum?</a> queries to get the upper and lower limit values of the setting range.
<b>Examples</b>	DISP <code>l</code> AY:IQVTIME:X:SCALE 100us sets the horizontal scale to 100 $\mu$ s.

## DISPlay:IQVTime:X[:SCALe]:AUTO (No Query Form)

Sets the horizontal scale automatically to fit the waveform to the screen in the RF I&Q versus Time view. Executing this command sets DISPlay:IQVTime X[:SCALe]:AUTO:STATe ON.

<b>Conditions</b>	Measurement views: RF I&Q versus Time
<b>Group</b>	Display commands
<b>Syntax</b>	DISPlay:IQVTime:X[:SCALe]:AUTO
<b>Related Commands</b>	<a href="#">DISPlay:IQVTime:X[:SCALe]</a> , <a href="#">DISPlay:IQVTime:X[:SCALe]:AUTO:STATe</a>
<b>Arguments</b>	None
<b>Examples</b>	DISPLAY:IQVTIME:X:SCALE:AUTO sets the horizontal scale automatically to fit the waveform to the screen.

## DISPlay:IQVTime:X[:SCALe]:AUTO:STATe

Determines whether to set the horizontal scale automatically or manually.

<b>Conditions</b>	Measurement views: RF I&Q versus Time
<b>Group</b>	Display commands
<b>Syntax</b>	DISPlay:IQVTime:X[:SCALe]:AUTO:STATe { OFF   ON   0   1 } DISPlay:IQVTime:X[:SCALe]:AUTO:STATe?
<b>Arguments</b>	OFF or 0 specifies that the horizontal scale is set manually. To set it, use the <a href="#">DISPlay:IQVTime:X[:SCALe]</a> and <a href="#">DISPlay:IQVTime:X[:SCALe]:OFFSet</a> commands.  ON or 1 specifies that the horizontal scale is set automatically.
<b>Examples</b>	DISPLAY:IQVTIME:X:SCALE:AUTO:STATE ON specifies that the horizontal scale is set automatically.

## DISPlay:IQVTime:X[:SCALe]:MAXimum? (Query Only)

Queries the upper limit of the horizontal scale setting range.

**Conditions** Measurement views: RF I&Q versus Time

**Group** Display commands

**Syntax** DISPlay:IQVTime:X[:SCALe]:MAXimum?

**Related Commands** [DISPlay:IQVTime:X\[:SCALe\]](#)

**Arguments** None

**Returns** <NRf> The upper limit of the horizontal scale setting range.

**Examples** DISPLAY:IQVTIME:X:SCALE:MAXIMUM? might return 18.135E-3, indicating that the upper limit of the horizontal scale setting range is 18.135 ms.

## DISPlay:IQVTime:X[:SCALe]:MINimum? (Query Only)

Queries the lower limit of the horizontal scale setting range.

**Conditions** Measurement views: RF I&Q versus Time

**Group** Display commands

**Syntax** DISPlay:IQVTime:X[:SCALe]:MINimum?

**Related Commands** [DISPlay:IQVTime:X\[:SCALe\]](#)

**Arguments** None

**Returns** <NRf> The lower limit of the horizontal scale setting range.

**Examples**     `DISPLAY:IQVTIME:X:SCALE:MINIMUM?` might return `10.0E-9`, indicating that the lower limit of the horizontal scale setting range is 10.0 ns.

## **DISPlay:IQVTime:X[:SCALe]:OFFSet**

Sets or queries the minimum horizontal value (left edge) of the RF I&Q versus Time graph. Programming a specified offset sets `DISPlay:IQVTime:X[:SCALe] AUTO:STATe OFF`.

**Conditions**     Measurement views: RF I&Q versus Time

**Group**     Display commands

**Syntax**     `DISPlay:IQVTime:X[:SCALe]:OFFSet <value>`  
`DISPlay:IQVTime:X[:SCALe]:OFFSet?`

**Related Commands**     [DISPlay:IQVTime:X\[:SCALe\]:AUTO:STATe](#), [DISPlay:IQVTime:X\[:SCALe\]](#)

**Arguments**     `<value>::={ <Nrf> | MAXimum | MINimum }` specifies the horizontal offset. `MAXimum` and `MINimum` represent the upper and lower limits of the setting range, respectively.

Use the [DISPlay:IQVTime:X\[:SCALe\]:OFFSet:MAXimum?](#) and [DISPlay:IQVTime:X\[:SCALe\]:OFFSet:MINimum?](#) queries to get the upper and lower limit values of the setting range.

**Examples**     `DISPLAY:IQVTIME:X:SCALE:OFFSET 800ns` sets the minimum horizontal value to 800 ns in the RF I&Q versus Time graph.

## **DISPlay:IQVTime:X[:SCALe]:OFFSet:MAXimum? (Query Only)**

Queries the upper limit of the horizontal offset setting range.

**Conditions**     Measurement views: RF I&Q versus Time

**Group**     Display commands

**Syntax**     `DISPlay:IQVTime:X[:SCALe]:OFFSet:MAXimum?`

---

<b>Related Commands</b>	<a href="#">DISPlay:IQVTime:X[:SCALE]:OFFSet</a>
<b>Arguments</b>	None
<b>Returns</b>	<NRf> The upper limit of the horizontal offset setting range.
<b>Examples</b>	DISPLAY:IQVTIME:X:SCALE:OFFSET:MAXIMUM? might return $-1.812E-3$ , indicating that the upper limit of the horizontal offset setting range is -1.812 ms.

### DISPlay:IQVTime:X[:SCALE]:OFFSet:MINimum? (Query Only)

Queries the lower limit of the horizontal offset setting range.

<b>Conditions</b>	Measurement views: RF I&Q versus Time
<b>Group</b>	Display commands
<b>Syntax</b>	DISPlay:IQVTime:X[:SCALE]:OFFSet:MINimum?
<b>Related Commands</b>	<a href="#">DISPlay:IQVTime:X[:SCALE]:OFFSet</a>
<b>Arguments</b>	None
<b>Returns</b>	<NRf> The lower limit of the horizontal offset setting range.
<b>Examples</b>	DISPLAY:IQVTIME:X:SCALE:OFFSET:MINIMUM? might return $-16.28E-3$ , indicating that the lower limit of the horizontal offset setting range is -16.28 ms.

### DISPlay:IQVTime:Y[:SCALE]

Sets or queries the vertical range of the RF I&Q versus Time graph.

<b>Conditions</b>	Measurement views: RF I&Q versus Time
<b>Group</b>	Display commands

**Syntax**     `DISPlay:IQVTime:Y[:SCALE] <value>`  
`DISPlay:IQVTime:Y[:SCALE]?`

**Related Commands**     [DISPlay:IQVTime:Y\[:SCALE\]:OFFSet](#)

**Arguments**     `<value>::=<NRF>` specifies the vertical range. Range: 1 $\mu$  to 10 V.

**Examples**     `DISPLAY:IQVTIME:Y:SCALE 1.5` sets the vertical range to 1.5 V in the RF I&Q versus Time graph.

## DISPlay:IQVTime:Y[:SCALE]:AUTO (No Query Form)

Sets the vertical scale automatically to fit the waveform to the screen in the RF I&Q versus Time view.

**Conditions**     Measurement views: RF I&Q versus Time

**Group**     Display commands

**Syntax**     `DISPlay:IQVTime:Y[:SCALE]:AUTO`

**Arguments**     None

**Examples**     `DISPLAY:IQVTIME:Y:SCALE:AUTO` sets the vertical scale automatically to fit the waveform to the screen.

## DISPlay:IQVTime:Y[:SCALE]:OFFSet

Sets or queries the vertical offset (the value at the center of the vertical axis) in the RF I&Q versus Time graph.

**Conditions**     Measurement views: RF I&Q versus Time

**Group**     Display commands

**Syntax**     `DISPlay:IQVTime:Y[:SCALE]:OFFSet <value>`  
`DISPlay:IQVTime:Y[:SCALE]:OFFSet?`

**Related Commands** [DISPlay:IQVTime:Y\[:SCALE\]](#)

**Arguments** <value> ::= <NRF> specifies the vertical offset. Range: -5 to +5 V.

**Examples** `DISPlay:IQVTime:Y:SCALE:OFFSET -82.75mV` sets the vertical offset to -82.75 mV in the RF I&Q versus Time graph.

## DISPlay:IQVTime:Y[:SCALE]:RESCale (No Query Form)

Rescales the vertical axis automatically to fit the waveform to the screen.

**Conditions** Measurement views: RF I&Q versus Time

**Group** Display commands

**Syntax** `DISPlay:IQVTime:Y[:SCALE]:RESCale`

**Arguments** None

**Examples** `DISPlay:IQVTime:Y:SCALE:RESCALE` rescales the vertical axis automatically to fit the waveform to the screen.

## DISPlay:MCPower:MARKer:SHOW:STATe

Determines whether to show or hide the readout for the selected marker in the MCPR view.

**Conditions** Measurement views: MCPR

**Group** Display commands

**Syntax** `DISPlay:MCPower:MARKer:SHOW:STATe { OFF | ON | 0 | 1 }`  
`DISPlay:MCPower:MARKer:SHOW:STATe?`

**Arguments** OFF or 0 hides the readout for the selected marker in the graph.

ON or 1 shows the readout for the selected marker in the graph.

**Examples**     `DISPLAY:MCPOWER:MARKER:SHOW:STATE ON` shows the readout for the selected marker in the graph.

## DISPlay:MCPower:PLEVel:SHOW:STATE

Determines whether to show or hide the power levels in the MCPR view.

**Conditions**     Measurement views: MCPR

**Group**     Display commands

**Syntax**     `DISP\ay:MCPower:PLEVe\ :SHOW:STATE { OFF | ON | 0 | 1 }`  
`DISP\ay:MCPower:PLEVe\ :SHOW:STATE?`

**Arguments**     OFF or 0 hides the power levels in the graph.  
                       ON or 1 shows the power levels in the graph.

**Examples**     `DISPLAY:MCPOWER:PLEVEL:SHOW:STATE ON` shows the power levels in the graph.

## DISPlay:MCPower:RESet:SCALE (No Query Form)

Resets the horizontal and vertical scale to the default values described below in the MCPR view.

Vertical offset = Reference level,  
 Vertical scale = 100 dB,  
 Horizontal offset = Center frequency, and  
 Horizontal scale = Default span

**Conditions**     Measurement views: MCPR

**Group**     Display commands

**Syntax**     `DISP\ay:MCPower:RESet:SCALE`

**Arguments**     None



**Examples** DISPLAY:MCPOWER:RESET:SCALE resets the horizontal and vertical scale to the default values.

## DISPlay:MCPower:WINDow:TRACe:GRATICule:GRID:STATe

Determines whether to show or hide the graticule grid on the screen.

**Conditions** Measurement views: MCPR

**Group** Display commands

**Syntax** DISPlay:MCPower:WINDow:TRACe:GRATICule:GRID:STATe { OFF | ON | 0 | 1 }  
DISPlay:MCPower:WINDow:TRACe:GRATICule:GRID:STATe?

**Arguments** OFF or 0 hides the graticule grid.  
ON or 1 shows the graticule grid.

**Examples** DISPLAY:MCPOWER:WINDOW:TRACE:GRATICULE:GRID:STATE ON shows the graticule grid on the screen.

## DISPlay:MCPower:X[:SCALE]

Sets or queries the horizontal range of the MCPR graph.

**Conditions** Measurement views: MCPR

**Group** Display commands

**Syntax** DISPlay:MCPower:X[:SCALE] <value>  
DISPlay:MCPower:X[:SCALE]?

**Related Commands** [DISPlay:MCPower:X\[:SCALE\]:OFFSet](#)

**Arguments** <value> ::= <Nrf> specifies the horizontal range.  
Range: 10 Hz to 6.2 GHz (RSA6106A) / 14 GHz (RSA6114A).

**Examples**     `DISPLAY:MCPOWER:X:SCALE 10MHZ` sets the horizontal range to 10 MHz.

## DISPlay:MCPower:X[:SCALE]:AUTO (No Query Form)

Rescales the horizontal axis automatically to fit the waveform to the screen in the MCPR view.

**Conditions**     Measurement views: MCPR

**Group**     Display commands

**Syntax**     `DISPly:MCPower:X[:SCALE]:AUTO`

**Arguments**     None

**Examples**     `DISPLAY:MCPOWER:X:SCALE:AUTO` rescales the horizontal scale automatically to fit the waveform to the screen.

## DISPlay:MCPower:X[:SCALE]:OFFSet

Sets or queries the minimum horizontal value (left edge) of the MCPR graph.

**Conditions**     Measurement views: MCPR

**Group**     Display commands

**Syntax**     `DISPly:MCPower:X[:SCALE]:OFFSet <value>`  
`DISPly:MCPower:X[:SCALE]:OFFSet?`

**Related Commands**     [DISPlay:MCPower:X\[:SCALE\]](#)

**Arguments**     `<value>::=<Nrf>` specifies the minimum horizontal value.  
 Range: [(center frequency) - (X scale) × 0.9] to [(center frequency) + (X scale) × 0.9]

**Examples**     `DISPLAY:MCPOWER:X:SCALE:OFFSET 1.45GHZ` sets the minimum horizontal value to 1.45 GHz in the MCPR graph.

## DISPlay:MCPower:Y[:SCALE]

Sets or queries the vertical range of the MCPR graph.

**Conditions** Measurement views: MCPR

**Group** Display commands

**Syntax** DISPlay:MCPower:Y[:SCALE] <value>  
DISPlay:MCPower:Y[:SCALE]?

**Related Commands** [DISPlay:MCPower:Y\[:SCALE\]:OFFSet](#)

**Arguments** <value>::=<Nrf> specifies the vertical range. Range: 0.1 to 200 dB.

**Examples** DISPLAY:MCPOWER:Y:SCALE 100 sets the vertical range to 100 dB in the MCPR graph.

## DISPlay:MCPower:Y[:SCALE]:AUTO (No Query Form)

Rescales the vertical axis automatically to fit the waveform to the screen in the MCPR view.

**Conditions** Measurement views: MCPR

**Group** Display commands

**Syntax** DISPlay:MCPower:Y[:SCALE]:AUTO

**Arguments** None

**Examples** DISPLAY:MCPOWER:Y:SCALE:AUTO rescales the vertical scale automatically to fit the waveform to the screen.

## DISPlay:MCPower:Y[:SCALE]:OFFSet

Sets or queries the vertical offset (the value at the top edge of the vertical axis) in the MCPR graph.

**Conditions** Measurement views: MCPR

**Group** Display commands

**Syntax** DISPlay:MCPower:Y[:SCALE]:OFFSet <value>  
DISPlay:MCPower:Y[:SCALE]:OFFSet?

**Related Commands** [DISPlay:MCPower:Y\[:SCALE\]](#)

**Arguments** <value>::=<NRF> specifies the vertical offset. Range: -170 to +50 dBm.

**Examples** DISPLAY:MCPOWER:Y:SCALE:OFFSET -12.5 sets the vertical offset to -12.5 dBm in the MCPR graph.

## DISPlay:MERRor:Y[:SCALE]

Sets or queries the vertical range of the Magnitude error versus Time graph.

**Conditions** Measurement views: Magnitude error versus Time

**Group** Display commands

**Syntax** DISPlay:MERRor:Y[:SCALE] <value>  
DISPlay:MERRor:Y[:SCALE]?

**Related Commands** [DISPlay:MERRor:Y\[:SCALE\]:OFFSet](#)

**Arguments** <value>::=<NRF> specifies the vertical range. Range: 1 to 100%.

**Examples** DISPLAY:MERROR:Y:SCALE 50 sets the vertical range to 50% in the Magnitude error versus Time graph.

## DISPlay:MERRor:Y[:SCALe]:AUTO (No Query Form)

Sets the vertical scale automatically to fit the waveform to the screen in the Magnitude error versus Time view.

**Conditions** Measurement views: Magnitude error versus Time

**Group** Display commands

**Syntax** DISPlay:MERRor:Y[:SCALe]:AUTO

**Arguments** None

**Examples** DISPLAY:MERROR:Y:SCALE:AUTO sets the vertical scale automatically to fit the waveform to the screen.

## DISPlay:MERRor:Y[:SCALe]:OFFSet

Sets or queries the minimum vertical value (bottom edge) of the Magnitude error versus Time graph.

**Conditions** Measurement views: Magnitude error versus Time

**Group** Display commands

**Syntax** DISPlay:MERRor:Y[:SCALe]:OFFSet <value>  
DISPlay:MERRor:Y[:SCALe]:OFFSet?

**Related Commands** [DISPlay:MERRor:Y\[:SCALe\]](#)

**Arguments** <value>::=<NRF> specifies the minimum vertical value. Range: -100 to +100%.

**Examples** DISPLAY:MERROR:Y:SCALE:OFFSET -9.5 sets the minimum vertical value to -9.5% in the Magnitude error versus Time graph.

## DISPlay:OBWidth:MARKer:SHOW:STATE

Determines whether to show or hide the readout for the selected marker in the Occupied Bandwidth view.

<b>Conditions</b>	Measurement views: Occupied Bandwidth
<b>Group</b>	Display commands
<b>Syntax</b>	DISPlay:OBwidth:MARKer:SHOW:STATE { OFF   ON   0   1 } DISPlay:OBwidth:MARKer:SHOW:STATE?
<b>Arguments</b>	OFF or 0 hides the readout for the selected marker in the view. ON or 1 shows the readout for the selected marker in the view.
<b>Examples</b>	DISPLAY:OBWIDTH:MARKER:SHOW:STATE ON shows the readout for the selected marker in the view.

## DISPlay:OBWidth:RESet:SCALE (No Query Form)

Resets the horizontal and vertical scale to the default values described below in the Occupied Bandwidth view.

Vertical offset = Reference level,  
Vertical scale = 100 dB,  
Horizontal offset = Center frequency, and  
Horizontal scale = Default span

<b>Conditions</b>	Measurement views: Occupied Bandwidth
<b>Group</b>	Display commands
<b>Syntax</b>	DISPlay:OBwidth:RESet:SCALE
<b>Arguments</b>	None
<b>Examples</b>	DISPLAY:OBWIDTH:RESET:SCALE resets the horizontal and vertical scale to the default values.

## DISPlay:OBWidth:SElected:BANDwidth

Selects or queries the bandwidth (OBW or x dB BW) to measure in the Occupied Bandwidth view.

**Conditions** Measurement views: Occupied Bandwidth

**Group** Display commands

**Syntax** DISPlay:OBwidth:SElected:BANDwidth { OBwidth | XDBbandwidth }  
DISPlay:OBwidth:SElected:BANDwidth?

**Arguments** OBwidth selects the occupied bandwidth to measure.  
XDBbandwidth selects the x dB bandwidth to measure.

**Examples** DISPLAY:OBWIDTH:SELECTED:BANDWIDTH OBwidth selects the occupied bandwidth to measure.

## DISPlay:OBWidth:WINDow:TRACe:GRATICule:GRID:STATe

Determines whether to show or hide the graticule grid on the screen.

**Conditions** Measurement views: Occupied Bandwidth

**Group** Display commands

**Syntax** DISPlay:OBwidth:WINDow:TRACe:GRATICule:GRID:STATe { OFF | ON | 0 | 1 }  
DISPlay:OBwidth:WINDow:TRACe:GRATICule:GRID:STATe?

**Arguments** OFF or 0 hides the graticule grid.  
ON or 1 shows the graticule grid.

**Examples** DISPLAY:OBWIDTH:WINDOW:TRACE:GRATICULE:GRID:STATE ON shows the graticule grid on the screen.

## DISPlay:OBWidth:X[:SCALe]

Sets or queries the horizontal range of the Occupied Bandwidth view.

**Conditions** Measurement views: Occupied Bandwidth

**Group** Display commands

**Syntax** DISPlay:OBwidth:X[:SCALe] <value>  
DISPlay:OBwidth:X[:SCALe]?

**Related Commands** [DISPlay:OBWidth:X\[:SCALe\]:OFFSet](#)

**Arguments** <value>::=<NRF> specifies the horizontal range.  
Range: 10 Hz to 6.2 GHz (RSA6106A) / 14 GHz (RSA6114A).

**Examples** DISPLAY:OBWIDTH:X:SCALE 10MHZ sets the horizontal range to 10 MHz.

## DISPlay:OBWidth:X[:SCALe]:AUTO (No Query Form)

Rescales the horizontal axis automatically to fit the waveform to the screen in the Occupied Bandwidth view.

**Conditions** Measurement views: Occupied Bandwidth

**Group** Display commands

**Syntax** DISPlay:OBwidth:X[:SCALe]:AUTO

**Arguments** None

**Examples** DISPLAY:OBWIDTH:X:SCALE:AUTO rescales the horizontal scale automatically to fit the waveform to the screen.



## DISPlay:OBWidth:X[:SCALE]:OFFSet

Sets or queries the minimum horizontal value (left edge) of the Occupied Bandwidth view.

**Conditions** Measurement views: Occupied Bandwidth

**Group** Display commands

**Syntax** DISPlay:OBWidth:X[:SCALE]:OFFSet <value>  
DISPlay:OBWidth:X[:SCALE]:OFFSet?

**Related Commands** [DISPlay:OBWidth:X\[:SCALE\]](#)

**Arguments** <value> ::= <NRF> specifies the minimum horizontal value.  
Range: [(center frequency) - (X scale) × 0.9] to [(center frequency) + (X scale) × 0.9]

**Examples** DISPLAY:OBWIDTH:X:SCALE:OFFSET 1.45GHZ sets the minimum horizontal value to 1.45 GHz in the Occupied Bandwidth view.

## DISPlay:OBWidth:Y[:SCALE]

Sets or queries the vertical range of the Occupied Bandwidth view.

**Conditions** Measurement views: Occupied Bandwidth

**Group** Display commands

**Syntax** DISPlay:OBWidth:Y[:SCALE] <value>  
DISPlay:OBWidth:Y[:SCALE]?

**Related Commands** [DISPlay:OBWidth:Y\[:SCALE\]:OFFSet](#)

**Arguments** <value> ::= <NRF> specifies the vertical range. Range: 0.1 to 200 dB.

**Examples** DISPLAY:OBWIDTH:Y:SCALE 100 sets the vertical range to 100 dB in the Occupied Bandwidth view.

## DISPlay:OBWidth:Y[:SCALE]:AUTO (No Query Form)

Rescales the vertical axis automatically to fit the waveform to the screen in the Occupied Bandwidth view.

**Conditions** Measurement views: Occupied Bandwidth

**Group** Display commands

**Syntax** DISPlay:OBWidth:Y[:SCALE]:AUTO

**Arguments** None

**Examples** DISPLAY:OBWIDTH:Y:SCALE:AUTO rescales the vertical scale automatically to fit the waveform to the screen.

## DISPlay:OBWidth:Y[:SCALE]:OFFSet

Sets or queries the vertical offset (the value at the top edge of the vertical axis) in the Occupied Bandwidth view.

**Conditions** Measurement views: Occupied Bandwidth

**Group** Display commands

**Syntax** DISPlay:OBWidth:Y[:SCALE]:OFFSet <value>  
DISPlay:OBWidth:Y[:SCALE]:OFFSet?

**Related Commands** [DISPlay:OBWidth:Y\[:SCALE\]](#)

**Arguments** <value>::=<NRF> specifies the vertical offset. Range: -170 to +50 dBm.

**Examples** DISPLAY:OBWIDTH:Y:SCALE:OFFSET -12.5 sets the vertical offset to -12.5 dBm in the Occupied Bandwidth view.

## DISPlay:PERRor:Y[:SCALE]

Sets or queries the vertical range of the Phase error versus Time graph.

**Conditions** Measurement views: Phase error versus Time

**Group** Display commands

**Syntax** DISPlay:PERRor:Y[:SCALE] <value>  
DISPlay:PERRor:Y[:SCALE]?

**Related Commands** [DISPlay:PERRor:Y\[:SCALE\]:OFFSet](#)

**Arguments** <value>::=<Nrf> specifies the vertical range. Range: 1 to 360°.

**Examples** DISPLAY:PERROR:Y:SCALE 30 sets the vertical range to 30 ° in the Phase error versus Time graph.

## DISPlay:PERRor:Y[:SCALE]:AUTO (No Query Form)

Sets the vertical scale automatically to fit the waveform to the screen in the Phase error versus Time view.

**Conditions** Measurement views: Phase error versus Time

**Group** Display commands

**Syntax** DISPlay:PERRor:Y[:SCALE]:AUTO

**Arguments** None

**Examples** DISPLAY:PERROR:Y:SCALE:AUTO sets the vertical scale automatically to fit the waveform to the screen.

## DISPlay:PERRor:Y[:SCALe]:OFFSet

Sets or queries the minimum vertical value (bottom edge) of the Phase error versus Time graph.

<b>Conditions</b>	Measurement views: Phase error versus Time
<b>Group</b>	Display commands
<b>Syntax</b>	DISPlay:PERRor:Y[:SCALe]:OFFSet <value> DISPlay:PERRor:Y[:SCALe]:OFFSet?
<b>Related Commands</b>	<a href="#">DISPlay:PERRor:Y[:SCALe]</a>
<b>Arguments</b>	<value>::=<NRF> specifies the minimum vertical value. Range: -360 to +360°.
<b>Examples</b>	DISPlay:PERRor:Y:SCALe:OFFSet -14.5 sets the minimum vertical value to -14.5 ° in the Phase Error versus Time graph.

## DISPlay:PHVTime:WINDow:TRACe:GRATICule:GRID:STATe

Determines whether to show or hide the graticule grid on the screen.

<b>Conditions</b>	Measurement views: Phase versus Time
<b>Group</b>	Display commands
<b>Syntax</b>	DISPlay:PHVTime:WINDow:TRACe:GRATICule:GRID:STATe { OFF   ON   0   1 } DISPlay:PHVTime:WINDow:TRACe:GRATICule:GRID:STATe?
<b>Arguments</b>	OFF or 0 hides the graticule grid. ON or 1 shows the graticule grid.
<b>Examples</b>	DISPlay:PHVTime:WINDow:TRACe:GRATICule:GRID:STATe ON shows the graticule grid on the Frequency versus Time view.

## DISPlay:PHVTime:X[:SCALE]

Sets or queries the horizontal scale (full-scale time) of the Phase versus Time graph. Programming a specified scale sets DISPlay:PHVTime:X[:SCALE] AUTO:STATe OFF.

**Conditions** Measurement views: Phase versus Time

**Group** Display commands

**Syntax** DISPlay:PHVTime:X[:SCALE] <value>  
DISPlay:PHVTime:X[:SCALE]?

**Related Commands** [DISPlay:PHVTime:X\[:SCALE\]:AUTO:STATe](#), [DISPlay:PHVTime:X\[:SCALE\]:OFFSet](#)

**Arguments** <value>::={ <Nrf> | MAXimum | MINimum } specifies the horizontal scale in full-scale time. MAXimum and MINimum represent the upper and lower limits of the setting range, respectively.

Use the [DISPlay:PHVTime:X\[:SCALE\]:MAXimum?](#) and [DISPlay:PHVTime:X\[:SCALE\]:OFFSet:MINimum?](#) queries to get the upper and lower limit values of the setting range.

**Examples** DISPLAY:PHVTIME:X:SCALE 1.5ms sets the horizontal scale to 1.5 ms.

## DISPlay:PHVTime:X[:SCALE]:AUTO (No Query Form)

Sets the horizontal scale automatically to fit the waveform to the screen in the Phase versus Time view. Executing this command sets DISPlay:PHVTime:X[:SCALE]:AUTO:STATe ON.

**Conditions** Measurement views: Phase versus Time

**Group** Display commands

**Syntax** DISPlay:PHVTime:X[:SCALE]:AUTO

**Related Commands** [DISPlay:PHVTime:X\[:SCALE\]:AUTO:STATe](#)

**Arguments** None

**Examples** `DISPLAY:PHVTIME:X:SCALE:AUTO` sets the horizontal scale automatically to fit the waveform to the screen.

## DISPlay:PHVTime:X[:SCALE]:AUTO:STATE

Determines whether to set the horizontal scale automatically or manually.

**Conditions** Measurement views: Phase versus Time

**Group** Display commands

**Syntax** `DISPlay:PHVTime:X[:SCALE]:AUTO:STATE { OFF | ON | 0 | 1 }`  
`DISPlay:PHVTime:X[:SCALE]:AUTO:STATE?`

**Arguments** OFF or 0 specifies that the horizontal scale is set manually. To set it, use the [DISPlay:PHVTime:X\[:SCALE\]](#) and [DISPlay:PHVTime:X\[:SCALE\]:OFFSet](#) commands.

ON or 1 specifies that the horizontal scale is set automatically.

**Examples** `DISPLAY:PHVTIME:X:SCALE:AUTO:STATE ON` specifies that the horizontal scale is set automatically.

## DISPlay:PHVTime:X[:SCALE]:MAXimum? (Query Only)

Queries the upper limit of the horizontal scale setting range.

**Conditions** Measurement views: Phase versus Time

**Group** Display commands

**Syntax** `DISPlay:PHVTime:X[:SCALE]:MAXimum?`

**Related Commands** [DISPlay:PHVTime:X\[:SCALE\]](#)

<b>Arguments</b>	None
<b>Returns</b>	<NRf> The upper limit of the horizontal scale setting range.
<b>Examples</b>	DISPLAY:PHVTIME:X:SCALE:MAXIMUM? might return 18.135E-3, indicating that the upper limit of the horizontal scale setting range is 18.135 ms.

## DISPlay:PHVTime:X[:SCALe]:MINimum? (Query Only)

Queries the lower limit of the horizontal scale setting range.

<b>Conditions</b>	Measurement views: Phase versus Time
<b>Group</b>	Display commands
<b>Syntax</b>	DISPlay:PHVTime:X[:SCALe]:MINimum?

**Related Commands** [DISPlay:PHVTime:X\[:SCALe\]](#)

<b>Arguments</b>	None
<b>Returns</b>	<NRf> The lower limit of the horizontal scale setting range.
<b>Examples</b>	DISPLAY:PHVTIME:X:SCALE:MINIMUM? might return 10.0E-9, indicating that the lower limit of the horizontal scale setting range is 10.0 ns.

## DISPlay:PHVTime:X[:SCALe]:OFFSet

Sets or queries the minimum horizontal value (left edge) of the Phase versus Time graph. Programming a specified offset sets DISPlay:PHVTime:X[:SCALe]:AUTO:STATe OFF.

<b>Conditions</b>	Measurement views: Phase versus Time
<b>Group</b>	Display commands

**Syntax**      `DISPlay:PHVTime:X[:SCALE]:OFFSet`  
`DISPlay:PHVTime:X[:SCALE]:OFFSet?`

**Related Commands**    [DISPlay:PHVTime:X\[:SCALE\]:AUTO:STATe](#), [DISPlay:PHVTime:X\[:SCALE\]](#),

**Arguments**      `<value>::={ <NRF> | MAXimum | MINimum }` specifies the horizontal offset. `MAXimum` and `MINimum` represent the upper and lower limits of the setting range, respectively.

Use the [DISPlay:PHVTime:X\[:SCALE\]:OFFSet:MAXimum?](#) and [DISPlay:PHVTime:X\[:SCALE\]:OFFSet:MINimum?](#) queries to get the upper and lower limit values of the setting range.

**Examples**      `DISPlay:PHVTime:X:SCALE:OFFSet 800ns` sets the minimum horizontal value to 800 ns in the Phase versus Time graph.

## DISPlay:PHVTime:X[:SCALE]:OFFSet:MAXimum? (Query Only)

Queries the upper limit of the horizontal offset setting range.

**Conditions**      Measurement views: Phase versus Time

**Group**            Display commands

**Syntax**          `DISPlay:PHVTime:X[:SCALE]:OFFSet:MAXimum?`

**Related Commands**    [DISPlay:PHVTime:X\[:SCALE\]:OFFSet](#)

**Arguments**      None

**Returns**        `<NRF>` The upper limit of the horizontal offset setting range.

**Examples**      `DISPlay:PHVTime:X:SCALE:OFFSet:MAXimum?` might return `-1.812E-3`, indicating that the upper limit of the horizontal offset setting range is -1.812 ms.

## DISPlay:PHVTime:X[:SCALE]:OFFSet:MINimum? (Query Only)

Queries the lower limit of the horizontal offset setting range.



---

<b>Conditions</b>	Measurement views: Phase versus Time
<b>Group</b>	Display commands
<b>Syntax</b>	DISPlay:PHVTime:X[:SCALE]:OFFSet:MINimum?
<b>Related Commands</b>	<a href="#">DISPlay:PHVTime:X[:SCALE]:OFFSet</a>
<b>Arguments</b>	None
<b>Returns</b>	<NRf> The lower limit of the horizontal offset setting range.
<b>Examples</b>	DISPLAY:PHVTIME:X:SCALE:OFFSET:MINIMUM? might return -16.28E-3, indicating that the lower limit of the horizontal offset setting range is -16.28 ms.

## DISPlay:PHVTime:Y[:SCALE]

Sets or queries the vertical range of the Phase versus Time graph.

<b>Conditions</b>	Measurement views: Phase versus Time
<b>Group</b>	Display commands
<b>Syntax</b>	DISPlay:PHVTime:Y[:SCALE] <value> DISPlay:PHVTime:Y[:SCALE]?
<b>Related Commands</b>	<a href="#">DISPlay:PHVTime:Y[:SCALE]:OFFSet</a>
<b>Arguments</b>	<value>::=<NRf> specifies the vertical range. Range: 1 to 1T°.
<b>Examples</b>	DISPLAY:PHVTIME:Y:SCALE 180 sets the vertical range to 180° in the Phase versus Time graph.

## DISPlay:PHVTime:Y[:SCALe]:AUTO (No Query Form)

Sets the vertical scale automatically to fit the waveform to the screen in the Phase versus Time view.

**Conditions** Measurement views: Phase versus Time

**Group** Display commands

**Syntax** DISPlay:PHVTime:Y[:SCALe]:AUTO

**Arguments** None

**Examples** DISPLAY:PHVTIME:Y:SCALE:AUTO sets the vertical scale automatically to fit the waveform to the screen.

## DISPlay:PHVTime:Y[:SCALe]:AXIS

Selects or queries the vertical axis representation.

**Conditions** Measurement views: Phase versus Time

**Group** Display commands

**Syntax** DISPlay:PHVTime:Y[:SCALe]:AXIS { MODuTopi | CONTinuous }  
DISPlay:PHVTime:Y[:SCALe]:AXIS?

**Arguments** MODuTopi (modulo  $\pi$ ) shows the phase constrained within  $\pm 180^\circ$  along the vertical axis.

CONTinuous shows the phase as continuous quantity along the vertical axis.

**Examples** DISPLAY:PHVTIME:Y:SCALE:AXIS MODuTopi selects modulo  $\pi$  representation for the vertical axis.

## DISPlay:PHVTime:Y[:SCALE]:AXIS:REFerence

Selects or queries which time point in the analysis period to use as the zero-phase-value reference.

**Conditions** Measurement views: Phase versus Time

**Group** Display commands

**Syntax** DISPlay:PHVTime:Y[:SCALE]:AXIS:REFerence <value>  
DISPlay:PHVTime:Y[:SCALE]:AXIS:REFerence?

**Arguments** <value>::=<NRF> specifies the phase reference time.

**Examples** DISPLAY:PHVTIME:Y:SCALE:AXIS:REFERENCE 1.5us sets the phase reference time to 1.5  $\mu$ s.

## DISPlay:PHVTime:Y[:SCALE]:OFFSet

Sets or queries the vertical offset (the value at the center of the vertical axis) in the Phase versus Time graph.

**Conditions** Measurement views: Phase versus Time

**Group** Display commands

**Syntax** DISPlay:PHVTime:Y[:SCALE]:OFFSet <value>  
DISPlay:PHVTime:Y[:SCALE]:OFFSet?

**Related Commands** [DISPlay:PHVTime:Y\[:SCALE\]](#)

**Arguments** <value>::=<NRF> specifies the vertical offset. Range:  $-0.5T$  to  $+0.5T^\circ$ .

**Examples** DISPLAY:PHVTIME:Y:SCALE:OFFSET -158.5 sets the vertical offset to  $-158.5^\circ$  in the Phase versus Time graph.

## DISPlay:PHVTime:Y[:SCALE]:RESCale (No Query Form)

Rescales the vertical axis automatically to fit the Phase versus Time waveform to the screen.

**Conditions** Measurement views: Phase versus Time

**Group** Display commands

**Syntax** DISPlay:PHVTime:Y[:SCALE]:RESCale

**Arguments** None

**Examples** DISPLAY:PHVTIME:Y:SCALE:RESCALE rescales the vertical axis automatically to fit the Phase versus Time waveform to the screen.

## DISPlay:PNOise:LEGend:STATE

Determines whether to show or hide the trace legend on the display. The legend indicates the trace detection and function on the screen for each displayed trace.

**Conditions** Measurement views: Phase versus Time

**Group** Display commands

**Syntax** DISPlay:PNOise:LEGend:STATE { OFF | ON | 0 | 1 }  
DISPlay:PNOise:LEGend:STATE?

**Arguments** OFF or 0 hides the trace legend.

ON or 1 shows the trace legend.

**Examples** DISPLAY:PNOISE:LEGEND:STATE ON shows the trace legend on the screen.

## DISPlay:PNOise:MARKer:SHOW:STATE

Determines whether to show or hide the readout for the selected marker in the phase noise view.

<b>Conditions</b>	Measurement views: Phase noise
<b>Group</b>	Display commands
<b>Syntax</b>	DISPlay:PNOise:MARKer:SHOW:STATE { OFF   ON   0   1 } DISPlay:PNOise:MARKer:SHOW:STATE?
<b>Arguments</b>	OFF or 0 hides the readout for the selected marker in the graph. ON or 1 shows the readout for the selected marker in the graph.
<b>Examples</b>	DISPLAY:PNOISE:MARKER:SHOW:STATE ON shows the readout for the selected marker in the graph.

## DISPlay:PNOise:RESet:SCALE (No Query Form)

Resets the horizontal and vertical scale to the default values described below in the phase noise view.

Vertical offset = -50 dBc/Hz,  
Vertical scale = 100 dB,  
Horizontal start = 10 Hz, and  
Horizontal stop = 1 GHz

<b>Conditions</b>	Measurement views: Phase noise
<b>Group</b>	Display commands
<b>Syntax</b>	DISPlay:PNOise:RESet:SCALE
<b>Arguments</b>	None
<b>Examples</b>	DISPLAY:PNOISE:RESET:SCALE resets the horizontal and vertical scale to the default values.

## DISPlay:PNOise:WINDow:TRACe:GRATICule:GRID:STATE

Determines whether to show or hide the graticule grid on the screen.

<b>Conditions</b>	Measurement views: Phase noise
<b>Group</b>	Display commands
<b>Syntax</b>	<pre>DISPlay:PNOise:WINDow:TRACe:GRATicule:GRID:STATE { OFF   ON   0   1 } DISPlay:PNOise:WINDow:TRACe:GRATicule:GRID:STATE?</pre>
<b>Arguments</b>	<p>OFF or 0 hides the graticule grid.</p> <p>ON or 1 shows the graticule grid.</p>
<b>Examples</b>	<pre>DISPlay:PNOISE:WINDOW:TRACE:GRATICULE:GRID:STATE ON</pre> <p>shows the graticule grid on the screen.</p>

## DISPlay:PNOise:X[:SCALE]:AUTO (No Query Form)

Rescales the horizontal axis automatically to fit the waveform to the screen in the phase noise view.

<b>Conditions</b>	Measurement views: Phase noise
<b>Group</b>	Display commands
<b>Syntax</b>	<pre>DISPlay:PNOise:X[:SCALE]:AUTO</pre>
<b>Arguments</b>	None
<b>Examples</b>	<pre>DISPlay:PNOISE:X:SCALE:AUTO</pre> <p>rescales the horizontal scale automatically to fit the waveform to the screen.</p>

## DISPlay:PNOise:X[:SCALE]:START

Sets or queries the start frequency (left edge) of the phase noise graph.

<b>Conditions</b>	Measurement views: Phase noise
-------------------	--------------------------------

<b>Group</b>	Display commands
<b>Syntax</b>	DISPlay:PNOise:X[:SCALE]:START <value> DISPlay:PNOise:X[:SCALE]:START?
<b>Arguments</b>	<value> ::= <Nrf> specifies the start frequency. Range: 10 mHz to 100 MHz.  Note that (start frequency) = $10^4 \times$ (stop frequency).
<b>Examples</b>	DISPLAY:PNOISE:X:SCALE:START 10HZ sets the start frequency to 10 Hz in the phase noise graph.

## DISPlay:PNOise:X[:SCALE]:STOP

Sets or queries the stop frequency (right edge) of the phase noise graph.

<b>Conditions</b>	Measurement views: Phase noise
<b>Group</b>	Display commands
<b>Syntax</b>	DISPlay:PNOise:X[:SCALE]:STOP <value> DISPlay:PNOise:X[:SCALE]:STOP?
<b>Arguments</b>	<value> ::= <Nrf> specifies the stop frequency. Range: 100 Hz to 1 THz.  Note that (start frequency) = $10^4 \times$ (stop frequency).
<b>Examples</b>	DISPLAY:PNOISE:X:SCALE:STOP 2GHZ sets the stop frequency to 2 GHz in the phase noise graph.

## DISPlay:PNOise:Y[:SCALE]

Sets or queries the vertical range of the phase noise graph.

<b>Conditions</b>	Measurement views: Phase noise
<b>Group</b>	Display commands

**Syntax**     `DISPlay:PNOise:Y[:SCALE] <value>`  
`DISPlay:PNOise:Y[:SCALE]?`

**Arguments**     `<value>::=<NRF>` specifies the vertical range. Range: 0.1 to 200 dB.

**Examples**     `DISPLAY:PNOISE:Y:SCALE 100` sets the vertical range to 100 dB for the phase noise graph.

## DISPlay:PNOise:Y[:SCALE]:AUTO (No Query Form)

Rescales the vertical axis automatically to fit the waveform to the screen in the phase noise view.

**Conditions**     Measurement views: Phase noise

**Group**     Display commands

**Syntax**     `DISPlay:PNOise:Y[:SCALE]:AUTO`

**Arguments**     None

**Examples**     `DISPLAY:PNOISE:Y:SCALE:AUTO` rescales the vertical scale automatically to fit the waveform to the screen.

## DISPlay:PNOise:Y[:SCALE]:OFFSet

Sets or queries the vertical offset (the value at the top edge of the vertical axis) of the phase noise graph.

**Conditions**     Measurement views: Phase noise

**Group**     Display commands

**Syntax**     `DISPlay:PNOise:Y[:SCALE]:OFFSet <value>`  
`DISPlay:PNOise:Y[:SCALE]:OFFSet?`

**Arguments**     `<value>::=<NRF>` specifies the vertical offset. Range: -200 to +20 dBc/Hz.



**Examples** `DISPLAY:PNOISE:Y:SCALE:OFFSET -12.5` sets the vertical offset to -12.5 dBc/Hz for the phase noise graph.

## DISPlay:PNOise:Y[:SCALe]:PDIVision

Sets or queries the vertical scale (per division) of the phase noise graph.

**Conditions** Measurement views: Phase noise

**Group** Display commands

**Syntax** `DISPlay:PNOise:Y[:SCALe]:PDIVision <value>`  
`DISPlay:PNOise:Y[:SCALe]:PDIVision?`

**Arguments** `<value>::=<NRf>` specifies the vertical scale (per division).  
 Range: 0.01 to 20 dB/div.

**Examples** `DISPLAY:PNOISE:Y:SCALE:PDIVISION 5` sets the vertical scale to 5 dB/div.

## DISPlay:PULSe:MEASview:DELeTe (No Query Form)

Deletes the measurement view in the pulsed RF measurements.

**Conditions** Measurement views: Pulsed RF measurements

**Group** Display commands

**Syntax** `DISPlay:PULSe:MEASview:DELeTe { RESULT | TRACe | STATistics }`

**Arguments** `RESULT` deletes the pulse table view.

`TRACe` deletes the pulse trace view.

`STATistics` deletes the pulse statistics view.

If you attempt to delete a view that is not displayed on screen, the error (-200, "Execution error; Measurement not running") will be returned.

**Examples**    `DISPLAY:PULSE:MEASVIEW:DELETE TRACE` deletes the pulse trace view.

## DISPlay:PULSe:MEASview:NEW (No Query Form)

Displays a new measurement view in the pulsed RF measurements.

**Conditions**    Measurement views: Pulsed RF measurements

**Group**        Display commands

**Syntax**       `DISPlay:PULSe:MEASview:NEW { RESuLt | TRACe | STATistics }`

**Arguments**    `RESuLt` opens the pulse table view.

`TRACe` opens the pulse trace view.

`STATistics` opens the pulse statistics view.

If you attempt to open a view that is currently displayed on screen, the error (-200, "Execution error; Measurement is already running") will be returned.

**Examples**    `DISPLAY:PULSE:MEASVIEW:NEW STATistics` creates the pulse statistics view.

## DISPlay:PULSe:MEASview:SElect

Selects a measurement view in the pulsed RF measurements on the screen. The query command returns the currently selected view.

**Conditions**    Measurement views: Pulsed RF measurements

**Group**        Display commands

**Syntax**       `DISPlay:PULSe:MEASview:SElect { RESuLt | TRACe | STATistics }`  
`DISPlay:PULSe:MEASview:SElect?`

**Arguments**    `RESuLt` selects the pulse table view.

`TRACe` selects the pulse trace view.

`STATistics` selects the pulse statistics view.

If you attempt to select a view that is not displayed on screen, the error (-200, "Execution error; Measurement not running") will be returned.

**Examples**     `DISPLAY:PULSE:MEASVIEW:SELECT TRACE` selects the pulse trace view.

## DISPlay:PULSe:RESult:ATX

Determines whether or not to show the average transmitted power measurement result in the pulse table.

**Conditions**     Measurement views: Pulse table

**Group**     Display commands

**Syntax**     `DISPlay:PULSe:RESult:ATX { OFF | ON | 0 | 1 }`  
`DISPlay:PULSe:RESult:ATX?`

**Arguments**     OFF or 0 does not show the average transmitted power measurement result.  
ON or 1 shows the average transmitted power measurement result in the pulse table.

**Examples**     `DISPLAY:PULSE:RESULT:ATX ON` shows the average transmitted power measurement result in the pulse table.

## DISPlay:PULSe:RESult:AVERAge

Determines whether or not to show the average on power measurement result in the pulse table.

**Conditions**     Measurement views: Pulse table

**Group**     Display commands

**Syntax**     `DISPlay:PULSe:RESult:AVERAge { OFF | ON | 0 | 1 }`  
`DISPlay:PULSe:RESult:AVERAge?`

**Arguments**     OFF or 0 does not show the average on power measurement result.  
ON or 1 shows the average on power measurement result in the results table.

**Examples**     `DISPLAY:PULSE:RESULT:AVERAGE ON` shows the average on power measurement result in the pulse table.

## DISPlay:PULSe:RESuLt:DROOp

Determines whether or not to show the droop measurement result in the pulse table.

**Conditions**     Measurement views: Pulse table

**Group**     Display commands

**Syntax**     `DISPly:PULSe:RESuLt:DROOp { OFF | ON | 0 | 1 }`  
`DISPly:PULSe:RESuLt:DROOp?`

**Arguments**     OFF or 0 does not show the droop measurement result.  
ON or 1 shows the droop measurement result in the pulse table.

**Examples**     `DISPLAY:PULSE:RESULT:DROOP ON` shows the droop measurement result in the pulse table.

## DISPly:PULSe:RESuLt:DUTPct

Determines whether or not to show the duty factor (%) measurement result in the pulse table.

**Conditions**     Measurement views: Pulse table

**Group**     Display commands

**Syntax**     `DISPly:PULSe:RESuLt:DUTPct { OFF | ON | 0 | 1 }`  
`DISPly:PULSe:RESuLt:DUTPct?`

**Arguments**     OFF or 0 does not show the duty factor measurement result.  
ON or 1 shows the duty factor measurement result in the pulse table.

**Examples** `DISPLAY:PULSE:RESULT:DUTPCT ON` shows the duty factor (%) measurement result in the pulse table.

## DISPlay:PULSe:RESUlt:DUTRatio

Determines whether or not to show the duty factor (ratio) measurement result in the pulse table.

**Conditions** Measurement views: Pulse table

**Group** Display commands

**Syntax** `DISPlay:PULSe:RESUlt:DUTRatio { OFF | ON | 0 | 1 }`  
`DISPlay:PULSe:RESUlt:DUTRatio?`

**Arguments** OFF or 0 does not show the duty factor measurement result.  
ON or 1 shows the duty factor measurement result in the pulse table.

**Examples** `DISPLAY:PULSE:RESULT:DUTRATIO ON` shows the duty factor (ratio) measurement result in the pulse table.

## DISPlay:PULSe:RESUlt:FALL

Determines whether or not to show the fall time measurement result in the pulse table.

**Conditions** Measurement views: Pulse table

**Group** Display commands

**Syntax** `DISPlay:PULSe:RESUlt:FALL { OFF | ON | 0 | 1 }`  
`DISPlay:PULSe:RESUlt:FALL?`

**Arguments** OFF or 0 does not show the fall time measurement result.  
ON or 1 shows the fall time measurement result in the pulse table.

**Examples**     `DISPLAY:PULSE:RESULT:FALL ON` shows the fall time measurement result in the pulse table.

## DISPlay:PULSe:RESuLt:FRDeviatiOn

Determines whether or not to show the frequency deviation measurement result in the pulse table.

**Conditions**     Measurement views: Pulse table

**Group**     Display commands

**Syntax**     `DISPlay:PULSe:RESuLt:FRDeviatiOn { OFF | ON | 0 | 1 }`  
`DISPlay:PULSe:RESuLt:FRDeviatiOn?`

**Arguments**     OFF or 0 does not show the frequency deviation measurement result.  
ON or 1 shows the frequency deviation measurement result in the pulse table.

**Examples**     `DISPLAY:PULSE:RESULT:FRDEVIATION ON` shows the frequency deviation measurement result in the pulse table.

## DISPlay:PULSe:RESuLt:MFReqerror

Determines whether or not to show the maximum frequency error measurement result in the pulse table.

**Conditions**     Measurement views: Pulse table

**Group**     Display commands

**Syntax**     `DISPlay:PULSe:RESuLt:MFReqerror { OFF | ON | 0 | 1 }`  
`DISPlay:PULSe:RESuLt:MFReqerror?`

**Arguments**     OFF or 0 does not show the maximum frequency error measurement result.  
ON or 1 shows the maximum frequency error measurement result in the pulse table.

**Examples** `DISPLAY:PULSE:RESULT:MFREQERROR ON` shows the maximum frequency error measurement result in the pulse table.

## DISPlay:PULSe:RESuLt:MPHerror

Determines whether or not to show the maximum phase error measurement result in the pulse table.

**Conditions** Measurement views: Pulse table

**Group** Display commands

**Syntax** `DISPlay:PULSe:RESuLt:MPHerror { OFF | ON | 0 | 1 }`  
`DISPlay:PULSe:RESuLt:MPHerror?`

**Arguments** OFF or 0 does not show the maximum phase error measurement result.  
ON or 1 shows the maximum phase error measurement result in the pulse table.

**Examples** `DISPLAY:PULSE:RESULT:MPHERROR ON` shows the maximum phase error measurement result in the pulse table.

## DISPlay:PULSe:RESuLt:PHDeviation

Determines whether or not to show the phase deviation measurement result in the pulse table.

**Conditions** Measurement views: Pulse table

**Group** Display commands

**Syntax** `DISPlay:PULSe:RESuLt:PHDeviation { OFF | ON | 0 | 1 }`  
`DISPlay:PULSe:RESuLt:PHDeviation?`

**Arguments** OFF or 0 does not show the phase deviation measurement result.  
ON or 1 shows the phase deviation measurement result in the pulse table.

**Examples**     `DISPLAY:PULSE:RESULT:PHDEVIATION ON` shows the phase deviation measurement result in the pulse table.

## DISPlay:PULSe:RESuLt:PPFRequency

Determines whether or not to show the pulse-pulse carrier frequency measurement result in the pulse table.

**Conditions**     Measurement views: Pulse table

**Group**     Display commands

**Syntax**     `DISPlay:PULSe:RESuLt:PPFRequency { OFF | ON | 0 | 1 }`  
`DISPlay:PULSe:RESuLt:PPFRequency?`

**Arguments**     OFF or 0 does not show the pulse-pulse carrier frequency measurement result.  
 ON or 1 shows the pulse-pulse carrier frequency measurement result in the pulse table.

**Examples**     `DISPLAY:PULSE:RESULT:PPFREQUENCY ON` shows the pulse-pulse carrier frequency measurement result in the pulse table.

## DISPlay:PULSe:RESuLt:PPOWER

Determines whether or not to show the peak power measurement result in the pulse table.

**Conditions**     Measurement views: Pulse table

**Group**     Display commands

**Syntax**     `DISPlay:PULSe:RESuLt:PPOWER { OFF | ON | 0 | 1 }`  
`DISPlay:PULSe:RESuLt:PPOWER?`

**Arguments**     OFF or 0 does not show the peak power measurement result.  
 ON or 1 shows the peak power measurement result in the pulse table.



**Examples** `DISPLAY:PULSE:RESULT:PPOWER ON` shows the peak power measurement result in the pulse table.

## DISPlay:PULSe:RESuLt:PPHase

Determines whether or not to show the pulse-pulse carrier phase measurement result in the pulse table.

**Conditions** Measurement views: Pulse table

**Group** Display commands

**Syntax** `DISPlay:PULSe:RESuLt:PPHase { OFF | ON | 0 | 1 }`  
`DISPlay:PULSe:RESuLt:PPHase?`

**Arguments** OFF or 0 does not show the pulse-pulse carrier phase measurement result.  
ON or 1 shows the pulse-pulse carrier phase measurement result in the pulse table.

**Examples** `DISPLAY:PULSE:RESULT:PPHASE ON` shows the pulse-pulse carrier phase measurement result in the pulse table.

## DISPlay:PULSe:RESuLt:RINTerval

Determines whether or not to show the repetition interval measurement result in the pulse table.

**Conditions** Measurement views: Pulse table

**Group** Display commands

**Syntax** `DISPlay:PULSe:RESuLt:RINTerval { OFF | ON | 0 | 1 }`  
`DISPlay:PULSe:RESuLt:RINTerval?`

**Arguments** OFF or 0 does not show the repetition interval measurement result.  
ON or 1 shows the repetition interval measurement result in the results table.

**Examples**     `DISPLAY:PULSE:RESULT:RINTERVAL ON` shows the repetition interval measurement result in the pulse table.

## DISPlay:PULSe:RESuLt:RIPPlE

Determines whether or not to show the ripple measurement result in the pulse table.

**Conditions**     Measurement views: Pulse table

**Group**     Display commands

**Syntax**     `DISPlay:PULSe:RESuLt:RIPPlE { OFF | ON | 0 | 1 }`  
`DISPlay:PULSe:RESuLt:RIPPlE?`

**Arguments**     OFF or 0 does not show the ripple measurement result.  
ON or 1 shows the ripple measurement result in the pulse table.

**Examples**     `DISPLAY:PULSE:RESULT:RIPPLE ON` shows the ripple measurement result in the pulse table.

## DISPlay:PULSe:RESuLt:RISE

Determines whether or not to show the rise time measurement result in the pulse table.

**Conditions**     Measurement views: Pulse table

**Group**     Display commands

**Syntax**     `DISPlay:PULSe:RESuLt:RISE { OFF | ON | 0 | 1 }`  
`DISPlay:PULSe:RESuLt:RISE?`

**Arguments**     OFF or 0 does not show the rise time measurement result.  
ON or 1 shows the rise time measurement result in the pulse table.

**Examples** `DISPLAY:PULSE:RESULT:RISE ON` shows the rise time measurement result in the pulse table.

## DISPlay:PULSe:RESuLt:RMSFreqerror

Determines whether or not to show the RMS frequency error measurement result in the pulse table.

**Conditions** Measurement views: Pulse table

**Group** Display commands

**Syntax** `DISPlay:PULSe:RESuLt:RMSFreqerror { OFF | ON | 0 | 1 }`  
`DISPlay:PULSe:RESuLt:RMSFreqerror?`

**Arguments** OFF or 0 does not show the RMS frequency error measurement result.  
ON or 1 shows the RMS frequency error measurement result in the pulse table.

**Examples** `DISPLAY:PULSE:RESULT:RMSFREQERROR ON` shows the RMS frequency error measurement result in the pulse table.

## DISPlay:PULSe:RESuLt:RMSPherror

Determines whether or not to show the RMS phase error measurement result in the pulse table.

**Conditions** Measurement views: Pulse table

**Group** Display commands

**Syntax** `DISPlay:PULSe:RESuLt:RMSPherror { OFF | ON | 0 | 1 }`  
`DISPlay:PULSe:RESuLt:RMSPherror?`

**Arguments** OFF or 0 does not show the RMS phase error measurement result.  
ON or 1 shows the RMS phase error measurement result in the pulse table.

**Examples**     `DISPLAY:PULSE:RESULT:RMSPHERROR ON` shows the RMS phase error measurement result in the pulse table.

## **DISPlay:PULSe:RESuLt:RRATe**

Determines whether or not to show the repetition rate measurement result in the pulse table.

**Conditions**     Measurement views: Pulse table

**Group**     Display commands

**Syntax**     `DISPly:PULSe:RESuLt:RRATe { OFF | ON | 0 | 1 }`  
`DISPly:PULSe:RESuLt:RRATe?`

**Arguments**     OFF or 0 does not show the repetition rate measurement result.  
ON or 1 shows the repetition rate measurement result in the pulse table.

**Examples**     `DISPLAY:PULSE:RESULT:RRATE ON` shows the repetition rate measurement result in the pulse table.

## **DISPlay:PULSe:RESuLt:TIME**

Determines whether or not to show the time measurement result in the pulse table.

**Conditions**     Measurement views: Pulse table

**Group**     Display commands

**Syntax**     `DISPly:PULSe:RESuLt:TIME { OFF | ON | 0 | 1 }`  
`DISPly:PULSe:RESuLt:TIME?`

**Arguments**     OFF or 0 does not show the time measurement result.  
ON or 1 shows the time measurement result in the pulse table.

**Examples**     `DISPLAY:PULSE:RESULT:TIME ON` shows the time measurement result in the pulse table.

## DISPlay:PULSe:RESult:WIDTh

Determines whether or not to show the pulse width measurement result in the pulse table.

**Conditions** Measurement views: Pulse table

**Group** Display commands

**Syntax** DISPlay:PULSe:RESult:WIDTh { OFF | ON | 0 | 1 }  
DISPlay:PULSe:RESult:WIDTh?

**Arguments** OFF or 0 does not show the pulse width measurement result.  
ON or 1 shows the pulse width measurement result in the pulse table.

**Examples** DISPLAY:PULSE:RESULT:WIDTH ON shows the pulse width measurement result in the pulse table.

## DISPlay:PULSe:SElect:NUMBER

Selects or queries a pulse to measure. For the selected pulse, the statistics view indicates the measurement result while the table view highlights it, and the trace view displays the waveform.

**Conditions** Measurement views: Pulse statistics, Pulse table, Pulse trace

**Group** Display commands

**Syntax** DISPlay:PULSe:SElect:NUMBER <number>  
DISPlay:PULSe:SElect:NUMBER?

**Arguments** <number> ::= <NR1> specifies the number of pulse to measure.  
Range: -(the number of acquired pulses before the time reference) to +(the number of acquired pulses after the time reference).  
Zero (0) represents the pulse at the analysis time reference specified using the [\[SENSe\]:ANALysis:REference](#) command. The number of acquired pulses depends on the analysis range.

**Examples**    `DISPLAY:WINDOW:SELECT:NUMBER -28` measures the pulse #-28.

## DISPlay:PULSe:SElect:RESult

Selects or queries which result is shown in the pulse trace and statistics views.

**Conditions**    Measurement views: Pulse statistics, Pulse trace

**Group**    Display commands

**Syntax**    `DISPlay:PULSe:SElect:RESult { AVERAge | PPOWer | ATX | WIDTH | RISE | FALL | RINTerval | RRATe | DUTPct | DUTRatio | RIPPlE | DROop | PPPHase | PPFRequency | RMSFReqerror | MFReqerror | RMSPherror | MPHerror | FRDeviation }`  
`DISPlay:PULSe:SElect:RESult?`

**Arguments**    The following table lists the arguments.

**Table 2-31: Pulse results**

Argument	Result
AVERAge	Average on power
PPOWer	Peak power
ATX	Average transmitted power
WIDTH	Pulse width
RISE	Rise time
FALL	Fall time
RINTerval	Repetition interval
RRATe	Repetition rate
DUTPct	Duty factor (%)
DUTRatio	Duty factor (ratio)
RIPPlE	Ripple
DROop	Droop
PPPHase	Pulse-pulse carrier phase
PPFRequency	Pulse-pulse carrier frequency
RMSFReqerror	RMS frequency error
MFReqerror	Maximum frequency error
RMSPherror	RMS phase error
MPHerror	Maximum phase error

Table 2-31: Pulse results (cont.)

Argument	Result
FRDeviation	Frequency deviation
PHDeviation	Phase deviation

**Examples** `DISPLAY:PULSE:SELECT:RESULT AVERAGE` shows the average on power result in the pulse trace and statistics views.

## DISPlay:PULSe:STATistics:MARKer:SHOW:STATE

Determines whether to show or hide the marker readout in the statistics graph. This command is valid when `DISPlay:PULSe:STATistics:PLOT` is set to FFT.

<b>Conditions</b>	Measurement views: Pulse statistics
<b>Group</b>	Display commands
<b>Syntax</b>	<code>DISPlay:PULSe:STATistics:MARKer:SHOW:STATE { OFF   ON   0   1 }</code> <code>DISPlay:PULSe:STATistics:MARKer:SHOW:STATE?</code>
<b>Arguments</b>	OFF or 0 hides the marker readout. ON or 1 shows the marker readout.
<b>Examples</b>	<code>DISPLAY:PULSE:STATISTICS:MARKER:SHOW:STATE ON</code> shows the marker readout in the statistics graph.

## DISPlay:PULSe:STATistics:PLOT

Selects or queries how to show the statistics graph.

<b>Conditions</b>	Measurement views: Pulse statistics
<b>Group</b>	Display commands
<b>Syntax</b>	<code>DISPlay:PULSe:STATistics:PLOT { TREND   FFT }</code> <code>DISPlay:PULSe:STATistics:PLOT?</code>

- Arguments**     TREND shows the statistics result along with the pulse number.  
                       FFT shows the statistics result transformed into the frequency domain by FFT.
- Examples**     DISPLAY:PULSE:STATISTICS:PLOT TREND shows the statistics result along with the pulse number.

## DISPlay:PULSe:STATistics:WINDow:TRACe:GRATICule:GRID:STATe

Determines whether to show or hide the graticule grid in the statistics view.

- Conditions**     Measurement views: Pulse statistics
- Group**            Display commands
- Syntax**            DISPlay:PULSe:STATistics:WINDow:TRACe:GRATICule:GRID:STATe {  
                           OFF | ON | 0 | 1 }  
                           DISPlay:PULSe:STATistics:WINDow:TRACe:GRATICule:GRID:STATe?
- Arguments**     OFF or 0 hides the graticule grid.  
                       ON or 1 shows the graticule grid.
- Examples**        DISPLAY:PULSE:STATISTICS:WINDOW:TRACE:GRATICULE:GRID:STATE  
                           ON shows the graticule grid on the statistics view.

## DISPlay:PULSe:STATistics:X:RSCale (No Query Form)

Rescales the horizontal axis to fit the waveform to the screen in the statistics graph.

- Conditions**     Measurement views: Pulse statistics
- Group**            Display commands
- Syntax**            DISPlay:PULSe:STATistics:X:RSCale
- Arguments**     None



**Examples** `DISPLAY:PULSE:STATISTICS:X:RSCALE` rescales the horizontal axis of the statistics graph.

## DISPlay:PULSe:STATistics:X[:SCALe]:NUMBer

Sets or queries the horizontal full scale in the statistics graph.

**Conditions** Measurement views: Pulse statistics

**Group** Display commands

**Syntax** `DISPlay:PULSe:STATistics:X[:SCALe]:NUMBer <value>`  
`DISPlay:PULSe:STATistics:X[:SCALe]:NUMBer?`

**Related Commands** [DISPlay:PULSe:STATistics:X\[:SCALe\]:OFFSet](#)

**Arguments** `<value>::=<NRF>` specifies the horizontal full scale. The setting range depends on the [DISPlay:PULSe:STATistics:PLOT](#) command parameters as shown in the table below.

<code>DISPlay:PULSe:STATistics:PLOT</code>	Setting range
TREND	1 to 1000
FFT	1 Hz to 120 MHz

**Examples** `DISPlay:PULSe:STATistics:X:SCALe:NUMBer 50` sets the horizontal full scale to 50 pulses when the plot is trend.

## DISPlay:PULSe:STATistics:X[:SCALe]:OFFSet

Selects or queries the minimum horizontal value (the first pulse to show) in the statistics graph.

**Conditions** Measurement views: Pulse statistics

**Group** Display commands

**Syntax** `DISPlay:PULSe:STATistics:X[:SCALe]:OFFSet <value>`  
`DISPlay:PULSe:STATistics:X[:SCALe]:OFFSet?`

**Arguments**     `<value>::=<Nrf>` specifies the number of the first pulse.  
 Range:  $-(X - X/10)$  to  $+(X - X/10)$   
 where X is the horizontal scale set by the `DISPlay:PULSe:STATistics:X[:SCALE]:NUMBer` command.

**Examples**     `DISPlay:PULSe:STATISTICS:X:SCALE:OFFSET 120` sets the first pulse number to #120.

## DISPlay:PULSe:STATistics:Y:RSCale (No Query Form)

Rescales the vertical axis to fit the waveform to the screen in the statistics graph.

**Conditions**     Measurement views: Pulse statistics

**Group**            Display commands

**Syntax**            `DISPlay:PULSe:STATistics:Y:RSCale`

**Arguments**        None

**Examples**        `DISPlay:PULSe:STATISTICS:Y:RSCALE` rescales the vertical axis of the statistics graph.

## DISPlay:PULSe:STATistics:Y[:SCALE]:FULL

Sets or queries the vertical full scale in the statistics graph.

**Conditions**        Measurement views: Pulse statistics

**Group**            Display commands

**Syntax**            `DISPlay:PULSe:STATistics:Y[:SCALE]:FULL <value>`  
`DISPlay:PULSe:STATistics:Y[:SCALE]:FULL?`

**Related Commands**     `DISPlay:PULSe:STATistics:X[:SCALE]:OFFSet`

**Arguments** `<value> ::= <NRF>` specifies the vertical full scale. The setting range depends on the `DISPlay:PULSe:STATistics:PLOT` command parameters and the measurement items as shown in the following table.

<code>DISPlay:PULSe:STATistics:PLOT</code>	Measurement item	Setting range
TRENd	Average on power, Peak power, Average transmitted power	0.1 to 200 dB
	Pulse width, Rise time, Fall time, Repetition interval	1 n to 5 Ms
	Repetition rate	100 m to 100 MHz
	Duty factor, Ripple	1 to 100%
	Droop	1 to 200%
	Pulse-pulse carrier phase	1 to 360°
	FFT	All

**Examples** `DISPlay:PULSe:STATistics:Y:SCALE:FULL 100` sets the vertical full scale to 100 dB.

## DISPlay:PULSe:STATistics:Y[:SCALE]:OFFSet

Sets or queries the vertical offset in the statistics graph.

**Conditions** Measurement views: Pulse statistics

**Group** Display commands

**Syntax** `DISPlay:PULSe:STATistics:Y[:SCALE]:OFFSet <value>`  
`DISPlay:PULSe:STATistics:Y[:SCALE]:OFFSet?`

**Arguments** `<value> ::= <NRF>` specifies the vertical offset. The vertical offset is the value at the top or the bottom edge of the graph depending on measurement items. The setting range depends on the `DISPlay:PULSe:STATistics:PLOT` command parameters and the measurement items as shown in the table below.

<code>DISPlay:PULSe:STATistics:PLOT</code>	Measurement item	Setting range	Offset position <sup>1</sup>
TRENd	Average on power, Peak power, Average transmitted power	-170 to +50 dBm	Top (Bottom for the unit of Volts or Watts)

DISPlay:PULSe :STATistics:PLOT	Measurement item	Setting range	Offset position <sup>1</sup>
	Pulse width, Rise time, Fall time, Repetition interval	0 to 5 Ms	Bottom
	Repetition rate	0 to 100 MHz	Bottom
	Duty factor, Ripple	0 to 100%	Bottom
	Droop	0 to +100%	Bottom
	Pulse-pulse carrier phase	-180 to +180°	Bottom
FFT	All	-400 to +100 dB	Top

<sup>1</sup> indicates whether the offset is the value at the top or the bottom edge of the graph.

**Examples**     `DISPlay:PULSe:STATISTICS:Y:SCALE:OFFSET 24.8` sets the maximum vertical value to 24.8 dBm in the statistics graph.

## DISPlay:PULSe:STATistics:Y[:SCALE]:STOP? (Query Only)

Queries the minimum vertical value (bottom edge) in the statistics graph.

**Conditions**     Measurement views: Pulse statistics

**Group**     Display commands

**Syntax**     `DISPlay:PULSe:STATistics:Y[:SCALE]:STOP?`

**Related Commands**     [DISPlay:PULSe:STATistics:X\[:SCALE\]:OFFSet](#)

**Arguments**     None

**Returns**     `<y_stop>::=<NRF>` is the minimum vertical value (bottom edge).

**Examples**     `DISPlay:PULSe:STATISTICS:Y:SCALE:STOP?` might return `-150.0`, indicating that the minimum vertical value is -150 dBm in the pulse statistics graph.

## DISPlay:PULSe:TRACe:MARKer:SHOW:STATE

Determines whether to show or hide the marker readout in the pulse trace view.

---

<b>Conditions</b>	Measurement views: Pulse trace
<b>Group</b>	Display commands
<b>Syntax</b>	<code>DISPlay:PULSe:TRACe:MARKer:SHOW:STATE { OFF   ON   0   1 }</code> <code>DISPlay:PULSe:TRACe:MARKer:SHOW:STATE?</code>
<b>Arguments</b>	OFF or 0 hides the marker readout. ON or 1 shows the marker readout.
<b>Examples</b>	<code>DISPLAY:PULSE:TRACE:MARKER:SHOW:STATE ON</code> shows the marker readout on the pulse trace view.

## DISPlay:PULSe:TRACe:POINt:SHOW

Determines whether to show or hide the measurement points and lines in the pulse trace view.

<b>Conditions</b>	Measurement views: Pulse trace
<b>Group</b>	Display commands
<b>Syntax</b>	<code>DISPlay:PULSe:TRACe:POINt:SHOW { OFF   ON   0   1 }</code> <code>DISPlay:PULSe:TRACe:POINt:SHOW?</code>
<b>Arguments</b>	OFF or 0 hides the measurement points and lines. ON or 1 shows the measurement points and lines.
<b>Examples</b>	<code>DISPLAY:PULSE:TRACE:POINT:SHOW ON</code> shows the measurement points and lines in the pulse trace view.

## DISPlay:PULSe:TRACe:WINDow:TRACe:GRATicule:GRID:STATE

Determines whether to show or hide the graticule grid in the pulse trace view.

<b>Conditions</b>	Measurement views: Pulse trace
-------------------	--------------------------------

<b>Group</b>	Display commands
<b>Syntax</b>	DISP <code>l</code> ay:PULSe:TRACe:WINDow:TRACe:GRATiCuLe:GRID:STATE { OFF   ON   0   1 } DISP <code>l</code> ay:PULSe:TRACe:WINDow:TRACe:GRATiCuLe:GRID:STATE?
<b>Arguments</b>	OFF or 0 hides the graticule grid. ON or 1 shows the graticule grid.
<b>Examples</b>	DISP <code>l</code> AY:PULSe:TRACe:WINDow:TRACe:GRATICULE:GRID:STATE ON shows the graticule grid on the pulse trace view.

## DISP`l`ay:PULSe:TRACe:X:RSCale (No Query Form)

Rescales the horizontal axis to fit the waveform to the screen in the pulse trace view.

<b>Conditions</b>	Measurement views: Pulse trace
<b>Group</b>	Display commands
<b>Syntax</b>	DISP <code>l</code> ay:PULSe:TRACe:X:RSCale
<b>Arguments</b>	None
<b>Examples</b>	DISP <code>l</code> AY:PULSe:TRACe:X:RSCALE rescales the horizontal axis in the pulse trace view.

## DISP`l`ay:PULSe:TRACe:X[:SCALE]

Sets or queries the horizontal full scale in the pulse trace view.

<b>Conditions</b>	Measurement views: Pulse trace
<b>Group</b>	Display commands

<b>Syntax</b>	DISP <code>l</code> ay:PULSE:TRACe:X[:SCALE] <value> DISP <code>l</code> ay:PULSE:TRACe:X[:SCALE]?
<b>Arguments</b>	<value> ::= <NRF> specifies the horizontal full scale. Range: 10 ns to acquisition memory capacity.
<b>Examples</b>	DISP <code>l</code> AY:PULSE:TRACe:X:SCALE 5.5E-6 sets the horizontal scale to 5.5 $\mu$ s.

## DISP`l`ay:PULSE:TRACe:X[:SCALE]:FULL

Selects or queries the full-scale reference for the horizontal rescale.

<b>Conditions</b>	Measurement views: Pulse trace
<b>Group</b>	Display commands
<b>Syntax</b>	DISP <code>l</code> ay:PULSE:TRACe:X[:SCALE]:FULL { SELEcted   MAXimum } DISP <code>l</code> ay:PULSE:TRACe:X[:SCALE]:FULL?
<b>Arguments</b>	SELEcted uses the selected pulse for the full-scale reference. MAXimum uses the maximum pulse for the full-scale reference.
<b>Examples</b>	DISP <code>l</code> AY:PULSE:TRACe:X:SCALE:FULL SELEcted uses the selected pulse for the full-scale reference.

## DISP`l`ay:PULSE:TRACe:X[:SCALE]:OFFSet

Sets or queries the minimum horizontal value (left edge) in the pulse trace view.

<b>Conditions</b>	Measurement views: Pulse trace
<b>Group</b>	Display commands
<b>Syntax</b>	DISP <code>l</code> ay:PULSE:TRACe:X[:SCALE]:OFFSet <value> DISP <code>l</code> ay:PULSE:TRACe:X[:SCALE]:OFFSet?

**Related Commands** [DISP`l`ay:PULSE:TRACe:X\[:SCALE\]:PDIVision](#)

**Arguments** <value> ::= <Nrf> specifies the minimum horizontal value.  
 Range: [(analysis offset) - (X scale) × 0.9] to [(analysis offset) + (analysis length) - (X scale) × 0.1]

**Examples** DISPLAY:PULSE:TRACE:X:SCALE:OFFSET 937.5E-9 sets the minimum horizontal value to 937.5 ns.

## DISPlay:PULSe:TRACe:X[:SCALe]:PDIVision

Sets or queries the horizontal full scale in the pulse trace view.

**Conditions** Measurement views: Pulse trace

**Group** Display commands

**Syntax** DISPlay:PULSe:TRACe:X[:SCALe]:PDIVision <value>  
 DISPlay:PULSe:TRACe:X[:SCALe]:PDIVision?

**Arguments** <value> ::= <Nrf> specifies the horizontal full scale.  
 Range: 10 ns to acquisition memory capacity.

**Examples** DISPLAY:PULSE:TRACE:X:SCALE:PDIVISION 5.5E-6 sets the horizontal scale to 5.5 μs.

## DISPlay:PULSe:TRACe:Y:RSCale (No Query Form)

Rescales the vertical axis to fit the waveform to the screen in the pulse trace view.

**Conditions** Measurement views: Pulse trace

**Group** Display commands

**Syntax** DISPlay:PULSe:TRACe:Y:RSCale

**Arguments** None



**Examples** `DISPLAY:PULSE:TRACE:Y:RSCALE` rescales the vertical axis in the pulse trace view.

## DISPlay:PULSe:TRACe:Y[:SCALe]:FULL

Sets or queries the vertical full scale in the pulse trace view.

**Conditions** Measurement views: Pulse trace

**Group** Display commands

**Syntax** `DISPlay:PULSe:TRACe:Y[:SCALe]:FULL <value>`  
`DISPlay:PULSe:TRACe:Y[:SCALe]:FULL?`

**Related Commands** [DISPlay:PULSe:TRACe:Y\[:SCALe\]:OFFSet](#)

**Arguments** `<value> ::= <NRf>` specifies the vertical full scale.  
Range: 0.1 to 200 dB.  
The unit can be changed by the [\[SENSe\]:POWer:UNITs](#) command.

**Examples** `DISPLAY:PULSE:TRACE:Y:SCALE:FULL 100` sets the vertical full scale to 100 dB.

## DISPlay:PULSe:TRACe:Y[:SCALe]:OFFSet

Sets or queries the vertical offset (the value at the top edge of the vertical axis) in the pulse trace view.

**Conditions** Measurement views: Pulse trace

**Group** Display commands

**Syntax** `DISPlay:PULSe:TRACe:Y[:SCALe]:OFFSet <value>`  
`DISPlay:PULSe:TRACe:Y[:SCALe]:OFFSet?`

**Related Commands** [DISPlay:PULSe:TRACe:Y\[:SCALe\]:STOP?](#)

**Arguments** <value>::=<Nrf> specifies the vertical offset. Range: -170 to +50 dBm.

**Examples** DISPLAY:PULSE:TRACE:Y:SCALE:OFFSET 23.5 sets the vertical offset to 23.5 dBm.

## DISPlay:PULSe:TRACe:Y[:SCALe]:STOP? (Query Only)

Queries the minimum vertical value (bottom edge) in the pulse trace view.

**Conditions** Measurement views: Pulse trace

**Group** Display commands

**Syntax** DISPlay:PULSe:TRACe:Y[:SCALe]:STOP?

**Related Commands** [DISPlay:PULSe:TRACe:Y\[:SCALe\]:OFFSet](#)

**Arguments** None

**Returns** <y\_stop>::=<Nrf> is the minimum vertical value (bottom edge).

**Examples** DISPLAY:PULSE:TRACE:Y:SCALE:STOP? might return -150.0, indicating that the minimum vertical value is -150 dBm in the pulse trace view.

## DISPlay:SGRam:FREQuency:AUTO (No Query Form)

Rescales the horizontal axis automatically to fit the waveform to the screen in the spectrogram view.

**Conditions** Measurement views: Spectrogram

**Group** Display commands

**Syntax** DISPlay:SGRam:FREQuency:AUTO

**Arguments** None

**Examples**     `DISPLAY:SGRAM:FREQUENCY:AUTO` rescales the horizontal scale automatically to fit the waveform to the screen.

## DISPlay:SGRam:FREQuency:OFFSet

Sets or queries the frequency offset (the value at the center of the horizontal axis) in the spectrogram.

**Conditions**     Measurement views: Spectrogram

**Group**            Display commands

**Syntax**           `DISPlay:SGRam:FREQuency:OFFSet <value>`  
`DISPlay:SGRam:FREQuency:OFFSet?`

**Related Commands**     [DISPlay:SPECtrum:FREQuency\[:SCAlE\]](#)

**Arguments**       `<value> ::= <NRF>` specifies the frequency offset.  
Range:  $[(\text{center frequency}) - (X \text{ scale}) \times 0.9]$  to  $[(\text{center frequency}) + (X \text{ scale}) \times 0.9]$

**Examples**         `DISPLAY:SGRAM:FREQUENCY:OFFSET 1.45GHZ` sets the frequency offset to 1.45 GHz in the spectrogram.

## DISPlay:SGRam:FREQuency:SCAlE

Sets or queries the horizontal range of the spectrogram.

**Conditions**       Measurement views: Spectrogram

**Group**            Display commands

**Syntax**           `DISPlay:SGRam:FREQuency:SCAlE <value>`  
`DISPlay:SGRam:FREQuency:SCAlE?`

**Related Commands**     [DISPlay:SPECtrum:FREQuency:OFFSet](#)

**Arguments**     `<value>::=<Nrf>` specifies the horizontal range.  
 Range: 10 Hz to 6.2 GHz (RSA6106A) / 14 GHz (RSA6114A).

**Examples**     `DISPlay:SGRAM:FREQUENCY:SCALE 10MHZ` sets the horizontal range to 10 MHz.

## DISPlay:SGRam:TIME:AUTO (No Query Form)

Rescales the vertical axis automatically to fit the graph to the screen in the spectrogram view.

**Conditions**     Measurement views: Spectrogram

**Group**            Display commands

**Syntax**          `DISPly:SGRam:TIME:AUTO`

**Arguments**     None

**Examples**     `DISPlay:SGRAM:TIME:AUTO` rescales the vertical scale automatically to fit the waveform to the screen.

## DISPlay:SGRam:TIME:OFFSet

Sets or queries the vertical axis (time) offset (bottom line number) in the spectrogram.

**Conditions**     Measurement views: Spectrogram

**Group**            Display commands

**Syntax**          `DISPly:SGRam:TIME:OFFSet <value>`  
`DISPly:SGRam:TIME:OFFSet?`

**Related Commands**     [DISPlay:SGRam:TIME:SCAle](#)

**Arguments** <value> ::= <Nrf> specifies the time offset.  
Range: Line #0 to 125000. Zero (0) represents the latest line.

**Examples** DISPLAY:SGRAM:TIME:OFFSET 15 sets the time offset to Line #15.

## DISPlay:SGRam:TIME:OVERlap

Determines whether or not to allow overlap between adjacent FFT frames on the time axis in the spectrogram.

**Conditions** Measurement views: Spectrogram

**Group** Display commands

**Syntax** DISPlay:SGRam:TIME:OVERlap { OFF | ON | 0 | 1 }  
DISPlay:SGRam:TIME:OVERlap?

**Arguments** OFF or 0 inhibits overlap between adjacent FFT frames on the time axis.  
ON or 1 allows overlap between adjacent FFT frames on the time axis.

**Examples** DISPLAY:SGRAM:TIME:OVERLAP ON allows overlap between adjacent FFT frames on the time axis in the spectrogram.

## DISPlay:SGRam:TIME:SCAlE

Sets or queries the vertical scale (the amount of time in each line) in the spectrogram. The vertical axis is composed of successive spectral displays. The new spectra can be added at a timed rate specified by this command. For example, if you set the scale to -5, one line is displayed every 5 spectra.

**Conditions** Measurement views: Spectrogram

**Group** Display commands

**Syntax** DISPlay:SGRam:TIME:SCAlE <value>  
DISPlay:SGRam:TIME:SCAlE?

**Related Commands** [DISPlay:SGRam:TIME:OFFSet](#)

**Arguments**     <value>::=<NR1> specifies the vertical scale.  
Range: -1023 to 0. Zero (0) displays every spectrum.

**Examples**     DISPLAY:SGRAM:TIME:SCALE -5 displays one line every 5 spectra in the spectrogram.

## DISPlay:SPECTrum:FREQuency:AUTO (No Query Form)

Rescales the horizontal axis automatically to fit the waveform to the screen in the spectrum view.

**Conditions**     Measurement views: Spectrum

**Group**            Display commands

**Syntax**           DISPLAY:SPECTrum:FREQuency:AUTO

**Arguments**     None

**Examples**     DISPLAY:SPECTRUM:FREQUENCY:AUTO rescales the horizontal scale automatically to fit the waveform to the screen.

## DISPlay:SPECTrum:FREQuency:OFFSet

Sets or queries the frequency offset (the value at the center of the horizontal axis) in the spectrum graph.

**Conditions**     Measurement views: Spectrum

**Group**            Display commands

**Syntax**           DISPLAY:SPECTrum:FREQuency:OFFSet <value>  
DISPLAY:SPECTrum:FREQuency:OFFSet?

**Related Commands**     [DISPlay:SPECTrum:FREQuency\[:SCALE\]](#)

- Arguments** <value>::=<Nrf> specifies the frequency offset.  
Range: [(center frequency) - (X scale) × 0.9] to [(center frequency) + (X scale) × 0.9]
- Examples** DISPLAY:SPECTRUM:FREQUENCY:OFFSET 1.45GHz sets the frequency offset to 1.45 GHz in the spectrum.

## DISPlay:SPECTrum:FREQuency[:SCAlE]

Sets or queries the horizontal range of the spectrum graph.

- Conditions** Measurement views: Spectrum
- Group** Display commands
- Syntax** DISPlay:SPECTrum:FREQuency[:SCAlE] <value>  
DISPlay:SPECTrum:FREQuency[:SCAlE]?

**Related Commands** [DISPlay:SPECTrum:FREQuency:OFFSet](#)

- Arguments** <value>::=<Nrf> specifies the horizontal range.  
Range: 10 Hz to 6.2 GHz (RSA6106A) / 14 GHz (RSA6114A).
- Examples** DISPLAY:SPECTRUM:FREQUENCY:SCALE 10MHZ sets the horizontal range to 10 MHz.

## DISPlay:SPECTrum:MARKer:NOISe:MODE

Determines whether to enable or disable the marker noise mode in the spectrum view. In this mode, the marker readout indicates amplitude in dBm/Hz. It is valid for all markers except for the reference marker.

---

**NOTE.** To use the marker noise mode, select dBm as the power unit by the [SENSe]:POWer:UNITs command.

---

- Conditions** Measurement views: Spectrum
- Group** Display commands

**Syntax**     `DISPLay:SPECTrum:MARKer:NOISe:MODE { OFF | ON | 0 | 1 }`  
`DISPLay:SPECTrum:MARKer:NOISe:MODE?`

**Related Commands**     [\[SENSe\]:POWer:UNITs](#)

**Arguments**     OFF or 0 disables the marker noise mode.  
                       ON or 1 enables the marker noise mode.

**Examples**     `DISPLay:SPECTrum:MARKer:NOISe:MODE ON` enables the marker noise mode.

## DISP<sub>L</sub>ay:SPECTrum:SCALe:LOG:STATe

Determines whether or not to set the horizontal axis logarithmic in the Spectrum view.

**Conditions**     Measurement views: Spectrum

**Group**            Display commands

**Syntax**     `DISPLay:SPECTrum:SCALe:LOG:STATe { OFF | ON | 0 | 1 }`  
`DISPLay:SPECTrum:SCALe:LOG:STATe?`

**Related Commands**     [DISP<sub>L</sub>ay:SPECTrum:X:LABel](#)

**Arguments**     OFF or 0 sets the horizontal axis linear (default).  
                       ON or 1 sets the horizontal axis logarithmic.  
                       Executing `DISPLay:SPECTrum:SCALe:LOG:STATe ON` sets  
`DISPLay:SPECTrum:X:LABel SSFReq`.

**Examples**     `DISPLay:SPECTrum:SCALe:LOG:STATe ON` sets the horizontal axis logarithmic in the Spectrum view.

## DISP<sub>L</sub>ay:SPECTrum:WINDow:TRACe:GRATICule:GRID:STATe

Determines whether to show or hide the graticule grid on the screen.

**Conditions**     Measurement views: Spectrum



<b>Group</b>	Display commands
<b>Syntax</b>	DISP <code>l</code> ay:SPECT <code>r</code> um:WIND <code>o</code> w:TRAC <code>e</code> :GRATIC <code>u</code> le:GRID:STATE { OFF   ON   0   1 } DISP <code>l</code> ay:SPECT <code>r</code> um:WIND <code>o</code> w:TRAC <code>e</code> :GRATIC <code>u</code> le:GRID:STATE?
<b>Arguments</b>	OFF or 0 hides the graticule grid. ON or 1 shows the graticule grid.
<b>Examples</b>	DISP <code>l</code> ay:SPECT <code>r</code> um:WIND <code>o</code> w:TRAC <code>e</code> :GRATIC <code>u</code> le:GRID:STATE ON shows the graticule grid on the screen in the spectrum measurement.

## DISP`l`ay:SPECT`r`um:WIND`o`w:TRAC`e`:LEG`e`nd:STAT`e`

Determines whether to show or hide the trace legend in the Spectrum view. The legend indicates the trace detection and function on the screen for each displayed spectrum trace.

<b>Conditions</b>	Measurement views: Spectrum
<b>Group</b>	Display commands
<b>Syntax</b>	DISP <code>l</code> ay:SPECT <code>r</code> um:WIND <code>o</code> w:TRAC <code>e</code> :LEG <code>e</code> nd:STATE { OFF   ON   0   1 } DISP <code>l</code> ay:SPECT <code>r</code> um:WIND <code>o</code> w:TRAC <code>e</code> :LEG <code>e</code> nd:STATE?
<b>Arguments</b>	OFF or 0 hides the trace legend. ON or 1 shows the trace legend.
<b>Examples</b>	DISP <code>l</code> ay:SPECT <code>r</code> um:WIND <code>o</code> w:TRAC <code>e</code> :LEG <code>e</code> nd:STATE ON shows the trace legend on the screen in the spectrum measurement.

## DISP`l`ay:SPECT`r`um:X:LAB`e`l

Selects or queries the labels for the horizontal (X) axis in the Spectrum view. The labels are indicated beneath the spectrum graph on the screen.

<b>Conditions</b>	Measurement views: Spectrum
-------------------	-----------------------------

<b>Group</b>	Display commands
<b>Syntax</b>	DISP <code>l</code> ay:SPECT <code>r</code> um:X:LABE <code>l</code> { SSFReq   CFSPan } DISP <code>l</code> ay:SPECT <code>r</code> um:X:LABE <code>l</code> ?
<b>Arguments</b>	SSFReq sets the labels to the start and stop frequencies. CFSPan sets the labels to the center frequency and span.
<b>Examples</b>	DISP <code>l</code> AY:SPECT <code>r</code> UM:X:LABE <code>l</code> SSFReq sets the labels to the start and stop frequencies for the horizontal axis in the Spectrum view.

## DISP`l`ay:SPECT`r`um:Y[:SCALE]

Sets or queries the vertical range of the spectrum graph.

<b>Conditions</b>	Measurement views: Spectrum
<b>Group</b>	Display commands
<b>Syntax</b>	DISP <code>l</code> ay:SPECT <code>r</code> um:Y[:SCALE] <value> DISP <code>l</code> ay:SPECT <code>r</code> um:Y[:SCALE]?
<b>Arguments</b>	<value>::=<NRF> specifies the vertical range. Range: 0.1 to 200 dB. The amplitude unit is set by the <a href="#">[SENSe]:POWeR:UNITs</a> command.  You can omit the unit in the argument. When you include the unit in the argument, only dB is available. For the amplitude units Watts, Volts, and Amps, omit the unit in the argument.
<b>Examples</b>	DISP <code>l</code> AY:SPECT <code>r</code> UM:Y:SCALE 50dB sets the vertical range to 50 dB in the Spectrum view.

## DISP`l`ay:SPECT`r`um:Y[:SCALE]:AUTO (No Query Form)

Rescales the vertical axis automatically to fit the waveform to the screen in the Spectrum view.

<b>Conditions</b>	Measurement views: Spectrum
-------------------	-----------------------------

<b>Group</b>	Display commands
<b>Syntax</b>	DISP <code>l</code> ay:SPECTrum:Y[:SCALE]:AUTO
<b>Arguments</b>	None
<b>Examples</b>	DISP <code>l</code> ay:SPECTrum:Y:SCALE:AUTO rescales the vertical scale automatically to fit the waveform to the screen.

## DISP`l`ay:SPECTrum:Y[:SCALE]:OFFSet

Sets or queries the vertical offset (the value at the top edge of the vertical axis) of the spectrum graph.

<b>Conditions</b>	Measurement views: Spectrum
<b>Group</b>	Display commands
<b>Syntax</b>	DISP <code>l</code> ay:SPECTrum:Y[:SCALE]:OFFSet <value> DISP <code>l</code> ay:SPECTrum:Y[:SCALE]:OFFSet?
<b>Arguments</b>	<value> ::=<NRF> specifies the vertical offset. Range: -270 to +150 dBm. The amplitude unit is set by the [SENSe]:POWer:UNITs command (default: dBm).  You can omit the unit in the argument. When you include the unit in the argument, only dBm is allowed. For the other amplitude units, omit the unit in the argument.
<b>Examples</b>	DISP <code>l</code> ay:SPECTrum:Y:SCALE:OFFSet -12.5dBm sets the vertical offset to -12.5 dBm.

## DISP`l`ay:SPECTrum:Y[:SCALE]:PDIVision

Sets or queries the vertical scale (per division) of the spectrum graph.

<b>Conditions</b>	Measurement views: Spectrum
<b>Group</b>	Display commands

**Syntax**     `DISPlay:SPECTrum:Y[:SCALE]:PDIVision <value>`  
`DISPlay:SPECTrum:Y[:SCALE]:PDIVision?`

**Related Commands**     [\[SENSe\]:POWer:UNITs](#)

**Arguments**     `<value>::=<NRF>` specifies the vertical scale (per division).  
 Range: 0.01 to 20 dB/div.

**Examples**     `SENSE:SPECTRUM:Y:SCALE:PDIVISION 0.5` sets the vertical scale to 0.5 dB/div.

## DISPlay:SPECTrum:Y[:SCALE]:RESet (No Query Form)

Resets the vertical scale of the spectrum graph to the default values:  
 Vertical offset = Reference level and Vertical scale = 100 dB

**Conditions**     Measurement views: Spectrum

**Group**     Display commands

**Syntax**     `DISPlay:SPECTrum:Y[:SCALE]:RESet`

**Arguments**     None

**Examples**     `DISPLAY:SPECTRUM:Y:SCALE:RESET` resets the vertical scale to the default values in the Spectrum view.

## DISPlay:SPURious:MARKer:SHOW:STATe

Determines whether to show or hide the readout for the selected marker in the Spurious view.

**Conditions**     Measurement views: Spurious

**Group**     Display commands

---

<b>Syntax</b>	<code>DISPlay:SPURious:MARKer:SHOW:STATe { OFF   ON   0   1 }</code> <code>DISPlay:SPURious:MARKer:SHOW:STATe?</code>
<b>Arguments</b>	OFF or 0 hides the readout for the selected marker in the graph. ON or 1 shows the readout for the selected marker in the graph.
<b>Examples</b>	<code>DISPlay:SPURious:MARKer:SHOW:STATe ON</code> shows the readout for the selected marker in the graph.

## **DISPlay:SPURious:RESet:SCALE (No Query Form)**

Resets the horizontal and vertical scale to the default values described below in the Spurious view.

Vertical offset = 0 dBm,  
Vertical scale = 100 dB,  
Horizontal offset = Center frequency, and  
Horizontal scale = Default span

<b>Conditions</b>	Measurement views: Spurious
<b>Group</b>	Display commands
<b>Syntax</b>	<code>DISPlay:SPURious:RESet:SCALE</code>
<b>Arguments</b>	None
<b>Examples</b>	<code>DISPlay:SPURious:RESet:SCALE</code> resets the horizontal and vertical scale to the default values.

## **DISPlay:SPURious:SCALE:LOG:STATE**

Determines whether or not to set the horizontal axis logarithmic in the Spurious view.

<b>Conditions</b>	Measurement views: Spurious
<b>Group</b>	Display commands

**Syntax**     `DISPlay:SPURious:SCALE:LOG:STATE { OFF | ON | 0 | 1 }`  
`DISPlay:SPURious:SCALE:LOG:STATE?`

**Arguments**     OFF or 0 sets the horizontal axis linear (default).  
                     ON or 1 sets the horizontal axis logarithmic.

**Examples**     `DISPLAY:SPURIOUS:SCALE:LOG:STATE ON` sets the horizontal axis logarithmic in the Spurious view.

## DISPlay:SPURious:SElect:NUMber

Selects or queries the spurious number in the Spurious view.

**Conditions**     Measurement views: Spurious

**Group**            Display commands

**Syntax**           `DISPlay:SPURious:SElect:NUMber <number>`  
`DISPlay:SPURious:SElect:NUMber?`

**Arguments**       <number>::=<NR1> specifies the spurious number.  
                     Range: 1 to the number of spurious signals.  
                     Use the [FETCh:SPURious:COUNT?](#) or [READ:SPURious:COUNT?](#) query to get the number of spurious signals.

**Examples**       `DISPLAY:SPURIOUS:SELECT:NUMBER 7` selects the spurious #7.

## DISPlay:SPURious:SHOW:LIMit

Selects or queries how to display the limits.

**Conditions**     Measurement views: Spurious

**Group**            Display commands

**Syntax**           `DISPlay:SPURious:SHOW:LIMit { SHADEd | LINE | OFF }`  
`DISPlay:SPURious:SHOW:LIMit?`

**Arguments** SHADed displays the limits with shade.  
 LINE displays the limits with line only.  
 OFF hides the limits.

**Examples** DISPLAY:SPURIOUS:SHOW:LIMIT LINE displays the limits with line only.

## DISPlay:SPURious:WINDow:TRACe:GRATICule:GRID:STATe

Determines whether to show or hide the graticule grid on the screen.

**Conditions** Measurement views: Spurious

**Group** Display commands

**Syntax** DISPlay:SPURious:WINDow:TRACe:GRATICule:GRID:STATe { OFF | ON | 0 | 1 }  
 DISPlay:SPURious:WINDow:TRACe:GRATICule:GRID:STATe?

**Arguments** OFF or 0 hides the graticule grid.  
 ON or 1 shows the graticule grid.

**Examples** DISPLAY:SPURIOUS:WINDOW:TRACE:GRATICULE:GRID:STATE ON shows the graticule grid on the screen.

## DISPlay:SPURious:X[:SCALE]:AUTO (No Query Form)

Rescales the horizontal axis automatically to fit the waveform to the screen in the Spurious view.

**Conditions** Measurement views: Spurious

**Group** Display commands

**Syntax** DISPlay:SPURious:X[:SCALE]:AUTO

**Arguments** None

**Examples**     `DISPLAY:SPURIOUS:X:SCALE:AUTO` rescales the horizontal scale automatically to fit the waveform to the screen.

## DISPlay:SPURious:X[:SCALe]:START

Sets or queries the minimum horizontal value (left edge) of the spectrum graph in the Spurious view.

**Conditions**     Measurement views: Spurious

**Group**            Display commands

**Syntax**           `DISPlay:SPURious:X[:SCALe]:START <value>`  
`DISPlay:SPURious:X[:SCALe]:START?`

**Arguments**       `<value>::=<Nrf>` specifies the minimum horizontal value.  
 Range: 0 Hz to 6.2 GHz (RSA6106A) / 14 GHz (RSA6114A).

**Examples**        `DISPLAY:SPURIOUS:X:SCALE:START 1.61GHz` sets the minimum horizontal value to 1.61 GHz in the spectrum graph.

## DISPlay:SPURious:X[:SCALe]:STOP

Sets or queries the maximum horizontal value (right edge) of the spectrum graph in the Spurious view.

**Conditions**       Measurement views: Spurious

**Group**            Display commands

**Syntax**           `DISPlay:SPURious:X[:SCALe]:STOP <value>`  
`DISPlay:SPURious:X[:SCALe]:STOP?`

**Arguments**       `<value>::=<Nrf>` specifies the minimum horizontal value.  
 Range: 0 Hz to 6.2 GHz (RSA6106A) / 14 GHz (RSA6114A).

**Examples**        `DISPLAY:SPURIOUS:X:SCALE:STOP 2.16GHz` sets the maximum horizontal value to 2.16 GHz in the spectrum graph.



## DISPlay:SPURious:Y[:SCALE]

Sets or queries the vertical range of the spectrum graph in the Spurious view.

<b>Conditions</b>	Measurement views: Spurious
<b>Group</b>	Display commands
<b>Syntax</b>	DISPlay:SPURious:Y[:SCALE] <value> DISPlay:SPURious:Y[:SCALE]?
<b>Arguments</b>	<value> ::= <NRf> specifies the vertical range. Range: 0.1 to 200 dB. The unit can be changed by the [SENSe]:POWer:UNITs command.
<b>Examples</b>	DISPLAY:SPURIOUS:Y:SCALE 100 sets the vertical range to 100 dB in the Spurious view.

## DISPlay:SPURious:Y[:SCALE]:AUTO (No Query Form)

Rescales the vertical axis automatically to fit the waveform to the screen in the Spurious view.

<b>Conditions</b>	Measurement views: Spurious
<b>Group</b>	Display commands
<b>Syntax</b>	DISPlay:SPURious:Y[:SCALE]:AUTO
<b>Arguments</b>	None
<b>Examples</b>	DISPLAY:SPURIOUS:Y:SCALE:AUTO rescales the vertical scale automatically to fit the waveform to the screen.

## DISPlay:SPURious:Y[:SCALE]:OFFSet

Sets or queries the vertical offset (the value at the top edge of the vertical axis) of the spectrum graph in the Spurious view.

<b>Conditions</b>	Measurement views: Spurious
<b>Group</b>	Display commands
<b>Syntax</b>	DISP <code>lay:SPURious:Y[:SCALE]:OFFSet</code> <value> DISP <code>lay:SPURious:Y[:SCALE]:OFFSet?</code>
<b>Arguments</b>	<value>::=<NRF> specifies the vertical offset. Range: -270 to +150 dBm. The unit can be changed by the <a href="#">[SENSE]:POWER:UNITS</a> command.
<b>Examples</b>	DISP <code>lay:SPURIOUS:Y:SCALE:OFFSET -12.5</code> sets the vertical offset to -12.5 dBm in the spectrum graph.

## DISP`lay:TDiagram:WINDOW:TRACE:GRATICule:GRID:STATE`

Determines whether to show or hide the graticule grid on the screen.

<b>Conditions</b>	Measurement views: Trellis diagram
<b>Group</b>	Display commands
<b>Syntax</b>	DISP <code>lay:TDiagram:WINDOW:TRACE:GRATICule:GRID:STATE</code> { OFF   ON   0   1 } DISP <code>lay:TDiagram:WINDOW:TRACE:GRATICule:GRID:STATE?</code>
<b>Arguments</b>	OFF or 0 hides the graticule grid. ON or 1 shows the graticule grid.
<b>Examples</b>	DISP <code>lay:TDiagram:WINDOW:TRACE:GRATICULE:GRID:STATE ON</code> shows the graticule grid on the screen in the trellis diagram.

## DISP`lay:TDiagram:Y[:SCALE]`

Sets or queries the vertical range of the trellis diagram.

<b>Conditions</b>	Measurement views: Trellis diagram
-------------------	------------------------------------

<b>Group</b>	Display commands
<b>Syntax</b>	DISP <code>l</code> ay:T <code>D</code> Iagram:Y[:SCALE] <value> DISP <code>l</code> ay:T <code>D</code> Iagram:Y[:SCALE]?
<b>Arguments</b>	<value> ::= <NRf> specifies the vertical range. Range: 1 ° to 1 T°.
<b>Examples</b>	DISP <code>l</code> AY:T <code>D</code> IAGRAM:Y:SCALE 2.5 sets the vertical range to 2.5 ° in the trellis diagram.

## DISP`l`ay:T`D`Iagram:Y[:SCALE]:AUTO (No Query Form)

Sets the vertical scale automatically to fit the waveform to the screen in the trellis diagram.

<b>Conditions</b>	Measurement views: Trellis diagram
<b>Group</b>	Display commands
<b>Syntax</b>	DISP <code>l</code> ay:T <code>D</code> Iagram:Y[:SCALE]:AUTO
<b>Arguments</b>	None
<b>Examples</b>	DISP <code>l</code> AY:T <code>D</code> IAGRAM:Y:SCALE:AUTO sets the vertical scale automatically to fit the waveform to the screen.

## DISP`l`ay:T`D`Iagram:Y[:SCALE]:OFFSet

Sets or queries the vertical offset (center point of the vertical axis) of the Trellis diagram.

<b>Conditions</b>	Measurement views: Trellis diagram
<b>Group</b>	Display commands
<b>Syntax</b>	DISP <code>l</code> ay:T <code>D</code> Iagram:Y[:SCALE]:OFFSet <value> DISP <code>l</code> ay:T <code>D</code> Iagram:Y[:SCALE]:OFFSet?

**Arguments**     <value>::=<Nrf> specifies the vertical offset. Range: -1 T° to +1 T°.

**Examples**     DISPLAY:TDIAGRAM:Y:SCALE:OFFSET -28.5 sets the vertical offset to -28.5 ° in the Trellis diagram.

## DISPlay:TOVerview:WINDow:TRACe:GRATICule:GRID:STATE

Determines whether to show or hide the graticule grid on the screen.

**Conditions**     Measurement views: Time overview

**Group**            Display commands

**Syntax**           DISPLAY:TOVerview:WINDow:TRACe:GRATICule:GRID:STATE { OFF | ON | 0 | 1 }  
 DISPLAY:TOVerview:WINDow:TRACe:GRATICule:GRID:STATE?

**Arguments**     OFF or 0 hides the graticule grid.  
 ON or 1 shows the graticule grid.

**Examples**     DISPLAY:TOVerview:WINDow:TRACe:GRATICule:GRID:STATE ON shows the graticule grid on the screen in the time overview.

## DISPlay:TOVerview:X[:SCALE]

Sets or queries the horizontal scale (full-scale time) of the time overview.

**Conditions**     Measurement views: Time overview

**Group**            Display commands

**Syntax**           DISPLAY:TOVerview:X[:SCALE] <value>  
 DISPLAY:TOVerview:X[:SCALE]?

**Related Commands**     [DISPlay:TOVerview:X\[:SCALE\]:OFFSet](#)

<b>Arguments</b>	<code>&lt;value&gt; ::= &lt;Nrf&gt;</code> specifies the horizontal scale in full-scale time. Range: 10 ns to the acquisition memory capacity.  You can see the acquisition memory capacity using the <a href="#">[SENSe]:ACquisition:MEMory:CAPacity[:TIME]?</a> query.
<b>Examples</b>	<code>DISPLAY:TOVERVIEW:X:SCALE 12.5us</code> sets the horizontal scale to 12.5 $\mu$ s.

## DISPlay:TOVerview:X[:SCALE]:AUTO (No Query Form)

Sets the horizontal scale and offset automatically to fit the waveform to the screen in the time overview.

<b>Conditions</b>	Measurement views: Time overview
<b>Group</b>	Display commands
<b>Syntax</b>	<code>DISPlay:TOVerview:X[:SCALE]:AUTO</code>
<b>Arguments</b>	None
<b>Examples</b>	<code>DISPLAY:TOVERVIEW:X:SCALE:AUTO</code> sets the horizontal scale and offset automatically to fit the waveform to the screen.

## DISPlay:TOVerview:X[:SCALE]:OFFSet

Sets or queries the minimum horizontal value (left edge) of the time overview.

<b>Conditions</b>	Measurement views: Time overview
<b>Group</b>	Display commands
<b>Syntax</b>	<code>DISPlay:TOVerview:X[:SCALE]:OFFSet &lt;value&gt;</code> <code>DISPlay:TOVerview:X[:SCALE]:OFFSet?</code>

**Related Commands**    [DISPlay:TOVerview:X\[:SCALE\]](#)

**Arguments** <value>::=<Nrf> specifies the minimum horizontal value.  
 Range: [(analysis offset) - (X scale) × 0.9] to [(analysis offset) + (analysis length) - (X scale) × 0.1]

**Examples** DISPLAY:TOVERVIEW:X:SCALE:OFFSET 800ns sets the minimum horizontal value to 800 ns in the time overview.

## DISPlay:TOVerview:Y[:SCALE]

Sets or queries the vertical range of the time overview.

**Conditions** Measurement views: Time overview

**Group** Display commands

**Syntax** DISPlay:TOVerview:Y[:SCALE] <value>  
 DISPlay:TOVerview:Y[:SCALE]?

**Related Commands** [DISPlay:TOVerview:Y\[:SCALE\]:OFFSet](#)

**Arguments** <value>::=<Nrf> specifies the vertical range. Range: 0.1 to 200 dB.

**Examples** DISPLAY:TOVERVIEW:Y:SCALE 50 sets the vertical range to 50 dBm in the time overview.

## DISPlay:TOVerview:Y[:SCALE]:AUTO (No Query Form)

Sets the vertical scale and offset automatically to fit the waveform to the screen in the time overview.

**Conditions** Measurement views: Time overview

**Group** Display commands

**Syntax** DISPlay:TOVerview:Y[:SCALE]:AUTO

**Arguments** None

**Examples** `DISPLAY:TOVERVIEW:Y:SCALE:AUTO` sets the vertical scale and offset automatically to fit the waveform to the screen.

## DISPlay:TOVerview:Y[:SCALe]:OFFSet

Sets or queries the vertical offset (the value at the top edge of the vertical axis) in the time overview.

**Conditions** Measurement views: Time overview

**Group** Display commands

**Syntax** `DISPlay:TOVerview:Y[:SCALe]:OFFSet <value>`  
`DISPlay:TOVerview:Y[:SCALe]:OFFSet?`

**Related Commands** [DISPlay:TOVerview:Y\[:SCALe\]](#)

**Arguments** `<value>[:=<NRF>]` specifies the vertical offset. Range: -170 to +50 dBm.

**Examples** `DISPLAY:TOVERVIEW:Y:SCALE:OFFSET -80` sets the vertical offset to -80 dBm in the time overview.

## DISPlay:TOVerview:Y[:SCALe]:RESCale (No Query Form)

Sets the vertical scale automatically to fit the waveform to the screen in the time overview.

**Conditions** Measurement views: Time overview

**Group** Display commands

**Syntax** `DISPlay:TOVerview:Y[:SCALe]:RESCale`

**Arguments** None

**Examples** `DISPLAY:TOVERVIEW:Y:SCALE:RESCALE` sets the vertical scale automatically to fit the waveform to the screen.

## DISPlay:WINDow:ACTive:MEASurement? (Query Only)

Queries the active measurement views.

<b>Conditions</b>	Measurement views: All
<b>Group</b>	Display commands
<b>Syntax</b>	DISPlay:WINDow:ACTive:MEASurement?
<b>Arguments</b>	None
<b>Returns</b>	<view1>, <view2>, ..., <view(n)>

Where

<view(n)> ::= <string> is the view name as shown in the following table.

**Table 2-32: Measurement view mnemonic**

Return value	Measurement view	Display group
"SPEC	Spectrum	General signal viewing
"DPSA"	DPX (Digital Phosphor) spectrum	
"MAGVT"	Amplitude versus Time	
"ACP"	Channel power and ACPR	
"FVT"	Frequency versus Time	
"FDVT"	Frequency deviation versus Time	
"PHVT"	Phase versus Time	
"IQVT"	RF I&Q versus Time	
"DIQV"	Demodulated I&Q versus Time	
EDI	Eye Diagram	
"SGRam"	Spectrogram	
"TOV"	Time overview	
"TDI"	Trellis Diagram	
"AM"	Amplitude modulation	
"FM"	Frequency modulation	
"PM"	Phase modulation	



**Table 2-32: Measurement view mnemonic (cont.)**

Return value	Measurement view	Display group
"CONS"	Constellation	General purpose digital modulation
"EVM"	EVM versus Time	
"MERR"	Magnitude error versus Time	
"PERR"	Phase error versus Time	
"SIGN"	Signal quality	
"STAB"	Symbol table	
"CCDF"	CCDF	RF measurements
"MCP"	MCPR (Multiple Carrier Power Ratio)	
"OBW"	Occupied bandwidth	
"PNO"	Phase noise	
"SPUR"	Spurious	
"STAT"	Pulse statistics	
"RES"	Pulse table (results table)	
"TRAC"	Pulse trace	

**Examples** `DISPLAY:WINDOW:ACTIVE:MEASUREMENT?` might return "SPEC", "TRAC", indicating that the views of spectrum and pulse trace are displayed on the screen.

## DISPlay:WINDow:COLor:SCHEME

Selects or queries the color scheme for displaying traces and background on the screen.

**Conditions** Measurement views: All

**Group** Display commands

**Syntax** `DISPlay:WINDow:COLor:SCHEME { THUNDERstorm | BLIZZard | CLASSic }`  
`DISPlay:WINDow:COLor:SCHEME?`

**Arguments** THUNDERstorm displays the background in dark blue.

BLIZZard displays the background in white. It saves ink when printing the screen image.

CLASSic displays the background in black (default).

**Examples**    `DISPLAY:WINDOW:COLOR:SCHEME BLizzard` displays the background in white.

## DISPlay:WINDow:OPTimized:MEASurement? (Query Only)

Queries the measurement views that are optimized. "Optimized" means that there is a perfect match between the view's settings and the actual acquisition parameters to meet the specifications. When multiple measurements are running at one time, the measurements can have different requirements for setting the acquisition hardware. You can make a measurement optimized by selecting it using the following commands:

- `DISPlay:GENeral:MEASview:SElect` for the general signal viewing
- `DISPlay:DDEMod:MEASview:SElect` for the digital modulation views
- `DISPlay:GPRF:MEASview:SElect` for the RF measurement views
- `DISPlay:PULSe:MEASview:SElect` for the pulsed RF measurement views

**Conditions**    Measurement views: All

**Group**        Display commands

**Syntax**       `DISPlay:WINDow:OPTimized:MEASurement?`

**Arguments**    None

**Returns**       `<view1>,<view2>,...,<view(n)>`

Where

`<view(n)>::=<string>` is the view name as shown in the table. (See Table 2-32 on page 2-342.)

**Examples**    `DISPLAY:WINDOW:OPTIMIZED:MEASUREMENT?` might return "SPEC", "MCP", indicating that the views of spectrum and MCPR are optimized.

## \*ESE

Sets or queries the bits in the Event Status Enable Register (ESER). The ESER prevents events from being reported to the Status Byte Register (STB). Refer to Section 3, *Status and Events*, for the register information.

**Conditions** Measurement views: All

**Group** IEEE common commands

**Syntax** \*ESE <value>  
\*ESE?

**Related Commands** [\\*CLS](#), [\\*ESR?](#), [\\*SRE](#), [\\*STB?](#)

**Arguments** <value> ::= <NR1> is a value in the range from 0 through 255.  
The binary bits of the ESER are set according to this value.

**Examples** \*ESE 145 sets the ESER to binary 10010001, which enables the PON, EXE, and OPC bits.  
  
\*ESE? might return the string \*ESE 184, showing that the ESER contains the binary value 10111000.

## \*ESR? (Query Only)

Returns the contents of the Standard Event Status Register (SESR). \*ESR? also clears the SESR (since reading the SESR clears it). Refer to Section 3, *Status and Events*, for the register information.

**Conditions** Measurement views: All

**Group** IEEE common commands

**Syntax** \*ESR?

**Related Commands** [\\*CLS](#), [\\*ESE](#), [\\*SRE](#), [\\*STB?](#)

**Arguments** None

**Returns** <NR1> representing the contents of the SESR by a 0 to 255 decimal number.

**Examples** \*ESR? might return the value 213, showing that the SESR contains binary 11010101.

## FETCH:ACPower? (Query Only)

Returns the Channel power and ACPR measurement results for all available channels.

**Conditions** Measurement views: Channel power and ACPR

**Group** Fetch commands

**Syntax** FETCH:ACPower?

**Arguments** None

**Returns** <chan\_power>, <acpr\_lower(1)>, <acpr\_upper(1)>, <acpr\_lower(2)>, <acpr\_upper(2)>, . . . <acpr\_lower(n)>, <acpr\_upper(n)>

Where

<chan\_power> is the average power of the main channel as the power reference in dBm. The unit can be changed by the [SENSe]:POWer:UNITs command.

<acpr\_lower(n)> is the ACPR for the lower channel #n in dB.

<acpr\_upper(n)> is the ACPR for the upper channel #n in dB.

The number of n depends on the setting of the [SENSe]:ACPower:CHANnel:PAIRs command.

**Examples** FETCH:ACPOWER? might return 4.227, -28.420, -23.847, -22.316, -29.225, indicating (average power of the main channel) = 4.227 dBm, (ACPR for the lower channel 1) = -28.420 dB, (ACPR for the upper channel 1) = -23.847 dB, (ACPR for the lower channel 2) = -22.316 dB, and (ACPR for the upper channel 2) = -29.225 dB.

## FETCh:ACPower:CHANnel:POWer? (Query Only)

Returns the average power of the main channel (power reference) in the Channel power and ACPR measurement.

**Conditions** Measurement views: Channel power and ACPR

**Group** Fetch commands

**Syntax** FETCh:ACPower:CHANnel:POWer?

**Arguments** None

**Returns** <chan\_power> ::= <NRF> is the average power of the main channel in dBm. The unit can be changed by the [\[SENSe\]:POWer:UNITs](#) command.

**Examples** FETCh:ACPower:CHANnel:POWer? might return 4.227, indicating that the average power of the main channel is 4.227 dBm.

## FETCh:ACPower:SPECTrum? (Query Only)

Returns spectrum trace data of the Channel power and ACPR measurement.

**Conditions** Measurement views: Channel power and ACPR

**Group** Fetch commands

**Syntax** FETCh:ACPower:SPECTrum?

**Arguments** None

**Returns** #<num\_digit><num\_byte><data(1)><data(2)>...<data(n)>

Where

<num\_digit> is the number of digits in <num\_byte>.

<num\_byte> is the number of bytes of data that follow.

<data(n)> is the amplitude in dBm at the n<sup>th</sup> data point,

4-byte little endian floating-point format specified in IEEE 488.2.

The unit can be changed by the `[SENSe]:POWer:UNITs` command.

**Examples** `FETCH:ACPOWER:SPECTRUM?` might return `#43204xxxx...` (3204-byte data) for the spectrum trace data of the Channel power and ACPR measurement.

## FETCH:{AM|FM|PM}? (Query Only)

Returns the trace data in the AM/FM/PM measurement.

**Conditions** Measurement views: AM, FM, and PM

**Group** Fetch commands

**Syntax** `FETCH: {AM|FM|PM}?`

**Arguments** None

**Returns** `#<num_digit><num_byte><data(1)><data(2)>...<data(n)>`

Where

`<num_digit>` is the number of digits in `<num_byte>`.

`<num_byte>` is the number of bytes of data that follow.

`<data(n)>` is the modulation factor in percent (AM), frequency deviation in Hz (FM), or phase deviation in degrees (PM) at the  $n^{\text{th}}$  data point, 4-byte little endian floating-point format specified in IEEE 488.2.

**Examples** `FETCH:AM?` might return `#3156xxxx...` (156-byte data) for the AM measurement trace.

## FETCH:AM:AMINdex? (Query Only)

Returns the modulation indexdepth which is the (positive peak modulation factor - negative peak modulation factor)/2 returned as a percentage (%).

**Conditions** Measurement views: AM

**Group** Fetch commands

---

<b>Syntax</b>	<code>FETCh:AM:AMIndex?</code>
<b>Arguments</b>	None
<b>Returns</b>	<code>&lt;value&gt;::=&lt;NRf&gt;</code> the modulation index.
<b>Examples</b>	<code>FETCh:AM:AMINDEX?</code> might return <code>77.1854035556E-3</code> , indicating the modulation index is 0.0772% or 77.2 m%.

### FETCh:AM:AMNegative? (Query Only)

Returns the negative peak modulation factor (–AM) in the AM measurement.

<b>Conditions</b>	Measurement views: AM
<b>Group</b>	Fetch commands
<b>Syntax</b>	<code>FETCh:AM:AMNegative?</code>
<b>Arguments</b>	None
<b>Returns</b>	<code>&lt;-AM&gt;::=&lt;NRf&gt;</code> is the negative peak modulation factor in percent (%).
<b>Examples</b>	<code>FETCh:AM:AMNEGATIVE?</code> might return <code>-23.4</code> , indicating the negative peak modulation factor is –23.4%.

### FETCh:AM:AMPositive? (Query Only)

Returns the positive peak modulation factor (+AM) in the AM measurement.

<b>Conditions</b>	Measurement views: AM
<b>Group</b>	Fetch commands
<b>Syntax</b>	<code>FETCh:AM:AMPositive?</code>

<b>Arguments</b>	None
<b>Returns</b>	<+AM>::=<Nrf> is the positive peak modulation factor in percent (%).
<b>Examples</b>	FETCH:AM:AMPOSITIVE? might return 43.8, indicating the positive peak modulation factor is 43.8%.

## FETCH:AM:RESult? (Query Only)

Returns the AM measurement results.

<b>Conditions</b>	Measurement views: AM
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCH:AM:RESult?
<b>Arguments</b>	None
<b>Returns</b>	<+AM>, <-AM>, <Total AM> Where <+AM>::=<Nrf> is the positive peak modulation factor in percent (%). <-AM>::=<Nrf> is the negative peak modulation factor in percent (%). <Total AM>::=<Nrf> is the (peak to peak modulation factor)/2 in percent (%).
<b>Examples</b>	FETCH:AM:RESULT? might return 62.63, -50.89, 56.76.

## FETCH:AVTime:AVERage? (Query Only)

Returns the RMS (root-mean-square) value for the selected trace in the Amplitude versus Time measurement. Select the trace using the [TRACe<x>:AVTime:SElect](#) command.

<b>Conditions</b>	Measurement views: Amplitude versus Time
<b>Group</b>	Fetch commands



<b>Syntax</b>	FETCh:AVTime:AVERAge?
<b>Arguments</b>	None
<b>Returns</b>	<avg> ::= <Nrf> is the RMS amplitude in dBm. The unit can be changed by the <a href="#">[SENSe]:POWer:UNITs</a> command.
<b>Examples</b>	FETCh:AVTIME:AVERAGE? might return -2.53, indicating the RMS amplitude is -2.53 dBm.

## FETCh:AVTime:{FIRSt|SECOnd|THIRd|FOURth}? (Query Only)

Returns the trace data in the Amplitude versus Time measurement.

The mnemonics FIRSt, SECOnd, THIRd, and FOURth represent Trace 1, Trace 2, Trace 3, and Math trace, respectively. The traces can be specified by the TRACe<x>:AVTime command subgroup.

<b>Conditions</b>	Measurement views: Amplitude versus Time
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCh:AVTime:{FIRSt SECOnd THIRd FOURth}?
<b>Arguments</b>	None
<b>Returns</b>	#<num_digit><num_byte><data(1)><data(2)>...<data(n)> Where <num_digit> is the number of digits in <num_byte>. <num_byte> is the number of bytes of data that follow. <data(n)> is the amplitude in dBm at the n <sup>th</sup> data point, 4-byte little endian floating-point format specified in IEEE 488.2. The unit can be changed by the <a href="#">[SENSe]:POWer:UNITs</a> command.
<b>Examples</b>	FETCh:AVTIME:FIRST? might return #3156xxxx... (156-byte data) for Trace 1.

## FETCh:AVTime:MAXimum? (Query Only)

Returns the maximum value for the selected trace in the Amplitude versus Time measurement. Select the trace using the [TRACe<x>:AVTime:SElect](#) command.

<b>Conditions</b>	Measurement views: Amplitude versus Time
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCh:AVTime:MAXimum?
<b>Related Commands</b>	<a href="#">FETCh:AVTime:MAXLocation?</a>
<b>Arguments</b>	None
<b>Returns</b>	<max>::=<Nrf> is the maximum Amplitude in dBm. The unit can be changed by the <a href="#">[SENSE]:POWER:UNITs</a> command.
<b>Examples</b>	FETCh:AVTIME:MAXIMUM? might return -2.84, indicating the maximum amplitude is -2.84 dBm.

## FETCh:AVTime:MAXLocation? (Query Only)

Returns the time at which the amplitude is maximum for the selected trace in the Amplitude versus Time measurement. Select the trace using the [TRACe<x>:AVTime:SElect](#) command.

<b>Conditions</b>	Measurement views: Amplitude versus Time
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCh:AVTime:MAXLocation?
<b>Related Commands</b>	<a href="#">FETCh:AVTime:MAXimum?</a>
<b>Arguments</b>	None

**Returns** <max\_time>::=<Nrf> is the time at the maximum in seconds.

**Examples** FETCH:AVTIME:MAXLOCATION? might return 25.03E-9, indicating the amplitude is maximum at 25.03 ns.

## FETCH:AVTime:MINimum? (Query Only)

Returns the minimum value for the selected trace in the Amplitude versus Time measurement. Select the trace using the [TRACe<x>:AVTime:SElect](#) command.

**Conditions** Measurement views: Amplitude versus Time

**Group** Fetch commands

**Syntax** FETCH:AVTime:MINimum?

**Related Commands** [FETCH:AVTime:MINLocation?](#)

**Arguments** None

**Returns** <min>::=<Nrf> is the minimum amplitude in dBm.  
The unit can be changed by the [\[SENSE\]:POWER:UNITs](#) command.

**Examples** FETCH:AVTIME:MINIMUM? might return -57.64, indicating the minimum amplitude is -57.64 dBm.

## FETCH:AVTime:MINLocation? (Query Only)

Returns the time at which the amplitude is minimum for the selected trace in the Amplitude versus Time measurement. Select the trace using the [TRACe<x>:AVTime:SElect](#) command.

**Conditions** Measurement views: Amplitude versus Time

**Group** Fetch commands

**Syntax** FETCH:AVTime:MINLocation?

<b>Related Commands</b>	<a href="#">FETCh:AVTime:MINimum?</a>
<b>Arguments</b>	None
<b>Returns</b>	<code>&lt;min_time&gt;::=&lt;Nrf&gt;</code> is the time at the minimum in seconds.
<b>Examples</b>	<code>FETCH:AVTIME:MINLOCATION?</code> might return <code>450.7E-9</code> , indicating the amplitude is minimum at 450.7 ns.

## FETCh:AVTime:RESult? (Query Only)

Returns the measurement results for the selected trace in the Amplitude versus Time measurement. Select the trace using the [TRACe<x>:AVTime:SElect](#) command.

<b>Conditions</b>	Measurement views: Amplitude versus Time
<b>Group</b>	Fetch commands
<b>Syntax</b>	<code>FETCh:AVTime:RESult?</code>
<b>Arguments</b>	None
<b>Returns</b>	<code>&lt;max&gt;, &lt;max_time&gt;, &lt;min&gt;, &lt;min_time&gt;, &lt;rms&gt;</code>  Where <code>&lt;max&gt;::=&lt;Nrf&gt;</code> is the maximum amplitude in dBm. <code>&lt;max_time&gt;::=&lt;Nrf&gt;</code> is the time at the maximum in seconds. <code>&lt;min&gt;::=&lt;Nrf&gt;</code> is the minimum amplitude in dBm. <code>&lt;min_time&gt;::=&lt;Nrf&gt;</code> is the time at the minimum in seconds. <code>&lt;rms&gt;::=&lt;Nrf&gt;</code> is the RMS amplitude in dBm. The unit of amplitude can be changed by the <a href="#">[SENSE]:POWER:UNITs</a> command.
<b>Examples</b>	<code>FETCH:AVTIME:RESULT?</code> might return <code>-2.68, 48.62E-6, -82.47, 22.11E-6, -8.24</code> , indicating that the maximum amplitude is -2.68 dBm at 48.62 $\mu$ s, the minimum amplitude is -82.47 dBm at 22.11 $\mu$ s, and the RMS amplitude is -8.24 dBm.

## FETCh:CCDF? (Query Only)

Returns the CCDF measurement results.

**Conditions** Measurement views: CCDF

**Group** Fetch commands

**Syntax** FETCh:CCDF?

### Related Commands

**Arguments** None

**Returns** <avg\_amp1>, <avg\_ccdf>, <crest\_factor>, <amp1\_10>, <amp1\_1>, <amp1\_p1>, <amp1\_p01>, <amp1\_p001>, <amp1\_p0001>

Where

<avg\_amp1> is the average amplitude in dBm.

The unit can be changed by the [\[SENSe\]:POWer:UNITs](#) command.

<avg\_ccdf> is the average CCDF in percent.

<crest\_factor> is the crest factor in dB.

<amp1\_10> is the amplitude at CCDF of 10% in dB.

<amp1\_1> is the amplitude at CCDF of 1% in dB.

<amp1\_p1> is the amplitude at CCDF of 0.1% in dB.

<amp1\_p01> is the amplitude at CCDF of 0.01% in dB.

<amp1\_p001> is the amplitude at CCDF of 0.001% in dB.

<amp1\_p0001> is the amplitude at CCDF of 0.0001% in dB.

**Examples** FETCh:CCDF? might return  
-33.35, 35.8, 9.75, 3.88, 7.07, 8.50, 9.25, 9.72, 9.74, indicating  
(average amplitude) = -33.35 dBm,  
(average CCDF) = 35.8%,  
(crest factor) = 9.75 dB,  
(amplitude at CCDF of 10%) = 3.88 dB,  
(amplitude at CCDF of 1%) = 7.07 dB,  
(amplitude at CCDF of 0.1%) = 8.50 dB,  
(amplitude at CCDF of 0.01%) = 9.25 dB,  
(amplitude at CCDF of 0.001%) = 9.72 dB, and  
(amplitude at CCDF of 0.0001%) = 9.74 dB.

## FETCh:CCDF:{FIRSt|SECOnd|THIRd}:X? (Query Only)

Returns the horizontal values of the specified trace in the CCDF measurement.

The mnemonics FIRSt, SECOnd, and THIRd represent Trace 1, Trace 2, and Gaussian reference curve, respectively.

**Conditions** Measurement views: CCDF

**Group** Fetch commands

**Syntax** FETCh:CCDF:{FIRSt|SECOnd|THIRd}:X?

**Arguments** None

**Returns** #<num\_digit><num\_byte><x(1)><x(2)>...<x(n)>

Where

<num\_digit> is the number of digits in <num\_byte>.

<num\_byte> is the number of bytes of data that follow.

<x(n)> is the horizontal value (dB) of the CCDF graph at the n<sup>th</sup> point, 4-byte little endian floating-point format specified in IEEE 488.2.

**Examples** FETCh:CCDF:FIRSt:X? might return #41024xxxx... (1024-byte data) for the horizontal values of Trace 1.

## FETCh:CCDF:{FIRSt|SECOnd|THIRd}:XY? (Query Only)

Returns the horizontal and vertical value pairs of the specified trace in the CCDF measurement.

The mnemonics FIRSt, SECOnd, and THIRd represent Trace 1, Trace 2, and Gaussian reference curve, respectively.

**Conditions** Measurement views: CCDF

**Group** Fetch commands

**Syntax** FETCh:CCDF:{FIRSt|SECOnd|THIRd}:XY?

<b>Arguments</b>	None
<b>Returns</b>	#<num_digit><num_byte><x(1)><y(1)><x(2)><y(2)>...<x(n)><y(n)> Where <num_digit> is the number of digits in <num_byte>. <num_byte> is the number of bytes of data that follow. <x(n)><y(n)> is the horizontal value (dB) and vertical value (%) pair at the n <sup>th</sup> data point, 4-byte little endian floating-point format specified in IEEE 488.2.
<b>Examples</b>	FETCH:CCDF:FIRST:XY? might return #41024xxxx... (1024-byte data) for the horizontal and vertical value pairs of Trace 1.

## FETCH:CCDF:{FIRST|SECond|THIRd}[:Y]? (Query Only)

Returns the vertical values of the specified trace in the CCDF measurement.

The mnemonics FIRST, SECond, and THIRd represent Trace 1, Trace 2, and Gaussian reference curve, respectively.

<b>Conditions</b>	Measurement views: CCDF
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCH:CCDF:{FIRST SECond THIRd}[:Y]?
<b>Arguments</b>	None
<b>Returns</b>	#<num_digit><num_byte><y(1)><y(2)>...<y(n)> Where <num_digit> is the number of digits in <num_byte>. <num_byte> is the number of bytes of data that follow. <y(n)> is the vertical value (%) of the CCDF graph at the n <sup>th</sup> point, 4-byte little endian floating-point format specified in IEEE 488.2.
<b>Examples</b>	FETCH:CCDF:FIRST:Y? might return #41024xxxx... (1024-byte data) for the vertical values of Trace 1.

## FETCh:CONStE:FERRor? (Query Only)

Returns the frequency error in Hz. The frequency error is the difference between the measured carrier frequency of the signal and the user-selected center frequency of the analyzer.

<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCh:CONStE:FERRor?
<b>Related Commands</b>	<a href="#">FETCh:EVM:FERRor?</a>
<b>Arguments</b>	None.
<b>Returns</b>	<freq_error> ::= <NRf> which is the frequency error in Hz.
<b>Examples</b>	FETCh:CONStE:? might return -10.7E+3, which is a frequency error of -10.7 kHz.

## FETCh:CONStE:RESuLts? (Query Only)

Returns the constellation measurement results of EVM RMS, peak and location displayed on the bottom of the screen.

<b>Conditions</b>	Measurement views: Constellation
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCh:CONStE:RESuLts?
<b>Arguments</b>	None
<b>Returns</b>	For modulation types 2 4 8 16FSK or C4FM: FSK_deviation_Avg_Leftmost, FSK_deviation_Avg_Rightmost Where FSK_deviation_Avg_Leftmost is the average FSK deviation of the left-most symbol in Hz.



FSK\_deviation\_Avg\_Rightmost is the average FSK deviation of the right-most symbol in Hz.

For all other valid modulation types:

<EVM\_RMS>, <EVM\_peak>, <location>

Where

<EVM\_RMS> ::= <NRf> is the RMS EVM in percent (%).

<EVM\_peak> ::= <NRf> is the peak EVM in percent (%).

<location> ::= <NRf> is the peak location in symbol number.

The time unit can be changed by the [\[SENSe\]:DDEMod:TIME:UNITs](#) command.

**Examples**     FETCH:CONSTE:RESULTS? might return 2.841, 3.227, 68.000, indicating that the RMS EVM is 2.841% and the peak EVM is 3.227% at symbol #68.

## FETCh:CONStE:TRACe? (Query Only)

Returns the constellation trace data.

**Conditions**     Measurement views: Constellation

**Group**            Fetch commands

**Syntax**            FETCh:CONStE:TRACe?

**Arguments**        None

**Returns**            #<num\_digit><num\_byte><I(1)><Q(1)><I(2)><Q(2)>...  
<I(n)><Q(n)>

Where

<num\_digit> is the number of digits in <num\_byte>.

<num\_byte> is the number of bytes of data that follow.

<I(n)> and <Q(n)> are the normalized I- and Q-coordinate values at the n<sup>th</sup> data point. 4-byte little endian floating-point format specified in IEEE 488.2.

**Examples**        FETCH:CONSTE:TRACE? might return #43848xxxx... (3848-byte data) for the constellation trace data.

## FETCh:DDEMod:STABle? (Query Only)

Returns the symbol table data.

**Conditions** Measurement views: Symbol table

**Group** Fetch commands

**Syntax** FETCh:DDEMod:STABle?

**Arguments** None

**Returns** #<num\_digit><num\_byte><data(1)><data(2)>...<data(n)>

Where

<num\_digit> is the number of digits in <num\_byte>.

<num\_byte> is the number of bytes of data that follow.

<data(n)> is the symbol table data at the n<sup>th</sup> data point,

4-byte little endian floating-point format specified in IEEE 488.2.

**Examples** FETCh:DDEMod:STABle? might return #3512xxxx... (512-byte data) for the symbol table.

## FETCh:DDEMod:SYNCh:WORD:LENGth? (Query Only)

Returns the length of the synch word in the symbol table.

**Conditions** Measurement views: Symbol table

**Group** Fetch commands

**Syntax** FETCh:DDEMod:SYNCh:WORD:LENGth?

**Related Commands** [FETCh:DDEMod:SYNCh:WORD:POSition?](#)

**Arguments** None

**Returns** <NR1> indicates the length of the synch word in symbols.

**Examples**     `FETCH:DDEMOD:SYNCH:WORD:LENGTH?` might return 3, indicating the length of the synch word is three symbols.

## **FETCh:DDEMod:SYNCh:WORD:POSition? (Query Only)**

Returns the position of the synch word in the symbol table.

**Conditions**     Measurement views: Symbol table

**Group**     Fetch commands

**Syntax**     `FETCh:DDEMod:SYNCh:WORD:POSition?`

**Related Commands**     [FETCh:DDEMod:SYNCh:WORD:LENGth?](#)

**Arguments**     None

**Returns**     <NR1> indicates what symbol number the synch word begins at in the table. Zero (0) represents the first symbol in the table. A “-1” indicates that the synch word was not found.

**Examples**     `FETCH:DDEMOD:SYNCH:WORD:POSITION?` might return 10, indicating the synch word begins at 11<sup>th</sup> symbol in the table.

## **FETCh:DIQVtime:FERRor? (Query Only)**

Returns the frequency error in the Demod I&Q versus Time measurement.

**Conditions**     Measurement views: Demod I&Q versus Time

**Group**     Fetch commands

**Syntax**     `FETCh:DIQVtime:FERRor?`

**Arguments**     None

**Returns** <freq\_error>::=<Nrf> is the frequency error in Hz.

**Examples** FETCH:DIQVTIME:FERROR? might return -10.7E+3, indicating the frequency error is -10.7 kHz.

## FETCH:DIQVtime:I? (Query Only)

Returns the I versus Time trace data.

**Conditions** Measurement views: Demod I&Q versus Time

**Group** Fetch commands

**Syntax** FETCH:DIQVtime:I?

**Arguments** None

**Returns** #<num\_digit><num\_byte><data(1)><data(2)>...<data(n)>

Where

<num\_digit> is the number of digits in <num\_byte>.

<num\_byte> is the number of bytes of data that follow.

<data(n)> is the I level in volts at the n<sup>th</sup> data point,

4-byte little endian floating-point format specified in IEEE 488.2.

**Examples** FETCH:DIQVTIME:I? might return #3160xxxx... (160-byte data) for the I versus Time trace.

## FETCH:DIQVtime:Q? (Query Only)

Returns the Q versus Time trace data.

**Conditions** Measurement views: Demod I&Q versus Time

**Group** Fetch commands

**Syntax** FETCH:DIQVtime:Q?

<b>Arguments</b>	None
<b>Returns</b>	#<num_digit><num_byte><data(1)><data(2)>...<data(n)> Where <num_digit> is the number of digits in <num_byte>. <num_byte> is the number of bytes of data that follow. <data(n)> is the Q level in volts at the n <sup>th</sup> data point, 4-byte little endian floating-point format specified in IEEE 488.2.
<b>Examples</b>	FETCH:DIQVTIME:Q? might return #3160xxxx... (160-byte data) for the Q versus Time trace.

## FETCH:DPSA:RESuLts:TRACe<x>? (Query Only)

Returns waveform data of specified trace <x> in the DPX spectrum measurement, where x is 1 to 5. The traces 1–4 are in the standard form. Trace 5 is the bitmap trace and its data is returned in a binary block.

<b>Conditions</b>	Measurement views: DPX spectrum
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCH:DPSA:RESuLts:TRACe<x>?
<b>Arguments</b>	<NR1>
<b>Returns</b>	For traces 1 to 4: #<num_digit><num_byte><data(1)><data(2)>...<data(n)> Where <num_digit> is the number of digits in <num_byte>. <num_byte> is the number of bytes of data that follow. <data(n)> is the amplitude of the trace sample at the n <sup>th</sup> data point. <data(n)> is in the 4-byte little endian floating-point format specified in IEEE 488.2.  For trace 5, the format differs depending on whether Option 200 is installed in the instrument.  Without Option 200, the format is a binary block of unsigned 16 bit integers. Each value ranges from 0 to 2 <sup>16</sup> -1, where 2 <sup>16</sup> -1 represents 100%.

With Option 200, the format is a binary block of 32 bit floating point values. Each value ranges from 0 to 1.0, where 1.0 represents 100%.

**Examples**     `FETCH:DPSA:RESULTS:TRACE1?` might return `#42004xxxx...` (2004-byte of data) for the waveform data of trace one (1).

## FETCH:DPSA:TRACE:AVERAGE? (Query Only)

Returns waveform data of the average trace in the DPX spectrum measurement.

**Conditions**     Measurement views: DPX spectrum

**Group**            Fetch commands

**Syntax**           `FETCH:DPSA:TRACE:AVERAGE?`

**Arguments**      None

**Returns**           `#<num_digit><num_byte><data(1)><data(2)>...<data(n)>`

Where

`<num_digit>` is the number of digits in `<num_byte>`.

`<num_byte>` is the number of bytes of data that follow.

`<data(n)>` is the amplitude of the average trace at the  $n^{\text{th}}$  data point in dBm, 4-byte little endian floating-point format specified in IEEE 488.2.

The unit can be changed by the [\[SENSE\]:POWER:UNITS](#) command.

**Examples**     `FETCH:DPSA:TRACE:AVERAGE?` might return `#42004xxxx...` (2004-byte data) for the waveform data of the average trace.

## FETCH:DPSA:TRACE:BITMAP? (Query Only)

Returns trace waveform data of the bitmap trace in the DPX spectrum measurement.

**Conditions**      Measurement views: DPX spectrum

**Group**            Fetch commands

<b>Syntax</b>	<code>FETCh:DPSA:TRACe:BITMap?</code>
<b>Arguments</b>	None
<b>Returns</b>	<p>For trace 5, the format differs depending on whether Option 200 is installed in the instrument. Without Option 200, the format is a binary block of unsigned 16 bit integers. Each value ranges from 0 to <math>2^{16}-1</math>, where <math>2^{16}-1</math> represents 100%.</p> <p>With Option 200, the format is a binary block of 32 bit floating point values. Each value ranges from 0 to 1.0, where 1.0 represents 100%.</p>
<b>Examples</b>	<code>FETCh:DPSA:TRACe:BITMAP?</code> might return <code>#42004xxxx...</code> (2004-byte data) for the waveform data of the bitmap trace.

## FETCh:DPSA:TRACe:MATH? (Query Only)

Returns waveform data of the math trace in the DPX spectrum measurement.

<b>Conditions</b>	Measurement views: DPX spectrum
<b>Group</b>	Fetch commands
<b>Syntax</b>	<code>FETCh:DPSA:TRACe:MATH?</code>
<b>Arguments</b>	None
<b>Returns</b>	<p><code>#&lt;num_digit&gt;&lt;num_byte&gt;&lt;data(1)&gt;&lt;data(2)&gt;...&lt;data(n)&gt;</code></p> <p>Where</p> <ul style="list-style-type: none"> <li><code>&lt;num_digit&gt;</code> is the number of digits in <code>&lt;num_byte&gt;</code>.</li> <li><code>&lt;num_byte&gt;</code> is the number of bytes of data that follow.</li> <li><code>&lt;data(n)&gt;</code> is the amplitude of the math trace at the <math>n^{\text{th}}</math> data point in dBm, 4-byte little endian floating-point format specified in IEEE 488.2.</li> </ul> <p>The unit can be changed by the <a href="#">[SENSe]:POWer:UNITs</a> command.</p>
<b>Examples</b>	<code>FETCh:DPSA:TRACe:MATH?</code> might return <code>#42004xxxx...</code> (2004-byte data) for the waveform data of the math trace.

## FETCh:DPSA:TRACe:MAXimum? (Query Only)

Returns waveform data of the maximum trace in the DPX spectrum measurement.

**Conditions** Measurement views: DPX spectrum

**Group** Fetch commands

**Syntax** FETCh:DPSA:TRACe:MAXimum?

**Arguments** None

**Returns** #<num\_digit><num\_byte><data(1)><data(2)>...<data(n)>

Where

<num\_digit> is the number of digits in <num\_byte>.

<num\_byte> is the number of bytes of data that follow.

<data(n)> is the amplitude of the maximum trace at the n<sup>th</sup> data point in dBm, 4-byte little endian floating-point format specified in IEEE 488.2.

The unit can be changed by the [\[SENSe\]:POWer:UNITs](#) command.

**Examples** FETCh:DPSA:TRACe:MAXIMUM? might return #42004xxxx... (2004-byte data) for the waveform data of the maximum trace.

## FETCh:DPSA:TRACe:MINimum? (Query Only)

Returns waveform data of the minimum trace in the DPX spectrum measurement.

**Conditions** Measurement views: DPX spectrum

**Group** Fetch commands

**Syntax** FETCh:DPSA:TRACe:MINimum?

**Arguments** None

**Returns** #<num\_digit><num\_byte><data(1)><data(2)>...<data(n)>

Where



`<num_digit>` is the number of digits in `<num_byte>`.  
`<num_byte>` is the number of bytes of data that follow.  
`<data(n)>` is the amplitude data of the minimum trace at the  $n^{\text{th}}$  data point in dBm,  
 4-byte little endian floating-point format specified in IEEE 488.2.  
 The unit can be changed by the [\[SENSe\]:POWer:UNITs](#) command.

**Examples** `FETCh:DPSA:TRACE:MINIMUM?` might return `#42004xxxx...` (2004-byte data) for the waveform data of the minimum trace.

## FETCh:EDlagram:FDEVIation? (Query Only)

Returns the frequency deviation versus Time trace data with the X values.

**Group** Fetch commands

**Syntax** `FETCh:EDIagram:FDEVIation?`

### Related Commands

**Returns** `#<num_digit><num_byte><Y(1)><X(1)><Y(2)><X(2)>...<Y(n)><X(n)>`

Where

`<num_digit>` is the number of digits in `<num_byte>`.

`<num_byte>` is the number of bytes of data that follow.

`<Y(n)>` and `<X(n)>` is the frequency deviation in Hz and time (symbols) pair at the  $n^{\text{th}}$  data point, 4-byte little endian floating-point format specified in IEEE 488.2.

**Examples** `FETCh:EDIAGRAM:FDEVIATION?` might return `#3160xxxx...` (160-byte data) for the frequency deviation versus Time trace.

## FETCh:EDlagram:FERRor? (Query Only)

Returns the frequency error in the eye diagram measurement.

**Conditions** Measurement views: Eye diagram

**Group** Fetch commands

<b>Syntax</b>	FETCh:EDIagram:FERRor?
<b>Arguments</b>	None
<b>Returns</b>	<freq_error> ::= <NRF> is the frequency error in Hz.
<b>Examples</b>	FETCh:EDIAGRAM:FERROR? might return -10.7E+3, indicating the frequency error is -10.7 kHz.

## FETCh:EDIagram:I? (Query Only)

Returns the I versus Time trace data in the eye diagram measurement.

<b>Conditions</b>	Measurement views: Eye diagram
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCh:EDIagram:I?
<b>Arguments</b>	None
<b>Returns</b>	#<num_digit><num_byte><Y(1)><X(1)><Y(2)><X(2)> . . . <Y(n)><X(n)> Where <num_digit> is the number of digits in <num_byte>. <num_byte> is the number of bytes of data that follow. <Y(n)><X(n)> is the I level (normalized) and time (symbols) pair at the n <sup>th</sup> data point, 4-byte little endian floating-point format specified in IEEE 488.2.
<b>Examples</b>	FETCh:EDIAGRAM:I? might return #3160xxxx . . . (160-byte data) for the I versus Time trace.

## FETCh:EDIagram:Q? (Query Only)

Returns the Q versus Time trace data in the eye diagram measurement.

<b>Conditions</b>	Measurement views: Eye diagram
-------------------	--------------------------------

<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCH:EDIagram:Q?
<b>Arguments</b>	None
<b>Returns</b>	#<num_digit><num_byte><Y(1)><X(1)><Y(2)><X(2)>...<Y(n)><X(n)> Where <num_digit> is the number of digits in <num_byte>. <num_byte> is the number of bytes of data that follow. <Y(n)><X(n)> is the Q level (normalized) and time (symbols) pair at the n <sup>th</sup> data point, 4-byte little endian floating-point format specified in IEEE 488.2.
<b>Examples</b>	FETCH:EDIAGRAM:Q? might return #3160xxxx... (160-byte data) for the Q versus Time trace.

## FETCH:EVM:FERRor? (Query Only)

Returns the frequency error in the EVM versus Time measurement.

<b>Conditions</b>	Measurement views: EVM versus Time
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCH:EVM:FERRor?
<b>Arguments</b>	None
<b>Returns</b>	<freq_error> ::= <NRf> is the frequency error in Hz.
<b>Examples</b>	FETCH:EVM:FERRor? might return -10.7E+3, indicating the frequency error is -10.7 kHz.

## FETCH:EVM:PEAK? (Query Only)

Returns the peak value in the EVM versus Time measurement.

<b>Conditions</b>	Measurement views: EVM versus Time
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCh:EVM:PEAK?
<b>Related Commands</b>	<a href="#">FETCh:EVM:PINDEx?</a>
<b>Arguments</b>	None
<b>Returns</b>	<peak> ::= <NRF> is the peak EVM value in percent (%).
<b>Examples</b>	FETCh:EVM:PEAK? might return 1.32, indicating the peak EVM value is 1.32%.

## FETCh:EVM:PINDEx? (Query Only)

Returns the time at the EVM peak.

<b>Conditions</b>	Measurement views: EVM versus Time
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCh:EVM:PINDEx?
<b>Related Commands</b>	<a href="#">FETCh:EVM:PEAK?</a>
<b>Arguments</b>	None
<b>Returns</b>	<peak_time> ::= <NRF> is the time at the EVM peak in symbol number. The unit can be changed by the <a href="#">[SENSE]:DDEMod:TIME:UNITs</a> command.
<b>Examples</b>	FETCh:EVM:PINDEx? might return 68.000, indicating that the EVM peak is at symbol #68.

## FETCh:EVM:RMS? (Query Only)

Returns the RMS (Root-Mean-Square) value in the EVM versus Time measurement.

**Conditions** Measurement views: EVM versus Time

**Group** Fetch commands

**Syntax** FETCh:EVM:RMS?

**Arguments** None

**Returns** <rms> ::= <Nrf> is the RMS EVM value in percent (%).

**Examples** FETCh:EVM:RMS? might return 0.582, indicating the RMS EVM value is 0.582%.

## FETCh:EVM:TRACe? (Query Only)

Returns the EVM versus Time trace data.

**Conditions** Measurement views: EVM versus Time

**Group** Fetch commands

**Syntax** FETCh:EVM:TRACe?

**Arguments** None

**Returns** #<num\_digit><num\_byte><data(1)><data(2)>...<data(n)>

Where

<num\_digit> is the number of digits in <num\_byte>.

<num\_byte> is the number of bytes of data that follow.

<data(n)> is the EVM value at the n<sup>th</sup> data point in percent (%), 4-byte little endian floating-point format specified in IEEE 488.2.

**Examples**     `FETCH:EVM:TRACE?` might return `#42036xxxx...` (2036-byte data) for the EVM versus Time trace.

## **FETCh:FDVTime:FERRor? (Query Only)**

Returns the frequency error in the Frequency deviation versus Time measurement.

**Conditions**     Measurement views: Frequency deviation versus Time

**Group**     Fetch commands

**Syntax**     `FETCh:FDVTime:FERRor?`

**Arguments**     None

**Returns**     `<freq_error>::=<Nrf>` is the frequency error in Hz.

**Examples**     `FETCH:FDVTIME:FERROR?` might return `-10.7E+3`, indicating the frequency error is -10.7 kHz.

## **FETCh:FDVTime:TRACe? (Query Only)**

Returns the Frequency deviation versus Time trace data.

**Conditions**     Measurement views: Frequency deviation versus Time

**Group**     Fetch commands

**Syntax**     `FETCh:FDVTime:TRACe?`

**Arguments**     None

**Returns**     `#<num_digit><num_byte><data(1)><data(2)>...<data(n)>`

Where

`<num_digit>` is the number of digits in `<num_byte>`.

`<num_byte>` is the number of bytes of data that follow.

<data(n)> is the frequency deviation in Hz at the  $n^{\text{th}}$  data point, 4-byte little endian floating-point format specified in IEEE 488.2.

**Examples**     `FETCH:FDVTIME:TRACE?` might return `#3160xxxx...` (160-byte data) for the Frequency deviation versus Time trace.

## **FETCH:{FM|PM}:FERRor? (Query Only)**

Returns the frequency error in the Frequency modulation and/or Phase modulation measurements.

**Conditions**     Measurement views: Frequency deviation versus Time

**Group**     Fetch commands

**Syntax**     `FETCH:{FM|PM}:FERRor?`

**Arguments**     None

**Returns**     `<freq_error>::=<Nrf>` is the frequency error in Hz.

**Examples**     `FETCH:{FM|PM}:FERRor?` might return `-10.7E+3`, indicating the frequency error is -10.7 kHz.

## **FETCH:FM:PHALf? (Query Only)**

Returns the half peak-peak frequency deviation ( $\text{Pk-Pk}/2$ ) in the FM measurement.

**Conditions**     Measurement views: FM

**Group**     Fetch commands

**Syntax**     `FETCH:FM:PHALf?`

**Arguments**     None

**Returns** <Pk-Pk/2>::=<NRf> is the half peak-peak frequency deviation in Hz.

**Examples** FETCH:FM:PHALF? might return 628.9E+3, indicating the half peak-peak frequency deviation is 628.9 kHz.

## FETCH:FM:PNEGative? (Query Only)

Returns the negative peak frequency deviation (-Pk) in the FM measurement.

**Conditions** Measurement views: FM

**Group** Fetch commands

**Syntax** FETCH:FM:PNEGative?

**Arguments** None

**Returns** <-Pk>::=<NRf> is the negative peak frequency deviation in Hz.

**Examples** FETCH:FM:PNEGATIVE? might return -495.6E+3, indicating the negative peak frequency deviation is -495.6 kHz.

## FETCH:FM:PPOSitive? (Query Only)

Returns the positive peak frequency deviation (+Pk) in the FM measurement.

**Conditions** Measurement views: FM

**Group** Fetch commands

**Syntax** FETCH:FM:PPOSitive?

**Arguments** None

**Returns** <+Pk>::=<NRf> is the positive peak frequency deviation in Hz.



**Examples**     `FETCH:FM:PPOSITIVE?` might return `763.2E+3`, indicating the positive peak frequency deviation is 763.2 kHz.

## **FETCH:FM:PTPeak? (Query Only)**

Returns the peak-peak frequency deviation (Pk-Pk) in the FM measurement.

**Conditions**     Measurement views: FM

**Group**     Fetch commands

**Syntax**     `FETCH:FM:PTPeak?`

**Arguments**     None

**Returns**     `<Pk-Pk> ::= <NRf>` is the peak-peak frequency deviation in Hz.

**Examples**     `FETCH:FM:PTPEAK?` might return `1.258E+6`, indicating the peak-peak frequency deviation is 1.258 MHz.

## **FETCH:FM:RESult? (Query Only)**

Returns the FM measurement results.

**Conditions**     Measurement views: FM

**Group**     Fetch commands

**Syntax**     `FETCH:FM:RESult?`

**Arguments**     None

**Returns**     `<+Pk> , <-Pk> , <RMS> , <Pk-Pk> , <Pk-Pk/2>`

Where

`<+Pk> ::= <NRf>` is the positive peak frequency deviation in Hz.

`<-Pk> ::= <NRf>` is the negative peak frequency deviation in Hz.

<RMS>::=<NRf> is the RMS frequency deviation in Hz.  
<Pk-Pk>::=<NRf> is the peak-peak frequency deviation in Hz.  
<Pk-Pk/2>::=<NRf> is the half peak-peak frequency deviation in Hz.

**Examples**    FETCh:FM:RESULT? might return  
763.2E+3, -494.6E+3, 271.2E+3, 1.258E+6, 628.9E+3.

## FETCh:FM:RMS? (Query Only)

Returns the RMS frequency deviation in the FM measurement.

**Conditions**    Measurement views: FM

**Group**        Fetch commands

**Syntax**       FETCh:FM:RMS?

**Arguments**    None

**Returns**       <RMS>::=<NRf> is the RMS frequency deviation in Hz.

**Examples**    FETCh:FM:RMS? might return 271.2E+3, indicating the RMS frequency deviation is 271.2 kHz.

## FETCh:FVTime? (Query Only)

Returns the Frequency versus Time trace data.

**Conditions**    Measurement views: Frequency versus Time

**Group**        Fetch commands

**Syntax**       FETCh:FVTime?

**Arguments**    None

**Returns** #<num\_digit><num\_byte><data(1)><data(2)>...<data(n)>

Where

<num\_digit> is the number of digits in <num\_byte>.

<num\_byte> is the number of bytes of data that follow.

<data(n)> is the frequency in Hz at the n<sup>th</sup> data point, 4-byte little endian floating-point format specified in IEEE 488.2.

**Examples** FETCH:FVTIME? might return #3156xxxx... (156-byte data) for the Frequency versus Time trace.

## FETCh:FVTime:MAXimum? (Query Only)

Returns the maximum value in the Frequency versus Time measurement.

**Conditions** Measurement views: Frequency versus Time

**Group** Fetch commands

**Syntax** FETCh:FVTime:MAXimum?

**Related Commands** [FETCh:FVTime:MAXLocation?](#)

**Arguments** None

**Returns** <max> ::= <NRF> is the maximum frequency drift in Hz.

**Examples** FETCH:FVTIME:MAXIMUM? might return 2.625E+6, indicating the maximum frequency drift is 2.625 MHz.

## FETCh:FVTime:MAXLocation? (Query Only)

Returns the time at which the frequency drift is maximum.

**Conditions** Measurement views: Frequency versus Time

**Group** Fetch commands

**Syntax**     `FETCh:FVTime:MAXLocation?`

**Related Commands**     [FETCh:FVTime:MAXimum?](#)

**Arguments**     None

**Returns**     `<max_time>::=<NRf>` is the time in seconds at which the frequency drift is maximum.

**Examples**     `FETCh:FVTime:MAXLOCATION?` might return `25.03E-9`, indicating the frequency drift is maximum at 25.03 ns.

## FETCh:FVTime:MINimum? (Query Only)

Returns the minimum value in the Frequency versus Time measurement.

**Conditions**     Measurement views: Frequency versus Time

**Group**     Fetch commands

**Syntax**     `FETCh:FVTime:MINimum?`

**Related Commands**     [FETCh:FVTime:MINLocation?](#)

**Arguments**     None

**Returns**     `<min>::=<NRf>` is the minimum frequency drift in Hz.

**Examples**     `FETCh:FVTime:MINIMUM?` might return `-6.618E+6`, indicating the minimum frequency drift is -6.618 MHz.

## FETCh:FVTime:MINLocation? (Query Only)

Returns the time at which the frequency drift is minimum.

**Conditions**     Measurement views: Frequency versus Time

<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCH:FVTime:MINLocation?
<b>Related Commands</b>	<a href="#">FETCH:FVTime:MINimum?</a>
<b>Arguments</b>	None
<b>Returns</b>	<min_time> ::= <NRf> is the time in seconds at which the frequency drift is minimum.
<b>Examples</b>	FETCH:FVTIME:MINLOCATION? might return 450.7E-9, indicating the frequency drift is minimum at 450.7 ns.

## FETCH:FVTime:RESult? (Query Only)

Returns the Frequency versus Time measurement results.

<b>Conditions</b>	Measurement views: Frequency versus Time
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCH:FVTime:RESult?
<b>Arguments</b>	None
<b>Returns</b>	<max>, <max_time>, <min>, <min_time> Where <max> ::= <NRf> is the maximum frequency drift in Hz. <max_time> ::= <NRf> is the time in seconds at which the frequency drift is maximum. <min> ::= <NRf> is the minimum frequency drift in Hz. <min_time> ::= <NRf> is the time in seconds at which the frequency drift is minimum.
<b>Examples</b>	FETCH:FVTIME:RESULT? might return 2.625E+6, 25.03E-9, -6.618E+6, 450.7E-9, indicating

the maximum frequency drift is 2.625 MHz at 25.03 ns and the minimum frequency drift is -6.618 MHz at 450.7 ns.

## FETCh:IQVTime:I? (Query Only)

Returns the I versus Time trace data.

<b>Conditions</b>	Measurement views: RF I&Q versus Time
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCh:IQVTime:I?
<b>Arguments</b>	None
<b>Returns</b>	#<num_digit><num_byte><data(1)><data(2)>...<data(n)> Where <num_digit> is the number of digits in <num_byte>. <num_byte> is the number of bytes of data that follow. <data(n)> is the I level in volts at the n <sup>th</sup> data point, 4-byte little endian floating-point format specified in IEEE 488.2.
<b>Examples</b>	FETCh:IQVTime:I? might return #3160xxxx... (160-byte data) for the I versus Time trace.

## FETCh:IQVTime:MAXimum? (Query Only)

Returns the maximum value in the RF I&Q versus Time measurement.

<b>Conditions</b>	Measurement views: RF I&Q versus Time
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCh:IQVTime:MAXimum?
<b>Related Commands</b>	<a href="#">FETCh:IQVTime:MAXLocation?</a>

<b>Arguments</b>	None
<b>Returns</b>	<code>&lt;max&gt; ::= &lt;Nrf&gt;</code> is the maximum I or Q level in volts. Use the <a href="#">TRACe:IQVTime:SElect:I</a> or <a href="#">TRACe:IQVTime:SElect:Q</a> command to select the trace.
<b>Examples</b>	<code>FETCH:IQVTIME:MAXIMUM?</code> might return 1.214, indicating the maximum I or Q level is 1.214 V.

## FETCH:IQVTime:MAXLocation? (Query Only)

Returns the time at which the I or Q level is maximum.

<b>Conditions</b>	Measurement views: RF I&Q versus Time
<b>Group</b>	Fetch commands
<b>Syntax</b>	<code>FETCH:IQVTime:MAXLocation?</code>
<b>Related Commands</b>	<a href="#">FETCH:IQVTime:MAXimum?</a>
<b>Arguments</b>	None
<b>Returns</b>	<code>&lt;max_time&gt; ::= &lt;Nrf&gt;</code> is the time in seconds at which the I or Q level is maximum.
<b>Examples</b>	<code>FETCH:IQVTIME:MAXLOCATION?</code> might return 175.3E-9, indicating the I or Q level is maximum at 175.3 ns.

## FETCH:IQVTime:MINimum? (Query Only)

Returns the minimum value in the RF I&Q versus Time measurement.

<b>Conditions</b>	Measurement views: RF I&Q versus Time
<b>Group</b>	Fetch commands

**Syntax**     `FETCh:IQVTime:MINimum? imum`

**Related Commands**     [FETCh:IQVTime:MINLocation?](#)

**Arguments**     None

**Returns**     `<min>::=<Nrf>` is the minimum I or Q level in volts.  
 Use the [TRACe:IQVTime:SElect:I](#) or [TRACe:IQVTime:SElect:Q](#) command to select the trace.

**Examples**     `FETCh:IQVTime:MINimum?` might return `-370.5E-3`, indicating the minimum I or Q level is `-370.5 mV`.

## FETCh:IQVTime:MINLocation? (Query Only)

Returns the time at which the I or Q level is minimum.

**Conditions**     Measurement views: RF I&Q versus Time

**Group**     Fetch commands

**Syntax**     `FETCh:IQVTime:MINLocation?`

**Related Commands**     [FETCh:IQVTime:MINimum?](#)

**Arguments**     None

**Returns**     `<min_time>::=<Nrf>` is the time in seconds at which the I or Q level is minimum.

**Examples**     `FETCh:IQVTime:MINLOCATION?` might return `450.7E-9`, indicating the I or Q level is minimum at `450.7 ns`.

## FETCh:IQVTime:Q? (Query Only)

Returns the Q versus Time trace data.



<b>Conditions</b>	Measurement views: RF I&Q versus Time
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCh:IQVTime:Q?
<b>Arguments</b>	None
<b>Returns</b>	#<num_digit><num_byte><data(1)><data(2)>...<data(n)> Where <num_digit> is the number of digits in <num_byte>. <num_byte> is the number of bytes of data that follow. <data(n)> is the Q level in volts at the n <sup>th</sup> data point, 4-byte little endian floating-point format specified in IEEE 488.2.
<b>Examples</b>	FETCh:IQVTime:Q? might return #3160xxxx... (160-byte data) for the Q versus Time trace.

## FETCh:IQVTime:RESult? (Query Only)

Returns the RF I&Q versus Time measurement results.

<b>Conditions</b>	Measurement views: RF I&Q versus Time
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCh:IQVTime:RESult?
<b>Arguments</b>	None
<b>Returns</b>	<max>,<max_time>,<min>,<min_time> Where <max>::=<NRf> is the maximum I or Q level in volts. <max_time>::=<NRf> is the time in seconds at which the I or Q level is maximum. <min>::=<NRf> is the minimum I or Q level in volts.

`<min_time>::=<NRF>` is the time in seconds at which the I or Q level is minimum.

Use the [TRACe:IQVTime:SElect:I](#) or [TRACe:IQVTime:SElect:Q](#) command to select the trace.

**Examples**     `FETCH:IQVTIME:RESULT?` might return  
 1.214, 175.3E-9, -370.5E-3, 450.7E-9, indicating  
 the maximum I or Q level is 1.214 V at 175.3 ns and  
 the minimum I or Q level is -370.5 mV at 450.7 ns.

## FETCh:MCPower:ADJacent:CHANnels? (Query Only)

Returns the power of adjacent channels in order of increasing frequency.

**Conditions**     Measurement views: MCPR

**Group**     Fetch commands

**Syntax**     `FETCh:MCPower:ADJacent:CHANnels?`

**Arguments**     None

**Returns**     `<acpr_lower(n)>, ... <acpr_lower(2)>, <acpr_lower(1)>, <acpr_upper(1)>, <acpr_upper(2)>, ... <acpr_upper(n)>`

Where

`<acpr_lower(n)>` is the ACPR for the lower channel #n in dB.

`<acpr_upper(n)>` is the ACPR for the upper channel #n in dB.

To add a pair of upper and lower adjacent channels, use the [\[SENSe\]:MCPower:CHANnel:ADJacent:ADD](#) command.

**Examples**     `FETCH:MCPOWER:ADJACENT:CHANNELS?` might return  
 -4.420, -4.847, -4.316, -4.225, indicating  
 (ACPR for the lower channel 2) = -4.420 dB,  
 (ACPR for the lower channel 1) = -4.847 dB,  
 (ACPR for the upper channel 1) = -4.316 dB, and  
 (ACPR for the upper channel 2) = -4.225 dB.

## FETCh:MCPower:CHANnel:POWer? (Query Only)

Returns the reference power in the MCPR measurement.

**Conditions** Measurement views: MCPR

**Group** Fetch commands

**Syntax** FETCh:MCPower:CHANnel:POWer?

**Arguments** None

**Returns** <ref\_power>:<Nrf> is the reference power in dBm.  
The unit can be changed by the [\[SENSE\]:POWER:UNITs](#) command.  
To select the power reference, use the [\[SENSE\]:MCPower:RCHannels?](#) commands.

**Examples** FETCh:MCPOWER:CHANNEL:POWER? might return 4.227, indicating that the reference power is 4.227 dBm.

## FETCh:MCPower:MAIN:CHANnels? (Query Only)

Returns the power of main channels in order of increasing frequency.

**Conditions** Measurement views: MCPR

**Group** Fetch commands

**Syntax** FETCh:MCPower:MAIN:CHANnels?

**Arguments** None

**Returns** <power\_main(1)>,<power\_main(2)>,...<power\_main(n)>

Where  
<power\_main(n)> is the power of main channel #n in dBm.  
The unit can be changed by the [\[SENSE\]:POWER:UNITs](#) command.

To specify the main channels, use the [SENSE]:MCPower:CHANnel:MAIN commands.

**Examples**     FETCH:MCPOWER:MAIN:CHANNELS? might return  
-2.420, -2.847, -2.316, -2.225, indicating  
(power of the main channel 1) = -2.420 dBm,  
(power of the main channel 2) = -2.847 dBm,  
(power of the main channel 3) = -2.316 dBm, and  
(power of the main channel 4) = -2.225 dBm.

## FETCH:MCPower:SPECTrum? (Query Only)

Returns spectrum trace data of the MCPR measurement.

**Conditions**     Measurement views: MCPR

**Group**            Fetch commands

**Syntax**            FETCH:MCPower:SPECTrum?

**Arguments**        None

**Returns**            #<num\_digit><num\_byte><data(1)><data(2)>...<data(n)>

Where

<num\_digit> is the number of digits in <num\_byte>.

<num\_byte> is the number of bytes of data that follow.

<data(n)> is the amplitude in dBm at the n<sup>th</sup> data point,

4-byte little endian floating-point format specified in IEEE 488.2.

The unit can be changed by the [SENSE]:POWER:UNITs command.

**Examples**     FETCH:MCPOWER:SPECTRUM? might return #43204xxxx... (3204-byte data)  
for the spectrum trace data of the MCPR measurement.

## FETCH:MERRor:FERRor? (Query Only)

Returns the frequency error in the Magnitude error versus Time measurement.

**Conditions**        Measurement views: Magnitude error versus Time

---

<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCh:MERRor:FERRor?
<b>Arguments</b>	None
<b>Returns</b>	<freq_error> ::= <NRf> is the frequency error in Hz.
<b>Examples</b>	FETCh:MERRor:FERRor? might return -10.7E+3, indicating the frequency error is -10.7 kHz.

### FETCh:MERRor:PEAK? (Query Only)

Returns the peak value in the Magnitude error versus Time measurement.

<b>Conditions</b>	Measurement views: Magnitude error versus Time
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCh:MERRor:PEAK?
<b>Related Commands</b>	<a href="#">FETCh:MERRor:PINDex?</a>
<b>Arguments</b>	None
<b>Returns</b>	<peak> ::= <NRf> is the peak magnitude error in percent (%).
<b>Examples</b>	FETCh:MERRor:PEAK? might return 1.57, indicating the peak magnitude error is 1.57%.

### FETCh:MERRor:PINDex? (Query Only)

Returns the time at the magnitude error peak.

<b>Conditions</b>	Measurement views: Magnitude error versus Time
-------------------	--

<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCh:MERRor:PINDEx?
<b>Related Commands</b>	<a href="#">FETCh:MERRor:PEAK?</a>
<b>Arguments</b>	None
<b>Returns</b>	<peak_time>::=<Nrf> is the time at the magnitude error peak in symbol number. The unit can be changed by the <a href="#">[SENSe]:DDEMod:TIME:UNITs</a> command.
<b>Examples</b>	FETCh:MERRor:PINDEx? might return 68.000, indicating that the magnitude error peak is at symbol #68.

## FETCh:MERRor:RMS? (Query Only)

Returns the RMS (Root-Mean-Square) value in the Magnitude error versus Time measurement.

<b>Conditions</b>	Measurement views: Magnitude error versus Time
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCh:MERRor:RMS?
<b>Arguments</b>	None
<b>Returns</b>	<rms>::=<Nrf> is the RMS magnitude error in percent (%).
<b>Examples</b>	FETCh:MERRor:RMS? might return 0.382, indicating the magnitude error is 0.382% RMS.

## FETCh:MERRor:TRACe? (Query Only)

Returns the Magnitude error versus Time trace data.

<b>Conditions</b>	Measurement views: Magnitude error versus Time
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCH:MERROR:TRACE?
<b>Arguments</b>	None
<b>Returns</b>	#<num_digit><num_byte><data(1)><data(2)>...<data(n)> Where <num_digit> is the number of digits in <num_byte>. <num_byte> is the number of bytes of data that follow. <data(n)> is the magnitude error in percent (%) at the n <sup>th</sup> data point, 4-byte little endian floating-point format specified in IEEE 488.2.
<b>Examples</b>	FETCH:MERROR:TRACE? might return #42036xxxx... (2036-byte data) for the Magnitude error versus Time trace.

## FETCH:OBWidth:FREQUENCY:ERROR? (Query Only)

Returns the frequency error in the Occupied Bandwidth measurement.

<b>Conditions</b>	Measurement views: Occupied Bandwidth
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCH:OBWidth:FREQUENCY:ERROR?
<b>Arguments</b>	None
<b>Returns</b>	<freq_error> ::= <Nrf> is the frequency error in Hz.
<b>Examples</b>	FETCH:OBWidth:FREQUENCY:ERROR? might return -10.7E+3, indicating the frequency error is -10.7 kHz.

## FETCh:OBWidth:OBWidth:BANDwidth? (Query Only)

Returns the occupied bandwidth in the Occupied Bandwidth measurement.

**Conditions** Measurement views: Occupied Bandwidth

**Group** Fetch commands

**Syntax** FETCh:OBwidth:OBwidth:BANDwidth?

**Arguments** None

**Returns** <OBW>::=<NRf> is the occupied bandwidth in Hz.

**Examples** FETCh:OBWIDTH:OBWIDTH:BANDWIDTH? might return 4.0E+6, indicating the occupied bandwidth is 4 MHz.

## FETCh:OBWidth:OBWidth:LEFT:FREQuency? (Query Only)

Returns the left (lower) frequency of the occupied bandwidth.

**Conditions** Measurement views: Occupied Bandwidth

**Group** Fetch commands

**Syntax** FETCh:OBwidth:OBwidth:LEFT:FREQuency?

**Related Commands** [FETCh:OBWidth:OBWidth:RIGHT:FREQuency?](#)

**Arguments** None

**Returns** <OBW\_left\_freq>::=<NRf> is the left frequency in Hz.

**Examples** FETCh:OBWIDTH:OBWIDTH:LEFT:FREQUENCY? might return 1.498E+9, indicating the left frequency is 1.498 GHz.



## FETCh:OBWidth:OBWidth:LEFT:LEVel? (Query Only)

Returns the level at the left frequency of the occupied bandwidth.

**Conditions** Measurement views: Occupied Bandwidth

**Group** Fetch commands

**Syntax** FETCh:OBwidth:OBwidth:LEFT:LEVel?

**Related Commands** [FETCh:OBWidth:OBWidth:RIGHT:LEVel?](#)

**Arguments** None

**Returns** <OBW\_left\_level>::=<NRf> is the level at the left frequency in dB.

**Examples** FETCh:OBWIDTH:OBWIDTH:LEFT:LEVEL? might return -23.5, indicating the level at the left frequency is -23.5 dB.

## FETCh:OBWidth:OBWidth:POWer? (Query Only)

Returns the reference power in the Occupied Bandwidth measurement.

**Conditions** Measurement views: Occupied Bandwidth

**Group** Fetch commands

**Syntax** FETCh:OBwidth:OBwidth:POWer?

**Arguments** None

**Returns** <OBW\_ref\_power>::=<NRf> is the reference power in dBm.  
The unit can be changed by the [\[SENSe\]:POWer:UNITs](#) command.

**Examples** FETCh:OBWIDTH:OBWIDTH:POWER? might return -10.0, indicating the reference power is -10 dBm.

## FETCh:OBWidth:OBWidth:RIGHT:FREQuency? (Query Only)

Returns the right (higher) frequency of the occupied bandwidth.

**Conditions** Measurement views: Occupied Bandwidth

**Group** Fetch commands

**Syntax** FETCh:OBwidth:OBwidth:RIGHT:FREquency?

**Related Commands** [FETCh:OBWidth:OBWidth:LEFT:FREQuency?](#)

**Arguments** None

**Returns** <OB\_right\_freq>::=<Nrf> is the right frequency in Hz.

**Examples** FETCh:OBWIDTH:OBWIDTH:RIGHT:FREQUENCY? might return 1.502E+9, indicating the right frequency is 1.502 GHz.

## FETCh:OBWidth:OBWidth:RIGHT:LEVel? (Query Only)

Returns the level at the right frequency of the occupied bandwidth.

**Conditions** Measurement views: Occupied Bandwidth

**Group** Fetch commands

**Syntax** FETCh:OBwidth:OBwidth:RIGHT:LEVel?

**Related Commands** [FETCh:OBWidth:OBWidth:LEFT:LEVel?](#)

**Arguments** None

**Returns** <OB\_right\_level>::=<Nrf> is the level at the right frequency in dB.

**Examples**    `FETCH:OBWIDTH:OBWIDTH:RIGHT:LEVEL?` might return `-23.5`, indicating the level at the right frequency is `-23.5` dB.

## FETCh:OBWidth:SPECTrum? (Query Only)

Returns spectrum trace data of the Occupied Bandwidth measurement.

**Conditions**    Measurement views: Occupied Bandwidth

**Group**        Fetch commands

**Syntax**       `FETCh:OBwidth:SPECTrum?`

**Arguments**    None

**Returns**       `#<num_digit><num_byte><data(1)><data(2)>...<data(n)>`

Where

`<num_digit>` is the number of digits in `<num_byte>`.

`<num_byte>` is the number of bytes of data that follow.

`<data(n)>` is the amplitude in dBm at the  $n^{\text{th}}$  data point, 4-byte little endian floating-point format specified in IEEE 488.2.

The unit can be changed by the [\[SENSE\]:POWER:UNITS](#) command.

**Examples**    `FETCH:OBWIDTH:SPECTRUM?` might return `#43204xxxx...` (3204-byte data) for the spectrum trace data of the Occupied Bandwidth measurement.

## FETCh:OBWidth:XDBBandwidth:BANDwidth? (Query Only)

Returns the x dB bandwidth in the Occupied Bandwidth measurement.

**Conditions**    Measurement views: Occupied Bandwidth

**Group**        Fetch commands

**Syntax**       `FETCh:OBwidth:XDBBandwidth:BANDwidth?`

**Arguments**    None

**Returns** <xdbbw>::=<Nrf> is the x dB bandwidth in Hz.

**Examples** FETCH:OBWIDTH:XDBBANDWIDTH:BANDWIDTH? might return 2.0E+6, indicating the x dB bandwidth is 2 MHz.

## FETCH:OBWidth:XDBBandwidth:LEFT:FREQUENCY? (Query Only)

Returns the left (lower) frequency of the x dB bandwidth.

**Conditions** Measurement views: Occupied Bandwidth

**Group** Fetch commands

**Syntax** FETCH:OBwidth:XDBBandwidth:LEFT:FREQUENCY?

**Related Commands** [FETCH:OBWidth:XDBBandwidth:RIGHT:FREQUENCY?](#)

**Arguments** None

**Returns** <xdbbw\_left\_freq>::=<Nrf> is the left frequency in Hz.

**Examples** FETCH:OBWIDTH:XDBBANDWIDTH:LEFT:FREQUENCY? might return 1.498E+9, indicating the left frequency is 1.498 GHz.

## FETCH:OBWidth:XDBBandwidth:LEFT:LEVEL? (Query Only)

Returns the level at the left frequency of the x dB bandwidth.

**Conditions** Measurement views: Occupied Bandwidth

**Group** Fetch commands

**Syntax** FETCH:OBwidth:XDBBandwidth:LEFT:LEVEL?

**Related Commands** [FETCH:OBWidth:XDBBandwidth:RIGHT:LEVEL?](#)

<b>Arguments</b>	None
<b>Returns</b>	<xdBW_left_level>::=<Nrf> is the level at the left frequency in dB.
<b>Examples</b>	FETCH:OBWIDTH:XDBBANDWIDTH:LEFT:LEVEL? might return -23.5, indicating the level at the left frequency is -23.5 dB.

## FETCH:OBWidth:XDBBandwidth:POWER? (Query Only)

Returns the reference power in the x dB bandwidth measurement.

<b>Conditions</b>	Measurement views: Occupied Bandwidth
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCH:OBwidth:XDBBandwidth:POWER?
<b>Arguments</b>	None
<b>Returns</b>	<xdBW_ref_power>::=<Nrf> is the reference power in dBm. The unit can be changed by the <a href="#">[SENSe]:POWER:UNITs</a> command.
<b>Examples</b>	FETCH:OBWIDTH:XDBBANDWIDTH:POWER? might return -10.0, indicating the reference power is -10 dBm.

## FETCH:OBWidth:XDBBandwidth:RIGHT:FREQUENCY? (Query Only)

Returns the right (higher) frequency of the x dB bandwidth.

<b>Conditions</b>	Measurement views: Occupied Bandwidth
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCH:OBwidth:XDBBandwidth:RIGHT:FREQUENCY?

**Related Commands** [FETCH:OBWidth:XDBBandwidth:LEFT:FREQUENCY?](#)

<b>Arguments</b>	None
<b>Returns</b>	<xdbbw_right_freq>::=<Nrf> is the right frequency in Hz.
<b>Examples</b>	FETCH:OBWIDTH:XDBBANDWIDTH:RIGHT:FREQUENCY? might return 1.502E+9, indicating the right frequency is 1.502 GHz.

## FETCH:OBWidth:XDBBandwidth:RIGHT:LEVEL? (Query Only)

Returns the level at the right frequency of the x dB bandwidth.

<b>Conditions</b>	Measurement views: Occupied Bandwidth
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCH:OBwidth:XDBBandwidth:RIGHT:LEVEL?
<b>Related Commands</b>	<a href="#">FETCH:OBWidth:XDBBandwidth:LEFT:LEVEL?</a>
<b>Arguments</b>	None
<b>Returns</b>	<xdbbw_right_level>::=<Nrf> is the level at the right frequency in dB.
<b>Examples</b>	FETCH:OBWIDTH:XDBBANDWIDTH:RIGHT:LEVEL? might return -23.5, indicating the level at the right frequency is -23.5 dB.

## FETCH:PERRor:FERRor? (Query Only)

Returns the frequency error in the Phase error versus Time measurement.

<b>Conditions</b>	Measurement views: Phase error versus Time
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCH:PERRor:FERRor?

<b>Arguments</b>	None
<b>Returns</b>	<freq_error> ::= <NRf> is the frequency error in Hz.
<b>Examples</b>	FETCH:ERROR:FERROR? might return -10.7E+3, indicating the frequency error is -10.7 kHz.

## FETCH:PERRor:PEAK? (Query Only)

Returns the peak value in the Phase error versus Time measurement.

<b>Conditions</b>	Measurement views: Phase error versus Time
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCH:PERRor:PEAK?

**Related Commands** [FETCH:PERRor:PINDEX?](#)

<b>Arguments</b>	None
<b>Returns</b>	<peak> ::= <NRf> is the peak phase error in degrees.
<b>Examples</b>	FETCH:PERRor:PEAK? might return 0.683, indicating the peak phase error is 0.683 °.

## FETCH:PERRor:PINDEX? (Query Only)

Returns the time at the phase error peak.

<b>Conditions</b>	Measurement views: Phase error versus Time
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCH:PERRor:PINDEX?

<b>Related Commands</b>	<a href="#">FETCh:PERRor:PEAK?</a> , <a href="#">[SENSe]:DDEMod:TIME:UNITs</a>
<b>Arguments</b>	None
<b>Returns</b>	<peak_time>::=<Nrf> is the time at the phase error peak in symbol number. The unit can be changed by the <a href="#">[SENSe]:DDEMod:TIME:UNITs</a> command.
<b>Examples</b>	FETCh:PERRor:PINDEX? might return 68.000, indicating that the phase error peak is at symbol #68.

## FETCh:PERRor:RMS? (Query Only)

Returns the RMS (Root-Mean-Square) value in the Phase error versus Time measurement.

<b>Conditions</b>	Measurement views: Phase error versus Time
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCh:PERRor:RMS?
<b>Arguments</b>	None
<b>Returns</b>	<rms>::=<Nrf> is the RMS phase error in degrees.
<b>Examples</b>	FETCh:PERRor:RMS? might return 0.746, indicating the phase error is 0.746 ° RMS.

## FETCh:PERRor:TRACe? (Query Only)

Returns the Phase error versus Time trace data.

<b>Conditions</b>	Measurement views: Phase error versus Time
<b>Group</b>	Fetch commands



---

<b>Syntax</b>	<code>FETCh:PERRor:TRACe?</code>
<b>Arguments</b>	None
<b>Returns</b>	<code>#&lt;num_digit&gt;&lt;num_byte&gt;&lt;data(1)&gt;&lt;data(2)&gt;...&lt;data(n)&gt;</code> Where <code>&lt;num_digit&gt;</code> is the number of digits in <code>&lt;num_byte&gt;</code> . <code>&lt;num_byte&gt;</code> is the number of bytes of data that follow. <code>&lt;data(n)&gt;</code> is the phase error in degrees at the $n^{\text{th}}$ data point, 4-byte little endian floating-point format specified in IEEE 488.2.
<b>Examples</b>	<code>FETCh:PERRor:TRACe?</code> might return <code>#42036xxxx...</code> (2036-byte data) for the Phase error versus Time trace.

## FETCh:PHVTime? (Query Only)

Returns the Phase versus Time trace data.

<b>Conditions</b>	Measurement views: Phase versus Time
<b>Group</b>	Fetch commands
<b>Syntax</b>	<code>FETCh:PHVTime?</code>
<b>Arguments</b>	None
<b>Returns</b>	<code>#&lt;num_digit&gt;&lt;num_byte&gt;&lt;data(1)&gt;&lt;data(2)&gt;...&lt;data(n)&gt;</code> Where <code>&lt;num_digit&gt;</code> is the number of digits in <code>&lt;num_byte&gt;</code> . <code>&lt;num_byte&gt;</code> is the number of bytes of data that follow. <code>&lt;data(n)&gt;</code> is the phase in degrees at the $n^{\text{th}}$ data point, 4-byte little endian floating-point format specified in IEEE 488.2.
<b>Examples</b>	<code>FETCh:PHVTime?</code> might return <code>#3160xxxx...</code> (160-byte data) for the Phase versus Time trace.

## FETCh:PHVTime:MAXimum? (Query Only)

Returns the maximum value in the Phase versus Time measurement.

**Conditions** Measurement views: Phase versus Time

**Group** Fetch commands

**Syntax** FETCh:PHVTime:MAXimum?

**Related Commands** [FETCh:PHVTime:MAXLocation?](#)

**Arguments** None

**Returns** <max>::=<NRF> is the maximum phase in degrees.

**Examples** FETCh:PHVTime:MAXimum? might return 153.8, indicating the maximum phase is 153.8 °.

## FETCh:PHVTime:MAXLocation? (Query Only)

Returns the time at which the phase is maximum.

**Conditions** Measurement views: Phase versus Time

**Group** Fetch commands

**Syntax** FETCh:PHVTime:MAXLocation?

**Related Commands** [FETCh:PHVTime:MAXimum?](#)

**Arguments** None

**Returns** <max\_time>::=<NRF> is the time in seconds at which the phase is maximum.

**Examples**     `FETCH:PHVTIME:MAXLOCATION?` might return `175.3E-9`, indicating the I or Q level is maximum at 175.3 ns.

## **FETCH:PHVTime:MINimum? (Query Only)**

Returns the minimum value in the Phase versus Time measurement.

**Conditions**     Measurement views: Phase versus Time

**Group**     Fetch commands

**Syntax**     `FETCH:PHVTime:MINimum?`

**Related Commands**     [FETCH:PHVTime:MINLocation?](#)

**Arguments**     None

**Returns**     `<min> ::= <Nrf>` is the minimum phase in degrees.

**Examples**     `FETCH:PHVTIME:MINIMUM?` might return `-176.3`, indicating the minimum phase is `-176.3 °`.

## **FETCH:PHVTime:MINLocation? (Query Only)**

Returns the time at which the phase is minimum.

**Conditions**     Measurement views: Phase versus Time

**Group**     Fetch commands

**Syntax**     `FETCH:PHVTime:MINLocation?`

**Related Commands**     [FETCH:PHVTime:MINimum?](#)

**Arguments**     None

**Returns** <min\_time>::=<Nrf> is the time in seconds at which the phase is minimum.

**Examples** FETCH:PHVTIME:MINLOCATION? might return 450.7E-9, indicating the phase is minimum at 450.7 ns.

## FETCh:PHVTime:RESult? (Query Only)

Returns the Phase versus Time measurement results.

**Conditions** Measurement views: Phase versus Time

**Group** Fetch commands

**Syntax** FETCh:PHVTime:RESult?

**Arguments** None

**Returns** <max>, <max\_time>, <min>, <min\_time>

Where

<max>::=<Nrf> is the maximum phase in degrees.

<max\_time>::=<Nrf> is the time in seconds at which the phase is maximum.

<min>::=<Nrf> is the minimum phase in degrees.

<min\_time>::=<Nrf> is the time in seconds at which the phase is minimum.

**Examples** FETCH:PHVTIME:RESULT? might return 153.8, 175.3E-9, -176.3, 450.7E-9, indicating the maximum phase is 153.8 ° at 175.3 ns and the minimum phase is -176.3 ° at 450.7 ns.

## FETCh:PM:PNEGative? (Query Only)

Returns the negative peak phase deviation (-Pk) in the PM measurement.

**Conditions** Measurement views: PM

**Group** Fetch commands

**Syntax** FETCh:PM:PNEGative?

<b>Arguments</b>	None
<b>Returns</b>	<-Pk> ::= <NRf> is the negative peak phase deviation in degrees.
<b>Examples</b>	FETCH:PM:PNEGATIVE? might return -23.42, indicating the positive peak phase deviation is -23.42 °.

### FETCH:PM:PPOSitive? (Query Only)

Returns the positive peak phase deviation (+Pk) in the PM measurement.

<b>Conditions</b>	Measurement views: PM
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCH:PM:PPOSitive?
<b>Arguments</b>	None
<b>Returns</b>	<+Pk> ::= <NRf> is the positive peak phase deviation in degrees.
<b>Examples</b>	FETCH:PM:PPOSITIVE? might return 26.87, indicating the positive peak phase deviation is 26.87 °.

### FETCH:PM:PTPeak? (Query Only)

Returns the peak-peak phase deviation (Pk-Pk) in the PM measurement.

<b>Conditions</b>	Measurement views: PM
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCH:PM:PTPeak?
<b>Arguments</b>	None

**Returns** <Pk-Pk> ::= <NRf> is the peak-peak phase deviation in degrees.

**Examples** FETCH:PM:PTPEAK? might return 46.34, indicating the peak-peak phase deviation is 46.34 °.

## FETCh:PM:RESult? (Query Only)

Returns the PM measurement results.

**Conditions** Measurement views: PM

**Group** Fetch commands

**Syntax** FETCh:PM:RESuLt?

**Arguments** None

**Returns** <+Pk>, <-Pk>, <RMS>, <Pk-Pk>

Where

<+Pk> ::= <NRf> is the positive peak phase deviation in degrees.

<-Pk> ::= <NRf> is the negative peak phase deviation in degrees.

<RMS> ::= <NRf> is the RMS phase deviation in degrees.

<Pk-Pk> ::= <NRf> is the peak-peak phase deviation in degrees.

**Examples** FETCH:PM:RESULT? might return 22.89, -23.45, 15.12, 46.34.

## FETCh:PM:RMS? (Query Only)

Returns the RMS phase deviation in the PM measurement.

**Conditions** Measurement views: PM

**Group** Fetch commands

**Syntax** FETCh:PM:RMS?

<b>Arguments</b>	None
<b>Returns</b>	<RMS> ::= <NRf> is the RMS phase deviation in degrees.
<b>Examples</b>	FETCH:PM:RMS? might return 15.12, indicating the RMS frequency deviation is 15.12 °.

## FETCh:PNOise:ALL? (Query Only)

Returns all results of the phase noise measurement.

<b>Conditions</b>	Measurement views: Phase noise
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCh:PNOise:ALL?
<b>Arguments</b>	None
<b>Returns</b>	<Cpower>, <Ferror>, <Pnoise>, <Tjitter>, <Rjitter>, <RFM> Where <Cpower> ::= <NRf> is the carrier power in dBm. <Ferror> ::= <NRf> is the frequency error in Hz. <Pnoise> ::= <NRf> is the RMS phase noise in degrees. <Tjitter> ::= <NRf> is the total jitter in seconds. <Rjitter> ::= <NRf> is the random jitter in seconds. <RFM> ::= <NRf> is the residual FM in Hz.
<b>Examples</b>	FETCH:PNOISE:ALL? might return -9.455, 1.235E+6, 51.43, 2.312E-9, 4.178E-9, 14.58, indicating Carrier power: -9.455 dBm, Frequency error: 1.235 MHz, RMS phase noise: 51.43 °, Total jitter: 2.312 ns, Random jitter: 4.178 ns, and Residual FM: 14.58 Hz.

## **FETCh:PNOise:CARRier:FERRor? (Query Only)**

Returns the carrier frequency error in the phase noise measurement.

**Conditions** Measurement views: Phase noise

**Group** Fetch commands

**Syntax** FETCh:PNOise:CARRier:FERRor?

**Arguments** None

**Returns** <NRF> Carrier frequency error in Hz.

**Examples** FETCh:PNOISE:CARRIER:FERROR? might return 1.235E+6, indicating that the carrier frequency error is 1.235 MHz.

## **FETCh:PNOise:CARRier:POWer? (Query Only)**

Returns the carrier power in the phase noise measurement.

**Conditions** Measurement views: Phase noise

**Group** Fetch commands

**Syntax** FETCh:PNOise:CARRier:POWer?

**Arguments** None

**Returns** <NRF> Carrier power in dBm.  
The unit can be changed by the [\[SENSe\]:POWer:UNITs](#) command.

**Examples** FETCh:PNOISE:CARRIER:POWER? might return -9.455, indicating that the carrier power is -9.455 dBm.



## FETCH:PNOise:JITTer? (Query Only)

Returns the jitter in the phase noise measurement.

**Conditions** Measurement views: Phase noise

**Group** Fetch commands

**Syntax** FETCH:PNOise:JITTer?

**Arguments** None

**Returns** <NRf> Jitter in seconds.

**Examples** FETCH:PNOISE:JITTER? might return 2.312E-9, indicating that the jitter is 2.312 ns.

## FETCH:PNOise:RESidual:FM? (Query Only)

Returns the residual FM in the phase noise measurement.

**Conditions** Measurement views: Phase noise

**Group** Fetch commands

**Syntax** FETCH:PNOise:RESidual:FM?

**Arguments** None

**Returns** <NRf> Residual FM in Hz.

**Examples** FETCH:PNOISE:RESIDUAL:FM? might return 14.58, indicating that the residual FM is 14.58 Hz.

## FETCh:PNOise:RMS:PNOise? (Query Only)

Returns the RMS phase noise in the phase noise measurement.

<b>Conditions</b>	Measurement views: Phase noise
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCh:PNOise:RMS:PNOise?
<b>Arguments</b>	None
<b>Returns</b>	<NRF> RMS phase noise in degrees.
<b>Examples</b>	FETCh:PNOISE:RMS:PNOISE? might return 51.43, indicating that the RMS phase noise is 51.43 °.

## FETCh:PNOise:SPECTrum<x>:X? (Query Only)

Returns the frequencies of the specified trace.

The parameter <x> = 1 and 2, representing Trace 1 and Trace 2, respectively.

<b>Conditions</b>	Measurement views: Phase noise
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCh:PNOise:SPECTrum<x>:X?
<b>Arguments</b>	None
<b>Returns</b>	#<num_digit><num_byte><x(1)><x(2)>...<x(n)> Where <num_digit> is the number of digits in <num_byte>. <num_byte> is the number of bytes of data that follow. <x(n)> is the frequency (Hz) at the n <sup>th</sup> data point, 4-byte little endian floating-point format specified in IEEE 488.2.

**Examples**    `FETCH:PNOISE:SPECTRUM1:X?` might return `#516020xxxx...` (16020-byte data) for the frequencies of Trace 1.

## **FETCH:PNOise:SPECTrum<x>:XY? (Query Only)**

Returns the frequency and phase noise pairs of the specified trace.

The parameter `<x>` = 1 and 2, representing Trace 1 and Trace 2, respectively.

**Conditions**    Measurement views: Phase noise

**Group**        Fetch commands

**Syntax**       `FETCH:PNOise:SPECTrum<x>:XY?`

**Arguments**    None

**Returns**       `#<num_digit><num_byte><x(1)><y(1)><x(2)><y(2)>...<x(n)><y(n)>`

Where

`<num_digit>` is the number of digits in `<num_byte>`.

`<num_byte>` is the number of bytes of data that follow.

`<x(n)><y(n)>` is the frequency (Hz) and phase noise (dBc/Hz) pair at the  $n^{\text{th}}$  data point, 4-byte little endian floating-point format specified in IEEE 488.2.

**Examples**    `FETCH:PNOISE:SPECTRUM1:XY?` might return `#516020xxxx...` (16020-byte data) for the frequency and phase noise pairs of the Trace 1.

## **FETCH:PNOise:SPECTrum<x>[:Y]? (Query Only)**

Returns the phase noise values of the specified trace.

The parameter `<x>` = 1 and 2, representing Trace 1 and Trace 2, respectively.

**Conditions**    Measurement views: Phase noise

**Group**        Fetch commands

**Syntax**       `FETCH:PNOise:SPECTrum<x>[:Y]?`

<b>Arguments</b>	None
<b>Returns</b>	<code>#&lt;num_digit&gt;&lt;num_byte&gt;&lt;y(1)&gt;&lt;y(2)&gt;...&lt;y(n)&gt;</code> Where <code>&lt;num_digit&gt;</code> is the number of digits in <code>&lt;num_byte&gt;</code> . <code>&lt;num_byte&gt;</code> is the number of bytes of data that follow. <code>&lt;y(n)&gt;</code> is the phase noise (dBc/Hz) at the $n^{\text{th}}$ data point, 4-byte little endian floating-point format specified in IEEE 488.2.
<b>Examples</b>	<code>FETCH:PNOISE:SPECTRUM1:Y</code> might return <code>#516020xxxx...</code> (16020-byte data) for the phase noise values of Trace 1.

## FETCH:PULSe[:RESult]:ATX? (Query Only)

Returns the average transmitted power in the pulse table.

<b>Conditions</b>	Measurement views: Pulse table
<b>Group</b>	Fetch commands
<b>Syntax</b>	<code>FETCH:PULSe[:RESult]:ATX?</code>
<b>Arguments</b>	None
<b>Returns</b>	<code>&lt;first_pulse_num&gt;,&lt;ATX(1)&gt;,&lt; ATX(2)&gt;,...&lt;ATX(n)&gt;</code> Where <code>&lt;first_pulse_num&gt;::=&lt;NR1&gt;</code> is the first pulse number. <code>&lt;ATX(n)&gt;::=&lt;NRf&gt;</code> is the average transmitted power for the pulse with the number of <code>[first_pulse_num + n - 1]</code> in dBm. The unit can be changed to watts by the <a href="#">[SENSe]:POWer:UNITs</a> command. Volt is invalid in the average transmitted power measurement.
<b>Examples</b>	<code>FETCH:PULSE:RESULT:ATX?</code> might return <code>0,-18.57,-18.73,-18.20,-18.53</code> for Pulse 0 to 3.

## FETCH:PULSe[:RESult]:AVERage? (Query Only)

Returns the average on power in the pulse table.

<b>Conditions</b>	Measurement views: Pulse table
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCH:PULSE[:RESULT]:AVERAGE?
<b>Arguments</b>	None
<b>Returns</b>	<p>&lt;first_pulse_num&gt;,&lt; avg(1)&gt;,&lt; avg(2)&gt;,...&lt;avg(n)&gt;</p> <p>Where            &lt;first_pulse_num&gt;::=&lt;NR1&gt; is the first pulse number.            &lt;avg(n)&gt;::=&lt;NRf&gt; is the average on power for the pulse with the number of [first_pulse_num + n - 1] in dBm.            The unit can be changed by the <a href="#">[SENSe]:POWer:UNITs</a> command.</p>
<b>Examples</b>	<p>FETCH:PULSE:RESULT:AVERAGE? might return            0,-2.354,-2.368,-2.343,-2.358 for Pulse 0 to 3.</p>

## FETCH:PULSE[:RESULT]:DROOP? (Query Only)

Returns the droop in the pulse table.

<b>Conditions</b>	Measurement views: Pulse table
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCH:PULSE[:RESULT]:DROOP?
<b>Arguments</b>	None
<b>Returns</b>	<p>&lt;first_pulse_num&gt;,&lt;droop(1)&gt;,&lt;droop(2)&gt;,...&lt;droop(n)&gt;</p> <p>Where            &lt;first_pulse_num&gt;::=&lt;NR1&gt; is the first pulse number.            &lt;droop(n)&gt;::=&lt;NRf&gt; is the wattage droop for the pulse with the number of [first_pulse_num + n - 1] in percent (%).</p>

**Examples**     `FETCH:PULSE:RESULT:DROOP?` might return 0, -270.9E-3, -193.0E-3, -242.7E-3, -177.5E-3 for Pulse 0 to 3.

## **FETCH:PULSe[:RESUlt]:DUTPct? (Query Only)**

Returns the duty factor (%) in the pulse table.

**Conditions**     Measurement views: Pulse table

**Group**            Fetch commands

**Syntax**          `FETCH:PULSe[:RESUlt]:DUTPct?`

**Arguments**      None

**Returns**          `<first_pulse_num>, <duty_pct(1)>, <duty_pct(2)>, ...`  
`<duty_pct(n)>`

Where

`<first_pulse_num> ::= <NR1>` is the first pulse number.

`<duty_pct(n)> ::= <NRf>` is the duty factor for the pulse with the number of `[first_pulse_num + n - 1]` in percent (%).

**Examples**     `FETCH:PULSE:RESULT:DUTPCT?` might return 0, 28.94, 28.96, 29.00, 29.01 for Pulse 0 to 3.

## **FETCH:PULSe[:RESUlt]:DUTRatio? (Query Only)**

Returns the duty factor (ratio) in the pulse table.

**Conditions**     Measurement views: Pulse table

**Group**            Fetch commands

**Syntax**          `FETCH:PULSe[:RESUlt]:DUTRatio?`

**Arguments**      None

**Returns** <first\_pulse\_num>, <duty\_ratio(1)>, <duty\_ratio(2)>, ...  
<duty\_ratio(n)>

Where

<first\_pulse\_num> ::= <NR1> is the first pulse number.

<duty\_ratio(n)> ::= <NRf> is the duty factor for the pulse with the number of [first\_pulse\_num + n - 1] (no unit).

**Examples** FETCH:PULSE:RESULT:DUTRATIO? might return 0, 289.4E-3, 289.6E-3, 290.0E-3, 290.1E-3 for Pulse 0 to 3.

## FETCH:PULSE[:RESult]:FALL? (Query Only)

Returns the fall time in the pulse table.

**Conditions** Measurement views: Pulse table

**Group** Fetch commands

**Syntax** FETCH:PULSE[:RESult]:FALL?

**Arguments** None

**Returns** <first\_pulse\_num>, <fall(1)>, <fall(2)>, ... <fall(n)>

Where

<first\_pulse\_num> ::= <NR1> is the first pulse number.

<fall(n)> ::= <NRf> is the fall time for the pulse with the number of [first\_pulse\_num + n - 1] in seconds.

**Examples** FETCH:PULSE:RESULT:FALL? might return 0, 110.3E-9, 90.45E-9, 95.03E-9, 111.9E-9 for Pulse 0 to 3.

## FETCH:PULSE[:RESult]:FRDeviation? (Query Only)

Returns the frequency deviation in the pulse table.

**Conditions** Measurement views: Pulse table

<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCH:PULSE[:RESULT]:FRDeviation?
<b>Arguments</b>	None
<b>Returns</b>	<p>&lt;first_pulse_num&gt;, &lt;freq_dev(1)&gt;, &lt;freq_dev(2)&gt;, ...                  &lt;freq_dev(n)&gt;</p> <p>Where                  &lt;first_pulse_num&gt;::=&lt;NR1&gt; is the first pulse number.                  &lt;freq_dev(n)&gt;::=&lt;NRf&gt; is the frequency deviation for the pulse with the                  number of [first_pulse_num + n - 1] in Hz.</p>
<b>Examples</b>	FETCH:PULSE:RESULT:FRDEVIATION? might return 1,740.6E+3, 736.5E+3,718.3E+3,672.2E+3 for Pulse 1 to 4.

## FETCH:PULSE[:RESULT]:MFRReqerror? (Query Only)

Returns the maximum frequency error in the pulse table.

<b>Conditions</b>	Measurement views: Pulse table
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCH:PULSE[:RESULT]:MFRReqerror?
<b>Arguments</b>	None
<b>Returns</b>	<p>&lt;first_pulse_num&gt;, &lt;max_freq_err(1)&gt;, &lt;max_freq_err(2)&gt;, ...                  &lt;max_freq_err(n)&gt;</p> <p>Where                  &lt;first_pulse_num&gt;::=&lt;NR1&gt; is the first pulse number.                  &lt;max_freq_err(n)&gt;::=&lt;NRf&gt; is the maximum frequency error for the pulse                  with the number of [first_pulse_num + n - 1] in Hz.</p>
<b>Examples</b>	FETCH:PULSE:RESULT:MFRREQERROR? might return 1,597.5E+3,675.8E+3,642.8E+3,598.2E+3 for Pulse 1 to 4.



## FETCh:PULSe[:RESUlt]:MPHerror? (Query Only)

Returns the maximum phase error in the pulse table.

<b>Conditions</b>	Measurement views: Pulse table
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCh:PULSe[:RESUlt]:MPHerror?
<b>Arguments</b>	None
<b>Returns</b>	<p>&lt;first_pulse_num&gt;, &lt;max_phase_err(1)&gt;, &lt;max_phase_err(2)&gt;, ...          &lt;max_phase_err(n)&gt;</p> <p>Where          &lt;first_pulse_num&gt; ::= &lt;NR1&gt; is the first pulse number.          &lt;max_phase_err(n)&gt; ::= &lt;NRf&gt; is the maximum phase error for the pulse with          the number of [first_pulse_num + n - 1] in degrees.</p>
<b>Examples</b>	FETCh:PULSe:RESUlt:MPHerror? might return 1, -9.221, -8.413, -11.853, -10.258 for Pulse 1 to 4.

## FETCh:PULSe[:RESUlt]:PHDeviation? (Query Only)

Returns the phase deviation in the pulse table.

<b>Conditions</b>	Measurement views: Pulse table
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCh:PULSe[:RESUlt]:PHDeviation?
<b>Arguments</b>	None
<b>Returns</b>	<p>&lt;first_pulse_num&gt;, &lt;phase_dev(1)&gt;, &lt;phase_dev(2)&gt;, ...          &lt;phase_dev(n)&gt;</p> <p>Where</p>

<first\_pulse\_num>::=<NR1> is the first pulse number.  
 <phase\_dev(n)>::=<NRf> is the phase deviation for the pulse with the number of [first\_pulse\_num + n - 1] in degrees.

**Examples**     FETCH:PULSE:RESULT:PHDEVIATION? might return  
 1, 11.658, 9.640, 10.509, 8.272 for Pulse 1 to 4.

## FETCH:PULSE[:RESult]:PPFREQUENCY? (Query Only)

Returns the pulse-pulse carrier frequency in the pulse table.

**Conditions**     Measurement views: Pulse table

**Group**            Fetch commands

**Syntax**            FETCH:PULSE[:RESult]:PPFREQUENCY?

**Arguments**        None

**Returns**            <first\_pulse\_num>, <pp\_freq(1)>, <pp\_freq(2)>, ... <pp\_freq(n)>  
 Where  
 <first\_pulse\_num>::=<NR1> is the first pulse number.  
 <pp\_freq(n)>::=<NRf> is the pulse-pulse carrier frequency for the pulse with the number of [first\_pulse\_num + n - 1] in Hz.

**Examples**     FETCH:PULSE:RESULT:PPFREQUENCY? might return  
 0, 0.000, 1.258E+3, -3.121E+3, 1.862E+3 for Pulse 0 to 3.

## FETCH:PULSE[:RESult]:PPOWER? (Query Only)

Returns the peak power in the pulse table.

**Conditions**        Measurement views: Pulse table

**Group**            Fetch commands

**Syntax**            FETCH:PULSE[:RESult]:PPOWER?

<b>Arguments</b>	None
<b>Returns</b>	<p>&lt;first_pulse_num&gt;, &lt;pk_power(1)&gt;, &lt;pk_power(2)&gt;, ... &lt;pk_power(n)&gt;</p> <p>Where          &lt;first_pulse_num&gt; ::= &lt;NR1&gt; is the first pulse number.          &lt;pk_power(n)&gt; ::= &lt;NRf&gt; is the peak power for the pulse with the number of [first_pulse_num + n - 1] in dBm.          The unit can be changed by the <a href="#">[SENSe]:POWER:UNITs</a> command.</p>
<b>Examples</b>	<p>FETCH:PULSE:RESULT:PPOWER? might return          0, -2.26, -2.27, -2.23, -2.25 for Pulse 0 to 3.</p>

## FETCH:PULSe[:RESult]:PPHase? (Query Only)

Returns the pulse-pulse carrier phase in the pulse table.

<b>Conditions</b>	Measurement views: Pulse table
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCH:PULSe[:RESult]:PPHase?
<b>Arguments</b>	None
<b>Returns</b>	<p>&lt;first_pulse_num&gt;, &lt;pp_phase(1)&gt;, &lt;pp_phase(2)&gt;, ... &lt;pp_phase(n)&gt;</p> <p>Where          &lt;first_pulse_num&gt; ::= &lt;NR1&gt; is the first pulse number.          &lt;pp_phase(n)&gt; ::= &lt;NRf&gt; is the pulse-pulse carrier phase for the pulse with the number of [first_pulse_num + n - 1] in degrees.</p>
<b>Examples</b>	<p>FETCH:PULSE:RESULT:PPPHASE? might return          0, 0.000, 21.66, 46.76, 57.56 for Pulse 0 to 3.</p>

## FETCH:PULSe[:RESult]:RINTerval? (Query Only)

Returns the repetition interval in the pulse table.

<b>Conditions</b>	Measurement views: Pulse table
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCh:PULSe[:RESuLt]:RINTERvaL?
<b>Arguments</b>	None
<b>Returns</b>	<p>&lt;first_pulse_num&gt;, &lt;rep_int(1)&gt;, &lt;rep_int(2)&gt;, ... &lt;rep_int(n)&gt;</p> <p>Where                      &lt;first_pulse_num&gt;::=&lt;NR1&gt; is the first pulse number.                      &lt;rep_int(n)&gt;::=&lt;NRf&gt; is the repetition interval for the pulse with the number of [first_pulse_num + n - 1] in seconds.</p>
<b>Examples</b>	FETCh:PULSe:RESuLt:RINTERvaL? might return 0, 16.03E-6, 16.08E-6, 16.07E-6, 16.02E-6 for Pulse 0 to 3.

## FETCh:PULSe[:RESuLt]:RIPPlE? (Query Only)

Returns the ripple in the pulse table.

<b>Conditions</b>	Measurement views: Pulse table
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCh:PULSe[:RESuLt]:RIPPlE?
<b>Arguments</b>	None
<b>Returns</b>	<p>&lt;first_pulse_num&gt;, &lt;ripple(1)&gt;, &lt;ripple(2)&gt;, ... &lt;ripple(n)&gt;</p> <p>Where                      &lt;first_pulse_num&gt;::=&lt;NR1&gt; is the first pulse number.                      &lt;ripple(n)&gt;::=&lt;NRf&gt; is the voltage ripple for the pulse with the number of [first_pulse_num + n - 1] in percent (%).</p>
<b>Examples</b>	FETCh:PULSe:RESuLt:RIPPlE? might return 0, 106.5E-3, 177.6E-3, 148.3E-3, 148.5E-3 for Pulse 0 to 3.

## FETCh:PULSe[:RESult]:RISE? (Query Only)

Returns the rise time in the pulse table.

<b>Conditions</b>	Measurement views: Pulse table
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCh:PULSe[:RESult]:RISE?
<b>Arguments</b>	None
<b>Returns</b>	<p>&lt;first_pulse_num&gt;,&lt;rise(1)&gt;,&lt;rise(2)&gt;,...&lt;rise(n)&gt;</p> <p>Where            &lt;first_pulse_num&gt;::=&lt;NR1&gt; is the first pulse number.            &lt;rise(n)&gt;::=&lt;NRf&gt; is the rise time for the pulse with the number of            [first_pulse_num + n - 1] in seconds.</p>
<b>Examples</b>	FETCh:PULSe:RESult:RISE? might return 0,92.94E-9,115.9E-9,115.1E-9,97.45E-9 for Pulse 0 to 3.

## FETCh:PULSe[:RESult]:RMSFreqerror? (Query Only)

Returns the RMS frequency error in the pulse table.

<b>Conditions</b>	Measurement views: Pulse table
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCh:PULSe[:RESult]:RMSFreqerror?
<b>Arguments</b>	None
<b>Returns</b>	<p>&lt;first_pulse_num&gt;,&lt;RMS_freq_err(1)&gt;,&lt;RMS_freq_err(2)&gt;,...&lt;RMS_freq_err(n)&gt;</p> <p>Where            &lt;first_pulse_num&gt;::=&lt;NR1&gt; is the first pulse number.</p>

`<RMS_freq_err(n)>::=<NRf>` is the RMS frequency error for the pulse with the number of `[first_pulse_num + n - 1]` in Hz.

**Examples** `FETCH:PULSE:RESULT:RMSFREQERROR?` might return `1, 51.54E+3, 69.20E+3, 64.21E+3, 51.02E+3` for Pulse 1 to 4.

## FETCH:PULSe[:RESuLt]:RMSPherror? (Query Only)

Returns the RMS phase error in the pulse table.

**Conditions** Measurement views: Pulse table

**Group** Fetch commands

**Syntax** `FETCH:PULSe[:RESuLt]:RMSPherror?`

**Arguments** None

**Returns** `<first_pulse_num>, <RMS_phase_err(1)>, <RMS_phase_err(2)>, ... <RMS_phase_err(n)>`

Where

`<first_pulse_num>::=<NR1>` is the first pulse number.

`<RMS_phase_err(n)>::=<NRf>` is the RMS phase error for the pulse with the number of `[first_pulse_num + n - 1]` in degrees.

**Examples** `FETCH:PULSE:RESULT:RMSPHERROR?` might return `1, 908.4E-3, 752.8E-3, 981.7E-3, 886.4E-3` for Pulse 1 to 4.

## FETCH:PULSe[:RESuLt]:RRATE? (Query Only)

Returns the repetition rate in the pulse table.

**Conditions** Measurement views: Pulse table

**Group** Fetch commands

**Syntax** `FETCH:PULSe[:RESuLt]:RRATE?`

<b>Arguments</b>	None
<b>Returns</b>	<first_pulse_num>, <rep_rate(1)>, <rep_rate(2)>, ... <rep_rate(n)>
	Where <first_pulse_num> := <NR1> is the first pulse number. <rep_rate(n)> := <NRf> is the repetition rate for the pulse with the number of [first_pulse_num + n - 1] in Hz.
<b>Examples</b>	FETCH:PULSE:RESULT:RRATE? might return 0, 62.50E+3, 62.52E+3, 62.51E+3, 62.49E+3 for Pulse 0 to 3.

## FETCH:PULSe[:RESUlt]:TIME? (Query Only)

Returns the time in the pulse table.

<b>Conditions</b>	Measurement views: Pulse table
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCH:PULSe[:RESUlt]:TIME?
<b>Arguments</b>	None
<b>Returns</b>	<first_pulse_num>, <time(1)>, <time(2)>, ... <time(n)>
	Where <first_pulse_num> := <NR1> is the first pulse number. <time(n)> := <NRf> is the time for the pulse with the number of [first_pulse_num + n - 1] in seconds.
<b>Examples</b>	FETCH:PULSE:RESULT:TIME? might return 1, 7.937E-3, 8.436E-3, 6.504E-3, 9.876E-3 for Pulse 1 to 4.

## FETCH:PULSe[:RESUlt]:WIDTh? (Query Only)

Returns the pulse width in the pulse table.

<b>Conditions</b>	Measurement views: Pulse table
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCh:PULSe[:RESuLt]:WIDTh?
<b>Arguments</b>	None
<b>Returns</b>	<p>&lt;first_pulse_num&gt;, &lt;width(1)&gt;, &lt;width(2)&gt;, ... &lt;width(n)&gt;</p> <p>Where                      &lt;first_pulse_num&gt;::=&lt;NR1&gt; is the first pulse number.                      &lt;width(n)&gt;::=&lt;NRf&gt; is the pulse width for the pulse with the number of                      [first_pulse_num + n - 1] in seconds.</p>
<b>Examples</b>	FETCh:PULSe:RESuLt:WIDTh? might return 0, 4.630E-6, 4.632E-6, 4.639E-6, 4.642E-6 for Pulse 0 to 3.

## FETCh:PULSe:STATistics? (Query Only)

Returns the trace data of the pulse statistics measurement selected by the [DISPlay:PULSe:SElect:RESuLt](#) command.

---

**NOTE.** Select the plot type (Trend or FFT) using the [DISPlay:PULSe:STATistics:PLOT](#) command before executing this query.

---

<b>Conditions</b>	Measurement views: Pulse statistics
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCh:PULSe:STATistics?
<b>Arguments</b>	None
<b>Returns</b>	<p>#&lt;num_digit&gt;&lt;num_byte&gt;&lt;data(1)&gt;&lt;data(2)&gt;...&lt;data(n)&gt;</p> <p>Where                      &lt;num_digit&gt; is the number of digits in &lt;num_byte&gt;.</p>



<num\_byte> is the number of bytes of data that follow.  
 <data(n)> is the amplitude at the n<sup>th</sup> data point.  
 The unit is dBm (Plot = Trend) or dB (Plot = FFT).  
 4-byte little endian floating-point format specified in IEEE 488.2.  
 The unit of power is selected by the [\[SENSe\]:POWer:UNITs](#) command.

**Examples** `FETCH:PULSE:STATISTICS?` might return `#264xxxx...` (64-byte data) for the statistics trace of the pulse width measurement when [DISPlay:PULSe:SElect:RESult](#) is set to `WIDTh`.

## FETCH:PULSe:STATistics:ATX? (Query Only)

Returns the average transmitted power in the pulse statistics. This command is valid when [DISPlay:PULSe:STATistics:PLOT](#) is set to `TREND`.

**Conditions** Measurement views: Pulse statistics

**Group** Fetch commands

**Syntax** `FETCH:PULSe:STATistics:ATX?`

**Arguments** None

**Returns** <ATX\_avg>, <ATX\_min>, <ATX\_max>

Where

<ATX\_avg> ::= <NRf> is the average of the average transmitted power.

<ATX\_min> ::= <NRf> is the minimum of the average transmitted power.

<ATX\_max> ::= <NRf> is the maximum of the average transmitted power.

Unit: dBm.

The unit can be changed to watts by the [\[SENSe\]:POWer:UNITs](#) command.

Volt is invalid in the average transmitted power measurement.

**Examples** `FETCH:PULSE:STATISTICS:ATX?` might return `-18.51, -18.74, -18.12` for the average transmitted power in the pulse statistics.

## FETCH:PULSe:STATistics:AVERage? (Query Only)

Returns the average on power in the pulse statistics. This command is valid when [DISPlay:PULSe:STATistics:PLOT](#) is set to `TREND`.

<b>Conditions</b>	Measurement views: Pulse statistics
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCH:PULSE:STATISTICS:AVERAGE?
<b>Arguments</b>	None
<b>Returns</b>	<p>&lt;avg_avg&gt;, &lt;avg_min&gt;, &lt;avg_max&gt;</p> <p>Where</p> <p>&lt;avg_avg&gt; ::= &lt;NRf&gt; is the average of the average on power.</p> <p>&lt;avg_min&gt; ::= &lt;NRf&gt; is the minimum of the average on power.</p> <p>&lt;avg_max&gt; ::= &lt;NRf&gt; is the maximum of the average on power.</p> <p>Unit: dBm.</p> <p>The unit can be changed to watts by the <a href="#">[SENSE]:POWER:UNITs</a> command.</p>
<b>Examples</b>	<p>FETCH:PULSE:STATISTICS:AVERAGE? might return -2.35, -2.36, -2.34 for the average on power in the pulse statistics.</p>

## FETCH:PULSE:STATISTICS:DROOP? (Query Only)

Returns the droop in the pulse statistics. This command is valid when [DISPLAY:PULSE:STATISTICS:PLOT](#) is set to TREND.

<b>Conditions</b>	Measurement views: Pulse statistics
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCH:PULSE:STATISTICS:DROOP?
<b>Arguments</b>	None
<b>Returns</b>	<p>&lt;droop_avg&gt;, &lt;droop_min&gt;, &lt;droop_max&gt;</p> <p>Where</p> <p>&lt;droop_avg&gt; ::= &lt;NRf&gt; is the average droop.</p> <p>&lt;droop_min&gt; ::= &lt;NRf&gt; is the minimum droop.</p> <p>&lt;droop_max&gt; ::= &lt;NRf&gt; is the maximum droop.</p>

Unit: Percent (%) by watts.

**Examples**    `FETCH:PULSE:STATISTICS:DROOP?` might return `22.67E-3, -613.5E-3, 633.8E-3` for the droop in the pulse statistics.

## FETCH:PULSE:STATISTICS:DUTPct? (Query Only)

Returns the duty factor (%) in the pulse statistics. This command is valid when `DISPlay:PULSE:STATISTICS:PLOT` is set to TREND.

**Conditions**    Measurement views: Pulse statistics

**Group**        Fetch commands

**Syntax**       `FETCH:PULSE:STATISTICS:DUTPct?`

**Arguments**    None

**Returns**       `<duty_pct_avg>, <duty_pct_min>, <duty_pct_max>`

Where

`<duty_pct_avg> ::= <NRf>` is the average duty factor.

`<duty_pct_min> ::= <NRf>` is the minimum duty factor.

`<duty_pct_max> ::= <NRf>` is the maximum duty factor.

Unit: Percent (%).

**Examples**    `FETCH:PULSE:STATISTICS:DUTPCT?` might return `2.437, 2.310, 2.657` for the duty factor (%) in the pulse statistics.

## FETCH:PULSE:STATISTICS:DUTRatio? (Query Only)

Returns the duty factor (ratio) in the pulse statistics. This command is valid when `DISPlay:PULSE:STATISTICS:PLOT` is set to TREND.

**Conditions**    Measurement views: Pulse statistics

**Group**        Fetch commands

<b>Syntax</b>	<code>FETCh:PULSe:STATistics:DUTRatio?</code>
<b>Arguments</b>	None
<b>Returns</b>	<code>&lt;duty_ratio_avg&gt;, &lt;duty_ratio_min&gt;, &lt;duty_ratio_max&gt;</code> Where <code>&lt;duty_ratio_avg&gt;::=&lt;Nrf&gt;</code> is the average duty factor. <code>&lt;duty_ratio_min&gt;::=&lt;Nrf&gt;</code> is the minimum duty factor. <code>&lt;duty_ratio_max&gt;::=&lt;Nrf&gt;</code> is the maximum duty factor. Unit: None.
<b>Examples</b>	<code>FETCh:PULSe:STATISTICS:DUTRATIO?</code> might return <code>24.37E-3, 23.11E-3, 26.57E-3</code> for the duty factor (ratio) in the pulse statistics.

## FETCh:PULSe:STATistics:FALL? (Query Only)

Returns the fall time in the pulse statistics. This command is valid when [DISPlay:PULSe:STATistics:PLOT](#) is set to TREND.

<b>Conditions</b>	Measurement views: Pulse statistics
<b>Group</b>	Fetch commands
<b>Syntax</b>	<code>FETCh:PULSe:STATistics:FALL?</code>
<b>Arguments</b>	None
<b>Returns</b>	<code>&lt;fall_avg&gt;, &lt;fall_min&gt;, &lt;fall_max&gt;</code> Where <code>&lt;fall_avg&gt;::=&lt;Nrf&gt;</code> is the average fall time. <code>&lt;fall_min&gt;::=&lt;Nrf&gt;</code> is the minimum fall time. <code>&lt;fall_max&gt;::=&lt;Nrf&gt;</code> is the maximum fall time. Unit: Seconds.
<b>Examples</b>	<code>FETCh:PULSe:STATISTICS:FALL?</code> might return <code>70.27E-9, 69.62E-9, 71.27E-9</code> for the fall time in the pulse statistics.

## FETCh:PULSe:STATistics:FRDeviation? (Query Only)

Returns the frequency deviation in the pulse statistics. This command is valid when [DISPlay:PULSe:STATistics:PLOT](#) is set to TREND.

<b>Conditions</b>	Measurement views: Pulse statistics
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCh:PULSe:STATistics:FRDeviation?
<b>Arguments</b>	None
<b>Returns</b>	<code>&lt;freq_dev_avg&gt;</code> , <code>&lt;freq_dev_min&gt;</code> , <code>&lt;freq_dev_max&gt;</code> Where <code>&lt;freq_dev_avg&gt; ::= &lt;NRf&gt;</code> is the average frequency deviation. <code>&lt;freq_dev_min&gt; ::= &lt;NRf&gt;</code> is the minimum frequency deviation. <code>&lt;freq_dev_max&gt; ::= &lt;NRf&gt;</code> is the maximum frequency deviation. Unit: Hz.
<b>Examples</b>	FETCh:PULSe:STATISTICS:FRDEVIATION? might return 754.1E+3, 660.5E+3, 835.2E+3 for the frequency deviation in the pulse statistics.

## FETCh:PULSe:STATistics:MFReqerror? (Query Only)

Returns the maximum frequency error in the pulse statistics. This command is valid when [DISPlay:PULSe:STATistics:PLOT](#) is set to TREND.

<b>Conditions</b>	Measurement views: Pulse statistics
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCh:PULSe:STATistics:MFReqerror?
<b>Arguments</b>	None
<b>Returns</b>	<code>&lt;max_freq_err_avg&gt;</code> , <code>&lt;max_freq_err_min&gt;</code> , <code>&lt;max_freq_err_max&gt;</code>

Where

<max\_freq\_err\_avg>::=<Nrf> is the average of maximum frequency error.

<max\_freq\_err\_min>::=<Nrf> is the minimum of maximum frequency error.

<max\_freq\_err\_max>::=<Nrf> is the maximum of maximum frequency error.

Unit: Hz.

**Examples**     FETCH:PULSE:STATISTICS:MFREQERROR? might return  
645.0E+3, 555.6E+3, 738.8E+3 for the maximum frequency error  
in the pulse statistics.

## FETCH:PULSE:STATISTICS:MPHError? (Query Only)

Returns the maximum phase error in the pulse statistics. This command is valid when [DISPlay:PULSE:STATISTICS:PLOT](#) is set to TRENd.

**Conditions**     Measurement views: Pulse statistics

**Group**            Fetch commands

**Syntax**            FETCH:PULSE:STATISTICS:MPHError?

**Arguments**        None

**Returns**            <max\_phase\_err\_avg>, <max\_phase\_err\_min>, <max\_phase\_err\_max>

Where

<max\_phase\_err\_avg>::=<Nrf> is the average of maximum phase error.

<max\_phase\_err\_min>::=<Nrf> is the minimum of maximum phase error.

<max\_phase\_err\_max>::=<Nrf> is the maximum of maximum phase error.

Unit: Degrees.

**Examples**     FETCH:PULSE:STATISTICS:MPHERROR? might return -11.47, -17.18,  
-7.61 for the maximum phase error in the pulse statistics.

## FETCH:PULSE:STATISTICS:PHDeviation? (Query Only)

Returns the phase deviation in the pulse statistics. This command is valid when [DISPlay:PULSE:STATISTICS:PLOT](#) is set to TRENd.

**Conditions**        Measurement views: Pulse statistics

<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCh:PULSe:STATistics:PHDeviation?
<b>Arguments</b>	None
<b>Returns</b>	<phase_dev_avg>, <phase_dev_min>, <phase_dev_max> Where <phase_dev_avg> ::= <NRf> is the average phase deviation. <phase_dev_min> ::= <NRf> is the minimum phase deviation. <phase_dev_max> ::= <NRf> is the maximum phase deviation. Unit: Degrees.
<b>Examples</b>	FETCh:PULSe:STATISTICS:PHDEVIATION? might return 11.678, 7.694, 17.374 for the phase deviation in the pulse statistics.

## FETCh:PULSe:STATistics:PPFRequency? (Query Only)

Returns the pulse-pulse carrier frequency in the pulse statistics. This command is valid when [DISPlay:PULSe:STATistics:PLOT](#) is set to TREND.

<b>Conditions</b>	Measurement views: Pulse statistics
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCh:PULSe:STATistics:PPFRequency?
<b>Arguments</b>	None
<b>Returns</b>	<pp_freq_avg>, <pp_freq_min>), <pp_freq_max> Where <pp_freq_avg> ::= <NRf> is the average pulse-pulse carrier frequency. <pp_freq_min> ::= <NRf> is the minimum pulse-pulse carrier frequency. <pp_freq_max> ::= <NRf> is the maximum pulse-pulse carrier frequency. Unit: Hz.

**Examples**     `FETCH:PULSE:STATISTICS:PPFREQUENCY?` might return `1.135E+3, 311.3E+3, -262.8E+3` for the pulse-pulse carrier frequency in the pulse statistics.

## FETCH:PULSe:STATistics:PPOWer? (Query Only)

Returns the peak power in the pulse statistics. This command is valid when [DISPlay:PULSe:STATistics:PLOT](#) is set to TREND.

**Conditions**     Measurement views: Pulse statistics

**Group**            Fetch commands

**Syntax**           `FETCH:PULSe:STATistics:PPOWer?`

**Arguments**       None

**Returns**           `<pk_power_avg>, <pk_power_min>, <pk_power_max>`

Where

`<pk_power_avg>::=<Nrf>` is the average peak power.

`<pk_power_min>::=<Nrf>` is the minimum peak power.

`<pk_power_max>::=<Nrf>` is the maximum peak power.

Unit: dBm.

The unit can be changed by the [\[SENSe\]:POWer:UNITs](#) command.

**Examples**     `FETCH:PULSE:STATISTICS:PPOWer?` might return `-2.273, -2.313, -2.235` for the peak power in the pulse statistics.

## FETCH:PULSe:STATistics:PPPHase? (Query Only)

Returns the pulse-pulse carrier phase in the pulse statistics. This command is valid when [DISPlay:PULSe:STATistics:PLOT](#) is set to TREND.

**Conditions**       Measurement views: Pulse statistics

**Group**            Fetch commands

**Syntax**           `FETCH:PULSe:STATistics:PPPHase?`



<b>Arguments</b>	None
<b>Returns</b>	<pp_phase_avg>, <pp_phase_min>, <pp_phase_max> Where <pp_phase_avg> ::= <NRf> is the average pulse-pulse carrier phase. <pp_phase_min> ::= <NRf> is the minimum pulse-pulse carrier phase. <pp_phase_max> ::= <NRf> is the maximum pulse-pulse carrier phase. Unit: Degrees.
<b>Examples</b>	FETCH:PULSE:STATISTICS:PPHASE? might return -9.298E-3, -254.3E-3, 311.7E-3 for the pulse-pulse carrier phase in the pulse statistics.

## FETCH:PULSe:STATistics:RINterval? (Query Only)

Returns the repetition interval in the pulse statistics. This command is valid when [DISPlay:PULSe:STATistics:PLOT](#) is set to TREND.

<b>Conditions</b>	Measurement views: Pulse statistics
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCH:PULSe:STATistics:RINterval?
<b>Arguments</b>	None
<b>Returns</b>	<rep_int_avg>, <rep_int_min>, <rep_int_max> Where <rep_int_avg> ::= <NRf> is the average repetition interval. <rep_int_min> ::= <NRf> is the minimum repetition interval. <rep_int_max> ::= <NRf> is the maximum repetition interval. Unit: Seconds.
<b>Examples</b>	FETCH:PULSE:STATISTICS:RINTERVAL? might return 240.5E-6, 217.9E-6, 281.2E-6 for the repetition interval in the pulse statistics.

## FETCh:PULSe:STATistics:RIPPlE? (Query Only)

Returns the ripple in the pulse statistics. This command is valid when [DISPlay:PULSe:STATistics:PLOT](#) is set to TRENd.

<b>Conditions</b>	Measurement views: Pulse statistics
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCh:PULSe:STATistics:RIPPlE?
<b>Arguments</b>	None
<b>Returns</b>	<code>&lt;ripple_avg&gt;</code> , <code>&lt;ripple_min&gt;</code> , <code>&lt;ripple_max&gt;</code> Where <code>&lt;ripple_avg&gt; ::= &lt;NRf&gt;</code> is the average ripple. <code>&lt;ripple_min&gt; ::= &lt;NRf&gt;</code> is the minimum ripple. <code>&lt;ripple_max&gt; ::= &lt;NRf&gt;</code> is the maximum ripple. Unit: Percent (%) by volts.
<b>Examples</b>	FETCh:PULSe:STATISTICS:RIPPLE? might return 160.4E-3, 83.78E-3, 287.7E-3 for the ripple in the pulse statistics.

## FETCh:PULSe:STATistics:RISE? (Query Only)

Returns the rise time in the pulse statistics. This command is valid when [DISPlay:PULSe:STATistics:PLOT](#) is set to TRENd.

<b>Conditions</b>	Measurement views: Pulse statistics
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCh:PULSe:STATistics:RISE?
<b>Arguments</b>	None
<b>Returns</b>	<code>&lt;rise_avg&gt;</code> , <code>&lt;rise_min&gt;</code> , <code>&lt;rise_max&gt;</code>

Where

<rise\_avg>::=<NRf> is the average rise time.

<rise\_min>::=<NRf> is the minimum rise time.

<rise\_max>::=<NRf> is the maximum rise time.

Unit: Seconds.

**Examples**    `FETCH:PULSE:STATISTICS:RISE?` might return 105.4E-9, 91.65E-9, 116.2E-9 for the rise time in the pulse statistics.

## FETCH:PULSe:STATistics:RMSFreqerror? (Query Only)

Returns the RMS frequency error in the pulse statistics. This command is valid when [DISPlay:PULSe:STATistics:PLOT](#) is set to TRENd.

**Conditions**    Measurement views: Pulse statistics

**Group**    Fetch commands

**Syntax**    `FETCH:PULSe:STATistics:RMSFreqerror?`

**Arguments**    None

**Returns**    <RMS\_freq\_err\_avg>, <RMS\_freq\_err\_min>, <RMS\_freq\_err\_max>

Where

<RMS\_freq\_err\_avg>::=<NRf> is the average of RMS frequency error.

<RMS\_freq\_err\_min>::=<NRf> is the minimum of RMS frequency error.

<RMS\_freq\_err\_max>::=<NRf> is the maximum of RMS frequency error.

Unit: Hz.

**Examples**    `FETCH:PULSE:STATISTICS:RMSFREQERROR?` might return 63.67E+3, 45.49E+3, 81.28E+3 for the RMS frequency error in the pulse statistics.

## FETCH:PULSe:STATistics:RMSPherror? (Query Only)

Returns the RMS phase error in the pulse statistics. This command is valid when [DISPlay:PULSe:STATistics:PLOT](#) is set to TRENd.

**Conditions**    Measurement views: Pulse statistics

<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCH:PULSE:STATISTICS:RMSPherror?
<b>Arguments</b>	None
<b>Returns</b>	<p>&lt;RMS_phase_err_avg&gt;, &lt;RMS_phase_err_min&gt;, &lt;RMS_phase_err_max&gt;</p> <p>Where</p> <p>&lt;RMS_phase_err_avg&gt;::=&lt;NRf&gt; is the average of RMS phase error.</p> <p>&lt;RMS_phase_err_min&gt;::=&lt;NRf&gt; is the minimum of RMS phase error.</p> <p>&lt;RMS_phase_err_max&gt;::=&lt;NRf&gt; is the maximum of RMS phase error.</p> <p>Unit: Degrees.</p>
<b>Examples</b>	<p>FETCH:PULSE:STATISTICS:RMSPHERROR? might return 1.032, 604.5E-3, 1.606 for the RMS phase error in the pulse statistics.</p>

## FETCH:PULSE:STATISTICS:RRATE? (Query Only)

Returns the repetition rate in the pulse statistics. This command is valid when [DISPlay:PULSE:STATISTICS:PLOT](#) is set to TREND.

<b>Conditions</b>	Measurement views: Pulse trace
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCH:PULSE:STATISTICS:RRATE?
<b>Arguments</b>	None
<b>Returns</b>	<p>&lt;rep_rate_avg&gt;, &lt;rep_rate_min&gt;, &lt;rep_rate_max&gt;</p> <p>Where</p> <p>&lt;rep_rate_avg&gt;::=&lt;NRf&gt; is the average repetition rate.</p> <p>&lt;rep_rate_min&gt;::=&lt;NRf&gt; is the minimum repetition rate.</p> <p>&lt;rep_rate_max&gt;::=&lt;NRf&gt; is the maximum repetition rate.</p> <p>Unit: Hz.</p>

**Examples**    `FETCH:PULSE:STATISTICS:RRATE?` might return 62.50E+3, 62.49E+3, 62.52E+3 for the repetition rate in the pulse statistics.

## FETCH:PULSE:STATISTICS:WIDTH? (Query Only)

Returns the pulse width in the pulse statistics. This command is valid when [DISPLAY:PULSE:STATISTICS:PLOT](#) is set to TREND.

**Conditions**    Measurement views: Pulse trace

**Group**    Fetch commands

**Syntax**    `FETCH:PULSE:STATISTICS:WIDTH?`

**Arguments**    None

**Returns**    `<width_avg>, <width_min>, <width_max>`

Where

`<width_avg> ::= <NRf>` is the average pulse width.

`<width_min> ::= <NRf>` is the minimum pulse width.

`<width_max> ::= <NRf>` is the maximum pulse width.

Unit: Seconds.

**Examples**    `FETCH:PULSE:STATISTICS:WIDTH?` might return 4.636E-6, 4.630E-6, 4.643E-6 for the pulse width in the pulse statistics.

## FETCH:PULSE:TRACE:X? (Query Only)

Returns the time values of the pulse trace. Use the [DISPLAY:PULSE:SELECT:NUMBER](#) command to select the pulse, and the [DISPLAY:PULSE:SELECT:RESULT](#) command to select the measurement result.

**Conditions**    Measurement views: Pulse trace

**Group**    Fetch commands

**Syntax**    `FETCH:PULSE:TRACE:X?`

<b>Arguments</b>	None
<b>Returns</b>	<code>#&lt;num_digit&gt;&lt;num_byte&gt;&lt;x(1)&gt;&lt;x(2)&gt;...&lt;x(n)&gt;</code> Where <code>&lt;num_digit&gt;</code> is the number of digits in <code>&lt;num_byte&gt;</code> . <code>&lt;num_byte&gt;</code> is the number of bytes of data that follow. <code>&lt;x(n)&gt;</code> is the time in seconds at the $n^{\text{th}}$ data point, 4-byte little endian floating-point format specified in IEEE 488.2.
<b>Examples</b>	<code>FETCh:PULSe:TRACe:X?</code> might return <code>#43204xxxx...</code> (3204-byte data) for the time values of the trace.

## FETCh:PULSe:TRACe:XY? (Query Only)

Returns the horizontal (time) and vertical value pairs of the pulse trace. Use the [DISPlay:PULSe:SElect:NUMBer](#) command to select the pulse, and the [DISPlay:PULSe:SElect:RESult](#) command to select the measurement result.

<b>Conditions</b>	Measurement views: Pulse trace
<b>Group</b>	Fetch commands
<b>Syntax</b>	<code>FETCh:PULSe:TRACe:XY?</code>
<b>Arguments</b>	None
<b>Returns</b>	<code>#&lt;num_digit&gt;&lt;num_byte&gt;&lt;x(1)&gt;&lt;y(1)&gt;&lt;x(2)&gt;&lt;y(2)&gt;...&lt;x(n)&gt;&lt;y(n)&gt;</code> Where <code>&lt;num_digit&gt;</code> is the number of digits in <code>&lt;num_byte&gt;</code> . <code>&lt;num_byte&gt;</code> is the number of bytes of data that follow. <code>&lt;x(n)&gt;&lt;y(n)&gt;</code> is the horizontal value (time in seconds) and vertical value pair at the $n^{\text{th}}$ data point, 4-byte little endian floating-point format specified in IEEE 488.2.  The vertical unit depends on measurement results: Hz for frequency error and deviation, degrees for phase error and deviation, otherwise dBm. The vertical unit can be changed by the <a href="#">[SENSe]:POWer:UNITs</a> command.

**Examples**    `FETCH:PULSE:TRACE:XY?` might return `#43204xxxx...` (3204-byte data) for the horizontal (time) and vertical value pairs of the pulse trace.

## FETCH:PULSe:TRACe[:Y]? (Query Only)

Returns the vertical values of the pulse trace. Use the `DISPlay:PULSe:SElect:NUMBer` command to select the pulse, and the `DISPlay:PULSe:SElect:RESult` command to select the measurement result.

**Conditions**    Measurement views: Pulse trace

**Group**    Fetch commands

**Syntax**    `FETCH:PULSe:TRACe[:Y]?`

**Arguments**    None

**Returns**    `#<num_digit><num_byte><y(1)><y(2)>...<y(n)>`

Where

`<num_digit>` is the number of digits in `<num_byte>`.

`<num_byte>` is the number of bytes of data that follow.

`<y(n)>` is the amplitude (dBm) at the  $n^{\text{th}}$  data point,

4-byte little endian floating-point format specified in IEEE 488.2.

The unit depends on measurement results: Hz for frequency error and deviation, degrees for phase error and deviation, otherwise dBm. The unit can be changed by the `[SENSE]:POWER:UNITs` command.

**Examples**    `FETCH:PULSE:TRACE:Y?` might return `#43204xxxx...` (3204-byte data) for the vertical values of the pulse trace.

## FETCH:RFIN:IQ? (Query Only)

Returns time-domain IQ data for a specific acquisition data record. You can set a range of IQ pairs optionally. The instrument needs to be in stopped mode. If not in stopped mode, it returns the execution error (-200).

**Conditions**    Measurement views: All

**Group** Fetch commands

**Syntax** `FETCh:RFIN:IQ? <rec_ID>[, <begin_num>, <end_num>]`

**Arguments** `<rec_ID>` specifies the acquisition data record ID number.  
`<begin_num>` specifies the beginning number of IQ pairs.  
`<end_num>` specifies the end number of IQ pairs.

Use the [FETCh:RFIN:RECOrd:IDS?](#) query to get the beginning and end ID's of acquisition data records.

**Returns** `#<num_digit><num_byte><I(1)><Q(1)><I(2)><Q(2)>...<I(n)><Q(n)>`

Where  
`<num_digit>` is the number of digits in `<num_byte>`.  
`<num_byte>` is the number of bytes of data that follow.  
`<I(n)>` and `<Q(n)>` are the time-domain IQ data pair.  
4-byte little endian floating-point format specified in IEEE 488.2.

To find out the range of IQ pairs, use the [FETCh:RFIN:IQ:HEADer?](#) query. The returned value of `<num_sample>` is the number of IQ pairs.

---

**NOTE.** *Do not fetch a large number of IQ pairs because of memory limitation.*

---

**Examples** `FETCh:RFIN:IQ? 10,25,350` might return `#43848xxxx...` (3848-byte data) for the record #10, ranging from 25<sup>th</sup> to 350<sup>th</sup> IQ pair.

## FETCh:RFIN:IQ:HEADer? (Query Only)

Returns the header information for a specific acquisition data record. The instrument needs to be in stopped mode. If not in stopped mode, it returns the execution error (-200).

**Conditions** Measurement views: All

**Group** Fetch commands

**Syntax** `FETCh:RFIN:IQ:HEADer? <rec_ID>`



- Arguments** <rec\_ID> specifies the acquisition data record ID number.
- Use the [FETCh:RFIN:RECOrd:IDS?](#) query to get the beginning and end ID's of acquisition data records.
- Returns** <span>, <sampling\_freq>, <num\_sample>, <center\_freq>, <acq\_BW>, <ref\_level>, <trig\_pos>, <time\_stamp>, <FastFrame\_ID>
- Where
- <span> ::= <NR3> is the span in Hz.
  - <sampling\_freq> ::= <NR3> is the sampling frequency in Hz.
  - <num\_sample> ::= <NR3> is the number of samples.
  - <center\_freq> ::= <NR3> is the center frequency in Hz.
  - <acq\_BW> ::= <NR3> is the acquisition bandwidth in Hz.
  - <ref\_level> ::= <NR3> is the reference level in dBm.
  - <trig\_pos> ::= <NR3> is the trigger position in seconds.
  - <time\_stamp> ::= <string> is the time stamp.
  - <FastFrame\_ID> ::= <NR1> is the Fast Frame ID: Zero or positive number. If the Fast Frame is disabled, the ID will be negative.
- Examples** FETCh:RFIN:IQ:HEADER? 10 might return 40.0E+6, 50.0E+6, 4.027E+3, 1.5E+9, 40.0E+6, 0.0, 20.242E-6, "10/31/2007 1118:32 AM", -1, indicating
- Span: 40 MHz,
  - Sampling frequency: 50 MHz,
  - Number of samples: 4027,
  - Center frequency: 1.5 GHz,
  - Acquisition bandwidth: 40 MHz,
  - Reference level: 0 dBm,
  - Trigger position: 20.242  $\mu$ s,
  - Time stamp: 10/31/2007 1118:32 AM, and
  - Fast Frame ID: -1

## FETCh:RFIN:IQ:SCALE? (Query Only)

Returns the internal RF linear data scaling factor contained in the .tiq file header. The scaling factor can be used to convert digital IQ output (Option 05) values into real IQ values.

**Conditions** Measurement views: All

**Group** Fetch commands

**Syntax**      FETCh:RFIN:IQ:SCALE?

**Related Commands**      FETCh:RFIN:RECOrd:IDS?

**Arguments**      None

**Returns**      <NR3> The RF linear data scaling factor.

**Examples**      FETCh:RFIN:IQ:SCALE? might return 19.553E-6 for the scaling factor.

## FETCh:RFIN:RECOrd:IDS? (Query Only)

Returns the beginning and end ID numbers of acquisition data.

---

**NOTE.** *The instrument needs to be in stopped mode. If not in stopped mode, it returns the execution error (-200).*

---

**Conditions**      Measurement views: All

**Group**      Fetch commands

**Syntax**      FETCh:RFIN:RECOrd:IDS?

**Arguments**      None

**Returns**      <begin\_ID>, <end\_ID>

Where

<begin\_ID>::=<NR1> is the beginning ID of acquisition data.

<end\_ID>::=<NR1> is the end ID of acquisition data.

---

**NOTE.** *“-1,-1” is returned when the span changes and the acquisition is armed, but the acquisition has not yet occurred.*

---

**Examples**      FETCh:RFIN:RECORD:IDS? might return 1, 147, indicating the beginning and end ID's of acquisition data are 1 and 147, respectively.

## FETCh:SGRam? (Query Only)

Returns trace data of a line in the spectrogram. The line is selected using the [TRACe:SGRam:SELEct:LINE](#) command.

**Conditions** Measurement views: Spectrogram

**Group** Fetch commands

**Syntax** FETCh:SGRam?

**Arguments** None

**Returns** #<num\_digit><num\_byte><data(1)><data(2)>...<data(n)>

Where

<num\_digit> is the number of digits in <num\_byte>.

<num\_byte> is the number of bytes of data that follow.

<data(n)> is the amplitude in dBm at the n<sup>th</sup> data point,

4-byte little endian floating-point format specified in IEEE 488.2.

The unit can be changed by the [\[SENSE\]:POWER:UNITs](#) command.

**Examples** FETCh:SGRAM? might return #43204xxxx... (3204-byte data) for the line in the spectrogram.

## FETCh:SPECTrum:TRACe<x>? (Query Only)

Returns the trace data in the Spectrum measurement.

The parameter <x> = 1 to 5.

---

**NOTE.** TRACe5 (spectrogram) is valid when the spectrum and spectrogram measurements are running.

---

**Conditions** Measurement views: Spectrum

**Group** Fetch commands

**Syntax** FETCh:SPECTrum:TRACe<x>?

<b>Related Commands</b>	TRACe<x>:SPECtrum command subgroup
<b>Arguments</b>	None
<b>Returns</b>	#<num_digit><num_byte><data(1)><data(2)>...<data(n)> Where <num_digit> is the number of digits in <num_byte>. <num_byte> is the number of bytes of data that follow. <data(n)> is the amplitude in dBm at the n <sup>th</sup> data point, 4-byte little endian floating-point format specified in IEEE 488.2. The unit can be changed by the [SENSe]:POWer:UNITs command.
<b>Examples</b>	FETCH:SPECTRUM:TRACE1? might return #43204xxxx... (3204-byte data) for Trace 1 in the Spectrum measurement.

## FETCH:SPURious:CARRier:POWer? (Query Only)

Returns the carrier power in the Spurious measurement.

<b>Conditions</b>	Measurement views: Spurious
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCH:SPURious:CARRier:POWer?
<b>Arguments</b>	None
<b>Returns</b>	<NRf> Carrier power in dBm. The unit can be changed by the [SENSe]:POWer:UNITs command.
<b>Examples</b>	FETCH:SPURIOUS:CARRIER:POWER? might return 4.227, indicating that the carrier power is 4.227 dBm.

## FETCH:SPURious:COUNT? (Query Only)

Returns the number of spurious signals in the Spurious measurement.

<b>Conditions</b>	Measurement views: Spurious
<b>Group</b>	Fetch commands
<b>Syntax</b>	<code>FETCh:SPURious:COUNT?</code>
<b>Arguments</b>	None
<b>Returns</b>	<NRf> The number of spurious signals.
<b>Examples</b>	<code>FETCh:SPURIOUS:COUNT?</code> might return 4, indicating that the spurious count is 4.

### **FETCh:SPURious:PASS? (Query Only)**

Returns the pass/fail limit test result in the Spurious measurement.

<b>Conditions</b>	Measurement views: Spurious
<b>Group</b>	Fetch commands
<b>Syntax</b>	<code>FETCh:SPURious:PASS?</code>
<b>Arguments</b>	None
<b>Returns</b>	0 (fail) or 1 (pass).
<b>Examples</b>	<code>FETCh:SPURIOUS:PASS?</code> might return 1, indicating that the limit test was successful.

### **FETCh:SPURious:SPECtrum:X? (Query Only)**

Returns the frequencies of the spectrum trace in the Spurious measurement.

<b>Conditions</b>	Measurement views: Spurious
-------------------	-----------------------------

<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCh:SPURious:SPECTrum:X?
<b>Arguments</b>	None
<b>Returns</b>	#<num_digit><num_byte><x(1)><x(2)>...<x(n)> Where <num_digit> is the number of digits in <num_byte>. <num_byte> is the number of bytes of data that follow. <x(n)> is the frequency (Hz) at the n <sup>th</sup> data point, 4-byte little endian floating-point format specified in IEEE 488.2.
<b>Examples</b>	FETCh:SPURIOUS:SPECTRUM:X? might return #516020xxxx... (16020-byte data) for the frequencies of the spectrum trace in the Spurious measurement.

## FETCh:SPURious:SPECTrum:XY? (Query Only)

Returns the frequency and amplitude pairs of the spectrum trace in the Spurious measurement.

<b>Conditions</b>	Measurement views: Spurious
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCh:SPURious:SPECTrum:XY?
<b>Arguments</b>	None
<b>Returns</b>	#<num_digit><num_byte><x(1)><y(1)><x(2)><y(2)>...<x(n)><y(n)> Where <num_digit> is the number of digits in <num_byte>. <num_byte> is the number of bytes of data that follow. <x(n)><y(n)> is the frequency (Hz) and amplitude (dBm) pair at the n <sup>th</sup> data point, 4-byte little endian floating-point format specified in IEEE 488.2. The amplitude unit can be changed by the [SENSe]:POWer:UNITs command.

**Examples**    `FETCH:SPURIOUS:SPECTRUM:XY?` might return `#516020xxxx...` (16020-byte data) for the frequency and amplitude pairs of the spectrum trace in the Spurious measurement.

## **FETCh:SPURious:SPECTrum[:Y]? (Query Only)**

Returns the amplitudes of the spectrum trace in the Spurious measurement.

**Conditions**    Measurement views: Spurious

**Group**    Fetch commands

**Syntax**    `FETCh:SPURious:SPECTrum[:Y]?`

**Arguments**    None

**Returns**    `#<num_digit><num_byte><y(1)><y(2)>...<y(n)>`

Where

`<num_digit>` is the number of digits in `<num_byte>`.

`<num_byte>` is the number of bytes of data that follow.

`<y(n)>` is the amplitude (dBm) at the  $n^{\text{th}}$  data point,

4-byte little endian floating-point format specified in IEEE 488.2.

The unit can be changed by the [\[SENSe\]:POWer:UNITs](#) command.

**Examples**    `FETCH:SPURIOUS:SPECTRUM:Y?` might return `#516020xxxx...` (16020-byte data) for the amplitudes of the spectrum trace in the Spurious measurement.

## **FETCh:SPURious:SPUR<x>:AMPLitude:ABSolute? (Query Only)**

Returns the absolute amplitude of the specified spurious signal in the Spurious measurement.

**Conditions**    Measurement views: Spurious

**Group**    Fetch commands

**Syntax**    `FETCh:SPURious:SPUR<x>:AMPLitude:ABSolute?`

<b>Arguments</b>	None
<b>Returns</b>	<NRF> Absolute amplitude of the specified spurious signal in dBm. The unit can be changed by the <a href="#">[SENSE]:POWER:UNITS</a> command.
<b>Examples</b>	FETCH:SPURIOUS:SPUR1:AMPLITUDE:ABSOLUTE? might return -19.782, indicating that the absolute amplitude of Spurious #1 is -19.782 dBm.

## FETCH:SPURious:SPUR<x>:AMPLitude:RELative? (Query Only)

Returns the relative amplitude of the specified spurious signal in the Spurious measurement.

<b>Conditions</b>	Measurement views: Spurious
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCH:SPURious:SPUR<x>:AMPLitude:RELative?
<b>Arguments</b>	None
<b>Returns</b>	<NRF> Relative amplitude of the specified spurious signal in dB. Use the <a href="#">[SENSE]:SPURious:REFerence</a> command to set the power reference.
<b>Examples</b>	FETCH:SPURIOUS:SPUR1:AMPLITUDE:RELATIVE? might return -9.782, indicating that the relative amplitude of Spurious #1 is -9.782 dB.

## FETCH:SPURious:SPUR<x>:FREQuency:ABSolute? (Query Only)

Returns the absolute frequency of the specified spurious signal in the Spurious measurement.

<b>Conditions</b>	Measurement views: Spurious
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCH:SPURious:SPUR<x>:FREQuency:ABSolute?



<b>Arguments</b>	None
<b>Returns</b>	<NRf> Absolute frequency of the spurious signal in Hz.
<b>Examples</b>	FETCH:SPURIOUS:SPUR1:FREQUENCY:ABSOLUTE? might return 2.235E+9, indicating that the absolute frequency of Spurious #1 is 2.235 GHz.

## FETCH:SPURious:SPUR<x>:FREQuency:RELative? (Query Only)

Returns the relative frequency of the specified spurious signal to the carrier in the Spurious measurement. This command is valid when [\[SENSe\]:SPURious:REFerence](#) is set to CARRier.

<b>Conditions</b>	Measurement views: Spurious
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCH:SPURious:SPUR<x>:FREQuency:RELative?
<b>Arguments</b>	None
<b>Returns</b>	<NRf> Relative frequency of the spurious signal to the carrier in Hz.
<b>Examples</b>	FETCH:SPURIOUS:SPUR1:FREQUENCY:RELATIVE might return 3.634E+6, indicating that the relative frequency of Spurious #1 is 3.634 MHz.

## FETCH:SPURious:SPUR<x>:LIMit:ABSolute? (Query Only)

Returns the absolute amplitude of the limit for the specified spurious signal in the Spurious measurement.

<b>Conditions</b>	Measurement views: Spurious
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCH:SPURious:SPUR<x>:LIMit:ABSolute?

<b>Arguments</b>	None
<b>Returns</b>	<NRF> Absolute amplitude of the limit for the specified spurious signal in dBm. The unit can be changed by the <a href="#">[SENSE]:POWER:UNITS</a> command.
<b>Examples</b>	FETCH:SPURIOUS:SPUR1:LIMIT:ABSOLUTE? might return -50.0, indicating that the absolute amplitude of the limit for Spurious #1 is -50 dBm.

## FETCH:SPURious:SPUR<x>:LIMIT:RELative? (Query Only)

Returns the relative amplitude of the limit for the specified spurious signal in the Spurious measurement.

<b>Conditions</b>	Measurement views: Spurious
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCH:SPURious:SPUR<x>:LIMIT:RELative?
<b>Arguments</b>	None
<b>Returns</b>	<NRF> Relative amplitude of the limit for the specified spurious signal in dB. Use the <a href="#">[SENSE]:SPURious:REFerence</a> command to set the power reference.
<b>Examples</b>	FETCH:SPURIOUS:SPUR1:LIMIT:RELATIVE? might return -10.0, indicating that the relative amplitude of the limit for Spurious #1 is -10 dB.

## FETCH:SPURious:SPUR<x>:LIMIT:VIOLation? (Query Only)

Returns whether the specified spurious signal exceeds the limit or not.

<b>Conditions</b>	Measurement views: Spurious
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCH:SPURious:SPUR<x>:LIMIT:VIOLation?

---

<b>Arguments</b>	None
<b>Returns</b>	0 (under the limit) or 1 (over the limit).
<b>Examples</b>	<code>FETCH:SPURIOUS:SPUR1:LIMIT:VIOLATION?</code> might return 1, indicating that Spurious #1 exceeds the limit.

## FETCH:SPURious:SPUR<x>:RANGe? (Query Only)

Returns the frequency range in which the specified spurious signal occurred.

<b>Conditions</b>	Measurement views: Spurious
<b>Group</b>	Fetch commands
<b>Syntax</b>	<code>FETCH:SPURious:SPUR&lt;x&gt;:RANGe?</code>
<b>Arguments</b>	None
<b>Returns</b>	<string> "A" to "T" representing Range A to T, respectively.
<b>Examples</b>	<code>FETCH:SPURIOUS:SPUR1:RANGE</code> might return "E", indicating that Spurious #1 is in Range E.

## FETCH:SQUality:FREQuency:DEViation? (Query Only)

Returns the frequency deviation in the signal quality measurement.

This command is valid when [\[SENSe\]:DDEMod:MODulation:TYPE](#) is set to C4FM, FSK2, FSK4, FSK8, or FSK16.

<b>Conditions</b>	Measurement views: Signal quality
<b>Group</b>	Fetch commands
<b>Syntax</b>	<code>FETCH:SQUality:FREQuency:DEViation?</code>

<b>Arguments</b>	None
<b>Returns</b>	<NRf> Frequency deviation in Hz.
<b>Examples</b>	FETCH:SQUALITY:FREQUENCY:DEVIATION? might return 12.68E+3, indicating the frequency deviation is 12.68 kHz.

## FETCh:SQUality:FREQUency:DEVIation:TABLE? (Query Only)

Returns the number of columns and the values in the frequency deviation table for a signal quality measurement.

This command is valid when [SENSE]:DDEMod:MODulation:TYPE is set to C4FM, FSK2, FSK4, FSK8, or FSK16.

<b>Conditions</b>	Measurement views: Signal quality
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCh:SQUality:FREQUency:DEVIation:TABLE?
<b>Arguments</b>	None
<b>Returns</b>	<p>&lt;Dev_Num&gt;, {&lt;Freq_dev_Max&gt;, &lt;Freq_dev_Min&gt;, &lt;Freq_dev_Avg&gt;}</p> <p>Where</p> <p>&lt;Dev_Num&gt; ::= &lt;NR1&gt; is the number of columns in the frequency deviation table.                      = 2 (2FSK), 4 (4FSK, C4FM), 8 (8FSK), or 16 (16FSK)</p> <p>&lt;Freq_dev_Max&gt; ::= &lt;NRf&gt; is the maximum frequency deviation in Hz.</p> <p>&lt;Freq_dev_Min&gt; ::= &lt;NRf&gt; is the minimum frequency deviation in Hz.</p> <p>&lt;Freq_dev_Avg&gt; ::= &lt;NRf&gt; is the average frequency deviation in Hz.</p> <p>The dataset &lt;Freq_dev_Max&gt;, &lt;Freq_dev_Min&gt;, &lt;Freq_dev_Avg&gt; is returned for each symbol in ascending order of its level (for example, in order of symbol -3, -1, +1, and +3 for 4FSK).</p>
<b>Examples</b>	<p>FETCH:SQUALITY:FREQUENCY:DEVIATION:TABLE? might return 2, 1.257E+3, 1.039E+3, 1.162E+3, 1.586E+3, 1.298E+3, 1.425E+3 for the frequency signal, populating the results table as follows.</p>

Deviations	-1	+1
Maximum	1.257 kHz	1.586 kHz
Minimum	1.039 kHz	1.298 kHz
Average	1.162 kHz	1.425 kHz

## FETCh:SQUality:FREQuency:ERRor? (Query Only)

Returns the frequency error in the signal quality measurement.

<b>Conditions</b>	Measurement views: Signal quality
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCh:SQUality:FREQuency:ERRor?
<b>Arguments</b>	None
<b>Returns</b>	<NRf> Frequency error in Hz.
<b>Examples</b>	FETCh:SQUality:FREQuency:ERRor? might return 612.043E+3, indicating that the frequency error is 612.043 kHz.

## FETCh:SQUality:GAIN:IMBalance? (Query Only)

Returns the gain imbalance in the signal quality measurement.

<b>Conditions</b>	Measurement views: Signal quality
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCh:SQUality:GAIN:IMBalance?
<b>Arguments</b>	None
<b>Returns</b>	<NRf> Gain imbalance in dB.

**Examples**     `FETCH:SQUALITY:GAIN:IMBALANCE?` might return `-57.746E-3`, indicating that the gain imbalance is `-0.057746` dB.

## **FETCH:SQUALITY:ORIGIN:OFFSET? (Query Only)**

Returns the origin offset in the signal quality measurement.

**Conditions**     Measurement views: Signal quality

**Group**            Fetch commands

**Syntax**           `FETCH:SQUALITY:ORIGIN:OFFSET?`

**Arguments**       None

**Returns**           <NRF> Origin offset in dB.

**Examples**        `FETCH:SQUALITY:ORIGIN:OFFSET?` might return `-44.968`, indicating that the origin offset is `-44.968` dB.

## **FETCH:SQUALITY:PEAK:EVM? (Query Only)**

Returns the peak EVM (%) in the signal quality measurement.

**Conditions**       Measurement views: Signal quality

**Group**            Fetch commands

**Syntax**           `FETCH:SQUALITY:PEAK:EVM?`

**Arguments**       None

**Returns**           <NRF> Peak EVM in percent (%).

**Examples**        `FETCH:SQUALITY:PEAK:EVM?` might return `4.276`, indicating that the peak EVM is `4.276%`.

## FETCh:SQUality:PEAK:EVM:DB? (Query Only)

Returns the peak EVM (dB) in the signal quality measurement.

<b>Conditions</b>	Measurement views: Signal quality
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCh:SQUality:PEAK:EVM:DB?
<b>Arguments</b>	None
<b>Returns</b>	<NRf> Peak EVM in dB.
<b>Examples</b>	FETCh:SQUALITY:PEAK:EVM:DB? might return -27.358, indicating that the peak EVM is -27.358 dB.

## FETCh:SQUality:PEAK:EVM:DB:OFFSet? (Query Only)

Returns the peak offset EVM (dB) in the signal quality measurement.

This command is valid when [\[SENSe\]:DDEMod:MODulation:TYPE](#) is set to OQPSK or SOQPSK.

<b>Conditions</b>	Measurement views: Signal quality
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCh:SQUality:PEAK:EVM:DB:OFFSet?
<b>Arguments</b>	None
<b>Returns</b>	<NRf> Peak offset EVM in dB.
<b>Examples</b>	FETCh:SQUALITY:PEAK:EVM:DB:OFFSET? might return -37.624, indicating the peak offset EVM is -37.624 dB.

## FETCH:SQUALITY:PEAK:EVM:LOCATION? (Query Only)

Returns the time at which the EVM is peak.

**Conditions** Measurement views: Signal quality

**Group** Fetch commands

**Syntax** FETCH:SQUALITY:PEAK:EVM:LOCATION?

**Arguments** None

**Returns** <NRF> The time in symbol number at which the EVM is peak.  
The unit can be changed by the [SENSE]:DDEMod:TIME:UNITs command.

**Examples** FETCH:SQUALITY:PEAK:EVM:LOCATION? might return 68.000, indicating that the EVM is peak at symbol #68.000.

## FETCH:SQUALITY:PEAK:EVM:LOCATION:OFFSET? (Query Only)

Returns the time at which the offset EVM is peak.

This command is valid when [SENSE]:DDEMod:MODulation:TYPE is set to OQPSK or SOQPSK.

**Conditions** Measurement views: Signal quality

**Group** Fetch commands

**Syntax** FETCH:SQUALITY:PEAK:EVM:LOCATION:OFFSET?

**Arguments** None

**Returns** <NRF> The time in symbol number at which the offset EVM is peak.  
The unit can be changed by the [SENSE]:DDEMod:TIME:UNITs command.

**Examples** FETCH:SQUALITY:PEAK:EVM:LOCATION:OFFSET? might return 123.00, indicating that the offset EVM is peak at symbol #123.



## FETCh:SQUality:PEAK:EVM:OFFSet? (Query Only)

Returns the peak offset EVM (%) in the signal quality measurement.

This command is valid when [\[SENSe\]:DDEMod:MODulation:TYPE](#) is set to OQPSK or SOQPSK.

<b>Conditions</b>	Measurement views: Signal quality
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCh:SQUality:PEAK:EVM:OFFSet?
<b>Arguments</b>	None
<b>Returns</b>	<NRf> Peak offset EVM in percent (%).
<b>Examples</b>	FETCh:SQUALITY:PEAK:EVM:OFFSET? might return 1.298, indicating the peak offset EVM is 1.298%.

## FETCh:SQUality:PEAK:FERRor? (Query Only)

Returns the peak FSK error in the signal quality measurement.

This command is valid when [\[SENSe\]:DDEMod:MODulation:TYPE](#) is set to FSK2, FSK4, FSK8, or FSK16.

<b>Conditions</b>	Measurement views: Signal quality
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCh:SQUality:PEAK:FERRor?
<b>Arguments</b>	None
<b>Returns</b>	<NRf> Peak FSK error in percent (%).

**Examples**     `FETCH:SQUALITY:PEAK:FERROR?` might return 9.136, indicating the peak FSK error is 9.136%.

## **FETCH:SQUALITY:PEAK:MERROR? (Query Only)**

Returns the peak magnitude error (%) in the signal quality measurement.

**Conditions**     Measurement views: Signal quality

**Group**            Fetch commands

**Syntax**           `FETCH:SQUALITY:PEAK:MERROR?`

**Arguments**       None

**Returns**           <NRF> Peak magnitude error in percent (%).

**Examples**     `FETCH:SQUALITY:PEAK:MERROR?` might return 3.595, indicating that the peak magnitude error is 3.595%.

## **FETCH:SQUALITY:PEAK:MERROR:DB? (Query Only)**

Returns the peak magnitude error (dB) in the signal quality measurement.

**Conditions**     Measurement views: Signal quality

**Group**            Fetch commands

**Syntax**           `FETCH:SQUALITY:PEAK:MERROR:DB?`

**Arguments**       None

**Returns**           <NRF> Peak magnitude error in dB.

**Examples**     `FETCH:SQUALITY:PEAK:MERROR:DB?` might return -28.583, indicating that the magnitude error is -28.583 dB.

## FETCh:SQUality:PEAK:MERRor:LOCation? (Query Only)

Returns the time at which the magnitude error is peak.

<b>Conditions</b>	Measurement views: Signal quality
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCh:SQUality:PEAK:MERRor:LOCation?
<b>Arguments</b>	None
<b>Returns</b>	<NRf> The time in symbol number at which the magnitude error is peak. The unit can be changed by the <a href="#">[SENSE]:DDEMod:TIME:UNITs</a> command.
<b>Examples</b>	FETCh:SQUALITY:PEAK:MERROR:LOCATION? might return 68.000, indicating that the magnitude error is peak at symbol #68.

## FETCh:SQUality:PEAK:PERRor? (Query Only)

Returns the peak phase error in the signal quality measurement.

<b>Conditions</b>	Measurement views: Signal quality
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCh:SQUality:PEAK:PERRor?
<b>Arguments</b>	None
<b>Returns</b>	<NRf> Peak phase error in degrees.
<b>Examples</b>	FETCh:SQUALITY:PEAK:PERROR? might return 1.907, indicating that the peak phase error is 1.907 °.

## **FETCh:SQUality:PEAK:PERRor:LOCation? (Query Only)**

Returns the time at which the phase error is peak.

**Conditions** Measurement views: Signal quality

**Group** Fetch commands

**Syntax** FETCh:SQUality:PEAK:PERRor:LOCation?

**Arguments** None

**Returns** <NRF> The time in symbol number at which the phase error is peak.  
The unit can be changed by the [SENSE]:DDEMod:TIME:UNITs command.

**Examples** FETCh:SQUALITY:PEAK:PERROR:LOCATION? might return 68.000, indicating that the phase error is peak at symbol #68.

## **FETCh:SQUality:QUADrature:ERRor? (Query Only)**

Returns the quadrature error in the signal quality measurement.

**Conditions** Measurement views: Signal quality

**Group** Fetch commands

**Syntax** FETCh:SQUality:QUADrature:ERRor?

**Arguments** None

**Returns** <NRF> Quadrature error in degrees.

**Examples** FETCh:SQUALITY:QUADRATURE:ERROR? might return -14.264E-3, indicating that the quadrature error is -0.014264°.

## FETCH:SQUALITY:RHO? (Query Only)

Returns the  $\rho$  (waveform quality) value in the signal quality measurement.

**Conditions** Measurement views: Signal quality

**Group** Fetch commands

**Syntax** FETCH:SQUALITY:RHO?

**Arguments** None

**Returns** <NRf>  $\rho$  value.

**Examples** FETCH:SQUALITY:RHO? might return 998.703E-3, indicating that  $\rho$  is 0.998703.

## FETCH:SQUALITY:RMS:EVM? (Query Only)

Returns the RMS EVM (%) in the signal quality measurement.

**Conditions** Measurement views: Signal quality

**Group** Fetch commands

**Syntax** FETCH:SQUALITY:RMS:EVM?

**Arguments** None

**Returns** <NRf> RMS EVM in percent (%).

**Examples** FETCH:SQUALITY:RMS:EVM? might return 2.417, indicating that the RMS EVM is 2.417%.

## FETCh:SQUality:RMS:EVM:DB? (Query Only)

Returns the RMS EVM (dB) in the signal quality measurement.

**Conditions** Measurement views: Signal quality

**Group** Fetch commands

**Syntax** FETCh:SQUality:RMS:EVM:DB?

**Arguments** None

**Returns** <NRF> RMS EVM in dB.

**Examples** FETCh:SQUality:RMS:EVM:DB? might return -32.356, indicating that the RMS EVM is -32.356 dB.

## FETCh:SQUality:RMS:EVM:DB:OFFSet? (Query Only)

Returns the RMS offset EVM (dB) in the signal quality measurement.

This command is valid when [\[SENSe\]:DDEMod:MODulation:TYPE](#) is set to OQPSK or SOQPSK.

**Conditions** Measurement views: Signal quality

**Group** Fetch commands

**Syntax** FETCh:SQUality:RMS:EVM:DB:OFFSet?

**Arguments** None

**Returns** <NRF> RMS offset EVM in dB.

**Examples** FETCh:SQUality:RMS:EVM:DB:OFFSet? might return -41.276, indicating the RMS offset EVM is -41.276 dB.

## FETCh:SQUality:RMS:EVM:OFFSet? (Query Only)

Returns the RMS offset EVM (%) in the signal quality measurement.

This command is valid when [\[SENSe\]:DDEMod:MODulation:TYPE](#) is set to OQPSK or SOQPSK.

<b>Conditions</b>	Measurement views: Signal quality
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCh:SQUality:RMS:EVM:OFFSet?
<b>Arguments</b>	None
<b>Returns</b>	<NRf> RMS offset EVM in percent (%).
<b>Examples</b>	FETCh:SQUality:RMS:EVM:OFFSet? might return 0.783, indicating the RMS offset EVM is 0.783%.

## FETCh:SQUality:RMS:FERRor? (Query Only)

Returns the RMS FSK error percent in the signal quality measurement.

This command is valid when [\[SENSe\]:DDEMod:MODulation:TYPE](#) is set to FSK2, FSK4, FSK8, or FSK16.

<b>Conditions</b>	Measurement views: Signal quality
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCh:SQUality:RMS:FERRor?
<b>Arguments</b>	None
<b>Returns</b>	<NRf> RMS FSK error in percent (%).

**Examples**     `FETCH:SQUALITY:RMS:FERROR?` might return 1.815, indicating the RMS FSK error is 1.815%.

## **FETCH:SQUALITY:RMS:MER:DB? (Query Only)**

Returns the RMS MER (Modulation Error Ratio) in dB in the signal quality measurement.

**Conditions**     Measurement views: Signal quality

**Group**            Fetch commands

**Syntax**           `FETCH:SQUALITY:RMS:MER:DB?`

**Arguments**       None

**Returns**           <NRF> RMS MER in dB.

**Examples**        `FETCH:SQUALITY:RMS:MER:DB?` might return 27.394, indicating that the RMS MER is 27.394 dB.

## **FETCH:SQUALITY:RMS:MERROR? (Query Only)**

Returns the RMS magnitude error (%) in the signal quality measurement.

**Conditions**       Measurement views: Signal quality

**Group**            Fetch commands

**Syntax**           `FETCH:SQUALITY:RMS:MERROR?`

**Arguments**       None

**Returns**           <NRF> RMS magnitude error in percent (%).



**Examples**     `FETCH:SQUALITY:RMS:MERROR?` might return `1.837`, indicating that the RMS magnitude error is 1.837%.

## **FETCH:SQUALITY:RMS:MERROR:DB? (Query Only)**

Returns the RMS magnitude error (dB) in the signal quality measurement.

**Conditions**     Measurement views: Signal quality

**Group**     Fetch commands

**Syntax**     `FETCH:SQUALITY:RMS:MERROR:DB?`

**Arguments**     None

**Returns**     `<NRf>` RMS MERROR in dB.

**Examples**     `FETCH:SQUALITY:RMS:MERROR:DB?` might return `-34.706`, indicating that the magnitude error is -34.706 dB.

## **FETCH:SQUALITY:RMS:PERROR? (Query Only)**

Returns the RMS phase error in the signal quality measurement.

**Conditions**     Measurement views: Signal quality

**Group**     Fetch commands

**Syntax**     `FETCH:SQUALITY:RMS:PERROR?`

**Arguments**     None

**Returns**     `<NRf>` RMS phase error in degrees.

**Examples**     `FETCH:SQUALITY:RMS:PERROR?` might return `893.472E-3`, indicating that the RMS phase error is 0.893472 °.

## FETCh:SQUality:SYMBol:LENGth? (Query Only)

Returns the number of analyzed symbols.

**Group** Fetch commands

**Syntax** FETCh:SQUality:SYMBol:LENGth?

### Related Commands

**Returns** <NR1> indicates the length of the synch word in symbols.

**Examples** FETCh:SQUality:SYMBol:LENGth? might return 3, indicating the length is three symbols.

## FETCh:SQUality:SYMBol:RATE? (Query Only)

Returns the value of the calculated symbol rate in Hz.

**Conditions** Measurement views: Signal quality

It is valid when the modulation type is 2|4|8|16FSK and [:SENSe]:DDEMod:SYMBol:RATE:SEARCh is ON.

**Group** Fetch commands

**Syntax** FETCh:SQUality:SYMBol:RATE?

**Related Commands** [\[SENSe\]:DDEMod:SYMBol:RATE:SEARCh](#)

**Returns** <NRf> is the calculated symbol rate in Hz.

**Examples** FETCh:SQUality:SYMBol:RATE? might return 95.24E+3, indicating the calculated symbol rate is 95.24 kHz.

## FETCh:SQUality:SYMBol:RATE:ERRor? (Query Only)

Returns the value of the symbol rate error in percent (%).

<b>Conditions</b>	Measurement views: Signal quality It is valid when the modulation type is 2 4 8 16FSK and [:SENSe]:DDEMod:SYMBOL:RATE:SEARCH is ON.
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCH:SQUALITY:SYMBOL:RATE:ERROR?
<b>Related Commands</b>	<a href="#">[SENSe]:DDEMod:SYMBOL:RATE:SEARCH</a>
<b>Returns</b>	<NRf> is the symbol error percent (%).
<b>Examples</b>	FETCH:SQUALITY:SYMBOL:RATE:ERROR? might return -0.002, indicating that the symbol rate error is -0.002%.

## FETCH:TDiagram:FERRor? (Query Only)

Returns the frequency error in the trellis diagram measurement.

<b>Conditions</b>	Measurement views: Trellis diagram
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCH:TDiagram:FERRor?
<b>Arguments</b>	None
<b>Returns</b>	<freq_error> ::= <NRf> is the frequency error in Hz.
<b>Examples</b>	FETCH:TDiagram:FERRor? might return -10.7E+3, indicating the frequency error is -10.7 kHz.

## FETCH:TDiagram:TRACe? (Query Only)

Returns the Trellis diagram trace data.

<b>Conditions</b>	Measurement views: Trellis diagram
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCh:TDIagram:TRACE?
<b>Arguments</b>	None
<b>Returns</b>	#<num_digit><num_byte><Y(1)><X(1)><Y(2)><X(2)> . . . <Y(n)><X(n)> Where <num_digit> is the number of digits in <num_byte>. <num_byte> is the number of bytes of data that follow. <Y(n)><X(n)> is the phase in degrees and the time in symbols pair at the n <sup>th</sup> data point. The 4-byte little endian floating-point format specified in IEEE 488.2.
<b>Examples</b>	FETCh:TDIAGRAM:TRACE? might return #3160xxxx . . . (160-byte data) for the Trellis diagram trace.

## FETCh:TOVerview? (Query Only)

Returns the trace data in the time overview.

<b>Conditions</b>	Measurement views: Time overview
<b>Group</b>	Fetch commands
<b>Syntax</b>	FETCh:TOVerview?
<b>Arguments</b>	None
<b>Returns</b>	#<num_digit><num_byte><data(1)><data(2)> . . . <data(n)> Where <num_digit> is the number of digits in <num_byte>. <num_byte> is the number of bytes of data that follow. <data(n)> is the amplitude in dBm at the n <sup>th</sup> data point, 4-byte little endian floating-point format specified in IEEE 488.2. The unit can be changed by the [SENSe]:POWer:UNITs command.

**Examples**     `FETCH:TOVERVIEW?` might return `#43204xxxx...` (3204-byte data) for the trace in the time overview.

## \*IDN? (Query Only)

Returns the analyzer identification code.

**Conditions**     Measurement views: All

**Group**     IEEE common commands

**Syntax**     `*IDN?`

**Arguments**     None

**Returns**     The analyzer identification code in the following format

```
TEKTRONIX,RSA61XXA,<serial_number>,<firmware_version>
```

Where

TEKTRONIX indicates that the manufacturer is Tektronix.

RSA61XXA is the model number (RSA6106A or RSA6114A).

<serial\_number> is the serial number.

<firmware\_version> is the firmware version.

**Examples**     `*IDN?` might return the response  
`TEKTRONIX,RSA6114A,B000111,FV1.0.1500.`

## INITiate:CONTinuous

Determines whether to place the analyzer in the single or the continuous acquisition mode.

**Conditions**     Measurement views: All

**Group**     Initiate commands

**Syntax**     `INITiate:CONTinuous { OFF | ON | 0 | 1 }`  
`INITiate:CONTinuous?`

**Related Commands**    [INITiate\[:IMMEDIATE\]](#)

**Arguments**    OFF or 0 places the analyzer in the single acquisition mode. To initiate the acquisition, use the `INITiate[:IMMEDIATE]` command. To stop acquisition when a trigger is not present, and to avoid a 2.7 hour time-out, send the free-run trigger command, `TRIGger:SEQuence:STATus 0`. Then, send the command `INITiate:CONTInuous OFF`. This sequence ensures a minimal delay before the `INIT:CONT OFF` command completes.

ON or 1 places the analyzer in the continuous acquisition mode. To initiate the acquisition, use the `INITiate[:IMMEDIATE]` command. To stop the acquisition in the continuous mode, send the following command: `INITiate:CONTInuous OFF`

**Examples**    `INITIATE:CONTINUOUS ON` places the analyzer in the continuous acquisition mode.

## INITiate[:IMMEDIATE] (No Query Form)

Starts input signal acquisition.

---

**NOTE.** *It is an overlapped command, which does not finish executing before the next command starts executing. Use the `*OPC(?)` and `*WAI` commands to synchronize all pending operations to the execution of this command.*

---

**Conditions**    Measurement views: All

**Group**    Initiate commands

**Syntax**    `INITiate[:IMMEDIATE]`

**Related Commands**    [\\*OPC](#), [\\*TRG](#), [\\*WAI](#), [INITiate:CONTInuous](#)

**Arguments**    None

**Examples**    `INITIATE:IMMEDIATE` starts input signal acquisition.

## INPut:CORRection:EXTErnal:EDIT<x>:INTERpolation

Selects or queries the interpolation setting to use with the indicated external gain table.

**Conditions** Measurement views: All

**Group** Input commands

**Syntax** INPut:CORRection:EXTErnal:EDIT<x>:INTERpolation { LINEar | LOGarithmic }  
INPut:CORRection:EXTErnal:EDIT<x>:INTERpolation

**Related Commands** [INPut:CORRection:EXTErnal:EDIT<x>:NEW](#)

**Arguments** LINEar select when the frequency scale of the spectrum or spurious measurements are linear.

LOGarithmic select when the frequency scale of the spectrum is logarithmic.

**Examples** INPut:CORRection:EXTErnal:EDIT1:INTERpolation LINEar uses linear interpolation when applying External correction Table one (1) to the chosen waveforms.

## INPut:CORRection:EXTErnal:EDIT<x>:NEW

Creates the indicated (x) external loss table from a series of frequency and gain value pairs.

**Conditions** Measurement views: All

**Group** Input commands

**Syntax** INPut:CORRection:EXTErnal:EDIT<x>:NEW  
<freq(1)>,<gain(1)>,<freq(2)>,<gain(2)>,...,<freq(n)>,<gain(n)>  
INPut:CORRection:EXTErnal:EDIT<x>:NEW?

**Related Commands** [INPut:CORRection:EXTErnal:TYPE](#)

- Arguments** <freq(n)>, <gain(n)> specifies a pair of frequency (<NR3> in Hz) and gain (+ | -<NR3> in dB) in the external correction table.
- The setting range is:  
 Frequency: 0 to 6.2 GHz for the RSA6106A) and 0 to 14 GHz for the RSA6114A.  
 Loss: -50 to +30 dB. Negative values indicate loss and positive values indicate gain. Resolution is 0.1 dB.
- Examples** `INPut:CORREction:EXTErnal:EDIT?:NEW 1.0E+9,-2.2,-1.5E+9,-2.3` creates the External correction Table specifying a loss of 2.2 dB at 1 GHz and a loss of 2.3 dB at 1.5 GHz.

## INPut:CORREction:EXTErnal:TYPE

Selects or queries the data type to use when applying the external loss table corrections.

- Conditions** Measurement views: All
- Group** Input commands
- Syntax** `INPut:CORREction:EXTErnal:TYPE { TRACE | DATA }`  
`INPut:CORREction:EXTErnal:TYPE`
- Related Commands** [INPut:CORREction:EXTErnal:EDIT<x>:NEW](#)
- Arguments** TRACE selects traces in the Spectrum, Spectrogram, Spurious, and Amplitude versus Time views. Selecting TRACE disables the CALibration:CORREction:EXTErnal:GAIN:STATE command.
- DATA selects all acquired data. Selecting DATA enables the CALibration:CORREction:EXTErnal:GAIN:STATE command.
- Examples** `INPut:CORREction:EXTErnal:TYPE TRACE` selects traces to apply the external loss table corrections.

## INPut:{MLEVel|RLEVel}

Sets or queries the reference level.



<b>Conditions</b>	Measurement views: All
<b>Group</b>	Input commands
<b>Syntax</b>	INPut:{MLEve RLEve} <value> INPut:{MLEve RLEve}?
<b>Arguments</b>	<value> ::= <NRf> specifies the reference level. Range: -170 to +50 dBm.
<b>Examples</b>	INPUT:RLEVEL -10 sets the reference level to -10 dBm.

## INPut[:RF]:ATTenuation

Sets or queries the input attenuation. Programming a specified attenuation sets INPut[:RF]:ATTenuation:AUTO OFF.

<b>Conditions</b>	Measurement views: All
<b>Group</b>	Input commands
<b>Syntax</b>	INPut[:RF]:ATTenuation <value> INPut[:RF]:ATTenuation?
<b>Related Commands</b>	<a href="#">INPut[:RF]:ATTenuation:AUTO</a>
<b>Arguments</b>	<value> ::= <NR1> specifies the input attenuation. Range: 0 to 75 dB in 5 dB steps.
<b>Examples</b>	INPUT:RF:ATTENUATION 20 sets the input attenuation to 20 dB.

## INPut[:RF]:ATTenuation:AUTO

Determines whether to set the input attenuation automatically or manually.

<b>Conditions</b>	Measurement views: All
-------------------	------------------------

<b>Group</b>	Input commands
<b>Syntax</b>	INPut[:RF]:ATTenuation:AUTO { OFF   ON   0   1 } INPut[:RF]:ATTenuation:AUTO?
<b>Arguments</b>	OFF or 0 specifies that the input attenuation is set manually. To set it, use the <a href="#">INPut[:RF]:ATTenuation</a> command.  ON or 1 specifies that the input attenuation is set automatically according to the reference level.
<b>Examples</b>	INPUT:RF:ATTENUATION:AUTO ON specifies that the input attenuation is set automatically.

## INPut[:RF]:ATTenuation:MONitor:STATe

Determines whether to enable or disable to monitor attenuator use.

<b>Conditions</b>	Measurement views: All
<b>Group</b>	Input commands
<b>Syntax</b>	INPut[:RF]:ATTenuation:MONitor:STATe { OFF   ON   0   1 } INPut[:RF]:ATTenuation:MONitor:STATe?
<b>Arguments</b>	OFF or 0 disables to monitor attenuator use.  ON or 1 enables to monitor attenuator use.
<b>Examples</b>	INPUT:RF:ATTENUATION:MONITOR:STATE ON enables to monitor attenuator use.

## INPut[:RF]:GAIN:STATe

Determines whether to enable or disable the internal pre-amp.

<b>Conditions</b>	Measurement views: All (Option 01 only)
<b>Group</b>	Input commands

<b>Syntax</b>	<code>INPut[:RF]:GAIN:STATE { OFF   ON   0   1 }</code> <code>INPut[:RF]:GAIN:STATE?</code>
<b>Arguments</b>	OFF or 0 disables the internal pre-amp. ON or 1 enables the internal pre-amp.
<b>Examples</b>	<code>INPUT:RF:GAIN:STATE ON</code> enables the internal pre-amp.

## MMEMory:{AM|FM|PM}:LOAD:TRACe (No Query Form)

Loads the AM/FM/PM measurement trace data from the specified file.

<b>Conditions</b>	Measurement views: AM, FM, PM
<b>Group</b>	Mass memory commands
<b>Syntax</b>	<code>MMEMory:{AM FM PM}:LOAD:TRACe &lt;file_name&gt;</code>
<b>Arguments</b>	<code>&lt;file_name&gt;::=&lt;string&gt;</code> specifies the file from which to load trace data. The file extension is <code>.AmVsTime</code> (AM), <code>.FmVsTime</code> (FM), or <code>.PmVsTime</code> (PM). You can omit the extension.
<b>Examples</b>	<code>MMEMORY:AM:LOAD:TRACE "Sample1"</code> loads the trace data from the <i>Sample1.AmVsTime</i> file in the AM measurement.

## MMEMory:{AM|FM|PM}:SHOW:TRACe<x>

Enables display of a recalled trace file in Trace<x>. The result is the same as selecting “Show recalled trace” in the Recall traces dialog box or selecting Show in the Trace Overview display.

<b>Conditions</b>	Measurement views: AM, FM, PM
<b>Group</b>	Mass memory commands
<b>Syntax</b>	<code>MMEMory:{AM FM PM}:SHOW:TRACe&lt;x&gt; { OFF   ON   0   1 }</code> <code>MMEMory:{AM FM PM}:SHOW:TRACe&lt;x&gt;?</code>

<b>Related Commands</b>	<a href="#">MMEMemory:{AM FM PM}:LOAD:TRACe</a>
<b>Arguments</b>	OFF or 0 disables display of the recalled trace. ON or 1 enables display of the recalled trace.
<b>Examples</b>	MMEMemory:FM:SHOW:TRACe2 ON enables display of the recalled data loaded in Trace2.

## MMEMemory:{AM|FM|PM}:STORE:TRACe (No Query Form)

Stores the AM/FM/PM measurement trace data in the specified file.

<b>Conditions</b>	Measurement views: AM, FM, PM
<b>Group</b>	Mass memory commands
<b>Syntax</b>	MMEMemory:{AM FM PM}:STORE:TRACe <file_name>
<b>Arguments</b>	<file_name>::=<string> specifies the file from which to load trace data. The file extension is .AmVsTime (AM), .FmVsTime (FM), or .PmVsTime (PM). You can omit the extension.
<b>Examples</b>	MMEMemory:AM:STORE:TRACe "Sample1" stores the trace data in the <i>Sample1.AmVsTime</i> file in the AM measurement.

## MMEMemory:AVTime:LOAD:TRACe<x> (No Query Form)

Loads the Amplitude versus Time trace data from the specified file.

The parameter <x> = 1 to 3; Trace 4 (math trace) is invalid.

<b>Conditions</b>	Measurement views: Amplitude versus Time
<b>Group</b>	Mass memory commands
<b>Syntax</b>	MMEMemory:AVTime:LOAD:TRACe<x> <file_name>

**Arguments** `<file_name>::=<string>` specifies the file from which to load trace data. The file extension is `.AmplVsTime`. You can omit the extension.

**Examples** `MMEMORY:AVTIME:LOAD:TRACE1 "Sample1"` loads Trace 1 data from the `Sample1.AmplVsTime` file.

## MMEMory:AVTime:SHOW:TRACe<x>

Enables display of a recalled trace file in Trace<x>. The result is the same as selecting “Show recalled trace” in the Recall traces dialog box or selecting Show in the Trace Overview display.

**Conditions** Measurement views: Amplitude versus Time

**Group** Mass memory commands

**Syntax** `MMEMory:AVTime:SHOW:TRACe<x> { OFF | ON | 0 | 1 }`  
`MMEMory:AVTime:SHOW:TRACe<x>?`

**Related Commands** [MMEMory:AVTime:LOAD:TRACe<x>](#)

**Arguments** OFF or 0 disables display of the recalled trace.  
 ON or 1 enables display of the recalled trace.

**Examples** `MMEMory:AVTime:SHOW:TRACe2 ON` enables display of the recalled data loaded in Trace2.

## MMEMory:AVTime:STORE:TRACe<x> (No Query Form)

Stores the Amplitude versus Time trace data in the specified file.  
 The parameter <x> = 1 to 4; All traces are valid.

**Conditions** Measurement views: Amplitude versus Time

**Group** Mass memory commands

**Syntax** `MMEMory:AVTime:STORE:TRACe<x> <file_name>`

**Arguments**     `<file_name>::=<string>` specifies the file in which to store trace data. The file extension is `.AmplVsTime`. You can omit the extension.

**Examples**     `MMEMORY:AVTIME:STORE:TRACE1 "Sample1"` stores Trace 1 data in the `Sample1.AmplVsTime` file.

## **MMEMory:CALibration:LOAD:CORRection:EXTErnal:EDIT<x> (No Query Form)**

Loads the external loss table from a specified file.

The parameter `<x>` = 1 to 3 represent External Loss Table 1 to 3, respectively.

**Conditions**     Measurement views: All

**Group**            Mass memory commands

**Syntax**          `MMEMory:CALibration:LOAD:CORRection:EXTErnal:EDIT<x>`  
`<file_name>`

**Arguments**     `<file_name>::=<string>` specifies the file to load the external loss table from. The file extension is `.csv`. You can omit the extension.

**Examples**     `MMEMORY:CALIBRATION:LOAD:CORRECTION:EXTERNAL:EDIT1 "Table1"` loads the External Loss Table 1 from the `Table1.csv` file.

## **MMEMory:CALibration:STORE:CORRection:EXTErnal:EDIT<x> (No Query Form)**

Stores the external loss table to a specified file.

The parameter `<x>` = 1 to 3 represent External Loss Table 1 to 3, respectively.

**Conditions**     Measurement views: All

**Group**            Mass memory commands

**Syntax**          `MMEMory:CALibration:STORE:CORRection:EXTErnal:EDIT<x>`  
`<file_name>`

**Arguments** `<file_name>::=<string>` specifies the file to store the external loss table to. The file extension is `.csv`. You can omit the extension.

**Examples** `MMEMORY:CALIBRATION:STORE:CORRECTION:EXTERNAL:EDIT1 "Table1"` stores the External Loss Table 1 to the `Table1.csv` file.

## MMEMory:CCDF:LOAD:TRACe<x> (No Query Form)

Loads the CCDF trace data from the specified file.

**Conditions** Measurement views: CCDF

**Group** Mass memory commands

**Syntax** `MMEMory:CCDF:LOAD:TRACe<x> <file_name>`

**Arguments** `<file_name>::=<string>` specifies the file from which to load trace data. The file extension is `.CCDF`. You can omit the extension.

**Examples** `MMEMORY:CCDF:LOAD:TRACE1 "Sample1"` loads Trace 1 data from the `Sample1.CCDF` file.

## MMEMory:CCDF:SHOW:TRACe<x>

Enables display of a recalled trace file in Trace<x>. The result is the same as selecting “Show recalled trace” in the Recall traces dialog box or selecting Show in the Trace Overview display.

**Conditions** Measurement views: CCDF

**Group** Mass memory commands

**Syntax** `MMEMory:CCDF:SHOW:TRACe<x> { OFF | ON | 0 | 1 }`  
`MMEMory:CCDF:SHOW:TRACe<x>?`

**Related Commands** [MMEMory:CCDF:LOAD:TRACe<x>](#)

**Arguments** OFF or 0 disables display of the recalled trace.  
ON or 1 enables display of the recalled trace.

**Examples** `MMEMemory:CCDF:SHOW:TRACE2 ON` enables display of the recalled data loaded in Trace2.

## MMEMemory:CCDF:STORE:TRACE<x> (No Query Form)

Stores the CCDF trace data in the specified file.

**Conditions** Measurement views: CCDF

**Group** Mass memory commands

**Syntax** `MMEMemory:CCDF:STORE:TRACE<x> <file_name>`

**Arguments** `<file_name>::=<string>` specifies the file in which to store trace data. The file extension is `.CCDF`. You can omit the extension.

**Examples** `MMEMemory:CCDF:STORE:TRACE1 "Sample1"` stores Trace 1 data in the *Sample1.CCDF* file.

## MMEMemory:DDEMod:LOAD:FILTer:MEASurement:UOTHer (No Query Form)

Loads a user-defined measurement filter from the specified file.

**Group** Mass memory commands

**Syntax** `MMEMemory:DDEMod:LOAD:FILTer:MEASurement:UOTHer <file_name>`

**Related Commands** [\[SENSe\]:DDEMod:FILTer:REference](#)  
[\[SENSe\]:DDEMod:FILTer:MEASurement](#)

**Arguments** `<file_name>::=<string>` specifies the filter file to load.



**Examples** `MMEMory:DDEMod:LOAD:FILTer:MEASurement:UOTHer "Table2"` loads User other filter from the file Table2.csv.

## MMEMory:DDEMod:LOAD:FILTer:MEASurement:USER<x> (No Query Form)

Loads the user-defined measurement filter from the specified file. The parameter <x> specifies one of the User Meas Filters, 1 to 3. The filter file must have a .csv file extension, though you may omit the file extension in the command line.

**Group** Mass memory commands

**Syntax** `MMEMory:DDEMod:LOAD:FILTer:MEASurement:USER<x> <file_name>`

**Related Commands** [\[SENSe\]:DDEMod:FILTer:REFerence](#)  
[\[SENSe\]:DDEMod:FILTer:MEASurement](#)

**Arguments** `<file_name>::=<string>` specifies the filter file to load.

**Examples** `MMEMory:DDEMod:LOAD:FILTer:MEASurement:USER1 "Table1"` loads User Meas Filter 1 from the file Table1.csv.

## MMEMory:DDEMod:LOAD:FILTer:REFerence:UOTHer (No Query Form)

Loads the specified user-defined reference filter, UOTHer, from a specified file.

**Group** Mass memory commands

**Syntax** `MMEMory:DDEMod:LOAD:FILTer:REFerence:UOTHer <file_name>`

**Related Commands** [\[SENSe\]:DDEMod:FILTer:REFerence](#)  
[\[SENSe\]:DDEMod:FILTer:MEASurement](#)

**Arguments** `<file_name>::=<string>` specifies the reference filter file to load. The file extension is type .csv.

**Examples** `MMEMory:DDEMOD:LOAD:FILTer:REFERENCE:UOTHer "FinalFilt"` loads the filter file FinalFilt.csv into the filter reference UOTHer.

## MMEMory:DDEMod:LOAD:FILTER:REFERENCE:USER<x> (No Query Form)

Loads the specified user-defined reference filter, USER1 | 2 | 3 from a specified file.

**Group** Mass memory commands

**Syntax** MMEMory:DDEMod:LOAD:FILTER:REFERENCE:USER<x> <file\_name>

**Related Commands** [\[SENSe\]:DDEMod:FILTer:REFerence](#)

**Arguments** <file\_name>::=<string> specifies the reference filter file to load. The file extension is type .csv.

**Examples** MMEMory:DDEMOD:LOAD:FILTER:REFERENCE:USER2 "DUTfil t2" loads the filter file DUTfilt2.csv into the filter reference USER2.

## MMEMory:DDEMod:LOAD:SYMBOL:MAP (No Query Form)

Loads the specified symbol map filename. The setting correlates to the field, User Symbol Map (per Modulation Type) on the Advanced Params tab in the Digital Modulation settings.

**Group** Mass memory commands

**Syntax** MMEMory:DDEMod:LOAD:SYMBOL:MAP <file\_name>

**Related Commands** [\[SENSe\]:DDEMod:MODulation:TYPE](#)

**Arguments** <file\_name>::=<string> specifies the symbol map file to load. The file extension is type .txt.

**Examples** MMEMory:DDEMod:LOAD:SYMBOL:MAP "C:\usymmap.txt" identifies the file to load for the symbol map.

## MMEMory:DPSA:LOAD:TRACe<x> (No Query Form)

Loads the DPX spectrum trace data from the specified file.

The parameter <x> = 1, 2, 3, or 5; TRACe4 (math trace) is invalid.

<b>Conditions</b>	Measurement views: DPX spectrum
<b>Group</b>	Mass memory commands
<b>Syntax</b>	MMEMory:DPSA:LOAD:TRACe<x> <file_name>
<b>Arguments</b>	<file_name>::=<string> specifies the file from which to load trace data. The file extension is .dpt. You can omit the extension.
<b>Examples</b>	MMEMORY:DPSA:LOAD:TRACE1 "Sample1" loads Trace 1 data from the <i>Sample1.dpt</i> file.

## MMEMory:DPSA:SHOW:TRACe<x>

Enables display of a recalled trace file in Trace<x>. The result is the same as selecting “Show recalled trace” in the Recall traces dialog box or selecting Show in the Trace Overview display.

<b>Conditions</b>	Measurement views:DPX spectrum
<b>Group</b>	Mass memory commands
<b>Syntax</b>	MMEMory:DPSA:SHOW:TRACe<x> { OFF   ON   0   1 } MMEMory:DPSA:SHOW:TRACe<x>?
<b>Related Commands</b>	<a href="#">MMEMory:DPSA:LOAD:TRACe&lt;x&gt;</a>
<b>Arguments</b>	OFF or 0 disables display of the recalled trace. ON or 1 enables display of the recalled trace.
<b>Examples</b>	MMEMORY:DPSA:SHOW:TRACE2 ON enables display of the recalled data loaded in Trace2.

## MMEMory:DPSA:STORE:TRACe<x> (No Query Form)

Stores the DPX spectrum trace data in the specified file.

The parameter <x> = 1 to 5; All traces are valid.

<b>Conditions</b>	Measurement views: DPX spectrum
<b>Group</b>	Mass memory commands
<b>Syntax</b>	MMEMory:DPSA:STORE:TRACe<x> <file_name>
<b>Arguments</b>	<file_name> ::= <string> specifies the file in which to store trace data. The file extension is .dpt. You can omit the extension.
<b>Examples</b>	MMEMORY:DPSA:STORE:TRACE1 "Sample1" stores Trace 1 data in the <i>Sample1.dpt</i> file.

## MMEMory:FVTime:LOAD:TRACe (No Query Form)

Loads the Frequency versus Time trace data from the specified file.

<b>Conditions</b>	Measurement views: Frequency versus Time
<b>Group</b>	Mass memory commands
<b>Syntax</b>	MMEMory:FVTime:LOAD:TRACe <file_name>
<b>Arguments</b>	<file_name> ::= <string> specifies the file from which to load trace data. The file extension is .FreqVsTime. You can omit the extension.
<b>Examples</b>	MMEMORY:FVTIME:LOAD:TRACE "Sample1" loads the Frequency versus Time trace data from the <i>Sample1.FreqVsTime</i> file.

## MMEMory:FVTIME:SHOW:TRACe<x>

Enables display of a recalled trace file in Trace<x>. The result is the same as selecting “Show recalled trace” in the Recall traces dialog box or selecting Show in the Trace Overview display.

**Conditions** Measurement views: Frequency versus Time

**Group** Mass memory commands

**Syntax** MMEMory:FVTIME:SHOW:TRACe<x> { OFF | ON | 0 | 1 }  
MMEMory:FVTIME:SHOW:TRACe<x>?

**Related Commands** [MMEMory:FVTime:LOAD:TRACe](#)

**Arguments** OFF or 0 disables display of the recalled trace.  
ON or 1 enables display of the recalled trace.

**Examples** MMEMory:FVTIME:SHOW:TRACe2 ON enables display of the recalled data loaded in Trace2.

## MMEMory:FVTime:STORE:TRACe (No Query Form)

Stores the Frequency versus Time trace data in the specified file.

**Conditions** Measurement views: Frequency versus Time

**Group** Mass memory commands

**Syntax** MMEMory:FVTime:STORE:TRACe <file\_name>

**Arguments** <file\_name>: :=<string> specifies the file in which to store trace data. The file extension is .FreqVsTime. You can omit the extension.

**Examples** MMEMory:FVTIME:STORE:TRACe "Sample1" stores the Frequency versus Time trace data in the *Sample1.FreqVsTime* file.

## MMEemory:IQVTime:LOAD:TRACe:I (No Query Form)

Loads I trace data from the specified file.

**Conditions** Measurement views: RF I&Q versus Time

**Group** Mass memory commands

**Syntax** MMEemory:IQVTime:LOAD:TRACe:I <file\_name>

**Arguments** <file\_name>::=<string> specifies the file from which to load trace data. The file extension is .RFIQVsTime. You can omit the extension.

**Examples** MMEemory:IQVTime:LOAD:TRACe:I "Sample1" loads the I trace data from the *Sample1.RFIQVsTime* file.

## MMEemory:IQVTime:LOAD:TRACe:Q (No Query Form)

Loads Q trace data from the specified file.

**Conditions** Measurement views: RF I&Q versus Time

**Group** Mass memory commands

**Syntax** MMEemory:IQVTime:LOAD:TRACe:Q <file\_name>

**Arguments** <file\_name>::=<string> specifies the file from which to load trace data. The file extension is .RFIQVsTime. You can omit the extension.

**Examples** MMEemory:IQVTime:LOAD:TRACe:Q "Sample2" loads the I trace data from the *Sample2.RFIQVsTime* file.

## MMEemory:IQVTime:SHOW:TRACe:I

Enables display of a recalled trace file in Trace. The result is the same as selecting "Show recalled trace" in the Recall traces dialog box or selecting Show in the Trace Overview display.

<b>Conditions</b>	Measurement views: RF I&Q versus Time
<b>Group</b>	Mass memory commands
<b>Syntax</b>	MMEMory:IQVTIME:SHOW:TRACe:I { OFF   ON   0   1 } MMEMory:IQVTIME:SHOW:TRACe:I?
<b>Related Commands</b>	<a href="#">MMEMory:IQVTime:LOAD:TRACe:I</a>
<b>Arguments</b>	OFF or 0 disables display of the recalled trace. ON or 1 enables display of the recalled trace.
<b>Examples</b>	MMEMory:IQVTIME:SHOW:TRACe:I ON enables display of the recalled data loaded in the Trace.

## MMEMory:IQVTIME:SHOW:TRACe<x>:Q

Enables display of a recalled trace file in Trace<x>. The result is the same as selecting “Show recalled trace” in the Recall traces dialog box or selecting Show in the Trace Overview display.

<b>Conditions</b>	Measurement views: RF I&Q versus Time
<b>Group</b>	Mass memory commands
<b>Syntax</b>	MMEMory:IQVTIME:SHOW:TRACe<x>:Q { OFF   ON   0   1 } MMEMory:IQVTIME:SHOW:TRACe<x>:Q?
<b>Related Commands</b>	<a href="#">MMEMory:IQVTIME:SHOW:TRACe&lt;x&gt;:Q</a>
<b>Arguments</b>	OFF or 0 disables display of the recalled trace. ON or 1 enables display of the recalled trace.
<b>Examples</b>	MMEMory:IQVTIME:SHOW:TRACe3:Q ON enables display of the recalled data loaded in Trace3.

## MMEemory:IQVTime:STORE:TRACe:I (No Query Form)

Stores I trace data in the specified file.

<b>Conditions</b>	Measurement views: RF I&Q versus Time
<b>Group</b>	Mass memory commands
<b>Syntax</b>	MMEemory:IQVTime:STORE:TRACe:I <file_name>
<b>Arguments</b>	<file_name>::=<string> specifies the file in which to store trace data. The file extension is .RFIQVsTime. You can omit the extension.
<b>Examples</b>	MMEemory:IQVTime:STORE:TRACe:I "Sample1" stores the I trace data in the <i>Sample1.RFIQVsTime</i> file.

## MMEemory:IQVTime:STORE:TRACe:Q (No Query Form)

Stores Q trace data in the specified file.

<b>Conditions</b>	Measurement views: RF I&Q versus Time
<b>Group</b>	Mass memory commands
<b>Syntax</b>	MMEemory:IQVTime:STORE:TRACe:Q <file_name>
<b>Arguments</b>	<file_name>::=<string> specifies the file in which to store trace data. The file extension is .RFIQVsTime. You can omit the extension.
<b>Examples</b>	MMEemory:IQVTime:STORE:TRACe:Q "Sample2" stores the Q trace data in the <i>Sample2.RFIQVsTime</i> file.

## MMEemory:LOAD:IQ (No Query Form)

Loads time-domain IQ waveform into the acquisition memory from a file.

<b>Conditions</b>	Measurement views: All
-------------------	------------------------



---

<b>Group</b>	Mass memory commands
<b>Syntax</b>	<code>MMEemory:LOAD:IQ &lt;file_name&gt;</code>
<b>Arguments</b>	<code>&lt;file_name&gt;::=&lt;string&gt;</code> specifies the file to load IQ data from. The file extension is <code>.tiq</code> . You can omit the extension.
<b>Examples</b>	<code>MMEemory:LOAD:IQ "IQ1"</code> loads IQ data from the <code>IQ1.tiq</code> file.

## MMEemory:LOAD:STATE (No Query Form)

Loads the instrument setup from a specified file for the currently selected view.

<b>Conditions</b>	Measurement views: All
<b>Group</b>	Mass memory commands
<b>Syntax</b>	<code>MMEemory:LOAD:STATE &lt;file_name&gt;</code>
<b>Arguments</b>	<code>&lt;file_name&gt;::=&lt;string&gt;</code> specifies the file to load the instrument setup from. The file extension is <code>.setup</code> . You can omit the extension.
<b>Examples</b>	<code>MMEemory:LOAD:STATE "STATE1"</code> loads the instrument setup from the <code>STATE1.setup</code> file.

## MMEemory:LOAD:TRACe (No Query Form)

Loads the trace data from a specified file for the currently selected view.

<b>Conditions</b>	Measurement views (See Table 2-33.)
<b>Group</b>	Mass memory commands
<b>Syntax</b>	<code>MMEemory:LOAD:TRACe &lt;file_name&gt;</code>

**Related Commands**    [MMEemory:STORe:TRACe](#)

**Arguments** <file\_name>::=<string> specifies the file to load the trace data from. The file extension is named for the measurement view as shown in the following table. The trace file is not available in some views which are indicated by "NA" in the file extension column.

For the views that allow multiple-trace display, select the trace to load or store using the command listed in the trace selection column in the following table. You can load the specified trace with any trace data that you saved in the view if the traces have the same units. For example, you can load Trace 2 with Trace 1 data that you saved.

**Table 2-33: Trace file extension and trace selection command**

Display group	Measurement view	File extension	Trace selection
General signal viewing	Spectrum	Specan	<a href="#">TRACe&lt;x&gt;:SPECtrum:SElect</a>
	DPX spectrum	dpt	<a href="#">TRACe&lt;x&gt;:DPSA:SElect</a>
	Amplitude versus Time	AmplVsTime	<a href="#">TRACe&lt;x&gt;:AVTime:SElect</a>
	Frequency versus Time	FreqVsTime	NA
	Phase versus Time	PhaseVsTime	NA
	RF I&Q versus Time	RFIQVsTime	NA
	Spectrogram	Sogram	NA
	Time overview	NA	NA
General purpose analog modulation (Option 21 only)	AM	AmVsTime	NA
	FM	FmVsTime	NA
	PM	PmVsTime	NA
General purpose digital modulation (Option 21 only)	Constellation	NA	NA
	Demodulated I & Q versus Time	NA	NA
	Eye Diagram	NA	NA
	EVM versus Time	NA	NA
	Frequency Deviation versus Time	NA	NA
	Magnitude error versus Time	NA	NA
	Phase error versus Time	NA	NA
	Signal quality	NA	NA
	Symbol table	NA	NA
	Trellis Diagram	NA	NA
RF measurements	CCDF	CCDF	<a href="#">TRACe&lt;x&gt;:CCDF:SElect</a>
	Channel power and ACPR	NA	NA
	MCPR	NA	NA
	Occupied Bandwidth	NA	NA
	Phase noise (Option 11 only)	PhaseNoise	<a href="#">TRACe&lt;x&gt;:PNOise:SElect</a>
	Spurious	NA	NA

Table 2-33: Trace file extension and trace selection command (cont.)

Display group	Measurement view	File extension	Trace selection
Pulsed RF (Option 20 only)	Pulse statistics	NA	NA
	Pulse table	NA	NA
	Pulse trace	NA	NA

**Examples** `MMEMORY:LOAD:TRACE "TRACE1"` loads the trace data from the *TRACE1.Specan* file when the spectrum view is selected.

## MMEMory:PHVTime:LOAD:TRACe (No Query Form)

Loads the Phase versus Time trace data from the specified file.

**Conditions** Measurement views: Phase versus Time

**Group** Mass memory commands

**Syntax** `MMEMory:PHVTime:LOAD:TRACe <file_name>`

**Arguments** `<file_name>::=<string>` specifies the file from which to load trace data. The file extension is *.PhaseVsTime*. You can omit the extension.

**Examples** `MMEMORY:PHVTIME:LOAD:TRACe "Sample1"` loads the Phase versus Time trace data from the *Sample1.PhaseVsTime* file.

## MMEMory:PHVTime:SHOW:TRACe

Enables display of a recalled trace file in Trace<x>. The result is the same as selecting “Show recalled trace” in the Recall traces dialog box or selecting Show in the Trace Overview display.

**Conditions** Measurement views: Phase versus Time

**Group** Mass memory commands

**Syntax** `MMEMory:PHVTime:SHOW:TRACe { OFF | ON | 0 | 1 }`  
`MMEMory:PHVTime:SHOW:TRACe?`

**Related Commands**    [MMEMory:PHVTime:LOAD:TRACe](#)

**Arguments**    OFF or 0 disables display of the recalled trace.  
                   ON or 1 enables display of the recalled trace.

**Examples**    `MMEMory:PHVTIME:SHOW:TRACe ON` enables display of the recalled data loaded in the Trace.

## MMEMory:PHVTime:STORE:TRACe (No Query Form)

Stores the Phase versus Time trace data in the specified file.

**Conditions**    Measurement views: Phase versus Time

**Group**    Mass memory commands

**Syntax**    `MMEMory:PHVTime:STORE:TRACe <file_name>`

**Arguments**    `<file_name>::=<string>` specifies the file in which to store trace data. The file extension is `.PhaseVsTime`. You can omit the extension.

**Examples**    `MMEMORY:PHVTIME:STORE:TRACE "Sample1"` stores the Phase versus Time trace data in the `Sample1.PhaseVsTime` file.

## MMEMory:PNOise:LOAD:TRACe<x> (No Query Form)

Loads the Phase Noise trace data from the specified file. The parameter `<x>` = 1 or 2; only Trace1 and Trace2 are used for Phase Noise measurement.

**Conditions**    Measurement views: Phase noise

**Group**    Mass memory commands

**Syntax**    `MMEMory:PNOise:LOAD:TRACe<x> <file_name>`

**Arguments**    `<file_name>::=<string>` specifies the file from which to load trace data.

**Examples**    `MMEMORY:PNOISE:LOAD:TRACE1 "wfm1"` loads Trace1 data from the Wfm1 file.

## **MMEMory:PNOise:SHOW:TRACe<x>**

Enables display of a recalled trace file in Trace<x>. The result is the same as selecting “Show recalled trace” in the Recall traces dialog box or selecting Show in the Trace Overview display.

**Conditions**    Measurement views: Phase noise

**Group**    Mass memory commands

**Syntax**    `MMEMory:PNOise:SHOW:TRACe<x> { OFF | ON | 0 | 1 }`  
`MMEMory:PNOise:SHOW:TRACe<x>?`

**Related Commands**    [MMEMory:PNOise:LOAD:TRACe<x>](#)

**Arguments**    OFF or 0 disables display of the recalled trace.  
 ON or 1 enables display of the recalled trace.

**Examples**    `MMEMory:PNOise:SHOW:TRACE1 ON` enables display of the recalled data loaded in Trace1.

## **MMEMory:PNOise:STORE:TRACe<x> (No Query Form)**

Stores the Spectrogram trace data in the specified file. The parameter <x> = 1 or 2; only Trace1 and Trace2 are used for Phase Noise measurement..

**Conditions**    Measurement views: Phase noise

**Group**    Mass memory commands

**Syntax**    `MMEMory:PNOise:STORE:TRACe<x> <file_name>`

**Arguments**    `<file_name>::=<string>` specifies the file in which to store trace data.

**Examples**    `MMEMORY:PNOISE:STORE:TRACE1 "WFM1"` stores Trace 1 data in the WFM1 file.

## MMEMory:SGRam:LOAD:TRACe (No Query Form)

Loads the Spectrogram trace data from the specified file. No trace number is needed or allowed.

**Conditions**    Measurement views: Spectrogram

**Group**    Mass memory commands

**Syntax**    `MMEMory:SGRam:LOAD:TRACe <file_name>`

**Arguments**    `<file_name>::=<string>` specifies the file from which to load trace data. The file extension is `.sogram`. You can omit the extension.

**Examples**    `MMEMORY:SGRAM:LOAD:TRACE5 "Spec2"` loads Trace5 data from the file *Spec2.sogram*.

## MMEMory:SGRam:SHOW:TRACe

Enables display of a recalled trace file in Trace<x>. The result is the same as selecting “Show recalled trace” in the Recall traces dialog box or selecting Show in the Trace Overview display.

**Conditions**    Measurement views: Spectrogram

**Group**    Mass memory commands

**Syntax**    `MMEMory:SGRam:SHOW:TRACe { OFF | ON | 0 | 1 }`  
`MMEMory:SGRam:SHOW:TRACe?`

**Related Commands**    [MMEMory:SGRam:LOAD:TRACe](#)

**Arguments**    OFF or 0 disables display of the recalled trace.

ON or 1 enables display of the recalled trace.

**Examples**    `MMEMemory:SGRAM:SHOW:TRACe ON` enables display of the recalled data loaded in Trace.

## MMEMemory:SGRam:STORe:TRACe (No Query Form)

Stores the Spectrogram trace data in the specified file. No trace number is needed or allowed.

---

**NOTE.** *Only valid when the spectrum and/or spectrogram measurements are running.*

---

**Conditions**    Measurement views: Spectrogram

**Group**        Mass memory commands

**Syntax**        `MMEMemory:SGRam:STORe:TRACe <file_name>`

**Arguments**    `<file_name>::=<string>` specifies the file in which to store trace data. The file extension is `.sogram`. You can omit the extension.

**Examples**        `MMEMemory:SGRAM:STORe:TRACe "Spec2"` stores Trace data in the *Spec2.sogram* file.

## MMEMemory:SPECTrum:LOAD:TRACe (No Query Form)

Loads the spectrum trace data from the specified file.

The parameter `<x> = 1 to 3`; Trace 4 (math trace) and; Trace 5 (spectrogram) are invalid.

**Conditions**    Measurement views: Spectrum

**Group**        Mass memory commands

**Syntax**        `MMEMemory:SPECTrum:LOAD:TRACe <file_name>`

**Arguments**    `<file_name>::=<string>` specifies the file from which to load trace data. The file extension is `.Specan`. You can omit the extension.

**Examples**    `MMEMORY:SPECTRUM:LOAD:TRACE1 "Sample1"` loads Trace 1 data from the *Sample1. Specan* file.

## **MMEMory:SPECTrum:SHOW:TRACe<x>**

Enables display of a recalled trace file in Trace<x>. The result is the same as selecting “Show recalled trace” in the Recall traces dialog box or selecting Show in the Trace Overview display.

**Conditions**    Measurement views: Spectrum

**Group**    Mass memory commands

**Syntax**    `MMEMory:SPECTrum:SHOW:TRACe<x> { OFF | ON | 0 | 1 }`  
`MMEMory:SPECTrum:SHOW:TRACe<x>?`

**Related Commands**    [MMEMory:SPECTrum:LOAD:TRACe](#)

**Arguments**    OFF or 0 disables display of the recalled trace.  
 ON or 1 enables display of the recalled trace.

**Examples**    `MMEMory:SPECTRUM:SHOW:TRACe2 ON` enables display of the recalled data loaded in Trace2.

## **MMEMory:SPECTrum:STORE:TRACe<x> (No Query Form)**

Stores the spectrum trace data in the specified file.

The parameter <x> = 1 to 5; All traces are valid.

---

**NOTE.** *TRACe5 (spectrogram) is valid when the spectrum and spectrogram measurements are running.*

---

**Conditions**    Measurement views: Spectrum

**Group**    Mass memory commands

**Syntax**    `MMEMory:SPECTrum:STORE:TRACe<x> <file_name>`



**Arguments** <file\_name>:=<string> specifies the file in which to store trace data. The file extension is .Specan. You can omit the extension.

**Examples** MMEMORY:SPECTRUM:STORE:TRACE1 "Sample1" stores Trace 1 data in the *Sample1.Specan* file.

## MMEMory:SPURious:LOAD:TABLE (No Query Form)

Loads the spurious table containing the limits for enabled ranges from the specified file.

**Conditions** Measurement views: Spurious

**Group** Mass memory commands

**Syntax** MMEMory:SPURious:LOAD:TABLE <file\_name>

**Arguments** <file\_name>:=<string> specifies the file to load the spurious table from. The file extension is .csv. You can omit the extension.

**Examples** MMEMORY:SPURIOUS:LOAD:TRACE1 "Table1" loads the spurious table from the *Table1.csv* file.

## MMEMory:SPURious:STORE:TABLE (No Query Form)

Stores the spurious table containing the limits for enabled ranges in a specified file in the CSV (Comma Separated Values) format, allowing you to export the file into Microsoft Excel or other database systems.

**Conditions** Measurement views: Spurious

**Group** Mass memory commands

**Syntax** MMEMory:SPURious:STORE:TABLE <file\_name>

**Arguments** <file\_name>:=<string> specifies the file to store the spurious table in. The file extension is .csv. You can omit the extension.

**Examples**    `MMEMORY:SPURIOUS:STORE:TABLE "Table1"` stores the spurious table in the *Table1.csv* file.

## MMEMemory:STORe:IQ (No Query Form)

Saves time-domain IQ waveform in the acquisition memory to a specified file.

**Conditions**    Measurement views: All

**Group**    Mass memory commands

**Syntax**    `MMEMemory:STORe:IQ <file_name>`

**Arguments**    `<file_name>::=<string>` specifies the file to save IQ data. The file extension is *.tiq*. You can omit the extension.

**Examples**    `MMEMORY:STORE:IQ "IQ1"` saves IQ data to the *IQ1.tiq* file.

## MMEMemory:STORe:IQ:CSV (No Query Form)

Saves time-domain IQ waveform in the acquisition memory to a specified file in the CSV (Comma Separated Values) format, allowing you to export the file into Microsoft Excel or other database systems.

**Conditions**    Measurement views: All

**Group**    Mass memory commands

**Syntax**    `MMEMemory:STORe:IQ:CSV <file_name>`

**Arguments**    `<file_name>::=<string>` specifies the file to save IQ data. The file extension is *.csv*. You can omit the extension.

**Examples**    `MMEMORY:STORE:IQ:CSV "IQ2"` saves IQ data to the *IQ2.cs(less t eq)* file.

## MMEMemory:STORe:IQ:MAT (No Query Form)

Saves time-domain IQ waveform in the acquisition memory to a specified file in the MATLAB format, allowing you to export the file into the MATLAB technical computing environment.

<b>Conditions</b>	Measurement views: All
<b>Group</b>	Mass memory commands
<b>Syntax</b>	MMEMemory:STORe:IQ:MAT <file_name>
<b>Arguments</b>	<file_name>::=<string> specifies the file to save IQ data. The file extension is .mat. You can omit the extension.
<b>Examples</b>	MMEMemory:STORe:IQ:MAT "IQ3" saves IQ data to the <i>IQ3.mat</i> file.

## MMEMemory:STORe:MStAtE (No Query Form)

Stores the measurement parameters to a specified file in the ASCII text format for the currently selected view, allowing you to export the file into other applications.

<b>Conditions</b>	Measurement views: All
<b>Group</b>	Mass memory commands
<b>Syntax</b>	MMEMemory:STORe:MStAtE <file_name>
<b>Arguments</b>	<file_name>::=<string> specifies the file to store the measurement parameters. The file extension is .txt. You can omit the extension.
<b>Examples</b>	MMEMemory:STORe:MStAtE "MSTATE1" stores the measurement parameters to the <i>MSTATE1.txt</i> file.

## MMEMemory:STORe:RESults (No Query Form)

Stores the measurement results including measurement parameters and trace data to a specified file in the CSV (Comma Separated Values) format for the

currently selected view, allowing you to export the file into Microsoft Excel or other database systems.

<b>Conditions</b>	Measurement views: All
<b>Group</b>	Mass memory commands
<b>Syntax</b>	<code>MMEMemory:STORE:RESULTS &lt;file_name&gt;</code>
<b>Arguments</b>	<code>&lt;file_name&gt;::=&lt;string&gt;</code> specifies the file to store the measurement results. The file extension is <code>.csv</code> . You can omit the extension.
<b>Examples</b>	<code>MMEMemory:STORE:RESULTS "RESULT1"</code> stores the measurement results to the <code>RESULT1.csv</code> file.

## MMEMemory:STORE:SCREEN (No Query Form)

Stores the current display as a bitmap image file in one of several standard formats. When no format is specified, the system uses the default, `.png`.

<b>Conditions</b>	Measurement views: All
<b>Group</b>	Mass memory commands
<b>Syntax</b>	<code>MMEMemory:STORE:SCREEN &lt;file_name&gt;{ .bmp   .jpg   .png }</code>
<b>Arguments</b>	<code>&lt;file_name&gt;::=&lt;string&gt;</code> specifies the file to store the screen image.
<b>Examples</b>	<code>MMEMemory:STORE:SCREEN "RESULT1.png"</code> stores the current screen image into the file <code>RESULT1.png</code> .

## MMEMemory:STORE:STATe (No Query Form)

Stores the instrument setup to a specified file for the currently selected view.

<b>Conditions</b>	Measurement views: All
-------------------	------------------------

<b>Group</b>	Mass memory commands
<b>Syntax</b>	<code>MMEmory:STORe:STATe &lt;file_name&gt;</code>
<b>Arguments</b>	<code>&lt;file_name&gt;::=&lt;string&gt;</code> specifies the file to store the instrument setup. The file extension is <code>.setup</code> . You can omit the extension.
<b>Examples</b>	<code>MMEmory:STORe:STATe "STATE1"</code> stores the instrument setup in the <code>STATE1.setup</code> file.

## MMEmory:STORe:TRACe (No Query Form)

Stores the trace data in a specified file for the currently selected view.

<b>Conditions</b>	Measurement views (See Table 2-33 on page 2-488.)
<b>Group</b>	Mass memory commands
<b>Syntax</b>	<code>MMEmory:STORe:TRACe &lt;file_name&gt;</code>
<b>Related Commands</b>	<a href="#">MMEmory:IQVTIME:SHOW:TRACe:I</a>
<b>Arguments</b>	<code>&lt;file_name&gt;::=&lt;string&gt;</code> specifies the file to store the trace data in. The file extension is named for the measurement view as shown in the table (See Table 2-33.) The trace file is not available in some views which are indicated by "NA" in the file extension column. For the views that allow multiple-trace display, select the trace to load or store using the command listed in the trace selection column.
<b>Examples</b>	<code>MMEmory:STORe:TRACe "TRACE1"</code> stores the trace data in the <code>TRACE1.Specan</code> file when the spectrum view is selected.

## MMEmory:TOVerview:LOAD:TRACe1 (No Query Form)

Loads the trace data from a specified file into Trace1. Refer to (See Table 2-33.) for the correct file extensions for each trace type.

<b>Conditions</b>	Measurement views
-------------------	-------------------

<b>Group</b>	Mass memory commands
<b>Syntax</b>	<code>MMEMemory:TOVerview:LOAD:TRACe1 &lt;file_name&gt;</code>
<b>Related Commands</b>	<a href="#">MMEMemory:STORe:TRACe</a>
<b>Arguments</b>	<code>&lt;file_name&gt;::=&lt;string&gt;</code> specifies the file path and name to load the trace data from. The file extension is named for the measurement view.(See Table 2-33.). Most trace file types are compatible with only one Measurement view.
<b>Examples</b>	<code>MMEMemory:TOVerview:LOAD:TRACe1 "TriAlB"</code> loads the trace data from the file <i>TRIALB.TOV</i> when the spectrum view is selected.

## MMEMemory:TOVerview:SHOW:TRACe1

Enables display of a recalled trace file in Trace<x>. The result is the same as selecting “Show recalled trace” in the Recall traces dialog box or selecting Show in the Trace Overview display.

<b>Conditions</b>	Measurement views
<b>Group</b>	Mass memory commands
<b>Syntax</b>	<code>MMEMemory:TOVerview:SHOW:TRACe1 { OFF   ON   0   1 }</code> <code>MMEMemory:TOVerview:SHOW:TRACe1?</code>
<b>Related Commands</b>	<a href="#">MMEMemory:TOVerview:LOAD:TRACe1</a>
<b>Arguments</b>	OFF or 0 disables display of the recalled trace. ON or 1 enables display of the recalled trace.
<b>Examples</b>	<code>MMEMemory:TOVerview:SHOW:TRACe1 ON</code> enables display of the recalled data loaded in Trace2.

## MMEMemory:TOVerview:STORe:TRACe1 (No Query Form)

Stores the trace data for Trace1 into the specified file.

<b>Conditions</b>	Measurement views
<b>Group</b>	Mass memory commands
<b>Syntax</b>	MMEMory:TOVerview:STORe:TRACe1 <file_name>

**Related Commands** [MMEMory:STORe:TRACe](#)

**Arguments** <file\_name>::=<string> specifies the file to store the trace data in. The file extension is named for the measurement view as shown in the table (See Table 2-33.) The trace file is not available in some views which are indicated by "NA" in the file extension column. For the views that allow multiple-trace display, select the trace to load or store using the command listed in the trace selection column.

**Examples** MMEMory:TOVerview:STORe:TRACe1 "TrialB" stores the Trace1 data into the file *TRIALB.TOV* when a spectrum view is selected.

## \*OPC

Generates the operation complete message in the Standard Event Status Register (SESR) when all pending operations finish. The \*OPC? query places the ASCII character "1" into the output queue when all pending operations are finished. The \*OPC? response is not available to read until all pending operations finish.

The \*OPC command allows you to synchronize the operation of the analyzer with your application program. Refer to *Synchronizing Execution* (See page 3-12.) for the details.

<b>Conditions</b>	Measurement views: All
<b>Group</b>	IEEE common commands
<b>Syntax</b>	*OPC *OPC?
<b>Arguments</b>	None

## \*OPT? (Query Only)

Returns a list of options installed in your analyzer.

**Conditions** Measurement views: All

**Group** IEEE common commands

**Syntax** \*OPT?

**Arguments** None

**Returns** The numbers of all the options installed in the analyzer, separated by commas. If no options have been installed, 0 is returned. The following table lists the options for the RSA6100A Series analyzers.

**Table 2-34: Instrument options**

Option	Description
01	Internal preamp, 5 MHz - 3 GHz, 30 dB gain, 8 dB noise figure at 2 GHz, typical
02	256 Msample deep memory, frequency mask trigger
05	Digital IQ output and 500 MHz analog IF output
06 <sup>1</sup>	Removable HDD, 80 GB
07 <sup>1</sup>	DVD-RW
20	Advanced signal analysis (including pulse measurements)
21	General purpose modulation analysis
110	110 MHz real-time capture bandwidth
1R <sup>1</sup>	Rackmount

<sup>1</sup> These options are not returned from this query.

**Examples** \*OPT? might return 02 , 05 , 21, indicating that Option 02, 05, and 21 are currently installed in the analyzer.

## OUTPut:IF:{BANDwidth|BWIDth}

Selects or queries the IF output filter when [OUTPut:IF\[:STATe\]](#) is set to ON.

**Conditions** Measurement views: All (Option 05 only)



<b>Group</b>	Output commands
<b>Syntax</b>	<pre> OUTPUT:IF:{BANDwidth BWIDth} { FLATtop   GAUSSian } OUTPUT:IF:{BANDwidth BWIDth}? </pre>
<b>Arguments</b>	<p>FLATtop selects the flattop filter.</p> <p>GAUSSian selects the Gaussian filter.</p>
<b>Examples</b>	OUTPUT:IF:BANDWIDTH GAUSSian selects the Gaussian filter for the IF output.

## OUTPUT:IF[:STATe]

Determines whether to turn on or off the 500 MHz IF Out on the rear panel.

<b>Conditions</b>	Measurement views: All (Option 05 only)
<b>Group</b>	Output commands
<b>Syntax</b>	<pre> OUTPUT:IF[:STATe] { OFF   ON   0   1 } OUTPUT:IF[:STATe]? </pre>
<b>Related Commands</b>	<a href="#">OUTPUT:IF:{BANDwidth BWIDth}</a>
<b>Arguments</b>	<p>OFF or 0 turns off IF Out.</p> <p>ON or 1 turns on IF Out.</p>
<b>Examples</b>	OUTPUT:IF:STATE ON turns on IF Out.

## OUTPUT:IQ[:STATe]

Determines whether to enable or disable the digital IQ output data stream from the rear panel connectors.

<b>Conditions</b>	Measurement views: All (Option 05 only)
<b>Group</b>	Output commands

**Syntax**    `OUTPut:IQ[:STATE] { 0 | 1 | OFF | ON }`  
`OUTPut:IQ[:STATE]?`

**Arguments**    OFF or 0 disables the digital IQ output.  
                   ON or 1 enables the digital IQ output.  
                   At \*RST, this value is set to OFF.

**Examples**    `OUTPUT:IQ:STATE ON` enables the digital IQ output.

## **OUTPut:NOISe[:STATe]**

Determines whether to turn on or off the +28 V DC Out on the rear panel.

**Conditions**    Measurement views: All

**Group**        Output commands

**Syntax**       `OUTPut:NOISe[:STATE] { OFF | ON | 0 | 1 }`  
`OUTPut:NOISe[:STATE]?`

**Arguments**    OFF or 0 turns off +28 V DC Out.  
                   ON or 1 turns on +28 V DC Out.

**Examples**    `OUTPUT:NOISE:STATE ON` turns on +28 V DC Out.

## **READ:ACPower? (Query Only)**

Returns the Channel power and ACPR measurement results for all available channels.

**Conditions**    Measurement views: Channel power and ACPR

**Group**        Read commands

**Syntax**       `READ:ACPower?`

<b>Arguments</b>	None
<b>Returns</b>	<p>&lt;chan_power&gt;, &lt;acpr_lower(1)&gt;, &lt;acpr_upper(1)&gt;, &lt;acpr_lower(2)&gt;, &lt;acpr_upper(2)&gt;, ... &lt;acpr_lower(n)&gt;, &lt;acpr_upper(n)&gt;</p> <p>Where          &lt;chan_power&gt; is the average power of the main channel as the power reference in dBm. The unit can be changed by the <a href="#">[SENSe]:POWer:UNITs</a> command.          &lt;acpr_lower(n)&gt; is the ACPR for the lower channel #n in dB.          &lt;acpr_upper(n)&gt; is the ACPR for the upper channel #n in dB.</p> <p>The number of n depends on the setting of the <a href="#">[SENSe]:ACPower:CHANnel:PAIRs</a> command.</p>
<b>Examples</b>	<p>READ:ACPOWER? might return 4.227, -28.420, -23.847, -22.316, -29.225, indicating</p> <p>(average power of the main channel) = 4.227 dBm,          (ACPR for the lower channel 1) = -28.420 dB,          (ACPR for the upper channel 1) = -23.847 dB,          (ACPR for the lower channel 2) = -22.316 dB, and          (ACPR for the upper channel 2) = -29.225 dB.</p>

## READ:ACPower:CHANnel:POWer? (Query Only)

Returns the average power of the main channel (power reference) in the Channel power and ACPR measurement.

<b>Conditions</b>	Measurement views: Channel power and ACPR
<b>Group</b>	Read commands
<b>Syntax</b>	READ:ACPower:CHANnel:POWer?
<b>Arguments</b>	None
<b>Returns</b>	<p>&lt;chan_power&gt; ::= &lt;NRf&gt; is the average power of the main channel in dBm. The unit can be changed by the <a href="#">[SENSe]:POWer:UNITs</a> command.</p>
<b>Examples</b>	<p>READ:ACPOWER:CHANNEL:POWER? might return 4.227, indicating that the average power of the main channel is 4.227 dBm.</p>

## READ:ACPower:SPECTrum? (Query Only)

Returns spectrum trace data of the Channel power and ACPR measurement.

<b>Conditions</b>	Measurement views: Channel power and ACPR
<b>Group</b>	Read commands
<b>Syntax</b>	READ:ACPower:SPECTrum?
<b>Arguments</b>	None
<b>Returns</b>	#<num_digit><num_byte><data(1)><data(2)>...<data(n)> Where <num_digit> is the number of digits in <num_byte>. <num_byte> is the number of bytes of data that follow. <data(n)> is the spectrum trace data in dBm for the point n, 4-byte little endian floating-point format specified in IEEE 488.2. The unit can be changed by the <a href="#">[SENSe]:POWer:UNITs</a> command.
<b>Examples</b>	READ:ACPOWER:SPECTRUM? might return #43204xxxx... (3204-byte data) for the spectrum trace data of the Channel power and ACPR measurement.

## READ:{AM|FM|PM}? (Query Only)

Returns the trace data in the AM/FM/PM measurement.

<b>Conditions</b>	Measurement views: AM, FM, PM
<b>Group</b>	Read commands
<b>Syntax</b>	READ:{AM FM PM}?
<b>Arguments</b>	None
<b>Returns</b>	#<num_digit><num_byte><data(1)><data(2)>...<data(n)> Where

`<num_digit>` is the number of digits in `<num_byte>`.  
`<num_byte>` is the number of bytes of data that follow.  
`<data(n)>` is the modulation factor in percent (AM), frequency deviation in Hz (FM), or phase deviation in degrees (PM) at the  $n^{\text{th}}$  data point, 4-byte little endian floating-point format specified in IEEE 488.2.

**Examples** `READ:AM` might return `#3156xxxx...` (156-byte data) for the AM measurement trace.

## READ:AM:AMIndex? (Query Only)

Returns the modulation index which is (positive peak modulation factor - negative peak modulation factor)/2, returned as a percentage (%).

**Conditions** Measurement views: AM

**Group** Read commands

**Syntax** `READ:AM:AMIndex?`

**Arguments** None

**Returns** `<value>::=<NRF>` the modulation index.

**Examples** `READ:AM:AMINDEX?` might return `36.48`, indicating the modulation index is 36.48%.

## READ:AM:AMNegative? (Query Only)

Returns the negative peak modulation factor (-AM) in the AM measurement.

**Conditions** Measurement views: AM

**Group** Read commands

**Syntax** `READ:AM:AMNegative?`

<b>Arguments</b>	None
<b>Returns</b>	<-AM> ::= <NRF> is the negative peak modulation factor in percent (%).
<b>Examples</b>	READ:AM:AMNEGATIVE? might return -23.4, indicating the negative peak modulation factor is -23.4%.

## READ:AM:AMPositive? (Query Only)

Returns the positive peak modulation factor (+AM) in the AM measurement.

<b>Conditions</b>	Measurement views: AM
<b>Group</b>	Read commands
<b>Syntax</b>	READ:AM:AMPositive?
<b>Arguments</b>	None
<b>Returns</b>	<+AM> ::= <NRF> is the positive peak modulation factor in percent (%).
<b>Examples</b>	READ:AM:AMPOSITIVE? might return 43.8, indicating the positive peak modulation factor is 43.8%.

## READ:AM:RESult? (Query Only)

Returns the AM measurement results.

<b>Conditions</b>	Measurement views: AM
<b>Group</b>	Read commands
<b>Syntax</b>	READ:AM:RESult?
<b>Arguments</b>	None

**Returns** <+AM>, <-AM>, <Total AM>

Where

<+AM> ::= <NRf> is the positive peak modulation factor in percent (%).

<-AM> ::= <NRf> is the negative peak modulation factor in percent (%).

<Total AM> ::= <NRf> is the (peak to peak modulation factor)/2 in percent (%).

**Examples** READ:AM:RESULT? might return 62.63, -50.89, 56.76.

## READ:AVTime:AVERAge? (Query Only)

Returns the RMS (root-mean-square) value for the selected trace in the Amplitude versus Time measurement. Select the trace using the [TRACe<x>:AVTime:SElect](#) command.

**Conditions** Measurement views: Amplitude versus Time

**Group** Read commands

**Syntax** READ:AVTime:AVERAge?

**Arguments** None

**Returns** <avg> ::= <NRf> is the RMS amplitude in dBm.  
The unit can be changed by the [\[SENSe\]:POWer:UNITs](#) command.

**Examples** READ:AVTIME:AVERAGE? might return -2.53, indicating the RMS amplitude is -2.53 dBm.

## READ:AVTime:{FIRSt|SECond|THIRd|FOURth}? (Query Only)

Returns the trace data in the Amplitude versus Time measurement.

The mnemonics FIRSt, SECond, THIRd, and FOURth represent Trace 1, Trace 2, Trace 3, and Math trace, respectively. The traces can be specified by the [TRACe<x>:AVTime](#) command subgroup.

**Conditions** Measurement views: Amplitude versus Time

<b>Group</b>	Read commands
<b>Syntax</b>	READ:AVTime:{FIRST SECOND THIRD FOURTH}?
<b>Arguments</b>	None
<b>Returns</b>	#<num_digit><num_byte><data(1)><data(2)>...<data(n)> Where <num_digit> is the number of digits in <num_byte>. <num_byte> is the number of bytes of data that follow. <data(n)> is the amplitude in dBm at the n <sup>th</sup> data point, 4-byte little endian floating-point format specified in IEEE 488.2. The unit can be changed by the <a href="#">[SENSE]:POWER:UNITs</a> command.
<b>Examples</b>	READ:AVTIME:FIRST? might return #3156xxxx... (156-byte data) for Trace 1.

## READ:AVTime:MAXimum? (Query Only)

Returns the maximum value for the selected trace in the Amplitude versus Time measurement. Select the trace using the [TRACe<x>:AVTime:SElect](#) command.

<b>Conditions</b>	Measurement views: Amplitude versus Time
<b>Group</b>	Read commands
<b>Syntax</b>	READ:AVTime:MAXimum?
<b>Related Commands</b>	<a href="#">READ:AVTime:MAXLocation?</a>
<b>Arguments</b>	None
<b>Returns</b>	<max>: :=<NRF> is the maximum Amplitude in dBm. The unit can be changed by the <a href="#">[SENSE]:POWER:UNITs</a> command.
<b>Examples</b>	READ:AVTIME:MAXIMUM? might return -2.84, indicating the maximum amplitude is -2.84 dBm.



## READ:AVTime:MAXLocation? (Query Only)

Returns the time at which the amplitude is maximum for the selected trace in the Amplitude versus Time measurement. Select the trace using the [TRACe<x>:AVTime:SElect](#) command.

**Conditions** Measurement views: Amplitude versus Time

**Group** Read commands

**Syntax** READ:AVTime:MAXLocation?

**Related Commands** [READ:AVTime:MAXimum?](#)

**Arguments** None

**Returns** <max\_time>::=<NRf> is the time at the maximum in seconds.

**Examples** READ:AVTIME:MAXLOCATION? might return 25.03E-9, indicating the amplitude is maximum at 25.03 ns.

## READ:AVTime:MINimum? (Query Only)

Returns the minimum value for the selected trace in the Amplitude versus Time measurement. Select the trace using the [TRACe<x>:AVTime:SElect](#) command.

**Conditions** Measurement views: Amplitude versus Time

**Group** Read commands

**Syntax** READ:AVTime:MINimum?

**Related Commands** [READ:AVTime:MINLocation?](#)

**Arguments** None

**Returns** <min>::=<NRF> is the minimum amplitude in dBm.  
The unit can be changed by the [\[SENSE\]:POWER:UNITS](#) command.

**Examples** READ:AVTIME:MINIMUM? might return -57.64, indicating the minimum amplitude is -57.64 dBm.

## READ:AVTime:MINLocation? (Query Only)

Returns the time at which the amplitude is minimum for the selected trace in the Amplitude versus Time measurement. Select the trace using the [TRACe<x>:AVTime:SElect](#) command.

**Conditions** Measurement views: Amplitude versus Time

**Group** Read commands

**Syntax** READ:AVTime:MINLocation?

**Related Commands** [READ:AVTime:MINimum?](#)

**Arguments** None

**Returns** <min\_time>::=<NRF> is the time at the minimum in seconds.

**Examples** READ:AVTIME:MINLOCATION? might return 450.7E-9, indicating the amplitude is minimum at 450.7 ns.

## READ:AVTime:RESult? (Query Only)

Returns the measurement results for the selected trace in the Amplitude versus Time measurement. Select the trace using the [TRACe<x>:AVTime:SElect](#) command.

**Conditions** Measurement views: Amplitude versus Time

**Group** Read commands

<b>Syntax</b>	READ:AVTime:RESult?
<b>Arguments</b>	None
<b>Returns</b>	<p>&lt;max&gt;, &lt;max_time&gt;, &lt;min&gt;, &lt;min_time&gt;, &lt;rms&gt;</p> <p>Where</p> <p>&lt;max&gt; ::= &lt;NRf&gt; is the maximum amplitude in dBm.          &lt;max_time&gt; ::= &lt;NRf&gt; is the time at the maximum in seconds.          &lt;min&gt; ::= &lt;NRf&gt; is the minimum amplitude in dBm.          &lt;min_time&gt; ::= &lt;NRf&gt; is the time at the minimum in seconds.          &lt;rms&gt; ::= &lt;NRf&gt; is the RMS amplitude in dBm.          The unit of amplitude can be changed by the <a href="#">[SENSe]:POWer:UNITs</a> command.</p>
<b>Examples</b>	<p>READ:AVTIME:RESULT? might return          -2.68, 48.62E-6, -82.47, 22.11E-6, -8.24, indicating that          the maximum amplitude is -2.68 dBm at 48.62 <math>\mu</math>s,          the minimum amplitude is -82.47 dBm at 22.11 <math>\mu</math>s, and          the RMS amplitude is -8.24 dBm.</p>

## READ:CCDF? (Query Only)

Returns the CCDF measurement results.

<b>Conditions</b>	Measurement views: CCDF
<b>Group</b>	Read commands
<b>Syntax</b>	READ:CCDF?
<b>Arguments</b>	None
<b>Returns</b>	<p>&lt;avg_amp1&gt;, &lt;avg_ccdf&gt;, &lt;crest_factor&gt;, &lt;amp1_10&gt;, &lt;amp1_1&gt;, &lt;amp1_p1&gt;, &lt;amp1_p01&gt;, &lt;amp1_p001&gt;, &lt;amp1_p0001&gt;</p> <p>Where</p> <p>&lt;avg_amp1&gt; is the average amplitude in dBm.          The unit can be changed by the <a href="#">[SENSe]:POWer:UNITs</a> command.          &lt;avg_ccdf&gt; is the average CCDF in percent.          &lt;crest_factor&gt; is the crest factor in dB.          &lt;amp1_10&gt; is the amplitude at CCDF of 10% in dB.</p>

<amp1\_1> is the amplitude at CCDF of 1% in dB.  
 <amp1\_p1> is the amplitude at CCDF of 0.1% in dB.  
 <amp1\_p01> is the amplitude at CCDF of 0.01% in dB.  
 <amp1\_p001> is the amplitude at CCDF of 0.001% in dB.  
 <amp1\_p0001> is the amplitude at CCDF of 0.0001% in dB.

**Examples** READ:CCDF? might return  
 -33.35, 35.8, 9.75, 3.88, 7.07, 8.50, 9.25, 9.72, 9.74, indicating  
 (average amplitude) = -33.35 dBm,  
 (average CCDF) = 35.8%,  
 (crest factor) = 9.75 dB,  
 (amplitude at CCDF of 10%) = 3.88 dB,  
 (amplitude at CCDF of 1%) = 7.07 dB,  
 (amplitude at CCDF of 0.1%) = 8.50 dB,  
 (amplitude at CCDF of 0.01%) = 9.25 dB,  
 (amplitude at CCDF of 0.001%) = 9.72 dB, and  
 (amplitude at CCDF of 0.0001%) = 9.74 dB.

## READ:CCDF:{FIRSt|SECond|THIRd}:X? (Query Only)

Returns the horizontal values of the specified trace in the CCDF measurement.

The mnemonics FIRSt, SECond, and THIRd represent Trace 1, Trace 2, and Gaussian reference curve, respectively.

---

**NOTE.** This query is invalid when *[SENSe]:CCDF:TIME:TYPE* is set to *CONTinuous* or *TOTal*.

---

**Conditions** Measurement views: CCDF

**Group** Read commands

**Syntax** READ:CCDF:{FIRSt|SECond|THIRd}:X?

**Related Commands** [READ:CCDF:{FIRSt|SECond|THIRd}\[:Y\]?](#)

**Arguments** None

**Returns** #<num\_digit><num\_byte><x(1)><x(2)>...<x(n)>

Where

<num\_digit> is the number of digits in <num\_byte>.  
 <num\_byte> is the number of bytes of data that follow.  
 <x(n)> is the horizontal value (dB) of the CCDF graph at the n<sup>th</sup> data point, 4-byte little endian floating-point format specified in IEEE 488.2.

**Examples** READ:CCDF:FIRST:X might return #41024xxxx... (1024-byte data) for the horizontal values of Trace 1.

## READ:CCDF:{FIRST|SECond|THIRd}:XY? (Query Only)

Returns the horizontal and vertical value pairs of the specified trace in the CCDF measurement.

The mnemonics FIRSt, SECond, and THIRd represent Trace 1, Trace 2, and Gaussian reference curve, respectively.

---

**NOTE.** This query is invalid when *[SENSE]:CCDF:TIME:TYPE* is set to *CONTinuous* or *TOTal*.

---

<b>Conditions</b>	Measurement views: CCDF
<b>Group</b>	Read commands
<b>Syntax</b>	READ:CCDF:{FIRST SECond THIRd}:XY?
<b>Arguments</b>	None
<b>Returns</b>	#<num_digit><num_byte><x(1)><y(1)><x(2)><y(2)>...<x(n)><y(n)> Where <num_digit> is the number of digits in <num_byte>. <num_byte> is the number of bytes of data that follow. <x(n)><y(n)> is the horizontal value (dB) and vertical value (%) pair at the n <sup>th</sup> data point, 4-byte little endian floating-point format specified in IEEE 488.2.
<b>Examples</b>	READ:CCDF:FIRST:XY? might return #41024xxxx... (1024-byte data) for the horizontal and vertical value pairs of Trace 1.

## READ:CCDF:{FIRSt|SECond|THIRd}[:Y]? (Query Only)

Returns the vertical values of the specified trace in the CCDF measurement.

The mnemonics FIRSt, SECond, and THIRd represent Trace 1, Trace 2, and Gaussian reference curve, respectively.

---

**NOTE.** This query is invalid when *[SENSe]:CCDF:TIME:TYPE* is set to *CONTinuous* or *TOTal*.

---

<b>Conditions</b>	Measurement views: CCDF
<b>Group</b>	Read commands
<b>Syntax</b>	READ:CCDF:{FIRSt SECond THIRd}[:Y]?
<b>Arguments</b>	None
<b>Returns</b>	#<num_digit><num_byte><y(1)><y(2)>...<y(n)> Where <num_digit> is the number of digits in <num_byte>. <num_byte> is the number of bytes of data that follow. <y(n)> is the vertical value (%) of the CCDF graph at the n <sup>th</sup> data point, 4-byte little endian floating-point format specified in IEEE 488.2.
<b>Examples</b>	READ:CCDF:FIRSt:Y might return #41024xxxx... (1024-byte data) for the vertical values of Trace 1.

## READ:CONStE:FERRor? (Query Only)

Returns the frequency error in Hz. The frequency error is the difference between the measured carrier frequency of the signal and the user-selected center frequency of the analyzer.

<b>Group</b>	Read commands
<b>Syntax</b>	READ:CONStE:FERRor?
<b>Related Commands</b>	<a href="#">READ:EVM:FERRor?</a>

<b>Arguments</b>	None.
<b>Returns</b>	<freq_error>::=<Nrf> which is the frequency error in Hz.
<b>Examples</b>	READ:CONStE:FERRor? might return -10.7E+3, which is a frequency error of -10.7 kHz.

## READ:CONStE:RESuLts? (Query Only)

Returns the constellation measurement results of EVM RMS, peak and location displayed on the bottom of the screen.

<b>Conditions</b>	Measurement views: Constellation
<b>Group</b>	Read commands
<b>Syntax</b>	READ:CONStE:RESuLts?
<b>Arguments</b>	None
<b>Returns</b>	<p>For modulation types 2 4 8 16FSK or C4FM:</p> <p>FSK_deviation_Avg_Leftmost, FSK_deviation_Avg_Rightmost</p> <p>Where</p> <p>FSK_deviation_Avg_Leftmost is the average FSK deviation of the left-most symbol in Hz.</p> <p>FSK_deviation_Avg_Rightmost is the average FSK deviation of the right-most symbol in Hz.</p> <p>For all other valid modulation types:</p> <p>&lt;EVM_RMS&gt;, &lt;EVM_peak&gt;, &lt;location&gt;</p> <p>Where</p> <p>&lt;EVM_RMS&gt;::=&lt;Nrf&gt; is the RMS EVM in percent (%).</p> <p>&lt;EVM_peak&gt;::=&lt;Nrf&gt; is the peak EVM in percent (%).</p> <p>&lt;location&gt;::=&lt;Nrf&gt; is the peak location in symbol number.</p> <p>The time unit can be changed by the <a href="#">[SENSE]:DDEMod:TIME:UNITs</a> command.</p>
<b>Examples</b>	READ:CONStE:RESuLts? might return 2.841, 3.227, 68.000, indicating that the RMS EVM is 2.841% and the peak EVM is 3.227% at symbol #68.

## READ:CONStE:TRACe? (Query Only)

Returns the constellation trace data.

<b>Conditions</b>	Measurement views: Constellation
<b>Group</b>	Read commands
<b>Syntax</b>	READ:CONStE:TRACe?
<b>Arguments</b>	None
<b>Returns</b>	#<num_digit><num_byte><I(1)><Q(1)><I(2)><Q(2)>...<I(n)><Q(n)> Where <num_digit> is the number of digits in <num_byte>. <num_byte> is the number of bytes of data that follow. <I(n)> and <Q(n)> are the normalized I- and Q-coordinate values at the n <sup>th</sup> data point. 4-byte little endian floating-point format specified in IEEE 488.2.
<b>Examples</b>	READ:CONStE:TRACe? might return #43848xxxx... (3848-byte data) for the constellation trace data.

## READ:DDEMod:StABle? (Query Only)

Returns the symbol table data.

<b>Conditions</b>	Measurement views: Symbol table
<b>Group</b>	Read commands
<b>Syntax</b>	READ:DDEMod:StABle?
<b>Arguments</b>	None
<b>Returns</b>	#<num_digit><num_byte><data(1)><data(2)>...<data(n)> Where <num_digit> is the number of digits in <num_byte>.



<num\_byte> is the number of bytes of data that follow.  
<data(n)> is the symbol table data for the point n,  
\4-byte little endian floating-point format specified in IEEE 488.2.

**Examples** READ:DDEMOD:STABLE? might return #3512xxxx... (512-byte data) for the symbol table.

## READ:DIQVtime:FERRor? (Query Only)

Returns the frequency error in the Demod I&Q versus Time measurement.

**Conditions** Measurement views: Demod I&Q versus Time

**Group** Read commands

**Syntax** READ:DIQVtime:FERRor?

**Arguments** None

**Returns** <freq\_error>::=<Nrf> is the frequency error in Hz.

**Examples** READ:DIQVTIME:FERRor? might return -10.7E+3, indicating the frequency error is -10.7 kHz.

## READ:DIQVtime:I? (Query Only)

Returns the I versus Time trace data.

**Conditions** Measurement views: Demod I&Q versus Time

**Group** Read commands

**Syntax** READ:DIQVtime:I?

**Arguments** None

**Returns** #<num\_digit><num\_byte><data(1)><data(2)>...<data(n)>

Where

<num\_digit> is the number of digits in <num\_byte>.

<num\_byte> is the number of bytes of data that follow.

<data(n)> is the I level in volts at the n<sup>th</sup> data point,

4-byte little endian floating-point format specified in IEEE 488.2.

**Examples** READ:DIQVTIME:I? might return #3160xxxx... (160-byte data) for the I versus Time trace.

## READ:DIQVtime:Q? (Query Only)

Returns the Q versus Time trace data.

**Conditions** Measurement views: Demod I&Q versus Time

**Group** Read commands

**Syntax** READ:DIQVtime:Q?

**Arguments** None

**Returns** #<num\_digit><num\_byte><data(1)><data(2)>...<data(n)>

Where

<num\_digit> is the number of digits in <num\_byte>.

<num\_byte> is the number of bytes of data that follow.

<data(n)> is the Q level in volts at the n<sup>th</sup> data point,

4-byte little endian floating-point format specified in IEEE 488.2.

**Examples** READ:DIQVTIME:Q? might return #3160xxxx... (160-byte data) for the Q versus Time trace.

## READ:DPSA:RESults:TRACe<x>? (Query Only)

Acquires a waveform and then returns waveform data of the specified trace <x> in the DPX spectrum measurement, where x is 1 to 5. The traces 1–4 are in the standard form. Trace 5 is the bitmap trace and its data is returned in a binary block.

<b>Conditions</b>	Measurement views: DPX spectrum
<b>Group</b>	Read commands
<b>Syntax</b>	READ:DPSA:RESuLts:TRACe<x>?
<b>Arguments</b>	<NR1>
<b>Returns</b>	<p>For traces 1 to 4:  #&lt;num_digit&gt;&lt;num_byte&gt;&lt;data(1)&gt;&lt;data(2)&gt;...&lt;data(n)&gt;</p> <p>Where  &lt;num_digit&gt; is the number of digits in &lt;num_byte&gt;.  &lt;num_byte&gt; is the number of bytes of data that follow.  &lt;data(n)&gt; is the amplitude of the trace sample at the n<sup>th</sup> data point.  &lt;data(n) is in the 4-byte little endian floating-point format specified in IEEE 488.2.</p> <p>For trace 5, the format differs depending on whether Option 200 is installed in the instrument.</p> <p>Without Option 200, the format is a binary block of unsigned 16 bit integers. Each value ranges from 0 to 2<sup>16</sup>-1, where 2<sup>16</sup>-1 represents 100%.</p> <p>With Option 200, the format is a binary block of 32 bit floating point values. Each value ranges from 0 to 1.0, where 1.0 represents 100%.</p>
<b>Examples</b>	READ:DPSA:RESuLts:TRACe1? might return #42004xxxx... (2004-byte of data) for the waveform data of trace one (1).

## READ:DPSA:TRACe:AVERAge? (Query Only)

RAcquires a waveform and then returns waveform data of the average trace in the DPX spectrum measurement.

<b>Conditions</b>	Measurement views: DPX spectrum
<b>Group</b>	Read commands
<b>Syntax</b>	READ:DPSA:TRACe:AVERAge?
<b>Arguments</b>	None

**Returns** #<num\_digit><num\_byte><data(1)><data(2)>...<data(n)>

Where

<num\_digit> is the number of digits in <num\_byte>.

<num\_byte> is the number of bytes of data that follow.

<data(n)> is the waveform data of the average trace for the point n in dBm, 4-byte little endian floating-point format specified in IEEE 488.2.

The unit can be changed by the [\[SENSE\]:POWER:UNITs](#) command.

**Examples** READ:DPSA:TRACE:AVERAGE? might return #42004xxxx... (2004-byte data) for the waveform data of the average trace.

## READ:DPSA:TRACe:BITMap? (Query Only)

RAcquires a waveform and then returns trace waveform data of the bitmap trace in the DPX spectrum measurement.

**Conditions** Measurement views: DPX spectrum

**Group** Read commands

**Syntax** READ:DPSA:TRACe:BITMap?

**Arguments** None

**Returns** For trace 5, the format differs depending on whether Option 200 is installed in the instrument. Without Option 200, the format is a binary block of unsigned 16 bit integers. Each value ranges from 0 to  $2^{16}-1$ , where  $2^{16}-1$  represents 100%.

With Option 200, the format is a binary block of 32 bit floating point values. Each value ranges from 0 to 1.0, where 1.0 represents 100%.

**Examples** READ:DPSA:TRACE:BITMAP? might return #42004xxxx... (2004-byte data) for the waveform data of the bitmap trace.

## READ:DPSA:TRACe:MATH? (Query Only)

Returns waveform data of the math trace in the DPX spectrum measurement.

**Conditions** Measurement views: DPX spectrum

<b>Group</b>	Read commands
<b>Syntax</b>	READ:DPSA:TRACe:MATH?
<b>Arguments</b>	None
<b>Returns</b>	#<num_digit><num_byte><data(1)><data(2)>...<data(n)> Where <num_digit> is the number of digits in <num_byte>. <num_byte> is the number of bytes of data that follow. <data(n)> is the waveform data of the math trace for the point n in dBm, 4-byte little endian floating-point format specified in IEEE 488.2. The unit can be changed by the <a href="#">[SENSe]:POWer:UNITs</a> command.
<b>Examples</b>	READ:DPSA:TRACe:MATH? might return #42004xxxx... (2004-byte data) for the waveform data of the math trace.

## READ:DPSA:TRACe:MAXimum? (Query Only)

Returns waveform data of the maximum trace in the DPX spectrum measurement.

<b>Conditions</b>	Measurement views: DPX spectrum
<b>Group</b>	Read commands
<b>Syntax</b>	READ:DPSA:TRACe:MAXimum?
<b>Arguments</b>	None
<b>Returns</b>	#<num_digit><num_byte><data(1)><data(2)>...<data(n)> Where <num_digit> is the number of digits in <num_byte>. <num_byte> is the number of bytes of data that follow. <data(n)> is the waveform data of the maximum trace for the point n in dBm, 4-byte little endian floating-point format specified in IEEE 488.2. The unit can be changed by the <a href="#">[SENSe]:POWer:UNITs</a> command.

**Examples** READ:DPSA:TRACE:MAXIMUM? might return #42004xxxx... (2004-byte data) for the waveform data of the maximum trace.

## READ:DPSA:TRACe:MINimum? (Query Only)

Returns waveform data of the minimum trace in the DPX spectrum measurement.

**Conditions** Measurement views: DPX spectrum

**Group** Read commands

**Syntax** READ:DPSA:TRACe:MINimum?

**Arguments** None

**Returns** #<num\_digit><num\_byte><data(1)><data(2)>...<data(n)>

Where

<num\_digit> is the number of digits in <num\_byte>.

<num\_byte> is the number of bytes of data that follow.

<data(n)> is the waveform data of the minimum trace for the point n in dBm, 4-byte little endian floating-point format specified in IEEE 488.2.

The unit can be changed by the [\[SENSe\]:POWer:UNITs](#) command.

**Examples** READ:DPSA:TRACE:MINIMUM? might return #42004xxxx... (2004-byte data) for the waveform data of the minimum trace.

## READ:EDIagram:FDEVIation? (Query Only)

Returns the frequency deviation versus Time trace data with the X values.

**Group** Read commands

**Syntax** READ:EDIagram:FDEVIation?

### Related Commands

**Returns** #<num\_digit><num\_byte><Y(1)><X(1)><Y(2)><X(2)>...<Y(n)><X(n)>

Where

<num\_digit> is the number of digits in <num\_byte>.  
 <num\_byte> is the number of bytes of data that follow.  
 <Y(n)> and <X(n)> is frequency deviation in Hz and time (symbols) pair at the n<sup>th</sup> data point, 4-byte little endian floating-point format specified in IEEE 488.2.

**Examples** READ:EDIAGRAM:FDEVIATION? might return #3160xxxx... (160-byte data) for the frequency deviation versus Time trace.

## READ:EDIagram:FERRor? (Query Only)

Returns the frequency error in the eye diagram measurement.

**Conditions** Measurement views: Eye diagram

**Group** Read commands

**Syntax** READ:EDIagram:FERRor?

**Arguments** None

**Returns** <freq\_error>::=<NRf> is the frequency error in Hz.

**Examples** READ:EDIAGRAM:FERROR? might return -10.7E+3, indicating the frequency error is -10.7 kHz.

## READ:EDIagram:I? (Query Only)

Returns the I versus Time trace data.

**Conditions** Measurement views: Eye diagram

**Group** Read commands

**Syntax** READ:EDIagram:I?

**Arguments** None

**Returns** #<num\_digit><num\_byte><data(1)><data(2)>...<data(n)>

Where

<num\_digit> is the number of digits in <num\_byte>.

<num\_byte> is the number of bytes of data that follow.

<Y(n)><X(n)> is the I level (normalized) and time (symbols) pair at the n<sup>th</sup> data point, 4-byte little endian floating-point format specified in IEEE 488.2.

**Examples** READ:EDIAGRAM:I? might return #3160xxxx... (160-byte data) for the I versus Time trace.

## READ:EDIagram:Q? (Query Only)

Returns the Q versus Time trace data.

**Conditions** Measurement views: Eye diagram

**Group** Read commands

**Syntax** READ:EDIagram:Q?

**Arguments** None

**Returns** #<num\_digit><num\_byte><data(1)><data(2)>...<data(n)>

Where

<num\_digit> is the number of digits in <num\_byte>.

<num\_byte> is the number of bytes of data that follow.

<Y(n)><X(n)> is the Q level (normalized) and time (symbols) pair at the n<sup>th</sup> data point, 4-byte little endian floating-point format specified in IEEE 488.2.

**Examples** READ:EDIAGRAM:Q? might return #3160xxxx... (160-byte data) for the Q versus Time trace.

## READ:EVM:FERRor? (Query Only)

Returns the frequency error in the EVM versus Time measurement.

**Conditions** Measurement views: EVM versus Time



---

<b>Group</b>	Read commands
<b>Syntax</b>	READ:EVM:FERRor?
<b>Arguments</b>	None
<b>Returns</b>	<freq_error> ::= <NRf> is the frequency error in Hz.
<b>Examples</b>	READ:EVM:FERROR? might return -10.7E+3, indicating the frequency error is -10.7 kHz.

### READ:EVM:PEAK? (Query Only)

Returns the peak value in the EVM versus Time measurement.

<b>Conditions</b>	Measurement views: EVM versus Time
<b>Group</b>	Read commands
<b>Syntax</b>	READ:EVM:PEAK?
<b>Related Commands</b>	<a href="#">READ:EVM:PINDEX?</a>
<b>Arguments</b>	None
<b>Returns</b>	<peak> ::= <NRf> is the peak EVM value in percent (%).
<b>Examples</b>	READ:EVM:PEAK? might return 1.32, indicating the peak EVM value is 1.32%.

### READ:EVM:PINDEX? (Query Only)

Returns the time at the EVM peak.

<b>Conditions</b>	Measurement views: EVM versus Time
-------------------	------------------------------------

<b>Group</b>	Read commands
<b>Syntax</b>	READ:EVM:PINDEX?
<b>Related Commands</b>	<a href="#">READ:EVM:PEAK?</a>
<b>Arguments</b>	None
<b>Returns</b>	<peak_time>::=<NRF> is the time at the EVM peak in symbol number. The unit can be changed by the <a href="#">[SENSE]:DDEMod:TIME:UNITs</a> command.
<b>Examples</b>	READ:EVM:PINDEX? might return 68.000, indicating that the EVM peak is at symbol #68.

## READ:EVM:RMS? (Query Only)

Returns the RMS (Root-Mean-Square) value in the EVM versus Time measurement.

<b>Conditions</b>	Measurement views: EVM versus Time
<b>Group</b>	Read commands
<b>Syntax</b>	READ:EVM:RMS?
<b>Arguments</b>	None
<b>Returns</b>	<rms>::=<NRF> is the RMS EVM value in percent (%).
<b>Examples</b>	READ:EVM:RMS? might return 0.582, indicating the RMS EVM value is 0.582%.

## READ:EVM:TRACe? (Query Only)

Returns the EVM versus Time trace data.

<b>Conditions</b>	Measurement views: EVM versus Time
-------------------	------------------------------------

<b>Group</b>	Read commands
<b>Syntax</b>	READ:EVM:TRACe?
<b>Arguments</b>	None
<b>Returns</b>	#<num_digit><num_byte><data(1)><data(2)>...<data(n)> Where <num_digit> is the number of digits in <num_byte>. <num_byte> is the number of bytes of data that follow. <data(n)> is the EVM versus Time trace data for the point n in percent (%), 4-byte little endian floating-point format specified in IEEE 488.2.
<b>Examples</b>	READ:EVM:TRACE? might return #42036xxxx... (2036-byte data) for the EVM versus Time trace.

## READ:FDVTime:FERRor? (Query Only)

Returns the frequency error in the Frequency deviation versus Time measurement.

<b>Conditions</b>	Measurement views: Frequency deviation versus Time
<b>Group</b>	Read commands
<b>Syntax</b>	READ:FDVTime:FERRor?
<b>Arguments</b>	None
<b>Returns</b>	<freq_error> ::= <Nrf> is the frequency error in Hz.
<b>Examples</b>	READ:FDVTIME:FERROR? might return -10.7E+3, indicating the frequency error is -10.7 kHz.

## READ:FDVTime:TRACe? (Query Only)

Returns the Frequency deviation versus Time trace data.

<b>Conditions</b>	Measurement views: Frequency deviation versus Time
<b>Group</b>	Read commands
<b>Syntax</b>	READ:FDVTime:TRACE?
<b>Arguments</b>	None
<b>Returns</b>	#<num_digit><num_byte><data(1)><data(2)>...<data(n)> Where <num_digit> is the number of digits in <num_byte>. <num_byte> is the number of bytes of data that follow. <data(n)> is the frequency deviation in Hz at the n <sup>th</sup> data point, 4-byte little endian floating-point format specified in IEEE 488.2.
<b>Examples</b>	READ:FDVTIME:TRACE? might return #3160xxxx... (160-byte data) for the Frequency deviation versus Time trace.

## READ:{FM|PM}:FERRor? (Query Only)

Returns the frequency error in the Frequency modulation and Phase modulation measurements.

<b>Conditions</b>	Measurement views: Frequency and Phase modulation
<b>Group</b>	Read commands
<b>Syntax</b>	READ:{FM PM}:FERRor?
<b>Arguments</b>	None
<b>Returns</b>	<freq_error>::=<Nrf> is the frequency error in Hz.
<b>Examples</b>	READ:FM:FERRor? might return -10.7E+3, indicating the frequency error is -10.7 kHz.

## READ:FM:PHALf? (Query Only)

Returns the half peak-peak frequency deviation ( $Pk-Pk/2$ ) in the FM measurement.

<b>Conditions</b>	Measurement views: Frequency deviation versus Time
<b>Group</b>	Read commands
<b>Syntax</b>	READ:FM:PHALf?
<b>Arguments</b>	None
<b>Returns</b>	<Pk-Pk/2> ::= <NRf> is the half peak-peak frequency deviation in Hz.
<b>Examples</b>	READ:FM:PHALF? might return 628.9E+3, indicating the half peak-peak frequency deviation is 628.9 kHz.

## READ:FM:PNEGative? (Query Only)

Returns the negative peak frequency deviation ( $-Pk$ ) in the FM measurement.

<b>Conditions</b>	Measurement views: FM
<b>Group</b>	Read commands
<b>Syntax</b>	READ:FM:PNEGative?
<b>Arguments</b>	None
<b>Returns</b>	<-Pk> ::= <NRf> is the negative peak frequency deviation in Hz.
<b>Examples</b>	READ:FM:PNEGATIVE? might return -495.6E+3, indicating the negative peak frequency deviation is -495.6 kHz.

## READ:FM:PPOSitive? (Query Only)

Returns the positive peak frequency deviation (+Pk) in the FM measurement.

<b>Conditions</b>	Measurement views: FM
<b>Group</b>	Read commands
<b>Syntax</b>	READ:FM:PPOSitive?
<b>Arguments</b>	None
<b>Returns</b>	<+Pk>::=<NRF> is the positive peak frequency deviation in Hz.
<b>Examples</b>	READ:FM:PPOSITIVE? might return 763.2E+3, indicating the positive peak frequency deviation is 763.2 kHz.

## READ:FM:PTPeak? (Query Only)

Returns the peak-peak frequency deviation (Pk-Pk) in the FM measurement.

<b>Conditions</b>	Measurement views: FM
<b>Group</b>	Read commands
<b>Syntax</b>	READ:FM:PTPeak?
<b>Arguments</b>	None
<b>Returns</b>	<Pk-Pk>::=<NRF> is the peak-peak frequency deviation in Hz.
<b>Examples</b>	READ:FM:PTPEAK? might return 1.258E+6, indicating the peak-peak frequency deviation is 1.258 MHz.

## READ:FM:RESult? (Query Only)

Returns the FM measurement results.

**Conditions** Measurement views: FM

**Group** Read commands

**Syntax** READ:FM:RESult?

**Arguments** None

**Returns** <+Pk> , <-Pk> , <RMS> , <Pk-Pk> , <Pk-Pk/2>

Where

<+Pk> ::= <NRf> is the positive peak frequency deviation in Hz.

<-Pk> ::= <NRf> is the negative peak frequency deviation in Hz.

<RMS> ::= <NRf> is the RMS frequency deviation in Hz.

<Pk-Pk> ::= <NRf> is the peak-peak frequency deviation in Hz.

<Pk-Pk/2> ::= <NRf> is the half peak-peak frequency deviation in Hz.

**Examples** READ:FM:RESULT? might return  
763.2E+3, -494.6E+3, 271.2E+3, 1.258E+6, 628.9E+3.

## READ:FM:RMS? (Query Only)

Returns the RMS frequency deviation in the FM measurement.

**Conditions** Measurement views: FM

**Group** Read commands

**Syntax** READ:FM:RMS?

**Arguments** None

**Returns** <RMS> ::= <NRf> is the RMS frequency deviation in Hz.

**Examples**    `READ:FM:RMS?` might return `271.2E+3`, indicating the RMS frequency deviation is 271.2 kHz.

## READ:FVTime? (Query Only)

Returns the Frequency versus Time trace data.

**Conditions**    Measurement views: Frequency versus Time

**Group**        Read commands

**Syntax**       `READ:FVTime?`

**Arguments**    None

**Returns**      `#<num_digit><num_byte><data(1)><data(2)>...<data(n)>`

Where

`<num_digit>` is the number of digits in `<num_byte>`.

`<num_byte>` is the number of bytes of data that follow.

`<data(n)>` is the frequency drift data for the point `n` in Hz, 4-byte little endian floating-point format specified in IEEE 488.2.

**Examples**    `READ:FVTIME?` might return `#3156xxxx...` (156-byte data) for the Frequency versus Time trace.

## READ:FVTime:MAXimum? (Query Only)

Returns the maximum value in the Frequency versus Time measurement.

**Conditions**    Measurement views: Frequency versus Time

**Group**        Read commands

**Syntax**       `READ:FVTime:MAXimum? imum`

**Related Commands**    [READ:FVTime:MAXLocation?](#)



<b>Arguments</b>	None
<b>Returns</b>	<max> ::= <Nrf> is the maximum frequency drift in Hz.
<b>Examples</b>	READ:FVTIME:MAXIMUM? might return 2.625E+6, indicating the maximum frequency drift is 2.625 MHz.

## READ:FVTime:MAXLocation? (Query Only)

Returns the time at which the frequency drift is maximum.

<b>Conditions</b>	Measurement views: Frequency versus Time
<b>Group</b>	Read commands
<b>Syntax</b>	READ:FVTime:MAXLocation?

**Related Commands** [READ:FVTime:MAXimum?](#)

<b>Arguments</b>	None
<b>Returns</b>	<max_time> ::= <Nrf> is the time in seconds at which the frequency drift is maximum.
<b>Examples</b>	READ:FVTIME:MAXLOCATION? might return 25.03E-9, indicating the frequency drift is maximum at 25.03 ns.

## READ:FVTime:MINimum? (Query Only)

Returns the minimum value in the Frequency versus Time measurement.

<b>Conditions</b>	Measurement views: Frequency versus Time
<b>Group</b>	Read commands
<b>Syntax</b>	READ:FVTime:MINimum?

**Related Commands**    [READ:FVTime:MINLocation?](#)

**Arguments**    None

**Returns**    <min>::=<Nrf> is the minimum frequency drift in Hz.

**Examples**    READ:FVTIME:MINIMUM? might return -6.618E+6, indicating the minimum frequency drift is -6.618 MHz.

## READ:FVTime:MINLocation? (Query Only)

Returns the time at which the frequency drift is minimum.

**Conditions**    Measurement views: Frequency versus Time

**Group**    Read commands

**Syntax**    READ:FVTime:MINLocation?

**Related Commands**    [READ:FVTime:MINimum?](#)

**Arguments**    None

**Returns**    <min\_time>::=<Nrf> is the time in seconds at which the frequency drift is minimum.

**Examples**    READ:FVTIME:MINLOCATION? might return 450.7E-9, indicating the frequency drift is minimum at 450.7 ns.

## READ:FVTime:RESult? (Query Only)

Returns the Frequency versus Time measurement results.

**Conditions**    Measurement views: Frequency versus Time

**Group**    Read commands

<b>Syntax</b>	READ:FVTime:RESult?
<b>Arguments</b>	None
<b>Returns</b>	<max>,<max_time>,<min>,<min_time> Where <max>::=<Nrf> is the maximum frequency drift in Hz. <max_time>::=<Nrf> is the time in seconds at which the frequency drift is maximum. <min>::=<Nrf> is the minimum frequency drift in Hz. <min_time>::=<Nrf> is the time in seconds at which the frequency drift is minimum.
<b>Examples</b>	READ:FVTIME:RESULT? might return 2.625E+6,25.03E-9,-6.618E+6,450.7E-9, indicating the maximum frequency drift is 2.625 MHz at 25.03 ns and the minimum frequency drift is -6.618 MHz at 450.7 ns.

## READ:IQVTime:I? (Query Only)

Returns the I versus Time trace data.

<b>Conditions</b>	Measurement views: RF I&Q versus Time
<b>Group</b>	Read commands
<b>Syntax</b>	READ:IQVTime:I?
<b>Arguments</b>	None
<b>Returns</b>	#<num_digit><num_byte><data(1)><data(2)>...<data(n)> Where <num_digit> is the number of digits in <num_byte>. <num_byte> is the number of bytes of data that follow. <data(n)> is the I level data for the point n in volts, 4-byte little endian floating-point format specified in IEEE 488.2.

**Examples** READ:IQVTIME:I? might return #3160xxxx... (160-byte data) for the I versus Time trace.

## READ:IQVTime:MAXimum? (Query Only)

Returns the maximum value in the RF I&Q versus Time measurement.

**Conditions** Measurement views: RF I&Q versus Time

**Group** Read commands

**Syntax** READ:IQVTime:MAXimum? *imum*

**Related Commands** [READ:IQVTime:MAXLocation?](#)

**Arguments** None

**Returns** <max> ::= <Nrf> is the maximum I or Q level in volts.

**Examples** READ:IQVTIME:MAXIMUM? might return 1.214, indicating the maximum I or Q level is 1.214 V.

## READ:IQVTime:MAXLocation? (Query Only)

Returns the time at which the I or Q level is maximum.

**Conditions** Measurement views: RF I&Q versus Time

**Group** Read commands

**Syntax** READ:IQVTime:MAXLocation?

**Related Commands** [READ:IQVTime:MAXimum?](#)

**Arguments** None

**Returns** <max\_time>::=<NRf> is the time in seconds at which the I or Q level is maximum.

**Examples** READ:IQVTIME:MAXLOCATION? might return 175.3E-9, indicating the I or Q level is maximum at 175.3 ns.

## READ:IQVTime:MINimum? (Query Only)

Returns the minimum value in the RF I&Q versus Time measurement.

**Conditions** Measurement views: RF I&Q versus Time

**Group** Read commands

**Syntax** READ:IQVTime:MINimum?

**Related Commands** [READ:IQVTime:MINLocation?](#)

**Arguments** None

**Returns** <min>::=<NRf> is the minimum I or Q level in volts.

**Examples** READ:IQVTIME:MINIMUM? might return -370.5E-3, indicating the minimum I or Q level is -370.5 mV.

## READ:IQVTime:MINLocation? (Query Only)

Returns the time at which the I or Q level is minimum.

**Conditions** Measurement views: RF I&Q versus Time

**Group** Read commands

**Syntax** READ:IQVTime:MINLocation?

**Related Commands** [READ:IQVTime:MINimum?](#)

<b>Arguments</b>	None
<b>Returns</b>	<code>&lt;min_time&gt;::=&lt;NRF&gt;</code> is the time in seconds at which the I or Q level is minimum.
<b>Examples</b>	<code>READ:IQVTIME:MINLOCATION?</code> might return <code>450.7E-9</code> , indicating the I or Q level is minimum at 450.7 ns.

## READ:IQVTime:Q? (Query Only)

Returns the Q versus Time trace data.

<b>Conditions</b>	Measurement views: IQ versus Time
<b>Group</b>	Read commands
<b>Syntax</b>	<code>READ:IQVTime:Q?</code>
<b>Arguments</b>	None
<b>Returns</b>	<p><code>#&lt;num_digit&gt;&lt;num_byte&gt;&lt;data(1)&gt;&lt;data(2)&gt;...&lt;data(n)&gt;</code></p> <p>Where</p> <ul style="list-style-type: none"> <li><code>&lt;num_digit&gt;</code> is the number of digits in <code>&lt;num_byte&gt;</code>.</li> <li><code>&lt;num_byte&gt;</code> is the number of bytes of data that follow.</li> <li><code>&lt;data(n)&gt;</code> is the Q level data for the point n in volts, 4-byte little endian floating-point format specified in IEEE 488.2.</li> </ul>
<b>Examples</b>	<code>READ:IQVTIME:Q?</code> might return <code>#3160xxxx...</code> (160-byte data) for the Q versus Time trace.

## READ:IQVTime:RESult? (Query Only)

Returns the RF I&Q versus Time measurement results.

<b>Conditions</b>	Measurement views: RF I&Q versus Time
<b>Group</b>	Read commands

<b>Syntax</b>	READ:IQVTime:RESUlt?
<b>Arguments</b>	None
<b>Returns</b>	<max>,<max_time>,<min>,<min_time> Where <max>::=<Nrf> is the maximum I or Q level in volts. <max_time>::=<Nrf> is the time in seconds at which the I or Q level is maximum. <min>::=<Nrf> is the minimum I or Q level in volts. <min_time>::=<Nrf> is the time in seconds at which the I or Q level is minimum.
<b>Examples</b>	READ:IQVTIME:RESULT? might return 1.214,175.3E-9,-370.5E-3,450.7E-9, indicating the maximum I or Q level is 1.214 V at 175.3 ns and the minimum I or Q level is -370.5 mV at 450.7 ns.

## READ:MCPower:ADJacent:CHANnels? (Query Only)

Returns the power of adjacent channels in order of increasing frequency.

<b>Conditions</b>	Measurement views: MCPR
<b>Group</b>	Read commands
<b>Syntax</b>	READ:MCPower:ADJacent:CHANnels?
<b>Arguments</b>	None
<b>Returns</b>	<acpr_lower(n)>,...<acpr_lower(2)>,<acpr_lower(1)>, <acpr_upper(1)>,<acpr_upper(2)>,...<acpr_upper(n)> Where <acpr_lower(n)> is the ACPR for the lower channel #n in dB. <acpr_upper(n)> is the ACPR for the upper channel #n in dB. To add a pair of upper and lower adjacent channels, use the <a href="#">[SENSe]:MCPower:CHANnel:ADJacent:ADD</a> command.

**Examples** READ:MCPOWER:ADJACENT:CHANNELS? might return -4.420, -4.847, -4.316, -4.225, indicating (ACPR for the lower channel 2) = -4.420 dB, (ACPR for the lower channel 1) = -4.847 dB, (ACPR for the upper channel 1) = -4.316 dB, and (ACPR for the upper channel 2) = -4.225 dB.

## READ:MCPower:CHANnel:POWer? (Query Only)

Returns the reference power in the MCPR measurement.

**Conditions** Measurement views: MCPR

**Group** Read commands

**Syntax** READ:MCPower:CHANnel:POWer?

**Arguments** None

**Returns** <ref\_power>: <NRF> is the reference power in dBm. The unit can be changed by the [SENSe]:POWer:UNITs command. To select the power reference, use the [SENSe]:MCPower:RCHannels commands.

**Examples** READ:MCPOWER:CHANNEL:POWER? might return 4.227, indicating that the reference power is 4.227 dBm.

## READ:MCPower:MAIN:CHANnels? (Query Only)

Returns the power of main channels in order of increasing frequency.

**Conditions** Measurement views: MCPR

**Group** Read commands

**Syntax** READ:MCPower:MAIN:CHANnels?

**Related Commands** [:SENSe]:MCPower:CHANnel:MAIN commands



<b>Arguments</b>	None
<b>Returns</b>	<p>&lt;power_main(1)&gt;, &lt;power_main(2)&gt;, ... &lt;power_main(n)&gt;</p> <p>Where          &lt;power_main(n)&gt; is the power of main channel #n in dBm.          The unit can be changed by the <a href="#">[SENSe]:POWer:UNITs</a> command.</p> <p>To specify the main channels, use the <a href="#">[SENSe]:MCPower:CHANnel:MAIN</a> commands.</p>
<b>Examples</b>	<p>READ:MCPOWER:MAIN:CHANNELS? might return          -2.420, -2.847, -2.316, -2.225, indicating          (power of the main channel 1) = -2.420 dBm,          (power of the main channel 2) = -2.847 dBm,          (power of the main channel 3) = -2.316 dBm, and          (power of the main channel 4) = -2.225 dBm.</p>

## READ:MCPower:SPECTrum? (Query Only)

Returns spectrum trace data of the MCPR measurement.

<b>Conditions</b>	Measurement views: MCPR
<b>Group</b>	Read commands
<b>Syntax</b>	READ:MCPower:SPECTrum?
<b>Arguments</b>	None
<b>Returns</b>	<p>#&lt;num_digit&gt;&lt;num_byte&gt;&lt;data(1)&gt;&lt;data(2)&gt;...&lt;data(n)&gt;</p> <p>Where          &lt;num_digit&gt; is the number of digits in &lt;num_byte&gt;.          &lt;num_byte&gt; is the number of bytes of data that follow.          &lt;data(n)&gt; is the spectrum trace data in dBm for the point n,          4-byte little endian floating-point format specified in IEEE 488.2.          The unit can be changed by the <a href="#">[SENSe]:POWer:UNITs</a> command.</p>
<b>Examples</b>	<p>READ:MCPOWER:SPECTRUM? might return #43204xxxx... (3204-byte data) for the spectrum trace data of the MCPR measurement.</p>

## READ:MERRor:FERRor? (Query Only)

Returns the frequency error in the Magnitude error versus Time measurement.

**Conditions** Measurement views: Magnitude error versus Time

**Group** Read commands

**Syntax** READ:MERRor:FERRor?

**Arguments** None

**Returns** <freq\_error> ::= <NRf> is the frequency error in Hz.

**Examples** READ:MERRor:FERRor? might return -10.7E+3, indicating the frequency error is -10.7 kHz.

## READ:MERRor:PEAK? (Query Only)

Returns the peak value in the Magnitude error versus Time measurement.

**Conditions** Measurement views: Magnitude error versus Time

**Group** Read commands

**Syntax** READ:MERRor:PEAK?

**Related Commands** [READ:MERRor:PINdex?](#)

**Arguments** None

**Returns** <peak> ::= <NRf> is the peak magnitude error in percent (%).

**Examples** READ:MERRor:PEAK? might return 1.57, indicating the peak magnitude error is 1.57%.

## READ:MERRor:PINdex? (Query Only)

Returns the time at the magnitude error peak.

**Conditions** Measurement views: Magnitude error versus Time

**Group** Read commands

**Syntax** READ:MERRor:PINdex?

**Related Commands** [READ:MERRor:PEAK?](#)

**Arguments** None

**Returns** <peak\_time>::=<NRf> is the time at the magnitude error peak in symbol number. The unit can be changed by the [\[SENSe\]:DDEMod:TIME:UNITs](#) command.

**Examples** READ:MERRor:PINdex? might return 68.000, indicating that the magnitude error peak is at symbol #68.

## READ:MERRor:RMS? (Query Only)

Returns the RMS (Root-Mean-Square) value in the Magnitude error versus Time measurement.

**Conditions** Measurement views: Magnitude error versus Time

**Group** Read commands

**Syntax** READ:MERRor:RMS?

**Arguments** None

**Returns** <rms>::=<NRf> is the RMS magnitude error in percent (%).

**Examples**     `READ:MERROR:RMS?` might return `0.382`, indicating the magnitude error is 0.382% RMS.

## **READ:MERRor:TRACe? (Query Only)**

Returns the Magnitude error versus Time trace data.

**Conditions**     Measurement views: Magnitude error versus Time

**Group**            Read commands

**Syntax**           `READ:MERRor:TRACe?`

**Arguments**       None

**Returns**           `#<num_digit><num_byte><data(1)><data(2)>...<data(n)>`

Where

`<num_digit>` is the number of digits in `<num_byte>`.

`<num_byte>` is the number of bytes of data that follow.

`<data(n)>` is the magnitude error data for the point `n` in percent (%), 4-byte little endian floating-point format specified in IEEE 488.2.

**Examples**     `READ:MERROR:TRACE?` might return `#42036xxxx...` (2036-byte data) for the Magnitude error versus Time trace.

## **READ:OBWidth:FREQuency:ERRor? (Query Only)**

Returns the frequency error in the Occupied Bandwidth measurement.

**Conditions**     Measurement views: Occupied Bandwidth

**Group**            Read commands

**Syntax**           `READ:OBWidth:FREQuency:ERRor?`

**Arguments**       None

**Returns** <freq\_error> ::= <Nrf> is the frequency error in Hz.

**Examples** READ:OBWIDTH:FREQUENCY:ERROR? might return -10.7E+3, indicating the frequency error is -10.7 kHz.

## READ:OBWidth:OBWidth:BANDwidth? (Query Only)

Returns the occupied bandwidth in the Occupied Bandwidth measurement.

**Conditions** Measurement views: Occupied Bandwidth

**Group** Read commands

**Syntax** READ:OBWidth:OBWidth:BANDwidth?

**Arguments** None

**Returns** <OBW> ::= <Nrf> is the occupied bandwidth in Hz.

**Examples** READ:OBWIDTH:OBWIDTH:BANDWIDTH? might return 4.0E+6, indicating the occupied bandwidth is 4 MHz.

## READ:OBWidth:OBWidth:LEFT:FREQUENCY? (Query Only)

Returns the left (lower) frequency of the occupied bandwidth.

**Conditions** Measurement views: Occupied Bandwidth

**Group** Read commands

**Syntax** READ:OBWidth:OBWidth:LEFT:FREQUENCY?

**Related Commands** [READ:OBWidth:OBWidth:RIGHT:FREQUENCY?](#)

**Arguments** None

**Returns** <OBW\_left\_freq>::=<Nrf> is the left frequency in Hz.

**Examples** READ:OBWIDTH:OBWIDTH:LEFT:FREQUENCY? might return 1.498E+9, indicating the left frequency is 1.498 GHz.

## READ:OBWidth:OBWidth:LEFT:LEVel? (Query Only)

Returns the level at the left frequency of the occupied bandwidth.

**Conditions** Measurement views: Occupied Bandwidth

**Group** Read commands

**Syntax** READ:OBwidth:OBwidth:LEFT:LEVel?

**Related Commands** [READ:OBWidth:OBWidth:RIGHT:LEVel?](#)

**Arguments** None

**Returns** <OBW\_left\_level>::=<Nrf> is the level at the left frequency in dB.

**Examples** READ:OBWIDTH:OBWIDTH:LEFT:LEVEL? might return -23.5, indicating the level at the left frequency is -23.5 dB.

## READ:OBWidth:OBWidth:POWer? (Query Only)

Returns the reference power in the Occupied Bandwidth measurement.

**Conditions** Measurement views: Occupied Bandwidth

**Group** Read commands

**Syntax** READ:OBwidth:OBwidth:POWer?

**Arguments** None

**Returns** <OBW\_ref\_power>::=<NRf> is the reference power in dBm.  
The unit can be changed by the [\[SENSe\]:POWer:UNITs](#) command.

**Examples** READ:OBWIDTH:OBWIDTH:POWER? might return -10.0, indicating the reference power is -10 dBm.

## READ:OBWidth:OBWidth:RIGHT:FREQUENCY? (Query Only)

Returns the right (higher) frequency of the occupied bandwidth.

**Conditions** Measurement views: Occupied Bandwidth

**Group** Read commands

**Syntax** READ:OBWidth:OBWidth:RIGHT:FREQUENCY?

**Related Commands** [READ:OBWidth:OBWidth:LEFT:FREQUENCY?](#)

**Arguments** None

**Returns** <OBW\_right\_freq>::=<NRf> is the right frequency in Hz.

**Examples** READ:OBWIDTH:OBWIDTH:RIGHT:FREQUENCY? might return 1.502E+9, indicating the right frequency is 1.502 GHz.

## READ:OBWidth:OBWidth:RIGHT:LEVEL? (Query Only)

Returns the level at the right frequency of the occupied bandwidth.

**Conditions** Measurement views: Occupied Bandwidth

**Group** Read commands

**Syntax** READ:OBWidth:OBWidth:RIGHT:LEVEL?

**Related Commands** [READ:OBWidth:OBWidth:LEFT:LEVEL?](#)

<b>Arguments</b>	None
<b>Returns</b>	<OBW_right_level>::=<Nrf> is the level at the right frequency in dB.
<b>Examples</b>	READ:OBWIDTH:OBWIDTH:RIGHT:LEVEL? might return -23.5, indicating the level at the right frequency is -23.5 dB.

## READ:OBWidth:SPECTrum? (Query Only)

Returns spectrum trace data of the Occupied Bandwidth measurement.

<b>Conditions</b>	Measurement views: Occupied Bandwidth
<b>Group</b>	Read commands
<b>Syntax</b>	READ:OBwidth:SPECTrum?
<b>Arguments</b>	None
<b>Returns</b>	#<num_digit><num_byte><data(1)><data(2)>...<data(n)> Where <num_digit> is the number of digits in <num_byte>. <num_byte> is the number of bytes of data that follow. <data(n)> is the amplitude in dBm at the n <sup>th</sup> data point, 4-byte little endian floating-point format specified in IEEE 488.2. The unit can be changed by the <a href="#">[SENSe]:POWer:UNITs</a> command.
<b>Examples</b>	READ:OBWIDTH:SPECTRUM? might return #43204xxxx... (3204-byte data) for the spectrum trace data of the Occupied Bandwidth measurement.

## READ:OBWidth:XDBBandwidth:BANDwidth? (Query Only)

Returns the x dB bandwidth in the Occupied Bandwidth measurement.

<b>Conditions</b>	Measurement views: Occupied Bandwidth
<b>Group</b>	Read commands



---

<b>Syntax</b>	READ:OBWidth:XDBBandwidth:BANDwidth?
<b>Arguments</b>	None
<b>Returns</b>	<xdBW> ::= <NRf> is the x dB bandwidth in Hz.
<b>Examples</b>	READ:OBWIDTH:XDBBANDWIDTH:BANDWIDTH? might return 2.0E+6, indicating the x dB bandwidth is 2 MHz.

### READ:OBWidth:XDBBandwidth:LEFT:FREQUENCY? (Query Only)

Returns the left (lower) frequency of the x dB bandwidth.

<b>Conditions</b>	Measurement views: Occupied Bandwidth
<b>Group</b>	Read commands
<b>Syntax</b>	READ:OBWidth:XDBBandwidth:LEFT:FREQUENCY?
<b>Related Commands</b>	<a href="#">READ:OBWidth:XDBBandwidth:RIGHT:FREQUENCY?</a>
<b>Arguments</b>	None
<b>Returns</b>	<xdBW_left_freq> ::= <NRf> is the left frequency in Hz.
<b>Examples</b>	READ:OBWIDTH:XDBBANDWIDTH:LEFT:FREQUENCY? might return 1.498E+9, indicating the left frequency is 1.498 GHz.

### READ:OBWidth:XDBBandwidth:LEFT:LEVEL? (Query Only)

Returns the level at the left frequency of the x dB bandwidth.

<b>Conditions</b>	Measurement views: Occupied Bandwidth
<b>Group</b>	Read commands

**Syntax** READ:OBwidth:XDBBandwidth:LEFT:LEVEL?

**Related Commands** [READ:OBWidth:XDBBandwidth:RIGHT:LEVEL?](#)

**Arguments** None

**Returns** <xdbbw\_left\_level>::=<NRF> is the level at the left frequency in dB.

**Examples** READ:OBWIDTH:XDBBANDWIDTH:LEFT:LEVEL? might return -23.5, indicating the level at the left frequency is -23.5 dB.

## READ:OBWidth:XDBBandwidth:POWer? (Query Only)

Returns the reference power in the x dB bandwidth measurement.

**Conditions** Measurement views: Occupied Bandwidth

**Group** Read commands

**Syntax** READ:OBwidth:XDBBandwidth:POWer?

**Arguments** None

**Returns** <xdbbw\_ref\_power>::=<NRF> is the reference power in dBm. The unit can be changed by the [\[SENSE\]:POWer:UNITs](#) command.

**Examples** READ:OBWIDTH:XDBBANDWIDTH:POWer? might return -10.0, indicating the reference power is -10 dBm.

## READ:OBWidth:XDBBandwidth:RIGHT:FREQuency? (Query Only)

Returns the right (higher) frequency of the x dB bandwidth.

**Conditions** Measurement views: Occupied Bandwidth

**Group** Read commands

**Syntax**     `READ:OBWidth:XDBBandwidth:RIGHT:FREQUENCY?`

**Related Commands**     [READ:OBWidth:XDBBandwidth:LEFT:FREQUENCY?](#)

**Arguments**     None

**Returns**     `<xdBW_right_freq>::=<Nrf>` is the right frequency in Hz.

**Examples**     `READ:OBWIDTH:XDBBANDWIDTH:RIGHT:FREQUENCY?` might return `1.502E+9`, indicating the right frequency is 1.502 GHz.

## **READ:OBWidth:XDBBandwidth:RIGHT:LEVEL? (Query Only)**

Returns the level at the right frequency of the x dB bandwidth.

**Conditions**     Measurement views: Occupied Bandwidth

**Group**     Read commands

**Syntax**     `READ:OBWidth:XDBBandwidth:RIGHT:LEVEL?`

**Related Commands**     [READ:OBWidth:XDBBandwidth:LEFT:LEVEL?](#)

**Arguments**     None

**Returns**     `<xdBW_right_level>::=<Nrf>` is the level at the right frequency in dB.

**Examples**     `READ:OBWIDTH:XDBBANDWIDTH:RIGHT:LEVEL?` might return `-23.5`, indicating the level at the right frequency is -23.5 dB.

## **READ:PERRor:FERRor? (Query Only)**

Returns the frequency error in the Phase error versus Time measurement.

**Conditions**     Measurement views: Phase error versus Time

<b>Group</b>	Read commands
<b>Syntax</b>	READ:PERRor:FERRor?
<b>Arguments</b>	None
<b>Returns</b>	<freq_error> ::= <NRf> is the frequency error in Hz.
<b>Examples</b>	READ:PERRor:FERRor? might return -10.7E+3, indicating the frequency error is -10.7 kHz.

## READ:PERRor:PEAK? (Query Only)

Returns the peak value in the Phase error versus Time measurement.

<b>Conditions</b>	Measurement views: Phase error versus Time
<b>Group</b>	Read commands
<b>Syntax</b>	READ:PERRor:PEAK?
<b>Related Commands</b>	<a href="#">READ:PERRor:PINDEX?</a>
<b>Arguments</b>	None
<b>Returns</b>	<peak> ::= <NRf> is the peak phase error in degrees.
<b>Examples</b>	READ:PERRor:PEAK? might return 0.683, indicating the peak phase error is 0.683 °.

## READ:PERRor:PINDEX? (Query Only)

Returns the time at the phase error peak.

<b>Conditions</b>	Measurement views: Phase error versus Time
-------------------	--

---

<b>Group</b>	Read commands
<b>Syntax</b>	READ:PERRor:PINdex?
<b>Related Commands</b>	<a href="#">READ:PERRor:PEAK?</a>
<b>Arguments</b>	None
<b>Returns</b>	<peak_time>::=<NRf> is the time at the phase error peak in symbol number. The unit can be changed by the <a href="#">[SENSe]:DDEMod:TIME:UNITs</a> command.
<b>Examples</b>	READ:PERRor:PINdex? might return 68.000, indicating that the phase error peak is at symbol #68.

## READ:PERRor:RMS (Query Only)

Returns the RMS (Root-Mean-Square) value in the Phase error versus Time measurement.

<b>Conditions</b>	Measurement views: Phase error versus Time
<b>Group</b>	Read commands
<b>Syntax</b>	READ:PERRor:RMS
<b>Arguments</b>	None
<b>Returns</b>	<rms>::=<NRf> is the RMS phase error in degrees.
<b>Examples</b>	READ:PERRor:RMS might return 0.746, indicating the phase error is 0.746 ° RMS.

## READ:PERRor:TRACe? (Query Only)

Returns the Phase error versus Time trace data.

<b>Conditions</b>	Measurement views: Phase error versus Time
<b>Group</b>	Read commands
<b>Syntax</b>	READ:PError:TRACe?
<b>Arguments</b>	None
<b>Returns</b>	#<num_digit><num_byte><data(1)><data(2)>...<data(n)> Where <num_digit> is the number of digits in <num_byte>. <num_byte> is the number of bytes of data that follow. <data(n)> is the phase error data for the point n in degrees, 4-byte little endian floating-point format specified in IEEE 488.2.
<b>Examples</b>	READ:PError:TRACe? might return #42036xxxx... (2036-byte data) for the Phase error versus Time trace.

## READ:PHVTime? (Query Only)

Returns the Phase versus Time trace data.

<b>Conditions</b>	Measurement views: Phase versus Time
<b>Group</b>	Read commands
<b>Syntax</b>	READ:PHVTime?
<b>Arguments</b>	None
<b>Returns</b>	#<num_digit><num_byte><data(1)><data(2)>...<data(n)> Where <num_digit> is the number of digits in <num_byte>. <num_byte> is the number of bytes of data that follow. <data(n)> is the phase in degrees at the n <sup>th</sup> data point, 4-byte little endian floating-point format specified in IEEE 488.2.

**Examples** READ:PHVTIME? might return #3160xxxx... (160-byte data) for the Phase versus Time trace.

## READ:PHVTime:MAXimum? (Query Only)

Returns the maximum value in the Phase versus Time measurement.

**Conditions** Measurement views: Phase versus Time

**Group** Read commands

**Syntax** READ:PHVTime:MAXimum?

**Related Commands** [READ:PHVTime:MAXLocation?](#)

**Arguments** None

**Returns** <max> ::= <Nrf> is the maximum phase in degrees.

**Examples** READ:PHVTime:MAXimum? might return 153.8, indicating the maximum phase is 153.8 °.

## READ:PHVTime:MAXLocation? (Query Only)

Returns the time at which the phase is maximum.

**Conditions** Measurement views: Phase versus Time

**Group** Read commands

**Syntax** READ:PHVTime:MAXLocation?

**Related Commands** [READ:PHVTime:MAXimum?](#)

**Arguments** None

**Returns** <max\_time>::=<NRF> is the time in seconds at which the phase is maximum.

**Examples** READ:PHVTIME:MAXLOCATION? might return 175.3E-9, indicating the I or Q level is maximum at 175.3 ns.

## READ:PHVTime:MINimum? (Query Only)

Returns the minimum value in the Phase versus Time measurement.

**Conditions** Measurement views: Phase versus Time

**Group** Read commands

**Syntax** READ:PHVTime:MINimum?

**Related Commands** [READ:PHVTime:MINLocation?](#)

**Arguments** None

**Returns** <min>::=<NRF> is the minimum phase in degrees.

**Examples** READ:PHVTIME:MINIMUM? might return -176.3, indicating the minimum phase is -176.3 °.

## READ:PHVTime:MINLocation? (Query Only)

Returns the time at which the phase is minimum.

**Conditions** Measurement views: Phase versus Time

**Group** Read commands

**Syntax** READ:PHVTime:MINLocation?

**Related Commands** [READ:PHVTime:MINimum?](#)



<b>Arguments</b>	None
<b>Returns</b>	<code>&lt;min_time&gt;::=&lt;NRf&gt;</code> is the time in seconds at which the phase is minimum.
<b>Examples</b>	<code>READ:PHVTIME:MINLOCATION?</code> might return <code>450.7E-9</code> , indicating the phase is minimum at 450.7 ns.

## READ:PHVTime:RESult? (Query Only)

Returns the Phase versus Time measurement results.

<b>Conditions</b>	Measurement views: Phase versus Time
<b>Group</b>	Read commands
<b>Syntax</b>	<code>READ:PHVTime:RESult?</code>
<b>Arguments</b>	None
<b>Returns</b>	<code>&lt;max&gt;, &lt;max_time&gt;, &lt;min&gt;, &lt;min_time&gt;</code> Where <code>&lt;max&gt;::=&lt;NRf&gt;</code> is the maximum phase in degrees. <code>&lt;max_time&gt;::=&lt;NRf&gt;</code> is the time in seconds at which the phase is maximum. <code>&lt;min&gt;::=&lt;NRf&gt;</code> is the minimum phase in degrees. <code>&lt;min_time&gt;::=&lt;NRf&gt;</code> is the time in seconds at which the phase is minimum.
<b>Examples</b>	<code>READ:PHVTIME:RESULT?</code> might return <code>153.8, 175.3E-9, -176.3, 450.7E-9</code> , indicating the maximum phase is $153.8^\circ$ at 175.3 ns and the minimum phase is $-176.3^\circ$ at 450.7 ns.

## READ:PM:PNEGative? (Query Only)

Returns the negative peak phase deviation ( $-P_k$ ) in the PM measurement.

<b>Conditions</b>	Measurement views: PM
<b>Group</b>	Read commands

**Syntax** READ:PM:PNEGative?

**Arguments** None

**Returns** <-Pk>::=<NRF> is the negative peak phase deviation in degrees.

**Examples** READ:PM:PNEGATIVE? might return -23.42, indicating the positive peak phase deviation is -23.42 °.

## READ:PM:PPOSitive? (Query Only)

Returns the positive peak phase deviation (+Pk) in the PM measurement.

**Conditions** Measurement views: PM

**Group** Read commands

**Syntax** READ:PM:PPOSitive?

**Arguments** None

**Returns** <+Pk>::=<NRF> is the positive peak phase deviation in degrees.

**Examples** READ:PM:PPOSITIVE? might return 26.87, indicating the positive peak phase deviation is 26.87 °.

## READ:PM:PTPeak? (Query Only)

Returns the peak-peak phase deviation (Pk-Pk) in the PM measurement.

**Conditions** Measurement views: PM

**Group** Read commands

**Syntax** READ:PM:PTPeak?

<b>Arguments</b>	None
<b>Returns</b>	<Pk-Pk> ::= <NRf> is the peak-peak phase deviation in degrees.
<b>Examples</b>	READ:PM:PTPEAK? might return 46.34, indicating the peak-peak phase deviation is 46.34 °.

## READ:PM:RESult? (Query Only)

Returns the PM measurement results.

<b>Conditions</b>	Measurement views: PM
<b>Group</b>	Read commands
<b>Syntax</b>	READ:PM:RESult?
<b>Arguments</b>	None
<b>Returns</b>	<+Pk> , <-Pk> , <RMS> , <Pk-Pk> Where <+Pk> ::= <NRf> is the positive peak phase deviation in degrees. <-Pk> ::= <NRf> is the negative peak phase deviation in degrees. <RMS> ::= <NRf> is the RMS phase deviation in degrees. <Pk-Pk> ::= <NRf> is the peak-peak phase deviation in degrees.
<b>Examples</b>	READ:PM:RESULT? might return 22.89, -23.45, 15.12, 46.34.

## READ:PM:RMS? (Query Only)

Returns the RMS phase deviation in the PM measurement.

<b>Conditions</b>	Measurement views: PM
<b>Group</b>	Read commands

**Syntax** READ:PM:RMS?

**Arguments** None

**Returns** <RMS>::=<Nrf> is the RMS phase deviation in degrees.

**Examples** READ:PM:RMS? might return 15.12, indicating the RMS frequency deviation is 15.12 °.

## READ:PNOise:ALL? (Query Only)

Returns all results of the phase noise measurement.

**Conditions** Measurement views: Phase noise

**Group** Read commands

**Syntax** READ:PNOise:ALL?

**Arguments** None

**Returns** <Cpower>, <Ferror>, <Pnoise>, <Tjitter>, <Rjitter>, <RFM>

Where

<Cpower>::=<Nrf> is the carrier power in dBm.

<Ferror>::=<Nrf> is the frequency error in Hz.

<Pnoise>::=<Nrf> is the RMS phase noise in degrees.

<Tjitter>::=<Nrf> is the total jitter in seconds.

<Rjitter>::=<Nrf> is the random jitter in seconds.

<RFM>::=<Nrf> is the residual FM in Hz.

**Examples** READ:PNOISE:ALL? might return  
 -9.455,1.235E+6,51.43,2.312E-9,4.178E-9,14.58, indicating  
 Carrier power: -9.455 dBm,  
 Frequency error: 1.235 MHz,  
 RMS phase noise: 51.43 °,  
 Total jitter: 2.312 ns,  
 Random jitter: 4.178 ns, and  
 Residual FM: 14.58 Hz.

## READ:PNOise:CARRier:FERRor? (Query Only)

Returns the carrier frequency error in the phase noise measurement.

**Conditions** Measurement views: Phase noise

**Group** Read commands

**Syntax** READ:PNOise:CARRier:FERRor?

**Arguments** None

**Returns** <NRf> Carrier frequency error in Hz.

**Examples** READ:PNOISE:CARRIER:FERROR? might return 1.235E+6, indicating that the carrier frequency error is 1.235 MHz.

## READ:PNOise:CARRier:POWER? (Query Only)

Returns the carrier power in the phase noise measurement.

**Conditions** Measurement views: Phase noise

**Group** Read commands

**Syntax** READ:PNOise:CARRier:POWER?

**Arguments** None

**Returns** <NRf> Carrier power in dBm.  
The unit can be changed by the [\[SENSe\]:POWER:UNITs](#) command.

**Examples** READ:PNOISE:CARRIER:POWER? might return -9.455, indicating that the carrier power is -9.455 dBm.

## READ:PNOise:JITTer? (Query Only)

Returns the jitter in the phase noise measurement.

**Conditions** Measurement views: Phase noise

**Group** Read commands

**Syntax** READ:PNOise:JITTer?

**Arguments** None

**Returns** <NRf> Jitter in seconds.

**Examples** READ:PNOISE:JITTER? might return 2.312E-9, indicating that the jitter is 2.312 ns.

## READ:PNOise:RESidual:FM? (Query Only)

Returns the residual FM in the phase noise measurement.

**Conditions** Measurement views: Phase noise

**Group** Read commands

**Syntax** READ:PNOise:RESidual:FM?

**Arguments** None

**Returns** <NRf> Residual FM in Hz.

**Examples** READ:PNOISE:RESIDUAL:FM? might return 14.58, indicating that the residual FM is 14.58 Hz.

## READ:PNOise:RMS:PNOise? (Query Only)

Returns the RMS phase noise in the phase noise measurement.

**Conditions** Measurement views: Phase noise

**Group** Read commands

**Syntax** READ:PNOise:RMS:PNOise?

**Arguments** None

**Returns** <NRf> RMS phase noise in degrees.

**Examples** READ:PNOISE:RMS:PNOISE? might return 51.43, indicating that the RMS phase noise is 51.43 °.

## READ:PNOise:SPECTrum<x>:X? (Query Only)

Returns the frequencies of the specified trace.

The parameter <x> = 1 and 2, representing Trace 1 and Trace 2, respectively.

**Conditions** Measurement views: Phase noise

**Group** Read commands

**Syntax** READ:PNOise:SPECTrum<x>:X?

**Arguments** None

**Returns** #<num\_digit><num\_byte><x(1)><x(2)>...<x(n)>

Where

<num\_digit> is the number of digits in <num\_byte>.

<num\_byte> is the number of bytes of data that follow.

<x(n)> is the frequency (Hz) at the n<sup>th</sup> point,

4-byte little endian floating-point format specified in IEEE 488.2.

**Examples** READ:PNOISE:SPECTRUM1:X? might return #516020xxxx... (16020-byte data) for the frequencies of Trace 1.

## READ:PNOise:SPECTrum<x>:XY? (Query Only)

Returns the frequency and phase noise pairs of the specified trace.

The parameter <x> = 1 and 2, representing Trace 1 and Trace 2, respectively.

**Conditions** Measurement views: Phase noise

**Group** Read commands

**Syntax** READ:PNOise:SPECTrum<x>:XY?

**Arguments** None

**Returns** #<num\_digit><num\_byte><x(1)><y(1)><x(2)><y(2)>...<x(n)><y(n)>

Where

<num\_digit> is the number of digits in <num\_byte>.

<num\_byte> is the number of bytes of data that follow.

<x(n)><y(n)> is the frequency (Hz) and phase noise (dBc/Hz) pair at the n<sup>th</sup> data point, 4-byte little endian floating-point format specified in IEEE 488.2.

**Examples** READ:PNOISE:SPECTRUM1:XY? might return #516020xxxx... (16020-byte data) for the frequency and phase noise pairs of the Trace 1.

## READ:PNOise:SPECTrum<x>[:Y]? (Query Only)

Returns the phase noise values of the specified trace.

The parameter <x> = 1 and 2, representing Trace 1 and Trace 2, respectively.

**Conditions** Measurement views: Phase noise

**Group** Read commands

**Syntax** READ:PNOise:SPECTrum<x>[:Y]?



<b>Arguments</b>	None
<b>Returns</b>	#<num_digit><num_byte><y(1)><y(2)>...<y(n)> Where <num_digit> is the number of digits in <num_byte>. <num_byte> is the number of bytes of data that follow. <y(n)> is the phase noise (dBc/Hz) at the n <sup>th</sup> data point, 4-byte little endian floating-point format specified in IEEE 488.2.
<b>Examples</b>	READ:PNOISE:SPECTRUM1:Y might return #516020xxxx... (16020-byte data) for the phase noise values of Trace 1.

## READ:PULSe[:RESult]:ATX? (Query Only)

Returns the average transmitted power in the pulse table.

<b>Conditions</b>	Measurement views: Pulse table
<b>Group</b>	Read commands
<b>Syntax</b>	READ:PULSe[:RESult]:ATX?
<b>Arguments</b>	None
<b>Returns</b>	<first_pulse_num>,<ATX(1)>,< ATX(2)>,...<ATX(n)> Where <first_pulse_num>::=<NR1> is the first pulse number. <ATX(n)>::=<NRf> is the average transmitted power for the pulse with the number of [first_pulse_num + n - 1] in dBm. The unit can be changed to watts by the <a href="#">[SENSe]:POWer:UNITs</a> command. Volt is invalid in the average transmitted power measurement.
<b>Examples</b>	READ:PULSE:RESULT:ATX? might return 0,-18.57,-18.73,-18.20,-18.53 for Pulse 0 to 3.

## READ:PULSe[:RESult]:AVERage? (Query Only)

Returns the average on power in the pulse table.

<b>Conditions</b>	Measurement views: Pulse table
<b>Group</b>	Read commands
<b>Syntax</b>	READ:PULSE[:RESuLt]:AVERAge?
<b>Arguments</b>	None
<b>Returns</b>	<p>&lt;first_pulse_num&gt;, &lt;avg(1)&gt;, &lt; avg(2)&gt;, ... &lt;avg(n)&gt;</p> <p>Where                      &lt;first_pulse_num&gt;::=&lt;NR1&gt; is the first pulse number.                      &lt;avg(n)&gt;::=&lt;NRf&gt; is the average on power for the pulse with the number of [first_pulse_num + n - 1] in dBm.                      The unit can be changed by the [SENSE]:POWer:UNITs command.</p>
<b>Examples</b>	<p>READ:PULSE:RESULT:AVERAGE? might return                      0, -2.354, -2.368, -2.343, -2.358 for Pulse 0 to 3.</p>

## READ:PULSE[:RESuLt]:DROOp? (Query Only)

Returns the average on power in the pulse table.

<b>Conditions</b>	Measurement views: Pulse table
<b>Group</b>	Read commands
<b>Syntax</b>	READ:PULSE[:RESuLt]:DROOp?
<b>Arguments</b>	None
<b>Returns</b>	<p>&lt;first_pulse_num&gt;, &lt;droop(1)&gt;, &lt;droop(2)&gt;, ... &lt;droop(n)&gt;</p> <p>Where                      &lt;first_pulse_num&gt;::=&lt;NR1&gt; is the first pulse number.                      &lt;droop(n)&gt;::=&lt;NRf&gt; is the wattage droop for the pulse with the number of [first_pulse_num + n - 1] in percent (%).</p>

**Examples** READ:PULSE:RESULT:DROOP? might return 0, -270.9E-3, -193.0E-3, -242.7E-3, -177.5E-3 for Pulse 0 to 3.

## READ:PULSe[:RESult]:DUTPct? (Query Only)

Returns the duty factor (%) in the pulse table.

**Conditions** Measurement views: Pulse table

**Group** Read commands

**Syntax** READ:PULSe[:RESult]:DUTPct?

**Arguments** None

**Returns** <first\_pulse\_num>, <duty\_pct(1)>, <duty\_pct(2)>, ...  
<duty\_pct(n)>

Where

<first\_pulse\_num> ::= <NR1> is the first pulse number.

<duty\_pct(n)> ::= <NRf> is the duty factor for the pulse with the number of [first\_pulse\_num + n - 1] in percent (%).

**Examples** READ:PULSE:RESULT:DUTPCT? might return 0, 28.94, 28.96, 29.00, 29.01 for Pulse 0 to 3.

## READ:PULSe[:RESult]:DUTRatio? (Query Only)

Returns the duty factor (ratio) in the pulse table.

**Conditions** Measurement views: Pulse table

**Group** Read commands

**Syntax** READ:PULSe[:RESult]:DUTRatio?

**Arguments** None

**Returns** <first\_pulse\_num>, <duty\_ratio(1)>, <duty\_ratio(2)>, ... <duty\_ratio(n)>

Where  
 <first\_pulse\_num>::=<NR1> is the first pulse number.  
 <duty\_ratio(n)>::=<NRf> is the duty factor for the pulse with the number of [first\_pulse\_num + n - 1] (no unit).

**Examples** READ:PULSE:RESULT:DUTRATIO? might return 0, 289.4E-3, 289.6E-3, 290.0E-3, 290.1E-3 for Pulse 0 to 3.

## READ:PULSe[:RESUlt]:FALL? (Query Only)

Returns the fall time in the pulse table.

**Conditions** Measurement views: Pulse table

**Group** Read commands

**Syntax** READ:PULSe[:RESUlt]:FALL?

**Arguments** None

**Returns** <first\_pulse\_num>, <fall(1)>, <fall(2)>, ... <fall(n)>

Where  
 <first\_pulse\_num>::=<NR1> is the first pulse number.  
 <fall(n)>::=<NRf> is the fall time for the pulse with the number of [first\_pulse\_num + n - 1] in seconds.

**Examples** READ:PULSE:RESULT:FALL? might return 0, 110.3E-9, 90.45E-9, 95.03E-9, 111.9E-9 for Pulse 0 to 3.

## READ:PULSe[:RESUlt]:FRDeviation? (Query Only)

Returns the frequency deviation in the pulse table.

**Conditions** Measurement views: Pulse table

<b>Group</b>	Read commands
<b>Syntax</b>	READ:PULSE[:RESuLt]:FRDeviation?
<b>Arguments</b>	None
<b>Returns</b>	<p>&lt;first_pulse_num&gt;, &lt;freq_dev(1)&gt;, &lt;freq_dev(2)&gt;, ... &lt;freq_dev(n)&gt;</p> <p>Where          &lt;first_pulse_num&gt; ::= &lt;NR1&gt; is the first pulse number.          &lt;freq_dev(n)&gt; ::= &lt;NRf&gt; is the frequency deviation for the pulse with the number of [first_pulse_num + n - 1] in Hz.</p>
<b>Examples</b>	<p>READ:PULSE:RESULT:FRDEVIATION? might return          1, 740.6E+3, 736.5E+3, 718.3E+3, 672.2E+3 for Pulse 1 to 4.</p>

## READ:PULSE[:RESuLt]:MFRReqerror? (Query Only)

Returns the maximum frequency error in the pulse table.

<b>Conditions</b>	Measurement views: Pulse table
<b>Group</b>	Read commands
<b>Syntax</b>	READ:PULSE[:RESuLt]:MFRReqerror?
<b>Arguments</b>	None
<b>Returns</b>	<p>&lt;first_pulse_num&gt;, &lt;max_freq_err(1)&gt;, &lt;max_freq_err(2)&gt;, ... &lt;max_freq_err(n)&gt;</p> <p>Where          &lt;first_pulse_num&gt; ::= &lt;NR1&gt; is the first pulse number.          &lt;max_freq_err(n)&gt; ::= &lt;NRf&gt; is the maximum frequency error for the pulse with the number of [first_pulse_num + n - 1] in Hz.</p>
<b>Examples</b>	<p>READ:PULSE:RESULT:MFRREQERROR? might return          1, 597.5E+3, 675.8E+3, 642.8E+3, 598.2E+3 for Pulse 1 to 4.</p>

## READ:PULSe[:RESuLt]:MPHerror? (Query Only)

Returns the maximum phase error in the pulse table.

**Conditions** Measurement views: Pulse table

**Group** Read commands

**Syntax** READ:PULSe[:RESuLt]:MPHerror?

**Arguments** None

**Returns** <first\_pulse\_num>, <max\_phase\_err(1)>, <max\_phase\_err(2)>, ...  
<max\_phase\_err(n)>

Where

<first\_pulse\_num> ::= <NR1> is the first pulse number.

<max\_phase\_err(n)> ::= <NRf> is the maximum phase error for the pulse with the number of [first\_pulse\_num + n - 1] in degrees.

**Examples** READ:PULSE:RESULT:MPHERROR? might return 1, -9.221, -8.413, -11.853, -10.258 for Pulse 1 to 4.

## READ:PULSe[:RESuLt]:PHDeviation? (Query Only)

Returns the phase deviation in the pulse table.

**Conditions** Measurement views: Pulse table

**Group** Read commands

**Syntax** READ:PULSe[:RESuLt]:PHDeviation?

**Arguments** None

**Returns** <first\_pulse\_num>, <phase\_dev(1)>, <phase\_dev(2)>, ...  
<phase\_dev(n)>

Where

`<first_pulse_num>::=<NR1>` is the first pulse number.  
`<phase_dev(n)>::=<NRf>` is the phase deviation for the pulse with the number of `[first_pulse_num + n - 1]` in degrees.

**Examples** `READ:PULSE:RESULT:PHDEVIATION?` might return  
 1, 11.658, 9.640, 10.509, 8.272 for Pulse 1 to 4.

## READ:PULSe[:RESult]:PPFrequency? (Query Only)

Returns the pulse-pulse carrier frequency in the pulse table.

**Conditions** Measurement views: Pulse table

**Group** Read commands

**Syntax** `READ:PULSe[:RESult]:PPFrequency?`

**Arguments** None

**Returns** `<first_pulse_num>, <pp_freq(1)>, <pp_freq(2)>, ...`  
`<pp_freq(n)>`

Where

`<first_pulse_num>::=<NR1>` is the first pulse number.

`<pp_freq(n)>::=<NRf>` is the pulse-pulse carrier frequency for the pulse with the number of `[first_pulse_num + n - 1]` in Hz.

**Examples** `READ:PULSE:RESULT:PPFREQUENCY?` might return  
 0, 0.000, 1.258E+3, -3.121E+3, 1.862E+3 for Pulse 0 to 3.

## READ:PULSe[:RESult]:PPOWer? (Query Only)

Returns the peak power in the pulse table.

**Conditions** Measurement views: Pulse table

**Group** Read commands

**Syntax** READ:PULSE[:RESuLt]:PPOWER?

**Arguments** None

**Returns** <first\_pulse\_num>, <pk\_power(1)>, <pk\_power(2)>, ...  
<pk\_power(n)>

Where

<first\_pulse\_num>::=<NR1> is the first pulse number.

<pk\_power(n)>::=<NRf> is the peak power for the pulse with the number of [first\_pulse\_num + n - 1] in dBm.

The unit can be changed by the [\[SENSE\]:POWER:UNITs](#) command.

**Examples** READ:PULSE:RESULT:PPOWER? might return 0, -2.26, -2.27, -2.23, -2.25 for Pulse 0 to 3.

## READ:PULSE[:RESuLt]:PPHase? (Query Only)

Returns the pulse-pulse carrier phase in the pulse table.

**Conditions** Measurement views: Pulse table

**Group** Read commands

**Syntax** READ:PULSE[:RESuLt]:PPHase?

**Arguments** None

**Returns** <first\_pulse\_num>, <pp\_phase(1)>, <pp\_phase(2)>, ... <pp\_phase(n)>

Where

<first\_pulse\_num>::=<NR1> is the first pulse number.

<pp\_phase(n)>::=<NRf> is the pulse-pulse carrier phase for the pulse with the number of [first\_pulse\_num + n - 1] in degrees.

**Examples** READ:PULSE:RESULT:PPHASE? might return 0, 0.000, 21.66, 46.76, 57.56 for Pulse 0 to 3.



## READ:PULSE[:RESult]:RINTerval? (Query Only)

Returns the repetition interval in the pulse table.

**Conditions** Measurement views: Pulse table

**Group** Read commands

**Syntax** READ:PULSE[:RESult]:RINTerval?

**Arguments** None

**Returns** <first\_pulse\_num>,<rep\_int(1)>,<rep\_int(2)>,...<rep\_int(n)>

Where

<first\_pulse\_num>::=<NR1> is the first pulse number.

<rep\_int(n)>::=<NRf> is the repetition interval for the pulse with the number of [first\_pulse\_num + n - 1] in seconds.

**Examples** READ:PULSE:RESULT:RINTERVAL? might return 0,16.03E-6,16.08E-6,16.07E-6,16.02E-6 for Pulse 0 to 3.

## READ:PULSE[:RESult]:RIPPlE? (Query Only)

Returns the ripple in the pulse table.

**Conditions** Measurement views: Pulse table

**Group** Read commands

**Syntax** READ:PULSE[:RESult]:RIPPlE?

**Arguments** None

**Returns** <first\_pulse\_num>,<ripple(1)>,<ripple(2)>,...<ripple(n)>

Where

<first\_pulse\_num>::=<NR1> is the first pulse number.

`<ripple(n)>::=<NRf>` is the voltage ripple for the pulse with the number of `[first_pulse_num + n - 1]` in percent (%).

**Examples** `READ:PULSE:RESULT:RIPPLE?` might return `0,106.5E-3,177.6E-3,148.3E-3,148.5E-3` for Pulse 0 to 3.

## READ:PULSe[:RESuLt]:RISE? (Query Only)

Returns the rise time in the pulse table.

**Conditions** Measurement views: Pulse table

**Group** Read commands

**Syntax** `READ:PULSe[:RESuLt]:RISE?`

**Arguments** None

**Returns** `<first_pulse_num>,<rise(1)>,<rise(2)>,...<rise(n)>`

Where

`<first_pulse_num>::=<NR1>` is the first pulse number.

`<rise(n)>::=<NRf>` is the rise time for the pulse with the number of `[first_pulse_num + n - 1]` in seconds.

**Examples** `READ:PULSE:RESULT:RISE?` might return `0,92.94E-9,115.9E-9,115.1E-9,97.45E-9` for Pulse 0 to 3.

## READ:PULSe[:RESuLt]:RMSFreqerror? (Query Only)

Returns the RMS frequency error in the pulse table.

**Conditions** Measurement views: Pulse table

**Group** Read commands

**Syntax** `READ:PULSe[:RESuLt]:RMSFreqerror?`

<b>Arguments</b>	None
<b>Returns</b>	<first_pulse_num>, <RMS_freq_err(1)>, <RMS_freq_err(2)>, ... <RMS_freq_err(n)>
	Where <first_pulse_num> ::= <NR1> is the first pulse number. <RMS_freq_err(n)> ::= <NRf> is the RMS frequency error for the pulse with the number of [first_pulse_num + n - 1] in Hz.
<b>Examples</b>	READ:PULSE:RESULT:RMSFREQERROR? might return 1, 51.54E+3, 69.20E+3, 64.21E+3, 51.02E+3 for Pulse 1 to 4.

## READ:PULSe[:RESult]:RMSPherror? (Query Only)

Returns the RMS phase error in the pulse table.

<b>Conditions</b>	Measurement views: Pulse table
<b>Group</b>	Read commands
<b>Syntax</b>	READ:PULSe[:RESult]:RMSPherror?
<b>Arguments</b>	None
<b>Returns</b>	<first_pulse_num>, <RMS_phase_err(1)>, <RMS_phase_err(2)>, ... <RMS_phase_err(n)>
	Where <first_pulse_num> ::= <NR1> is the first pulse number. <RMS_phase_err(n)> ::= <NRf> is the RMS phase error for the pulse with the number of [first_pulse_num + n - 1] in degrees.
<b>Examples</b>	READ:PULSE:RESULT:RMSPHERROR? might return 1, 908.4E-3, 752.8E-3, 981.7E-3, 886.4E-3 for Pulse 1 to 4.

## READ:PULSe[:RESult]:RRATe? (Query Only)

Returns the repetition rate in the pulse table.

<b>Conditions</b>	Measurement views: Pulse table
<b>Group</b>	Read commands
<b>Syntax</b>	READ:PULSE[:RESuLt]:RRATE?
<b>Arguments</b>	None
<b>Returns</b>	<p>&lt;first_pulse_num&gt;, &lt;rep_rate(1)&gt;, &lt;rep_rate(2)&gt;, ...          &lt;rep_rate(n)&gt;</p> <p>Where          &lt;first_pulse_num&gt;::=&lt;NR1&gt; is the first pulse number.          &lt;rep_rate(n)&gt;::=&lt;NRf&gt; is the repetition rate for the pulse with the number of          [first_pulse_num + n - 1] in Hz.</p>
<b>Examples</b>	READ:PULSE:RESULT:RRATE? might return 0, 62.50E+3, 62.52E+3, 62.51E+3, 62.49E+3 for Pulse 0 to 3.

## READ:PULSE[:RESuLt]:TIME? (Query Only)

Returns the time in the pulse table.

<b>Conditions</b>	Measurement views: Pulse table
<b>Group</b>	Read commands
<b>Syntax</b>	READ:PULSE[:RESuLt]:TIME?
<b>Arguments</b>	None
<b>Returns</b>	<p>&lt;first_pulse_num&gt;, &lt;time(1)&gt;, &lt;time(2)&gt;, ... &lt;time(n)&gt;</p> <p>Where          &lt;first_pulse_num&gt;::=&lt;NR1&gt; is the first pulse number.          &lt;time(n)&gt;::=&lt;NRf&gt; is the time for the pulse with the number of          [first_pulse_num + n - 1] in seconds.</p>

**Examples** READ:PULSE:RESULT:TIME? might return 1,7.937E-3,8.436E-3,6.504E-3,9.876E-3 for Pulse 1 to 4.

## READ:PULSe[:RESUlt]:WIDTh? (Query Only)

Returns the pulse width in the pulse table.

**Conditions** Measurement views: Pulse table

**Group** Read commands

**Syntax** READ:PULSe[:RESUlt]:WIDTh?

**Arguments** None

**Returns** <first\_pulse\_num>, <width(1)>, <width(2)>, ... <width(n)>

Where <first\_pulse\_num> ::= <NR1> is the first pulse number.

<width(n)> ::= <NRf> is the pulse width for the pulse with the number of [first\_pulse\_num + n - 1] in seconds.

**Examples** READ:PULSE:RESULT:WIDTH? might return 0,4.630E-6,4.632E-6,4.639E-6,4.642E-6 for Pulse 0 to 3.

## READ:PULSe:STATistics? (Query Only)

Returns the trace data of the pulse statistics measurement selected by the DISPLAY:PULSe:SElect:RESUlt command.

---

**NOTE.** Select the plot type (Trend or FFT) using the *DISPLAY:PULSe:STATistics:PLOT* command before executing this query.

---

**Conditions** Measurement views: Pulse statistics

**Group** Read commands

**Syntax** READ:PULSe:STATistics?

<b>Related Commands</b>	<a href="#">DISPlay:PULSe:SElect:RESult</a>
<b>Arguments</b>	None
<b>Returns</b>	<code>#&lt;num_digit&gt;&lt;num_byte&gt;&lt;data(1)&gt;&lt;data(2)&gt;...&lt;data(n)&gt;</code> Where <code>&lt;num_digit&gt;</code> is the number of digits in <code>&lt;num_byte&gt;</code> . <code>&lt;num_byte&gt;</code> is the number of bytes of data that follow. <code>&lt;data(n)&gt;</code> is the amplitude at the $n^{\text{th}}$ data point. The unit is dBm (Plot = Trend) or dB (Plot = FFT). 4-byte little endian floating-point format specified in IEEE 488.2. The unit of power is selected by the <a href="#">[SENSe]:POWer:UNITs</a> command.
<b>Examples</b>	<code>READ:PULSE:STATISTICS?</code> might return <code>#264xxxx...</code> (64-byte data) for the statistics trace of the pulse width measurement when <code>DISPlay:PULSe:SElect:RESult</code> is set to <code>WIDTH</code> .

## READ:PULSe:STATistics:ATX? (Query Only)

Returns the average transmitted power in the pulse statistics. This command is valid when [DISPlay:PULSe:STATistics:PLOT](#) is set to `TREND`.

<b>Conditions</b>	Measurement views: Pulse statistics
<b>Group</b>	Read commands
<b>Syntax</b>	<code>READ:PULSe:STATistics:ATX?</code>
<b>Arguments</b>	None
<b>Returns</b>	<code>&lt;ATX_avg&gt;, &lt;ATX_min&gt;, &lt;ATX_max&gt;</code> Where <code>&lt;ATX_avg&gt;::=&lt;NRF&gt;</code> is the average of the average transmitted power. <code>&lt;ATX_min&gt;::=&lt;NRF&gt;</code> is the minimum of the average transmitted power. <code>&lt;ATX_max&gt;::=&lt;NRF&gt;</code> is the maximum of the average transmitted power. Unit: dBm. The unit can be changed to watts by the <a href="#">[SENSe]:POWer:UNITs</a> command. Volt is invalid in the average transmitted power measurement.

**Examples** READ:PULSE:STATISTICS:ATX? might return -18.51, -18.74, -18.12 for the average transmitted power in the pulse statistics.

## READ:PULSe:STATistics:AVERAge? (Query Only)

Returns the average on power in the pulse statistics. This command is valid when [DISPlay:PULSe:STATistics:PLOT](#) is set to TREND.

**Conditions** Measurement views: Pulse statistics

**Group** Read commands

**Syntax** READ:PULSe:STATistics:AVERAge?

**Arguments** None

**Returns** <avg\_avg>, <avg\_min>, < avg\_max>

Where

<avg\_avg> ::= <NRf> is the average of the average on power.

<avg\_min> ::= <NRf> is the minimum of the average on power.

<avg\_max> ::= <NRf> is the maximum of the average on power.

Unit: dBm.

The unit can be changed by the [\[SENSe\]:POWer:UNITs](#) command.

**Examples** READ:PULSE:STATISTICS:AVERAGE? might return -2.35, -2.36, -2.34 for the average on power in the pulse statistics.

## READ:PULSe:STATistics:DROOp? (Query Only)

Returns the droop in the pulse statistics. This command is valid when [DISPlay:PULSe:STATistics:PLOT](#) is set to TREND.

**Conditions** Measurement views: Pulse statistics

**Group** Read commands

**Syntax** READ:PULSe:STATistics:DROOp?

<b>Arguments</b>	None
<b>Returns</b>	<code>&lt;droop_avg&gt;</code> , <code>&lt;droop_min&gt;</code> , <code>&lt;droop_max&gt;</code> Where <code>&lt;droop_avg&gt;::=&lt;Nrf&gt;</code> is the average droop. <code>&lt;droop_min&gt;::=&lt;Nrf&gt;</code> is the minimum droop. <code>&lt;droop_max&gt;::=&lt;Nrf&gt;</code> is the maximum droop. Unit: Percent (%) by watts.
<b>Examples</b>	<code>READ:PULSE:STATISTICS:DROOP?</code> might return <code>22.67E-3</code> , <code>-613.5E-3</code> , <code>633.8E-3</code> for the droop in the pulse statistics.

## READ:PULSe:STATistics:DUTPct? (Query Only)

Returns the duty factor (%) in the pulse statistics. This command is valid when [DISPlay:PULSe:STATistics:PLOT](#) is set to TRENd.

<b>Conditions</b>	Measurement views: Pulse statistics
<b>Group</b>	Read commands
<b>Syntax</b>	<code>READ:PULSe:STATistics:DUTPct?</code>

### Related Commands

<b>Arguments</b>	None
<b>Returns</b>	<code>&lt;duty_pct_avg&gt;</code> , <code>&lt;duty_pct_min&gt;</code> , <code>&lt;duty_pct_max&gt;</code> Where <code>&lt;duty_pct_avg&gt;::=&lt;Nrf&gt;</code> is the average duty factor. <code>&lt;duty_pct_min&gt;::=&lt;Nrf&gt;</code> is the minimum duty factor. <code>&lt;duty_pct_max&gt;::=&lt;Nrf&gt;</code> is the maximum duty factor. Unit: Percent (%).
<b>Examples</b>	<code>READ:PULSE:STATISTICS:DUTPCT?</code> might return <code>2.437</code> , <code>2.310</code> , <code>2.657</code> for the duty factor (%) in the pulse statistics.



## READ:PULSe:STATistics:DUTRatio? (Query Only)

Returns the duty factor (ratio) in the pulse statistics. This command is valid when [DISPlay:PULSe:STATistics:PLOT](#) is set to TREND.

<b>Conditions</b>	Measurement views: Pulse statistics
<b>Group</b>	Read commands
<b>Syntax</b>	READ:PULSe:STATistics:DUTRatio?
<b>Arguments</b>	None
<b>Returns</b>	<duty_ratio_avg>, <duty_ratio_min>, <duty_ratio_max> Where <duty_ratio_avg> ::= <NRf> is the average duty factor. <duty_ratio_min> ::= <NRf> is the minimum duty factor. <duty_ratio_max> ::= <NRf> is the maximum duty factor. Unit: None.
<b>Examples</b>	READ:PULSE:STATISTICS:DUTRATIO? might return 24.37E-3, 23.11E-3, 26.57E-3 for the duty factor (ratio) in the pulse statistics.

## READ:PULSe:STATistics:FALL? (Query Only)

Returns the fall time in the pulse statistics. This command is valid when [DISPlay:PULSe:STATistics:PLOT](#) is set to TREND.

<b>Conditions</b>	Measurement views: Pulse statistics
<b>Group</b>	Read commands
<b>Syntax</b>	READ:PULSe:STATistics:FALL?
<b>Arguments</b>	None
<b>Returns</b>	<fall_avg>, <fall_min>, <fall_max>

Where  
 <fall\_avg>::=<NRf> is the average fall time.  
 <fall\_min>::=<NRf> is the minimum fall time.  
 <fall\_max>::=<NRf> is the maximum fall time.  
 Unit: Seconds.

**Examples** READ:PULSE:STATISTICS:FALL? might return 70.27E-9, 69.62E-9, 71.27E-9 for the fall time in the pulse statistics.

## READ:PULSe:STATistics:FRDeviation? (Query Only)

Returns the frequency deviation in the pulse statistics. This command is valid when [DISPlay:PULSe:STATistics:PLOT](#) is set to TREND.

**Conditions** Measurement views: Pulse statistics

**Group** Read commands

**Syntax** READ:PULSe:STATistics:FRDeviation?

**Arguments** None

**Returns** <freq\_dev\_avg>, <freq\_dev\_min>, <freq\_dev\_max>

Where  
 <freq\_dev\_avg>::=<NRf> is the average frequency deviation.  
 <freq\_dev\_min>::=<NRf> is the minimum frequency deviation.  
 <freq\_dev\_max>::=<NRf> is the maximum frequency deviation.  
 Unit: Hz.

**Examples** READ:PULSE:STATISTICS:FRDEVIATION? might return 754.1E+3, 660.5E+3, 835.2E+3 for the frequency deviation in the pulse statistics.

## READ:PULSe:STATistics:MFRReqerror? (Query Only)

Returns the maximum frequency error in the pulse statistics. This command is valid when [DISPlay:PULSe:STATistics:PLOT](#) is set to TREND.

**Conditions** Measurement views: Pulse statistics

<b>Group</b>	Read commands
<b>Syntax</b>	READ:PULSe:STATistics:MFreqerror?
<b>Arguments</b>	None
<b>Returns</b>	<p>&lt;max_freq_err_avg&gt;,&lt;max_freq_err_min&gt;,&lt;max_freq_err_max&gt;</p> <p>Where</p> <p>&lt;max_freq_err_avg&gt;::=&lt;NRf&gt; is the average of maximum frequency error.</p> <p>&lt;max_freq_err_min&gt;::=&lt;NRf&gt; is the minimum of maximum frequency error.</p> <p>&lt;max_freq_err_max&gt;::=&lt;NRf&gt; is the maximum of maximum frequency error.</p> <p>Unit: Hz.</p>
<b>Examples</b>	<p>READ:PULSE:STATISTICS:MFREQERROR? might return</p> <p>645.0E+3,555.6E+3,738.8E+3 for the maximum frequency error</p> <p>in the pulse statistics.</p>

## READ:PULSe:STATistics:MPHerror? (Query Only)

Returns the maximum phase error in the pulse statistics. This command is valid when [DISPlay:PULSe:STATistics:PLOT](#) is set to TREND.

<b>Conditions</b>	Measurement views: Pulse statistics
<b>Group</b>	Read commands
<b>Syntax</b>	READ:PULSe:STATistics:MPHerror?
<b>Arguments</b>	None
<b>Returns</b>	<p>&lt;max_phase_err_avg&gt;,&lt;max_phase_err_min&gt;,&lt;max_phase_err_max&gt;</p> <p>Where</p> <p>&lt;max_phase_err_avg&gt;::=&lt;NRf&gt; is the average of maximum phase error.</p> <p>&lt;max_phase_err_min&gt;::=&lt;NRf&gt; is the minimum of maximum phase error.</p> <p>&lt;max_phase_err_max&gt;::=&lt;NRf&gt; is the maximum of maximum phase error.</p> <p>Unit: Degrees.</p>

**Examples** READ:PULSE:STATISTICS:MPHERROR? might return -11.47, -17.18, -7.61 for the maximum phase error in the pulse statistics.

## READ:PULSe:STATistics:PHDeviation? (Query Only)

Returns the phase deviation in the pulse statistics. This command is valid when [DISPlay:PULSe:STATistics:PLOT](#) is set to TREND.

**Conditions** Measurement views: Pulse statistics

**Group** Read commands

**Syntax** READ:PULSe:STATistics:PHDeviation?

**Arguments** None

**Returns** <phase\_dev\_avg>, <phase\_dev\_min>, <phase\_dev\_max>

Where

<phase\_dev\_avg> ::= <NRf> is the average phase deviation.

<phase\_dev\_min> ::= <NRf> is the minimum phase deviation.

<phase\_dev\_max> ::= <NRf> is the maximum phase deviation.

Unit: Degrees.

**Examples** READ:PULSE:STATISTICS:PHDEVIATION? might return 11.678, 7.694, 17.374 for the phase deviation in the pulse statistics.

## READ:PULSe:STATistics:PPFRequency? (Query Only)

Returns the pulse-pulse carrier frequency in the pulse statistics. This command is valid when [DISPlay:PULSe:STATistics:PLOT](#) is set to TREND.

**Conditions** Measurement views: Pulse statistics

**Group** Read commands

**Syntax** READ:PULSe:STATistics:PPFRequency?

<b>Arguments</b>	None
<b>Returns</b>	<pp_freq_avg>, <pp_freq_min>, <pp_freq_max> Where <pp_freq_avg> ::= <Nrf> is the average pulse-pulse carrier frequency. <pp_freq_min> ::= <Nrf> is the minimum pulse-pulse carrier frequency. <pp_freq_max> ::= <Nrf> is the maximum pulse-pulse carrier frequency. Unit: Hz.
<b>Examples</b>	READ:PULSE:STATISTICS:PPFREQUENCY? might return 1.135E+3, 311.3E+3, -262.8E+3 for the pulse-pulse carrier frequency in the pulse statistics.

## READ:PULSe:STATistics:PPOWer? (Query Only)

Returns the peak power in the pulse statistics. This command is valid when [DISPlay:PULSe:STATistics:PLOT](#) is set to TREND.

<b>Conditions</b>	Measurement views: Pulse statistics
<b>Group</b>	Read commands
<b>Syntax</b>	READ:PULSe:STATistics:PPOWer?
<b>Arguments</b>	None
<b>Returns</b>	<pk_power_avg>, <pk_power_min>, <pk_power_max> Where <pk_power_avg> ::= <Nrf> is the average peak power. <pk_power_min> ::= <Nrf> is the minimum peak power. <pk_power_max> ::= <Nrf> is the maximum peak power. Unit: dBm. The unit can be changed by the <a href="#">[SENSe]:POWer:UNITs</a> command.
<b>Examples</b>	READ:PULSe:STATistics:PPOWer? might return -2.273, -2.313, -2.235 for the peak power in the pulse statistics.

## READ:PULSe:STATistics:PPPhase? (Query Only)

Returns the pulse-pulse carrier phase in the pulse statistics. This command is valid when [DISPlay:PULSe:STATistics:PLOT](#) is set to TREND.

<b>Conditions</b>	Measurement views: Pulse statistics
<b>Group</b>	Read commands
<b>Syntax</b>	READ:PULSe:STATistics:PPPhase?
<b>Arguments</b>	None
<b>Returns</b>	<code>&lt;pp_phase_avg&gt;</code> , <code>&lt;pp_phase_min&gt;</code> , <code>&lt;pp_phase_max&gt;</code> Where <code>&lt;pp_phase_avg&gt; ::= &lt;Nrf&gt;</code> is the average pulse-pulse carrier phase. <code>&lt;pp_phase_min&gt; ::= &lt;Nrf&gt;</code> is the minimum pulse-pulse carrier phase. <code>&lt;pp_phase_max&gt; ::= &lt;Nrf&gt;</code> is the maximum pulse-pulse carrier phase. Unit: Degrees.
<b>Examples</b>	READ:PULSE:STATISTICS:PPPHASE? might return -9.298E-3, -254.3E-3, 311.7E-3 for the pulse-pulse carrier phase in the pulse statistics.

## READ:PULSe:STATistics:RINterval? (Query Only)

Returns the repetition interval in the pulse statistics. This command is valid when [DISPlay:PULSe:STATistics:PLOT](#) is set to TREND.

<b>Conditions</b>	Measurement views: Pulse statistics
<b>Group</b>	Read commands
<b>Syntax</b>	READ:PULSe:STATistics:RINterval?
<b>Arguments</b>	None

**Returns** <rep\_int\_avg>,<rep\_int\_min>,<rep\_int\_max>

Where

<rep\_int\_avg>::=<NRf> is the average repetition interval.

<rep\_int\_min>::=<NRf> is the minimum repetition interval.

<rep\_int\_max>::=<NRf> is the maximum repetition interval.

Unit: Seconds.

**Examples** READ:PULSE:STATISTICS:RINTERVAL? might return  
240.5E-6,217.9E-6,281.2E-6 for the repetition interval in the  
pulse statistics.

## READ:PULSe:STATistics:RIPPlE? (Query Only)

Returns the ripple in the pulse statistics. This command is valid when  
[DISPlay:PULSe:STATistics:PLOT](#) is set to TREND.

**Conditions** Measurement views: Pulse statistics

**Group** Read commands

**Syntax** READ:PULSe:STATistics:RIPPlE?

**Arguments** None

**Returns** <ripple\_avg>,<ripple\_min>,<ripple\_max>

Where

<ripple\_avg>::=<NRf> is the average ripple.

<ripple\_min>::=<NRf> is the minimum ripple.

<ripple\_max>::=<NRf> is the maximum ripple.

Unit: Percent (%) by volts.

**Examples** READ:PULSE:STATISTICS:RIPPLE? might return  
160.4E-3,83.78E-3,287.7E-3 for the ripple in the pulse statistics.

## READ:PULSe:STATistics:RISE? (Query Only)

Returns the rise time in the pulse statistics. This command is valid when  
[DISPlay:PULSe:STATistics:PLOT](#) is set to TREND.

<b>Conditions</b>	Measurement views: Pulse statistics
<b>Group</b>	Read commands
<b>Syntax</b>	READ:PULSE:STATISTICS:RISE?
<b>Arguments</b>	None
<b>Returns</b>	<p>&lt;rise_avg&gt;, &lt;rise_min&gt;, &lt;rise_max&gt;</p> <p>Where</p> <p>&lt;rise_avg&gt;::=&lt;NRf&gt; is the average rise time.</p> <p>&lt;rise_min&gt;::=&lt;NRf&gt; is the minimum rise time.</p> <p>&lt;rise_max&gt;::=&lt;NRf&gt; is the maximum rise time.</p> <p>Unit: Seconds.</p>
<b>Examples</b>	READ:PULSE:STATISTICS:RISE? might return 105.4E-9, 91.65E-9, 116.2E-9 for the rise time in the pulse statistics.

## READ:PULSE:STATISTICS:RMSFreqerror? (Query Only)

Returns the RMS frequency error in the pulse statistics. This command is valid when [DISPlay:PULSE:STATISTICS:PLOT](#) is set to TREND.

<b>Conditions</b>	Measurement views: Pulse statistics
<b>Group</b>	Read commands
<b>Syntax</b>	READ:PULSE:STATISTICS:RMSFreqerror?
<b>Arguments</b>	None
<b>Returns</b>	<p>&lt;RMS_freq_err_avg&gt;, &lt;RMS_freq_err_min&gt;, &lt;RMS_freq_err_max&gt;</p> <p>Where</p> <p>&lt;RMS_freq_err_avg&gt;::=&lt;NRf&gt; is the average of RMS frequency error.</p> <p>&lt;RMS_freq_err_min&gt;::=&lt;NRf&gt; is the minimum of RMS frequency error.</p> <p>&lt;RMS_freq_err_max&gt;::=&lt;NRf&gt; is the maximum of RMS frequency error.</p> <p>Unit: Hz.</p>



**Examples** READ:PULSE:STATISTICS:RMSFREQERROR? might return 63.67E+3,45.49E+3,81.28E+3 for the RMS frequency error in the pulse statistics.

## READ:PULSe:STATistics:RMSPherror? (Query Only)

Returns the RMS phase error in the pulse statistics. This command is valid when [DISPlay:PULSe:STATistics:PLOT](#) is set to TREND.

**Conditions** Measurement views: Pulse statistics

**Group** Read commands

**Syntax** READ:PULSe:STATistics:RMSPherror?

**Arguments** None

**Returns** <RMS\_phase\_err\_avg>,<RMS\_phase\_err\_min>,<RMS\_phase\_err\_max>

Where

<RMS\_phase\_err\_avg>::=<NRf> is the average of RMS phase error.

<RMS\_phase\_err\_min>::=<NRf> is the minimum of RMS phase error.

<RMS\_phase\_err\_max>::=<NRf> is the maximum of RMS phase error.

Unit: Degrees.

**Examples** READ:PULSE:STATISTICS:RMSPHERROR? might return 1.032,604.5E-3,1.606 for the RMS phase error in the pulse statistics.

## READ:PULSe:STATistics:RRATe? (Query Only)

Returns the repetition rate in the pulse statistics. This command is valid when [DISPlay:PULSe:STATistics:PLOT](#) is set to TREND.

**Conditions** Measurement views: Pulse statistics

**Group** Read commands

**Syntax** READ:PULSe:STATistics:RRATe?

**Arguments** None

**Returns** <rep\_rate\_avg>, <rep\_rate\_min>, <rep\_rate\_max>

Where

<rep\_rate\_avg>::=<NRf> is the average repetition rate.

<rep\_rate\_min>::=<NRf> is the minimum repetition rate.

<rep\_rate\_max>::=<NRf> is the maximum repetition rate.

Unit: Hz.

**Examples** READ:PULSE:STATISTICS:RRATE? might return  
62.50E+3, 62.49E+3, 62.52E+3 for the repetition rate in the pulse statistics.

## READ:PULSe:STATistics:WIDTh? (Query Only)

Returns the pulse width in the pulse statistics. This command is valid when [DISPlay:PULSe:STATistics:PLOT](#) is set to TREND.

**Conditions** Measurement views: Pulse statistics

**Group** Read commands

**Syntax** READ:PULSe:STATistics:WIDTh?

**Arguments** None

**Returns** <width\_avg>, <width\_min>, <width\_max>

Where

<width\_avg>::=<NRf> is the average pulse width.

<width\_min>::=<NRf> is the minimum pulse width.

<width\_max>::=<NRf> is the maximum pulse width.

Unit: Seconds.

**Examples** READ:PULSE:STATISTICS:WIDTH? might return  
4.636E-6, 4.630E-6, 4.643E-6 for the pulse width in the pulse statistics.

## READ:PULSe:TRACe:X? (Query Only)

Returns the time values of the pulse trace. Use the [DISPlay:PULSe:SElect:NUMBer](#) command to select the pulse, and the [DISPlay:PULSe:SElect:RESult](#) command to select the measurement result.

<b>Conditions</b>	Measurement views: Pulse trace
<b>Group</b>	Read commands
<b>Syntax</b>	READ:PULSe:TRACe:X?
<b>Arguments</b>	None
<b>Returns</b>	#<num_digit><num_byte><X(1)><X(2)>...<X(n)> Where <num_digit> is the number of digits in <num_byte>. <num_byte> is the number of bytes of data that follow. <X(n)> is the time in seconds at the n <sup>th</sup> data point, 4-byte little endian floating-point format specified in IEEE 488.2.
<b>Examples</b>	READ:PULSE:TRACE:X? might return #43204xxxx... (3204-byte data) for the time values of the trace.

## READ:PULSe:TRACe:XY? (Query Only)

Returns the horizontal (time) and vertical value pairs of the pulse trace. Use the [DISPlay:PULSe:SElect:NUMBer](#) command to select the pulse, and the [DISPlay:PULSe:SElect:RESult](#) command to select the measurement result.

<b>Conditions</b>	Measurement views: Pulse trace
<b>Group</b>	Read commands
<b>Syntax</b>	READ:PULSe:TRACe:XY?
<b>Arguments</b>	None

**Returns** #<num\_digit><num\_byte><x(1)><y(1)><x(2)><y(2)> . . . <x(n)><y(n)>

Where

<num\_digit> is the number of digits in <num\_byte>.

<num\_byte> is the number of bytes of data that follow.

<x(n)><y(n)> is the horizontal value (time in seconds) and vertical value pair at the n<sup>th</sup> data point, 4-byte little endian floating-point format specified in IEEE 488.2.

The vertical unit depends on measurement results: Hz for frequency error and deviation, degrees for phase error and deviation, otherwise dBm. The vertical unit can be changed by the [\[SENSe\]:POWer:UNITs](#) command.

**Examples** READ:PULSE:TRACE:XY? might return #43204xxxx . . . (3204-byte data) for the horizontal (time) and vertical value pairs of the pulse trace.

## READ:PULSe:TRACe[:Y]? (Query Only)

Returns the vertical values of the pulse trace. Use the [DISPlay:PULSe:SElect:NUMBer](#) command to select the pulse, and the [DISPlay:PULSe:SElect:RESult](#) command to select the measurement result.

**Conditions** Measurement views: Pulse trace

**Group** Read commands

**Syntax** READ:PULSe:TRACe[:Y]?

**Arguments** None

**Returns** #<num\_digit><num\_byte><y(1)><y(2)> . . . <y(n)>

Where

<num\_digit> is the number of digits in <num\_byte>.

<num\_byte> is the number of bytes of data that follow.

<y(n)> is the vertical value of the pulse trace at the n<sup>th</sup> data point, 4-byte little endian floating-point format specified in IEEE 488.2.

The unit depends on measurement results: Hz for frequency error and deviation, degrees for phase error and deviation, otherwise dBm. The unit can be changed by the [\[SENSe\]:POWer:UNITs](#) command.

**Examples** READ:PULSE:TRACE:Y? might return #43204xxxx... (3204-byte data) for the vertical values of the pulse trace.

## READ:SGRam? (Query Only)

Returns the spectrogram trace data. The line is selected using the [TRACe:SGRam:SElect:LINE](#) command.

**Conditions** Measurement views: Spectrogram

**Group** Read commands

**Syntax** READ:SGRam?

**Arguments** None

**Returns** #<num\_digit><num\_byte><data(1)><data(2)>...<data(n)>

Where

<num\_digit> is the number of digits in <num\_byte>.

<num\_byte> is the number of bytes of data that follow.

<data(n)> is the trace data in dBm for the point n,

4-byte little endian floating-point format specified in IEEE 488.2.

The unit can be changed by the [\[SENSe\]:POWer:UNITs](#) command.

**Examples** READ:SGRAM? might return #43204xxxx... (3204-byte data) for the spectrogram trace.

## READ:SPECTrum:TRACe<x>? (Query Only)

Returns the trace data in the Spectrum measurement.

The parameter <x> = 1 to 5.

---

**NOTE.** TRACe5 (spectrogram) is valid when the spectrum and spectrogram measurements are running.

---

**Conditions** Measurement views: Spectrum

<b>Group</b>	Read commands
<b>Syntax</b>	READ:SPECTrum:TRACe<x>?
<b>Arguments</b>	None
<b>Returns</b>	#<num_digit><num_byte><data(1)><data(2)>...<data(n)> Where <num_digit> is the number of digits in <num_byte>. <num_byte> is the number of bytes of data that follow. <data(n)> is the trace data in dBm for the point n, 4-byte little endian floating-point format specified in IEEE 488.2. The unit can be changed by the <a href="#">[SENSe]:POWer:UNITs</a> command.
<b>Examples</b>	READ:SPECTRUM:TRACE1 might return #43204xxxx... (3204-byte data) for Trace 1 in the Spectrum measurement.

## READ:SPURious:CARRier:POWer? (Query Only)

Returns the carrier power in the Spurious measurement.

<b>Conditions</b>	Measurement views: Spurious
<b>Group</b>	Read commands
<b>Syntax</b>	READ:SPURious:CARRier:POWer?
<b>Arguments</b>	None
<b>Returns</b>	<Nrf> Carrier power in dBm. The unit can be changed by the <a href="#">[SENSe]:POWer:UNITs</a> command.
<b>Examples</b>	READ:SPURIOUS:CARRIER:POWER? might return 4.227, indicating that the carrier power is 4.227 dBm.

## READ:SPURious:COUNT? (Query Only)

Returns the number of spurious signals in the Spurious measurement.

<b>Conditions</b>	Measurement views: Spurious
<b>Group</b>	Read commands
<b>Syntax</b>	READ:SPURious:COUNT?
<b>Arguments</b>	None
<b>Returns</b>	<Nrf> The spurious count.
<b>Examples</b>	READ:SPURIOUS:COUNT? might return 4, indicating that the spurious count is 4.

## READ:SPURious:PASS? (Query Only)

Returns the pass/fail limit test result in the Spurious measurement.

<b>Conditions</b>	Measurement views: Spurious
<b>Group</b>	Read commands
<b>Syntax</b>	READ:SPURious:PASS?
<b>Arguments</b>	None
<b>Returns</b>	0 (fail) or 1 (pass).
<b>Examples</b>	READ:SPURIOUS:PASS? might return 1, indicating that the limit test was successful.

## READ:SPURious:SPECTrum:X? (Query Only)

Returns the frequencies of the spectrum trace in the Spurious measurement.

<b>Conditions</b>	Measurement views: Spurious
<b>Group</b>	Read commands
<b>Syntax</b>	READ:SPURious:SPECTrum:X?
<b>Arguments</b>	None
<b>Returns</b>	#<num_digit><num_byte><x(1)><x(2)>...<x(n)> Where <num_digit> is the number of digits in <num_byte>. <num_byte> is the number of bytes of data that follow. <x(n)> is the frequency (Hz) at the n <sup>th</sup> data point, 4-byte little endian floating-point format specified in IEEE 488.2.
<b>Examples</b>	READ:SPURIOUS:SPECTRUM:X? might return #516020xxxx... (16020-byte data) for the frequencies of the spectrum trace in the Spurious measurement.

## READ:SPURious:SPECTrum:XY? (Query Only)

Returns the frequency and amplitude pairs of the spectrum trace in the Spurious measurement.

<b>Conditions</b>	Measurement views: Spurious
<b>Group</b>	Read commands
<b>Syntax</b>	READ:SPURious:SPECTrum:XY?
<b>Arguments</b>	None
<b>Returns</b>	#<num_digit><num_byte><x(1)><y(1)><x(2)><y(2)>...<x(n)><y(n)> Where <num_digit> is the number of digits in <num_byte>. <num_byte> is the number of bytes of data that follow. <x(n)><y(n)> is the frequency (Hz) and amplitude (dBm) pair at the n <sup>th</sup> data point,



4-byte little endian floating-point format specified in IEEE 488.2.  
The amplitude unit can be changed by the [\[SENSe\]:POWer:UNITs](#) command.

**Examples** `READ:SPURIOUS:SPECTRUM:XY?` might return `#516020xxxx...` (16020-byte data) for the frequency and amplitude pairs of the spectrum trace in the Spurious measurement.

## READ:SPURious:SPECTrum[:Y]? (Query Only)

Returns the amplitudes of the spectrum trace in the Spurious measurement.

**Conditions** Measurement views: Spurious

**Group** Read commands

**Syntax** `READ:SPURious:SPECTrum[:Y]?`

**Related Commands** [READ:SPURious:SPECTrum:X?](#)

**Arguments** None

**Returns** `#<num_digit><num_byte><y(1)><y(2)>...<y(n)>`

Where

`<num_digit>` is the number of digits in `<num_byte>`.

`<num_byte>` is the number of bytes of data that follow.

`<y(n)>` is the amplitude (dBm) at the  $n^{\text{th}}$  data point,

4-byte little endian floating-point format specified in IEEE 488.2.

The unit can be changed by the [\[SENSe\]:POWer:UNITs](#) command.

**Examples** `READ:SPURIOUS:SPECTRUM:Y` might return `#516020xxxx...` (16020-byte data) for the amplitudes of the spectrum trace in the Spurious measurement.

## READ:SPURious:SPUR<x>:AMPLitude:ABSolute? (Query Only)

Returns the absolute amplitude of the specified spurious signal in the Spurious measurement.

**Conditions** Measurement views: Spurious

<b>Group</b>	Read commands
<b>Syntax</b>	READ:SPURious:SPUR<x>:AMPLitude:ABSolute?
<b>Arguments</b>	None
<b>Returns</b>	<NRf> Absolute amplitude of the specified spurious in dBm. The unit can be changed by the <a href="#">[SENSe]:POWer:UNITs</a> command.
<b>Examples</b>	READ:SPURIOUS:SPUR1:AMPLITUDE:ABSOLUTE? might return -19.782, indicating that the absolute amplitude of Spurious #1 is -19.782 dBm.

### READ:SPURious:SPUR<x>:AMPLitude:RELative? (Query Only)

Returns the relative amplitude of the specified spurious signal in the Spurious measurement.

<b>Conditions</b>	Measurement views: Spurious
<b>Group</b>	Read commands
<b>Syntax</b>	READ:SPURious:SPUR<x>:AMPLitude:RELative?
<b>Arguments</b>	None
<b>Returns</b>	<NRf> Relative amplitude of the specified spurious signal in dB. Use the <a href="#">[SENSe]:SPURious:REFerence</a> command to set the power reference.
<b>Examples</b>	READ:SPURIOUS:SPUR1:AMPLITUDE:RELATIVE? might return -9.782, indicating that the relative amplitude of Spurious #1 is -9.782 dB.

### READ:SPURious:SPUR<x>:FREQuency:ABSolute? (Query Only)

Returns the absolute frequency of the specified spurious signal in the Spurious measurement.

<b>Conditions</b>	Measurement views: Spurious
-------------------	-----------------------------

---

<b>Group</b>	Read commands
<b>Syntax</b>	READ:SPURious:SPUR<x>:FREQUency:ABSolute?
<b>Arguments</b>	None
<b>Returns</b>	<Nrf> Absolute frequency of the spurious signal in Hz.
<b>Examples</b>	READ:SPURIOUS:SPUR1:FREQUENCY:ABSOLUTE? might return 2.235E+9, indicating that the absolute frequency of Spurious #1 is 2.235 GHz.

### READ:SPURious:SPUR<x>:FREQUency:RELative? (Query Only)

Returns the relative frequency of the specified spurious signal to the carrier in the Spurious measurement. This command is valid when [\[SENSe\]:SPURious:REFeRence](#) is set to CARRier.

<b>Conditions</b>	Measurement views: Spurious
<b>Group</b>	Read commands
<b>Syntax</b>	READ:SPURious:SPUR<x>:FREQUency:RELative?
<b>Arguments</b>	None
<b>Returns</b>	<Nrf> Relative frequency of the spurious signal to the carrier in Hz.
<b>Examples</b>	READ:SPURIOUS:SPUR1:FREQUENCY:RELATIVE? might return 3.634E+6, indicating that the relative frequency of Spurious #1 is 3.634 MHz.

### READ:SPURious:SPUR<x>:LIMit:ABSolute? (Query Only)

Returns the absolute amplitude of the limit for the specified spurious signal in the Spurious measurement.

<b>Conditions</b>	Measurement views: Spurious
-------------------	-----------------------------

<b>Group</b>	Read commands
<b>Syntax</b>	READ:SPURious:SPUR<x>:LIMit:ABSolute?
<b>Arguments</b>	None
<b>Returns</b>	<NRF> Absolute amplitude of the limit for the specified spurious signal in dBm. The unit can be changed by the <a href="#">[SENSe]:POWer:UNITs</a> command.
<b>Examples</b>	READ:SPURIOUS:SPUR1:LIMIT:ABSOLUTE? might return -50.0, indicating that the absolute amplitude of the limit for Spurious #1 is -50 dBm.

### READ:SPURious:SPUR<x>:LIMit:RELative? (Query Only)

Returns the relative amplitude of the limit for the specified spurious signal in the Spurious measurement.

<b>Conditions</b>	Measurement views: Spurious
<b>Group</b>	Read commands
<b>Syntax</b>	READ:SPURious:SPUR<x>:LIMit:RELative?
<b>Arguments</b>	None
<b>Returns</b>	<NRF> Relative amplitude of the limit for the specified spurious signal in dB. Use the <a href="#">[SENSe]:SPURious:REFerence</a> command to set the power reference.
<b>Examples</b>	READ:SPURIOUS:SPUR1:LIMIT:RELATIVE? might return -10.0, indicating that the relative amplitude of the limit for Spurious #1 is -10 dB.

### READ:SPURious:SPUR<x>:LIMit:VIOLation? (Query Only)

Returns whether the specified spurious signal exceeds the limit or not.

<b>Conditions</b>	Measurement views: Spurious
-------------------	-----------------------------

---

<b>Group</b>	Read commands
<b>Syntax</b>	READ:SPURious:SPUR<x>:LIMit:VIOLation?
<b>Arguments</b>	None
<b>Returns</b>	0 (under the limit) or 1 (over the limit).
<b>Examples</b>	READ:SPURIOUS:SPUR1:LIMIT:VIOLATION? might return 1, indicating that Spurious #1 exceeds the limit.

## READ:SPURious:SPUR<x>:RANGe? (Query Only)

Returns the frequency range in which the specified spurious signal occurred.

<b>Conditions</b>	Measurement views: Spurious
<b>Group</b>	Read commands
<b>Syntax</b>	READ:SPURious:SPUR<x>:RANGe?
<b>Arguments</b>	None
<b>Returns</b>	<string> "A" to "T" representing Range A to T, respectively.
<b>Examples</b>	READ:SPURIOUS:SPUR1:RANGE? might return "E", indicating that Spurious #1 is in Range E.

## READ:SQUality:FREQuency:DEViation? (Query Only)

Returns the frequency deviation in the signal quality measurement.

This command is valid when [\[SENSe\]:DDEMod:MODulation:TYPE](#) is set to C4FM, FSK2, FSK4, FSK8, or FSK16.

<b>Conditions</b>	Measurement views: Signal quality
-------------------	-----------------------------------

<b>Group</b>	Read commands
<b>Syntax</b>	READ:SQUALITY:FREQUENCY:DEVIATION?
<b>Arguments</b>	None
<b>Returns</b>	<Nrf> Frequency deviation in Hz.
<b>Examples</b>	READ:SQUALITY:FREQUENCY:DEVIATION? might return 12.68E+3, indicating the frequency deviation is 12.68 kHz.

## READ:SQUALITY:FREQUENCY:DEVIATION:TABLE? (Query Only)

Returns the number of columns and the values in the frequency deviation table for a signal quality measurement.

This command is valid when [SENSE]:DDEMOD:MODULATION:TYPE is set to C4FM, FSK2, FSK4, FSK8, or FSK16.

<b>Conditions</b>	Measurement views: Signal quality
<b>Group</b>	Read commands
<b>Syntax</b>	READ:SQUALITY:FREQUENCY:DEVIATION:TABLE?
<b>Arguments</b>	None
<b>Returns</b>	<p>&lt;Dev_Num&gt;, {&lt;Freq_dev_Max&gt;, &lt;Freq_dev_Min&gt;, &lt;Freq_dev_Avg&gt;}</p> <p>Where</p> <p>&lt;Dev_Num&gt; ::= &lt;NR1&gt; is the number of columns in the frequency deviation table.                      = 2 (2FSK), 4 (4FSK, C4FM), 8 (8FSK), or 16 (16FSK)</p> <p>&lt;Freq_dev_Max&gt; ::= &lt;Nrf&gt; is the maximum frequency deviation in Hz.</p> <p>&lt;Freq_dev_Min&gt; ::= &lt;Nrf&gt; is the minimum frequency deviation in Hz.</p> <p>&lt;Freq_dev_Avg&gt; ::= &lt;Nrf&gt; is the average frequency deviation in Hz.</p> <p>The dataset &lt;Freq_dev_Max&gt;, &lt;Freq_dev_Min&gt;, &lt;Freq_dev_Avg&gt; is returned for each symbol in ascending order of its level (for example, in order of symbol -3, -1, +1, and +3 for 4FSK).</p>

**Examples** READ:QUALITY:FREQUENCY:DEVIATION:TABLE? might return 2,1.257E+3,1.039E+3,1.162E+3,1.586E+3,1.298E+3,1.425E+3 for the frequency signal, populating the results table as follows.

Deviations	-1	+1
Maximum	1.257 kHz	1.586 kHz
Minimum	1.039 kHz	1.298 kHz
Average	1.162 kHz	1.425 kHz

## READ:QUALITY:FREQUENCY:ERROR? (Query Only)

Returns the frequency error in the signal quality measurement.

**Conditions** Measurement views: Signal quality

**Group** Read commands

**Syntax** READ:QUALITY:FREQUENCY:ERROR?

**Arguments** None

**Returns** <NRf> Frequency error in Hz.

**Examples** READ:QUALITY:FREQUENCY:ERROR? might return 612.043E+3, indicating that the frequency error is 612.043 kHz.

## READ:QUALITY:GAIN:IMBALANCE? (Query Only)

Returns the gain imbalance in the signal quality measurement.

**Conditions** Measurement views: Signal quality

**Group** Read commands

**Syntax** READ:QUALITY:GAIN:IMBALANCE?

**Arguments** None

**Returns** <NRf> Gain imbalance in dB.

**Examples** READ:QUALITY:GAIN:IMBALANCE? might return -57.746E-3, indicating that the gain imbalance is -0.057746 dB.

## READ:QUALITY:ORIGIN:OFFSET? (Query Only)

Returns the origin offset in the signal quality measurement.

**Conditions** Measurement views: Signal quality

**Group** Read commands

**Syntax** READ:QUALITY:ORIGIN:OFFSET?

**Arguments** None

**Returns** <NRf> Origin offset in dB.

**Examples** READ:QUALITY:ORIGIN:OFFSET? might return -44.968, indicating that the origin offset is -44.968 dB.

## READ:QUALITY:PEAK:EVM? (Query Only)

Returns the peak EVM (%) in the signal quality measurement.

**Conditions** Measurement views: Signal quality

**Group** Read commands

**Syntax** READ:QUALITY:PEAK:EVM?

**Arguments** None

**Returns** <NRf> Peak EVM in percent (%).



**Examples** READ:QUALITY:PEAK:EVM? might return 4.276, indicating that the peak EVM is 4.276%.

## READ:QUALITY:PEAK:EVM:DB? (Query Only)

Returns the peak EVM (dB) in the signal quality measurement.

**Conditions** Measurement views: Signal quality

**Group** Read commands

**Syntax** READ:QUALITY:PEAK:EVM:DB?

**Arguments** None

**Returns** <NRf> Peak EVM in dB.

**Examples** READ:QUALITY:PEAK:EVM:DB? might return -27.358, indicating that the peak EVM is -27.358 dB.

## READ:QUALITY:PEAK:EVM:DB:OFFSET? (Query Only)

Returns the peak offset EVM (dB) in the signal quality measurement.

This command is valid when [\[SENSe\]:DDEMod:MODulation:TYPE](#) is set to OQPSK or SOQPSK.

**Conditions** Measurement views: Signal quality

**Group** Read commands

**Syntax** READ:QUALITY:PEAK:EVM:DB:OFFSET?

**Arguments** None

**Returns** <NRf> Peak offset EVM in dB.

**Examples**     `READ:SQUALITY:PEAK:EVM:DB:OFFSET?` might return `-37.624`, indicating the peak offset EVM is `-37.624` dB.

## **READ:SQUALITY:PEAK:EVM:LOCATION? (Query Only)**

Returns the time at which the EVM is peak.

**Conditions**     Measurement views: Signal quality

**Group**     Read commands

**Syntax**     `READ:SQUALITY:PEAK:EVM:LOCATION?`

**Arguments**     None

**Returns**     `<NRF>` The time in symbol number at which the EVM is peak.  
The unit can be changed by the `[SENSE]:DDEMOD:TIME:UNITS` command.

**Examples**     `READ:SQUALITY:PEAK:EVM:LOCATION?` might return `68.000`, indicating that the EVM is peak at symbol #`68.000`.

## **READ:SQUALITY:PEAK:EVM:LOCATION:OFFSET? (Query Only)**

Returns the time at which the offset EVM is peak.

This command is valid when `[SENSE]:DDEMOD:MODULATION:TYPE` is set to `OQPSK` or `SOQPSK`.

**Conditions**     Measurement views: Signal quality

**Group**     Read commands

**Syntax**     `READ:SQUALITY:PEAK:EVM:LOCATION:OFFSET?`

**Arguments**     None

**Returns**     `<NRF>` The time in symbol number at which the offset EVM is peak.

The unit can be changed by the `[SENSe]:DDEMod:TIME:UNITs` command.

**Examples** `READ:SQUALITY:PEAK:EVM:LOCATION:OFFSET?` might return `123.00`, indicating that the offset EVM is peak at symbol #123.

## READ:SQUALITY:PEAK:EVM:OFFSet? (Query Only)

Returns the peak offset EVM (%) in the signal quality measurement.

This command is valid when `[SENSe]:DDEMod:MODulation:TYPE` is set to `OQPSK` or `SOQPSK`.

**Conditions** Measurement views: Signal quality

**Group** Read commands

**Syntax** `READ:SQUALITY:PEAK:EVM:OFFSet?`

**Arguments** None

**Returns** `<Nrf>` Peak offset EVM in percent (%).

**Examples** `READ:SQUALITY:PEAK:EVM:OFFSet?` might return `1.298`, indicating the peak offset EVM is 1.298%.

## READ:SQUALITY:PEAK:FERRor? (Query Only)

Returns the peak FSK error in the signal quality measurement.

This command is valid when `[SENSe]:DDEMod:MODulation:TYPE` is set to `FSK2`, `FSK4`, `FSK8`, or `FSK16`.

**Conditions** Measurement views: Signal quality

**Group** Read commands

**Syntax** `READ:SQUALITY:PEAK:FERRor?`

<b>Arguments</b>	None
<b>Returns</b>	<NRF> Peak FSK error in percent (%).
<b>Examples</b>	READ: SQUALITY: PEAK: FERROR? might return 9.136, indicating the peak FSK error is 9.136%.

## READ:SQUALITY:PEAK:MERROR? (Query Only)

Returns the peak magnitude error (%) in the signal quality measurement.

<b>Conditions</b>	Measurement views: Signal quality
<b>Group</b>	Read commands
<b>Syntax</b>	READ: SQUALITY: PEAK: MERROR?
<b>Arguments</b>	None
<b>Returns</b>	<NRF> Peak magnitude error in percent (%).
<b>Examples</b>	READ: SQUALITY: PEAK: MERROR? might return 3.595, indicating that the peak magnitude error is 3.595%.

## READ:SQUALITY:PEAK:MERROR:DB? (Query Only)

Returns the peak magnitude error (dB) in the signal quality measurement.

<b>Conditions</b>	Measurement views: Signal quality
<b>Group</b>	Read commands
<b>Syntax</b>	READ: SQUALITY: PEAK: MERROR: DB?
<b>Arguments</b>	None

**Returns** <NRf> Peak magnitude error in dB.

**Examples** READ:QUALITY:PEAK:MERROR:DB? might return -28.583, indicating that the magnitude error is -28.583 dB.

## READ:QUALITY:PEAK:MERROR:LOCATION? (Query Only)

Returns the time at which the magnitude error is peak.

**Conditions** Measurement views: Signal quality

**Group** Read commands

**Syntax** READ:QUALITY:PEAK:MERROR:LOCATION?

**Arguments** None

**Returns** <NRf> The time in symbol number at which the magnitude error is peak. The unit can be changed by the [\[SENSE\]:DDEMod:TIME:UNITS](#) command.

**Examples** READ:QUALITY:PEAK:MERROR:LOCATION? might return 68.000, indicating that the magnitude error is peak at symbol #68.

## READ:QUALITY:PEAK:PERROR? (Query Only)

Returns the peak phase error in the signal quality measurement.

**Conditions** Measurement views: Signal quality

**Group** Read commands

**Syntax** READ:QUALITY:PEAK:PERROR?

**Arguments** None

**Returns** <NRf> Peak phase error in degrees.

**Examples**    `READ:SQUALITY:PEAK:PERROR?` might return 1.907, indicating that the peak phase error is 1.907 °.

## **READ:SQUALITY:PEAK:PERROR:LOCATION? (Query Only)**

Returns the time at which the phase error is peak.

**Conditions**    Measurement views: Signal quality

**Group**        Read commands

**Syntax**       `READ:SQUALITY:PEAK:PERROR:LOCATION?`

**Arguments**    None

**Returns**       <NRF> The time in symbol number at which the phase error is peak.  
The unit can be changed by the [\[SENSe\]:DDEMod:TIME:UNITs](#) command.

**Examples**    `READ:SQUALITY:PEAK:PERROR:LOCATION?` might return 68.000, indicating that the phase error is peak at symbol #68.

## **READ:SQUALITY:QUADRATURE:ERROR? (Query Only)**

Returns the quadrature error in the signal quality measurement.

**Conditions**    Measurement views: Signal quality

**Group**        Read commands

**Syntax**       `READ:SQUALITY:QUADRATURE:ERROR?`

**Arguments**    None

**Returns**       <NRF> Quadrature error in degrees.

**Examples** READ:QUALITY:QUADRATURE:ERROR? might return -14.264E-3, indicating that the quadrature error is -0.014264°.

## READ:QUALITY:RHO? (Query Only)

Returns the  $\rho$  (waveform quality) value in the signal quality measurement.

**Conditions** Measurement views: Signal quality

**Group** Read commands

**Syntax** READ:QUALITY:RHO?

**Arguments** None

**Returns** <NRf>  $\rho$  value.

**Examples** READ:QUALITY:RHO? might return 998.703E-3, indicating that  $\rho$  is 0.998703.

## READ:QUALITY:RMS:EVM? (Query Only)

Returns the RMS EVM (%) in the signal quality measurement.

**Conditions** Measurement views: Signal quality

**Group** Read commands

**Syntax** READ:QUALITY:RMS:EVM?

**Arguments** None

**Returns** <NRf> RMS EVM in percent (%).

**Examples** READ:QUALITY:RMS:EVM? might return 2.417, indicating that the RMS EVM is 2.417%.

## READ:SQUALITY:RMS:EVM:DB? (Query Only)

Returns the RMS EVM (dB) in the signal quality measurement.

**Conditions** Measurement views: Signal quality

**Group** Read commands

**Syntax** READ:SQUALITY:RMS:EVM:DB?

**Arguments** None

**Returns** <NRF> RMS EVM in dB.

**Examples** READ:SQUALITY:RMS:EVM:DB? might return -32.356, indicating that the RMS EVM is -32.356 dB.

## READ:SQUALITY:RMS:EVM:DB:OFFSET? (Query Only)

Returns the RMS offset EVM (dB) in the signal quality measurement.

This command is valid when [\[SENSe\]:DDEMod:MODulation:TYPE](#) is set to OQPSK or SOQPSK.

**Conditions** Measurement views: Signal quality

**Group** Read commands

**Syntax** READ:SQUALITY:RMS:EVM:DB:OFFSET?

**Arguments** None

**Returns** <NRF> RMS offset EVM in dB.

**Examples** READ:SQUALITY:RMS:EVM:DB:OFFSET? might return -41.276, indicating the RMS offset EVM is -41.276 dB.



## READ:SQUality:RMS:EVM:OFFSet? (Query Only)

Returns the RMS offset EVM (%) in the signal quality measurement.

This command is valid when [SENSe]:DDEMod:MODulation:TYPE is set to OQPSK or SOQPSK.

<b>Conditions</b>	Measurement views: Signal quality
<b>Group</b>	Read commands
<b>Syntax</b>	READ:SQUality:RMS:EVM:OFFSet?
<b>Arguments</b>	None
<b>Returns</b>	<NRf> RMS offset EVM in percent (%).
<b>Examples</b>	READ:SQUALITY:RMS:EVM:OFFSET? might return 0.783, indicating the RMS offset EVM is 0.783%.

## READ:SQUality:RMS:FERRor? (Query Only)

Returns the RMS FSK error in the signal quality measurement.

This command is valid when [SENSe]:DDEMod:MODulation:TYPE is set to FSK2, FSK4, FSK8, or FSK16.

<b>Conditions</b>	Measurement views: Signal quality
<b>Group</b>	Read commands
<b>Syntax</b>	READ:SQUality:RMS:FERRor?
<b>Arguments</b>	None
<b>Returns</b>	<NRf> RMS FSK error in percent (%).

**Examples**     `READ:SQUALITY:RMS:FERROR?` might return `8.67`, indicating the RMS FSK error is 8.67%.

## **READ:SQUALity:RMS:MER:DB? (Query Only)**

Returns the RMS MER (Modulation Error Ratio) in dB in the signal quality measurement.

**Conditions**     Measurement views: Signal quality

**Group**         Read commands

**Syntax**        `READ:SQUALity:RMS:MER:DB?`

**Arguments**     None

**Returns**        <NRF> RMS MER in dB.

**Examples**     `READ:SQUALITY:RMS:MER:DB?` might return `27.394`, indicating that the RMS MER is 27.394 dB.

## **READ:SQUALity:RMS:MERRor? (Query Only)**

Returns the RMS magnitude error (%) in the signal quality measurement.

**Conditions**     Measurement views: Signal quality

**Group**         Read commands

**Syntax**        `READ:SQUALity:RMS:MERRor?`

**Arguments**     None

**Returns**        <NRF> RMS magnitude error in percent (%).

**Examples** READ:QUALITY:RMS:MERROR? might return 1.837, indicating that the RMS magnitude error is 1.837%.

## READ:QUALITY:RMS:MERROR:DB? (Query Only)

Returns the RMS magnitude error (dB) in the signal quality measurement.

**Conditions** Measurement views: Signal quality

**Group** Read commands

**Syntax** READ:QUALITY:RMS:MERROR:DB?

**Arguments** None

**Returns** <NRf> RMS magnitude error in dB.

**Examples** READ:QUALITY:RMS:MERROR:DB? might return -34.706, indicating that the magnitude error is -34.706 dB.

## READ:QUALITY:RMS:PERROR? (Query Only)

Returns the RMS phase error in the signal quality measurement.

**Conditions** Measurement views: Signal quality

**Group** Read commands

**Syntax** READ:QUALITY:RMS:PERROR?

**Arguments** None

**Returns** <NRf> RMS phase error in degrees.

**Examples** READ:QUALITY:RMS:PERROR? might return 893.472E-3, indicating that the RMS phase error is 0.893472 °.

## READ:SQUALity:SYMBOL:LENGTH? (Query Only)

Returns the number of analyzed symbols.

**Conditions** Measurement views: Signal quality

**Group** Read commands

**Syntax** READ:SQUALity:SYMBOL:LENGTH?

### Related Commands

**Returns** <NR1> indicates the length of the synch word in symbols.

**Examples** READ:SQUALITY:SYMBOL:LENGTH? might return 3, indicating the length is three symbols.

## READ:SQUALity:SYMBOL:RATE? (Query Only)

Returns the value of the calculated symbol rate in Hz.

**Conditions** Measurement views: Signal quality

It is valid when the modulation type is 2|4|8|16FSK and [:SENSe]:DDEMod:SYMBOL:RATE:SEARCh is ON.

**Group** Read commands

**Syntax** READ:SQUALity:SYMBOL:RATE?

**Related Commands** [\[SENSe\]:DDEMod:SYMBOL:RATE:SEARCh](#)

**Returns** <NRf> is the calculated symbol rate in Hz.

**Examples** READ:SQUALITY:SYMBOL:RATE? might return 95.24E+3, indicating the calculated symbol rate is 95.24 kHz.

## READ:SQUALity:SYMBOL:RATE:ERROR? (Query Only)

Returns the value of the symbol rate error in percent (%).

**Conditions** Measurement views: Signal quality  
It is valid when the modulation type is 2|4|8|16FSK and [:SENSe]:DDEMod:SYMBOL:RATE:SEARCh is ON.

**Group** Read commands

**Syntax** READ:SQUALity:SYMBOL:RATE:ERROR?

**Related Commands** [\[:SENSe\]:DDEMod:SYMBOL:RATE:SEARCh](#)

**Returns** <NRf> is the symbol error percent (%).

**Examples** READ:SQUALITY:SYMBOL:RATE:ERROR? might return -0.002, indicating that the symbol rate error is -0.002%.

## READ:TDIagram:FERRor? (Query Only)

Returns the frequency error in the trellis diagram measurement.

**Conditions** Measurement views: Trellis diagram

**Group** Read commands

**Syntax** READ:TDIagram:FERRor?

**Arguments** None

**Returns** <freq\_error> := <NRf> is the frequency error in Hz.

**Examples** READ:TDIAGRAM:FERROR? might return -10.7E+3, indicating the frequency error is -10.7 kHz.

## READ:TDIagram:TRACe? (Query Only)

Returns the Trellis diagram trace data.

<b>Conditions</b>	Measurement views: Trellis diagram
<b>Group</b>	Read commands
<b>Syntax</b>	READ:TDIagram:TRACe?
<b>Arguments</b>	None
<b>Returns</b>	<code>#&lt;num_digit&gt;&lt;num_byte&gt;&lt;Y(1)&gt;&lt;X(1)&gt;&lt;Y(2)&gt;&lt;X(2)&gt;...&lt;Y(n)&gt;&lt;X(n)&gt;</code> Where <code>&lt;num_digit&gt;</code> is the number of digits in <code>&lt;num_byte&gt;</code> . <code>&lt;num_byte&gt;</code> is the number of bytes of data that follow. <code>&lt;Y(n)&gt;&lt;X(n)&gt;</code> is the phase in degrees and the time in symbols pair at the $n^{\text{th}}$ data point, 4-byte little endian floating-point format specified in IEEE 488.2.
<b>Examples</b>	READ:TDIAGRAM:TRACE? might return <code>#3160xxxx...</code> (160-byte data) for the Trellis diagram trace.

## READ:TOVerview? (Query Only)

Returns the trace data in the time overview.

<b>Conditions</b>	Measurement views: Time overview
<b>Group</b>	Read commands
<b>Syntax</b>	READ:TOVerview?
<b>Arguments</b>	None
<b>Returns</b>	<code>#&lt;num_digit&gt;&lt;num_byte&gt;&lt;data(1)&gt;&lt;data(2)&gt;...&lt;data(n)&gt;</code> Where <code>&lt;num_digit&gt;</code> is the number of digits in <code>&lt;num_byte&gt;</code> .

<num\_byte> is the number of bytes of data that follow.  
 <data(n)> is the trace data in dBm for the point n,  
 4-byte little endian floating-point format specified in IEEE 488.2.  
 The unit can be changed by the [\[SENSe\]:POWer:UNITs](#) command.

**Examples** READ:TOVERVIEW? might return #43204xxxx... (3204-byte data) for the trace in the time overview.

## \*RST (No Query Form)

Returns the instrument settings to the factory defaults ((See page 3-1, *Factory Initialization Settings*.)

The \*RST command does not alter the following

- The state of the GPIB interface.
- The selected GPIB address of the analyzer.
- Alignment data that affect device specifications.
- The Output Queue.
- The Service Request Enable Register setting.
- The Standard Event Status Enable Register setting.
- The Power-on status clear flag setting.
- Stored settings.

---

**NOTE.** Execution of the \*RST command is not complete until all changes from resetting the instrument are completed. Following commands and queries will not be executed until these actions are completed.

---

**Conditions** Measurement views: All

**Group** IEEE common commands

**Syntax** \*RST

**Related Commands** [\\*CLS](#)

**Arguments** None

**Examples** \*RST returns the instrument settings to the factory defaults.

## [SENSe]:ACPower:AVERage

Selects or queries how to average waveform in the Channel power and ACPR measurement.

**Conditions** Measurement views: Channel power and ACPR

**Group** Sense commands

**Syntax** [SENSe]:ACPower:AVERage { OFF | TIME | FREquency }  
[SENSe]:ACPower:AVERage?

**Arguments** OFF disables averaging.  
TIME averages waveform using time samples.  
FREquency averages waveform using frequency samples.

**Examples** SENSE:ACPOWER:AVERAGE TIME averages waveform using time samples.

## [SENSe]:ACPower:AVERage:COUNT

Sets or queries the number of traces for averaging in the Channel power and ACPR measurement.

**Conditions** Measurement views: Channel power and ACPR

**Group** Sense commands

**Syntax** [SENSe]:ACPower:AVERage:COUNT <number>  
[SENSe]:ACPower:AVERage:COUNT?

**Arguments** <number> ::= <NR1> specifies the average count. Range: 2 to 10000.

**Examples** SENSE:ACPOWER:AVERAGE:COUNT 64 sets the average count to 64.



**[SENSe]:ACPower:{BANDwidth|BWIDth}[:RESolution]**

Sets or queries the resolution bandwidth (RBW). Programming a specified RBW sets [SENSe]:ACPower:{BANDwidth|BWIDth}[:RESolution]:AUTO OFF.

**Conditions** Measurement views: Channel power and ACPR

**Group** Sense commands

**Syntax** [SENSe]:ACPower:{BANDwidth|BWIDth}[:RESolution] <value>  
[SENSe]:ACPower:{BANDwidth|BWIDth}[:RESolution]?

**Related Commands** [SENSe]:ACPower:{BANDwidth|BWIDth}[:RESolution]:AUTO

**Arguments** <value> ::= <NRf> specifies the RBW. Range: 100 Hz to 5 MHz.

**Examples** SENSE:ACPOWER:BANDWIDTH:RESOLUTION 200kHz sets the RBW to 200 kHz.

**[SENSe]:ACPower:{BANDwidth|BWIDth}[:RESolution]:ACTual? (Query Only)**

Queries the actual resolution bandwidth (RBW) in the Channel power and ACPR measurement.

**Conditions** Measurement views: Channel power and ACPR

**Group** Sense commands

**Syntax** [SENSe]:ACPower:{BANDwidth|BWIDth}[:RESolution]:ACTual?

**Arguments** None

**Returns** <NRf> The actual RBW in Hz.

**Examples** SENSE:ACPOWER:BANDWIDTH:RESOLUTION:ACTUAL? might return 299.624E+3, indicating that the actual RBW is 299.624 kHz.

**[SENSe]:ACPower:{BANDwidth|BWIDth}:RESolution:AUTO**

Determines whether to set the resolution bandwidth (RBW) automatically or manually in the Channel power and ACPR measurement.

<b>Conditions</b>	Measurement views: Channel power and ACPR
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:ACPower:{BANDwidth BWIDth}:RESolution:AUTO { OFF   ON   0   1 } [SENSe]:ACPower:{BANDwidth BWIDth}:RESolution:AUTO?
<b>Arguments</b>	OFF or 0 specifies that the RBW is set manually using the [SENSe]:ACPower:{BANDwidth BWIDth}:RESolution command. ON or 1 specifies that the RBW is set automatically.
<b>Examples</b>	SENSE:ACPOWER:BANDWIDTH:AUTO ON sets the RBW automatically.

**[SENSe]:ACPower:{BANDwidth|BWIDth}:VIDeo**

Sets or queries the video bandwidth (VBW). Programming a specified VBW sets [SENSe]:ACPower:{BANDwidth|BWIDth}:VIDeo:STATE OFF.

<b>Conditions</b>	Measurement views: Channel power and ACPR
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:ACPower:{BANDwidth BWIDth}:VIDeo <value> [SENSe]:ACPower:{BANDwidth BWIDth}:VIDeo?
<b>Related Commands</b>	[SENSe]:ACPower:{BANDwidth BWIDth}:VIDeo:STATE
<b>Arguments</b>	<value>::=<NRF> specifies the VBW. Range: Current RBW/10 <sup>4</sup> (1 Hz minimum) to Current RBW.
<b>Examples</b>	SENSE:ACPOWER:BANDWIDTH:VIDEO 200kHz sets the VBW to 200 kHz.

## [SENSe]:ACPower:{BANDwidth|BWIDth}:VIDeo:STATe

Determines whether to enable or disable the video bandwidth (VBW) in the Channel power and ACPR measurement.

<b>Conditions</b>	Measurement views: Channel power and ACPR
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:ACPower:{BANDwidth BWIDth}:VIDeo:STATe { OFF   ON   0   1 } [SENSe]:ACPower:{BANDwidth BWIDth}:VIDeo:STATe?
<b>Arguments</b>	OFF or 0 disables the VBW. ON or 1 enables the VBW.
<b>Examples</b>	SENSE:ACPOWER:BANDWIDTH:VIDEO:STATE ON enables the VBW.

## [SENSe]:ACPower:CHANnel:{BANDwidth|BWIDth}

Sets or queries frequency bandwidth of each channel (all share the same value) in the Channel power and ACPR measurement.

<b>Conditions</b>	Measurement views: Channel power and ACPR
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:ACPower:CHANnel:{BANDwidth BWIDth} <value> [SENSe]:ACPower:CHANnel:{BANDwidth BWIDth}?
<b>Arguments</b>	<value> ::= <NRf> specifies the channel bandwidth. Range: 1 Hz to full span.
<b>Examples</b>	SENSE:ACPOWER:CHANNEL:BANDWIDTH 1.5MHZ sets the channel bandwidth to 1.5 MHz.

## [SENSe]:ACPower:CHANnel:FILTer

Selects or queries the adjacent channel filter in the Channel power and ACPR measurement.

**Conditions** Measurement views: Channel power and ACPR

**Group** Sense commands

**Syntax** [SENSe]:ACPower:CHANnel:FILTer { RRCosine | NONE }  
[SENSe]:ACPower:CHANnel:FILTer?

**Arguments** RRCosine uses the Root-Raised Cosine filter.  
NONE uses no filter.

**Examples** SENSE:ACPOWER:CHANNEL:FILTER RRCosine uses the Root-Raised Cosine filter for the Channel power and ACPR measurement.

## [SENSe]:ACPower:CHANnel:PAIRs

Sets or queries the number of adjacent channel pairs (upper and lower) in the Channel power and ACPR measurement.

**Conditions** Measurement views: Channel power and ACPR

**Group** Sense commands

**Syntax** [SENSe]:ACPower:CHANnel:PAIRs <number>  
[SENSe]:ACPower:CHANnel:PAIRs?

**Arguments** <number>::=<NR1> specifies the number of adjacent pairs. Range: 0 to 50.

**Examples** SENSE:ACPOWER:CHANNEL:PAIRS 5 sets five adjacent channel pairs.

## [SENSe]:ACPower:CHANnel:SPACing

Sets or queries frequency difference between centers of each channel in the Channel power and ACPR measurement.

<b>Conditions</b>	Measurement views: Channel power and ACPR
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSE]:ACPower:CHANnel:SPACing <value> [SENSE]:ACPower:CHANnel:SPACing?
<b>Arguments</b>	<value>::=<Nrf> specifies the channel-to-channel spacing. Range: 1 Hz to 1 GHz.
<b>Examples</b>	SENSE:ACPOWER:CHANNEL:SPACING 5MHZ sets the channel-to-channel spacing to 5 MHz.

## [SENSE]:ACPower:CHIPrate

Sets or queries the chip rate when [SENSE]:ACPower:CHANnel:FILTer is set to RRCosine (Root Raised Cosine).

<b>Conditions</b>	Measurement views: Channel power and ACPR
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSE]:ACPower:CHIPrate <value> [SENSE]:ACPower:CHIPrate?
<b>Related Commands</b>	<a href="#">[SENSE]:ACPower:CHANnel:FILTer</a>
<b>Arguments</b>	<value>::=<Nrf> specifies the chip rate. Range: 100 Hz to 105 MHz.
<b>Examples</b>	SENSE:ACPOWER:CHIPRATE 5kHz sets the chip rate to 5 kHz.

## [SENSE]:ACPower:CLEar:RESults (No Query Form)

Restarts the average trace.

<b>Conditions</b>	Measurement views: Channel power and ACPR
-------------------	---

<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:ACPower:CLEAr:RESuIts
<b>Arguments</b>	None
<b>Examples</b>	SENSE:ACPOWER:CLEAR:RESULTS restarts the average trace.

## [SENSe]:ACPower:FREQuency

Sets or queries the center frequency in the Channel power and ACPR measurement.

<b>Conditions</b>	Measurement views: Channel power and ACPR
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:ACPower:FREQuency <vaLue> [SENSe]:ACPower:FREQuency?
<b>Arguments</b>	<vaLue>::=<Nrf> specifies the center frequency. Range: 0 to 6.2 GHz (RSA6106A) / 14 GHz (RSA6114A).
<b>Examples</b>	SENSE:ACPOWER:FREQUENCY 2.35GHZ sets the center frequency to 2.35 GHz.

## [SENSe]:ACPower:FREQuency:STEP

Sets or queries the frequency step size in the Channel power and ACPR measurement. Programming a specified step size sets [SENSe]:ACPower:FREQuency:STEP:AUTO OFF.

<b>Conditions</b>	Measurement views: Channel power and ACPR
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:ACPower:FREQuency:STEP <vaLue> [SENSe]:ACPower:FREQuency:STEP?

---

<b>Related Commands</b>	<a href="#">[SENSe]:ACPower:FREQuency:STEP:AUTO</a>
<b>Arguments</b>	<value> ::= <NRF> specifies the frequency step size. Range: 0 to 6.2 GHz (RSA6106A) / 14 GHz (RSA6114A).
<b>Examples</b>	SENSE:ACPOWER:FREQUENCY:STEP 1kHz sets the frequency step size to 1 kHz.

## [SENSe]:ACPower:FREQuency:STEP:AUTO

Determines whether to set the frequency step size automatically or manually in the Channel power and ACPR measurement.

<b>Conditions</b>	Measurement views: Channel power and ACPR
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:ACPower:FREQuency:STEP:AUTO { OFF   ON   0   1 } [SENSe]:ACPower:FREQuency:STEP:AUTO?
<b>Arguments</b>	OFF or 0 specifies that the frequency step size is set manually using the <a href="#">[SENSe]:ACPower:FREQuency:STEP</a> command. ON or 1 specifies that the frequency step size is set automatically.
<b>Examples</b>	SENSE:ACPOWER:FREQUENCY:STEP:AUTO ON specifies that the frequency step size is set automatically.

## [SENSe]:ACPower:NFLoor:STATe

Determines whether to enable or disable the correction for noise floor.

<b>Conditions</b>	Measurement views: Channel power and ACPR
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:ACPower:NFLoor:STATe { OFF   ON   0   1 } [SENSe]:ACPower:NFLoor:STATe?

**Arguments** OFF or 0 disables the correction for noise floor.  
ON or 1 enables the correction for noise floor.

**Examples** SENSE:ACPOWER:NFLOOR:STATE ON enables the correction for noise floor.

## [SENSE]:ACPower:OPTimize:SPAN

Selects or queries the optimization method in the Channel power and ACPR measurement.

**Conditions** Measurement views: Channel power and ACPR

**Group** Sense commands

**Syntax** [SENSE]:ACPower:OPTimize:SPAN { RTBandwidth | DRANGE }  
[SENSE]:ACPower:OPTimize:SPAN?

**Arguments** RTBandwidth optimizes the measurement for real-time bandwidth.  
DRANGE optimizes the measurement for dynamic range.

**Examples** SENSE:ACPOWER:OPTIMIZE:SPAN RTBandwidth optimizes the measurement for real-time bandwidth.

## [SENSE]:ACPower:RRCRolloff

Sets or queries the filter parameter (roll-off ratio) for the Root Raised Cosine filter.

**Conditions** Measurement views: Channel power and ACPR

**Group** Sense commands

**Syntax** [SENSE]:ACPower:RRCRolloff <value>  
[SENSE]:ACPower:RRCRolloff?

**Related Commands** [\[SENSE\]:ACPower:CHANnel:FILTer](#)



**Arguments** <value>::=<Nrf> specifies the filter parameter.  
Range: 0.0001 to 1 in 0.0001 steps.

**Examples** SENSE:ACPOWER:RRCROLLOFF 0.3 sets the filter parameter to 0.3.

## [SENSE]:ACQuisition:{BANDwidth|BWIDth}

Sets or queries the acquisition bandwidth (frequency range of the acquisition) when [SENSE]:ACQuisition:MODE is set to SAMPlEs or LENGth.

**Conditions** Measurement views: All

**Group** Sense commands

**Syntax** [SENSE]:ACQuisition:{BANDwidth|BWIDth} <value>  
[SENSE]:ACQuisition:{BANDwidth|BWIDth}?

**Arguments** <value>::=<Nrf> specifies the acquisition bandwidth.  
Range: 1 MHz to 40 MHz (Standard) / 110 MHz (Option 110).

**Examples** SENSE:ACQUISITION:BANDWIDTH 30MHZ sets the acquisition bandwidth to 30 MHz.

## [SENSE]:ACQuisition:FFrame:ACTual? (Query Only)

Queries the actual number of Fast Frames.

**Conditions** Measurement views: All

**Group** Sense commands

**Syntax** [SENSE]:ACQuisition:FFrame:ACTual?

**Arguments** None

**Returns** <NR1> The actual number of Fast Frames.

**Examples**     `SENSE:ACQUISITION:FFRAME:ACTUAL?` might return 178, indicating that the actual number of Fast Frames is 178.

## **[SENSe]:ACQuisition:FFRame:LIMit**

Sets or queries the limit number of Fast Frames.

**Conditions**     Measurement views: All

**Group**     Sense commands

**Syntax**     `[SENSe]:ACQuisition:FFRame:LIMit`  
`[SENSe]:ACQuisition:FFRame:LIMit?`

**Arguments**     `<value>::=<NR1>` specifies the fast frame limit. Range: 1 to 65535 frames.

**Examples**     `SENSE:ACQUISITION:FFRAME:LIMIT 500` sets the Fast Frame limit to 500.

## **[SENSe]:ACQuisition:FFRame:STATe**

Determines whether to enable or disable the Fast Frame.

**Conditions**     Measurement views: All

**Group**     Sense commands

**Syntax**     `[SENSe]:ACQuisition:FFRame:STATe { OFF | ON | 0 | 1 }`  
`[SENSe]:ACQuisition:FFRame:STATe?`

**Arguments**     OFF or 0 disables the Fast Frame.  
ON or 1 enables the Fast Frame.

**Examples**     `SENSE:ACQUISITION:FFRAME:STATE ON` enables the Fast Frame.

## [SENSe]:ACQuisition:MEMory:AVAIlable:SAMPles? (Query Only)

Returns the amount of acquisition memory available in the instrument.

<b>Conditions</b>	Measurement views: All
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:ACQuisition:MEMory:AVAIlable:SAMPles?
<b>Arguments</b>	None
<b>Returns</b>	<NRf> The amount of acquisition memory available in samples.
<b>Examples</b>	SENSE:ACQUISITION:MEMORY:AVAILABLE:SAMPLES? might return 999.424E+3, indicating that 999424 samples are available.

## [SENSe]:ACQuisition:MEMory:CAPacity[:TIME]? (Query Only)

Returns the acquisition memory capacity (maximum period of time that can be acquired with the acquisition memory).

<b>Conditions</b>	Measurement views: All
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:ACQuisition:MEMory:CAPacity[:TIME]?
<b>Arguments</b>	None
<b>Returns</b>	<NRf> The acquisition memory capacity in seconds.
<b>Examples</b>	SENSE:ACQUISITION:MEMORY:CAPACITY:TIME? might return 26.651E-3, indicating that 26.651 ms can be acquired.

## [SENSe]:ACQuisition:MEMory:USED[:PERCent]? (Query Only)

Returns the percentage of the capacity used based on the current settings.

<b>Conditions</b>	Measurement views: All
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:ACQuisition:MEMory:USED[:PERCent]?
<b>Arguments</b>	None
<b>Returns</b>	<NRF> The percentage of the capacity used.
<b>Examples</b>	SENSe:ACQuisition:MEMory:USED:PERCENT? might return 50.0, indicating that 50% is used.

## [SENSe]:ACQuisition:MODE

Selects or queries the acquisition mode (how to determine the sampling parameters of acquisition bandwidth, samples, and length).

<b>Conditions</b>	Measurement views: All
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:ACQuisition:MODE { AUTO   SAMPlEs   LENGth } [SENSe]:ACQuisition:MODE?
<b>Related Commands</b>	<a href="#">[SENSe]:ACQuisition:{BANDwidth BWIDth}</a> , <a href="#">[SENSe]:ACQuisition:SAMPlEs</a> , <a href="#">[SENSe]:ACQuisition:SEConds</a>
<b>Arguments</b>	AUTO sets the all sampling parameters automatically.  SAMPlEs sets the acquisition bandwidth and samples manually, using the <a href="#">[SENSe]:ACQuisition:{BANDwidth BWIDth}</a> and <a href="#">:SAMPlEs</a> commands.  LENGth sets the acquisition bandwidth and length manually, using the <a href="#">[SENSe]:ACQuisition:{BANDwidth BWIDth}</a> and <a href="#">:SEConds</a> commands.

**Examples** SENSE:ACQUISITION:MODE AUTO sets the all sampling parameters automatically.

## [SENSE]:ACQUISITION:SAMPLES

Sets or queries the acquisition samples (number of samples acquired over the acquisition time) when [SENSE]:ACQUISITION:MODE is set to SAMPLES.

**Conditions** Measurement views: All

**Group** Sense commands

**Syntax** [SENSE]:ACQUISITION:SAMPLES <value>  
[SENSE]:ACQUISITION:SAMPLES?

**Arguments** <value>::=<NR1> specifies the acquisition samples. Range: 2 to 1 G samples.

**Examples** SENSE:ACQUISITION:SAMPLES 1114 sets the acquisition samples to 1114.

## [SENSE]:ACQUISITION:SECONDS

Sets or queries the acquisition length (time over which the acquisition occurs) when [SENSE]:ACQUISITION:MODE is set to LENGTH.

**Conditions** Measurement views: All

**Group** Sense commands

**Syntax** [SENSE]:ACQUISITION:SECONDS <value>  
[SENSE]:ACQUISITION:SECONDS?

**Arguments** <value>::=<NRf> specifies the acquisition length.

**Examples** SENSE:ACQUISITION:SAMPLES 12.5ms sets the acquisition length to 12.5 ms.

**[SENSe]:{AM|FM|PM}:{BANDwidth|BWIDth}:MEASurement**

Sets measurement bandwidth for the AM, FM, or PM demodulation to analyze.

<b>Conditions</b>	Measurement views: AM, FM, PM
<b>Group</b>	Sense commands
<b>Syntax</b>	<code>[SENSe]:{AM FM PM}:{BANDwidth BWIDth}:MEASurement &lt;value&gt;</code> <code>[SENSe]:{AM FM PM}:{BANDwidth BWIDth}:MEASurement?</code>
<b>Related Commands</b>	<a href="#">FETCh:{AM FM PM}?</a> <a href="#">READ:AM:RESult?</a> <a href="#">READ:FM:RESult?</a> <a href="#">READ:PM:RESult?</a>
<b>Arguments</b>	<code>&lt;value&gt;::=&lt;Nrf&gt;</code> specifies the demodulation bandwidth for the specified modulation type.
<b>Examples</b>	<code>SENSE:AM:BANDwidth:MEASurement 1e6</code> sets the amplitude demodulation bandwidth to 1 MHz.

**[SENSe]:{AM|FM|PM}:CLEAr:RESults (No Query Form)**

Clear results in the AM/FM/PM measurement.

<b>Conditions</b>	Measurement views: AM, FM, PM
<b>Group</b>	Sense commands
<b>Syntax</b>	<code>[SENSe]:{AM FM PM}:CLEAr:RESults</code>
<b>Arguments</b>	None
<b>Examples</b>	<code>SENSE:AM:CLEAR:RESULTS</code> clears results in the AM measurement.

**[SENSe]:{AM|FM|PM}:{MTPoints|MAXTracepoints}**

Selects or queries the maximum trace points in the AM/FM/PM measurement.

**Conditions** Measurement views: AM, FM, PM

**Group** Sense commands

**Syntax** [SENSe]:{AM|FM|PM}:{MTPoints|MAXTracepoints} { ONEK | TENK | HUNDredk | NDECimate | NEVerdecimate }  
[SENSe]:{AM|FM|PM}:{MTPoints|MAXTracepoints}?

**Arguments** The following table lists the arguments.

Argument	Maximum trace points
ONEK	1k
TENK	10k
HUNDredk	100k
NDECimate or NEVerdecimate	Never decimate

**Examples** SENSE:AM:MTPOINTS ONEK selects the maximum trace points of 1000 in the AM measurement.

**[SENSe]:AM:DETECT:AMPLitude**

Selects or queries the carrier amplitude detection method used to determine the 0% reference modulation in the AM measurement.

**Conditions** Measurement views: AM

**Group** Sense commands

**Syntax** [SENSe]:AM:DETECT:AMPLitude { AVERAGE | MEDIAN }  
[SENSe]:AM:DETECT:AMPLitude?

**Arguments** AVERAGE defines the 0% reference modulation as the average amplitude in the analysis range (default).

MEDIAN defines the 0% reference modulation as the median amplitude  $\left(\frac{[(\text{maximum})+(\text{minimum})]}{2}\right)$  in the analysis range.

**Examples**     `SENSE:AM:DETECT:AMPLITUDE AVERAGE` defines the 0% modulation as the average amplitude in the analysis range.

## **[SENSe]:ANALysis:ADVanced:DITHer**

Determines whether to enable or disable dithering, or set it automatically.

Dither is a random low-level signal consisting of white noise of one quantizing level peak-to-peak amplitude which may be added to an analog signal prior to sampling for the purpose of minimizing quantization error.

**Conditions**     Measurement views: All

**Group**     Sense commands

**Syntax**     `[SENSe]:ANALysis:ADVanced:DITHer { AUTO | ON | OFF }`  
`[SENSe]:ANALysis:ADVanced:DITHer?`

**Arguments**     AUTO specifies that the dither is set automatically.  
                       ON enables dithering.  
                       OFF disables dithering.

**Examples**     `SENSE:ANALYSIS:ADVANCED:DITHER ON` enables dithering.

## **[SENSe]:ANALysis:ADVanced:DITHer:HWARe:STATus? (Query Only)**

Queries the dithering hardware status.

**Conditions**     Measurement views: All

**Group**     Sense commands

**Syntax**     `[SENSe]:ANALysis:ADVanced:DITHer:HWARe:STATus?`

**Arguments**     None

**Returns**     One of the following status information.



**Table 2-35: Dithering status**

Status	Description
DUNaligned	Dithering is disabled and unaligned.
ON	Dithering is enabled
OFF	Dithering is disabled.

**Examples** SENSE:ANALYSIS:ADVANCED:DITHER:HWARE:STATUS? might return OFF, indicating that the dithering is disabled.

## [SENSe]:ANALySis:LENGth

Sets or queries the analysis length. Programming a specified length sets [SENSe]:ANALySis:AUTO OFF.

**Conditions** Measurement views: All

**Group** Sense commands

**Syntax** [SENSe]:ANALySis:LENGth <value>  
[SENSe]:ANALySis:LENGth?

**Related Commands** [\[SENSe\]:ANALySis:LENGth:AUTO](#)

**Arguments** <value> ::= <NRf> specifies the analysis length.  
Range: 10 ns to [(acquisition length) - 400 ns].  
If [(analysis start) + (analysis length)] > [(acquisition length) - 400 ns], the actual analysis length is reduced to [(acquisition length) - 200 ns].

**Examples** SENSE:ANALYSIS:LENGTH 25.625us sets the analysis length to 25.625 μs.

## [SENSe]:ANALySis:LENGth:ACTual? (Query Only)

Queries the actual analysis length.

**Conditions** Measurement views: All

**Group** Sense commands

**Syntax** [SENSe]:ANALysis:LENGth:ACTual?

**Arguments** None

**Returns** <NRF> Actual analysis length in seconds.

**Examples** SENSE:ANALYSIS:LENGTH:ACTUAL? might return 25.625E-6, indicating that the actual analysis length is 25.625  $\mu$ s.

## [SENSe]:ANALysis:LENGth:AUTO

Determines whether to set the analysis length automatically or manually.

**Conditions** Measurement views: All

**Group** Sense commands

**Syntax** [SENSe]:ANALysis:LENGth:AUTO { OFF | ON | 0 | 1 }  
[SENSe]:ANALysis:LENGth:AUTO?

**Arguments** OFF or 0 sets the analysis length manually, using the [\[SENSe\]:ANALysis:LENGth](#) command.

ON or 1 sets the analysis length automatically.

**Examples** SENSE:ANALYSIS:LENGTH:AUTO ON sets the analysis length automatically.

## [SENSe]:ANALysis:REFerence

Selects or queries the analysis time reference.

**Conditions** Measurement views: All

**Group** Sense commands

**Syntax** [SENSe]:ANALysis:REFerence { ACQSTART | TRIGGER }  
[SENSe]:ANALysis:REFerence?

**Arguments** ACQSTART specifies the acquisition start as the time zero reference.  
TRIGGER specifies the trigger point as the time zero reference.

**Examples** SENSE:ANALYSIS:REFERENCE ACQSTART specifies the acquisition start as the analysis time reference.

## [SENSE]:ANALYSIS:START

Sets or queries the analysis offset time. Programming a specified offset time sets [SENSE]:ANALYSIS:START:AUTO OFF.

**Conditions** Measurement views: All

**Group** Sense commands

**Syntax** [SENSE]:ANALYSIS:START <value>  
[SENSE]:ANALYSIS:START?

**Related Commands** [\[SENSE\]:ANALYSIS:LENGTH](#), [\[SENSE\]:ANALYSIS:START:AUTO](#)

**Arguments** <value> ::= <NRf> specifies the analysis offset time.  
Range: 0 to [(acquisition length) - 200 ns].  
If [(analysis start) + (analysis length)] > [(acquisition length) - 400 ns], the actual analysis length is reduced to [(acquisition length) - 200 ns].

**Examples** SENSE:ANALYSIS:START 23.5us sets the analysis offset to 23.5  $\mu$ s.

## [SENSE]:ANALYSIS:START:AUTO

Determines whether to set the analysis offset automatically or manually.

**Conditions** Measurement views: All

**Group** Sense commands

**Syntax** [SENSE]:ANALYSIS:START:AUTO { OFF | ON | 0 | 1 }  
[SENSE]:ANALYSIS:START:AUTO?

- Arguments** OFF or 0 sets the analysis offset manually, using the [\[SENSe\]:ANALysis:START](#) command.  
ON or 1 sets the analysis offset automatically.
- Examples** `SENSE:ANALYSIS:START:AUTO ON` sets the analysis offset automatically.

## **[SENSe]:AVTime:{BANDwidth|BWIDth}**

Sets or queries the time-domain bandwidth filter in the Amplitude versus Time measurement. Programming a specified bandwidth disables the [\[SENSe\]:AVTime:SPAN](#) setting.

- Conditions** Measurement views: Amplitude versus Time
- Group** Sense commands
- Syntax** `[SENSe]:AVTime:{BANDwidth|BWIDth} <value>`  
`[SENSe]:AVTime:{BANDwidth|BWIDth}?`
- Arguments** `<value>::=<NRF>` specifies the filter bandwidth.  
Range: 1 Hz to 20 MHz (Standard) / 60 MHz (Option 110).
- Examples** `SENSE:AVTIME:BANDWIDTH 10MHZ` sets the filter bandwidth to 10 MHz.

## **[SENSe]:AVTime:{BANDwidth|BWIDth}:ACTual? (Query Only)**

Queries the actual time-domain bandwidth in the Amplitude versus Time measurement.

- Conditions** Measurement views: Amplitude versus Time
- Group** Sense commands
- Syntax** `[SENSe]:AVTime:{BANDwidth|BWIDth}:ACTual?`
- Arguments** None

**Returns** <NRf> The actual time-domain bandwidth in Hz.

**Examples** SENSE:AVTIME:BANDWIDTH:ACTUAL? might return 20E+6, indicating that the actual time-domain bandwidth is 20 MHz.

## [SENSE]:AVTime:CLEAr:RESuLts (No Query Form)

Restarts multi-trace functions (Average and Max/Min Hold).

**Conditions** Measurement views: Amplitude versus Time

**Group** Sense commands

**Syntax** [SENSE]:AVTime:CLEAr:RESuLts

**Arguments** None

**Examples** SENSE:AVTIME:CLEAR:RESULTS restarts multi-trace functions.

## [SENSE]:AVTime:MAXTracepoints

Selects or queries the maximum trace points in the Amplitude versus Time measurement.

**Conditions** Measurement views: Amplitude versus Time

**Group** Sense commands

**Syntax** [SENSE]:AVTime:MAXTracepoints { ONEK | TENK | HUNDredk | NEVERdecimate }  
[SENSE]:AVTime:MAXTracepoints?

**Arguments** ONEK sets the maximum trace points to 1 k.  
TENK sets the maximum trace points to 10 k.  
HUNDredk sets the maximum trace points to 100 k.  
NEVERdecimate never decimates the trace points.

**Examples**     `SENSE:AVTIME:MAXTRACEPOINTS TENK` sets the maximum trace points to 10 k.

## [SENSe]:AVTime:METhod

Selects or queries the method to set the measurement bandwidth in the Amplitude versus Time measurement.

**Conditions**     Measurement views: Amplitude versus Time

**Group**     Sense commands

**Syntax**     `[SENSe]:AVTime:METhod { SPAN | TDBW }`  
`[SENSe]:AVTime:METhod?`

**Arguments**     SPAN specifies that the measurement bandwidth is set by the frequency span, using the `[SENSe]:AVTime:SPAN` command.

TDBW specifies that the measurement bandwidth is set by the time-domain bandwidth, using the `[SENSe]:AVTime:{BANDwidth|BWIDth}` command.

**Examples**     `SENSE:AVTIME:METHOD SPAN` specifies that the measurement bandwidth is set by the frequency span.

## [SENSe]:AVTime:SPAN

Sets or queries the frequency span in the Amplitude versus Time measurement. Programming a specified span disables the `[SENSe]:AVTime:{BANDwidth|BWIDth}` setting.

**Conditions**     Measurement views: Amplitude versus Time

**Group**     Sense commands

**Syntax**     `[SENSe]:AVTime:SPAN <value>`  
`[SENSe]:AVTime:SPAN?`

**Arguments**     `<value>::=<Nrf>` specifies the frequency span.  
 Range: 10 Hz to 40 MHz (Standard) / 110 MHz (Option 110)

**Examples**    `SENSE:AVTIME:SPAN 5MHz` sets the frequency span to 5 MHz.

## **[SENSe]:CCDF:{BANDwidth|BWIDth}**

Sets or queries the CCDF measurement bandwidth (frequency span).

**Conditions**    Measurement views: CCDF

**Group**    Sense commands

**Syntax**    `[SENSe]:CCDF:{BANDwidth|BWIDth} <value>`  
`[SENSe]:CCDF:{BANDwidth|BWIDth}?`

**Arguments**    `<value> ::= <Nrf>` is the CCDF measurement bandwidth.  
 Range: 10 Hz to 40 MHz (Standard) / 60 MHz (Option 110).

**Examples**    `SENSE:CCDF:BANDWIDTH 1MHz` sets the CCDF measurement bandwidth to 1 MHz.

## **[SENSe]:CCDF:CLEAr (No Query Form)**

Clears the CCDF accumulator and restarts the measurement.

**Conditions**    Measurement views: CCDF

**Group**    Sense commands

**Syntax**    `[SENSe]:CCDF:CLEAr`

**Arguments**    None

**Examples**    `SENSE:CCDF:CLEAr` clears the CCDF accumulator and restarts the measurement.

## **[SENSe]:CCDF:TIME:TOTAl:LENGth**

Sets or queries the CCDF measurement time when [\[SENSe\]:CCDF:TIME:TYPE](#) is set to `TOTAl`.

<b>Conditions</b>	Measurement views: CCDF
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:CCDF:TIME:TOTAl:LENGth <value> [SENSe]:CCDF:TIME:TOTAl:LENGth?
<b>Arguments</b>	<value>::=<Nrf> specifies the CCDF measurement time. Range: 20 ms to 100 s.
<b>Examples</b>	SENSE:CCDF:TIME:TOTAL:LENGTH 10 sets the CCDF measurement time to 10 s.

## [SENSe]:CCDF:TIME:TYPE

Determines how to repeat the CCDF measurement.

<b>Conditions</b>	Measurement views: CCDF
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:CCDF:TIME:TYPE { SINGLE   TOTAl   CONTinuous } [SENSe]:CCDF:TIME:TYPE?
<b>Related Commands</b>	INITiate commands
<b>Arguments</b>	<p>SINGLE specifies that the analyzer sets the analysis length to 1 ms and then acquire data once to calculate CCDF.</p> <p>TOTAl specifies that the analyzer sets the analysis length to 20 ms and then repeats data acquisition and CCDF calculation for the time specified by the <a href="#">[SENSe]:CCDF:TIME:TOTAl:LENGth</a> command.</p> <p>CONTinuous specifies that the analyzer sets the analysis length to 1 ms and then repeats data acquisition and CCDF calculation continuously. To reset the process, use the <a href="#">[SENSe]:CCDF:CLEAr</a> command or the INITiate commands.</p>
<b>Examples</b>	SENSE:CCDF:TIME:TYPE SINGLE specifies that the analyzer sets the analysis length to 1 ms and then acquire data once to calculate CCDF.



## [SENSe]:DDEMod:ANALysis:LENGth

Sets or queries the analysis length in seconds or symbols. The command [SENSe]:DDEMod:TIME:UNITs determines which is used. For example, if the symbol rate is 1 MHz and the acquisition length is 20 ms, the range may be 0 to 19999. Setting a specified length changes [SENSe]:DDEMod:ANALysis:AUTO to OFF.

**Conditions** Measurement views: General purpose digital modulation

**Group** Sense commands

**Syntax** [SENSe]:DDEMod:ANALysis:LENGth <value>  
[SENSe]:DDEMod:ANALysis:LENGth?

**Related Commands** [SENSe]:DDEMod:ANALysis:LENGth:ACTual?  
[SENSe]:DDEMod:TIME:UNITs  
[SENSe]:DDEMod:ANALysis:LENGth:AUTO

**Arguments** <value> ::= <NRF> specifies the analysis length in seconds or symbols.  
Range in seconds: 200 ns to [(acquisition length) - 400 ns].  
If [(analysis start) + (analysis length)] > [(acquisition length) - 400 ns], the actual analysis length is reduced to [(acquisition length) - 200 ns].  
Range in symbols: 200 ns \* (symbol rate) to [(acquisition length) - 400 ns] \* (symbol rate).  
If [(analysis start) + (analysis length)] > [(acquisition length) - 400 ns], the actual analysis length is reduced to [(acquisition length) - 200 ns] \* (symbol rate).

**Examples** SENSE:DDEMOD:ANALYSIS:LENGTH 25.625us sets the analysis length to 25.625  $\mu$ s.  
SENSE:DDEMOD:ANALYSIS:LENGTH 256 sets the analysis length to 256 symbols.

## [SENSe]:DDEMod:ANALysis:LENGth:ACTual? (Query Only)

Queries the actual analysis length which returns a value in either seconds or symbols. The command [SENSe]:DDEMod:TIME:UNITs determines which is used.

<b>Conditions</b>	Measurement views: General purpose digital modulation
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:DDEMod:ANALysis:LENGth:ACTual?
<b>Related Commands</b>	<a href="#">[SENSe]:DDEMod:ANALysis:LENGth</a> <a href="#">[SENSe]:DDEMod:TIME:UNITs</a>
<b>Arguments</b>	None
<b>Returns</b>	<NRF> Actual analysis length in seconds or symbols.
<b>Examples</b>	SENSE:DDEMOD:ANALYSIS:LENGTH:ACTUAL? might return 25.625E-6, indicating that the actual analysis length is 25.625 $\mu$ s.

## [SENSe]:DDEMod:ANALysis:LENGth:AUTO

Determines whether to set the analysis length automatically or manually.

<b>Conditions</b>	Measurement views: General purpose digital modulation
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:DDEMod:ANALysis:LENGth:AUTO { OFF   ON   0   1 } [SENSe]:DDEMod:ANALysis:LENGth:AUTO?
<b>Arguments</b>	OFF or 0 sets the analysis length manually, using the <a href="#">[SENSe]:DDEMod:ANALysis:LENGth</a> command. ON or 1 sets the analysis length automatically.
<b>Examples</b>	SENSE:DDEMOD:ANALYSIS:LENGTH:AUTO ON sets the analysis length automatically.

**[SENSe]:DDEMod:{BANDwidth|BWIDth}:TINterval**

Sets or queries the measurement bandwidth (frequency span).

**Conditions** Measurement views: General purpose digital modulation

**Group** Sense group

**Syntax** [SENSe]:DDEMod:{BANDwidth|BWIDth}:TINterval <value>  
[SENSe]:DDEMod:{BANDwidth|BWIDth}:TINterval?

**Related Commands** [\[SENSe\]:DDEMod:SRATe](#)

**Arguments** <value> ::= <Nrf> specifies the measurement bandwidth.  
Range: Symbol rate to 40 MHz or, with Option 110, 110 MHz.  
The minimum value depends on the setting of [:SENSe]:DDEMod:SRATe.

**Returns** <Nrf> Actual measurement bandwidth.

**Examples** DDEMOD: BANDWIDTH: TINTERVAL 35.255MHZ sets the measurement bandwidth to 35.255 MHz.

**[SENSe]:DDEMod:{BANDwidth|BWIDth}:TINterval:AUTO**

Sets the measurement bandwidth (frequency span) automatically.

**Conditions** Measurement views: General purpose digital modulation

**Group** Sense group

**Syntax** [SENSe]:DDEMod:{BANDwidth|BWIDth}:TINterval:AUTO { OFF | ON  
| 0 | 1 }  
[SENSe]:DDEMod:{BANDwidth|BWIDth}:TINterval:AUTO?

**Related Commands** [\[SENSe\]:DDEMod:{BANDwidth|BWIDth}:TINterval](#)

**Arguments** OFF or 0 sets the measurement bandwidth manually, using the `[SENSe]:DDEMod:{BANDwidth|BWIDth}:TINterval` command.  
ON or 1 sets the measurement bandwidth automatically.

**Examples** `SENSE:DDEMOD:BANDWIDTH:TINTERVAL:AUTO` sets the measurement bandwidth automatically

## [SENSe]:DDEMod:BURSt:DETECT

Determines how to detect bursts.

**Conditions** Measurement views: General purpose digital modulation

**Group** Sense commands

**Syntax** `[SENSe]:DDEMod:BURSt:DETECT { ON | OFF }`  
`[SENSe]:DDEMod:BURSt:DETECT?`

**Related Commands** [\[SENSe\]:DDEMod:BURSt:THReshold](#)

**Arguments** ON analyzes just that burst period if a burst is found. If a burst is not found, does not analyze but displays an error message.

OFF analyzes the whole analysis length.

---

**NOTE.** *When selecting On and if the signal is not adequate for the demodulation, the measurement will fail and show an error message.*

---

**Examples** `SENSE:DDEMOD:BURST:DETECT OFF` analyzes the whole analysis length.

## [SENSe]:DDEMod:BURSt:THReshold

Sets or queries the threshold level above which the input signal is determined to be a burst.

**Conditions** Measurement views: General purpose digital modulation

**Group** Sense commands

**Syntax** [SENSE]:DDEMod:BURSt:THReshold <value>  
[SENSE]:DDEMod:BURSt:THReshold?

**Related Commands** [\[SENSe\]:DDEMod:BURSt:DETECT](#)

**Arguments** <value> ::= <NRf> specifies the threshold level for detecting bursts.  
Range: -100 to -10 dBc.

**Examples** SENSE:DDEMOD:BURST:THRESHOLD -25 sets the threshold level to -25 dBc.

## [SENSe]:DDEMod:CARRier:OFFSet

Sets or queries the carrier frequency offset in digital modulation analysis.

**Conditions** Measurement views: General purpose digital modulation

**Group** Sense commands

**Syntax** [SENSE]:DDEMod:CARRier:OFFSet <value>  
[SENSE]:DDEMod:CARRier:OFFSet?

**Related Commands** The settings of the following commands may narrow the effective range.

[\[SENSe\]:DDEMod:FILTer:ALPHa](#)

[\[SENSe\]:DDEMod:FILTer:REFerence](#)

[\[SENSe\]:DDEMod:MODulation:TYPE](#)

[\[SENSe\]:DDEMod:SRATe](#)

**Arguments** <value> ::= <NRf> specifies the carrier frequency offset.  
Range: -20 MHz to +20 MHz or with Option 110, -55 MHz to +55 MHz .

**Examples** SENSE:DDEMOD:CARRIER:OFFSET 2kHz sets the carrier frequency offset to 2 kHz.

## [SENSe]:DDEMod:CARRier:OFFSet:AUTO

Sets or queries whether to detect the carrier frequency automatically in digital modulation analysis.

<b>Conditions</b>	Measurement views: General purpose digital modulation
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSE]:DDEMod:CARRier:OFFSet:AUTO { OFF   ON   0   1 } [SENSe]:DDEMod:CARRier:OFFSet:AUTO?
<b>Related Commands</b>	[SENSe]:DDEMod:CARRier:OFFSet
<b>Arguments</b>	OFF or 0 sets the carrier frequency manually, using the[SENSe]:DDEMod:CARRier:OFFSet command.  ON or 1 detects the carrier frequency automatically.
<b>Examples</b>	[SENSE]:DDEMOD:CARRIER:OFFSET:AUTO ON enables automatic detection of the carrier frequency.

## [SENSe]:DDEMod:FILTer:ALPHa

Sets or queries the filter factor ( $\alpha$ /BT) in the digital modulation analysis.

<b>Conditions</b>	Measurement views: General purpose digital modulation
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSE]:DDEMod:FILTer:ALPHa <value> [SENSe]:DDEMod:FILTer:ALPHa?
<b>Arguments</b>	<value>::=<NRF> specifies the filter factor. Range: 0.001 to 1.
<b>Examples</b>	SENSE:DDEMOD:FILTER:ALPHA 0.5 sets the filter factor to 0.5.

## [SENSe]:DDEMod:FILTer:MEASurement

Selects or queries the measurement filter in the digital modulation analysis.

<b>Conditions</b>	Measurement views: General purpose digital modulation
-------------------	---

**Group** Sense commands

**Syntax** [SENSE]:DDEMod:FILTer:MEASurement { OFF | RRCosine | RCOSine | GAUSSian | RECTangular | IS95TXEQ\_MEA | IS95TX\_MEA | C4FM\_P25 | USERx | UOTHer }  
[SENSE]:DDEMod:FILTer:MEASurement?

**Arguments** The following table lists the arguments.

**Table 2-36: Digital modulation measurement filter**

Argument	Measurement filter
OFF	No filter
RRCosine	Root Raised Cosine
RCOSine	Raised Cosine
GAUSSian	Gaussian
RECTangular	Rectangular
IS95TXEQ_MEA	IS95 receive filter for the transmitter configured with both the transmit filter and the phase equalizer.
IS95TX_MEA	IS95 receive filter for the transmitter configured with only the transmit filter.
C4FM_P25	C4FM-P25
USER1	User defined Measurement Filter 1
USER2	User defined Measurement Filter 2
USER3	User defined Measurement Filter 3
UOTHer	Other user defined Measurement Filter

**Examples** SENSE:DDEMOD:FILTER:MEASUREMENT RRCosine selects the Root Raised Cosine filter as the measurement filter.

## [SENSE]:DDEMod:FILTer:REFerence

Selects or queries the reference filter in the digital modulation analysis.

**Conditions** Measurement views: General purpose digital modulation

**Group** Sense commands

**Syntax** [SENSe]:DDEMod:FILTEr:REFEreNce { OFF | RCOSine | GAUSSian | RECTAngular | IS95REF | HSINe | SOQPSK\_MIL | SOQPSK\_ARTM | SBPSK\_MIL | USERx | UOTHer }  
[SENSe]:DDEMod:FILTEr:REFEreNce?

**Arguments** The following table lists the arguments.

**Table 2-37: Digital modulation reference filter**

Argument	Measurement filter
OFF	No filter
RCOSine	Raised Cosine
GAUSSian	Gaussian
RECTAngular	Rectangular
IS95REF	IS95 reference filter including the response of the transmit filter, the phase equalizer, and the receive (complementary) filter.
HSINe	Half Sine
SOQPSK_MIL	SOQPSK-MIL
SOQPSK_ARTM	SOQPSK-ARTM
SBPSK_MIL	SBPSK-MIL
USER1	User defined Measurement Filter 1
USER2	User defined Measurement Filter 2
USER3	User defined Measurement Filter 3
UOTHer	Other user defined Measurement Filter

**Examples** SENSE:DDEMOD:FILTEr:REFEreNce RCOSine selects the Raised Cosine filter as the reference filter.

## [SENSe]:DDEMod:FREQuency:DEViation

Sets or queries the frequency deviation in the digital modulation analysis. Programming a specified frequency deviation sets [SENSe]:DDEMod:FREQuency:DEViation:AUTO OFF.

This command is valid when [SENSe]:DDEMod:MODulation:TYPE is set to C4FM, FSK2, FSK4, FSK8, or FSK16.

**Conditions** Measurement views: General purpose digital modulation

**Group** Sense commands



<b>Syntax</b>	<code>[SENSe]:DDEMod:FREQuency:DEVIation &lt;value&gt;</code> <code>[SENSe]:DDEMod:FREQuency:DEVIation?</code>
<b>Arguments</b>	<code>&lt;value&gt;::=&lt;Nrf&gt;</code> sets the frequency deviation. Standard product range: 100 Hz to 40 MHz. Option 110 product range: 100 Hz to 110 MHz.
<b>Examples</b>	<code>SENSE:DDEMOD:FREQUENCY:DEVIATION 1MHZ</code> sets the frequency deviation to 1 MHz.

## [SENSe]:DDEMod:FREQuency:DEVIation:AUTO

Determines whether to detect automatically or set manually the frequency deviation used to determine the symbol values of an FSK or GFSK signal.

This command is valid when [\[SENSe\]:DDEMod:MODulation:TYPE](#) is set to C4FM, FSK2, FSK4, FSK8, or FSK16.

<b>Conditions</b>	Measurement views: General purpose digital modulation
<b>Group</b>	Sense commands
<b>Syntax</b>	<code>[SENSe]:DDEMod:FREQuency:DEVIation:AUTO { OFF   ON   0   1 }</code> <code>[SENSe]:DDEMod:FREQuency:DEVIation:AUTO?</code>
<b>Arguments</b>	ON or 1 automatically calculates the frequency deviation for the analysis range (default). OFF or 0 sets the frequency deviation using the <a href="#">[SENSe]:DDEMod:FREQuency:DEVIation</a> command.
<b>Examples</b>	<code>SENSE:DDEMOD:FREQUENCY:DEVIATION:AUTO ON</code> automatically calculates the frequency deviation.

## [SENSe]:DDEMod:MAGNitude:NORMAlize

Selects or queries the method for the magnitude normalization.

<b>Conditions</b>	Measurement views: General purpose digital modulation
-------------------	---

- Group** Sense commands
- Syntax** [SENSe]:DDEMod:MAGNitude:NORMALize { RSYMBOL | MSYMBOL }  
[SENSe]:DDEMod:MAGNitude:NORMALize?
- Arguments** RSYMBOL normalizes the magnitude with the RMS symbol magnitude.  
MSYMBOL normalizes the magnitude with the maximum symbol magnitude.
- Examples** SENSE:DDEMOD:MAGNITUDE:NORMALIZE RSYMBOL normalizes the magnitude with the RMS symbol magnitude.

## [SENSe]:DDEMod:MINDEX

Selects or queries the modulation index of a CPM signal. This command is valid when [SENSe]:DDEMod:MODulation:TYPE is set to CPM and [SENSe]:DDEMod:MINDEX:AUTO is set to OFF.

- Conditions** Measurement views: General purpose digital modulation
- Group** Sense commands
- Syntax** [SENSe]:DDEMod:MINDEX { 1 | 2 | 3 | 4 | 5 | 6 }  
[SENSe]:DDEMod:MINDEX?
- Arguments** The following table shows the arguments and modulation index.

### CPM modulation index

Argument	Modulation index
1	4/16, 5/16
2	5/16, 6/16
3	6/16, 7/16
4	7/16, 10/16
5	12/16, 13/16
6	8/16, 8/16

- Examples** SENSE:DDEMOD:MINDEX 1 selects the modulation index to “4/16, 5/16”.

## [SENSe]:DDEMod:MINDEX:AUTO

Determines whether to detect automatically or set manually the modulation index of a CPM signal. This command is valid when [\[SENSe\]:DDEMod:MODulation:TYPE](#) is set to CPM.

<b>Conditions</b>	Measurement views: General purpose digital modulation
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:DDEMod:MINDEX:AUTO { OFF   ON   0   1 } [SENSe]:DDEMod:MINDEX:AUTO
<b>Arguments</b>	ON or 1 automatically calculates the modulation index for the analysis range. OFF or 0 sets the modulation index using the <a href="#">[SENSe]:DDEMod:MINDEX</a> command.
<b>Examples</b>	SENSE:DDEMOD:MINDEX:AUTO ON automatically calculates the modulation index for the analysis range.

## [SENSe]:DDEMod:MODulation:TYPE

Selects or queries the modulation type in the digital modulation analysis.

<b>Conditions</b>	Measurement views: General purpose digital modulation
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:DDEMod:MODulation:TYPE { QPSK   PSK8   D8PSK   PIOVER2DBPSK   DQPSK   PIOVER4DQPSK   BPSK   OQPSK   QAM16   QAM32   QAM64   QAM128   QAM256   MSK   GFSK   FSK2   FSK4   FSK8   FSK16   CPM   SOQPSK   SBPSK   C4FM } [SENSe]:DDEMod:MODulation:TYPE?
<b>Arguments</b>	The following table lists the arguments and corresponding modulation type.

**Table 2-38: Modulation type**

Argument	Modulation type
QPSK	QPSK

**Table 2-38: Modulation type (cont.)**

<b>Argument</b>	<b>Modulation type</b>
PSK8	8PSK
D8PSK	D8PSK
PIOVER2DBPSK	$\pi/2$ DBPSK
DQPSK	DQPSK
PIOVER4DQPSK	$\pi/4$ QPSK
BPSK	BPSK
OQPSK	OQPSK
QAM16	16QAM
QAM32	32QAM
QAM64	64QAM
QAM128	128QAM
QAM256	256QAM
MSK	MSK
FSK2	FSK2
FSK4	FSK4
FSK8	FSK8
FSK16	FSK16
CPM	CPM
SOQPSK	SOQPSK
SBPSK	SBPSK
C4FM	C4FM

**Examples**     SENSE:DDEMOD:MODULATION:TYPE QPSK selects QPSK modulation system.

## [SENSe]:DDEMod:PRESet (No Query Form)

Presets the modulation analysis to a communication standard.

**Conditions**     Measurement views: General purpose digital modulation

**Group**     Sense commands

**Syntax**     [SENSe]:DDEMod:PRESet <standard\_name>

**Related Commands**     [SENSe]:DDEMod:MODulation:TYPE

**Arguments** The following table lists the preset standard names with their modulation types and settings.

**Table 2-39: Modulation Presets**

Preset Name	Modulation type	Settings
"802.15.4"	OQPSK	Symbol rate: 1 MHz Meas Filter: None Ref Filter: Half sine Filter Param: None Symbol Pt Location: NA Remove Q offset: not checked
"SBPSK-MIL"	SBPSK	Symbol rate: 2.4 kHz Meas Filter: None Ref Filter: SBPSK-MIL Filter Param: 0.5 Symbol Pt Location: NA Remove Q offset: NA
"SOQPSK-MIL"	SOQPSK	Symbol rate: 2.4 kHz Meas Filter: None Ref Filter: SOQPSK-MIL Filter Param: 0.5 Symbol Pt Location: Center Remove Q offset: checked
"CPM-MIL"	CPM	Symbol rate: 19.2 KHz Meas Filter: None Ref Filter: None Filter Param: None Symbol Pt Location: NA Remove Q offset: NA
"SOQPSK-ARTM Tier 1"	SOQPSK	Symbol rate: 2.5 MHz Meas Filter: None Ref Filter: SOQPSK-ARTM Filter Param: None Symbol Pt Location: Center Remove Q offset: checked

**Table 2-39: Modulation Presets (cont.)**

Preset Name	Modulation type	Settings
"Project25 Phase I"	C4FM	Symbol rate: 4.8 kHz
		Meas Filter: C4FM-P25
		Ref Filter: Raised cosine
		Filter Param: 0.2
		Symbol Pt Location: NA
		Remove Q offset: NA
"CDMA2000-Base"	QPSK	Symbol rate: 1.2288 MHz
		Meas Filter: IS95 TXEQ_MEA
		Ref Filter: IS95 REF
		Filter Param: None
		Symbol Pt Location: NA
		Remove Q offset: NA
"W-CDMA"	QPSK	Symbol rate: 3.84 MHz
		Meas Filter: Root raised cosine
		Ref Filter: Raised cosine
		Filter Param: 0.22
		Symbol Pt Location: NA
		Remove Q offset: NA

In addition to the specific settings listed in the table, the following general settings are also made when you load any of the defined presets.

Setting	Value
Points/symbol	4
Burst detection mode	Off
Burst detection threshold	-10 dBc
Analysis offset	Auto
Analysis length	Auto
Frequency offset	Auto
Measurement BW	Auto
Frequency deviation	Auto
Modulation index	Auto

**Returns**

**Examples**

[SENSE]:DDEMOD:PRESET "802.15.4" sets demodulation to the standard OQPSK modulation.

## [SENSe]:DDEMod:SRATe

Sets or queries the symbol rate in the digital modulation analysis.

<b>Conditions</b>	Measurement views: General purpose digital modulation
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:DDEMod:SRATe <value> [SENSe]:DDEMod:SRATe?
<b>Arguments</b>	<value> ::= <NRf> specifies the symbol rate. Standard product range: 100 Hz to 40 MHz. Option 110 product range: 100 Hz to 110 MHz.
<b>Examples</b>	SENSE:DDEMOD:SRATE 21.0E3 sets the symbol rate to 21 kHz.

## [SENSe]:DDEMod:SWAP:IQ

Determines whether or not to exchange I and Q data before demodulating.

<b>Conditions</b>	Measurement views: General purpose digital modulation
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:DDEMod:SWAP:IQ { OFF   ON   0   1 } [SENSe]:DDEMod:SWAP:IQ?
<b>Arguments</b>	OFF or 0 uses I and Q data as they are. ON or 1 exchanges I and Q data.
<b>Examples</b>	SENSE:DDEMOD:SWAP:IQ ON exchanges I and Q data before demodulating.

## [SENSe]:DDEMod:SYMBOL:HSSHift

Selects or queries the Q data half-symbol shift for OQPSK and SOQPSK signals.

<b>Conditions</b>	Measurement views: General purpose digital modulation
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:DDEMod:SYMBOL:HSSHift { OFF   ON   0   1 } [SENSe]:DDEMod:SYMBOL:HSSHift?
<b>Related Commands</b>	[SENSe]:DDEMod:MODulation:TYPE
<b>Arguments</b>	OFF or 0 the Q offset shift is not applied. ON or 1 the Q offset shift is applied.
<b>Examples</b>	DDEMod:SYMBOL:HSSHift ON the Q offset is applied.

### [SENSe]:DDEMod:SYMBOL:MAP:SOURce? (Query Only)

Queries the user symbol map.

<b>Conditions</b>	Measurement views: General purpose digital modulation
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:DDEMod:SYMBOL:MAP:SOURce?
<b>Arguments</b>	None.
<b>Examples</b>	SENSE:DDEMOD:SYMBOL:MAP:SOURCE? returns the symbol map filename.

### [SENSe]:DDEMod:SYMBOL:MAP[:STATe]

Determines whether or not to use the user symbol map.

<b>Conditions</b>	Measurement views: General purpose digital modulation
<b>Group</b>	Sense commands



**Syntax** [SENSe]:DDEMod:SYMBol:MAP[:STATe] { OFF | ON | 0 | 1 }  
[SENSe]:DDEMod:SYMBol:MAP[:STATe]?

**Related Commands** [\[SENSe\]:DDEMod:SYMBol:MAP:SOURce?](#)

**Arguments** OFF or 0 disables the user symbol map.  
ON or 1 enables the user symbol map.

**Examples** SENSE:DDEMOD:SYMBOL:MAP:STATE ON enables the user symbol map.

## [SENSe]:DDEMod:SYMBol:PLOT:POSition

Sets or queries the symbol point location on an SOQPSK waveform.

**Conditions** Effective only on an SOQPSK waveform and on any general purpose digital demodulation views except Signal Quality and Symbol Table.

**Group** Sense commands

**Syntax** [SENSe]:DDEMod:SYMBol:PLOT:POSition { EDGe | MIDDle }  
[SENSe]:DDEMod:SYMBol:PLOT:POSition?

**Related Commands**

**Arguments** EDGe sets the symbol location at the edge of the eye opening.  
MIDDle sets the symbol location at the middle of the eye opening.

**Examples** [SENSE]:DDEMOD:SYMBOL:PLOT:POSITION EDGE sets the symbol location the edge of the eye opening.

## [SENSe]:DDEMod:SYMBol:POINts

Selects or queries the number of points per symbol (how many points to use between symbols when connecting the dots).

---

**NOTE.** 1 is not valid for the GMSK modulation.

*In the constellation view, select VECTors using the [TRACe:CONSt:MODE](#) command first to change Points/Symbol.*

---

**Conditions** Measurement views: Constellation, EVM versus Time, Magnitude error versus Time, Phase error versus Time, Freq Dev versus Time, Demod I&Q versus Time.

**Group** Sense commands

**Syntax** [SENSE]:DDEMod:SYMBOL:POINTS { ONE | TWO | FOUR | EIGHT }  
[SENSE]:DDEMod:SYMBOL:POINTS?

**Arguments** ONE, TWO, FOUR, and EIGHT represent the number of points per symbol. The following table lists the conditions of use.

Argument	Modulation type supported
ONE	All but SOQPSK, OQPSK, SBPSK
TWO	All but SOQPSK
FOUR	All
EIGHT	All

**Examples** SENSE:DDEMOD:SYMBOL:POINTS FOUR sets the number of points per symbol to four.

## [SENSE]:DDEMod:SYMBOL:RATE:SEARCH

Determines whether to enable a symbol rate search. This command is valid when the demodulation type is set to FSK2, FSK4, FSK8 or FSK16.

**Conditions** Measurement views: General purpose digital modulation

**Group** Sense commands

**Syntax** [SENSE]:DDEMod:SYMBOL:RATE:SEARCH { OFF | ON | 0 | 1 }

**Related Commands** [\[SENSE\]:DDEMod:MODulation:TYPE](#)

**Arguments** OFF or 0 disables the search.  
ON or 1 enables the search.

**Examples** [SENSE]:DDEMOD:SYMBOL:RATE:SEARCH? ON returns the modulation enables the symbol rate search.

## [SENSe]:DDEMod:SYNCh:WORD

Determines whether to enable the synchronization word.

**Conditions** Measurement views: General purpose digital modulation

**Group** Sense commands

**Syntax** [SENSe]:DDEMod:SYNCh:WORD { OFF | ON | 0 | 1 }  
[SENSe]:DDEMod:SYNCh:WORD?

**Related Commands** [\[SENSe\]:DDEMod:SYNCh:WORD:SYMBOL](#)

**Arguments** OFF or 0 disables the synchronization word.

ON or 1 enables the synchronization word.

**Examples** SENSE:DDEMOD:SYNCH:WORD ON enables the synchronization word.

## [SENSe]:DDEMod:SYNCh:WORD:SYMBOL

Sets or queries the synchronization word when [\[SENSe\]:DDEMod:SYNCh:WORD](#) is ON. The word depends on the modulation type selected by the [\[SENSe\]:DDEMod:MODulation:TYPE](#) command.

**Conditions** Measurement views: General purpose digital modulation

**Group** Sense commands

**Syntax** [SENSe]:DDEMod:SYNCh:WORD:SYMBOL <block>  
[SENSe]:DDEMod:SYNCh:WORD:SYMBOL?

**Arguments** <block> ::= #<num\_digit><num\_byte><sym(1)><sym(2)>...<sym(n)>

Where  
<num\_digit> is the number of digits in <num\_byte>.

<num\_byte> is the number of bytes of data that follow.  
 <sym(n)> is the n<sup>th</sup> symbol value of the sync word. 32-bit integer.  
 n: Max 256.

**Examples** SENSE:DDEMOD:SYNCH:WORD:SYMBOL #216xxxx (4 symbols) sets a sync word composed of four symbols.

## [SENSe]:DDEMod:TIME:UNITs

Selects or queries the fundamental unit of time.

**Conditions** Measurement views: General purpose digital modulation

**Group** Sense commands

**Syntax** [SENSe]:DDEMod:TIME:UNITs { SECONDS | SYMBOLs }  
 [SENSe]:DDEMod:TIME:UNITs?

**Arguments** SECONDS specifies the fundamental unit of time as seconds.  
 SYMBOLs specifies the fundamental unit of time as symbols.

**Examples** SENSE:DDEMOD:TIME:UNITs SECONDS specifies the fundamental unit of time as seconds.

## [SENSe]:DPSA:AUDio:DEMod:GAIN

Sets or queries the audio gain.

---

**NOTE.** *The sound level is also affected by the Windows volume control.*

---

**Conditions** Measurement views: DPX spectrum

**Group** Sense commands

**Syntax** [SENSe]:DPSA:AUDio:DEMod:GAIN <value>  
 [SENSe]:DPSA:AUDio:DEMod:GAIN?

**Arguments** <value>::=<NR1> specifies the audio gain. Range: 0 to 15 (integer).

**Examples** SENSE:DPSA:AUDIO:DEMOD:GAIN 7 sets the audio gain to 7.

## [SENSE]:DPSA:AUDIO:DEMOD:RXBWidth

Sets or queries the receiver bandwidth in the audio demodulation.

**Conditions** Measurement views: DPX spectrum

**Group** Sense commands

**Syntax** [SENSE]:DPSA:AUDIO:DEMOD:RXBWidth <value>  
[SENSE]:DPSA:AUDIO:DEMOD:RXBWidth?

**Arguments** <value>::=<NRf> specifies the receiver bandwidth in the audio demodulation. Range: 1 kHz to 500 kHz.

**Examples** SENSE:DPSA:AUDIO:DEMOD:RXBWIDTH 30kHz sets the receiver bandwidth to 30 kHz.

## [SENSE]:DPSA:AUDIO:DEMOD:RXFrequency? (Query Only)

Returns the receiver frequency in the audio demodulation. The frequency depends on the setting of the [SENSE]:DPSA:AUDIO:DEMOD:TUNE command.

**Conditions** Measurement views: DPX spectrum

**Group** Sense commands

**Syntax** [SENSE]:DPSA:AUDIO:DEMOD:RXFrequency?

**Arguments** None

**Returns** <frequency>::=<NRf> is the receiver frequency in the audio demodulation.

**Examples** SENSE:DPSA:AUDIO:DEM0D:RXFREQUENCY? might return 80.3E+6, indicating that the receiver frequency is 80.3 MHz.

## [SENSe]:DPSA:AUDio:DEMod:STATe

Determines whether to enable the audio demodulation.

**Conditions** Measurement views: DPX spectrum

**Group** Sense commands

**Syntax** [SENSe]:DPSA:AUDio:DEMod:STATe { OFF | ON | 0 | 1 }  
[SENSe]:DPSA:AUDio:DEMod:STATe?

**Arguments** OFF or 0 disables the audio demodulation.  
ON or 1 enables the audio demodulation.

**Examples** SENSE:DPSA:AUDIO:DEM0D:STATe ON enables the audio demodulation.

## [SENSe]:DPSA:AUDio:DEMod:TUNE

Selects or queries how to determine the tuning frequency in the audio demodulation.

**Conditions** Measurement views: DPX spectrum

**Group** Sense commands

**Syntax** [SENSe]:DPSA:AUDio:DEMod:TUNE { MR | MARK1 | MARK2 | MARK3 | MARK4 | SMARKer | FREQcontro1 }  
[SENSe]:DPSA:AUDio:DEMod:TUNE?

**Arguments** The following table lists the arguments.

**Table 2-40: Frequency tuning**

Argument	Tune with
MR	Reference marker (MR)

Table 2-40: Frequency tuning (cont.)

Argument	Tune with
MARK1	Marker 1 (M1)
MARK2	Marker 2 (M2)
MARK3	Marker 3 (M3)
MARK4	Marker 4 (M4)
SMARker	Selected marker
FREQcontrol	Center frequency setting

**Examples**     `SENSE:DPSA:AUDIO:DEM0D:TUNE MARK1` sets the tuning frequency to the value at Marker 1.

## [SENSe]:DPSA:AUDio:DEMod:TYPE

Selects or queries the modulation type in the audio demodulation.

**Conditions**     Measurement views: DPX spectrum

**Group**     Sense commands

**Syntax**     `[SENSe]:DPSA:AUDio:DEMod:TYPE { AM | FM }`  
`[SENSe]:DPSA:AUDio:DEMod:TYPE?`

**Arguments**     AM selects the AM (Amplitude Modulation).  
 FM selects the FM (Frequency Modulation).

**Examples**     `SENSE:DPSA:AUDIO:DEM0D:TYPE FM` selects FM in the audio demodulation.

## [SENSe]:DPSA:{BANDwidth|BWIDth}:ACTual? (Query Only)

Queries the actual bandwidth whether set automatically or manually.

**Conditions**     Measurement views: DPX spectrum

**Group**     Sense commands

**Syntax** [SENSE]:DPSA:{BANDwidth|BWIDth}:ACTual?

**Related Commands** [SENSE]:DPSA:{BANDwidth|BWIDth}:OPTimization

**Arguments** None

**Examples** SENSE:DPSA:BANDWIDTH:ACTUAL? returns the RBW as a percentage of the Span.

## [SENSE]:DPSA:{BANDwidth|BWIDth}:OPTimization

Sets or queries the RF & IF Optimization for the Spectrum display and the Option 200 DPX Spectrum displays. The settings optimize the gain and bandwidth in the RF and IF stages. resolution bandwidth (RBW) in the DPX spectrum measurement.

**Conditions** Measurement views: DPX spectrum

**Group** Sense commands

**Syntax** [SENSE]:DPSA:{BANDwidth|BWIDth}:OPTimization { AUTO | MINTime | MINNoise }  
[SENSE]:DPSA:{BANDwidth|BWIDth}:OPTimization?

### Related Commands

**Arguments** AUTO optimizes the gain and bandwidth in the RF and IF stages of the RF input circuits.

MINTime optimizes the gain and bandwidth to minimize the sweep time.

MINNoise optimizes the gain and bandwidth to minimize noise.

**Examples** SENSE:DPSA:BANDWIDTH:OPTimization AUTO automatically sets RBW as a percentage of the Span.

## [SENSE]:DPSA:{BANDwidth|BWIDth}[:RESolution]:AUTO

Determines whether to set the resolution bandwidth (RBW) automatically or manually in the DPX spectrum measurement.



<b>Conditions</b>	Measurement views: DPX spectrum
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSE]:DPSA:{BANDwidth BWIDth}[:RESolution]:AUTO { OFF   ON   0   1 } [SENSE]:DPSA:{BANDwidth BWIDth}[:RESolution]:AUTO?
<b>Arguments</b>	OFF or 0 specifies that the resolution bandwidth is set manually using the [SENSE]:DPSA:{BANDwidth BWIDth}:ACTual? command. ON or 1 specifies that the resolution bandwidth is set automatically.
<b>Examples</b>	SENSE:DPSA:BANDWIDTH:AUTO ON sets the resolution bandwidth automatically.

## [SENSE]:DPSA:CLEAr:RESuLts (No Query Form)

Restarts multi-trace functions (Average and Max/Min Hold).

<b>Conditions</b>	Measurement views: DPX spectrum
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSE]:DPSA:CLEAr:RESuLts
<b>Arguments</b>	None
<b>Examples</b>	SENSE:DPSA:CLEAR:RESULTS restarts multi-trace functions.

## [SENSE]:DPSA:COLOr

Selects or queries the color palette of three-dimensional graphs.

<b>Conditions</b>	Measurement views: DPX spectrum
<b>Group</b>	Sense commands

**Syntax** [SENSe]:DPSA:COLOr { RED | GREEn | BLUe | CYAN | BCYan | YELLow | MAGenta | GRAY | TEMPerature | SPECTra }  
[SENSe]:DPSA:COLOr?

**Arguments** The following table lists the arguments.

**Table 2-41: Color palette for DPX spectrum**

Argument	Palette
RED	Red
GREEn	Green
BLUe	Blue
CYAN	Cyan
BCYan	Binary cyan
YELLow	Yellow
MAGenta	Magenta
GRAY	Gray
TEMPerature	Temperature
SPECTral	Spectral

**Examples** SENSE:DPSA:COLOR TEMPerature selects the temperature color palette.

## [SENSe]:DPSA:COLOr:MAXimum

Sets or queries the maximum value of the color axis in the DPX spectrum measurement.

**Conditions** Measurement views: DPX spectrum

**Group** Sense commands

**Syntax** [SENSe]:DPSA:COLOr:MAXimum <value>  
[SENSe]:DPSA:COLOr:MAXimum?

**Arguments** <value>::=<Nrf> specifies the maximum value of the color axis.  
Range: The minimum value to 100%.

The minimum value is set using the [SENSe]:DPSA:POINts:COUNT command.

**Examples**    `SENSE:DPSA:COLOR:MAXIMUM 90` sets the maximum value of the color axis to 90%.

## [SENSe]:DPSA:COLor:MINimum

Sets or queries the minimum value of the color axis in the DPX spectrum measurement.

**Conditions**    Measurement views: DPX spectrum

**Group**    Sense commands

**Syntax**    `[SENSe]:DPSA:COLor:MINimum <value>`  
`[SENSe]:DPSA:COLor:MINimum?`

**Arguments**    `<value> ::= <Nrf>` specifies the minimum value of the color axis.  
 Range: 0% to the maximum value.

The maximum value is set using the [\[SENSe\]:DPSA:COLor:MAXimum](#) command.

**Examples**    `SENSE:DPSA:COLOR:MINIMUM 10` sets the minimum value of the color axis to 10%.

## [SENSe]:DPSA:DWELl

Sets or queries the value of the Dwell time for the DPX spectrum measurement.

**Conditions**    Measurement views: DPX spectrum

**Group**    Sense commands

**Syntax**    `[SENSe]:DPSA:DWELl <value>`  
`[SENSe]:DPSA:DWELl?`

**Arguments**    `<value> ::= <Nrf>` specifies the time the DPX sweep remains in a frequency segment collecting data and updating the bitmap and traces before moving on to the next higher frequency segment.

Range: 50 ms to 100 s per frequency segment.

**Examples**     `SENSE:DPSA:DWEL1 100ms` sets the dwell value for sweeps to 100 ms.

## [SENSe]:DPSA:DWEL1:AUTO

Sets the value of the Dwell time automatically or queries for the current value.

**Conditions**     Measurement views: DPX spectrum

**Group**            Sense commands

**Syntax**           `[SENSe]:DPSA:DWEL1:AUTO { OFF | ON | 0 | 1 }`  
`[SENSe]:DPSA:DWEL1:AUTO?`

**Related Commands**     [\[SENSe\]:DPSA:DWEL1](#)

**Arguments**        OFF or 0 specifies that the dwell is set manually.  
                           ON or 1 specifies that the dwell is set automatically.

**Examples**        `SENSE:DPSA:DWEL1:AUTO ON` sets the dwell value automatically for sweeps.

## [SENSe]:DPSA:FREQuency:CENTer

Sets or queries the center frequency in the DPX spectrum measurement.

---

**NOTE.** *The center, start and stop frequencies are set interlocking each other with the following relationships: (start frequency) = (center frequency) - (span)/2 and (stop frequency) = (center frequency) + (span)/2.*

---

**Conditions**        Measurement views: DPX spectrum

**Group**            Sense commands

**Syntax**           `[SENSe]:DPSA:FREQuency:CENTer <value>`  
`[SENSe]:DPSA:FREQuency:CENTer?`

**Related Commands**     [\[SENSe\]:DPSA:FREQuency:START](#), [\[SENSe\]:DPSA:FREQuency:STOP](#)

**Arguments** <value>::=<Nrf> specifies the center frequency.  
Range: 0 Hz to 6.2 GHz (RSA6106A) / 14 GHz (RSA6114A).

**Examples** SENSE:DPSA:FREQUENCY:CENTER 7.5GHZ sets the center frequency to 7.5 GHz.

## [SENSe]:DPSA:FREQuency:SPAN

Sets or queries the frequency span in the DPX spectrum measurement.

**Conditions** Measurement views: DPX spectrum

**Group** Sense commands

**Syntax** [SENSe]:DPSA:FREQuency:SPAN <value>  
[SENSe]:DPSA:FREQuency:SPAN?

**Arguments** <value>::=<Nrf> is the frequency span.  
Range: 10 Hz to 40 MHz (Standard) / 110 MHz (Option 110)

**Examples** SENSE:DPSA:FREQUENCY:SPAN 20MHZ sets the span to 20 MHz.

## [SENSe]:DPSA:FREQuency:SPAN:{BANDwidth|BWIDth}[:RESolution]:RATio

Determines whether to set the resolution bandwidth (RBW) automatically or manually in the DPX spectrum measurement.

**Conditions** Measurement views: DPX spectrum

**Group** Sense commands

**Syntax** [SENSe]:DPSA:FREQuency:SPAN:{BANDwidth|BWIDth}[:RESolution]:  
RATio <value>  
[SENSe]:DPSA:FREQuency:SPAN:{BANDwidth|BWIDth}[:RESolution]:  
RATio?

**Related Commands** [SENSe]:DPSA:{BANDwidth|BWIDth}[:RESolution]:AUTO

**Arguments** <value>::=<NRF> is used to calculate the RBW.

**Examples** SENSE:DPSA:FREQUENCY:SPAN:BANDWIDTH:RATIO 100 the ratio of 100 is used to set the resolution bandwidth when [SENSE]:DPSA:{BANDwidth|BWIDth}[:RESolution]:AUTO is set to ON.

## [SENSE]:DPSA:FREQUENCY:START

Sets or queries the measurement start frequency (left edge on the graph) in the DPX spectrum measurement.

The center, start and stop frequencies are set interlocking each other. Refer to the [SENSE]:DPSA:FREQUENCY:CENTER command.

**Conditions** Measurement views: DPX spectrum

**Group** Sense commands

**Syntax** [SENSE]:DPSA:FREQUENCY:START <value>  
[SENSE]:DPSA:FREQUENCY:START?

**Related Commands** [SENSE]:DPSA:FREQUENCY:STOP

**Arguments** <value>::=<NRF> is the measurement start frequency.  
Range: (center frequency) ± (span)/2.

**Examples** SENSE:DPSA:FREQUENCY:START 6.95GHZ sets the start frequency to 6.95 GHz.

## [SENSE]:DPSA:FREQUENCY:STEP

Sets or queries the frequency step size (the amount per press by which the up or down key changes the setting value). Programming a specified step size sets [SENSE]:DPSA:FREQUENCY:STEP:AUTO OFF.

**Conditions** Measurement views: DPX spectrum

**Group** Sense commands

**Syntax**     [SENSe]:DPSA:FREQuency:STEP <value>  
                   [SENSe]:DPSA:FREQuency:STEP?

**Related Commands**   [\[SENSe\]:DPSA:FREQuency:STEP:AUTO](#)

**Arguments**     <value> ::= <Nrf> specifies the frequency step size.  
                   Range: 0 Hz to 6.2 GHz (RSA6106A) / 14 GHz (RSA6114A).

**Examples**       SENSE:DPSA:FREQUENCY:STEP 1.5kHz sets the step size to 1.5 kHz.

## **[SENSe]:DPSA:FREQuency:STEP:AUTO**

Determines whether to set the frequency step size automatically or manually.

**Conditions**     Measurement views: DPX spectrum

**Group**          Sense commands

**Syntax**         [SENSe]:DPSA:FREQuency:STEP:AUTO { OFF | ON | 0 | 1 }  
                   [SENSe]:DPSA:FREQuency:STEP:AUTO?

**Arguments**     OFF or 0 specifies that the frequency step size is set manually using the  
                   [\[SENSe\]:DPSA:FREQuency:STEP](#) command.  
                   ON or 1 specifies that the frequency step size is set automatically.

**Examples**       SENSE:DPSA:BANDWIDTH:AUTO ON sets the frequency step size automatically.

## **[SENSe]:DPSA:FREQuency:STOP**

Sets or queries the measurement stop frequency (right edge of the graph) in the DPX spectrum measurement.

The center, start and stop frequencies are set interlocking each other. Refer to the [\[SENSe\]:DPSA:FREQuency:CENTer](#) command.

**Conditions**     Measurement views: DPX spectrum

**Group**          Sense commands

**Syntax** [SENSe]:DPSA:FREQuency:STOP <value>  
[SENSe]:DPSA:FREQuency:STOP?

**Related Commands** [\[SENSe\]:DPSA:FREQuency:START](#)

**Arguments** <value>::=<Nrf> is the measurement stop frequency.  
Range: (center frequency) ± (span)/2.

**Examples** SENSE:DPSA:FREQUENCY:STOP 7.05GHZ sets the stop frequency to 7.05 GHz.

## [SENSe]:DPSA:POINts:COUNT

Sets the number of trace points acquired for the DPX spectrum display.

**Conditions** Measurement views: DPX spectrum

**Group** Sense commands

**Syntax** [SENSe]:DPSA:POINts:COUNT { P801 | P2401 | P4001 | P10401 }  
[SENSe]:DPSA:POINts:COUNT?

**Arguments** P801 sets the number of sample points to 801.  
P2401 sets the number of sample points to 2401.  
P4001 sets the number of sample points to 4001.  
P8001 sets the number of sample points to 8001.  
P10401 sets the number of sample points to 10401.

**Examples** SENSE:DPSA:POINts:COUNT P2401 sets the number of trace points to acquire for the DPX spectrum display.

## [SENSe]:{FM|PM}:BURSt:THReshold

Sets or queries the threshold level above which the input signal is determined to be a burst in the FM/PM measurement. The burst detected first is used for the measurement.

**Conditions** Measurement views: FM, PM



<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSE]:{FM PM}:BURSt:THRESHold <value> [SENSE]:{FM PM}:BURSt:THRESHold?
<b>Arguments</b>	<value> ::= <NRF> specifies the threshold level. Range: -100.0 to -10.0 dB.
<b>Examples</b>	SENSE:FM:BURST:THRESHOLD -10 sets the threshold level to -10 dB in the FM measurement.

## [SENSE]:{FM|PM}:FREQUENCY:OFFSet

Sets or queries the carrier frequency offset in the FM/PM measurement.

<b>Conditions</b>	Measurement views: FM, PM
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSE]:{FM PM}:FREQUENCY:OFFSet <value> [SENSE]:{FM PM}:FREQUENCY:OFFSet?
<b>Arguments</b>	<value> ::= <NRF> specifies the frequency offset from the center frequency. Range: $-(\text{MeasBW} * 1.1) / 2$ to $+(\text{MeasBW} * 1.1) / 2$ where MeasBW is set by the command [SENSE]:{AM FM PM};{BANDwidth BWIDth}:MEASurement.
<b>Examples</b>	SENSE:FM:FREQUENCY:OFFSET 10MHZ sets the carrier frequency offset to 10 MHz.

## [SENSE]:{FM|PM}:FREQUENCY:OFFSet:MARKer (No Query Form)

Sets the frequency offset from selected marker location in the FM/PM measurement.

Sets the frequency offset from the selected marker location in the FM measurement.

Sets the frequency offset from the selected delta marker location in the PM measurement.

<b>Conditions</b>	Measurement views: FM, PM
-------------------	---------------------------

<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:{FM PM}:FREQUency:OFFSet:MARKer { OFF   ON   0   1 } [SENSe]:{FM PM}:FREQUency:OFFSet:MARKer?
<b>Arguments</b>	OFF or 0 specifies that the frequency offset is not set from the selected Marker position. None. ON or 1 specifies that the frequency offset is set from the selected Marker position.
<b>Examples</b>	SENSE:FM:FREQUENCY:OFFSET:MARKER ON sets frequency offset from the selected Marker position.

## [SENSe]:{FM|PM}:FREQUency:SEARch:AUTO

Determines whether to detect the carrier frequency automatically or manually in the FM/PM measurements.

<b>Conditions</b>	Measurement views: FM, PM
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:{FM PM}:FREQUency:SEARch:AUTO { OFF   ON   0   1 } [SENSe]:{FM PM}:FREQUency:SEARch:AUTO?
<b>Arguments</b>	OFF or 0 specifies that the carrier frequency is set manually. Use the command [SENSe]:{FM PM}:FREQUency:OFFSet to set the carrier offset frequency. ON or 1 specifies that the carrier frequency is detected automatically.
<b>Examples</b>	SENSE:FM:FREQUENCY:SEARCH:AUTO ON specifies that the carrier frequency is detected automatically.

## [SENSe]:FVTime:CLEAr:RESults (No Query Form)

Restarts multi-trace functions (Average and Max/Min Hold).

<b>Conditions</b>	Measurement views: Frequency versus Time
-------------------	--

<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSE]:FVTime:CLEAR:RESULTS
<b>Arguments</b>	None
<b>Examples</b>	SENSE:FVTIME:CLEAR:RESULTS restarts multi-trace functions.

## [SENSE]:FVTime:FREQUENCY:CENTER

Sets or queries the center frequency in the Frequency versus Time measurement.

---

**NOTE.** *The center, start and stop frequencies are set interlocking each other with the following relationships: (start frequency) = (center frequency) - (span)/2 and (stop frequency) = (center frequency) + (span)/2.*

---

<b>Conditions</b>	Measurement views: Frequency versus Time
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSE]:FVTime:FREQUENCY:CENTER <value> [SENSE]:FVTime:FREQUENCY:CENTER?
<b>Related Commands</b>	[SENSE]:FVTime:FREQUENCY:START, [SENSE]:FVTime:FREQUENCY:STOP
<b>Arguments</b>	<value> ::= <NRF> specifies the center frequency. Range: 0 Hz to 6.2 GHz (RSA6106A) / 14 GHz (RSA6114A).
<b>Examples</b>	SENSE:FVTIME:FREQUENCY:CENTER 7.5GHZ sets the center frequency to 7.5 GHz.

## [SENSE]:FVTime:FREQUENCY:SPAN

Sets or queries the frequency span in the Frequency versus Time measurement.

<b>Conditions</b>	Measurement views: Frequency versus Time
-------------------	--

<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:FVTime:FREQuency:SPAN <value> [SENSe]:FVTime:FREQuency:SPAN?
<b>Arguments</b>	<value>::=<Nrf> is the frequency span. Range: 10 Hz to 40 MHz (Standard) / 110 MHz (Option 110)
<b>Examples</b>	SENSE:FVTIME:FREQUENCY:SPAN 20MHZ sets the span to 20 MHz.

## [SENSe]:FVTime:FREQuency:STARt

Sets or queries the measurement start frequency (left edge on the graph) in the Frequency versus Time measurement.

The center, start and stop frequencies are set interlocking each other. Refer to the [\[SENSe\]:FVTime:FREQuency:CENTer](#) command.

<b>Conditions</b>	Measurement views: Frequency versus Time
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:FVTime:FREQuency:STARt <value> [SENSe]:FVTime:FREQuency:STARt?
<b>Related Commands</b>	<a href="#">[SENSe]:FVTime:FREQuency:STOP</a>
<b>Arguments</b>	<value>::=<Nrf> is the measurement start frequency. Range: (center frequency) ± (span)/2.
<b>Examples</b>	SENSE:FVTIME:FREQUENCY:STARt 6.95GHZ sets the start frequency to 6.95 GHz.

## [SENSe]:FVTime:FREQuency:STEP

Sets or queries the frequency step size (the amount per press by which the up or down key changes the setting value). Programming a specified step size sets [\[SENSe\]:FVTime:FREQuency:STEP:AUTO](#) OFF.

<b>Conditions</b>	Measurement views: Frequency versus Time
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:FVTime:FREQUENCY:STEP <value> [SENSe]:FVTime:FREQUENCY:STEP?
<b>Related Commands</b>	<a href="#">[SENSe]:FVTime:FREQUENCY:STEP:AUTO</a>
<b>Arguments</b>	<value> ::= <NRf> specifies the frequency step size. Range: 0 Hz to 6.2 GHz (RSA6106A) / 14 GHz (RSA6114A).
<b>Examples</b>	SENSE:FVTIME:FREQUENCY:STEP 1.5kHz sets the step size to 1.5 kHz.

## [SENSe]:FVTime:FREQUENCY:STEP:AUTO

Determines whether to set the frequency step size automatically or manually.

<b>Conditions</b>	Measurement views: Frequency versus Time
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:FVTime:FREQUENCY:STEP:AUTO { OFF   ON   0   1 } [SENSe]:FVTime:FREQUENCY:STEP:AUTO?
<b>Arguments</b>	OFF or 0 specifies that the frequency step size is set manually using the <a href="#">[SENSe]:FVTime:FREQUENCY:STEP</a> command. ON or 1 specifies that the frequency step size is set automatically.
<b>Examples</b>	SENSE:FVTIME:BANDWIDTH:AUTO ON sets the frequency step size automatically.

## [SENSe]:FVTime:FREQUENCY:STOP

Sets or queries the measurement stop frequency (right edge of the graph) in the Frequency versus Time measurement.

The center, start and stop frequencies are set interlocking each other. Refer to the [\[SENSe\]:FVTime:FREQUENCY:CENTer](#) command.

<b>Conditions</b>	Measurement views: Frequency versus Time
<b>Group</b>	Sense commands
<b>Syntax</b>	<code>[SENSe]:FVTime:FREQUENCY:STOP &lt;value&gt;</code> <code>[SENSe]:FVTime:FREQUENCY:STOP?</code>
<b>Related Commands</b>	<a href="#">[SENSe]:FVTime:FREQUENCY:START</a>
<b>Arguments</b>	<code>&lt;value&gt;::=&lt;Nrf&gt;</code> is the measurement stop frequency. Range: (center frequency) ± (span)/2.
<b>Examples</b>	<code>SENSE:FVTIME:FREQUENCY:STOP 7.05GHZ</code> sets the stop frequency to 7.05 GHz.

## [SENSe]:FVTime:MAXTracepoints

Selects or queries the maximum trace points in the Frequency versus Time measurement.

<b>Conditions</b>	Measurement views: Frequency versus Time
<b>Group</b>	Sense commands
<b>Syntax</b>	<code>[SENSe]:FVTime:MAXTracepoints { ONEK   TENK   HUNDredk   NEVERdecimate }</code> <code>[SENSe]:FVTime:MAXTracepoints?</code>
<b>Arguments</b>	ONEK sets the maximum trace points to 1 k. TENK sets the maximum trace points to 10 k. HUNDredk sets the maximum trace points to 100 k. NEVERdecimate never decimates the trace points.
<b>Examples</b>	<code>SENSE:FVTIME:MAXTRACEPOINTS TENK</code> sets the maximum trace points to 10 k.

## [SENSE]:IQVTime:CLEar:RESults (No Query Form)

Restarts multi-trace functions (Average and Max/Min Hold).

<b>Conditions</b>	Measurement views: RF I&Q versus Time
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSE]:IQVTime:CLEar:RESults
<b>Arguments</b>	None
<b>Examples</b>	SENSE:IQVTIME:CLEAR:RESULTS restarts multi-trace functions.

## [SENSE]:IQVTime:FREQuency:CENTer

Sets or queries the center frequency in the RF I&Q versus Time measurement.

---

**NOTE.** *The center, start and stop frequencies are set interlocking each other with the following relationships: (start frequency) = (center frequency) - (span)/2 and (stop frequency) = (center frequency) + (span)/2.*

---

<b>Conditions</b>	Measurement views: RF I&Q versus Time
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSE]:IQVTime:FREQuency:CENTer <value> [SENSE]:IQVTime:FREQuency:CENTer?
<b>Related Commands</b>	[SENSE]:IQVTime:FREQuency:START, [SENSE]:IQVTime:FREQuency:STOP
<b>Arguments</b>	<value> ::= <Nrf> specifies the center frequency. Range: 0 Hz to 6.2 GHz (RSA6106A) / 14 GHz (RSA6114A).
<b>Examples</b>	SENSE:IQVTIME:FREQUENCY:CENTER 7.5GHZ sets the center frequency to 7.5 GHz.

## [SENSe]:IQVTime:FREQuency:SPAN

Sets or queries the frequency span in the RF I&Q versus Time measurement.

**Conditions** Measurement views: RF I&Q versus Time

**Group** Sense commands

**Syntax** [SENSe]:IQVTime:FREQuency:SPAN <value>  
[SENSe]:IQVTime:FREQuency:SPAN?

**Arguments** <value>::=<Nrf> is the frequency span.  
Range: 10 Hz to 40 MHz (Standard) / 110 MHz (Option 110)

**Examples** SENSE:IQVTIME:FREQUENCY:SPAN 20MHZ sets the span to 20 MHz.

## [SENSe]:IQVTime:FREQuency:START

Sets or queries the measurement start frequency (left edge on the graph) in the RF I&Q versus Time measurement.

The center, start and stop frequencies are set interlocking each other. Refer to the [\[SENSe\]:IQVTime:FREQuency:CENTer](#) command.

**Conditions** Measurement views: RF I&Q versus Time

**Group** Sense commands

**Syntax** [SENSe]:IQVTime:FREQuency:START <value>  
[SENSe]:IQVTime:FREQuency:START?

**Related Commands** [\[SENSe\]:IQVTime:FREQuency:STOP](#)

**Arguments** <value>::=<Nrf> is the measurement start frequency.  
Range: (center frequency)  $\pm$  (span)/2.

**Examples** SENSE:IQVTIME:FREQUENCY:START 6.95GHZ sets the start frequency to 6.95 GHz.



## [SENSe]:IQVTime:FREQuency:STEP

Sets or queries the frequency step size (the amount per press by which the up or down key changes the setting value). Programming a specified step size sets [SENSe]:IQVTime:FREQuency:STEP:AUTO OFF.

**Conditions** Measurement views: RF I&Q versus Time

**Group** Sense commands

**Syntax** [SENSe]:IQVTime:FREQuency:STEP <value>  
[SENSe]:IQVTime:FREQuency:STEP?

**Related Commands** [\[SENSe\]:IQVTime:FREQuency:STEP:AUTO](#)

**Arguments** <value>::=<Nrf> specifies the frequency step size.  
Range: 0 Hz to 6.2 GHz (RSA6106A) / 14 GHz (RSA6114A).

**Examples** SENSE:IQVTIME:FREQUENCY:STEP 1.5kHz sets the step size to 1.5 kHz.

## [SENSe]:IQVTime:FREQuency:STEP:AUTO

Determines whether to set the frequency step size automatically or manually.

**Conditions** Measurement views: RF I&Q versus Time

**Group** Sense commands

**Syntax** [SENSe]:IQVTime:FREQuency:STEP:AUTO { OFF | ON | 0 | 1 }  
[SENSe]:IQVTime:FREQuency:STEP:AUTO?

**Arguments** OFF or 0 specifies that the frequency step size is set manually using the [\[SENSe\]:IQVTime:FREQuency:STEP](#) command.

ON or 1 specifies that the frequency step size is set automatically.

**Examples** SENSE:IQVTIME:FREQUENCY:STEP:AUTO ON sets the frequency step size automatically.

## [SENSe]:IQVTime:FREQuency:STOP

Sets or queries the measurement stop frequency (right edge of the graph) in the RF I&Q versus Time measurement.

The center, start and stop frequencies are set interlocking each other. Refer to the [\[SENSe\]:IQVTime:FREQuency:CENTer](#) command.

**Conditions** Measurement views: RF I&Q versus Time

**Group** Sense commands

**Syntax** [SENSe]:IQVTime:FREQuency:STOP <value>  
[SENSe]:IQVTime:FREQuency:STOP?

**Related Commands** [\[SENSe\]:IQVTime:FREQuency:STARt](#)

**Arguments** <value>::=<Nrf> is the measurement stop frequency.  
Range: (center frequency) ± (span)/2.

**Examples** SENSE:IQVTIME:FREQUENCY:STOP 7.05GHZ sets the stop frequency to 7.05 GHz.

## [SENSe]:IQVTime:MAXTracepoints

Selects or queries the maximum trace points in the RF I&Q versus Time measurement.

**Conditions** Measurement views: RF I&Q versus Time

**Group** Sense commands

**Syntax** [SENSe]:IQVTime:MAXTracepoints { ONEK | TENK | HUNDredk | NEVERdecimate }  
[SENSe]:IQVTime:MAXTracepoints?

**Arguments** ONEK sets the maximum trace points to 1 k.  
TENK sets the maximum trace points to 10 k.  
HUNDredk sets the maximum trace points to 100 k.

NEVERdecimate never decimates the trace points.

**Examples** SENSE:IQVTIME:MAXTRACEPOINTS TENK sets the maximum trace points to 10 k.

## [SENSe]:MCPower:AVERage

Selects or queries the average method in the MCPR measurement.

**Conditions** Measurement views: MCPR

**Group** Sense commands

**Syntax** [SENSe]:MCPower:AVERage { OFF | TIME | FREQUENCY }  
[SENSe]:MCPower:AVERage?

**Arguments** OFF disables averaging.  
TIME performs averaging for time samples.  
FREQUENCY performs averaging for frequency samples.

**Examples** SENSE:MCPOWER:AVERAGE TIME performs averaging for time samples.

## [SENSe]:MCPower:AVERage:COUNT

Sets or queries the average count in the MCPR measurement.

**Conditions** Measurement views: MCPR

**Group** Sense commands

**Syntax** [SENSe]:MCPower:AVERage:COUNT <value>  
[SENSe]:MCPower:AVERage:COUNT?

**Arguments** <value>::=<NR1> specifies the average count. Range: 2 to 10000.

**Examples** SENSE:MCPOWER:AVERAGE:COUNT 256 sets the average count to 256.

**[SENSe]:MCPower:{BANDwidth|BWIDth}[:RESolution]**

Sets or queries the resolution bandwidth (RBW). Programming a specified RBW sets [SENSe]:MCPower{BANDwidth|BWIDth}[:RESolution]:AUTO OFF.

<b>Conditions</b>	Measurement views: MCPR
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:MCPower:{BANDwidth BWIDth}[:RESolution] <value> [SENSe]:MCPower:{BANDwidth BWIDth}[:RESolution]?
<b>Related Commands</b>	[SENSe]:MCPower:{BANDwidth BWIDth}[:RESolution]:AUTO
<b>Arguments</b>	<value>::=<Nrf> specifies the RBW. Range: 100 Hz to 5 MHz.
<b>Examples</b>	SENSE:MCPOWER:BANDWIDTH:RESOLUTION 200kHz sets the RBW to 200 kHz.

**[SENSe]:MCPower:{BANDwidth|BWIDth}[:RESolution]:ACTual? (Query Only)**

Queries the actual resolution bandwidth (RBW) in the MCPR measurement.

<b>Conditions</b>	Measurement views: MCPR
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:MCPower:{BANDwidth BWIDth}[:RESolution]:ACTual?
<b>Arguments</b>	None
<b>Returns</b>	<Nrf> The actual RBW in Hz.
<b>Examples</b>	SENSE:MCPOWER:BANDWIDTH:RESOLUTION:ACTUAL? might return 299.624E+3, indicating that the actual RBW is 299.624 kHz.

## [SENSe]:MCPower:{BANDwidth|BWIDth}[:RESolution]:AUTO

Determines whether to set the resolution bandwidth (RBW) automatically or manually.

**Conditions** Measurement views: MCPR

**Group** Sense commands

**Syntax** [SENSe]:MCPower:{BANDwidth|BWIDth}[:RESolution]:AUTO { OFF | ON | 0 | 1 }  
[SENSe]:MCPower:{BANDwidth|BWIDth}[:RESolution]:AUTO?

**Arguments** OFF or 0 specifies that the resolution bandwidth is set manually using the [SENSe]:MCPower:{BANDwidth|BWIDth}[:RESolution] command.  
ON or 1 specifies that the resolution bandwidth is set automatically.

**Examples** SENSE:MCPOWER:BANDWIDTH:AUTO ON sets the resolution bandwidth automatically.

## [SENSe]:MCPower:{BANDwidth|BWIDth}:VIDeo

Sets or queries the video bandwidth (VBW). Programming a specified VBW sets [SENSe]:MCPower:{BANDwidth|BWIDth}:VIDeo:STATe OFF.

**Conditions** Measurement views: MCPR

**Group** Sense commands

**Syntax** [SENSe]:MCPower:{BANDwidth|BWIDth}:VIDeo <value>  
[SENSe]:MCPower:{BANDwidth|BWIDth}:VIDeo?

**Related Commands** [SENSe]:MCPower:{BANDwidth|BWIDth}:VIDeo:STATe

**Arguments** <value>::=<NRf> specifies the VBW.  
Range: Current RBW/10<sup>4</sup> (1 Hz minimum) to Current RBW.

**Examples** SENSE:MCPOWER:BANDWIDTH:VIDEO 200kHz sets the VBW to 200 kHz.

**[SENSe]:MCPower:{BANDwidth|BWIDth}:VIDeo:STATe**

Determines whether to enable the video bandwidth (VBW) in the MCPR measurement.

<b>Conditions</b>	Measurement views: MCPR
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:MCPower:{BANDwidth BWIDth}:VIDeo:STATE { OFF   ON   0   1 } [SENSe]:MCPower:{BANDwidth BWIDth}:VIDeo:STATE?
<b>Arguments</b>	OFF or 0 disables the VBW. ON or 1 enables the VBW.
<b>Examples</b>	SENSE:MCPOWER:BANDWIDTH:VIDEO:STATE ON enables the VBW.

**[SENSe]:MCPower:CHANnel:ADJacent:ADD (No Query Form)**

Adds a pair of upper and lower adjacent channels in the MCPR measurement.

<b>Conditions</b>	Measurement views: MCPR
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:MCPower:CHANnel:ADJacent:ADD <offset>,<bandwidth>
<b>Arguments</b>	<offset>::=<NRF> specifies the offset from the center frequency for the adjacent channel. Range: 0 to 6.2 GHz (RSA6106A) / 14 GHz (RSA6114A).  <bandwidth>::=<NRF> specifies the bandwidth of the adjacent channel. Range: 0 to 6.2 GHz (RSA6106A) / 14 GHz (RSA6114A).
<b>Examples</b>	SENSE:MCPOWER:CHANNEL:ADJACENT:ADD 200kHz,80kHz adds a pair of upper and lower adjacent channels with the offset of $\pm 200$ kHz and the bandwidth of 80 kHz.

## [SENSe]:MCPower:CHANnel:ADJacent:DELeTe (No Query Form)

Deletes a selected adjacent channel in the MCPR measurement.

<b>Conditions</b>	Measurement views: MCPR
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:MCPower:CHANnel:ADJacent:DELeTe <channel>
<b>Arguments</b>	<channel> ::= <string> specifies the channel to be deleted. Specify the channel with "A<n>" for the adjacent channel where <n> represents the channel number (<n> = 1, 2, 3,...). See the example below.
<b>Examples</b>	SENSe:MCPower:CHANnel:ADJacent:DELeTe "A2" deletes A2 (the adjacent channel 2).

## [SENSe]:MCPower:CHANnel:FILTer

Selects or queries the adjacent channel filter in the MCPR measurement.

<b>Conditions</b>	Measurement views: MCPR
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:MCPower:CHANnel:FILTer { RRCosine   NONE } [SENSe]:MCPower:CHANnel:FILTer?
<b>Arguments</b>	RRCosine selects the Root-Raised-Cosine filter. NONE uses no filter.
<b>Examples</b>	SENSe:MCPOWER:CHANNEL:FILTER RRCosine selects Root-Raised-Cosine for the adjacent channel filter.

**[SENSe]:MCPower:CHANnel:MAIN:{BANDwidth|BWIDth}**

Sets or queries the frequency bandwidth of the main channels (all share the same value) in the MCPR measurement.

**Conditions** Measurement views: MCPR

**Group** Sense commands

**Syntax** [SENSe]:MCPower:CHANnel:MAIN:{BANDwidth|BWIDth} <value>  
[SENSe]:MCPower:CHANnel:MAIN:{BANDwidth|BWIDth}?

**Arguments** <value>::=<Nrf> specifies the main channel bandwidth.  
Range: 1 Hz to full span.

**Examples** SENSE:MCPOWER:CHANNEL:MAIN:BANDWIDTH 4.5MHZ sets the main channel bandwidth to 4.5 MHz.

**[SENSe]:MCPower:CHANnel:MAIN:COUNT**

Sets or queries the number of main channels in the MCPR measurement. You can use this command to add and remove main channels.

**Conditions** Measurement views: MCPR

**Group** Sense commands

**Syntax** [SENSe]:MCPower:CHANnel:MAIN:COUNT <value>  
[SENSe]:MCPower:CHANnel:MAIN:COUNT?

**Arguments** <value>::=<Nrf> specifies the number of main channels. Range: 1 to 99.

**Examples** SENSE:MCPOWER:CHANNEL:MAIN:COUNT 3 sets the the number of main channels to 3.



## [SENSe]:MCPower:CHANnel:MAIN:INActive

Makes a specified main channel inactive. You can set it on or off. The query returns all inactive main channels.

<b>Conditions</b>	Measurement views: MCPR
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:MCPower:CHANnel:MAIN:INActive <channel>, <boolean> [SENSe]:MCPower:CHANnel:MAIN:INActive?
<b>Arguments</b>	<channel>::=<string> specifies the channel to be inactive. Specify the channel with "M<n>" for the main channel where <n> represents the channel number (<n> = 1, 2, 3,...). See the example below.  <boolean>::={ OFF   ON   0   1 } specifies that the specified channel is inactive (On) or not (Off).
<b>Examples</b>	SENSE:MCPOWER:CHANNEL:MAIN:INACTIVE "M2", ON makes the main channel 2 inactive.

## [SENSe]:MCPower:CHANnel:MAIN:SPACing

Sets or queries frequency difference between centers of each main channel in the MCPR measurement.

<b>Conditions</b>	Measurement views: MCPR
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:MCPower:CHANnel:MAIN:SPACing <value> [SENSe]:MCPower:CHANnel:MAIN:SPACing?
<b>Arguments</b>	<value>::=<Nrf> specifies the spacing between two adjacent main channels. Range: 1 Hz to 1 GHz.
<b>Examples</b>	SENSE:MCPOWER:CHANNEL:MAIN:SPACING 5MHZ sets the main channel spacing to 5 MHz.

## [SENSe]:MCPower:CHIPrate

Sets or queries the chip rate in the MCPR measurement. This command is valid when [SENSe]:MCPower:CHANnel:FILTer is set to RRCosine (Root-Raised-Cosine).

<b>Conditions</b>	Measurement views: MCPR
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:MCPower:CHIPrate <value> [SENSe]:MCPower:CHIPrate?
<b>Arguments</b>	<value>::=<nrf> specifies the chip rate. Range: 100 Hz to 105 MHz.
<b>Examples</b>	SENSE:MCPOWER:CHIPRATE 1kHz sets the chip rate to 1 kHz.

## [SENSe]:MCPower:CLEar:RESuLts (No Query Form)

Restarts the average trace.

<b>Conditions</b>	Measurement views: MCPR
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:MCPower:CLEar:RESuLts
<b>Arguments</b>	None
<b>Examples</b>	SENSE:MCPOWER:CLEAR:RESULTS restarts the average trace.

## [SENSe]:MCPower:FREQuency

Sets or queries the center frequency in the MCPR measurement.

<b>Conditions</b>	Measurement views: MCPR
-------------------	-------------------------

<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:MCPower:FREQUENCY <value> [SENSe]:MCPower:FREQUENCY?
<b>Arguments</b>	<value> ::= <Nrf> specifies the center frequency. Range: 0 to 6.2 GHz (RSA6106A) / 14 GHz (RSA6114A).
<b>Examples</b>	SENSE:MCPOWER:FREQUENCY 2.35GHZ sets the center frequency to 2.35 GHz.

## [SENSe]:MCPower:FREQUENCY:STEP

Sets or queries the frequency step size. Programming a specified step size sets [SENSe]:MCPower:FREQUENCY:STEP:AUTO OFF.

<b>Conditions</b>	Measurement views: MCPR
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:MCPower:FREQUENCY:STEP <value> [SENSe]:MCPower:FREQUENCY:STEP?
<b>Related Commands</b>	<a href="#">[SENSe]:MCPower:FREQUENCY:STEP:AUTO</a>
<b>Arguments</b>	<value> ::= <Nrf> specifies the frequency step size. Range: 0 to 6.2 GHz (RSA6106A) / 14 GHz (RSA6114A).
<b>Examples</b>	SENSE:MCPOWER:FREQUENCY:STEP 50kHz sets the frequency step size to 50 kHz.

## [SENSe]:MCPower:FREQUENCY:STEP:AUTO

Determines whether to set the frequency step size automatically or manually in the MCPR measurement.

<b>Conditions</b>	Measurement views: MCPR
-------------------	-------------------------

<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:MCPower:FREQUENCY:STEP:AUTO { OFF   ON   0   1 } [SENSe]:MCPower:FREQUENCY:STEP:AUTO?
<b>Arguments</b>	OFF or 0 specifies that the frequency step size is set manually using the [SENSe]:MCPower:FREQUENCY:STEP command. ON or 1 specifies that the frequency step size is set automatically.
<b>Examples</b>	SENSE:MCPOWER:FREQUENCY:STEP:AUTO ON specifies that the frequency step size is set automatically.

## [SENSe]:MCPower:NFLoor:STATE

Determines whether to enable correction for noise floor.

<b>Conditions</b>	Measurement views: MCPR
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:MCPower:NFLoor:STATE { OFF   ON   0   1 } [SENSe]:MCPower:NFLoor:STATE?
<b>Arguments</b>	OFF or 0 disables correction for noise floor. ON or 1 enables correction for noise floor.
<b>Examples</b>	SENSE:MCPOWER:NFLOOR:STATE ON enables correction for noise floor.

## [SENSe]:MCPower:OPTimize:SPAN

Selects or queries the optimization method in the MCPR measurement.

<b>Conditions</b>	Measurement views: MCPR
<b>Group</b>	Sense commands

<b>Syntax</b>	<code>[SENSE]:MCPower:OPTimize:SPAN { RTBandwidth   DRANGE }</code> <code>[SENSE]:MCPower:OPTimize:SPAN?</code>
<b>Arguments</b>	RTBandwidth optimizes the measurement for real-time bandwidth. DRANGE optimizes the measurement for dynamic range.
<b>Examples</b>	<code>SENSE:MCPOWER:OPTIMIZE:SPAN RTBandwidth</code> optimizes the measurement for real-time bandwidth.

## [SENSE]:MCPower:RChannels? (Query Only)

Queries the power reference in the MCPower measurement.

<b>Conditions</b>	Measurement views: MCPower
<b>Group</b>	Sense commands
<b>Syntax</b>	<code>[SENSE]:MCPower:RChannels?</code>
<b>Arguments</b>	None
<b>Returns</b>	<code>&lt;power_ref&gt;::={ Total   M&lt;x&gt; }</code> where <code>&lt;x&gt; = 1 to 99</code> . Total indicates that the power reference is the total power of all the active channels. M<x> indicates that the power reference is the main channel with the index (<x>).
<b>Examples</b>	<code>SENSE:MCPOWER:RCHANNELS?</code> might return M3, indicating that the power reference is the main channel 3.

## [SENSE]:MCPower:RChannels:MAIN<x> (No Query Form)

Sets the power reference to the main channel with the index (<x>) in the MCPower measurement.

The parameter `<x> = 1 to 99`, representing the main channel 1 to 99, respectively. The main channel must be defined using the `[SENSE]:MCPower:CHANnel:MAIN` commands.

<b>Conditions</b>	Measurement views: MCPR
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSE]:MCPower:RChannels:MAIN<x>
<b>Related Commands</b>	[:SENSE]:MCPower:CHANnel:MAIN commands
<b>Arguments</b>	None
<b>Examples</b>	SENSE:MCPOWER:RCHANNELS:MAIN3 selects Main 3 for the power reference channel.

### [SENSE]:MCPower:RChannels:TOTal (No Query Form)

Sets the power reference to the total power of all the active channels in the MCPR measurement.

<b>Conditions</b>	Measurement views: MCPR
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSE]:MCPower:RChannels:TOTal
<b>Arguments</b>	None
<b>Examples</b>	SENSE:MCPOWER:RCHANNELS:TOTAL sets the power reference to the total power of all the active channels.

### [SENSE]:MCPower:RRCRolloff

Sets or queries the filter parameter (roll-off ratio) for the Root Raised Cosine filter.

<b>Conditions</b>	Measurement views: MCPR
<b>Group</b>	Sense commands

**Syntax** [SENSe]:MCPower:RRCRo1loff <value>  
[SENSe]:MCPower:RRCRo1loff?

**Related Commands** [SENSe]:MCPower:CHANnel:FILTer

**Arguments** <value> ::= <NRf> specifies the filter parameter.  
Range: 0.001 to 1, 0.0001 step.

**Examples** SENSE:MCPOWER:RRCROLLOFF 0.3 sets the filter parameter to 0.3.

## [SENSe]:MEASurement:FREQuency

Sets or queries the measurement frequency.

**Conditions** Measurement views: All

**Group** Sense commands

**Syntax** [SENSe]:MEASurement:FREQuency <value>  
[SENSe]:MEASurement:FREQuency?

**Arguments** <value> ::= <NRf> specifies the measurement frequency.  
Range: 0 Hz to 6.2 GHz (RSA6106A) / 14 GHz (RSA6114A).

**Examples** SENSE:MEASUREMENT:FREQUENCY 7.5GHZ sets the measurement frequency to 7.5 GHz.

## [SENSe]:OBWidth:AVERage

Selects or queries whether to enable averaging in the Occupied Bandwidth measurement.

**Conditions** Measurement views: Occupied Bandwidth

**Group** Sense commands

**Syntax** [SENSe]:OBwidth:AVERAge { OFF | ON | 0 | 1 }  
[SENSe]:OBwidth:AVERAge?

**Arguments** OFF or 0 disables averaging.  
ON or 1 enables averaging.

**Examples** SENSE:OBWIDTH:AVERAGE ON enables averaging.

## [SENSe]:OBWidth:AVERAge:COUNT

Sets or queries the number of measurements for averaging in the Occupied Bandwidth measurement.

**Conditions** Measurement views: Occupied Bandwidth

**Group** Sense commands

**Syntax** [SENSe]:OBwidth:AVERAge:COUNT <number>  
[SENSe]:OBwidth:AVERAge:COUNT?

**Arguments** <number>::=<NR1> specifies the average count. Range: 2 to 10000.

**Examples** SENSE:OBWIDTH:AVERAGE:COUNT 64 sets the average count to 64.

## [SENSe]:OBWidth:{BANDwidth|BWIDth}:MEASurement

Sets or queries the measurement bandwidth to determine the total power in the Occupied Bandwidth measurement.

**Conditions** Measurement views: Occupied Bandwidth

**Group** Sense commands

**Syntax** [SENSe]:OBwidth:{BANDwidth|BWIDth}:MEASurement <value>  
[SENSe]:OBwidth:{BANDwidth|BWIDth}:MEASurement?



**Arguments** <value>::=<Nrf> specifies the measurement bandwidth.  
Range: 100 Hz to 109 MHz.

**Examples** SENSE:OBWIDTH:BANDWIDTH:MEASUREMENT 10MHz sets the measurement bandwidth to 10 MHz.

## [SENSE]:OBWidth:{BANDwidth|BWIDth}[:RESolution]

Sets or queries the resolution bandwidth (RBW). Programming a specified RBW sets [SENSE]:OBWidth{BANDwidth|BWIDth}[:RESolution]:AUTO OFF.

**Conditions** Measurement views: Occupied Bandwidth

**Group** Sense commands

**Syntax** [SENSE]:OBWidth:{BANDwidth|BWIDth}[:RESolution] <value>  
[SENSE]:OBWidth:{BANDwidth|BWIDth}[:RESolution]?

**Related Commands** [SENSE]:OBWidth:{BANDwidth|BWIDth}[:RESolution]:AUTO

**Arguments** <value>::=<Nrf> specifies the RBW. Range: 100 Hz to 5 MHz.

**Examples** SENSE:OBWIDTH:BANDWIDTH:RESOLUTION 200kHz sets the RBW to 200 kHz.

## [SENSE]:OBWidth:{BANDwidth|BWIDth}[:RESolution]:ACTual? (Query Only)

Queries the actual resolution bandwidth (RBW) in the Occupied Bandwidth measurement.

**Conditions** Measurement views: Occupied Bandwidth

**Group** Sense commands

**Syntax** [SENSE]:OBWidth:{BANDwidth|BWIDth}[:RESolution]:ACTual?

**Arguments** None

**Returns** <NRf> The actual RBW in Hz.

**Examples** SENSE:OBWIDTH:BANDWIDTH:RESOLUTION:ACTUAL? might return 299.624E+3, indicating that the actual RBW is 299.624 kHz.

## [SENSE]:OBWidth:{BANDwidth|BWIDth}:RESolution]:AUTO

Determines whether to set the resolution bandwidth (RBW) automatically or manually in the Occupied Bandwidth measurement.

**Conditions** Measurement views: Occupied Bandwidth

**Group** Sense commands

**Syntax** [SENSE]:OBwidth:{BANDwidth|BWIDth}:RESolution]:AUTO { OFF | ON | 0 | 1 }  
[SENSE]:OBwidth:{BANDwidth|BWIDth}:RESolution]:AUTO?

**Arguments** OFF or 0 specifies that the RBW is set manually using the [SENSE]:OBWidth:{BANDwidth|BWIDth}:RESolution] command.  
ON or 1 specifies that the RBW is set automatically.

**Examples** SENSE:OBWIDTH:BANDWIDTH:AUTO ON sets the RBW automatically.

## [SENSE]:OBWidth:{BANDwidth|BWIDth}:VIDeo

Sets or queries the video bandwidth (VBW). Programming a specified VBW sets [SENSE]:OBWidth{BANDwidth|BWIDth}:VIDeo:STATe OFF.

**Conditions** Measurement views: Occupied Bandwidth

**Group** Sense commands

**Syntax** [SENSE]:OBwidth:{BANDwidth|BWIDth}:VIDeo <value>  
[SENSE]:OBwidth:{BANDwidth|BWIDth}:VIDeo?

**Arguments** <value>::=<NRf> specifies the VBW.  
Range: Current RBW/10<sup>4</sup> (1 Hz minimum) to Current RBW.

**Examples**    `SENSE:OBWIDTH:BANDWIDTH:VIDEO 200kHz` sets the VBW to 200 kHz.

## **[SENSe]:OBWidth:{BANDwidth|BWIDth}:VIDeo:STATe**

Determines whether to enable the video bandwidth (VBW) in the Occupied Bandwidth measurement.

**Conditions**    Measurement views: Occupied Bandwidth

**Group**    Sense commands

**Syntax**    `[SENSe]:OBwidth:{BANDwidth|BWIDth}:VIDeo:STATE { OFF | ON  
| 0 | 1 }`  
`[SENSe]:OBwidth:{BANDwidth|BWIDth}:VIDeo:STATE?`

**Arguments**    OFF or 0 disables the VBW.  
ON or 1 enables the VBW.

**Examples**    `SENSE:OBWIDTH:BANDWIDTH:VIDEO:STATE ON` enables the VBW.

## **[SENSe]:OBWidth:CLear:RESuLts (No Query Form)**

Restarts the average trace. This command is valid when [\[SENSe\]:OBWidth:AVERage](#) is set to ON.

**Conditions**    Measurement views: Occupied Bandwidth

**Group**    Sense commands

**Syntax**    `[SENSe]:OBwidth:CLear:RESuLts`

**Arguments**    None

**Examples**    `SENSE:OBWIDTH:CLEAR:RESULTS` restarts the average trace.

## [SENSe]:OBWidth:FREQuency:CENTer

Sets or queries the center frequency in the Occupied Bandwidth measurement.

<b>Conditions</b>	Measurement views: Occupied Bandwidth
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:OBwidth:FREQuency:CENTer <value> [SENSe]:OBwidth:FREQuency:CENTer?
<b>Arguments</b>	<value>::=<Nrf> specifies the center frequency. Range: 0 Hz to 6.2 GHz (RSA6106A) / 14 GHz (RSA6114A).
<b>Examples</b>	SENSE:OBWIDTH:FREQUENCY:CENTER 7.5GHZ sets the center frequency to 7.5 GHz.

## [SENSe]:OBWidth:FREQuency:STEP

Sets or queries the frequency step size in the Occupied Bandwidth measurement. Programming a specified step size sets [SENSe]:OBWidth:FREQuency:STEP AUTO OFF.

<b>Conditions</b>	Measurement views: Occupied Bandwidth
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:OBwidth:FREQuency:STEP <value> [SENSe]:OBwidth:FREQuency:STEP?
<b>Related Commands</b>	<a href="#">[SENSe]:OBWidth:FREQuency:STEP:AUTO</a>
<b>Arguments</b>	<value>::=<Nrf> specifies the frequency step size. Range: 0 to 6.2 GHz (RSA6106A) / 14 GHz (RSA6114A).
<b>Examples</b>	SENSE:OBWIDTH:FREQUENCY:STEP 1kHz sets the frequency step size to 1 kHz.

## [SENSe]:OBWidth:FREQuency:STEP:AUTO

Determines whether to set the frequency step size automatically or manually in the Occupied Bandwidth measurement.

<b>Conditions</b>	Measurement views: Occupied Bandwidth
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:OBWidth:FREQuency:STEP:AUTO { OFF   ON   0   1 } [SENSe]:OBWidth:FREQuency:STEP:AUTO?
<b>Arguments</b>	OFF or 0 specifies that the frequency step size is set manually using the [SENSe]:OBWidth:FREQuency:STEP command. ON or 1 specifies that the frequency step size is set automatically.
<b>Examples</b>	SENSE:OBWIDTH:FREQUENCY:STEP:AUTO ON specifies that the frequency step size is set automatically.

## [SENSe]:OBWidth:PERCent

Sets or queries the occupied bandwidth percent power (power ratio of the occupied bandwidth to the measurement bandwidth).

<b>Conditions</b>	Measurement views: Occupied Bandwidth
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:OBWidth:PERCent <value> [SENSe]:OBWidth:PERCent?
<b>Arguments</b>	<value> ::= <NRf> specifies the occupied bandwidth percent power. Range: 50 to 99.9%.
<b>Examples</b>	SENSE:OBWIDTH:PERCENT 98 sets the occupied bandwidth percent power to 98%.

## [SENSe]:OBWidth:XDBLevel

Sets or queries the x dB level (how far down from the peak level the bandwidth is measured) in the x dB bandwidth measurement.

<b>Conditions</b>	Measurement views: Occupied Bandwidth
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:OBwidth:XDBLevel <value> [SENSe]:OBwidth:XDBLevel?
<b>Arguments</b>	<value>::=<NRF> specifies the x dB level. Range: -80 to -1 dB.
<b>Examples</b>	SENSE:OBWIDTH:XDBLEVEL -10 sets the x dB level to -10 dB.

## [SENSe]:PHVTime:CLEar:RESuLts (No Query Form)

Restarts multi-trace functions (Average and Max/Min Hold).

<b>Conditions</b>	Measurement views: Phase versus Time
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:PHVTime:CLEar:RESuLts
<b>Arguments</b>	None
<b>Examples</b>	SENSE:PHVTIME:CLEAR:RESULTS restarts multi-trace functions.

## [SENSe]:PHVTime:FREQuency:CENTer

Sets or queries the center frequency in the Phase versus Time measurement.

---

**NOTE.** The center, start and stop frequencies are set interlocking each other with the following relationships:  $(start\ frequency) = (center\ frequency) - (span)/2$  and  $(stop\ frequency) = (center\ frequency) + (span)/2$ .

---

<b>Conditions</b>	Measurement views: Phase versus Time
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSE]:PHVTime:FREQUENCY:CENTER <value> [SENSE]:PHVTime:FREQUENCY:CENTER?
<b>Related Commands</b>	<a href="#">[SENSE]:PHVTime:FREQUENCY:START</a> , <a href="#">[SENSE]:PHVTime:FREQUENCY:STOP</a>
<b>Arguments</b>	<value>::=<NRF> specifies the center frequency. Range: 0 Hz to 6.2 GHz (RSA6106A) / 14 GHz (RSA6114A).
<b>Examples</b>	SENSE:PHVTIME:FREQUENCY:CENTER 7.5GHZ sets the center frequency to 7.5 GHz.

## [SENSE]:PHVTime:FREQUENCY:SPAN

Sets or queries the frequency span in the Phase versus Time measurement.

<b>Conditions</b>	Measurement views: Phase versus Time
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSE]:PHVTime:FREQUENCY:SPAN <value> [SENSE]:PHVTime:FREQUENCY:SPAN?
<b>Arguments</b>	<value>::=<NRF> is the frequency span. Range: 10 Hz to 40 MHz (Standard) / 110 MHz (Option 110)
<b>Examples</b>	SENSE:PHVTIME:FREQUENCY:SPAN 20MHZ sets the span to 20 MHz.

## [SENSE]:PHVTime:FREQUENCY:START

Sets or queries the measurement start frequency (left edge on the graph) in the Phase versus Time measurement.

The center, start and stop frequencies are set interlocking each other. Refer to the [\[SENSE\]:PHVTime:FREQUENCY:CENTER](#) command.

<b>Conditions</b>	Measurement views: Phase versus Time
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:PHVTime:FREQUENCY:START <value> [SENSe]:PHVTime:FREQUENCY:START?
<b>Related Commands</b>	[SENSe]:PHVTime:FREQUENCY:STOP
<b>Arguments</b>	<value>::=<Nrf> is the measurement start frequency. Range: (center frequency) ± (span)/2.
<b>Examples</b>	SENSE:PHVTIME:FREQUENCY:START 6.95GHZ sets the start frequency to 6.95 GHz.

## [SENSe]:PHVTime:FREQUENCY:STEP

Sets or queries the frequency step size (the amount per press by which the up or down key changes the setting value). Programming a specified step size sets [SENSe]:PHVTime:FREQUENCY:STEP:AUTO OFF.

<b>Conditions</b>	Measurement views: Phase versus Time
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:PHVTime:FREQUENCY:STEP <value> [SENSe]:PHVTime:FREQUENCY:STEP?
<b>Related Commands</b>	[SENSe]:PHVTime:FREQUENCY:STEP:AUTO
<b>Arguments</b>	<value>::=<Nrf> specifies the frequency step size. Range: 0 Hz to 6.2 GHz (RSA6106A) / 14 GHz (RSA6114A).
<b>Examples</b>	SENSE:PHVTIME:FREQUENCY:STEP 1.5kHz sets the step size to 1.5 kHz.



## [SENSe]:PHVTime:FREQuency:STEP:AUTO

Determines whether to set the frequency step size automatically or manually.

<b>Conditions</b>	Measurement views: Phase versus Time
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:PHVTime:FREQuency:STEP:AUTO { OFF   ON   0   1 } [SENSe]:PHVTime:FREQuency:STEP:AUTO?
<b>Arguments</b>	OFF or 0 specifies that the frequency step size is set manually using the <a href="#">[SENSe]:PHVTime:FREQuency:STEP</a> command.  ON or 1 specifies that the frequency step size is set automatically.
<b>Examples</b>	SENSE:PHVTIME:BANDWIDTH:AUTO ON sets the frequency step size automatically.

## [SENSe]:PHVTime:FREQuency:STOP

Sets or queries the measurement stop frequency (right edge of the graph) in the Phase versus Time measurement.

The center, start and stop frequencies are set interlocking each other. Refer to the [\[SENSe\]:PHVTime:FREQuency:CENTer](#) command.

<b>Conditions</b>	Measurement views: Phase versus Time
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:PHVTime:FREQuency:STOP <value> [SENSe]:PHVTime:FREQuency:STOP?
<b>Related Commands</b>	<a href="#">[SENSe]:PHVTime:FREQuency:START</a>
<b>Arguments</b>	<value> ::= <Nrf> is the measurement stop frequency. Range: (center frequency) ± (span)/2.

**Examples**     `SENSE:PHVTIME:FREQUENCY:STOP 7.05GHZ` sets the stop frequency to 7.05 GHz.

## [SENSe]:PHVTime:MAXTracepoints

Selects or queries the maximum trace points in the Phase versus Time measurement.

**Conditions**     Measurement views: Phase versus Time

**Group**     Sense commands

**Syntax**     `[SENSe]:PHVTime:MAXTracepoints { ONEK | TENK | HUNDredk | NEVERdecimate }`  
`[SENSe]:PHVTime:MAXTracepoints?`

**Arguments**     ONEK sets the maximum trace points to 1 k.  
                       TENK sets the maximum trace points to 10 k.  
                       HUNDredk sets the maximum trace points to 100 k.  
                       NEVERdecimate never decimates the trace points.

**Examples**     `SENSE:PHVTIME:MAXTRACEPOINTS TENK` sets the maximum trace points to 10 k.

## [SENSe]:PM:PHASe:OFFSet

Sets or queries the phase offset in the PM measurement.

**Conditions**     Measurement views: PM

**Group**     Sense commands

**Syntax**     `[SENSe]:PM:PHASe:OFFSet <value>`  
`[SENSe]:PM:PHASe:OFFSet?`

**Arguments**     `<value>::=<NRf>` specifies the phase offset. Range: -180 to +180 °.

**Examples**    `SENSE:PM:PHASE:OFFSET 10deg` sets the phase offset to 10 °.

## [SENSe]:PM:PHASe:OFFSet:MARKer (No Query Form)

Sets or queries the phase offset from the selected marker location in the PM measurement.

**Conditions**    Measurement views: PM

**Group**    Sense commands

**Syntax**    `[SENSe]:PM:PHASe:OFFSet:MARKer`

**Arguments**    None.

**Examples**    `SENSE:PM:PHASe:OFFSet:MARKer` sets the phase offset from the selected Marker position.

## [SENSe]:PM:PHASe:SEARCh:AUTO

Determines whether to detect the phase automatically or manually in the PM measurement.

**Conditions**    Measurement views: PM

**Group**    Sense commands

**Syntax**    `[SENSe]:PM:PHASe:SEARCh:AUTO { OFF | ON | 0 | 1 }`  
`[SENSe]:PM:PHASe:SEARCh:AUTO?`

**Arguments**    OFF or 0 specifies that the phase offset is set manually using the command [\[SENSe\]:PM:PHASe:OFFSet](#).

ON or 1 specifies that the phase is detected automatically.

**Examples**    `SENSE:PM:PHASe:SEARCh:AUTO ON` specifies that the phase is detected automatically.

## [SENSe]:PNOise:AVERage:COUNT

Sets or queries the number of traces to combine for averaging in the phase noise measurement. This command is effective when [SENSe]:PNOise:AVERage:ENABLe is set to ON.

<b>Conditions</b>	Measurement views: Phase noise
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:PNOise:AVERage:COUNT <number> [SENSe]:PNOise:AVERage:COUNT?
<b>Arguments</b>	<number>::=<NR1> specifies the average count. Range: 2 to 10000.
<b>Examples</b>	SENSE:PNOISE:AVERAGE:COUNT 64 sets the average count to 64.

## [SENSe]:PNOise:AVERage:ENABLe

Determines whether to enable averaging trace in the phase noise measurement.

<b>Conditions</b>	Measurement views: Phase noise
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:PNOise:AVERage:ENABLe { OFF   ON   0   1 } [SENSe]:PNOise:AVERage:ENABLe?
<b>Arguments</b>	OFF disables averaging trace. ON enables averaging trace.
<b>Examples</b>	SENSE:PNOISE:AVERAGE:ENABLE ON enables averaging trace.

## [SENSe]:PNOise:CARRier:FREQuency:TRACk

Determines whether to enable or disable tracking the carrier frequency in the phase noise measurement.

<b>Conditions</b>	Measurement views: Phase noise
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:PNOise:CARRier:FREQUency:TRACk { OFF   ON   0   1 } [SENSe]:PNOise:CARRier:FREQUency:TRACk?
<b>Arguments</b>	OFF or 0 disables tracking the carrier frequency. ON or 1 enables tracking the carrier frequency.
<b>Examples</b>	SENSE:PNOISE:CARRIER:FREQUENCY:TRACK ON enables tracking the carrier frequency.

## [SENSe]:PNOise:CARRier:THReshold

Sets or queries the threshold level to detect the carrier in the phase noise measurement.

<b>Conditions</b>	Measurement views: Phase noise
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:PNOise:CARRier:THReshold <value> [SENSe]:PNOise:CARRier:THReshold?
<b>Arguments</b>	<value> ::= <NRF> specifies the threshold level above which the input signal is determined to be a carrier. Range: -60 to 0 dBm.
<b>Examples</b>	SENSE:PNOISE:CARRIER:THRESHOLD -25 sets the carrier threshold level to -25 dB.

## [SENSe]:PNOise:CLEar:RESults (No Query Form)

Restarts the average process, clearing average data and counter.

<b>Conditions</b>	Measurement views: Phase noise
-------------------	--------------------------------

<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSE]:PNOise:CLEAR:RESuLts
<b>Arguments</b>	None
<b>Examples</b>	SENSE:PNOISE:CLEAR:RESULTS restarts the average process.

### [SENSE]:PNOise:FREQuency:INTEgration:OFFSet:START

Sets or queries the start offset frequency for integration in the phase noise measurement.

<b>Conditions</b>	Measurement views: Phase noise
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSE]:PNOise:FREQuency:INTEgration:OFFSet:START <value> [SENSE]:PNOise:FREQuency:INTEgration:OFFSet:START?
<b>Arguments</b>	<value>::=<NRF> specifies the start offset frequency for integration. It must be less than the stop offset frequency. Range: 10 Hz to Stop Offset Frequency - 1 Hz.
<b>Examples</b>	SENSE:PNOISE:FREQUENCY:INTEGRATION:OFFSET:START 100kHz sets the start offset frequency for integration to 100 kHz.

### [SENSE]:PNOise:FREQuency:INTEgration:OFFSet:STOP

Sets or queries the stop offset frequency for integration in the phase noise measurement.

<b>Conditions</b>	Measurement views: Phase noise
<b>Group</b>	Sense commands

**Syntax** [SENSE]:PNOise:FREQUENCY:INTEGRation:OFFSet:STOP <value>  
[SENSE]:PNOise:FREQUENCY:INTEGRation:OFFSet:STOP?

**Arguments** <value>::=<Nrf> specifies the stop offset frequency for integration.  
It must be greater than the start offset frequency.  
Range: 11 Hz to 1 GHz.

**Examples** SENSE:PNOISE:FREQUENCY:INTEGRATION:OFFSET:STOP 100MHZ sets the stop offset frequency for integration to 100 MHz.

## [SENSE]:PNOise:FREQUENCY:PLOT:OFFSet:START

Sets or queries the start offset frequency for plotting the phase noise trace.

**Conditions** Measurement views: Phase noise

**Group** Sense commands

**Syntax** [SENSE]:PNOise:FREQUENCY:PLOT:OFFSet:START <value>  
[SENSE]:PNOise:FREQUENCY:PLOT:OFFSet:START?

**Arguments** <value>::=<Nrf> specifies the start offset frequency for the trace plot.  
It must be less than the stop offset frequency.  
Range: 10 Hz to 100 MHz in a tenfold sequence.

**Examples** SENSE:PNOISE:FREQUENCY:PLOT:OFFSET:START 100kHz sets the start offset frequency for plot to 100 kHz.

## [SENSE]:PNOise:FREQUENCY:PLOT:OFFSet:STOP

Sets or queries the stop offset frequency for plotting the phase noise trace.

**Conditions** Measurement views: Phase noise

**Group** Sense commands

**Syntax** [SENSE]:PNOise:FREQUENCY:PLOT:OFFSet:STOP <value>  
[SENSE]:PNOise:FREQUENCY:PLOT:OFFSet:STOP?

- Arguments** <value> ::= <Nrf> specifies the stop offset frequency for plot. It must be greater than the start offset frequency. Range: 100 Hz to 1 GHz in a tenfold sequence.
- Examples** SENSE:PNOISE:FREQUENCY:PLOT:OFFSET:STOP 100MHZ sets the stop offset frequency for plot to 100 MHz.

## [SENSe]:PNOise:OPTimization

Selects or queries the method of optimizing the gain and input bandwidth in the phase noise measurement.

- Conditions** Measurement views: Phase noise
- Group** Sense commands
- Syntax** [SENSe]:PNOise:OPTimization { DRANge | SPEEd }  
[SENSe]:PNOise:OPTimization?
- Arguments** DRANge optimizes the gain and input bandwidth to maximize the dynamic range. SPEEd optimizes the gain and input bandwidth to speed the measurement.
- Examples** SENSE:PNOISE:OPTIMIZATION DRANge optimizes the gain and input bandwidth to maximize the dynamic range.

## [SENSe]:POWER:UNITs

Selects or queries the fundamental unit of power.

- Conditions** Measurement views: All
- Group** Sense commands
- Syntax** [SENSe]:POWER:UNITs { DBM | DBV | VOLTS | WATTS | DBUW | DBW | DBUV | DBMV | DBUA | DBUV\_M | DBUA\_M | AMPS }  
[SENSe]:POWER:UNITs?



**Arguments** The following table lists the arguments.

**Table 2-42: Power units**

Argument	Power unit
DBM	dBm
DBV	dBV
VOLTs	Volts
WATTs	Watts
DBUW	dB $\mu$ W
DBW	dBW
DBUV	dB $\mu$ V
DBMV	dBmV
DBUA	dB $\mu$ A
DBUV_M	dB $\mu$ V/m
DBUA_M	dB $\mu$ A/m
AMPS	Amps

**NOTE.** Select dB $\mu$ V/m or dB $\mu$ A/m unit when using an antenna table.

**Examples** SENSE:POWER:UNITS DBM specifies the fundamental unit of power as dBm.

## [SENSe]:PULSe:ANALyze:LEVel

Selects or queries how to determine the 50% level for the pulsed RF measurements.

**Conditions** Measurement views: Pulse statistics, Pulse table, Pulse trace

**Group** Sense commands

**Syntax** [SENSe]:PULSe:ANALyze:LEVel { VOLTage | POWER }  
[SENSe]:PULSe:ANALyze:LEVel?

**Arguments** VOLTage uses -6 dB to determine the 50% level.  
POWER uses -3 dB to determine the 50% level.

**Examples** SENSE:PULSe:ANALyze:LEVel POWER uses -3 dB to determine the 50% level.

## [SENSe]:PULSe:ANALyze:LEVel:FIFTy

Selects or queries how to determine the 50% level for the pulsed RF measurements. This command is equivalent to the [\[SENSe\]:PULSe:ANALyze:LEVel](#) command.

<b>Conditions</b>	Measurement views: Pulse statistics, Pulse table, Pulse trace
<b>Group</b>	Sense commands
<b>Syntax</b>	<code>[SENSe]:PULSe:ANALyze:LEVel:FIFTy { VOLTage   POWER }</code> <code>[SENSe]:PULSe:ANALyze:LEVel:FIFTy?</code>
<b>Arguments</b>	<code>VOLTage</code> uses -6 dB to determine the 50% level. <code>POWER</code> uses -3 dB to determine the 50% level.
<b>Examples</b>	<code>SENSe:PULSe:ANALyze:LEVel:FIFTy POWER</code> uses -3 dB to determine the 50% level.

## [SENSe]:PULSe:ANALyze:LEVel:HUNDred

Selects or queries how to determine the 100% level in the pulsed RF measurements. This command is equivalent to the [\[SENSe\]:PULSe:ANALyze:POINt:LOCation](#) command.

<b>Conditions</b>	Measurement views: Pulse statistics, Pulse table, Pulse trace
<b>Group</b>	Sense commands
<b>Syntax</b>	<code>[SENSe]:PULSe:ANALyze:LEVel:HUNDred { AVERAge   INDEpendent }</code> <code>[SENSe]:PULSe:ANALyze:LEVel:HUNDred?</code>

### Related Commands

<b>Arguments</b>	<code>AVERAge</code> uses the average amplitude calculated for the pulse-on as the 100% reference to measure the rise and fall times. <code>INDEpendent</code> uses the amplitudes at the beginning and end of the pulse-on as the 100% references to measure the rise and fall times, respectively
------------------	--

**Examples**     `SENSE:PULSE:ANALYZE:LEVEL:HUNDRED AVERAGE` uses pulse average amplitude to set the 100% level.

## **[SENSe]:PULSe:ANALyze:MEASurement:TIME:AUTO**

Determines whether to set the measurement time for frequency and phase results automatically or manually in the pulsed RF measurements.

**Conditions**     Measurement views: Pulse statistics, Pulse table, Pulse trace

**Group**     Sense commands

**Syntax**     `[SENSe]:PULSe:ANALyze:MEASurement:TIME:AUTO { OFF | ON | 0 | 1 }`  
`[SENSe]:PULSe:ANALyze:MEASurement:TIME:AUTO?`

**Arguments**     OFF or 0 sets the measurement time manually. Use the [\[SENSe\]:PULSe:ANALyze:MEASurement:TIME:START](#) and [\[SENSe\]:PULSe:ANALyze:MEASurement:TIME:STOP](#) commands to set the measurement start and stop time.

ON or 1 sets the measurement time automatically.

**Examples**     `SENSE:PULSE:ANALYZE:MEASUREMENT:TIME:AUTO ON` sets the measurement time for frequency and phase results automatically.

## **[SENSe]:PULSe:ANALyze:MEASurement:TIME:START**

Sets or queries the measurement start time for frequency and phase results in the pulsed RF measurements.

**Conditions**     Measurement views: Pulse statistics, Pulse table, Pulse trace

**Group**     Sense commands

**Syntax**     `[SENSe]:PULSe:ANALyze:MEASurement:TIME:START <value>`  
`[SENSe]:PULSe:ANALyze:MEASurement:TIME:START?`

**Related Commands**     [\[SENSe\]:PULSe:ANALyze:MEASurement:TIME:STOP](#)

**Arguments**     `<value>::=<Nrf>` specifies the measurement start time from the 50% level of the pulse rising edge. Range: -100 to 100 ms.

**Examples**     `SENSe:PULSe:ANALyze:MEASurement:TIME:START 2.8us` sets the start time to 2.8  $\mu$ s from the 50% level of the pulse rising edge.

## [SENSe]:PULSe:ANALyze:MEASurement:TIME:STOP

Sets or queries the measurement stop time for frequency and phase results in the pulsed RF measurements.

**Conditions**     Measurement views: Pulse statistics, Pulse table, Pulse trace

**Group**            Sense commands

**Syntax**           `[SENSe]:PULSe:ANALyze:MEASurement:TIME:STOP <value>`  
`[SENSe]:PULSe:ANALyze:MEASurement:TIME:STOP?`

**Related Commands**     [\[SENSe\]:PULSe:ANALyze:MEASurement:TIME:START](#)

**Arguments**     `<value>::=<Nrf>` specifies the measurement stop time from the 50% level of the pulse falling edge. Range: -100 to 100 ms.

**Examples**     `SENSe:PULSe:ANALyze:MEASurement:TIME:STOP 1.2us` sets the stop time to 1.2  $\mu$ s from the 50% level of the pulse falling edge.

## [SENSe]:PULSe:ANALyze:PMLocation

Sets or queries the phase measurement location (the position along the pulse tops where the phase is measured) in the pulse-pulse phase measurement.

**Conditions**     Measurement views: Pulse statistics, Pulse table, Pulse trace

**Group**            Sense commands

**Syntax**           `[SENSe]:PULSe:ANALyze:PMLocation <value>`  
`[SENSe]:PULSe:ANALyze:PMLocation?`

**Arguments** <value> ::= <NRF> specifies the pulse-pulse phase measurement location.  
Range: 5 ns to 100 ms.

**Examples** SENSE:PULSE:ANALYZE:PMLOCATION 1.5ms sets the phase measurement location to 1.5 ms.

## [SENSE]:PULSE:ANALYZE:POINT:LOCATION

Selects or queries the point location method in the pulsed RF measurements.

**Conditions** Measurement views: Pulse statistics, Pulse table, Pulse trace

**Group** Sense commands

**Syntax** [SENSE]:PULSE:ANALYZE:POINT:LOCATION { AVERAGE | INDEPENDENT }  
[SENSE]:PULSE:ANALYZE:POINT:LOCATION?

**Arguments** AVERAGE uses the average amplitude calculated for the pulse-on as the 100% reference to measure the rise and fall times.  
INDEPENDENT uses the amplitudes at the beginning and end of the pulse-on as the 100% references to measure the rise and fall times, respectively.

**Examples** SENSE:PULSE:ANALYZE:POINT:LOCATION AVERAGE uses pulse average amplitude to locate points.

## [SENSE]:PULSE:ANALYZE:RFALI

Selects or queries the threshold levels to measure the rise/fall time.

**Conditions** Measurement views: Pulse statistics, Pulse table, Pulse trace

**Group** Sense commands

**Syntax** [SENSE]:PULSE:ANALYZE:RFALI { WIDE | NARROW }  
[SENSE]:PULSE:ANALYZE:RFALI?

- Arguments**     WIDE selects 10 – 90% to measure the rise/fall time.  
                       NARROW selects 20 – 80% to measure the rise/fall time.
- Examples**     SENSE:PULSE:ANALYZE:RFALL WIDE selects 10 – 90% to measure the rise/fall time.

## [SENSe]:PULSe:ANALyze:RIPPlE

Sets or queries the ripple portion of the pulse top (that is, how much of the beginning and end of the pulse top is excluded from the ripple calculation).

- Conditions**     Measurement views: Pulse statistics, Pulse table, Pulse trace
- Group**            Sense commands
- Syntax**           [SENSe]:PULSe:ANALyze:RIPPlE <value>  
                       [SENSe]:PULSe:ANALyze:RIPPlE?
- Arguments**     <value>::=<NRF> specifies the ripple portion of the pulse top.  
                       Range: 10 to 100% in 1% steps.
- Examples**     SENSE:PULSE:ANALYZE:RIPPLE 30 sets the ripple portion to 30% of the pulse top.

## [SENSe]:PULSe:CARRier:OFFSet

Sets or queries the carrier frequency offset.

- Conditions**     Measurement views: Pulse statistics, Pulse table, Pulse trace
- Group**            Sense commands
- Syntax**           [SENSe]:PULSe:CARRier:OFFSet <value>  
                       [SENSe]:PULSe:CARRier:OFFSet?
- Related Commands**    [\[SENSe\]:PULSe:CARRier:SEARCh](#)

**Arguments** <value> ::= <NRF> specifies the carrier frequency offset.  
Range: -50 kHz to +50 kHz.

**Examples** SENSE:PULSE:CARRIER:OFFSET 2.5kHz sets the offset frequency to 2.5 kHz to the carrier.

## [SENSe]:PULSe:CARRier:SEARCh

Selects or queries how to detect the carrier in the pulsed RF measurements.

**Conditions** Measurement views: Pulse statistics, Pulse table, Pulse trace

**Group** Sense commands

**Syntax** [SENSe]:PULSe:CARRier:SEARCh { AUTO | MANua1 }  
[SENSe]:PULSe:CARRier:SEARCh?

**Arguments** AUTO specifies that the carrier is detected automatically.  
MANua1 specifies that the carrier frequency offset is set manually, using the [\[SENSe\]:PULSe:CARRier:OFFSet](#) command.

**Examples** SENSE:PULSE:CARRIER:SEARCH AUTO specifies that the carrier is detected automatically.

## [SENSe]:PULSe:DETEct:MEASurement

Determines whether or not to set the maximum number of pulses to measure within the analysis time.

**Conditions** Measurement views: Pulse statistics, Pulse table, Pulse trace

**Group** Sense commands

**Syntax** [SENSe]:PULSe:DETEct:MEASurement { OFF | ON | 0 | 1 }  
[SENSe]:PULSe:DETEct:MEASurement?

- Arguments** OFF or 0 measures all pulses (max. 1000) in the analysis time.  
 ON or 1 specifies that the maximum number of pulses is set manually, using the `[SENSe]:PULSe:DETECT:NUMBER` command.
- Examples** `SENSe:PULSe:DETECT:MEASUREMENT ON` specifies that the maximum number of pulses is set manually.

## `[SENSe]:PULSe:DETECT:NUMBER`

Sets or queries the maximum number of pulses to measure within the analysis time when `[SENSe]:PULSe:DETECT:MEASUREMENT` is On.

- Conditions** Measurement views: Pulse statistics, Pulse table, Pulse trace
- Group** Sense commands
- Syntax** `[SENSe]:PULSe:DETECT:NUMBER <value>`  
`[SENSe]:PULSe:DETECT:NUMBER?`
- Arguments** `<value>::=<NRF>` specifies the maximum number of pulses to measure within the analysis time. Range: 1 to 1000.  
 If the analysis time contains fewer pulses than this number, all of these are measured.
- Examples** `SENSe:PULSe:DETECT:NUMBER 850` sets the maximum number of pulses to 850.

## `[SENSe]:PULSe:DETECT:POWER[:THReshold]`

Sets or queries the power threshold to detect pulses.

- Conditions** Measurement views: Pulse statistics, Pulse table, Pulse trace
- Group** Sense commands
- Syntax** `[SENSe]:PULSe:DETECT:POWER[:THReshold] <value>`  
`[SENSe]:PULSe:DETECT:POWER[:THReshold]?`



**Arguments** `<value>::=<Nrf>` specifies the power threshold to detect pulses.  
Range: -70 to 0 dB.

**Examples** `SENSE:PULSE:DETECT:POWER:THRESHOLD -20` sets the power threshold to -20 dB.

## [SENSE]:PULSE:DETECT:TIME[:THRESHOLD]

Sets or queries the minimum off-time between pulses.

**Conditions** Measurement views: Pulse statistics, Pulse table, Pulse trace

**Group** Sense commands

**Syntax** `[SENSE]:PULSE:DETECT:TIME[:THRESHOLD] <value>`  
`[SENSE]:PULSE:DETECT:TIME[:THRESHOLD]?`

**Arguments** `<value>::=<Nrf>` specifies the minimum off-time between pulses.  
Range: 1 ns to 100 ms.

**Examples** `SENSE:PULSE:DETECT:TIME:THRESHOLD 1.5ms` sets the time threshold to 1.5 ms.

## [SENSE]:PULSE:FILTER:{BANDWIDTH|BWIDTh}

Sets or queries the filter or acquisition bandwidth when `[SENSE]:PULSE:FILTER:MEASUREMENT` is set to GAUSSian or NONE (No filter), respectively.

**Conditions** Measurement views: Pulse statistics, Pulse table, Pulse trace

**Group** Sense commands

**Syntax** `[SENSE]:PULSE:FILTER:{BANDWIDTH|BWIDTh} <value>`  
`[SENSE]:PULSE:FILTER:{BANDWIDTH|BWIDTh}?`

**Related Commands** [\[SENSE\]:PULSE:FILTER:MEASUREMENT](#)

**Arguments** <value>::=<Nrf> specifies the filter/acquisition bandwidth depending the [SENSe]:PULSe:FILTer:MEASurement setting. The table below shows the setting range. You can enter any value, but it is rounded up to the next valid number.

[SENSe]:PULSe:FILTer:MEASurement	Range
GAUSSian	100 Hz to 20 MHz (Standard) / 100 Hz to 55 MHz (Option 110) in 1-2-3-5 sequence.
NONE	152, 305, 610, 1.22 k, 2.44 k, 4.88 k, 9.76 k, 19.3 k, 39 k, 78 k, 156 k, 312 k, 625 k, 1.25 M, 2.5 M, 5 M, 10 M, 20 M, 40 MHz, and optionally 60 M and 110 MHz (Option 110).

**Examples** SENSE:PULSE:FILTER:BANDWIDTH 10MHZ sets the filter bandwidth to 10 MHz.

## [SENSe]:PULSe:FILTer:MEASurement

Selects or queries the measurement filter in the pulsed RF measurements.

**Conditions** Measurement views: Pulse statistics, Pulse table, Pulse trace

**Group** Sense commands

**Syntax** [SENSe]:PULSe:FILTer:MEASurement { GAUSSian | NONE | MAXRtbw }  
[SENSe]:PULSe:FILTer:MEASurement?

**Related Commands** [SENSe]:PULSe:FILTer: {BANDwidth|BWIDth}

**Arguments** GAUSSian uses the Gaussian filter in the pulsed RF measurements. Use the [SENSe]:PULSe:FILTer: {BANDwidth|BWIDth} command to set the filter bandwidth.

NONE uses no filter. Use the [SENSe]:PULSe:FILTer: {BANDwidth|BWIDth} command to set the acquisition bandwidth.

MAXRtbw uses no filter. The acquisition bandwidth is fixed to the maximum real-time bandwidth: 40 MHz (Standard) or 110 MHz (Option 110).

**Examples** SENSE:PULSE:FILTER:MEASUREMENT GAUSSian uses the Gaussian filter in the pulsed RF measurements.

## [SENSe]:PULSe:FREFerence:AUTO

Determines whether to estimate the pulse frequency reference automatically or manually in the pulsed RF measurements.

<b>Conditions</b>	Measurement views: Pulse statistics, Pulse table, Pulse trace
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:PULSe:FREFerence:AUTO { OFF   ON   0   1 } [SENSe]:PULSe:FREFerence:AUTO?
<b>Arguments</b>	OFF or 0 estimates the frequency reference manually. Use the <a href="#">[SENSe]:PULSe:FREFerence:OFFSet</a> command to set the frequency offset. Use the <a href="#">[SENSe]:PULSe:FREFerence:CHIRpbw</a> command to set the chirp bandwidth.  ON or 1 estimates the frequency reference automatically.
<b>Examples</b>	SENSE:PULSE:FREFERENCE:AUTO ON specifies that the frequency reference is estimated automatically.

## [SENSe]:PULSe:FREFerence:CHIRpbw

Sets or queries the chirp bandwidth. This command is valid when [\[SENSe\]:PULSe:MODulation:TYPE](#) is set to LChirp and [\[SENSe\]:PULSe:FREFerence:AUTO](#) is set to OFF.

<b>Conditions</b>	Measurement views: Pulse statistics, Pulse table, Pulse trace
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:PULSe:FREFerence:CHIRpbw <value> [SENSe]:PULSe:FREFerence:CHIRpbw?
<b>Arguments</b>	<value>::=<NRf> specifies the chirp bandwidth. Range: 100 Hz to 40 MHz (Standard) / 110 MHz (Option 110).
<b>Examples</b>	SENSE:PULSE:FREFERENCE:CHIRPBW 1.5MHZ sets the chirp bandwidth to 1.5 MHz.

## [SENSe]:PULSe:FREFerence:OFFSet

Sets or queries the frequency reference offset. This command is valid when [\[SENSe\]:PULSe:FREFerence:AUTO](#) is set to OFF.

<b>Conditions</b>	Measurement views: Pulse statistics, Pulse table, Pulse trace
<b>Group</b>	Sense commands
<b>Syntax</b>	<code>[SENSe]:PULSe:FREFerence:OFFSet &lt;value&gt;</code> <code>[SENSe]:PULSe:FREFerence:OFFSet?</code>
<b>Arguments</b>	<code>&lt;value&gt;::=&lt;NRF&gt;</code> specifies the frequency reference offset. Range: -50 kHz to +50 kHz.
<b>Examples</b>	<code>SENSe:PULSe:FREFerence:OFFSet 2.5kHz</code> sets the frequency offset to 2.5 kHz to the reference.

## [SENSe]:PULSe:MODulation:TYPE

Selects or queries the modulation type in the pulsed RF measurements. This command is equivalent to the [\[SENSe\]:PULSe:SIGNal:TYPE](#) command.

<b>Conditions</b>	Measurement views: Pulse statistics, Pulse table, Pulse trace
<b>Group</b>	Sense commands
<b>Syntax</b>	<code>[SENSe]:PULSe:MODulation:TYPE { CWConst   CWCHange   LCHirp }</code> <code>[SENSe]:PULSe:MODulation:TYPE?</code>
<b>Arguments</b>	<code>CWConst</code> selects the CW (continuous wave) with constant phase. <code>CWCHange</code> selects the CW (continuous wave) with changing phase. <code>LCHirp</code> selects the linear chirp.
<b>Examples</b>	<code>SENSe:PULSe:MODULATION:TYPE CWCHange</code> selects the CW with changing phase as the modulation type.

## [SENSE]:PULSE:SIGNAl:TYPE

Selects or queries the signal type in the pulsed RF measurements.

<b>Conditions</b>	Measurement views: Pulse statistics, Pulse table, Pulse trace
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSE]:PULSE:SIGNAl:TYPE { CWConst   CWCHange   LCHirp } [SENSE]:PULSE:SIGNAl:TYPE?
<b>Arguments</b>	CWConst selects the CW (continuous wave) with constant phase. CWCHange selects the CW (continuous wave) with changing phase. LCHirp selects the linear chirp.
<b>Examples</b>	SENSE:PULSE:SIGNAl:TYPE CWCHange selects the CW with changing phase as the signal type.

## [SENSE]:REANalyze (No Query Form)

Have all measurements reanalyze the current acquisition record.

---

**NOTE.** *It is an overlapped command, which does not finish executing before the next command starts executing. Use the \*OPC(?) and \*WAI commands to synchronize all pending operations to the execution of this command.*

---

<b>Conditions</b>	Measurement views: All
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSE]:REANalyze
<b>Related Commands</b>	*OPC, *WAI
<b>Arguments</b>	None

**Examples**     `SENSE:REANALYZE` have all measurements reanalyze the current acquisition record.

## **[SENSe]:ROSCillator:SOURce**

Selects or queries the frequency reference oscillator source.

**Conditions**     Measurement views: All

**Group**            Sense commands

**Syntax**           `[SENSe]:ROSCillator:SOURce { INTERNAL | EXTERNAL }`  
`[SENSe]:ROSCillator:SOURce?`

**Arguments**       `INTERNAL` specifies that the analyzer uses the 10 MHz internal oscillator.  
`EXTERNAL` specifies that the analyzer uses the external reference signal. Use the Ref In connector on the rear panel to input the signal.  
 Selecting `EXTERNAL` initiates an attempt to lock the internal reference oscillator to the external reference signal. If the signal is not connected or is at an invalid frequency or amplitude, an error (2028, "External frequency reference signal not valid. Using internal reference") is returned. If not able to lock to the external reference, an error (2029, "Unable to lock to external frequency reference. Using internal reference.") is returned.

**Examples**        `SENSE:ROSCILLATOR:SOURCE INTERNAL` uses the 10 MHz internal oscillator for the frequency reference.

## **[SENSe]:SGRam:{BANDwidth|BWIDth}:OPTimization**

Selects or queries the method of optimizing the gain and input bandwidth in the spectrogram.

**Conditions**       Measurement views: Spectrogram

**Group**            Sense commands

**Syntax**           `[SENSe]:SGRam:{BANDwidth|BWIDth}:OPTimization { AUTO |`  
`MAXDynrange | MINNoise | MINTime }`  
`[SENSe]:SGRam:{BANDwidth|BWIDth}:OPTimization?`

<b>Arguments</b>	AUTO optimizes automatically the gain and input bandwidth. MAXDynrange optimizes the gain and input bandwidth to maximize the dynamic range. MINNoise optimizes the gain and input bandwidth to minimize noise. MINTime optimizes the gain and input bandwidth to minimize sweep time.
<b>Examples</b>	SENSE:SGRAM:BANDWIDTH:OPTIMIZATION AUTO optimizes automatically the gain and input bandwidth.

## [SENSE]:SGRam:{BANDwidth|BWIDth}:RESolution

Sets or queries the resolution bandwidth (RBW). Programming a specified RBW sets [SENSE]:SGRam{BANDwidth|BWIDth}:RESolution:AUTO OFF.

<b>Conditions</b>	Measurement views: Spectrogram
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSE]:SGRam:{BANDwidth BWIDth}:RESolution <value> [SENSE]:SGRam:{BANDwidth BWIDth}:RESolution?
<b>Related Commands</b>	<a href="#">[SENSE]:SGRam:{BANDwidth BWIDth}[:RESolution]:AUTO</a>
<b>Arguments</b>	<value> ::= <NRf> specifies the RBW. Range: 1 Hz to 10 MHz.
<b>Examples</b>	SENSE:SGRAM:BANDWIDTH:RESOLUTION 200kHz sets the RBW to 200 kHz.

## [SENSE]:SGRam:{BANDwidth|BWIDth}[:RESolution]:ACTual? (Query Only)

Queries the actual resolution bandwidth (RBW) in the spectrogram.

<b>Conditions</b>	Measurement views: Spectrogram
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSE]:SGRam:{BANDwidth BWIDth}[:RESolution]:ACTual?

<b>Arguments</b>	None
<b>Returns</b>	<Nrf> The actual RBW in Hz.
<b>Examples</b>	SENSE:SGRAM:BANDWIDTH:RESOLUTION:ACTUAL? might return 299.624E+3, indicating that the actual RBW is 299.624 kHz.

## [SENSe]:SGRam:{BANDwidth|BWIDth}[:RESolution]:AUTO

Determines whether to set the resolution bandwidth (RBW) automatically or manually in the spectrogram.

<b>Conditions</b>	Measurement views: Spectrogram
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:SGRam:{BANDwidth BWIDth}[:RESolution]:AUTO { OFF   ON   0   1 } [SENSe]:SGRam:{BANDwidth BWIDth}[:RESolution]:AUTO?
<b>Arguments</b>	OFF or 0 specifies that the resolution bandwidth is set manually using the [SENSe]:DPSA:{BANDwidth BWIDth}:ACTual? command. ON or 1 specifies that the resolution bandwidth is set automatically.
<b>Examples</b>	SENSE:SGRAM:BANDWIDTH:RESOLUTION:AUTO ON sets the resolution bandwidth automatically.

## [SENSe]:SGRam:{BANDwidth|BWIDth}[:RESolution]:MODE

Determines whether to enable or disable the RBW processing in the spectrogram.

<b>Conditions</b>	Measurement views: Spectrogram
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:SGRam:{BANDwidth BWIDth}[:RESolution]:MODE { OFF   ON   0   1 } [SENSe]:SGRam:{BANDwidth BWIDth}[:RESolution]:MODE?



<b>Arguments</b>	OFF or 0 disables the RBW processing. You can select the FFT window using the <code>[SENSe]:SGRam:FFT:WINDow</code> command.  ON or 1 enables the RBW processing. Refer to the <code>[SENSe]:SGRam:{BANDwidth BWIDth}:RESolution</code> command to set the RBW.
<b>Examples</b>	<code>SENSE:SGRAM:BANDWIDTH:RESOLUTION:MODE ON</code> enables the RBW processing.

## `[SENSe]:SGRam:{BANDwidth|BWIDth}:VIDeo`

Sets or queries the video bandwidth (VBW). Programming a specified VBW sets `[SENSe]:SGRam:{BANDwidth|BWIDth}:VIDeo:STATe` OFF.

<b>Conditions</b>	Measurement views: Spectrogram
<b>Group</b>	Sense commands
<b>Syntax</b>	<code>[SENSe]:SGRam:{BANDwidth BWIDth}:VIDeo &lt;value&gt;</code> <code>[SENSe]:SGRam:{BANDwidth BWIDth}:VIDeo?</code>
<b>Related Commands</b>	<code>[SENSe]:SGRam:{BANDwidth BWIDth}:VIDeo:STATe</code>
<b>Arguments</b>	<code>&lt;value&gt;::=&lt;NRf&gt;</code> specifies the VBW. Range: Current RBW/10 <sup>4</sup> (1 Hz minimum) to Current RBW.
<b>Examples</b>	<code>SENSE:SGRAM:BANDWIDTH:VIDEO 200kHz</code> sets the VBW to 200 kHz.

## `[SENSe]:SGRam:{BANDwidth|BWIDth}:VIDeo:STATe`

Determines whether to enable or disable the video bandwidth (VBW) in the spectrogram measurement.

<b>Conditions</b>	Measurement views: Spectrogram
<b>Group</b>	Sense commands
<b>Syntax</b>	<code>[SENSe]:SGRam:{BANDwidth BWIDth}:VIDeo:STATe { OFF   ON   0   1 }</code>

[SENSE]:SGRAM:{BANDwidth|BWIDth}:VIDeo:STATE?

**Arguments** OFF or 0 disables the VBW.  
ON or 1 enables the VBW.

**Examples** SENSE:SGRAM:BANDWIDTH:VIDEO:STATE ON enables the VBW.

## [SENSE]:SGRAM:COLor

Selects or queries the color palette of three-dimensional graphs.

**Conditions** Measurement views: Spectrogram

**Group** Sense commands

**Syntax** [SENSE]:SGRAM:COLor { RED | GREen | BLUe | CYAN | BCYan |  
YELLOW | MAGenta | GRAY | TEMPerature | SPECTra }  
[SENSE]:SGRAM:COLor?

**Arguments** The following table lists the arguments.

**Table 2-43: Color palette for spectrogram**

Argument	Palette
RED	Red
GREen	Green
BLUe	Blue
CYAN	Cyan
BCYan	Binary cyan
YELLow	Yellow
MAGenta	Magenta
GRAY	Gray
TEMPerature	Temperature
SPECTral	Spectral

**Examples** SENSE:SGRAM:COLOR TEMPerature selects the temperature color palette.

## [SENSe]:SGRam:COLor:MAXimum

Sets or queries the maximum value of the color axis in the spectrogram.

**Conditions** Measurement views: Spectrogram

**Group** Sense commands

**Syntax** [SENSe]:SGRam:COLor:MAXimum <value>  
[SENSe]:SGRam:COLor:MAXimum?

**Related Commands** [\[SENSe\]:SGRam:COLor:MINimum](#)

**Arguments** <value> ::= <NRF> specifies the maximum value of the color axis.  
Range: -100 to +100 dBm.

**Examples** SENSE:SGRAM:COLOR:MAXIMUM 10 sets the maximum value of the color axis to 10 dBm.

## [SENSe]:SGRam:COLor:MINimum

Sets or queries the minimum value of the color axis in the spectrogram.

**Conditions** Measurement views: Spectrogram

**Group** Sense commands

**Syntax** [SENSe]:SGRam:COLor:MINimum <value>  
[SENSe]:SGRam:COLor:MINimum?

**Related Commands** [\[SENSe\]:SGRam:COLor:MAXimum](#)

**Arguments** <value> ::= <NRF> specifies the minimum value of the color axis.  
Range: -100 to +100 dBm.

**Examples** SENSE:SGRAM:COLOR:MINIMUM 10 sets the minimum value of the color axis to 10 dBm.

## [SENSe]:SGRam:FFT:WINDow

Selects or queries the FFT window in the spectrogram. This command is equivalent to [\[SENSe\]:SGRam:FILTer\[:SHAPE\]](#).

**Conditions** Measurement views: Spectrogram

**Group** Sense commands

**Syntax** [SENSe]:SGRam:FFT:WINDow { KAISer | MIL6db | CISPr | BH4B | UNIFORM | FLATtop | HANNing }  
[SENSe]:SGRam:FFT:WINDow?

**Arguments** KAISer selects the Kaiser (RBW) window.  
MIL6db selects the -6 dB RBW (MIL) window.  
CISPr selects the CISPR window.  
FLATtop selects the flat-top window.  
HANNing selects the Hanning window.  
BH4B selects the Blackman-Harris 4B type window.  
UNIFORM selects the uniform window.

**Examples** SENSE:SGRAM:FFT:WINDOW HANNing selects the Hanning window.

## [SENSe]:SGRam:FILTer[:SHAPE]

Selects or queries the filter shape in the spectrogram. This command is equivalent to [\[SENSe\]:SGRam:FFT:WINDow](#).

**Conditions** Measurement views: Spectrogram

**Group** Sense commands

**Syntax** [SENSe]:SGRam:FILTer[:SHAPE] { KAISer | MIL6db | CISPr | BH4B | UNIFORM | FLATtop | HANNing }  
[SENSe]:SGRam:FILTer[:SHAPE]?

**Arguments**    **KAISeR** selects the Kaiser (RBW) window.  
**MIL6db** selects the -6 dB RBW (MIL) window.  
**CISPr** selects the CISPR window.  
**FLATtop** selects the flat-top window.  
**HANNing** selects the Hanning window.  
**BH4B** selects the Blackman-Harris 4B type window.  
**UNIFORM** selects the uniform window.

**Examples**    **SENSE:SGRAM:FILTER:SHAPE HANNing** selects the Hanning window.

## [SENSe]:SGRam:FREQuency:CENTer

Sets or queries the center frequency in the spectrogram.

---

**NOTE.** *The center, start and stop frequencies are set interlocking each other with the following relationships: (start frequency) = (center frequency) - (span)/2 and (stop frequency) = (center frequency) + (span)/2.*

---

**Conditions**    Measurement views: Spectrogram

**Group**    Sense commands

**Syntax**    [SENSe]:SGRam:FREQuency:CENTer <value>  
 [SENSe]:SGRam:FREQuency:CENTer?

**Related Commands**    [SENSe]:SGRam:FREQuency:START, [SENSe]:SGRam:FREQuency:STOP

**Arguments**    <value>::=<NRF> specifies the center frequency.  
 Range: 0 Hz to 6.2 GHz (RSA6106A) / 14 GHz (RSA6114A).

**Examples**    **SENSE:SGRAM:FREQUENCY:CENTER 7.5GHz** sets the center frequency to 7.5 GHz.

## [SENSe]:SGRam:FREQuency:SPAN

Sets or queries the frequency span in the spectrogram.

<b>Conditions</b>	Measurement views: Spectrogram
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSE]:SGRAM:FREQUENCY:SPAN <value> [SENSE]:SGRAM:FREQUENCY:SPAN?
<b>Arguments</b>	<value>::=<NRF> specifies the frequency span. Range: 10 Hz to 6.2 GHz (RSA6106A) / 14 GHz (RSA6114A).
<b>Examples</b>	SENSE:SGRAM:FREQUENCY:SPAN 20MHZ sets the span to 20 MHz.

### [SENSE]:SGRAM:FREQUENCY:SPAN:BANDWIDTH[:RESOLUTION]:RATIO

Sets or queries the ratio of span to RBW (Resolution Bandwidth) in the spectrogram. This command is valid when [SENSE]:SGRAM:{BANDWIDTH|BWIDTh}[:RESOLUTION]:AUTO is set to On.

<b>Conditions</b>	Measurement views: Spectrogram
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSE]:SGRAM:FREQUENCY:SPAN:BANDWIDTH[:RESOLUTION]:RATIO <value> [SENSE]:SGRAM:FREQUENCY:SPAN:BANDWIDTH[:RESOLUTION]:RATIO?
<b>Arguments</b>	<value>::=<NRF> specifies the ratio of span to RBW. Range: 20 to 1000. Programming a specified ratio sets the RBW (= span/ratio), which is rounded down to the nearest valid value.
<b>Examples</b>	SENSE:SGRAM:FREQUENCY:SPAN:BANDWIDTH:RESOLUTION:RATIO 200 sets the ratio to 200, setting the RBW to 200 kHz for the span of 40 MHz.

### [SENSE]:SGRAM:FREQUENCY:SPAN:MAXIMUM (No Query Form)

Sets the frequency range to the maximum real-time span in the spectrogram.

<b>Conditions</b>	Measurement views: Spectrogram
-------------------	--------------------------------

<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSE]:SGRAM:FREQUENCY:SPAN:MAXIMUM <value>
<b>Arguments</b>	None
<b>Examples</b>	SENSE:SGRAM:FREQUENCY:SPAN:MAXIMUM sets the frequency range to the maximum real-time span.

## [SENSE]:SGRAM:FREQUENCY:START

Sets or queries the measurement start frequency (left edge of the graph) in the spectrogram.

The center, start and stop frequencies are set interlocking each other. Refer to the [\[SENSE\]:SGRAM:FREQUENCY:CENTER](#) command.

<b>Conditions</b>	Measurement views: Spectrogram
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSE]:SGRAM:FREQUENCY:START <value> [SENSE]:SGRAM:FREQUENCY:START?
<b>Related Commands</b>	<a href="#">[SENSE]:SGRAM:FREQUENCY:STOP</a>
<b>Arguments</b>	<value> ::= <NRF> is the measurement start frequency. Range: (center frequency) ± (span)/2.
<b>Examples</b>	SENSE:SGRAM:FREQUENCY:START 6.95GHZ sets the start frequency to 6.95 GHz.

## [SENSE]:SGRAM:FREQUENCY:STEP

Sets or queries the frequency step size. Programming a specified step size sets [SENSE]:SGRAM:FREQUENCY:STEP:AUTO OFF.

<b>Conditions</b>	Measurement views: Spectrogram
-------------------	--------------------------------

<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:SGRam:FREQUENCY:STEP <value> [SENSe]:SGRam:FREQUENCY:STEP?
<b>Related Commands</b>	<a href="#">[SENSe]:SGRam:FREQUENCY:STEP:AUTO</a>
<b>Arguments</b>	<value>::=<NRF> specifies the frequency step size. Range: 0 to 6.2 GHz (RSA6106A) / 14 GHz (RSA6114A).
<b>Examples</b>	SENSE:SGRAM:FREQUENCY:STEP 1kHz sets the frequency step size to 1 kHz.

## [SENSe]:SGRam:FREQUENCY:STEP:AUTO

Determines whether to set the frequency step size automatically or manually in the spectrogram.

<b>Conditions</b>	Measurement views: Spectrogram
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:SGRam:FREQUENCY:STEP:AUTO { OFF   ON   0   1 } [SENSe]:SGRam:FREQUENCY:STEP:AUTO?
<b>Arguments</b>	OFF or 0 specifies that the frequency step size is set manually using the <a href="#">[SENSe]:SGRam:FREQUENCY:STEP</a> command. ON or 1 specifies that the frequency step size is set automatically.
<b>Examples</b>	SENSE:SGRAM:FREQUENCY:STEP:AUTO ON specifies that the frequency step size is set automatically.

## [SENSe]:SGRam:FREQUENCY:STOP

Sets or queries the measurement stop frequency (right edge of the graph) in the spectrogram.

The center, start and stop frequencies are set interlocking each other. Refer to the [\[SENSe\]:SGRam:FREQUENCY:CENTer](#) command.



<b>Conditions</b>	Measurement views: Spectrogram
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSE]:SGRAM:FREQUENCY:STOP <value> [SENSE]:SGRAM:FREQUENCY:STOP?
<b>Related Commands</b>	<a href="#">[SENSE]:SGRAM:FREQUENCY:START</a>
<b>Arguments</b>	<value> ::= <NRF> is the measurement start frequency. Range: (center frequency) ± (span)/2.
<b>Examples</b>	SENSE:SGRAM:FREQUENCY:STOP 7.05GHZ sets the stop frequency to 7.05 GHz.

## [SENSE]:SPECTRUM:{BANDwidth|BWIDth}:OPTimization

Selects or queries the method of optimizing the gain and input bandwidth in the spectrum measurement.

<b>Conditions</b>	Measurement views: Spectrum
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSE]:SPECTRUM:{BANDwidth BWIDth}:OPTimization { AUTO   MAXDynrange   MINNoise   MINTime } [SENSE]:SPECTRUM:{BANDwidth BWIDth}:OPTimization?
<b>Arguments</b>	AUTO optimizes automatically the gain and input bandwidth.  MAXDynrange optimizes the gain and input bandwidth to maximize the dynamic range.  MINNoise optimizes the gain and input bandwidth to minimize noise.  MINTime optimizes the gain and input bandwidth to minimize sweep time.
<b>Examples</b>	SENSE:SPECTRUM:BANDWIDTH:OPTIMIZATION AUTO optimizes automatically the gain and input bandwidth.

**[SENSe]:SPECTrum:{BANDwidth|BWIDth}{:RESolution}**

Sets or queries the resolution bandwidth (RBW). Programming a specified RBW sets [SENSe]:SPECTrum:{BANDwidth|BWIDth}{:RESolution}:AUTO OFF.

<b>Conditions</b>	Measurement views: Spectrum
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:SPECTrum:{BANDwidth BWIDth}{:RESolution} <value> [SENSe]:SPECTrum:{BANDwidth BWIDth}{:RESolution}?
<b>Related Commands</b>	[SENSe]:SPECTrum:{BANDwidth BWIDth}{:RESolution}:AUTO
<b>Arguments</b>	<value>::=<Nrf> specifies the RBW. Range: 1 Hz to 10 MHz.
<b>Examples</b>	SENSE:SPECTRUM:BANDWIDTH:RESOLUTION 200kHz sets the RBW to 200 kHz.

**[SENSe]:SPECTrum:{BANDwidth|BWIDth}{:RESolution}:ACTual? (Query Only)**

Queries the actual resolution bandwidth (RBW) in the spectrum measurement.

<b>Conditions</b>	Measurement views: Spectrum
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:SPECTrum:{BANDwidth BWIDth}{:RESolution}:ACTual?
<b>Arguments</b>	None
<b>Returns</b>	<Nrf> The actual RBW in Hz.
<b>Examples</b>	SENSE:SPECTRUM:BANDWIDTH:RESOLUTION:ACTUAL? might return 299.624E+3, indicating that the actual RBW is 299.624 kHz.

## [SENSE]:SPECtrum:{BANDwidth|BWIDth}[:RESolution]:AUTO

Determines whether to set the resolution bandwidth (RBW) automatically or manually in the spectrum measurement.

<b>Conditions</b>	Measurement views: Spectrum
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSE]:SPECtrum:{BANDwidth BWIDth}[:RESolution]:AUTO { OFF   ON   0   1 } [SENSE]:SPECtrum:{BANDwidth BWIDth}[:RESolution]:AUTO?
<b>Arguments</b>	OFF or 0 specifies that the resolution bandwidth is set manually using the <a href="#">[SENSE]:SPECtrum:{BANDwidth BWIDth}[:RESolution]</a> command.  ON or 1 specifies that the resolution bandwidth is set automatically.
<b>Examples</b>	SENSE:SPECTRUM:BANDWIDTH:RESOLUTION:AUTO ON sets the resolution bandwidth automatically.

## [SENSE]:SPECtrum:{BANDwidth|BWIDth}[:RESolution]:MODE

Determines whether to enable or disable the RBW process.

<b>Conditions</b>	Measurement views: Spectrum
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSE]:SPECtrum:{BANDwidth BWIDth}[:RESolution]:MODE { OFF   ON   0   1 } [SENSE]:SPECtrum:{BANDwidth BWIDth}[:RESolution]:MODE?
<b>Arguments</b>	OFF or 0 disables the RBW process. You can select the FFT window using the <a href="#">[SENSE]:SPECtrum:FFT:WINDow</a> command.  ON or 1 enables the RBW process. Refer to the <a href="#">[SENSE]:SPECtrum:{BANDwidth BWIDth}[:RESolution]</a> command to set the RBW.

**Examples** SENSE:SPECTRUM:BANDWIDTH:RESOLUTION:MODE ON enables the RBW process.

## [SENSe]:SPECTrum:{BANDwidth|BWIDth}:VIDeo

Sets or queries the video bandwidth (VBW). Programming a specified VBW sets [SENSe]:SPECTrum{BANDwidth|BWIDth}:VIDeo:STATe OFF.

**Conditions** Measurement views: Spectrum

**Group** Sense commands

**Syntax** [SENSe]:SPECTrum:{BANDwidth|BWIDth}:VIDeo <value>  
[SENSe]:SPECTrum:{BANDwidth|BWIDth}:VIDeo?

**Arguments** <value>::=<Nrf> specifies the VBW.  
Range: Current RBW/10<sup>4</sup> (1 Hz minimum) to Current RBW.

**Examples** SENSE:SPECTRUM:BANDWIDTH:VIDEO 200kHz sets the VBW to 200 kHz.

## [SENSe]:SPECTrum:{BANDwidth|BWIDth}:VIDeo:STATe

Determines whether to enable or disable the video bandwidth (VBW) in the spectrum measurement.

**Conditions** Measurement views: Spectrum

**Group** Sense commands

**Syntax** [SENSe]:SPECTrum:{BANDwidth|BWIDth}:VIDeo:STATe { OFF | ON  
| 0 | 1 }  
[SENSe]:SPECTrum:{BANDwidth|BWIDth}:VIDeo:STATe?

**Arguments** OFF or 0 disables the VBW.  
ON or 1 enables the VBW.

**Examples** SENSE:SPECTRUM:BANDWIDTH:VIDEO:STATE ON enables the VBW.

## [SENSe]:SPECtrum:CLEar:RESuLts (No Query Form)

Restarts multi-trace functions (Average and Max/Min Hold).

<b>Conditions</b>	Measurement views: Spectrum
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:SPECtrum:CLEar:RESuLts
<b>Arguments</b>	None
<b>Examples</b>	SENSE:SPECTRUM:CLEAR:RESULTS restarts multi-trace functions.

## [SENSe]:SPECtrum:FFT:WINDow

Selects or queries the FFT window in the spectrum measurement. This command is equivalent to [\[SENSe\]:SPECtrum:FILTer\[:SHAPE\]](#).

<b>Conditions</b>	Measurement views: Spectrum
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:SPECtrum:FFT:WINDow { KAISer   MIL6db   CISPr   BH4B   UNIForm   FLATtop   HANNing } [SENSe]:SPECtrum:FFT:WINDow?
<b>Arguments</b>	KAISer selects the Kaiser (RBW) window. MIL6db selects the -6 dB RBW (MIL) window. CISPr selects the CISPR window. BH4B selects the Blackman-Harris 4B type window. UNIForm selects the uniform window. FLATtop selects the flat-top window. HANNing selects the Hanning window.
<b>Examples</b>	SENSE:SPECTRUM:FFT:WINDOW HANNing selects the Hanning window.

## [SENSe]:SPECTrum:FILTer[:SHAPE]

Selects or queries the filter shape in the spectrum measurement. This command is equivalent to [\[SENSe\]:SPECTrum:FFT:WINDow](#).

<b>Conditions</b>	Measurement views: Spectrum
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:SPECTrum:FILTer[:SHAPE] { KAISer   MIL6db   CISPr   BH4B   UNIForm   FLATtop   HANNing } [SENSe]:SPECTrum:FILTer[:SHAPE]?
<b>Arguments</b>	KAISer selects the Kaiser (RBW) window. MIL6db selects the -6 dB RBW (MIL) window. CISPr selects the CISPR window. BH4B selects the Blackman-Harris 4B type window. UNIForm selects the uniform window. FLATtop selects the flat-top window. HANNing selects the Hanning window.
<b>Examples</b>	SENSE:SPECTRUM:FILTER:SHAPE HANNing selects the Hanning window.

## [SENSe]:SPECTrum:FREQuency:CENTer

Sets or queries the center frequency in the spectrum measurement.

---

**NOTE.** The center, start and stop frequencies are set interlocking each other with the following relationships:  $(start\ frequency) = (center\ frequency) - (span)/2$  and  $(stop\ frequency) = (center\ frequency) + (span)/2$ .

---

<b>Conditions</b>	Measurement views: Spectrum
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:SPECTrum:FREQuency:CENTer <value> [SENSe]:SPECTrum:FREQuency:CENTer?

**Related Commands** [\[SENSe\]:SPECtrum:FREQuency:START](#), [\[SENSe\]:SPECtrum:FREQuency:STOP](#)

**Arguments** `<value>::=<Nrf>` specifies the center frequency.  
Range: 0 Hz to 6.2 GHz (RSA6106A) / 14 GHz (RSA6114A).

**Examples** `SENSE:SPECTRUM:FREQUENCY:CENTER 7.5GHZ` sets the center frequency to 7.5 GHz.

## **[SENSe]:SPECtrum:FREQuency:SPAN**

Sets or queries the frequency span in the spectrum measurement.

**Conditions** Measurement views: Spectrum

**Group** Sense commands

**Syntax** `[SENSe]:SPECtrum:FREQuency:SPAN <value>`  
`[SENSe]:SPECtrum:FREQuency:SPAN?`

**Arguments** `<value>::=<Nrf>` specifies the frequency span.  
Range: 10 Hz to 6.2 GHz (RSA6106A) / 14 GHz (RSA6114A).

**Examples** `SENSE:SPECTRUM:FREQUENCY:SPAN 20MHZ` sets the span to 20 MHz.

## **[SENSe]:SPECtrum:FREQuency:SPAN:BANDwidth[:RESolution]:RATio**

Sets or queries the ratio of span to RBW (Resolution Bandwidth) in the spectrum measurement. This command is valid when [\[SENSe\]:SPECtrum:{BANDwidth|BWIDth}\[:RESolution\]:AUTO](#) is set to On.

**Conditions** Measurement views: Spectrum

**Group** Sense commands

**Syntax** `[SENSe]:SPECtrum:FREQuency:SPAN:BANDwidth[:RESolution]:RATio <value>`  
`[SENSe]:SPECtrum:FREQuency:SPAN:BANDwidth[:RESolution]:RATio?`

**Arguments** <value>::=<nrf> specifies the ratio of span to RBW. Range: 20 to 1000.  
Programming a specified ratio sets the RBW (= span/ratio), which is rounded down to the nearest valid value.

**Examples** SENSE:SPECTRUM:FREQUENCY:SPAN:BANDWIDTH:RESOLUTION:RATIO 200 sets the ratio to 200, setting the RBW to 200 kHz for the span of 40 MHz.

## [SENSe]:SPECTrum:FREQuency:START

Sets or queries the measurement start frequency (left edge on the graph) in the spectrum measurement.

The center, start and stop frequencies are set interlocking each other. Refer to the [\[SENSe\]:SPECTrum:FREQuency:CENTer](#) command.

**Conditions** Measurement views: Spectrum

**Group** Sense commands

**Syntax** [SENSe]:SPECTrum:FREQuency:START <value>  
[SENSe]:SPECTrum:FREQuency:START?

**Related Commands** [\[SENSe\]:SPECTrum:FREQuency:STOP](#)

**Arguments** <value>::=<nrf> is the measurement start frequency.  
Range: (center frequency) ±(span)/2.

**Examples** SENSE:SPECTRUM:FREQUENCY:START 6.95GHZ sets the start frequency to 6.95 GHz.

## [SENSe]:SPECTrum:FREQuency:STEP

Sets or queries the frequency step size (the amount per press by which the up or down key changes the setting value). Programming a specified step size sets [SENSe]:SPECTrum:FREQuency:STEP:AUTO OFF.

**Conditions** Measurement views: Spectrum

**Group** Sense commands



**Syntax** [SENSE]:SPECTrum:FREQUENCY:STEP <value>  
[SENSE]:SPECTrum:FREQUENCY:STEP?

**Related Commands** [\[SENSe\]:SPECTrum:FREQUENCY:STEP:AUTO](#)

**Arguments** <value> ::= <NRf> specifies the frequency step size.  
Range: 0 Hz to 6.2 GHz (RSA6106A) / 14 GHz (RSA6114A).

**Examples** SENSE:SPECTRUM:FREQUENCY:STEP 1.5kHz sets the step size to 1.5 kHz.

## [SENSe]:SPECTrum:FREQUENCY:STEP:AUTO

Determines whether to set the frequency step size automatically or manually.

**Conditions** Measurement views: Spectrum

**Group** Sense commands

**Syntax** [SENSe]:SPECTrum:FREQUENCY:STEP:AUTO { OFF | ON | 0 | 1 }  
[SENSe]:SPECTrum:FREQUENCY:STEP:AUTO?

**Arguments** OFF or 0 specifies that the frequency step size is set manually using the [\[SENSe\]:SPECTrum:FREQUENCY:STEP](#) command.

ON or 1 specifies that the frequency step size is set automatically.

**Examples** SENSE:SPECTRUM:FREQUENCY:STEP:AUTO ON sets the frequency step size automatically.

## [SENSe]:SPECTrum:FREQUENCY:STOP

Sets or queries the measurement stop frequency (right edge on the graph) in the spectrum measurement.

The center, start and stop frequencies are set interlocking each other. Refer to the [\[SENSe\]:SPECTrum:FREQUENCY:CENTer](#) command.

**Conditions** Measurement views: Spectrum

<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:SPECTrum:FREQuency:STOP <value> [SENSe]:SPECTrum:FREQuency:STOP?
<b>Related Commands</b>	[SENSe]:SPECTrum:FREQuency:START
<b>Arguments</b>	<value>::=<Nrf> is the measurement start frequency. Range: (center frequency) ± (span)/2.
<b>Examples</b>	SENSE:SPECTRUM:FREQUENCY:STOP 7.05GHZ sets the stop frequency to 7.05 GHz.

## [SENSe]:SPECTrum:LENGth

Sets or queries the spectrum length when [SENSe]:SPECTrum:TIME:MODE is INDEPENDent. Programming a specified length sets [SENSe]:SPECTrum:LENGth:AUTO OFF.

<b>Conditions</b>	Measurement views: All
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:SPECTrum:LENGth <value> [SENSe]:SPECTrum:LENGth?
<b>Related Commands</b>	[SENSe]:SPECTrum:LENGth:AUTO, [SENSe]:SPECTrum:START
<b>Arguments</b>	<value>::=<Nrf> specifies the spectrum length. Range: 0 to [(acquisition length) - (spectrum start)].  If [(spectrum start) + (spectrum length)] > (acquisition length), the actual spectrum length is reduced to the acquisition length.
<b>Examples</b>	SENSE:SPECTRUM:LENGTH 38.5us sets the spectrum length to 38.5 μs.

## [SENSe]:SPECtrum:LENGth:ACTual? (Query Only)

Queries the actual spectrum length.

<b>Conditions</b>	Measurement views: All
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:SPECtrum:LENGth:ACTual?
<b>Arguments</b>	None
<b>Returns</b>	<NRf> Actual spectrum length in seconds.
<b>Examples</b>	SENSE:SPECTRUM:LENGTH:ACTUAL? might return 6.337E-6, indicating that the actual spectrum length is 6.337 $\mu$ s.

## [SENSe]:SPECtrum:LENGth:AUTO

Determines whether to set the spectrum length automatically or manually when [\[SENSe\]:SPECtrum:TIME:MODE](#) is INDEPENDENT.

<b>Conditions</b>	Measurement views: All
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:SPECtrum:LENGth:AUTO { OFF   ON   0   1 } [SENSe]:SPECtrum:LENGth:AUTO?
<b>Arguments</b>	OFF or 0 sets the spectrum length manually, using the <a href="#">[SENSe]:SPECtrum:LENGth</a> command. ON or 1 sets the spectrum length automatically.
<b>Examples</b>	SENSE:SPECTRUM:LENGTH:AUTO ON sets the spectrum length automatically.

## [SENSe]:SPECTrum:MAX:SPAN (No Query Form)

Sets the frequency span to the maximum full span instead of the maximum real-time span. For the RSA6106A Real-Time Spectrum Analyzer that is 6.2 GHz and for the / RSA6114A Real-Time Spectrum Analyzer that is 14 GHz.

**Conditions** Measurement views: Spectrum

**Group** Sense commands

**Syntax** [SENSe]:SPECTrum:MAX:SPAN

**Arguments** None

**Examples** SENSE:SPECTRUM:MAX:SPAN sets the frequency span to the maximum span.

## [SENSe]:SPECTrum:POINTs:COUNT

Sets or queries the number of sample points on the signal spectrum.

**Conditions** Measurement views: Spectrum

**Group** Sense commands

**Syntax** [SENSe]:SPECTrum:POINTs:COUNT { P801 | P2401 | P4001 | P8001  
| P10401 }  
[SENSe]:SPECTrum:POINTs:COUNT?

**Arguments** P801 sets the number of sample points to 801.  
P2401 sets the number of sample points to 2401.  
P4001 sets the number of sample points to 4001.  
P8001 sets the number of sample points to 8001.  
P10401 sets the number of sample points to 10401.

**Examples** SENSE:SPECTRUM:POINTS:COUNT P801 sets the number of sample points to 801.

## [SENSe]:SPECtrum:START

Sets or queries the spectrum offset time when [SENSe]:SPECtrum:TIME:MODE is INDEpendent.

**Conditions** Measurement views: All

**Group** Sense commands

**Syntax** [SENSe]:SPECtrum:START <value>  
[SENSe]:SPECtrum:START?

**Related Commands** [SENSe]:SPECtrum:LENGth

**Arguments** <value> ::= <NRf> specifies the spectrum offset time.  
Range: 0 to the acquisition length.  
If [(spectrum start) + (spectrum length)] > (acquisition length), the actual spectrum length is reduced to the acquisition length.

**Examples** SENSE:SPECTRUM:START 23.5us sets the analysis offset to 23.5  $\mu$ s.

## [SENSe]:SPECtrum:TIME:MODE

Determines whether to set the spectrum time parameters automatically or manually.

**Conditions** Measurement views: All

**Group** Sense commands

**Syntax** [SENSe]:SPECtrum:TIME:MODE { INDEpendent | COMMON }  
[SENSe]:SPECtrum:TIME:MODE?

**Related Commands** [SENSe]:ANALysis commands

**Arguments** INDEpendent sets the spectrum time parameters manually, using the [SENSe]:SPECtrum:START and [SENSe]:SPECtrum:LENGth commands.

COMMON sets the spectrum time parameters automatically using the analysis time settings.

**Examples** SENSE:SPECTRUM:TIME:MODE COMMON sets the spectrum time parameters automatically.

## [SENSe]:SPURious:CARRier:{BANDwidth|BWIDth}

Sets or queries the channel bandwidth for the carrier as power reference. This command is valid when [SENSe]:SPURious:REFeRence is set to CARRier.

**Conditions** Measurement views: Spurious

**Group** Sense commands

**Syntax** [SENSe]:SPURious:CARRier:{BANDwidth|BWIDth} <value>  
[SENSe]:SPURious:CARRier:{BANDwidth|BWIDth}?

**Arguments** <value>::=<NRF> specifies the channel bandwidth.  
Range: 100 Hz to 40 MHz (Standard) / 110 MHz (Option 110).

**Examples** SENSE:SPURIOUS:CARRIER:BANDWIDTH 20MHZ sets the channel bandwidth to 20 MHz.

## [SENSe]:SPURious:CARRier:{BANDwidth|BWIDth}:INTEgration

Sets or queries the integration bandwidth to calculate the carrier power. This command is valid when [SENSe]:SPURious:REFeRence is set to CARRier.

**Conditions** Measurement views: Spurious

**Group** Sense commands

**Syntax** [SENSe]:SPURious:CARRier:{BANDwidth|BWIDth}:INTEgration  
<value>  
[SENSe]:SPURious:CARRier:{BANDwidth|BWIDth}:INTEgration?

**Arguments** <value>::=<Nrf> specifies the integration bandwidth.  
Range: 100 Hz to 40 MHz (Standard) / 110 MHz (Option 110).

**Examples** SENSE:SPURIOUS:CARRIER:BANDWIDTH:INTEGRATION 2MHZ sets the integration bandwidth to 2 MHz.

## [SENSE]:SPURious:CARRier:{BANDwidth|BWIDth}:RESolution

Sets or queries the resolution bandwidth (RBW) to measure the carrier power. This command is valid when [\[SENSE\]:SPURious:REFerence](#) is set to CARRier. Programming a specified RBW sets [\[SENSE\]:SPURious:CARRier:BANDwidth](#) [\[RESolution\]:AUTO](#) OFF.

**Conditions** Measurement views: Spurious

**Group** Sense commands

**Syntax** [SENSE]:SPURious:CARRier:{BANDwidth|BWIDth}:RESolution  
<value>  
[SENSE]:SPURious:CARRier:{BANDwidth|BWIDth}:RESolution?

**Related Commands** [\[SENSE\]:SPURious:CARRier:{BANDwidth|BWIDth}:RESolution\]:AUTO](#)

**Arguments** <value>::=<Nrf> specifies the RBW. Range: 1 Hz to 10 MHz.

**Examples** SENSE:SPURIOUS:CARRIER:BANDWIDTH:RESOLUTION 200kHz sets the RBW to 200 kHz.

## [SENSE]:SPURious:CARRier:{BANDwidth|BWIDth}:RESolution]:AUTO

Determines whether to set the resolution bandwidth (RBW) automatically or manually when the power reference is set to carrier ([\[SENSE\]:SPURious:REFerence](#) is set to CARRier) in the Spurious measurement.

**Conditions** Measurement views: Spurious

**Group** Sense commands

**Syntax** [SENSe]:SPURious:CARRier:{BANDwidth|BWIDth}[:RESOlution]:  
 AUTO { OFF | ON | 0 | 1 }  
 [SENSe]:SPURious:CARRier:{BANDwidth|BWIDth}[:RESOlution]:  
 AUTO?

**Arguments** OFF or 0 specifies that the resolution bandwidth is set manually using the [SENSe]:SPURious:CARRier:{BANDwidth|BWIDth}[:RESOlution] command.  
 ON or 1 specifies that the resolution bandwidth is set automatically.

**Examples** SENSE:SPURIOUS:CARRIER:BANDWIDTH:RESOLUTION:AUTO ON sets the resolution bandwidth automatically.

## [SENSe]:SPURious:CARRier:DETEction

Selects or queries the carrier detection method. This command is valid when [SENSe]:SPURious:REFerence is set to CARRier.

**Conditions** Measurement views: Spurious

**Group** Sense commands

**Syntax** [SENSe]:SPURious:CARRier:DETEction { AVERAge | PEAK }  
 [SENSe]:SPURious:CARRier:DETEction?

**Arguments** AVERAge selects the average detection.  
 PEAK selects the peak detection.

**Examples** SENSE:SPURIOUS:CARRIER:DETECTION PEAK selects the peak detection.

## [SENSe]:SPURious:CARRier:FREQuency

Sets or queries the carrier frequency in the Spurious measurement. This command is valid when [SENSe]:SPURious:REFerence is set to CARRier.

**Conditions** Measurement views: Spurious

**Group** Sense commands



<b>Syntax</b>	<code>[SENSe]:SPURious:CARRier:FREQuency &lt;value&gt;</code> <code>[SENSe]:SPURious:CARRier:FREQuency?</code>
<b>Arguments</b>	<code>&lt;value&gt;::=&lt;Nrf&gt;</code> specifies the carrier frequency. Range: 0 Hz to 6.2 GHz (RSA6106A) / 14 GHz (RSA6114A).
<b>Examples</b>	<code>SENSE:SPURIOUS:CARRIER:FREQUENCY 7.5GHZ</code> sets the carrier frequency to 7.5 GHz.

## [SENSe]:SPURious:CARRier:THReshold

Sets or queries the threshold level to detect the carrier in the Spurious measurement. This command is valid when [\[SENSe\]:SPURious:REFErence](#) is set to CARRIER.

<b>Conditions</b>	Measurement views: Spurious
<b>Group</b>	Sense commands
<b>Syntax</b>	<code>[SENSe]:SPURious:CARRier:THReshold &lt;value&gt;</code> <code>[SENSe]:SPURious:CARRier:THReshold?</code>
<b>Arguments</b>	<code>&lt;value&gt;::=&lt;Nrf&gt;</code> specifies the threshold level above which the input signal is determined to be a carrier. Range: -170 to +50 dBm. The unit can be changed by the <a href="#">[SENSe]:POWEr:UNITs</a> or <a href="#">UNIT:POWEr</a> command.
<b>Examples</b>	<code>SENSE:SPURIOUS:CARRIER:THRESHOLD -25</code> sets the carrier threshold level to -25 dBm.

## [SENSe]:SPURious:CLEAr:RESults (No Query Form)

Restarts multi-trace functions (Average and Max Hold).

<b>Conditions</b>	Measurement views: Spurious
<b>Group</b>	Sense commands
<b>Syntax</b>	<code>[SENSe]:SPURious:CLEAr:RESults</code>

**Arguments** None

**Examples** SENSE:SPURIOUS:CLEAR:RESULTS restarts multi-trace functions.

## [SENSe]:SPURious[:FREQuency]:OVERlap? (Query Only)

Queries whether any of the frequency ranges (A to T) overlap, including the carrier when [SENSe]:SPURious:REFeRence is set to CARRier.

---

**NOTE.** *If there are any overlaps between the ranges, the measurement will not run correctly.*

---

**Conditions** Measurement views: Spurious

**Group** Sense commands

**Syntax** [SENSe]:SPURious[:FREQuency]:OVERlap?

**Arguments** None

**Returns** 0 (no overlap) or 1 (overlap).

**Examples** SENSE:SPURIOUS:FREQUENCY:OVERLAP? might return 1, indicating that some frequency ranges overlap.

## [SENSe]:SPURious:LIST

Selects or queries how to list the spurious signals in the Spurious measurement.

**Conditions** Measurement views: Spurious

**Group** Sense commands

**Syntax** [SENSe]:SPURious:LIST { ALL | OVERlimit }  
[SENSe]:SPURious:LIST?

**Arguments** ALL lists all of the detected spurious signals.  
 OVERlimit lists the spurious signals exceeding the limits. Use the [SENSe]:SPURious:RANGe<x>:LIMit command group to set the limits.

**Examples** SENSE:SPURIOUS:LIST ALL lists all of the detected spurious signals.

## [SENSe]:SPURious:MODE

Selects or queries the frequency range mode in the Spurious measurement.

**Conditions** Measurement views: Spurious

**Group** Sense commands

**Syntax** [SENSe]:SPURious:MODE { MULTi | SINGle }  
 [SENSe]:SPURious:MODE?

**Arguments** MULTi displays all of the ranges that are enabled. Use the [SENSe]:SPURious:RANGe<x>:STATe command to enable the range.  
 SINGle displays only the range that the selected spurious signal is in. Use the DISPlay:SPURious:SELect:NUMBer command to select the spurious signal.

**Examples** SENSE:SPURIOUS:MODE MULTi displays all of the enabled ranges.

## [SENSe]:SPURious:OPTimization

Selects or queries the method of optimizing the gain and input bandwidth in the Spurious measurement.

**Conditions** Measurement views: Spurious

**Group** Sense commands

**Syntax** [SENSe]:SPURious:OPTimization { AUTO | MINTime | MAXDynrange  
 | MINNoise }  
 [SENSe]:SPURious:OPTimization?

<b>Arguments</b>	AUTO optimizes automatically the gain and input bandwidth. MINTime optimizes the gain and input bandwidth to minimize sweep time. MAXDynrange optimizes the gain and input bandwidth to maximize the dynamic range. MINNoise optimizes the gain and input bandwidth to minimize noise.
<b>Examples</b>	SENSE:SPURIOUS:OPTIMIZATION AUTO optimizes automatically the gain and input bandwidth.

## [SENSe]:SPURious:POINTs:COUNT

Sets or queries the number of sample points on the spectrum trace per range in the Spurious measurement.

<b>Conditions</b>	Measurement views: Spurious
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:SPURious:POINTs:COUNT { P801   P2401   P4001   P8001   P10401 } [SENSe]:SPURious:POINTs:COUNT?
<b>Arguments</b>	P801 sets the trace points to 801 per range. P2401 sets the trace points to 2401 per range. P4001 sets the trace points to 4001 per range. P8001 sets the trace points to 8001 per range. P10401 sets the trace points to 10401 per range.
<b>Examples</b>	SENSE:SPURIOUS:POINTS:COUNT P801 sets the trace points to 801 per range.

## [SENSe]:SPURious:RANGe<x>:BANDwidth:VIDeo

Sets or queries the video bandwidth (VBW) in the specified frequency range. Programming a specified VBW sets [SENSe]:SPURious:BANDwidth:VIDeo STATE OFF.

The parameter <x> = 1 to 20, representing Range A to T, respectively.

<b>Conditions</b>	Measurement views: Spurious
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSE]:SPURious:RANGe<x>:BANDwidth:VIDeo <value> [SENSE]:SPURious:RANGe<x>:BANDwidth:VIDeo?
<b>Related Commands</b>	[SENSE]:SPECTrum:{BANDwidth BWIDth}:VIDeo:STATe
<b>Arguments</b>	<value> ::= <NRf> specifies the VBW. Range: Current RBW/10 <sup>4</sup> (1 Hz minimum) to Current RBW.
<b>Examples</b>	SENSE:SPURIOUS:RANGE1:BANDWIDTH:VIDEO 200kHz sets the VBW to 200 kHz for Range A.

## [SENSE]:SPURious:RANGe<x>:BANDwidth:VIDeo:STATe

Determines whether to enable or disable the video bandwidth (VBW) in the specified frequency range.

The parameter <x> = 1 to 20, representing Range A to T, respectively.

<b>Conditions</b>	Measurement views: Spurious
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSE]:SPURious:RANGe<x>:BANDwidth:VIDeo:STATe { OFF   ON   0   1 } [SENSE]:SPURious:RANGe<x>:BANDwidth:VIDeo:STATe?
<b>Arguments</b>	OFF or 0 disables the VBW. ON or 1 enables the VBW.
<b>Examples</b>	SENSE:SPURIOUS:RANGE1:BANDWIDTH:VIDEO:STATE ON enables the VBW for Range A.

## [SENSe]:SPURious:RANGe<x>:DETection

Selects or queries the spurious detection method in the specified frequency range.

The parameter <x> = 1 to 20, representing Range A to T, respectively.

<b>Conditions</b>	Measurement views: Spurious
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:SPURious:RANGe<x>:DETection { AVERAge   PEAK   QUASipeak   CAVERage   CPEak } [SENSe]:SPURious:RANGe<x>:DETection?
<b>Arguments</b>	AVERAge selects the average detection. PEAK selects the peak detection. QUASipeak selects the quasi-peak detection. CAVERage selects the CISPR average detection. CPEak selects the CISPR peak detection.
<b>Examples</b>	SENSe:SPURIOUS:RANGE1:DETECTION PEAK selects the peak detection for Range A.

## [SENSe]:SPURious:RANGe<x>:EXCursion

Sets or queries the excursion level (how far down the signal must drop between spurious emissions) in the specified frequency range.

The parameter <x> = 1 to 20, representing Range A to T, respectively.

<b>Conditions</b>	Measurement views: Spurious
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:SPURious:RANGe<x>:EXCursion <value> [SENSe]:SPURious:RANGe<x>:EXCursion?
<b>Arguments</b>	<value>::=<NRF> specifies the excursion level. A signal with amplitude less than the excursion level is considered to be a noise. Range: 1 to 50 dB.

**Examples**    `SENSE:SPURIOUS:RANGE1:EXCURSION 8` sets the excursion level to 8 dB.

## **[SENSE]:SPURious:RANGe<x>:FILTer[:SHAPE]**

Selects or queries the filter shape to search the specified frequency range for spurious signals.

The parameter <x> = 1 to 20, representing Range A to T, respectively.

**Conditions**    Measurement views: Spurious

**Group**    Sense commands

**Syntax**    `[SENSE]:SPURious:RANGe<x>:FILTer[:SHAPE] { RBW | MIL6db | CISPr }`  
`[SENSE]:SPURious:RANGe<x>:FILTer[:SHAPE]?`

**Arguments**    `RBW` selects the RBW filter.  
`MIL6db` selects the -6 dB RBW (MIL) filter.  
`CISPr` selects the CISPR filter.

**Examples**    `SENSE:SPURIOUS:RANGE1:FILTER:SHAPE CISPr` uses the CISPR filter in Range A.

## **[SENSE]:SPURious:RANGe<x>:FILTer[:SHAPE]:BANDwidth**

Sets or queries the filter bandwidth to search the specified frequency range for spurious signals.

The parameter <x> = 1 to 20, representing Range A to T, respectively.

**Conditions**    Measurement views: Spurious

**Group**    Sense commands

**Syntax**    `[SENSE]:SPURious:RANGe<x>:FILTer[:SHAPE]:BANDwidth <value>`  
`[SENSE]:SPURious:RANGe<x>:FILTer[:SHAPE]:BANDwidth?`

- Arguments** <value>::=<NRF> specifies the filter bandwidth.
- The setting range varies depending on the center frequency and trace detector when using the CISPR filters and detectors. Otherwise, the bandwidth minimum is a function of the span (= (stop frequency) - (start frequency)) of the range and the maximum is fixed at 5 MHz.
- By default, the value is set automatically ([SENSe]:SPURious:RANGe<x>:FILTer[:SHAPE]:BANDwidth:AUTO is ON). When the detection is set to CISPR QPk ([SENSe]:SPURious:RANGe<x>:DETEction is QUASipeak), only one value is allowed, which is set automatically.
- Examples** SENSE:SPURIOUS:RANGE1:FILTER:SHAPE:BANDWIDTH 200kHz sets the filter bandwidth to 200 kHz for Range A.

## [SENSe]:SPURious:RANGe<x>:FILTer[:SHAPE]:BANDwidth:AUTO

Determines whether to set the filter bandwidth automatically or manually for the specified frequency range in the Spurious measurement.

The parameter <x> = 1 to 20, representing Range A to T, respectively.

- Conditions** Measurement views: Spurious
- Group** Sense commands
- Syntax** [SENSe]:SPURious:RANGe<x>:FILTer[:SHAPE]:BANDwidth:AUTO {  
OFF | ON | 0 | 1 }  
[SENSe]:SPURious:RANGe<x>:FILTer[:SHAPE]:BANDwidth:AUTO?
- Arguments** OFF or 0 specifies that the filter bandwidth is set manually using the [SENSe]:SPURious:RANGe<x>:FILTer[:SHAPE]:BANDwidth command.
- ON or 1 specifies that the filter bandwidth is set automatically.
- Examples** SENSE:SPURIOUS:RANGE1:FILTER:SHAPE:BANDWIDTH:AUTO ON sets the filter bandwidth automatically for Range A.

## [SENSe]:SPURious:RANGe<x>:FREQuency:START

Sets or queries the start frequency of the specified range in the Spurious measurement.

The parameter <x> = 1 to 20, representing Range A to T, respectively.



---

**NOTE.** The frequency ranges must not be overlapped. Use the `[SENSe]:SPURious[:FREQuency]:OVERlap?` query to check whether there is any overlap.

---

<b>Conditions</b>	Measurement views: Spurious
<b>Group</b>	Sense commands
<b>Syntax</b>	<code>[SENSe]:SPURious:RANGe&lt;x&gt;:FREQuency:START &lt;value&gt;</code> <code>[SENSe]:SPURious:RANGe&lt;x&gt;:FREQuency:START?</code>
<b>Arguments</b>	<code>&lt;value&gt;::=&lt;Nrf&gt;</code> specifies the start frequency. Range: 0 Hz to 6.2 GHz (RSA6106A) / 14 GHz (RSA6114A).
<b>Examples</b>	<code>SENSe:SPURIOUS:RANGE1:FREQUENCY:START 1.615GHZ</code> sets the start frequency of Range A to 1.615 GHz.

## `[SENSe]:SPURious:RANGe<x>:FREQuency:STOP`

Sets or queries the stop frequency of the specified range in the Spurious measurement.

The parameter `<x>` = 1 to 20, representing Range A to T, respectively.

---

**NOTE.** The frequency ranges must not be overlapped. Use the `[SENSe]:SPURious[:FREQuency]:OVERlap?` query to check whether there is any overlap.

---

<b>Conditions</b>	Measurement views: Spurious
<b>Group</b>	Sense commands
<b>Syntax</b>	<code>[SENSe]:SPURious:RANGe&lt;x&gt;:FREQuency:STOP &lt;value&gt;</code> <code>[SENSe]:SPURious:RANGe&lt;x&gt;:FREQuency:STOP?</code>
<b>Arguments</b>	<code>&lt;value&gt;::=&lt;Nrf&gt;</code> specifies the stop frequency. Range: 0 Hz to 6.2 GHz (RSA6106A) / 14 GHz (RSA6114A).

**Examples**     `SENSE:SPURIOUS:RANGE1:FREQUENCY:STOP 1.715GHZ` sets the stop frequency of Range A to 1.715 GHz.

## **[SENSe]:SPURious:RANGe<x>:LIMit:ABSolute:START**

Sets or queries the absolute amplitude of the limits at the start (left edge) of the specified range in the Spurious measurement. This command is valid when [\[SENSe\]:SPURious:RANGe<x>:LIMit:MASK](#) is set to ABS, AND, or OR.

The parameter <x> = 1 to 20, representing Range A to T, respectively.

**Conditions**     Measurement views: Spurious

**Group**            Sense commands

**Syntax**          `[SENSe]:SPURious:RANGe<x>:LIMit:ABSolute:START <value>`  
`[SENSe]:SPURious:RANGe<x>:LIMit:ABSolute:START?`

**Arguments**      `<value>::=<NRF>` specifies the absolute start amplitude of the limits.  
Range: -170 to +50 dBm.  
The unit can be changed by the [\[SENSe\]:POWer:UNITs](#) or [UNIT:POWer](#) command.

**Examples**     `SENSE:SPURIOUS:RANGE1:LIMIT:ABSOLUTE:START -30` sets the absolute start amplitude of the limits for Range A to -30 dBm.

## **[SENSe]:SPURious:RANGe<x>:LIMit:ABSolute:STOP**

Sets or queries the absolute amplitude of the limits at the stop (right edge) of the specified range in the Spurious measurement. This command is valid when [\[SENSe\]:SPURious:RANGe<x>:LIMit:MASK](#) is set to ABS, AND, or OR.

The parameter <x> = 1 to 20, representing Range A to T, respectively.

**Conditions**     Measurement views: Spurious

**Group**            Sense commands

**Syntax**          `[SENSe]:SPURious:RANGe<x>:LIMit:ABSolute:STOP <value>`  
`[SENSe]:SPURious:RANGe<x>:LIMit:ABSolute:STOP?`

**Related Commands** [\[SENSe\]:POWer:UNITs](#), [UNIT:POWer](#)

**Arguments** `<value> ::= <NRf>` specifies the absolute stop amplitude of the limits.  
Range: -170 to +50 dBm.  
The unit can be changed by the [\[SENSe\]:POWer:UNITs](#) or [UNIT:POWer](#) command.

**Examples** `SENSE:SPURIOUS:RANGE1:LIMIT:ABSOLUTE:STOP -10` sets the absolute stop amplitude of the limits for Range A to -10 dBm.

## [\[SENSe\]:SPURious:RANGe<x>:LIMit:MASK](#)

Selects or queries the limit mask function mode for the specified range in the Spurious measurement.

The parameter `<x>` = 1 to 20, representing Range A to T, respectively.

**Conditions** Measurement views: Spurious

**Group** Sense commands

**Syntax** `[SENSe]:SPURious:RANGe<x>:LIMit:MASK { ABS | REL | AND | OR | OFF }`  
`[SENSe]:SPURious:RANGe<x>:LIMit:MASK?`

**Arguments** The following table lists the arguments.

**Table 2-44: Limit mask mode**

Argument	Description
ABS	Failure is detected when one of the spurious signals is larger than the absolute amplitude limit.
REL	Failure is detected when one of the spurious signals is larger than the relative amplitude limit.
AND	Failure is detected when one of the spurious signals is larger than the absolute AND relative amplitude limits.
OR	Failure is detected when one of the spurious signals is larger than the absolute OR relative amplitude limit.
OFF	Disables the mask.

To set the absolute amplitude limits, use the [\[SENSe\]:SPURious:RANGe<x>:LIMit:ABSolute:START](#) and [\[SENSe\]:SPURious:RANGe<x>:LIMit:ABSolute:STOP](#) commands.

To set the relative amplitude limits, use the [\[SENSe\]:SPURious:RANGe<x>:LIMit:RELative:START](#) and [\[SENSe\]:SPURious:RANGe<x>:LIMit:RELative:STOP](#) commands.

**Examples**     `SENSE:SPURIOUS:RANGE1:LIMIT:MASK ABS` specifies that failure is detected when one of the spurious signals is larger than the absolute amplitude limit in Range A.

## [\[SENSe\]:SPURious:RANGe<x>:LIMit:RELative:START](#)

Sets or queries the relative amplitude of the limits at the start (left edge) of the specified range in the Spurious measurement. This command is valid when [\[SENSe\]:SPURious:RANGe<x>:LIMit:MASK](#) is set to REL, AND, or OR.

The parameter <x> = 1 to 20, representing Range A to T, respectively.

**Conditions**     Measurement views: Spurious

**Group**     Sense commands

**Syntax**     `[SENSe]:SPURious:RANGe<x>:LIMit:RELative:START <value>`  
`[SENSe]:SPURious:RANGe<x>:LIMit:RELative:START?`

**Arguments**     `<value>::=<Nrf>` specifies the relative start amplitude of the limits.  
 Range: -100 to 0 dB.

Use the [\[SENSe\]:SPURious:REFerence](#) command to select the power reference.

**Examples**     `SENSE:SPURIOUS:RANGE1:LIMIT:RELATIVE:START -30` sets the relative start amplitude of the limits for Range A to -30 dB.

## [\[SENSe\]:SPURious:RANGe<x>:LIMit:RELative:STOP](#)

Sets or queries the relative amplitude of the limits at the stop (right edge) of the specified range in the Spurious measurement. This command is valid when [\[SENSe\]:SPURious:RANGe<x>:LIMit:MASK](#) is set to REL, AND, or OR.

The parameter <x> = 1 to 20, representing Range A to T, respectively.

**Conditions**     Measurement views: Spurious

<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSE]:SPURIOUS:RANGE<x>:LIMIT:RELATIVE:STOP <value> [SENSE]:SPURIOUS:RANGE<x>:LIMIT:RELATIVE:STOP?
<b>Arguments</b>	<value> ::= <NRf> specifies the relative stop amplitude of the limits. Range: -100 to 0 dB.  Use the [SENSE]:SPURIOUS:REFERENCE command to select the power reference.
<b>Examples</b>	SENSE:SPURIOUS:RANGE1:LIMIT:RELATIVE:STOP -10 sets the relative stop amplitude of the limits for Range A to -10 dB.

## [SENSE]:SPURIOUS:RANGE<x>:STATE

Determines whether to enable or disable the frequency range in the Spurious measurement.

The parameter <x> = 1 to 20, representing Range A to T, respectively.

<b>Conditions</b>	Measurement views: Spurious
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSE]:SPURIOUS:RANGE<x>:STATE { OFF   ON   0   1 } [SENSE]:SPURIOUS:RANGE<x>:STATE?
<b>Arguments</b>	OFF or 0 disables the frequency range.  ON or 1 enables the frequency range.
<b>Examples</b>	SENSE:SPURIOUS:RANGE1:STATE ON enables Range A.

## [SENSE]:SPURIOUS:RANGE<x>:THRESHOLD

Sets or queries the threshold level to detect spurious signals in the specified frequency range.

The parameter <x> = 1 to 20, representing Range A to T, respectively.

<b>Conditions</b>	Measurement views: Spurious
-------------------	-----------------------------

<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:SPURious:RANGe<x>:THReshoId <value> [SENSe]:SPURious:RANGe<x>:THReshoId?
<b>Arguments</b>	<value>::=<NRF> specifies the threshold level above which the signal is determined to be spurious. Range: -50 to +30 dBm.  The unit can be changed by the [SENSe]:POWer:UNITs or UNIT:POWer command.
<b>Examples</b>	SENSE:SPURIOUS:RANGE1:THRESHOLD -25 sets the threshold level to -25 dBm in Range A.

## [SENSe]:SPURious:REFerence

Selects or queries the power reference in the Spurious measurement.

<b>Conditions</b>	Measurement views: Spurious
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSe]:SPURious:REFerence { CARRier   MANuaI   NONE } [SENSe]:SPURious:REFerence?
<b>Arguments</b>	CARRier uses the carrier as the power reference.  MANuaI sets the power reference using the [SENSe]:SPURious:REFerence:MANuaI:POWer command.  NONE uses no reference.
<b>Examples</b>	SENSE:SPURIOUS:REFERENCE CARRier uses the carrier as the power reference.

## [SENSe]:SPURious:REFerence:MANuaI:POWer

Sets or queries the reference power level in the Spurious measurement. This command is valid when [SENSe]:SPURious:REFerence is set to MANuaI.

<b>Conditions</b>	Measurement views: Spurious
-------------------	-----------------------------

<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSE]:SPURIOUS:REFERENCE:MANUAL:POWER <value> [SENSE]:SPURIOUS:REFERENCE:MANUAL:POWER?
<b>Arguments</b>	<value> ::= <Nrf> specifies the reference power level. Range: -170 to +50 dBm. The unit can be changed by the [SENSe]:POWer:UNITs or UNIT:POWer command.
<b>Examples</b>	SENSE:SPURIOUS:REFERENCE:MANUAL:POWER -25 sets the reference power level to -25 dBm.

## [SENSe]:TOVerview:FREQUency:CENTer

Sets or queries the center frequency in the time overview.

<b>Conditions</b>	Measurement views: Time overview
<b>Group</b>	Sense commands
<b>Syntax</b>	[SENSE]:TOVerview:FREQUency:CENTer <value> [SENSE]:TOVerview:FREQUency:CENTer?
<b>Arguments</b>	<value> ::= <Nrf> specifies the center frequency. Range: 0 Hz to 6.2 GHz (RSA6106A) / 14 GHz (RSA6114A).
<b>Examples</b>	SENSE:TOVerview:FREQUency:CENTer 7.5GHz sets the center frequency to 7.5 GHz.

## [SENSe]:TOVerview:MAXTracepoints

Selects or queries the maximum trace points in the time overview.

<b>Conditions</b>	Measurement views: Time overview
<b>Group</b>	Sense commands

**Syntax** [SENSe]:TOVerview:MAXTracepoints { ONEK | TENK | HUNDredk  
| NEVERdecimate }  
[SENSe]:TOVerview:MAXTracepoints?

**Arguments** ONEK sets the maximum trace points to 1 k.  
TENK sets the maximum trace points to 10 k.  
HUNDredk sets the maximum trace points to 100 k.  
NEVERdecimate never decimates the trace points.

**Examples** SENSE:TOVERVIEW:MAXTRACEPOINTS TENK sets the maximum trace points to 10 k.

## [SENSe]:USETtings (No Query Form)

Updates the analyzer settings. This command is useful when you need to set the analyzer including the RF attenuation before taking data acquisition. Unless this command is executed, the attenuation value is not set until acquisition is taken.

**Conditions** Measurement views: All

**Group** Sense commands

**Syntax** [SENSe]:USETtings

**Arguments** None

**Examples** SENSE:USETTINGS updates settings.

## \*SRE

Sets or queries the value of the Service Request Enable Register (SRER). Refer to Section 3, *Status and Events*, for the register information.

**Conditions** Measurement views: All

**Group** IEEE common commands



**Syntax** \*SRE <value>  
\*SRE?

**Related Commands** \*CLS, \*ESE, \*ESR?, \*STB?

**Arguments** <value> ::= <NR1> is a value in the range from 0 to 255.  
The binary bits of the SRER are set according to this value.  
Using an out-of-range value causes an execution error.

**Examples** \*SRE 48 sets binary 00110000 in the SRER's bits.  
\*SRE? might return 32, indicating that binary value 00100000 has been set in the SRER's bits.

## STATus:ACPower:EVENTs? (Query Only)

Returns the current events for the Channel power and ACPR measurement.

**Conditions** Measurement views: Channel power and ACPR

**Group** Status commands

**Syntax** STATus:ACPower:EVENTs?

**Arguments** None

**Returns** <ecode>,"<edesc>[<einfo>]"{"<ecode>,"<edesc>[:<einfo>]}"

Where

<ecode> ::= <NR1> is the error/event code (-32768 to 32767).

<edesc> ::= <string> is the description on the error/event.

<einfo> ::= <string> is the additional information on the error/event.

If there is no error, the response is 0,"No error".

**Examples** STATus:ACPOWER:EVENTS? might return 2026,"Acq Sampling Params: manual control", indicating that the sampling parameters are controlled manually.

## STATus:{AM|FM|PM}:EVENTs? (Query Only)

Returns the current events for the AM/FM/PM measurement.

<b>Conditions</b>	Measurement views: AM, FM, PM
<b>Group</b>	Status commands
<b>Syntax</b>	STATus:{AM FM PM}:EVENTs?
<b>Arguments</b>	None
<b>Returns</b>	<code>&lt;ecode&gt;,"&lt;edesc&gt;[&lt;einfo&gt;]"{,&lt;ecode&gt;,"&lt;edesc&gt;[:&lt;einfo&gt;]"}</code> Where <code>&lt;ecode&gt;::=&lt;NR1&gt;</code> is the error/event code (-32768 to 32767). <code>&lt;edesc&gt;::=&lt;string&gt;</code> is the description on the error/event. <code>&lt;einfo&gt;::=&lt;string&gt;</code> is the additional information on the error/event. If there is no error, the response is 0,"No error".
<b>Examples</b>	STATus:AM:EVENTs? might return 2026,"Acq Sampling Params: manual control", indicating that the sampling parameters are controlled manually in the AM measurement.

## STATus:AVTime:EVENTs? (Query Only)

Returns the current events for the Amplitude versus Time measurement.

<b>Conditions</b>	Measurement views: Amplitude versus Time
<b>Group</b>	Status commands
<b>Syntax</b>	STATus:AVTime:EVENTs?
<b>Arguments</b>	None
<b>Returns</b>	<code>&lt;ecode&gt;,"&lt;edesc&gt;[&lt;einfo&gt;]"{,&lt;ecode&gt;,"&lt;edesc&gt;[:&lt;einfo&gt;]"}</code>

Where  
`<ecode> ::= <NR1>` is the error/event code (-32768 to 32767).  
`<edesc> ::= <string>` is the description on the error/event.  
`<einfo> ::= <string>` is the additional information on the error/event.

If there is no error, the response is 0, "No error".

**Examples**     `STATUS:AVTIME:EVENTS?` might return 2026, "Acq Sampling Params: manual control", indicating that the sampling parameters are controlled manually.

## STATUS:CCDF:EVENTS? (Query Only)

Returns the current events for the CCDF measurement.

**Conditions**     Measurement views: CCDF

**Group**     Status commands

**Syntax**     `STATUS:CCDF:EVENTS?`

**Arguments**     None

**Returns**     `<ecode>, "<edesc> [<einfo>]" {, <ecode>, "<edesc>[:<einfo>]"}`

Where  
`<ecode> ::= <NR1>` is the error/event code (-32768 to 32767).  
`<edesc> ::= <string>` is the description on the error/event.  
`<einfo> ::= <string>` is the additional information on the error/event.

If there is no error, the response is 0, "No error".

**Examples**     `STATUS:CCDF:EVENTS?` might return 2026, "Acq Sampling Params: manual control", indicating that the sampling parameters are controlled manually.

## STATUS:CONStE:EVENTS? (Query Only)

Returns the current events for the constellation measurement.

<b>Conditions</b>	Measurement views: Constellation
<b>Group</b>	Status commands
<b>Syntax</b>	STATUS:CONStE:EVENTs?
<b>Arguments</b>	None
<b>Returns</b>	<p>&lt;ecode&gt;,"&lt;edesc&gt;[&lt;einfo&gt;]"{,&lt;ecode&gt;,"&lt;edesc&gt;[:&lt;einfo&gt;]}            Where            &lt;ecode&gt;::=&lt;NR1&gt; is the error/event code (-32768 to 32767).            &lt;edesc&gt;::=&lt;string&gt; is the description on the error/event.            &lt;einfo&gt;::=&lt;string&gt; is the additional information on the error/event.</p> <p>If there is no error, the response is 0,"No error".</p>
<b>Examples</b>	STATUS:CONStE:EVENTs? might return 2026,"Acq Sampling Params: manual control", indicating that the sampling parameters are controlled manually.

## STATUs:DIQVtime:EVENTs? (Query Only)

Returns the current events for the Demod I&Q versus Time measurement.

<b>Conditions</b>	Measurement views: Demod I&Q versus Time
<b>Group</b>	Status commands
<b>Syntax</b>	STATUs:DIQVtime:EVENTs?
<b>Arguments</b>	None
<b>Returns</b>	<p>&lt;ecode&gt;,"&lt;edesc&gt;[&lt;einfo&gt;]"{,&lt;ecode&gt;,"&lt;edesc&gt;[:&lt;einfo&gt;]}            Where            &lt;ecode&gt;::=&lt;NR1&gt; is the error/event code (-32768 to 32767).            &lt;edesc&gt;::=&lt;string&gt; is the description on the error/event.            &lt;einfo&gt;::=&lt;string&gt; is the additional information on the error/event.</p>

If there is no error, the response is 0,"No error".

**Examples** STATUS:DIQVTIME:EVENTS? might return 2026,"Acq Sampling Params: manual control", indicating that the sampling parameters are controlled manually.

## STATUS:DPSA:EVENTS? (Query Only)

Returns the current events for the DPX spectrum measurement.

**Conditions** Measurement views: DPX spectrum

**Group** Status commands

**Syntax** STATUS:DPSA:EVENTS?

**Arguments** None

**Returns** <ecode>,"<edesc>[<einfo>]"{,<ecode>,"<edesc>[:<einfo>]"} }

Where

<ecode> ::= <NR1> is the error/event code (-32768 to 32767).

<edesc> ::= <string> is the description on the error/event.

<einfo> ::= <string> is the additional information on the error/event.

If there is no error, the response is 0,"No error".

**Examples** STATUS:DPSA:EVENTS? might return 2026,"Acq Sampling Params: manual control", indicating that the sampling parameters are controlled manually.

## STATUS:EDiagram:EVENTS? (Query Only)

Returns the current events for the eye diagram measurement.

**Conditions** Measurement views: Eye diagram

**Group** Status commands

<b>Syntax</b>	STATUS:EDIagram:EVENTS?
<b>Arguments</b>	None
<b>Returns</b>	<p>&lt;ecode&gt;,"&lt;edesc&gt;[&lt;einfo&gt;]"{,&lt;ecode&gt;,"&lt;edesc&gt;[:&lt;einfo&gt;]}"</p> <p>Where            &lt;ecode&gt;::=&lt;NR1&gt; is the error/event code (-32768 to 32767).            &lt;edesc&gt;::=&lt;string&gt; is the description on the error/event.            &lt;einfo&gt;::=&lt;string&gt; is the additional information on the error/event.</p> <p>If there is no error, the response is 0,"No error".</p>
<b>Examples</b>	STATUS:EDIAGRAM:EVENTS? might return 2026,"Acq Sampling Params: manual control", indicating that the sampling parameters are controlled manually.

## STATUS:EVM:EVENTS? (Query Only)

Returns the current events for the EVM versus Time measurement.

<b>Conditions</b>	Measurement views: EVM versus Time
<b>Group</b>	Status commands
<b>Syntax</b>	STATUS:EVM:EVENTS?
<b>Arguments</b>	None
<b>Returns</b>	<p>&lt;ecode&gt;,"&lt;edesc&gt;[&lt;einfo&gt;]"{,&lt;ecode&gt;,"&lt;edesc&gt;[:&lt;einfo&gt;]}"</p> <p>Where            &lt;ecode&gt;::=&lt;NR1&gt; is the error/event code (-32768 to 32767).            &lt;edesc&gt;::=&lt;string&gt; is the description on the error/event.            &lt;einfo&gt;::=&lt;string&gt; is the additional information on the error/event.</p> <p>If there is no error, the response is 0,"No error".</p>
<b>Examples</b>	STATUS:EVM:EVENTS? might return 2026,"Acq Sampling Params: manual control", indicating that the sampling parameters are controlled manually.

## STATus:FDVTime:EVENTs? (Query Only)

Returns the current events for the Frequency deviation versus Time measurement.

<b>Conditions</b>	Measurement views: Frequency deviation versus Time
<b>Group</b>	Status commands
<b>Syntax</b>	STATus:FDVTime:EVENTs?
<b>Arguments</b>	None
<b>Returns</b>	<p>&lt;ecode&gt;,"&lt;edesc&gt;[&lt;einfo&gt;"]{,&lt;ecode&gt;,"&lt;edesc&gt;[:&lt;einfo&gt;"]}</p> <p>Where</p> <p>&lt;ecode&gt;::=&lt;NR1&gt; is the error/event code (-32768 to 32767).</p> <p>&lt;edesc&gt;::=&lt;string&gt; is the description on the error/event.</p> <p>&lt;einfo&gt;::=&lt;string&gt; is the additional information on the error/event.</p> <p>If there is no error, the response is 0,"No error".</p>
<b>Examples</b>	<p>STATus:FDVTime:EVENTs? might return 2026,"Acq Sampling Params: manual control", indicating that the sampling parameters are controlled manually.</p>

## STATus:FVTime:EVENTs? (Query Only)

Returns the current events for the Frequency versus Time measurement.

<b>Conditions</b>	Measurement views: Frequency versus Time
<b>Group</b>	Status commands
<b>Syntax</b>	STATus:FVTime:EVENTs?
<b>Arguments</b>	None
<b>Returns</b>	<p>&lt;ecode&gt;,"&lt;edesc&gt;[&lt;einfo&gt;"]{,&lt;ecode&gt;,"&lt;edesc&gt;[:&lt;einfo&gt;"]}</p>

Where

<ecode> ::= <NR1> is the error/event code (-32768 to 32767).

<edesc> ::= <string> is the description on the error/event.

<einfo> ::= <string> is the additional information on the error/event.

If there is no error, the response is 0,"No error".

**Examples** STATUS:FVTIME:EVENTS? might return 2026,"Acq Sampling Params: manual control", indicating that the sampling parameters are controlled manually.

## STATUS:IQVTime:EVENTs? (Query Only)

Returns the current events for the RF I&Q versus Time measurement.

**Conditions** Measurement views: RF I&Q versus Time

**Group** Status commands

**Syntax** STATUS:IQVTime:EVENTs?

**Arguments** None

**Returns** <ecode>,"<edesc> [<einfo>]" {,<ecode>,"<edesc>[:<einfo>]"}  
 Where

Where

<ecode> ::= <NR1> is the error/event code (-32768 to 32767).

<edesc> ::= <string> is the description on the error/event.

<einfo> ::= <string> is the additional information on the error/event.

If there is no error, the response is 0,"No error".

**Examples** STATUS:IQVTIME:EVENTS? might return 2026,"Acq Sampling Params: manual control", indicating that the sampling parameters are controlled manually.

## STATUS:MCPower:EVENTs? (Query Only)

Returns the current events for the MCPR (multi-carrier ACPR) measurement.

**Conditions** Measurement views: MCPR



<b>Group</b>	Status commands
<b>Syntax</b>	STATUS:MCPOWER:EVENTS?
<b>Arguments</b>	None
<b>Returns</b>	<p>&lt;ecode&gt;,"&lt;edesc&gt;[&lt;einfo&gt;]"{"&lt;ecode&gt;,"&lt;edesc&gt;[:&lt;einfo&gt;]}"</p> <p>Where</p> <p>&lt;ecode&gt;::=&lt;NR1&gt; is the error/event code (-32768 to 32767).</p> <p>&lt;edesc&gt;::=&lt;string&gt; is the description on the error/event.</p> <p>&lt;einfo&gt;::=&lt;string&gt; is the additional information on the error/event.</p> <p>If there is no error, the response is 0,"No error".</p>
<b>Examples</b>	STATUS:MCPOWER:EVENTS? might return 2026,"Acq Sampling Params: manual control", indicating that the sampling parameters are controlled manually.

## STATUS:MERROR:EVENTS? (Query Only)

Returns the current events for the Magnitude error versus Time measurement.

<b>Conditions</b>	Measurement views: Magnitude error versus Time
<b>Group</b>	Status commands
<b>Syntax</b>	STATUS:MERROR:EVENTS?
<b>Arguments</b>	None
<b>Returns</b>	<p>&lt;ecode&gt;,"&lt;edesc&gt;[&lt;einfo&gt;]"{"&lt;ecode&gt;,"&lt;edesc&gt;[:&lt;einfo&gt;]}"</p> <p>Where</p> <p>&lt;ecode&gt;::=&lt;NR1&gt; is the error/event code (-32768 to 32767).</p> <p>&lt;edesc&gt;::=&lt;string&gt; is the description on the error/event.</p> <p>&lt;einfo&gt;::=&lt;string&gt; is the additional information on the error/event.</p> <p>If there is no error, the response is 0,"No error".</p>

**Examples** STATUS:MERROR:EVENTS? might return 2026,"Acq Sampling Params: manual control", indicating that the sampling parameters are controlled manually.

## STATus:OBWidth:EVENTs? (Query Only)

Returns the current events for the Occupied Bandwidth (OBW) measurement.

**Conditions** Measurement views: Occupied Bandwidth

**Group** Status commands

**Syntax** STATus:OBwidth:EVENTs?

**Arguments** None

**Returns** <ecode>,"<edesc>[<einfo>]" {,<ecode>,"<edesc>[:<einfo>"]}

Where

<ecode> ::= <NR1> is the error/event code (-32768 to 32767).

<edesc> ::= <string> is the description on the error/event.

<einfo> ::= <string> is the additional information on the error/event.

If there is no error, the response is 0,"No error".

**Examples** STATUS:OBWIDTH:EVENTS? might return 2026,"Acq Sampling Params: manual control", indicating that the sampling parameters are controlled manually.

## STATus:OPERation:CONDition? (Query Only)

Returns the contents of the Operation Condition Register (OCR).

**Conditions** Measurement views: All

**Group** Status commands

**Syntax** STATus:OPERation:CONDition?

<b>Arguments</b>	None
<b>Returns</b>	<NR1> is a decimal number showing the contents of the OCR.
<b>Examples</b>	STATUS:OPERATION:CONDITION? might return 16, showing that the bits in the OCR have the binary value 000000000010000, which means the analyzer is in measurement.

## STATUS:OPERation:ENABLE

Sets or queries the enable mask of the Operation Enable Register (OENR) which allows true conditions in the Operation Event Register to be reported in the summary bit.

<b>Conditions</b>	Measurement views: All
<b>Group</b>	Status commands
<b>Syntax</b>	STATUS:OPERation:ENABLE <bit_value> STATUS:OPERation:ENABLE?
<b>Arguments</b>	<bit_value> ::= <NR1> is the enable mask of the OENR. Range: 0 to 65535.
<b>Returns</b>	<NR1> is a decimal number showing the contents of the OENR. Range: 0 to 32767 (The most-significant bit cannot be set true.)
<b>Examples</b>	STATUS:OPERATION:ENABLE 1 enables the ALIGNing bit.  STATUS:OPERATION:ENABLE? might return 1, showing that the bits in the OENR have the binary value 00000000 00000001, which means that the ALIGNing bit is valid.

## STATUS:OPERation[:EVENT]? (Query Only)

Returns the contents of the Operation Event Register (OEVr). Reading the OEVr clears it.

<b>Conditions</b>	Measurement views: All
-------------------	------------------------

<b>Group</b>	Status commands
<b>Syntax</b>	STATUS:OPERation[:EVENT]?
<b>Arguments</b>	None
<b>Returns</b>	<NR1> is a decimal number showing the contents of the OEVR.
<b>Examples</b>	STATUS:OPERATION:EVENT? might return 1, showing that the bits in the OEVR have the binary value 00000000 00000001, which means that the ALIGNing bit is set.

## STATUS:OPERation:NTRansition

Sets or queries the negative transition filter value of the Operation Transition Register (OTR).

<b>Conditions</b>	Measurement views: All
<b>Group</b>	Status commands
<b>Syntax</b>	STATUS:OPERation:NTRansition <bit_value> STATUS:OPERation:NTRansition?
<b>Arguments</b>	<bit_value>::=<NR1> is the negative transition filter value. Range: 0 to 65535.
<b>Returns</b>	<NR1> is a decimal number showing the contents of the OTR. Range: 0 to 32767 (The most-significant bit cannot be set true.)
<b>Examples</b>	STATUS:OPERATION:NTRANSITION #H0011 sets the negative transition filter value to #H0011.  STATUS:OPERATION:NTRANSITION? might return 17.

## STATUS:OPERation:PTRansition

Sets or queries the positive transition filter value of the Operation Transition Register (OTR).

<b>Conditions</b>	Measurement views: All
<b>Group</b>	Status commands
<b>Syntax</b>	<pre> STATUS:OPERATION:PTRANSITION &lt;bit_value&gt; STATUS:OPERATION:PTRANSITION? </pre>
<b>Arguments</b>	<bit_value> ::= <NR1> is the positive transition filter value. Range: 0 to 65535.
<b>Returns</b>	<NR1> is a decimal number showing the contents of the OTR. Range: 0 to 32767 (The most-significant bit cannot be set true.)
<b>Examples</b>	<p>STATUS:OPERATION:PTRANSITION 0 sets the positive transition filter value to 0.</p> <p>STATUS:OPERATION:PTRANSITION? might return 0.</p>

## STATUS:PERRor:EVENTs? (Query Only)

Returns the current events for the Phase error versus Time measurement.

<b>Conditions</b>	Measurement views: Phase error versus Time
<b>Group</b>	Status commands
<b>Syntax</b>	<pre> STATUS:PERRor:EVENTs? </pre>
<b>Arguments</b>	None
<b>Returns</b>	<pre> &lt;ecode&gt;,"&lt;edesc&gt;[&lt;einfo&gt;]"{"&lt;ecode&gt;,"&lt;edesc&gt;[:&lt;einfo&gt;]"} </pre> <p>Where</p> <p>&lt;ecode&gt; ::= &lt;NR1&gt; is the error/event code (-32768 to 32767).</p> <p>&lt;edesc&gt; ::= &lt;string&gt; is the description on the error/event.</p> <p>&lt;einfo&gt; ::= &lt;string&gt; is the additional information on the error/event.</p> <p>If there is no error, the response is 0,"No error".</p>

**Examples** STATUS:PEROR:EVENTS? might return 2026,"Acq Sampling Params: manual control", indicating that the sampling parameters are controlled manually.

## STATus:PHVTime:EVENTs? (Query Only)

Returns the current events for the Phase versus Time measurement.

**Conditions** Measurement views: Phase versus Time

**Group** Status commands

**Syntax** STATus:PHVTime:EVENTs?

**Arguments** None

**Returns** <ecode>,"<edesc>[<einfo>]"{"<ecode>,"<edesc>[:<einfo>]"}

Where

<ecode> ::= <NR1> is the error/event code (-32768 to 32767).

<edesc> ::= <string> is the description on the error/event.

<einfo> ::= <string> is the additional information on the error/event.

If there is no error, the response is 0,"No error".

**Examples** STATus:PHVTime:EVENTs? might return 2026,"Acq Sampling Params: manual control", indicating that the sampling parameters are controlled manually.

## STATus:PNOise:EVENTs? (Query Only)

Returns the current events for the phase noise measurement.

**Conditions** Measurement views: Spurious

**Group** Status commands

**Syntax** STATus:PNOise:EVENTs?

<b>Arguments</b>	None
<b>Returns</b>	<code>&lt;ecode&gt;, "&lt;edesc&gt; [&lt;einfo&gt;]" {, &lt;ecode&gt;, "&lt;edesc&gt;[:&lt;einfo&gt;]"}</code> Where <code>&lt;ecode&gt; ::= &lt;NR1&gt;</code> is the error/event code (-32768 to 32767). <code>&lt;edesc&gt; ::= &lt;string&gt;</code> is the description on the error/event. <code>&lt;einfo&gt; ::= &lt;string&gt;</code> is the additional information on the error/event. If there is no error, the response is 0, "No error".
<b>Examples</b>	STATUS:PNOISE:EVENTS? might return 2026, "Acq Sampling Params: manual control", indicating that the sampling parameters are controlled manually.

## STATUS:PRESet (No Query Form)

Presets the SCPI enable registers and transition registers.

<b>Conditions</b>	Measurement views: All
<b>Group</b>	Status commands
<b>Syntax</b>	STATUS:PRESet
<b>Arguments</b>	None
<b>Examples</b>	STATUS:PRESET presets the SCPI enable registers and transition registers.

## STATUS:PULSe:RESult:EVENTS? (Query Only)

Returns the current events for the pulse table measurement.

<b>Conditions</b>	Measurement views: Pulse table
<b>Group</b>	Status commands
<b>Syntax</b>	STATUS:PULSe:RESult:EVENTS?

<b>Arguments</b>	None
<b>Returns</b>	<p><code>&lt;ecode&gt;,"&lt;edesc&gt;[&lt;einfo&gt;]"{,&lt;ecode&gt;,"&lt;edesc&gt;[:&lt;einfo&gt;]"}</code></p> <p>Where</p> <p><code>&lt;ecode&gt;::=&lt;NR1&gt;</code> is the error/event code (-32768 to 32767).</p> <p><code>&lt;edesc&gt;::=&lt;string&gt;</code> is the description on the error/event.</p> <p><code>&lt;einfo&gt;::=&lt;string&gt;</code> is the additional information on the error/event.</p> <p>If there is no error, the response is 0,"No error".</p>
<b>Examples</b>	<p><code>STATUS:PULSE:RESULT:EVENTS?</code> might return 2026,"Acq Sampling Params: manual control", indicating that the sampling parameters are controlled manually.</p>

## STATus:PULSe:STATistics:EVENTs? (Query Only)

Returns the current events for the pulse statistics measurement.

<b>Conditions</b>	Measurement views: Pulse statistics
<b>Group</b>	Status commands
<b>Syntax</b>	<code>STATus:PULSe:STATistics:EVENTs?</code>
<b>Arguments</b>	None
<b>Returns</b>	<p><code>&lt;ecode&gt;,"&lt;edesc&gt;[&lt;einfo&gt;]"{,&lt;ecode&gt;,"&lt;edesc&gt;[:&lt;einfo&gt;]"}</code></p> <p>Where</p> <p><code>&lt;ecode&gt;::=&lt;NR1&gt;</code> is the error/event code (-32768 to 32767).</p> <p><code>&lt;edesc&gt;::=&lt;string&gt;</code> is the description on the error/event.</p> <p><code>&lt;einfo&gt;::=&lt;string&gt;</code> is the additional information on the error/event.</p> <p>If there is no error, the response is 0,"No error".</p>
<b>Examples</b>	<p><code>STATUS:PULSE:STATISTICS:EVENTS?</code> might return 2026,"Acq Sampling Params: manual control", indicating that the sampling parameters are controlled manually.</p>



## STATus:PULSe:TRACe:EVENTs? (Query Only)

Returns the current events for the pulse trace measurement.

<b>Conditions</b>	Measurement views: Pulse trace
<b>Group</b>	Status commands
<b>Syntax</b>	STATus:PULSe:TRACe:EVENTs?
<b>Arguments</b>	None
<b>Returns</b>	<p>&lt;ecode&gt;,"&lt;edesc&gt;[&lt;einfo&gt;]"{"&lt;ecode&gt;,"&lt;edesc&gt;[:&lt;einfo&gt;]}"</p> <p>Where</p> <p>&lt;ecode&gt; ::= &lt;NR1&gt; is the error/event code (-32768 to 32767).</p> <p>&lt;edesc&gt; ::= &lt;string&gt; is the description on the error/event.</p> <p>&lt;einfo&gt; ::= &lt;string&gt; is the additional information on the error/event.</p> <p>If there is no error, the response is 0,"No error".</p>
<b>Examples</b>	<p>STATus:PULSe:TRACe:EVENTs? might return 2026,"Acq Sampling Params: manual control", indicating that the sampling parameters are controlled manually.</p>

## STATus:QUESTionable:CALibration:CONDition? (Query Only)

Returns the contents of the questionable calibration condition register.

<b>Conditions</b>	Measurement views: All
<b>Group</b>	Status commands
<b>Syntax</b>	STATus:QUESTionable:CALibration:CONDition?
<b>Arguments</b>	None
<b>Returns</b>	<p>&lt;NR1&gt; is a decimal number showing the contents of the questionable calibration condition register.</p>

**Examples**     `STATUS:QUESTIONABLE:CALIBRATION:CONDITION?` might return 16384, showing that the bits in the questionable calibration condition register have the binary value 01000000 00000000, which means the Alignment Needed bit is set.

## **STATus:QUEStionable:CALibration:ENABLE**

Sets or queries the enable mask of the questionable calibration enable register which allows true conditions in the questionable calibration event register to be reported in the summary bit.

**Conditions**     Measurement views: All

**Group**            Status commands

**Syntax**          `STATUS:QUESTIONable:CALibration:ENABLE <bit_value>`  
`STATUS:QUESTIONable:CALibration:ENABLE?`

**Arguments**      `<bit_value> ::= <NR1>` is the enable mask of the questionable calibration enable register. Range: 0 to 65535.

**Returns**          `<NR1>` is a decimal number showing the contents of the questionable calibration enable register. Range: 0 to 32767 (The most-significant bit cannot be set true.)

**Examples**        `STATUS:QUESTIONABLE:CALIBRATION:ENABLE 16384` enables the Alignment Needed bit.

`STATUS:QUESTIONABLE:CALIBRATION:ENABLE?` might return 16384, showing that the bits in the questionable calibration enable register have the binary value 01000000 00000000, which means that the Calibration Summary bit is valid.

## **STATus:QUEStionable:CALibration[:EVENT]? (Query Only)**

Returns the contents of the questionable calibration event register. Reading the register clears it.

**Conditions**      Measurement views: All

**Group**            Status commands

<b>Syntax</b>	<code>STATUS:QUESTIONABLE:CALIBRATION[:EVENT]?</code>
<b>Arguments</b>	None
<b>Returns</b>	<NR1> is a decimal number showing the contents of the questionable calibration event register.
<b>Examples</b>	<code>STATUS:QUESTIONABLE:CALIBRATION:EVENT?</code> might return 16384, showing that the bits in the questionable calibration event register have the binary value 01000000 00000000, which means that the Calibration Summary bit is set.

## STATUS:QUESTIONABLE:CALIBRATION:NTRANSITION

Sets or queries the negative transition filter value of the questionable calibration transition register.

<b>Conditions</b>	Measurement views: All
<b>Group</b>	Status commands
<b>Syntax</b>	<code>STATUS:QUESTIONABLE:CALIBRATION:NTRANSITION &lt;bit_value&gt;</code> <code>STATUS:QUESTIONABLE:CALIBRATION:NTRANSITION?</code>
<b>Arguments</b>	<bit_value> ::= <NR1> is the negative transition filter value. Range: 0 to 65535.
<b>Returns</b>	<NR1> is a decimal number showing the contents of the questionable calibration transition register. Range: 0 to 32767 (The most-significant bit cannot be set true.)
<b>Examples</b>	<code>STATUS:QUESTIONABLE:CALIBRATION:NTRANSITION #H4000</code> sets the negative transition filter value to #H4000.  <code>STATUS:QUESTIONABLE:CALIBRATION:NTRANSITION?</code> might return 16384.

## STATUS:QUESTIONABLE:CALIBRATION:PTRANSITION

Sets or queries the positive transition filter value of the questionable calibration transition register.

<b>Conditions</b>	Measurement views: All
<b>Group</b>	Status commands
<b>Syntax</b>	STATUS:QUESTIONABLE:CALIBRATION:PTRANSITION <bit_value> STATUS:QUESTIONABLE:CALIBRATION:PTRANSITION?
<b>Arguments</b>	<bit_value>::=<NR1> is the positive transition filter value. Range: 0 to 65535.
<b>Returns</b>	<NR1> is a decimal number showing the contents of the questionable calibration transition register. Range: 0 to 32767 (The most-significant bit cannot be set true.)
<b>Examples</b>	STATUS:QUESTIONABLE:CALIBRATION:PTRANSITION 0 sets the positive transition filter value to 0.  STATUS:QUESTIONABLE:CALIBRATION:PTRANSITION? might return 0.

## STATUS:QUESTIONABLE:CONDITION? (Query Only)

Returns the contents of the Questionable Condition Register (QCR).

<b>Conditions</b>	Measurement views: All
<b>Group</b>	Status commands
<b>Syntax</b>	STATUS:QUESTIONABLE:CONDITION?
<b>Arguments</b>	None
<b>Returns</b>	<NR1> is a decimal number showing the contents of the QCR.
<b>Examples</b>	STATUS:QUESTIONABLE:CONDITION? might return 256, showing that the bits in the QCR have the binary value 00000001 00000000, which means the Calibration Summary bit is set.

## STATus:QUESTionable:ENABLE

Sets or queries the enable mask of the Questionable Enable Register (QENR) which allows true conditions in the Questionable Event Register to be reported in the summary bit.

<b>Conditions</b>	Measurement views: All
<b>Group</b>	Status commands
<b>Syntax</b>	STATus:QUESTionable:ENABLE <bit_value> STATus:QUESTionable:ENABLE?
<b>Arguments</b>	<bit_value> ::= <NR1> is the enable mask of QENR. Range: 0 to 65535.
<b>Returns</b>	<NR1> is a decimal number showing the contents of the QENR. Range: 0 to 32767 (The most-significant bit cannot be set true.)
<b>Examples</b>	<p>STATus:QUESTIONABLE:ENABLE 256 enables the Calibration Summary bit.</p> <p>STATus:QUESTIONABLE:ENABLE? might return 256, showing that the bits in the QENR have the binary value 00000001 00000000, which means that the Calibration Summary bit is valid.</p>

## STATus:QUESTionable[:EVENT]? (Query Only)

Returns the contents of the Questionable Event Register (QEVr). Reading the QEVr clears it.

<b>Conditions</b>	Measurement views: All
<b>Group</b>	Status commands
<b>Syntax</b>	STATus:QUESTionable[:EVENT]?
<b>Arguments</b>	None
<b>Returns</b>	<NR1> is a decimal number showing the contents of the QEVr.

**Examples** STATUS:QUESTIONABLE:EVENT? might return 256, showing that the bits in the QEVr have the binary value 00000001 00000000, which means that the Calibration Summary bit is set.

## STATus:QUEStionable:FREQuency:CONDition? (Query Only)

Returns the contents of the questionable frequency condition register.

**Conditions** Measurement views: All

**Group** Status commands

**Syntax** STATus:QUEStionable:FREQuency:CONDition?

**Arguments** None

**Returns** <NR1> is a decimal number showing the contents of the questionable frequency condition register.

**Examples** STATUS:QUESTIONABLE:FREQUENCY:CONDITION? might return 512, showing that the bits in the questionable frequency condition register have the binary value 00000010 00000000, which means the Locked To External Ref bit is set.

## STATus:QUEStionable:FREQuency:ENABLE

Sets or queries the enable mask of the questionable frequency enable register which allows true conditions in the questionable frequency event register to be reported in the summary bit.

**Conditions** Measurement views: All

**Group** Status commands

**Syntax** STATus:QUEStionable:FREQuency:ENABLE <bit\_value>  
STATus:QUEStionable:FREQuency:ENABLE?

**Arguments** <bit\_value>::=<NR1> is the enable mask of the questionable frequency enable register. Range: 0 to 65535.

**Returns** <NR1> is a decimal number showing the contents of the questionable frequency enable register. Range: 0 to 32767 (The most-significant bit cannot be set true.)

**Examples** STATUS:QUESTIONABLE:FREQUENCY:ENABLE 512 enables the Locked To External Ref bit.

STATUS:QUESTIONABLE:FREQUENCY:ENABLE? might return 512, showing that the bits in the questionable calibration enable register have the binary value 00000010 00000000, which means that the Locked To External Ref bit is valid.

## STATUS:QUESTIONABLE:FREQUENCY[:EVENT]? (Query Only)

Returns the contents of the questionable frequency event register. Reading the register clears it.

**Conditions** Measurement views: All

**Group** Status commands

**Syntax** STATUS:QUESTIONABLE:FREQUENCY[:EVENT]?

**Arguments** None

**Returns** <NR1> is a decimal number showing the contents of the questionable frequency event register.

**Examples** STATUS:QUESTIONABLE:FREQUENCY:EVENT? might return 512, showing that the bits in the questionable frequency event register have the binary value 00000010 00000000, which means that the Locked To External Ref bit is set.

## STATUS:QUESTIONABLE:FREQUENCY:NTRANSITION

Sets or queries the negative transition filter value of the questionable frequency transition register.

**Conditions** Measurement views: All

**Group** Status commands

**Syntax**     `STATus:QUESTionable:FREQuency:NTRansition <bit_value>`  
`STATus:QUESTionable:FREQuency:NTRansition?`

**Arguments**     `<bit_value>::=<NR1>` is the negative transition filter value. Range: 0 to 65535.

**Returns**     `<NR1>` is a decimal number showing the contents of the questionable frequency transition register. Range: 0 to 32767 (The most-significant bit cannot be set true.)

**Examples**     `STATus:QUESTIONABLE:FREQUENCY:NTRANSITION #H0200` sets the negative transition filter value to #H0200.

`STATus:QUESTIONABLE:FREQUENCY:NTRANSITION?` might return 512.

## STATus:QUESTionable:FREQuency:PTRansition

Sets or queries the positive transition filter value of the questionable frequency transition register.

**Conditions**     Measurement views: All

**Group**     Status commands

**Syntax**     `STATus:QUESTionable:FREQuency:PTRansition <bit_value>`  
`STATus:QUESTionable:FREQuency:PTRansition?`

**Arguments**     `<bit_value>::=<NR1>` is the positive transition filter value. Range: 0 to 65535.

**Returns**     `<NR1>` is a decimal number showing the contents of the questionable frequency transition register. Range: 0 to 32767 (The most-significant bit cannot be set true.)

**Examples**     `STATus:QUESTIONABLE:FREQUENCY:PTRANSITION 0` sets the positive transition filter value to 0.

`STATus:QUESTIONABLE:FREQUENCY:PTRANSITION?` might return 0.

## STATus:QUESTionable:NTRansition

Sets or queries the negative transition filter value of the Questionable Transition Register (QTR).



<b>Conditions</b>	Measurement views: All
<b>Group</b>	Status commands
<b>Syntax</b>	<pre> STATUS:QUESTIONABLE:NTRANSITION &lt;bit_value&gt; STATUS:QUESTIONABLE:NTRANSITION? </pre>
<b>Arguments</b>	<bit_value> ::= <NR1> is the negative transition filter value. Range: 0 to 65535.
<b>Returns</b>	<NR1> is a decimal number showing the contents of the QTR. Range: 0 to 32767 (The most-significant bit cannot be set true.)
<b>Examples</b>	<pre> STATUS:QUESTIONABLE:NTRANSITION #H0020 sets the negative transition filter value to #H0020.  STATUS:QUESTIONABLE:NTRANSITION? might return 32. </pre>

## STATUS:QUESTIONABLE:PTRANSITION

Sets or queries the positive transition filter value of the Questionable Transition Register (QTR).

<b>Conditions</b>	Measurement views: All
<b>Group</b>	Status commands
<b>Syntax</b>	<pre> STATUS:QUESTIONABLE:PTRANSITION &lt;bit_value&gt; STATUS:QUESTIONABLE:PTRANSITION? </pre>
<b>Arguments</b>	<bit_value> ::= <NR1> is the positive transition filter value. Range: 0 to 65535.
<b>Returns</b>	<NR1> is a decimal number showing the contents of the QTR. Range: 0 to 32767 (The most-significant bit cannot be set true.)
<b>Examples</b>	<pre> STATUS:QUESTIONABLE:PTRANSITION 0 sets the positive transition filter value to 0.  STATUS:QUESTIONABLE:PTRANSITION? might return 0. </pre>

## STATus:SGRAM:EVENTs? (Query Only)

Returns the current events for the spectrogram measurement.

<b>Conditions</b>	Measurement views: Spectrogram
<b>Group</b>	Status commands
<b>Syntax</b>	STATus:SGRAM:EVENTs?
<b>Arguments</b>	None
<b>Returns</b>	<code>&lt;ecode&gt;,"&lt;edesc&gt;[&lt;einfo&gt;]"{,&lt;ecode&gt;,"&lt;edesc&gt;[:&lt;einfo&gt;]"}</code> Where <code>&lt;ecode&gt;::=&lt;NR1&gt;</code> is the error/event code (-32768 to 32767). <code>&lt;edesc&gt;::=&lt;string&gt;</code> is the description on the error/event. <code>&lt;einfo&gt;::=&lt;string&gt;</code> is the additional information on the error/event. If there is no error, the response is 0,"No error".
<b>Examples</b>	STATus:SGRAM:EVENTs? might return 2026,"Acq Sampling Params: manual control", indicating that the sampling parameters are controlled manually.

## STATus:SPECTrum:EVENTs? (Query Only)

Returns the current events for the spectrum measurement.

<b>Conditions</b>	Measurement views: Spectrum
<b>Group</b>	Status commands
<b>Syntax</b>	STATus:SPECTrum:EVENTs?
<b>Arguments</b>	None
<b>Returns</b>	<code>&lt;ecode&gt;,"&lt;edesc&gt;[&lt;einfo&gt;]"{,&lt;ecode&gt;,"&lt;edesc&gt;[:&lt;einfo&gt;]"}</code>

Where

<ecode> ::= <NR1> is the error/event code (-32768 to 32767).

<edesc> ::= <string> is the description on the error/event.

<einfo> ::= <string> is the additional information on the error/event.

If there is no error, the response is 0, "No error".

**Examples** STATUS:SPECTRUM:EVENTS? might return 2026, "Acq Sampling Params: manual control", indicating that the sampling parameters are controlled manually.

## STATUS:SPURIOUS:EVENTS? (Query Only)

Returns the current events for the Spurious measurement.

**Conditions** Measurement views: Spurious

**Group** Status commands

**Syntax** STATUS:SPURIOUS:EVENTS?

**Arguments** None

**Returns** <ecode>,"<edesc>[<einfo>]"{"<ecode>,"<edesc>[:<einfo>]"} }

Where

<ecode> ::= <NR1> is the error/event code (-32768 to 32767).

<edesc> ::= <string> is the description on the error/event.

<einfo> ::= <string> is the additional information on the error/event.

If there is no error, the response is 0, "No error".

**Examples** STATUS:SPURIOUS:EVENTS? might return 2026, "Acq Sampling Params: manual control", indicating that the sampling parameters are controlled manually.

## STATUS:SQUALITY:EVENTS? (Query Only)

Returns the current events for the signal quality measurement.

**Conditions** Measurement views: Signal quality

<b>Group</b>	Status commands
<b>Syntax</b>	STATUS:SQUALITY:EVENTS?
<b>Arguments</b>	None
<b>Returns</b>	<p>&lt;ecode&gt;,"&lt;edesc&gt;[&lt;einfo&gt;]"{,&lt;ecode&gt;,"&lt;edesc&gt;[:&lt;einfo&gt;]}"</p> <p>Where</p> <p>&lt;ecode&gt;::=&lt;NR1&gt; is the error/event code (-32768 to 32767).</p> <p>&lt;edesc&gt;::=&lt;string&gt; is the description on the error/event.</p> <p>&lt;einfo&gt;::=&lt;string&gt; is the additional information on the error/event.</p> <p>If there is no error, the response is 0,"No error".</p>
<b>Examples</b>	STATUS:SQUALITY:EVENTS? might return 2026,"Acq Sampling Params: manual control", indicating that the sampling parameters are controlled manually.

## STATUS:TDiagram:EVENTS? (Query Only)

Returns the current events for the trellis diagram measurement.

<b>Conditions</b>	Measurement views: Trellis diagram
<b>Group</b>	Status commands
<b>Syntax</b>	STATUS:TDiagram:EVENTS?
<b>Arguments</b>	None
<b>Returns</b>	<p>&lt;ecode&gt;,"&lt;edesc&gt;[&lt;einfo&gt;]"{,&lt;ecode&gt;,"&lt;edesc&gt;[:&lt;einfo&gt;]}"</p> <p>Where</p> <p>&lt;ecode&gt;::=&lt;NR1&gt; is the error/event code (-32768 to 32767).</p> <p>&lt;edesc&gt;::=&lt;string&gt; is the description on the error/event.</p> <p>&lt;einfo&gt;::=&lt;string&gt; is the additional information on the error/event.</p> <p>If there is no error, the response is 0,"No error".</p>

**Examples** STATUS:TDIAGRAM:EVENTS? might return 2026, "Acq Sampling Params: manual control", indicating that the sampling parameters are controlled manually.

## \*STB? (Query Only)

Returns the contents of the Status Byte Register (SBR) in the status/event reporting structure using the Master Summary Status (MSS) bit. Refer to Section 3, *Status and Events*, for the register information.

**Conditions** Measurement views: All

**Group** IEEE common commands

**Syntax** \*STB?

**Related Commands** [\\*CLS](#), [\\*ESE](#), [\\*ESR?](#), [\\*SRE](#)

**Arguments** None

**Returns** <NR1> representing the contents of the SBR as a decimal number.

**Examples** \*STB? might return 96, indicating that the SBR contains binary 0110 0000.

## SYSTem:COMMunicate:GPIB[:SELF]:ADDRess

Sets or queries the GPIB address of the instrument.

**Conditions** Measurement views: All

**Group** System commands

**Syntax** SYSTem:COMMunicate:GPIB[:SELF]:ADDRess <value>  
SYSTem:COMMunicate:GPIB[:SELF]:ADDRess?

**Arguments** <value>::=<NR1> specifies the GPIB address of the instrument.  
\*RST has no effect on the value.

**Examples**     `SYSTEM:COMMUNICATE:GPIB:SELF:ADDRESS 18` sets the GPIB address to 18.

## SYSTem:DATE

Sets or queries the date (year, month, and day). This command is equivalent to the date setting through the Windows Control Panel.

**Conditions**     Measurement views: All

**Group**           System commands

**Syntax**          `SYSTem:DATE <year>, <month>, <day>`  
`SYSTem:DATE?`

**Related Commands**     [SYSTem:TIME](#)

**Arguments**        `<year>::=<Nrf>` specifies the year (4 digits). Range: 2000 to 2099.  
`<month>::=<Nrf>` specifies the month. Range: 1 (January) to 12 (December).  
`<day>::=<Nrf>` specifies the day. Range: 1 to 31.  
 These values are rounded to the nearest integer.  
**\*RST** has no effect on the settings.

**Examples**        `SYSTEM:DATE 2008, 3, 19` sets the internal calendar to March 19, 2008.

## SYSTem:ERRor:ALL? (Query Only)

Queries the error/event queue for all the unread items and removes them from the queue. The response is a comma separated list of number, string pairs in FIFO order. For details of the error messages, refer to (See Table 3-8.)

**Conditions**        Measurement views: All

**Group**            System commands

**Syntax**           `SYSTem:ERRor:ALL?`

**Arguments**        None

**Returns** <ecode>,"<edesc>[;<einfo>]"{"<ecode>,"<edesc>[;<einfo>]"}

Where

<ecode> ::= <NR1> is the error/event code (-32768 to 32767).

<edesc> ::= <string> is the description on the error/event.

<einfo> ::= <string> is the detail of the error/event.

If the queue is empty, the response is 0, "No error; Queue empty - No events to report".

**Examples** SYSTEM:ERROR:ALL? might return -130, "Suffix error; Unrecognized suffix, INPUTMLeve1 -10dB", , indicating that the unit of the reference level is improper.

## SYSTem:ERRor:CODE:ALL? (Query Only)

Queries the error/event queue for all the unread items and removes them from the queue. The response returns a comma separated list of only the error/event code numbers in FIFO order. For details of the error messages, refer to (See Table 3-8.)

**Conditions** Measurement views: All

**Group** System commands

**Syntax** SYSTem:ERRor:CODE:ALL?

**Arguments** None

**Returns** <ecode>{ ,<ecode>}

Where

<ecode> ::= <NR1> is the error/event code, ranging from -32768 to 32767.

If the queue is empty, the response is 0.

**Examples** SYSTEM:ERROR:CODE:ALL? might return -101, -108 of the error codes.

## SYSTem:ERRor:CODE[:NEXT]? (Query Only)

Queries the error/event queue for the next item and removes it from the queue. The response returns only the error/event code number omitting the string. Except for the shortened response, the query operates identically to

[SYSTem:ERRor\[:NEXT\]?](#). For details of the error messages, refer to (See Table 3-8.)

<b>Conditions</b>	Measurement views: All
<b>Group</b>	System commands
<b>Syntax</b>	SYSTem:ERRor:CODE[:NEXT]?
<b>Arguments</b>	None
<b>Returns</b>	<code>::=<NR1> is the error/event code, ranging from -32768 to 32767.
<b>Examples</b>	SYSTem:ERRor:CODE:NEXT? might return -101 of the error code.

## SYSTem:ERRor:COUNT? (Query Only)

Queries the error/event queue for the number of unread items. As errors and events may occur at any time, more items may be present in the queue at the time it is actually read.

<b>Conditions</b>	Measurement views: All
<b>Group</b>	System commands
<b>Syntax</b>	SYSTem:ERRor:COUNT?
<b>Arguments</b>	None
<b>Returns</b>	<enum>::=<NR1> is the number of errors/events. If the queue is empty, the response is 0.
<b>Examples</b>	SYSTem:ERRor:COUNT? might return 2, indicating that the error/event queue contains two of unread errors/events.



## SYSTem:ERRor[:NEXT]? (Query Only)

Queries the error/event queue for the next item and removes it from the queue. The response returns the full queue item consisting of an integer and a string. For details of the error messages, refer to (See Table 3-8.)

**Conditions** Measurement views: All

**Group** System commands

**Syntax** SYSTem:ERRor[:NEXT]?

**Arguments** None

**Returns** <ecode>,"<edesc>[:<einfo>]"

Where

<ecode> ::= <NR1> is the error/event code, ranging from -32768 to 32767.

<edesc> ::= <string> is the description on the error/event.

<einfo> ::= <string> is the additional information on the error/event.

**Examples** SYSTem:ERRor:NEXT? might return -130, "suffix error; Unrecognized suffix, INPutMLEve1 -10dB", indicating that the unit is improper.

## SYSTem:OPTions? (Query Only)

Queries the options installed in the analyzer. This command is equivalent to the IEEE common command \*OPT?.

**Conditions** Measurement views: All

**Group** System commands

**Syntax** SYSTem:OPTions?

**Arguments** None

**Returns** <option>::=<string> contains the comma-separated option numbers.

**Examples** SYSTEM:OPTIONS? might return "01,02,20", indicating that Option 01, 02, and 20 are currently installed in the analyzer.

## SYSTEM:PRESet (No Query Form)

Restores the analyzer to the defaults. This command is equivalent to the **Preset** key on the front panel.

**Conditions** Measurement views: All

**Group** System commands

**Syntax** SYSTEM:PRESet

**Arguments** None

**Examples** SYSTEM:PRESET restores the analyzer to the defaults.

## SYSTEM:TIME

Sets or queries the time (hours, minutes, and seconds). This command is equivalent to the time setting through the Windows Control Panel.

**Conditions** Measurement views: All

**Group** System commands

**Syntax** SYSTEM:TIME <hour>, <minute>, <second>  
SYSTEM:TIME?

**Related Commands** [SYSTEM:DATE](#)

**Arguments** <hour>::=<NRf> specifies the hours. Range: 0 to 23.  
<minute>::=<NRf> specifies the minutes. Range: 0 to 59.  
<second>::=<NRf> specifies the seconds. Range: 0 to 59.

These values are rounded to the nearest integer.

\*RST has no effect on the settings.

**Examples**    `SYSTEM:TIME 10,15,30` sets the time to 1015:30.

## SYSTem:VERSion? (Query Only)

Returns the SCPI version number for which the analyzer complies.

**Conditions**    Measurement views: All

**Group**        System commands

**Syntax**       `SYSTem:VERSion?`

**Arguments**    None

**Returns**       <NR2> has the form YYYY.V where the Ys represent the year-version (for example, 1999) and the V represents an approved revision number for that year.

**Examples**       `SYSTEM:VERSION?` might return `1999.0` for the SCPI version.

## TRACe:{AM|FM|PM}

Determines whether or not to show the trace in the AM/FM/PM view.

**Conditions**    Measurement views: AM, FM, PM

**Group**        Trace commands

**Syntax**       `TRACe:{AM|FM|PM} { OFF | ON | 0 | 1 }`  
`TRACe:{AM|FM|PM}?`

**Arguments**    OFF or 0 hides the trace in the AM, FM, or PM view.

ON or 1 shows the trace in the AM, FM, or PM view.

**Examples** TRACE:AM ON shows the trace in the AM view.

## TRACe:{AM|FM|PM}:DETection

Selects or queries the display detector, the method to be used for decimating traces to fit the available horizontal space on screen. The number of horizontal pixels on screen is generally smaller than that of waveform data points. When actually displayed, the waveform data is therefore thinned out, according to the number of pixels, for being compressed.

**Conditions** Measurement views: AM, FM, PM

**Group** Trace commands

**Syntax** TRACe:{AM|FM|PM}:DETection { AVERage | POSitive | NEGative }  
TRACe:{AM|FM|PM}:DETection?

**Arguments** AVERage displays the average data value for each pixel.  
POSitive displays the maximum data value for each pixel.  
NEGative displays the minimum data value for each pixel.

**Examples** TRACE:AM:DETECTION AVERage specifies that the trace displays the average data value for each pixel.

## TRACe:{AM|FM|PM}:FREeze

Determines whether or not to freeze the trace display in the AM/FM/PM view.

**Conditions** Measurement views: AM, FM, PM

**Group** Trace commands

**Syntax** TRACe:{AM|FM|PM}:FREeze { OFF | ON | 0 | 1 }  
TRACe:{AM|FM|PM}:FREeze?

**Arguments** OFF or 0 updates the trace display normally.  
ON or 1 stops updating the trace display.

**Examples** TRACE:AM:FREEZE ON freezes the trace display.

## TRACe:{AM|FM|PM}:FUNctIon

Selects or queries the trace function in the AM/FM/PM view.

**Conditions** Measurement views: AM, FM, PM

**Group** Trace commands

**Syntax** TRACe:{AM|FM|PM}:FUNctIon { NORMa1 }  
TRACe:{AM|FM|PM}:FUNctIon?

**Arguments** NORMa1 selects the normal display.

**Examples** TRACE:AM:FUNCTION NORMa1 selects the normal display in the AM view.

## TRACe<x>:AVTime

Determines whether or not to show the specified trace in the Amplitude versus Time view.

The parameter <x> = 1 to 4; All traces are valid.

**Conditions** Measurement views: Amplitude versus Time

**Group** Trace commands

**Syntax** TRACe<x>:AVTime { OFF | ON | 0 | 1 }  
TRACe<x>:AVTime?

**Arguments** OFF or 0 hides the specified trace in the Amplitude versus Time view.  
ON or 1 shows the specified trace in the Amplitude versus Time view.

**Examples** TRACE1:AVTIME ON shows Trace 1 in the Amplitude versus Time view.

## TRACe<x>:AVTime:AVERage:COUNT

Sets or queries the number of traces to combine. This command is effective when you select AVERage with the [TRACe<x>:AVTime:FUNCTION](#) command.

The parameter <x> = 1 to 3; Trace 4 (math trace) is invalid.

**Conditions** Measurement views: Amplitude versus Time

**Group** Trace commands

**Syntax** TRACe<x>:AVTime:AVERage:COUNT <number>  
TRACe<x>:AVTime:AVERage:COUNT?

**Arguments** <number>: :=<NR1> specifies the number of traces to combine for averaging.  
Range: 1 to 10000.

**Examples** TRACE1:AVTIME:AVERAGE:COUNT 64 sets the average count to 64 for Trace 1.

## TRACe<x>:AVTime:AVERage:RESet (No Query Form)

Restarts acquisition and display of waveforms for the specified trace. For an Average, Max Hold, or Min Hold trace, it restarts the sequence, discarding accumulated data and resetting the counter.

The parameter <x> = 1 to 3; Trace 4 (math trace) is invalid.

**Conditions** Measurement views: Amplitude versus Time

**Group** Trace commands

**Syntax** TRACe<x>:AVTime:AVERage:RESet

**Related Commands** [TRACe<x>:AVTime:FUNCTION](#)

**Arguments** None

**Examples** TRACE1:AVTIME:AVERAGE:RESET restarts acquisition and display of waveforms for Trace 1.

## TRACe<x>:AVTime:COUNT

Sets or queries how many acquisitions run in the single acquisition mode for the Max or Min Hold trace in the Amplitude versus Time measurement. This command is effective when [TRACe<x>:AVTime:FUNCTION](#) is set to MAXHold or MINHold and [INITiate:CONTinuous](#) is set to OFF.

The parameter <x> = 1 to 3; Trace 4 (math trace) is invalid.

<b>Conditions</b>	Measurement views: Amplitude versus Time
<b>Group</b>	Trace commands
<b>Syntax</b>	TRACe<x>:AVTime:COUNT <number> TRACe<x>:AVTime:COUNT?
<b>Arguments</b>	<number> ::= <NR1> specifies the count for Max/Min Hold. Range: 1 to 10000.
<b>Examples</b>	TRACE1:AVTIME:COUNT 32 sets the count to 32 for Trace 1.

## TRACe<x>:AVTime:COUNT:ENABLE

Determines whether to enable or disable the count for the Max or Min Hold trace in the Amplitude versus Time view. This command is effective when [TRACe<x>:AVTime:FUNCTION](#) is set to MAXHold or MINHold.

The parameter <x> = 1 to 3; Trace 4 (math trace) is invalid.

<b>Conditions</b>	Measurement views: Amplitude versus Time
<b>Group</b>	Trace commands
<b>Syntax</b>	TRACe<x>:AVTime:COUNT:ENABLE { OFF   ON   0   1 } TRACe<x>:AVTime:COUNT:ENABLE?
<b>Arguments</b>	OFF or 0 disables the count for the Max/Min Hold trace. ON or 1 enables the count for the Max/Min Hold trace.

**Examples** TRACE1:AVTIME:COUNT:ENABLE ON enables the Max/Min Hold count for Trace 1.

## TRACe<x>:AVTime:COUNT:RESet (No Query Form)

Clears the Max or Min Hold data and counter, and restarts the process for the specified trace in the Amplitude versus Time view. This command is effective when TRACe<x>:AVTime:FUNCTION is set to MAXHold or MINHold.

The parameter <x> = 1 to 3; Trace 4 (math trace) is invalid.

**Conditions** Measurement views: Amplitude versus Time

**Group** Trace commands

**Syntax** TRACe<x>:AVTime:COUNT:RESet

**Arguments** None

**Examples** TRACE1:AVTIME:COUNT:RESET clears the Max/Min Hold data and counter, and restarts the process for Trace 1.

## TRACe<x>:AVTime:DETection

Selects or queries the display detector (method to be used for decimating traces to fit the available horizontal space on screen). The number of horizontal pixels on screen is generally smaller than that of waveform data points. When actually displayed, the waveform data is therefore thinned out, according to the number of pixels, for being compressed.

**Conditions** Measurement views: Amplitude versus Time

**Group** Trace commands

**Syntax** TRACe<x>:AVTime:DETection { AVERAge | POSitive | NEGative | POSNegative | SAMPlE }  
TRACe<x>:AVTime:DETection?



<b>Arguments</b>	<p><b>AVERage</b> displays the average data value for each pixel.</p> <p><b>POSitive</b> displays the maximum data value for each pixel.</p> <p><b>NEGative</b> displays the minimum data value for each pixel.</p> <p><b>POSNegative</b> displays the maximum and minimum data values for each pixel.</p> <p><b>SAMPle</b> displays the first sample value received for each pixel.</p>
<b>Examples</b>	<p><code>TRACE:AVTIME:DETECTION AVERAGE</code> specifies that the trace displays the average data value for each pixel.</p>

## TRACe<x>:AVTime:FREeze

Determines whether or not to freeze the display of the specified trace in the Amplitude versus Time view.

The parameter <x> = 1 to 4; All traces are valid.

<b>Conditions</b>	Measurement views: Amplitude versus Time
<b>Group</b>	Trace commands
<b>Syntax</b>	<pre>TRACe&lt;x&gt;:AVTime:FREeze { OFF   ON   0   1 } TRACe&lt;x&gt;:AVTime:FREeze?</pre>
<b>Arguments</b>	<p><b>OFF</b> or <b>0</b> updates the display of the specified trace normally.</p> <p><b>ON</b> or <b>1</b> stops updating the display of the specified trace.</p>
<b>Examples</b>	<p><code>TRACE1:AVTIME:FREEZE ON</code> freezes the display for Trace 1.</p>

## TRACe<x>:AVTime:FUNCTion

Selects or queries the function for the specified trace in the Amplitude versus Time view.

The parameter <x> = 1 to 3; Trace 4 (math trace) is invalid.

<b>Conditions</b>	Measurement views: Amplitude versus Time
<b>Group</b>	Trace commands

**Syntax** TRACE<x>:AVTime:FUNCTION { NORMa1 | AVERAge | MAXHO1d | MINHO1d }  
TRACE<x>:AVTime:FUNCTION?

**Arguments** NORMa1 selects the normal display.  
AVERAge selects the Average display that indicates the average amplitude at each time point.  
MAXHO1d selects the Max Hold display that indicates the maximum amplitude at each time point.  
MINHO1d selects the Min Hold display that indicates the minimum amplitude at each time point.

**Examples** TRACE1:AVTIME:FUNCTION MAXHO1d selects Max Hold for Trace 1 in the Amplitude versus Time view.

## TRACe<x>:AVTime:LEFToperand

Selects or queries the left operand for the math trace (Trace 4) in the Amplitude versus Time view.

The parameter <x> = 4; Only Trace 4 (math trace) is valid.

**Conditions** Measurement views: Amplitude versus Time

**Group** Trace commands

**Syntax** TRACe<x>:AVTime:LEFToperand { TRACE1 | TRACE2 | TRACE3 }  
TRACe<x>:AVTime:LEFToperand?

**Related Commands** [TRACe<x>:AVTime:RIGHtoperand](#)

**Arguments** TRACE1 selects Trace 1 as the left operand for the math trace.  
TRACE2 selects Trace 2 as the left operand for the math trace.  
TRACE3 selects Trace 3 as the left operand for the math trace.

**Examples** TRACE4:AVTIME:LEFTOPERAND TRACE2 selects Trace 2 as the left operand for the math trace.

## TRACe<x>:AVTime:RIGHToperand

Selects or queries the right operand for the math trace (Trace 4) in the Amplitude versus Time view.

The parameter <x> = 4; Only Trace 4 (math trace) is valid.

**Conditions** Measurement views: Amplitude versus Time

**Group** Trace commands

**Syntax** TRACe<x>:AVTime:RIGHToperand { TRACE1 | TRACE2 | TRACE3 }  
TRACe<x>:AVTime:RIGHToperand?

**Related Commands** [TRACe<x>:AVTime:LEFToperand](#)

**Arguments** TRACE1 selects Trace 1 as the right operand for the math trace.  
TRACE2 selects Trace 2 as the right operand for the math trace.  
TRACE3 selects Trace 3 as the right operand for the math trace.

**Examples** TRACE4:AVTIME:RIGHTOPERAND TRACE1 selects Trace 1 as the right operand for the math trace.

## TRACe<x>:AVTime:SElect

Selects or queries the trace whose measurement results are being displayed in the readout on the top and bottom of the view.

The parameter <x> = 1 to 4; All traces are valid.

**Conditions** Measurement views: Amplitude versus Time

**Group** Trace commands

**Syntax** TRACe<x>:AVTime:SElect  
TRACe<x>:AVTime:SElect?

**Arguments** None

**Returns** { 0 | 1 }

0 indicates that the results are not being displayed in the readout for the trace.  
 1 indicates that the results are being displayed in the readout for the trace.

**Examples** TRACE1:AVTIME:SELECT selects Trace 1 to display the measurement results in the readout.

TRACE1:AVTIME:SELECT? might return 1, indicating that the results are being displayed in the readout for Trace 1.

## TRACe<x>:CCDF:FREEze

Determines whether or not to freeze the display of the specified trace (Trace 1 or 2) in the CCDF view.

The parameter <x> = 1 or 2; Trace 3 (Gaussian curve) is invalid.

**Conditions** Measurement views: CCDF

**Group** Trace commands

**Syntax** TRACe<x>:CCDF:FREEze { OFF | ON | 0 | 1 }  
 TRACe<x>:CCDF:FREEze?

**Arguments** OFF or 0 updates the display of the specified trace normally.  
 ON or 1 stops updating the display of the specified trace.

**Examples** TRACE1:CCDF:FREEZE ON freezes the display for Trace 1.

## TRACe<x>:CCDF:SElect

Selects or queries the trace whose measurement results are being displayed in the readout on the top of the view. The selected trace is indicated by the measurement pointer (pink triangle) on the waveform.

The parameter <x> = 1 to 3; All traces are valid.

**Conditions** Measurement views: CCDF

<b>Group</b>	Trace commands
<b>Syntax</b>	TRACe<x>:CCDF:SElect TRACe<x>:CCDF:SElect?
<b>Arguments</b>	None
<b>Returns</b>	{ 0   1 }  0 indicates that the results are not being displayed in the readout for the trace. 1 indicates that the results are being displayed in the readout for the trace.
<b>Examples</b>	TRACE1:CCDF:SELECT selects Trace 1 to display the measurement results in the readout.  TRACE1:CCDF:SELECT? might return 1, indicating that the results are being displayed in the readout for Trace 1.

## TRACe<x>:CCDF:SHOW

Determines whether to show or hide the specified trace in the CCDF view.  
The parameter <x> = 1 to 3; All traces are valid.

<b>Conditions</b>	Measurement views: CCDF
<b>Group</b>	Trace commands
<b>Syntax</b>	TRACe<x>:CCDF:SHOW { OFF   ON   0   1 } TRACe<x>:CCDF:SHOW?
<b>Arguments</b>	OFF or 0 hides the specified trace. ON or 1 shows the specified trace.
<b>Examples</b>	TRACE1:CCDF:SHOW ON shows Trace 1 in the CCDF view.

## TRACe<x>:CCDF:X

Sets or queries the horizontal position of the measurement pointer (pink triangle) to measure the CCDF. Use the [TRACe<x>:CCDF:Y?](#) query to read the value.

The parameter <x> = 1 to 3.

---

**NOTE.** Use the [TRACe<x>:CCDF:SHOW](#) command to show the specified trace and the [TRACe<x>:CCDF:SElect](#) command to select the trace before running the [TRACe<x>:CCDF:X](#) command.

---

<b>Conditions</b>	Measurement views: CCDF
<b>Group</b>	Trace commands
<b>Syntax</b>	TRACe<x>:CCDF:X <value> TRACe<x>:CCDF:X?
<b>Arguments</b>	<value>::=<NRF> specifies the horizontal position of the measurement pointer. Range: 0 to 20 dB.
<b>Examples</b>	TRACE1:CCDF:X 5 puts the measurement pointer at 5 dB on Trace 1.

## TRACe<x>:CCDF:Y? (Query Only)

Queries the vertical position (CCDF value) of the measurement pointer (displayed as a pink triangle). Use the [TRACe<x>:CCDF:X](#) command to set the horizontal position of the pointer.

The parameter <x> = 1 to 3.

---

**NOTE.** Use the [TRACe<x>:CCDF:SHOW](#) command to show the specified trace and the [TRACe<x>:CCDF:SElect](#) command to select the trace before running the [TRACe<x>:CCDF:Y?](#) query.

---

<b>Conditions</b>	Measurement views: CCDF
<b>Group</b>	Trace commands
<b>Syntax</b>	TRACe<x>:CCDF:Y?

<b>Arguments</b>	None
<b>Returns</b>	<p>&lt;value&gt; ::= &lt;NRf&gt; is the vertical position (CCDF) of the measurement pointer. Range: 0 to 100%.</p> <p>The value of 99.0999953003E+36 is returned if the trace is not available.</p>
<b>Examples</b>	TRACE1:CCDF:Y? might return 14.72, indicating the CCDF is 14.72% at the measurement pointer on Trace 1.

## TRACe:CONStE:MODE

Selects or queries how to display the constellation trace.

<b>Conditions</b>	Measurement views: Constellation
<b>Group</b>	Trace commands
<b>Syntax</b>	<pre>TRACe:CONStE:MODE { VECTors   SYMBols } TRACe:CONStE:MODE?</pre>
<b>Arguments</b>	<p>VECTors connects adjacent symbol points with the signal locus.</p> <p>SYMBols displays individual symbol points.</p>
<b>Examples</b>	TRACe:CONStE:MODE VECTors shows the constellation connecting adjacent symbol points with the signal locus.

## TRACe:DIQVtime:ENABle:I

Determines whether to show or hide the I trace in the Demod I&Q versus Time measurement.

<b>Conditions</b>	Measurement views: Demod I&Q versus Time
<b>Group</b>	Trace commands
<b>Syntax</b>	<pre>TRACe:DIQVtime:ENABle:I { OFF   ON   0   1 } TRACe:DIQVtime:ENABle:I?</pre>

- Arguments** OFF or 0 hides the I trace.  
ON or 1 shows the I trace.
- Examples** TRACE:DIQVTIME:ENABLE:I ON shows the I trace in the Demod I&Q versus Time measurement.

## TRACe:DIQVtime:ENABLE:Q

Determines whether to show or hide the Q trace in the Demod I&Q versus Time measurement.

- Conditions** Measurement views: Demod I&Q versus Time
- Group** Trace commands
- Syntax** TRACe:DIQVtime:ENABLe:Q { OFF | ON | 0 | 1 }  
TRACe:DIQVtime:ENABLe:Q?
- Arguments** OFF or 0 hides the Q trace.  
ON or 1 shows the Q trace.
- Examples** TRACE:DIQVTIME:ENABLE:Q ON shows the Q trace in the Demod I&Q versus Time measurement.

## TRACe:DIQVtime:SElect:I

Selects the I trace in the Demod I&Q versus Time. The query version of this command returns whether the I trace is selected or not.

- Conditions** Measurement views: Demod I&Q versus Time
- Group** Trace commands
- Syntax** TRACe:DIQVtime:SElect:I  
TRACe:DIQVtime:SElect:I?
- Arguments** None



**Returns** { 0 | 1 }

0 indicates that the I trace is deselected.

1 indicates that the I trace is selected.

**Examples** TRACE:DIQVTIME:SELECT:I selects the I trace in the Demod I&Q versus Time.

## TRACe:DIQVtime:SElect:Q

Selects the Q trace in the Demod I&Q versus Time. The query version of this command returns whether the Q trace is selected or not.

**Conditions** Measurement views: Demod I&Q versus Time

**Group** Trace commands

**Syntax** TRACe:DIQVtime:SElect:Q  
TRACe:DIQVtime:SElect:Q?

**Arguments** None

**Returns** { 0 | 1 }

0 indicates that the Q trace is deselected.

1 indicates that the Q trace is selected.

**Examples** TRACE:DIQVTIME:SELECT:Q selects the Q trace in the Demod I&Q versus Time.

## TRACe<x>:DPSA

Determines whether or not to show the specified trace in the DPX spectrum view.  
The parameter <x> = 1 to 5; All traces are valid.

**Conditions** Measurement views: DPX spectrum

**Group** Trace commands

**Syntax** TRACE<x>:DPSA { OFF | ON | 0 | 1 }  
TRACE<x>:DPSA?

**Arguments** OFF or 0 hides the specified trace in the DPX spectrum view.  
ON or 1 shows the specified trace in the DPX spectrum view.

**Examples** TRACE1:DPSA ON shows Trace 1 (the maximum trace) in the DPX spectrum view.

## TRACe<x>:DPSA:AVERAge:COUNT

Sets or queries the number of traces to combine for averaging in the DPX spectrum view.

The parameter <x> = 3; Only Trace 3 (average trace) is valid.

**Conditions** Measurement views: DPX spectrum

**Group** Trace commands

**Syntax** TRACe<x>:DPSA:AVERAge:COUNT <number>  
TRACe<x>:DPSA:AVERAge:COUNT?

**Arguments** <number> ::= <NR1> specifies the number of traces to combine for averaging.  
Range: 1 to 10000.

**Examples** TRACE3:DPSA:AVERAGE:COUNT 32 sets the average count to 32.

## TRACe<x>:DPSA:COLor:CURVe

Sets or queries how colors are mapped to the signal density in the DPX spectrum bitmap display. The mapping can be linear (Curve = 1), or it can be set to concentrate the resolution on the lower level of the range (Curve > 1) or the mapping can be set to show the best resolution on the upper range of density or hit count (Curve = 0.1 – 0.99). This command is only valid for the Bitmap display.

The parameter <x> = 5; only Trace5 is valid.

**Conditions** Measurement views: DPX spectrum

<b>Group</b>	Trace commands
<b>Syntax</b>	TRACe<x>:DPSA:COLor:CURVe <value> TRACe<x>:DPSA:COLor:CURVe?
<b>Arguments</b>	<value> ::= <Nrf> specifies how colors are mapped to the signal density. Range:
<b>Examples</b>	TRACe<x>:DPSA:COLor:CURVe 1.5 concentrates the resolution on the lower level of the range on the Bitmap display.

## TRACe<x>:DPSA:COLor:INTensity

Sets or queries the color intensity in the DPX spectrum view. The value is common to all traces.

The parameter <x> = 1 to 5; All traces are valid.

<b>Conditions</b>	Measurement views: DPX spectrum
<b>Group</b>	Trace commands
<b>Syntax</b>	TRACe<x>:DPSA:COLor:INTensity <value> TRACe<x>:DPSA:COLor:INTensity?
<b>Arguments</b>	<value> ::= <Nrf> specifies color intensity. Range: 1 to 100%.
<b>Examples</b>	TRACE1:DPSA:COLOR:INTENSITY 30 sets the color intensity to 30%.

## TRACe<x>:DPSA:COLor:SCALE:AUTO (No Query Form)

Automatically adjusts the Max and Min color settings to display the broadest range of colors in the DPX spectrum bitmap display. This command is only valid for the Bitmap display.

The parameter <x> = 5; only Trace5 is valid.

<b>Conditions</b>	Measurement views: DPX spectrum
<b>Group</b>	Trace commands

**Syntax** TRACe<x>:DPSA:COLor:SCALE:AUTO

**Arguments** <x>::=5 specifies the auto-color setting for the Bitmap trace.

**Examples** TRACE5:DPSA:COLor:SCALE:AUTO autosets the Bitmap display color scheme.

## TRACe<x>:DPSA:DETEction

Selects or queries the detection type (POSitive, NEGitive, AVERAge) for traces 1, 2 and 3 in the DPX spectrum view.

Trace 4 (math trace) and Trace 5 (bitmap trace) are invalid choices.

**Conditions** Measurement views: DPX spectrum

**Group** Trace commands

**Syntax** TRACe<x>:DPSA:DETEction { AVERAge | NEGative | POSitive }  
TRACe<x>:DPSA:DETEction?

**Arguments** The following table shows the trace function and display. For the average trace, use the [TRACe<x>:DPSA:AVERAge:COUNT](#) command to set the average count.

**Examples** TRACE1:DPSA:DETEction AVERAge enables analysis to look for AVERAge on Trace 1.

## TRACe<x>:DPSA:DOT:PERSistent

Determines whether to enable or disable the dot persistence for the bitmap trace (Trace 5) in the DPX spectrum view.

The parameter <x> = 5; Only Trace 5 (bitmap trace) is valid.

**Conditions** Measurement views: DPX spectrum

**Group** Trace commands

**Syntax** TRACe<x>:DPSA:DOT:PERSistent { OFF | ON | 0 | 1 }  
TRACe<x>:DPSA:DOT:PERSistent?

<b>Arguments</b>	OFF or 0 disables the dot persistence. ON or 1 enables the dot persistence.
<b>Examples</b>	TRACE5:DPSA:DOT:PERSISTENT ON enables the dot persistence in the DPX spectrum view.

## TRACe<x>:DPSA:DOT:PERSistent:TYPE

Selects or queries the persistence type for the bitmap trace (Trace 5) in the DPX spectrum view.

The parameter <x> = 5; Only Trace 5 (bitmap trace) is valid.

<b>Conditions</b>	Measurement views: DPX spectrum
<b>Group</b>	Trace commands
<b>Syntax</b>	TRACe<x>:DPSA:DOT:PERSistent:TYPE { VARIable   INFinite } TRACe<x>:DPSA:DOT:PERSistent:TYPE?
<b>Arguments</b>	VARIable selects the variable persistence display which leaves acquired data points on the display for a period of time specified by the <a href="#">TRACe&lt;x&gt;:DPSA:DOT:PERSistent:VARIable</a> command.  INFinite selects the infinite persistence display which accumulates data points on the display indefinitely.
<b>Examples</b>	TRACE5:DPSA:DOT:PERSISTENT:TYPE VARIable selects the variable persistence display.

## TRACe<x>:DPSA:DOT:PERSistent:VARIable

Sets or queries how long data points are displayed. This command is effective when [TRACe<x>:DPSA:DOT:PERSistent:TYPE](#) is set to VARIable. This affects the display only.

The parameter <x> = 5; Only Trace 5 (bitmap trace) is valid.

<b>Conditions</b>	Measurement views: DPX spectrum
-------------------	---------------------------------

<b>Group</b>	Trace commands
<b>Syntax</b>	TRACe<x>:DPSA:DOT:PERSistent:VARiablE <number> TRACe<x>:DPSA:DOT:PERSistent:VARiablE?
<b>Arguments</b>	<number>: :=<NR1> specifies the number that the waveform points are displayed on the screen. Range: 1 to 1000 (unitless; the default value is 10).
<b>Examples</b>	TRACE5:DPSA:DOT:PERSISTENT:VARIABLE 20 specifies that the waveform points are displayed on the screen for a period of 20 before they disappear.

## TRACe<x>:DPSA:FREEze

Determines whether or not to freeze the display of the specified trace in the DPX spectrum view.

The parameter <x> = 1 to 5; All traces are valid.

<b>Conditions</b>	Measurement views: DPX spectrum
<b>Group</b>	Trace commands
<b>Syntax</b>	TRACe<x>:DPSA:FREEze { OFF   ON   0   1 } TRACe<x>:DPSA:FREEze?
<b>Arguments</b>	OFF or 0 updates the display of the specified trace normally. ON or 1 stops updating the display of the specified trace.
<b>Examples</b>	TRACE1:DPSA:FREEZE ON freezes the display for the +peak trace.

## TRACe<x>:DPSA:FUNCtion

Selects or queries the trace function for the +Peak, -Peak, or Average trace (Trace 1, 2, or 3, respectively) in the DPX spectrum view.

The parameter <x> = 1 to 3; Trace 4 (math trace) and Trace 5 (bitmap trace) are invalid.

<b>Conditions</b>	Measurement views: DPX spectrum
-------------------	---------------------------------

<b>Group</b>	Trace commands																
<b>Syntax</b>	TRACe<x>:DPSA:FUNCTION { NORMAl   HOLD   AVERAge } TRACe<x>:DPSA:FUNCTION?																
<b>Arguments</b>	The following table shows the trace function and display. For the average trace, use the <a href="#">TRACe&lt;x&gt;:DPSA:AVERAge:COUNT</a> command to set the average count.																
	<table border="1"> <thead> <tr> <th>Function</th> <th>Trace1 (+Peak trace)</th> <th>Trace2 (-Peak trace)</th> <th>Trace3 (Average trace)</th> </tr> </thead> <tbody> <tr> <td>NORMAl</td> <td>Normal spectrum (Detection: +Peak)</td> <td>Normal spectrum (Detection: -Peak)</td> <td>Normal spectrum (Detection: Average)</td> </tr> <tr> <td>HOLD</td> <td>Max-hold spectrum</td> <td>Min-hold spectrum</td> <td>NA</td> </tr> <tr> <td>AVERAge</td> <td>NA</td> <td>NA</td> <td>Average spectrum</td> </tr> </tbody> </table>	Function	Trace1 (+Peak trace)	Trace2 (-Peak trace)	Trace3 (Average trace)	NORMAl	Normal spectrum (Detection: +Peak)	Normal spectrum (Detection: -Peak)	Normal spectrum (Detection: Average)	HOLD	Max-hold spectrum	Min-hold spectrum	NA	AVERAge	NA	NA	Average spectrum
Function	Trace1 (+Peak trace)	Trace2 (-Peak trace)	Trace3 (Average trace)														
NORMAl	Normal spectrum (Detection: +Peak)	Normal spectrum (Detection: -Peak)	Normal spectrum (Detection: Average)														
HOLD	Max-hold spectrum	Min-hold spectrum	NA														
AVERAge	NA	NA	Average spectrum														
<b>Examples</b>	TRACE1:DPSA:FUNCTION HOLD selects the max hold waveform for Trace 1.																

## TRACe<x>:DPSA:LEFToperand

Selects or queries the left operand for the math trace (Trace 4) in the DPX spectrum view. With Option 200, trace detection is not configurable.

The parameter <x> = 4; Only Trace 4 (math trace) is valid.

<b>Conditions</b>	Measurement views: DPX spectrum
<b>Group</b>	Trace commands
<b>Syntax</b>	TRACe<x>:DPSA:LEFToperand { TRACE1   TRACe2   TRACe3 } TRACe<x>:DPSA:LEFToperand?
<b>Related Commands</b>	<a href="#">TRACe&lt;x&gt;:DPSA:RIGHToperand</a>
<b>Arguments</b>	TRACE1 selects Trace 1 as the left operand for the math trace. TRACE2 selects Trace 2 as the left operand for the math trace. TRACE3 selects Trace 3 as the left operand for the math trace.
<b>Examples</b>	TRACE4:DPSA:LEFTOPERAND TRACE2 selects Trace 2 as the left operand for the math trace.

## TRACe<x>:DPSA:RIGHToperand

Selects or queries the right operand for the math trace (Trace 4) in the DPX spectrum view. With Option 200, trace detection is not configurable.

The parameter <x> = 4; Only Trace 4 (math trace) is valid.

**Conditions** Measurement views: DPX spectrum

**Group** Trace commands

**Syntax** TRACe<x>:DPSA:RIGHToperand { TRACE1 | TRACE2 | TRACE3 }  
TRACe<x>:DPSA:RIGHToperand?

**Related Commands** [TRACe<x>:DPSA:LEFToperand](#)

**Arguments** TRACE1 selects Trace 1 as the right operand for the math trace.

TRACE2 selects Trace 2 as the right operand for the math trace.

TRACE3 selects Trace 3 as the right operand for the math trace.

**Examples** TRACE4:DPSA:RIGHTOPERAND TRACE1 selects Trace 1 as the right operand for the math trace.

## TRACe<x>:DPSA:SElect

Selects or queries the trace to display the readout at the upper left of the DPX spectrum view.

The parameter <x> = 1 to 5; All traces are valid.

**Conditions** Measurement views: DPX spectrum

**Group** Trace commands

**Syntax** TRACe<x>:DPSA:SElect  
TRACe<x>:DPSA:SElect?

**Arguments** None



**Returns** { 0 | 1 }

0 indicates that the readout is not being displayed for the specified trace.  
1 indicates that the readout is being displayed for the specified trace.

**Examples** TRACE1:DPSA:SELECT selects Trace 1 (+Peak trace) to display the readout.  
TRACE1:DPSA:SELECT? might return 1, indicating that the readout is being displayed for Trace 1.

## TRACe:EDIagram:ENABLE:I

Determines whether to show or hide the I trace in the eye diagram.

**Conditions** Measurement views: Eye diagram

**Group** Trace commands

**Syntax** TRACe:EDIagram:ENABle:I { OFF | ON | 0 | 1 }  
TRACe:EDIagram:ENABle:I?

**Arguments** OFF or 0 hides the I trace.  
ON or 1 shows the I trace.

**Examples** TRACe:EDIAGRAM:ENABLE:I ON shows the I trace in the eye diagram.

## TRACe:EDIagram:ENABLE:Q

Determines whether to show or hide the Q trace in the eye diagram.

**Conditions** Measurement views: Eye diagram

**Group** Trace commands

**Syntax** TRACe:EDIagram:ENABle:Q { OFF | ON | 0 | 1 }  
TRACe:EDIagram:ENABle:Q?

**Arguments** OFF or 0 hides the Q trace.  
ON or 1 shows the Q trace.

**Examples** TRACE:EDIAGRAM:ENABLE:Q ON shows the Q trace in the eye diagram.

## TRACe:EDiagram:SElect:I

Selects the I trace in the eye diagram. The query version of this command returns whether the I trace is selected or not.

**Conditions** Measurement views: Eye diagram

**Group** Trace commands

**Syntax** TRACe:EDIagram:SElect:I  
TRACe:EDIagram:SElect:I?

**Arguments** None

**Returns** { 0 | 1 }  
0 indicates that the I trace is deselected.  
1 indicates that the I trace is selected.

**Examples** TRACE:EDIAGRAM:SELECT:I selects the I trace in the eye diagram.

## TRACe:EDiagram:SElect:Q

Selects the Q trace in the eye diagram. The query version of this command returns whether the Q trace is selected or not.

**Conditions** Measurement views: Eye diagram

**Group** Trace commands

**Syntax** TRACe:EDIagram:SElect:Q  
TRACe:EDIagram:SElect:Q?

<b>Arguments</b>	None
<b>Returns</b>	{ 0   1 } 0 indicates that the Q trace is deselected. 1 indicates that the Q trace is selected.
<b>Examples</b>	TRACE:EDIAGRAM:SELECT:Q selects the Q trace in the eye diagram.

## TRACe:FVTime

Determines whether or not to show the trace in the Frequency versus Time view.

<b>Conditions</b>	Measurement views: Frequency versus Time
<b>Group</b>	Trace commands
<b>Syntax</b>	TRACe:FVTime { OFF   ON   0   1 } TRACe:FVTime?
<b>Arguments</b>	OFF or 0 hides the trace in the Frequency versus Time view. ON or 1 shows the trace in the Frequency versus Time view.
<b>Examples</b>	TRACE:FVTIME ON shows the trace in the Frequency versus Time view.

## TRACe:FVTime:AVERAge:COUNT

Sets or queries the number of traces to combine. This command is effective when you select AVERAge with the [TRACe:FVTime:FUNCTion](#) command.

<b>Conditions</b>	Measurement views: Frequency versus Time
<b>Group</b>	Trace commands
<b>Syntax</b>	TRACe:FVTime:AVERAge:COUNT <number> TRACe:FVTime:AVERAge:COUNT?

**Arguments** <number>::=<NR1> specifies the number of traces to combine for averaging. Range: 1 to 10000.

**Examples** TRACE:FVTIME:AVERAGE:COUNT 64 sets the average count to 64.

## TRACe:FVTime:COUNT

Sets or queries how many acquisitions run in the single acquisition mode for the Max or Min Hold trace in the Frequency versus Time measurement. This command is effective when [TRACe:FVTime:FUNCTION](#) is set to MAXHold or MINHold and [INITiate:CONTInuous](#) is set to OFF.

**Conditions** Measurement views: Frequency versus Time

**Group** Trace commands

**Syntax** TRACe:FVTime:COUNT <number>  
TRACe:FVTime:COUNT?

**Arguments** <number>::=<NR1> specifies the count for Max/Min Hold. Range: 1 to 10000.

**Examples** TRACe:FVTime:COUNT 32 sets the count to 32 for the Max/Min Hold trace.

## TRACe:FVTime:COUNT:ENABLE

Determines whether to enable or disable the count for the Max or Min Hold trace in the Frequency versus Time view. This command is effective when [TRACe:FVTime:FUNCTION](#) is set to MAXHold or MINHold.

**Conditions** Measurement views: Frequency versus Time

**Group** Trace commands

**Syntax** TRACe:FVTime:COUNT:ENABle { OFF | ON | 0 | 1 }  
TRACe:FVTime:COUNT:ENABle?

**Arguments** OFF or 0 disables the count for the Max/Min Hold trace.  
ON or 1 enables the count for the Max/Min Hold trace.

**Examples** TRACe:FVTime:COUNT:ENABle ON enables the Max/Min Hold count.

## TRACe:FVTime:COUNT:RESet (No Query Form)

Clears the Max or Min Hold data and counter, and restarts the process in the Frequency versus Time view. This command is effective when TRACe:FVTime:FUNCTION is set to MAXHold or MINHold.

**Conditions** Measurement views: Frequency versus Time

**Group** Trace commands

**Syntax** TRACe:FVTime:COUNT:RESet

**Arguments** None

**Examples** TRACe:FVTime:COUNT:RESet clears the Max/Min Hold data and counter, and restarts the process.

## TRACe<x>:FVTime:DETection

Enables or queries the type of detection for the specified trace. The parameter <x> represents traces 1 to 4.

**Conditions** Measurement views: Frequency versus Time

**Group** Trace commands

**Syntax** TRACe<x>:FVTime:DETection { AVERAge | POSitive | NEGative | POSnegative | SAMPlE }  
TRACe<x>:FVTime:DETection?

**Arguments** AVERAge displays the average data value for each pixel.  
POSitive displays the maximum data value for each pixel.

NEGative displays the minimum data value for each pixel.

POSNegative displays the maximum and minimum data values for each pixel.

SAMPle displays the first sample value received for each pixel.

**Examples** TRACE2:FVTime:DETEction POSitive enables positive detection on Trace2.

## TRACe:FVTime:FREeze

Determines whether or not to freeze the display of the trace in the Frequency versus Time measurement.

**Conditions** Measurement views: Frequency versus Time

**Group** Trace commands

**Syntax** TRACe:FVTime:FREeze { OFF | ON | 0 | 1 }  
TRACe:FVTime:FREeze?

**Arguments** OFF or 0 updates the display of the trace normally.  
ON or 1 stops updating the display of the trace.

**Examples** TRACE:FVTIME:FREEZE ON stops updating the display of the trace.

## TRACe:FVTime:FUNCTion

Selects or queries the trace function in the Frequency versus Time measurement.

**Conditions** Measurement views: Frequency versus Time

**Group** Trace commands

**Syntax** TRACe:FVTime:FUNCTion { NORMAl | AVERAge | MAXHOld | MINHOld }  
TRACe:FVTime:FUNCTion?

<b>Arguments</b>	<p><b>NORMal</b> selects the normal waveform display.</p> <p><b>AVERage</b> selects the Average display that indicates the average frequency drift at each time point.</p> <p><b>MAXHo1d</b> selects the Max Hold display that indicates the maximum frequency drift at each time point.</p> <p><b>MINHo1d</b> selects the Min Hold display that indicates the minimum frequency drift at each time point.</p>
<b>Examples</b>	<p><code>TRACE:FVTIME:FUNCTION MAXHo1d</code> displays the Max Hold trace in the Frequency versus Time measurement.</p>

## TRACe:IQVTime:AVERAge:COUNT

Sets or queries the number of traces to combine. This command works for both I and Q traces when you select **AVERage** in the [TRACe:IQVTime:FUNCTioN](#) command.

<b>Conditions</b>	Measurement views: RF I&Q versus Time
<b>Group</b>	Trace commands
<b>Syntax</b>	<p><code>TRACe:IQVTime:AVERAge:COUNT &lt;number&gt;</code></p> <p><code>TRACe:IQVTime:AVERAge:COUNT?</code></p>
<b>Arguments</b>	<p><code>&lt;number&gt; ::= &lt;NR1&gt;</code> specifies the number of traces to combine for averaging. Range: 1 to 10000.</p>
<b>Examples</b>	<p><code>TRACE:IQVTIME:AVERAGE:COUNT 64</code> sets the average count to 64.</p>

## TRACe:IQVTime:COUNT

Sets or queries how many acquisitions run in the single acquisition mode for the Max or Min Hold trace in the RF I&Q versus Time measurement. This command is effective when [TRACe:IQVTime:FUNCTioN](#) is set to **MAXHold** or **MINHold** and [INITiate:CONTInuous](#) is set to **OFF**.

<b>Conditions</b>	Measurement views: RF I&Q versus Time
-------------------	---------------------------------------

<b>Group</b>	Trace commands
<b>Syntax</b>	TRACe:IQVTime:COUNT <number> TRACe:IQVTime:COUNT?
<b>Arguments</b>	<number> ::= <NR1> specifies the count for Max/Min Hold. Range: 1 to 10000.
<b>Examples</b>	TRACe:IQVTime:COUNT 32 sets the count to 32 for the Max/Min Hold trace.

## TRACe:IQVTime:COUNT:ENABLE

Determines whether to enable or disable the count for the Max or Min Hold trace in the RF I&Q versus Time view. This command is effective when [TRACe:IQVTime:FUNCTION](#) is set to MAXHold or MINHold.

<b>Conditions</b>	Measurement views: RF I&Q versus Time
<b>Group</b>	Trace commands
<b>Syntax</b>	TRACe:IQVTime:COUNT:ENABLE { OFF   ON   0   1 } TRACe:IQVTime:COUNT:ENABLE?
<b>Arguments</b>	OFF or 0 disables the count for the Max/Min Hold trace. ON or 1 enables the count for the Max/Min Hold trace.
<b>Examples</b>	TRACe:IQVTime:COUNT:ENABLE ON enables the Max/Min Hold count.

## TRACe:IQVTime:COUNT:RESet (No Query Form)

Clears the Max or Min Hold data and counter, and restarts the process in the RF I&Q versus Time view. This command is effective when [TRACe:IQVTime:FUNCTION](#) is set to MAXHold or MINHold.

<b>Conditions</b>	Measurement views: RF I&Q versus Time
<b>Group</b>	Trace commands



<b>Syntax</b>	TRACe:IQVTime:COUNT:RESet
<b>Arguments</b>	None
<b>Examples</b>	TRACe:IQVTime:COUNT:RESet clears the Max/Min Hold data and counter, and restarts the process.

## TRACe:IQVTime:DETection

Sets or queries the detection method for the RF I&Q versus Time view.

<b>Conditions</b>	Measurement views: RF I&Q versus Time
<b>Group</b>	Trace commands
<b>Syntax</b>	TRACe:IQVTime:DETection { AVERAge   POSitive   NEGative   POSNegative   SAMPlE } TRACe:IQVTime:DETection?
<b>Arguments</b>	AVERAge displays the average data value for each pixel. POSitive displays the maximum data value for each pixel. NEGative displays the minimum data value for each pixel. POSNegative displays the maximum and minimum data values for each pixel. SAMPlE displays the first sample value received for each pixel.
<b>Examples</b>	TRACe:IQVTime:DETection AVERAge enables display of the average value for each pixel.

## TRACe:IQVTime:ENABle:I

Determines whether to show or hide the I trace in the RF I&Q versus Time measurement.

<b>Conditions</b>	Measurement views: RF I&Q versus Time
<b>Group</b>	Trace commands

**Syntax** TRACE:IQVTime:ENABLe:I { OFF | ON | 0 | 1 }  
TRACE:IQVTime:ENABLe:I?

**Arguments** OFF or 0 hides the I trace.  
ON or 1 shows the I trace.

**Examples** TRACE:IQVTIME:ENABLE:I ON shows the I trace in the RF I&Q versus Time measurement.

## TRACe:IQVTime:ENABLe:Q

Determines whether to show or hide the Q trace in the RF I&Q versus Time measurement.

**Conditions** Measurement views: RF I&Q versus Time

**Group** Trace commands

**Syntax** TRACE:IQVTime:ENABLe:Q { OFF | ON | 0 | 1 }  
TRACE:IQVTime:ENABLe:Q?

**Arguments** OFF or 0 hides the Q trace.  
ON or 1 shows the Q trace.

**Examples** TRACE:IQVTIME:ENABLE:Q ON shows the Q trace in the IQ level versus Time measurement.

## TRACe:IQVTime:FReeze

Determines whether to freeze the IQ traces in the RF I&Q versus Time measurement.

**Conditions** Measurement views: RF I&Q versus Time

**Group** Trace commands

<b>Syntax</b>	TRACE:IQVTime:FREEze { OFF   ON   0   1 } TRACE:IQVTime:FREEze?
<b>Arguments</b>	OFF or 0 updates IQ trace display normally. ON or 1 stops updating IQ trace display.
<b>Examples</b>	TRACE:IQVTIME:FREEZE ON freezes the IQ traces.

## TRACe:IQVTime:FUNcTION

Selects or queries the trace function in the RF I&Q versus Time measurement.

<b>Conditions</b>	Measurement views: RF I&Q versus Time
<b>Group</b>	Trace commands
<b>Syntax</b>	TRACE:IQVTime:FUNcTION { NORMAl   AVERAge   MAXHOld   MINHOld } TRACE:IQVTime:FUNcTION?
<b>Arguments</b>	NORMAl selects the normal waveform display. AVERAge selects the Average display that indicates the average signal level at each time point. MAXHOld selects the Max Hold display that indicates the maximum signal level at each time point. MINHOld selects the Min Hold display that indicates the minimum signal level at each time point.
<b>Examples</b>	TRACE:IQVTIME:FUNcTION MAXHOld displays the Max Hold trace in the IQ level versus Time measurement.

## TRACe:IQVTime:SElect:I

Determines whether or not to select the I trace to obtain the maximum and minimum measurement results.

<b>Conditions</b>	Measurement views: RF I&Q versus Time
-------------------	---------------------------------------

<b>Group</b>	Trace commands
<b>Syntax</b>	TRACe:IQVTime:SElect:I { OFF   ON   0   1 } TRACe:IQVTime:SElect:I?
<b>Related Commands</b>	<a href="#">TRACe:IQVTime:SElect:Q</a>
<b>Arguments</b>	OFF or 0 deselects the I trace. ON or 1 selects the I trace. Executing TRACe:IQVTime:SElect:I ON sets TRACe:IQVTime:SElect:Q OFF.
<b>Examples</b>	TRACE:IQVTIME:SELECT:I ON selects the I trace in the RF I&Q versus Time measurement.

## TRACe:IQVTime:SElect:Q

	Determines whether or not to select the Q trace to obtain the maximum and minimum measurement results.
<b>Conditions</b>	Measurement views: RF I&Q versus Time
<b>Group</b>	Trace commands
<b>Syntax</b>	TRACe:IQVTime:SElect:Q { OFF   ON   0   1 } TRACe:IQVTime:SElect:Q?
<b>Related Commands</b>	<a href="#">TRACe:IQVTime:SElect:I</a>
<b>Arguments</b>	OFF or 0 deselects the Q trace. ON or 1 selects the Q trace. Executing TRACe:IQVTime:SElect:Q ON sets TRACe:IQVTime:SElect:I OFF.
<b>Examples</b>	TRACE:IQVTIME:SELECT:Q ON selects the Q trace in the RF I&Q versus Time measurement.

## TRACe:OBW:MAXHold

Determines whether or not to perform a Max Hold on the spectrum data for the Occupied Bandwidth trace.

**Conditions** Measurement views: Occupied Bandwidth

**Group** Trace commands

**Syntax** TRACe:OBW:MAXHo1d { OFF | ON | 0 | 1 }  
TRACe:OBW:MAXHo1d?

**Arguments** OFF or 0 does not perform a Max Hold on the spectrum data.  
ON or 1 performs a Max Hold on the spectrum data.

**Examples** TRACe:OBW:MAXHOLD ON performs a Max Hold on the spectrum data for the Occupied Bandwidth trace.

## TRACe:PHVTime

Determines whether or not to show the trace in the Phase versus Time view.

**Conditions** Measurement views: Phase versus Time

**Group** Trace commands

**Syntax** TRACe:PHVTime { OFF | ON | 0 | 1 }  
TRACe:PHVTime?

**Arguments** OFF or 0 hides the trace in the Phase versus Time view.  
ON or 1 shows the trace in the Phase versus Time view.

**Examples** TRACe:PHVTIME ON shows the trace in the Phase versus Time view.

## TRACe:PHVTime:AVERAge:COUNT

Sets or queries the number of traces to combine. This command is effective when you select AVERAge with the [TRACe:PHVTime:FUNCTion](#) command.

<b>Conditions</b>	Measurement views: Phase versus Time
<b>Group</b>	Trace commands
<b>Syntax</b>	TRACe:PHVTime:AVERAge:COUNT <number> TRACe:PHVTime:AVERAge:COUNT?
<b>Arguments</b>	<number>::=<NR1> specifies the number of traces to combine for averaging. Range: 1 to 10000.
<b>Examples</b>	TRACE:PHVTIME:AVERAGE:COUNT 64 sets the average count to 64.

## TRACe:PHVTime:COUNT

Sets or queries how many acquisitions run in the single acquisition mode for the Max or Min Hold trace in the Phase versus Time measurement. This command is effective when [TRACe:PHVTime:FUNCTion](#) is set to MAXHold or MINHold and [INITiate:CONTinuous](#) is set to OFF.

<b>Conditions</b>	Measurement views: Phase versus Time
<b>Group</b>	Trace commands
<b>Syntax</b>	TRACe:PHVTime:COUNT <number> TRACe:PHVTime:COUNT?
<b>Arguments</b>	<number>::=<NR1> specifies the count for Max/Min Hold. Range: 1 to 10000.
<b>Examples</b>	TRACE:PHVTIME:COUNT 32 sets the count to 32 for the Max/Min Hold trace.

## TRACe:PHVTime:COUNT:ENABle

Determines whether to enable or disable the count for the Max or Min Hold trace in the Phase versus Time view. This command is effective when [TRACe:PHVTime:FUNCTion](#) is set to MAXHold or MINHold.

**Conditions** Measurement views: Phase versus Time

**Group** Trace commands

**Syntax** TRACe:PHVTime:COUNT:ENABle { OFF | ON | 0 | 1 }  
TRACe:PHVTime:COUNT:ENABle?

### Related Commands

**Arguments** OFF or 0 disables the count for the Max/Min Hold trace.  
ON or 1 enables the count for the Max/Min Hold trace.

**Examples** TRACE:PHVTIME:COUNT:ENABLE ON enables the Max/Min Hold count.

## TRACe:PHVTime:COUNT:RESEt (No Query Form)

Clears the Max or Min Hold data and counter, and restarts the process in the Phase versus Time view. This command is effective when [TRACe:PHVTime:FUNCTion](#) is set to MAXHold or MINHold.

**Conditions** Measurement views: Phase versus Time

**Group** Trace commands

**Syntax** TRACe:PHVTime:COUNT:RESEt

**Arguments** None

**Examples** TRACE:PHVTIME:COUNT:RESEt clears the Max/Min Hold data and counter, and restarts the process.

## TRACe<x>:PHVTime:DETection

Selects or queries the display detector (method to be used for decimating traces to fit the available horizontal space on screen). The number of horizontal pixels on screen is generally smaller than that of waveform data points. When actually displayed, the waveform data is therefore thinned out, according to the number of pixels, for being compressed.

<b>Conditions</b>	Measurement views: Phase versus Time
<b>Group</b>	Trace commands
<b>Syntax</b>	TRACe<x>:PHVTime:DETection { AVERAge   POSitive   NEGative   POSNegative   SAMPlE } TRACe<x>:PHVTime:DETection?
<b>Arguments</b>	AVERAge displays the average data value for each pixel. POSitive displays the maximum data value for each pixel. NEGative displays the minimum data value for each pixel. POSNegative displays the maximum and minimum data values for each pixel. SAMPlE displays the first sample value received for each pixel.
<b>Examples</b>	TRACe1:PHVTime:DETection POSitive displays the maximum data value for each pixel.

## TRACe:PHVTime:FREeze

Determines whether to freeze the trace display in the Phase versus Time measurement.

<b>Conditions</b>	Measurement views: Phase versus Time
<b>Group</b>	Trace commands
<b>Syntax</b>	TRACe:PHVTime:FREeze { OFF   ON   0   1 } TRACe:PHVTime:FREeze?



**Arguments** OFF or 0 updates the trace display normally.  
ON or 1 stops updating trace display.

**Examples** TRACE:PHVTIME:FREEZE ON stops updating trace display.

## TRACe:PHVTime:FUNCTion

Selects or queries the trace function in the Phase versus Time measurement.

**Conditions** Measurement views: Phase versus Time

**Group** Trace commands

**Syntax** TRACe:PHVTime:FUNCTion { NORMal | AVERAge | MAXHOld | MINHOld }  
TRACe:PHVTime:FUNCTion?

**Arguments** NORMal selects the normal waveform display.  
AVERAge selects the Average display that indicates the average phase drift at each time point.  
MAXHOld selects the Max Hold display that indicates the maximum phase drift at each time point.  
MINHOld selects the Min Hold display that indicates the minimum phase drift at each time point.  
POSnegative displays the maximum and minimum data values for each pixel.  
SAMPle displays the first sample value received for each pixel.

**Examples** TRACE:PHVTIME:FUNCTION MAXHOld displays the Max Hold trace in the Phase versus Time measurement.

## TRACe<x>:PNOise:SElect

Selects the trace in the phase noise measurement. The query returns the currently selected trace.

The parameter <x> = 1 and 2.

<b>Conditions</b>	Measurement views: Phase noise
<b>Group</b>	Trace commands
<b>Syntax</b>	TRACe<x>:PNOise:SElect TRACe<x>:PNOise:SElect?
<b>Arguments</b>	None
<b>Returns</b>	0 (not selected) or 1 (selected).
<b>Examples</b>	TRACE2:PNOISE:SELECT selects Trace 2.

## TRACe<x>:PNOise:SHOW

Determines whether to show or hide the specified trace in the phase noise view.  
The parameter <x> = 1 and 2.

<b>Conditions</b>	Measurement views: Phase noise
<b>Group</b>	Trace commands
<b>Syntax</b>	TRACe<x>:PNOise:SHOW { OFF   ON   0   1 } TRACe<x>:PNOise:SHOW?
<b>Arguments</b>	OFF or 0 hides the specified trace. ON or 1 shows the specified trace.
<b>Examples</b>	TRACE1:PNOISE:SHOW ON shows Trace 1 in the phase noise view.

## TRACe<x>:PNOise:SMOothing:COUNT

Sets or queries the number of data points to take the moving average for smoothing the trace. This command is effective when [TRACe<x>:PNOise:SMOothing:ENABLE](#) is set to ON.

The parameter <x> = 1 and 2.

<b>Conditions</b>	Measurement views: Phase noise
<b>Group</b>	Trace commands
<b>Syntax</b>	TRACe<x>:PNOise:SMOothing:COUNT <number> TRACe<x>:PNOise:SMOothing:COUNT?
<b>Arguments</b>	<number>::=<NR1> specifies the number of data points to take the moving average for smoothing. Range: 3 to 50.
<b>Examples</b>	TRACE1:PNOISE:SMOOTHING:COUNT 16 sets the smoothing count to 16 for Trace 1.

## TRACe<x>:PNOise:SMOothing:ENABLE

Determines whether to enable or disable smoothing the specified trace in the phase noise view.

The parameter <x> = 1 and 2.

<b>Conditions</b>	Measurement views: Phase noise
<b>Group</b>	Trace commands
<b>Syntax</b>	TRACe<x>:PNOise:SMOothing:ENABLE { OFF   ON   0   1 } TRACe<x>:PNOise:SMOothing:ENABLE?
<b>Arguments</b>	OFF or 0 disables smoothing. ON or 1 enables smoothing.
<b>Examples</b>	TRACE1:PNOISE:SMOOTHING:ENABLE ON enables smoothing Trace 1 in the phase noise view.

## TRACe<x>:PNOise:SMOothing:RESet (No Query Form)

Restarts the smoothing process, discarding accumulated data and resetting the counter. This command is effective when [TRACe<x>:PNOise:SMOothing:ENABLE](#) is set to ON.

The parameter <x> = 1 and 2.

<b>Conditions</b>	Measurement views: Phase noise
<b>Group</b>	Trace commands
<b>Syntax</b>	TRACe<x>:PNOiSe:SMOoThing:RESet
<b>Arguments</b>	None
<b>Examples</b>	TRACE1:PNOISE:SMOOTHING:RESET restarts the smoothing process for Trace 1.

## TRACe:SGRam:DETection

Selects or queries the display detector (method to be used for decimating traces to fit the available horizontal space on screen). The number of horizontal pixels on screen is generally smaller than that of waveform data points. When actually displayed, the waveform data is therefore thinned out, according to the number of pixels, for being compressed.

<b>Conditions</b>	Measurement views: Spectrogram
<b>Group</b>	Trace commands
<b>Syntax</b>	TRACe:SGRam:DETection { AVERAge   POSitive   NEGative   CAVERage   CPEak   QUASipeak } TRACe:SGRam:DETection?
<b>Arguments</b>	AVERAge displays the average data value for each pixel. POSitive displays the maximum data value for each pixel. NEGative displays the minimum data value for each pixel. CAVERage displays the CISPR average value for each pixel. CPEak displays the CISPR peak value for each pixel. QUASipeak displays the quasi-peak value for each pixel.

**Examples** TRACE:SGRAM:DETECTION POSITIVE displays the maximum data value for each pixel.

## TRACe:SGRam:FREeze

Determines whether or not to freeze the spectrogram display.

**Conditions** Measurement views: Spectrogram

**Group** Trace commands

**Syntax** TRACe:SGRam:FREeze { OFF | ON | 0 | 1 }  
TRACe:SGRam:FREeze?

**Arguments** OFF or 0 updates the display of the spectrogram normally.  
ON or 1 stops updating the display of the spectrogram.

**Examples** TRACE:SGRAM:FREEZE ON freezes the spectrogram display.

## TRACe:SGRam:FUNcTION

Selects or queries the trace function for the specified trace in the spectrogram.

**Conditions** Measurement views: Spectrogram

**Group** Trace commands

**Syntax** TRACe:SGRam:FUNcTION { NONE | AVERAge | MAXHOLD | MINHOLD }  
TRACe:SGRam:FUNcTION?

**Arguments** NONE selects the normal spectrogram display.  
AVERAge selects the Average display that indicates the average signal level at each frequency point.  
MAXHOLD selects the Max Hold display that indicates the maximum signal level at each frequency point.  
MINHOLD selects the Min Hold display that indicates the minimum signal level at each frequency point.

**Examples** TRACE:SGRAM:FUNCTION MAXHold selects the Max Hold display for the spectrogram.

## TRACe:SGRam:FUNCTioN:TIME

Sets or queries the time length to combine traces for averaging in the spectrogram. This command is effective when TRACe:SGRam:FUNCTioN is set to AVERAge, MAXHold or MINHold.

**Conditions** Measurement views: Spectrogram

**Group** Trace commands

**Syntax** TRACe:SGRam:FUNCTioN:TIME <value>  
TRACe:SGRam:FUNCTioN:TIME?

**Arguments** <value>::=<NR1> specifies the time length to combine traces for averaging. Range: 0.02 to 60 minutes.

**Examples** TRACe:SGRAM:FUNCTION:TIME 1.5 sets the time length to 1.5 minutes to combine traces for averaging.

## TRACe:SGRam:SELEct:LINE

Selects or queries the number of line to send to the spectrum display.

**Conditions** Measurement views: Spectrogram

**Group** Trace commands

**Syntax** TRACe:SGRam:SELEct:LINE <number>  
TRACe:SGRam:SELEct:LINE?

**Related Commands** TRACe<x>:SPECTrum

**Arguments** <number>::=<NR1> specifies the number of line to send to the spectrum display. Range: 0 to the maximum line number of the spectrogram displayed on screen.

**Examples** TRACE:SGRAM:SELECT:LINE 75 selects Line #75 in the spectrogram to send to the spectrum display.

## TRACe<x>:SPECTrum

Determines whether to show or hide the specified trace in the Spectrum view.

The parameter <x> = 1 to 5; All traces are valid.

**Conditions** Measurement views: Spectrum

**Group** Trace commands

**Syntax** TRACe<x>:SPECTrum { OFF | ON | 0 | 1 }  
TRACe<x>:SPECTrum?

**Arguments** OFF or 0 hides the specified trace.

ON or 1 shows the specified trace.

For Trace 5 (spectrogram), use the [TRACe:SGRam:SElect:LINE](#) command to select the number of line to send to the spectrum display.

**Examples** TRACE1:SPECTRUM ON shows Trace 1 in the Spectrum Analyzer view.

## TRACe<x>:SPECTrum:AVERAge:COUNT

Sets or queries the number of traces to combine. This command is effective when [TRACe<x>:SPECTrum:FUNCtion](#) is AVERAge, MAXHold or MINHold.

The parameter <x> = 1 to 3; Trace 4 (math trace) and Trace 5 (spectrogram) are invalid.

**Conditions** Measurement views: Spectrum

**Group** Trace commands

**Syntax** TRACe<x>:SPECTrum:AVERAge:COUNT <number>  
TRACe<x>:SPECTrum:AVERAge:COUNT?

**Arguments**     `<number>::=<NR1>` specifies the number of traces to combine for averaging. Range: 1 to 10000.

**Examples**     `TRACE1:SPECTRUM:AVERAGE:COUNT 64` sets the average count to 64 for Trace 1.

## TRACe<x>:SPECtrum:AVERage:RESet (No Query Form)

Clears average data and counter, and restarts the average process for the specified trace in the Spectrum view. This command is effective when [TRACe<x>:SPECtrum:FUNction](#) is set to AVERage, MAXHold or MINHold.

The parameter `<x>` = 1 to 3; Trace 4 (math trace) and Trace 5 (spectrogram) are invalid.

**Conditions**     Measurement views: Spectrum

**Group**           Trace commands

**Syntax**         `TRACe<x>:SPECtrum:AVERage:RESet`

**Arguments**     None

**Examples**     `TRACE1:SPECTRUM:AVERAGE:RESET` clears average data and counter, and restarts the average process for Trace 1.

## TRACe<x>:SPECtrum:COUNT

Sets or queries how many acquisitions run in the single acquisition mode for the Max or Min Hold trace in the Spectrum measurement. This command is effective when [TRACe<x>:SPECtrum:FUNction](#) is set to MAXHold or MINHold and [INITiate:CONTinuous](#) is set to OFF.

The parameter `<x>` = 1 to 3; Trace 4 (math trace) and Trace 5 (spectrogram) are invalid.

**Conditions**     Measurement views: Spectrum

**Group**           Trace commands



<b>Syntax</b>	TRACe<x>:SPECTrum:COUNT <number> TRACe<x>:SPECTrum:COUNT?
<b>Arguments</b>	<number> ::= <NR1> specifies the count for Max/Min Hold. Range: 1 to 10000.
<b>Examples</b>	TRACE1:SPECTRUM:COUNT 32 sets the count to 32 for Trace 1.

## TRACe<x>:SPECTrum:COUNT:ENABLE

Determines whether to enable or disable the count for the Max or Min Hold trace in the Spectrum view. This command is effective when [TRACe<x>:SPECTrum:FUNCTION](#) is set to MAXHold or MINHold.

The parameter <x> = 1 to 3; Trace 4 (math trace) and Trace 5 (spectrogram) are invalid.

<b>Conditions</b>	Measurement views: Spectrum
<b>Group</b>	Trace commands
<b>Syntax</b>	TRACe<x>:SPECTrum:COUNT:ENABLE { OFF   ON   0   1 } TRACe<x>:SPECTrum:COUNT:ENABLE?
<b>Arguments</b>	OFF or 0 disables the count for the Max/Min Hold trace. ON or 1 enables the count for the Max/Min Hold trace.
<b>Examples</b>	TRACE1:SPECTRUM:COUNT:ENABLE ON enables the Max/Min Hold count for Trace 1.

## TRACe<x>:SPECTrum:COUNT:RESet (No Query Form)

Clears the Max or Min Hold data and counter, and restarts the process for the specified trace in the Spectrum view. This command is effective when [TRACe<x>:SPECTrum:FUNCTION](#) is set to MAXHold or MINHold.

The parameter <x> = 1 to 3; Trace 4 (math trace) and Trace 5 (spectrogram) are invalid.

<b>Conditions</b>	Measurement views: Spectrum
-------------------	-----------------------------

<b>Group</b>	Trace commands
<b>Syntax</b>	TRACe<x>:SPECTrum:COUNT:RESet
<b>Arguments</b>	None
<b>Examples</b>	TRACE1:SPECTRUM:COUNT:RESET clears the Max/Min Hold data and counter, and restarts the process for Trace 1.

## TRACe<x>:SPECTrum:DETection

Selects or queries the display detector (method to be used for decimating traces to fit the available horizontal space on screen). The number of horizontal pixels on screen is generally smaller than that of waveform data points. When actually displayed, the waveform data is therefore thinned out, according to the number of pixels, for being compressed.

The parameter <x> = 1 to 3; Trace 4 (math trace) and Trace 5 (spectrogram) are invalid.

<b>Conditions</b>	Measurement views: Spectrum
<b>Group</b>	Trace commands
<b>Syntax</b>	TRACe<x>:SPECTrum:DETection { AVERAge   POSitive   NEGative   CAVERage   CPEak   QUASipeak   SAMPlE} TRACe<x>:SPECTrum:DETection?
<b>Arguments</b>	AVERAge displays the average data value for each pixel. POSitive displays the maximum data value for each pixel. NEGative displays the minimum data value for each pixel. CAVERage displays the CISPR average value for each pixel. CPEak displays the CISPR peak value for each pixel. QUASipeak displays the quasi-peak value for each pixel. SAMPlE displays the most recent sample value for each pixel.
<b>Examples</b>	TRACE1:SPECTRUM:DETECTION POSitive displays the maximum data value for each pixel on Trace 1.

## TRACe<x>:SPECTrum:FREEze

Determines whether or not to freeze the display of the specified trace in the Spectrum view.

The parameter <x> = 1 to 5; All traces are valid.

<b>Conditions</b>	Measurement views: Spectrum
<b>Group</b>	Trace commands
<b>Syntax</b>	TRACe<x>:SPECTrum:FREEze { OFF   ON   0   1 } TRACe<x>:SPECTrum:FREEze?
<b>Arguments</b>	OFF or 0 updates the display of the specified trace normally. ON or 1 stops updating the display of the specified trace.
<b>Examples</b>	TRACE1:SPECTRUM:FREEZE ON freezes Trace 1 in the Spectrum Analysis display.

## TRACe<x>:SPECTrum:FUNCTION

Selects or queries the function for the specified trace in the Spectrum view.

The parameter <x> = 1 to 3; Trace 4 (math trace) and Trace 5 (spectrogram) are invalid.

<b>Conditions</b>	Measurement views: Spectrum
<b>Group</b>	Trace commands
<b>Syntax</b>	TRACe<x>:SPECTrum:FUNCTION { NONE   AVERAGE   MAXHOLD   MINHOLD } TRACe<x>:SPECTrum:FUNCTION?
<b>Arguments</b>	NONE selects the normal spectrum display. AVERAGE selects the Average display that indicates the average signal level at each frequency point.

**MAXHold** selects the Max Hold display that indicates the maximum signal level at each frequency point.

**MINHold** selects the Min Hold display that indicates the minimum signal level at each frequency point.

**Examples** `TRACE1:SPECTRUM:FUNCTION MAXHold` selects Max Hold for Trace 1 in the Spectrum view.

## TRACe<x>:SPECtrum:LEFToperand

Selects or queries the left operand for the math trace (Trace 4) in the Spectrum view.

The parameter <x> = 4; Only Trace 4 (math trace) is valid.

**Conditions** Measurement views: Spectrum

**Group** Trace commands

**Syntax** `TRACe<x>:SPECtrum:LEFToperand { TRACE1 | TRACE2 | TRACE3 }`  
`TRACe<x>:SPECtrum:LEFToperand?`

**Related Commands** [TRACe<x>:SPECtrum:RIGHToperand](#)

**Arguments** `TRACE1` selects Trace 1 as the left operand for the math trace.  
`TRACE2` selects Trace 2 as the left operand for the math trace.  
`TRACE3` selects Trace 3 as the left operand for the math trace.

**Examples** `TRACE4:SPECTRUM:LEFTOPERAND TRACE1` selects Trace 1 as the left operand for the math trace.

## TRACe<x>:SPECtrum:RIGHToperand

Selects or queries the right operand for the math trace (Trace 4) in the Spectrum view.

The parameter <x> = 4; Only Trace 4 (math trace) is valid.

**Conditions** Measurement views: Spectrum

<b>Group</b>	Trace commands
<b>Syntax</b>	TRACe<x>:SPECTrum:RIGHToperand { TRACE1   TRACE2   TRACE3 } TRACe<x>:SPECTrum:RIGHToperand?
<b>Related Commands</b>	<a href="#">TRACe&lt;x&gt;:SPECTrum:LEFToperand</a>
<b>Arguments</b>	TRACE1 selects Trace 1 as the right operand for the math trace. TRACE2 selects Trace 2 as the right operand for the math trace. TRACE3 selects Trace 3 as the right operand for the math trace.
<b>Examples</b>	TRACE4:SPECTRUM:RIGHTOPERAND TRACE1 selects Trace 1 as the right operand for the math trace.

## TRACe<x>:SPECTrum:SElect

Selects or queries the trace to display the readout at the upper left of the Spectrum view.

The parameter <x> = 1 to 5; All traces are valid.

---

**NOTE.** TRACe5 (spectrogram) is valid when the spectrum and spectrogram measurements are running.

---

<b>Conditions</b>	Measurement views: Spectrum
<b>Group</b>	Trace commands
<b>Syntax</b>	TRACe<x>:SPECTrum:SElect TRACe<x>:SPECTrum:SElect?
<b>Arguments</b>	None
<b>Returns</b>	{ 0   1 } 0 indicates that the readout is not being displayed for the specified trace. 1 indicates that the readout is being displayed for the specified trace.

- Examples** TRACE1:SPECTRUM:SELECT selects Trace 1 to display the readout.  
 TRACE1:SPECTRUM:SELECT? might return 1, indicating that the readout is being displayed for Trace 1.

## TRACe:SPURious:COUNT

Sets or queries how many acquisitions run in the single acquisition mode for multi-trace functions (Max Hold and Average) in the Spurious measurement. This command is effective when [TRACe:SPURious:FUNCTION](#) is set to MAXHold or AVERAge and [INITiate:CONTinuous](#) is set to OFF.

- Conditions** Measurement views: Spurious
- Group** Trace commands
- Syntax** TRACe:SPURious:COUNT <number>  
 TRACe:SPURious:COUNT?
- Arguments** <number> ::= <NR1> specifies the count for multi-trace functions.  
 Range: 1 to 10000.
- Examples** TRACE:SPURIOUS:COUNT 32 sets the count to 32 for multi-trace functions.

## TRACe:SPURious:COUNT:ENABLE

Determines whether to enable or disable the count for multi-trace functions (Max Hold and Average) in the Spurious view. This command is effective when [TRACe:SPURious:FUNCTION](#) is set to MAXHold or AVERAge.

- Conditions** Measurement views: Spurious
- Group** Trace commands
- Syntax** TRACe:SPURious:COUNT:ENABle { OFF | ON | 0 | 1 }  
 TRACe:SPURious:COUNT:ENABle?
- Arguments** OFF or 0 disables the count for multi-trace functions.  
 ON or 1 enables the count for multi-trace functions.

**Examples** TRACE:SPURIOUS:COUNT:ENABLE ON enables the count for multi-trace functions.

## TRACe:SPURious:COUnT:RESet (No Query Form)

Clears the multi-function (Max Hold or Average) data and counter, and restarts the process in the Spurious view. This command is effective when TRACe:SPURious:FUnCtion is set to MAXHold or AVERAge.

**Conditions** Measurement views: Spurious

**Group** Trace commands

**Syntax** TRACe:SPURious:COUnT:RESet

**Arguments** None

**Examples** TRACE:SPURIOUS:COUNT:RESET clears the multi-function data and counter, and restarts the process.

## TRACe:SPURious:FReeze

Determines whether or not to freeze the display of the trace in the Spurious view.

**Conditions** Measurement views: Spurious

**Group** Trace commands

**Syntax** TRACe:SPURious:FReeze { OFF | ON | 0 | 1 }  
TRACe:SPURious:FReeze?

**Arguments** OFF or 0 updates the display of the trace normally.  
ON or 1 stops updating the display of the trace.

**Examples** TRACE:SPURIOUS:FREEZE ON stops updating the display of the trace.

## TRACe:SPURious:FUNcTion

Selects or queries the trace function in the Spurious view.

**Conditions** Measurement views: Spurious

**Group** Trace commands

**Syntax** TRACe:SPURious:FUNcTion { NONE | MAXHOLD | AVERAge }  
TRACe:SPURious:FUNcTion?

**Arguments** NONE selects normal display.

MAXHOLD selects the Max Hold display that indicates the maximum amplitude drift at each frequency point.

AVERAge selects the Average display that indicates the average amplitude drift at each frequency point.

**Examples** TRACe:SPURIOUS:FUNcTION MAXHOLD displays the Max Hold trace in the Spurious measurement.

## TRACe1:TOVerview

Enables display of or queries the display status of the specified trace. Only Trace1 is valid.

**Conditions** Measurement views: General Waveform display

**Group** Trace commands

**Syntax** TRACe1:TOVerview { OFF | ON | 0 | 1 }  
TRACe1:TOVerview?

**Arguments** OFF or 0 disables the trace overview.

ON or 1 enables the trace overview.

**Examples** TRACe1:TOVerview ON enables display of Trace1.



## TRACe1:TOVerview:AVERAge:COUNT

Sets or queries the number of traces averaged to generate the specified trace. Only Trace1 is valid.

<b>Conditions</b>	Measurement views: Trace Function set to Average
<b>Group</b>	Trace commands
<b>Syntax</b>	TRACe1:TOVerview:AVERAge:COUNT <value> TRACe1:TOVerview:AVERAge:COUNT?
<b>Arguments</b>	<value> ::= <NR1> an integer number of traces to average to create the waveform display.
<b>Examples</b>	TRACe1:TOVerview:AVERAge:COUNT 200 sets the Average count for Trace 1 to 200.

## TRACe1:TOVerview:COUNT

Enables or queries the count set for the specified trace. Only Trace1 is valid.

<b>Conditions</b>	Measurement views: Trace Function set to Average
<b>Group</b>	Trace commands
<b>Syntax</b>	TRACe1:TOVerview:COUNT <value> TRACe1:TOVerview:COUNT?
<b>Arguments</b>	<value> ::= <NRf>
<b>Examples</b>	TRACe1:TOVerview:COUNT 200 sets the Trace1 Average count to 200.

## TRACe1:TOVerview:COUNT:ENABLE

Enables or queries the Average count for the specified trace. Only Trace1 is valid.

<b>Conditions</b>	Measurement views: Trace Function set to Average
<b>Group</b>	Trace commands
<b>Syntax</b>	TRACe1:TOVerview:COUNT:ENABle { OFF   ON   0   1 } TRACe1:TOVerview:COUNT:ENABle?
<b>Arguments</b>	OFF or 0 disables the trace count. ON or 1 enables the trace count.
<b>Examples</b>	TRACe1:TOVerview:COUNT:ENABle ON enables the Trace1 Average count.

## TRACe1:TOVerview:COUNT:RESet (No Query Form)

Resets the waveform count for the specified trace. Only Trace1 is valid..

<b>Conditions</b>	Measurement views: Trace Function set to Average
<b>Group</b>	Trace commands
<b>Syntax</b>	TRACe1:TOVerview:COUNT:RESet
<b>Arguments</b>	None
<b>Examples</b>	TRACe1:TOVerview:COUNT:RESet sets the trace count to 1.

## TRACe1:TOVerview:DETection

Enables or queries the type of detection for the specified trace. Only Trace1 is valid.

<b>Conditions</b>	Measurement views: all
<b>Group</b>	Trace commands

**Syntax** TRACe1:TOVerview:DETection { AVERAge | POSitive | NEGative | POSNegative | SAMPlE }  
TRACe1:TOVerview:DETection?

**Arguments** AVERAge displays the average data value for each pixel.  
POSitive displays the maximum data value for each pixel.  
NEGative displays the minimum data value for each pixel.  
POSNegative displays the maximum and minimum data values for each pixel.  
SAMPlE displays the first sample value received for each pixel.

**Examples** TRACe1:TOVerview:DETection POSitive enables positive detection on Trace1.

## TRACe1:TOVerview:FREeze

Enables or queries a halt to acquisition updates for the specified trace. Only Trace1 is valid.

**Conditions** Measurement views: all

**Group** Trace commands

**Syntax** TRACe1:TOVerview:FREeze { OFF | ON | 0 | 1 }  
TRACe1:TOVerview:FREeze?

**Arguments** OFF or 0 disables the trace freeze function.  
ON or 1 enables the trace freeze function.

**Examples** TRACe1:TOVerview:FREeze ON Halts acquisition updates to Trace1.

## TRACe1:TOVerview:FUNCTION

Enables or queries the selected Function for the specified trace. Only Trace1 is valid.

**Conditions** Measurement views: all

<b>Group</b>	Trace commands
<b>Syntax</b>	TRACE1:TOVerview:FUNCTION { NORMAl   AVERAge   MAXHOld   MINHOld } TRACe1:TOVerview:FUNCTION?
<b>Arguments</b>	NORMAl Each new trace is displayed and then replaced by the next trace.. AVERAge Multiple traces are averaged together to generate the displayed trace.. MAXHOld Displays the maximum value in the trace record for each display point. MINHOld Displays the minimum value in the trace record for each display point.
<b>Examples</b>	TRACe1:TOVerview:FUNCTION AVERAge enables the averaging of multiple traces on Trace1.

## \*TRG (No Query Form)

Generates a trigger. It produces the same effect as the Force Trigger button on the Trigger control panel. This command is valid when the trigger mode is Triggered.

<b>Conditions</b>	Measurement views: All
<b>Group</b>	IEEE common commands
<b>Syntax</b>	*TRG
<b>Related Commands</b>	<a href="#">TRIGger[:SEQuence]:TIME:QUALified:TIME&lt;x&gt;</a>
<b>Arguments</b>	None
<b>Examples</b>	*TRG generates a trigger.

## TRIGger:DPSA:SHOW:FRAMES

Determines when to show frames in the swept acquisition mode. Show frames continuously when ON or show only triggered frames when OFF.

<b>Conditions</b>	Measurement views: All
<b>Group</b>	Trigger commands
<b>Syntax</b>	TRIGger:DPSA:SHOW:FRAMES { OFF   ON   0   1 } TRIGger:DPSA:SHOW:FRAMES?
<b>Arguments</b>	OFF or 0 shows only triggered frames. ON or 1 shows frames continuously.
<b>Examples</b>	TRIGger:DPSA:SHOW:FRAMES ON shows frames continuously.

## TRIGger:MASK:NEW (No Query Form)

Loads a new frequency mask.

<b>Conditions</b>	Measurement views: All
<b>Group</b>	Trigger commands
<b>Syntax</b>	TRIGger:MASK:NEW <freq(1)>,<amp1(1)>,<freq(2)>,<amp1(2)>, ...,<freq(n)>,<amp1(n)> (n = 500 maximum)
<b>Arguments</b>	<p>&lt;freq(n)&gt;,&lt;amp1(n)&gt; is a frequency (Hz) and amplitude (dBm) pair to specify a point of the mask. Up to 500 pairs can be specified with zero frequency being the center screen. The mask is visible in the spectrum view with the following trigger conditions</p> <ul style="list-style-type: none"> <li>■ Trigger mode: Triggered (TRIGger[:SEQUence]:TIME:QUALified:TIME&lt;x&gt; is set to ON or 1.)</li> <li>■ Trigger type: Frequency Mask (TRIGger[:SEQUence]:EVENT:INPut:TYPE is set to FMASK.)</li> </ul>
<b>Examples</b>	TRIGGER:MASK:NEW -8E6,-80,0,-10,8E6,-80 loads the mask with the points A (-8 MHz, -80 dBm), B (0 Hz, -10 dBm), and C (8 MHz, -80 dBm), as shown in the following figure.




Figure 2-6: Trigger mask setting example

## TRIGger:MASK:NEW:AUTO (No Query Form)

Draws a new frequency mask automatically based on a reference trace.

**Conditions** Measurement views: All

**Group** Trigger commands

**Syntax** TRIGger:MASK:NEW:AUTO  
<meas\_ID>, <trace\_ID>, <x\_margin>, <y\_margin>

**Arguments** <meas\_ID>::=<string> specifies the measurement view.

<trace\_ID> specifies the reference trace.

The values of <meas\_ID> and <trace\_ID> are listed in the following table for each possible measurement view.

<x\_margin>::=<NRf> specifies the X margin (horizontal offset from the reference trace) in Hz.

<y\_margin>::=<NRf> specifies the Y margin (vertical offset from the reference trace) in dB.

Measurement view	<meas_ID>	<trace_ID>
Spectrum	"specan"	TRACE1 (Trace 1), TRACE2 (Trace 2), TRACE3 (Trace 3), TRACE4 (Math trace), TRACE5 (Spectrogram trace)
DPX spectrum	"dpsa"	TRACE1 (+Peak trace), TRACE2 (-Peak trace), TRACE3 (Avg trace), TRACE4 (Math trace)
Channel power and ACPR	"acpr"	TRACE1 (Trace 1)
MCPR	"mcpr"	TRACE1 (Trace 1)
OBW	"obw"	TRACE1 (Trace 1)

**Examples** TRIGGER:MASK:NEW:AUTO "specan", TRACE1, 2E+6, 15 draws a new frequency mask automatically in the Spectrum view based on Trace 1 with the horizontal margin of 2 MHz and the vertical margin of 15 dB.

## TRIGger:MASK:OPEN (No Query Form)

Opens a trigger mask with a specified file. To save a trigger mask, use the [TRIGger:MASK:SAVE](#) command.

**Conditions** Measurement views: All

**Group** Trigger commands

**Syntax** TRIGger:MASK:OPEN <file\_name>

**Arguments** <file\_name>::=<string> specifies the trigger mask file to open. The file extension is .msk. You can omit the extension.

For the directory of file, refer to *Specifying the File* (See page 2-44.)

**Examples** TRIGGER:MASK:OPEN "C:\My Documents\Mask1" opens the trigger mask with the *Mask1* file in the *My Documents* directory.

## TRIGger:MASK:SAVE (No Query Form)

Saves the current trigger mask to a specified file. To open the trigger mask, use the [TRIGger:MASK:OPEN](#) command.

<b>Conditions</b>	Measurement views: All
<b>Group</b>	Trigger commands
<b>Syntax</b>	TRIGger:MASK:SAVE <file_name>
<b>Arguments</b>	<file_name>::=<string> specifies the file to save the trigger mask. The file extension is .msk. You can omit the extension.  For the directory of file, refer to <i>Specifying the File</i> (See page 2-44.)
<b>Examples</b>	TRIGGER:MASK:SAVE "C:\My Documents\Mask1" saves the trigger mask to the <i>Mask1</i> file in the <i>My Documents</i> directory.

## TRIGger[:SEQuence]:ADVanced:HOLDoff

Sets or queries the trigger holdoff time which prevents triggers until there have been no trigger events for at least the specified holdoff period.

<b>Conditions</b>	Measurement views: All
<b>Group</b>	Trigger commands
<b>Syntax</b>	TRIGger[:SEQuence]:ADVanced:HOLDoff <value> TRIGger[:SEQuence]:ADVanced:HOLDoff?
<b>Arguments</b>	<value>::=<NRF> specifies the trigger holdoff time. Range: 20 ns to 10 s.
<b>Examples</b>	TRIGger[:SEQuence]:ADVanced:HOLDoff 1.5us sets the trigger holdoff time to 1.5 $\mu$ s.



## TRIGger[:SEQuence]:ADVanced:HOLDoff:ENABLE

Enables or queries the status of the Advanced Trigger Holdoff function.

<b>Conditions</b>	Measurement views: All
<b>Group</b>	Trigger commands
<b>Syntax</b>	TRIGger[:SEQuence]:ADVanced:HOLDoff:ENABle { OFF   ON   0   1 } TRIGger[:SEQuence]:ADVanced:HOLDoff:ENABle?
<b>Arguments</b>	OFF or 0 does not trigger based on the advanced trigger holdoff settings. ON or 1 enables triggering based on the advanced trigger holdoff settings.
<b>Examples</b>	TRIGger:ADVanced:HOLDoff:ENABle ON enables triggering based on the advanced trigger holdoff settings.

## TRIGger[:SEQuence]:ADVanced:SWEEp:MODE

Determines whether or not to trigger each segment in the swept acquisition mode.

<b>Conditions</b>	Measurement views: All
<b>Group</b>	Trigger commands
<b>Syntax</b>	TRIGger[:SEQuence]:ADVanced:SWEEp:MODE { OFF   ON   0   1 } TRIGger[:SEQuence]:ADVanced:SWEEp:MODE?
<b>Arguments</b>	OFF or 0 does not trigger each segment in the swept acquisition mode. ON or 1 triggers each segment in the swept acquisition mode.
<b>Examples</b>	TRIGGER:SEQUENCE:ADVANCED:SWEEP:MODE ON triggers each segment in the swept acquisition mode.

## TRIGger[:SEQuence]:ADVanced:SWEPT:SEGMENT:ENABLE

Determines whether or not to set the spectrum analyzer to wait for a trigger for each acquisition in a swept spectrum or other measurement requiring multiple acquisitions worth of span.

<b>Conditions</b>	Measurement views: All
<b>Group</b>	Trigger commands
<b>Syntax</b>	TRIGger[:SEQuence]:ADVanced:SWEPT:SEGMENT:ENABle { OFF   ON   0   1 } TRIGger[:SEQuence]:ADVanced:SWEPT:SEGMENT:ENABle?
<b>Arguments</b>	OFF or 0 does not trigger each segment in the swept acquisition mode. ON or 1 triggers each segment in the swept acquisition mode.
<b>Examples</b>	TRIGger[:SEQuence]:ADVanced:SWEPT:SEGMENT:ENABle ON waits for a trigger for each acquisition in a swept spectrum or other measurement requiring multiple acquisitions worth of span.

## TRIGger[:SEQuence]:EVENT:EXTFront:IMPedance

Selects or queries the impedance of the external trigger input on the front panel.

<b>Conditions</b>	Measurement views: All
<b>Group</b>	Trigger commands
<b>Syntax</b>	TRIGger[:SEQuence]:EVENT:EXTFront:IMPedance { OHM50   OHM5K } TRIGger[:SEQuence]:EVENT:EXTFront:IMPedance?
<b>Arguments</b>	OHM50 selects 50 $\Omega$ impedance. OHM5K selects 5 k $\Omega$ impedance.
<b>Examples</b>	TRIGGER:SEQUENCE:EVENT:EXTFRONT:IMPEDANCE OHM50 selects 50 $\Omega$ impedance for the external trigger input on the front panel.

## TRIGger[:SEQuence]:EVENT:EXTFront:LEVel

Sets or queries the trigger level at the external trigger input on the front panel.

<b>Conditions</b>	Measurement views: All
<b>Group</b>	Trigger commands
<b>Syntax</b>	TRIGger[:SEQuence]:EVENT:EXTFront:LEVel <value> TRIGger[:SEQuence]:EVENT:EXTFront:LEVel?
<b>Arguments</b>	<value> ::= <Nrf> specifies the trigger level. Range: -2.5 to +2.5 V.
<b>Examples</b>	TRIGGER:SEQUENCE:EVENT:EXTFRONT:LEVEL 1.5 sets the trigger level to 1.5 V at the external trigger input on the front panel.

## TRIGger[:SEQuence]:EVENT:EXTFront:SLOPe

Selects or queries the trigger slope of the external trigger input on the front panel.

<b>Conditions</b>	Measurement views: All
<b>Group</b>	Trigger commands
<b>Syntax</b>	TRIGger[:SEQuence]:EVENT:EXTFront:SLOPe { RISE   FALL } TRIGger[:SEQuence]:EVENT:EXTFront:SLOPe?
<b>Arguments</b>	RISE causes the trigger event on the rising edge. FALL causes the trigger event on the falling edge.
<b>Examples</b>	TRIGGER:SEQUENCE:EVENT:EXTFRONT:SLOPE RISE causes the trigger event on the rising edge of the external input signal.

## TRIGger[:SEQuence]:EVENT:EXTRear:SLOPe

Selects or queries the trigger slope of the external trigger input on the rear panel. The trigger level is fixed to the TTL threshold.

<b>Conditions</b>	Measurement views: All
<b>Group</b>	Trigger commands
<b>Syntax</b>	TRIGger[:SEQuence]:EVENT:EXTREar:SLOPe { RISE   FALL } TRIGger[:SEQuence]:EVENT:EXTREar:SLOPe?
<b>Arguments</b>	RISe causes the trigger event on the rising edge. FALL causes the trigger event on the falling edge.
<b>Examples</b>	TRIGGER:SEQUENCE:EVENT:EXTREAR:SLOPE RISE causes the trigger event on the rising edge of the external input signal.

## TRIGger[:SEQuence]:EVENT:GATed

Selects or queries the positive or negative logic for the gated trigger input on the rear panel.

<b>Conditions</b>	Measurement views: All
<b>Group</b>	Trigger commands
<b>Syntax</b>	TRIGger[:SEQuence]:EVENT:GATed { HIGH   LOW } TRIGger[:SEQuence]:EVENT:GATed?
<b>Arguments</b>	HIGH specifies that the gated trigger input is high active. LOW specifies that the gated trigger input is low active.
<b>Examples</b>	TRIGGER:SEQUENCE:EVENT:GATED HIGH specifies that the gated trigger input is high active.

## TRIGger[:SEQuence]:EVENT:INPut:DDENsity:AMPLitude

Sets or queries the center vertical level for the density trigger region of the RF input DPX bitmap display.

<b>Conditions</b>	Measurement views: DPX bitmap
-------------------	-------------------------------

<b>Group</b>	Trigger commands
<b>Syntax</b>	TRIGger[:SEQuence]:EVENT:INPut:DDENsity:AMPLitude <value> TRIGger[:SEQuence]:EVENT:INPut:DDENsity:AMPLitude?
<b>Related Commands</b>	<a href="#">TRIGger[:SEQuence]:EVENT:INPut:DDENsity:AMPLitude:TOLerance</a>
<b>Arguments</b>	<value>::=<NRF> specifies the vertical center of the trigger region in dBm. Range: 0 to 200 dBm.
<b>Examples</b>	TRIGger[:SEQuence]:EVENT:INPut:DDENsity:AMPLitude 100dBm sets the center level to 100 dBm for the density trigger region.

## TRIGger[:SEQuence]:EVENT:INPut:DDENsity:AMPLitude:TOLerance

Sets or queries the positive and negative extensions of the density trigger region from the center vertical level. The density trigger region is defined for the DPX bitmap display.

<b>Conditions</b>	Measurement views: DPX bitmap
<b>Group</b>	Trigger commands
<b>Syntax</b>	TRIGger[:SEQuence]:EVENT:INPut:DDENsity:AMPLitude:TOLerance <value> TRIGger[:SEQuence]:EVENT:INPut:DDENsity:AMPLitude:TOLerance?
<b>Related Commands</b>	<a href="#">TRIGger[:SEQuence]:EVENT:INPut:DDENsity:FREQuency:TOLerance</a>
<b>Arguments</b>	<value>::=<NRF> specifies an absolute amplitude value for the positive and negative limits of the density trigger region in dBm. Range: within the defined measurement box.
<b>Examples</b>	TRIGger[:SEQuence]:EVENT:INPut:DDENsity:AMPLitude:TOLerance 50dBm sets the positive limit 50 dBm above the AMPLitude level and the negative limit 50 dBm below the AMPLitude level.

## TRIGger[:SEquence]:EVENT:INPut:DDENsity:FREQuency

Sets or queries the center horizontal level for the density trigger region of the RF input DPX bitmap display.

**Conditions** Measurement views: DPX bitmap

**Group** Trigger commands

**Syntax** TRIGger[:SEquence]:EVENT:INPut:DDENsity:FREQuency <value>  
TRIGger[:SEquence]:EVENT:INPut:DDENsity:FREQuency?

### Related Commands

**Arguments** <value>::=<NRF> specifies the horizontal center of the trigger region. Range: within the defined measurement box.

**Examples** TRIGger[:SEquence]:EVENT:INPut:DDENsity:FREQuency 1.82GHz sets the center horizontal level to 1.82 GHz for the density trigger region.

## TRIGger[:SEquence]:EVENT:INPut:DDENsity:FREQuency:TOLerance

Sets or queries the left and right extensions of the density trigger region from the center horizontal level. The density trigger region is defined for the DPX bitmap display.

**Conditions** Measurement views: DPX bitmap

**Group** Trigger commands

**Syntax** TRIGger[:SEquence]:EVENT:INPut:DDENsity:FREQuency:TOLerance <value>  
TRIGger[:SEquence]:EVENT:INPut:DDENsity:FREQuency:TOLerance?

### Related Commands

**Arguments** <value>::=<NRF> specifies an absolute frequency value for the left and right limits from the center frequency of the density trigger region. Range: within the defined measurement box.

**Examples** `TRIGger[:SEquence]:EVENT:INPut:DDENsity:FREQuency:TOLerance 0.2GHZ`, for a center frequency of 1.82 GHz, sets the left horizontal limit to 1.62 GHz and the right horizontal limit to 2.02 GHz for the density trigger region.

## TRIGger[:SEquence]:EVENT:INPut:DDENsity:THReshold

Sets or queries the DPX Density threshold that defines a trigger event for the density trigger region of the DPX bitmap display. The DPX Density must be higher or lower (specified by the Density selection) than this value to define a trigger event.

**Conditions** Measurement views: DPX bitmap

**Group** Trigger commands

**Syntax** `TRIGger[:SEquence]:EVENT:INPut:DDENsity:THReshold <value>`  
`TRIGger[:SEquence]:EVENT:INPut:DDENsity:THReshold?`

### Related Commands

**Arguments** `<value>::=<Nrf>` specifies the DPX Density threshold as a percentage (%). Range: within the defined measurement box.

**Examples** `TRIGger[:SEquence]:EVENT:INPut:DDENsity:THReshold 2` sets the DPX Density threshold to 2 % for the density trigger.

## TRIGger[:SEquence]:EVENT:INPut:DDENsity:VIOLation

Sets or queries whether a density value higher or lower than the THReshold value defines a trigger event for the density trigger region of the DPX bitmap display.

**Conditions** Measurement views: DPX bitmap

**Group** Trigger commands

**Syntax** `TRIGger[:SEquence]:EVENT:INPut:DDENsity:VIOLation { HIGHer | LOWer }`  
`TRIGger[:SEquence]:EVENT:INPut:DDENsity:VIOLation?`

**Related Commands**    [TRIGger\[:SEQuence\]:EVENT:INPut:DDENsity:THReshold](#)

**Arguments**    HIGHER a DPX density value above the THReshold value defines the trigger event.  
 LOWER a DPX Density value below the THReshold value defines the trigger event.

**Examples**    TRIGger:EVENT:INPut:DDENsity:VIOLation LOWER sets the DPX Density VIOLATION to trigger when the probability of occurrence is lower than the THRESHOLD percentage.

## TRIGger[:SEQuence]:EVENT:INPut:FMASK:{BANDwidth|BWIDth[:RESolution]}

Sets or queries the Resolution Bandwidth value to be used in the spectrum view for the frequency mask trigger.

**Conditions**    Measurement views: All

**Group**    Trigger commands

**Syntax**    TRIGger[:SEQuence]:EVENT:INPut:FMASK:{BANDwidth|BWIDth[:RESolution]} <value>  
 TRIGger[:SEQuence]:EVENT:INPut:FMASK:{BANDwidth|BWIDth[:RESolution]}?

**Arguments**    <value>::=<NRF> specifies the resolution bandwidth for Frequency Mask triggering. Range: .

**Examples**    TRIGger[:SEQuence]:EVENT:INPut:FMASK:BANDwidth 300kHz sets the resolution bandwidth to 300 kHz.

## TRIGger[:SEQuence]:EVENT:INPut:FMASK:BANDwidth|BWIDth[:RESolution]:ACTual? (Query Only)

Queries current setting for the Resolution Bandwidth value used in the spectrum view for the frequency mask trigger.

**Conditions**    Measurement views: All

**Group**    Trigger commands



<b>Syntax</b>	<code>TRIGger[:SEquence]:EVENT:INPut:FMASK:BANDwidth BWIDth[:RESolution]:ACTual?</code>
<b>Arguments</b>	None.
<b>Examples</b>	<code>TRIGger:EVENT:INPut:FMASK:BWIDth:ACTUAL?</code> returns the resolution bandwidth value.

## **TRIGger[:SEquence]:EVENT:INPut:FMASK:BANDwidth|BWIDth[:RESolution]:AUTO**

Sets or queries whether to automatically set the Resolution Bandwidth value used in the spectrum view for the frequency mask trigger.

<b>Conditions</b>	Measurement views: All
<b>Group</b>	Trigger commands
<b>Syntax</b>	<code>TRIGger[:SEquence]:EVENT:INPut:FMASK:BANDwidth BWIDth[:RESolution]:AUTO { OFF   ON   0   1 }</code> <code>TRIGger[:SEquence]:EVENT:INPut:FMASK:BANDwidth BWIDth[:RESolution]:AUTO?</code>
<b>Arguments</b>	OFF or 0 sets the resolution bandwidth manually with the command <code>TRIGger[:SEquence]:EVENT:INPut:FMASK:{BANDwidth BWIDth}[:RESolution]</code> . ON or 1 sets the resolution bandwidth automatically.
<b>Examples</b>	<code>TRIGger:EVENT:INPut:FMASK:BWIDth:AUTO ON</code> sets the resolution bandwidth automatically.

## **TRIGger[:SEquence]:EVENT:INPut:FMASK:VIOLation**

Selects or queries when the analyzer triggers in the frequency mask trigger.

<b>Conditions</b>	Measurement views: All
<b>Group</b>	Trigger commands

**Syntax** TRIGger[:SEQuence]:EVENT:INPut:FMASK:VIOLation { T | F | TF | FT | TFT | FTF }  
 TRIGger[:SEQuence]:EVENT:INPut:FMASK:VIOLation?

**Arguments** The following table lists the arguments which represent the trigger violations.

**Table 2-45: Trigger violations**

Violation	Description
T	Only one state is required to initiate a trigger event. The signal has at least one data point inside the mask. The trigger event occurs at the first point that appears inside the mask. A trigger event could occur on the first acquisition.
F	Only one state change is required to initiate a trigger event. The signal has at least one data point outside the mask. The trigger event occurs at the first point that appears outside the mask. A trigger event could occur on the first acquisition.
TF	Two states are required to initiate a trigger event. The signal must be inside the mask and then passes out of the mask. The trigger event occurs at the first transition where the signal passes out of the mask.
FT	Two states are required to initiate a trigger event. The signal must be outside the mask and then passes into the mask. The trigger event occurs at the first transition where the signal passes into the mask.
TFT	Three states are required to initiate a trigger event. The signal starts inside the mask and then passes out of the mask. Next, the signal must pass into the mask. The trigger event occurs at the second transition where the signal passes back into the mask.
FTF	Three states are required to initiate a trigger event. The signal starts outside the mask and then passes into the mask. Next, the signal must pass back outside the mask. The trigger event occurs at the second transition where the signal passes back out of the mask.

**Examples** TRIGGER:SEQUENCE:EVENT:INPUT:FMASK:VIOLATION TF specifies that the analyzer will trigger when the signal has crossed into the mask and then outside of the mask.

## TRIGger[:SEQuence]:EVENT:INPut:LEVel

Sets or queries the trigger level for the RF input level trigger.

**Conditions** Measurement views: All

**Group** Trigger commands

<b>Syntax</b>	TRIGger[:SEquence]:EVENT:INPut:LEVel <value> TRIGger[:SEquence]:EVENT:INPut:LEVel?
<b>Arguments</b>	<value> ::= <NRf> specifies the trigger level. Range: -170 to +50 dBm.
<b>Examples</b>	TRIGGER:SEQUENCE:EVENT:INPUT:LEVEL -10 sets the trigger level to -10 dBm for the RF input level trigger.

## TRIGger[:SEquence]:EVENT:INPut:RUNT:PULSe

Selects or queries the Runt trigger for a positive or negative going pulse.

<b>Conditions</b>	Measurement views: All
<b>Group</b>	Trigger commands
<b>Syntax</b>	TRIGger[:SEquence]:EVENT:INPut:RUNT:PULSe { POSitive   NEGative } TRIGger[:SEquence]:EVENT:INPut:RUNT:PULSe?
<b>Arguments</b>	POSitive causes the trigger event on a positive runt pulse. NEGative causes the trigger event on a negative runt pulse.
<b>Examples</b>	TRIGger:EVENT:INPut:RUNT:PULSE POSitive causes the trigger event on a positive pulse.

## TRIGger[:SEquence]:EVENT:INPut:RUNT:PULSe:LOW:LEVel

Sets or queries the lower level (second threshold) to qualify a Runt trigger.

<b>Conditions</b>	Measurement views: All
<b>Group</b>	Trigger commands
<b>Syntax</b>	TRIGger[:SEquence]:EVENT:INPut:RUNT:PULSe:LOW:LEVel <value> TRIGger[:SEquence]:EVENT:INPut:RUNT:PULSe:LOW:LEVel?

**Arguments** <value>::=<NRF> sets the lower vertical level for a runt pulse in dBm.

**Examples** TRIGGER:EVENT:INPUT:RUNT:PULSE 3 causes the trigger event when the following edge of a pulse crosses the 3 dBm level.

## TRIGGER[:SEQUENCE]:EVENT:INPUT:RUNT:PULSE:HIGH:LEVEL

Sets or queries the upper level (first threshold) to qualify a Runt trigger.

**Conditions** Measurement views: All

**Group** Trigger commands

**Syntax** TRIGGER[:SEQUENCE]:EVENT:INPUT:RUNT:PULSE:HIGH:LEVEL <value>  
TRIGGER[:SEQUENCE]:EVENT:INPUT:RUNT:PULSE:HIGH:LEVEL?

**Arguments** <value>::=<NRF> sets the upper vertical level for a runt pulse in dBm.

**Examples** TRIGGER:EVENT:INPUT:RUNT:PULSE 300 causes the trigger event when the leading edge of a pulse crosses the 300 dBm level.

## TRIGGER[:SEQUENCE]:EVENT:INPUT:SLOPE

Selects or queries the trigger slope for the RF input level trigger.

**Conditions** Measurement views: All

**Group** Trigger commands

**Syntax** TRIGGER[:SEQUENCE]:EVENT:INPUT:SLOPE { RISE | FALL }  
TRIGGER[:SEQUENCE]:EVENT:INPUT:SLOPE?

**Arguments** RISE causes the trigger event on the rising edge.  
FALL causes the trigger event on the falling edge.

**Examples** TRIGGER:SEQUENCE:EVENT:INPUT:SLOPE RISE causes the trigger event on the rising edge of the RF input signal.

## TRIGger[:SEQuence]:EVENT:INPut:TDBWidth

Sets or queries the time-domain bandwidth for the RF input power trigger. This command is effective when [TRIGger\[:SEQuence\]:EVENT:INPut:TDBWidth:STATe](#) is ON.

<b>Conditions</b>	Measurement views: All
<b>Group</b>	Trigger commands
<b>Syntax</b>	TRIGger[:SEQuence]:EVENT:INPut:TDBWidth <value> TRIGger[:SEQuence]:EVENT:INPut:TDBWidth?
<b>Arguments</b>	<value> ::= <Nrf> specifies the time-domain bandwidth. Range: 1 Hz to 60 MHz.
<b>Examples</b>	TRIGGER:SEQUENCE:EVENT:INPUT:TDBWIDTH 5MHZ sets the time-domain bandwidth to 5 MHz for the RF input power trigger.

## TRIGger[:SEQuence]:EVENT:INPut:TDBWidth:ACTual? (Query Only)

Queries the actual time-domain bandwidth for the RF input power trigger.

<b>Conditions</b>	Measurement views: All
<b>Group</b>	Trigger commands
<b>Syntax</b>	TRIGger[:SEQuence]:EVENT:INPut:TDBWidth:ACTual?
<b>Related Commands</b>	<a href="#">TRIGger[:SEQuence]:EVENT:INPut:TDBWidth</a>
<b>Arguments</b>	None
<b>Returns</b>	<Nrf> Actual time-domain bandwidth.
<b>Examples</b>	TRIGGER:SEQUENCE:EVENT:INPUT:TDBWIDTH:ACTUAL? might return 1.000E+6, indicating that the actual time-domain bandwidth is 1 MHz.

## TRIGger[:SEquence]:EVENT:INPut:TDBWidth:STATe

Determines whether to set the time-domain bandwidth automatically or manually for the RF input power trigger.

<b>Conditions</b>	Measurement views: All
<b>Group</b>	Trigger commands
<b>Syntax</b>	TRIGger[:SEquence]:EVENT:INPut:TDBwidth:STATe { OFF   ON   0   1 } TRIGger[:SEquence]:EVENT:INPut:TDBwidth:STATe?
<b>Arguments</b>	OFF or 0 sets the time-domain bandwidth automatically. ON or 1 sets the time-domain bandwidth manually using the <a href="#">TRIGger[:SEquence]:EVENT:INPut:TDBWidth</a> command.
<b>Examples</b>	TRIGGER:SEQUENCE:EVENT:INPUT:TDBWIDTH:STATE OFF sets the time-domain bandwidth automatically.

## TRIGger[:SEquence]:EVENT:INPut:TYPE

Selects or queries the trigger type for the source of RF input.

<b>Conditions</b>	Measurement views: All
<b>Group</b>	Trigger commands
<b>Syntax</b>	TRIGger[:SEquence]:EVENT:INPut:TYPE { POWER   FMASK   DDENSITY   RUNT } TRIGger[:SEquence]:EVENT:INPut:TYPE?
<b>Arguments</b>	POWER uses the power level for triggering. FMASK uses the frequency mask for triggering. DDENSITY uses the density mask for triggering. RUNT uses the runt mask for triggering.

**Examples** TRIGGER:SEQUENCE:EVENT:INPUT:TYPE FMASK uses the frequency mask for triggering.

## TRIGger[:SEQuence]:EVENT:SOURce

Selects or queries the trigger event source.

**Conditions** Measurement views: All

**Group** Trigger commands

**Syntax** TRIGger[:SEQuence]:EVENT:SOURce { INPut | EXTFront | EXTrear | EXTGated | LINE }  
TRIGger[:SEQuence]:EVENT:SOURce?

**Arguments** The following table lists the arguments.

**Table 2-46: Trigger event source**

Argument	Source
INPut	RF input
EXTFront	Trigger in (front)
EXTrear	Trigger in (rear)
EXTGated	Gate in
LINE	AC line

**Examples** TRIGGER:SEQUENCE:EVENT:SOURce INPut specifies the trigger event source as the RF input.

## TRIGger[:SEQuence]:FORCed

Determines whether or not to cause a manual trigger if the acquisition is armed, ready and waiting for a trigger. This command is valid when TRIGger[:SEQuence]:TIME:QUALified:TIME<x> is set to On (the trigger mode is Triggered).

**Conditions** Measurement views: All

**Group** Trigger commands

**Syntax** TRIGger[:SEQuence]:FORCed { OFF | ON | 0 | 1 }  
 TRIGger[:SEQuence]:FORCed?

**Arguments** OFF or 0 does not cause a manual trigger.  
 ON or 1 causes a manual trigger.

**Examples** TRIGGER:SEQUENCE:FORCED ON causes a manual trigger if the acquisition is armed, ready and waiting for a trigger.

## TRIGger[:SEQuence]:IMMediate (No Query Form)

Causes a trigger immediately, skipping the event detection and delay. This command is valid when TRIGger[:SEQuence]:TIME:QUALified:TIME<x> is set to On (the trigger mode is Triggered).

**Conditions** Measurement views: All

**Group** Trigger commands

**Syntax** TRIGger[:SEQuence]:IMMediate

**Arguments** None

**Examples** TRIGGER:SEQUENCE:IMMEDIATE causes a trigger immediately, skipping the event detection and delay.

## TRIGger[:SEQuence]:STATUs

Selects or queries the trigger mode (Free Run or Triggered).

**Conditions** Measurement views: All

**Group** Trigger commands

**Syntax** TRIGger[:SEQuence]:STATUs { OFF | ON | 0 | 1 }  
 TRIGger[:SEQuence]:STATUs?



**Arguments** OFF or 0 selects the free-run mode.  
ON or 1 selects the triggered mode.

**Examples** TRIGGER:SEQUENCE:STATUS ON selects the triggered mode.

## TRIGger[:SEQuence]:TIME:DELay

Sets or queries the trigger delay time which occurs after recognizing an event but before actually declaring the trigger.

**Conditions** Measurement views: All

**Group** Trigger commands

**Syntax** TRIGger[:SEQuence]:TIME:DELay <value>  
TRIGger[:SEQuence]:TIME:DELay?

**Arguments** <value>::=<Nrf> specifies the trigger delay time. Range: 0 to 60 s.

**Examples** TRIGGER:SEQUENCE:TIME:DELAY 1.5 sets the trigger delay time to 1.5 s.

## TRIGger[:SEQuence]:TIME:POSition

Sets or queries the position of the trigger event within the acquisition record.

**Conditions** Measurement views: All

**Group** Trigger commands

**Syntax** TRIGger[:SEQuence]:TIME:POSition <value>  
TRIGger[:SEQuence]:TIME:POSition?

**Arguments** <value>::=<Nrf> specifies the trigger position. Range: 1% to 99%.

**Examples** TRIGGER:SEQUENCE:TIME:POSITION 20 sets the trigger position to 20% of the acquisition record.

## TRIGger[:SEQuence]:TIME:QUALified

Selects or queries the timing qualification setting for triggers. Trigger events that do not meet the timing qualifications are ignored.

**Conditions** Measurement views: All

**Group** Trigger commands

**Syntax** TRIGger[:SEQuence]:TIME:QUALified { SHORTer | LONGer |  
INSide | OUTSide | NONE }  
TRIGger[:SEQuence]:TIME:QUALified?

### Related Commands

**Arguments** SHORTer the length of the trigger event is shorter than the time specified by the TRIGger:TIME:QUALified:TIME1 setting.

LONGer the length of the trigger event is longer than the time specified by the TRIGger:TIME:QUALified:TIME1 setting.

INSide the length of the trigger event is longer than the time TRIGger:TIME:QUALified:TIME1 setting and shorter than the TRIGger:TIME:QUALified:TIME2 setting.

OUTSide the length of the trigger event is shorter than the time TRIGger:TIME:QUALified:TIME1 setting or longer than the TRIGger:QUALified:TIME2 setting.

**Examples** TRIGger:SEQuence:TIME:QUALified SHORTer the length of the trigger event is shorter than the time specified by the TRIGger:TIME:DELAY setting

## TRIGger[:SEQuence]:TIME:QUALified:TIME<x>

Sets or queries the Time1 and Time2 parameters for time qualified triggering. Time1 is the shorter or first time, and Time2 is the second or later time for the qualifying period. Each TIME<x> must be set with a separate command.

**Conditions** Measurement views: All

**Group** Trigger commands

**Syntax** TRIGger[:SEQuence]:TIME:QUALified:TIME<x> <value>

**Related Commands** [TRIGger\[:SEQuence\]:TIME:QUALified](#)

**Arguments** <value> ::= <NRf> the length of the trigger time for TIME1 or TIME2. Range: 0 s to 28 s.

**Examples** TRIGger:TIME:QUALified:TIME1 55us sets the TIME1 trigger point at 55 us after the trigger event.

## UNIT:POWer

Selects or queries the fundamental unit of power. This command is equivalent to [\[SENSE\]:POWer:UNITs](#).

**Conditions** Measurement views: All

**Group** Unit commands

**Syntax** UNIT:POWer { DBM | DBV | VOLTs | WATTs | DBUW | DBW | DBUV | DBMV | DBUA | DBUV\_M | DBUA\_M | AMPS }  
UNIT:POWer?

**Arguments** The following table lists the arguments.

**Table 2-47: Power units**

Argument	Power unit
DBM	dBm
DBV	dBV
VOLTs	Volts
WATTs	Watts
DBUW	dB $\mu$ W
DBW	dBW
DBUV	dB $\mu$ V
DBMV	dBmV
DBUA	dB $\mu$ A
DBUV_M	dB $\mu$ V/m
DBUA_M	dB $\mu$ A/m
AMPS	Amps

---

**NOTE.** Select  $dB\mu V/m$  or  $dB\mu A/m$  unit when using an antenna table.

---

**Examples**     `UNIT:POWER DBM` specifies the fundamental unit of power as dBm.

## **\*WAI (No Query Form)**

Prevents the analyzer from executing further commands or queries until all pending operations finish. This command allows you to synchronize the operation of the analyzer with your application program. For the details, refer to *Synchronizing Execution* (See page 3-12.).

**Conditions**     Measurement views: All

**Group**     IEEE common commands

**Syntax**     \*WAI

**Related Commands**     \*OPC

**Arguments**     None

---

# Status and Events



# Status and Events

The SCPI interface in the analyzer includes a status and event reporting system that enables the user to monitor crucial events that occur in the instrument. The analyzer is equipped with four registers and one queue that conform to IEEE Std 488.2-1987. This section will discuss these registers and queues along with status and event processing.

## Status and Event Reporting System

The following figure outlines the status and event reporting mechanism offered in the RSA6100A Series analyzers. It contains three major blocks

- Standard Event Status
- Operation Status
- Questionable Status (fan-out structure)

The processes performed in these blocks are summarized in the Status Byte. The three blocks contain four types of registers as shown in the following table.

**Table 3-1: Register type**

Register	Description
Condition register	Records event occurrence in the instrument. Read only.
Transition register (positive/negative)	A positive transition filter allows an event to be reported when a condition changes from false to true. A negative filter allows an event to be reported when a condition changes from true to false. Setting both positive and negative filters true allows an event to be reported anytime the condition changes. Clearing both filters disables event reporting.
Event register	Records events filtered by the transition register. Read only.
Enable register	Masks the event register to report in the summary bit. User-definable.

\* The use of Bit 15 is not allowed in SCPI.  
 The value of this bit is always zero.

CR: Condition Register  
 TR: Transition Register  
 EVR: Event Register  
 ENR: Enable Register




Figure 3-1: Status/Event reporting mechanism






Figure 3-2: Status/Event reporting mechanism (Cont.)

## Status Byte

The Status Byte contains the following two registers

- Status Byte Register (SBR)
- Service Request Enable Register (SRER)

### Status Byte Register (SBR)

The SBR is made up of 8 bits. Bits 4, 5 and 6 are defined in accordance with IEEE Std 488.2-1987. These bits are used to monitor the output queue, SESR and service requests, respectively. The contents of this register are returned when the \*STB? query is used.




Figure 3-3: Status Byte Register (SBR)

Table 3-2: SBR bit functions

Bit	Description
7	Operation Summary Status (OSS). Summary of the operation status register.
6	Request Service (RQS)/Master Status Summary (MSS). When the instrument is accessed using the GPIB serial poll command, this bit is called the Request Service (RQS) bit and indicates to the controller that a service request has occurred (in other words, that the GPIB bus SRQ line is LOW). The RQS bit is cleared when serial poll ends.  When the instrument is accessed using the *STB? query, this bit is called the Master Status Summary (MSS) bit and indicates that the instrument has issued a service request for one or more reasons. The MSS bit is never cleared to 0 by the *STB? query.
5	Event Status Bit (ESB). This bit indicates whether or not a new event has occurred after the previous Standard Event Status Register (SESR) has been cleared or after an event readout has been performed.
4	Message Available Bit (MAV). This bit indicates that a message has been placed in the output queue and can be retrieved.
3	Questionable Summary Status (QSS). Summary of the Questionable Status Byte register.
2	Event Quantity Available (EAV). Summary of the Error Event Queue.
1-0	Not used

**Service Request Enable Register (SRER)**

The SRER is made up of bits defined exactly the same as bits 0 through 7 in the SBR as shown in the following figure. This register is used by the user to determine what events will generate service requests.

The SRER bit 6 cannot be set. Also, the RQS is not maskable.

The generation of a service request with the GPIB interface involves changing the SRQ line to LOW and making a service request to the controller. The result is that a status byte for which an RQS has been set is returned in response to serial polling by the controller.

Use the \*SRE command to set the bits of the SRER. Use the \*SRE? query to read the contents of the SRER. Bit 6 must normally be set to 0.

7	6	5	4	3	2	1	0
OSB	—	ESB	MAV	QSB	—	—	—

**Figure 3-4: Service Request Enable Register (SRER)**

## Standard Event Status Block

Reports the power on/off state, command errors, and the running state. It consists of the following registers

- Standard Event Status Register (SESR)
- Event Status Enable Register (ESER)

These registers are made up of the same bits defined in the following figure and table. Use the \*ESR? query to read the contents of the SESR. Use the \*ESE() command to access the ESER.

7	6	5	4	3	2	1	0
PON	—	CME	EXE	DDE	QYE	—	OPC

**Figure 3-5: Standard event status register**

**Table 3-3: Standard event status register bit definition**

Bit	Description
7	Power On (PON). Indicates that the power to the instrument is on.
6	Not used.
5	Command Error (CME). Indicates that a command error has occurred while parsing by the command parser was in progress.
4	Execution Error (EXE). Indicates that an error occurred during the execution of a command. Execution errors occur for one of the following reasons <ul style="list-style-type: none"> <li>■ When a value designated in the argument is outside the allowable range of the instrument, or is in conflict with the capabilities of the instrument.</li> <li>■ When the command could not be executed properly because the conditions for execution differed from those essentially required.</li> </ul>
3	Device-Dependent Error (DDE). An instrument error has been detected.
2	Query Error (QYE). Indicates that a query error has been detected by the output queue controller. Query errors occur for one of the following reasons <ul style="list-style-type: none"> <li>■ An attempt was made to retrieve messages from the output queue, despite the fact that the output queue is empty or in pending status.</li> <li>■ The output queue messages have been cleared despite the fact that they have not been retrieved.</li> </ul>
1	Not used.
0	Operation Complete (OPC). This bit is set with the results of the execution of the *OPC command. It indicates that all pending operations have been completed.

When an event occurs, the SESR bit corresponding to the event is set, resulting in the event being stacked in the Error/Event Queue. The SBR OAV bit is also set. If the bit corresponding to the event has also been set in the ESER, the SBR ESB bit is also set. When a message is sent to the Output Queue, the SBR MAV bit is set.

## Operation Status Block

The operation status block contains conditions that are part of the instrument's normal operation. It consists of the following registers

- Operation Condition Register (OCR)
- Operation Positive/ Negative Transition Register (OPTR/ONTR)
- Operation Event Register (OEVR)
- Operation Enable Register (OENR)

These registers are made up of the same bits defined in the following table and figure. Use the STATUS:OPERation commands to access the operation status register set.

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
											MEAS				ALIG

Figure 3-6: Operation status register

Table 3-4: Operation status register bit definition

Bit	Description
15	Always zero (0).
14 - 5	Not used.
4	Measuring (MEAS). Indicates that the instrument is actively measuring. When the measurement ends after this bit is set in measurement, it is reset. "In measurement" means that one of the following commands is in execution: <ul style="list-style-type: none"> <li>■ INITiate commands</li> <li>■ READ commands</li> </ul>
3 - 1	Not used.
0	Aligning (ALIG). Indicates that the instrument is currently performing an alignment. When the alignment ends after this bit is set in alignment, it is reset.

When the specified state changes in the OCR, its bit is set or reset. This change is filtered with a transition register, and the corresponding bit of the OEVR is set. If the bit corresponding to the event has also been set in the OENR, the SBR OSS bit is also set.

## Questionable Status Block

The questionable status register set contains bits which give an indication of the quality of various aspects of the signal together with the fanned out registers as described in the next subsections. It consists of the following registers

- Questionable Condition Register (QCR)
- Questionable Positive/Negative Transition Register (QPTR/QNTR)
- Questionable Event Register (QEVN)
- Questionable Enable Register (QENR)

These registers are made up of the same bits defined in the following table and figure. Use the STATUS:QUESTIONABLE commands to access the questionable status register set.

15	14 CW	13	12	11	10	9	8 CAL	7	6	5 FREQ	4 TEMP	3 POW	2	1	0
----	----------	----	----	----	----	---	----------	---	---	-----------	-----------	----------	---	---	---

Figure 3-7: Questionable status register

Table 3-5: Questionable status register bit definition

Bit	Description
15	Always zero (0).
14	Command Warning (CW). Indicates a non-fatal warning that relates to the instrument's interpretation of a command, query, or one or more parameters of a specific command or query.
13 - 9	Not used.
8	CALibration Summary (CAL). Summary of the Questionable Calibration register.
7, 6	Not used.
5	FREQuency Summary (FREQ). Summary of the Questionable Frequency register.
4	TEMPerature Summary (TEMP). Summary of the Questionable Temperature register.
3	POWER Summary (POW). Summary of the Questionable Power register.
2 - 0	Not used.

When the specified state changes in the QCR, its bit is set or reset. This change is filtered with a transition register, and the corresponding bit of the QEVN is set. If the bit corresponding to the event has also been set in the QENR, the SBR QSS bit is also set.

### Questionable Power Register Set

Refines the power error for the POWER bit in the QCR.

*Currently not used.*

**Questionable Temperature Register Set** Refines the temperature error for the TEMPerature bit in the QCR.  
*Currently not used.*

**Questionable Frequency Register Set** The questionable frequency register set is made up of bits defined in the following table and figure. It refines the frequency error for the FREQuency bit in the QCR. Use the STATus:QUEStionable:FREQuency commands to access the questionable frequency register set.

15	14	13	12	11	10 ERNV	9 LTER	8	7	6	5	4	3	2	1	0
----	----	----	----	----	------------	-----------	---	---	---	---	---	---	---	---	---

Figure 3-8: Questionable frequency status register

Table 3-6: Questionable frequency status register bit definition

Bit	Description
15	Always zero (0).
14 - 11	Not used.
10	External Ref Not Valid (ERNV). Indicates that the external reference signal is not valid so the instrument is no longer locked to it.
9	Locked To External Ref (LTER). Indicates that the instrument is locked to the external reference signal.
8 - 0	Not used.

**Questionable Calibration Register Set** The questionable calibration register set is made up of bits defined in the following table and figure. It refines the calibration error for the CALibration bit in the QCR. Use the STATus:QUEStionable:CALibration commands to access the questionable calibration register set.

15	14 ALN	13	12	11	10	9	8	7	6	5	4	3	2	1	0
----	-----------	----	----	----	----	---	---	---	---	---	---	---	---	---	---

Figure 3-9: Questionable calibration status register

Table 3-7: Questionable calibration status register bit definition

Bit	Description
15	Always zero.
14	Alignment Needed (ALN). Indicates the instrument needs the alignment.
13 - 0	Not used.

## Queues

There are two types of queues in the status reporting system used in the analyzer: output queues and event queues.

### Output Queue

The output queue is a FIFO (first in, first out) queue and holds response messages to queries, where they await retrieval. When there are messages in the queue, the SBR MAV bit is set.

The output queue will be emptied each time a command or query is received, so the controller must read the output queue before the next command or query is issued. If this is not done, an error will occur and the output queue will be emptied; however, the operation will proceed even if an error occurs.

### Event Queue

The event queue is a FIFO queue and stores events as they occur in the analyzer. If more than 32 events occur, event 32 will be replaced with event code -350 ("Queue Overflow"). The error code and text are retrieved using the SYSTem:ERRor queries.



## Status and Event Processing Sequence

The following figure shows an outline of the sequence for status and event processing.




Figure 3-10: Status and event processing sequence

1. If an event has occurred, the SESR bit corresponding to that event is set and the event is placed in the event queue.
2. A bit corresponding to that event in the ESER has is set.
3. The SBR ESB bit is set to reflect the status of the ESER.
4. When a message is sent to the output queue, the SBR MAV bit is set.

5. Setting either the ESB or MAV bits in the SBR sets the respective bit in the SRER.
6. When the SRER bit is set, the SBR MSS bit is set and a service request is generated when using the GPIB interface.

## Synchronizing Execution

Almost all commands are executed in the order in which they are sent from the controller, and the execution of each command is completed in a short period of time. However, the following commands perform data analysis in another thread, and another command can thus be executed concurrently

- INITiate commands
- READ commands
- [SENSe]:REANalyze

These commands are designed so that the next command to be sent is executed without waiting for the previous command to be completed. In some cases, a process executed by another command must first be completed before these commands can be executed; in other cases, these commands must be completed before the next command is executed.

You have two options to achieve command synchronization

- Using the status and event reporting function
- Using synchronizing commands

### Using the Status and Event Reporting Function

In the following example, a READ command is used to obtain the measurement results while the Operation Condition Register (OCR) is being used to provide synchronization.

```

STATUS:OPERation:NTRansition 16
    // Set the filter of the OCR MEASuring bit
STATUS:OPERation:ENABle 16
    // Enable the filter of the OCR MEASuring bit
*SRE 128
    // Set the SRER OSS bit
READ:SPECTrum:TRACe
    // Obtain the measurement results
    
```

The command waits for generation of SRQ.

## Using Synchronizing Commands

The IEEE-488.2 common commands include the following synchronizing commands

- \*OPC
- \*OPC?
- \*WAI

**Using the \*OPC command.** The \*OPC command sets the SESR OPC bit when all the operations for which it is waiting are completed. If the GPIB interface is in use, you can synchronize the execution by using this command together with the serial polling or service request function.

The following is a command sequence example:

```
*ESE 1
  // Enable the ESER OPC bit
*SRE 32
  // Enable the SRER ESB bit
ABORt;INITiate:IMMediate;*OPC
  // Wait for SRQ to provide synchronization
```

**Using the \*OPC? query.** The query \*OPC? writes ASCII code "1" into the Output Queue when all operations for which it is waiting are completed. You can provide synchronization using the command string as the following example:

```
ABORt;INITiate:IMMediate;*OPC
```

The command waits until "1" is written into the Output Queue. When the command goes to the Output Queue to read the data, a time-out may occur before the data is written into the queue.

**Using the \*WAI Command.** After the process of the preceding command is completed, the \*WAI command begins to execute the process of the next command as the following example:

```
ABORt;INITiate:IMMediate;*WAI
  // Wait for the *WAI process to provide synchronization
```

## Error Messages and Codes

Error codes with a negative value are SCPI standard error codes; errors with a positive value are unique to the RSA6100A Series Real-Time Spectrum Analyzers.

Event codes and messages can be obtained by using the queries `SYSTEM:ERROR?` and `SYSTEM:ERROR:ALL?` These are returned in the following format

```
<event_code>,"<event_message>"
```

## Command Errors

Command errors are returned when there is a syntax error in the command.

**Table 3-8: Command errors**

<b>Error code</b>	<b>Error message</b>
-100	Command error
-101	Invalid character
-102	Syntax error
-103	Invalid separator
-104	Data type error
-105	GET not allowed
-108	Parameter not allowed
-109	Missing parameter
-110	Command header error
-111	Header separator error
-112	Program mnemonic too long
-113	Undefined header
-114	Header suffix out of range
-120	Numeric data error
-121	Character
-123	Exponent too large
-124	Too many digits
-128	Numeric data not allowed
-130	Suffix error
-131	Invalid suffix
-134	Suffix too long
-138	Suffix not allowed
-140	Character data error
-141	Invalid character data
-144	Character data too long

**Table 3-8: Command errors (cont.)**

<b>Error code</b>	<b>Error message</b>
-148	Character data not allowed
-150	String data error
-151	Invalid string data
-158	String data not allowed
-160	Block data error
-161	Invalid block data
-168	Block data not allowed
-170	Command expression error
-171	Invalid expression
-178	Expression data not allowed
-180	Macro error
-181	Invalid outside macro definition
-183	Invalid inside macro definition
-184	Macro parameter error

## Execution Errors

These error codes are returned when an error is detected while a command is being executed.

**Table 3-9: Execution errors**

<b>Error code</b>	<b>Error message</b>
-200	Execution error
-201	Invalid while in local
-202	Settings lost due to RTL
-210	Trigger error
-211	Trigger ignored
-212	Arm ignored
-213	Init ignored
-214	Trigger deadlock
-215	Arm deadlock
-220	Parameter error
-221	Settings conflict
-222	Data out of range
-223	Too much data
-224	Illegal parameter value
-225	Out of memory

**Table 3-9: Execution errors (cont.)**

<b>Error code</b>	<b>Error message</b>
-226	Lists not same length
-230	Data corrupt or stale
-231	Data questionable
-240	Hardware error
-241	Hardware missing
-250	Mass storage error
-251	Missing mass storage
-252	Missing media
-253	Corrupt media
-254	Media full
-255	Directory full
-256	Filename not found
-257	Filename error
-258	Media protected
-260	Execution expression error
-261	Math error in expression
-270	Execution macro error
-271	Macro syntax error
-272	Macro execution error
-273	Illegal macro label
-274	Execution macro parameter error
-275	Macro definition too long
-276	Macro recursion error
-277	Macro redefinition not allowed
-278	Macro header not found
-280	Program error
-281	Cannot create program
-282	Illegal program name
-283	Illegal variable name
-284	Program currently running
-285	Program syntax error
-286	Program runtime error

## Device Specific Errors

These error codes are returned when an internal instrument error is detected. This type of error may indicate a hardware problem.

**Table 3-10: Device specific errors**

<b>Error code</b>	<b>Error message</b>
-300	Device specific error
-310	System error
-311	Memory error
-312	PUD memory lost
-313	Calibration memory lost
-314	Save/Recall memory lost
-315	Configuration memory lost
-330	Self test failed
-350	Queue overflow

## Query Errors

These error codes are returned in response to an unanswered query.

**Table 3-11: Query errors**

<b>Error code</b>	<b>Error message</b>
-400	Query error
-410	Query interrupted
-420	Query untermiated
-430	Query deadlocked
-440	Query untermiated after indefinite period

## Device Errors

These error codes are unique to the RSA6100A Series. They are classified into three groups: global, measurement, and source conditions, as shown in the following tables.

**Table 3-12: Device errors, global condition**

<b>Error code</b>	<b>Error message</b>
100	Setup error
101	Disabled: data is from swept acquisition
102	Disabled: swept settings; Acquire data while display is selected
103	Acquisition bandwidth too small for current setup
104	Can't get acquisition data record
105	Can't open the requested display
106	Analysis failure
107	Analysis length was limited
108	Analysis length too small for current setup
109	No math trace: unmatched trace lengths
110	Analysis time was adjusted
111	Not enough samples for current setup
112	Can't replay. Data is from swept acquisition.
113	Can't replay. Live data needed for swept settings.
114	Recall error: setup not completely restored
115	Recall failure: problem with file or file contents
116	Save failure: file not saved
117	Unexpected software error. Please cycle power and try again.
118	Export failure: file not saved
119	Export failure: unable to open results file for export. File not saved.
120	Search condition for this result is already defined.
121	Search condition for this result was not found.
124	Load failed: <filename>
125	Store error: file not saved.
126	No Math trace: unmatched trace X range
127	Not enough memory for measurement
128	Incomplete analysis
129	Not enough samples for current setup
130	Mask creation error: <reason message>



**Table 3-13: Device errors, measurement condition**

<b>Error code</b>	<b>Error message</b>
1000	TDBW actual (TDBW: Time Domain Bandwidth)
1001	Average transmit not available in volts units
1002	RBW increased to
1003	RBW limited by acquisition bandwidth to
1004	RBW conflict. Increase span or analysis length
1005	Analysis stopped: ambiguous pulse shape
1006	Setup error: Phase measurement location.
1007	No pulses found
1008	No FFT (not all pulses have results)
1009	No burst detected
1011	Audio disabled: configuration problem
1012	Audio Demod disabled: swept acquisition
1013	Audio Demod disabled: trigger in use
1014	Audio disabled: IF band outside Acq BW
1015	Calibration error. See Windows Event Viewer for error detail.
<b>OBW errors</b>	
1016	Analysis failure: $\text{AcqBW} < \text{MeasBW} + (5 \times \text{RBW})$
1017	Analysis failure: AcqBW must be 10 kHz or more
1018	$x \text{ dB BW} > \text{Meas BW}$
<b>Pulse errors</b>	
1019	AcqBW too low for current Chirp BW setting
1023	Not enough memory for measurement
<b>Other measurements</b>	
1024	BW actual (limited by Acq BW)
1025	CISPR not available in FastFrame. Uncheck FastFrame in the Acquire panel.
1026	Analysis length must be in auto.
1027	Carrier not found
1029	CISPR accuracy limited by acq memory. Adjust RBW or freq range.
1030	CISPR: Acq BW too small for RBW. Try increasing span or freq range.
1031	Insufficient data for CISPR. Acquire while display is selected.
1032	VBW increased - Analysis Length too short
1033	VBW does not use full Analysis Length.

**Table 3-14: Device errors, source condition**

<b>Error code</b>	<b>Error message</b>
2000	Data acquired during RF ADC overrange
2001	(internal use only)
2002	(internal use only)
2003	Preamp not specified for frequencies > 3 GHz
2004	Data acquired using preamp
2005	Aligning
2006	Not aligned
2007	Data from unaligned instrument
2008	Not calibrated
2009	Data from uncalibrated instrument
2010	Dither: manual control
2011	Hardware failure - see Windows Event Viewer
2012	Data acquired during hardware failure
2013	Hardware failure detected by diagnostics
2014	Data acquired during RF digital gain overflow
2015	Locking to external frequency reference signal
2016	Locked to external reference
2017	No_RF_Deck mode
2018	RF attenuator: manual control
2019	Saving acquisition data
2020	Restoring acquisition data
2021	Simulated data
2022	Disabled: data is from swept acquisition
2023	Disabled: frequency mask trigger in use
2024	Span > RF acquisition bandwidth
2025	RBW not valid for current acquisition bandwidth
2026	Acquisition sampling parameters: manual control
2027	Swept: RF trigger invalid for most signals
2028	External frequency reference signal not valid. Using internal reference.
2029	Unable to lock to external frequency reference. Using internal reference.
2030	Data acquired during RF ADC overrange
2031	Data acquired during RF digital gain overflow
2032	Source factory error
2033	Alignment error. Please run alignment again. If the problem persists, contact your Tektronix Service Center.
2034	Operational error: unable to complete operation. Please try again. If the problem persists, contact your Tektronix Service Center. See Windows Event Viewer for error detail.

**Table 3-14: Device errors, source condition (cont.)**

<b>Error code</b>	<b>Error message</b>
2035	Hardware error: unable to configure hardware. Please try again. If the problem persists, contact your Tektronix Service Center. See Windows Event Viewer for error detail.
2036	Shutting down - internal temperature is too high. Check fans and airflow. If the problem persists, contact your Tektronix Service Center.
2037	Hardware error detected. To clear error, exit and restart the application. If the problem persists, contact your Tektronix Service Center.
2038	Disabled: RefLev too low\nfor Volts/Watts units
2042	Ext Corr > 20 dB pk-pk in acq segment
2044	Combined External Correction tables exceed the 60 dB peak-to-peak limit. External Correction tables were disabled. Please check table values and try again.
2045	Disabled: FastFrame doesn't support swept settings.
2046	Attenuator use currently exceeds the cautionary limit of 1200 changes per hour. Operation was stopped to protect against premature wear-out. The monitor function can be temporarily disabled in the Amplitude control panel or over the programmatic interface. Specified lifetime for an attenuator is 10,000,000 changes.
2047	Disabled: settings conflict with selected measurement




---

# Appendices



# Appendix A: Character Charts

B7 B6 B5 BITS B4 B3 B2 B1	0 0		0 0 1		0 1 0		0 1 1		1 0 0		1 0 1		1 1 0		1 1 1	
	CONTROL				NUMBERS SYMBOLS				UPPER CASE				LOWER CASE			
0 0 0 0	0 NUL	20 DLE	40 SP	60 0	100 @	120 P	140 ' ,	160 p	0 0	20 10	40 20	60 30	100 40	120 50	140 60	160 70
0 0 0 1	1 SOH	21 DC1	41 !	61 1	101 A	121 Q	141 a	161 q	1 1	21 11	41 21	61 31	101 41	121 51	141 61	161 71
0 0 1 0	2 STX	22 DC2	42 "	62 2	102 B	122 R	142 b	162 r	0 1 0	22 12	42 22	62 32	102 42	122 52	142 62	162 72
0 0 1 1	3 ETX	23 DC3	43 #	63 3	103 C	123 S	143 c	163 s	1 0 1	23 13	43 23	63 33	103 43	123 53	143 63	163 73
0 1 0 0	4 EOT	24 DC4	44 \$	64 4	104 D	124 T	144 d	164 t	0 1 0 0	24 14	44 24	64 34	104 44	124 54	144 64	164 74
0 1 0 1	5 ENQ	25 NAK	45 %	65 5	105 E	125 U	145 e	165 u	0 1 0 1	25 15	45 25	65 35	105 45	125 55	145 65	165 75
0 1 1 0	6 ACK	26 SYN	46 &	66 6	106 F	126 V	146 f	166 v	0 1 1 0	26 16	46 26	66 36	106 46	126 56	146 66	166 76
0 1 1 1	7 BEL	27 ETB	47 ' ,	67 7	107 G	127 W	147 g	167 w	0 1 1 1	27 17	47 27	67 37	107 47	127 57	147 67	167 77
1 0 0 0	8 BS	30 CAN	50 (	70 8	110 H	130 X	150 h	170 x	1 0 0 0	28 18	48 28	68 38	108 48	128 58	148 68	168 78
1 0 0 1	9 HT	31 EM	51 )	71 9	111 I	131 Y	151 i	171 y	1 0 0 1	29 19	49 29	69 39	109 49	129 59	149 69	169 79
1 0 1 0	A LF	32 SUB	52 *	72 :	112 J	132 Z	152 j	172 z	1 0 1 0	30 20	50 30	70 40	90 50	110 60	130 70	150 80
1 0 1 1	B VT	33 ESC	53 +	73 ;	113 K	133 [	153 k	173 {	1 0 1 1	31 21	51 31	71 41	91 51	111 61	131 71	151 81
1 1 0 0	C FF	34 FS	54 ,	74 <	114 L	134 \	154 l	174 ;	1 1 0 0	32 22	52 32	72 42	92 52	112 62	132 72	152 82
1 1 0 1	D CR	35 GS	55 -	75 =	115 M	135 ]	155 m	175 }	1 1 0 1	33 23	53 33	73 43	93 53	113 63	133 73	153 83
1 1 1 0	E SO	36 RS	56 .	76 >	116 N	136 ^	156 n	176 ~	1 1 1 0	34 24	54 34	74 44	94 54	114 64	134 74	154 84
1 1 1 1	F SI	37 US	57 /	77 ?	117 O	137 -	157 o	177 RUBOUT (DEL)	1 1 1 1	35 25	55 35	75 45	95 55	115 65	135 75	155 85
	ADDRESSED COMMANDS		UNIVERSAL COMMANDS		LISTEN ADDRESSES				TALK ADDRESSES				SECONDARY ADDRESSES OR COMMANDS			



**Tektronix**  
REF: ANSI STD X3.4-1977  
IEEE STD 488.1-1987  
ISO STD 646-2973





# Appendix B: GPIB Interface Specification

This appendix lists and describes the GPIB functions and messages the instrument can implement.

## Interface Functions

The following table lists the GPIB interface functions this instrument implements. Each function is briefly described.

**Table B-1: GPIB interface function implementation**

<b>Interface function</b>	<b>Implemented subset</b>	<b>Capability</b>
Source Handshake (SH)	SH1	Complete
Acceptor Handshake (AH)	AH1	Complete
Talker (T)	T6	Basic Talker, Serial Poll Unaddress if my-listen-address (MLA) No Talk Only mode
Listener (L)	L4	Basic Listener Unaddress if my talk address (MTA) No Listen Only mode
Service Request (SR)	SR1	Complete
Remote/Local (RL)	RL0	None
Parallel Poll (PP)	PP0	None
Device Clear (DC)	DC1	Complete
Device Trigger (DT)	DT0	None
Controller (C)	C0	None
Electrical Interface	E2	Three-state driver

- Source Handshake (SH). Enables a talking device to support the coordination of data transfer. The SH function controls the initiation and termination of data byte transfers.
- Acceptor Handshake (AH). Enables a listening device to coordinate data reception. The AH function delays data transfer initiation or termination until the listening device is ready to receive the next data byte.
- Talker (T). Enables a device to send device-dependent data over the interface. This capability is available only when the device is addressed to talk, and uses a one-byte address.
- Listener (L). Enables a device to receive device-dependent data over the interface. This capability is available only when the device is addressed to listen, and uses a one-byte address.
- Service Request (SR). Enables a device to assert an SRQ (Service Request) line to notify the controller when it requires service.
- Remote/Local (RL). Enables a device to respond to both the GTL (Go To Local) and LLO (Local Lock Out) interface messages.
- Parallel Poll (PP). Enables a device to respond to the following interface messages: PPC, PPD, PPE, and PPU, as well as to send out a status message when the ATN (Attention) and EOI (End or Identify) lines are asserted simultaneously.
- Device Clear (DC). Enables a device to be cleared or initialized, either individually, or as part of a group of devices.
- Device Trigger (DT). Enables a device to respond to the GET (Group Execute Trigger) interface message when acting as a listener.
- Controller (C). Enables a device that has this capability to send its address, universal commands, and addressed commands to other devices over the interface.
- Electrical Interface (E). Identifies the electrical interface driver type. The notation E1 means the electrical interface uses open collector drivers, E2 means the electrical interface uses three-state drivers.

## Interface Messages

**Table B-2: Standard interface messages**

Message	Type <sup>1</sup>	Implemented
Device Clear (DCL)	UC	Yes
Local Lockout (LLO)	UC	No
Serial Poll Disable (SPD)	UC	Yes
Serial Poll Enable (SPE)	UC	Yes
Parallel Poll Unconfigure (PPU)	UC	No
Go To Local (GTL)	AC	Yes
Selected Device Clear (SDC)	AC	Yes
Group Execute Trigger (GET)	AC	No
Take Control (TCT)	AC	No
Parallel Poll Configure (PPC)	AC	No

<sup>1</sup> UC: Universal command; AC: Address command

- Device Clear (DCL). Will clear (initialize) all devices on the bus that have a device clear function, whether or not the controller has addressed them.
- Local Lockout (LLO). Disables the return to local function.
- Serial Poll Disable (SPD). Changes all devices on the bus from the serial poll state to the normal operating state.
- Serial Poll Enable (SPE). Puts all bus devices that have a service request function into the serial poll enabled state. In this state, each device sends the controller its status byte, instead of its normal output, after the device receives its talk address on the data lines. This function may be used to determine which device sent a service request.
- Go To Local (GTL). Causes the listen-addressed device to switch from remote to local (front-panel) control.
- Select Device Clear (SDC). Clears or initializes all listen-addressed devices.
- Group Execute Trigger (GET). Triggers all applicable devices and causes them to initiate their programmed actions.
- Take Control (TCT). Allows the controller in charge to pass control of the bus to another controller on the bus.
- Parallel Poll Configure (PPC). Causes the listen-addressed device to respond to the secondary commands Parallel Poll Enable (PPE) and Parallel Poll Disable (PPD), which are placed on the bus following the PPC command. PPE enables a device with parallel poll capability to respond on a particular data line. PPD disables the device from responding to the parallel poll.



# Appendix C: Factory Initialization Settings

The factory initialization settings provide a known state for the analyzer. The \*RST command returns the instrument settings to the factory defaults. Factory initialization sets values as shown in the following tables in this section.

**Table C-1: Factory initialization settings, IEEE common commands**

Header	Default value
*ESE	0
*OPC	0
*SRE	0

**Table C-2: Factory initialization settings, Calculate commands**

Header	Default value
<b>CALCulate basic command subgroup</b>	
CALCulate:MARKer:DENSity:EXCursion	50
CALCulate:MARKer:DENSity:SMOothing	5
CALCulate:MARKer:DENSity:THReshold	500
CALCulate:MARKer:MODE	ABSolute
CALCulate:MARKer:PEAK:EXCursion	6 dB
CALCulate:MARKer:PEAK:THReshold	-150 dBm
CALCulate:SEARch:LIMit:MATCh:BEEP[:STATe]	OFF
CALCulate:SEARch:LIMit:MATCh:SACQuire[:STATe]	OFF
CALCulate:SEARch:LIMit:MATCh:SDATa[:STATe]	OFF
CALCulate:SEARch:LIMit:MATCh:SPICture[:STATe]	OFF
CALCulate:SEARch:LIMit:MATCh:STRace[:STATe]	OFF
CALCulate:SEARch:LIMit:OPERation	GT
CALCulate:SEARch:LIMit:OPERation:FEED	"Spectrum", "Trace 1"
CALCulate:SEARch:LIMit:OPERation:SLIMit	-20 dBm
CALCulate:SEARch:LIMit:STATe	OFF
<b>CALCulate:DPSA subgroup</b>	
CALCulate:DPSA:MARKer<x>:TRACe	TRACE1
CALCulate:DPSA:MARKer<x>:X:AMPLitude	0 dBm
CALCulate:DPSA:MARKer<x>:X[:FREQuency]	1.5 GHz
<b>CALCulate:SPECTrum subgroup</b>	
CALCulate:SPECTrum:MARKer<x>:TRACe	TRACE1

**Table C-3: Factory initialization settings, Calibration commands**

Header	Default value
CALibration:AUTO	ON
CALibration:CORRection:EXTErnal:EDIT<x>:LABel	Ext Gain Table n
CALibration:CORRection:EXTErnal:EDIT<x>:STATe	OFF
CALibration:CORRection:EXTErnal:GAIN[:MAGNitude]	30 dB
CALibration:CORRection:EXTErnal:GAIN:STATe	OFF
CALibration:CORRection:EXTErnal:PROBe:STATe	OFF
INPut:CORRection:EXTErnal:EDIT<x>:INTErpolation	TRACe

**Table C-4: Factory initialization settings, Display commands**

Header	Default value
<b>DISPlay basic command subgroup</b>	
DISPlay:WINDow:COLor:SCHEme	CLASsic
<b>DISPlay:ACPower subgroup</b>	
DISPlay:ACPower:MARKer:SHOW:STATe	ON
DISPlay:ACPower:PLEVel:SHOW:STATe	ON
DISPlay:ACPower:WINDow:TRACe:GRATICule:GRID:STATe	ON
DISPlay:ACPower:X[:SCALe]	13.84 MHz
DISPlay:ACPower:X[:SCALe]:OFFSet	1.5 GHz
DISPlay:ACPower:Y[:SCALe]	100 dB
DISPlay:ACPower:Y[:SCALe]:OFFSet	0
<b>DISPlay:{AM FM PM} subgroup</b>	
DISPlay:{AM FM PM}:MARKer:SHOW:STATe	ON
DISPlay:{AM FM PM}:WINDow:TRACe:GRATICule:GRID:STATe	ON
<b>DISPlay:AVTime subgroup</b>	
DISPlay:AVTime:MARKer:SHOW:STATe	ON
DISPlay:AVTime:TRIGger:LEVel:STATe	ON
DISPlay:AVTime:WINDow:TRACe:GRATICule:GRID:STATe	ON
DISPlay:AVTime:X[:SCALe]:AUTO:STATe	ON
DISPlay:AVTime:X[:SCALe]:OFFSet	0
DISPlay:AVTime:Y[:SCALe]:FULL	100 dB
DISPlay:AVTime:Y[:SCALe]:OFFSet	0
<b>DISPlay:CONSte subgroup</b>	
DISPlay:CONSte:MPHase	P1
DISPlay:CONSte:WINDow:TRACe:GRATICule:GRID:STATe	ON
<b>DISPlay:DDEMod subgroup</b>	

Table C-4: Factory initialization settings, Display commands (cont.)

Header	Default value
DISPlay:DDEMod:RADix	BINary
DISPlay:DDEMod:X[:SCALe]	128 symbols
DISPlay:DDEMod:X[:SCALe]:AUTO:STATe	ON
DISPlay:DDEMod:X[:SCALe]:OFFSet	-1 symbol
<b>DISPlay:DIQVtime subgroup</b>	
DISPlay:DIQVtime:WINDow:TRACe:GRATICule:GRID:STATe	ON
<b>DISPlay:DPSA subgroup</b>	
DISPlay:CCDF:WINDow:TRACe:GRATICule:GRID:STATe	ON
DISPlay:DPSA:Y[:SCALe]:PDIVision	10 dB/div
<b>DISPlay:EDiagram subgroup</b>	
DISPlay:EDiagram:WINDow:TRACe:GRATICule:GRID:STATe	ON
<b>DISPlay:EVM subgroup</b>	
DISPlay:EVM:Y[:SCALe]	100%
DISPlay:EVM:Y[:SCALe]:OFFSet	-100
<b>DISPlay:FDVTime subgroup</b>	
DISPlay:FDVTime:WINDow:TRACe:GRATICule:GRID:STATe	ON
<b>DISPlay:FVTime subgroup</b>	
DISPlay:FVTime:WINDow:TRACe:GRATICule:GRID:STATe	ON
DISPlay:FVTime:X[:SCALe]:AUTO:STATe	ON
DISPlay:FVTime:X[:SCALe]:OFFSet	0
DISPlay:FVTime:Y[:SCALe]	10 120 MHz
DISPlay:FVTime:Y[:SCALe]:OFFSet	0
<b>DISPlay:GENeral subgroup</b>	
DISPlay:GENeral:MEASview:SElect	SPECTrum
<b>DISPlay:IQVTime subgroup</b>	
DISPlay:IQVTime:WINDow:TRACe:GRATICule:GRID:STATe	ON
DISPlay:IQVTime:X[:SCALe]:AUTO:STATe	ON
DISPlay:IQVTime:X[:SCALe]:OFFSet	0
DISPlay:IQVTime:Y[:SCALe]	1 $\mu$ 0 V
DISPlay:IQVTime:Y[:SCALe]:OFFSet	0
<b>DISPlay:MCPower subgroup</b>	
DISPlay:MCPower:MARKer:SHOW:STATe	ON
DISPlay:MCPower:PLEVel:SHOW:STATe	ON
DISPlay:MCPower:WINDow:TRACe:GRATICule:GRID:STATe	ON
DISPlay:MCPower:X[:SCALe]	38.84 MHz
DISPlay:MCPower:X[:SCALe]:OFFSet	1.5 GHz
DISPlay:MCPower:Y[:SCALe]	100 dB

**Table C-4: Factory initialization settings, Display commands (cont.)**

<b>Header</b>	<b>Default value</b>
DISPlay:MCPower:Y[:SCALe]:OFFSet	0
<b>DISPlay:MERRor subgroup</b>	
DISPlay:MERRor:Y[:SCALe]	100%
DISPlay:MERRor:Y[:SCALe]:OFFSet	-100
<b>DISPlay:OBWidth subgroup</b>	
DISPlay:OBWidth:MARKer:SHOW:STATe	ON
DISPlay:OBWidth:SELEcted:BANDwidth	OBWidth
DISPlay:OBWidth:WINDow:TRACe:GRATicule:GRID:STATe	ON
DISPlay:OBWidth:X[:SCALe]:OFFSet	0
DISPlay:OBWidth:Y[:SCALe]	100 dB
DISPlay:OBWidth:Y[:SCALe]:OFFSet	0
<b>DISPlay:PERRor subgroup</b>	
DISPlay:PERRor:Y[:SCALe]	360 (degrees)
DISPlay:PERRor:Y[:SCALe]:OFFSet	-360
<b>DISPlay:PHVTime subgroup</b>	
DISPlay:PHVTime:WINDow:TRACe:GRATicule:GRID:STATe	ON
DISPlay:PHVTime:X[:SCALe]:AUTO:STATe	ON
DISPlay:PHVTime:X[:SCALe]:OFFSet	0
DISPlay:PHVTime:Y[:SCALe]	1°
DISPlay:PHVTime:Y[:SCALe]:AXIS	MODulopi
DISPlay:PHVTime:Y[:SCALe]:AXIS:REFerence	0
DISPlay:PHVTime:Y[:SCALe]:OFFSet	0
<b>DISPlay:PNOise subgroup</b>	
DISPlay:PNOise:MARKer:SHOW:STATe	ON
DISPlay:PNOise:WINDow:TRACe:GRATicule:GRID:STATe	ON
DISPlay:PNOise:X[:SCALe]:START	10 Hz
DISPlay:PNOise:X[:SCALe]:STOP	1 GHz
DISPlay:PNOise:Y[:SCALe]	100 dB
DISPlay:PNOise:Y[:SCALe]:OFFSet	-50 dBc/Hz
DISPlay:PNOise:Y[:SCALe]:PDIVision	10 dB
<b>DISPlay:PULSe subgroup</b>	
DISPlay:PULSe:RESult:ATX	OFF
DISPlay:PULSe:RESult:AVERAge	ON
DISPlay:PULSe:RESult:DROop	OFF
DISPlay:PULSe:RESult:DUTPct	OFF
DISPlay:PULSe:RESult:DUTRatio	OFF
DISPlay:PULSe:RESult:FALL	OFF



Table C-4: Factory initialization settings, Display commands (cont.)

Header	Default value
DISPlay:PULSe:RESult:FRDeviation	OFF
DISPlay:PULSe:RESult:MFRReqerror	OFF
DISPlay:PULSe:RESult:MPHerror	OFF
DISPlay:PULSe:RESult:PHDeviation	OFF
DISPlay:PULSe:RESult:PPFRequency	OFF
DISPlay:PULSe:RESult:PPOWer	OFF
DISPlay:PULSe:RESult:PPPHas	OFF
DISPlay:PULSe:RESult:RIPLe	OFF
DISPlay:PULSe:RESult:RMSFReqerror	OFF
DISPlay:PULSe:RESult:RMSPherror	OFF
DISPlay:PULSe:RESult:RRATe	OFF
DISPlay:PULSe:RESult:RInterval	OFF
DISPlay:PULSe:RESult:RISE	OFF
DISPlay:PULSe:RESult:TIME	OFF
DISPlay:PULSe:RESult:WIDTh	OFF
DISPlay:PULSe:SElect:NUMBer	0
DISPlay:PULSe:SElect:RESult	AVERAge
DISPlay:PULSe:STATistics:MARKer:SHOW:STATe	ON
DISPlay:PULSe:STATistics:PLOT	TREND
DISPlay:PULSe:STATistics:WINDow:TRACe:GRATICule:GRID:STATe	ON
DISPlay:PULSe:STATistics:X[:SCALe]:NUMBer	1
DISPlay:PULSe:STATistics:X[:SCALe]:OFFSet	0
DISPlay:PULSe:STATistics:Y[:SCALe]:OFFSet	0
DISPlay:PULSe:STATistics:Y[:SCALe]:FULL	100 dB
DISPlay:PULSe:STATistics:Y[:SCALe]:OFFSet	0
DISPlay:PULSe:TRACe:MARKer:SHOW:STATe	ON
DISPlay:PULSe:TRACe:POINt:SHOW	ON
DISPlay:PULSe:TRACe:WINDow:TRACe:GRATICule:GRID:STATe	ON
DISPlay:PULSe:TRACe:X[:SCALe]:FULL	SElected
DISPlay:PULSe:TRACe:X[:SCALe]:OFFSet	0
DISPlay:PULSe:TRACe:X[:SCALe]:PDIVision	10 $\mu$ s
DISPlay:PULSe:TRACe:Y[:SCALe]:FULL	100 dB
DISPlay:PULSe:TRACe:Y[:SCALe]:OFFSet	0
<b>DISPlay:SGRam subgroup</b>	
DISPlay:SGRam:TIME:OFFSet	0
DISPlay:SGRam:TIME:OVERlap	ON
DISPlay:SGRam:TIME:SCALE	0

Table C-4: Factory initialization settings, Display commands (cont.)

Header	Default value
<b>DISPlay:SPECtrum subgroup</b>	
DISPlay:SPECtrum:FREQUency:OFFSet	1.5 GHz
DISPlay:SPECtrum:FREQUency[:SCAle]	40 MHz
DISPlay:SPECtrum:MARKer:NOISe:MODE	OFF
DISPlay:SPECtrum:SCAle:LOG:STATe	OFF
DISPlay:SPECtrum:WINDow:TRACe:GRATICule:GRID:STATe	ON
DISPlay:PNOise:LEGend:STATe	OFF
DISPlay:SPECtrum:X:LABel	CFSPan
DISPlay:SPECtrum:Y[:SCAle]:PDIVision	10 dB/div
<b>DISPlay:SPURious subgroup</b>	
DISPlay:SPURious:MARKer:SHOW:STATe	ON
DISPlay:SPURious:SCAle:LOG:STATe	OFF
DISPlay:SPURious:SElect:NUMBer	1
DISPlay:SPURious:SHOW:LIMit	SHADed
DISPlay:SPURious:WINDow:TRACe:GRATICule:GRID:STATe	ON
DISPlay:SPURious:X[:SCAle]:START	1.61 GHz
DISPlay:SPURious:X[:SCAle]:STOP	2.16 GHz
DISPlay:SPECtrum:Y[:SCAle]	100 dB
DISPlay:SPECtrum:Y[:SCAle]:OFFSet	0
<b>DISPlay:TDIagram subgroup</b>	
DISPlay:TDIagram:WINDow:TRACe:GRATICule:GRID:STATe	ON
<b>DISPlay:TOVerview subgroup</b>	
DISPlay:TOVerview:WINDow:TRACe:GRATICule:GRID:STATe	ON
DISPlay:TOVerview:X[:SCAle]:OFFSet	0
DISPlay:TOVerview:Y[:SCAle]	100 dB
DISPlay:TOVerview:Y[:SCAle]:OFFSet	0

Table C-5: Factory initialization settings, Initiate commands

Header	Default value
INITiate:CONTinuous	ON

Table C-6: Factory initialization settings, Input commands

Header	Default value
INPut[:RF]:ATTenuation	20 dB

Table C-6: Factory initialization settings, Input commands (cont.)

Header	Default value
INPut[:RF]:ATTenuation:AUTO	ON
INPut[:RF]:ATTenuation:MONitor:STATe	ON
INPut[:RF]:GAIN:STATe	OFF
INPut:{MLEVel RLEVel}	0 dBm

Table C-7: Factory initialization settings, Output commands

Header	Default value
OUTPut:IF:{BANDwidth BWIDth} (Option 05 only)	FLATop
OUTPut:IF[:STATe] (Option 05 only)	OFF
OUTPut:IQ[:STATe] (Option 05 only)	OFF
OUTPut:NOISe[:STATe]	OFF

Table C-8: Factory initialization settings, Sense commands

Header	Default value
<b>[SENSe] basic command subgroup</b>	
[SENSe]:ACQuisition:FFRame:LIMit	1
[SENSe]:ACQuisition:FFRame:STATe	OFF
[SENSe]:ACQuisition:MODE	AUTO
[SENSe]:ANALysis:ADVanced:DITHer	AUTO
[SENSe]:ANALysis:LENGth	7.44 $\mu$ s
[SENSe]:ANALysis:LENGth:AUTO	ON
[SENSe]:ANALysis:REFerence	ACQSTART
[SENSe]:ANALysis:STARt	0
[SENSe]:ANALysis:STARt:AUTO	ON
[SENSe]:POWER:UNITs	DBM
[SENSe]:ROSCillator:SOURce	INTernal
[SENSe]:SPECtrum:LENGth	7.44 $\mu$ s
[SENSe]:SPECtrum:LENGth:AUTO	ON
[SENSe]:SPECtrum:STARt	0
[SENSe]:SPECtrum:TIME:MODE	COMMOn
<b>[SENSe]:ACPower subgroup</b>	
[SENSe]:ACPower:AVERage	OFF
[SENSe]:ACPower:AVERage:COUNT	10
[SENSe]:ACPower:{BANDwidth BWIDth}{:RESolution}	30 kHz

Table C-8: Factory initialization settings, Sense commands (cont.)

Header	Default value
[SENSe]:ACPower:{BANDwidth BWIDth}{:RESolution}:AUTO	ON
[SENSe]:ACPower:{BANDwidth BWIDth}:VIDeo	300 kHz
[SENSe]:ACPower:{BANDwidth BWIDth}:VIDeo:STATe	OFF
[SENSe]:ACPower:CHANnel:{BANDwidth BWIDth}	3.84 MHz
[SENSe]:ACPower:CHANnel:FILTer	RRCosine
[SENSe]:ACPower:CHANnel:PAIRs	1
[SENSe]:ACPower:CHANnel:SPACing	5 MHz
[SENSe]:ACPower:CHIPrate	3.84 MHz
[SENSe]:ACPower:FREQuency	1.5 GHz
[SENSe]:ACPower:FREQuency:STEP	1 MHz
[SENSe]:ACPower:FREQuency:STEP:AUTO	ON
[SENSe]:ACPower:NFLoor:STATe	OFF
[SENSe]:ACPower:OPTimize:SPAN	DRANge
[SENSe]:ACPower:RRCRolloff	0.22
<b>[SENSe]:AM:FM:PM subgroup</b>	
[SENSe]:AM:DETECT:AMPLitude	AVERage
[SENSe]:{AM FM PM}:{MTPoints MAXTracepoints}	HUNDredk
[SENSe]:{FM PM}:BURSt:THReshold	-100 dBc
[SENSe]:{FM PM}:FREQuency:SEARch:AUTO	ON
[SENSe]:PM:PHASe:SEARch:AUTO	ON
<b>[SENSe]:AVTime subgroup</b>	
[SENSe]:AVTime:{BANDwidth BWIDth}	1 MHz
[SENSe]:AVTime:MAXTracepoints	HUNDredk
[SENSe]:AVTime:METHod	SPAN
[SENSe]:AVTime:SPAN	40 MHz
<b>[SENSe]:CCDF subgroup</b>	
[SENSe]:CCDF:{BANDwidth BWIDth}	40 MHz
[SENSe]:CCDF:TIME:TYPE	SINGLE
<b>[SENSe]:DDEMod subgroup</b>	
[SENSe]:DDEMod:ANALysis:LENGth	128 symbols
[SENSe]:DDEMod:ANALysis:LENGth:AUTO	ON
[SENSe]:DDEMod:BURSt:DETECT	OFF
[SENSe]:DDEMod:BURSt:THReshold	-20 dBc
[SENSe]:DDEMod:CARRier:OFFSet	0
[SENSe]:DDEMod:FILTer:ALPHa	0.22
[SENSe]:DDEMod:FILTer:MEASurement	RRCosine
[SENSe]:DDEMod:FILTer:REFerence	RCOSine

Table C-8: Factory initialization settings, Sense commands (cont.)

Header	Default value
[SENSe]:DDEMod:FREQuency:DEViation:AUTO	ON
[SENSe]:DDEMod:MAGNitude:NORMAlize	RSYMBol
[SENSe]:DDEMod:MINDEX	1
[SENSe]:DDEMod:MINDEX:AUTO	ON
[SENSe]:DDEMod:MODulation:TYPE	QPSK
[SENSe]:DDEMod:SRATe	3.84 MHz
[SENSe]:DDEMod:SWAP:IQ	OFF
[SENSe]:DDEMod:SYMBOL:MAP[:STATe]	OFF
[SENSe]:DDEMod:SYMBOL:POINTS	FOUR
[SENSe]:DDEMod:SYNCh:WORD	OFF
[SENSe]:DDEMod:SYNCh:WORD:SYMBOL	#10
[SENSe]:DDEMod:TIME:UNITs	SYMBOLs
<b>[SENSe]:DPSA subgroup</b>	
[SENSe]:DPSA:AUDIO:DEMod:GAIN	3
[SENSe]:DPSA:AUDIO:DEMod:RXBWidth	30 kHz
[SENSe]:DPSA:AUDIO:DEMod:STATe	OFF
[SENSe]:DPSA:AUDIO:DEMod:TUNE	SMARker
[SENSe]:DPSA:AUDIO:DEMod:TYPE	FM
[SENSe]:DPSA:{BANDwidth BWIDTH}:ACTual?	400 kHz
[SENSe]:DPSA:FREQuency:SPAN:{BANDwidth BWIDTH}[:RESolution]:RATIo	ON
[SENSe]:DPSA:COLor	TEMPerature
[SENSe]:DPSA:COLor:MAXimum	100%
[SENSe]:DPSA:POINTS:COUNT	0%
[SENSe]:DPSA:FREQuency:CENTer	1.5 GHz
[SENSe]:DPSA:FREQuency:SPAN	40 MHz
[SENSe]:DPSA:FREQuency:STARt	1.48 GHz
[SENSe]:DPSA:FREQuency:STEP	2 MHz
[SENSe]:DPSA:FREQuency:STEP:AUTO	ON
[SENSe]:DPSA:FREQuency:STOP	1.52 GHz
<b>[SENSe]:FVTime subgroup</b>	
[SENSe]:FVTime:FREQuency:CENTer	1.5 GHz
[SENSe]:FVTime:FREQuency:SPAN	40 MHz
[SENSe]:FVTime:FREQuency:STARt	1.48 GHz
[SENSe]:FVTime:FREQuency:STEP	2 MHz
[SENSe]:FVTime:FREQuency:STEP:AUTO	ON
[SENSe]:FVTime:FREQuency:STOP	1.52 GHz

Table C-8: Factory initialization settings, Sense commands (cont.)

Header	Default value
[SENSe]:FVTime:MAXTracepoints	HUNDredk
<b>[SENSe]:IQVTime subgroup</b>	
[SENSe]:IQVTime:FREQuency:CENTer	1.5 GHz
[SENSe]:IQVTime:FREQuency:SPAN	40 MHz
[SENSe]:IQVTime:FREQuency:START	1.48 GHz
[SENSe]:IQVTime:FREQuency:STEP	2 MHz
[SENSe]:IQVTime:FREQuency:STEP:AUTO	ON
[SENSe]:IQVTime:FREQuency:STOP	1.52 GHz
[SENSe]:IQVTime:MAXTracepoints	HUNDredk
<b>[SENSe]:MCPower subgroup</b>	
[SENSe]:MCPower:AVERAge	OFF
[SENSe]:MCPower:AVERAge:COUNT	10
[SENSe]:MCPower:{BANDwidth BWIDth}{:RESolution}	30 kHz
[SENSe]:MCPower:{BANDwidth BWIDth}{:RESolution}:ACTual?	ON
[SENSe]:MCPower:{BANDwidth BWIDth}{:RESolution}:AUTO	300 kHz
[SENSe]:MCPower:{BANDwidth BWIDth}:VIDeo	OFF
[SENSe]:MCPower:{BANDwidth BWIDth}:VIDeo:STATe	3.84 MHz
[SENSe]:MCPower:CHANnel:FILTer	RRCosine
[SENSe]:MCPower:CHANnel:MAIN:{BANDwidth BWIDth}	3.84 MHz
[SENSe]:MCPower:CHANnel:MAIN:COUNT	4
[SENSe]:MCPower:CHANnel:MAIN:INACTive	NONE
[SENSe]:MCPower:CHANnel:MAIN:SPACing	5 MHz
[SENSe]:MCPower:CHIPrate	3.84 MHz
[SENSe]:MCPower:FREQuency	1.5 GHz
[SENSe]:MCPower:FREQuency:STEP	2 MHz
[SENSe]:MCPower:FREQuency:STEP:AUTO	ON
[SENSe]:MCPower:NFLoor:STATe	OFF
[SENSe]:MCPower:OPTimize:SPAN	DRANge
[SENSe]:MCPower:RRCRolloff	0.22
<b>[SENSe]:OBWidth subgroup</b>	
[SENSe]:OBWidth:AVERAge	OFF
[SENSe]:OBWidth:AVERAge:COUNT	10
[SENSe]:OBWidth:{BANDwidth BWIDth}:MEASurement	10 MHz
[SENSe]:OBWidth:{BANDwidth BWIDth}{:RESolution}	33 kHz
[SENSe]:OBWidth:{BANDwidth BWIDth}{:RESolution}:AUTO	ON
[SENSe]:OBWidth:{BANDwidth BWIDth}:VIDeo	300 kHz
[SENSe]:OBWidth:{BANDwidth BWIDth}:VIDeo:STATe	OFF

Table C-8: Factory initialization settings, Sense commands (cont.)

Header	Default value
[SENSe]:OBWidth:FREQUency:CENTer	1.5 GHz
[SENSe]:OBWidth:FREQUency:STEP	2 MHz
[SENSe]:OBWidth:FREQUency:STEP:AUTO	ON
[SENSe]:OBWidth:PERCent	99%
[SENSe]:OBWidth:XDBLevel	-26 dB
<b>[SENSe]:PHVTime subgroup</b>	
[SENSe]:PHVTime:FREQUency:CENTer	1.5 GHz
[SENSe]:PHVTime:FREQUency:SPAN	40 MHz
[SENSe]:PHVTime:FREQUency:STARt	1.48 GHz
[SENSe]:PHVTime:FREQUency:STEP	2 MHz
[SENSe]:PHVTime:FREQUency:STEP:AUTO	ON
[SENSe]:PHVTime:FREQUency:STOP	1.52 GHz
[SENSe]:PHVTime:MAXTracepoints	HUNDredk
<b>[SENSe]:PNOise subgroup</b>	
[SENSe]:PNOise:AVERAge:COUNT	10
[SENSe]:PNOise:AVERAge:ENABle	OFF
[SENSe]:PNOise:CARRier:FREQUency:TRACK	ON
[SENSe]:PNOise:CARRier:THReshold	-26 dBm
[SENSe]:PNOise:FREQUency:INTegration:OFFSet:STARt	100 Hz
[SENSe]:PNOise:FREQUency:INTegration:OFFSet:STOP	10 MHz
[SENSe]:PNOise:FREQUency:PLOT:OFFSet:STARt	10 Hz
[SENSe]:PNOise:FREQUency:PLOT:OFFSet:STOP	100 MHz
[SENSe]:PNOise:OPTimization	SPEEd
<b>[SENSe]:PULSe subgroup</b>	
[SENSe]:PULSe:ANALyze:LEVel	VOLTage
[SENSe]:PULSe:ANALyze:LEVel:FIFTy	VOLTage
[SENSe]:PULSe:ANALyze:LEVel:HUNDred	AVERAge
[SENSe]:PULSe:ANALyze:MEASurement:TIME:AUTO	ON
[SENSe]:PULSe:ANALyze:MEASurement:TIME:STARt	0
[SENSe]:PULSe:ANALyze:MEASurement:TIME:STOP	0
[SENSe]:PULSe:ANALyze:PMLocation	500 ns
[SENSe]:PULSe:ANALyze:POINt:LOCation	AVERAge
[SENSe]:PULSe:ANALyze:RFALI	WIDE
[SENSe]:PULSe:ANALyze:RIPPlE	50%
[SENSe]:PULSe:CARRier:OFFSet	0
[SENSe]:PULSe:CARRier:SEARCh	AUTO
[SENSe]:PULSe:DETECT:MEASurement	OFF

**Table C-8: Factory initialization settings, Sense commands (cont.)**

<b>Header</b>	<b>Default value</b>
[SENSe]:PULSe:DETECT:NUMBER	100
[SENSe]:PULSe:DETECT:POWER[:THRESHOLD]	-10 dBc
[SENSe]:PULSe:DETECT:TIME[:THRESHOLD]	1 ns
[SENSe]:PULSe:FILTer:{BANDwidth BWIDth}	20 MHz (Standard), 60 MHz (Option 110)
[SENSe]:PULSe:FILTer:MEASUREMENT	GAUSSIAN
[SENSe]:PULSe:FREFerence:AUTO	ON
[SENSe]:PULSe:FREFerence:CHIRPbw	1 MHz
[SENSe]:PULSe:FREFerence:OFFSet	0
[SENSe]:PULSe:MODulation:TYPE	CWConst
[SENSe]:PULSe:SIGNAL:TYPE	CWConst
<b>[SENSe]:SGRam subgroup</b>	
[SENSe]:SGRam:{BANDwidth BWIDth}:OPTimization	AUTO
[SENSe]:SGRam:{BANDwidth BWIDth}:RESolution	300 kHz
[SENSe]:SGRam:{BANDwidth BWIDth}[:RESolution]:AUTO	ON
[SENSe]:SGRam:{BANDwidth BWIDth}[:RESolution]:MODE	ON
[SENSe]:SGRam:{BANDwidth BWIDth}:VIDeo	300 kHz
[SENSe]:SGRam:{BANDwidth BWIDth}:VIDeo:STATE	OFF
[SENSe]:SGRam:COLor	TEMPerature
[SENSe]:SGRam:COLor:MAXimum	0 dBm
[SENSe]:SGRam:COLor:MINimum	-100 dBm
[SENSe]:SGRam:FFT:WINDow	KAISer
[SENSe]:SGRam:FILTer[:SHAPE]	KAISer
[SENSe]:SGRam:FREQuency:CENTer	1.5 GHz
[SENSe]:SGRam:FREQuency:SPAN	40 MHz
[SENSe]:SGRam:FREQuency:SPAN:BANDwidth[:RESolution]:RATio	100
[SENSe]:SGRam:FREQuency:START	1.48 GHz
[SENSe]:SGRam:FREQuency:STEP	2 MHz
[SENSe]:SGRam:FREQuency:STEP:AUTO	ON
[SENSe]:SGRam:FREQuency:STOP	1.52 GHz
<b>[SENSe]:SPECTrum subgroup</b>	
[SENSe]:SPECTrum:{BANDwidth BWIDth}:OPTimization	AUTO
[SENSe]:SPECTrum:{BANDwidth BWIDth}[:RESolution]	300 kHz
[SENSe]:SPECTrum:{BANDwidth BWIDth}[:RESolution]:AUTO	ON
[SENSe]:SPECTrum:{BANDwidth BWIDth}[:RESolution]:MODE	ON



Table C-8: Factory initialization settings, Sense commands (cont.)

Header	Default value
[SENSe]:SPECTrum:{BANDwidth BWIDth}:VIDeo	300 kHz
[SENSe]:SPECTrum:{BANDwidth BWIDth}:VIDeo:STATe	OFF
[SENSe]:SPECTrum:FFT:WINDow	KAISeR
[SENSe]:SPECTrum:FILTer[:SHAPE]	KAISeR
[SENSe]:SPECTrum:FREQuency:CENTer	1.5 GHz
[SENSe]:SPECTrum:FREQuency:SPAN	40 MHz
[SENSe]:SPECTrum:FREQuency:SPAN:BANDwidth[:RESolution]:RATio	100
[SENSe]:SPECTrum:FREQuency:START	1.48 GHz
[SENSe]:SPECTrum:FREQuency:STEP	2 MHz
[SENSe]:SPECTrum:FREQuency:STEP:AUTO	ON
[SENSe]:SPECTrum:FREQuency:STOP	1.52 GHz
[SENSe]:SPECTrum:POINts:COUNT	P801
<b>[SENSe]:SPURious subgroup</b>	
[SENSe]:SPURious:CARRier:{BANDwidth BWIDth}	4 MHz
[SENSe]:SPURious:CARRier:{BANDwidth BWIDth}:INTegration	1 MHz
[SENSe]:SPURious:CARRier:{BANDwidth BWIDth}[:RESolution]:AUTO	ON
[SENSe]:SPURious:CARRier:DETection	PEAK
[SENSe]:SPURious:CARRier:FREQuency	1.484 GHz
[SENSe]:SPURious:CARRier:THReshold	-10 dBm
[SENSe]:SPURious:LIST	OVERlimit
[SENSe]:SPURious:MODE	MULTi
[SENSe]:SPURious:OPTimization	AUTO
[SENSe]:SPURious:POINts:COUNT	P801
[SENSe]:SPURious:RANGe<x>:BANDwidth:VIDeo	300 kHz
[SENSe]:SPURious:RANGe<x>:BANDwidth:VIDeo:STATe	OFF
[SENSe]:SPURious:RANGe<x>:DETection	PEAK
[SENSe]:SPURious:RANGe<x>:EXCursion	6 dB
[SENSe]:SPURious:RANGe<x>:FILTer[:SHAPE]	RBW
[SENSe]:SPURious:RANGe<x>:FILTer[:SHAPE]:BANDwidth	200 kHz
[SENSe]:SPURious:RANGe<x>:FILTer[:SHAPE]:BANDwidth:AUTO	ON
[SENSe]:SPURious:RANGe<x>:LIMit:ABSolute:START	-50 dBm
[SENSe]:SPURious:RANGe<x>:LIMit:ABSolute:STOP	-50 dBm
[SENSe]:SPURious:RANGe<x>:LIMit:MASK	ABS
[SENSe]:SPURious:RANGe<x>:LIMit:RELative:START	-30 dB
[SENSe]:SPURious:RANGe<x>:LIMit:RELative:STOP	-30 dB

Table C-8: Factory initialization settings, Sense commands (cont.)

Header	Default value
[SENSe]:SPURious:RANGe<x>:STATe	<x>=1: ON <x>=2 to 20: OFF
[SENSe]:SPURious:REFerence	NONE
[SENSe]:SPURious:REFerence:MANual:POWer	-10 dBm
<b>[SENSe]:TOVerview subgroup</b>	
[SENSe]:TOVerview:FREQuency:CENTer	1.5 GHz
[SENSe]:TOVerview:MAXTracepoints	HUNDredk

Table C-9: Factory initialization settings, Trace commands

Header	Default value
<b>TRACe:{AM FM PM} subgroup</b>	
TRACe:{AM FM PM}	ON
TRACe<x>:AVTime:DETection	POSitive
TRACe:{AM FM PM}:FREeze	OFF
TRACe:{AM FM PM}:FUNCTion	NORMal
<b>TRACe&lt;x&gt;:AVTime subgroup</b>	
TRACe<x>:AVTime	<x>=1: ON <x>=2 to 4: OFF
TRACe<x>:AVTime:AVERage:COUNT	10
TRACe<x>:AVTime:COUNT	10
TRACe<x>:AVTime:COUNT:ENABLE	ON
TRACe<x>:AVTime:FREeze	OFF
TRACe<x>:AVTime:FUNCTion	NORMal
TRACe<x>:AVTime:LEFToperand	TRACE2
TRACe<x>:AVTime:RIGHToperand	TRACE1
<b>TRACe&lt;x&gt;:CCDF subgroup</b>	
TRACe<x>:CCDF:FREeze	OFF
TRACe<x>:CCDF:SHOW	<x>=1: ON <x>=2 and 3: OFF
TRACe<x>:CCDF:X	3 dB
<b>TRACe:CONSte subgroup</b>	
TRACe:CONSte:MODE	VECTors
<b>TRACe:DIQVtime subgroup</b>	
TRACe:DIQVtime:ENABLE:I	ON
TRACe:DIQVtime:ENABLE:Q	ON
<b>TRACe&lt;x&gt;:DPSA subgroup</b>	

Table C-9: Factory initialization settings, Trace commands (cont.)

Header	Default value
TRACe<x>:DPSA	<x>=1 and 5: ON <x>=2 to 4: OFF
TRACe<x>:DPSA:AVERAge:COUNT	10
TRACe<x>:DPSA:COLor:CURVe	25 %
TRACe<x>:DPSA:DOT:PERsistent	(<x>=5 only) ON
TRACe<x>:DPSA:DOT:PERsistent:TYPE	(<x>=5 only) VARiable
TRACe<x>:DPSA:DOT:PERsistent:VARiable	(<x>=5 only) 10
TRACe<x>:DPSA:FREeze	OFF
TRACe<x>:DPSA:DETection	NORMal
TRACe<x>:DPSA:LEFTooperand	TRACE1
TRACe<x>:DPSA:RIGHTooperand	TRACE3
<b>TRACe:EDlagram subgroup</b>	
TRACe:EDlagram:ENABle:I	ON
TRACe:EDlagram:ENABle:Q	ON
<b>TRACe:FVTime subgroup</b>	
TRACe:FVTime:COUNT	10
TRACe:FVTime:COUNT:ENABle	ON
TRACe:FVTime:FREeze	OFF
TRACe:FVTime:FUNCTion	NORMal
<b>TRACe:IQVTime subgroup</b>	
TRACe:IQVTime:COUNT	10
TRACe:IQVTime:DETection	ON
TRACe:IQVTime:ENABle:I	ON
TRACe:IQVTime:ENABle:Q	ON
TRACe:IQVTime:FREeze	OFF
TRACe:IQVTime:FUNCTion	NORMal
TRACe:IQVTime:SElect:I	ON
TRACe:IQVTime:SElect:Q	OFF
<b>TRACe:OBWidth subgroup</b>	
TRACe:OBW:MAXHold	OFF
<b>TRACe:PHVTime subgroup</b>	
TRACe:PHVTime:COUNT	10
TRACe:PHVTime:COUNT:ENABle	ON
TRACe:PHVTime:FREeze	OFF
TRACe:PHVTime:FUNCTion	NORMal
<b>TRACe&lt;x&gt;:PNOise subgroup</b>	

**Table C-9: Factory initialization settings, Trace commands (cont.)**

Header	Default value
TRACe<x>:PNOise:SHOW	<x>=1: ON <x>=2: OFF
TRACe<x>:PNOise:SMOothing:COUNT	5
TRACe<x>:PNOise:SMOothing:ENABle	ON
<b>TRACe:SGRam subgroup</b>	
TRACe<x>:PHVTime:DETectiOn	POSitive
TRACe:SGRam:FREeze	OFF
TRACe:SGRam:FUNCTiOn	NONE
TRACe:SGRam:FUNCTiOn:TIME	0.02 minutes
TRACe:SGRam:SELect:LINE	0
<b>TRACe&lt;x&gt;:SPECtrum subgroup</b>	
TRACe<x>:SPECtrum	<x>=1: ON <x>=2 to 4: OFF
TRACe<x>:SPECtrum:AVERAge:COUNT	10
TRACe<x>:SPECtrum:COUNT	10
TRACe<x>:SPECtrum:COUNT:ENABle	ON
TRACe<x>:SPECtrum:DETectiOn	POSitive
TRACe<x>:SPECtrum:FREeze	OFF
TRACe<x>:SPECtrum:FUNCTiOn	NONE
TRACe<x>:SPECtrum:LEFTopeRand	TRACE2
TRACe<x>:SPECtrum:RIghTopeRand	TRACE1
<b>TRACe:SPURious subgroup</b>	
TRACe:SPURious:COUNT	10
TRACe:SPURious:COUNT:ENABle	ON
TRACe1:TOVerview:COUNT:RESet	OFF
TRACe:SPURious:FUNCTiOn	NONE

**Table C-10: Factory initialization settings, Trigger commands**

Header	Default value
TRIGger:DPSA:SHOW:FRAMES	OFF
TRIGger[:SEQuence]:EVENT:EXTFront:IMPedance	5 kΩ
TRIGger[:SEQuence]:EVENT:EXTFront:LEVel	1.6 V
TRIGger[:SEQuence]:EVENT:EXTFront:SLOPe	RISe
TRIGger[:SEQuence]:EVENT:GATed	HIGH
TRIGger[:SEQuence]:EVENT:INPut:FMASk:BANDwidth BWIDth[:RESolution]:ACTual?	FT

Table C-10: Factory initialization settings, Trigger commands (cont.)

Header	Default value
TRIGger[:SEQuence]:EVENT:INPut:DDENsity:AMPLitude:TOLerance	-20 dBm
TRIGger[:SEQuence]:EVENT:INPut:RUNT:PULse:HIGh:LEVel	-10 dBm
TRIGger[:SEQuence]:EVENT:INPut:TDBWidth	1 MHz
TRIGger[:SEQuence]:EVENT:INPut:TDBWidth:STATe	ON
TRIGger[:SEQuence]:EVENT:INPut:TYPE	POWer
TRIGger[:SEQuence]:EVENT:SOURce	INPut
TRIGger[:SEQuence]:FORCed	OFF
TRIGger[:SEQuence]:TIME:QUALified:TIME<x>	OFF
TRIGger[:SEQuence]:ADVanced:HOLDoff:ENABle	0 s
TRIGger[:SEQuence]:TIME:POSition	25%

Table C-11: Factory initialization settings, UNIT commands

Header	Default value
UNIT:POWer	dBm



# Appendix D: SCPI Conformance Information

All commands for the RSA6100A Series analyzers are based on SCPI Version 1999.0. The following table lists the commands that are defined in the SCPI 1999.0 Standard. The other commands not listed in the table are not defined in the SCPI 1999.0 Standard.

**Table D-1: SCPI 1999.0-defined commands**

Command group	Command			
IEEE common	*CAL			
	*CLS			
	*ESE			
	*ESR			
	*IDN			
	*OPC			
	*OPT			
	*RST			
	*SRE			
	*STB			
	*TRG			
	*WAI			
ABORT	:ABORT			
INITiate	:INITiate	:CONTinuous		
		[:IMMediate]		
STATus	:STATus	:OPERation	:CONDition?	
			:ENABle	
		[:EVENT]?		
		:NTRansition		
		:PTRansition		
		:PRESet		
		:QUESTionable	:CONDition?	
			:ENABle	
			[:EVENT]?	
			:NTRansition	
:PTRansition				

**Table D-1: SCPI 1999.0-defined commands (cont.)**

<b>Command group</b>	<b>Command</b>	
<b>SYSTEM</b>	:SYSTEM :COMMunicate :GPIB [:SELF] :ADDRESS	
	:DATE	
	:ERRor :ALL?	
	:CODE :ALL?	
	:NEXT?	
	:COUNT?	
	:NEXT?	
	:PRESet	
	:TIME	
	:VERSion?	
	<b>UNIT</b>	:UNIT :POWER



---

# Glossary



---

# Glossary

**ASCII**

Acronym for the American Standard Code for Information Interchange. Controllers transmit commands to the instrument using ASCII character encoding.

**ASK**

Acronym for Amplitude Shift Keying. The process, or result of a process, in which the amplitude of the carrier is varied in accordance with the state of a digital input signal.

**BNF (Backus-Naur Form)**

A standard notation system for command syntax diagrams. The syntax diagrams in this manual use BNF notation.

**Controller**

A computer or other device that sends commands to and accepts responses from the analyzer.

**EVM (Error Vector Magnitude)**

The magnitude of an error of an actual signal relative to an ideal signal in a constellation display.

**GPIB**

Acronym for General Purpose Interface Bus, the common name for the communications interface system defined in IEEE Std 488.

**IEEE**

Acronym for the Institute for Electrical and Electronic Engineers.

**IS95**

Acronym for Interim Standard-95. The standards name for first-generation CDMA cellphone technology.

**Modulation**

The process of varying some characteristic of a signal with a second signal.

**PSK**

Acronym for Phase Shift Keying. The process, or result of a process, in which the carrier phase is varied discretely in accordance with a digital code.

**QAM**

Acronym for Quadrature Amplitude Modulation. The process, or result of a process, in which the amplitude and phase of the carrier are varied concurrently by synthesizing two orthogonal ASK waves (see ASK).



# Index

## A

ABORt, 2-75

## C

\*CAL, 2-75

Calculate Commands, 2-15

CALCulate:{AM|FM|PM}:MARKer<x>:DELTA:  
X?, 2-79

CALCulate:{AM|FM|PM}:MARKer<x>:DELTA:  
Y?, 2-80

CALCulate:{AM|FM|PM}:MARKer<x>:  
MAXimum, 2-81

CALCulate:{AM|FM|PM}:MARKer<x>:PEAK:  
HIGHer, 2-81

CALCulate:{AM|FM|PM}:MARKer<x>:PEAK:  
LEFT, 2-82

CALCulate:{AM|FM|PM}:MARKer<x>:PEAK:  
LOWer, 2-82

CALCulate:{AM|FM|PM}:MARKer<x>:PEAK:  
RIGHT, 2-83

CALCulate:{AM|FM|PM}:MARKer<x>:X, 2-83

CALCulate:{AM|FM|PM}:MARKer<x>:Y?, 2-84

CALCulate:ACPower:MARKer<x>:DELTA:X?, 2-76

CALCulate:ACPower:MARKer<x>:DELTA:Y?, 2-76

CALCulate:ACPower:MARKer<x>:MAXimum, 2-77

CALCulate:ACPower:MARKer<x>:PEAK:  
LEFT, 2-77

CALCulate:ACPower:MARKer<x>:PEAK:  
RIGHT, 2-78

CALCulate:ACPower:MARKer<x>:X, 2-78

CALCulate:ACPower:MARKer<x>:Y?, 2-79

CALCulate:AVTime:MARKer<x>:DELTA:X?, 2-84

CALCulate:AVTime:MARKer<x>:DELTA:Y?, 2-85

CALCulate:AVTime:MARKer<x>:MAXimum, 2-85

CALCulate:AVTime:MARKer<x>:PEAK:  
HIGHer, 2-86

CALCulate:AVTime:MARKer<x>:PEAK:LEFT, 2-86

CALCulate:AVTime:MARKer<x>:PEAK:  
LOWer, 2-87

CALCulate:AVTime:MARKer<x>:PEAK:  
RIGHT, 2-87

CALCulate:AVTime:MARKer<x>:TRACe, 2-88

CALCulate:AVTime:MARKer<x>:X, 2-88

CALCulate:AVTime:MARKer<x>:Y?, 2-89

CALCulate:CONStE:MARKer<x>:DELTA:X[:  
TIME]?, 2-89

CALCulate:CONStE:MARKer<x>:FDEVIation?, 2-90

CALCulate:CONStE:MARKer<x>:  
MAGNitude?, 2-91

CALCulate:CONStE:MARKer<x>:MAXimum, 2-91

CALCulate:CONStE:MARKer<x>:PEAK:LEFT, 2-92

CALCulate:CONStE:MARKer<x>:PEAK:  
RIGHT, 2-92

CALCulate:CONStE:MARKer<x>:PHASe?, 2-93

CALCulate:CONStE:MARKer<x>:SYMBOL?, 2-94

CALCulate:CONStE:MARKer<x>:VALue?, 2-94

CALCulate:CONStE:MARKer<x>:X, 2-95

CALCulate:DIQVtime:MARKer<x>:DELTA:X[:  
TIME]?, 2-95

CALCulate:DIQVtime:MARKer<x>:DELTA:Y?, 2-96

CALCulate:DIQVtime:MARKer<x>:  
MAXimum, 2-97

CALCulate:DIQVtime:MARKer<x>:PEAK:  
HIGHer, 2-97

CALCulate:DIQVtime:MARKer<x>:PEAK:  
LEFT, 2-98

CALCulate:DIQVtime:MARKer<x>:PEAK:  
LOWer, 2-98

CALCulate:DIQVtime:MARKer<x>:PEAK:  
RIGHT, 2-99

CALCulate:DIQVtime:MARKer<x>:TRACe, 2-99

CALCulate:DIQVtime:MARKer<x>:X[:  
TIME], 2-100

CALCulate:DIQVtime:MARKer<x>:Y?, 2-101

CALCulate:DPSA:MARKer<x>:DELTA:X:  
AMPLitude?, 2-101

CALCulate:DPSA:MARKer<x>:DELTA:X[:  
FREQuency]?, 2-102

CALCulate:DPSA:MARKer<x>:DELTA:Y?, 2-103

CALCulate:DPSA:MARKer<x>:MAXimum, 2-103

CALCulate:DPSA:MARKer<x>:PEAK:  
HIGHer, 2-104

CALCulate:DPSA:MARKer<x>:PEAK:LEFT, 2-104

CALCulate:DPSA:MARKer<x>:PEAK:  
LOWer, 2-105

CALCulate:DPSA:MARKer<x>:PEAK:RIGHT, 2-105

CALCulate:DPSA:MARKer<x>:TRACe, 2-106

- CALCulate:DPSA:MARKer<x>:X:  
AMPLitude, 2-107
- CALCulate:DPSA:MARKer<x>:X[:  
FREQuency], 2-108
- CALCulate:DPSA:MARKer<x>:Y?, 2-108
- CALCulate:DPSA:MARKer<x>[:SET]:  
CENTer, 2-106
- CALCulate:EDIagram:MARKer<x>:DELTA:X[:  
TIME]?, 2-109
- CALCulate:EDIagram:MARKer<x>:DELTA:  
Y?, 2-110
- CALCulate:EDIagram:MARKer<x>:  
MAXimum, 2-110
- CALCulate:EDIagram:MARKer<x>:PEAK:  
HIGHer, 2-111
- CALCulate:EDIagram:MARKer<x>:PEAK:  
LEFT, 2-111
- CALCulate:EDIagram:MARKer<x>:PEAK:  
LOWer, 2-112
- CALCulate:EDIagram:MARKer<x>:PEAK:  
RIGHT, 2-112
- CALCulate:EDIagram:MARKer<x>:TRACe, 2-113
- CALCulate:EDIagram:MARKer<x>:X[:  
TIME], 2-114
- CALCulate:EDIagram:MARKer<x>:Y?, 2-114
- CALCulate:EVM:MARKer<x>:DELTA:X?, 2-115
- CALCulate:EVM:MARKer<x>:DELTA:Y?, 2-115
- CALCulate:EVM:MARKer<x>:MAXimum, 2-116
- CALCulate:EVM:MARKer<x>:PEAK:  
HIGHer, 2-117
- CALCulate:EVM:MARKer<x>:PEAK:LEFT, 2-117
- CALCulate:EVM:MARKer<x>:PEAK:LOWer, 2-118
- CALCulate:EVM:MARKer<x>:PEAK:RIGHT, 2-118
- CALCulate:EVM:MARKer<x>:X, 2-119
- CALCulate:EVM:MARKer<x>:Y?, 2-119
- CALCulate:FDVTime:MARKer<x>:DELTA:X[:  
TIME]?, 2-120
- CALCulate:FDVTime:MARKer<x>:DELTA:  
Y?, 2-121
- CALCulate:FDVTime:MARKer<x>:  
MAXimum, 2-121
- CALCulate:FDVTime:MARKer<x>:PEAK:  
HIGHer, 2-122
- CALCulate:FDVTime:MARKer<x>:PEAK:  
LEFT, 2-122
- CALCulate:FDVTime:MARKer<x>:PEAK:  
LOWer, 2-123
- CALCulate:FDVTime:MARKer<x>:PEAK:  
RIGHT, 2-123
- CALCulate:FDVTime:MARKer<x>:X[:TIME], 2-124
- CALCulate:FDVTime:MARKer<x>:Y?, 2-124
- CALCulate:FVTime:MARKer<x>:DELTA:X?, 2-125
- CALCulate:FVTime:MARKer<x>:DELTA:Y?, 2-125
- CALCulate:FVTime:MARKer<x>:MAXimum, 2-126
- CALCulate:FVTime:MARKer<x>:PEAK:  
HIGHer, 2-126
- CALCulate:FVTime:MARKer<x>:PEAK:  
LEFT, 2-127
- CALCulate:FVTime:MARKer<x>:PEAK:  
LOWer, 2-127
- CALCulate:FVTime:MARKer<x>:PEAK:  
RIGHT, 2-128
- CALCulate:FVTime:MARKer<x>:X, 2-128
- CALCulate:FVTime:MARKer<x>:Y?, 2-129
- CALCulate:IQVTime:MARKer<x>:DELTA:X?, 2-130
- CALCulate:IQVTime:MARKer<x>:DELTA:Y?, 2-130
- CALCulate:IQVTime:MARKer<x>:  
MAXimum, 2-131
- CALCulate:IQVTime:MARKer<x>:PEAK:  
HIGHer, 2-131
- CALCulate:IQVTime:MARKer<x>:PEAK:  
LEFT, 2-132
- CALCulate:IQVTime:MARKer<x>:PEAK:  
LOWer, 2-132
- CALCulate:IQVTime:MARKer<x>:PEAK:  
RIGHT, 2-133
- CALCulate:IQVTime:MARKer<x>:TRACe, 2-133
- CALCulate:IQVTime:MARKer<x>:X, 2-134
- CALCulate:IQVTime:MARKer<x>:Y?, 2-134
- CALCulate:MARKer:ADD, 2-135
- CALCulate:MARKer:AOff, 2-135
- CALCulate:MARKer:DELeTe, 2-136
- CALCulate:MARKer:DENSity:EXCursion, 2-136
- CALCulate:MARKer:DENSity:SMOothing, 2-137
- CALCulate:MARKer:DENSity:THReShold, 2-138
- CALCulate:MARKer:MODE, 2-138
- CALCulate:MARKer:PEAK:EXCursion, 2-139
- CALCulate:MARKer:PEAK:THReShold, 2-139
- CALCulate:MCPower:MARKer<x>:DELTA:  
X?, 2-140
- CALCulate:MCPower:MARKer<x>:DELTA:  
Y?, 2-140
- CALCulate:MCPower:MARKer<x>:  
MAXimum, 2-141

- CALCulate:MCPower:MARKer<x>:PEAK:  
LEFT, 2-141
- CALCulate:MCPower:MARKer<x>:PEAK:  
RIGHT, 2-142
- CALCulate:MCPower:MARKer<x>:X, 2-142
- CALCulate:MCPower:MARKer<x>:Y?, 2-143
- CALCulate:MERRor:MARKer<x>:DELTA:X?, 2-143
- CALCulate:MERRor:MARKer<x>:DELTA:Y?, 2-144
- CALCulate:MERRor:MARKer<x>:  
MAXimum, 2-145
- CALCulate:MERRor:MARKer<x>:PEAK:  
HIGHer, 2-145
- CALCulate:MERRor:MARKer<x>:PEAK:  
LEFT, 2-146
- CALCulate:MERRor:MARKer<x>:PEAK:  
LOWer, 2-146
- CALCulate:MERRor:MARKer<x>:PEAK:  
RIGHT, 2-147
- CALCulate:MERRor:MARKer<x>:X, 2-147
- CALCulate:MERRor:MARKer<x>:Y?, 2-148
- CALCulate:OBWidth:MARKer<x>:DELTA:X?, 2-148
- CALCulate:OBWidth:MARKer<x>:DELTA:Y?, 2-149
- CALCulate:OBWidth:MARKer<x>:  
MAXimum, 2-150
- CALCulate:OBWidth:MARKer<x>:PEAK:  
HIGHer, 2-150
- CALCulate:OBWidth:MARKer<x>:PEAK:  
LEFT, 2-151
- CALCulate:OBWidth:MARKer<x>:PEAK:  
LOWer, 2-151
- CALCulate:OBWidth:MARKer<x>:PEAK:  
RIGHT, 2-152
- CALCulate:OBWidth:MARKer<x>:X, 2-153
- CALCulate:OBWidth:MARKer<x>:Y?, 2-153
- CALCulate:OBWidth:MARKer<x>[:SET]:  
CENTer, 2-152
- CALCulate:PERRor:MARKer<x>:DELTA:X?, 2-154
- CALCulate:PERRor:MARKer<x>:DELTA:Y?, 2-154
- CALCulate:PERRor:MARKer<x>:MAXimum, 2-155
- CALCulate:PERRor:MARKer<x>:PEAK:  
HIGHer, 2-155
- CALCulate:PERRor:MARKer<x>:PEAK:  
LEFT, 2-156
- CALCulate:PERRor:MARKer<x>:PEAK:  
LOWer, 2-156
- CALCulate:PERRor:MARKer<x>:PEAK:  
RIGHT, 2-157
- CALCulate:PERRor:MARKer<x>:X, 2-157
- CALCulate:PERRor:MARKer<x>:Y?, 2-158
- CALCulate:PHVTime:MARKer<x>:DELTA:  
X?, 2-158
- CALCulate:PHVTime:MARKer<x>:DELTA:  
Y?, 2-159
- CALCulate:PHVTime:MARKer<x>:  
MAXimum, 2-160
- CALCulate:PHVTime:MARKer<x>:PEAK:  
HIGHer, 2-160
- CALCulate:PHVTime:MARKer<x>:PEAK:  
LEFT, 2-161
- CALCulate:PHVTime:MARKer<x>:PEAK:  
LOWer, 2-161
- CALCulate:PHVTime:MARKer<x>:PEAK:  
RIGHT, 2-162
- CALCulate:PHVTime:MARKer<x>:X, 2-162
- CALCulate:PHVTime:MARKer<x>:Y?, 2-163
- CALCulate:PULSe:STATistics:MARKer<x>:DELTA:  
X?, 2-163
- CALCulate:PULSe:STATistics:MARKer<x>:DELTA:  
Y?, 2-164
- CALCulate:PULSe:STATistics:MARKer<x>:  
MAXimum, 2-164
- CALCulate:PULSe:STATistics:MARKer<x>:PEAK:  
HIGHer, 2-165
- CALCulate:PULSe:STATistics:MARKer<x>:PEAK:  
LEFT, 2-165
- CALCulate:PULSe:STATistics:MARKer<x>:PEAK:  
LOWer, 2-166
- CALCulate:PULSe:STATistics:MARKer<x>:PEAK:  
RIGHT, 2-166
- CALCulate:PULSe:STATistics:MARKer<x>:  
X, 2-167
- CALCulate:PULSe:STATistics:MARKer<x>:  
Y?, 2-167
- CALCulate:PULSe:TRACe:MARKer<x>:DELTA:  
X?, 2-168
- CALCulate:PULSe:TRACe:MARKer<x>:DELTA:  
Y?, 2-169
- CALCulate:PULSe:TRACe:MARKer<x>:  
MAXimum, 2-169
- CALCulate:PULSe:TRACe:MARKer<x>:PEAK:  
HIGHer, 2-170
- CALCulate:PULSe:TRACe:MARKer<x>:PEAK:  
LEFT, 2-170

- CALCulate:PULSe:TRACe:MARKer<x>:PEAK:  
LOWer, 2-171
- CALCulate:PULSe:TRACe:MARKer<x>:PEAK:  
RIGHt, 2-171
- CALCulate:PULSe:TRACe:MARKer<x>:X, 2-172
- CALCulate:PULSe:TRACe:MARKer<x>:Y?, 2-172
- CALCulate:SEARCh:LIMit:FAIL?, 2-173
- CALCulate:SEARCh:LIMit:MATCH:BEEP[:  
STATE], 2-173
- CALCulate:SEARCh:LIMit:MATCH:SACQuire[:  
STATE], 2-174
- CALCulate:SEARCh:LIMit:MATCH:SDATa[:  
STATE], 2-174
- CALCulate:SEARCh:LIMit:MATCH:SPICture[:  
STATE], 2-175
- CALCulate:SEARCh:LIMit:MATCH:STRace[:  
STATE], 2-176
- CALCulate:SEARCh:LIMit:OPERation, 2-176
- CALCulate:SEARCh:LIMit:OPERation:FEED, 2-177
- CALCulate:SEARCh:LIMit:OPERation:MASK:  
LOAD, 2-178
- CALCulate:SEARCh:LIMit:OPERation:MASK:  
STORE, 2-179
- CALCulate:SEARCh:LIMit:OPERation:  
SLIMit, 2-179
- CALCulate:SEARCh:LIMit:REPort:DATA?, 2-180
- CALCulate:SEARCh:LIMit:REPort:POINts?, 2-180
- CALCulate:SEARCh:LIMit:STATE, 2-181
- CALCulate:SGRam:MARKer<x>:DELTA:X:  
FREQuency?, 2-181
- CALCulate:SGRam:MARKer<x>:DELTA:X[:  
TIME]?, 2-182
- CALCulate:SGRam:MARKer<x>:DELTA:Y?, 2-182
- CALCulate:SGRam:MARKer<x>:MAXimum, 2-183
- CALCulate:SGRam:MARKer<x>:PEAK:  
HIGHer, 2-183
- CALCulate:SGRam:MARKer<x>:PEAK:  
LEFT, 2-184
- CALCulate:SGRam:MARKer<x>:PEAK:  
LOWer, 2-184
- CALCulate:SGRam:MARKer<x>:PEAK:  
RIGHt, 2-185
- CALCulate:SGRam:MARKer<x>:X:  
FREQuency, 2-186
- CALCulate:SGRam:MARKer<x>:X[:TIME], 2-186
- CALCulate:SGRam:MARKer<x>:Y?, 2-187
- CALCulate:SGRam:MARKer<x>[:SET]:  
CENTer, 2-185
- CALCulate:SPECtrum:MARKer<x>:DELTA:  
X?, 2-187
- CALCulate:SPECtrum:MARKer<x>:DELTA:  
Y?, 2-188
- CALCulate:SPECtrum:MARKer<x>:  
MAXimum, 2-189
- CALCulate:SPECtrum:MARKer<x>:PEAK:  
HIGHer, 2-189
- CALCulate:SPECtrum:MARKer<x>:PEAK:  
LEFT, 2-189
- CALCulate:SPECtrum:MARKer<x>:PEAK:  
LOWer, 2-190
- CALCulate:SPECtrum:MARKer<x>:PEAK:  
RIGHt, 2-190
- CALCulate:SPECtrum:MARKer<x>:TRACe, 2-191
- CALCulate:SPECtrum:MARKer<x>:X, 2-192
- CALCulate:SPECtrum:MARKer<x>:Y?, 2-193
- CALCulate:SPECtrum:MARKer<x>[:SET]:  
CENTer, 2-191
- CALCulate:SPURious:MARKer<x>:DELTA:  
X?, 2-193
- CALCulate:SPURious:MARKer<x>:DELTA:  
Y?, 2-194
- CALCulate:SPURious:MARKer<x>:  
MAXimum, 2-194
- CALCulate:SPURious:MARKer<x>:PEAK:  
HIGHer, 2-195
- CALCulate:SPURious:MARKer<x>:PEAK:  
LEFT, 2-195
- CALCulate:SPURious:MARKer<x>:PEAK:  
LOWer, 2-196
- CALCulate:SPURious:MARKer<x>:PEAK:  
RIGHt, 2-196
- CALCulate:SPURious:MARKer<x>:X, 2-197
- CALCulate:SPURious:MARKer<x>:Y?, 2-197
- CALCulate:SPURious:MARKer<x>[:SET]:  
CENTer, 2-196
- CALCulate:TDIagram:MARKer<x>:DELTA:X[:  
TIME]?, 2-198
- CALCulate:TDIagram:MARKer<x>:DELTA:  
Y?, 2-198
- CALCulate:TDIagram:MARKer<x>:  
MAXimum, 2-199
- CALCulate:TDIagram:MARKer<x>:PEAK:  
HIGHer, 2-200



CALCulate:TDIagram:MARKer<x>:PEAK:  
   LEFT, 2-200  
 CALCulate:TDIagram:MARKer<x>:PEAK:  
   LOWer, 2-201  
 CALCulate:TDIagram:MARKer<x>:PEAK:  
   RIGHt, 2-201  
 CALCulate:TDIagram:MARKer<x>:X[:  
   TIME], 2-202  
 CALCulate:TDIagram:MARKer<x>:Y?, 2-202  
 CALCulate:TOVerview:MARKer<x>:DELTA:  
   X?, 2-203  
 CALCulate:TOVerview:MARKer<x>:DELTA:  
   Y?, 2-203  
 CALCulate:TOVerview:MARKer<x>:  
   MAXimum, 2-204  
 CALCulate:TOVerview:MARKer<x>:PEAK:  
   HIGHer, 2-204  
 CALCulate:TOVerview:MARKer<x>:PEAK:  
   LEFT, 2-205  
 CALCulate:TOVerview:MARKer<x>:PEAK:  
   LOWer, 2-205  
 CALCulate:TOVerview:MARKer<x>:PEAK:  
   RIGHt, 2-206  
 CALCulate:TOVerview:MARKer<x>:X, 2-206  
 CALCulate:TOVerview:MARKer<x>:Y?, 2-207  
 CALibration:CORRection:EXTErnal:EDIT<x>:  
   LABel, 2-208  
 CALibration:CORRection:EXTErnal:EDIT<x>:  
   NEW, 2-209  
 CALibration:CORRection:EXTErnal:EDIT<x>:  
   STATe, 2-209  
 CALibration:CORRection:EXTErnal:GAIN:  
   STATe, 2-210  
 CALibration:CORRection:EXTErnal:GAIN[:  
   MAGNitude], 2-210  
 CALibration:CORRection:EXTErnal:PROBE:  
   CONNect?, 2-211  
 CALibration:CORRection:EXTErnal:PROBE:  
   STATe, 2-212  
 CALibration:CORRection:EXTErnal:PROBE[:  
   MAGNitude]?, 2-211  
 CALibration:CORRection:EXTErnal:TYPE, 2-212  
 CALibration:ABORt, 2-207  
 CALibration:AUTO, 2-208  
 \*CLS, 2-213

## D

DISPlay:{AM|FM|PM}:MARKer:SHOW:  
   STATe, 2-220  
 DISPlay:{AM|FM|PM}:WINDow:TRACe:  
   GRATicule:GRID:STATe, 2-221  
 DISPlay:{AM|FM|PM}:X:RSCale, 2-221  
 DISPlay:{AM|FM|PM}:X[:SCALe]:AUTO, 2-222  
 DISPlay:{AM|FM|PM}:X[:SCALe]:FULL, 2-222  
 DISPlay:{AM|FM|PM}:X[:SCALe]:OFFSet, 2-222  
 DISPlay:{AM|FM|PM}:Y:RSCale, 2-223  
 DISPlay:{AM|FM|PM}:Y[:SCALe], 2-223  
 DISPlay:{AM|FM|PM}:Y[:SCALe]:OFFSet, 2-224  
 DISPlay:ACPower:MARKer:SHOW:STATe, 2-214  
 DISPlay:ACPower:PLEVel:SHOW:STATe, 2-214  
 DISPlay:ACPower:RESet:SCALe, 2-215  
 DISPlay:ACPower:WINDow:TRACe:GRATicule:  
   GRID:STATe, 2-215  
 DISPlay:ACPower:X[:SCALe], 2-216  
 DISPlay:ACPower:X[:SCALe]:AUTO, 2-216  
 DISPlay:ACPower:X[:SCALe]:OFFSet, 2-217  
 DISPlay:ACPower:Y[:SCALe], 2-217  
 DISPlay:ACPower:Y[:SCALe]:AUTO, 2-218  
 DISPlay:ACPower:Y[:SCALe]:OFFSet, 2-218  
 DISPlay:ADEMod:MEASview:DELeTe, 2-219  
 DISPlay:ADEMod:MEASview:NEW, 2-219  
 DISPlay:ADEMod:MEASview:SELeCt, 2-220  
 DISPlay:AVTime:LEGend:STATe, 2-225  
 DISPlay:AVTime:MARKer:SHOW:STATe, 2-225  
 DISPlay:AVTime:RESet, 2-226  
 DISPlay:AVTime:TRIGger:LEVel:STATe, 2-226  
 DISPlay:AVTime:WINDow:TRACe:GRATicule:  
   GRID:STATe, 2-227  
 DISPlay:AVTime:X:RSCale, 2-227  
 DISPlay:AVTime:X[:SCALe]:AUTO, 2-228  
 DISPlay:AVTime:X[:SCALe]:AUTO:STATe, 2-228  
 DISPlay:AVTime:X[:SCALe]:FULL, 2-229  
 DISPlay:AVTime:X[:SCALe]:MAXimum?, 2-229  
 DISPlay:AVTime:X[:SCALe]:MINimum?, 2-230  
 DISPlay:AVTime:X[:SCALe]:OFFSet, 2-230  
 DISPlay:AVTime:X[:SCALe]:OFFSet:  
   MAXimum?, 2-231  
 DISPlay:AVTime:X[:SCALe]:OFFSet:  
   MINimum?, 2-231  
 DISPlay:AVTime:Y:RSCale, 2-232  
 DISPlay:AVTime:Y[:SCALe]:FULL, 2-232  
 DISPlay:AVTime:Y[:SCALe]:OFFSet, 2-233  
 DISPlay:CCDF:LEGend:STATe, 2-233

- DISPlay:CCDF:WINDow:TRACe:GRATICule:GRID: STATE, 2-234
- DISPlay:CONStE:MPHase, 2-234
- DISPlay:CONStE:WINDow:TRACe:GRATICule: GRID:STATE, 2-235
- DISPlay:DDEMod:MEASview:DELeTe, 2-235
- DISPlay:DDEMod:MEASview:NEW, 2-236
- DISPlay:DDEMod:MEASview:SELeCt, 2-237
- DISPlay:DDEMod:RADix, 2-237
- DISPlay:DDEMod:X[:SCALe], 2-238
- DISPlay:DDEMod:X[:SCALe]:AUTO, 2-239
- DISPlay:DDEMod:X[:SCALe]:AUTO:STATE, 2-239
- DISPlay:DDEMod:X[:SCALe]:MAXimum?, 2-240
- DISPlay:DDEMod:X[:SCALe]:MINimum?, 2-240
- DISPlay:DDEMod:X[:SCALe]:OFFSet, 2-241
- DISPlay:DDEMod:X[:SCALe]:OFFSet: MAXimum?, 2-241
- DISPlay:DDEMod:X[:SCALe]:OFFSet: MINimum?, 2-242
- DISPlay:DDEMod:X[:SCALe]:RESet, 2-242
- DISPlay:DIAGram:X[:SCALe], 2-243
- DISPlay:DIAGram:X[:SCALe]:RESet, 2-243
- DISPlay:DIQVtime:WINDow:TRACe:GRATICule: GRID:STATE, 2-244
- DISPlay:DIQVtime:Y[:SCALe], 2-244
- DISPlay:DIQVtime:Y[:SCALe]:AUTO, 2-245
- DISPlay:DIQVtime:Y[:SCALe]:OFFSet, 2-245
- DISPlay:DPSA:LEGenD:STATE, 2-245
- DISPlay:DPSA:WINDow:TRACe:GRATICule:GRID: STATE, 2-246
- DISPlay:DPSA:Y[:SCALe]:PDIVision, 2-246
- DISPlay:EDIagram:WINDow:TRACe:GRATICule: GRID:STATE, 2-247
- DISPlay:EDIagram:Y[:SCALe], 2-247
- DISPlay:EDIagram:Y[:SCALe]:AUTO, 2-248
- DISPlay:EDIagram:Y[:SCALe]:OFFSet, 2-248
- DISPlay:EVM:Y[:SCALe], 2-249
- DISPlay:EVM:Y[:SCALe]:AUTO, 2-249
- DISPlay:EVM:Y[:SCALe]:OFFSet, 2-250
- DISPlay:FDVTime:WINDow:TRACe:GRATICule: GRID:STATE, 2-250
- DISPlay:FDVTime:Y[:SCALe], 2-251
- DISPlay:FDVTime:Y[:SCALe]:AUTO, 2-251
- DISPlay:FDVTime:Y[:SCALe]:OFFSet, 2-252
- DISPlay:FVTime:WINDow:TRACe:GRATICule: GRID:STATE, 2-252
- DISPlay:FVTime:X[:SCALe], 2-253
- DISPlay:FVTime:X[:SCALe]:AUTO, 2-253
- DISPlay:FVTime:X[:SCALe]:AUTO:STATE, 2-254
- DISPlay:FVTime:X[:SCALe]:MAXimum?, 2-254
- DISPlay:FVTime:X[:SCALe]:MINimum?, 2-255
- DISPlay:FVTime:X[:SCALe]:OFFSet, 2-255
- DISPlay:FVTime:X[:SCALe]:OFFSet: MAXimum?, 2-256
- DISPlay:FVTime:X[:SCALe]:OFFSet: MINimum?, 2-256
- DISPlay:FVTime:Y[:SCALe], 2-257
- DISPlay:FVTime:Y[:SCALe]:AUTO, 2-257
- DISPlay:FVTime:Y[:SCALe]:OFFSet, 2-258
- DISPlay:GENeral:MEASview:DELeTe, 2-258
- DISPlay:GENeral:MEASview:NEW, 2-259
- DISPlay:GENeral:MEASview:SELeCt, 2-260
- DISPlay:GPRF:MEASview:DELeTe, 2-260
- DISPlay:GPRF:MEASview:NEW, 2-261
- DISPlay:GPRF:MEASview:SELeCt, 2-262
- DISPlay:IQVTime:WINDow:TRACe:GRATICule: GRID:STATE, 2-262
- DISPlay:IQVTime:X[:SCALe], 2-263
- DISPlay:IQVTime:X[:SCALe]:AUTO, 2-264
- DISPlay:IQVTime:X[:SCALe]:AUTO:STATE, 2-264
- DISPlay:IQVTime:X[:SCALe]:MAXimum?, 2-265
- DISPlay:IQVTime:X[:SCALe]:MINimum?, 2-265
- DISPlay:IQVTime:X[:SCALe]:OFFSet, 2-266
- DISPlay:IQVTime:X[:SCALe]:OFFSet: MAXimum?, 2-266
- DISPlay:IQVTime:X[:SCALe]:OFFSet: MINimum?, 2-267
- DISPlay:IQVTime:Y[:SCALe], 2-267
- DISPlay:IQVTime:Y[:SCALe]:AUTO, 2-268
- DISPlay:IQVTime:Y[:SCALe]:OFFSet, 2-268
- DISPlay:IQVTime:Y[:SCALe]:RESCale, 2-269
- DISPlay:MCPower:MARKer:SHOW:STATE, 2-269
- DISPlay:MCPower:PLEVel:SHOW:STATE, 2-270
- DISPlay:MCPower:RESet:SCALe, 2-270
- DISPlay:MCPower:WINDow:TRACe:GRATICule: GRID:STATE, 2-271
- DISPlay:MCPower:X[:SCALe], 2-271
- DISPlay:MCPower:X[:SCALe]:AUTO, 2-272
- DISPlay:MCPower:X[:SCALe]:OFFSet, 2-272
- DISPlay:MCPower:Y[:SCALe], 2-273
- DISPlay:MCPower:Y[:SCALe]:AUTO, 2-273
- DISPlay:MCPower:Y[:SCALe]:OFFSet, 2-274
- DISPlay:MERRor:Y[:SCALe], 2-274
- DISPlay:MERRor:Y[:SCALe]:AUTO, 2-275

- DISPlay:MERRor:Y[:SCALe]:OFFSet, 2-275  
 DISPlay:OBWidth:MARKer:SHOW:STATe, 2-276  
 DISPlay:OBWidth:RESet:SCALe, 2-276  
 DISPlay:OBWidth:SELEcted:BANDwidth, 2-277  
 DISPlay:OBWidth:WINDow:TRACe:GRATicule:  
   GRID:STATe, 2-277  
 DISPlay:OBWidth:X[:SCALe], 2-278  
 DISPlay:OBWidth:X[:SCALe]:AUTO, 2-278  
 DISPlay:OBWidth:X[:SCALe]:OFFSet, 2-279  
 DISPlay:OBWidth:Y[:SCALe], 2-279  
 DISPlay:OBWidth:Y[:SCALe]:AUTO, 2-280  
 DISPlay:OBWidth:Y[:SCALe]:OFFSet, 2-280  
 DISPlay:PERRor:Y[:SCALe], 2-281  
 DISPlay:PERRor:Y[:SCALe]:AUTO, 2-281  
 DISPlay:PERRor:Y[:SCALe]:OFFSet, 2-282  
 DISPlay:PHVTime:WINDow:TRACe:GRATicule:  
   GRID:STATe, 2-282  
 DISPlay:PHVTime:X[:SCALe], 2-283  
 DISPlay:PHVTime:X[:SCALe]:AUTO, 2-283  
 DISPlay:PHVTime:X[:SCALe]:AUTO:STATe, 2-284  
 DISPlay:PHVTime:X[:SCALe]:MAXimum?, 2-284  
 DISPlay:PHVTime:X[:SCALe]:MINimum?, 2-285  
 DISPlay:PHVTime:X[:SCALe]:OFFSet, 2-285  
 DISPlay:PHVTime:X[:SCALe]:OFFSet:  
   MAXimum?, 2-286  
 DISPlay:PHVTime:X[:SCALe]:OFFSet:  
   MINimum?, 2-286  
 DISPlay:PHVTime:Y[:SCALe], 2-287  
 DISPlay:PHVTime:Y[:SCALe]:AUTO, 2-288  
 DISPlay:PHVTime:Y[:SCALe]:AXIS, 2-288  
 DISPlay:PHVTime:Y[:SCALe]:AXIS:  
   REFerence, 2-289  
 DISPlay:PHVTime:Y[:SCALe]:OFFSet, 2-289  
 DISPlay:PHVTime:Y[:SCALe]:RESCale, 2-290  
 DISPlay:PNOise:LEGend:STATe, 2-290  
 DISPlay:PNOise:MARKer:SHOW:STATe, 2-290  
 DISPlay:PNOise:RESet:SCALe, 2-291  
 DISPlay:PNOise:WINDow:TRACe:GRATicule:  
   GRID:STATe, 2-291  
 DISPlay:PNOise:X[:SCALe]:AUTO, 2-292  
 DISPlay:PNOise:X[:SCALe]:START, 2-292  
 DISPlay:PNOise:X[:SCALe]:STOP, 2-293  
 DISPlay:PNOise:Y[:SCALe], 2-293  
 DISPlay:PNOise:Y[:SCALe]:AUTO, 2-294  
 DISPlay:PNOise:Y[:SCALe]:OFFSet, 2-294  
 DISPlay:PNOise:Y[:SCALe]:PDIVision, 2-295  
 DISPlay:PULSe:MEASview:DELeTe, 2-295  
 DISPlay:PULSe:MEASview:NEW, 2-296  
 DISPlay:PULSe:MEASview:SELEct, 2-296  
 DISPlay:PULSe:RESult:ATX, 2-297  
 DISPlay:PULSe:RESult:AVERAge, 2-297  
 DISPlay:PULSe:RESult:DROOp, 2-298  
 DISPlay:PULSe:RESult:DUTPct, 2-298  
 DISPlay:PULSe:RESult:DUTRatio, 2-299  
 DISPlay:PULSe:RESult:FALL, 2-299  
 DISPlay:PULSe:RESult:FRDeviAtion, 2-300  
 DISPlay:PULSe:RESult:MFRReqerror, 2-300  
 DISPlay:PULSe:RESult:MPHerror, 2-301  
 DISPlay:PULSe:RESult:PHDeviAtion, 2-301  
 DISPlay:PULSe:RESult:PPFRequency, 2-302  
 DISPlay:PULSe:RESult:PPOWer, 2-302  
 DISPlay:PULSe:RESult:PPPHase, 2-303  
 DISPlay:PULSe:RESult:RINTerval, 2-303  
 DISPlay:PULSe:RESult:RIPple, 2-304  
 DISPlay:PULSe:RESult:RISE, 2-304  
 DISPlay:PULSe:RESult:RMSFReqerror, 2-305  
 DISPlay:PULSe:RESult:RMSPherror, 2-305  
 DISPlay:PULSe:RESult:RRATe, 2-306  
 DISPlay:PULSe:RESult:TIME, 2-306  
 DISPlay:PULSe:RESult:WIDTh, 2-307  
 DISPlay:PULSe:SELEct:NUMBer, 2-307  
 DISPlay:PULSe:SELEct:RESult, 2-308  
 DISPlay:PULSe:STATistics:MARKer:SHOW:  
   STATe, 2-309  
 DISPlay:PULSe:STATistics:PLOT, 2-309  
 DISPlay:PULSe:STATistics:WINDow:TRACe:  
   GRATicule:GRID:STATe, 2-310  
 DISPlay:PULSe:STATistics:X:RSCale, 2-310  
 DISPlay:PULSe:STATistics:X[:SCALe]:  
   NUMBer, 2-311  
 DISPlay:PULSe:STATistics:X[:SCALe]:  
   OFFSet, 2-311  
 DISPlay:PULSe:STATistics:Y:RSCale, 2-312  
 DISPlay:PULSe:STATistics:Y[:SCALe]:FULL, 2-312  
 DISPlay:PULSe:STATistics:Y[:SCALe]:  
   OFFSet, 2-313  
 DISPlay:PULSe:STATistics:Y[:SCALe]:  
   STOP?, 2-314  
 DISPlay:PULSe:TRACe:MARKer:SHOW:  
   STATe, 2-314  
 DISPlay:PULSe:TRACe:POINt:SHOW, 2-315  
 DISPlay:PULSe:TRACe:WINDow:TRACe:  
   GRATicule:GRID:STATe, 2-315  
 DISPlay:PULSe:TRACe:X:RSCale, 2-316

- DISPlay:PULSe:TRACe:X[:SCALe], 2-316  
 DISPlay:PULSe:TRACe:X[:SCALe]:FULL, 2-317  
 DISPlay:PULSe:TRACe:X[:SCALe]:OFFSet, 2-317  
 DISPlay:PULSe:TRACe:X[:SCALe]:  
   PDIVision, 2-318  
 DISPlay:PULSe:TRACe:Y:RSCale, 2-318  
 DISPlay:PULSe:TRACe:Y[:SCALe]:FULL, 2-319  
 DISPlay:PULSe:TRACe:Y[:SCALe]:OFFSet, 2-319  
 DISPlay:PULSe:TRACe:Y[:SCALe]:STOP?, 2-320  
 DISPlay:SGRam:FREQuency:AUTO, 2-320  
 DISPlay:SGRam:FREQuency:OFFSet, 2-321  
 DISPlay:SGRam:FREQuency:SCALe, 2-321  
 DISPlay:SGRam:TIME:AUTO, 2-322  
 DISPlay:SGRam:TIME:OFFSet, 2-322  
 DISPlay:SGRam:TIME:OVERlap, 2-323  
 DISPlay:SGRam:TIME:SCALe, 2-323  
 DISPlay:SPECTrum:FREQuency:AUTO, 2-324  
 DISPlay:SPECTrum:FREQuency:OFFSet, 2-324  
 DISPlay:SPECTrum:FREQuency[:SCALe], 2-325  
 DISPlay:SPECTrum:MARKer:NOISe:MODE, 2-325  
 DISPlay:SPECTrum:SCALe:LOG:STATe, 2-326  
 DISPlay:SPECTrum:WINDow:TRACe:GRATICule:  
   GRID:STATe, 2-326  
 DISPlay:SPECTrum:WINDow:TRACe:LEGend:  
   STATe, 2-327  
 DISPlay:SPECTrum:X:LABel, 2-327  
 DISPlay:SPECTrum:Y[:SCALe], 2-328  
 DISPlay:SPECTrum:Y[:SCALe]:AUTO, 2-328  
 DISPlay:SPECTrum:Y[:SCALe]:OFFSet, 2-329  
 DISPlay:SPECTrum:Y[:SCALe]:PDIVision, 2-329  
 DISPlay:SPECTrum:Y[:SCALe]:RESet, 2-330  
 DISPlay:SPURious:MARKer:SHOW:STATe, 2-330  
 DISPlay:SPURious:RESet:SCALe, 2-331  
 DISPlay:SPURious:SCALe:LOG:STATe, 2-331  
 DISPlay:SPURious:SElect:NUMBer, 2-332  
 DISPlay:SPURious:SHOW:LIMit, 2-332  
 DISPlay:SPURious:WINDow:TRACe:GRATICule:  
   GRID:STATe, 2-333  
 DISPlay:SPURious:X[:SCALe]:AUTO, 2-333  
 DISPlay:SPURious:X[:SCALe]:START, 2-334  
 DISPlay:SPURious:X[:SCALe]:STOP, 2-334  
 DISPlay:SPURious:Y[:SCALe], 2-335  
 DISPlay:SPURious:Y[:SCALe]:AUTO, 2-335  
 DISPlay:SPURious:Y[:SCALe]:OFFSet, 2-335  
 DISPlay:TDIagram:WINDow:TRACe:GRATICule:  
   GRID:STATe, 2-336  
 DISPlay:TDIagram:Y[:SCALe], 2-336  
 DISPlay:TDIagram:Y[:SCALe]:AUTO, 2-337  
 DISPlay:TDIagram:Y[:SCALe]:OFFSet, 2-337  
 DISPlay:TOVerview:WINDow:TRACe:GRATICule:  
   GRID:STATe, 2-338  
 DISPlay:TOVerview:X[:SCALe], 2-338  
 DISPlay:TOVerview:X[:SCALe]:AUTO, 2-339  
 DISPlay:TOVerview:X[:SCALe]:OFFSet, 2-339  
 DISPlay:TOVerview:Y[:SCALe], 2-340  
 DISPlay:TOVerview:Y[:SCALe]:AUTO, 2-340  
 DISPlay:TOVerview:Y[:SCALe]:OFFSet, 2-341  
 DISPlay:TOVerview:Y[:SCALe]:RESCale, 2-341  
 DISPlay:WINDow:ACTive:MEASurement?, 2-342  
 DISPlay:WINDow:COLor:SCHEme, 2-343  
 DISPlay:WINDow:OPTimized:  
   MEASurement?, 2-344
- ## E
- \*ESE, 2-345  
 \*ESR?, 2-345
- ## F
- FETCh:{FM|PM}:FERRor?, 2-373  
 FETCh:ACPower:CHANnel:POWER?, 2-347  
 FETCh:ACPower:SPECTrum?, 2-347  
 FETCh:AM:AMNegative?, 2-349  
 FETCh:AM:AMPositive?, 2-349  
 FETCh:AVTime:  
   {FIRSt|SECond|THIRd|FOURth}?, 2-351  
 FETCh:AVTime:AVERage?, 2-350  
 FETCh:AVTime:MAXimum?, 2-352  
 FETCh:AVTime:MAXLocation?, 2-352  
 FETCh:AVTime:MINimum?, 2-353  
 FETCh:AVTime:MINLocation?, 2-353  
 FETCh:AVTime:RESult?, 2-354  
 FETCh:CCDF:{FIRSt|SECond|THIRd}:X?, 2-356  
 FETCh:CCDF:{FIRSt|SECond|THIRd}:XY?, 2-356  
 FETCh:CCDF:{FIRSt|SECond|THIRd}[:Y]?, 2-357  
 FETCh:CONSte:FERRor?, 2-358  
 FETCh:CONSte:RESults?, 2-358  
 FETCh:DDEMod:STABLE?, 2-360  
 FETCh:DDEMod:SYNCh:WORD:LENGth?, 2-360  
 FETCh:DDEMod:SYNCh:WORD:POSITION?, 2-361  
 FETCh:DIQVtime:FERRor?, 2-361  
 FETCh:DPSA:RESults:TRACe<x>?, 2-363  
 FETCh:DPSA:TRACe:AVERage?, 2-364  
 FETCh:DPSA:TRACe:BITMap?, 2-364

FETCh:DPSA:TRACe:MATH?, 2-365  
 FETCh:DPSA:TRACe:MAXimum?, 2-366  
 FETCh:DPSA:TRACe:MINimum?, 2-366  
 FETCh:EDIagram:FDEviation?, 2-367  
 FETCh:EDIagram:FERRor?, 2-367  
 FETCh:FDVTime:FERRor?, 2-372  
 FETCh:FDVTime:TRACe?, 2-372  
 FETCh:FVTime:MAXimum?, 2-377  
 FETCh:FVTime:MAXLocation?, 2-377  
 FETCh:FVTime:MINimum?, 2-378  
 FETCh:FVTime:MINLocation?, 2-378  
 FETCh:FVTime:RESult?, 2-379  
 FETCh:IQVTime:MAXimum?, 2-380  
 FETCh:IQVTime:MAXLocation?, 2-381  
 FETCh:IQVTime:MINimum?, 2-381  
 FETCh:IQVTime:MINLocation?, 2-382  
 FETCh:IQVTime:RESult?, 2-383  
 FETCh:MCPower:ADJacent:CHANnels?, 2-384  
 FETCh:MCPower:CHANnel:POWer?, 2-385  
 FETCh:MCPower:MAIN:CHANnels?, 2-385  
 FETCh:MCPower:SPECTrum?, 2-386  
 FETCh:MERRor:FERRor?, 2-386  
 FETCh:MERRor:PINDEX?, 2-387  
 FETCh:OBWidth:FREQuency:ERRor?, 2-389  
 FETCh:OBWidth:OBWidth:BANDwidth?, 2-390  
 FETCh:OBWidth:OBWidth:LEFT:  
   FREQuency?, 2-390  
 FETCh:OBWidth:OBWidth:LEFT:LEVel?, 2-391  
 FETCh:OBWidth:OBWidth:POWer?, 2-391  
 FETCh:OBWidth:OBWidth:RIGHT:  
   FREQuency?, 2-392  
 FETCh:OBWidth:OBWidth:RIGHT:LEVel?, 2-392  
 FETCh:OBWidth:SPECTrum?, 2-393  
 FETCh:OBWidth:XDBBANDwidth:  
   BANDwidth?, 2-393  
 FETCh:OBWidth:XDBBANDwidth:LEFT:  
   FREQuency?, 2-394  
 FETCh:OBWidth:XDBBANDwidth:LEFT:  
   LEVel?, 2-394  
 FETCh:OBWidth:XDBBANDwidth:POWer?, 2-395  
 FETCh:OBWidth:XDBBANDwidth:RIGHT:  
   FREQuency?, 2-395  
 FETCh:OBWidth:XDBBANDwidth:RIGHT:  
   LEVel?, 2-396  
 FETCh:PERRor:FERRor?, 2-396  
 FETCh:PERRor:PINDEX?, 2-397  
 FETCh:PHVTime:MAXimum?, 2-400  
 FETCh:PHVTime:MAXLocation?, 2-400  
 FETCh:PHVTime:MINimum?, 2-401  
 FETCh:PHVTime:MINLocation?, 2-401  
 FETCh:PHVTime:RESult?, 2-402  
 FETCh:PNOise:CARRier:FERRor?, 2-406  
 FETCh:PNOise:CARRier:POWer?, 2-406  
 FETCh:PNOise:JITTer?, 2-407  
 FETCh:PNOise:RESidual:FM?, 2-407  
 FETCh:PNOise:RMS:PNOise?, 2-408  
 FETCh:PNOise:SPECTrum<x>:X?, 2-408  
 FETCh:PNOise:SPECTrum<x>:XY?, 2-409  
 FETCh:PNOise:SPECTrum<x>[:Y]?, 2-409  
 FETCh:PULSe:STATistics:ATX?, 2-423  
 FETCh:PULSe:STATistics:AVERAge?, 2-423  
 FETCh:PULSe:STATistics:DROOp?, 2-424  
 FETCh:PULSe:STATistics:DUTPct?, 2-425  
 FETCh:PULSe:STATistics:DUTRatio?, 2-425  
 FETCh:PULSe:STATistics:FALL?, 2-426  
 FETCh:PULSe:STATistics:FRDeviAtion?, 2-427  
 FETCh:PULSe:STATistics:MFRReqerror?, 2-427  
 FETCh:PULSe:STATistics:MPHerror?, 2-428  
 FETCh:PULSe:STATistics:PHDeviAtion?, 2-428  
 FETCh:PULSe:STATistics:PPFRequency?, 2-429  
 FETCh:PULSe:STATistics:PPOWer?, 2-430  
 FETCh:PULSe:STATistics:PPPHase?, 2-430  
 FETCh:PULSe:STATistics:RINTerval?, 2-431  
 FETCh:PULSe:STATistics:RIPple?, 2-432  
 FETCh:PULSe:STATistics:RISE?, 2-432  
 FETCh:PULSe:STATistics:RMSFrequerror?, 2-433  
 FETCh:PULSe:STATistics:RMSPherror?, 2-433  
 FETCh:PULSe:STATistics:RRATE?, 2-434  
 FETCh:PULSe:STATistics:WIDTh?, 2-435  
 FETCh:PULSe:STATistics?, 2-422  
 FETCh:PULSe:TRACe:X?, 2-435  
 FETCh:PULSe:TRACe:XY?, 2-436  
 FETCh:PULSe:TRACe[:Y]?, 2-437  
 FETCh:PULSe[:RESult]:ATX?, 2-410  
 FETCh:PULSe[:RESult]:AVERAge?, 2-410  
 FETCh:PULSe[:RESult]:DROOp?, 2-411  
 FETCh:PULSe[:RESult]:DUTPct?, 2-412  
 FETCh:PULSe[:RESult]:DUTRatio?, 2-412  
 FETCh:PULSe[:RESult]:FALL?, 2-413  
 FETCh:PULSe[:RESult]:FRDeviAtion?, 2-413  
 FETCh:PULSe[:RESult]:MFRReqerror?, 2-414  
 FETCh:PULSe[:RESult]:MPHerror?, 2-415  
 FETCh:PULSe[:RESult]:PHDeviAtion?, 2-415  
 FETCh:PULSe[:RESult]:PPFRequency?, 2-416

- FETCh:PULSe[:REsult]:PPOWer?, 2-416  
 FETCh:PULSe[:REsult]:PPPHasE?, 2-417  
 FETCh:PULSe[:REsult]:RINTerval?, 2-417  
 FETCh:PULSe[:REsult]:RIPPLe?, 2-418  
 FETCh:PULSe[:REsult]:RISE?, 2-419  
 FETCh:PULSe[:REsult]:RMSFreqerror?, 2-419  
 FETCh:PULSe[:REsult]:RMSPherror?, 2-420  
 FETCh:PULSe[:REsult]:RRATE?, 2-420  
 FETCh:PULSe[:REsult]:TIME?, 2-421  
 FETCh:PULSe[:REsult]:WIDTh?, 2-421  
 FETCh:RFIN:IQ:HEADer?, 2-438  
 FETCh:RFIN:IQ:SCALe?, 2-439  
 FETCh:RFIN:RECORD:IDS?, 2-440  
 FETCh:SPECTrum:TRACe<x>?, 2-441  
 FETCh:SPURious:CARRier:POWer?, 2-442  
 FETCh:SPURious:COUNt?, 2-442  
 FETCh:SPURious:PASS?, 2-443  
 FETCh:SPURious:SPECTrum:X?, 2-443  
 FETCh:SPURious:SPECTrum:XY?, 2-444  
 FETCh:SPURious:SPECTrum[Y]?, 2-445  
 FETCh:SPURious:SPUR<x>:AMPLitude:  
   ABSolute?, 2-445  
 FETCh:SPURious:SPUR<x>:AMPLitude:  
   RELative?, 2-446  
 FETCh:SPURious:SPUR<x>:FREQuency:  
   ABSolute?, 2-446  
 FETCh:SPURious:SPUR<x>:FREQuency:  
   RELative?, 2-447  
 FETCh:SPURious:SPUR<x>:LIMit:  
   ABSolute?, 2-447  
 FETCh:SPURious:SPUR<x>:LIMit:RELative?, 2-448  
 FETCh:SPURious:SPUR<x>:LIMit:  
   VIOLation?, 2-448  
 FETCh:SPURious:SPUR<x>:RANGe?, 2-449  
 FETCh:SQUality:FREQuency:DEViation:  
   TABLe?, 2-450  
 FETCh:SQUality:FREQuency:DEViation?, 2-449  
 FETCh:SQUality:FREQuency:ERRor?, 2-451  
 FETCh:SQUality:GAIN:IMBalance?, 2-451  
 FETCh:SQUality:ORIGin:OFFSet?, 2-452  
 FETCh:SQUality:PEAK:EVM:DB:OFFSet?, 2-453  
 FETCh:SQUality:PEAK:EVM:DB?, 2-453  
 FETCh:SQUality:PEAK:EVM:LOCation:  
   OFFSet?, 2-454  
 FETCh:SQUality:PEAK:EVM:LOCation?, 2-454  
 FETCh:SQUality:PEAK:EVM:OFFSet?, 2-455  
 FETCh:SQUality:PEAK:EVM?, 2-452  
 FETCh:SQUality:PEAK:FERRor?, 2-455  
 FETCh:SQUality:PEAK:MERRor:DB?, 2-456  
 FETCh:SQUality:PEAK:MERRor:LOCation?, 2-457  
 FETCh:SQUality:PEAK:MERRor?, 2-456  
 FETCh:SQUality:PEAK:PERRor:LOCation?, 2-458  
 FETCh:SQUality:PEAK:PERRor?, 2-457  
 FETCh:SQUality:QUADrature:ERRor?, 2-458  
 FETCh:SQUality:RMS:EVM:DB:OFFSet?, 2-460  
 FETCh:SQUality:RMS:EVM:DB?, 2-460  
 FETCh:SQUality:RMS:EVM:OFFSet?, 2-461  
 FETCh:SQUality:RMS:EVM?, 2-459  
 FETCh:SQUality:RMS:FERRor?, 2-461  
 FETCh:SQUality:RMS:MERRor:DB?, 2-462  
 FETCh:SQUality:RMS:MERRor:DB?, 2-463  
 FETCh:SQUality:RMS:MERRor?, 2-462  
 FETCh:SQUality:RMS:PERRor?, 2-463  
 FETCh:SQUality:SYMBOL:LENGth?, 2-464  
 FETCh:SQUality:SYMBOL:RATE:ERRor?, 2-464  
 FETCh:SQUality:SYMBOL:RATE?, 2-464  
 FETCh:TDIagram:FERRor?, 2-465  
 FETCh:TDIagram:TRACe?, 2-465  
 FETCh:{AM|FM|PM}?, 2-348  
 FETCh:ACPower?, 2-346  
 FETCh:AM:AMINdex?, 2-348  
 FETCh:AM:RESult?, 2-350  
 FETCh:CCDF?, 2-355  
 FETCh:CONSte:TRACe?, 2-359  
 FETCh:DIQVtime:I?, 2-362  
 FETCh:DIQVtime:Q?, 2-362  
 FETCh:EDIagram:I?, 2-368  
 FETCh:EDIagram:Q?, 2-368  
 FETCh:EVM:FERRor?, 2-369  
 FETCh:EVM:PEAK?, 2-369  
 FETCh:EVM:PINDex?, 2-370  
 FETCh:EVM:RMS?, 2-371  
 FETCh:EVM:TRACe?, 2-371  
 FETCh:FM:PHALf?, 2-373  
 FETCh:FM:PNEGative?, 2-374  
 FETCh:FM:PPOSitive?, 2-374  
 FETCh:FM:PTPeak?, 2-375  
 FETCh:FM:RESult?, 2-375  
 FETCh:FM:RMS?, 2-376  
 FETCh:FVTime?, 2-376  
 FETCh:IQVTime:I?, 2-380  
 FETCh:IQVTime:Q?, 2-382  
 FETCh:MERRor:PEAK?, 2-387  
 FETCh:MERRor:RMS?, 2-388

FETCh:MERRor:TRACe?, 2-388  
 FETCh:PERRor:PEAK?, 2-397  
 FETCh:PERRor:RMS?, 2-398  
 FETCh:PERRor:TRACe?, 2-398  
 FETCh:PHVTime?, 2-399  
 FETCh:PM:PNEGative?, 2-402  
 FETCh:PM:PPOSitive?, 2-403  
 FETCh:PM:PTPeak?, 2-403  
 FETCh:PM:RESult?, 2-404  
 FETCh:PM:RMS?, 2-404  
 FETCh:PNOise:ALL?, 2-405  
 FETCh:RFIN:IQ?, 2-437  
 FETCh:SGRam?, 2-441  
 FETCh:SQUality:RHO?, 2-459  
 FETCh:TOVerview?, 2-466

## I

\*IDN?, 2-467  
 INITiate[:IMMediate], 2-468  
 INITiate:CONTInuous, 2-467  
 INPut: {MLEVel|RLVEl}, 2-470  
 INPut:CORRection:EXTernal:EDIT<x>:  
   INTerpolation, 2-469  
 INPut:CORRection:EXTernal:EDIT<x>:NEW, 2-469  
 INPut:CORRection:EXTernal:TYPE, 2-470  
 INPut[:RF]:ATTenuation, 2-471  
 INPut[:RF]:ATTenuation:AUTO, 2-471  
 INPut[:RF]:ATTenuation:MONitor:STATe, 2-472  
 INPut[:RF]:GAIN:STATe, 2-472

## M

MMEMory: {AM|FM|PM}:LOAD:TRACe, 2-473  
 MMEMory: {AM|FM|PM}:SHOW:TRACe<x>, 2-473  
 MMEMory: {AM|FM|PM}:STORE:TRACe, 2-474  
 MMEMory:AVTime:LOAD:TRACe<x>, 2-474  
 MMEMory:AVTime:SHOW:TRACe<x>, 2-475  
 MMEMory:AVTime:STORE:TRACe<x>, 2-475  
 MMEMory:CALibration:LOAD:CORRection:  
   EXTernal:EDIT<x>, 2-476  
 MMEMory:CALibration:STORE:CORRection:  
   EXTernal:EDIT<x>, 2-476  
 MMEMory:CCDF:LOAD:TRACe<x>, 2-477  
 MMEMory:CCDF:SHOW:TRACe<x>, 2-477  
 MMEMory:CCDF:STORE:TRACe<x>, 2-478  
 MMEMory:DDEMod:LOAD:FILTer:MEASurement:  
   UOTHer, 2-478

MMEMory:DDEMod:LOAD:FILTer:MEASurement:  
   USER<x>, 2-479  
 MMEMory:DDEMod:LOAD:FILTer:REFerence:  
   UOTHer, 2-479  
 MMEMory:DDEMod:LOAD:FILTer:REFerence:  
   USER<x>, 2-480  
 MMEMory:DDEMod:LOAD:SYMBOL:MAP, 2-480  
 MMEMory:DPSA:LOAD:TRACe<x>, 2-480  
 MMEMory:DPSA:SHOW:TRACe<x>, 2-481  
 MMEMory:DPSA:STORE:TRACe<x>, 2-482  
 MMEMory:FVTime:LOAD:TRACe, 2-482  
 MMEMory:FVTIME:SHOW:TRACe<x>, 2-483  
 MMEMory:FVTime:STORE:TRACe, 2-483  
 MMEMory:IQVTime:LOAD:TRACe:I, 2-484  
 MMEMory:IQVTime:LOAD:TRACe:Q, 2-484  
 MMEMory:IQVTIME:SHOW:TRACe:I, 2-484  
 MMEMory:IQVTIME:SHOW:TRACe<x>:Q, 2-485  
 MMEMory:IQVTime:STORE:TRACe:I, 2-486  
 MMEMory:IQVTime:STORE:TRACe:Q, 2-486  
 MMEMory:PHVTime:LOAD:TRACe, 2-489  
 MMEMory:PHVTime:SHOW:TRACe, 2-489  
 MMEMory:PHVTime:STORE:TRACe, 2-490  
 MMEMory:PNOise:LOAD:TRACe<x>, 2-490  
 MMEMory:PNOise:SHOW:TRACe<x>, 2-491  
 MMEMory:PNOise:STORE:TRACe<x>, 2-491  
 MMEMory:SGRam:LOAD:TRACe, 2-492  
 MMEMory:SGRam:SHOW:TRACe, 2-492  
 MMEMory:SGRam:STORE:TRACe, 2-493  
 MMEMory:SPECTrum:LOAD:TRACe, 2-493  
 MMEMory:SPECTrum:SHOW:TRACe<x>, 2-494  
 MMEMory:SPECTrum:STORE:TRACe<x>, 2-494  
 MMEMory:SPURious:LOAD:TABLE, 2-495  
 MMEMory:SPURious:STORE:TABLE, 2-495  
 MMEMory:STORE:IQ:CSV, 2-496  
 MMEMory:STORE:IQ:MAT, 2-497  
 MMEMory:STORE:MSTate, 2-497  
 MMEMory:STORE:RESults, 2-497  
 MMEMory:STORE:SCReen, 2-498  
 MMEMory:TOVerview:LOAD:TRACe1, 2-499  
 MMEMory:TOVerview:SHOW:TRACe1, 2-500  
 MMEMory:TOVerview:STORE:TRACe1, 2-500  
 MMEMory:LOAD:IQ, 2-486  
 MMEMory:LOAD:STATe, 2-487  
 MMEMory:LOAD:TRACe, 2-487  
 MMEMory:STORE:IQ, 2-496  
 MMEMory:STORE:STATe, 2-498  
 MMEMory:STORE:TRACe, 2-499

## O

\*OPC, 2-501  
 \*OPT?, 2-502  
 OUTPut:IF: {BANDwidth|BWIDth}, 2-502  
 OUTPut:NOISe[:STATe], 2-504  
 OUTPut:IF[:STATe], 2-503  
 OUTPut:IQ[:STATe], 2-503  
 Overview of the Manual, 1-1

## R

READ: {FM|PM}:FERRor?, 2-530  
 READ:ACPower:CHANnel:POWER?, 2-505  
 READ:ACPower:SPECTrum?, 2-506  
 READ:AVTime:  
   {FIRSt|SECond|THIRd|FOURth}?, 2-509  
 READ:AVTime:AVERAge?, 2-509  
 READ:AVTime:MAXimum?, 2-510  
 READ:AVTime:MAXLocation?, 2-511  
 READ:AVTime:MINimum?, 2-511  
 READ:AVTime:MINLocation?, 2-512  
 READ:CCDF: {FIRSt|SECond|THIRd}:X?, 2-514  
 READ:CCDF: {FIRSt|SECond|THIRd}:XY?, 2-515  
 READ:CCDF: {FIRSt|SECond|THIRd}[:Y]?, 2-516  
 READ:CONSt:REsults?, 2-517  
 READ:DIQVtime:FERRor?, 2-519  
 READ:DPSA:REsults:TRACe<x>?, 2-520  
 READ:DPSA:TRACe:AVERAge?, 2-521  
 READ:DPSA:TRACe:BITMap?, 2-522  
 READ:DPSA:TRACe:MATH?, 2-522  
 READ:DPSA:TRACe:MAXimum?, 2-523  
 READ:DPSA:TRACe:MINimum?, 2-524  
 READ:EDIagram:FDEVIation?, 2-524  
 READ:EDIagram:FERRor?, 2-525  
 READ:FDVTime:FERRor?, 2-529  
 READ:FVTime:MAXimum?, 2-534  
 READ:FVTime:MAXLocation?, 2-535  
 READ:FVTime:MINimum?, 2-535  
 READ:FVTime:MINLocation?, 2-536  
 READ:IQVTime:MAXimum?, 2-538  
 READ:IQVTime:MAXLocation?, 2-538  
 READ:IQVTime:MINimum?, 2-539  
 READ:IQVTime:MINLocation?, 2-539  
 READ:IQVTime:REsult?, 2-540  
 READ:MCPower:ADJacent:CHANnels?, 2-541  
 READ:MCPower:CHANnel:POWER?, 2-542  
 READ:MCPower:MAIn:CHANnels?, 2-542  
 READ:MCPower:SPECTrum?, 2-543  
 READ:OBWidth:FREQuency:ERRor?, 2-546  
 READ:OBWidth:OBWidth:BANDwidth?, 2-547  
 READ:OBWidth:OBWidth:LEFT:  
   FREQuency?, 2-547  
 READ:OBWidth:OBWidth:LEFT:LEVel?, 2-548  
 READ:OBWidth:OBWidth:POWER?, 2-548  
 READ:OBWidth:OBWidth:RIGHT:  
   FREQuency?, 2-549  
 READ:OBWidth:OBWidth:RIGHT:LEVel?, 2-549  
 READ:OBWidth:SPECTrum?, 2-550  
 READ:OBWidth:XDBBANDwidth:  
   BANDwidth?, 2-550  
 READ:OBWidth:XDBBANDwidth:LEFT:  
   FREQuency?, 2-551  
 READ:OBWidth:XDBBANDwidth:LEFT:  
   LEVel?, 2-551  
 READ:OBWidth:XDBBANDwidth:POWER?, 2-552  
 READ:OBWidth:XDBBANDwidth:RIGHT:  
   FREQuency?, 2-552  
 READ:OBWidth:XDBBANDwidth:RIGHT:  
   LEVel?, 2-553  
 READ:PHVTime:MAXimum?, 2-557  
 READ:PHVTime:MAXLocation?, 2-557  
 READ:PHVTime:MINimum?, 2-558  
 READ:PHVTime:MINLocation?, 2-558  
 READ:PHVTime:REsult?, 2-559  
 READ:PNOise:CARRier:FERRor?, 2-563  
 READ:PNOise:CARRier:POWER?, 2-563  
 READ:PNOise:RESidual:FM?, 2-564  
 READ:PNOise:RMS:PNOise?, 2-565  
 READ:PNOise:SPECTrum<x>:X?, 2-565  
 READ:PNOise:SPECTrum<x>:XY?, 2-566  
 READ:PNOise:SPECTrum<x>[:Y]?, 2-566  
 READ:PULSe:STATistics:ATX?, 2-580  
 READ:PULSe:STATistics:AVERAge?, 2-581  
 READ:PULSe:STATistics:DROOp?, 2-581  
 READ:PULSe:STATistics:DUTPct?, 2-582  
 READ:PULSe:STATistics:DUTRatio?, 2-583  
 READ:PULSe:STATistics:FALL?, 2-583  
 READ:PULSe:STATistics:FRDEVIation?, 2-584  
 READ:PULSe:STATistics:MFRReqerror?, 2-584  
 READ:PULSe:STATistics:MPHerror?, 2-585  
 READ:PULSe:STATistics:PHDEVIation?, 2-586  
 READ:PULSe:STATistics:PPFRReqency?, 2-586  
 READ:PULSe:STATistics:PPower?, 2-587  
 READ:PULSe:STATistics:PPPHase?, 2-588  
 READ:PULSe:STATistics:RINTerval?, 2-588



- READ:PULSe:STATistics:RIPple?, 2-589  
 READ:PULSe:STATistics:RISe?, 2-589  
 READ:PULSe:STATistics:RMSFreqerror?, 2-590  
 READ:PULSe:STATistics:RMSPherror?, 2-591  
 READ:PULSe:STATistics:RRATe?, 2-591  
 READ:PULSe:STATistics:WIDTh?, 2-592  
 READ:PULSe:STATistics?, 2-579  
 READ:PULSe:TRACe:XY?, 2-593  
 READ:PULSe:TRACe[:Y]?, 2-594  
 READ:PULSe[:REsult]:ATX?, 2-567  
 READ:PULSe[:REsult]:AVERAge?, 2-567  
 READ:PULSe[:REsult]:DROop?, 2-568  
 READ:PULSe[:REsult]:DUTPct?, 2-569  
 READ:PULSe[:REsult]:DUTRatio?, 2-569  
 READ:PULSe[:REsult]:FALL?, 2-570  
 READ:PULSe[:REsult]:FRDeViation?, 2-570  
 READ:PULSe[:REsult]:MFRReqerror?, 2-571  
 READ:PULSe[:REsult]:MPHerror?, 2-572  
 READ:PULSe[:REsult]:PHDeViation?, 2-572  
 READ:PULSe[:REsult]:PPFRequency?, 2-573  
 READ:PULSe[:REsult]:PPOWer?, 2-573  
 READ:PULSe[:REsult]:PPPHasE?, 2-574  
 READ:PULSe[:REsult]:RINTerval?, 2-575  
 READ:PULSe[:REsult]:RIPple?, 2-575  
 READ:PULSe[:REsult]:RISe?, 2-576  
 READ:PULSe[:REsult]:RMSFreqerror?, 2-576  
 READ:PULSe[:REsult]:RMSPherror?, 2-577  
 READ:PULSe[:REsult]:RRATe?, 2-577  
 READ:PULSe[:REsult]:TIME?, 2-578  
 READ:PULSe[:REsult]:WIDTh?, 2-579  
 READ:SPECTrum:TRACe<x>?, 2-595  
 READ:SPURious:CARRier:POWer?, 2-596  
 READ:SPURious:COUNT?, 2-597  
 READ:SPURious:SPECTrum:X?, 2-597  
 READ:SPURious:SPECTrum:XY?, 2-598  
 READ:SPURious:SPECTrum[:Y]?, 2-599  
 READ:SPURious:SPUR<x>:AMPLitude:  
   ABSolute?, 2-599  
 READ:SPURious:SPUR<x>:AMPLitude:  
   RELative?, 2-600  
 READ:SPURious:SPUR<x>:FREQUency:  
   ABSolute?, 2-600  
 READ:SPURious:SPUR<x>:FREQUency:  
   RELative?, 2-601  
 READ:SPURious:SPUR<x>:LIMit:ABSolute?, 2-601  
 READ:SPURious:SPUR<x>:LIMit:RELative?, 2-602  
 READ:SPURious:SPUR<x>:LIMit:  
   VIOLation?, 2-602  
 READ:SPURious:SPUR<x>:RANGe?, 2-603  
 READ:SQUality:FREQUency:DEVIation:  
   TABLe?, 2-604  
 READ:SQUality:FREQUency:DEVIation?, 2-603  
 READ:SQUality:FREQUency:ERRor?, 2-605  
 READ:SQUality:GAIN:IMBalance?, 2-605  
 READ:SQUality:ORIGIN:OFFSet?, 2-606  
 READ:SQUality:PEAK:EVM:DB:OFFSet?, 2-607  
 READ:SQUality:PEAK:EVM:DB?, 2-607  
 READ:SQUality:PEAK:EVM:LOCation:  
   OFFSet?, 2-608  
 READ:SQUality:PEAK:EVM:LOCation?, 2-608  
 READ:SQUality:PEAK:EVM:OFFSet?, 2-609  
 READ:SQUality:PEAK:EVM?, 2-606  
 READ:SQUality:PEAK:FERRor?, 2-609  
 READ:SQUality:PEAK:MERRor:DB?, 2-610  
 READ:SQUality:PEAK:MERRor:LOCation?, 2-611  
 READ:SQUality:PEAK:MERRor?, 2-610  
 READ:SQUality:PEAK:PERRor:LOCation?, 2-612  
 READ:SQUality:PEAK:PERRor?, 2-611  
 READ:SQUality:QUADrature:ERRor?, 2-612  
 READ:SQUality:RMS:EVM:DB:OFFSet?, 2-614  
 READ:SQUality:RMS:EVM:DB?, 2-614  
 READ:SQUality:RMS:EVM:OFFSet?, 2-615  
 READ:SQUality:RMS:EVM?, 2-613  
 READ:SQUality:RMS:FERRor?, 2-615  
 READ:SQUality:RMS:MERRor:DB?, 2-616  
 READ:SQUality:RMS:MERRor:DB?, 2-617  
 READ:SQUality:RMS:MERRor?, 2-616  
 READ:SQUality:RMS:PERRor?, 2-617  
 READ:SQUality:SYMBOL:LENGth?, 2-618  
 READ:SQUality:SYMBOL:RATE:ERRor?, 2-619  
 READ:SQUality:SYMBOL:RATE?, 2-618  
 READ:TDIagram:FERRor?, 2-619  
 READ:TDIagram:TRACe?, 2-620  
 READ:{AM|FM|PM}?, 2-506  
 READ:ACPower?, 2-504  
 READ:AM:AMINdex?, 2-507  
 READ:AM:AMNeGative?, 2-507  
 READ:AM:AMPositive?, 2-508  
 READ:AM:RESult?, 2-508  
 READ:AVTime:RESult?, 2-512  
 READ:CCDF?, 2-513  
 READ:CONSte:FERRor?, 2-516  
 READ:CONSte:TRACe?, 2-518

READ:DDEMod:STABle?, 2-518  
 READ:DIQVtime:I?, 2-519  
 READ:DIQVtime:Q?, 2-520  
 READ:EDIagram:I?, 2-525  
 READ:EDIagram:Q?, 2-526  
 READ:EVM:FERRor?, 2-526  
 READ:EVM:PEAK?, 2-527  
 READ:EVM:PINDex?, 2-527  
 READ:EVM:RMS?, 2-528  
 READ:EVM:TRACe?, 2-528  
 READ:FDVTime:TRACe?, 2-529  
 READ:FM:PHALf?, 2-531  
 READ:FM:PNEGative?, 2-531  
 READ:FM:PPOSitive?, 2-532  
 READ:FM:PTPeak?, 2-532  
 READ:FM:RESult?, 2-533  
 READ:FM:RMS?, 2-533  
 READ:FVTime?, 2-534  
 READ:FVTime:RESult?, 2-536  
 READ:IQVTime:I?, 2-537  
 READ:IQVTime:Q?, 2-540  
 READ:MERRor:FERRor?, 2-544  
 READ:MERRor:PEAK?, 2-544  
 READ:MERRor:PINDex?, 2-545  
 READ:MERRor:RMS?, 2-545  
 READ:MERRor:TRACe?, 2-546  
 READ:PERRor:FERRor?, 2-553  
 READ:PERRor:PEAK?, 2-554  
 READ:PERRor:PINDex?, 2-554  
 READ:PERRor:RMS, 2-555  
 READ:PERRor:TRACe?, 2-555  
 READ:PHVTime?, 2-556  
 READ:PM:PNEGative?, 2-559  
 READ:PM:PPOSitive?, 2-560  
 READ:PM:PTPeak?, 2-560  
 READ:PM:RESult?, 2-561  
 READ:PM:RMS?, 2-561  
 READ:PNOise:ALL?, 2-562  
 READ:PNOise:JITTer?, 2-564  
 READ:PULSe:TRACe:X?, 2-593  
 READ:SGRam?, 2-595  
 READ:SPURious:PASS?, 2-597  
 READ:SQUality:RHO?, 2-613  
 READ:TOVerview?, 2-620  
 Related Documentation, iii  
 \*RST, 2-621

## S

[SENSe]:{AM|FM|PM}:{BANDwidth|BWIDth}:  
 MEASurement, 2-636  
 [SENSe]:{AM|FM|PM}:  
 {MTPoints|MAXTracepoints}, 2-637  
 [SENSe]:{AM|FM|PM}:CLEar:RESults, 2-636  
 [SENSe]:{FM|PM}:BURSt:THREshold, 2-678  
 [SENSe]:{FM|PM}:FREQuency:OFFSet, 2-679  
 [SENSe]:{FM|PM}:FREQuency:OFFSet:  
 MARKer, 2-679  
 [SENSe]:{FM|PM}:FREQuency:SEARch:  
 AUTO, 2-680  
 [SENSe]:ACPower:{BANDwidth|BWIDth}:  
 VIDEo, 2-624  
 [SENSe]:ACPower:{BANDwidth|BWIDth}:VIDEo:  
 STATe, 2-625  
 [SENSe]:ACPower:{BANDwidth|BWIDth}[:  
 RESolution], 2-623  
 [SENSe]:ACPower:{BANDwidth|BWIDth}[:  
 RESolution]:ACTual?, 2-623  
 [SENSe]:ACPower:{BANDwidth|BWIDth}[:  
 RESolution]:AUTO, 2-624  
 [SENSe]:ACPower:AVERage, 2-622  
 [SENSe]:ACPower:AVERage:COUNt, 2-622  
 [SENSe]:ACPower:CHANnel:  
 {BANDwidth|BWIDth}, 2-625  
 [SENSe]:ACPower:CHANnel:FILTer, 2-626  
 [SENSe]:ACPower:CHANnel:PAIRs, 2-626  
 [SENSe]:ACPower:CHANnel:SPACing, 2-626  
 [SENSe]:ACPower:CHIPrate, 2-627  
 [SENSe]:ACPower:CLEar:RESults, 2-627  
 [SENSe]:ACPower:FREQuency, 2-628  
 [SENSe]:ACPower:FREQuency:STEP, 2-628  
 [SENSe]:ACPower:FREQuency:STEP:AUTO, 2-629  
 [SENSe]:ACPower:NFLoor:STATe, 2-629  
 [SENSe]:ACPower:OPTimize:SPAN, 2-630  
 [SENSe]:ACPower:RRCRolloff, 2-630  
 [SENSe]:ACQuisition:{BANDwidth|BWIDth}, 2-631  
 [SENSe]:ACQuisition:FFRame:ACTual?, 2-631  
 [SENSe]:ACQuisition:FFRame:LIMit, 2-632  
 [SENSe]:ACQuisition:FFRame:STATe, 2-632  
 [SENSe]:ACQuisition:MEMory:AVAILable:  
 SAMPlEs?, 2-633  
 [SENSe]:ACQuisition:MEMory:CAPacity[:  
 TIME]?, 2-633  
 [SENSe]:ACQuisition:MEMory:USED[:  
 PERCent]?, 2-634

- [SENSe]:ACQuisition:MODE, 2-634
- [SENSe]:ACQuisition:SAMPles, 2-635
- [SENSe]:ACQuisition:SEConds, 2-635
- [SENSe]:AM:DETECT:AMPLitude, 2-637
- [SENSe]:ANALysis:ADVanced:DITHer, 2-638
- [SENSe]:ANALysis:ADVanced:DITHer:HWARe:
  - STATus?, 2-638
- [SENSe]:ANALysis:LENGth, 2-639
- [SENSe]:ANALysis:LENGth:ACTual?, 2-639
- [SENSe]:ANALysis:LENGth:AUTO, 2-640
- [SENSe]:ANALysis:REFerence, 2-640
- [SENSe]:ANALysis:STARt, 2-641
- [SENSe]:ANALysis:STARt:AUTO, 2-641
- [SENSe]:AVTime: {BANDwidth|BWIDth}, 2-642
- [SENSe]:AVTime: {BANDwidth|BWIDth}:
  - ACTual?, 2-642
- [SENSe]:AVTime:CLear:RESults, 2-643
- [SENSe]:AVTime:MAXTracepoints, 2-643
- [SENSe]:AVTime:METHod, 2-644
- [SENSe]:CCDF: {BANDwidth|BWIDth}, 2-645
- [SENSe]:CCDF:TIME:TOTal:LENGth, 2-645
- [SENSe]:CCDF:TIME:TYPE, 2-646
- [SENSe]:DDEMod: {BANDwidth|BWIDth}:
  - TINterval, 2-649
- [SENSe]:DDEMod: {BANDwidth|BWIDth}:
  - TINterval:AUTO, 2-649
- [SENSe]:DDEMod:ANALysis:LENGth, 2-647
- [SENSe]:DDEMod:ANALysis:LENGth:
  - ACTual?, 2-647
- [SENSe]:DDEMod:ANALysis:LENGth:
  - AUTO, 2-648
- [SENSe]:DDEMod:BURSt:DETECT, 2-650
- [SENSe]:DDEMod:BURSt:THReshold, 2-650
- [SENSe]:DDEMod:CARRier:OFFSet, 2-651
- [SENSe]:DDEMod:CARRier:OFFSet:AUTO, 2-651
- [SENSe]:DDEMod:FILTer:ALPHa, 2-652
- [SENSe]:DDEMod:FILTer:MEASurement, 2-652
- [SENSe]:DDEMod:FILTer:REFerence, 2-653
- [SENSe]:DDEMod:FREQuency:DEViation, 2-654
- [SENSe]:DDEMod:FREQuency:DEViation:
  - AUTO, 2-655
- [SENSe]:DDEMod:MAGNitude:NORMAlize, 2-655
- [SENSe]:DDEMod:MINdex, 2-656
- [SENSe]:DDEMod:MINdex:AUTO, 2-657
- [SENSe]:DDEMod:MODulation:TYPE, 2-657
- [SENSe]:DDEMod:PRESet, 2-658
- [SENSe]:DDEMod:SRATe, 2-661
- [SENSe]:DDEMod:SWAP:IQ, 2-661
- [SENSe]:DDEMod:SYMBOL:HSSHift, 2-661
- [SENSe]:DDEMod:SYMBOL:MAP:SOURce?, 2-662
- [SENSe]:DDEMod:SYMBOL:MAP[:STATe], 2-662
- [SENSe]:DDEMod:SYMBOL:PLOT:POSition, 2-663
- [SENSe]:DDEMod:SYMBOL:POINts, 2-663
- [SENSe]:DDEMod:SYMBOL:RATE:SEARch, 2-664
- [SENSe]:DDEMod:SYNCh:WORD, 2-665
- [SENSe]:DDEMod:SYNCh:WORD:SYMBOL, 2-665
- [SENSe]:DDEMod:TIME:UNITs, 2-666
- [SENSe]:DPSA: {BANDwidth|BWIDth}:
  - ACTual?, 2-669
- [SENSe]:DPSA: {BANDwidth|BWIDth}:
  - OPTimization, 2-670
- [SENSe]:DPSA: {BANDwidth|BWIDth}[:
  - RESolution]:AUTO, 2-670
- [SENSe]:DPSA:AUDio:DEMod:GAIN, 2-666
- [SENSe]:DPSA:AUDio:DEMod:RXBWidth, 2-667
- [SENSe]:DPSA:AUDio:DEMod:
  - RXFRequency?, 2-667
- [SENSe]:DPSA:AUDio:DEMod:STATe, 2-668
- [SENSe]:DPSA:AUDio:DEMod:TUNE, 2-668
- [SENSe]:DPSA:AUDio:DEMod:TYPE, 2-669
- [SENSe]:DPSA:CLear:RESults, 2-671
- [SENSe]:DPSA:COLor:MAXimum, 2-672
- [SENSe]:DPSA:COLor:MINimum, 2-673
- [SENSe]:DPSA:DWELl:AUTO, 2-674
- [SENSe]:DPSA:FREQuency:CENTer, 2-674
- [SENSe]:DPSA:FREQuency:SPAN, 2-675
- [SENSe]:DPSA:FREQuency:SPAN:
  - {BANDwidth|BWIDth}[:RESolution]:
    - RATio, 2-675
- [SENSe]:DPSA:FREQuency:STARt, 2-676
- [SENSe]:DPSA:FREQuency:STEP, 2-676
- [SENSe]:DPSA:FREQuency:STEP:AUTO, 2-677
- [SENSe]:DPSA:FREQuency:STOP, 2-677
- [SENSe]:DPSA:POINts:COUNt, 2-678
- [SENSe]:FVTime:CLear:RESults, 2-680
- [SENSe]:FVTime:FREQuency:CENTer, 2-681
- [SENSe]:FVTime:FREQuency:SPAN, 2-681
- [SENSe]:FVTime:FREQuency:STARt, 2-682
- [SENSe]:FVTime:FREQuency:STEP, 2-682
- [SENSe]:FVTime:FREQuency:STEP:AUTO, 2-683
- [SENSe]:FVTime:FREQuency:STOP, 2-683
- [SENSe]:FVTime:MAXTracepoints, 2-684
- [SENSe]:IQVTime:CLear:RESults, 2-685
- [SENSe]:IQVTime:FREQuency:CENTer, 2-685

- [SENSe]:IQVTime:FREQuency:SPAN, 2-686  
[SENSe]:IQVTime:FREQuency:START, 2-686  
[SENSe]:IQVTime:FREQuency:STEP, 2-687  
[SENSe]:IQVTime:FREQuency:STEP:AUTO, 2-687  
[SENSe]:IQVTime:FREQuency:STOP, 2-688  
[SENSe]:IQVTime:MAXTracepoints, 2-688  
[SENSe]:MCPower: {BANDwidth|BWIDth}:  
  VIDeo, 2-691  
[SENSe]:MCPower: {BANDwidth|BWIDth}:VIDeo:  
  STATe, 2-692  
[SENSe]:MCPower: {BANDwidth|BWIDth}[:  
  RESolution], 2-690  
[SENSe]:MCPower: {BANDwidth|BWIDth}[:  
  RESolution]:ACTual?, 2-690  
[SENSe]:MCPower: {BANDwidth|BWIDth}[:  
  RESolution]:AUTO, 2-691  
[SENSe]:MCPower:AVERAge, 2-689  
[SENSe]:MCPower:AVERAge:COUNT, 2-689  
[SENSe]:MCPower:CHANnel:ADJacent:ADD, 2-692  
[SENSe]:MCPower:CHANnel:ADJacent:  
  DELete, 2-693  
[SENSe]:MCPower:CHANnel:FILTer, 2-693  
[SENSe]:MCPower:CHANnel:MAIN:  
  {BANDwidth|BWIDth}, 2-694  
[SENSe]:MCPower:CHANnel:MAIN:COUNT, 2-694  
[SENSe]:MCPower:CHANnel:MAIN:  
  INACTive, 2-695  
[SENSe]:MCPower:CHANnel:MAIN:  
  SPACing, 2-695  
[SENSe]:MCPower:CHIPrate, 2-696  
[SENSe]:MCPower:CLear:RESults, 2-696  
[SENSe]:MCPower:FREQuency, 2-696  
[SENSe]:MCPower:FREQuency:STEP, 2-697  
[SENSe]:MCPower:FREQuency:STEP:AUTO, 2-697  
[SENSe]:MCPower:NFLoor:STATe, 2-698  
[SENSe]:MCPower:OPTimize:SPAN, 2-698  
[SENSe]:MCPower:RCHannels:MAIN<x>, 2-699  
[SENSe]:MCPower:RCHannels:TOTal, 2-700  
[SENSe]:MCPower:RCHannels?, 2-699  
[SENSe]:MCPower:RRCRolloff, 2-700  
[SENSe]:MEASurement:FREQuency, 2-701  
[SENSe]:OBWidth: {BANDwidth|BWIDth}:  
  MEASurement, 2-702  
[SENSe]:OBWidth: {BANDwidth|BWIDth}:  
  VIDeo, 2-704  
[SENSe]:OBWidth: {BANDwidth|BWIDth}:VIDeo:  
  STATe, 2-705  
[SENSe]:OBWidth: {BANDwidth|BWIDth}[:  
  RESolution], 2-703  
[SENSe]:OBWidth: {BANDwidth|BWIDth}[:  
  RESolution]:ACTual?, 2-703  
[SENSe]:OBWidth: {BANDwidth|BWIDth}[:  
  RESolution]:AUTO, 2-704  
[SENSe]:OBWidth:AVERAge, 2-701  
[SENSe]:OBWidth:AVERAge:COUNT, 2-702  
[SENSe]:OBWidth:CLear:RESults, 2-705  
[SENSe]:OBWidth:FREQuency:CENTer, 2-706  
[SENSe]:OBWidth:FREQuency:STEP, 2-706  
[SENSe]:OBWidth:FREQuency:STEP:AUTO, 2-707  
[SENSe]:OBWidth:PERCent, 2-707  
[SENSe]:OBWidth:XDBLevel, 2-708  
[SENSe]:PHVTime:CLear:RESults, 2-708  
[SENSe]:PHVTime:FREQuency:CENTer, 2-708  
[SENSe]:PHVTime:FREQuency:SPAN, 2-709  
[SENSe]:PHVTime:FREQuency:START, 2-709  
[SENSe]:PHVTime:FREQuency:STEP, 2-710  
[SENSe]:PHVTime:FREQuency:STEP:AUTO, 2-711  
[SENSe]:PHVTime:FREQuency:STOP, 2-711  
[SENSe]:PHVTime:MAXTracepoints, 2-712  
[SENSe]:PM:PHASe:OFFSet, 2-712  
[SENSe]:PM:PHASe:OFFSet:MARKer, 2-713  
[SENSe]:PM:PHASe:SEARch:AUTO, 2-713  
[SENSe]:PNOise:AVERAge:COUNT, 2-714  
[SENSe]:PNOise:AVERAge:ENABLE, 2-714  
[SENSe]:PNOise:CARRier:FREQuency:  
  TRACk, 2-714  
[SENSe]:PNOise:CARRier:THReshold, 2-715  
[SENSe]:PNOise:CLear:RESults, 2-715  
[SENSe]:PNOise:FREQuency:INTegration:OFFSet:  
  START, 2-716  
[SENSe]:PNOise:FREQuency:INTegration:OFFSet:  
  STOP, 2-716  
[SENSe]:PNOise:FREQuency:PLOT:OFFSet:  
  START, 2-717  
[SENSe]:PNOise:FREQuency:PLOT:OFFSet:  
  STOP, 2-717  
[SENSe]:PNOise:OPTimization, 2-718  
[SENSe]:PULSe:ANALyze:LEVel, 2-719  
[SENSe]:PULSe:ANALyze:LEVel:FIFTy, 2-720  
[SENSe]:PULSe:ANALyze:LEVel:HUNDred, 2-720  
[SENSe]:PULSe:ANALyze:MEASurement:TIME:  
  AUTO, 2-721  
[SENSe]:PULSe:ANALyze:MEASurement:TIME:  
  START, 2-721

- [SENSe]:PULSe:ANALyze:MEASurement:TIME:STOP, 2-722
- [SENSe]:PULSe:ANALyze:PMLocation, 2-722
- [SENSe]:PULSe:ANALyze:POINt:LOCation, 2-723
- [SENSe]:PULSe:ANALyze:RFALL, 2-723
- [SENSe]:PULSe:ANALyze:RIPple, 2-724
- [SENSe]:PULSe:CARRier:OFFSet, 2-724
- [SENSe]:PULSe:CARRier:SEARch, 2-725
- [SENSe]:PULSe:DETECT:MEASurement, 2-725
- [SENSe]:PULSe:DETECT:NUMBER, 2-726
- [SENSe]:PULSe:DETECT:POWER[:THReshold], 2-726
- [SENSe]:PULSe:DETECT:TIME[:THReshold], 2-727
- [SENSe]:PULSe:FILTer:  
  {BANDwidth|BWIDth}, 2-727
- [SENSe]:PULSe:FILTer:MEASurement, 2-728
- [SENSe]:PULSe:FREference:AUTO, 2-729
- [SENSe]:PULSe:FREference:CHIRpbw, 2-729
- [SENSe]:PULSe:FREference:OFFSet, 2-730
- [SENSe]:PULSe:MODulation:TYPE, 2-730
- [SENSe]:PULSe:SIGNAL:TYPE, 2-731
- [SENSe]:ROSCillator:SOURce, 2-732
- [SENSe]:SGRam: {BANDwidth|BWIDth}:  
  OPTimization, 2-732
- [SENSe]:SGRam: {BANDwidth|BWIDth}:  
  RESolution, 2-733
- [SENSe]:SGRam: {BANDwidth|BWIDth}:  
  VIDeo, 2-735
- [SENSe]:SGRam: {BANDwidth|BWIDth}:VIDeo:  
  STATe, 2-735
- [SENSe]:SGRam: {BANDwidth|BWIDth}[:  
  RESolution]:ACTual?, 2-733
- [SENSe]:SGRam: {BANDwidth|BWIDth}[:  
  RESolution]:AUTO, 2-734
- [SENSe]:SGRam: {BANDwidth|BWIDth}[:  
  RESolution]:MODE, 2-734
- [SENSe]:SGRam:COLor:MAXimum, 2-737
- [SENSe]:SGRam:COLor:MINimum, 2-737
- [SENSe]:SGRam:FFT:WINDow, 2-738
- [SENSe]:SGRam:FILTer[:SHAPE], 2-738
- [SENSe]:SGRam:FREQuency:CENTer, 2-739
- [SENSe]:SGRam:FREQuency:SPAN, 2-739
- [SENSe]:SGRam:FREQuency:SPAN:BANDwidth[:  
  RESolution]:RATio, 2-740
- [SENSe]:SGRam:FREQuency:SPAN:  
  MAXimum, 2-740
- [SENSe]:SGRam:FREQuency:STARt, 2-741
- [SENSe]:SGRam:FREQuency:STEP, 2-741
- [SENSe]:SGRam:FREQuency:STEP:AUTO, 2-742
- [SENSe]:SGRam:FREQuency:STOP, 2-742
- [SENSe]:SPECtrum: {BANDwidth|BWIDth}:  
  OPTimization, 2-743
- [SENSe]:SPECtrum: {BANDwidth|BWIDth}:  
  VIDeo, 2-746
- [SENSe]:SPECtrum: {BANDwidth|BWIDth}:VIDeo:  
  STATe, 2-746
- [SENSe]:SPECtrum: {BANDwidth|BWIDth}[:  
  RESolution], 2-744
- [SENSe]:SPECtrum: {BANDwidth|BWIDth}[:  
  RESolution]:ACTual?, 2-744
- [SENSe]:SPECtrum: {BANDwidth|BWIDth}[:  
  RESolution]:AUTO, 2-745
- [SENSe]:SPECtrum: {BANDwidth|BWIDth}[:  
  RESolution]:MODE, 2-745
- [SENSe]:SPECtrum:CLEar:RESults, 2-747
- [SENSe]:SPECtrum:FFT:WINDow, 2-747
- [SENSe]:SPECtrum:FILTer[:SHAPE], 2-748
- [SENSe]:SPECtrum:FREQuency:CENTer, 2-748
- [SENSe]:SPECtrum:FREQuency:SPAN, 2-749
- [SENSe]:SPECtrum:FREQuency:SPAN:  
  BANDwidth[:RESolution]:RATio, 2-749
- [SENSe]:SPECtrum:FREQuency:STARt, 2-750
- [SENSe]:SPECtrum:FREQuency:STEP, 2-750
- [SENSe]:SPECtrum:FREQuency:STEP:AUTO, 2-751
- [SENSe]:SPECtrum:FREQuency:STOP, 2-751
- [SENSe]:SPECtrum:LENGth, 2-752
- [SENSe]:SPECtrum:LENGth:ACTual?, 2-753
- [SENSe]:SPECtrum:LENGth:AUTO, 2-753
- [SENSe]:SPECtrum:MAX:SPAN, 2-754
- [SENSe]:SPECtrum:POINts:COUNT, 2-754
- [SENSe]:SPECtrum:STARt, 2-755
- [SENSe]:SPECtrum:TIME:MODE, 2-755
- [SENSe]:SPURious:CARRier:  
  {BANDwidth|BWIDth}, 2-756
- [SENSe]:SPURious:CARRier:  
  {BANDwidth|BWIDth}:INTegration, 2-756
- [SENSe]:SPURious:CARRier:  
  {BANDwidth|BWIDth}[:RESolution], 2-757
- [SENSe]:SPURious:CARRier:  
  {BANDwidth|BWIDth}[:RESolution]:  
  AUTO, 2-757
- [SENSe]:SPURious:CARRier:DETECTION, 2-758
- [SENSe]:SPURious:CARRier:FREQuency, 2-758
- [SENSe]:SPURious:CARRier:THReshold, 2-759
- [SENSe]:SPURious:CLEar:RESults, 2-759

- [SENSe]:SPURious:LIST, 2-760
- [SENSe]:SPURious:MODE, 2-761
- [SENSe]:SPURious:OPTimization, 2-761
- [SENSe]:SPURious:POINts:COUNT, 2-762
- [SENSe]:SPURious:RANGe<x>:BANDwidth:  
VIDeo, 2-762
- [SENSe]:SPURious:RANGe<x>:BANDwidth:  
VIDeo:STATe, 2-763
- [SENSe]:SPURious:RANGe<x>:DETEction, 2-764
- [SENSe]:SPURious:RANGe<x>:EXCURsion, 2-764
- [SENSe]:SPURious:RANGe<x>:FILTer[:  
SHAPE], 2-765
- [SENSe]:SPURious:RANGe<x>:FILTer[:SHAPE]:  
BANDwidth, 2-765
- [SENSe]:SPURious:RANGe<x>:FILTer[:SHAPE]:  
BANDwidth:AUTO, 2-766
- [SENSe]:SPURious:RANGe<x>:FREQUency:  
START, 2-766
- [SENSe]:SPURious:RANGe<x>:FREQUency:  
STOP, 2-767
- [SENSe]:SPURious:RANGe<x>:LIMit:ABSolute:  
START, 2-768
- [SENSe]:SPURious:RANGe<x>:LIMit:ABSolute:  
STOP, 2-768
- [SENSe]:SPURious:RANGe<x>:LIMit:MASK, 2-769
- [SENSe]:SPURious:RANGe<x>:LIMit:RELative:  
START, 2-770
- [SENSe]:SPURious:RANGe<x>:LIMit:RELative:  
STOP, 2-770
- [SENSe]:SPURious:RANGe<x>:STATe, 2-771
- [SENSe]:SPURious:RANGe<x>:THREshold, 2-771
- [SENSe]:SPURious:REFerence, 2-772
- [SENSe]:SPURious:REFerence:MANual:  
POWER, 2-772
- [SENSe]:SPURious[:FREQUency]:OVERlap?, 2-760
- [SENSe]:TOVerview:FREQUency:CENTer, 2-773
- [SENSe]:TOVerview:MAXTracepoints, 2-773
- [SENSe]:AVTime:SPAN, 2-644
- [SENSe]:CCDF:CLEar, 2-645
- [SENSe]:DPSA:COLor, 2-671
- [SENSe]:DPSA:DWELl, 2-673
- [SENSe]:POWER:UNITs, 2-718
- [SENSe]:REANalyze, 2-731
- [SENSe]:SGRAM:COLor, 2-736
- [SENSe]:USEttings, 2-774
- \*SRE, 2-774
- STATus:{AM|FM|PM}:EVENTs?, 2-776
- STATus:ACPower:EVENTs?, 2-775
- STATus:AVTime:EVENTs?, 2-776
- STATus:CONStE:EVENTs?, 2-777
- STATus:DIQVtime:EVENTs?, 2-778
- STATus:EDIagram:EVENTs?, 2-779
- STATus:FDVTime:EVENTs?, 2-781
- STATus:FVTime:EVENTs?, 2-781
- STATus:IQVTime:EVENTs?, 2-782
- STATus:MCPower:EVENTs?, 2-782
- STATus:MERRor:EVENTs?, 2-783
- STATus:OBWidth:EVENTs?, 2-784
- STATus:OPERation:CONDition?, 2-784
- STATus:OPERation:ENABle, 2-785
- STATus:OPERation:NTRansition, 2-786
- STATus:OPERation:PTRansition, 2-786
- STATus:OPERation[:EVENT]?, 2-785
- STATus:PERRor:EVENTs?, 2-787
- STATus:PHVTime:EVENTs?, 2-788
- STATus:PNOise:EVENTs?, 2-788
- STATus:PULSe:RESult:EVENTs?, 2-789
- STATus:PULSe:STATistics:EVENTs?, 2-790
- STATus:PULSe:TRACe:EVENTs?, 2-791
- STATus:QUESTionable:CALibration:  
CONDition?, 2-791
- STATus:QUESTionable:CALibration:ENABle, 2-792
- STATus:QUESTionable:CALibration:  
NTRansition, 2-793
- STATus:QUESTionable:CALibration:  
PTRansition, 2-793
- STATus:QUESTionable:CALibration[:EVENT]?, 2-792
- STATus:QUESTionable:CONDition?, 2-794
- STATus:QUESTionable:ENABle, 2-795
- STATus:QUESTionable:FREQUency:  
CONDition?, 2-796
- STATus:QUESTionable:FREQUency:ENABle, 2-796
- STATus:QUESTionable:FREQUency:  
NTRansition, 2-797
- STATus:QUESTionable:FREQUency:  
PTRansition, 2-798
- STATus:QUESTionable:FREQUency[:EVENT]?, 2-797
- STATus:QUESTionable:NTRansition, 2-798
- STATus:QUESTionable:PTRansition, 2-799
- STATus:QUESTionable[:EVENT]?, 2-795
- STATus:SGRAM:EVENTs?, 2-800
- STATus:SPECTrum:EVENTs?, 2-800
- STATus:SPURious:EVENTs?, 2-801
- STATus:SQUALity:EVENTs?, 2-801

STATus:TDIagram:EVENTs?, 2-802  
 STATus:CCDF:EVENTs?, 2-777  
 STATus:DPSA:EVENTs?, 2-779  
 STATus:EVM:EVENTs?, 2-780  
 STATus:PRESet, 2-789  
 \*STB?, 2-803  
 SYSTem:COMMunicate:GPIB[:SELF]:  
   ADDRess, 2-803  
 SYSTem:ERRor:CODE:ALL?, 2-805  
 SYSTem:ERRor:CODE[:NEXT]?, 2-805  
 SYSTem:ERRor[:NEXT]?, 2-807  
 SYSTem:DATE, 2-804  
 SYSTem:ERRor:ALL?, 2-804  
 SYSTem:ERRor:COUNt?, 2-806  
 SYSTem:OPTions?, 2-807  
 SYSTem:PRESet, 2-808  
 SYSTem:TIME, 2-808  
 SYSTem:VERSion?, 2-809

## T

TRACe: {AM|FM|PM}:DETection, 2-810  
 TRACe: {AM|FM|PM}:FREeze, 2-810  
 TRACe: {AM|FM|PM}:FUNCTion, 2-811  
 TRACe:DIQVtime:ENABle:I, 2-821  
 TRACe:DIQVtime:ENABle:Q, 2-822  
 TRACe:DIQVtime:SELeCt:I, 2-822  
 TRACe:DIQVtime:SELeCt:Q, 2-823  
 TRACe:EDIagram:ENABle:I, 2-831  
 TRACe:EDIagram:ENABle:Q, 2-831  
 TRACe:EDIagram:SELeCt:I, 2-832  
 TRACe:EDIagram:SELeCt:Q, 2-832  
 TRACe:FVTime:AVERAge:COUNt, 2-833  
 TRACe:FVTime:COUNt:ENABle, 2-834  
 TRACe:FVTime:COUNt:RESet, 2-835  
 TRACe:FVTime:FUNCTion, 2-836  
 TRACe:IQVTime:AVERAge:COUNt, 2-837  
 TRACe:IQVTime:COUNt:ENABle, 2-838  
 TRACe:IQVTime:COUNt:RESet, 2-838  
 TRACe:IQVTime:DETection, 2-839  
 TRACe:IQVTime:ENABle:I, 2-839  
 TRACe:IQVTime:ENABle:Q, 2-840  
 TRACe:IQVTime:FREeze, 2-840  
 TRACe:IQVTime:FUNCTion, 2-841  
 TRACe:IQVTime:SELeCt:I, 2-841  
 TRACe:IQVTime:SELeCt:Q, 2-842  
 TRACe:PHVTime:AVERAge:COUNt, 2-844  
 TRACe:PHVTime:COUNt:ENABle, 2-845  
 TRACe:PHVTime:COUNt:RESet, 2-845  
 TRACe:PHVTime:FREeze, 2-846  
 TRACe:PHVTime:FUNCTion, 2-847  
 TRACe:SGRam:DETection, 2-850  
 TRACe:SGRam:FUNCTion, 2-851  
 TRACe:SGRam:FUNCTion:TIME, 2-852  
 TRACe:SGRam:SELeCt:LINE, 2-852  
 TRACe:SPURious:COUNt, 2-860  
 TRACe:SPURious:COUNt:ENABle, 2-860  
 TRACe:SPURious:COUNt:RESet, 2-861  
 TRACe:SPURious:FREeze, 2-861  
 TRACe:SPURious:FUNCTion, 2-862  
 TRACe: {AM|FM|PM}, 2-809  
 TRACe:CONSte:MODE, 2-821  
 TRACe:FVTime, 2-833  
 TRACe:FVTime:COUNt, 2-834  
 TRACe:FVTime:FREeze, 2-836  
 TRACe:IQVTime:COUNt, 2-837  
 TRACe:OBW:MAXHold, 2-843  
 TRACe:PHVTime, 2-843  
 TRACe:PHVTime:COUNt, 2-844  
 TRACe:SGRam:FREeze, 2-851  
 TRACe<x>:AVTime:AVERAge:COUNt, 2-812  
 TRACe<x>:AVTime:AVERAge:RESet, 2-812  
 TRACe<x>:AVTime:COUNt, 2-813  
 TRACe<x>:AVTime:COUNt:ENABle, 2-813  
 TRACe<x>:AVTime:COUNt:RESet, 2-814  
 TRACe<x>:AVTime:DETection, 2-814  
 TRACe<x>:AVTime:FREeze, 2-815  
 TRACe<x>:AVTime:FUNCTion, 2-815  
 TRACe<x>:AVTime:LEFTooperand, 2-816  
 TRACe<x>:AVTime:RIGHToperand, 2-817  
 TRACe<x>:AVTime:SELeCt, 2-817  
 TRACe<x>:CCDF:FREeze, 2-818  
 TRACe<x>:CCDF:SELeCt, 2-818  
 TRACe<x>:DPSA:AVERAge:COUNt, 2-824  
 TRACe<x>:DPSA:COLor:CURVe, 2-824  
 TRACe<x>:DPSA:COLor:INTensity, 2-825  
 TRACe<x>:DPSA:COLor:SCALE:AUTo, 2-825  
 TRACe<x>:DPSA:DETection, 2-826  
 TRACe<x>:DPSA:DOT:PERsistent, 2-826  
 TRACe<x>:DPSA:DOT:PERsistent:TYPE, 2-827  
 TRACe<x>:DPSA:DOT:PERsistent:VARiable, 2-827  
 TRACe<x>:DPSA:FREeze, 2-828  
 TRACe<x>:DPSA:FUNCTion, 2-828  
 TRACe<x>:DPSA:LEFTooperand, 2-829  
 TRACe<x>:DPSA:RIGHToperand, 2-830

- TRACe<x>:DPSA:SElect, 2-830
- TRACe<x>:FVTime:DETection, 2-835
- TRACe<x>:PHVTime:DETection, 2-846
- TRACe<x>:PNOise:SElect, 2-847
- TRACe<x>:PNOise:SHOW, 2-848
- TRACe<x>:PNOise:SMOothing:COUNT, 2-848
- TRACe<x>:PNOise:SMOothing:ENABle, 2-849
- TRACe<x>:PNOise:SMOothing:RESet, 2-849
- TRACe<x>:SPECTrum:AVERAge:COUNT, 2-853
- TRACe<x>:SPECTrum:AVERAge:RESet, 2-854
- TRACe<x>:SPECTrum:COUNT, 2-854
- TRACe<x>:SPECTrum:COUNT:ENABle, 2-855
- TRACe<x>:SPECTrum:COUNT:RESet, 2-855
- TRACe<x>:SPECTrum:DETection, 2-856
- TRACe<x>:SPECTrum:FREeze, 2-857
- TRACe<x>:SPECTrum:FUNCTion, 2-857
- TRACe<x>:SPECTrum:LEFTooperand, 2-858
- TRACe<x>:SPECTrum:RIGHTooperand, 2-858
- TRACe<x>:SPECTrum:SElect, 2-859
- TRACe<x>:AVTime, 2-811
- TRACe<x>:CCDF:SHOW, 2-819
- TRACe<x>:CCDF:X, 2-820
- TRACe<x>:CCDF:Y?, 2-820
- TRACe<x>:DPSA, 2-823
- TRACe<x>:SPECTrum, 2-853
- TRACe1:TOVerview:AVERAge:COUNT, 2-863
- TRACe1:TOVerview:COUNT, 2-863
- TRACe1:TOVerview:COUNT:ENABle, 2-863
- TRACe1:TOVerview:COUNT:RESet, 2-864
- TRACe1:TOVerview:DETection, 2-864
- TRACe1:TOVerview:FREeze, 2-865
- TRACe1:TOVerview:FUNCTion, 2-865
- TRACe1:TOVerview, 2-862
- \*TRG, 2-866
- TRIGger:DPSA:SHOW:FRAMES, 2-866
- TRIGger:MASK:NEW:AUTO, 2-868
- TRIGger[:SEquence]:ADVanced:HOLDoff, 2-870
- TRIGger[:SEquence]:ADVanced:HOLDoff:  
ENABle, 2-871
- TRIGger[:SEquence]:ADVanced:SWEep:  
MODE, 2-871
- TRIGger[:SEquence]:ADVanced:SWEpt:SEGment:  
ENABle, 2-872
- TRIGger[:SEquence]:EVENT:EXTFront:  
IMPedance, 2-872
- TRIGger[:SEquence]:EVENT:EXTFront:  
LEVel, 2-873
- TRIGger[:SEquence]:EVENT:EXTFront:  
SLOPe, 2-873
- TRIGger[:SEquence]:EVENT:EXTRear:  
SLOPe, 2-873
- TRIGger[:SEquence]:EVENT:GATed, 2-874
- TRIGger[:SEquence]:EVENT:INPut:DDENSity:  
AMPLitude, 2-874
- TRIGger[:SEquence]:EVENT:INPut:DDENSity:  
AMPLitude:TOLerance, 2-875
- TRIGger[:SEquence]:EVENT:INPut:DDENSity:  
FREQuency, 2-876
- TRIGger[:SEquence]:EVENT:INPut:DDENSity:  
FREQuency:TOLerance, 2-876
- TRIGger[:SEquence]:EVENT:INPut:DDENSity:  
THReshold, 2-877
- TRIGger[:SEquence]:EVENT:INPut:DDENSity:  
VIOLation, 2-877
- TRIGger[:SEquence]:EVENT:INPut:FMASK:  
{BANDwidth|BWIDth}{:RESolution}, 2-878
- TRIGger[:SEquence]:EVENT:INPut:FMASK:  
BANDwidth|BWIDth[:RESolution]:  
ACTual?, 2-878
- TRIGger[:SEquence]:EVENT:INPut:FMASK:  
BANDwidth|BWIDth[:RESolution]:AUTO, 2-879
- TRIGger[:SEquence]:EVENT:INPut:FMASK:  
VIOLation, 2-879
- TRIGger[:SEquence]:EVENT:INPut:LEVel, 2-880
- TRIGger[:SEquence]:EVENT:INPut:RUNT:  
PULSe, 2-881
- TRIGger[:SEquence]:EVENT:INPut:RUNT:PULSe:  
HIGH:LEVel, 2-882
- TRIGger[:SEquence]:EVENT:INPut:RUNT:PULSe:  
LOW:LEVel, 2-881
- TRIGger[:SEquence]:EVENT:INPut:SLOPe, 2-882
- TRIGger[:SEquence]:EVENT:INPut:  
TDBWidth, 2-883
- TRIGger[:SEquence]:EVENT:INPut:TDBWidth:  
ACTual?, 2-883
- TRIGger[:SEquence]:EVENT:INPut:TDBWidth:  
STATe, 2-884
- TRIGger[:SEquence]:EVENT:INPut:TYPE, 2-884
- TRIGger[:SEquence]:EVENT:SOURce, 2-885
- TRIGger[:SEquence]:FORCed, 2-885
- TRIGger[:SEquence]:IMMEDIATE, 2-886
- TRIGger[:SEquence]:STATus, 2-886
- TRIGger[:SEquence]:TIME:DELay, 2-887
- TRIGger[:SEquence]:TIME:POSition, 2-887



TRIGger[:SEQuence]:TIME:QUALified, 2-888  
TRIGger[:SEQuence]:TIME:QUALified:  
  TIME<x>, 2-888  
TRIGger:MASK:NEW, 2-867  
TRIGger:MASK:OPEN, 2-869  
TRIGger:MASK:SAVE, 2-870

**U**

UNIT:POWer, 2-889

**W**

\*WAI, 2-890