

WARNING

THE FOLLOWING SERVICING INSTRUCTIONS ARE FOR USE BY QUALIFIED PERSONNEL ONLY. TO AVOID PERSONAL INJURY, DO NOT PERFORM ANY SERVICING OTHER THAN THAT CONTAINED IN OPERATING INSTRUCTIONS UNLESS YOU ARE QUALIFIED TO DO SO.

TEKTRONIX®

465

OSCILLOSCOPE

WITH OPTIONS

(SN B250000 & UP)

SERVICE

INSTRUCTION MANUAL

TABLE OF CONTENTS

	Page
LIST OF TABLES	iv
LIST OF ILLUSTRATIONS	v
SECTION 1	SPECIFICATIONS
	Introduction 1-1
	VERTICAL DEFLECTION 1-1
	TRIGGERING 1-1
	HORIZONTAL DEFLECTION SYSTEM 1-2
	X-Y OPERATION 1-2
	CALIBRATOR 1-3
	Z-AXIS INPUT 1-3
	SIGNAL OUTPUTS 1-3
	POWER SOURCE 1-3
	CATHODE RAY TUBE (CRT) 1-3
	SUPPLEMENTAL INFORMATION 1-3
	Vertical Deflection System 1-3
	Triggering 1-4
	Horizontal Deflection System 1-4
	Calibrator 1-4
	External Z-Axis Input 1-4
	Output Resistances 1-4
	Cathode Ray Tube (CRT) 1-4
SECTION 2	OPERATING INFORMATION
	Introduction 2-1
	Operating Voltage 2-1
	CONTROLS AND CONNECTORS 2-2
	Introduction 2-2
	Cathode Ray Tube (CRT) and Display 2-2
	Vertical Deflection System Channel 1 and Channel 2 2-2
	A and B Triggering 2-4
	A and B Sweep 2-5
	Calibrator and Power 2-6
	Rear Panel 2-6
	OBTAINING BASIC DISPLAYS 2-6
	Introduction 2-6
	Normal Sweep Display 2-6
	Magnified Sweep Display 2-7
	Delayed Sweep Display 2-7
	Mixed Sweep Display 2-7
	X-Y Display 2-7
SECTION 3	CIRCUIT DESCRIPTION
	Introduction 3-1
	Digital Logic 3-1
	BLOCK DIAGRAM 3-1
	CHANNEL 1 PREAMP 3-3
	Introduction 3-3
	Scale Factor Switching 3-4
	Input Coupling 3-4
	Input Attenuator 3-4
	Source Follower 3-4
	First Cascode Amplifier 3-5
	Second Cascode Amplifier 3-5
	Third Cascode Amplifier 3-5

TABLE OF CONTENTS (cont)

SECTION 3	CIRCUIT DESCRIPTION (cont)	Page
	CHANNEL 2 PREAMP	3-5
	Introduction	3-5
	Second Cascode Amplifier	3-5
	Third Cascode Amplifier	3-6
	VERTICAL SWITCHING CIRCUIT	3-6
	Introduction	3-6
	Diode Gates	3-6
	Switching Multivibrator	3-7
	Delay Line Driver	3-9
	Reference Feedback Amplifier	3-9
	Normal Trigger Pickoff	3-9
	VERTICAL OUTPUT AMPLIFIER	3-9
	Introduction	3-9
	Delay Line	3-9
	Vertical Output Amplifier—Discrete Version	3-9
	Vertical Output Amplifier—IC Version	3-10
	A AND B TRIGGER GENERATORS	3-10
	Introduction	3-10
	Trigger Source	3-10
	Trigger Coupling	3-10
	Input Source Follower	3-10
	Paraphase Amplifier	3-10
	Tunnel Diode Driver	3-11
	A AND B SWEEP GENERATOR	3-11
	Introduction	3-11
	Disconnect Amplifier	3-12
	Output Buffer Amplifier	3-12
	Sweep Start Amplifier	3-12
	Logic Multivibrator	3-12
	B Sweep Differences	3-12
	SWEEP AND Z-AXIS LOGIC CIRCUIT	3-13
	Introduction	3-13
	A Sweep Gate	3-13
	B Sweep Gate	3-13
	Sweep Control Integrated Circuit	3-13
	Holdoff Timing	3-14
	A Sweep Holdoff Amplifier	3-14
	B Sweep Holdoff Amplifier	3-14
	B Sweep Latch	3-14
	A Sweep Z-Axis Gate	3-14
	B Sweep Z-Axis	3-15
	A +Gate and B +Gate Emitter Followers	3-15
	HORIZONTAL AMPLIFIER	3-15
	Introduction	3-15
	X-Axis Amplifier	3-15
	Input Paraphase Amplifier	3-16
	Gain Setting Amplifier	3-16
	Output Amplifier	3-16
	CRT CIRCUIT	3-17
	Introduction	3-17
	High Voltage Oscillator	3-17
	High Voltage Regulator	3-18
	High Voltage Rectifier and Output	3-18
	CRT Control Circuits	3-18
	Z-Axis Amplifier	3-18
	DC Restorer Circuit	3-19

TABLE OF CONTENTS (cont)

SECTION 3	CIRCUIT DESCRIPTION (cont)	Page
	CALIBRATOR	3-19
	Introduction	3-19
	Multivibrator	3-19
	Output Amplifier	3-19
	A TRIGGER VIEW AMPLIFIER	3-20
	Introduction	3-20
	Amplifier	3-20
	LOW VOLTAGE POWER SUPPLY	3-20
	Introduction	3-20
	Power Input	3-20
	Secondary Circuit	3-20
	FAN MOTOR CIRCUIT	3-22
SECTION 4	MAINTENANCE	
	Introduction	4-1
	CABINET AND RACK ADAPTER REMOVAL	4-1
	PREVENTIVE MAINTENANCE	4-3
	Introduction	4-3
	Cleaning	4-3
	Visual Inspection	4-4
	Lubrication	4-5
	Semiconductor Checks	4-5
	Recalibration	4-5
	TROUBLESHOOTING	4-5
	Introduction	4-5
	Troubleshooting Aids	4-5
	Troubleshooting Equipment	4-7
	Troubleshooting Techniques	4-7
	CORRECTIVE MAINTENANCE	4-9
	Introduction	4-9
	Obtaining Replacement Parts	4-9
	Soldering Techniques	4-10
	Component Removal and Replacement	4-11
	Recalibration After Repair	4-16
	Instrument Repackaging	4-16
	RACKMOUNTING	4-17
SECTION 5	PERFORMANCE CHECK	
	Purpose	5-1
	Limits and Tolerances	5-1
	Line Voltage Selection	5-1
	Equipment Required	5-1
	Special Fixtures	5-1
	Test Equipment Alternatives	5-1
	Preparation	5-1
	INDEX TO PERFORMANCE CHECK	5-1
	VERTICAL	5-3
	TRIGGERS	5-7
	HORIZONTAL	5-10

TABLE OF CONTENTS (cont)

SECTION 6	CALIBRATION	Page
	Purpose	6-1
	Limits and Tolerances	6-1
	Step Titles	6-1
	Line Voltage Selection	6-1
	Internal Adjustments	6-1
	Display	6-1
	Test Equipment Required	6-1
	Interactions	6-1
	Preparation	6-1
	INDEX TO CALIBRATION PROCEDURE	6-5
	POWER SUPPLY	6-8
	DISPLAY AND Z-AXIS	6-10
	VERTICAL	6-12
	TRIGGERS	6-24
	HORIZONTAL	6-35
	GATES, CALIBRATOR AND EXT Z-AXIS	6-43
SECTION 7	ELECTRICAL PARTS LIST	7-1
	OPTIONS	TAB PAGE
SECTION 8	DIAGRAMS	
SECTION 9	MECHANICAL PARTS LIST	9-1
CHANGE INFORMATION		

LIST OF TABLES


Table		Page
2-1	REGULATING RANGES	2-1
3-1	GAIN SWITCHING AND ATTENUATION	3-4
5-1	DEFLECTION FACTOR ACCURACY	5-5
5-2	LOW FREQUENCY COMPENSATION SETUP	5-5
5-3	A AND B TIMING ACCURACY	5-10
5-4	DELAY OR DIFFERENTIAL TIME ACCURACY	5-11
6-1	ADJUSTMENT INTERACTIONS	6-2
6-2	TEST EQUIPMENT REQUIRED	6-3
6-3	LOW VOLTAGE POWER SUPPLY LIMITS	6-8
6-4	TYPICAL LOW VOLTAGE POWER SUPPLY RIPPLE ..	6-9
6-5	VERTICAL DEFLECTION FACTOR ACCURACY	6-16
6-6	A AND B TIMING ACCURACY	6-39
6-7	A AND B MAGNIFIED ACCURACY	6-39
6-8	DIFFERENTIAL TIME ACCURACY	6-40

OPTION 7, TABLE 1 POWER SETTINGS

OPTION 7, PAGE 1

LIST OF ILLUSTRATIONS

	Page
Fig 1-1	465 Oscilloscope
Fig. 2-1	Power supply regulating range selector. 2-2
Fig. 2-2	Front and rear panel controls and connectors. 2-3
Fig. 3-1	Basic block diagram of the 465. 3-2
Fig. 3-2	Detailed block diagram of the Channel 1 Preamplifier. 3-3
Fig. 3-3	Detailed block diagram of the Channel 2 Preamplifier. 3-6
Fig. 3-4	Detailed block diagram of the Vertical Switching Circuit. 3-7
Fig. 3-5	Effect of Diode Gates on signal path (simplified Vertical Switching diagram). Conditions shown for CH 1 position of Vertical Mode switch. 3-8
Fig. 3-6	Detailed block diagram of the A Sweep Generator. 3-11
Fig. 3-7	Detailed block diagram of the Horizontal Amplifier. 3-16
Fig. 3-8	Detailed block diagram of the CRT and Z-Axis circuits. 3-17
Fig. 3-9	Detailed block diagram of the Calibrator circuit. 3-19
Fig. 3-10	Detailed block diagram of the Trigger View Amplifier. 3-20
Fig. 3-11	Detailed block diagram of the Low Voltage Power Supply. 3-21
Fig. 3-12	Foldover circuit action. 3-22
Fig. 4-1	Removing the wrap around cabinet. 4-1
Fig. 4-2	Color codes. 4-6
Fig. 4-3	Slide-out track assemblies. 4-9
Fig. 4-4	Hardware to mount instrument in the rack. 4-19
Fig. 4-5	Locating mounting holes for stationary sections. 4-20
Fig. 4-6	Mounting the stationary section to front rails. 4-20
Fig. 4-7	Supporting the rear of the stationary sections. 4-21
Fig. 4-8	Rear support kit. 4-22
Fig. 4-9	Installing the support block on the instrument. 4-22
Fig. 4-10	Inserting or removing the instrument with slide-out tracks. 4-23
Fig. 4-11	Alignment adjustments for correct operation. 4-24
Fig. 4-12	Alternative method of installing the instrument. 4-24
Fig. 4-13	Dimensional drawing. 4-25
Fig. 8-1	Semiconductor lead configurations.
Fig. 8-2	A4—Vertical Mode Switch board.
Fig. 8-3	A1 & A2 Attenuators and A3—Vertical Preamp boards.
Fig. 8-4	A5a—Vertical Output Amplifier board (discrete).
Fig. 8-5	A5b—Vertical Output Amplifier board (IC).
Fig. 8-6	A8—Trigger Generator and Sweep Logic board.
Fig. 8-7	A9 Interface board.
Fig. 8-8	A7—Timing board.
Fig. 8-9	A6—Fan board.
Fig. 8-10	Partial A8—Trigger Gen and Sweep Logic board.
Fig. 8-11	Partial A9—Interface board.
Fig. 8-12	Interface board adjustment locations.
Fig. 8-13	Vert Preamp & Atten board adjustment locations.
Fig. 8-14	Vert Output Ampl adjustment locations (discrete).
Fig. 8-15	Vert Output Ampl adjustment locations (IC).
Fig. 8-16	Trigger Gen & Sweep Logic adjustment locations.
Fig. 8-17	Timing board adjustment locations.



1861-19

Fig. 1-1. 465 Oscilloscope.

SPECIFICATIONS

Introduction

The 465 Oscilloscope is a wide-band, portable oscilloscope designed to operate in a wide range of environmental conditions. The instrument is light in weight and compact of design for ease of transportation, yet capable of performance necessary for accurate high-frequency measurements. The dual-channel dc-to-100 megahertz vertical deflection system provides calibrated deflection factors from 5 millivolts to 5 volts/division. The bandwidth limiting switch reduces interference from signals above about 20 megahertz for viewing low-frequency, low-level signals.

The trigger circuits provide stable sweep triggering to beyond the bandwidth of the vertical deflection system. Separate controls are provided to select the desired mode of triggering for the A and B sweeps. The A sweep can be operated in one of three modes: automatic triggering, normal triggering, or single sweep. A variable trigger holdoff control provides the ability for A sweep to trigger stably on aperiodic signals or complex digital words. The horizontal deflection system has calibrated sweep rates from 0.5 second to 0.05 microsecond/division. A X10 magnifier increases each sweep rate by a factor of 10 to provide a maximum sweep rate of 5 nanoseconds/division in the 0.05 μ s position. The delayed and mixed sweep features allow the start of the B sweep to be delayed a selected amount from the start of A sweep to provide accurate relative-time measurements. Calibrated X-Y measurements can be made with Channel 2 providing the vertical deflection and Channel 1 providing the horizontal deflection (TIME/DIV switch fully counterclockwise and VERT MODE switch to CH 2). The regulated dc power supplies ensure that instrument performance is not affected by variations in line voltage and frequency. Maximum power consumption of the instrument is approximately 75 watts.

The following instrument specifications apply over an ambient temperature range of -15°C to $+55^{\circ}\text{C}$ unless otherwise specified. Warm-up time for specified accuracies is 20 minutes. The calibration procedure given in section 6, if performed completely, will allow an instrument to meet the electrical characteristics listed below.

VERTICAL DEFLECTION SYSTEM

Deflection Factor

Calibrated range is from 5 millivolts to 5 volts/division in 10 steps in a 1-2-5 sequence. Accuracy is within 3%. Uncalibrated VAR control provides deflection factors continuously variable between the calibrated settings and extends deflection factor to at least 12.5 volts/division in the 5 VOLTS/DIV position.

Frequency Response

Bandwidth in both Channel 1 and Channel 2 is dc to at least 100 megahertz from -15°C to -40°C and dc to at least 85 megahertz from -40°C to -55°C . Risetime is 3.5 nanoseconds or less from 0°C to $+40^{\circ}\text{C}$ and 4.2 nanoseconds or less from -40°C to -55°C . The ac-coupled lower 3 dB point is 10 hertz or less (1 hertz or less when using a 10X probe). Vertical system bandwidth with the BW LIMIT pushbutton pulled is approximately 20 megahertz.

Chopped Mode Repetition Rate

Approximately 250 kilohertz.

Input Resistance And Capacitance

One megohm within 2% paralleled by approximately 20 picofarads.

Maximum Input Voltage

Dc coupled: 250 V (dc + peak ac) or 500 V p-p ac at 1 kHz or less.

Ac coupled: 500 V (dc + peak ac) or 500 V p-p ac at 1 kHz or less.

Cascaded Operation (CH 1 VERT SIGNAL OUT Connected to CH 2 OR Y)

Bandwidth is dc to at least 50 MHz with a sensitivity of at least 1 millivolt/division.

TRIGGERING

Sensitivity

DC Coupled: 0.3 division internal or 50 millivolts external from dc to 25 megahertz, increasing to 1.5 divisions internal or 150 millivolts external at 100 megahertz.

AC Coupled: 0.3 division internal or 50 millivolts external from 60 hertz to 25 megahertz, increasing to 1.5 divisions internal or 150 millivolts external at 100 megahertz. Attenuates all signals below about 60 hertz.

LF REJ Coupled: 0.5 division internal or 100 millivolts external from 50 kilohertz to 25 megahertz, increasing to 1.5 divisions internal or 300 millivolts external at

Specifications—465 Service (SN B250000 & up)

100 megahertz. Blocks dc and attenuates all signals below about 50 kilohertz.

HF REJ Coupled: 0.5 division internal or 100 millivolts external from 60 hertz to 50 kilohertz. Blocks dc and attenuates all signals below about 60 hertz and above about 50 kilohertz.

Trigger Jitter

0.5 nanosecond or less at 5 nanoseconds/division with 100 megahertz applied (X10 MAG on).

External Trigger Input

Maximum input voltage is 250 volts (dc + peak ac) or 250 volts peak to peak ac (1 kilohertz or less). Input resistance is 1 megohm within 10%.

Level Range

EXT: At least + and -2 volts, 4 volts peak to peak.

EXT ÷10: At least + and -20 volts, 40 volts peak to peak.

HORIZONTAL DEFLECTION SYSTEM

Calibrated Sweep Range

A Sweep: From 0.5 second/division to 0.05 microsecond/division in 22 steps in a 1-2-5 sequence. X10 MAG extends maximum sweep rate to 5 nanoseconds/division.

B Sweep: From 50 milliseconds/division to 0.05 microsecond/division in 19 steps in a 1-2-5 sequence. X10 MAG extends maximum sweep rate to 5 nanoseconds/division.

Calibrated Sweep Accuracy

Unmagnified sweep accuracy is within 2% from +20°C to -30°C (+68°F to -86°F) and within 3% from -15°C to -20°C and +30°C to +55°C (+5°F to +68°F and -86°F to +131°F). For the same temperature ranges, magnified sweep accuracy is within 3% and within 4% respectively. Exclude the first and last 50 nanoseconds of the 5 nanoseconds, 10 nanoseconds, and 20 nanoseconds magnified sweep rates. Accuracy specifications apply over full 10 divisions unless otherwise specified.

Sweep accuracy, over any 2 or less division portion of the sweep, is within 5%. Exclude the first and last magnified divisions of the 5 nanosecond and

10 nanosecond/division magnified sweep rates. Also exclude the first and last 50 nanoseconds of the 5, 10, and 20 nanoseconds/division sweep rates.

Mixed sweep accuracy is within 2% plus the measured A sweep error when viewing the A sweep portion only. The B sweep portion retains its normal accuracy. The following exclusion applies: First .5 division after display start, and first .2 division or .1 μ s (whichever is greater) after transition of A to B.

A Time/Division Variable Range

Provides continuously variable (Uncalibrated) sweep rates between the calibrated settings of the A TIME/DIV switch. Extends the slowest A sweep rate to at least 1.25 seconds/division.

A Trigger Holdoff

Increases A sweep holdoff time by at least a factor of 10.

Delay Time And Differential Time Measurement Accuracy

	+10°C to +35°C (+50°F to +95°F)	-15°C to +55°C (+5°F to +131°F)
Over 1 Or More Major Dial Division	±1%	±2.5%
Over Less Than 1 Major Dial Division	±0.01 Major Dial Division	±0.03 Major Dial Division

Delay or Differential Time Jitter

Within 0.002% (less than one part in 50,000) of the maximum available delay time when operating on power line frequencies other than 50 hertz.

Within 0.005% (less than one part in 20,000) of the maximum available delay time when operating on 50 hertz power line frequency.

Maximum available delay time is 10 times the setting of the A TIME/DIV switch.

Calibrated Delay Time (A VAR set to calibrated position)

Continuous from 5 seconds to 0.2 microsecond.

X-Y OPERATION

Sensitivity

Same as vertical deflection system.

X Axis deflection accuracy within 4%.

Specifications—465 Service (SN B250000 & up)

Variable Range

Same as vertical deflection system.

X-Axis Bandwidth

Dc to at least 4 megahertz.

Y-Axis Bandwidth

Same as vertical deflection system.

Input Resistance

Same as vertical deflection system.

Input Capacitance

Same as vertical deflection system.

Maximum Usable Input Voltage

Same as vertical deflection system.

CALIBRATOR

Output

An approximate 1 kilohertz, 30 milliamperere (within 2%), 300 millivolt (within 1%), square-wave signal.

Z AXIS INPUT

Sensitivity

A 5-volt peak to peak signal causes noticeable modulation at normal intensity.

Usable Frequency Range

From dc to 50 megahertz.

SIGNAL OUTPUTS

Ch 1 Vertical

Output voltage is at least 50 millivolts/division into a 1 megohm load (at least 25 millivolts/division into a 50 ohm load).

Bandwidth is from dc to at least 50 megahertz into a 50 ohm load.

Output dc level is approximately zero volts.

A and B - Gate

Output voltage is approximately 5.5 volts, positive-going.

POWER SOURCE

Line Voltages

110, 115, 120, 220, 230, or 240 Volts ac (all within 10%), depending on the settings of the Line Voltage Selector switch and the Regulating Range Selector assembly, with a line frequency of 48 to 440 hertz. Maximum power consumption is 75 watts at 115 volts ac, 60 hertz.

CATHODE-RAY TUBE (CRT)

Graticule Area

Eight by 10 centimeters.

Phosphor

P31 is the standard phosphor with P11 offered as an option.

SUPPLEMENTAL INFORMATION

NOTE

The following supplemental information represents limits that, when met, ensure optimum instrument operation. They are, however, not instrument specifications but are intended to be used only as maintenance or operational aids.

VERTICAL DEFLECTION SYSTEM

Low—Frequency Linearity

There should be no more than 0.1 division of compression or expansion of a 2-division signal, at center screen, when the signal is positioned to the upper and lower extremes of the crt graticule area.

Bandwidth Limiter Switch

The -3 dB point should be between 15 and 25 megahertz with the 20 MHz BW switch pulled (yellow showing).

Step Response Aberrations

Aberrations on a positive going 5 division step should be +3%, - 3% or less not to exceed 3% peak-to-peak on

Specifications—465 Service (SN B250000 & up)

all ranges except at 5 VOLTS/DIV. Aberrations at 5 VOLTS/DIV should be +4%, -4% or less not to exceed 4% peak-to-peak. Position effect should cause aberrations to be no more than +5%, -5% not to exceed 5% peak-to-peak.

Common-Mode Rejection Ratio (CMRR)

At least 10:1 at 20 megahertz for common mode signals of 6 divisions or less with vertical gain adjusted for best cmrr at 50 kilohertz.

Step Attenuator Balance

Adjustable to 0.2 division or less of trace shift when switching between adjacent deflection factors.

Trace Shift as Variable is Rotated

Adjustable to 1 division or less.

Invert Trace Shift

Two divisions or less when switching from normal to inverted.

Input Gate Current

0.5 nanoampere or less (0.1 division of deflection at 5 millivolts/division) from +20°C to +30°C. Four nanoamperes or less (0.8 division of deflection at 5 millivolts/division) from -15°C to +55°C.

Channel Isolation

At least 100:1 at 25 megahertz.

Position Range

Twelve divisions up and 12 divisions down from graticule center.

TRIGGERING

External Trigger Input Capacitance

Twenty picofarads within 30%.

HORIZONTAL DEFLECTION SYSTEM

A Sweep Length

10.5 to 11.5 divisions

Magnifier Registration

There should be 0.2 division or less difference at graticule center when switching from MAG on to MAG off.

Position Range

Should be able to position the start of the sweep to the right of graticule center, and the end of the sweep to the left of graticule center.

Phase Difference Between X And Y Axes Amplifiers

Typically 3° or less from dc to 50 kilohertz.

CALIBRATOR

Repetition Rate

Repetition rate accuracy is 1 kilohertz within 25%.

Output Resistance

Approximately 9.4 ohms.

EXTERNAL Z AXIS INPUT

Voltages applied to the EXT Z AXIS INPUT connector should be limited to less than 100 volts (dc + peak ac) or 100 volts peak to peak ac at 1 kilohertz or less.

OUTPUT RESISTANCES

Output resistance of the CH 1 VERT SIG OUT connector is approximately 50 ohms.

Output resistance of A+ and B+ GATE outputs is approximately 500 ohms.

CATHODE-RAY TUBE

Resolution

Typically at least 15 lines/division horizontally and vertically.

Geometry

0.1 division or less of tilt or bowing.

Raster Distortion

0.1 division or less.

Nominal Accelerating Potential

Approximately 18,500 volts.

OPERATING INFORMATION

Introduction

This section of the manual is intended to allow the operator to become familiar with the instrument power requirements, functions of controls and connectors, and how to obtain a few basic displays. For more complete operating information, refer to the 465 Operators Handbook.

Operating Voltage

WARNING

This instrument is designed for operation from a power source with its neutral at or near earth (ground) potential with a separate safety-earth conductor. It is not intended for operation from two phases of a multi-phase system, or across the legs of a single-phase three-wire system.

This instrument can be operated from either a 115-volt or 230-volt nominal line voltage source, 48 to 440 hertz. The Line Voltage Selector switch on the right side panel converts the instrument from one nominal operating voltage to the other. The Regulating Range Selector assembly on the instrument rear panel selects one of three regulating ranges for each nominal line voltage; it also contains the line fuse for overload protection. To select the correct nominal line voltage and regulating range, proceed as follows:

1. Disconnect the instrument from the power source.

2. To convert from 115-volts nominal to 230-volts nominal line voltage, set the selector switch to the 230 volts position (toward the rear of the instrument). Change the line-cord plug to match the power source or use a 115-to-230 volt adapter. Check for correct fuse for the line voltage selected (see Table 2-1).

Power Cord Conductor Identification

Conductor	Color	Alternate Color
Ungrounded (Line)	Brown	Black
Grounded (Neutral)	Blue	White
Grounding (Earthing)	Green-Yellow	Green-Yellow

3. To change regulating ranges, loosen the 2 captive screws which hold the cover onto the Regulating Range Selector assembly, then pull to remove the cover.

4. Pull out the range selector switch bar (see Fig. 2-1). Slide the bar to the desired position and plug it back in. Select a range which is centered about the average line voltage to which the instrument is to be connected (see Table 2-1).

TABLE 2-1

REGULATING RANGES

Range Selector Switch Position	Regulating Range	
	115 V Nominal	230 V Nominal
Lo (switch bar in bottom holes)	99 to 121 V	198 to 242 V
M (switch bar in middle holes)	104 to 126 V	208 to 252 V
HI (switch bar in top holes)	108 to 132 V	216 to 264 V
Fuse Size	1.5 A 3AG Fast-blow	0.75 A 3AG Fast-blow

5. Re-install the cover and tighten the 2 captive screws.

6. Before applying power to the instrument, check that the line voltage selector switch and the indicating tab on the Regulating Range Selector assembly are in the correct position for the desired nominal line voltage and regulating range.

CAUTION

This instrument may be damaged if operated with the line voltage selector switch or the Regulating Range Selector assembly set to incorrect positions for the line voltage applied, or if the wrong line fuse is used.




Fig. 2-1. Power supply regulating range selector.

The 465 is designed to be used with a three-wire ac power system. If a 3 to 2 wire adapter is used to connect this instrument to a 2 wire ac power system, be sure to connect the ground lead of the adapter to earth (ground). Failure to complete the ground system may allow the chassis of this instrument to be elevated above ground potential and pose a shock hazard.

The feet on the rear panel provide a convenient cord wrap to store the power cord when not in use.

CONTROLS AND CONNECTORS

Introduction

The major controls and connectors for operation of the 465 are located on the front panel of the instrument. A few auxiliary functions are provided on the rear panel. Fig. 2-2 shows the front and rear panels of the 465. A brief description of each control and connector is given here. More detailed operating information is given in the 465 Oscilloscope Operators Manual.

Cathode-Ray Tube (CRT) and Display

1. BEAM FINDER Compresses the display to within the graticule area, independently of display position or applied signals
2. INTENSITY Controls brightness of the display.

3. FOCUS Provides adjustment for optimum display definition.
4. SCALE ILLUM Controls graticule brightness.
5. ASTIG Screwdriver adjustment used in conjunction with the FOCUS control to obtain a well-defined display. Does not require readjustment in normal use.
6. TRACE ROTATION Screwdriver adjustment to align the trace with the horizontal graticule lines.

Vertical Deflection System (Channel 1 & Channel 2)

7. POSITION Controls the vertical position of the trace. In the X-Y mode of operation, the Ch 2 control positions on the Y-axis (vertically) and the Horizontal POSITION control positions on the X-axis (horizontally).
8. CH 1 OR X Input connector for Channel 1 deflection signals or X-axis deflection in the X-Y mode of operation.
9. CH 2 OR Y Input connector for Channel 2 deflection signals or Y-axis deflection in the X-Y mode of operation.
10. VOLTS/DIV Selects vertical deflection factor in a 1-2-5 sequence (VAR control must be in the calibrated detent for the indicated deflection factor).
11. VAR Provides continuously variable uncalibrated deflection factors between the calibrated settings of the VOLTS/DIV switch.
12. UNCAL Light indicates that the VAR control is not in the calibrated position.
13. Input Coupling Selects the method of coupling signal to the input of the Vertical Amplifier.
 - AC:** Signal is capacitively coupled to the Vertical Amplifier. Dc component of signal is blocked. Low-frequency limit (lower -3 dB point) is about 10 hertz.
 - GND:** Input signal is removed and the input circuit is grounded. Does not ground the input signal.
 - DC:** All components of the input signal are passed to the Vertical Amplifier.





Fig. 2-2. Front and rear panel controls and connectors.

Operating Information—465 Service (SN B250000 & up)

14. 20 MHz BW/
TRIG VIEW Dual-purpose switch that, when pulled out, limits the bandwidth of the complete Vertical Deflection System to approximately 20 megahertz, or when pressed causes signal present in A Trigger Generator circuit to be displayed on the CRT.
15. INVERT Pushbutton switch that inverts the Channel 2 display.
16. VERT MODE **CH 1:** Displays Channel 1 only.
- ALT:** Dual-trace display of signals on both channels. Display is switched between channels at the end of each sweep.
- ADD:** Signals applied to the CH 1 OR X and CH 2 OR Y connectors are algebraically added and the sum is displayed on the CRT. The INVERT switch in Channel 2 allows the display to be CH 1 + CH 2 or CH 1 – CH 2.
- CHOP:** Dual-trace display of signals on both channels. Display is switched between channels at an approximate repetition rate of 250 kilohertz.
- CH 2 OR X-Y:** Displays Channel 2 only. Must be pushed when operating in X-Y mode.
- A and B Triggering (both where applicable)**
17. COUPLING Determines the method used to couple signal to input of trigger circuits.
- AC:** Rejects dc and attenuates signals below about 60 hertz. Accepts signals above about 60 hertz.
- LF REJ:** Rejects dc and attenuates signals below about 50 kilohertz. Accepts signals above about 50 kilohertz.
- HF REJ:** Accepts signals between 60 hertz and 50 kilohertz. Rejects dc and attenuates all signals outside the above range.
- DC:** Accepts all trigger signals from dc to 100 megahertz or greater.
18. SOURCE Selects source of trigger signal.
- NORM:** Internal trigger signal obtained from Vertical Deflection System. Actual source is signal(s) displayed on crt.
- CH 1:** A sample of the signal connected to the CH 1 OR X input connector is used as a trigger signal.
- CH 2:** A sample of the signal connected to the CH 2 OR Y input connector is used as a trigger signal.
- EXT:** Trigger signal is obtained from signal connected to the External Trigger Input connector.
- EXT ÷10 (A trigger circuit only):** External trigger signal is attenuated by a factor of 10.
- STARTS AFTER DELAY (B trigger circuit only):** B sweep starts immediately after the delay time selected by the DELAY-TIME POSITION dial and the DELAY-TIME switch.
- LINE (A trigger circuit only):** Trigger signal is obtained from a sample of the line voltage applied to the instrument.
19. SLOPE Selects the slope of the trigger signal which starts the sweep.
- +: Sweep can be triggered from the positive-going portion of the trigger signal.
- : Sweep can be triggered from the negative-going portion of the trigger signal.
20. LEVEL Selects the amplitude point on the trigger signal at which the sweep is triggered.
21. A TRIG MODE Determines the operating mode for the A Trigger Circuit.
- AUTO:** With the proper trigger control settings, A Sweep can be initiated by signals that have repetition rates above about 20 hertz and are within the frequency range selected by the

COUPLING switch. In the absence of an adequate trigger signal or when the trigger controls are misadjusted, the sweep free-runs to produce a reference trace.

NORM: With the proper trigger control settings, A Sweep can be initiated by signals that are within the frequency range selected by the COUPLING switch. In the absence of an adequate trigger signal or when the trigger controls are misadjusted, there is no trace.

SINGL SWP: After a sweep is displayed, further sweeps cannot be presented until the SINGL SWP pushbutton is pressed again. The display is triggered the same as for NORM operation using the A Triggering controls.

22. A TRIG HOLD-OFF

Provides control of holdoff time between sweeps to obtain stable displays when triggering on aperiodic signals (such as complex digital words). Variable can increase holdoff time up to at least 10 times the holdoff time of the NORM position. In the B ENDS A position (fully clockwise), the A sweep is reset at the end of the B sweep to provide the fastest possible sweep repetition rate for delayed sweep presentations.

23. External Trigger

Input connectors for external trigger signals.

24. TRIG

Light that indicates A sweep is triggered.

A and B Sweep

25. DELAY-TIME POSITION

Provides variable sweep delay between 0.20 and 10.20 times the delay time indicated by the DELAY TIME switch.

26. A AND B TIME/DIV

A TIME/DIV switch (clear plastic outer flange) selects the sweep rate of the A sweep circuit and selects the basic delay time (to be multiplied by DELAY-TIME POSITION dial setting) for delayed-sweep operation. B TIME/DIV switch (inner dark knob) selects sweep rate of the B sweep circuit for delayed sweep operation only. VAR control must be in calibrated detent for calibrated A sweep rates.

27. VAR

Provides continuously variable A sweep rates between the calibrated settings of the A TIME/DIV switch. The A sweep rate is calibrated when the VAR control is fully clockwise into the calibrated detent.

28. UNCAL

Light that indicates when the VAR TIME/DIV control is out of the calibrated detent and the horizontal sweep rate is uncalibrated.

29. X10 MAG Indicator

Light that indicates when the X10 MAG is turned on.

30. READY

Light that indicates that A Sweep has been prepared to present a single sweep upon receipt of an adequate trigger signal.

31. HORIZ DISPLAY

Selects the horizontal mode of operation.

A: Horizontal deflection provided by A Sweep. B Sweep inoperative.

MIX: The first part of the horizontal sweep is displayed at a rate set by the A TIME/DIV switch and the latter part of the sweep at a rate set by the B TIME/DIV switch. Relative amounts of the display allocated to each of the two rates are determined by the setting of the DELAY-TIME POSITION dial.

A INTEN: Displayed sweep rate determined by the A TIME/DIV switch. An intensified portion appears on the display during the B sweep time. This switch position provides a check of the duration and position of the B sweep (delayed sweep) with respect to the delaying sweep (A).

B DLYD: Sweep rate determined by the B TIME/DIV switch with the delay time determined by the setting of the DELAY TIME (A TIME/DIV) switch and the DELAY-TIME POSITION dial.

32. Horizontal

Positions the display horizontally.

33. FINE

Provides fine horizontal positioning.

34. X10 MAG

Increases the displayed sweep rate by a factor of 10.

Operating Information—465 Service (SN B250000 & up)

Calibrator and Power

35. CALIBRATOR A combination current loop and square-wave voltage output device. Provides a 30 milliampere square-wave current, 300 millivolt square-wave voltage signal with a repetition rate of approximately 1 kilohertz.
36. POWER Turns instrument power on and off.
37. LOW LINE Light that indicates the applied line voltage is below the lower limit of the regulating range selected by the Regulating Range Selector assembly.

VOLTS/DIV VAR Controls	Calibrated detent
Input Coupling Switches	AC
Vertical POSITION Controls	Midrange
20 MHz BW Switch	Not limited
INVERT Switch	Button out
INTENSITY Control	Fully counterclockwise
FOCUS Control	Midrange
SCALE ILLUM Control	Midrange

Rear Panel

38. A +GATE Output connector providing a positive-going rectangular pulse coincident with the A sweep time.
39. B +GATE Output connector providing a positive-going rectangular pulse coincident with the B sweep time.
40. CH 1 VERT Output connector providing a sample of the signal applied to the CH 1 input connector.
41. EXT Z AXIS Input connector for intensity modulation of the crt display.
42. Regulating Range Selector Selects the regulating range of the internal power supplies (low, medium, high; determined by specific line voltage applied to instrument).

Trigger Controls (both A and B if applicable)

SLOPE Switch	+
LEVEL Control	0
SOURCE Switch	NORM
COUPLING Switch	AC
TRIG MODE Switch	AUTO
A TRIG HOLDOFF Control	NORM

Horizontal Sweep Controls

TIME/DIV Switches	Locked together at 1 ms
A TIME/DIV VAR	Calibrated detent
HORIZ DISPLAY Switch	A
X10 MAG Switch	Off (button out)
POSITION Control	Midrange

Normal Sweep Display

1. Set the POWER switch to on (button out). Allow several minutes for instrument warmup.
2. Connect the external signal to the CH 1 input connector.
3. Advance the INTENSITY control until the display is visible. If the display is not visible with the INTENSITY control at midrange, press the BEAM FINDER pushbutton and adjust the CH 1 VOLTS/DIV switch until the display is reduced in size vertically. Then, center the compressed display with the vertical and horizontal POSITION controls, and release the BEAM FINDER pushbutton.
4. Set the CH 1 VOLTS/DIV switch and CH 1 POSITION control for a display which remains in the display area vertically.
5. Adjust the A Trigger LEVEL control for a stable display.
6. Set the A TIME/DIV switch and the horizontal POSITION control for a display which remains in the display area horizontally.

OBTAINING BASIC DISPLAYS

Introduction

The following instructions will allow the operator who is unfamiliar with the operation of the 465 to obtain the basic displays commonly used. Before proceeding with these instructions, preset the instrument controls as follows.

Vertical Controls

VERT MODE Switch	CH 1
VOLTS/DIV Switches	Proper position determined by amplitude of signal to be applied.

Magnified Sweep Display

1. Preset the instrument controls and follow steps 1 through 6 for obtaining a Normal Sweep Display.

2. Adjust the horizontal POSITION control to move the area to be magnified to within the center graticule division of the crt (0.5 division on each side of the center vertical graticule line). If necessary, change the TIME/DIV switch setting so the complete area to be magnified is within the center division.

3. Set the X10 MAG switch to the on position (button in) and adjust the horizontal POSITION and FINE controls for precise positioning of the magnified display.

Delayed Sweep Displays

1. Preset the instrument controls and follow steps 1 through 6 for obtaining a Normal Sweep Display.

2. Set the HORIZ DISPLAY switch to A INTEN and the B Trigger SOURCE switch to STARTS AFTER DELAY.

3. Pull out the B TIME/DIV switch knob and turn clockwise so the intensified zone on the display is the desired length. Adjust the INTENSITY control to achieve the desired display brightness.

4. Adjust the DELAY-TIME POSITION dial to position the intensified zone to the portion of the display to be delayed.

5. Set the HORIZ DISPLAY switch to B DLYD. The intensified zone on the display noted in step 3 is now being displayed in delay form. The delayed sweep rate is indicated by the white line on the B TIME/DIV switch knob.

6. For a delayed sweep display that will exhibit less jitter, set the B Trigger SOURCE switch to the same position as the A Trigger SOURCE switch and adjust the B Trigger LEVEL control for a stable display. If the A Trigger

SOURCE switch is in the LINE position, a sample of the line voltage will have to be supplied to the B Trigger circuit through the B EXT trigger input with the B SOURCE switch in the EXT position.

Mixed Sweep Displays

1. Preset the instrument controls and follow steps 1 through 6 for obtaining a Normal Sweep Display.

2. Pull out on the B TIME/DIV switch knob and turn clockwise to the desired sweep rate. Adjust the INTENSITY control to achieve the desired display brightness.

3. Set the HORIZ DISPLAY switch to MIX and B SOURCE to STARTS AFTER DELAY. The CRT display now contains more than one time factor on the horizontal axis. The left portion of the display is at the A Time Base sweep rate and the right part is at the B Time Base sweep rate. The start of the B Time Base portion of the display can be changed by adjusting the DELAY-TIME POSITION control.

X-Y Display

1. Preset the instrument controls and turn the instrument power on. Allow several minutes for instrument warm-up.

2. Set the TIME/DIV switch to X-Y and the VERT MODE to CH 2. Apply the vertical signal to the CH 2 or Y input connector and the horizontal signal to the CH 1 or X input connector. The CH 2 POSITION control will provide vertical positioning and the Horizontal POSITION control will provide horizontal positioning.

3. Advance the INTENSITY control until the display is visible. If the display is not visible with the INTENSITY control at midrange, press the BEAM FINDER pushbutton and adjust the CH 1 and CH 2 VOLTS/DIV switches until the display is reduced in size both vertically and horizontally. Then, center the compressed display with the CH 2 POSITION and horizontal POSITION controls, and release the BEAM FINDER pushbutton. Adjust the FOCUS control for a well-defined display.