

Installation Manual



TLA700 Series Logic Analyzer

071-1235-00

Warning

The servicing instructions are for use by qualified personnel only. To avoid personal injury, do not perform any servicing unless you are qualified to do so. Refer to all safety summaries prior to performing service.

www.tektronix.com

Copyright © Tektronix, Inc. All rights reserved. Licensed software products are owned by Tektronix or its suppliers and are protected by United States copyright laws and international treaty provisions.

Use, duplication, or disclosure by the Government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.227-7013, or subparagraphs (c)(1) and (2) of the Commercial Computer Software - Restricted Rights clause at FAR 52.227-19, as applicable.

Tektronix products are covered by U.S. and foreign patents, issued and pending. Information in this publication supercedes that in all previously published material. Specifications and price change privileges reserved.

Tektronix, Inc., 14200 SW Karl Braun Drive, Beaverton, OR 97077

TEKTRONIX, TEK, TLAVu, PatGenVu, and MagniVu are registered trademarks of Tektronix, Inc.

HARDWARE WARRANTY

Tektronix warrants that the products that it manufactures and sells will be free from defects in materials and workmanship for a period of one (1) year from the date of shipment. If a product proves defective during this warranty period, Tektronix, at its option, either will repair the defective product without charge for parts and labor, or will provide a replacement in exchange for the defective product.

In order to obtain service under this warranty, Customer must notify Tektronix of the defect before the expiration of the warranty period and make suitable arrangements for the performance of service. Customer shall be responsible for packaging and shipping the defective product to the service center designated by Tektronix, with shipping charges prepaid. Tektronix shall pay for the return of the product to Customer if the shipment is to a location within the country in which the Tektronix service center is located. Customer shall be responsible for paying all shipping charges, duties, taxes, and any other charges for products returned to any other locations.

This warranty shall not apply to any defect, failure or damage caused by improper use or improper or inadequate maintenance and care. Tektronix shall not be obligated to furnish service under this warranty a) to repair damage resulting from attempts by personnel other than Tektronix representatives to install, repair or service the product; b) to repair damage resulting from improper use or connection to incompatible equipment; c) to repair any damage or malfunction caused by the use of non-Tektronix supplies; or d) to service a product that has been modified or integrated with other products when the effect of such modification or integration increases the time or difficulty of servicing the product.

THIS WARRANTY IS GIVEN BY TEKTRONIX IN LIEU OF ANY OTHER WARRANTIES, EXPRESS OR IMPLIED. TEKTRONIX AND ITS VENDORS DISCLAIM ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. TEKTRONIX' RESPONSIBILITY TO REPAIR OR REPLACE DEFECTIVE PRODUCTS IS THE SOLE AND EXCLUSIVE REMEDY PROVIDED TO THE CUSTOMER FOR BREACH OF THIS WARRANTY. TEKTRONIX AND ITS VENDORS WILL NOT BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES IRRESPECTIVE OF WHETHER TEKTRONIX OR THE VENDOR HAS ADVANCE NOTICE OF THE POSSIBILITY OF SUCH DAMAGES.

SOFTWARE WARRANTY

Tektronix warrants that the media on which this software product is furnished and the encoding of the programs on the media will be free from defects in materials and workmanship for a period of three (3) months from the date of shipment. If a medium or encoding proves defective during the warranty period, Tektronix will provide a replacement in exchange for the defective medium. Except as to the media on which this software product is furnished, this software product is provided "as is" without warranty of any kind, either express or implied. Tektronix does not warrant that the functions contained in this software product will meet Customer's requirements or that the operation of the programs will be uninterrupted or error-free.

In order to obtain service under this warranty, Customer must notify Tektronix of the defect before the expiration of the warranty period. If Tektronix is unable to provide a replacement that is free from defects in materials and workmanship within a reasonable time thereafter, Customer may terminate the license for this software product and return this software product and any associated materials for credit or refund.

THIS WARRANTY IS GIVEN BY TEKTRONIX IN LIEU OF ANY OTHER WARRANTIES, EXPRESS OR IMPLIED. TEKTRONIX AND ITS VENDORS DISCLAIM ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. TEKTRONIX' RESPONSIBILITY TO REPLACE DEFECTIVE MEDIA OR REFUND CUSTOMER'S PAYMENT IS THE SOLE AND EXCLUSIVE REMEDY PROVIDED TO THE CUSTOMER FOR BREACH OF THIS WARRANTY. TEKTRONIX AND ITS VENDORS WILL NOT BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES IRRESPECTIVE OF WHETHER TEKTRONIX OR THE VENDOR HAS ADVANCE NOTICE OF THE POSSIBILITY OF SUCH DAMAGES.

Table of Contents

General Safety Summary	v
Service Safety Summary	vii
Preface	ix
TLA700 Series Logic Analyzers	ix
Related Documentation	xi
Contacting Tektronix	xii
Basic Installation	1
Check the Shipping List	1
Environmental Considerations	1
TLA715 Portable Mainframe Site Considerations	2
TLA721 Benchtop Mainframe and TLA7XM Expansion Mainframe Site Considerations	2
Installing TLA7XM Expansion Mainframes	2
Install the Expansion Module	2
Install the Expansion Cables	5
Chassis Ground Connections	6
Installing TLA700 Modules	7
Logical Address Switches	7
Merging Modules	8
Installing Modules in the TLA715 Portable Mainframe	9
Installing Modules in the TLA721 Benchtop or TLA7XM Expansion Mainframe	9
Keying Modules	11
Covering Empty Slots	12
Connecting Accessories	13
Connecting Accessories to the TLA700 Series	13
Additional Accessory Connection Information	14
Connecting Probes	14
Connecting Probes to the Logic Analyzer Module	15
Configuring and Connecting the Pattern Generator Probes	16
First Time Operation	17
Turning the Logic Analyzer On	17
Turning on the TLA7XM Expansion Mainframes	19
Turning off the Mainframes	19
Performing the Incoming Inspection	19
Checking the P68xx Logic Analyzer Probes (Optional)	20
Checking the P64xx Logic Analyzer Probes (Optional)	20
Checking the P624x Oscilloscope Probes (Optional)	21
Checking the P647x Pattern Generator Probes (Optional)	21
Checking the TLA700 Mainframe (Optional)	21
Backing Up User Files	21
Removing the Replaceable Hard Disk Drive	21
Connecting Probes to the Target System	22
Additional Information	23

Merging TLA700 Modules	25
Logic Analyzer Merging Rules	25
TLA7PG2 Pattern Generator Module Merging Rules	26
Merge Procedure	26
Merging TLA7Axx Logic Analyzer Modules	27
Unmerging TLA7Axx Logic Analyzer Modules	31
Merging TLA7Lx/Mx/Nx/Px/Qx Logic Analyzer Modules	32
Two-Way Logic Analyzer Merge Procedure	32
Three-Way Logic Analyzer Merge Procedure	37
Storing the Logic Analyzer Module Merge Cable	37
Product Overview	39
Front Panel Controls	39
TLA700 Series External Connectors	39
Restoring and Reinstalling Software	41
Restoring the Hard Disk Image	41
TLA714, or TLA720 Logic Analyzers	41
TLA715 or TLA721 Logic Analyzers	41
Flashing the BIOS	42
Reinstalling the Hard Disk Image	46
Backing Up Files	47
Installing the Operating System and TLA Application Software	48
Reinstalling the TLA Application Software and the Pattern Generator Application Software	50
Installing the TPI or PPI Remote Operation Software	51
Installing the TLAVu and PatGenVu Software on a PC	52
Upgrading or Restoring Firmware	53
Upgrading Firmware on TLA7Axx Logic Analyzer Modules	53
Upgrading Firmware on TLA7Lx/Mx/Nx/Px/Qx/Dx/7Ex Modules	55
Upgrading Firmware on the TLA7PG2 Pattern Generator Modules	58
Appendix A: TLA721 Mainframe Power Information	61
Appendix B: User Service Procedures	65
Service Offerings	65
Warranty Repair Service	65
Calibration and Repair Service	65
General Care	65
Preventive Maintenance	66
Cleaning the Flat Panel Display	66
Exterior Surfaces	66
Floppy Disk Drive	67
In Case of Problems	67
Diagnostics	67
Software Problems	68
Hardware Problems	68
Repacking for Shipment	68

List of Figures

Figure i: TLA715 Portable Mainframe	ix
Figure ii: TLA721 Benchtop Mainframe with a TLA7XM Expansion Mainframe	x
Figure 1: TLA721 Benchtop Mainframe with one TLA7XM Expansion Mainframe.	3
Figure 2: TLA721 Benchtop Mainframe with two TLA7XM Expansion Mainframes	4
Figure 3: TLA715 Portable Mainframe with two TLA7XM Expansion Mainframes	4
Figure 4: Location of the ground connection on the TLA700 logic analyzers	6
Figure 5: Logical address switches (set to address FF)	8
Figure 6: Installing modules	10
Figure 7: Keying modules	11
Figure 8: Installing panel covers on the TLA715 Portable Mainframe	12
Figure 9: Installing panel covers on the TLA721 Benchtop Mainframe	12
Figure 10: TLA700 series accessories connections	13
Figure 11: Connecting the P68xx logic analyzer probes to the TLA7Axx logic analyzer module	15
Figure 12: Connecting the P64xx logic analyzer probes to the TLA7Lx/Mx/Nx/Px/Qx logic analyzer modules	16
Figure 13: Line fuse and power cord connector locations	18
Figure 14: TLA700 On/Standby switch locations	19
Figure 15: Accessing the TLA700 replaceable hard disk drive	22
Figure 16: Location of modules in a merged system	27
Figure 17: Removing the merger connector assembly from the module	28
Figure 18: Connecting modules in a merged set	29
Figure 19: Installing the merged module set in the mainframe	30
Figure 20: Removing the cover	33
Figure 21: Feeding the merge cable through the cover	34
Figure 22: Seating the cover on the chassis	35
Figure 23: Lining up the two modules	36
Figure 24: Positioning the merge cable before installing the cover .	38
Figure 25: TLA715 Portable mainframe front panel	39

List of Tables

Figure 26: TLA700 series external connectors	40
Figure 27: Flash programming pins	56
Figure 28: Power cord identification chart	63
Table i: Tektronix Logic Analyzer Family documentation	xi
Table 1: Additional accessory connection information	14
Table 2: TLA700 series line fuses	17
Table 3: TLA714 and TLA720 Controller BIOS setup	43
Table 4: TLA user file suffixes	47
Table 5: Bios Boot settings for reinstalling software from the CD-ROM	48
Table 6: TLA firmware files	57
Table 7: Power for instrument modules	61

General Safety Summary

Review the following safety precautions to avoid injury and prevent damage to this product or any products connected to it.

To avoid potential hazards, use this product only as specified.

Only qualified personnel should perform service procedures.

While using this product, you may need to access other parts of the system. Read the *General Safety Summary* in other system manuals for warnings and cautions related to operating the system.

To Avoid Fire or Personal Injury

Use Proper Power Cord. Use only the power cord specified for this product and certified for the country of use.

Connect and Disconnect Properly. Do not connect or disconnect probes or test leads while they are connected to a voltage source.

Ground the Product. This product is grounded through the grounding conductor of the power cord. To avoid electric shock, the grounding conductor must be connected to earth ground. Before making connections to the input or output terminals of the product, ensure that the product is properly grounded.

Observe All Terminal Ratings. To avoid fire or shock hazard, observe all ratings and markings on the product. Consult the product manual for further ratings information before making connections to the product.

Connect the ground lead of the probe to earth ground only.

Powering Off. The power cord provides Mains disconnect.

Do Not Operate Without Covers. Do not operate this product with covers or panels removed.

Use Proper Fuse. Use only the fuse type and rating specified for this product.

Avoid Exposed Circuitry. Do not touch exposed connections and components when power is present.

Do Not Operate With Suspected Failures. If you suspect there is damage to this product, have it inspected by qualified service personnel.

Do Not Operate in Wet/Damp Conditions.

Do Not Operate in an Explosive Atmosphere.

Keep Product Surfaces Clean and Dry.

Provide Proper Ventilation. Refer to the manual's installation instructions for details on installing the product so it has proper ventilation.

Symbols and Terms

Terms in this Manual. These terms may appear in this manual:



WARNING. *Warning statements identify conditions or practices that could result in injury or loss of life.*



CAUTION. *Caution statements identify conditions or practices that could result in damage to this product or other property.*

Terms on the Product. These terms may appear on the product:

DANGER indicates an injury hazard immediately accessible as you read the marking.

WARNING indicates an injury hazard not immediately accessible as you read the marking.

CAUTION indicates a hazard to property including the product.

Symbols on the Product. The following symbols may appear on the product:



CAUTION
Refer to Manual



WARNING
High Voltage



Protective Ground
(Earth) Terminal



Mains Disconnected
OFF (Power)



Mains Connected
ON (Power)



Standby

Service Safety Summary

Only qualified personnel should perform service procedures. Read this *Service Safety Summary* and the *General Safety Summary* before performing any service procedures.

Do Not Service Alone. Do not perform internal service or adjustments of this product unless another person capable of rendering first aid and resuscitation is present.

Disconnect Power. To avoid electric shock, switch off the instrument power, then disconnect the power cord from the mains power.

Use Care When Servicing With Power On. Dangerous voltages or currents may exist in this product. Disconnect power, remove battery (if applicable), and disconnect test leads before removing protective panels, soldering, or replacing components.

To avoid electric shock, do not touch exposed connections.

Preface

This manual contains all information needed to install your Tektronix logic analyzer and related accessories.

To prevent personal injury or damage consider the following requirements before attempting service:

- The procedures in this manual should be performed only by qualified service personnel.
- Read the *General Safety Summary* and *Service Safety Summary* found at the beginning of this manual.

Be sure to follow all warnings, cautions, and notes in this manual.

TLA700 Series Logic Analyzers

The TLA700 series logic analyzers are comprised of a portable mainframe, benchtop mainframe, expansion mainframe (Figure i and Figure ii), and all of the accessories and supports that can be used with them. The logic analyzers are built upon the Windows operating system which allows you to install any PC-compatible, third-party hardware and software on the instrument.

The TLA700 series logic analyzers combine high-performance logic analyzer and pattern generator modules with optional application modules or an external Tektronix oscilloscope.




Figure i: TLA715 Portable Mainframe

Several logic analyzer modules are available in various combinations of channel width, state speed, and memory depth. All of the logic analyzer modules provide simultaneous state and timing measurements through a single probe.

For a complete list of accessories, refer to the online help.






Figure ii: TLA721 Benchtop Mainframe with a TLA7XM Expansion Mainframe

Related Documentation

Most of the product documentation is available via online help with the TLA or Pattern Generator application. Table i lists other documentation that you may need to support your Tektronix logic analyzer product.

For documentation not specified in the table, contact your local Tektronix representative.

Table i: Tektronix Logic Analyzer Family documentation

Location	TLA Documentation
Documents available in printed form and downloadable from the Tektronix web site.	
	Tektronix Logic Analyzer Family User Manual TLA700 Series Logic Analyzer Installation Manual P68xx Logic Analyzer Probes Instruction Manual P6417 & P6418 Logic Analyzer Probes Instructions P6419 Logic Analyzer Probes Instructions P6434 Mass Termination Probe Instructions TLA7UP Field Upgrade Kit Instructions TLA7PG2 Pattern Generator Module Instructions
Documents available as PDF files on the documentation CD.	
	Tektronix Logic Analyzer Family User Manual TLA700 Series Logic Analyzer Installation Manual Tektronix Logic Analyzer Programmatic Interface (TPI.net) P68xx Logic Analyzer Probes Instruction Manual P6417 & P6418 Logic Analyzer Probes Instructions P6419 Logic Analyzer Probes Instructions P6434 Mass Termination Probe Instructions TLA7PG2 Pattern Generator Module Instructions

Contacting Tektronix

Phone	1-800-833-9200*
Address	Tektronix, Inc. Department or name (if known) 14200 SW Karl Braun Drive P.O. Box 500 Beaverton, OR 97077 USA
Web site	www.tektronix.com
Sales support	1-800-833-9200, select option 1*
Service support	1-800-833-9200, select option 2*
Technical support	Email: techsupport@tektronix.com 1-800-833-9200, select option 3* 6:00 a.m. - 5:00 p.m. Pacific time

* **This phone number is toll free in North America. After office hours, please leave a voice mail message. Outside North America, contact a Tektronix sales office or distributor; see the Tektronix web site for a list of offices.**

Basic Installation

This chapter describes all of the steps needed to install your Tektronix logic analyzer and its related accessories. It is written from the perspective that you purchased most of the items uninstalled and you intend to install all of the pieces. If you purchased a logic analyzer with modules already installed, you should still review this chapter and perform the steps that apply to your situation.

Check the Shipping List

Check that you have received all of the parts of your logic analyzer using the shipping list. Also check the following:

- That you have the correct power cords for your geographical area.
- That you have the correct probes and modules.
- That you have all the standard and optional accessories that you ordered.

Fill out and return the customer registration card that is packaged with this manual.

Environmental Considerations

Read this section before installing the logic analyzer. This section describes site considerations, power requirements, and ground connections for your logic analyzer.



CAUTION. Allow a 5.1 cm (2 in) clearance at the bottom and sides of the instrument to ensure proper cooling. Inadequate clearances can cause the instrument to overheat and shut down.

**TLA715 Portable
Mainframe Site
Considerations**

You can use the TLA715 Portable Mainframe on a bench or on a cart in the normal position (on the bottom feet). You can also use the logic analyzer while it rests on the rear feet. If you use the instrument while it is resting on the rear feet, make sure that you properly route any cables connected to the rear of the instrument to avoid damaging them.

**TLA721 Benchtop
Mainframe and TLA7XM
Expansion Mainframe Site
Considerations**

The TLA721 Benchtop and TLA7XM Expansion Mainframes are designed to operate on a bench or in a rackmount environment. If you need to stack more than two benchtop and expansion mainframes, install the mainframes in a rack. Rackmount kits are available from third-party vendors. Please refer to the online help under Standard and Optional Accessories for rackmount kit part numbers.



WARNING. *To avoid personal injury, never lift or move a benchtop or expansion mainframe by yourself. The size and weight of these mainframes requires two people to lift or move them.*

Do not stack more than one expansion mainframe on top of a benchtop mainframe or another expansion mainframe. Always use a rackmount kit to ensure that the expansion mainframes are secure and will not fall.

Installing TLA7XM Expansion Mainframes

If your logic analyzer does not contain any expansion mainframes, skip this section. Observe the following guidelines when installing expansion mainframes:



CAUTION. *Verify that all mainframes are powered off before continuing the installation procedure. If you are installing more than two expansion mainframes, always use a rackmount kit. Contact your local Tektronix representative for information on site considerations for multiple mainframes.*

**Install the Expansion
Module**

If you have a benchtop mainframe, install the expansion module in any slot of the mainframe except 0 through 2; these slots are reserved for the benchtop controller module (refer to Figure 1 on page 3). If you have only one expansion mainframe, install the expansion module in slot 12 to keep the expansion cables out of your way.

If you are installing two expansion mainframes, consider installing the two expansion modules next to the benchtop controller module to maximize the number of open slots as shown in Figure 2 on page 4.

If you have a TLA715 Portable Mainframe, install the expansion module in any slot. If you install one or two expansion mainframes, you can install the expansion module in slot 1 as shown in Figure 3 on page 4.

You can configure up to four expansion mainframes with the TLA715 Portable Mainframe and up to ten expansion mainframes with a TLA721 Benchtop Mainframe.

To install the expansion module complete the following steps:

1. If the expansion module is not already installed in slot 0 of the expansion mainframe, install it now.



CAUTION. To avoid damaging the chassis, do not use the retaining screws to seat the expansion module. These screws are intended for securing the module and reinforcing the grounding.

2. Seat the expansion module by pushing it into place.
3. Use a screwdriver to tighten the retaining screws (maximum of 2.5 in-lbs).




Figure 1: TLA721 Benchtop Mainframe with one TLA7XM Expansion Mainframe.

4. Place the EXPANSION 1 label in the outlined area on the upper right side of the expansion mainframe.

When you install two expansion mainframes, software determines which chassis is expansion 1 and which is expansion 2 by the order in which you install the expansion modules in the TLA721 Benchtop Mainframe. The expansion module in the lower numbered slot will be expansion 1, and the expansion module in the higher numbered slot will be expansion 2.

5. For the setup in Figure 2 or Figure 3, place the EXPANSION 1 label in the outlined area on the upper right side of the expansion mainframe to the left of the TLA721 Benchtop Mainframe or TLA715 Portable Mainframe. Place the EXPANSION 2 label in the outlined area on the upper right side of the expansion mainframe to the right of the TLA721 Benchtop Mainframe or TLA715 Portable Mainframe.




Figure 2: TLA721 Benchtop Mainframe with two TLA7XM Expansion Mainframes




Figure 3: TLA715 Portable Mainframe with two TLA7XM Expansion Mainframes

Install the Expansion Cables

To connect the three cables from the expansion modules together, complete the following steps:

1. Examine the gray expansion cable to determine if the connectors have labels. If the connectors are not labeled, apply the C labels to each connector.
2. Connect one end of the gray expansion cable to connector C of the expansion module on the expansion mainframe side. Connect the other end of the gray expansion cable to connector C of the expansion module on the TLA721 Benchtop Mainframe or TLA715 Portable Mainframe side.
3. Fasten the expansion cable connector to the expansion module by tightening the two hold-down screws.
4. Examine the two blue expansion cables to determine if the connectors are labeled A and B.
 - a. If the cables are labeled A and B, select the B cable and proceed to step 5.
 - b. If the cables are not labeled, select either blue expansion cable and label each connector with the B label. Select the other cable and apply the A labels to each connector.
5. Connect one end of the blue expansion cable to connector B of the expansion module on the expansion mainframe side. Connect the other end of the blue expansion cable to connector B of the expansion module on the TLA721 Benchtop Mainframe or TLA715 Portable Mainframe side.
6. Fasten the expansion cable connector to the expansion module by tightening the two hold-down screws.
7. Connect one end of the blue expansion cable to connector A of the expansion module on the expansion mainframe side. Connect the other end of the blue expansion cable to connector A of the expansion module on the TLA721 Benchtop Mainframe or TLA715 Portable Mainframe side.
8. Fasten the expansion cable connector to the expansion module by tightening the two hold-down screws.

Chassis Ground Connections

Use the chassis ground connections to connect the grounds of the target system (system-under-test) to the logic analyzer to ensure a common ground connection between instruments (see Figure 4).



WARNING. To reduce the risk of an electrical shock, do not remove the safety ground screw from the logic analyzer. The safety ground screw must always be in place to ensure proper grounding of the power supply to the logic analyzer.




Figure 4: Location of the ground connection on the TLA700 logic analyzers

Installing TLA700 Modules

This section describes how to install modules in your TLA700 mainframe.



CAUTION. *To avoid damaging the instrument, do not install or remove any modules while the instrument is powered on. Always power down the instrument before installing or removing modules.*

Logical Address Switches

Every module in the instrument must have a unique logical address; no two modules can have the same address. Use the two rotary switches on the rear panel of the modules to select the logical address (see Figure 5).

The factory default switch setting is FF (Dynamic Auto Configuration). With dynamic logical address auto configuration, the instrument automatically sets the address to an unused value.

Normally, you would not want to change the default settings. However, you can set the address to a fixed static logical address value. You can select any static addresses between 01 and FE hexadecimal (1 to 254 decimal). If you set the logical address switches to any other setting than FF, you must verify that no two modules (or devices) share the same address.

NOTE. *Do not set any module to logical address 00. Logical address 00 is reserved exclusively for the controller.*




Figure 5: Logical address switches (set to address FF)

Merging Modules

You can merge modules together to create wider modules. If your application requires you to merge modules, refer to *Merging TLA700 Modules* (beginning on page 25) for the merge instructions before continuing with this section.

Installing Modules in the TLA715 Portable Mainframe

You can install any of the modules in any slot that the module key will allow; see Figure 7 on page 11. If you intend to merge the modules, disregard the following suggestions and refer to the merging modules rules on page 25. If you are not merging the modules, and for air flow considerations, follow these guidelines:

- Install a single module in slots 3-4. Place a double-width slot cover over slots 1-2.
- When installing two logic analyzer modules, install the module with the higher channel count in slots 1-2. Install the module with the lower channel count in slots 3-4.
- When installing two logic analyzer modules with different amounts of memory, install the module with the larger memory in slots 3-4. Install the module with the lower memory in slots 1-2.
- Install TLA7Lx/Mx/Nx/Px/Qx modules, TLA7Dx/Ex modules, or TLA7PG2 modules before you install TLA7Axx modules.
- When installing a logic analyzer module with an oscilloscope module, install the oscilloscope module in slots 1-2, and the logic analyzer module in slots 3-4.

Use a screwdriver to tighten the retaining screws to 2.5 in-lbs after seating the modules in place. See Figure 6 on page 10.

Installing Modules in the TLA721 Benchtop or TLA7XM Expansion Mainframe

You must install the benchtop controller in the benchtop mainframe in slots 0-2 (the TLA7XM Expansion Module must be located in slot 0). You can install any of the modules in any slot that the module key will allow; see Figure 7 on page 11. If you intend to merge the modules, disregard the following suggestions and refer to the merging modules rules on page 25. If you are not merging the modules, and for air flow considerations, follow these guidelines:

- Install a single module in slots 3-4. Place a double-width slot cover over slots 5-6, 7-8, 9-10, and 11-12.
- When installing two or more logic analyzer modules, install the module with the highest channel count in slots 3-4. Install the module with the lower channel count in slots 5-6. Place double-width slot covers over slots 7-8, 9-10, and 11-12.
- When installing two or more logic analyzer modules with different amounts of memory, install the module with the largest memory in slots 3-4. Install the module with the lower memory in slots 5-6. Place double-width slot covers over slots 7-8, 9-10, and 11-12.
- Install TLA7Lx/Mx/Nx/Px/Qx modules, TLA7Dx/Ex modules, or TLA7PG2 modules before you install TLA7Axx modules.

- When installing a logic analyzer module with an oscilloscope module, install the logic analyzer module in slots 3-4 and the oscilloscope module in slots 5-6. Place double-width slot covers over slots 7-8, 9-10, and 11-12.

Use a screwdriver to tighten the retaining screws to 2.5 in-lbs after seating the modules in place. See Figure 6.




Figure 6: Installing modules

Keying Modules

Pay careful attention to the module keys when installing the modules. Each module has a key that only allows certain modules to be installed next to other modules. For example, you can install a TLA7Dx Oscilloscope module to the left of a TLA7XM Expansion module, but you cannot install a TLA7Nx Logic Analyzer module to the immediate left of a TLA7XM Expansion module. See Figure 7.




Figure 7: Keying modules

Covering Empty Slots

If you have any unused (empty) slots in your mainframe, install blank-slot panel covers to meet EMC and cooling specifications. Install a blank-slot panel cover for each empty slot as shown in Figure 8 or 9. Use only Tektronix TLA covers; otherwise the mainframe may not meet EMC and cooling requirements.

Make sure that the EMI shielding is in contact with the adjacent panel or module cover, and that the airflow shutter activation arms protrude through the holes in the blank-slot panel.




Figure 8: Installing panel covers on the TLA715 Portable Mainframe




Figure 9: Installing panel covers on the TLA721 Benchtop Mainframe

Connecting Accessories

After installing the mainframes and modules, you can connect the accessories such as external monitors, keyboard, and printer.

Connecting Accessories to the TLA700 Series

The connection points are shown in Figure 10. Use the icons that appear in the circled areas as a guide.




Figure 10: TLA700 series accessories connections

NOTE. Only TLA715/721 instruments have both primary and secondary video outputs. TLA714/720 instruments are equipped with only one video output.

Additional Accessory Connection Information

Table 1 provides additional information on accessories.

Table 1: Additional accessory connection information

Item	Description
Monitor	If you use a non standard monitor, you may need to change the the Windows display settings to achieve the proper resolution.
Printer	Connect the printer to the ECP connector directly. If your printer has a DB-25 connector, use the adapter cable that came with your logic analyzer to connect to the ECP connector.
Rackmount	The TLA600 series logic analyzers, TLA721 Benchtop Mainframes, and the TLA7XM Expansion Mainframes can be installed in rackmount kits. Refer to the respective rackmount kit instructions for installation information.

Connecting Probes

After you have connected all the accessories, you can connect the probes to the instrument. Refer to the appropriate section for your instrument.

For additional information on the individual probes, refer to the instructions that accompanied your probes.



CAUTION. When attaching the probe to the logic analyzer, you must use care to evenly tighten probe screws until they are snug. First slightly tighten screws, then snug each screw to 4 in-lbs (max). Under tightening the probe screws can result in intermittence. Over tightening can result in stripped screws.

Connecting Probes to the Logic Analyzer Module

Connect the logic analyzer probes as shown in Figure 11 and Figure 12.




Figure 11: Connecting the P68xx logic analyzer probes to the TLA7Axx logic analyzer module




Figure 12: Connecting the P64xx logic analyzer probes to the TLA7Lx/Mx/Nx/Px/Qx logic analyzer modules

Configuring and Connecting the Pattern Generator Probes

Some of the TLA Pattern Generator probes require series termination resistors to provide impedance matching for the pattern generator and the target system. Determine the impedance matching for your application, and then refer to the *TLA7PG2 Probe Instruction Manual* for information about how to change the series termination resistors.

Always power down the logic analyzer before connecting the pattern generator probes to the logic analyzer and to the target system.

First Time Operation

Use the information in this section to turn on the logic analyzer for the first time.



CAUTION. *Connect the keyboard, mouse, and other accessories before applying power to the logic analyzer. Connecting the accessories after turning on the logic analyzer can damage the accessories.*

Turning the Logic Analyzer On

Follow these steps to turn the logic analyzer on:

1. Check that the line fuse is correct for your application. See Table 2.
2. Connect the power cord. See Figure 13 on page 18.
3. If you have an external monitor, connect the power cord and turn on the monitor.

Table 2: TLA700 series line fuses

Line voltage	Rating	Tektronix part number
Portable mainframe		
90 V to 132 V operation	8 A, fast blow, 250 V	159-0046-xx
207 V to 250 V operation	6.3 A, fast blow, 250 V	159-0381-xx
Benchtop mainframe		
90 V to 132 V operation	20 A, slow blow, 250 V	159-0379-xx
103 V to 250 V operation	15 A, fast blow, 125 V	159-0256-xx
207 V to 250 V operation	6.3 A, fast blow, 250 V	159-0381-xx




Figure 13: Line fuse and power cord connector locations



CAUTION. To avoid overloading the power distribution system, if you have four or more modules in your mainframe, you must determine the correct fuse and power cord combination.

Although the benchtop mainframe can use the power cord with the 15 A plug, mainframes operating at low line (90 VAC) with four or more instrument modules may require the power cord with the 20 A plug.

See Appendix A: Power Cord and Line Fuse Requirements for the Benchtop Mainframe for further information.

4. Press the On/Standby switch to turn on the mainframe (see Figure 14 for the switch location).
5. Wait for the mainframe to complete the power-on self-tests and start Windows.




Figure 14: TLA700 On/Standby switch locations

Turning on the TLA7XM Expansion Mainframes

The expansion mainframe automatically powers on when the connected benchtop or portable mainframe powers on. If everything is properly connected and operational, you will see the expansion mainframe and the installed modules in the System window.

NOTE. You must have a module installed in the expansion mainframe before the expansion mainframe appears in the System window.

Turning off the Mainframes

To turn off the mainframes, press the On/Standby switch on the mainframe. Both the portable and benchtop mainframes have a built-in soft power-down function that safely powers down the mainframe when you press the On/Standby switch. The expansion mainframes automatically power down when you turn off the benchtop or portable mainframe.

Performing the Incoming Inspection

Incoming inspection consists of verifying the basic operation of the logic analyzer. The power-on diagnostics check the basic functionality. The diagnostics run every time you turn on the logic analyzer.

You can also verify more detailed functionality by running the self-calibration and extended diagnostics.

NOTE. Allow the mainframe and modules to warm up for 30 minutes before running the self-calibration.

To run self-calibration and diagnostics, perform the following:

1. Disconnect any probes attached to the modules.
2. Select the System menu and click Calibration and Diagnostics.
3. Run the self-calibration, and then the extended diagnostics by selecting the proper tab. Results of the tests display on the individual property page.

To run self calibration and external diagnostics for a pattern generator, perform the following:

1. Select the Pattern Generator System menu and click Calibration and Diagnostics.
2. Run the self-calibration, and then the extended diagnostics by selecting the proper tab. Results of the tests display on the individual property page.

NOTE. The time required to run the self calibration on the logic analyzer modules depends on the number of acquisition channels. Modules with a large number of channels may take several minutes to run the self calibration.

Checking the P68xx Logic Analyzer Probes (Optional)

To check the P68xx logic analyzer probes, connect the probes to a signal source, start an acquisition, and verify that the acquired data is displayed in either the listing or waveform windows.

If available, use the TLACAL2 fixture to run the performance verification. For further details, refer to the performance verification procedure in the *TLA7Axx Logic Analyzer Module Service Manual*.

Checking the P64xx Logic Analyzer Probes (Optional)

Connect the P64xx logic analyzer probes to a signal source, start an acquisition, and verify that the acquired data is displayed in either the listing or waveform windows. You can also use the Activity Indicators in the logic analyzer Setup window to view signal activity at the probe tips.

NOTE. If you connect probes to any channels other than the A2 and A3 groups, you must define the groups and channels in the Setup window before acquiring data on other probe channels.

**Checking the P624x
Oscilloscope Probes
(Optional)**

Connect the oscilloscope probes to the Probe Compensation connector on the front panel of the oscilloscope modules. You can then run the Calibrate Probe function in each vertical setup page for the module.

**Checking the P647x
Pattern Generator Probes
(Optional)**

Set up a simple pattern generator program to output a signal to the probes. Connect an oscilloscope probe to the probe outputs and verify that the signal is present at the probe outputs.

**Checking the TLA700
Mainframe (Optional)**

To check the mainframe diagnostics not covered by the TLA Application software, run the TLA700 Mainframe Diagnostics located under the Windows Start menu (Start/Programs/Tektronix Logic Analyzer/TLA Mainframe Diagnostics). Exit the TLA Application before running the external diagnostics.

Backing Up User Files

Back up your user files on a regular basis. Use the Windows back up tools or copy the files to or to another media. Always keep a backup copy of files that you access on a regular basis.

Removing the Replaceable Hard Disk Drive



CAUTION. To avoid permanently damaging the replaceable hard disk drive, do not remove it while the instrument is powered on. Always power down the instrument before removing the hard disk drive.

1. Verify that the instrument is turned off.
2. Remove the replaceable hard disk drive cartridge by depressing it to release the latch; see Figure 15 on page 22.
3. Pull on the replaceable hard disk drive cartridge to remove it from the chassis.




Figure 15: Accessing the TLA700 replaceable hard disk drive

Connecting Probes to the Target System

The logic analyzer connects to the target system through probes. The logic analyzer probes allow you to connect to the target system in several different ways. For probe-specific connection details, refer to the appropriate probe instruction manual or browse the Tektronix website.

Additional Information

For a quick overview of your Tektronix logic analyzer, refer to *Product Overview* beginning on page 39. For detailed information on using the logic analyzer refer to the *Tektronix Logic Analyzer Family User Manual* or to the TLA online help.

To access main online help, go to the Help menu or click the toolbar buttons shown:



TPI Online Help. Select Help on TPI from the drop-down help menu for information on using the TLA Programmatic Interface. A printable version of the TPI online help is available on the instrument. Click Start > Programs > Tektronix Logic Analyzer > TLA Documentation > TPI Manual.

TLAScript Online Help. TLAScript is a script that works with TPI. Select Help from the menu bar within the TLAScript application. To start TLAScript, select Start > Programs > Tektronix Logic Analyzer > TLAScript.

PPI Online Help. Select Help on the TLA7PG2 PPI from the drop-down help menu for information on using the TLA Pattern Generator. A printable version of the PPI online help is available on the instrument. Click Start > Programs > Tektronix Pattern Generator > Pattern Generator Documentation > PPI Manual.

TLAVu and PatGenVu Software. TLAVu and PatGenVu software applications provide you with the ability to view your TLA data offline on your own Microsoft Windows-based PC.

Release Notes. To access the Logic Analyzer Release Notes, click Start > Programs > Tektronix Logic Analyzer > TLA Release Notes. To access the Pattern Generator Release Notes, click Start > Programs > Tektronix Pattern Generator > Pattern Generator Release Notes.

Merging TLA700 Modules

This chapter describes how to merge TLA700 series logic analyzer and pattern generator modules to form wider modules, that all operate from a single time base.

A merged logic analyzer module set consists of a master logic analyzer module and up to four slave logic analyzer modules that are physically connected together by a merge cable and are merged in software. Review the guidelines under *Logic Analyzer Module Merging Rules* and then follow the steps to physically connect the modules together before installing the modules in the mainframe.

A merged pattern generator module set consists of a master pattern generator module and up to four slave pattern generator modules merged in software. Review the guidelines under *TLA7PG2 Pattern Generator Module Merging Rules* on page 26 before installing the modules in the mainframe.

Logic Analyzer Merging Rules

The following logic analyzer module merging rules must be followed:

- Only modules with 102 or 136 channels can be merged.
- Logic analyzer modules must be in adjacent slots and physically connected.
- Logic analyzer modules cannot be merged across mainframes (between the benchtop mainframe and one or more expansion mainframes).
- Merging logic analyzer modules with unequal memory depths will result in the merged modules assuming the depth of the shallowest module.
- When merging logic analyzer modules of unequal channel widths, use the logic analyzer module with the highest number of channels as the master module. If there is a second slave module, the first slave must have greater than or equal the number of channels as the second slave module. Slave 3 cannot have more channels than the master, slave 1 or slave 2. Slave 4 cannot have more channels than the master, slave 1, slave 2, or slave 3.
- The logic analyzer modules must have the same firmware version.
- The maximum merged combinations are two TLA7Lx and TLA7Mx logic analyzer modules; three TLA7Nx, TLA7Px, or TLA7Qx logic analyzer modules; and five TLA7Axx logic analyzer modules.

- TLA7Nx, TLA7Px, and TLA7Qx Logic analyzer modules cannot be merged with TLA7Lx and TLA7Mx Logic analyzer modules (even if they are connected together).
- TLA7Axx modules cannot be merged with TLA7Nx, TLA7Px, TLA7Qx, TLA7Lx, or TLA7Mx modules.
- To merge a logic analyzer module to an established merged set, the established merged set must first be unmerged through software. Unmerged modules are the only potential candidates to add to a merged configuration.

TLA7PG2 Pattern Generator Module Merging Rules

The following pattern generator module merging rules must be followed:

- Pattern generator modules are merged through software.
- Pattern generator modules must be physically adjacent.
- Pattern generator modules may not be merged across mainframes.
- Merging pattern generator modules with unequal memory depths will result in the merged set assuming the depth of the shallowest pattern generator module.
- Pattern generator modules must have the same firmware version.
- When merged, the left-most pattern generator module is the master.

Merge Procedure

Complete the following steps to create a merged module from two or more individual modules. You must complete these steps prior to installing the modules in a mainframe.



CAUTION. *To avoid damaging the mainframe or any modules, always power off the mainframe before removing or installing modules.*

1. Determine which modules will reside in the highest-numbered slots in a single mainframe.
2. Place the merge connector of these modules in the extended position. The module in the lowest-numbered slot must have the merge connector in the recessed position.

Use Figure 16 as a guide for determining the location of the master module with the merged module set. Even though Figure 16 shows a five module set, you can still use the illustration to position the master module with respect to the slave module. For example, if you have a two module set, the master module is located in the lower-numbered slot, and the slave module is in the higher-numbered slot.




Figure 16: Location of modules in a merged system

Merging TLA7Axx Logic Analyzer Modules

Complete the following steps to create a merged module from two to five individual TLA7Axx modules.

1. Place the module on the right side.
2. Using a Torx T-10 screwdriver, remove the two screws holding the merge connector to the module (see Figure 17).




Figure 17: Removing the merger connector assembly from the module

3. Gently lift the merge connector out of the slot and place it in the extended position such that the screw holes line up over the two standoff posts.
4. Install the two screws into the standoff posts. Tighten the screws to 4-in. lbs.
5. Repeat steps 1 through 4 for the remaining modules.

NOTE. When installing the merged modules into a mainframe, you may need the help of another individual.

6. Place the first pair of modules to be merged side-by-side such that the merge connector assemblies line up and connect between the two modules (see Figure 18).
7. Push the two modules together until the connectors are seated in place.

8. Add any additional modules to the set.




Figure 18: Connecting modules in a merged set



CAUTION. Ensure that the mainframe is powered-off before installing or removing the modules. Failure to do so can damage the mainframe or the modules.

9. Place the merged module set into the mainframe.
10. Align the tops and bottoms of the modules with the slots in the mainframe (see Figure 19 on page 30). You may need the help of another individual if your merged module set contains more than two modules.




Figure 19: Installing the merged module set in the mainframe

- 11.** Slide the modules all the way into the mainframe until they rest against the rear panel connectors.

12. Use the injector handles to firmly seat the modules in place one at a time. The merge cable assembly should allow enough play between two side-by-side modules to allow you to seat or unseat them individually.
13. Tighten the four retaining screws on each module to 2.5-in. lbs.
14. After installing all of the modules, power on the mainframe and complete the merge process listed under the Merged Modules tab in the System Configuration dialog box.

Unmerging TLA7Axx Logic Analyzer Modules

Although you can unmerge modules from a merged set from within the TLA application without physically separating modules, there will be situations when you have to physically unmerge the modules. The following procedures provide the steps for unmerging the modules.



CAUTION. *Ensure that the mainframe is powered-off before installing or removing the modules. Failure to do so can damage the mainframe or the modules.*

1. Power off the mainframe before removing the modules from the mainframe.
2. Loosen the four retaining screws on each module.
3. Use the ejector handles to disengage each module in the merged module set from the mainframe.
4. With the assistance of another individual, slide all of the merged modules out of the mainframe and place them on a static-free working surface.
5. Gently separate the modules one at a time from the merged module set.
6. Lay the modules on their right sides.
7. Remove the two Torx T-10 screws that hold the merge cable assembly to the module.
8. Place the merge cable assembly into the recessed position.
9. Install the two Torx T-10 screws onto the assembly and tighten the screws to 4 in-lbs.
10. Repeat steps 7 through 9 for the other modules.

You can now reinstall the modules in the mainframe as needed.

Merging TLA7Lx/Mx/Nx/Px/Qx Logic Analyzer Modules

Use the following procedures to physically merge the logic analyzer modules together.



CAUTION. *Ensure that the mainframe is powered-off before installing or removing the modules. Failure to do so can damage the mainframe or the modules.*

Two-Way Logic Analyzer Merge Procedure

Use the following procedure to merge two logic analyzer modules. For information on merging three modules, see *Three-Way Logic Analyzer Merge Procedure* on page 37.



CAUTION. *Static discharge can damage any semiconductor component in the logic analyzer module.*

Discharge the static voltage from your body by wearing a grounded antistatic wrist strap while performing the merge procedure.

Perform the following steps to merge two modules:

1. If you have not already done so, power off the mainframe and remove the modules that you want to merge together.
2. Determine which module will be designated as the slave module and which module will be the master module.
3. Lay the slave module on the right side (as viewed from the front panel).
4. Remove the screws from the module cover with a screwdriver with a T-10 Torx tip; refer to Figure 20 on page 33.
5. Remove the screws near the front of the module.
6. Remove the screws holding the merge cable bracket to the cover.
7. Remove the top part of the cable bracket and set it aside.
8. Remove the module cover and locate the merge cable.




Figure 20: Removing the cover

9. Replace the cover while feeding the merge cable through the hole in the cover (see Figure 21).

NOTE. Do not twist the cable while feeding it through the hole. If the cable is twisted, the modules will not merge correctly.




Figure 21: Feeding the merge cable through the cover

10. Turn the merge cable bracket over so that the guide pins point up.
11. Place the bracket over the merge cable connector.
12. Install the two screws that hold the merge cable bracket in place.



CAUTION. To prevent damage to the module during the installation process, reinstall the cover exactly as described in steps 14 through 19.

If the cover is not properly seated, the module can be damaged when you install it in the mainframe and it will not meet EMC requirements.

13. Replace the logic analyzer module cover.
14. Push forward on the cover so the tab on the front edge of the cover inserts into the rear of the front subpanel. Make sure that the cover is fully seated (no gaps) against the front and rear chassis flanges.




Figure 22: Seating the cover on the chassis

15. While holding the cover in place, install the screws at the front of the module (two on the top and two on the bottom) to secure the cover to the chassis.
16. Install the screws near the front of the module.
17. Slide the rear panel on the chassis and install the rear panel screws.

18. Install the top and bottom rear screws.
19. Check and tighten all screws.
20. Place the master module adjacent to the slave module so that the two guide pins from the slave module line up with the guide pin holes in the master module.




Figure 23: Lining up the two modules

21. Gently push the two modules together so that the merge connector of the slave module merges with the connector on the master module.
22. Slide the modules all the way into the mainframe until they rest against the rear panel connectors.
23. Use the injector handles to firmly seat the modules in place one at a time.
24. Tighten the four retaining screws on each module to 2.5-in. lbs.

Three-Way Logic Analyzer Merge Procedure

The following procedure is used for merging three logic analyzer modules together to form a merged set with a higher logic analyzer channel count.

In a three-way merge (TLA7Nx, TLA7Px, and TLA7Qx logic analyzer modules only), the master module is in the center. Slave module 1 is to the right of the master module. Slave module 2 is on the left of the master module as shown in Figure 16 on page 27.



CAUTION. *Static discharge can damage any semiconductor component in the logic analyzer module.*

Discharge the static voltage from your body by wearing a grounded antistatic wrist strap while performing the merge procedure.

Perform the *Two-Way Logic Analyzer Merge Procedure* beginning on page 32.

Perform the following steps to merge the second slave module:

1. Lay the two merged module set on its right side (as viewed from the front panel).
2. Follow the procedure beginning on page 32 to merge the second slave module to the left of the center master module.

Storing the Logic Analyzer Module Merge Cable

Perform the following steps to store the logic analyzer merge cable inside the logic analyzer module:

1. Use the screwdriver with the T-10 Torx tip to remove the screws that hold the merge cable bracket in place.
2. Remove the merge cable bracket.
3. Remove the screws from the side cover and rear cover.
4. Push the merge cable through the side cover and remove the cover.
5. Position the merge cable as shown in Figure 24.




Figure 24: Positioning the merge cable before installing the cover

6. Push forward on the cover so that you insert the tab on the front edge of the cover into the rear of the front subpanel. Make sure that the cover is fully seated and there are no gaps between the front and rear chassis flanges; refer to Figure 22 on page 35.
7. While holding the cover in place, install the screws nearest the front of the module to secure the cover to the chassis.
8. Install the screws near the front of the module.
9. Slide the rear panel on the chassis and install the rear panel screws.
10. Install the top and bottom rear screws.
11. Install the merge cable bracket so that the guide pins point into the module.
12. Install and tighten the screws on the merge cable bracket.
13. Verify that you have installed and tightened all screws on the module.

Product Overview

This chapter describes the product controls and connectors of the logic analyzers. Refer to the online help for detailed operating information for the logic analyzer.

Front Panel Controls

You can use the front panel controls to operate most of the TLA715 portable mainframes (see Figure 25). You can also attach an external keyboard, monitor, and mouse to operate the logic analyzers. The TLA721 Benchtop Mainframes do not have front-panel controls and require an external keyboard, monitor, and mouse.




Figure 25: TLA715 Portable mainframe front panel

TLA700 Series External Connectors

The mainframe external connectors are shown in Figure 26. The following connections are available:

- System Trigger In and System Trigger Out, used to receive or send a trigger from/to an external source.
- External Signal In and External Signal Out, used to receive or send a signal from/to an external source.
- Accessory connections.




Figure 26: TLA700 series external connectors

Restoring and Reinstalling Software

Most of the software comes factory-installed when you receive your logic analyzer. You only need to refer to this section if you reinstall your software. These instructions only refer to reinstalling the application software and operating system. If you want to upgrade to a newer application software version and operating system, contact your local Tektronix representative about purchasing the TLA7UP field upgrade kit. This section also provides information on installing related logic analyzer software on a PC for remote operation or for offline applications.

NOTE. *If you install or reinstall software on a remote PC, make sure that the software version matches that of the main application on the logic analyzer.*

Restoring the Hard Disk Image



CAUTION. *The software installation procedure using the Hard Disk Image CD will overwrite the **entire contents** of your hard disk. If you want to save files or software applications from the hard disk, back them up to another media (a second hard disk drive, CD, or network drive) before continuing with this procedure.*

TLA714, or TLA720 Logic Analyzers

Before restoring the software on your instrument, you are encouraged to update the BIOS settings. To update the BIOS or to verify the BIOS settings, follow the procedures under *Flashing the BIOS* before restoring the software on your hard disk.

If you feel that your BIOS settings do not need updating, continue with the steps under *Reinstalling the Hard Disk Image* beginning on page 46.

TLA715 or TLA721 Logic Analyzers

If you have a TLA715 or TLA721 logic analyzer, there is no need to update the BIOS settings. Continue with the steps under *Reinstalling the Hard Disk Image* beginning on page 46.

Flashing the BIOS

You may need to flash the controller BIOS on your logic analyzer to update the controller with the latest flash image before reinstalling software on the hard disk.

This procedure is only necessary if you need to update the latest flash image. To flash the BIOS, complete the following steps (use the TLA700 BIOS floppy disk that came with your instrument or with the TLA7UP Upgrade kit):

1. Power on the logic analyzer and press function key F2 before the Windows operating system starts. The BIOS Setup menu displays.
2. From the BIOS Setup menu, go to the Exit menu.
3. Insert the TLA700 BIOS disk in the floppy disk drive.
4. From the Exit menu, choose Exit & Update BIOS.
5. When the system displays a dialog box asking if you want to proceed with the Flash update, confirm your choice.

The display goes blank during the flash operation for about one minute. When the update is complete, the logic analyzer automatically reboots.

6. Remove the BIOS disk from the floppy disk drive.



CAUTION. Do not remove the floppy disk drive or power down the logic analyzer during the flash operation. Doing so will cause the system to become inoperable.

The following procedure is necessary after replacing the hard disk drive or when the BIOS settings are corrupted or lost. To configure the Controller BIOS, complete the following steps:

1. Power on the logic analyzer and press function key F2 before the logic analyzer boots the Windows operating system.
2. Press function key F9, select Yes, and then press Enter to set the default settings. Verify that the hard disk was auto-recognized and that the correct size of the hard disk is displayed in the Primary Master setting.

NOTE. The TLA715 and TLA721 logic analyzers use the default BIOS settings. Because of this, no BIOS settings are provided in this document.

3. If you have a TLA715 or TLA721 logic analyzer, press function key F10 to exit and save the default BIOS settings and then continue with the hard disk image installation procedure on page 46.
4. If you have a TLA714 or TLA720 logic analyzer verify that all of the settings are the same as the settings in Table 3.
5. Press function key F10 to exit and save the BIOS setup.

Table 3: TLA714 and TLA720 Controller BIOS setup

Parameter	Factory setting	Submenu parameter	Factory setting
Main			
System Time	<i>Set to current time</i>		
System Date	<i>Set to current date</i>		
Legacy Diskette A	[1.44/1.25 MB, 3 1/2"]		
▶ Primary Master	<i>hard disk drive size</i>		
		Type	[Auto]
		Cylinders	<i>Set by Autotype</i>
		Heads	<i>Set by Autotype</i>
		Sectors	<i>Set by Autotype</i>
		Maximum Capacity	<i>Set by Autotype</i>
		Multi-sector transfers	<i>Set by Autotype</i>
		LBA Mode Control	<i>Set by Autotype</i>
		32-Bit I/O	[Disabled]
		Transfer Mode	<i>Set by Autotype</i>
		Ultra DMA Mode	<i>Set by Autotype</i>
▶ Primary Slave	[None]		
▶ Secondary Master	[CD-ROM]		
▶ Secondary Slave	[None]		
Enable SimulScan	[Disabled]		
Summary Screen	[Disabled]		

Table 3: TLA714 and TLA720 Controller BIOS setup (Cont.)

Parameter	Factory setting	Submenu parameter	Factory setting
▶ Memory Cache			
		Memory Cache	[Enabled]
		External Cache	[Disabled]
		Cache System BIOS area:	[Enabled]
		Cache Video BIOS area:	[Disabled]
		Cache D000 - D3FF:	[Disabled]
		Cache D400 - D7FF:	[Disabled]
		Cache D800 - DBFF:	[Disabled]
System Memory	640 KB		
Extended Memory	<i>Installed memory - 640 K</i>		
Advanced			
▶ I/O Device Configuration			
		Local Bus IDE Adapter	[Both]
		Serial port A	[Enabled]
		Base I/O Address	[3F8]
		Interrupt	[IRQ4]
		Serial port B	[Enabled]
		Mode	[Normal]
		Base I/O Address	[2F8]
		Interrupt	[IRQ3]
		Parallel Port	[Enabled]
		Mode	[ECP]
		Base I/O Address	[378]
		Interrupt	[IRQ7]
		DMA Channel	[DMA 1]
		Floppy disk controller	[Enabled]
▶ Advanced Chipset Control			
		DRAM Speed	[60 ns]
		DMA Aliasing	[Enabled]
		16 Bit I/O Recovery	[4.5]
		8 Bit I/O Recovery	[4.5]
Plug & Play O/S	[Yes]		
Reset Configuration Data	[No]		

Table 3: TLA714 and TLA720 Controller BIOS setup (Cont.)

Parameter	Factory setting	Submenu parameter	Factory setting
PS/2 Mouse	[AutoDetect]		
Large Disk Access Mode:	[Other]		
Secured Setup Configurations	[No]		
▶ PCI Configuration			
		ISA graphics device installed	[No]
		▶ PCI/PNP ISA UMB Region Exclusion	
		C800 - CBFF	[Available]
		CC00 - CFFF	[Available]
		D000 - D3FF	[Available]
		D400 - D7FF	[Available]
		D800 - DBFF	[Available]
		DC00 - DFFF	[Available]
		▶ PCI/PNP ISA IRQ Resource Exclusion	
		IRQ3	[Available]
		IRQ4	[Available]
		IRQ5	[Available]
		IRQ7	[Available]
		IRQ9	[Available]
		IRQ10	[Available]
		IRQ11	[Available]
		IRQ14	[Available]
		IRQ15	[Available]

Table 3: TLA714 and TLA720 Controller BIOS setup (Cont.)

Parameter	Factory setting	Submenu parameter	Factory setting
Power			
Power Savings	[Disabled]		
Standby Timeout:	[Off]		
Auto Suspend Timeout	[Off]		
Resume On Time	[Off]		
IDE Drive 0 Monitoring	[Disabled]		
IDE Drive 1 Monitoring	[Disabled]		
IDE Drive 2 Monitoring	[Disabled]		
IDE Drive 3 Monitoring	[Disabled]		
PCI Bus Monitoring	[Disabled]		
Boot			
1.	[Diskette Drive]		
2.	[Removable Devices]		
3.	[Hard Drive]		
4.	[ATAPI CD-ROM Drive]		
▶ Hard Drive			
		1.	<i>Currently installed drive ID</i>
		2.	[Bootable Add-in Card]
▶ Removable Devices			
Exit			
▶ CMOS Save & Restore			
		CMOS Restore Condition	[Never]

Reinstalling the Hard Disk Image

The Tektronix Logic Analyzer comes with a CD containing the Microsoft Windows operating system and the latest application software. The process of reloading the software on the hard disk will destroy any files or programs installed on the hard disk.

Use the appropriate CD for your application.

- For TLA715 or TLA721 instruments (or upgraded TLA714 and TLA720 instruments with new controllers), use the CD labeled *TLA715 & TLA721 Hard Disk Image*. Upgraded TLA714 and TLA721 instruments can be identified by a TLA7UP Option 16 or Option 17 label on the instrument.

- For TLA714 or TLA720 instruments, use the CD labeled *TLA714 & TLA720 Hard Disk Image*.



CAUTION. To avoid destroying the *entire contents* of your hard disk, save any files or applications by backing them up to another media (a second hard drive, CD, or a network drive) before continuing with this procedure.

Backing Up Files

Before loading the Hard Disk Image software, make sure that you back up any files and personal documents to an external storage device.

You can find most TLA user files using the Windows Search utility. For example, open Windows Explorer and select the C:\My Documents folder. Right click on the folder and select Search. Enter one of the suffixes from Table 4 to locate the files in the current folder and all subfolders (you may want to search for other file suffixes depending on the files installed on your logic analyzer).

Table 4: TLA user file suffixes

Suffix	Description
.tla	TLA setup files
.tsf	TLA symbol files
.tbf	Tektronix binary format
.tls	TLA script file
.tpg	Tektronix pattern generator files
.txt	Tektronix TLA data exchange format files
.stk	Stack files
.spz	Protocol files

Once you find the files, copy them to the external storage device. Use this procedure to find any files or applications that you may want to save.

If you purchased any microprocessor support packages, you need to reinstall the application after you reinstall the hard disk image. If you don't have a copy of the microprocessor support software, contract your Tektronix Account Manager to order a replacement copy. If you cannot contact the account manager, contact the Tektronix Support Center (refer to *Contacting Tektronix* on page xii at the beginning of this document).

NOTE. You can reinstall the Microsoft Windows operating system and other software only from the Hard Disk Image CD that came with your instrument. These software applications are licensed and cannot be reinstalled by any other method without violating the license agreements. The SnagIt and CheckIt Utilities are also available on the Tektronix application CD.

Installing the Operating System and TLA Application Software

This procedure reformats the hard disk, installs the operating system software, and installs the Tektronix Logic Analyzer application software. Because this procedure reformats the hard disk drive, be sure to back up any files or software that you want to preserve by following the steps in the previous section.



CAUTION. To avoid losing user files on your hard disk, back them up before proceeding.

Change the BIOS Boot Settings. Before installing the Hard Disk Image, you may need to change the BIOS settings to enable booting the logic analyzer from the CD-ROM.

1. Restart the logic analyzer and then press function key F2 to enter the BIOS setup.
2. In the BIOS setup, go to the Boot menu.
3. Set the Boot devices for your instrument as shown in Table 5 (follow the on-screen instructions to change the settings).

Table 5: Bios Boot settings for reinstalling software from the CD-ROM

Instrument	Setting
TLA715 or TLA721	ATAPI CD-ROM Drive
	+Removable Devices
	+Hard Drive
TLA714 or TLA720	First Boot Device: [ATAPI CDROM Drive]
	Second Boot Device: [Diskette Drive]
	Third Boot Device: [Hard Drive]

4. Save the settings by pressing function key F10 and confirm that you want to save the new settings.

Load the Hard Disk Image. Complete the following steps to load the Hard Disk Image.

1. Insert the Hard Disk Image CD in the CD-ROM drive.
2. Reboot the logic analyzer.
3. Review the license agreement. If you agree to the terms of the license agreement, proceed with the next step.

NOTE. Use care when proceeding through the software license agreement. Ensure that you make the proper selections.

4. After you review the software license agreement, a dialog box prompts you to either continue or cancel the upgrade process. Click Continue to begin loading the hard disk image.
5. There is a warning that the contents of your hard disk will be destroyed if you choose to continue. Click Yes to continue the process.
6. The program will automatically start and guide you through the rest of the procedure. The image loading procedure is fully automatic and takes approximately 15 minutes to complete.

The image loading procedure automatically installs and sets up the logic analyzer application. You do not need to make any changes to the setup to use the logic analyzer.

7. After the image is loaded, remove the CD from the CD-ROM drive and reboot the logic analyzer.
8. The Systems Settings Change error message displays, prompting you to restart the instrument before your changes can take effect. Click Yes to restart the instrument.
9. Reinstall any user files that you backed up previously. Reinstall any software (such as the microprocessor support packages) that you want to use on the logic analyzer.
10. If desired, reconfigure the TLA network interface.

Reinstalling the TLA Application Software and the Pattern Generator Application Software

Complete the following steps to reinstall the latest version of the TLA application software or the pattern generator application software. Use these steps as a first resort to recovering from application software problems. If you still experience problems with the software after completing these steps, follow the instructions under *Restoring the Hard Disk Image* beginning on page 41.

While using this procedure you will be asked to log on as Administrator. The logic analyzer is initially set up to automatically log on as Administrator (with no password) so you may not see the login prompt. If the network setups have been changed on your instrument, make sure that you log on as Administrator or as a user who has administrator privileges. Failure to do so can prevent the software upgrade from completing successfully.

1. Log on to the instrument as Administrator and quit any applications.
2. Install Disc 1 of the Tektronix Logic Analyzer Family Application Software in the CD-ROM drive of the logic analyzer.
3. Click Run in the Windows Start menu to display the Run dialog box.
4. To reinstall the TLA application software, enter D:\TLA Application SW\Setup.exe in the Run dialog box (if your CD-ROM drive is not the D-drive, enter the appropriate letter for your drive).
5. To reinstall the pattern generator application software, enter D:\Pattern Generator Application SW\Setup.exe in the Run dialog box (if your CD-ROM drive is not the D-drive, enter the appropriate letter for your drive).
6. Click OK to perform the installation.

If you have an existing version of the software on the hard disk, the installation program will detect it and ask if you want to remove it. Follow the on-screen instructions to remove the software, answering “Yes” to any prompts. Restart the instrument when prompted. Repeat Step 4 to reinstall the software following any on-screen prompts.

7. After the software has been successfully installed, restart the instrument.

Installing the TPI or PPI Remote Operation Software

The TPI client software and the PPI client software are software packages that allow you to remotely control the logic analyzer or pattern generator from a PC. These software packages are located on Disc 1 of the TLA application software set. You must ensure that the version of the TPI and PPI client software is the same as that of TLA and pattern generator application on your logic analyzer.

NOTE. *Controlling the TLA instruments with the TPI.NET software from a PC, does not require the installation of any additional software. For information on setting up and running the TPI.NET software on your PC, refer to the TPI.NET Instructions on the TLA Documentation CD.*

Complete the following steps to update the TPI and PPI client software packages on your PC. If you have an older version already installed on your PC, the program will automatically detect it and replace it during the upgrade process.

1. Install Disc 1 of the Tektronix Logic Analyzer Family Application Software in the CD-ROM drive of the PC.
2. Click Run in the Windows Start menu to display the Run dialog box.
3. To install the TPI client software, enter D:\TPI Client SW\Setup.exe in the Run dialog box.
4. To install the PPI client software, enter D:\PPI Client SW\Setup.exe in the Run dialog box.
5. Click OK to perform the installation. Follow any on-screen instructions.
6. If you have an earlier version of either software package installed on your PC, the Setup.exe program will uninstall the application before installing the new version. If you are prompted for permission to remove unused shared files or any read-only files, select Yes to All.

NOTE. *You may also want to refer to the TPI or PPI online help for configuration instructions for the TPI and PPI client software.*

Installing the TLAVu and PatGenVu Software on a PC

TLAVu application software and the PatGenVu application software allow you to view data and create setups for your logic analyzer or pattern generator on a PC. You must ensure that the versions of the software are the same as that of TLA and PatGenVu applications. The TLAVu and PatGenVu application software are located on Disc 2 of the Tektronix Logic Analyzer Family Application Software set.

Complete the following steps to update the application software on your PC:

1. Install Disc 2 of the Tektronix Logic Analyzer Family Application Software in the CD-ROM drive of the PC.
2. Click Run in the Windows Start menu to display the Run dialog box.
3. To install the TLAVu software, enter D:\TLAVu\Setup.exe in the Run dialog box.
4. To install the PatGenVu software, enter D:\PatGenVu\Setup.exe in the Run dialog box.
5. Click OK to perform the installation. Follow any on-screen instructions.
6. If you have an earlier version of the TLAVu or PatGenVu applications installed on your PC, the respective Setup.exe programs will uninstall the old application before installing the new version. If you are prompted for permission to remove unused shared files or any read-only files, select Yes to All.

NOTE. *The ReadMe file for the TLAVu application contains most of the information that you need to run the application. Access the ReadMe file by selecting: Start → Programs → Tektronix Logic Analyzer → TLA Documentation → TLAVu ReadMe or Start → Programs → Tektronix Pattern Generator → Pattern Generator Documentation → PatGenVu ReadMe.*

Upgrading or Restoring Firmware

You may have to upgrade the firmware on the logic analyzer or on individual modules if the firmware version is not compatible with the TLA application software version. This will be indicated by one or more messages (one per module) when you start the logic analyzer. The most current firmware for the TLA application software resides in a file on the hard disk of the logic analyzer.

Although the firmware update procedures are similar, there are some key differences between the Tektronix Logic Analyzer products and are therefore listed as separate procedures. If you have mixed modules within your TLA700 mainframe, review the procedures for each of the modules before beginning the upgrade.

Upgrading Firmware on TLA7Axx Logic Analyzer Modules

Use the following procedure to upgrade the firmware for the TLA7Axx Series Logic Analyzer Modules.

1. Note which modules require new firmware.

If any modules are missing from the System window, you can verify the status of the modules by doing the following steps:

- a. Select System Properties from the System menu.
- b. Click the Modules tab.
- c. Note the information under the Messages column for any installed modules. If any modules indicate invalid or similar messages, you must update the firmware for those modules.

2. Exit the logic analyzer application.
3. Click Start → Programs → Tektronix Logic Analyzer → TLA Firmware Loader.
4. You may be prompted to cycle the power on the mainframe after completing the upgrade operation. Click Yes to continue.

The logic analyzer will scan the mainframe to determine which modules are installed and which modules can have their firmware upgraded. If you have any older modules, you may see them listed in the bottom half of the window. These modules cannot be updated until you install the flash jumper on the rear of the modules.

5. Select the modules that you want to update from the list of modules displayed in the Supported list box near the top of the window. If you are updating more than one module at a time, note the slot location of the module in the selection box.
6. Select Load Firmware from the Execute menu.

7. Click the TLA7A.lod file for the selected module.

NOTE. Be sure to select the proper .lod file for each module. Note the slot number in the title bar so that you select the correct module for the .lod file.

8. Click OK. You will be prompted to confirm your action; click Yes.

NOTE. The program will not allow you to load firmware to an incompatible module. For example, the program will not load oscilloscope firmware to a logic analyzer module.

The program will load the firmware for each module one at a time. The process may take several minutes per module.

9. When the firmware has been loaded for each module, exit the firmware loader program and power down the logic analyzer. You must power down the logic analyzer to allow the TLA application to start up properly.
10. Remove the logic analyzer module from the mainframe.
11. Locate the big label on the side of the module.
12. Record the firmware version that is printed on the label. You will need this information to see that the firmware version matches the label.
13. Reinstall the module in the mainframe and power on the mainframe.
14. After the logic analyzer completes the power-on diagnostics, select System Properties from the System menu.
15. Click the module tab (for example, LA1).
16. Verify that the firmware version for the selected module matches the version on the label that you recorded in step 12.
17. If the firmware versions do not match, power down the mainframe, remove the module from the mainframe and update the label.

**Upgrading Firmware on
TLA7Lx/Mx/Nx/Px/Qx/
Dx/7Ex Modules**

Complete the following steps to upgrade the module firmware on the TLA7Lx, TLA7Mx, TLA7Nx, TLA7Px, or TLA7Qx logic analyzer modules and the TLA7Dx or TLA7Ex oscilloscope modules. These modules require you to install a jumper on the rear of the module before you can upgrade the firmware.

1. Note which of the modules that may require new firmware.

If any modules are missing from the System window, you can verify the status of the modules by doing the following steps:

- a. Select System Properties in the System menu.
 - b. Click the Modules tab.
 - c. Note the information under the Messages column for any installed modules. If any modules indicate invalid or similar messages, you must update the firmware for those modules.
2. Turn off the logic analyzer and disconnect the power cord.
 3. Remove the modules from the logic analyzer.
 4. Refer to Figure 27 on page 56 and locate the flash programming pins on the rear of each module.
 5. Install a jumper on the flash programming pins (use one of the spare jumpers that came with your logic analyzer).
 6. Reinstall the module(s) in the logic analyzer.
 7. Reconnect the power cord and then power on the logic analyzer.
 8. Wait for the TLA application to start.

NOTE. Any modules with the flash programming jumper installed will not display in the System window.

9. Exit the TLA application (and pattern generator application if you have it installed on your instrument).




Figure 27: Flash programming pins

10. Click Start → Programs → Tektronix Logic Analyzer → TLA Firmware Loader.
11. Select the modules that you want to update from the list of modules displayed in the Supported list box near the top of the window. This selects the modules for the upgrade.
12. If you are upgrading more than one module at a time, note the slot location of the module in the selection box.
13. Select Load Firmware from the Execute menu.
14. Click the proper .lod file for the selected module; refer to Table 6 if necessary. (The .lod files are located in the C:\Program Files\TLA 700\Firmware directory).

NOTE. Be sure to select the proper .lod file for each module. Note the slot number in the title bar so that you select the correct module for the .lod file.

Table 6: TLA firmware files

Module type	.lod file
TLA7Nx, TLA7Px, TLA7Qx logic analyzer modules	TLA7NPQ.lod
TLA7Lx and TLA7Mx logic analyzer modules	TLA7LM.lod
TLA7Dx and TLA7Ex oscilloscope modules	FirmwareDSO.lod
TLA720 Benchtop controller module	TLA720.lod

15. Click OK. You will be asked to confirm your action; click Yes when prompted.

NOTE. The program will not allow you to load firmware to an incompatible module. For example, the program will not load oscilloscope firmware to a logic analyzer module.

The program will load the firmware for each module one at a time. The process may take several minutes per module.

16. When the upgrade is complete, exit the program.
17. Turn off the logic analyzer and disconnect the power cord.
18. Remove the module from the instrument and remove the jumper from the Flash programming pins on the rear of the module. Keep the jumper for future updates.
19. Locate the big label on the side of the module.
20. Record the firmware version that is printed on the label. You will need this information to see that the firmware version matches the label.
21. Reinstall the module in the mainframe and power on the mainframe.
22. After the logic analyzer completes the power-on diagnostics, select System Properties from the System menu.
23. Click the module tab (for example, LA1).
24. Verify that the firmware version for the selected module matches the version on the label that you recorded in step 20.
25. If the firmware versions do not match, power down the mainframe, remove the module from the mainframe and update the label.

Upgrading Firmware on the TLA7PG2 Pattern Generator Modules

Use the following procedure to upgrade the firmware on the pattern generator modules.

1. Note which modules require new firmware.

If any modules are missing from the System window, you can verify the status of the modules by doing the following steps:

- a. Select System Properties in the System menu.
 - b. Click the Modules tab.
 - c. Note the information under the Messages column for any installed modules. If any modules indicate invalid or similar messages, you must update the firmware for those modules.
2. Power down the mainframe and disconnect the power cord.
 3. Remove the modules from the mainframe.
 4. Refer to Figure 27 on page 56 and locate the flash programming pins on the rear of each module.
 5. Install a jumper on the flash programming pins (use one of the spare jumpers that came with your pattern generator).
 6. Reinstall the modules in the mainframe.
 7. Reconnect the power cord, and then power on the mainframe.
 8. Wait for the pattern generator application to start.

NOTE. Any modules with the flash programming jumper installed will not display in the System window.

9. Exit the pattern generator application (and the TLA application).
10. Click Start → Programs → Tektronix Logic Analyzer → TLA Firmware Loader.
11. Select the modules that you want to update from the list of modules displayed in the Supported list box near the top of the window. This selects the modules for the upgrade.
12. If you are upgrading more than one module at a time, note the slot location of the module in the selection box.
13. Select Load Firmware from the Execute menu.
14. Select the tla7pg2.lod file for the selected module; if necessary, navigate to the C:\Program Files\Tektronix Pattern Generator\Firmware folder.

15. Click OK. You will be prompted to confirm your action; click Yes.

The program will load the firmware for each module one at a time. The process may take several minutes per module.

16. When the upgrade is complete, exit the program.
17. Power down the mainframe and disconnect the power cord.
18. Remove the module from the instrument and remove the jumper from the Flash programming pins on the rear of the module. Keep the jumper for future updates.
19. Locate the big label on the side of the module.
20. Record the firmware version that is printed on the label. You will need this information to see that the firmware version matches the label.
21. Reinstall the module in the mainframe and power on the mainframe.
22. After the instrument completes the power-on diagnostics, select System Properties from the System menu.
23. Click the module tab (for example, PG1).
24. Verify that the firmware version for the selected module matches the version on the label that you recorded in step 20.
25. If the firmware versions do not match, power down the mainframe, remove the module from the mainframe and update the label.

Appendix A: TLA721 Mainframe Power Information

The benchtop and expansion mainframes come with two power cords and three fuses (one fuse is already installed).



CAUTION. *You must determine the correct fuse and power cord for your configuration. This is important to avoid overloading the power distribution system and ensures that you comply with the National Electrical Code.*

The power consumption depends on the number and type of instrument modules installed in the mainframes. Table 7 lists the power consumed for each module.

To determine the total power consumption, perform the following steps:

1. Use Table 7 to determine the power consumption for each module.
2. Add the power for each module to determine the total power consumption.
3. Determine at which line voltage you will be operating.
4. Refer to Figure 28 on page 63 to determine the proper power cord and line fuse for your mainframe.

Table 7: Power for instrument modules

Module type	Power (Watts)
Mainframe ¹	100
TLA721 Benchtop Controller	70
TLA720 Benchtop Controller	50
TLA7XM Expansion Module	20
TLA7AA1	45
TLA7AA2	65
TLA7AA3	85
TLA7AA4	105
TLA7AB2	65
TLA7AB4	105
TLA7Q2	51
TLA7Q4	75
TLA7P2	50
TLA7P4	74
TLA7N1	45

Table 7: Power for instrument modules (Cont.)

Module type	Power (Watts)
TLA7N2	58
TLA7N3	71
TLA7N4	82
TLA7L1	55
TLA7L2	73
TLA7L3	94
TLA7L4	109
TLA7M1	57
TLA7M2	76
TLA7M3	99
TLA7M4	116
TLA7D1	80
TLA7D2	111
TLA7E1	90
TLA7E2	121
TLA7PG2	110

¹ **Power for benchtop mainframe and expansion mainframe with fans operating at maximum speed.**

For power usage in the unshaded region of Figure 28, use either the power cord with the 15 A plug (two parallel prongs and ground) or the power cord with the 20 A plug (two perpendicular prongs and ground).

For high power usage combined with low input line voltages (shaded region), use only the power cord with the 20 A plug. Select the proper fuse based on the ranges shown in Figure 28.




Figure 28: Power cord identification chart

For example, assume that your TLA721 benchtop system consists of four TLA7Q4 Logic Analyzer Modules and one TLA7E2 DSO Module. Also assume that you will be operating the mainframe at 90 VAC.

Add 121 Watts (for the DSO Module) + 4 X 75 Watts (for the logic analyzer modules) + 70 Watts (for the controller) + 100 Watts for the mainframe to come up with a total value of 591 Watts.

Because the power consumption (at 90 VAC) is approaching the shaded area of the graph in Figure 28, you should consider using the 20A power cord.

NOTE. *If you are configuring an expansion mainframe, remember to use the power value for the expansion module instead of the benchtop controller.*

Appendix B: User Service Procedures

This appendix describes high-level service information and procedures for the Tektronix logic analyzers. Mainframe and module service troubleshooting procedures are located in the service manuals.

Service Offerings

Tektronix provides service to cover repair under warranty as well as other services that are designed to meet your specific service needs.

Whether providing warranty repair service or any of the other services listed below, Tektronix service technicians are well equipped to service the logic analyzers. *Services are provided at Tektronix Services Centers and on-site at your facility, depending on your location.*

Warranty Repair Service

Tektronix warrants this product as described in the warranty statements at the front of this manual. Tektronix technicians provide warranty service at most Tektronix service locations worldwide. The Tektronix product catalog lists all service locations worldwide.

Calibration and Repair Service

In addition to warranty repair, Tektronix Service offers calibration and other services that provide cost-effective solutions to your service needs and quality-standards compliance requirements. Our instruments are supported worldwide by the leading-edge design, manufacturing, and service resources of Tektronix to provide the best possible service.

General Care

Protect the instrument from adverse weather conditions. The instrument is not waterproof. Do not store or leave the instrument where the LCD display will be exposed to direct sunlight for long periods of time.



CAUTION. *To avoid damage to the instrument, do not expose it to sprays, liquids, or solvents.*

Preventive Maintenance

Once a year the electrical performance should be checked and the instrument accuracy certified (calibrated). This service must be performed by a qualified service technician using the procedures outlined in the appropriate service manual for the Tektronix Logic Analyzer product.

Preventive maintenance mainly consists of periodic cleaning. Periodic cleaning reduces instrument breakdown and increases reliability. Clean the instrument as needed, based on the operating environment. Dirty conditions may require more frequent cleaning than computer room conditions.

Refer to your logic analyzer probe instructions for specific cleaning procedures for the probes and probe connectors.

Cleaning the Flat Panel Display

The LCD flat panel is a soft plastic display and must be treated with care during cleaning.



CAUTION. *Improper cleaning agents or methods can damage the flat panel display.*

Do not use abrasive cleaners or commercial glass cleaners to clean the display surface.

Do not spray liquids directly on the display surface.

Do not scrub the display with excessive force.

Avoid getting moisture inside the instrument while cleaning the display; use only enough solution to dampen the wipe.

Clean the flat panel display surface by gently rubbing the display with a cleanroom wipe (such as Wypall Medium Duty Wipes, #05701, available from Kimberly-Clark Corporation).

If the display is very dirty, moisten the wipe with distilled water or a 75% isopropyl alcohol solution and gently rub the display surface. Avoid using excess force or you may damage the plastic display surface.

Exterior Surfaces

Clean the exterior surfaces with a dry, lint-free cloth or a soft-bristle brush. If dirt remains, use a cloth or swab dampened with a 75% isopropyl alcohol solution. A swab is useful for cleaning in narrow spaces around the controls and connectors. Do not use abrasive compounds on any part of the instrument.



CAUTION. *To avoid damaging the instrument follow these precautions:*

Avoid getting moisture inside the instrument during external cleaning and use only enough solution to dampen the cloth or swab.

Do not wash the front-panel On/Standby switch. Cover the switch while washing the instrument.

Use only deionized water when cleaning. Use a 75% isopropyl alcohol solution as a cleanser and rinse with deionized water.

Do not use chemical cleaning agents; they may damage the instrument. Avoid chemicals that contain benzene, toluene, xylene, acetone, or similar solvents.

Floppy Disk Drive

The floppy disk drive requires routine maintenance to operate at maximum efficiency. The disks can be damaged if dirt and dust accumulate on the recording surfaces. To prevent damage, the disks should be properly stored in their protective containers where they will not be exposed to dust or dirt. In addition, you must clean the head periodically.

You will need a 3.5-inch floppy disk head-cleaning kit for routine maintenance. Perform the routine maintenance as follows:

Clean the face of the floppy disk drive monthly with a dampened cloth.



CAUTION. *Do not allow moisture to enter the disk drive. When power is applied, the internal components can be damaged.*

Clean the head monthly following the instructions provided with the head-cleaning kit.

In Case of Problems

Review the following sections if you encounter any problems with your instrument. Detailed troubleshooting procedures are available in the service manuals for your logic analyzer product. For additional help, contact your local Tektronix Service Representative.

Diagnostics

The logic analyzer runs power-on diagnostics every time you power on the instrument. You can view the results of the diagnostics by selecting Calibration and Diagnostics from the System menu. You can run more detailed diagnostics by selecting Extended diagnostics. Here you can run all tests, loop on one or more tests, or loop on a test until a failure occurs.

Before running the extended diagnostics, disconnect any attached probes.

TLA Mainframe Diagnostics. The TLA mainframe diagnostics program is a stand-alone application. These diagnostics check the operation of the mainframe beyond the basic PC circuitry. These diagnostics also check the front-panel knobs of the portable mainframe.

CheckIt Utilities. The CheckIt Utilities is a separate application located in the Windows Start Programs menu (Start > Programs > CheckIt Utilities). The diagnostics check the basic PC operations of the controller.

Software Problems

Your logic analyzer comes with most software installed. Before running any of the diagnostics, check the online release notes to verify that the logic analyzer software is compatible with the module firmware.

Many software problems can be due to corrupted or missing software files. In most cases the easiest way to solve software problems is to reinstall the software and follow the on-screen instructions. Refer to *Restoring and Reinstalling Software* beginning on page 41 for instructions on reinstalling or upgrading software.

Hardware Problems

If you are certain that you have installed the logic analyzer correctly, run the extended diagnostics (located under the System menu) to identify any problems. If your logic analyzer powers up so that you have access to the desktop, run the CheckIt Utilities software to identify possible controller hardware problems.

You can also run the external TLA mainframe diagnostics to identify problems not covered by other diagnostics. The TLA mainframe diagnostics are located under the Start menu under the Tektronix Logic Analyzer programs.

Repacking for Shipment

If a mainframe or module is to be shipped to a Tektronix service center for repair, attach a tag to the mainframe or module showing the owner's name and address, the serial number, and a description of the problem(s) encountered and/or service required. Always include the module and the probes so that the entire unit can be tested.

When packing an instrument for shipment, use the original packaging. If it is unavailable or not fit for use, contact your Tektronix representative to obtain new packaging.

Index

A

- Accessories, connecting, TLA700 series, 13
- Address, Tektronix, xii
- Application
 - PatGenVu, 23
 - TLAVu, 23
- Autoconfiguration, module, 7

B

- BIOS
 - configuring, 42
 - Controller BIOS setup, TLA714 and TLA720, 43
 - flashing, 42

C

- Calibration, service, 65
- Chassis ground location, 6
- Checking the shipping list, 1
- Cleaning, 66
 - LCD display, 66
- Configuring, P6470 pattern generator probes, 16
- Connecting
 - accessories, TLA700 series, 13
 - LA probes, TLA700 series, 15
- Connectors, external, TLA700 series, 39
- Contacting Tektronix, xii
- Controller BIOS, setup table, TLA714 and TLA720, 43
- Cover plate installation, 12
- Customer registration card, 1

D

- Diagnostics, 67
 - mainframe, 68
- documentation, xi
- Dynamic autoconfiguration, 7

E

- Expansion cables, installing, 5
- Expansion module, installing
 - in a benchtop mainframe, 2
 - in a portable mainframe, 3
- Extended diagnostics, 67
- External, signal connectors, TLA700 series, 39
- External connectors, 40

F

- Firmware, Upgrading, 53
- Front panel controls, TLA715 Portable Mainframe, 39
- Fuse, requirements, TLA700 series, 17
- Fuse requirements
 - benchtop mainframe, 63
 - expansion mainframe, 63

G

- General maintenance, 65
- Ground
 - chassis, 6
 - safety, 6
- Guidelines, for merging modules, 25

H

- Hard disk
 - drive, removal, 21
 - image, installing, 46
 - reformatting, 48
- Hardware problems, 68

I

- Incoming inspection
 - checking probes, 20
 - checking the mainframe, 21
 - performing, 19
- Installing
 - expansion cables, 5
 - expansion mainframe, 2
 - expansion module
 - in a benchtop mainframe, 2
 - in a portable mainframe, 3
 - software, 48

- PatGenVu, 52
- PPI software, 51
- TLA application software, 50
- TLAVu software, 52
- TPI software, 51

L

LA module. *See* Logic analyzer

Logic analyzer

- chassis ground connections, 6
- description, x
- installing software, 41
- merge cable location, 32
- merging, 25
- merging rules, 25
- probes, connecting LA probes TLA700 series, 15
- reinstalling software, 41
- shipping list, 1
- site considerations, 1
- TLA700 Series description, ix

Logical address

- module, 7
- setting, 7

M

Mainframe

- configuring P6470 pattern generator probes, 16
- connecting accessories, TLA700 series, 13
- connecting LA probes, TLA700 series, 15
- diagnostics, 68
- equipment required to merge modules, 32
- fuse location, TLA700 series, 17
- fuse requirements
 - for the benchtop mainframe, 61
 - for the expansion mainframe, 61
 - TLA700 series, 17
- incoming inspection, 19
- merging modules rules, 25
- module installation
 - in the benchtop mainframe, 9
 - in the expansion mainframe, 11
 - in the portable mainframe, 9
 - keying, 11
- panel cover, 12
- power cord requirements
 - for the benchtop mainframe, 61
 - for the expansion mainframe, 61

Maintenance

- BIOS configuration, TLA700, 42
- equipment required to merge modules, 32
- installing software, 41

- merging modules rules, 25

Merged modules, rules, 25

Merging modules, 25

- equipment required, 32
- merge cable location, 32
- three-way merge procedure, 37
- two-way merge procedure, 32

Module

- dynamic autoconfiguration of address, 7
- installing
 - in the benchtop mainframe, 9
 - in the expansion mainframe, 11
 - in the portable mainframe, 9
- keying, 11
- logical address, 7
- merge cable location, 32
- merging, 25
- merging guidelines, 25
- power requirements, 61
 - expansion mainframe, 61
- static logical address, 7
- three-way merge procedure, 37
- two-way merge procedure, 32

O

On/Standby switch

- benchtop mainframe, 18
- portable mainframe, 18

Online help

- PPI help, 23
- TLAScript, 23
- TPI online help, 23

P

Panel cover installation, 12

Pattern Generator module

- merging, 25
- merging rules, 26
- probes, configuring P6470, 16

PC card connector, TLA700 series, 39

Phone number, Tektronix, xii

Power cord, identification chart, 63

Power requirements

- benchtop mainframe, 61
- expansion mainframe, 61

Power-on diagnostics, 67

Power-on procedure

- benchtop mainframe, 18
- portable mainframe, 18
- TLA714, 18

- TLA720, 18
- Preventive maintenance, 66
 - cleaning, 66
 - disks, floppy disk drive, 67
 - LCD display, 66
- Probes
 - configuring P6470 pattern generator probes, 16
 - connecting LA probes, TLA700 series, 15
- Problems
 - hardware, 68
 - software, 68
- Product support, contact information, xii

R

- Registration card, 1
- Reinstalling software, 48
 - PatGenVu, 52
 - Pattern Generator application software, 50
 - PPI software, 51
 - TLA application software, 50
 - TLAVu software, 52
 - TPI software, 51
- Removing the hard disk drive, 21
- Repacking for shipment, 68
- Repair service, 65
- Requirements, site consideration, 1
- Rules, for merging modules, 25

S

- Service, mainframe diagnostics, 68
- Service offerings, 65
 - calibration and repair service, 65
 - warranty repair service, 65
- Service support, contact information, xii
- Service, user, preventive maintenance, 66
- Setting the logical address, 7
- Shipping, 68
- Shipping list, checking, 1
- Slot
 - covers, 12
 - fillers, 12
- Software
 - BIOS configuration, TLA700, 42
 - installing, 41

- PatGenVu, 52
- Pattern Generator application software, 50
- PPI software, 51
- TLA application software, 50
- TLAVU software, 52
- TPI software, 51
- mainframe diagnostics, 68
- problems, 68
- Static logical address, 7

T

- Technical support, contact information, xii
- Tektronix, contacting, xii
- Three-way merge procedure, 37
- TLA700, BIOS configuration, 42
- TLA700 Series, logic analyzer description, ix
- TLA7XM Expansion Mainframe
 - installing, 2
 - installing the expansion cables, 5
 - installing the expansion module, in a benchtop mainframe, 2
- Trigger, system, external signal, 39
- Troubleshooting, 67
- Two-way merge procedure, 32

U

- Upgrading firmware, 53
- URL, Tektronix, xii
- User service
 - general maintenance, 65
 - preventive maintenance, 66

V

- Video output
 - in a TLA715/721, 14
 - in a TLA714/720, 14
 - primary and secondary, 14

W

- Warranty repair service, 65
- Web site address, Tektronix, xii

