

## Fonts printing incorrectly from Windows

If fonts are printing incorrectly from Windows, make sure you installed the correct Tektronix driver for Windows 3.1 depending on the version of the printer you have.

If you have the optional Plus configuration of the printer, you must install the *Tek Phaser 340 (TekColor) 600* for Windows to recognize and use all of the printer's fonts.

If you select *Tek Phaser 340 (TekColor) 600* and you have only the standard version of the printer with 17 fonts, any of the additional fonts selected within an application are printed in the Courier typeface.

1. Print a copy of the printer's startup page to determine which version of the printer you have. The standard configuration has 17 fonts and 8 Mbytes of memory; the Plus configuration has 69 fonts and 24 Mbytes of memory. Refer to the *Phaser 340 Color Printer User Manual* for instructions on printing a startup page.
2. Open the **Printers** dialog box by double-clicking the **Printers** icon in the **Control Panel**.
3. In the list of **Installed Printers**, look for your printer:
  - If you have the standard version of the printer, you should have installed **Tek Phaser 340 (TekColor)**.
  - If you have the optional Plus configuration of the printer, you should have installed **Tek Phaser 340 (TekColor) 600**.
4. If your printer doesn't appear in the list, follow the driver installation procedure.

If your printer does appear in the list, select it and follow the driver configuration instructions.