

Network problems

Symptom	Solution
The printer doesn't appear in the Chooser .	<ul style="list-style-type: none">■ Always make network connections before turning on the printer. Turn the printer off, wait at least 15 seconds and turn the printer's power on again.■ Check the termination; refer to the documentation for your network adapter or connector for information on termination.■ Check the configuration page to get the zone name and printer name. Make sure that the correct zone and printer name have been selected in the Chooser.■ If you have changed the printer's name, did you make it a unique name (not the same as any other printer in the zone)?■ Make sure that the correct network is selected in the Network Control Panel.
