General **Specifications**

Model PR300 Power and Energy Meter



GS 77C01E01-01E





Overview

This panel-mounted power and energy meter with a large, three-row LED display integrates all the measuring functions required for power management in locations such as factories and buildings into a single

With the objective of working toward the preservation of the global environment by saving energy and performing equipment maintenance, the PR300 is designed to display and output the energy of various types of electrical equipment.

Features

- · Saves on cost, wiring, and space Integrates a wide selection of functions for measuring things like energy (active, regenerative, reactive, and apparent), power (active, regenerative, reactive, and apparent), voltage, current, frequency, and power factor into a single
- Employs a large, three-row LED display Capable of displaying three-phase current and voltage simultaneously, and the measurement items you assign.
- Analog output function Equipped with a transducer function for power (active, regenerative, reactive, and apparent), voltage, current, frequency, and power factor (4 to 20 mA DC).
- Demand measurement Measures the average power and current within a specified period. It also allows you to set up alarm points to output alarms.
- Equipped with a multitude of functions Enables measurement of the maximum and minimum values of voltage and the maximum value of current, as well as, for example, the use of external digital input to measure energy at arbitrary times.
- Pulse output Capable of outputting pulses proportional to energy (one measurement item from active, regenerative, reactive, and apparent energy).
- Converts the phase and wire system of an AC power system and an input voltage circuit to a universal format

The PR300 can handle from the single-phase two-wire system and single-phase three-wire system to the threephase three-wire system and three-phase four-wire system, and also universally cope with input voltage circuits up to 600 V AC

· Compatible with ANSI 4-inch round form size and DIN 96-square instrument size The ability to attach and detach JIS/ANSI-mounting kit

makes the PR300 compatible with panel cutouts of ANSI 4inch round form, JIS 110-square instrument size, and DIN 96-square instrument size.

- Standard equipped with an RS-485 communication function and capable of Ethernet communication
- · Compatible with overseas requirements Power line indications A, B, and C provided for overseas use, in addition to R, S, and T

ANSI 4-inch round form size



The ability to attach and detach JIS/ANSI-mounting kit ensures compatibility with two sizes.

Model and Suffix Codes

Model

Phase and wire system

- 3: Universal three-phase three-wire system (single-phase two-wire, single-phase three-wire, and three-phase three-wire systems)
- 4: Universal three-phase four-wire system (single-phase two-wire, single-phase three-wire, three-phase three-wire, and three-phase four-wire systems)
- 5: Three-phase four-wire system (2.5 element)*1

Input voltage/input current

- 1: Universal voltage input*2 (150 V, 300V, 600 V) / 1 A AC
- 2: Universal voltage input*2 (150 V, 300 V, 600 V) / 5 A AC

Additional input and output function

- 0: 1 digital input
- 1: 1 digital input, 1 analog output
- 2: 1 digital input, 1 pulse output
 3: 1 digital input, 1 analog output, 1 pulse output

Communication function

- 0: RS-485 communication
- 3: RS-485 communication, Ethernet communication*3

Optional measuring function

- 3: Demand measurement (1 demand alarm output)

Power supply

6: 100-240 V AC ±10% (50/60 Hz) or 130-300 V DC ±15%

Phase indication format

A: A, B, and C indications

R: R, S, and T indications

- Can be used only when the voltage is in a state of equilibrium. The phase and wire system cannot be changed. Set the voltage range (150 V, 300 V, or 600 V) according to the
- rated input voltage to be measured. (Refer to "Rated Input Voltage" of the Input Specifications on page 6.)
 *3 For Ethernet communication, the RS-485 communication interface
- is exclusively for the Ethernet-serial gateway function.

■ Ordering Information

Specify the model and suffix codes. Example: PR300-31000-6A-0



■ Measuring Functions

Measurement item		Single-phase two-wire system	Single-phase three-wire system	Three-phase three-wire system	Three-phase four-wire system	Three-phase four-wire system (2.5 element) *3	Unit and symbol	Remarks								
Active energy (+) *1	~	~	~	~	~	kWh, MWh									
Active energy (-) *1	~	~	~	V	~	-kWh, -MWh	Regenerative energy								
Reactive energy	(+) *1	~	~	~	~	*4	kvarh, Mvarh	LAG: +								
Reactive energy	(-) *1	~	~	~	V	*4	-kvarh, -Mvarh	LEAD: -								
Apparent energy		V	V	~	V	*4	kVAh, MVAh									
Optional active e		V	V	~	V	~	Wh									
	Instantaneous															
Active power	Maximum	~	~	~	~	V	W, kW, MW									
	Minimum															
	Instantaneous															
Reactive power	Maximum	~	~	·	~	*4	var, kvar, Mvar									
·	Minimum						, ,									
	Instantaneous															
Apparent power	Maximum	~	~	~	_	*4	VA, kVA, MVA									
11	Minimum						, ,									
	Instantaneous															
Voltage-1	Maximum	~	~	~	_	· /	V, kV									
	Minimum		-				.,									
	Instantaneous															
Voltage-2	Maximum	_	~	_	·	_	V, kV									
	Minimum						*,									
	Instantaneous															
Voltage-3	Maximum	-	_	_	_	_	_	_	~	_	v	V, kV				
vollago o	Minimum						۷,۱۲۷									
	Instantaneous		_	_		_										
Current-1	Maximum	~	~	~	~	*4	A, kA									
0	Instantaneous															
Current-2	Maximum	_	~	_	~	_	A, kA									
0 10	Instantaneous											_		*4	A 1 A	
Current-3	Maximum	_	_	~	~	*4	A, kA									
	Instantaneous							0.1.11.11								
Frequency	Maximum	~	_	~	·	· /	Hz	Calculated from the								
. 1	Minimum							voltage-1								
	Instantaneous															
Power factor	Maximum	~	~	·	~	*4	COSo	LAG: +								
	Minimum	-			-			LEAD: -								
Demand current-1 Demand current-2 Demand current-3	Demand	~	~	~	~	*4	A, kA									
	Maximum	~	~	~	~	*4	A, kA									
Ĭ	Demand	_	~	_	~	_	A, kA									
ত Demand current-2	Maximum	_	~	_	~	_	A, kA									
nau	Demand	_	_	~	~	*4	A, kA									
Demand current-3	Maximum	_	_	~	~	*4	A, kA									
<u> *2</u>	Demand	~	~	~	~	~	W, kW, MW									

^{*1} Integrated low-cut power can be set for each energy. Integrated low-cut power: This is a function for not integrating power less than a set value as energy. The setting range of integrated low-cut power is 0.05 to 20.00% of the rated power (initial value: 0.05%).

✓: Effective–: Ineffective

^{*2} Either demand power or demand current can be set as a measurement item.

^{*3} Can be used only when the voltage is in a state of equilibrium.

^{*4} Can be measured only when the current is in a state of equilibrium.

Optional integrating function

Power is integrated while a control signal for optional integration is on.

When the control signal is switched from off to on, the optional integrated value indication is reset and integration starts. (The integrated value prior to the reset is held in a register.) The integrated value cannot be guaranteed in the event of a power failure occurring during integration.


Demand measurement (when demand measurement is specified)

The PR300 measures average power or average current within a set demand period.


The maximum demand value for the demand measuring time is held until the power is turned off, remote reset is executed, or the next demand measurement is started.

Item	Setting Range	Resolution	Initial Value	Remarks
Demand power/current	Active power, current	_	Active power	
Demand period	1 to 60 minutes (Demand alarm mask time to 60 minutes)	1 minute	30 minutes	Demand alarm mask time ≦ Demand period
Demand alarm mask time*	1 minute to length of demand period	1 minute	1 minute	
Demand power alarm point	1 to 1000 kW	1 kW	100 kW	When demand power is selected
Demand current alarm point	1 to 1000 A	1 A	100 A	When demand current is selected
Alarm release function	Automatic release and manual release	_	Automatic release	
Data update interval	10 seconds	_	_	

^{*} This is the time from the start of the demand period to the set time in which no judgment is made for the alarm (alarm masked). During the alarm mask time, no maximum demand value is updated and no alarm is output.



■ Display and Operation Specifications



(1) Measured Value Display 5-digit, 3-row, 7-segment LED display

Display color: red

Measured Value display:

Measurement Item	Display	
Active energy	□□□□ [kWh, MWh]	*1
Reactive energy	± □□□□□ [kvarh, Mvarh]	*2
Apparent energy	□□□□ [kVAh, MVAh]	*1
Regenerative energy	– □□□□□ [kWh, MWh]	*2
Optional active energy	□□□□ [Wh]	
Active/regenerative power (instantaneous, maximum, and minimum values)	□□□□ [W, kW, MW]	*2, *3
Reactive power (instantaneous, maximum, and minimum values)	□□□□ [var, kvar, Mvar]	*2, *3
Apparent power (instantaneous, maximum, and minimum values)	□□□□ [VA, kVA, MVA]	*1, *3
Voltage (instantaneous, maximum, and minimum values)	□□□□ [V, kV]	*1, *3
Current (instantaneous and maximum values)	□□□□ [A, kA]	*2, *4
Power factor (instantaneous, maximum, and minimum values)	LEAD: d □.□□□ [COS♠] LAG: G□.□□□ [COS♠]	*3
Frequency (instantaneous, maximum, and minimum values)		*3
Demand power	UUUU [W, kW, MW] [DEM	V NID1 *4
Maximum demand power		AND] 4
Demand current	[A, kA] [DEMAND]	*4
Maximum demand current		4

^{*1:} Without sign, but with a decimal point

Measured Value screen:

Display pattern: The measurement items you want to display are assigned to each of the upper, middle, and lower displays to provide indications using three display rows as one pattern. Up to eight display patterns can be set. The initial values are as shown in the following table. (Combinations other than those shown in the following table are also available if the parameters are set.)

Number of display patterns: Can be set in the range of 1 to 8. Pressing the SET/ENT key switches the display from "display pattern-1," "display pattern-2," and so on in order according to the number of patterns set. The initial value is "1" and only display pattern-1 is displayed when this value is set.

	Display Pattern-1	Display Pattern-2	Display Pattern-3	Display Pattern-4	Display Pattern-5	Display Pattern-6	Display Pattern-7	Display Pattern-8
Upper display	Current (Phase switch indication)*	Active power	Active energy	Current-1	Voltage-1	Current (Phase switch indication)*	Current (Phase switch indication)*	Active power
Middle display	Voltage (Phase switch indication)*	Reactive power	LEAD reactive energy	Current-2	Voltage-2	Voltage (Phase switch indication)*	Active power	Maximum demand value
Lower	Active power	Power factor	Apparent energy	Current-3	Voltage-3	Frequency	Power factor	Demand value

<Continued on the following page>

^{*2:} With a sign and a decimal point ("+" is not indicated). Regenerative power (energy) always shows "-" negative indication. The position of a decimal point differs depending on the primary rated power, VT ratio, and CT ratio.

^{*3: &}quot;MAX" lights up for the maximum value and "MIN" lights up for the minimum value.

^{*4: &}quot;MAX" lights up for the maximum value.

The display of current (phase switch indication) is switched between current-1, current-2, and current-3 each time the SEL key is pressed. The display of voltage (phase switch indication) is switched between voltage-1, voltage-2, and voltage-3 each time the SEL key is pressed.

		VT votic/CT votice							
		VT ratio/CT ratio: If the VT ratio and CT ratio are set, input to the PR300 is displayed after converting it to the primary input value before VT							
		or CT. The VT and CT ratios can be set via communication or using the operation keys.							
		VT ratio setting range: 1 to 6000*							
		CT ratio setting range: 0.05 to 32000*							
		* Set the VT ratio and CT ratio so that [secondary rated power] × [VT ratio] × [CT ratio] is smaller than 10 GW.							
(2)	Unit Lamps	The relevant unit lamp lights up acco							
(2)	Onit Lamps	Display color: red	ording to a rin		om ana mease	rea value.			
(3)	MAX and MIN Lamps	Either the MAX or MIN lamp lights up	n when a ma	vimum or mini	mum measure	d value is dis	nlaved		
(5)	W/ OX and Will Lamps	Display color: red	o whom a ma.	KIIII OI IIIIII	mam measure	a value is als	piayeu.		
(4)	Phase Indication Lamps	Indicate the phase to which the mea	sured value o	corrosponds	(The A. B. and	Cindications	or D. C. and	Γ indications	
(+)	i nase malcation Lamps	should be specified in accordance w			(THE A, D, and	Ciridications	or it, o, and	indications	
		Display color: red	itil tile sullix	code.)					
				17.11				0 10	
		Phase and Wire System	Voltage-1	Voltage-2	Voltage-3	Current-1	Current-2	Current-3	
		Single-phase two-wire system	A (R)	- D O (O T)	_	A (R)	- O (T)	_	
			A, B (R, S) A, B (R, S)	B, C (S, T)	B, C (S, T)	A (R) A (R)	C (T)	- C (T)	
		Three-phase three-wire system Three-phase four-wire system	A, B (R, S) A (R)	B (S)	C (T)	A (R)	B (S)	C (T) C (T)	
		Three-phase four-wire system		Б (3)			Б (3)		
		(2.5 element)	A(R)	_	C (T)	A (R)*	-	C (T)*	
		* Can be measured only when the	ho current is	in a state of o	auilibrium				
		-	ne current is	in a state of e	quiibiiuiii.				
(5)	Power Lamp	Lights up when power is supplied.							
		Blinks (4 times/sec) until it returns to	normal wher	n the commun	ication error o	ccurs.			
		Display color: green							
(6)	Communication Lamp	Blinks during communication (RS-48	Blinks during communication (RS-485 or Ethernet).						
		Display color: green							
(7)	Pulse Output Lamp	Lights up when output is produced d	uring pulse o	utput, and goe	es out when no	output is pro	duced.		
		Display color: green							
(8)	Demand Alarm Lamp	If a demand value exceeds the demand alarm point at a time other than during the alarm mask time, the OVER lamp					OVER lamp		
` ′	'	lights up to indicate the occurrence of an alarm.							
		Display color: red							
(9)	Phase and Wire	The lamps of the phase and wire sys	stem that hav	e been set lig	ht up.				
(-)	System Lamps	Display color: green		g					
(10)	Input Range Lamps	The input voltage range (150 V, 300	V or 600 V)	and input curr	ent range (1 A	or 5 A) that h	ave been set l	ight up	
(,		Display color: green	,		g- (31.	
(11)	DEMAND Lamp	Lights up when a demand value is di	isplayed						
(,	5 2 m m t 5 2 amp	Display color: red	.op.ayou.						
(12)	Operation Keys	Llood to awitah magazirad va	alue display n	atterns					
(12)	Operation Reys	This key is also used for set							
		Used to move the display di	0.						
		This key is also used for set			1.				
		This key is also used for set	ung paramet	C15.					
		Used to display the maximu	m or minimur	m measured v	alue.				
		These keys are also used for	or setting para	ameters.					
		Used to switch phase indica						indication can be	
		changed. (Phase switch inc			single-phase t	wo-wire syste	m.)		
		This key is also used for set	ting paramet	ers.					
		☐ Used to start/stop demand r	neasurement	i.					
		The lamp in the key lights up	p during dem	and measurer	ment. Display	color: green			
Indica	ator-out Mode Setting	This function turns off LEDs after a					ımp (LED)		
		The ON/OFF setting of the indicator				•	,	t mode can	
		•				no omening u	io iridioator-ou	. mode dan	
		be set using the operation keys. (Cannot be set via communication.)							
Indicator-out mode: ON/OFF (initial value: OFF)					minuto) (initial	value: 10 min	utos)		
A /D C	Compling Data	Indicator-out mode wait time: 1 to	oo minutes (16201011011. T I	imiute) (iriitial	value. 10 IIIIN	uies)		
	Sampling Rate, Update Interval	A/D sampling rate: 4.8 kHz	,						
Dala	Opuate IIItel Val	Internal measurement data: display/	communicati	on data is upo	lated at an inte	erval of 1 seco	ond or less		

■ Input Specifications

Phase and Wire				three-wire system		the settin	g fro	om single-ph	ase two-w	ire system, single	e-phase t	hree-wir
System	S	ystem, or thi	ree-phase	three-wire system	m)							
				four-wire system					ase two-w	re system, single	-phase tl	hree-wi
				ree-wire system,		-phase fo	ur-w	vire system)				
	• TI	hree-phase	four-wire	system (2.5 elem	ient)							
Frequency	45	to 65 Hz										
Rated Input Voltage		Rated Vol	tage Vo	oltage Range (Var	iable)	The r	rima	ary voltage o	of V/T	Allowable In	nut Volta	nde
		120 V		150 V	iabio)	1110		900 kV	,, , ,	150		igo
		240 V		300 V			1	1800 kV		300) V	
		480 V		600 V			3	3600 kV		600	V	
Rated Input Current	\vdash											
tated input ourient		Rated Cui	rrent (Current Range (Fi	ixed)	The prima	ary c	urrent of CT		owable Input Cur		
		1 A		1 A			32 k	κA		the current range		
		5 A		5 A			160	kA		current range (1 the current range		
									10 tillies	ine current range	(3 3600)	103)
Rated Input Power		• Single-ph	ase two-v	vire system				• Single-ph	ase three	-wire system		
and Measuring Range		Input (AC)		Input		oximate		Input (AC)		Input	Approx	
When VT and CT are	l ' ' '		Rated	 Measuring 	Consu	med VA		put (/ 10/	Rated	Measuring	Consur	nea va
used, their respective secondary values)			Power	Range	Voltage	Current			Power	Range	Voltage	Curre
		120 V / 1 A	100 W	-120 to 120 W	0.2.1/4			240 V / 1 A	200 W	-240 to 240 W	0.2 VA/	0.2 VA
		120 V / 5 A	500 W	-600 to 600 W	0.2 VA			240 V / 5 A	1000 W	-1200 to 1200 W	phase	phase
		240 V / 1 A	200 W	-240 to 240 W	0.4 VA	0.2 VA						
		240 V / 5 A	1000 W	-1200 to 1200 W		- 0.2 171						
		480 V / 1 A	400 W	-480 to 480 W	0.8 VA							
		480 V / 5 A	2000 W	-2400 to 2400 W								
		• Three-pha	ase three	-wire system			,	Three-ph	nase four-	wire system		
		Input (AC)		Input Measuring	Appro Consu	oximate med VA		Input (AC)		Input Measuring	Approx Consur	ximate ned VA
			Rated Power	Range	Voltage	Current			Rated Power	Range	Voltage	Curre
		120 V / 1 A	200 W	-240 to 240 W	0.2 VA		1	120 V / 1 A	300 W	-360 to 360 W	0.2 VA/	
		120 V / 5 A	1000 W	-1200 to 1200 W	phase			120 V / 5 A		-1800 to 1800 W	phase	
		240 V / 1 A	400 W	-480 to 480 W	0.4 VA			240 V / 1 A	600 W	-720 to 720 W	0.4 VA/	0,2 V
		240 V / 5 A	2000 W	-2400 to 2400 W	phase	phase		240 V / 5 A	3000 W	-3600 to 3600 W	phase	phase
		480 V / 1 A	800 W	-960 to 960 W	0.8 VA	'		480 V / 1 A	1200 W	-1440 to 1440 W	0.8 VA/	
		480 V / 5 A	4000 W	-4800 to 4800 W	phase			480 V / 5 A	6000 W	-7200 to 7200 W	phase	
		The prim value calc	ary input ulated by	ange when VT an power (Secondar the following equ	y rated pation is	oower × ′	inpu	ut measuring) GW and	d the
		Inp	out measi	uring range (W) =		ratio × C						
					v I	iauo a C	ı ıdl	li U				

■ Digital Input Specifications

For digital input, either the optional integration start/stop or the demand alarm release can be used. If demand measurement is specified for an optional measuring function, digital input enters demand alarm release status. In this case, the optional integration start/stop cannot be used.

Control signal for optional integration

Function	Starts or stops optional integration.
Number of Inputs	1
Input Signal	Voltage signal* ON signal: 4.5 to 25 V DC OFF signal: within ±1 V DC
Minimum ON time	50 ms

^{*} A special order can be placed for no-voltage contact.

Note: Optional integration control is also possible via communication.

Once control is performed by digital input, only digital input-based control is available. Communication-based control is no longer possible until the power is turned off/on or remote reset is executed.

Demand alarm release (when demand measurement is specified)

Function	Cancels demand alarm.
Number of Inputs	1
Input Signal	Voltage signal* ON signal:4.5 to 25 V DC OFF signal: within ±1 V DC
Minimum ON time	50 ms

^{*} A special order can be placed for no-voltage contact.

■ Analog Output Specifications (When Analog Output is Specified)

Function	Converts measurement data into DC current for output.					
Measurement Item for Output	One item selecte	One item selected from active power, reactive power, apparent power, voltage (1 to 3), current (1 to 3),				
	power factor, and	ower factor, and frequency				
Output Signal	4 to 20 mA DC					
Output Accuracy	Measurement ac	curacy of measurement item for output + (±0.5% of F.S.)				
Allowable Load Resistance	0 to 600 Ω					
Response speed	2 seconds or less	s (until ±1% of the final value is reached)				
Setting Item	Measurement ite	Measurement item for output and the lower and upper limits of scaling.				
	Initial value: act	Initial value: active power (W), lower limit of scaling: 50% (0 W), upper limit of scaling: 100% (maximum value of				
	the	the input measuring range W)				
	Scaling setting	condition: upper limit of scaling - lower limit of scaling ≥ 50%				
Setting Range of	Active power	-rated power (W) to rated power (W)				
Lower/Upper Limits	Reactive power	-rated power (var) to rated power (var)				
of Scaling According to	Apparent power	0 to rated power (VA)				
Measurement Item	Voltage (1 to 3) 0 to rated voltage (V)					
for Output	Current (1 to 3) 0 to rated current (A)					
	Power factor	(LEAD)0.5 to 1 to (LAG)0.5				
	Frequency	45 to 65 (Hz)				

■ Pulse Output Specifications (When Pulse Output is Specified)

Function	Outputs pulses proportional to energy.					
Measurement Item for Output	One item selected from active energy, regenerative energy, reactive energy (LEAD, LAG), and apparent energy					
Number of Outputs	1					
Output Signal	Open collector					
Contact Capacity	30 V DC at 200 mA					
Pulse Unit	0.1 to 5000.0 kWh/pulse* (set in 100 Wh increments)					
Setting Item	Measurement item for output, pulse unit, and ON pulse width					
	Initial value: active energy (kWh), pulse unit: 1 kWh/pulse, and ON pulse width: 50 ms					
ON Pulse Width	Represents the ON time of pulses to be output. (Set the pulse width so that the maximum ON pulse width obtained					
	by the following equation is not exceeded.)					
	Within the range of 10 to 1270 ms (set in 10 ms increments)					
	Pulse unit [kWh/pulse]* × 3600 × 1000 ²					
	Maximum ON pulse width (ms) = $\frac{1}{\text{Secondary rated power [W]} \times \text{VT ratio} \times \text{CT ratio} \times 1.2 \times 2}$					

^{*} The units are kvarh/pulse for reactive energy and kVAh/pulse for apparent energy.


■ Demand Alarm Output Specifications (When Demand Measurement is Specified)

Function	Outputs an alarm if the measured demand value exceeds the set demand alarm point.
Output Signal	Open collector
Contact Capacity	30 V DC at 200 mA
Alarm Release Function	Automatic release: Cancels the alarm if demand falls below the demand alarm point when the next measurement is
	performed.
	Manual release*: Holds the status of an alarm that occurred once. Cancels the alarm by digital input or the operation
	key, or via communication.

 $^{^{\}star}$ Refer to "Demand alarm release" of the Digital Input Specifications.

■ Communication Specifications


RS-485 communication



Function	RS-485 comm	RS-485 communication enables you to use the command/response method to read a variety of measurements and				
	write various s	ite various settings.				
Protocol	PC link (with c	hecksum, without checksum), Modbus (RTU, ASCII), PR201 original (Note 1)				
Transmission Distance	Approx. 1200 i	m maximum (when 24 AWG twisted-pair cable is used)				
Connection Method	Multi-drop con	nection (a maximum of 32 units [including a higher-level device])				
Station Number	01 to 99 (maximum number of units to be connected: 31 [number of units that can be connected to a PC etc.])					
	(Setting range: 01 to 31 is recommended)					
Transmission Method	Half-duplex co	Half-duplex communication				
Synchronization Method	Start-stop synd	chronization				
Baud Rate	19200, 9600, a	and 2400 bps				
Xon/Xoff Control	None					
Data Format	Data length	Data length 8 bits, 7 bits				
	Parity	None, even, odd				
	Stop bit 1 bit, 2 bits					

For details, refer to the user's manual for communications of each device to be connected. (Note 1) The settings cannot be written.

Example of Connection Diagram




Notes:


The PR300 employs a two-wire system for RS-485 communication.

SG: The SG terminal is connected to match the signal level of the RS-485 communication line.

FG: All shielded wires must be connected and then grounded at one place to provide noise protection for RS-485 communication lines.

• Ethernet communication (when the Ethernet communication function is specified)





For details, refer to the user's manual for communications of each device to be connected.

Note: If Ethernet communication is used, the RS-485 communication interface is used specifically for the Ethernet-serial gateway function.

Therefore, it is not possible for a higher-level device such as a PC to access the PR300 via the RS-485 communication interface.

■ Standard Performance

A D ::	A C () () () () () () () ()	0.50/ /5100007	
Accuracy Rating	Active energy/optional active energy (Wh)	±0.5% (EN60687 accuracy: class 0.5 or equivalent)	
	Active power (W)	±0.5% of F.S.	
	Voltage (V)	±0.25% of F.S. (voltage rms)	
	Current (A)	±0.25% of F.S. (current rms)	
	Frequency (Hz)	±0.5 Hz	
	Demand	±0.5%	
Calculation Accuracy	Calculation Accuracy The value is calculated to an accuracy of ±1 digit from the measured value for reactive energy, and the control of the value is calculated to an accuracy of ±1 digit from the measured value for reactive energy, and the value is calculated to an accuracy of ±1 digit from the measured value for reactive energy, and the value is calculated to an accuracy of ±1 digit from the measured value for reactive energy, and the value is calculated to an accuracy of ±1 digit from the measured value for reactive energy, and the value is calculated to an accuracy of ±1 digit from the measured value for reactive energy, and the value is calculated to an accuracy of ±1 digit from the measured value for reactive energy, and the value is calculated to an accuracy of ±1 digit from the measured value for reactive energy, and the value is calculated to an accuracy of ±1 digit from the measured value for the value is calculated to an accuracy of ±1 digit from the measured value for the value is calculated to an accuracy of ±1 digit from the measured value for the value is calculated to an accuracy of ±1 digit from the measured value for the value is calculated to an accuracy of ±1 digit from the measured value for the value is calculated to an accuracy of ±1 digit from the measured value for the value is calculated to an accuracy of ±1 digit from the measured value for the value is calculated to an accuracy of ±1 digit from the value is calculated to an accuracy of ±1 digit from the value is calculated to accuracy of ±1 digit from the value is calculated to accuracy of ±1 digit from the measured value is calculated to accuracy of ±1 digit from the value is calculated to accuracy of ±1 digit from the value is calculated to accuracy of ±1 digit from the value is calculated to accuracy of ±1 digit from the value is calculated to accuracy of ±1 digit from the value is calculated to accuracy of ±1 digit from the value is calculated to accuracy of ±1 digit from the value is calculated to accuracy of ±1 digit from the v		
	reactive power, apparent power, power factor or current*.		
	* Current is only for the 2.5 element measurement.		
Backup upon Power Failure	The last integrated values obtained immediately before the power failure are held for active energy,		
	regenerative energy, reactive energy, and apparent energy.		
Insulation Resistance	Between each of the voltage input, current input, power,	100 MΩ or more (at 500 V DC)	
	ground, digital input, pulse output, analog output, RS485		
	communication output, Ethernet communication output, and		
	alarm output terminals		
Withstand Voltage	Between each of the voltage input, current input, power, and	2500 V AC for 1 minute	
Ü	ground terminals:		
	Between (the voltage input, current input, power and ground	2500 V AC for 1 minute	
	terminals) and the digital input, pulse output, analog output,		
	alarm output, RS-485 communication output, and Ethernet		
	communication output terminals:		
	Between each of the digital input, pulse output, analog output,	1000 V AC for 1 minute	
	alarm output, and (RS-485 communication output, Ethernet		
	communication output) terminals:		
	Between the RS-485 communication output, and Ethernet	500 V AC for 1 minute	
	communication output terminals:	Too vito for i minuto	
Impulse Withstand Voltage	Between all of the voltage input, current input, and power termi	inals and the ground terminal:	
Impulse Willistana Veltage	Between all of the output and ground terminals and all of the voltage input and current input terminals:		
	6 kV (1.2/50μs), 10 times for positive and negative		
Effects of Magnetic Field	400 A/m or less Active power: ±0.5% of F.S. Voltage/Current:	ů	
Effects of Changes in Ambient	±0.03%/°C for a temperature change rate of 10°C/h or less (when 0.05 ln ≤ l ≤ l max, power factor = 1)		
_	acts of Changes in Ambient $\pm 0.03\%$ /°C for a temperature change rate of 10°C/h or less (when 0.05 in $\leq 1 \leq 1$ max, power factor = 1) $\pm 0.05\%$ /°C for a temperature change rate of 10°C/h or less (when 0.1 in $\leq 1 \leq 1$ max, power factor = LAG 0.5) in: rated current, I: present current input		
remperature			
Effects of Power Supply Voltage			
Variations	Active power: ±0.25%, Voltage/Current: ±0.125%		
Effects of Input Frequency	(for variations within the power supply operating range (when 0.01 In and power factor = 1)) In: rated current Active power: ±0.25%, Voltage/Current: ±0.125% (for variation of 45 to 65 Hz)		
	, , ,		
Power Supply Power Consumption	100-240 V AC ±10% (50/60 Hz) or 130-300 V DC ±15% AC drive: 10 VA maximum, DC drive: 5 W maximum		
Power Consumption	TAC drive: 10 va maximum, DC drive: 5 vv maximum		

■ Safety and EMC Standards

Safety Standards	Compliant with IEC/EN61010-1 and		
	UL61010 Listed		
Measurement category	600V CAT. III		
	Measurement Category	Description	Remarks
	CAT.I	Circuits not directly connected to main power supply	
	CAT.II	Circuits directly connected to low-voltage facility	Home-use equipment, portable tools, etc.
	CAT.III	Circuits in building facilities	Switchboards, circuit breakers, etc.
	CAT.IV	Supply sources to low-voltage facilities	Overhead lines, cable systems, etc.
Installation category	CAT. II		
	Pollution degree: 2 (IEC/EN61010-1)		
Rated measurement input	Voltage input: 600V AC (between terminals)		
	Current input: 600V AC (across ground)		
MC-compliant Standards	Compliant with EN61326		
	During testing, the instrument continues to operate at a measurement accuracy within the range of ±20%.		

■ Environmental Conditions

N	Normal Operating Conditions		
	Warm-up time	At least 30 minutes	
	Ambient temperature	0 to 50°C (reference temperature: 23 ±2°C)	
	Temperature change	10°C/h or less	
	Ambient humidity	20 to 90% RH (no condensation)	
	Magnetic field	400 A/m or less	
	Continuous vibration	10 to 60 Hz, 0.035 mm, 75 minutes	
		60 to 150 Hz, 4.9 m/s ² , 75 minutes	
	Short-time vibration	14.7 m/s ² for 15 seconds or less	
	Shock	98 m/s ² or less (for shock time of 11 ms)	
	Installation	Indoor installation only	
	Mounting position	Vertical surface mounting only	
L	Installation altitude	2000 m or less	
E	Effects on Operating Conditions		
	Effects of ambient temperature	Analog output: ±0.05% of F.S./°C or less	
	Effects on supply voltage variations	Analog output: ±0.05% of F.S./°C or less	
Т	Transport and Storage Conditions		
	Temperature	−20 to 70°C	
	Humidity	5 to 95% RH (no condensation)	
	Shock and dropping of package	90 cm (provided that an external packing box is used)	

■ Power Items and Equations

		(V and A	are rms values)
Phase and Wire Syatem	Apparent Power	Reactive Power (without using reactive power meter method)	Power Factor
Single-phase two-wire system	VA= V×A	$Q = \sqrt{((VA)^2 - P^2)}$	
Single-phase three-wire system	VAi= Vi×Ai i=1, 2 ΣVA= VA1+VA2	$Qi = \sqrt{((VAi)^2 - Pi^2)}$ $i = 1, 2$ $\Sigma Q = Q1 + Q2$	ΣΡ/ΣVΑ
Three-phase three-wire system	$VAi = Vi \times Ai$ $i = 1, 3$ $\Sigma VA = \sqrt{3}/2(VA1 + VA3)$	Qi= $\sqrt{((VAi)^2 - Pi^2)}$ i= 1, 3 ∑Q = Q1+Q3	(without using reactive power meter method)
Three-phase four-wire system	VAi= Vi×Ai i=1, 2, 3 ΣVA= VA1+VA2+VA3	Qi= $\sqrt{((VAi)^2 - Pi^2)}$ i= 1, 2, 3 $\Sigma Q = Q1+Q2+Q3$	
Three-phase four-wire system (2.5 element)	$VAi = Vi \times Ai$ $i = 1, 3$ $\Sigma VA = \sqrt{3}/2(VA1 + VA3)$	Qi= $\sqrt{(\sqrt{3}/2(VAi)^2 - Pi^2)}$ i= 1, 3 $\Sigma Q = Q1 + Q3$	

^{(2.5} element) ∑VA=√3/2(VA1+VA3) ∑Q = Q1+Q3

* For distorted wave input, there may be differences between the PR300 and a measuring instrument that uses a different measurement principle.

■ Initial Settings (Time of Shipment)

The PR300 has the following initial settings at the time of shipment. Settings can be modified after delivery

ucii	ivery.	
	Setting Item	Initial Value
Input	Phase and wire system	Three-phase three-wire system (for three-phase three-wire system)
	Thase and wire system	Three-phase four-wire system (for three-phase four-wire system)
	Voltage range	300 V
	VT ratio	1
	CT ratio	1.00
	Integrated low-cut power	0.05 %
	Station number	01
	Protocol	PC link with checksum
ڃ	Baud rate	9600 bps
Communication	Parity	None
J.	Stop bit	1 bit
ΠL	Data length	8 bits
Ē	IP address *1	192.168.1.1
ပိ	Port number *1	502
	Subnet mask *1	255.255.255.0
	Default gateway *1	0.0.0.0
t *2	Measurement item for pulse output Pulse unit ON pulse width Measurement item for analog output	Active energy (kWh)
la gr	Pulse unit	1 kWh/pulse
₫₫	ON pulse width	50 ms
		Active power (W)
ga	Lower limit of scaling Upper limit of scaling	50% (0 W)
ont Outr	Upper limit of scaling	100% (maximum value of the
40		input measuring range W)
*	Demand power/current	Active power
j j	Demand period	30 minutes
	Demand alarm mask time	1 minute
	Demand period Demand alarm mask time Demand power alarm point Demand current alarm point Alarm release function	100 kW
	Demand current alarm point	100 A
		Automatic release
Other	Indicator-out mode/indicator-out mode wait time	Off/10 minutes

^{*1} When the Ethernet communication function is specified
*2 When pulse output is specified
*3 When analog output is specified
*4 When demand measurement is specified

■ Mounting and Shape

	0	
Materials	Casing: polycarbonate resin (PC), UL94 V-0	
	Terminal block: polybutylene terephthalate (PBT),	
	UI 94 V-0	
	020.10	
	Terminal cover: polyamide resin (PA6), UL94 V-2	
Mounting Method	Panel mounting (refer to Panel Cutout	
	Dimensions)	
Connection Method	M3 screws for terminal connections:	
	analog output, pulse output, demand alarm output,	
	digital input, and RS-485 communication	
	M4 screws for terminal connections:	
	voltage/current input and power supply	
	RJ45 connection: Ethernet communication	
External Dimensions	110(H) × 110(W) × 128(D) mm or	
(including a terminal cover)	96(H) × 96(W) × 126(D) mm	
Weight	Approx. 600 g (when the accessories such as	
	mounting bracket are attached)	

Accessories


JIS/ANSI-mounting kit	1 set
DIN-mounting bracket	2
Dust cover (with a screw)	1
Terminal cover (with screws)	1
Shorting bar (for RS-485 communication termination)	1
Tag number label	2

■ Connection Diagrams


A phase and wire system can be selected by specifying the parameters.

If measurement input does not exceed 600 V AC or 5A AC, direct input without using a VT or CT is possible. Do not ground the input circuit when a VT or CT is not used. Perform wiring for the voltage and current in the same circuit.


Single-phase two-wire system




Single-phase three-wire system




■ Three-phase three-wire system



● Three-phase four-wire system




● Three-phase four-wire system (2.5 element)




■ External Dimensions

• ANSI 4-inch round form size (when a bezel is attached)





<Panel Cutout Dimensions>




Normal Allowable Deviation= ±(Value of JIS B 0401-1999 tolerance grade IT18)/2

● DIN 96-square instrument size





<Panel Cutout Dimensions>



Normal Allowable Deviation= ±(Value of JIS B 0401-1999 tolerance grade IT18)/2