


**TECHNICAL MANUAL
NET CONTROL STATION (NCS)
POCKET GUIDE**

**SINGGARS ICOM GROUND RADIOS
RADIO SETS**

**MANPACK RADIO
(AN/PRC-119A/D/F)(NSN: N/A) (EIC:
N/A)**

**VEHICULAR RADIOS
(AN/VRC-87A/D/F
THRU AN/VRC-92A/D/F)(NSN: N/A)
(EIC: N/A)**



Used with
Automated Net Control Device
(ANCD) AN/CYZ-10
and
Precision Lightweight GPS Receiver
(PLGR) AN/PSN-11

Approved for public release; distribution is unlimited.

Headquarters, Department of the Army

1 December 1998

WARNING*LITHIUM BATTERY WARNINGS*

Your manpack radio uses a lithium battery as the main power source. All SINCGARS radios use a lithium battery for the HUB, and the ANCD uses three 3-volt lithium batteries for power. Lithium batteries contain pressurized toxic, sulfur dioxide gas. Batteries *can* explode; *treat them with CARE!*

For safety's sake, follow these rules when handling lithium batteries:

Do NOT ABUSE LITHIUM BATTERIES IN ANY WAY.

Do NOT HEAT, SHORT CIRCUIT, CRUSH, PUNCTURE, OR CUT THEM.

Do NOT USE ANY LITHIUM BATTERY SHOWING SIGNS OF DAMAGE.

Do NOT TEST THEM FOR STATE OF CHARGE (MAINTAINER TASK ONLY).

Do NOT ATTEMPT TO RECHARGE LITHIUM BATTERIES.

Do NOT PLACE THEM IN ORDINARY TRASH; TURN IN USED BATTERIES TO UNIT SUPPLY, OR WHEN OPERATIONAL FOLLOW UNIT SOP REGARDING DISPOSAL.

Do NOT USE A HALON-TYPE FIRE EXTINGUISHER ON A LITHIUM FIRE. IN CASE OF FIRE, DOUSE WATER, USE CO2 OR CLASS D [GRAPHITE BASED] EXTINGUISHER

Do NOT STORE BATTERIES IN UNUSED EQUIPMENT.

Do NOT STORE LITHIUM BATTERIES WITH OTHER HAZARDOUS MATERIALS.

Do NOT STORE LITHIUM BATTERIES NEAR FLAME OR HEAT.

If battery compartment becomes hot to touch, if it hisses or makes a burping sound, or if you smell an irritating gas:

TURN OFF EQUIPMENT

LET EQUIPMENT COOL FOR AT LEAST AN HOUR.

AFTER EQUIPMENT IS COOL, REMOVE BATTERY/BATTERIES.

INSTALL NEW BATTERY/BATTERIES; RESUME OPERATING.

If you experience a safety hazard or incident, notify your unit Safety Officer; file Form 368 (Product Quality Deficiency Report); and notify CECOM Safety Office, Ft. Monmouth, NJ (DSN 995-3112).

TM 11-5820-890-10-7

b (blank)

TABLE OF CONTENTS

Chapter	Page	Chapter	Page
1 INTRODUCTION	1- 1	4.4 PLGR TASK 4: <i>Load PLGR Key From ANCD Into PLGR</i>	4- 3
1.1 PURPOSE:	1- 1	5 FHMUX Tasks	5- 1
1.2 SCOPE:	1- 1	5.1	5- 1
1.3 DESIGNATIONS:	1- 1	6 Recap of Primary Operator Tasks	6- 1
1.4 AUXILIARY:	1- 1	6.1 Primary Task 1: <i>Load Single Channel Frequencies into Radio</i>	6- 1
1.5 REFERENCES;	1- 1	6.2 Primary Task 2: <i>Load COMSEC/FH Data into RT, using ICOM Fill</i>	6- 1
2 GRAPHICS	2- 1	6.3 Primary Task 3: <i>Perform Hot Start Net Opening</i>	6- 2
2.1	2- 1	6.4 Primary Task 4: <i>Perform Passive Late Net Entry</i>	6- 2
3 PRIMARY NCS/PREPARATION TASKS	3- 1	6.5 Primary Task 5: <i>Obtain SOI Information from ANCD (QREF in ANCD)</i>	6- 3
3.1 Preparation TASK 1: <i>Select RT Preparation Settings from MENU</i>	3- 1	7 Recap of Special Operator Tasks	7- 1
3.2 SUMMARY OF PRIMARY NCS TASKS	3- 1	7.1 Special Task 1: <i>Transfer COMSEC/FH Data, ANCD to ANCD</i>	7- 1
3.3 PRIMARY TASK 1: <i>Transfer Partial COMSEC/FH Data, ANCD to ANCD</i> ¹	3- 2	7.2 Special Task 2: <i>Transfer QREF SOI Information, ANCD to ANCD</i>	7- 2
3.3.1 OPTION 1A: <i>Transfer COMSEC Key, ANCD to RT</i> ²	3- 2	7.3 Special Task 2 (Alt): <i>Transfer Full SOI Information, ANCD to ANCD</i>	7- 2
3.3.2 OPTION 1B: <i>Designate New Default Loadset</i>	3- 3	7.4 Special Task 3: <i>Perform Cold Start Net Opening</i>	7- 3
3.3.3 OPTION 1C: <i>Change Eset in One Channel</i>	3- 3	7.5 Special Task 4: <i>Receive Net Update ERF from NCS</i>	7- 4
3.4 PRIMARY TASK 2: <i>Transfer Selected SOI Information, ANCD to ANCD</i> ³	3- 4	7.6 Special Task 5: <i>CUE and ERF Late Net Entry</i> ⁷	7- 4
3.5 PRIMARY TASK 3: <i>Conduct Hot Start Net Opening</i>	3- 5	7.7 Special Task 6: <i>Conduct RXMT Operations</i>	7- 4
3.6 PRIMARY TASK 4: <i>Conduct Cold Start Net Opening</i>	3- 5	7.8 Special Task 7: <i>Send an ERF as Part of RXMT Operation</i>	7- 5
3.7 PRIMARY TASK 5: <i>Respond to CUE Calls</i>	3- 7	7.9 Special Task 8: <i>Change Net ID</i>	7- 6
4 PLGR Tasks	4- 1	7.10 Special Task 9: <i>Use SIP/ASIP RT as an RCU</i>	7- 6
4.1 PLGR TASK 1: <i>Obtain Date and GPS Zulu Time From PLGR</i> ³⁻¹²⁸	4- 1	7.11 Special Task 10: <i>Use SIP/ASIP RT to Send Data Via RS-232 Mode</i>	7- 7
4.2 PLGR TASK 2: <i>Manually Load PLGR Date and Zulu Time Into ANCD</i>	4- 1	8 HRCRD OPERATIONS	8- 1
4.3 PLGR TASK 3: <i>Load PLGR Date and Zulu Time Into SINCGARS RT</i>	4- 2	8.1 GENERAL:	8- 1
		8.2 RADIO CONTROL	8- 1
		8.3 VOLUME	8- 1

⁸ TFOM reading of 8 or less indicates accurate GPS time. TFOM 9 means PLGR is not tracking satellites and time is not of GPS accuracy. It may take as long as 15 minutes for the PLGR to acquire satellites when device is first turned on. Battery powered PLGR will automatically go to standby as soon as satellite tracking is accomplished.

TM 11-5820-890-10-7

8.4	BACK LIGHT	8- 1	9.1	9- 1
8.5	CABLING	8- 1	10	Miscellaneous	10- 1
8.6	RT KEYPAD	8- 1	10.1	NCS Checklist	10- 1
8.7	VEHICULAR USE	8- 1	10.2	ABBREVIATIONS USED	10- 1
9	PMCS FOR SINCGARS RADIOS	9- 1			

CHAPTER 1

INTRODUCTION

1.1 PURPOSE:

This Pocket Guide is designed for use by Net Control Station (NCS) personnel equipped with the SINCGARS ICOM Ground Radio, Automated Net Control Device (ANCD), Precision Lightweight GPS Receiver (PLGR), and Frequency Hopping Multiplexer (FHMUX) (when available). It is expected that users of this Pocket Guide have been trained, both as operators and as NCSs, on all items of equipment being employed. NCS personnel using this pocket guide are expected to be proficient in the performance of all operator tasks, both primary and special. The purpose of this Pocket Guide is to provide SINCGARS NCS personnel with quick reference, easy to use, memory joggers that can be carried on the job during field operations. Users should understand that reference to other manuals may be required, when appropriate, to supplement the summary guidance contained in this Pocket Guide.

1.2 SCOPE:

This pocket guide covers the basic and special SINCGARS/ANCD tasks that an NCS must be able to perform as normal requirements during unit field operations. It also covers use of the PLGR, HRCRD and FHMUX by an NCS. The user is provided essential graphics, and each task is presented in abbreviated flowchart format for ease of use. The user is told what to do to perform required tasks, but not how or why. For NCS

special purposes tasks, electronic updating and STU transfer, see SINCGARS Operator's Manual, TM 11-5820-8-90-10-8.

1.3 DESIGNATIONS:

SIP radio configurations carry a "D" designation. Unit authorized SIP radio configurations will receive only SIP components: RT-1523C/D and AM-7239C/D. ASIP radio configurations carry a "F" designation. Unit authorized ASIP radio configurations will receive only ASIP components: RT-1523E and AM-7239E. Other SINCGARS radios will carry an "A" designation.

1.4 AUXILIARY:

The Automated Net Control Device (ANCD) and ITEMS: PLGR are considered to be authorized and employed in conjunction with SINCGARS.

1.5 REFERENCES:

TB 11-5820-890-12, ANCD Operator & Unit Maintenance Manual
TM 11-5820-890-10-6, SINCGARS Operator's Pocket Guide
TM 11-5820-890-10-8, SINCGARS Operator's Manual
TM 11-5825-291-13, Operation & Maintenance, PLGR (AN/PSN-11)
PM-SINCGARS New Equipment Handbook

TM 11-5820-890-10-7

CHAPTER 2 GRAPHICS

2.1




Figure 2-1 RT-1523/A/B FRONT PANEL



Figure 2-2 RT-1523/A/B KEYBOARD




Figure 2-3 1523C/D (SIP) FRONT PANEL



Figure 2-4 1523C/D (SIP) KEYBOARD

Table 2-1

NOTES:

1. Four keys of SIP keypad are redesignated.
2. SA and CID keys are not used.
3. RCU key enables use of SIP RT as an RCU.
4. GPS key enables loading of GPS time.




Figure 2-5 RT-1523E (ASIP) KEYBOARD

Table 2-2

NOTES:

1. Six keys of ASIP keypad are redesignated.
2. SA, CID and GPS keys are not used.
3. RCU key enables use of ASIP RT as an RCU.
4. MENU key scrolls athrough MENU selections.
5. FREQ/Backlight key controls backlight brightness. RT must be in SQ ON and CHG scrolls level.




Figure 2-6 RT-1523E (ASIP) FRONT PANEL




Figure 2-8 REAR VIEW (cover open)




Figure 2-7 FRONT VIEW

LAMP	ZERO	MAIN MENU	RCV	SEND	ABORT	ON/OFF
A P UP	B BAT	C CLR	D DELE	E 7	F 8	G 9
H P DN	I ↑	J	K	L 4	M 5	N 6
O ←	P SPACE	Q →	R	S 1	T 2	U 3
LOCK LTR	V ↓	W -	X /	Y 0	Z .	ENTR

Figure 2-9 AUTOMATED NET CONTROL DEVICE, AN/CYZ-10




Figure 2-10 PRECISION LIGHTWEIGHT GPS RECEIVER
(PLGR)

TM 11-5820-890-10-7

CHAPTER 3

PRIMARY NCS/PREPARATION TASKS

3.1 Preparation TASK 1: Select RT Preparation Settings from MENU

Table 3-3

SUBTASKS	ACTION	RESULTS
a. Set RT Volume	(1) Press MENU (2) Press Digit (1-9) for Vol Setting (0) for Whisper Mode	Press Menu to display Vol level Display reads WHSP if 0 selected
b. Set RT Channel	(2) Press MENU (until CHAN) (2) Press Digit (1-6) for Channel desired (0) for MAN (7) for CUE	Display reads (1-6), (Q) for CUE, (M) for Manual
c. Set RT Power	(1) Press MENU (until PWR) (2) Press CHG for desired PRW setting	Display reads (LO, M, HI, PA)
d. Set RT Mode	(1) Press MENU (until MODE) (2) Press CHG for desired MODE	Display reads (SC, FH, FHM)
e. Set COMSEC	(1) Press MENU (until CMSC) (2) Press CHG for desired CMSC setting	Display reads (PT, CT, TD, RV)
f. Set Backlight	(1) Place RT in SQ ON (2) Press FREQ/Backlight (3) Press CHG until desired setting	Backlight lights (4 settings Low to High, then OFF)
DEFAULT SETTINGS ARE: VOL (5), CHAN (1), PWR (LO), MODE (FH), COMSEC (CT)		

3.2 SUMMARY OF PRIMARY NCS TASKS

Table 3-4

<i>PRIMARY TASK 1:</i>	<i>Transfer Partial COMSEC/FH Data, ANCD to ANCD</i>
	Used to download selected COMSEC keys or FH data elements from one ANCD to another. Supplements Special Operator Task 1 which transfers complete loads.
<i>PRIMARY TASK 2:</i>	<i>Transfer Selected SOI Information, ANCD to ANCD</i>
	Used when less than a complete SOI load is to be downloaded from one ANCD to another. Supplements Special Operator Task 2.

PRIMARY TASK 3:	Conduct Hot Start Net Opening
	Principal method used for net openings; operators load required data and sync time; then request to enter the secure, FH net.
PRIMARY TASK 4:	Conduct Cold Start Net Opening
	An alternate method for net openings in which NCS sends ERF to all net members; requires close coordination and correct operator actions.
PRIMARY TASK 5:	Respond to CUE Calls
	Performed when CUE message appears in NCS RT display; requires NCS to answer CUE sender and send ERF if needed.

3.3 PRIMARY TASK 1: Transfer Partial COMSEC/FH Data, ANCD to ANCD¹

¹ This task is primarily used to transfer specific loadsets, Esets, keys, or time from one ANCD to another. When replacing/overwriting keys, new COMSEC and FH keys must be named the same as those to be replaced or overwritten.

Table 3-5 FOR ALL TASKS: RT-1523E Settings are set in MENU

SOURCE ANCD**	TARGET ANCD**
1} select: Soi Radio sUpervisor	1} select: Soi Radio sUpervisor
2} Send Receive Database sEtap Comsec Time	2} Send Receive Database sEtap Comsec Time
3} send to: Radio Ancd Stu Pc	3} receive from: Ancd Cfd Stu Pc Mx
4} select: Database Loadset Eset Key Time ***	4} select: Database Loadset Eset Key Time ***
5} select: Loadset# (name) ENTR	5} Connect to ANCD and press [RCV]##
6} Do you want to include time? (Y/N)	6} select: Replace iNsert (data item name)###
7} Connect to ANCD and press [SEND](WAIT)##	7} Transfer successful [↓]
8} Transfer successful [↓]	
<p>**You may select Loadset, Eset, Key, or Time. Item selected for Target ANCD must be the same as that selected for the Source ANCD. # Press [P UP]/[P DN] to scroll. ## DO NOT press SEND until ready to press RCV. Press RCV within 20 seconds of pressing SEND. ### This screen will appear only if data item name exists in Target ANCD.</p>	

3.3.1 OPTION 1A: Transfer COMSEC Key, ANCD to RT²

² Caution: CUE & MAN channels use COMSEC key stored in Chan 5.

Table 3-6

1} select: Soi <i>Radio</i> sUpervisor	5} Select key qUit (name/number) [ENTR]
2} Send Receive Database sEtup <i>Comsec</i> Time	6} Select key <i>qUit</i> (key selected) XMT
3} vG <i>Ld</i> Rv Ak Mk vU	7} Connect ANCD to RT** [↓]
4} select: Tek* Kek	8} Press [LOAD] on RT***
** Set RT FCTN to LD. (This procedure may be used to transfer COMSEC keys to KYK-13 and other COMSEC devices.) *** RT display will show H TEK; press STO, then CHAN in which you want to store the COMSEC key.	

3.3.2 OPTION 1B: Designate New Default Loadset

Table 3-7

1} select: Soi <i>Radio</i> sUpervisor	4} select: <i>Loadset</i> None
2} Send Receive Database sEtup <i>Comsec</i> Time	5} select: <i>Loadset</i> (name) [ENTR] (DI)**
3} select: <i>Com*</i> Nonicom	6} ICOM Fill will now load new DI loadset.)
* ICOM is also selected for RCU. ** Loadsets are identified with "D" indicating <i>default loadset</i> , followed by "I" for ICOM, or "N" for Non-ICOM.	

3.3.3 OPTION 1C: Change Eset in One Channel

Table 3-8

1} select: Soi <i>Radio</i> sUpervisor	6} select: <i>Eset</i> qUit
2} Send Receive <i>Database</i> sEtup <i>Comsec</i> Time	7} select: <i>Eset</i> (name)**[ENTR]
3} select: <i>Display Modify</i> Remove Copy bUild	8} Modify another loadset element? (Y/N)
* Select the Eset you wish to replace. ** Select your replacement Eset by name.	

4} select: Loadset (name)[ENTR] (DI)	9} select: <i>Replace</i> iNsert (name)
5} <i>Replace</i> Delete ESET#: (name)*[ENTR]	
* Select the Eset you wish to replace. ** Select your replacement Eset by name.	

3.4 PRIMARY TASK 2: Transfer Selected SOI Information, ANCD to ANCD³

³ For transfer of QREF file from ANCD to ANCD, use Operator Special Task 2 procedure.

Table 3-9

SOURCE ANCD	TARGET ANCD
1} select: <i>Soi</i> Radio sUpervisor	1} select: <i>Soi</i> Radio sUpervisor
2} qRef Group Net sufX Pyro TmPd <i>Set</i> C/s Find Memo	2} qRef Group Net sufX Pyro TmPd <i>Set</i> C/s Find Memo
3} select: Choose <i>Send</i> Receive	3} select: Choose <i>Send</i> <i>Receive</i>
4} Scroll (↑/↓) and press <i>ENTR</i> to select SOI [↓]	4} receive from: <i>Ancd</i> Pc Broadcast
5} SOI Set: (name/nr) Edn: (name/tp)	5} Connect ANCD to ANCD [↓]
6} Do you want to transfer QREF? (Y/N)	6} Press [<i>RCV</i>] to receive***
7} Do you want to specify groups to send? (Y/N)	7} Processing. Please wait (shows nr of bytes sent)
8} Scroll (↑/↓) and press <i>ENTR</i> to select groups	8} Receive operation was successful [↓]
9} 1 groups selected - Keep selecting? (Y/N)	
10} Do you want to specify a time pd to send: (Y/N)	
11} Enter Time Pd (#-#) = ~} ##	
12} Include Suffix & Smoke/Pyro data? (Y/N)	
13} Send to: <i>Ancd</i> Pc Broadcast	
** If this screen appears, enter NO. Either the set or QREF may be transferred, but not both at one time. *** DO NOT press SEND until ready to press RCV. Press RCV within 20 seconds of pressing SEND.	

SOURCE ANCD	TARGET ANCD
14}Do you want to save this new SOI set? (Y/N)	
15}New SOI set name: = ~} ??????????	
16}Connect ANCD to ANCD [↓]	
17}Press [SEND] to send (WAIT)**	
18}Processing. Please wait (shows % of bytes sent)	
19}Sending of SOI data is completed [↓]	
** If this screen appears, enter NO. Either the set or QREF may be transferred, but not both at one time. *** DO NOT press SEND until ready to press RCV. Press RCV within 20 seconds of pressing SEND.	

3.5 PRIMARY TASK 3: Conduct Hot Start Net Opening

Table 3-10

SUBTASK	ACTION	RESULTS
a. Load NCS RT w/COMSEC/FH data and time*	(See section 6.2 for ICOM Fill Procedure)	COMSEC/FH data and time are loaded into all 6 RT channels**
b. Load net RTs w/COMSEC/FH data and time	Direct net members to perform Opr Primary Task 3 (Hot Start)***	Net member RTs are prepared to enter FH, CT net upon request
c. Admit members to net	Respond to call in FH, CT mode	Hot Start net opening is complete
* If ANCD message "RT cannot accept time from ANCD" appears during ICOM fill procedure, go to section 6.3, perform subtasks "c" and "d", then standby while members request net entry. ** ANCD converts current date to two-digit Julian Date. *** Unit SOP should specify if net RTs are loaded by individual operators, communications specialists, or designated unit NCOs.		

3.6 PRIMARY TASK 4: Conduct Cold Start Net Opening

Table 3-11

SUBTASK	ACTION	RESULTS
a. Load NCS RT with data	(1) Load CUE, MAN, & SC freq as required	Perform Primary Opr Task 1
	(2) Load COMSEC, FH data, sync time	Perform Primary Opr Task 2
* An alternate procedure is to move the FCTN switch from LD to SQ ON. ** For various reasons, some net operators may not be available, or ready, to receive and store the Cold Start net opening ERF at the time specified by the NCS. Unit SOP should require one or more Alternate NCS to monitor the Cold Start net opening, note which operators do not enter at the prescribed time, and when possible, bring each into the FH, secure net.		

SUBTASK	ACTION	RESULTS
b. Set proper RT controls	<i>Set:</i> CHAN to MAN MODE to FH-M COMSEC to CT FCTN to LD	Prepares NCS radio for alert of net members
c. Alerts Oprs that net will open at time prescribed	(1) <i>Announce:</i> time net is to be opened	Gives Oprs time to load COMSEC/FH
	(2) <i>Alert:</i> net for ERF on MAN, using CT	Alerts Oprs to stand by for receipt of ERF
	(3) <i>Direct:</i> Alt NCS to follow up*	NCS focus is on Oprs who respond
d. Send ERF	(1) <i>Press:</i> LOAD	Causes RT to obtain data from memory
	(2) <i>Enter:</i> Chan in which data is stored	Display shows "HF xxx," blinks, beeps
	(3) <i>Press:</i> ERF	Display shows "SEND"
	(4) <i>Press:</i> STO, and CHAN # to store*	Display shows "STO_," "STO x," beeps
e. Confirm receipt	(1) <i>Allow:</i> Oprs time to store the ERF	N/A
	(2) <i>Direct:</i> Oprs ACK receipt and storage	NCS & Oprs continue to use MAN in CT
f. Perform comm check	(1) <i>Direct:</i> Oprs go to Opnl Chan, SQ ON	Net goes to FH mode of communications
	(2) <i>Check:</i> Comm with net members	Note which Oprs do not respond
	(3) <i>Direct:</i> Alt NCS to enter other net oprs**	FH SINCGARS net is now open
<p>* An alternate procedure is to move the FCTN switch from LD to SQ ON.</p> <p>** For various reasons, some net operators may not be available, or ready, to receive and store the Cold Start net opening ERF at the time specified by the NCS. Unit SOP should require one or more Alternate NCS to monitor the Cold Start net opening, note which operators do not enter at the prescribed time, and when possible, bring each into the FH, secure net.</p>		

3.7 PRIMARY TASK 5: Respond to CUE Calls

Table 3-12

SUBTASK	ACTION	RESULTS
a. Note "CUE" in RT display	(1) <i>Switch</i> : to CUE channel	Caller CUEs in PT, listens in CT
	(2) <i>Call</i> : CUE caller on CUE freq, in CT	QUE caller gets response
	(3) <i>Direct</i> : CUEer go to MAN/CT	
	(4) <i>Determine</i> : CUE caller's need	Authenticate if required
	(5) <i>Provide</i> : ERF if appropriate	If CUEer wishes to enter net
	(6) <i>Return</i> : to Opnl Channel	
	(7) <i>Displace</i> : If enemy has DF cap	CUE & MAN freqs can be DF'd
b. Have Alt NCS reply to CUE calls	(1) <i>Continue</i> : to control the net	NCS primary responsibility
	(2) <i>Ensure</i> : Alt NCS takes above steps*	Alt responds, then displaces
<p>* To send an ERF, the Alt NCS must go to FH-M. The Alt NCS may use FH-M on MAN (SC freq) while the NCS continues to use FH-M on a FH channel. But, it is important for the Alt NCS to switch to the MAN channel <i>before</i> changing to FH-M, and equally important for the Alt NCS to switch back to FH <i>before</i> returning to the operational channel.</p>		

TM 11-5820-890-10-7

CHAPTER 4

PLGR Tasks

4.1 PLGR TASK 1: Obtain Date and GPS Zulu Time From PLGR³⁻¹²⁴

Table 4-13

1} Press PLGR [ON] key	4} Press down arrow on PLGR
2} Observe PLGR perform its self-test	5} 2124:43Z TFOM 4** 29-11-93 MON Speed too slow GS < 1 mph ↑/↓P
3} FIX FOM 5 18T MGRS-New WK 82223e 63528n EL -00027m ↑/↓P	6} Read calendar date and Zulu time direct from PLGR

⁴ TFOM reading of 8 or less indicates accurate GPS time. TFOM 9 means PLGR is not tracking satellites and time is not of GPS accuracy. It may take as long as 15 minutes for the PLGR to acquire satellites when device is first turned on. Battery powered PLGR will automatically go to standby as soon as satellite tracking is accomplished.

4.2 PLGR TASK 2: Manually Load PLGR Date and Zulu Time Into ANCD

Table 4-14

1} Perform PLGR Task 1 to obtain date and time	8} Appl Date Time sEtap Util Bit
2} Turn ANCD ON	9} Time is: 15:27:42 New hh:mm:ss
3} select: Soi Radio sUpervisor	10} Time is:15:27:42 New hh:mm:ss:21:55:00**
4} Answer questions until following screen appears	11} Appl Date Time sEtap Util Bit*** {MAIN}
<p>* Upon entry, ANCD automatically converts calendar date to two-digit Julian Date required by the SINCGARS radio. ** Press ENTR on ANCD when PLGR and ANCD times are identical (00/00) or ANCD reads :59. You may find that it takes the ANCD about one second for time to load. Go to RADIO menu of ANCD and select TIME to check accuracy of GPS Zulu running time loaded into the ANCD. If there is more than one second difference, re-load time from PLGR. *** Follow Steps 11-13 to return to SOI or RADIO program.</p>	

TM 11-5820-890-10-7

5} ApplDate Time sEtop Util Bit {MAIN}	12}SOI RADIO RDS
6} Date is Mon 11-29-1993 New mm-dd-yy:	13}select: Soi Radio sUpervisor
7} Date is Mon 11-29-1993 New mm-dd-yy:12-07-93*	
<p>* Upon entry, ANCD automatically converts calendar date to two-digit Julian Date required by the SINCGARS radio. ** Press ENTR on ANCD when PLGR and ANCD times are identical (00/00) or ANCD reads :59. You may find that it takes the ANCD about one second for time to load. Go to RADIO menu of ANCD and select TIME to check accuracy of GPS Zulu running time loaded into the ANCD. If there is more than one second difference, re-load time from PLGR. *** Follow Steps 11-13 to return to SOI or RADIO program.</p>	

4.3 PLGR TASK 3: Load PLGR Date and Zulu Time Into SINCGARS RT

Table 4-15

1} Turn PLGR ON, observe self-test	9} Connect PLGR to RT AUD/FILL
2} FIX FOM 5 18T MGRS-New WK 82223e 63528n EL -00027m ↑/darr;P	10}Set RT FCTN to LD
3} Press PLGR [MENU] twice	11}Press PLGR down arrow to select "ACTIVATE"
4} DATA-XFR SV-SEL DOP-CALC ALERTS SINCGARS KOI-18 <more>P	12}SINCGARS Press LOAD key on radio QUIT
5} Press PLGR right arrow four times to highlight "SINCGARS"	13}Press [LOAD] on RT
6} Press PLGR down arrow to select "SINCGARS"	14}SINCGARS Time fill successful QUIT
7} SINCGARS Start time fill ACTIVATE QUIT	15}Press PLGR down arrow to select QUIT
8} Press PLGR left arrow to highlight "ACTIVATE"	

4.4 PLGR TASK 4: Load PLGR Key From ANCD Into PLGR

Table 4-16

1} Turn PLGR ON, observe self-test	7} vG <i>Ld Rv</i> Ak Mk vU
2} FIX FOM 5 18T MGRS-New WK 82223e 63528n EL -00027m ↑/↓P	8} Select: <i>Tek Kek</i>
	9} Select key <i>qUit</i> (PLGR key name)
3} Connect W4 to PLGR	10}Note next screen, press down arrow; DO NOT CONNECT ANCD TO RT*
4} Turn ANCD ON	11}Connect ANCD to RT [↓]
5} select: Soi <i>Radio sUpervisor</i>	12}Press [LOAD] on RT
6} Send Receive Database sEtup <i>Comsec Time</i>	13}Now connect W4 to ANCD
	14}Key loaded
* When screen 11 appears, press <i>down arrow</i> prior to connecting the W4 to the ANCD. Key is immediately transferred once the W4 is connected to the ANCD.	

TM 11-5820-890-10-7

CHAPTER 5

FHMUX Tasks

5.1

Table 5-17

SUBTASK	ACTION	RESULTS
a. Set POWER switch	(1) Set POWER switch to ON.	Power indicator illuminates continuously. The 4 BIT indicators should blink for 5 seconds after Power ON, then extinguish.*
b. Set RADIO PRIORITY switch.	(2) Set RADIO PRIORITY switch to**: EQUAL or 1A or 1B or 2A or 2B or RXMT (1A+1B)	All connected RTs have equal communications priority. RT 1A has highest communications priority. RT 1B has highest communications priority. RT 2A has highest communications priority. RT 2A has highest communications priority. RTs 1A and 1A have highest communications priority (retransmit).
<p>* Any other indication other than described, call Unit Level Maintenance. ** Select the RADIO PRIORITY switch position based on the desired operating scenario (which radio, if any, should get highest communications priority).</p>		

TM 11-5820-890-10-7

CHAPTER 6

Recap of Primary Operator Tasks

6.1 Primary Task 1: Load Single Channel Frequencies into Radio

FOR ALL TASKS: RT-1523 E Settings are set in MENU

Table 6-18

ACTION	RESULT
1} <i>Obtain:</i> required frequencies from ANCD*	1} Load CUE only if directed.
2} <i>Set</i> RT to CT, SC, LD, & CHAN to MAN/CUE/or 1-6	2} N/A
3} <i>Press:</i> FREQ, CLR, XXXXX, & STO	Display shows 00000/30000, -----, XXXXX, & blinks (data is stored)
4} <i>Repeat:</i> Step 3} for each freq	(As directed by NCS or SOP)
5} <i>Set:</i> FCTN to SQ ON	SC freq loading is complete
*In units using CT, FH nets, Oprs normally load only a MAN freq routinely. CUE and SC freqs for Chan 1-6 are loaded only as needed.	

6.2 Primary Task 2: Load COMSEC/FH Data into RT, using ICOM Fill

NOTE

Set RT to CT, LD, FH, MAN, & DATA OFF (PTT twice to clear alarm)

Table 6-19

1} select: Soi Radio sUpervisor	5} Connect to RT AUD/FILL Connector [↓]
2} <i>Send</i> Receive Database sEtap Comsec Time	6} Set FCTN switch to LD on RT [↓]
3} send to: Radio Ancd Stu Pc	7} Do you want to include time?*(Y/N)
* Load time for <i>net opening only</i> , not during updates. ** If this message appears, load date and time manually. When screen 11 appears, press <i>down arrow</i> prior to connecting the W4 to the ANCD. Key is immediately transferred once the W4 is connected to the ANCD.	

TM 11-5820-890-10-7

4} select: <i>iCom Nonicom Abn Rcu</i>	8} Press [LOAD] on RT
9} Transfer in progress/ Transfer successful	10}RT cannot accept time from ANCD*
* Load time for <i>net opening only</i> , not during updates. ** If this message appears, load date and time manually. When screen 11 appears, press <i>down arrow</i> prior to connecting the W4 to the ANCD. Key is immediately transferred once the W4 is connected to the ANCD.	

6.3 Primary Task 3: Perform Hot Start Net Opening

Table 6-20

1} Load RT w/COMSEC/FH, Date and Time*	2} Call NCS and request to enter CT, FH net
* If message "RT cannot accept time from ANCD" appears, set FCTN to LD and go to steps 3 & 4 to load time.	
3} Load Julian Day in RT (Read down)	4} Load Sync Time in RT (Read down)
select: <i>Soi Radio sU</i> ervisor	Julian Day: X X [↓]
Send Receive Database <i>sE</i> tup Comsec <i>Time</i>	ANCD Time: (running) HH:MM:SS (22:45:15)
Julian Day: X X [↓]	<i>Press</i> : TIME on RT; Display shows "HH MM"
<i>Press</i> : TIME on RT; Display shows "D D"	<i>Press</i> : CLR on RT; Display shows "_ _ _ _"
<i>Press</i> : CLR on RT; Display shows "_ _"	<i>Enter</i> : HH from ANCD; Display shows "HH"
<i>Enter</i> : X X (JD) in RT; Display shows "X X" (JD)	<i>Enter</i> : MM (min ahead of ANCD) Display shows "HH MM"
<i>Press</i> : STO on RT; Display blinks and JD is stored	<i>Press</i> : STO when ANCD MM:SS are same as RT MM:SS**
**Time stored in RT should be within 1 sec of that in ANCD; if not, repeat.	

6.4 Primary Task 4: Perform Passive Late Net Entry

Table 6-21

1} <i>Press</i> : FREQ Display shows "F XXX"	3} <i>Wait</i> : for traffic*** Display shows "F XXX" (No L)
2} <i>Press</i> : SYNC Display shows "LF XXX"	4} <i>Call</i> : NCS and re-enter net (Passive LNE is complete)
*** Do NOT PTT while waiting; if not traffic after 3 min, use CUE an ERF LNE or Hot Start method of net entry.	

6.5 Primary Task 5: Obtain SOI Information from ANCD (QREF in ANCD)

1. To look at any of the QREF items, perform the following steps:

Table 6-22

1} select: Soi Radio sUpervisor	2} qRef Group Net sufX Pyro Tmpd Set C/s Find Memo
------------------------------------	---

2. QREF displays up to 40 items from Net, sufX, Pyro, or C/s, available by scrolling. For each net stored as QREF items, the following information is available to the QREF user: net name, CUE frequency, MAN frequency, time period, call sign, net ID, and call word. To view items in Group, Tmpd, Set, Find, and Memo, as extensions of QREF entries, return to the main SOI menu and select the type of information needed. In viewing QREF or extension entries, be sure you have the correct time period selected.
3. Rules to remember in obtaining SOI information from the ANCD are:

Table 6-23

ABORT	Causes ANCD to return to SOI menu
Arrow down (shown as [↓])	You must press the down arrow to go to next screen
Arrow right/arrow left	Allows viewing of additional information and return
Arrow up/Arrow down	Allows viewing of each item
DELETE	To delete SOI set, enter SOI, then Set, and press DELE key
ENTER (shown as [ENTR])	Causes activation of the entry you have selected
Hot keys	Capital letter of selection (eg, sufX). Allows direct shift from QREF to full SOI file category.
"J" key (for JUMP)	In Find, causes ANCD to continue search for next item
""K" key (for KEEP)	Causes item being viewed to be stored in QREF file
MAIN MENU	Returns you to SOI/RADIO/SUPERVISOR menu
PgUP/PgDN	Moves to top or bottom of list
ZERO (red button)	Used in combat emergency only; DO NOT use foe deletions

4. Examples of information available in a full SOI information file are:⁶
 1. a. GROUP: (Group)

Table 6-24

1} qRef Group Net sufX Pyro Tmpd Set C/s Find Memo	2} TO1 Set:52ID DEM 003 003 52ID SPT
---	---

2. b. NET: (Net)

Table 6-25

1} qRef Group <i>Net</i> sufX Pyro Tmpd Set C/s Find Memo	3} TO6 1-4 FA BN W7T Callwrd:BULLDOG**
2} TO6 1-4 FA BN W7T C81975 M74800 0424	
** Callword is obtained by pressing right arrow; then left arrow to return to NET display.	

3. c. SUFFIX: (sufX)

Table 6-26

1} qRef Group <i>Net</i> sufX Pyro Tmpd Set C/s Find Memo	2} Commander 02 COFS/XO 27
--	-------------------------------

4. d. PYRO: (Pyro)

Table 6-27

1} qRef Group <i>Net</i> sufX <i>Pyro</i> Tmpd Set C/s Find Memo	3} Safe to land or drop supplies here*
2} GREEN SMOKE* [↓/→]	
* Press right arrow to obtain explanation; left arrow to return to Pyro menu.	

5. e. TIME PERIOD: (Tmpd)

Table 6-28

1} qRef Group <i>Net</i> sufX Pyro Tmpd Set C/s Find Memo	2} Enter Time Pd: = > # #
--	------------------------------

6. f. SET: (Set)

Table 6-29

1} qRef Group <i>Net</i> sufX Pyro Tmpd <i>Set</i> C/s Find Memo	3} Scroll "/#, press <i>ENTR</i> to select net [↓]
2} select: <i>Choose</i> Send Receive	4} Set: (name/nr) Edn: (Name/tp) [<i>ENTR</i>]

7. SIGN/CNTRSIGN: (C/s)

Table 6-30

1} qRef Group Net sufX Pyro Tmpd Set C/s Find Memo	2} TO1 Sign: HARDWOOD Cntrsign: SNEAKER
---	--

8. h. FIND: (Find)

Table 6-31

1} qRef Group Net sufX Pyro Tmpd Set C/s Find Memo	2} Find: Net nEtid Sfx Word Cisgn Grp gRp# Des Frq
---	---

9. i. MEMO:⁵ (Memo)

Table 6-32

1} qRef Group Net sufX Pyro Tmpd Set C/s Find Memo	2} Memo: 1- 2- 3- 4-
---	-------------------------

56

⁵ Four memos may be 6 lines, 22 spaces each; part of QREF/SOI transfer.

⁶ Once a time period has been selected, the same time period will appear each subsequent time the ANCD is turned on. Thus, you need to change the time period only when advancing to the next day. To change the time period, enter SET and make time period selection.

TM 11-5820-890-10-7

CHAPTER 7

Recap of Special Operator Tasks

7.1 Special Task 1: Transfer COMSEC/FH Data, ANCD to ANCD

Table 7-33

SOURCE ANCD	TARGET ANCD
1} select: Soi Radio sUpervisor	1} select: Soi Radio sUpervisor
2} Send Receive Database sEtop Comsec Time	2} Send <i>Receive</i> Database sEtop Comsec Time
3} send to: Radio Ancd Stu Pc	3} receive: Ancd Cfd Stu Pc Mx
4} select: <i>Database</i> * Loadset Eset Key Time	4} select: <i>Database</i> Loadset Eset Key Time
5} Do you want to include time? (Y/N)	5} Want to delete*** FH & COMSEC data? (Y/N)
6} Connect to ANCD and press [SEND](WAIT)**	6} Connect to ANCD and press [RCV]**
7} Transfer in progress/ Transfer successful	7} Transfer in progress/ Transfer successful
<p>* You <i>must</i> enter "DATABASE" to proceed. ** <i>DO NOT</i> press [SEND] until you are ready to press [RCV]. Then press [RCV] within about 20 seconds of pressing [SEND]. *** You <i>must</i> enter "YES" to proceed. NOTE: You can clear your ANCD of COMSEC/FH data by performing Target ANCD Steps 1-5, above, and pressing ABORT.</p>	

TM 11-5820-890-10-7

7.2 Special Task 2: Transfer QREF SOI Information, ANCD to ANCD

Table 7-34

SOURCE ANCD	TARGET ANCD
1} select: <i>Soi</i> Radio sUpervisor	1} select: <i>Soi</i> Radio sUpervisor
2} qRef Group Net sufX Pyro TmPd <i>Set C/s</i> Find Memo	2} qRef Group Net sufX Pyro TmPd <i>Set C/s</i> Find Memo
3} select: Choose <i>Send</i> Receive	3} select: Choose <i>Send Receive</i>
4} Scroll (↑/↓) and press <i>ENTR</i> to select <i>Set</i> [↓]	4} receive from: <i>Ancd</i> Pc Broadcast
5} <i>Set</i> : (name/nr) <i>Edn</i> : (name/tp)	5} Connect ANCD to ANCD [↓]
6} Do you want to transfer QREF? (Y/N)	6} Press [<i>RCV</i>] to receive**
7} send to: <i>ANCD</i> Pc Broadcast	7} Processing Please wait (shows number sent)
8} Connect ANCD TO ANCD [↓]	8} Receive operation was successful [↓]
9} Press [<i>SEND</i>] to send (WAIT)**	
10} Processing Please wait (shows % of bytes sent)	
11} Sending of SOI data is completed [↓]	
<p>* You <i>must</i> select YES. ** DO NOT press SEND until ready to press RCV; then press [RCV] within 20 seconds of pressing SEND. *** See section 7.3 if full SOI data is required.</p>	

7.3 Special Task 2 (Alt): Transfer Full SOI Information, ANCD to ANCD

Table 7-35

SOURCE ANCD	TARGET ANCD
1} select: <i>Soi</i> Radio sUpervisor	1} select: <i>Soi</i> Radio sUpervisor
2} qRef Group Net sufX Pyro TmPd <i>Set C/s</i> Find Memo	2} qRef Group Net sufX Pyro TmPd <i>Set C/s</i> Find Memo
<p>* Screens 6-9 appear only if related data is in ANCD. ** You <i>must</i> enter NO to transfer full SOI. *** DO NOT press [SEND] until ready to press [RCV]; then press [RCV] within 20 seconds of pressing [SEND].</p>	

SOURCE ANCD	TARGET ANCD
3} select: Choose <i>Send Receive</i>	3} select: Choose <i>Send Receive</i>
4} Scroll ("/#) and press ENTR to select Set [↓]	4} receive from: <i>Ancd Pc Broadcast Stu</i>
5} Set: (name/nr) Edn: (name/tp) [ENTR]	5} Connect ANCD to ANCD [↓]
6*} Do you want to transfer QREF?** (Y/N)	6} Press [RCV] to receive***
7*} Want to specify groups to send?** (Y/N)	7} Processing Please wait (shows number sent)
8*} Want to specify a time pd to send? (Y/N)	8} Receive operation was successful [↓]
9*} Want to specify a Smoke/Pyro data? (Y/N)	
10} send to: <i>Ancd Pc Broadcast Stu</i>	
11} Connect ANCD to ANCD [↓]	
12} Press [SEND] to send (WAIT)***	
13} Processing Please wait (shows % of bytes sent)	
14} Sending of SOI data is completed	
* Screens 6-9 appear only if related data is in ANCD. ** You <i>must</i> enter NO to transfer full SOI. *** DO NOT press [SEND] until ready to press [RCV]; then press [RCV] within 20 seconds of pressing [SEND].	

7.4 Special Task 3: Perform Cold Start Net Opening

Table 7-36

1} Load MAN freq into RT	5} Press: STO; Display shows "STO _"
2} Load RT with COMSEC/FH data	6} Press: X (1-6); Display shows "STO X", blinks
* Net may open in PT if COMSEC is not a consideration. ** If NCS contact fails, standby on MAN for NCS call.	

TM 11-5820-890-10-7

3} <i>Set:</i> RT to LD, CT*, MAN, & FH	7} <i>Set:</i> CHAN to X (1-6) and FCTN to SQ ON
4} <i>Standby</i> for ERF; Display shows "HF XXX"	8} <i>Call or respond</i> to NCS comm check**
* Net may open in PT if COMSEC is not a consideration. ** If NCS contact fails, standby on MAN for NCS call.	

7.5 Special Task 4: Receive Net Update ERF from NCS

Table 7-37

1} <i>Set:</i> RT FCTN to LD (stay on net operational channel)	4} <i>Enter:</i> X (1-6)*; Display shows "STO X", blinks
2} <i>Standby:</i> for update ERF; Display shows "HF XXX"	5} <i>Set:</i> CHAN to X (1-6) and FCTN to SQ ON
3} <i>Press:</i> STO; Display shows "STO ___"	6} <i>Call or respond</i> to NCS call (Net update is complete)**
* NCS directs Chan for storage. When update is effective, go to this Chan. ** Assumes same COMSEC key in Chan 1-5 or 1-6.	

7.6 Special Task 5: CUE and ERF Late Net Entry⁷

⁷ The Hot Start net opening procedure may be used in lieu of CUE & ERF when a loaded ANCD and GPS time are available.

Table 7-38

1} <i>Load</i> CUE and MAN freq is not already loaded	6} <i>Repeat:</i> every 15 sec (CUE goes thru only if net is quiet)
2} <i>Set:</i> CHAN-CUE, COMSEC-PT	7} <i>Request:</i> ERF (when NCS responds)
3} <i>Press:</i> PTT for 4-5 seconds (Do not talk)	8} <i>Store:</i> ERF (when received)
4} <i>Set:</i> COMSEC-CT (at once) (NCS responds in CT)	9} <i>Re-enter:</i> net (CUE & ERF LNE is complete)
5} <i>Wait:</i> for NCS to respond	

7.7 Special Task 6: Conduct RXMT Operations

Table 7-39

1} Obtain RXMT COMSEC/FH data	6} Send ERF to RT-B if needed*
2} Load RXMT radios	7} Install RXMT cable, RT-C to D
* See section 7.8, below.	

3} Move to RXMT site	8} Set RT-C&D FCTN to RXMT
4} Call RT-A on F1 using RT-C	9} Set RT-C to FH, RT-D to FH-M
5} Call RT-B using RT-D	10} Have RT-A call RT-B via RXMT
* See section 7.8, below.	




Figure 7-11 RETRANSMISSION GRAPHIC

NOTES: 1) RXMT RTs should be set to CT to enable RXMT crew to monitor RT-A to RT-B communications. 2) An RXMT station operating in EDM mode will pass both EDM and SDM data traffic, as well as voice messages. 3) For RXMT of RS-232 data, both RXMT radios must be set to the data rate used for RS-232 data transfer. Transfer of data by RS-232 mode through an RXMT station requires a longer time than FH only RXMT or point-to-point RS-232 traffic. 4) Mixed mode RXMT (SC to FH, FH to SC) of data traffic can be passed in SDM mode only, not in EDM mode.

NOTE

7.8 Special Task 7: Send an ERF as Part of RXMT Operation

Table 7-40

1} Obtain data to be sent by ERF	7} Press ERF
2} Load data into RT	8} Press STO*
3} Alert receiver, ERF to be sent	9} Enter CHAN for storing data*
4} Set RT to LD and FH-M	10} Wait for receiver to store ERF
5} Press LOAD	11} Confirm receipt of ERF
6} Enter CHAN where ERF data is stored	12} Set RT to FH and SQ ON; resume normal communications
* Or, move FCTN switch from LD to SQ ON.	

7.9 Special Task 8: Change Net ID

Table 7-41

1} Set RT to LD*	4} Enter new net ID (XXX)**
2} Set CHAN to 1-6 (one to change)	5} Press STO
3} Press FREQ, then CLR	6} Set RT to SQ ON, chan desired
<p>* Some versions of the RT require the FCTN to be set to the FH-M position in order to change the Net ID of any channel. When the FH-M position is required for a Net ID change, it is important that the FH-M back to FH upon task completion (except for NCS).</p> <p>** Some versions of the SINCGARS radio will allow you to change only the last two Net ID numbers.</p>	

7.10 Special Task 9: Use SIP/ASIP RT as an RCU

Table 7-42

STEP	ACTION	RESULT
1	Load RT & RCU(RT) with proper data	Prepares SIP RTs for remote operations*
2	Install wire link from RCU(RT) to Rem radio	(See TM 11-5820-890-10-8 for setup instructions)
3	Set Rem RT FCTN switch to REM position	Enables RCU(RT) to control Rem radio
4	Set RCU(RT) FCTN switch to SQ ON	(LD, SQ OFF, and RXMT may also be used)
5	Set RCU(RT) DATA to any option	N/A
6	Press [RCU] key on RCU(RT); select "RCU"	"RT," "RCU," "EXT," and "LDE" show in RT display
7	Wait 7 sec; then note RCU(RT) display blink	SIP RT is now ready to perform as an RCU(RT)
8	Set RCU(RT) FCTN to REM position	Enables RCU(RT) Opr to call remote radio by wire
9	Press RCU(RT) CALL key & PTT at same time; hold for 4 to 7 seconds	Produces ring tone and CALL message at Rem RT; oprs can talk on orderwire
10	Set RCU(RT) FCTN to SQ ON	Remoted radio is now controlled by RCU(RT)
<p>* For use of a SIP RT as either a manpack RCU or a manpack remoted radio, Battery Box CY-8523A/B is required. ASIP requires a two wire adapter.</p> <p>** RCU, C-11561, may be used for remote control of a SIP radio for voice and SDM data only, not for EDM data.</p> <p>*** RCU(RT) COMSEC must be set to PT to talk over orderwire.</p>		

7.11 Special Task 10: Use SIP/ASIP RT to Send Data Via RS-232 Mode

Table 7-43

STEP	ACTION	RESULT
1	Load PC with commercial comm SW*	Use any SW program offering "Xmodem"
2	Connect PC to SIP RT AUD/DATA PORT	RS-232 method does not require SW in SIP VAA
3	Alert net data is to be sent via RS-232 mode	If not fixed, coordinate data rate to be used**
4	Select data rate to be used for RS-232 data**	Sending and receiving RTs must use same data rate
5	Prepare data message or load PC with data	N/A
6	Check to ensure net is clear of traffic	Need clear net to ensure data goes through****
7	Follow comm SW procedures to send/receive RS-232 data	Control is from computer; SIP radio serves as data communications carrier

* Both sending and receiving stations must use the same or compatible communications programs.
 ** Depending upon the distance between sending and receiving stations, any one of four enhanced data rates may be used for RS-232 traffic; 1200N, 2400N, 4800N, and 9600N.
 *** To select data rate, select RS-232 at SIP RT, press ENTER on PC, and note data rate displayed on PC screen.
 **** If voice mode has priority of use on your net, it may be necessary to wait for a quiet period to send data messages. (Pressing PTT will not interrupt data flow except to your radio.)

TM 11-5820-890-10-7

CHAPTER 8

HRCRD OPERATIONS

8.1 GENERAL:

The HRCRD is used with the SINCGARS manpack radio, AN/PRC-119A/D/F, and dismount kits of vehicular radios AN/VRC-88A/D/F and -91A/D/F.

8.2 RADIO CONTROL

Using the HRCRD, a manpack radio operator can control the Channel, RF Power, Mode, and COMSEC functions of the radio, without requiring access to the RT. RT FCTN switch must be set to REM for HRCRD to be functional.

8.3 VOLUME

The level of audio volume at the HRCRD can be adjusted by use of the thumb wheel on the side of the HRCRD.

8.4 BACK LIGHT

The HRCRD back light can be turned on with one press of the round light button. A second press of the light button turns the back light off.

8.5 CABLING

The cable of the HRCRD forms a "Y," with one end connected to the RT AUD/DATA or AUD/FILL port. The other end is connected to the 6-pin connector on Battery Box CY-8523C or the AUX connector of the RT-1523E. This battery box is required for use of the HRCRD in normal manpack radio configuration.

8.6 RT KEYPAD

Access to the RT Front Panel is required whenever it is necessary to change the FCTN switch, to adjust audio volume at the RT, and to change the light level in the RT display.

8.7 VEHICULAR USE

Although the HRCRD is intended for use with manpack radios, it can be employed with vehicular configurations that do not

include a control-monitor. To do so, connect one end of the "Y" cable to the RT (A position) AUD/DATA or AUD/FILL port and the other end to J9 connector (C-M) at the rear of the VAA.




Figure 8-12 HRCRD

TM 11-5820-890-10-7

CHAPTER 9

PMCS FOR SINGARS RADIOS

9.1

Table 9-44

ITEM/WHEN	CHECK/SERVICE	NMC IF:
1. (B,D,A)** <i>Controls:</i> (Front of RT and on VAA)	a. Cracked/broken? b. Loose? c. Frozen? d. Missing?	Any RT or VAA control is missing or cannot be used
2. (B,D,A) <i>Cables:</i> (W2, RF, W4, and PA Pwr)	a. Missing? b. Installed properly? c. Connectors tight? d. Obvious damage?	Any cable is missing or damaged and cannot be used
3. (B,D,A) <i>Antennas:</i> (Manpack short and long; vehicular regular and SLPA)	a. Installed properly? b. Grounded? c. Broken parts? d. Missing parts? e. Tips and tie- downs present?	a. b. Not grounded c. Cannot be used d. Missing
4. (B) <i>Power:</i> Manpack Vehicular Manpack or vehicular	a. Main battery present? b. Vehicle power available? c. Move COMSEC from Z to PT, adjust DIM, move FCTN from OFF to Z-FH, and check that RT display lights?	a. Missing, cannot be replaced b. No power, cannot correct c. RT display does not light
5. (B) <i>Self-Test:</i>	a. (FCTN in Z-FH) Display shows [GOOD]? b. (COMSEC to CT) Alarm will clear? c. (FCTN to TST) self-test results [GOOD]?	a. Display does not show [GOOD] b. COMSEC alarm will not clear c. Display shows 1other than [GOOD]

*Non Mission Capable and reportable under The Army Maintenance System (TAMMS).

**Before, During, and After Operations checks and services.

ITEM/WHEN	CHECK/SERVICE	NMC IF:
6. (B) <i>Keypad:</i>	(RT at CT, SC, LD, and CHAN as shown below: a. Press FREQ , CLR , and enter frequency: CUE 31000 MAN 32000 CHAN 1 43000 CHAN 2 54000 CHAN 3 65000 CHAN 4 76000 CHAN 5 87000 CHAN 6 87975b. Press STO for each frequency entered	a. Any test frequency (0-9) cannot be entered into the RT b. Cannot store any frequency
7. (B) <i>Data Loading:</i> (SC freq, COMSEC key, FH data, sync time)	a. Load SC frequency b. Load COMSEC key c. Load FH data d. Load sync time	a. Will not load b. Will not load c. Will not load d. Will not load
8. (B,D,A) <i>Comm Check:</i> (Voice/data in SC/FH modes; PT/CT and RXMT, as required by mission)	a. Check sidetone b. Check voice comm in SC-PT c. If data comm to be used, check using mission-related data device d. If RXMT to be used, check in mission-related modes	a. Not heard b. No voice comm in SC-PT or FH-CT c. No data comm using mission-related data device d. No RXMT capability in mission-related modes
*Non Mission Capable and reportable under The Army Maintenance System (TAMMS). **Before, During, and After Operations checks and services.		

Table 9-45

CHECK/SERVICE	OPERATOR PROCEDURE	NOT FULLY MISSION CAPABLE IF:*
<p><i>CONTROLS:</i> (B,D,A)</p> <p><i>LIGHT</i> (B,D,A)</p> <p><i>VOLUME</i> (B,D,A)</p> <p><i>CABLE</i> (B,D,A)</p>	<p>To control radio functions, press [SEL] until the required function is highlighted (CHAN; COMSEC; RF PWR; MODE). Then press the [DOWN ARROW] until specific item you need appears in the display.</p> <p>To turn backlight on, press the light button. To turn the light off, press the light button a second time.</p> <p>To change the level of audio volume, rotate the volume control knob on the side of the HRCRD to reach desired level.</p> <p>a. Check for proper installation. b. Check for tightness of connectors. c. Check for obvious damage to cable.</p>	
<p><i>CONNECTORS:</i> (B,D,A)</p>	<p>a. Check for obvious damage to connectors. b. Check for missing O-rings. c. Check for bent/broken pins.</p>	
<p><i>COMM CHECK:</i> (B,D,A)</p>	<p>a. Check for sidetone. b. Check voice comm.</p>	<p>a. Cannot transmit or receive.</p>
<p>Before (B), During (D), After (A)</p> <p style="text-align: center;">NOTE</p> <p>HRCRD IS MISSION CAPABLE AS LONG AS TRANSMIT AND RECEIVE FUNCTIONS ARE OPERABLE. If controls are not functioning, place radio function switch to normal operating position (SQ ON)/LD) and change functions via keypad/switches</p>		

TM 11-5820-890-10-7

CHAPTER 10

Miscellaneous

10.1 NCS Checklist

It is suggested you use the following general checklist to ensure you are ready to meet all NCS requirements.

USE THE OPERATOR CHECKLIST IN TM 10-6 TO CHECK YOUR RADIO, ANCD, AND ABILITY TO COMMUNICATE.

ENSURE YOU AND NET OPERATORS HAVE THE CORRECT COMSEC/FH/SOI DATA.

USE YOUR PLGR AS A READY SOURCE OF JULIAN DATE AND GPS ZULU TIME.

DESIGNATE ONE OR MORE ALT NCS TO FOLLOW UP NET OPENINGS, RESPOND TO CUE CALLS, AND DISPLACE WHEN REQUIRED.

HAVE RXMT CREW(S) READY FOR EMPLOYMENT WHEN NEEDED.

ONCE EVERY 24 HOURS, CHECK YOUR RT'S SYNC TIME AGAINST PLGR GPS TIME; IF MORE THAN 2 SECONDS OFF, RELOAD TIME.

WHEN OPERATING OVER MIDNIGHT OF 31 DECEMBER, RESET JD TO 0.1. OPTIONS ARE (1) RELOAD TIME FROM ANCD, (2) CHANGE JD USING RT KEYPAD, OR (3) NCS CHANGE JD AND SEND NET UPDATE ERF ON MAN.

WHEN CHANGING TO ANOTHER CHANNEL, CHANGE TO FH.

HOLD ADMINISTRATIVE TRAFFIC TO A MINIMUM, AND WAIT UNTIL NET IS QUIET.

TALK OPERATORS THROUGH TASKS WHENEVER APPROPRIATE.

MAKE BEST USE OF SECOND/THIRD RADIOS TO MONITOR KEY OPERATIONS.

ENSURE THAT ONLY THE NCS RADIO IS SET TO FH-M.

WHEN NET TRAFFIC IS HEAVY, TRANSMIT (OR PUSH PTT) AT LEAST EVERY HALF-HOUR.

KEEP AN INFORMAL RECORD OF WHICH OPERATORS ARE ACTIVE IN THE NET.

10.2 ABBREVIATIONS USED

ACK	Acknowledge
AK	Automatic Key
ANCD	Automated Net Control Device
APPL	Application
ASIP	Advanced System Improvement Program
BCAST	Broadcast

BPS	Bits Per Second
CID	Combat Identificaiton
C/S	Sign/Countersign
CALWD	Call Word
CFD	COMSEC Fill Device
CLR	Clear
COMSEC	Communications Security
CNTRSIGN	Countersign
CT	Cipher Text
DBS	Databases
DD	Days shown as two-digit number
DI	Default Identification
DTG	Date-time-group
ECCM	Electronic Counter Counter-Measure
EDITN/EDN	Edition
EDM	Enhanced Data Mode
ERF	Electronic Remote Fill
ESET	One Channel of FH Data
EXT	External
FCTN	RT Function Control
FH-M	Frequency Hopping-Master
FHMUX	Frequency-Hopping Multiplexer
FREQ/FRQ	Frequency
GPS	Global Positioning System
GRP	Group
HRCRD	Handheld Remote Control Radio Device
HH:MM:SS	Hours:Minutes:Seconds
ICOM	Integrated Communications Security
ID	Identification/Infantry Division
INC	Internet Controller
INTCM	Intercom
JD	Julian Date/Day
KEK	Key Encryption Key
LD	Load
LDE	Local Data Entry
LNE	Late Net Entry
MAN	Manual Frequency
MK	Manual Key
MM-DD-YY	Month-Day-Year
N	New or Enhanced Data Mode
NETID	Net Identification
NR	Number
OPR	Operator
OTAR	Over-The-Air-Rekey

TM 11-5820-890-10-7

PC	Personal Computer	SC	Single Channel
PCKT	Packet Data Mode	SIP	System Improvement Program
PLGR	Precision Lightweight GPS Receiver	SQ ON	Squelch On
PT	Plain Text	STO	Stow
PTT	Push-To-Talk [Switch]	STU	Secure Telephone Unit
PYRO	Pyrotechnics	SUFFIX	Suffix
QREF	Quick Reference	TEK	Transmission Encryption Key
RCU	Remote Control Unit	TFOM	Time Figure of Merit
RCT (RT)	SIP/ASIP used as an RCU	TMPD/TP	Time Period
RCV	Receive	TSK	Transmission Security Key
RDS	RBECS DTD Software	VAA	Vehicular Amplifier Adapter
RT	Receiver-Transmitter	VG	Variable Generate
RV	Receive Variable	VU	Variable Update
RXMT	Retransmission	XMT	Transmit
SA	Situational Awareness	Z-FH	Zero Frequency Hopping Data