

DEPARTMENT OF THE ARMY TECHNICAL MANUAL

GENERAL SUPPORT MAINTENANCE REPAIR PARTS AND
SPECIAL TOOLS LISTS (INCLUDING DEPOT MAINTENANCE
REPAIR PARTS AND SPECIAL TOOLS)
CHARGERS, BATTERY PP-1660/G AND PP-1660A/G
FSN 6130-669-6659

Headquarters, Department of the Army, Washington, D.C.
28 June 1974

Current as of November 1973

	Paragraph	Page
SECTION I. INTRODUCTION		
Scope	1-1	2
General	1-2	2
Explanation of columns	1-3	2
Special information	1-4	4
Location of repair parts	1-5	4
Abbreviations (Nat applicable)	1-6	4
Reporting of equipment publication improvements	1-7	4
II. REPAIR PARTS LIST		6
III. SPECIAL TOOLS, TEST AND SUPPORT EQUIPMENT (Not applicable)		
IV. INDEX — FEDERAL STOCK NUMBER AND REFERENCE NUMBER CROSS- REFERENCE TO FIGURE AND ITEM NUMBER		9

*This manual supersedes TM 11-6130-227-45P, 27 November 1964

SECTION I INTRODUCTION

1-1. Scope

This manual lists repair parts and special tools required for the performance of general support and depot maintenance of the PP-1660/G and PP-1660A/G. The PCCN for the equipment is GTBAAR for all models.

NOTE

No parts authorized for stockage at direct Support.

1-2 General

This repair parts and special tools list is divided into the following sections:

a. Repair Parts List - Section II. A list of repair parts authorized for the performance of maintenance at the general support, and depot level. This repair parts list is arranged in alphabetical order.

b. Special Tools, Test and support Equipment-Section III. Not applicable.

c. Index - Federal Stock Number and Reference Number Cross-Reference to Figure and Item Number - Section IV. A list, in ascending numerical sequence, of all Federal stock numbers appearing in the listings, followed by a list, in alphameric sequence, of all reference numbers appearing in the listings. Federal stock number and reference numbers are cross-referenced to each illustration figure and item number or reference designation appearance.

1-3. Explanation of Columns

The following provides an explanation of columns found in the tabular list.

a. Source, Maintenance, and Recoverability Codes (SMR).

(1) *Source* code. Indicates the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are —

<i>Code</i>	<i>Explanation</i>
PA —	Item procured and stocked for anticipated or known usage.
PB —	Item procured and stocked for insurance purposes because essentiality dictates that a minimum quantity be available in the supply systems.
PC —	Item procured and stocked and which otherwise would be coded PA except that it is deteriorative in nature.

<i>Code</i>	<i>Explanation</i>
PD —	Support item, excluding support equipment, procured for initial issue or outfitting and stocked only for subsequent or additional initial issues or outfittings. Not subject to automatic replenishment.
PE —	Support equipment procured and stocked for initial issue or outfitting to specified maintenance repair activities.
PF —	Support equipment which will not be stocked but which will be centrally procured on demand.
PG —	Item procured and stocked to provide for sustained support for the life of the equipment. It is applied to an item peculiar to the equipment which because of probable discontinuance or shutdown of production facilities would prove uneconomical to reproduce at a later time.
KD —	An item of depot overhaul/repair kit and not purchased separately. Depot kit defined as a kit that provides items required at the time of overhaul or repair.
KF —	An item of a maintenance kit and not purchased separately. Maintenance kit defined as a kit that provides an item that can be replaced at organizational or direct support or general support levels of maintenance.
KB —	Item included in both a depot overhaul/repair kit and a maintenance kit.
MO —	Item to be manufactured or fabricated at organizational level.
MF —	Item to be manufactured or fabricated at direct support maintenance level.
MH —	Item to be manufactured or fabricated at general support maintenance level.
MD —	Item to be manufactured or fabricated at depot maintenance level.
AO —	Item to be assembled at organizational level.
AF —	Item to be assembled at direct support maintenance level.
AH —	Item to be assembled at general support maintenance level.
AD —	Item to be assembled at depot maintenance level.
XA —	Item is not procured or stocked because the requirements for the item will result in the replacement of the next higher assembly.
XB —	Item is not procured or stocked. If not

<i>Code</i>	<i>Explanation</i>
	available through salvage, requisition.
XC —	Installation drawing, diagram instruction sheet, field service drawing, that is identified by manufacturers' part number.
XD —	Support items can be requisitioned with justification.

NOTE

Cannibalization or salvage may be used as a source of supply for any items source coded above except those coded XA and aircraft support items as restricted by AR 700-42.

(2) *Maintenance code.* Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code Format as follows:

(a) *Use (third position).* The maintenance code entered in the third position indicates the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position indicates one of the following levels of maintenance.

<i>Code</i>	<i>Application/Explanation</i>
O—	Support item is removed, replaced, used at the organizational level of maintenance.

NOTE

A code "C" may be used in this position to denote crew or operator maintenance performed within organizational maintenance.

F—	Support item is removed, replaced, used at the direct support maintenance level.
H—	Support item is removed, replaced, used at the general support maintenance.
D—	Support items that are removed, replaced, used at depot only.

(b) *Repair (fourth position).* The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions). When a maintenance code is not used a dash (-) sign is entered. For multi-service equipment/systems or when a code is entered, this position will contain one of the following maintenance codes as assigned by the service(s) that require the code:

<i>Code</i>	<i>Application/Explanation</i>
O—	The lowest maintenance level capable of complete repair of the support item is the organizational level.

<i>Cbde</i>	<i>Application/Explanation</i>
F—	The lowest maintenance level capable of complete repair of the support item is direct support.
H —	The lowest maintenance level capable of complete repair of the support item is general support.
D—	The lowest maintenance level capable of complete repair of the support item is the depot level.
L—	Repair restricted to designated Specialized Repair Activity.
Z—	Non-repairable. No repair is authorized.
B—	No repair is authorized. The item may be reconditioned by adjusting, lubricating, etc., at the user level. No parts or special tools are procured for the maintenance of this item.

(3) *Recoverability code.* Recoverability codes are assigned to support items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the uniform SMR Code Format as follows:

<i>Code</i>	<i>Explanation</i>
Z—	Nonrepairable item. When unserviceable, condemn and dispose at the level indicated in the first digit of the maintenance code.
O—	Repairable item. When uneconomically repairable, condemn and dispose at organizational level.
F—	Repairable item. When uneconomically repairable, condemn and dispose at the direct support level.
H—	Repairable item. When uneconomically repairable, condemn and dispose at the general support level.
D—	Repairable item. When beyond lower level repair capability, return to depot. Condemnation and disposal not authorized below depot level.
L—	Repairable item. Repair, condemnation, and disposal not authorized below depot/Specialized Repair Activity level.
A—	Item requires special handling or condemnation procedures because of specific reasons (i.e., precious metal content, high dollar value, critical material or hazardous material).

b. Federal Stock Number. Indicates the Federal stock number assigned to the item and will be used for requisitioning purposes.

c. Description. Indicates the Federal item name and a minimum description required to identify the

item. The last line indicates the reference number followed by the applicable Federal Supply Code for Manufacturer (FSCM) in parentheses. The FSCM is used as an element in item identification to designate manufacturer or distributor or Government agency, etc., and is identified in SB 708-42.

d. Unit of Measure (UIM). Indicates the standard or basic quantity by which the listed item is used in performing the actual maintenance function. This measure is expressed by a two-character alphabetical abbreviation; e.g., ea, in, pr, etc., and is the basis used to indicate quantities and allowances in subsequent columns. When the unit of measure differs from the unit of issue, the lowest unit of issue that will satisfy the required units of measure will be requisitioned.

e. Quantity Incorporated in Unit. This column indicates the quantity of the item used in the equipment. Subsequent appearances of the same item in the same assembly are indicated by the letters "REF".

f. 30-Day DS/GS Maintenance Allowances.

NOTE

Allowances in GS column are for GS maintenance only.

(1) The repair parts indicated by asterisk entries in separate allowance columns for GS represent those authorized for use at that category of maintenance to be requisitioned on an "as required" basis, until stockage is based on demand in accordance with AR 710-2.

(2) Allowance quantities are indicated in the special tool lists section for special tools, TMDE, and other support equipment.

g. 1-Year Allowances Per 100 Equipments/Contingency Planning Purposes. Column intentionally left blank

h. Depot Maintenance Allowance Per 100 Equipments. This column indicates opposite the first appearance of each item the total quantity authorized for depot maintenance of 100 equipments.

i. Illustration. This column is divided as follows:

(1) *Figure number.* Indicates the figure number of the illustration on which the item is shown in TM 11-6130-22745.

(2) *Item number.* Indicates the item number or reference designation used to reference the item in the illustration.

1-4. Special Information

a. Usable on codes are included in column 3. Uncoded items are applicable to all models. Identification of the usable *on codes* used in this publication are —

<i>Code</i>	<i>Used on</i>
A7C	PP-1660/G

Code
B29

Used on
PP-1660A/G

b. The following publications pertain to the equipment and its components:

TM 11-6130-227-20P	Organizational Maintenance Repair Parts and Special Tools Lists: Chargers, Battery PP-1660/G and PP-1660AG.
--------------------	---

TM 11-6130-227-45	Field (Fourth Echelon) and Depot Maintenance Manual: Charger, Battery PP-1660/G.
-------------------	--

1-5. Location of Repair Parts

a. This manual contains one cross-reference index (see IV) to be used to locate a repair part when either the Federal stock number or reference number (manufacturer's part number) is known. The first column in the index is prepared in numerical or alphanumeric sequence in ascending order. The reference numbers (manufacturer's part numbers) are listed immediately following the last listed Federal stock number in the index of Federal stock numbers.

b. When the Federal stock number or reference number is known, follow the procedures given in (1) and (2) below.

(1) Refer to the index of Federal stock numbers (see IV) and locate the Federal stock number or reference number. The FSN and reference number are cross-referenced to the applicable figure and item number or reference designation.

(2) Refer to the repair parts list (see II) and locate the figure number (col 10a and item number or reference designation (col 10b) as noted in the FSN index.

c. When the figure and item number or reference designation are known, scrutinize columns 10a and 10b of the repair parts list (sec II) until the item is located.

d. When the FSN, reference number, figure number, item number and reference designation are not known, scrutinize column 3 of the repair parts list (sec II), which is arranged in alphabetical order.

1-6. Abbreviations

Not applicable.

1-7. Reporting of Equipment Publication Improvements

The reporting of errors, omissions, and recommendations for improving this publication by the individual

user is encouraged. Reports should be submitted on DA Form 2028 (Recommended Changes to Publications) and forwarded direct to Commander, US Army

Electronics Command, ATTN: AMSEL-MA-TMDE,
Fort Monmouth, N.J., 07703.

SECTION II		TM11-6130-227-40P														
(1)	(2)	(3)	(4)	(5)	(6)			(7)			(8)	(9)	(10)			
SMR	FEDERAL	DESCRIPTION	UNIT	QTY	30-DAY DS MAINT			30-DAY GS MAINT			1-YR	DEPOT	ILLUSTRATION			
CODE	STOCK	REFERENCE NUMBER & MFR. CODE	OF	INC	ALLOWANCE	(A)	(B)	(C)	ALLOWANCE	(A)	(B)	(C)	ALW PER	MAINT	(A)	(B)
NUMBER	NUMBER		MEAS	IN	1-20	21-50	51-100	1-20	21-50	51-100	100	EQUIP	100	FIGURE	ITEM	
			USABLE CN CODE	UNIT	1-20	21-50	51-100	1-20	21-50	51-100	CNTGNCY	EQUIP	NO.	NO.	NO.	
PAHZZ	6625-078-7417	AMMETER M2 PANEL TYPE 0 TO 100 AMPS RANGE ME36M100SPECR (81349)		EA	1			*	*	*				3	3	10
PAHZZ	6625-877-6786	AMMETER M2 PANEL TYPE 0 TO 75 AMP RANGE 4-1/2 IN W X 3-3/8 IN H X 2 IN LG APPROX O/A 677-55 (82386)	B29	EA	1			*	*	*				3	3	10
PCHZZ	5340-813-9751	BUMPER, RUBBER H55 1-1/2 IN OD X 5/8 IN THK O/A 1019 (70485)	A7C	EA	4			*	*	*				10		H55
PCHZZ	5340-813-9751	BUMPER, RUBBER H56 1-1/2 IN OD X 5/8 IN THK O/A 1019 (70485)		EA	REF			*	*	*				10		H56
PCHZZ	5340-813-9751	BUMPER, RUBBER H57 1-1/2 IN OD X 5/8 IN THK O/A 1019 (70485)		EA	REF			*	*	*				10		H57
PCHZZ	5340-813-9751	BUMPER, RUBBER H58 1-1/2 IN OD X 5/8 IN THK O/A 1019 (70485)		EA	REF			*	*	*				10		H58
PAHZZ	5975-803-2536	BUSHING, STRAIN RELIEF CABLE MP6 NYLON 0.812 IN LG O/A SR8P1 (28520)		EA	3			*	*	*				3		MP6
PAHZZ	6145-283-9475	CABLE, POWER ELECTRICAL NO-REF-DESIG COND #14AWG 600V CO-03HG3-14-056* 0 (81349)	3			*	*	*			5					
PAHZZ	5925-884-0066	CIRCUIT BREAKER 4 100/220 VAC, 5 AMP 1.210 IN LG X 0.645 IN W X 0.567 IN H SB21 (82647)		EA	1			*	*	*				5	4	4
PAHZZ	5925-813-8258	CIRCUIT BREAKER 6 110V/220V AC 40 AMP 30VDC 2 IN LG X 1.189 IN W X 1.281 IN H O/A CLA40 (82647)		EA	2			*	*	*				5	4	6
PAHZZ	5925-813-8258	CIRCUIT BREAKER 7 110V/220V AC 40 AMP 30 VDC 2 IN LG X 1.189 IN W X 1.281 IN H O/A CLA40 (82647)	A7C	EA	REF			*	*	*				5	4	7
PAOZZ	5940-884-0094	CLIP, ELECTRICAL BATTERYCLIP ALLIGATOR TYPE 2 IN H X 5 IN LG X 1-1/16 IN W 11A (76545)	A7C	EA	2			*	*	*				3		P2
PAOZZ	5935-888-7319	CONNECTOR, PLUG, ELECTRICAL PLUGCONNECTOR 3 CONT 1-1/2 IN DIA X 1-5/8 IN LG O/A 5277 (74545)		EA	1			*	*	*				3		P1
PAOZZ	5935-201-8467	CONNECTOR, PLUG, ELECTRICAL P1 3 CONT 1-1/2 IN DIA X 1-5/8 IN LG O/A 15AMP, 125V 0.562 IN DIA O/A 5264 (74545)	A7C	EA	1			*	*	*				3		P1
PAHZZ	4140-815-2687	IMPELLER, FAN, AXIAL MP3 4 BLADES 6 IN DIA X 0.984 IN W SETSCREW MTD 587-105 (82386)	B29	EA	1			*	*	*				5	3	MP3
PAHZZ	4140-889-2430	IMPELLER, FAN, AXIAL MP3 MULTIBLADE TYPE FORWARD CURVED BLADE ALUMINUM ALLOY	A7C	EA	1			*	*	*				5	3	MP3

SECTION II		TM11-6130-227-40P												
(1)	(2)	(3)	(4)	(5)	(6)			(7)			(8)	(9)	(10)	
SMR	FEDERAL	DESCRIPTION	UNIT	QTY	30-DAY DS MAINT			30-DAY GS MAINT			1-YR	DEPOT	ILLUSTRATION	
CODE	STOCK	REFERENCE NUMBER & MFR. CODE	OF	INC	(A)	(B)	(C)	(A)	(B)	(C)	ALW PER	MAINT	(A)	(B)
NUMBER	NUMBER	CONTINUED	MEAS	UNIT	1-20	21-50	51-100	1-20	21-50	51-100	EQUIP	100	FIGURE	ITEM
											CNTGCTY	EQUIP	NO.	NO.
		SINGLE WIDTH 4 BLADES DESIGNED CW ROTATION												
		SMB57321 (80063)												
PAOZZ	5935-802-8046	JACK, TIP E6 P/O CABLE ASSEMBLY 2543-002 (82386)	B29	EA	1			*	*	*			2	E6
PAOZZ	5935-802-8048	JACK, TIP E2 P/O CABLE ASSEMBLY 2543-004 (82386)		EA	1			*	*	*			2	E2
PAOZZ	5355-813-9107	KNOB MP12 RD PHENOLIC 1-1/8 IN OD X 9/16 IN THK RB200 (86797)		EA	2			*	*	*			3	3 MP12
PAOZZ	5355-813-9107	KNOB MP12 RD PHENOLIC 1-1/8 IN OD X 9/16 IN THK RB200 (86797)	A7C	EA	REF			*	*	*			3	3 MP12
PAOZZ	5355-823-9888	KNOB MP11 RD PHENOLIC 1-5/8 IN OD X 7/8 IN THK 1901 (82386)	A7C	EA	1			*	*	*			3	3 MP11
PAHZZ	6105-823-3088	MOTOR, ALTERNATING CURRENT B1 115V 50/60 CYC SINGLE PH 1/7-5 HP 2 IN LG EXCL SHAFT X 2-3/6 IN W X 3-5/8 IN H FG1526 (61942)		EA	1			*	*	*			3	3 B1
PAHZZ	6105-059-8859	MOTOR, ALTERNATING CURRENT B1 115V, 60 CYC SINGLE PH	A7C	EA	1			*	*	*			3	3 2
PAOZZ	5310-804-2409	SMB57322 (80063)	B29	EA	1			*	*	*			3	H14
PAOZZ	5310-804-2410	NUT, SPECIAL H14 2558-002 (82386)		EA	1			*	*	*			3	H15
PAHZZ	5950-888-7293	NUT, SPECIAL H15 2558-001 (82386)		EA	1			*	*	*			2	4 L1
		REACTOR L1 FIXED INDUCTANCE TYPE 200V RMS 2.594 IN LG X 3.094 IN LG X 1.625 IN W 778-55 (82386)		EA	1			*	*	*			2	4 L1
PAHZZ	6130-823-3104	RECTIFIER, METALLIC CR1 SELENIUM 4 STACKS 1 PH FULL WAVE RECTIFICATION 5-312 IN LG X 5 IN W X 6 IN H 744-209 (82386)		EA	2			*	*	*			3	5 CR1
PAHZZ	6130-823-3104	RECTIFIER, METALLIC CR2 SELENIUM 4 STACKS 1 PH FULL WAVE RECTIFICATION 5-312 IN LG X 5 IN W X 6 IN H 744-209 (82386)		EA	REF			*	*	*			3	5 CR2
PAHZZ	5945-823-3085	RELAY, ARMATURE L1 DC 32V MAX 15 AMP NOMINAL CUT RATING 3.875 IN LG X 1.875 IN W X 2.219 IN H O/A 85722-14 (29326)		EA	1			*	*	*			3	4 L1
PAHZZ	5945-577-2010	RELAY, SOLENOID K2 SINGLE-THROW DOUBLE-BREAK NORMALLY OPEN 50 VDC 50 AMP RESISTIVE CUT RATING 3-1/2 IN LG X 2-19/64 IN W X 2-1/2 IN H 70-108224 (29326)		EA	5			*	*	*			3	4 K2
PAHZZ	5945-577-2010	RELAY, SOLENOID K3 SINGLE-THROW DOUBLE-BREAK NORMALLY OPEN 50 VDC 50 AMP RESISTIVE CUT RATING 3-1/2 IN LG X 2-CONTINUE		EA	REF			*	*	*			3	4

SECTION II		TM11-6130-227-40P												
(1)	(2)	(3)	(4)	(5)	(6)			(7)			(8)	(9)	(10)	
SMR	FEDERAL	DESCRIPTION	UNIT	QTY	30-DAY DS MAINT			30-DAY GS MAINT			1-YR	DEPOT	ILLUSTRATION	
CODE	STOCK		OF	INC	ALLOWANCE			ALLOWANCE			ALW PER	MAINT	(A)	(B)
NUMBER	NUMBER	REFERENCE NUMBER & MFR. CODE	MEAS	IN	(A)	(B)	(C)	(A)	(B)	(C)	100	100	FIGURE	ITEM
		CONTINUED		UNIT	1-20	21-50	51-100	1-20	21-50	51-100	CNTGNCY	EQUIP	NO.	NO.
		19/64 IN W X 2-1/2 IN H												
		70-108224 (29326)												
PAHZZ	5945-577-2010	RELAY, SOLENCID K4 SINGLE-THROW DOUBLE-BREAK NORMALLY OPEN 50 VDC 50 AMP RESISTIVE CUT RATING 3-1/2 IN LG X 2-19/64 IN W X 2-1/2 IN H	EA	REF	*	*	*					3	4	K4
		70-108224 (29326)												
PAHZZ	5945-577-2010	RELAY, SOLENCID K5 SINGLE-THROW DOUBLE-BREAK NORMALLY OPEN 50 VDC 50 AMP RESISTIVE CUT RATING 3-1/2 IN LG X 2-19/64 IN W X 2-1/2 IN H	EA	REF	*	*	*					3	4	K5
		70-108224 (29326)												
PAHZZ	5945-577-2010	RELAY, SOLENCID K6 SINGLE-THROW DOUBLE-BREAK NORMALLY OPEN 50 VDC 50 AMP RESISTIVE CUT RATING 3-1/2 IN LG X 2-19/64 IN W X 2-1/2 IN H	EA	REF	*	*	*					3	4	K6
		70-108224 (29326)												
PAHZZ	6625-045-9332	SHUNT, INSTRUMENT R1 EXTERNAL TYPE 50 MV, 100 AMPS DC	EA	1	*	*	*					2	4	5
		SMB35317 (80063)												
PAHZZ	625-892-5453	SHUNT, INSTRUMENT R1 EXT TYPE 50 MV 90 AMP DC 4.750 IN LG X 1.250 IN W X 1.750 IN THK	EA	1	*	*	*					2	4	5
		2604 (82386)												
PAHZZ	5930-899-7581	SWITCH, ROTARY S2 3 POSITION/NON PILE-UP TYPE 1-5/8 IN H X 1/2 IN LG O/A	EA	1	*	*	*					5	4	S2
		762-26 (82386)												
PAHZZ	5930-887-7582	SWITCH, ROTARY S1 5 POSITION/NON PILE-UP TYPE 1-3/4 IN LG X 2-1/4 IN DIA O/A	EA	1	*	*	*					5	4	S1
		2138-3 (82386)												
PAHZZ	6645-888-7278	TIMER, INTERVAL M1 115V 20 AMP 2.175 IN CD X 1-51/64 IN D O/A	EA	1	*	*	*					3	3	M1
		1550G11 (37266)												
PAHZZ	5950-888-7292	TRANSFORMER, POWER, STEP-DOWN T1 OPEN FRAME 115V 60 CYPS 1 PH AC PRI WND 20V CT 65 AMP SECD WND 5.687 IN H X 6.125 IN LG X 7.625 IN W O/A	EA	1	*	*	*					3	4	T1
		778-53 (82386)												
PAHZZ	6145-635-9460	WIRE, ELECTRICAL NO-REF-DESIG 1 #4 AWG 0.610 IN D	FT	11	*	*	*					2		
		CDQHFI-4-0610 (81349)												
PAZZZ	5940-884-0094	CLIP, ELECTRICAL BATTERYCLIP ALLIGATOR TYPE 2 IN H X 5 IN LG X 1-1/16 IN W	EA	2	*	*	*						1	P3
		11A(76545)												

INDEX - FEDERAL STOCK NUMBER AND REFERENCE NUMBER

CROSS-REFERENCE TO FIGURE AND ITEM NUMBER

STOCK NUMBER	FIGURE NO.	ITEM NO.	STOCK NUMBER	FIGURE NO.	ITEM NO.	REFERENCE NO.	MFR CODE	FIG. NO.	ITEM NO.
4140-815-2687	3	MP3	5945-577-2010	4	K2				
4140-889-2430	3	MP3	5945-577-2010	4	K3				
5310-804-2409		H14	5945-577-2010	4	K4				
5310-804-2410		H15	5945-577-2010	4	K5				
5340-813-9751		H55	5945-577-2010	4	K6				
5340-813-9751		H56	5945-823-3085	4	L1				
5340-813-9751		H57	5950-888-7292	4	T1				
5340-813-9751		H58	5950-888-7293	4	L1				
5355-813-9107	3	MP12	5975-803-2536		MP6				
5355-823-9888	3	MP11	6105-059-8859	3	2				
5925-813-8258	4	6	6105-823-3088	3	81				
5925-813-8258	4	7	6130-823-3104	5	CR1				
5925-884-0066	4	4	6130-823-3104	5	CR2				
5930-889-7582	4	S1	6145-283-9475						
5930-899-7581	4	S2	6145-635-9460						
5935-201-8467		P1	6625-045-9332	4	5				
5935-802-8046		E6	6625-078-7417	3	10				
5935-802-8048		E2	6625-877-6786	3	10				
5935-888-7319		P1	6625-892-5453	4	5				
5940-884-0094		P2P3	6645-888-7278	3	M1				
REFERENCE NO.	MFR CODE	FIG. NO.	ITEM NO.	REFERENCE NO.	MFR CODE	FIG. NO.	ITEM NO.		
CLA40	82647	4	6	2543-002	82386		E6		
CLA40	82647	4	7	2543004	82386		E2		
C0-03HGF3-14-0560	81349			2558-001	82386		H15		
COQ1HF1-4-0610	81349			2558-002	82386		H14		
FG1526	61942	3	B1	2604	82386	4	R1		
MR36W100SPECR	81349	3	10	5264	74545		P1		
RB200	86797	3	MP12	5277	74545		P1		
SB21	82647	4	4	587-105	82386	3	MP3		
SMB35317	80063	4	5	677-55	82386	3	10		
SMB357321	80063	3	MP3	70-108224	29326	4	K2		
SMB357322	80063	3	2	70-108224	29326	4	K3		
SR8P1	28520		MP6	70-108224	29326	4	K4		
1019	70485		H55	70-108224	29326	4	K5		
1019	70485		H56	70-108224	29326	4	K6		
1019	70485		H57	744-209	82386	5	CR1		
1019	70485		H58	744-209	82386	5	CR2		
11A	76545		P2P3	762-26	82386	4	S2		
1550G11	37266	3	M1	778-53	82386	4	T1		
1901	82386	3	MP11	778-55	82386	4	L1		
2138-3	82386	4	S1	85722-14	29326	4	L1		

By Order of the Secretary of the Army:

CREIGHTON W. ABRAMS
*General, United States Army
Chief of Staff*

Official:

VERNE L. BOWERS
*Major General, United States Army
The Adjutant General*

Distribution:

Active Army:

USASA (2)	USASESS (5)
CNGB (1)	USAINTCS (3)
ACSC-E (2)	USAADS (2)
Dir of Trans (1)	USAFAS (2)
COE (1)	USAARMS (2)
TSG (1)	USAIS (2)
USAARENBD (1)	USAES (2)
USAMB (10)	AD (1) except
AMC (1)	SAAD (30)
MICOM (2)	LBAD (14)
TECOM (2)	TOAD (14)
TRADOC (2)	ATAD (10)
ARADCOM (2)	USA Dep (2)
ARADCOM Rgn (2)	Sig Sec USA Dep (2)
OS Maj Comd (4)	Sig Dep (2)
LOGCOMD (3)	ATS (1)
USACC (4)	MAAG (1)
HISA (Ft Monmouth) (10)	WRAMC (1)
MDW (1)	USARMIS (1)
Armies (2)	USAERDAA (1)
Corps (2)	USAERDAW (1)
Ft Gordon (10)	Sig FLDMS (1)
Ft Huachuca (10)	Units org under fol TOE:
Ft Carson (5)	11-500 (AA-AC) (1)
Ft Richardson (ECOM Ofc) (2)	29-134 (1)
WSMR (1)	29-136 (1)
Svc Colleges (1)	

ARNG & USAR: None.

For explanation of abbreviations used, see AR 310-50.

★U.S. GOVERNMENT PRINTING OFFICE: 1992-311-831/44101

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS



THEN...JOT DOWN THE DOPE ABOUT IT ON THIS FORM. CAREFULLY TEAR IT OUT, FOLD IT AND DROP IT IN THE MAIL.

SOMETHING WRONG WITH PUBLICATION

FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS)

DATE SENT

PUBLICATION NUMBER

PUBLICATION DATE

PUBLICATION TITLE

BE EXACT PIN-POINT WHERE IT IS

PAGE NO.

PARA-GRAPH

FIGURE NO.

TABLE NO.

IN THIS SPACE, TELL WHAT IS WRONG AND WHAT SHOULD BE DONE ABOUT IT.

TEAR ALONG PERFORATED LINE

PRINTED NAME, GRADE OR TITLE AND TELEPHONE NUMBER

SIGN HERE

PIN : 020654-000