

TB 9-6625-2329-35

DEPARTMENT OF THE ARMY TECHNICAL BULLETIN

CALIBRATION PROCEDURE FOR SIGNAL GENERATOR

ROHDE AND SCHWARZ, MODEL 801.0001.43

Headquarters, Department of the Army, Washington, DC
27 November 2002

REPORTING OF ERRORS AND RECOMMENDING IMPROVEMENTS

You can improve this manual. If you find any mistakes or if you know of a way to improve these procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms) directly to Commander, U.S. Army Aviation and Missile Command, ATTN: AMSAM-MMC-MA-NP, Redstone Arsenal, AL 35898-5000. A reply will be furnished to you. You may also provide DA Form 2028 information to AMCOM via e-mail, fax, or the World Wide Web. Our FAX number is: DSN 788-6546 or Commercial 256-842-6546. Our e-mail address is: 2028@redstone.army.mil. Instructions for sending an electronic 2028 may be found at the back of this manual. For the World Wide Web, use: <https://amcom2028.redstone.army.mil>.

Approved for public release; distribution is unlimited.

SECTION		Paragraph	Page
I.	IDENTIFICATION AND DESCRIPTION		
	Test instrument identification	1	2
	Forms, records, and reports.....	2	2
	Calibration description.....	3	2
II.	EQUIPMENT REQUIREMENTS		
	Equipment required.....	4	4
	Accessories required.....	5	4
III.	CALIBRATION PROCESS		
	Preliminary instructions.....	6	5
	Equipment setup	7	6
	Frequency accuracy.....	8	7
	RF output and flatness.....	9	9
	Attenuation	10	12
	Spectral purity.....	11	14
	Modulation generator	12	16
	Amplitude modulation	13	19
	Phase modulation.....	14	23
	Frequency modulation.....	15	26
	Pulse modulation.....	16	28
	Final procedure	17	32

**SECTION I
IDENTIFICATION AND DESCRIPTION**

1. Test Instrument Identification. This bulletin provides instructions for the calibration of Signal Generator, Rhode & Schwarz Model 801.0001.43. The manufacturer’s manual was used as the prime data source in compiling these instructions. The equipment being calibrated will be referred to as the TI (test instrument) throughout this bulletin.

a. Model Variations. None.

b. Time and Technique. The time required for this calibration is approximately 6 hours, using the dc and low frequency and microwave technique.

2. Forms, Records, and Reports. Forms, records, and reports required for calibration personnel at all levels are prescribed by TB 750-25.

3. Calibration Description. TI parameters and performance specifications which pertain to this calibration are listed in table 1.

Table 1. Calibration Description

Test instrument parameters	Performance specifications
Frequency	Range: 100 kHz to 1000 MHz Accuracy: RF > 31.25 MHz ($\pm 0.5 \times 10^{-9}$) + ref. error Accuracy: RF < 31.25 MHz (± 0.1 Hz + ref. error.) Time base stability: $\pm 1 \times 10^{-9}$ per day
RF output	Range: 13 dBm Accuracy: ± 1.5 dB Flatness range: 100 kHz to 1000 MHz Accuracy: <1 dB at 0 dBm Attenuation (interrupted) ¹ Range: 0 to 120 dB Accuracy: ± 1.5 dB Attenuation (non-interrupted) Range: 0 to 20 dB Accuracy: ± 0.2 dB at -5 dB. ± 0.5 dB at -10 dB ± 0.5 dB at -15 dB ± 0.5 dB at -20 dB
Spectral purity	Harmonics Range: 100 kHz to 1000 MHz: Accuracy <-30 dBc Spurious signal range: 100 kHz to 31.25 MHz Accuracy <-70 dBc 31.25 MHz to 250 MHz <-80 dBc 250 MHz to 1000 MHz <-70 dBc

See footnote at end of document.

Table 1. Calibration Description - Continued

Test instrument parameters	Performance specifications
Pulse modulation	Pulse rate: Dc to 10 MHz Pulse envelope on/off ratio: Pulse range: 100 kHz to 500 MHz Accuracy: >70 dB Pulse range: 500 MHz to 1000 MHz Accuracy: >50 dB
Amplitude modulation	Frequency range: 100 kHz to 1000 MHz Depth: 0 to 99% Accuracy: $\pm 4\%$ of setting +1% Distortion: <1%, 0 to 30% depth, 1 kHz rate <2%, 30 to 80% depth, 1 kHz rate Incidental PM: <0.20 Radians (30% AM depth at 1 kHz mod. frequency) Modulated Frequency Response ² Range: 30 Hz to 10 kHz Accuracy: < 0.4 dB 10 Hz to 50 kHz Accuracy: < 1.0 dB
Frequency modulation	Deviation range: Modulating rate ³ ≤ 400 kHz (.01 to 31.25 MHz) between 10 Hz and ≤ 100 kHz (31.25 to 62.5 MHz) 100 kHz ≤ 200 kHz (62.5 to 125 MHz) ≤ 400 kHz (125 to 250 MHz) ≤ 800 kHz (250 to 500 MHz) ≤ 1600 kHz (500 to 1000 MHz) ≤ 3200 kHz (1000 MHz and above) Accuracy: $\pm(5\%$ of setting + 20 Hz) Incidental AM: <0.1% (>1 MHz carrier, 40 kHz deviation, 1 kHz rate) Distortion: $\leq 0.5\%$ for 50% deviation at 1 kHz rate Modulation frequency response ⁴ Range: 20 Hz to 100 kHz Accuracy: < 0.5 dB
Phase modulation	Deviation range 20 radians, 100 kHz to 31.25 MHz 5 radians, 31.25 to 62.5 MHz 10 radians, 62.5 to 125 MHz 20 radians, 125 to 250 MHz 40 radians, 250 to 500 MHz 80 radians, 500 to 1000 MHz Accuracy: +(5% of setting + 0.1 radians) Distortion: <0.5% at 1 kHz rate (50% maximum deviation) External modulation frequency response ⁵ Range: 10 Hz to 10 kHz Accuracy: <1.0 dB

See footnote at end of table.

Table 1. Calibration Description - Continued

Test instrument parameters	Performance specifications
Modulation generator	Frequency range: 10 Hz to 100 kHz Accuracy: ± 40 PPM Level range: 2 mV to 2 V Accuracy: $\pm 1\% + 1$ mV Frequency response range: Accuracy: 10 Hz to 20 kHz $\pm 2.5\%$ 20 Hz to 100 kHz $\pm 3.5\%$ Distortion: >0.5 V level Accuracy: $<0.1\%$ (10 Hz to 100 kHz)

¹Verified to -110 dB.

²Verified from 30 Hz to 50 kHz.

³Verified to 400 kHz dev.

⁴Verified from 30 Hz to 50 kHz.

⁵Verified from 300 Hz to 5 kHz.

SECTION II EQUIPMENT REQUIREMENTS

4. Equipment Required. Table 2 identifies the specific equipment to be used in this calibration procedure. This equipment is issued with Secondary Transfer Calibration Standards Set AN/GSM-287. Alternate items may be used by the calibrating activity. The items selected must be verified to perform satisfactorily prior to use and must bear evidence of current calibration. The equipment must meet or exceed the minimum use specifications listed in table 2. The accuracies listed in table 2 provided a four-to-one ratio between the standard and TI. Where the four-to-one ratio cannot be met, the actual accuracy of the equipment is shown in parenthesis.

5. Accessories Required. The accessories required for the calibration are common usage accessories, issued as indicated in paragraph 4 above, and are not listed in this calibration procedure.

Table 2. Minimum Specifications of Equipment Required

Common name	Minimum use specifications	Manufacturer and model (part number)
AUDIO ANALYZER	Frequency: 10 Hz to 100 kHz Distortion capability: $\leq 0.1\%$	Boonton, Model 1120-S/10 (MIS-35954/2)
ELECTRONIC COUNTER	Frequency: 10 Hz to 1000 MHz Accuracy: ± 1.25 part in 10^{10}	John Fluke, Model PM 6681/656 (6681/656)
FREQUENCY DIFFERENCE METER	Range capability: 1 part in 10^9	Tracor, Model 527E (MIS-10318)
MEASURING RECEIVER	Power measurement: Frequency: 100 kHz to 1000 MHz Level: +13 dB to -110 dB Accuracy: $+0.375$ dB Flatness measurement: Frequency: 100 kHz to 1000 MHz Level: 0 dBm Accuracy: ± 0.25 dB	Hewlett-Packard, Model 8902A (8902A) w/sensors, Hewlett-Packard, Model 11722A (11722A) and 11792A (11792A), Hewlett-Packard, Model 11793A (11793A), Hewlett-Packard Model 8673M (SG1219).

Table 2. Minimum Specifications of Equipment Required

Common name	Minimum use specifications	Manufacturer and model (part number)
MULTIMETER	Voltage measurement: Frequency: 10 Hz to 100 kHz Level: 2 V to 2 mV ac Accuracy: $\pm 0.25\%$	Hewlett-Packard, Model 3458A (3458A)
PULSEGENERATOR	Amplitude: 5 V Period: 10 ms Width: 5 ms	LeCroy, Model 9210 (9210) w/plug-ins, models 9211 (9211) and 9215 (9215)
SPECTRUMANALYZER	Harmonics measurement: Frequency: 100 kHz to 1000 MHz Level: 13 to -80 dB Accuracy: < -80 dB	(AN/USM-489A)
TIME/FREQUENCY WORKSTATION	Frequency: 1 MHz Accuracy: ± 2.5 part in 10^{11}	Autek Systems Corp., Model 620 (MIS-38946)

SECTION III CALIBRATION PROCESS

6. Preliminary Instructions

a. The instructions outlined in paragraphs **6** and **7** are preparatory to the calibration process. Personnel should become familiar with the entire bulletin before beginning the calibration.

b. Items of equipment used in this procedure are referenced within the text by common name as listed in table 2.

c. Unless otherwise specified, verify the result of each test and, whenever the test requirement is not met, take corrective action before continuing with the calibration. Adjustments required to calibrate the TI are included in this procedure. Additional maintenance information is contained in manufacture manual for this TI.

d. When indications specified in paragraphs **7** through **16** are not within tolerance, perform the power supply check prior to making adjustments. After adjustments are made, repeat paragraphs **7** through **16**. Do not perform power supply check if all other parameters are within tolerance.

e. Unless otherwise specified, all controls and control settings refer to the TI.

7. Equipment Setup

WARNING

HIGH VOLTAGE is used or exposed during the performance of this calibration. DEATH ON CONTACT may result if personnel fail to observe safety precautions. REDUCE OUTPUT(S) to minimum after each step within the performance check.

NOTE

Before connecting TI, the protective earth terminal of the instrument must be connected to the protective conductor of the line power cord. The line plug shall only be inserted in a socket outlet provided with a protective earth contact. The protective action must not be negated by the use of an extension cord (power cable) without a protective conductor (grounding). Grounding one conductor of a two-conductor outlet is not sufficient protection.

NOTE

When indications specified in this procedure are not within tolerance, perform the power supply check prior to making adjustments.

CAUTION

Before connecting TI to power source, make sure TI is set to the power source line voltage as shown on rear of TI.

- a.. Connect TI to a 115 V ac source.
- b. Set **POWER** switch to **ON** and allow at least 1 hour for TI to warm up and stabilize.
- c. Connect equipment as shown in figure 1 below:




Figure 1. Internal oscillator stability.

- d. In figure 2 adjust **REF FREQ 10 MHz** for minimum drift indication on the frequency difference meter.
- e. Check frequency drift after 24 hours. The drift will be less than ± 1 part in 10^9 .
- f. Disconnect frequency difference meter from TI and time/frequency workstation.




Figure 2. 10 MHz REF FREQ adjust.

8. Frequency Accuracy

a. Performance Check

- (1) Connect equipment as shown in figure 3 below:




Figure 3. Frequency accuracy.

- (2) Set up electronic counter controls to measure frequency with 50Ω input.
- (3) Press pushbuttons as listed in (a) through (f) below:
 - (a) **SHIFT- INSTR PRESET.**
 - (b) **PARAMETER- RF.**
 - (c) **ON/OFF- EXT AC.**
 - (d) **PARAMETER- LEVEL.**
 - (e) **DATA- 0.**
 - (f) **ENTER/UNITS- dBm.**
- (4) Press TI **PARAMETER-RF** pushbutton, enter **DATA** numerical value, and press **ENTER/UNITS MHz** key for each row in table 3. Electronic counter will indicate within the limits specified.

Table 3. Frequency

Test instrument DATA and ENTER/UNITS (MHz)	Frequency counter indications (MHz)	
	Min	Max
10	9.999999	10.000001
60	59.999999	60.000001
90	89.999999	90.000001
150	149.999999	150.000001

- (5) Press **PARAMETER- LEVEL** pushbutton and press **ON/OFF-OFF** key.
- (6) Disconnect TI **RF 50W** output at electronic counter **A** input.
- (7) Connect TI **RF 50W** output to electronic counter **C** input.
- (8) Set electronic counter to **C** input.
- (9) Press **PARAMETER- LEVEL** pushbutton and press **ON/OFF-INT ON** key.

(10) Press TI **PARAMETER-RF**, enter **DATA** numerical value, and **ENTER/UNITS MHz** key for each row in table 4. Frequency will indicate within limits specified.

Table 4. Frequency

Test instrument DATA and ENTER/UNITS (MHz)	Frequency counter indications (MHz)	
	Min	Max
400	399.999999	400.000001
700	699.999999	700.000001
1000	999.999999	1000.000001

(11) Press **PARAMETER- LEVEL** pushbutton and press **ON/OFF-OFF** key.

(12) Disconnect TI **RF 50W** from electronic counter.

b. Adjustments. No adjustments can be made.

9. RF Output and Flatness

a. Performance Check

(1) Set measuring receiver pushbuttons as listed in (a) through (e) below:

(a) Connect sensor module (11722A) to measuring receiver. Zero, calibrate, and save sensor values as necessary.

(b) **INSTR PRESET.**

(c) **LOG/LIN** to **LOG.**

(d) Enter **32.0 SPCL** (0.01 dB resolution).

(e) Connect sensor module (11722A) input to TI **RF 50W.**

(2) Perform pushbutton steps as listed in (a) through (d) below:

(a) **SHIFT- INSTR PRESET.**

(b) **PARAMETER-RF.**

(c) **DATA-100.**

(d) **ENTER/UNITS- MHz.**

(3) Press TI **PARAMETER-LEVEL** pushbutton, enter **DATA** numerical value, and press **ENTER/UNITS dBm** key for each row in table 5. Using measuring receiver and RF power measurement techniques, measured power will indicate within limits specified.

Table 5. RF Output

Test instrument DATA and ENTER/UNITS (dBm)	Measuring receiver indications (dBm)	
	Min	Max
13	11.5	14.5
0	-1.5	1.5

(4) Press TI **PARAMETER-RF** pushbutton, enter **DATA** numerical value, and press **ENTER/UNITS** frequency key for each row in table 6. Measure and record the RF power using the measuring receiver.

(5) Calculate the flatness using the formula below. The flatness will be less than the maximum limits listed in table 6.

FORMULA

$$\text{Flatness} = (\text{highest reading} - \text{lowest reading})/2$$

Table 6. Output Level Flatness


Test instrument DATA and ENTER/UNITS MHz	Measuring receiver indications	
	Reading (dB)	Maximum limit <(dB)
.1		1
.2		1
.3		1
.4		1
.5		1
.6		1
.7		1
.8		1
.9		1
1		1
2		1
3		1
4		1
5		1
6		1
7		1
8		1
9		1
10		1
20		1
30		1
40		1
50		1

Table 6. Output Level Flatness- Continued

Test instrument DATA and ENTER/UNITS (MHz)	Measuring receiver indications	
	Reading (dB)	Maximum limit <(dB)
60		1
70		1
80		1
90		1
100		1
200		1
300		1
400		1
500		1
600		1
700		1
800		1
900		1
1000		1

b. Adjustments

- (1) Press **SHIFT- INSTR PRESET** pushbuttons, **PARAMETER-LEVEL** pushbutton, then press **ON/OFF-OFF** key.
- (2) Remove top cover.
- (3) Press pushbuttons as listed in (a) through (f) below:
 - (a) **PARAMETER- RF.**
 - (b) **DATA- 100.**
 - (c) **ENTER/UNITS-MHz.**
 - (d) **PARAMETER-LEVEL.**
 - (e) **DATA-0.**
 - (f) **ENTER/UNITS-dBm.**
- (4) Adjust R514 (fig. 4) for a 0 ± 0.1 dBm power indication (R).



**TEST INSTRUMENT
TOP VIEW**

Figure 4. Adjustment locations.

TB 9-6625-2329-35

(5) Press TI **PARAMETER–RF** pushbutton, enter **DATA 8** numerical value, and press **ENTER/UNITS MHz** key.

(6) Using measuring receiver RF power measurement techniques, measure RF power and set **RATIO** on.

(7) Press TI **PARAMETER–RF** pushbutton, enter **DATA 7.999** numerical value and press **ENTER/UNITS MHz** key.

(8) Using measuring receiver, set tune receiver to 7.999 MHz and measure RF power.

(9) Adjust R641 (fig. 4) for a 0.00 ± 0.05 dBm power indication (R) on measuring receiver.

(10) Press **SHIFT-INSTR PRESET** pushbuttons, **PARAMETER–LEVEL** pushbutton, and press **ON/OFF–OFF** key.

(11) Replace top cover.

10. Attenuation

a. Performance Check

(1) Ensure measuring receiver, sensor module (11722A) input is connected to TI **RF 50W**.

NOTE

On measuring receiver zero, calibrate, and save sensor values as necessary.

(2) Using measuring receiver with sensor module (11722A), press **SHIFT- INSTR PRESET** pushbuttons.

(3) Perform pushbutton steps as listed in (a) through (d) below:

(a) **SHIFT-INSTR PRESET**.

(b) **PARAMETER–RF**.

(c) **DATA–30**.

(d) **ENTER/UNITS–MHz**.

(4) Press measuring receiver pushbuttons as listed in (a) through (d) below:

(a) **AUTOMATIC OPERATION**.

(b) **RF POWER**.

(c) **LOG/LIN** to **LOG**.

(d) Enter **32.0 SPCL** (0.01 dB resolution).

(5) Press TI **PARAMETER–LEVEL** pushbutton, enter **DATA** numerical value and press **ENTER/UNITS dBm** key for each row in table 7. Using measuring receiver and RF power measurement techniques, measured power will indicate within limits specified.

Table 7. RF Attenuator Accuracy

Test instrument DATA and ENTER/UNITS (dBm)	Measuring receiver indications (dBm)	
	Min	Max
0	-1.5	+1.5
10	8.5	11.5
13	11.5	14.5

(6) Press TI **PARAMETER-LEVEL** pushbutton, enter **DATA 0** numerical value and press **ENTER/UNITS dBm** key.

(7) Press measuring receiver pushbuttons as listed in (a) through (d) below:

- (a) **FREQ.**
- (b) **TUNED RF LEVEL** power.
- (c) **CALIBRATE.**
- (d) **SHIFT- SET REF.**

(8) Press TI **PARAMETER-LEVEL** pushbutton, enter **DATA** numerical value, and press **ENTER/UNITS dBm** key for each row in table 8. Using measuring receiver and RF power measurement techniques, measured power will indicate within limits.

NOTE

RECAL (CALIBRATE) as necessary.

Table 8. RF Attenuator Accuracy (Interrupted)

Test instrument DATA and ENTER/UNITS (dBm)	Measuring receiver indications (dBm)	
	Min	Max
-10	-8	-12
-20	-18	-22
-30	-28	-32
-40	-38	-42
-50	-48	-52
-60	-58	-62
-70	-68	-72
-80	-78	-82
-90	-88	-92
-100	-98	-102
-110	-108	-112

(9) Press TI **PARAMETER-LEVEL** pushbutton, enter **DATA 0** numerical value and press **ENTER/UNITS dBm** key.

(10) Press measuring receiver pushbuttons as listed in (a) through (e) below:

- (a) **SHIFT- INSTR PRESET.**
- (b) **TUNED RF LEVEL** power.

TB 9-6625-2329-35

- (c) **LOG/LIN** to **LOG**.
- (d) **CALIBRATE**.
- (e) **SHIFT- SET REF**.

(11) Adjust controls as listed in (a) through (c) below:

(a) Press **SHIFT- PARAMETER-SPECIAL** pushbutton, enter **DATA 1** numerical value, and press **ENTER/UNITS dBm** key.

(b) Press **PARAMETER- LEVEL** pushbutton, **PARAMETER- STEP** pushbutton, enter **DATA 5** numerical value, and press **ENTER/UNITS dBm** key.

(c) Press **VARIATION-STEP** key.

(12) Press TI **VARIATION- STEP** β pushbutton for each row in table 9. Using measuring receiver and tuned RF power measurement techniques, measured power will indicate within limits specified.

NOTE

RECAL (CALIBRATE) as necessary.

Table 9. RF Attenuator Accuracy (Non-interrupted)

Test instrument VARIATION STEP (dBm)	Measuring receiver indications (dBm)	
	Min	Max
-5	-4.8	-5.2
-10	-9.5	-10.5
-15	-14.5	-15.5
-20	-19.5	-20.5

(13) Press **SHIFT- INSTR PRESET** pushbuttons, **PARAMETER- LEVEL** pushbutton, and press **ON/OFF- OFF** key.

(14) Press measuring receiver **SHIFT-INSTR PRESET** pushbutton.

(15) Disconnect measuring **SENSOR MODULE** from TI **RF 50W**.

b. Adjustments. No adjustments can be made.

11. Spectral Purity

a. Performance Check

(1) Connect equipment as shown in figure 5.




Figure 5. Spectral purity.

- (2) Press **SHIFT- INSTR PRESET** pushbuttons.
- (3) Adjust controls as listed in (a) through (c) below for each row in table 10 below.
 - (a) Press TI **PARAMETER-RF** pushbutton, enter **DATA** numerical value, and press **ENTER/UNITS MHz** key.
 - (b) Press TI **PARAMETER- LEVEL** pushbutton, enter **DATA** numerical value and press **ENTER/UNITS dBm** key.
 - (c) Set spectrum analyzer to TI frequency, set power reference then tune to harmonic frequency listed. Power amplitude will be less than dBc specified limit.

NOTE

Some spurious signals may be generated by the spectrum analyzer. If a spurious signal is present, change TI frequency. If it disappears, it most likely is from the TI. If the spurious signal moves with the TI frequency it most likely is in the spectrum analyzer.

Table 10. Spectral Purity

Test instrument		Spectrum analyzer indications	
DATA and ENTER/UNITS (dBm)	DATA and ENTER/UNITS (MHz)	Harmonic frequency (MHz)	(dBc)
13	.1	.2	<-30
13	.500	1	<-30
13	1	2	<-30
13	2	4	<-30
13	4	8	<-30
13	10	20	<-30
13	32	64	<-30
13	125	250	<-30
13	375	750	<-30
13	500	1000	<-30
13	1000	2000	<-30

TB 9-6625-2329-35

(4) Adjust controls as listed in (a) through (c) below for each row in table 11 below:

- (a) Press TI **PARAMETER-RF** pushbutton, enter **DATA** numerical value, and press **ENTER/UNITS MHz** key.
- (b) Press TI **PARAMETER-LEVEL** pushbutton, enter **DATA** numerical value, and press **ENTER/UNITS dBm** key.
- (c) Set spectrum analyzer to TI frequency; set power reference, then tune to harmonic frequency listed. Power amplitude will be less than dBc specified limit.

Table 11. Spurious Signals

Test instrument		Spectrum analyzer indications	
DATA and ENTER/UNITS (dBm)	DATA and ENTER/UNITS (MHz)	Harmonic frequency (MHz)	(dBc)
0	31	26	<-70
0	31	57	<-70
0	31	150	<-70
0	31	181	<-70
0	195	150	<-80
0	195	169	<-80
0	988	741	<-70
0	988	962	<-70
0	988	988.1	<-70

- (5) Press **PARAMETER-LEVEL** pushbutton and press **ON/OFF-OFF** key.
- (6) Disconnect all TI connections from spectrum analyzer.

b. Adjustments. No adjustments can be made.

12. Modulation Generator

a. Performance Check

- (1) Connect equipment as shown in figure 6.




Figure 6. Modulation generator accuracy.

- (2) Press **SHIFT- INSTR PRESET** pushbutton.
- (3) Set up multimeter to measure ac voltage.
- (4) Press **SHIFT- PARAMETER-SPECIAL** pushbutton, enter **DATA 5** numerical value, and press **ENTER/UNITS mV** key.
- (5) Press **PARAMETER- LEVEL** pushbutton, enter **DATA 1000** numerical value, and press **ENTER/UNITS mV** key.
- (6) Press TI **PARAMETER-AF** pushbutton, enter **DATA** numerical value, and press **ENTER/UNITS Hz** key for each row in table 12. Using multimeter and ac voltage measurement techniques, multimeter will be between specified limits.

Table 12. Frequency Response

Test instrument DATA and ENTER/UNITS (Hz)	Multimeter indications (ac V)	
	Min	Max
10	.975	1.025
60	.975	1.025
150	.975	1.025
400	.975	1.025
1000	.975	1.025
7000	.975	1.025
10000	.975	1.025
19200	.975	1.025
25000	.965	1.035
76800	.965	1.035
99900	.965	1.035

(7) Press **PARAMETER-AF** pushbutton, enter **DATA 1** numerical value, and press **ENTER/UNITS kHz** key.

(8) Press TI **PARAMETER-LEVEL** pushbutton, enter **DATA** numerical value, and press **ENTER/UNITS mV** key for each row in table 13. Using multimeter and ac voltage measurement techniques, multimeter will be between specified limits.

Table 13. Level Accuracy

Test instrument DATA and ENTER/UNITS (mV)	Multimeter indications at 1 kHz (ac V)	
	Min	Max
2	.00098	.00302
6	.00494	.00706
18	.01682	.01918
36	.03464	.03736
64	.06236	.06564
100	.98	.102

Table 13. Level Accuracy - Continued

Test instrument DATA and ENTER/UNITS (mV)	Multimeter indications at 1 kHz (ac V)	
	Min	Max
130	.1277	.1323
290	.2861	.2939
550	.5435	.5565
1000	.989	1.011
1200	1.187	1.213
1500	1.484	1.516
1750	1.7315	1.7685
2000	1.979	2.021

- (9) Press **PARAMETER-LEVEL** pushbutton and press **ON/OFF-OFF** key.
- (10) Disconnect TI **AF INT** from multimeter.
- (11) Connect TI **AF INT** to audio analyzer **INPUT HIGH**.
- (12) Set up audio analyzer to measure distortion.
- (13) Press **PARAMETER-LEVEL** pushbutton, enter **DATA 1000** numerical value, and press **ENTER/UNITS mV** key.
- (14) Press TI **PARAMETER-AF** pushbutton, enter **DATA** numerical value, and press **ENTER/UNITS kHz** for each row in table 14. Distortion analyzer will indicate within limits.

Table 14. Modulation Generator Distortion

Test instrument DATA and ENTER/UNITS (kHz)	Audio analyzer distortion indications (<%)
1	0.1
19.2	0.1
99.9	0.1

- (15) Press **PARAMETER-LEVEL** pushbutton and press **ON/OFF-OFF** key.
- (16) Disconnect TI **AF INT** audio analyzer **INPUT HIGH**.
- (17) Connect TI **AF INT** to frequency counter **CHANNEL A** input.
- (18) Set up frequency counter to measure frequency.
- (19) Press **PARAMETER-LEVEL** pushbutton, enter **DATA 1000** numerical value, and press **ENTER/UNITS mV** level key.
- (20) Press TI **PARAMETER-AF** pushbutton, enter **DATA** numerical value, and press **ENTER/UNITS Hz** key for each row in table 15. Frequency counter will indicate within limits listed.

Table 15. Frequency Range

Test instrument DATA and ENTER/UNITS (Hz)	Frequency counter indications (Hz)	
	Min	Max
10	9.9996	10.0004
60	59.9976	60.0024
150	149.994	150.006
400	399.984	400.016
1000	999.96	1000.04
7000	6999.72	7000.28
10000	9999.6	10000.4
19200	19199.232	19200.768
25000	24999	25001
76800	76796.928	76803.072
99900	99896.004	99903.996

- (21) Press **PARAMETER-LEVEL** pushbutton and press **ON/OFF-OFF** key.
- (22) Disconnect TI from frequency counter.

b. Adjustments. No adjustments can be made.

13. Amplitude Modulation

a. Performance Check

- (1) Connect equipment as shown in figure 7.




Figure 7. AM modulation.

- (2) Press **SHIFT- INSTR PRESET** pushbutton.
- (3) Press pushbuttons on measuring receiver as listed in (a) through (f) below:

TB 9-6625-2329-35

- (a) **SHIFT- INSTR PRESET.**
 - (b) **AM.**
 - (c) **PEAK +.**
 - (d) **300 Hz** high-pass filter.
 - (e) **15 kHz** low-pass filter.
 - (f) **FM** de-emphasis (off).
- (4) Initiate audio analyzer and set to measure percent distortion.
- (5) Press **PARAMETER-AF** pushbutton, enter **DATA 1** numerical value, and press **ENTER/UNITS kHz** key.
- (6) Press **PARAMETER-LEVEL** pushbutton, enter **DATA 0** numerical value, and press **ENTER/UNITS dBm** key.
- (7) Adjust controls as listed in (a) through (c) below for each row in table 16 below:
- (a) Press TI **PARAMETER-RF** pushbutton, enter **DATA** numerical value and press **ENTER/UNITS MHz** key.
 - (b) Press TI **PARAMETER-AM** pushbutton, enter **DATA** numerical value, and press **ENTER/UNITS %** key.
 - (c) Using measuring receiver and AM modulation measurement techniques, modulation will be between specified limits.

Table 16. AM Accuracy

Test instrument		Measuring receiver modulation indications (%)	
DATA and ENTER/UNITS (MHz)	DATA and ENTER/UNITS (%)	Min	Max
1	30	27.8	32.2
1	80	75.8	84.2
10	30	27.8	32.2
10	80	75.8	84.2
100	30	27.8	32.2
100	80	75.8	84.2
1000	30	27.8	32.2
1000	80	75.8	84.2

- (8) Adjust controls as listed in (a) through (c) below for each row in table 17 below:
- (a) Press TI **PARAMETER-RF** pushbutton, enter **DATA** numerical value, and press **ENTER/UNITS MHz** key.
 - (b) Press TI **PARAMETER-AM** pushbutton, enter **DATA** numerical value, and press **ENTER/UNITS %** key.
 - (c) Using audio analyzer and distortion measurement techniques, distortion will be between specified limits.

Table 17. Distortion Accuracy

Test instrument		Audio analyzer distortion indications (<%)
DATA and ENTER/UNITS (MHz)	DATA and ENTER/UNITS (%)	
1	30	1
1	80	2
10	30	1
10	80	2
100	30	1
100	80	2
1000	30	1
1000	80	2

(9) Press **PARAMETER-AM** pushbutton, enter **DATA 30** numerical value, and press **ENTER/UNITS %** key.

(10) Set measuring receiver to measure **fM**.

(11) Press TI **PARAMETER-RF** pushbutton, enter **DATA** numerical value, and press **ENTER/UNITS MHz** key for each row in table 18. Measuring receiver will indicate within limits specified.

Table 18. Incidental PM

Test instrument DATA and ENTER/UNITS (MHz)	Measuring receiver modulation indications (<rad)
4	0.2
100	0.2
400	0.2
1000	0.2

(12) Press pushbuttons as listed in (a) through (c) below:

(a) **PARAMETER-RF**, enter **DATA 100** numerical value, and press **ENTER/UNITS MHz** key.

(b) **PARAMETER-AM**, enter **DATA 80** numerical value, and press **ENTER/UNITS %** key.

(c) **PARAMETER-AM** and press **ON/OFF-EXT AC** key.

(13) Set up measuring receiver to measure **AM** with all filters off.

(14) Press pushbuttons on audio analyzer as listed in (a) through (e) below:

(a) Source **FREQ - 30 Hz**.

(b) Source **LEVEL - 1 V**.

TB 9-6625-2329-35

- (c) Source-600Ω (SPCL 77).
- (d) Analyzer **LEVEL-dB**.
- (e) Analyzer **RATIO**.

(15) Set up audio analyzer source frequency for each row in table 19. Audio analyzer will indicate within limits specified.

Table 19. Ext Modulation Frequency Response

Audio analyzer source frequency (Hz)	Audio analyzer indications (dB)	
	Min	Max
100	-0.4	+0.4
1000	-0.4	+0.4
2000	-0.4	+0.4
5000	-0.4	+0.4
10000	-0.4	+0.4
20000	-1	+1
50000	-1	+1

(16) Reduce output on audio analyzer.

b. Adjustments

- (1) Remove TI top cover.
- (2) Press pushbuttons as listed in (a) through (e) below:

(a) **PARAMETER-RF**, enter **DATA 100** numerical value, and press **ENTER/UNITS MHz** key.

(b) **PARAMETER-LEVEL**, enter **DATA 0** numerical value, and press **ENTER/UNITS dBm** key.

(c) **PARAMETER-AF**, enter **DATA 1** numerical value, and press **ENTER/UNITS kHz** key.

(d) **PARAMETER-AM**, enter **DATA 80** numerical value, and press **ENTER/UNITS %** key.

(e) **PARAMETER-AM** and press **ON/OFF-INT/ON** key.

(3) Press pushbuttons on measuring receiver as listed in (a) through (e) below:

(a) **SHIFT-INSTR PRESET**.

(b) **AM**

(c) **PEAK +**.

(d) **300 Hz** high pass filter.

(e) **15 kHz** low pass filter.

(f) **FM de-emphasis** (off).

(4) Adjust R503 (fig.4) for a 80 ±1% indication (R).

- (5) Press **PARAMETER- LEVEL** pushbutton and press **ON/OFF- OFF** key.

14. Phase Modulation

a. Performance Check

- (1) Connect equipment as shown in figure 8.




Figure 8. PM modulation.

- (2) Press **SHIFT- INSTR PRESET** pushbutton.
- (3) Press pushbuttons on measuring receiver as listed in (a) through (d) below:
- SHIFT- INSTR PRESET.**
 - F M.**
 - PEAK +.**
 - 300 Hz** high pass filter.
 - 15 kHz** low pass filter.
- (4) Initiate audio analyzer and set to measure percent distortion.
- (5) Press pushbuttons as listed in (a) through (e) below:
- PARAMETER-RF**, enter **DATA 15** numerical value, and press **ENTER/UNITS MHz** key.
 - PARAMETER- LEVEL**, enter **DATA 0** numerical value, and press **ENTER/UNITS dBm** key.
 - PARAMETER-AF**, enter **DATA 1** numerical value, and press **ENTER/UNITS kHz** key.
- (6) Press TI **PARAMETER- F M** pushbutton, enter **DATA** numerical value, and press **ENTER/UNITS rad** key for each row in table 20. Measuring receiver will indicate within limits specified.

Table 20. PM accuracy

Test instrument DATA and ENTER/UNITS (rad)	Measuring receiver modulation indications (rad)	
	Min	Max
20	18.9	21.1
10	9.4	10.6
3	2.75	3.25
1	0.85	1.15
.3	0.185	0.415

(7) Press **PARAMETER- F M** pushbutton and press **ON/OFF-OFF** key.

(8) Press pushbuttons and adjust controls as listed in (a) through (c) below for each row in table 21 below:

(a) Press TI **PARAMETER-RF** pushbutton, enter **DATA** numerical value, and press **ENTER/UNITS MHz** key.

(b) Press TI **PARAMETER- F M** pushbutton, enter **DATA** numerical value, and press **ENTER/UNITS rad** key.

(c) Using measuring receiver and Φ M measurement techniques, modulation will be between specified limits.

Table 21. PM Accuracy

Test instrument		Measuring receiver modulation indications (rad)	
DATA and ENTER/UNITS (MHz)	DATA and ENTER/UNITS (rad)	Min	Max
46	5	4.65	5.35
46	2.5	2.275	2.725
93.5	10	9.4	10.6
93.5	5	4.65	5.35
187.5	20	18.9	21.1
187.5	10	9.4	10.6
375	40	37.9	42.1
375	20	18.9	21.1
750	80	75.9	84.1
750	40	37.9	42.1

(9) Press **PARAMETER- F M** pushbutton and press **ON/OFF-OFF** key.

(10) Adjust controls as listed in (a) through (c) below for each row in table 22 below:

(a) Press TI **PARAMETER-RF** pushbutton, enter **DATA** numerical value, and press **ENTER/UNITS MHz** key.

(b) Press TI **PARAMETER- F M** pushbutton, enter **DATA** numerical value, and press **ENTER/UNIT rad** key.

(c) Using audio analyzer and distortion measurement techniques, distortion will be between specified limits.

Table 22. Distortion Accuracy

Test instrument		Audio analyzer distortion indications (<%)
DATA and ENTER/UNITS (MHz)	DATA and ENTER/UNITS (rad)	
15	10	0.5
46	2.5	0.5
93.5	5	0.5
187.5	10	0.5
375	20	0.5
750	40	0.5

(11) Press pushbuttons as listed in (a) through (e) below:

- (a) **PARAMETER-LEVEL** and press **ON/OFF-OFF** key.
- (b) **PARAMETER-F M** and press **ON/OFF-OFF** key.
- (c) **PARAMETER-RF**, enter **DATA 100** numerical value, and press **ENTER/UNITS MHz** key.
- (d) **PARAMETER-F M**, enter **DATA 10** numerical value, and press **ENTER/UNIT rad** key.
- (e) **ON/OFF-EXT AC** key.

(12) Using measuring receiver, ensure both 50 Hz high-pass filter and 15 kHz low-pass filter are on.

(13) Press **PARAMETER-LEVEL** pushbutton and press **ON/OFF-ON** key.

(14) Press pushbuttons on audio analyzer as listed in (a) through (e) below:

- (a) Source **FREQ-300 Hz**.
- (b) Source **LEVEL-1 V**.
- (c) Source-600Ω (SPCL 77).
- (d) Analyzer **LEVEL-dB**.
- (e) Analyzer **RATIO**.

(15) Set up audio analyzer source frequency for each row in table 23. Audio analyzer will indicate within limits specified.

Table 23. Ext Modulation Frequency Response

Audio analyzer source frequency (Hz)	Audio analyzer indications (dB)	
	Min	Max
500	-1	+1
1000	-1	+1
2000	-1	+1
5000	-1	+1

(16) Press **PARAMETER-LEVEL** pushbutton and press **ON/OFF-OFF** key.

(17) Reduce output on audio analyzer.

b. Adjustments. No adjustments can be made.

15. Frequency Modulation

a. Performance Check

- (1) Press **SHIFT- INSTR PRESET** pushbutton.
- (2) Press pushbuttons on measuring receiver as listed in (a) through (d) below:
 - (a) **SHIFT- INSTR PRESET.**
 - (b) **FM.**
 - (c) **PEAK +.**
 - (d) **50 Hz** high pass filter.
 - (e) **15 kHz** low pass filter.

(3) Initiate audio analyzer and set to measure percent distortion.

(4) Press pushbuttons as listed in (a) through (c) below:

(a) **PARAMETER-RF**, enter **DATA 100** numerical value, and press **ENTER/UNITS MHz** key.

(b) **PARAMETER- LEVEL**, enter **DATA 0** numerical value, and press **ENTER/UNITS dBm** key.

(c) **PARAMETER-AF**, enter **DATA 1** numerical value, and press **ENTER/UNITS kHz** key.

(5) Press TI **PARAMETER- FM** pushbutton, enter **DATA** numerical value, and press **ENTER/UNITS kHz** key for each row table 24. Using measuring receiver and FM measurement techniques, modulation will be between specified limits.

Table 24. FM Accuracy

Test instrument DATA and ENTER/UNITS (kHz)	Measuring receiver modulation indications FM (kHz)	
	Min	Max
1	0.93	1.07
3	2.83	3.17
10	9.48	10.52
30	28.48	31.52
100	94.98	105.02

(6) Press **PARAMETER-FM** pushbutton and press **ON/OFF- OFF** key.

(7) Adjust controls as listed in (a) through (c) below for each row in table 25 below:

(a) Press TI **PARAMETER-RF** pushbutton, enter **DATA** numerical value and press **ENTER/UNITS MHz** key.

(b) Press TI **PARAMETER- FM** pushbutton, enter **DATA** numerical value, and press **ENTER/UNIT kHz** key.

TB 9-6625-2329-35

(c) Using audio analyzer and distortion measurement techniques, distortion will be between specified limits.

Table 25. Distortion Accuracy

Test instrument		Audio analyzer distortion indications (<%)
DATA and ENTER/UNITS (MHz)	DATA and ENTER/UNITS (kHz)	
15	100	0.5
15	25	0.5
46	25	0.5
93	25	0.5
93	50	0.5
187	100	0.5
375	200	0.5
900	400	0.5

(8) Press **PARAMETER-FM** pushbutton and press **ON/OFF-OFF** key.

(9) Press **PARAMETER-FM** pushbutton, enter **DATA 40** numerical value, and press **ENTER/UNIT kHz** key.

(10) Press pushbuttons on measuring receiver as listed in (a) through (c) below:

- (a) **AM.**
- (b) **PEAK +.**
- (c) **300 Hz** high pass filter.
- (d) **15 kHz** low pass filter.

(11) Press TI **PARAMETER-RF** pushbutton, enter **DATA** numerical value, and press **ENTER/UNITS MHz** key for each row in table 26. Measuring receiver will indicate within limits specified.

Table 26. Incidental AM

Test instrument DATA and ENTER/UNITS (MHz)	Measuring receiver modulation indications (<%)
20	0.1
100	0.1
375	0.1
999	0.1

(12) Press **PARAMETER-FM** pushbutton and press **ON/OFF-OFF** key.

(13) Press pushbuttons as listed in (a) through (c) below:

(a) **PARAMETER-RF**, enter **DATA 100** numerical value, and press **ENTER/UNITS MHz** key.

(b) **PARAMETER-FM**, enter **DATA 100** numerical value, and press **ENTER/UNIT kHz** key.

(c) **PARAMETER-FM** and press **ON/OFF-EXT AC** key.

(14) Set measuring receiver to measure **FM** and **PEAK +** with all filters off.

(15) Press pushbuttons on audio analyzer as listed in (a) through (e) below:

- (a) Source **FREQ - 30 Hz**.
- (b) Source **LEVEL - 1 V**.
- (c) Source - 600Ω (SPCL 77).
- (d) Analyzer **LEVEL - dB**.
- (e) Analyzer **RATIO**.

(16) Set up audio analyzer source frequency for each row in table 27. Audio analyzer will indicate within limits specified.

Table 27. Ext Modulation Frequency Response

Audio analyzer source frequency (Hz)	Audio analyzer indications (dB)	
	Min	Max
100	-0.5	+0.5
1000	-0.5	+0.5
2000	-0.5	+0.5
5000	-0.5	+0.5
10000	-0.5	+0.5
20000	-0.5	+0.5
50000	-0.5	+0.5

(16) Press **PARAMETER-LEVEL** pushbutton and press **ON/OFF-OFF** key.

(17) Reduce output on audio analyzer.

b. Adjustments. No adjustments can be made.

16. Pulse Modulation

a. Performance Check

(1) Connect equipment as shown in figure 9.




Figure 9. Pulse modulation.

- (2) Press pulse generator pushbuttons as listed in (a) through (h) below:
 - (a) **CHANNEL A.**
 - (b) **Period** and enter **10 m/kHz**
 - (c) **Width** and enter **5 m/kHz.**
 - (d) **Vhigh** and **5 ENTER/Hz.**
 - (e) **Vlow** and **0 ENTER/Hz.**
 - (f) **Delay** and enter **0 n/GHz.**
 - (g) **2 Pulse** and **OFF ENTER/Hz.**
 - (h) **DISABLE** red light (on) on the 9211 output module,
- (3) Press TI pushbuttons as listed in (a) through (c) below:
 - (a) **SHIFT- INSTR PRESET.**
 - (b) **PARAMETER-RF**, enter **DATA 150** numerical value, and press **ENTER/UNITS MHz** key.
 - (c) **PARAMETER-LEVEL**, enter **DATA 10** numerical value, and press **ENTER/UNITS dBm** key.
- (4) Press **DISABLE** red light to off on pulse generator 9211 output module.
- (5) Press spectrum analyzer pushbuttons as listed in (a) through (g) below:
 - (a) **PRESET.**
 - (b) **FREQUENCY- MORE- 10 MHz EXT.**
 - (b) **AMPLITUDE-REF LVL.**
 - (c) **DATA-(+10 dBM).**
 - (d) **FREQUENCY-CENTER FREQ.**
 - (e) **DATA-150 MHz.**
 - (f) **SPAN.**
 - (g) **DATA-1MHz.**
- (6) Press **SHIFT, PARAMETER-SPECIAL** pushbutton, enter **DATA 19** numerical value, and press **ENTER/UNITS mV** key.

(7) Press spectrum analyzer pushbuttons and adjust controls as listed in (a) through (q) below:

- (a) **CONTROL-BW.**
- (b) **RES BW.**
- (c) **DATA-100 kHz.**
- (d) **VIDEO BW.**
- (e) **DATA-100 kHz.**
- (f) **MARKER-ON.**
- (g) **SPAN.**
- (h) **DATA-0 Hz.**
- (i) **CONTROL-SWEEP.**
- (j) **DATA-50 ms.**
- (k) **CONTROL-TRIG.**
- (l) **VIDEO.**
- (m) **DATA-(-10 dBm).**
- (n) **MARKER-ON.**
- (o) Adjust **MARKER** control to top of square wave.
- (p) **MARKER DELTA.**
- (q) Adjust **DELTA** control to bottom of square wave.

(8) Using spectrum analyzer, measure top to bottom of square wave in dB. Pulse envelope on/off ratio will indicate within limits specified in table 28.

Table 28. Pulse Modulation On/Off Ratio

Spectrum analyzer (>dB)
70

(9) Press **SHIFT, PARAMETER-SPECIAL** pushbuttons, enter **DATA 20** numerical value, and press **ENTER/UNITS mV** key.

(10) Press **PARAMETER-RF** pushbutton, enter **DATA 300** numerical value, and press **ENTER/UNITS MHz** key.

(11) Press spectrum analyzer pushbuttons as listed in (a) through (g) below:

- (a) **PRESET.**
- (b) **FREQUENCY- MORE- 10 MHz EXT.**
- (b) **AMPLITUDE-REF LVL.**
- (c) **DATA-(+10 dBM).**
- (d) **FREQUENCY-CENTER FREQ.**
- (e) **DATA-300 MHz.**
- (f) **SPAN.**
- (g) **DATA-1MHz.**

(12) Press **SHIFT, PARAMETER-SPECIAL** pushbutton, enter **DATA 19** numerical value, and press **ENTER/UNITS mV** key.

TB 9-6625-2329-35

(13) Press spectrum analyzer pushbuttons and adjust controls as listed in (a) through (q) below:

- (a) **CONTROL-BW.**
- (b) **RES BW.**
- (c) **DATA-100 kHz.**
- (d) **VIDEO BW.**
- (e) **DATA -00 kHz.**
- (f) **MARKER-ON.**
- (g) **SPAN.**
- (h) **DATA-0 Hz.**
- (i) **CONTROL-SWEEP.**
- (j) **DATA-50 ms.**
- (k) **CONTROL-TRIG.**
- (l) **VIDEO.**
- (m) **DATA - (-10 dBm).**
- (n) **MARKER-ON.**
- (o) Adjust **MARKER** control to top of square wave.
- (p) **MARKER DELTA.**
- (q) Adjust **DELTA** control to bottom of square wave.

(14) Using spectrum analyzer, measure top to bottom of square wave in dB. Pulse envelope on/off ratio will indicate within limits specified in table 29.

Table 29. Pulse Modulation On/Off Ratio

Spectrum analyzer > dB
70

(15) Press **SHIFT, PARAMETER-SPECIAL** pushbuttons, enter **DATA 20** numerical value, and press **ENTER/UNITS mV** key.

(16) Press **PARAMETER-RF** pushbutton, enter **DATA 1000** numerical value, and press **ENTER/UNITS MHz** key.

(17) Press spectrum analyzer pushbuttons as listed in (a) through (g) below:

- (a) **PRESET.**
- (b) **FREQUENCY- MORE- 10 MHz EXT.**
- (b) **AMPLITUDE - REF LVL.**
- (c) **DATA - (+10 dBM).**
- (d) **FREQUENCY-CENTER FREQ.**
- (e) **DATA-1000 MHz.**
- (f) **SPAN.**
- (g) **DATA-1 MHz.**

(18) Press **SHIFT, PARAMETER-SPECIAL** pushbuttons, enter **DATA 19** numerical value, and press **ENTER/UNITS mV** key.

(19) Press spectrum analyzer pushbuttons as listed in (a) through (q) below:

- (a) **CONTROL-BW.**
- (b) **RES BW.**
- (c) **DATA-100 kHz.**
- (d) **VIDEO BW.**
- (e) **DATA-100 kHz.**
- (f) **MARKER-ON.**
- (g) **SPAN.**
- (h) **DATA-0 Hz.**
- (i) **CONTROL-SWEEP.**
- (j) **DATA-50 ms.**
- (k) **CONTROL-TRIG.**
- (l) **VIDEO.**
- (m) **DATA - (-10 dBm).**
- (n) **MARKER-ON.**
- (o) Adjust **MARKER** control to top of square wave.
- (p) **MARKER DELTA.**
- (q) Adjust **DELTA** control to bottom of square wave.

(20) Using spectrum analyzer, measure top to bottom of square wave in dB. Pulse envelope on/off ratio will indicate within limits specified in table 30.

Table 30. Pulse Modulation On/Off ratio

Spectrum analyzer > dB
50

- (21) Press **SHIFT- INSTR PRESET** pushbutton.
- (22) Press **PARAMETER-LEVEL** pushbutton and press **ON/OFF-OFF** key.
- (23) Press **DISABLE** red light on pulse generator 9211 output module to on.
- (24) Press spectrum analyzer **PRESET** pushbuttons.

b. Adjustments. No adjustments can be made.

17. Final Procedure

- a.** Deenergize and disconnect all equipment.
- b.** Annotate and affix DA label/form in accordance with TB 750-25

THESE ARE THE INSTRUCTIONS FOR SENDING AN ELECTRONIC 2028

The following format must be used if submitting an electronic 2028. The subject line must be exactly the same and all fields must be included; however, only the following fields are mandatory: 1, 3, 4, 5, 6, 7, 8, 9, 10, 13, 15, 16, 17, and 27.

From: "Whomever" whomever@avma27.army.mil

To: 2028@redstone.army.mil

Subject: DA Form 2028


1. **From:** Joe Smith
2. Unit: Home
3. **Address:** 4300 Park
4. **City:** Hometown
5. **St:** MO
6. **Zip:** 77777
7. **Date Sent:** 19-Oct-93
8. **Pub No:** TB 9-6625-xxxx-35
9. **Pub Title:** Calibration Procedure for ...
10. **Publication Date:** 04 Jul 95
11. Change Number: 7
12. **Submitted Rank:** MSG
13. **Submitter Fname:** Joe
14. **Submitter Mname:** T
15. **Submitter Lname:** Smith
16. **Submitter Phone:** (123) 123-1234
17. **Problem:** 1
18. Page: 2
19. Paragraph: 3
20. Line: 4
21. NSN: 5
22. Reference: 6
23. Figure : 7
24. Table: 8
25. Item: 9
26. Total: 123
27. **Text:**

This is the text for the problem below line 27.

By Order of the Secretary of the Army:

ERIC K. SHINSEKI
General, United States Army
Chief of Staff

OFFICIAL:



JOEL B. HUDSON
Administrative Assistant to the
Secretary of the Army

0227704

Distribution:

To be distributed in accordance with initial distribution number 344757, requirements for calibration procedure TB 9-6625-2329-35.