

***TM 11-6665-224-40P**

TECHNICAL MANUAL

**GENERAL SUPPORT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LISTS
(INCLUDING DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS)**

FOR

**RADIAC SET AN/PDR-27P
(NSN 6665-00-975-7222)**

**HEADQUARTERS, DEPARTMENT OF THE ARMY
12 DECEMBER 1977**

TECHNICAL MANUAL
No. 11-6665-224-40P }

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, DC, 12 December 1977

GENERAL SUPPORT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LISTS
(INCLUDING DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS)

FOR

RADIAC SET AN/PDR-27P
(NSN 6665-09-975-7222)

Current as of 24 September 1977

REPORTING OF ERRORS

You can improve this manual by recommending improvements using DA Form 2028-2 (Test) located in the back of the manual. Simply tear out the self-addressed form, fill it out as shown on the sample, fold it where shown, and drop it in the mail.

If there are no blank DA Forms 2028-2 (Test) in the back of your manual, use the standard DA Form 2028 (Recommended Changes to Publications and Blank Forms) and forward to the Commander, US Army Electronics Command, ATTN: DRSEL-MA-Q, Fort Monmouth, NJ 07703.

In either case, a reply will be furnished direct to you.

TABLE OF CONTENTS

	Page	Illus	Figure
SECTION I. INTRODUCTION -----	1		
II. Repair parts list -----	5		
GROUP 0 0 Radiac Set AN/PDR-27P -----	5	1	
01 Radiac Meter IM-177/PDR-27P -----	7	2,3	
0101 Printed circuit board (A3) -----	13	4	
02 Radiac Detector DT-196/PDR-27J -----	17	5	
03 Headset H-43B/U (See TM 11-5965-247-35P for parts) -----			
04 Case, Carrying CY-2312/PDR-27L (No parts authorized) -----			
SECTION III. Special tools list (Not applicable) -----			
IV. National stock number and part number index -----	18		

• This manual supersedes TM 11-6665-224-40P, 30 July 1973.

SECTION I

INTRODUCTION

1. Scope

This manual lists spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE), and other special support equipment required for performance of general support maintenance of the AN/PDR-27P. It authorizes the requisitioning and issue of spares and repair parts as indicated by the source and maintenance codes.

2. General

This Repair Parts and Special Tools List is divided into the following sections:

a. Section II-Repair Parts List. A list of spares and repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in numeric sequence, with the parts in each group listed in figure and item number sequence.

b. Section III.-Special Tools List. Not applicable.

c. Section IV.-National Stock Number and Part Number Index. A list, in National item identification number (NIIN) sequence, of all National stock numbers (NSN) appearing in the listings, followed by a list, in alphabetic sequence, of all part numbers appearing in the listings. National stock numbers and part numbers are cross-referenced to each illustration figure and item number appearance.

3. Explanation of Columns

a. Illustration. This column is divided as follows:

(1) *Figure number.* Indicates the figure number of the illustration on which the item is shown.

(2) *Item number.* The number used to identify item called out in the illustration.

b. Source, Maintenance, and Recoverability (SMR) Codes.

(1) *Source code.* Source codes indicate the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are entered in the first and second positions of the Uniform SMR Code format as follows:

<i>Code</i>	<i>Definition</i>
PA	PA-Item procured and stocked for anticipated or known usage.
PD	PD-Support item, excluding support equipment, procured for initial issue or outfitting and stocked only for subsequent or additional initial issues or outfittings. Not subject to automatic replenishment.
XD-A	XD-A support item that is not stocked. When required, item will be procured through normal supply channels.

NOTE

Cannibalization or salvage may be used as a source of supply for any items source coded above except those coded XA and aircraft support items as restricted by AR 700-42.

(2) *Maintenance code.* Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code format as follows:

(a) The maintenance code entered in the third position will indicate the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position will indicate the following level of maintenance:

<i>Code</i>	<i>Application/Explanation</i>
O	O-Support item is removed, replaced, used at the organizational level.

H	H-Support item is removed, replaced, used at the general support level.
---	---

D	D-Support items are removed, replaced, used at depot, mobile depot, specialized repair activity only.
---	---

(b) The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions). This position will contain one of the following maintenance codes:

<i>Code</i>	<i>Application/Explanation</i>
-------------	--------------------------------

H-The lowest maintenance level capable of complete repair of the support item is the general support level.

D-The lowest maintenance level capable of complete repair of the support item is the depot level.

Z-Nonreparable. No repair is authorized.

(3) *Recoverability code.* Recoverability codes are assigned to support items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the Uniform SMR Code format as follows:

<i>Recoverability Codes</i>	<i>Definition</i>
-----------------------------	-------------------

Z-Nonreparable item. When unserviceable, condemn and dispose at the level indicated in position 3.

H-Reparable item. When uneconomically reparable, condemn and dispose at the general support level.

D-Reparable item. When beyond lower level repair capability, return to depot. Condemnation and disposal not authorized below depot level.

L-Reparable item. Repair, condemnation, and disposal not authorized below depot/specialized repair activity level.

c. *National Stock Number.* Indicates the National stock number assigned to the item and will be used for requisitioning purposes.

d. *Part Number.* Indicates the primary number used by the manufacturer (individual, company, firm, corporation, or Government activity), which controls the design and characteristics of the item by means of its engineering drawings, specifications, standards, and inspection requirements, to identify an item or range of items.

NOTE

When a stock-numbered item is requisitioned, the repair part received may have a different part number than the part being replaced.

e. *Federal Supply Code for Manufacturer (FSCM).* The FSCM is a 5-digit numeric code listed in SB 708-42 which is used to identify the manufacturer, distributor, or Government agency, etc.

f. *Description.* Indicates the Federal item name and, if required, a minimum description to identify the item.

g. *Unit of Measure (U/M).* Indicates the standard of the basic quantity of the listed item as used

in performing the actual maintenance function. This measure is expressed by a two-character alphabetical abbreviation (e.g., ea, in, pr, etc). When the unit of measure differs from the unit of issue, the lowest unit of issue that will satisfy the required units of measure will be requisitioned.

h. *Quantity Incorporated in Unit.* Indicates the quantity of the item used in the breakout shown a functional group, subfunctional group, or an assembly.

4. Special Information

The following publications pertain to the AN/PDR-27P and its components:

TM 11-6665-224-15, RADIAC SET
AN/PDR-27P

TM 11-6665-224-20P, RADIAC SET
AN/PDR-27P

TM 11-5965-247-12P, HEADSET, ELECTRICAL
H-43B/U

TM 11-5965-247-35P, HEADSET, ELECTRICAL
H-43B/U

5. How to Locate Repair Parts

a. When National stock number or part number is unknown:

(1) *First.* Using the table of contents, determine the functional group within which the item belongs. This is necessary since illustrations are prepared for functional groups and listings are divided into the same groups.

(2) *Second.* Find the illustration covering the functional group to which the item belongs.

(3) *Third.* Identify the item on the illustration figure and item number of the item.

(4) *Fourth.* Using the Repair Parts Listing, find the figure and item number noted on the illustration.

b. When National stock number or part number is known:

(1) *First.* Using the Index of National Stock Numbers and Part Numbers, find the pertinent National stock number or part number. This index is in NIIN sequence, followed by a list of part numbers in alphabetic sequence, cross-referenced to the illustration figure number and item number.

(2) *Second.* After finding the figure and item number, locate the figure and item number in the repair parts list.

6. Abbreviations

(Not applicable.)

(Next printed page is 4)






Figure 1. Radiac Set AN/PDR-27P

(1) ILLUSTRATION (a) FIG NO.	(2) ITEM NO.	(3) SMR CODE	(4) NATIONAL STOCK NUMBER	(5) PART NUMBER	(6) DESCRIPTION	(7) QTY INC IN	(8) U\ M UNIT
GROUP 00 RADIAC SET AN/PDR-27P							
1	1	XDODD		CY2312/PDR-27L	CASE,CARRYING	EA	1
1	2	PAHHH	6665-00-684-1533	DT-196/PDR-27J	DETECTOR,RADIAC	EA	1
1	3	PAOHD	6665-00-078-4179	IM177PDR27P	RADIAC METER	EA	1
1	4	PDODD	5965-00-651-7372	H-43B/U	HEADSET	EA	1



LEFT SIDE



RIGHT SIDE


EL4FW002

Figure 2. Radiac Meter IM-177/PDR-27P

SECTION II

TM11-6665-224-40P

(1) ILLUSTRATION (a) FIG NO.	(2) ITEM NO.	(3) SMR CODE	(4) NATIONAL STOCK NUMBER	(5) PART NUMBER	(6) DESCRIPTION	(7) QTY INC IN U\ M	(8) QTY INC IN UNIT
GROUP 01 RADIAC METER IM-177/PDR-27P							
2	1	PAOZZ	5355-00-656-1275	3651527	94988 KNOB	EA	1
2	2	PAOZZ	5305-00-685-1799	11383	94988 SCREW,EXT RLV BODY	EA	2
2	3	PAOZZ	5305-00-947-7033	11364	94988 SCREW,SEAL	EA	2
2	4	PAOZZ	6665-00-675-9415	3061503	94988 PLATE,DETENT	EA	1
2	5	PAHZZ	5940-00-762-7498	8-140	71785 TERMINAL BOARD	EA	1
2	6	PAOZZ	5305-00-685-1800	11414	94988 SCREW,EXT RLV BODY	EA	7
2	7	PAOZZ	5930-00-950-4541	11365	97539 NUT,SEAL	EA	1
2	8	PAHZZ	5930-00-615-1383	30-1	81073 SWITCH,PUSH SPST	EA	1
2	9	PAOZZ	5305-00-281-3118	3201505	94988 SCREW,SET	EA	2
2	10	PAHZZ	5935-00-201-3511	UG290AU	81349 CONNECTRO,RCPT,ELEC	EA	1
2	11	XDOZZ		902-1	86579 GASKET	EA	1
2	12	PAHZZ	6240-00-577-8456	NE2E	08108 LAMP,GLOW	EA	1
2	13	XDHDL		521-11391	15249 PRINTED CIRCUIT BD	EA	1
2	14	PAHZZ	6665-00-069-3031	MR36M201	81349 METER,ROENTGEN RATE	EA	1
2	15	PAHZZ	5355-00-926-5504	3651528	97913 EXTENSION SHAFT	EA	4
2	16	PAOZZ	5330-00-542-1752	1320048	70064 GASKET	EA	1
2	17	PAHZZ	5935-00-583-7985	11416	80028 CONNECTOR,PLUG,ELEC	EA	1
2	18	PAHZZ	5935-00-885-2264	MILC39012-25	81349 COVER,DUST	EA	1



EL4FW003

Figure 3. Radiac Meter IM-177/PDR-27P, Battery Cover Removed.

(1) ILLUSTRATION (a) FIG NO.	(2) (b) ITEM NO.	(3) NATIONAL STOCK CODE	(4) PART NUMBER	(5) FSCM	(6) DESCRIPTION	(7) U\M	(8) QTY INC IN UNIT
3	1	PAOZZ	6665-00-675-9401	11319	94988	CAP, ALUMINUM	EA 1
3	2	PAOZZ	5305-00-947-7033	11364	94988	SCREW, SEAL	EA 1
3	3	PAHZZ	5970-00-675-9392	11373	94988	INSULATOR, PLATE	EA 1
3	4	PAOZZ	5330-00-542-1753	521-1320047	15249	GASKET	EA 1
3	5	PAHZZ	5975-00-683-2152	11327	94988	NUT, PAKCING	EA 4
3	6	XDOZZ		902-1	86579	GASKET	EA 1





Figure 4. Printed Circuit Board (A3) (Sheet 1 of 2).



BOTTOM VIEW

EL4FW005

Figure 4. Printed Circuit Board (A3) (Sheet 2 of 2).

SECTION II

TM11-6665-224-40P

(1) ILLUSTRATION (a) FIG NO.	(2) ITEM NO.	(3) SMR CODE	(4) NATIONAL STOCK NUMBER	(5) PART NUMBER	(6) DESCRIPTION	(7) U\M	(8) QTY INC IN UNIT
GROUP 0101 PRINTED CIRCUIT BOARD A3							
4	1	PADZZ	5930-00-972-8439	11394	97913 SWITCH,ROTARY	EA	1
4	2	PADZZ	5910-00-808-5313	CM20D102J03	81349 CAPACITOR,FXD,MICA	EA	1
4	3	PADZZ	5905-00-141-1073	RCR20G564JS	81349 RESISTOR,FXD,CMPSN	EA	1
4	4	PADZZ	5935-00-678-9774	3303	97913 SOCKET,ELCTRN TUBE	EA	5
4	5	PADZZ	5910-00-577-3149	BB60101AW4X	71590 CAPACITOR,FXD,CER	EA	3
4	6	PADZZ	5905-00-192-0390	RC20G105J	81349 RESISTOR,FXD,CMPSN	EA	3
4	7	PADZZ	5961-00-752-5362	2N388	81349 TRANSISTOR	EA	1
4	8	XDDZZ		CCR100-1-5-4	14655 CAPACITOR,ELCTLT	EA	1
4	9	PADZZ	5905-00-254-7100	RC20GF913J	81349 RESISTOR,FXD,CMPSN	EA	1
4	10	PADZZ	5935-00-972-5464	46A13124	97913 SOCKET,ELCTRN TUBE	EA	2
4	11	PADZZ	5905-00-974-1774	3070020	94033 RESISTOR,VAR,CMPSN	EA	2
4	12	PADZZ	5910-00-683-3009	DA150-001CB	71590 CAPACITOR,FXD,CER	EA	2
4	13	PADZZ	5905-00-279-1866	RC20GF106K	81349 RESISTOR,FXD,CMPSN	EA	1
4	14	PADZZ	5960-00-296-3370	6088	81349 ELECTRON TUBE	EA	2
4	15	PADZZ	5910-00-583-1782	BBR2-150	14655 CAPACITOR,ELCTLT	EA	1
4	16	PADZZ	6130-00-682-9950	4U1	81483 RECTIFIER,SELENIUM	EA	3
4	17	PADZZ	6130-00-681-8503	61-5683	81483 RECTIFIER,SELENIUM	EA	2
4	18	PADZZ	5999-00-593-3805	1454	83330 CAP,ELECTRICAL	EA	1
4	19	PADZZ	5905-00-104-8332	RCR20G475JS	81349 RESISTOR,FXD,CMPSN	EA	1
4	20	PADZZ	5910-00-583-0717	BYA6D5L	71590 CAPACITOR,FXD,CER	EA	3
4	21	PADZZ	5960-00-188-6592	5962	81349 ELECTRON TUBE	EA	1
4	22	PADZZ	6665-00-676-6297	3131506	94988 RETAINER,TRANSISTOR	EA	5
4	23	PADZZ	5961-00-683-4182	2N526	04713 TRANSISOTR	EA	4
4	24	PADZZ	5905-00-249-3661	RC20GF683J	81349 RESISTOR,FXD,CMPSN	EA	1
4	25	PADZZ	5905-00-256-0409	RC20GF221K	81349 RESISTOR,FXD,CMPSN	EA	1
4	26	PADZZ	5905-00-195-6806	RC20GF102J	81349 RESISTOR,FXD,CMPSN	EA	1
4	27	PADZZ	5905-00-279-3497	RC20GF393J	81349 RESISTOR,FXD,CMPSN	EA	1
4	28	PADZZ	5905-00-171-2004	RC20GF223J	81349 RESISTOR,FXD,CMPSN	EA	2
4	29	PADZZ	5905-00-106-9344	RCR20G101JS	81349 RESISTOR,FXD,CMPSN	EA	1
4	30	PADZZ	5950-00-072-0827	11395	97913 TRANSFORMER,POWER	EA	1
4	31	PADZZ	5905-00-279-3499	RC20GF273J	81349 RESISTOR,FDXD,CMPSN	EA	2
4	32	PADZZ	6240-00-681-8561	NE80	08108 LAMP,GLOW	EA	1
4	33	PADZZ	5961-00-556-2091	IN270	81349 RECTIFIER,GERMANIUM	EA	1
4	34	PADZZ	5905-00-073-8701	3071505	97913 RESISTOR,VAR	EA	1
4	35	PADZZ	5905-00-190-8885	RC20GF225J	81349 RESISTOR,FXD,CMPSN	EA	1
4	36	PADZZ	5905-00-974-1773	3071507	80667 RESISTOR,VAR	EA	1
4	37	PADZZ	5905-00-688-4523	UPE65-5MEGD	71450 RESISTOR,VAR	EA	1
4	38	PADZZ	5905-00-688-4521	UPE65-500KD	71450 RESISTOR,VAR	EA	1
4	39	PADZZ	6130-00-504-1239	2T1	81483 RECTIFIER,SELENIUM	EA	1

(1) ILLUSTRATION (a) FIG NO.	(2) ITEM NO.	(3) SMR CODE	(4) NATIONAL STOCK NUMBER	(5) PART NUMBER	(6) DESCRIPTION	(7) U\ M	(8) QTY INC IN UNIT	
4	40	PADZZ	5905-00-171-2000	RC20GF684J	81349	RESISTOR, FXD, CMPSN	EA	1
4	41	PADZZ	5905-00-114-5393	RCR20G224JS	81349	RESISTOR, FXD, CMPSN	EA	3
4	42	PADZZ	5935-00-222-0841	91MPF3S	02660	CONNECTOR, PLUG, ELEC	EA	1
4	43	PADZZ	5905-00-114-5489	RCR20G823JS	81349	RESISTOR, FXD, CMPSN	EA	1
4	44	XDDZZ		DA147-001B	71590	CAPACITOR, FXD, CER	EA	2
4	45	PADZZ	5905-00-192-9260	RC20GF154K	81349	RESISTOR, FXD, CMPSN	EA	1
4	46	PADZZ	5905-00-171-1985	RC20GF822K	81349	RESISTOR, FXD, CMPSN	EA	1
4	47	PADZZ	5905-00-069-4508	RN70D2493F	81349	RESISTOR, FXD, FILM	EA	1




Figure 5. Radiac Detector DT-196/PDR-27J.

SECTION II

TM11-6665-224-40P

(1) ILLUSTRATION (a) FIG NO.	(2) (b) ITEM NO.	(3) SMR CODE	(4) NATIONAL STOCK NUMBER	(5) PART NUMBER	(6) DESCRIPTION	(7) QTY INC IN	(8) UNIT
GROUP 02 RADIAC DETECTOR DT-196/PDR-27J							
5	1	PAHZZ	6665-00-675-9422	11355	94988 GUARD	EA	1
5	2	PAHZZ	6665-00-675-9419	11330	94988 LATCH, COVER	EA	1
5	3	PAHZZ	6665-00-675-9419	11330	94988 LATCH, COVER	EA	1
5	4	PAHZZ	5330-00-171-8622	212-8307	25184 PACKING, PREFORMED	EA	1
5	5	PAHZZ	5995-00-628-7297	11410	94988 CABLE ASSEMBLY	EA	1
5	6	PAHZZ	6665-00-632-9218	11412	94988 CABLE ASSEMBLY	EA	1
5	7	PAHZZ	5330-00-248-3840	MS29513-14	96906 PAKCING, PREFORMED	EA	1
5	8	PAHZZ	5960-00-542-6544	5980	81349 ELECTRON TUBE	EA	1
5	9	PAHZZ	6665-00-676-6330	11379	94988 HOLDER, TUBE	EA	1
5	10	PAHZZ	5960-00-686-9101	5979	81349 ELECTRON TUBE	EA	1

NATIONAL STOCK NUMBER AND PART NUMBER INDEX

NOTE: LATEST NATIONAL STOCK NUMBER AND PART NUMBER ASSIGNMENTS ARE INCLUDED AT END OF INDEX

STOCK NUMBER	FIGURE NO.	ITEM NO.	STOCK NUMBER	FIGURE NO.	ITEM NO.
6665-00-069-3031	2	14	5930-00-615-1383	2	8
5950-00-072-0827	4	30	5995-00-628-7297	5	5
5905-00-073-8701	4	34	6665-00-632-9218	5	6
5905-00-171-1985	4	46	5355-00-656-1275	2	1
5905-00-171-2000	4	40	5970-00-675-9392	3	3
5905-00-171-2004	4	28	6665-00-675-9401	3	1
5960-00-188-6592	4	21	6665-00-675-9415	2	4
5905-00-190-8885	4	35	6665-00-675-9419	5	3
5905-00-192-0390	4	6	6665-00-675-9422	5	1
5905-00-192-9260	4	45	6665-00-676-6297	4	22
5905-00-195-6806	4	26	6665-00-676-6330	5	9
5935-00-201-3511	2	10	5935-00-678-9774	4	4
5935-00-222-0841	4	42	6130-00-681-8503	4	17
5330-00-248-3840	5	7	6240-00-681-8561	4	32
5905-00-249-3661	4	24	6130-00-682-9950	4	16
5905-00-254-7100	4	9	5975-00-683-2152	3	5
5905-00-256-0409	4	25	5910-00-683-3009	4	12
5905-00-279-1866	4	13	6665-00-684-1533	1	2
5905-00-279-3497	4	27	5305-00-685-1799	2	2
5905-00-279-3499	4	31	5305-00-685-1800	2	6
5305-00-281-3118	2	9	5960-00-686-9101	2	10
5960-00-296-3370	4	14	5905-00-688-4521	4	38
6130-00-504-1239	4	39	5905-00-688-4523	4	37
5330-00-542-1752	2	16	5961-00-752-5362	4	7
5330-00-542-1753	3	4	5940-00-762-7498	2	5
5960-00-542-6544	5	8	6625-00-791-6046	5	2
5961-00-556-2091	4	33	5355-00-926-5504	2	15
5910-00-577-3149	4	5	5305-00-947-7033	2	3
5910-00-583-0717	4	20	5305-00-947-7033	3	2
5910-00-583-1782	4	15	5930-00-950-4541	2	7
5935-00-583-7985	2	17	5935-00-972-5464	4	10
5999-00-593-3805	4	18	5905-00-974-1773	4	36

PART NUMBER	FIG FSCM	ITEM NO	PART NUMBER	FIG FSCM	ITEM NO
BBR2-150	14655	4	15	11353	94988 5
BB60101AW4X	71590	4	5	11355	94988 5
BYA6D5L	71590	4	20	11364	94988 2
CCR100-1-5-4	14655	4	8	11364	94988 3
CM20D102J03	81349	4	2	11365	97539 2
	80058	1	1	11373	94988 3
DA147-001B	71590	4	44	11379	94988 5
DA150-001CB	71590	4	12	11383	94988 2
DT-196/PDR-27J	80058	1	2	11394	97913 4
H-43B/U	80058	1	4	11395	97913 4
1M177PDR27P	80058	1	3	11410	94988 5
MR36M201	81349	2	14	11412	94988 5
MS29513-14	96906	5	7	11414	94988 2
			11416	80028 2	
			1320048	70064 2	
NE80	08108	4	32	1454	83330 4
CY2312/PDR-27L			2N388	81349 4	
RC20GF102J	81349	4	26	2N526	04713 4
RC20GF106K	81349	4	13	2T1	81483 4
RC20GF154K	81349	4	45	30-1	81073 2
RC20GF221K	81349	4	25	3061503	94988 2
RC20GF223J	81349	4	28	3070020	94033 4
			3071505	97913 4	
RC20GF225J	81349	4	35	3071507	80667 4
RC20GF273J	81349	4	31	3131506	94988 4
RC20GF393J	81349	4	27	3201505	94988 2
			3303	97913 4	
			3651527	94988 2	
RC20GF633J	81349	4	24	3651528	97913 2
RC20GF684J	81349	4	40	4U1	81483 4
RC20GF822K	81349	4	46	46A13124	97913 4
			521-11391	15249 2	
RC20GF913J	81349	4	9	521-1320047	15249 3
RC20G105J	81349	4	6	5962	81349 4
			5979	81349 5	
UG290AU	81349	2	10	5980	81349 5
UPE65-5MEGD	71450	4	37	6088	81349 4
UPE65-500KD	71450	4	38	61-5683	81483 4
IN270	81349	4	33	8-140	71785 2
11319	94988	3	1	902-1	86579 2
11327	94988	3	5	902-1	86579 3
11330	94988	5	3	91MPF3S	02660 4

NATIONAL STOCK NUMBER AND PART NUMBER INDEX

LATEST NATIONAL STOCK NUMBER ASSIGNMENTS

STOCK NUMBER	FIG. NO.	ITEM NO.	STOCK NUMBER	FIG. NO.	ITEM NO.
5905-00-069-4508	4	47	6240-00-577-8456	2	12
6665-00-078-4179	1	3	5965-00-651-7372	1	4
5905-00-104-8332	4	19	5961-00-683-4182	4	23
5905-00-106-9344	4	29	5910-00-808-5313	4	2
5905-00-114-5393	4	41	5935-00-885-2264	2	18
5905-00-114-5489	4	43	5930-00-972-8439	4	1
5905-00-114-5489	4	3	5905-00-974-1774	4	11
5330-00-171-8622	5	4			

LATEST PART NUMBER ASSIGNMENTS

PART NUMBER	FSCM	FIG NO	ITEM NO	PART NUMBER	FSCM	FIG NO	ITEM NO
MILC39012-25	81349	2	18	RCR20G823JS	81349	4	43
RCR20G101JS	81349	4	29	RN70D2493F	81349	4	47
RCR20G224JS	81349	4	41	NE2E	08108	2	12
RCR20G475JS	81349	4	19	212-8307	25184	5	4
RCR20G564JS	81349	4	3				

By Order of the Secretary of the Army:

BERNARD W. ROGERS
General, United States Army
Chief of Staff

Official:

J. C. PENNINGTON
Brigadier General, United States Army
The Adjutant General

Distribution:

To be distributed in accordance with DA Form 12-50, Direct and General Support maintenance requirements for AN/PDR-27.

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL MANUALS

SOMETHING WRONG WITH THIS MANUAL?

THEN... JOT DOWN THE
DOPE ABOUT IT ON THIS
FORM, TEAR IT OUT, FOLD
IT AND DROP IT IN THE
MAIL!

FROM: (YOUR UNIT'S COMPLETE ADDRESS)

Commander
Stateside Army Depot
ATTN: AMSTA-US
Stateside, N.J. 07703

DATE 10 July 1975

PUBLICATION NUMBER	DATE	TITLE
TM 11-5840-340-12	23 Jan 74	Radar Set AN/PDE-76

BE EXACT... PIN-POINT WHERE IT IS				IN THIS SPACE TELL WHAT IS WRONG AND WHAT SHOULD BE DONE ABOUT IT:
PAGE NO.	PARA-GRAPH	FIGURE NO.	TABLE NO.	
2-25	2-28			Recommend that the installation antenna alignment procedure be changed throughout to specify a 2° IFF antenna lag rather than 1°. REASON: Experience has shown that with only a 1° lag, the antenna servo system is too sensitive to wind gusting in excess of 25 knots, and has a tendency to rapidly accelerate and decelerate as it hunts, causing strain to the drive train. Hunting is minimized by adjusting the lag to 2° without degradation of operation.
3-10	3-3	3-1		Item 5, Function column. Change "2 db" to "3db." REASON: The adjustment procedure for the TRANS POWER FAULT indicator calls for a 3 db (500 watts) adjustment to light the TRANS POWER FAULT indicator.
5-6	5-8			Add new step f.1 to read, "Replace cover plate removed in step e.1, above." REASON: To replace the cover plate.
	F03			Zone C 3. On J1-2, change "+24 VDC to "+5 VDC." REASON: This is the output line of the 5 VDC power supply. + 24 VDC is the input voltage.

TYPED NAME, GRADE OR TITLE, AND TELEPHONE NUMBER

SSG I. M. DeSpiritof 999-1776

SIGN HERE:

DA FORM 2028-2 (TEST) 1 AUG 74

P.S.--IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR MANUAL "FIND," MAKE A CARBON COPY OF THIS AND GIVE IT TO YOUR HEADQUARTERS.

HISA 1686-75



RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL MANUALS

SOMETHING WRONG WITH THIS MANUAL?

THEN. . .JOT DOWN THE
DOPE ABOUT IT ON THIS
FORM, TEAR IT OUT, FOLD
IT AND DROP IT IN THE
MAIL!

FROM: (YOUR UNIT'S COMPLETE ADDRESS)

DATE

PUBLICATION NUMBER

DATE

TITLE

TH 11-6665-224-409

13 Dec 77

BE EXACT...PIN-POINT WHERE IT IS

**IN THIS SPACE TELL WHAT IS WRONG
AND WHAT SHOULD BE DONE ABOUT IT:**

PAGE NO.	PARA-GRAPH	FIGURE NO.	TABLE NO.
----------	------------	------------	-----------

TEAR ALONG DOTTED LINE

DA FORM 1 AUG 74 2028-2 (TEST)

P.S.--IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR MANUAL "FIND," MAKE A CARBON COPY OF THIS AND GIVE IT TO YOUR HEADQUARTERS.

FILL IN YOUR
UNIT'S ADDRESS



FOLD BACK

DEPARTMENT OF THE ARMY

OFFICIAL BUSINESS

PENALTY FOR PRIVATE USE, \$300

POSTAGE AND FEES PAID
DEPARTMENT OF THE ARMY
DOD-314



Commander
US Army Electronics Command
ATTN: DRSEL-MA-Q
Fort Monmouth, New Jersey 07703

TEAR ALONG DOTTED LINE

FOLD BACK

THE METRIC SYSTEM AND EQUIVALENTS

NEAR MEASURE

Centimeter = 10 Millimeters = 0.01 Meters = 0.3937 Inches
 1 Meter = 100 Centimeters = 1000 Millimeters = 39.37 Inches
 1 Kilometer = 1000 Meters = 0.621 Miles

WEIGHTS

Gram = 0.001 Kilograms = 1000 Milligrams = 0.035 Ounces
 1 Kilogram = 1000 Grams = 2.2 lb.
 1 Metric Ton = 1000 Kilograms = 1 Megagram = 1.1 Short Tons

LIQUID MEASURE

1 Milliliter = 0.001 Liters = 0.0338 Fluid Ounces
 1 Liter = 1000 Milliliters = 33.82 Fluid Ounces

SQUARE MEASURE

1 Sq. Centimeter = 100 Sq. Millimeters = 0.155 Sq. Inches
 1 Sq. Meter = 10,000 Sq. Centimeters = 10.76 Sq. Feet
 1 Sq. Kilometer = 1,000,000 Sq. Meters = 0.386 Sq. Miles

CUBIC MEASURE

1 Cu. Centimeter = 1000 Cu. Millimeters = 0.06 Cu. Inches
 1 Cu. Meter = 1,000,000 Cu. Centimeters = 35.31 Cu. Feet

TEMPERATURE

$5/9(F - 32) = ^\circ C$
 212° Fahrenheit is equivalent to 100° Celsius

90° Fahrenheit is equivalent to 32.2° Celsius
 32° Fahrenheit is equivalent to 0° Celsius

$9/5C + 32 = ^\circ F$

APPROXIMATE CONVERSION FACTORS

TO CHANGE

Inches.....
 Feet.....
 Yards.....
 Miles.....
 Square Inches.....
 Square Feet.....
 Square Yards.....
 Square Miles.....
 Acres.....
 Cubic Feet.....
 Cubic Yards.....
 Fluid Ounces.....
 nts.....
 arts.....
 allons.....
 Ounces.....
 Pounds.....
 Short Tons.....
 Pound-Feet.....
 Pounds per Square Inch.....
 Miles per Gallon.....
 Miles per Hour.....

TO

Centimeters.....
 Meters.....
 Meters.....
 Kilometers.....
 Square Centimeters.....
 Square Meters.....
 Square Meters.....
 Square Kilometers.....
 Square Hectometers.....
 Cubic Meters.....
 Cubic Meters.....
 Milliliters.....
 Liters.....
 Liters.....
 Liters.....
 Grams.....
 Kilograms.....
 Metric Tons.....
 Newton-Meters.....
 Kilopascals.....
 Kilometers per Liter.....
 Kilometers per Hour.....

MULTIPLY BY

2.540
 0.305
 0.914
 1.609
 6.451
 0.093
 0.836
 2.590
 0.405
 0.028
 0.765
 29.573
 0.473
 0.946
 3.785
 28.349
 0.454
 0.907
 1.356
 6.895
 0.425
 1.609

TO CHANGE


Centimeters.....
 Meters.....
 Meters.....
 Kilometers.....
 Square Centimeters.....
 Square Meters.....
 Square Meters.....
 Square Kilometers.....
 Square Hectometers.....
 Cubic Meters.....
 Cubic Meters.....
 Milliliters.....
 Liters.....
 Liters.....
 ers.....
 ms.....
 ograms.....
 Metric Tons.....
 Newton-Meters.....
 Kilopascals.....
 Miles per Liter.....
 Miles per Hour.....

TO

Inches.....
 Feet.....
 Yards.....
 Miles.....
 Square Inches.....
 Square Feet.....
 Square Yards.....
 Square Miles.....
 Acres.....
 Cubic Feet.....
 Cubic Yards.....
 Fluid Ounces.....
 Pints.....
 Quarts.....
 Gallons.....
 Ounces.....
 Pounds.....
 Short Tons.....
 Pounds-Feet.....
 Pounds per Square Inch.....
 Miles per Gallon.....
 Miles per Hour.....

MULTIPLY BY

0.394
 3.280
 1.094
 0.621
 0.155
 10.764
 1.196
 0.386
 2.471
 35.315
 1.308
 0.034
 2.113
 1.057
 0.264
 0.035
 2.205
 1.102
 0.738
 0.145
 2.354
 0.621



PIN: 019513-000