

# PXI™

---

## PXI-1025 MegaPAC™ User Manual

## **Worldwide Technical Support and Product Information**

www.ni.com

### **National Instruments Corporate Headquarters**

11500 North Mopac Expressway Austin, Texas 78759-3504 USA Tel: 512 794 0100

### **Worldwide Offices**

Australia 03 9879 5166, Austria 0662 45 79 90 0, Belgium 02 757 00 20, Brazil 011 284 5011,  
Canada (Calgary) 403 274 9391, Canada (Ontario) 905 785 0085, Canada (Québec) 514 694 8521,  
China 0755 3904939, Denmark 45 76 26 00, Finland 09 725 725 11, France 01 48 14 24 24,  
Germany 089 741 31 30, Greece 30 1 42 96 427, Hong Kong 2645 3186, India 91805275406,  
Israel 03 6120092, Italy 02 413091, Japan 03 5472 2970, Korea 02 596 7456, Mexico (D.F.) 5 280 7625,  
Mexico (Monterrey) 8 357 7695, Netherlands 0348 433466, Norway 32 27 73 00, Poland 48 22 528 94 06,  
Portugal 351 1 726 9011, Singapore 2265886, Spain 91 640 0085, Sweden 08 587 895 00,  
Switzerland 056 200 51 51, Taiwan 02 2377 1200, United Kingdom 01635 523545

For further support information, see the *Technical Support Resources* appendix. To comment on the documentation, send e-mail to [techpubs@ni.com](mailto:techpubs@ni.com)

© Copyright 1999 National Instruments Corporation. All rights reserved.

# Important Information

---

## Warranty

The PXI-1025 MegaPAC is warranted against defects in materials and workmanship for a period of one year from the date of shipment, as evidenced by receipts or other documentation. National Instruments will, at its option, repair or replace equipment that proves to be defective during the warranty period. This warranty includes parts and labor.

The media on which you receive National Instruments software are warranted not to fail to execute programming instructions, due to defects in materials and workmanship, for a period of 90 days from date of shipment, as evidenced by receipts or other documentation. National Instruments will, at its option, repair or replace software media that do not execute programming instructions if National Instruments receives notice of such defects during the warranty period. National Instruments does not warrant that the operation of the software shall be uninterrupted or error free.

A Return Material Authorization (RMA) number must be obtained from the factory and clearly marked on the outside of the package before any equipment will be accepted for warranty work. National Instruments will pay the shipping costs of returning to the owner parts which are covered by warranty.

National Instruments believes that the information in this document is accurate. The document has been carefully reviewed for technical accuracy. In the event that technical or typographical errors exist, National Instruments reserves the right to make changes to subsequent editions of this document without prior notice to holders of this edition. The reader should consult National Instruments if errors are suspected. In no event shall National Instruments be liable for any damages arising out of or related to this document or the information contained in it.

EXCEPT AS SPECIFIED HEREIN, NATIONAL INSTRUMENTS MAKES NO WARRANTIES, EXPRESS OR IMPLIED, AND SPECIFICALLY DISCLAIMS ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. CUSTOMER'S RIGHT TO RECOVER DAMAGES CAUSED BY FAULT OR NEGLIGENCE ON THE PART OF NATIONAL INSTRUMENTS SHALL BE LIMITED TO THE AMOUNT THEREFORE PAID BY THE CUSTOMER. NATIONAL INSTRUMENTS WILL NOT BE LIABLE FOR DAMAGES RESULTING FROM LOSS OF DATA, PROFITS, USE OF PRODUCTS, OR INCIDENTAL OR CONSEQUENTIAL DAMAGES, EVEN IF ADVISED OF THE POSSIBILITY THEREOF. This limitation of the liability of National Instruments will apply regardless of the form of action, whether in contract or tort, including negligence. Any action against National Instruments must be brought within one year after the cause of action accrues. National Instruments shall not be liable for any delay in performance due to causes beyond its reasonable control. The warranty provided herein does not cover damages, defects, malfunctions, or service failures caused by owner's failure to follow the National Instruments installation, operation, or maintenance instructions; owner's modification of the product; owner's abuse, misuse, or negligent acts; and power failure or surges, fire, flood, accident, actions of third parties, or other events outside reasonable control.

## Copyright

Under the copyright laws, this publication may not be reproduced or transmitted in any form, electronic or mechanical, including photocopying, recording, storing in an information retrieval system, or translating, in whole or in part, without the prior written consent of National Instruments Corporation.

## Trademarks

National Instruments™, ni.com™, and PXI™ are trademarks of National Instruments Corporation.

Product and company names mentioned herein are trademarks or trade names of their respective companies.

## WARNING REGARDING USE OF NATIONAL INSTRUMENTS PRODUCTS

(1) NATIONAL INSTRUMENTS PRODUCTS ARE NOT DESIGNED WITH COMPONENTS AND TESTING FOR A LEVEL OF RELIABILITY SUITABLE FOR USE IN OR IN CONNECTION WITH SURGICAL IMPLANTS OR AS CRITICAL COMPONENTS IN ANY LIFE SUPPORT SYSTEMS WHOSE FAILURE TO PERFORM CAN REASONABLY BE EXPECTED TO CAUSE SIGNIFICANT INJURY TO A HUMAN.

(2) IN ANY APPLICATION, INCLUDING THE ABOVE, RELIABILITY OF OPERATION OF THE SOFTWARE PRODUCTS CAN BE IMPAIRED BY ADVERSE FACTORS, INCLUDING BUT NOT LIMITED TO FLUCTUATIONS IN ELECTRICAL POWER SUPPLY, COMPUTER HARDWARE MALFUNCTIONS, COMPUTER OPERATING SYSTEM SOFTWARE FITNESS, FITNESS OF COMPILERS AND DEVELOPMENT SOFTWARE USED TO DEVELOP AN APPLICATION, INSTALLATION ERRORS, SOFTWARE AND HARDWARE COMPATIBILITY PROBLEMS, MALFUNCTIONS OR FAILURES OF ELECTRONIC MONITORING OR CONTROL DEVICES, TRANSIENT FAILURES OF ELECTRONIC SYSTEMS (HARDWARE AND/OR SOFTWARE), UNANTICIPATED USES OR MISUSES, OR ERRORS ON THE PART OF THE USER OR APPLICATIONS DESIGNER (ADVERSE FACTORS SUCH AS THESE ARE HEREAFTER COLLECTIVELY TERMED "SYSTEM FAILURES"). ANY APPLICATION WHERE A SYSTEM FAILURE WOULD CREATE A RISK OF HARM TO PROPERTY OR PERSONS (INCLUDING THE RISK OF BODILY INJURY AND DEATH) SHOULD NOT BE RELIANT SOLELY UPON ONE FORM OF ELECTRONIC SYSTEM DUE TO THE RISK OF SYSTEM FAILURE. TO AVOID DAMAGE, INJURY, OR DEATH, THE USER OR APPLICATION DESIGNER MUST TAKE REASONABLY PRUDENT STEPS TO PROTECT AGAINST SYSTEM FAILURES, INCLUDING BUT NOT LIMITED TO BACK-UP OR SHUT DOWN MECHANISMS. BECAUSE EACH END-USER SYSTEM IS CUSTOMIZED AND DIFFERS FROM NATIONAL INSTRUMENTS' TESTING PLATFORMS AND BECAUSE A USER OR APPLICATION DESIGNER MAY USE NATIONAL INSTRUMENTS PRODUCTS IN COMBINATION WITH OTHER PRODUCTS IN A MANNER NOT EVALUATED OR CONTEMPLATED BY NATIONAL INSTRUMENTS, THE USER OR APPLICATION DESIGNER IS ULTIMATELY RESPONSIBLE FOR VERIFYING AND VALIDATING THE SUITABILITY OF NATIONAL INSTRUMENTS PRODUCTS WHENEVER NATIONAL INSTRUMENTS PRODUCTS ARE INCORPORATED IN A SYSTEM OR APPLICATION, INCLUDING, WITHOUT LIMITATION, THE APPROPRIATE DESIGN, PROCESS AND SAFETY LEVEL OF SUCH SYSTEM OR APPLICATION.

# Compliance

---

## FCC/Canada Radio Frequency Interference Compliance\*

### Determining FCC Class


The Federal Communications Commission (FCC) has rules to protect wireless communications from interference. The FCC places digital electronics into two classes. These classes are known as Class A (for use in industrial-commercial locations only) or Class B (for use in residential or commercial locations). Depending on where it is operated, this product could be subject to restrictions in the FCC rules. (In Canada, the Department of Communications (DOC), of Industry Canada, regulates wireless interference in much the same way.)

Digital electronics emit weak signals during normal operation that can affect radio, television, or other wireless products. By examining the product you purchased, you can determine the FCC Class and therefore which of the two FCC/DOC Warnings apply in the following sections. (Some products may not be labelled at all for FCC, if so the reader should then assume these are Class A devices.)

FCC Class A products only display a simple warning statement of one paragraph in length regarding interference and undesired operation. Most of our products are FCC Class A. The FCC rules have restrictions regarding the locations where FCC Class A products can be operated.

FCC Class B products display either a FCC ID code, starting with the letters **EXN**, or the FCC Class B compliance mark that appears as shown here on the right.

The curious reader can consult the FCC web site <http://www.fcc.gov> for more information.



### FCC/DOC Warnings

This equipment generates and uses radio frequency energy and, if not installed and used in strict accordance with the instructions in this manual and the CE Mark Declaration of Conformity\*\*, may cause interference to radio and television reception. Classification requirements are the same for the Federal Communications Commission (FCC) and the Canadian Department of Communications (DOC).

Changes or modifications not expressly approved by National Instruments could void the user's authority to operate the equipment under the FCC Rules.

### Class A

#### Federal Communications Commission

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

#### Canadian Department of Communications

This Class A digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

Cet appareil numérique de la classe A respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

### Class B

#### Federal Communications Commission

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful

interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## **Canadian Department of Communications**

This Class B digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

Cet appareil numérique de la classe B respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

## **European Union - Compliance to EEC Directives**

Readers in the EU/EEC/EEA must refer to the Manufacturer's Declaration of Conformity (DoC) for information\*\* pertaining to the CE Mark compliance scheme. The Manufacturer includes a DoC for most every hardware product except for those bought for OEMs, if also available from an original manufacturer that also markets in the EU, or where compliance is not required as for electrically benign apparatus or cables.

\* Certain exemptions may apply in the USA, see FCC Rules §15.103 **Exempted devices**, and §15.105(c). Also available in sections of CFR 47.

\*\* The CE Mark Declaration of Conformity will contain important supplementary information and instructions for the user or installer.

# For Your Safety

---



**Caution** Before undertaking any troubleshooting, maintenance, or exploratory procedure, read carefully the WARNING and CAUTION notices.

This equipment contains voltage hazardous to human life and safety, and is capable of inflicting personal injury.

- **Chassis Grounding**—The PXI-1025 MegaPAC chassis requires a connection from the premise wire safety ground to the PXI-1025 MegaPAC chassis ground. The earth safety ground must be connected during use of this equipment to minimize shock hazards. Refer to the *Connecting Safety Ground* section of Chapter 2, *Installation, Configuration, and Operation*, for instructions on connecting safety ground.
- **Live Circuits**—Operating personnel and service personnel must *not* remove protective covers when operating the PXI-1025 MegaPAC. Adjustments and service to internal components must be undertaken by qualified service technicians. During service of this product, the mains connector to the premise wiring must be disconnected. Dangerous voltages may be present under certain conditions; use extreme caution.
- **Explosive Atmosphere**—Do *not* operate the chassis in conditions where flammable gases are present. Under such conditions this equipment is unsafe and may ignite the gases or gas fumes.
- **Part Replacement**—Only service this equipment with parts that are exact replacements, both electrically and mechanically. Contact National Instruments for replacement part information. Installation of parts with those that are not direct replacements may cause harm to personnel operating the chassis. Furthermore, damage or fire may occur if replacement parts are unsuitable.
- **Modification**—Do *not* modify any part of the chassis from its original condition. Unsuitable modifications may result in safety hazards.

# Contents

---

## About This Manual

|                            |    |
|----------------------------|----|
| Conventions .....          | xi |
| Related Documentation..... | xi |

## Chapter 1 Getting Started

|  |     |
|--|-----|
| Unpacking .....  | 1-1 |
| What You Need to Get Started .....                           | 1-1 |
| Optional Equipment .....                                     | 1-2 |
| Battery Pack and Cable for DC-Capable PXI-1025 MegaPAC ..... | 1-2 |
| Rack-Mount Kit.....  | 1-2 |
| Key Features .....   | 1-2 |
| PXI-1025 Backplane Overview .....                            | 1-5 |
| Interoperability with CompactPCI .....                       | 1-5 |
| System Controller Slot .....                                 | 1-6 |
| Star Trigger Slot .....                                      | 1-6 |
| Peripheral Slots.....  | 1-6 |
| Local Bus .....  | 1-6 |
| Trigger Bus .....  | 1-7 |
| System Reference Clock.....                                  | 1-7 |

## Chapter 2 Installation, Configuration, and Operation

|   |      |
|---|------|
| Site Considerations .....                                       | 2-1  |
| Using Handle/Tilt Stand for Bench-Top Application .....         | 2-3  |
| Fold-Down Keyboard .....  | 2-3  |
| Rack Mounting .....   | 2-4  |
| Status LED Indicators .....                                     | 2-4  |
| Setting Fan Speed .....   | 2-4  |
| Connecting Safety Ground.....                                   | 2-4  |
| Connecting to Power Source.....                                 | 2-5  |
| DC Connector (DC-Capable Chassis Only) .....                    | 2-5  |
| Installing the Battery Pack (DC-Capable Power Supply Only)..... | 2-6  |
| Charging the Battery Pack (DC-Capable Power Supply Only) .....  | 2-7  |
| Input Voltage Priority (DC-Capable Power Supply Only) .....     | 2-8  |
| Installing PXI Modules .....                                    | 2-8  |
| Installing Filler Panels .....                                  | 2-10 |
| Using the Chassis Initialization File .....                     | 2-10 |

## Chapter 3 Maintenance

|                               |     |
|-------------------------------|-----|
| Service Interval.....         | 3-1 |
| Preparation.....              | 3-1 |
| Cleaning.....                 | 3-1 |
| Interior Cleaning .....       | 3-2 |
| Exterior Cleaning .....       | 3-2 |
| Cleaning the Fan Filter ..... | 3-2 |

## Chapter 4 Troubleshooting

|  |     |
|--|-----|
| Troubleshooting the PXI-1025 MegaPAC .....                                   | 4-1 |
| Replacing the Fuse for Optional Battery Pack (DC-Capable Chassis Only) ..... | 4-2 |

## Appendix A Specifications

## Appendix B Pinouts

## Appendix C Technical Support Resources

## Glossary

## Index

## Figures

|             |  |     |
|-------------|--|-----|
| Figure 1-1. | Front View of the PXI-1025 MegaPAC Chassis .....                     | 1-4 |
| Figure 1-2. | Rear View of the AC-Only PXI-1025 MegaPAC Chassis .....              | 1-4 |
| Figure 1-3. | Rear View of the DC-Capable PXI-1025 MegaPAC Chassis .....           | 1-5 |
| Figure 1-4. | PXI Local Bus and Star Trigger Routing.....                          | 1-7 |
| Figure 2-1. | PXI-1025 MegaPAC Chassis Airflow Side View .....                     | 2-2 |
| Figure 2-2. | Using the Handle for Bench-Top Applications .....                    | 2-3 |
| Figure 2-3. | DC Connector on Rear of DC-Capable PXI-1025<br>MegaPAC Chassis ..... | 2-6 |
| Figure 2-4. | Installing Battery Pack.....   | 2-7 |



Figure 2-5. Installing PXI or CompactPCI Modules .....2-9  
 Figure 2-6. Injector/Ejector Handle Position during Module Insertion .....2-9  
 Figure 4-1. Optional Battery Pack .....4-3  
 Figure A-1. PXI-1025 MegaPAC Dimensions .....A-5

**Tables**

Table 4-1. Troubleshooting.....4-1  
 Table B-1. P1 (J1) Connector Pinout for the System Controller Slot .....B-2  
 Table B-2. P2 (J2) Connector Pinout for the System Controller Slot .....B-3  
 Table B-3. P1 (J1) Connector Pinout for the Star Trigger Slot .....B-4  
 Table B-4. P2 (J2) Connector Pinout for the Star Trigger Slot .....B-5  
 Table B-5. P1 (J1) Connector Pinout for the Peripheral Slot .....B-6  
 Table B-6. P2 (J2) Connector Pinout for the Peripheral Slot .....B-7

# About This Manual

---

The *PXI-1025 MegaPAC User Manual* describes the features of the PXI-1025 MegaPAC chassis and contains information about configuration, installing the modules, and operating the PXI-1025 MegaPAC.

## Conventions

---



The following conventions appear in this manual:

This icon denotes a note, which alerts you to important information.



This icon denotes a caution, which advises you of precautions to take to avoid injury, data loss, or a system crash.



This icon denotes a warning, which advises you of precautions to take to avoid being electrically shocked.

*italic*

Italic text denotes variables, emphasis, a cross reference, or an introduction to a key concept. This font also denotes text that is a placeholder for a word or value that you must supply.

monospace

Text in this font denotes text or characters that you should enter from the keyboard, sections of code, programming examples, and syntax examples. This font is also used for the proper names of disk drives, paths, directories, programs, subprograms, subroutines, device names, functions, operations, variables, filenames and extensions, and code excerpts.

## Related Documentation

---

The following documents contain information that you may find helpful as you read this manual:

- *CompactPCI Specification PICMG 2.0 R2.1*
- *PXI Specification Revision 1.0*
- *IEEE 1101.1-1991, IEEE Standard for Mechanical Core Specifications for Microcomputers Using IEC 603-2 Connectors*
- *IEEE 1101.10 and P1101.11, IEEE Standard for Additional Mechanical Specifications for Microcomputers Using IEEE 1101.1 Equipment Practice*

---

# Getting Started

This chapter describes the key features of the PXI-1025 MegaPAC chassis, lists the contents of your kit, and lists optional equipment you can order from National Instruments.

## Unpacking

---

Carefully inspect the shipping container and the chassis for damage. Check for visible damage to the metal work. Check to make sure all handles, hardware, and switches are undamaged. Inspect the inner chassis for any possible damage, debris, or detached components. If damage appears to have been caused in shipment, file a claim with the carrier. Retain the packing material for possible inspection and/or reshipment.

## What You Need to Get Started

---

The PXI-1025 MegaPAC kit contains the following items:

- PXI-1025 MegaPAC chassis
- Filler panels
- PXI-1025 MegaPAC User Manual*
- Floppy disk with Chassis Initialization file, `chassis.ini`

Other required equipment includes:

- AC Power Cord (Contact National Instruments to order your power cord)



**Note** AC mains supply cords used with the PXI-1025 MegaPAC must meet the requirements of ANSI/UL817 for use in the United States, CSA C22.2 21 and 49 for use in Canada, and IEC 227 or 245 for use in the European Union. AC mains power supply cords used with the PXI-1025 MegaPAC in other countries must be approved by the authority having jurisdiction in that country.

## Optional Equipment

---

Contact National Instruments to order the following options for your PXI-1025 MegaPAC chassis.

### Battery Pack and Cable for DC-Capable PXI-1025 MegaPAC

A DC input capable power supply is optionally installed in your PXI-1025 Mega PAC chassis at the factory. The DC-capable supply can be powered with AC input or 10 to 32 VDC input and has 150 W of output.

If you have purchased a PXI-1025 MegaPAC with the DC-capable power supply, you can install an optional 1.7 Ah NiCd battery pack. The chassis can draw power from this battery pack and operate when no AC or DC input are present or if the DC input drops below 10 V. The battery can power the PXI-1025 MegaPAC for up to 12 minutes under full load.

A DC input cable is available for the PXI-1025 MegaPAC with the DC-capable power supply. This cable contains an inline fuse and has unterminated ends allowing the user to install connectors for their specific DC source.

### Rack-Mount Kit

Optional rack-mount kits are available from National Instruments. These kits allow you to install the PXI-1025 MegaPAC chassis into a standard 19 in. (48 cm) wide instrument cabinet with a cabinet depth of either 24 in. (61 cm) or 30 in. (76 cm).

## Key Features

---


The PXI-1025 MegaPAC is a self-contained portable computer platform which combines a high-performance 8-slot PXI backplane with a high-output power supply and a structural design that has been optimized for maximum usability in a wide range of applications. The PXI-1025 MegaPAC fully complies with the PXI Specification, Revision 1.0, offering advanced timing and synchronization features.

The key features of the PXI-1025 MegaPAC include:


- PXI and CompactPCI (PICMG 2.0 R 2.1) module compatibility
- Compact, 8-slot chassis for portable applications
- 275 W of usable power; 150 W for DC-capable supply

- Universal AC input: auto-voltage and auto-frequency ranging
- Carrying handle/tilt stand
- Rear floor-standing feet double as a cable wrap
- Built-in CD ROM drive
- 10.4 in. 800 × 600 SVGA LCD color display
- Fold-down/removable keyboard with built-in pointing device and mouse buttons
- Temperature sensing module controls fan speed to maintain proper cooling


Figures 1-1, 1-2, and 1-3 show some of the key features and components of the PXI-1025 MegaPAC chassis. Figure 1-1 shows the front view of the PXI-1025 MegaPAC. Figure 1-2 shows the rear view of the AC-only chassis, and Figure 1-3 shows the rear view of the DC-capable chassis.



**Figure 1-1.** Front View of the PXI-1025 MegaPAC Chassis



**Figure 1-2.** Rear View of the AC-Only PXI-1025 MegaPAC Chassis



**Figure 1-3.** Rear View of the DC-Capable PXI-1025 MegaPAC Chassis

## PXI-1025 Backplane Overview

### Interoperability with CompactPCI

The PXI-1025 MegaPAC backplane is interoperable with PXI-compatible products and standard CompactPCI products. This is an important feature, as many PXI-compatible systems may not require components that do not implement PXI-specific features. For example, you may want to use a standard CompactPCI network interface card in a PXI chassis.

The signals on the P1 connector of the backplane meet the requirements of the CompactPCI specification for both the peripheral and system modules.

The PXI-specific signals are located on P2 and are only found on the signals that are reserved or not used in the CompactPCI 64-bit specification. Therefore, all modules that meet the requirements of the CompactPCI 64-bit specification will function in the PXI-1025 MegaPAC.

## System Controller Slot

The System Controller slot is located in Slot 1 of the chassis as defined by the PXI specification. It has three controller expansion slots, which are used for system controller modules that are wider than one slot. As defined in the PXI specification, these slots allow the controller to expand to the left to prevent the controller from using up peripheral slots.

## Star Trigger Slot

The Star Trigger (ST) slot is located at Slot 2. This slot has a dedicated trigger line between each peripheral slot (see Figure 1-4). This slot is intended for modules with ST functionality that can provide individual triggers to all other peripherals. Additionally, you can use the ST slot as a high-precision 10 MHz clock source. However, if you do not require advanced trigger functionality, you can install any standard peripheral module into this slot.

## Peripheral Slots

There are seven peripheral slots including the ST slot.


## Local Bus

The PXI backplane's local bus is a daisy-chained bus that connects each peripheral slot with its adjacent peripheral slots to the left and right, as shown in Figure 1-4.

For example, a given peripheral slot's right local bus connects to the adjacent slot's left local bus and so on. Each local bus is 13 lines wide and can pass analog signals between cards or provide a high-speed side-band communication path that does not affect the PCI bandwidth.

Local Bus signals may range from high-speed TTL signals to analog signals as high as 42 V. Initialization software keys adjacent boards to prohibit the use of incompatible boards. This software uses the configuration information specific to each peripheral board to evaluate compatibility. This method is a flexible way to define local bus functionality that is not limited by hardware keying.





**Figure 1-4.** PXI Local Bus and Star Trigger Routing

## Trigger Bus

The eight PXI trigger lines are bused to each slot. You can use the trigger lines in a variety of ways. For example, you can use triggers to synchronize the operation of several different PXI peripheral modules. In other applications, one module can control carefully timed sequences of operations performed on other modules in the system. Modules can pass triggers to one another, allowing precisely timed responses to asynchronous external events the system is monitoring or controlling.

## System Reference Clock

The PXI-1025 MegaPAC supplies the PXI 10 MHz system clock signal (PXI\_CLK10) independently to each peripheral slot. An independent buffer (having a source impedance matched to the backplane and a skew of less than 1 ns between slots) drives the clock signal to each peripheral slot. You can use this common reference clock signal to synchronize multiple modules in a measurement or control system. You can drive PXI\_CLK10 from an external source through the PXI\_CLK10\_IN pin on the P2 connector of the Star Trigger Slot. (See Table B-4, *P2 (J2) Connector Pinout for the Star Trigger Slot*, in Appendix B, *Pinouts*.) Sourcing an external clock on this pin automatically disables the backplane's 10 MHz source.

---

# Installation, Configuration, and Operation

This chapter describes how to prepare and operate your PXI-1025 MegaPAC chassis.


Before connecting the chassis to a power source, read this chapter and the *For Your Safety* section located at the beginning of this manual.

## Site Considerations

---

The PXI-1025 MegaPAC is designed to operate on a bench or in an instrument rack. Determine how you want to use your PXI-1025 Mega PAC and follow the appropriate installation instructions.


To facilitate power supply and module cooling, air enters through filters and fan inlets located in the lower rear of the chassis and exits through the upper section on the rear panel, as shown in Figure 2-1, *PXI-1025 MegaPAC Chassis Airflow Side View*. Place your PXI-1025 MegaPAC on a bench top or in an instrument rack so that the fans (air inlets) and the air outlet apertures along the rear of the chassis have adequate ventilation. Keep other equipment a minimum of 3.0 in. (76.2 mm) away from the air inlets and outlets.



**Figure 2-1.** PXI-1025 MegaPAC Chassis Airflow Side View

## Using Handle/Tilt Stand for Bench-Top Application

Press the handle release buttons located on each side of the chassis to release the handle. You can then rotate the handle shown in Figure 2-2 to a variety of positions. When the handle is at the desired position, release the buttons. Make sure it locks into position.



**Figure 2-2.** Using the Handle for Bench-Top Applications

## Fold-Down Keyboard

The removable fold-down keyboard is shown in Figure 1-1, *Front View of the PXI-1025 MegaPAC Chassis*. The fold-down keyboard incorporates a pointing device and left and right mouse buttons.

To close the keyboard it is necessary to grasp the coiled keyboard cable and pull it away from the LCD screen as you begin closing the keyboard. Keep pulling the cable higher while continuing to close the keyboard. Then release the cable just as the keyboard snaps into place.

To remove the keyboard unplug the coiled cable from the chassis, press the button on both sides of the keyboard and remove it.

## Rack Mounting

---

Rack-mount applications require one of the optional rack-mount kits available from National Instruments. Refer to the instructions supplied with the rack-mount kit to install your PXI-1025 MegaPAC in an instrument rack.

## Status LED Indicators

---

There are three status LED indicators on the PXI-1025 MegaPAC as shown in Figure 1-1, *Front View of the PXI-1025 MegaPAC Chassis*. The green LED indicates the main system power is on. The yellow LED indicates hard drive activity. The red LED indicates an internal over-temperature condition exists.

## Setting Fan Speed

---

The fan speed selector switch is located on the rear panel of the PXI-1025 MegaPAC. Refer to Figure 1-2, *Rear View of the AC-Only PXI-1025 MegaPAC Chassis*, or Figure 1-3, *Rear View of the DC-Capable PXI-1025 MegaPAC Chassis*, for the location of the fan speed selector switch. Select HIGH for maximum cooling or AUTO to employ the temperature sensing module that controls the fan speed.

## Connecting Safety Ground

---



**Warning** The PXI-1025 MegaPAC chassis is designed with a three-position NEMA 15-5 style plug that connects the ground line to the chassis ground. To minimize shock hazard, make sure your electrical power outlet has an appropriate earth safety ground that is connected whenever you power up the chassis.

If your power outlet does not have an appropriate ground connection, you must connect the premise wire safety ground to the chassis grounding screw located on the rear panel. Refer to Figure 1-2, *Rear View of the AC-Only PXI-1025 MegaPAC Chassis*, or Figure 1-3, *Rear View of the DC-Capable PXI-1025 MegaPAC Chassis*, for the location of the chassis

grounding screw. To connect the safety ground, complete the following steps:

1. Connect a 16 AWG (1.3 mm) wire to the chassis grounding screw using a toothed grounding lug. The wire must have green insulation with a yellow stripe or must be non-insulated (bare).
2. Attach the opposite end of the wire to permanent earth ground using toothed washers or a toothed lug.

## Connecting to Power Source

---

If your PXI-1025 MegaPAC has an AC-only input power supply, attach input power through the rear AC inlet using the appropriate line cord supplied. Refer to Figure 1-2, *Rear View of the AC-Only PXI-1025 MegaPAC Chassis*, for a diagram of the IEC 320 inlet.

If your PXI-1025 MegaPAC has a DC-capable power supply, you can attach an AC line cord or a DC cord if a DC power source is available.

Push the power switch to the On position (if not already on). Observe that all fans become operational.

## DC Connector (DC-Capable Chassis Only)

---

Figure 2-3 shows the DC connector (P1) on the rear panel of the DC-capable PXI-1025 MegaPAC.

If you want to build a custom DC cable, be sure to note the positive (+) and negative (–) terminals shown in Figure 2-3. Use the following components or their equivalents to mate to the P1 port:


- Positronic connector, part number CBD7W2F20000
- Norcomp hood, part number 972-015-010-011
- Two Positronic contacts, part number FS4008D

Install a 20 A inline fuse on the positive (+) wire of the custom cable.



**Note** You can purchase an optional DC cable from National Instruments that incorporates an inline fuse and the mating connector for the P1 port.

Figure 2-3 details the P1 connector on the chassis, *not* the cable.



**Figure 2-3.** DC Connector on Rear of DC-Capable PXI-1025 MegaPAC Chassis

## Installing the Battery Pack (DC-Capable Power Supply Only)

---

If you purchased a DC-capable PXI-1025 MegaPAC and an optional 1.7 Ah NiCd battery pack, install it according to the following steps and refer to Figure 2-4, [Installing Battery Pack](#).

1. Make sure the power switch is in the off position.
2. Disconnect AC power cord (and DC power cable, if attached).
3. Remove the two screws located on the center rail on each side of the rear bezel.
4. Pull the rear bezel away from the chassis until it slides out from the center rails.
5. Lift and pull the rear edge of the top cover to remove it.
6. Secure the battery pack inside the chassis using the four screws supplied with the battery pack.
7. Inside the chassis, there are two connectors cabled from the DC supply that mate with the two connectors cabled from the battery pack. Connect the two connectors to their corresponding mates.
8. Replace the top cover by inserting the front edge of the top cover onto the MegaPAC into the front bezel. Lower cover and make sure it fits into the grooves of the center rail on the left and right sides of the chassis.

9. Fit the rear bezel onto the covers so that it fits securely over the screw holes located on each side of the center rail.
10. Replace the two screws.
11. Reconnect the AC power cord (and DC power cable, if previously attached).




Figure 2-4. Installing Battery Pack

## Charging the Battery Pack (DC-Capable Power Supply Only)

The optional battery pack is charged when either the AC power or the external DC power is connected, regardless of the power switch position. The power supply has circuitry to prevent the battery pack from overcharging.



## Input Voltage Priority (DC-Capable Power Supply Only)

---

If more than one power source is connected at the same time, the priority of the power sources is as follows.

1. AC Input
2. DC Input
3. Internal Battery Pack

## Installing PXI Modules


---




**Caution** Turn off the chassis power before installing CompactPCI or PXI modules.

Install a module into a chassis slot by first placing the module's card edges into the front module guides (top and bottom), as shown in Figure 2-5, *Installing PXI or CompactPCI Modules*. Slide the module into the chassis (making sure that the injector/ejector handle is pushed down as shown in Figure 2-6, *Injector/Ejector Handle Position during Module Insertion*).

When you begin to feel resistance, push up on the injector/ejector handle to inject the card into the frame. Secure the module's front panel to the chassis using the module's front-panel mounting screws.



**Figure 2-5.** Installing PXI or CompactPCI Modules



**Figure 2-6.** Injector/Ejector Handle Position during Module Insertion

## Installing Filler Panels

---

To optimize module cooling performance, install filler panels into unused or empty slots. Secure with the captive mounting screws.

## Using the Chassis Initialization File

---

To assist system integrators, the PXI specification requires manufacturers of PXI chassis and system modules to document the capabilities of their products. The minimum documentation requirements are contained in `.ini` files, which consist of ASCII text. The system integrator can read the `.ini` file, and configuration utilities and device drivers can also use this file. The PXI-1025 MegaPAC chassis initialization file, `chassis.ini`, is included on the diskette for your PXI-1025 MegaPAC.

---

# Maintenance

This chapter describes basic maintenance procedures you can perform on the PXI-1025 MegaPAC chassis.

## Service Interval

---

Clean the chassis fan filter at a maximum interval of six months. Depending upon the amount of use and ambient dust levels in the operating environment, the filter may require more frequent cleaning.

Clean dust from the chassis exterior (and interior) as needed, based on the operating environment. Periodic cleaning increases reliability.

## Preparation

---

The information in this section is designed for use by qualified service personnel. Read the *For Your Safety* section at the beginning of this manual before attempting any procedures in this chapter.



**Caution** Many components within the chassis are susceptible to static discharge damage. Service the chassis only in a static-free environment. Observe standard handling precautions for static-sensitive devices while servicing the chassis. Always wear a grounded wrist strap, or equivalent, while servicing the chassis.

## Cleaning

---

Cleaning procedures consist of exterior and interior cleaning of the chassis and cleaning the fan filter. Refer to your module user documentation for information on cleaning the individual CompactPCI or PXI modules.



**Caution** Always power-off the chassis and disconnect the power cord before cleaning or servicing the chassis.

## Interior Cleaning

Use a dry, low-velocity stream of air to clean the interior of the chassis. Use a soft-bristle brush for cleaning around components. If you must use a liquid for minor interior cleaning, use a 75% isopropyl alcohol solution and rinse with deionized water.

## Exterior Cleaning

Clean the exterior surfaces of the chassis with a dry lint-free cloth or a soft-bristle brush. If any dirt remains, wipe with a cloth moistened in a mild soap solution. Remove any soap residue by wiping with a cloth moistened with clear water. Do not use abrasive compounds on any part of the chassis.

To clean the LCD display, wipe with lens paper or optical cloth.



**Cautions** Avoid getting moisture inside the chassis during exterior cleaning. Use just enough moisture to dampen the cloth.

Do *not* let any liquid or harsh chemicals come in contact with LCD display, as it may cause discoloration or spots.

Do *not* wash the connectors or switches. Cover these components while cleaning the chassis.

Do *not* use chemical cleaning agents; they may damage the chassis. Avoid chemicals that contain benzene, toluene, xylene, acetone, or similar solvents.

## Cleaning the Fan Filter

---

You can easily remove the fan filter from the bottom of the chassis by removing the two screws and filter bracket and sliding the filter out.

Clean the filter by washing it in a mild soap solution. Rinse the filter with water and allow it to dry before reinstalling.

# Troubleshooting

This chapter addresses solutions to various issues you might encounter with your PXI-1025 MegaPAC that are not described elsewhere in this manual.

## Troubleshooting the PXI-1025 MegaPAC

Refer to Table 4-1 to troubleshoot the PXI-1025 MegaPAC chassis. The table lists possible causes for power failure and recommends ways to correct the problem.

**Table 4-1.** Troubleshooting

| Possible Cause   | What to Do  |
|--|---|
| PXI-1025 MegaPAC chassis is not connected to power source.   | Make sure that the PXI-1025 MegaPAC is connected to a live electrical outlet. Try operating another piece of equipment from this outlet.  |
| Power switch is not switched on.   | Set the power switch to the On (1) position.  |
| If DC-capable PXI-1025 MegaPAC is powered by an external DC source, inline fuse on DC-power cord may be blown.   | Check fuse and replace, if necessary, with a 20 A 32 V Automatic Type Fuse (ATF).   |
| If DC-capable PXI-1025 MegaPAC is powered by an external DC source, DC input fuse on rear of chassis may be blown. (See Figure 1-3, <i>Rear View of the DC-Capable PXI-1025 MegaPAC Chassis.</i> ) | Check fuse and replace, if necessary, with a 20 A 32 V Automatic Type Fuse (ATF).   |
| If DC-capable PXI-1025 MegaPAC is powered by optional battery pack, the inline fuse to the battery pack may be blown.  | Check fuse and replace with a 10 A 32 V Automatic Type Fuse (ATF). See the section <i>Replacing the Fuse for Optional Battery Pack (DC-Capable Chassis Only)</i> in this chapter. |


**Table 4-1.** Troubleshooting (Continued)

| Possible Cause  | What to Do   |
|---|--|
| If DC-capable PXI-1025 MegaPAC is powered by an optional battery pack only, the battery pack may be discharged. | Connect PXI-1025 MegaPAC to AC or DC power source to charge battery. (Notice: The battery is charged whether the power switch is in the On or Off position). |
| Power supply has failed.  | Contact National Instruments.  |

## Replacing the Fuse for Optional Battery Pack (DC-Capable Chassis Only)

The optional battery pack for the DC-capable PXI-1025 MegaPAC has a 10 A inline automotive-type fuse. Complete the following steps to replace the fuse shown in Figure 4-1. Refer to Figure 2-4, *Installing Battery Pack*, for component location.

1. Make sure the power switch is in the off position.
2. Disconnect AC power cord (and DC power cable, if attached).
3. Remove the two screws located on the center rail on each side of the rear bezel.
4. Pull the rear bezel away from the chassis until it slides out from the center rails.
5. Lift and pull the rear edge of the top cover to remove it.
6. Replace the battery pack fuse.
7. Replace the top cover by inserting the front edge on to the MegaPac and into the front bezel. Lower the top cover so it fits into the grooves of the center rail on the left and right sides of the chassis.
8. Fit the rear bezel onto the covers so that it fits securely over the screw holes located on each side of the center rail.
9. Replace the two screws.
10. Reconnect the AC power cord (and DC power cable, if previously attached).



**Figure 4-1.** Optional Battery Pack



## Specifications

This appendix contains specifications for the PXI-1025 MegaPAC chassis.

### Electrical

#### AC Input Specifications for AC-Only Power Supply

Input voltage range..... 90–265 VAC

Input frequency range ..... 50 to 60 Hz

Power disconnect ..... The power switch causes the power module to supply DC power to the CompactPCI/PXI backplane. The power cord provides main power disconnect.

Efficiency ..... 70%

#### DC Output Specifications for AC-Only Power Supply

Maximum usable power ..... 275 W

Ripple and noise..... 1%, 20 MHz bandwidth

DC Current Capacity ( $I_{MP}$ )

| Voltage | $I_{MP}$ (Steady-State Current) | Regulation |
|---------|---------------------------------|------------|
| +3.3 V  | 10 A                            | 1%         |
| +12 V   | 9 A                             | 5%         |
| +5 V    | 32 A (3.3 V power)              | 5%         |
| -12 V   | .8 A                            | 5%         |

## AC Input Specifications for DC-Capable Power Supply

|                             |   |
|-----------------------------|---|
| Input voltage range .....   | 85–265 VAC  |
| Input frequency range ..... | 45 to 65 Hz   |
| Power disconnect .....      | The power switch causes the power module to supply DC power to the CompactPCI/PXI backplane. The power cord provides main power disconnect. |
| Efficiency.....             | 85%   |

## DC Input Specifications for DC-Capable Power Supply

|                              |   |
|------------------------------|---|
| Input voltage range .....    | 10–32 VDC   |
| DC to DC isolation .....     | 500 Vrms  |
| Over-current protection..... | Inline fuse must be installed into DC input cable   |
| Power disconnect .....       | The power switch causes the power module to supply DC power to the CompactPCI/PXI backplane. The power cord provides main power disconnect. |
| Efficiency.....              | 82%   |

## DC Output Specifications for DC-Capable Power Supply

Maximum usable power ..... 150 W

Ripple and noise ..... 1%, 20 MHz BW

DC Current Capacity ( $I_{MP}$ )

| Voltage | $I_{MP}$ (Steady-State Current) | Regulation |
|---------|---------------------------------|------------|
| +3.3 V  | 10 A                            | 2%         |
| +12 V   | 4 A                             | 2%         |
| +5 V    | 20 A (3.3 V power)              | 2%         |
| -12 V   | .4 A                            | 5%         |

## Cooling

Per slot cooling capacity ..... Slot cooling capacity in worst-case slot is 20 W with fan speed set to HIGH

Module cooling system ..... Forced air circulation (positive pressurization) via two fans with AUTO/HIGH speed selector

Slot airflow direction..... P1 to P2, bottom of module to top of module

Module cooling

Intake ..... Bottom rear of chassis

Exhaust..... Along rear of chassis

## Safety

UL 3111-1, IEC 1010-1, CSA 22.2 No. 1010.1

Installation Category II

Pollution Degree 2

Safety Class 1

## Environmental

|                                    |  |
|------------------------------------|--|
| Operating temperature .....        | 0 to 50 °C   |
| Storage temperature .....          | -20 to 70 °C   |
| Operating relative humidity .....  | 10 to 90%, noncondensing   |
| Functional shock (operating) ..... | MIL-T-28800E CLASS 3,<br>30 g half-sine shock pulse<br>(also meets IEC 60068-2-27) |
| Operating location .....           | Indoor use   |
| Random vibration                   |  |
| Operational .....                  | 5 to 500 Hz, 0.3 g <sub>RMS</sub>  |
| Non-operational <sup>1</sup> ..... | 10 to 500 Hz, 2.4 g <sub>RMS</sub>   |
| EMC emissions .....                | FCC Class A compliant and<br>EN 55011 Group 1 Class A<br>Compliant                 |
| EMC immunity .....                 | Refer to DOC supplied with<br>chassis for compliance to<br>relevant directives.    |

## Backplane

|            |   |
|------------|---|
| Size ..... | 3U-sized; one system slot<br>(with three system expansion<br>slots) and seven peripheral slots.<br>Compliant with IEEE 1101.10<br>mechanical packaging.<br>PXI Specification Revision 1.0<br>compliant.<br>Accepts both PXI and<br>CompactPCI (PICMG 2.0 R2.1)<br>3U modules. |
|------------|---|

---

<sup>1</sup> Random vibration profiles were developed in accordance with MIL-T-28800E CLASS 3 and MIL-STD-810E Method 514 Test levels exceed those recommended in MIL-STD-810E for Category 1 (Basic Transportation), Figures 514.4-1 through 514.4-3.

- Backplane bare-board material ..... UL 94 V-0 recognized  
(File No. E 116551)
- Backplane connectors ..... Conform to IEC 917 and  
IEC 1076-4-101, and are  
UL 94 V-0 rated

## Mechanical


Overall dimensions standard chassis

- Height..... 8.41 in. (21.36 cm)
- Width..... 16.25 in. (41.27 cm)
- Depth..... 18.25 in. (46.35 cm)

Weight ..... 28.1 lb. (12.74 kg)

Maximum module weight ..... 4 lb. (1.8 kg)

Figure A-1 shows the PXI-1025 MegaPAC dimensions.



**Figure A-1.** PXI-1025 MegaPAC Dimensions

---

## Pinouts

This appendix describes the P1 and P2 connector pinouts for the PXI-1025 Mega PAC backplane.

Table B-1 shows the P1 (J1) connector pinout for the System Controller slot.

Table B-2 shows the P2 (J2) connector pinout for the System Controller slot.

Table B-3 shows the P1 (J1) connector pinout for the Star Trigger slot.

Table B-4 shows the P2 (J2) connector pinout for the Star Trigger slot.

Table B-5 shows the P1 (J1) connector pinout for the peripheral slots.

Table B-6 shows the P2 (J2) connector pinout for the peripheral slots.



**Note** PXI signals are shown in **bold**.

**Table B-1.** P1 (J1) Connector Pinout for the System Controller Slot

| Pin   | Z        | A        | B        | C      | D      | E        | F   |
|-------|----------|----------|----------|--------|--------|----------|-----|
| 25    | GND      | 5V       | REQ64#   | ENUM#  | 3.3V   | 5V       | GND |
| 24    | GND      | AD[1]    | 5V       | V(I/O) | AD[0]  | ACK64#   | GND |
| 23    | GND      | 3.3V     | AD[4]    | AD[3]  | 5V     | AD[2]    | GND |
| 22    | GND      | AD[7]    | GND      | 3.3V   | AD[6]  | AD[5]    | GND |
| 21    | GND      | 3.3V     | AD[9]    | AD[8]  | M66EN  | C/BE[0]# | GND |
| 20    | GND      | AD[12]   | GND      | V(I/O) | AD[11] | AD[10]   | GND |
| 19    | GND      | 3.3V     | AD[15]   | AD[14] | GND    | AD[13]   | GND |
| 18    | GND      | SERR#    | GND      | 3.3V   | PAR    | C/BE[1]# | GND |
| 17    | GND      | 3.3V     | SDONE    | SBO#   | GND    | PERR#    | GND |
| 16    | GND      | DEVSEL#  | GND      | V(I/O) | STOP#  | LOCK#    | GND |
| 15    | GND      | 3.3V     | FRAME#   | IRDY#  | GND    | TRDY#    | GND |
| 12–14 | Key Area |          |          |        |        |          |     |
| 11    | GND      | AD[18]   | AD[17]   | AD[16] | GND    | C/BE[2]# | GND |
| 10    | GND      | AD[21]   | GND      | 3.3V   | AD[20] | AD[19]   | GND |
| 9     | GND      | C/BE[3]# | IDSEL    | AD[23] | GND    | AD[22]   | GND |
| 8     | GND      | AD[26]   | GND      | V(I/O) | AD[25] | AD[24]   | GND |
| 7     | GND      | AD[30]   | AD[29]   | AD[28] | GND    | AD[27]   | GND |
| 6     | GND      | REQ#     | GND      | 3.3V   | CLK    | AD[31]   | GND |
| 5     | GND      | BRSVP1A5 | BRSVP1B5 | RST#   | GND    | GNT#     | GND |
| 4     | GND      | BRSVP1A4 | GND      | V(I/O) | INTP   | INTS     | GND |
| 3     | GND      | INTA#    | INTB#    | INTC#  | 5V     | INTD#    | GND |
| 2     | GND      | TCK      | 5V       | TMS    | TDO    | TDI      | GND |
| 1     | GND      | 5V       | -12V     | TRST#  | +12V   | 5V       | GND |

**Table B-2.** P2 (J2) Connector Pinout for the System Controller Slot

| Pin | Z   | A                  | B                 | C                 | D                 | E                 | F   |
|-----|-----|--------------------|-------------------|-------------------|-------------------|-------------------|-----|
| 22  | GND | <b>PXI_RSVA22</b>  | <b>PXI_RSVB22</b> | <b>PXI_RSVC22</b> | <b>PXI_RSVD22</b> | <b>PXI_RSVE22</b> | GND |
| 21  | GND | RSV                | GND               | RSV               | RSV               | RSV               | GND |
| 20  | GND | RSV                | RSV               | RSV               | GND               | RSV               | GND |
| 19  | GND | RSV                | GND               | RSV               | RSV               | RSV               | GND |
| 18  | GND | <b>PXI_TRIG3</b>   | <b>PXI_TRIG4</b>  | <b>PXI_TRIG5</b>  | GND               | <b>PXI_TRIG6</b>  | GND |
| 17  | GND | <b>PXI_TRIG2</b>   | GND               | PRST#             | REQ6#             | GNT6#             | GND |
| 16  | GND | <b>PXI_TRIG1</b>   | <b>PXI_TRIG0</b>  | DEG#              | GND               | <b>PXI_TRIG7</b>  | GND |
| 15  | GND | <b>PXI_BRSVA15</b> | GND               | FAL#              | REQ5#             | GNT5#             | GND |
| 14  | GND | AD[35]             | AD[34]            | AD[33]            | GND               | AD[32]            | GND |
| 13  | GND | AD[38]             | GND               | V(I/O)            | AD[37]            | AD[36]            | GND |
| 12  | GND | AD[42]             | AD[41]            | AD[40]            | GND               | AD[39]            | GND |
| 11  | GND | AD[45]             | GND               | V(I/O)            | AD[44]            | AD[43]            | GND |
| 10  | GND | AD[49]             | AD[48]            | AD[47]            | GND               | AD[46]            | GND |
| 9   | GND | AD[52]             | GND               | V(I/O)            | AD[51]            | AD[50]            | GND |
| 8   | GND | AD[56]             | AD[55]            | AD[54]            | GND               | AD[53]            | GND |
| 7   | GND | AD[59]             | GND               | V(I/O)            | AD[58]            | AD[57]            | GND |
| 6   | GND | AD[63]             | AD[62]            | AD[61]            | GND               | AD[60]            | GND |
| 5   | GND | C/BE[5]#           | GND               | V(I/O)            | C/BE[4]#          | PAR64             | GND |
| 4   | GND | V(I/O)             | <b>PXI_BRSVB4</b> | C/BE[7]#          | GND               | C/BE[6]#          | GND |
| 3   | GND | CLK4               | GND               | GNT3#             | REQ4#             | GNT4#             | GND |
| 2   | GND | CLK2               | CLK3              | SYSEN#            | GNT2#             | REQ3#             | GND |
| 1   | GND | CLK1               | GND               | REQ1#             | GNT1#             | REQ2#             | GND |



**Table B-3.** P1 (J1) Connector Pinout for the Star Trigger Slot

| Pin   | Z        | A        | B        | C      | D      | E        | F   |
|-------|----------|----------|----------|--------|--------|----------|-----|
| 25    | GND      | 5V       | REQ64#   | ENUM#  | 3.3V   | 5V       | GND |
| 24    | GND      | AD[1]    | 5V       | V(I/O) | AD[0]  | ACK64#   | GND |
| 23    | GND      | 3.3V     | AD[4]    | AD[3]  | 5V     | AD[2]    | GND |
| 22    | GND      | AD[7]    | GND      | 3.3V   | AD[6]  | AD[5]    | GND |
| 21    | GND      | 3.3V     | AD[9]    | AD[8]  | M66EN  | C/BE[0]# | GND |
| 20    | GND      | AD[12]   | GND      | V(I/O) | AD[11] | AD[10]   | GND |
| 19    | GND      | 3.3V     | AD[15]   | AD[14] | GND    | AD[13]   | GND |
| 18    | GND      | SERR#    | GND      | 3.3V   | PAR    | C/BE[1]# | GND |
| 17    | GND      | 3.3V     | SDONE    | SBO#   | GND    | PERR#    | GND |
| 16    | GND      | DEVSEL#  | GND      | V(I/O) | STOP#  | LOCK#    | GND |
| 15    | GND      | 3.3V     | FRAME#   | IRDY#  | GND    | TRDY#    | GND |
| 12–14 | Key Area |          |          |        |        |          |     |
| 11    | GND      | AD[18]   | AD[17]   | AD[16] | GND    | C/BE[2]# | GND |
| 10    | GND      | AD[21]   | GND      | 3.3V   | AD[20] | AD[19]   | GND |
| 9     | GND      | C/BE[3]# | IDSEL    | AD[23] | GND    | AD[22]   | GND |
| 8     | GND      | AD[26]   | GND      | V(I/O) | AD[25] | AD[24]   | GND |
| 7     | GND      | AD[30]   | AD[29]   | AD[28] | GND    | AD[27]   | GND |
| 6     | GND      | REQ#     | GND      | 3.3V   | CLK    | AD[31]   | GND |
| 5     | GND      | BRSVP1A5 | BRSVP1B5 | RST#   | GND    | GNT#     | GND |
| 4     | GND      | BRSVP1A4 | GND      | V(I/O) | INTP   | INTS     | GND |
| 3     | GND      | INTA#    | INTB#    | INTC#  | 5V     | INTD#    | GND |
| 2     | GND      | TCK      | 5V       | TMS    | TDO    | TDI      | GND |
| 1     | GND      | 5V       | -12V     | TRST#  | +12V   | 5V       | GND |

**Table B-4.** P2 (J2) Connector Pinout for the Star Trigger Slot

| Pin | Z   | A           | B          | C          | D            | E          | F   |
|-----|-----|-------------|------------|------------|--------------|------------|-----|
| 22  | GND | PXI_RSVA22  | PXI_RSVB22 | PXI_RSVC22 | PXI_RSVD22   | PXI_RSVE22 | GND |
| 21  | GND | PXI_LBR0    | GND        | PXI_LBR1   | PXI_LBR2     | PXI_LBR3   | GND |
| 20  | GND | PXI_LBR4    | PXI_LBR5   | PXI_STAR0  | GND          | PXI_STAR1  | GND |
| 19  | GND | PXI_STAR2   | GND        | PXI_STAR3  | PXI_STAR4    | PXI_STAR5  | GND |
| 18  | GND | PXI_TRIG3   | PXI_TRIG4  | PXI_TRIG5  | GND          | PXI_TRIG6  | GND |
| 17  | GND | PXI_TRIG2   | GND        | PRST#      | PXI_CLK10_IN | PXI_CLK10  | GND |
| 16  | GND | PXI_TRIG1   | PXI_TRIG0  | DEG#       | GND          | PXI_TRIG7  | GND |
| 15  | GND | PXI_BRSVA15 | GND        | FAL#       | PXI_STAR6    | PXI_LBR6   | GND |
| 14  | GND | AD[35]      | AD[34]     | AD[33]     | GND          | AD[32]     | GND |
| 13  | GND | AD[38]      | GND        | V(I/O)     | AD[37]       | AD[36]     | GND |
| 12  | GND | AD[42]      | AD[41]     | AD[40]     | GND          | AD[39]     | GND |
| 11  | GND | AD[45]      | GND        | V(I/O)     | AD[44]       | AD[43]     | GND |
| 10  | GND | AD[49]      | AD[48]     | AD[47]     | GND          | AD[46]     | GND |
| 9   | GND | AD[52]      | GND        | V(I/O)     | AD[51]       | AD[50]     | GND |
| 8   | GND | AD[56]      | AD[55]     | AD[54]     | GND          | AD[53]     | GND |
| 7   | GND | AD[59]      | GND        | V(I/O)     | AD[58]       | AD[57]     | GND |
| 6   | GND | AD[63]      | AD[62]     | AD[61]     | GND          | AD[60]     | GND |
| 5   | GND | C/BE[5]#    | GND        | V(I/O)     | C/BE[4]#     | PAR64      | GND |
| 4   | GND | V(I/O)      | PXI_BRSVB4 | C/BE[7]#   | GND          | C/BE[6]#   | GND |
| 3   | GND | PXI_LBR7    | GND        | PXI_LBR8   | PXI_LBR9     | PXI_LBR10  | GND |
| 2   | GND | PXI_LBR11   | PXI_LBR12  | SYSEN#     | PXI_STAR7    | PXI_STAR8  | GND |
| 1   | GND | PXI_STAR9   | GND        | PXI_STAR10 | PXI_STAR11   | PXI_STAR12 | GND |

**Table B-5.** P1 (J1) Connector Pinout for the Peripheral Slot

| Pin   | Z        | A        | B        | C      | D      | E        | F   |
|-------|----------|----------|----------|--------|--------|----------|-----|
| 25    | GND      | 5V       | REQ64#   | ENUM#  | 3.3V   | 5V       | GND |
| 24    | GND      | AD[1]    | 5V       | V(I/O) | AD[0]  | ACK64#   | GND |
| 23    | GND      | 3.3V     | AD[4]    | AD[3]  | 5V     | AD[2]    | GND |
| 22    | GND      | AD[7]    | GND      | 3.3V   | AD[6]  | AD[5]    | GND |
| 21    | GND      | 3.3V     | AD[9]    | AD[8]  | M66EN  | C/BE[0]# | GND |
| 20    | GND      | AD[12]   | GND      | V(I/O) | AD[11] | AD[10]   | GND |
| 19    | GND      | 3.3V     | AD[15]   | AD[14] | GND    | AD[13]   | GND |
| 18    | GND      | SERR#    | GND      | 3.3V   | PAR    | C/BE[1]# | GND |
| 17    | GND      | 3.3V     | SDONE    | SBO#   | GND    | PERR#    | GND |
| 16    | GND      | DEVSEL#  | GND      | V(I/O) | STOP#  | LOCK#    | GND |
| 15    | GND      | 3.3V     | FRAME#   | IRDY#  | GND    | TRDY#    | GND |
| 12–14 | Key Area |          |          |        |        |          |     |
| 11    | GND      | AD[18]   | AD[17]   | AD[16] | GND    | C/BE[2]# | GND |
| 10    | GND      | AD[21]   | GND      | 3.3V   | AD[20] | AD[19]   | GND |
| 9     | GND      | C/BE[3]# | IDSEL    | AD[23] | GND    | AD[22]   | GND |
| 8     | GND      | AD[26]   | GND      | V(I/O) | AD[25] | AD[24]   | GND |
| 7     | GND      | AD[30]   | AD[29]   | AD[28] | GND    | AD[27]   | GND |
| 6     | GND      | REQ#     | GND      | 3.3V   | CLK    | AD[31]   | GND |
| 5     | GND      | BRSVP1A5 | BRSVP1B5 | RST#   | GND    | GNT#     | GND |
| 4     | GND      | BRSVP1A4 | GND      | V(I/O) | INTP   | INTS     | GND |
| 3     | GND      | INTA#    | INTB#    | INTC#  | 5V     | INTD#    | GND |
| 2     | GND      | TCK      | 5V       | TMS    | TDO    | TDI      | GND |
| 1     | GND      | 5V       | -12V     | TRST#  | +12V   | 5V       | GND |

**Table B-6.** P2 (J2) Connector Pinout for the Peripheral Slot

| Pin | Z   | A           | B          | C          | D          | E          | F   |
|-----|-----|-------------|------------|------------|------------|------------|-----|
| 22  | GND | PXI_RSVA22  | PXI_RSVB22 | PXI_RSVC22 | PXI_RSVD22 | PXI_RSVE22 | GND |
| 21  | GND | PXI_LBR0    | GND        | PXI_LBR1   | PXI_LBR2   | PXI_LBR3   | GND |
| 20  | GND | PXI_LBR4    | PXI_LBR5   | PXI_LBL0   | GND        | PXI_LBL1   | GND |
| 19  | GND | PXI_LBL2    | GND        | PXI_LBL3   | PXI_LBL4   | PXI_LBL5   | GND |
| 18  | GND | PXI_TRIG3   | PXI_TRIG4  | PXI_TRIG5  | GND        | PXI_TRIG6  | GND |
| 17  | GND | PXI_TRIG2   | GND        | PRST#      | PXI_STAR   | PXI_CLK10  | GND |
| 16  | GND | PXI_TRIG1   | PXI_TRIG0  | DEG#       | GND        | PXI_TRIG7  | GND |
| 15  | GND | PXI_BRSVA15 | GND        | FAL#       | PXI_LBL6   | PXI_LBR6   | GND |
| 14  | GND | AD[35]      | AD[34]     | AD[33]     | GND        | AD[32]     | GND |
| 13  | GND | AD[38]      | GND        | V(I/O)     | AD[37]     | AD[36]     | GND |
| 12  | GND | AD[42]      | AD[41]     | AD[40]     | GND        | AD[39]     | GND |
| 11  | GND | AD[45]      | GND        | V(I/O)     | AD[44]     | AD[43]     | GND |
| 10  | GND | AD[49]      | AD[48]     | AD[47]     | GND        | AD[46]     | GND |
| 9   | GND | AD[52]      | GND        | V(I/O)     | AD[51]     | AD[50]     | GND |
| 8   | GND | AD[56]      | AD[55]     | AD[54]     | GND        | AD[53]     | GND |
| 7   | GND | AD[59]      | GND        | V(I/O)     | AD[58]     | AD[57]     | GND |
| 6   | GND | AD[63]      | AD[62]     | AD[61]     | GND        | AD[60]     | GND |
| 5   | GND | C/BE[5]#    | GND        | V(I/O)     | C/BE[4]#   | PAR64      | GND |
| 4   | GND | V(I/O)      | PXI_BRSVB4 | C/BE[7]#   | GND        | C/BE[6]#   | GND |
| 3   | GND | PXI_LBR7    | GND        | PXI_LBR8   | PXI_LBR9   | PXI_LBR10  | GND |
| 2   | GND | PXI_LBR11   | PXI_LBR12  | SYSEN#     | PXI_LBL7   | PXI_LBL8   | GND |
| 1   | GND | PXI_LBL9    | GND        | PXI_LBL10  | PXI_LBL11  | PXI_LBL12  | GND |



---

# Technical Support Resources

This appendix describes the comprehensive resources available to you in the Technical Support section of the National Instruments Web site and provides technical support telephone numbers for you to use if you have trouble connecting to our Web site or if you do not have internet access.

## NI Web Support

---

To provide you with immediate answers and solutions 24 hours a day, 365 days a year, National Instruments maintains extensive online technical support resources. They are available to you at no cost, are updated daily, and can be found in the Technical Support section of our Web site at [www.ni.com/support](http://www.ni.com/support)

### Online Problem-Solving and Diagnostic Resources

- **KnowledgeBase**—A searchable database containing thousands of frequently asked questions (FAQs) and their corresponding answers or solutions, including special sections devoted to our newest products. The database is updated daily in response to new customer experiences and feedback.
- **Troubleshooting Wizards**—Step-by-step guides lead you through common problems and answer questions about our entire product line. Wizards include screen shots that illustrate the steps being described and provide detailed information ranging from simple getting started instructions to advanced topics.
- **Product Manuals**—A comprehensive, searchable library of the latest editions of National Instruments hardware and software product manuals.
- **Hardware Reference Database**—A searchable database containing brief hardware descriptions, mechanical drawings, and helpful images of jumper settings and connector pinouts.
- **Application Notes**—A library with more than 100 short papers addressing specific topics such as creating and calling DLLs, developing your own instrument driver software, and porting applications between platforms and operating systems.

## Software-Related Resources

- **Instrument Driver Network**—A library with hundreds of instrument drivers for control of standalone instruments via GPIB, VXI, or serial interfaces. You also can submit a request for a particular instrument driver if it does not already appear in the library.
- **Example Programs Database**—A database with numerous, non-shipping example programs for National Instruments programming environments. You can use them to complement the example programs that are already included with National Instruments products.
- **Software Library**—A library with updates and patches to application software, links to the latest versions of driver software for National Instruments hardware products, and utility routines.

## Worldwide Support

---

National Instruments has offices located around the globe. Many branch offices maintain a Web site to provide information on local services. You can access these Web sites from [www.ni.com/worldwide](http://www.ni.com/worldwide)

If you have trouble connecting to our Web site, please contact your local National Instruments office or the source from which you purchased your National Instruments product(s) to obtain support.

For telephone support in the United States, dial 512 795 8248. For telephone support outside the United States, contact your local branch office:

Australia 03 9879 5166, Austria 0662 45 79 90 0, Belgium 02 757 00 20,  
Brazil 011 284 5011, Canada (Calgary) 403 274 9391,  
Canada (Ontario) 905 785 0085, Canada (Québec) 514 694 8521,  
China 0755 3904939, Denmark 45 76 26 00, Finland 09 725 725 11,  
France 01 48 14 24 24, Germany 089 741 31 30, Greece 30 1 42 96 427,  
Hong Kong 2645 3186, India 91805275406, Israel 03 6120092,  
Italy 02 413091, Japan 03 5472 2970, Korea 02 596 7456,  
Mexico (D.F.) 5 280 7625, Mexico (Monterrey) 8 357 7695,  
Netherlands 0348 433466, Norway 32 27 73 00, Poland 48 22 528 94 06,  
Portugal 351 1 726 9011, Singapore 2265886, Spain 91 640 0085,  
Sweden 08 587 895 00, Switzerland 056 200 51 51,  
Taiwan 02 2377 1200, United Kingdom 01635 523545

# Glossary

---

| Prefix  | Meaning | Value     |
|---------|---------|-----------|
| n-      | nano-   | $10^{-9}$ |
| $\mu$ - | micro-  | $10^{-6}$ |
| m-      | milli-  | $10^{-3}$ |
| c-      | centi-  | $10^{-2}$ |
| k-      | kilo-   | $10^3$    |
| M-      | mega-   | $10^6$    |

## Symbols

|        |                       |
|--------|-----------------------|
| °      | Degrees               |
| $\geq$ | Equal or greater than |
| $\leq$ | Equal or less than    |
| %      | Percent               |

## A

|      |                                       |
|------|---------------------------------------|
| A    | Amperes                               |
| AC   | Alternating current                   |
| Ah   | Ampere hours                          |
| ANSI | American National Standards Institute |
| AWG  | American Wire Gauge                   |

## **B**

backplane An assembly, typically a printed circuit board, with connectors and signal paths that bus the connector pins

## **C**

C Celsius

cfm Cubic feet per minute

CFR Cooperative Fuel Research

CSA Canadian Standards Association

## **D**

daisy-chain A method of propagating signals along a bus, in which the devices are prioritized on the basis of their position on the bus

DC Direct current

## **E**

ECL Emitter-coupled logic

EIA Electronic Industries Association

EMC Electromagnetic Compatibility

## **F**

FCC Federal Communications Commission

## **G**

g 1) grams 2) A measure of acceleration equal to  $9.8 \text{ m/s}^2$

GPIB General Purpose Interface Bus (IEEE 488)



$g_{RMS}$  A measure of random vibration. The root mean square of acceleration levels in a random vibration test profile.

## H

Hz Hertz; cycles per second

## I

IEC International Electrotechnical Commission; an organization that sets international electrical and electronics standards

IEEE Institute of Electrical and Electronics Engineers

$I_{MP}$  Mainframe peak current

in. Inches

## L

lb Pounds

## M

m Meters

MTBF Mean time between failure

MTTR Mean time to repair

## N

NEMA National Electrical Manufacturers Association

## P

PXI PCI eXtensions for Instrumentation

## R

|     |   |
|-----|---|
| RH  | Relative humidity   |
| RMS | Root mean square. A method used to measure electrical output in volts and watts |

## S

|                   |   |
|-------------------|---|
| s                 | Seconds   |
| ST                | Star Trigger  |
| Star Trigger slot | This slot is located at slot 2 and has a dedicated trigger line between each peripheral slot. Use this slot for a module with ST functionality that can provide individual triggers to all other peripherals.   |
| System controller | A module configured for installation in Slot 1 of a PXI chassis. This device is unique in the PXI system in that it performs the PCI system controller functions, including clock sourcing and arbitration for data transfers across the backplane. Installing such a device into any other slot can damage the device, the PXI backplane, or both. |

## U

|    |                            |
|----|----------------------------|
| UL | Underwriter's Laboratories |
|----|----------------------------|

## V

|                 |                           |
|-----------------|---------------------------|
| V               | Volts                     |
| VAC             | Volts alternating current |
| V <sub>PP</sub> | Peak to peak voltage      |

## W

|   |       |
|---|-------|
| W | Watts |
|---|-------|

# Index

---

## B

- backplane, 1-5
  - interoperability with CompactPCI, 1-5
  - local bus, 1-6
  - overview, 1-5
  - peripheral slots, 1-6
  - specifications, A-4
  - Star Trigger (ST) slot, 1-6
  - system reference clock, 1-7
  - trigger bus, 1-7
- battery pack
  - charging, 2-7
  - DC connector (DC chassis only), 2-5
  - DC connector (figure), 2-6
  - description, 1-2
  - installation, 2-6
  - power supply module (figure), 2-5

## C

- chassis initialization file, 2-10
- CompactPCI
  - installing modules (figure), 2-9
  - interoperability with PXI-1025 MegaPAC backplane, 1-5
- configuration. *See* installation, configuration, and operation.
- cooling
  - air cooling of PXI-1025 MegaPAC, 2-1
  - air intake (figure), 2-2
  - filler panel installation, 2-10
  - setting fan speed, 2-4

## D

- DC connector (DC chassis only), 2-5
- DC connector (figure), 2-6

- dimensions (figure), A-5
- documentation
  - conventions used in manual, *xi*
  - related documentation, *xi*

## F

- fan
  - setting speed, 2-4
- fan filter
  - cleaning, 3-2
- filler panel installation, 2-10
- fold-down keyboard, 2-3

## G

- getting started
  - what you need, 1-1
- ground, connecting, 2-4

## H

- handle/tilt stand
  - using (figure), 2-3

## I

- IEC 320 inlet, 1-4, 2-5
- installation, configuration, and operation, 2-1 to 2-10
  - battery pack
    - charging, 2-7
    - installation, 2-6
  - chassis initialization file, 2-10
  - connecting safety ground, 2-4
  - filler panel installation, 2-10
  - input voltage priority (DC only), 2-8

- module installation, 2-8 to 2-9
  - (figure), 2-9
  - CompactPCI or PXI modules (figure), 2-9
  - injector/ejector handle position (figure), 2-9
- rack mounting, 2-4
- setting fan speed, 2-4
- site considerations, 2-1
- testing power up, 2-5
- unpacking the PXI-1025 MegaPAC, 1-1

interoperability with CompactPCI, 1-5

## K

- key features, 1-2
- kit contents, 1-1

## L

- LEDs
  - status LED indicators, 2-4
- local bus
  - routing (figure), 1-6, 1-7

## M

- maintenance of PXI-1025 MegaPAC, 2-1, 3-1
  - cleaning
    - exterior cleaning, 3-2
    - fan filter, 3-1, 3-2
    - interior cleaning, 3-2
  - preparation, 3-1
  - service interval, 3-1
  - static discharge damage (caution), 3-1
  - troubleshooting
    - causes, what to do (table), 4-1

## N

- National Instruments Web support, C-1

## O

- online problem-solving and diagnostic resources, C-1
- optional equipment, 1-2

## P

- P1 (J1) connector
  - peripheral slot (table), B-6
  - Star Trigger slot (table), B-4
  - system controller slot (table), B-2
- P2 (J2) connector
  - peripheral slot (table), B-7
  - Star Trigger slot (table), B-5
  - system controller slot (table), B-3
- peripheral slots
  - overview, 1-6
  - P1 (J1) connector pinouts (table), B-6
  - P2 (J2) connector pinouts (table), B-7
- pinouts, B-1
  - P1 (J1) connector
    - peripheral slot (table), B-6
    - Star Trigger slot (table), B-4
    - system controller slot (table), B-2
  - P2 (J2) connector
    - peripheral slot (table), B-7
    - Star Trigger slot (table), B-5
    - system controller slot (table), B-3
- power problems, troubleshooting, 4-1
- power supply
  - connecting to, 2-5
  - DC connector (DC chassis only), 2-5
  - DC connector (figure), 2-6
  - input voltage priority (DC only), 2-8
  - power supply module (figure), 2-5
- power up, testing, 2-5
- PXI\_CLK10, 1-7
- PXI\_CLK10\_IN pin, 1-7

**PXI-1025 MegaPAC**

- battery pack
    - charging, 2-7
    - DC connector (DC chassis only), 2-5
    - DC connector (figure), 2-6
    - description, 1-2
    - installation, 2-6
    - replacing fuse (DC only), 4-2
  - battery pack (figure), 4-3
  - cooling air intake (figure), 2-2
  - fan speed, setting, 2-4
  - fold-down keyboard, 2-3
  - frontview (figure), 1-4
  - handle/tilt stand, 2-3
  - installation
    - See* installation and configuration.
  - key features, 1-2
  - maintenance
    - See* maintenance of PXI-1025 MegaPAC.
  - optional equipment, 1-2
  - power supply module (figure), 2-5
  - rack mounting, 2-4
  - rack-mount kit, 1-2
  - rearview of AC-only (figure), 1-4
  - rearview of DC-capable (figure), 1-5
  - safety ground, connecting, 2-4
  - status LED indicators, 2-4
- PXI-1025 MegaPAC backplane, 1-5**
- interoperability with CompactPCI, 1-5
  - local bus, 1-6
  - overview, 1-5
  - peripheral slots, 1-6
  - specifications, A-4
  - Star Trigger (ST) slot, 1-6
  - system reference clock, 1-7
  - trigger bus, 1-7

**R**

- rack mounting, 2-4
- rack-mount kit, 1-2

**S**

- safety ground, connecting, 2-4
- safety specifications, A-3
- safety, warning and caution notices, *vi*
- service interval, 3-1
- setting fan speed, 2-4
- software-related resources, C-2
- specifications, A-1 to A-5
  - backplane, A-4
  - cooling, A-3
  - dimensions (figure), A-5
  - electrical, A-1
  - environmental, A-4
  - mechanical, A-5
  - safety, A-3
- Star Trigger (ST) slot
  - description, 1-6
  - P1 (J1) connector pinouts (table), B-4
  - P2 (J2) connector pinouts (table), B-5
- status LED indicators, 2-4
- system controller slot
  - description, 1-6
  - P1 (J1) connector pinouts (table), B-2
  - P2 (J2) connector pinouts (table), B-3
- system reference clock, 1-7

**T**

- technical support resources, C-1
- telephone support, C-2
- testing power up, 2-5
- trigger bus, 1-7
- troubleshooting the PXI-1025 MegaPAC (table), 4-1

## **U**

unpacking the PXI-1025 MegaPAC, 1-1

## **W**

Web support from National Instruments  
    online problem-solving and diagnostic  
        resources, C-1  
    software-related resources, C-2  
worldwide technical support, C-2