

# NI-SERIAL™ FOR USB INSTALLATION GUIDE

This guide includes instructions for installing your USB serial hardware and software.

Refer to the *Serial Hardware and Software for Windows User Manual* (in PDF format on the CD) for more information about troubleshooting problems, configuring the hardware and software, programming requirements, and more.

## Install the Software

---

Before you install your USB serial hardware, complete the following steps to install the NI-Serial (USB) Software for Windows 2000/XP:

1. Log in as administrator or as a user with administrator privileges.
2. Insert the *NI-Serial (USB) Software for Windows 2000/XP* CD.
3. If the NI-Serial (USB) setup starts automatically, follow the onscreen instructions and skip to *Install the Hardware*. Otherwise, select

---

National Instruments™, NI™, ni.com™, and NI-Serial™ are trademarks of National Instruments Corporation. Product and company names mentioned herein are trademarks or trade names of their respective companies. For patents covering National Instruments products, refer to the appropriate location: **Help»Patents** in your software, the `patents.txt` file on your CD, or `ni.com/patents`.

December 2002  
323365B-01

ni.com

© 2002 National Instruments Corp. All rights reserved.



**Start»Settings»Control Panel** and double-click the **Add/Remove Programs** icon. The **Add/Remove Programs** dialog box appears.

4. Click **Add New Programs** and then **CD or Floppy**, or click **Install**.
5. When prompted, insert the *NI-Serial (USB) Software for Windows 2000/XP* CD and click **Next**.
6. When prompted, click **Finish** to install the program files from the CD.
7. The setup wizard begins. The setup wizard guides you through the necessary steps to install the NI-Serial software. To exit the setup wizard at any time, click **Cancel**.

## Install the Hardware

---



**Note** If you are installing a USB-485/2 or USB-485/4, you may need to adjust the value of the bias resistors, depending on your application. For more information, refer to Chapter 7, *Using Your Serial Hardware*, in the *Serial Hardware and Software for Windows User Manual*.

To install your USB serial hardware, complete the following steps:

1. Install the software.
2. If you are installing a USB-485/4, connect the external power supply.
3. Connect the USB connector from the USB hardware to an available USB port on your computer or USB hub.
4. If your computer is not already on, power it on and start Windows 2000/XP.
5. Windows 2000/XP should automatically detect your hardware and display the Found New Hardware Wizard. If necessary, complete the wizard by clicking **Next** in each window and then **Finish**.

If the Found New Hardware Wizard does not appear, refer to Appendix D, *Troubleshooting and Common Questions*, in the *Serial Hardware and Software for Windows User Manual*.

The USB serial hardware installation is complete. Continue to the next section, *Verify the Installation*.

## Verify the Installation

---

To verify the hardware and software installation:

1. Run the diagnostic utility by selecting **Start»Programs»National Instruments»NI-Serial»USB»Diagnostics**.

The diagnostic utility verifies that your software is installed properly and that the serial driver can communicate with your serial hardware correctly.

If the test is successful, your serial hardware and software are installed properly. If the test fails, refer to Appendix D, *Troubleshooting and Common Questions*, in the *Serial Hardware and Software for Windows User Manual*.

2. After you verify the hardware and software installation, connect the serial cables to your device(s). Refer to Appendix A, *Connector Descriptions*, in the *Serial Hardware and Software for Windows User Manual*.