

Field Feature Bill of Material (FBM)

PN 08J5505

RPQ 7L1331 or 7L1332

**Replace ESCP (FC 5500) or ESCP2 (FC 5522) with ESCP3 (FC 5523)
in IBM 3746 Models 9X0**

Written by: J. Michaut
Checked by: F. Falconetti
Approved by: A. Badino
Reviewed by: B. Kelly

3746 FFBM	PN 08J5505 1 of 12	EC F12406 29AUG97				
--------------	-----------------------	----------------------	--	--	--	--

Before Installation (Steps 1-8)

Net Priced Feature

All parts removed from this machine are IBM property and must be returned to IBM.

1.0 Machines Affected

3746 Models 900 or 950.

This feature should only be applied on the machine serial for which it is specified.

2.0 Related BMs and ECs

2.1 Prerequisites

(Must be installed prior to this installation)

- EC microcode D46130D minimum level or higher.

Checkpoint: Check that the CSS basic level packaging unit (BLPU) EC level is D46133-011 or higher.

(Refer to SPIM, Chapter 3, 'Displaying the EC Level of Code Installed on the Hard Disk).

2.2 Concurrent

(Must be installed together)

None.

2.3 Companion

(May be installed together)

None.

3.0 BMs to be Used

FFBM	Title
08J5274	Replace ESCP (FC 5500) or ESCP2 (FC 5222) with ESCP3 (FC 5523)
08J5505	Installation Instructions.

4.0 Preparation

1. Familiarize yourself with the purpose and details of the installation instruction before negotiating machine time with the customer.
2. Check all items listed on the BM(s) to determine that all parts have been received.
3. *This FFBM contains ESD sensitive parts. Prior to handling such part refer to "ESD Sensitive Parts Handling," outlined in Service Memorandum No. 305 of the IBM General Technical Service Memorandums group, IBM order number S230-9009.*
4. Obtain the *HONE configuration/plugging sheet* from the Customer or from the IBM representative.

5.0 Programming

5.1 Diagnostic Programs

None.

6.0 Purpose and Description

6.1 Purpose

Replace ESCP (FC 5500) or ESCP2 (FC 5522) with ESCP3 (FC 5523).

6.2 Description

Exchange of a cassette processor.

7.0 Installation Time

FFBM	Machine Hours	System Hours	Nbr. CE
08J5274	0.5	0.0	1

8.0 Tools/Materials Required

Part No. Name.
6428316 ESD kit

Installation (Steps 9-12)

9.0 Safety

Review the **Safety Notices** and the **Safety Inspection Procedures** located at the beginning of the *IBM 3745 Communication Controller All Models, IBM 3746 Expansion Unit Model 900, IBM 3746 Nways Multinetwork Controller Model 950 Safety Information*, GA33-0400.

10.0 Details of the Installation

Before the installation, ask the customer:

- ___ • To deactivate resources for the identified coupler/processor.
- ___ • For the maintenance password.
- ___ • To logoff the Service Processor (SP), if not already done.

10.1 Setting 3746-9x0 Power Mode

On the 3746-9x0 Control Panel:

- ___ Check that the **Power Control** indicator displays **3**.

If it does not record the value ___, press the **Power Control** key until (3) is displayed in the Power Control window. Then, press the **Validate** key.

Otherwise continue with next step.

10.2 Logging ON the Service Processor.

- ___ 1. On **MOSS-E View** window, click on **Program**.
- ___ 2. Click on **LOG ON MOSS-E**.
- ___ 3. Enter the Maintenance Password. Then, press **ENTER**.

10.3 Replacing the Processor.

On the Service Processor:

- ___ 1. Double click on the 3746-9x0 icon.
- ___ 2. On **3746-9x0 Menu** window, click on **Problem Management** option..
- ___ 3. Double click on **Perform Maintenance** option.
- ___ 4. On the **Resource Options Selection for maintenance** window, click on **Via the Active CDF-E** option, then click on **OK**.

- ___ 5. On the **Resource Selector** window, select (click on) the ESCP you want to replace.
- ___ 6. Once the resource is set to concurrent mode, the **Maintenance Options** window is displayed.
- ___ 7. Click on **Replace the Resource** option, then click on **OK**.
- ___ 8. On **Confirmation** window, click on **OK**.

From the front side of the 3746-9x0:

- ___ 9. Open the front cover.
- ___ 10. Locate the ESCP or ESCP2 cassette to be replaced.
(Refer to the *HONE configuration/plugging sheet* and the following figures).

Q	P	M	K	H	F	D	B
Dummy	TRP / ESCP / CLP	TRP / ESCP / CLP	TRP / ESCP / CLP	TRP / ESCP / CLP	CBSP	SPS	CSCE

Figure 1. Basic Enclosure

Q	P	M	K	H	F	D	B
Dummy	TRP / ESCP / CLP	TRP / ESCP / CLP	TRP / ESCP / CLP	TRP / ESCP / CLP	TRP / ESCP / CLP	TRP / ESCP / CLP	CSCE

Figure 2. 1st or 2nd Expansion Enclosure.

Warning

Use the ESD kit and procedures.

- ___ 11. Remove the ESCP or ESCP2 cassette (Follow the instruction label affix close to the enclosure).
- ___ 12. Insert the ESCP3 cassette into the enclosure and slide it firmly until it clicks (Locks in).
- ___ 13. If there was a cable in front of the ESCP, plug it on the ESCP3 and secure it with the bracket previously removed.
- ___ 14. Wait until the **Alarm xxxx FRU Unplugged**, and **Alarm xxxx FRU Plugged** messages are displayed on the Service Processor screen, then continue.
- ___ 15. On the **Confirmation** window, click on **OK**.
- ___ 16. Return to the **Maintenance Options** window.
- ___ 17. Click on **Perform Diagnostics on the resource** option, then click on **OK**.
- ___ 18. A **Diagnostics** window is displayed. Check that the **Specific adapter** and **No wrap** options are selected, then click on **Start**.

- ___ 19. A **Specific Adapter** window is displayed, select (click on) the ESCP3 just installed, then click on **OK**
- ___ 20. The **Diagnostics** window is displayed again and the **Elapsed time** is incremented during the test.

At the end of the test, the number of errors is indicated by an arrow.
 - ___ a. If there is an error: Call support for assistance
 - ___ b. Otherwise, click on **Cancel** to return to the **Maintenance Options** window, then continue on next step.
- ___ 21. Click on **Initialize the Resource** option to reinitialize the ESCP3.
- ___ 22. Follow the instruction of the **Warning** window, then click on **OK** when prompted.
- ___ 23. The **Maintenance Options** window is displayed
- ___ 24. Click on **Remove the Resource from the Concurrent Mode** option, then click on **OK**
- ___ 25. On the **Warning** window, click on **OK**
- ___ 26. On the **Resource Selector** window, click on **Cancel**
- ___ 27. Return to the **3746-9x0 Menu** window

10.4 Upgrading EEPROM.

- ___ 1. On the **3746-9x0 Menu** window, click on **Change Management**.
- ___ 2. Double click on **Upgrade/Downgrade EEPROM Code Level**.
A window is displayed with a message box saying that the service processor is searching the 3746-9x0 configuration.
On **EEPROM Upgrade** window, the processors subject to upgrade or downgrade are **highlighted** according to the preselected status of the options "Upgrade" or "Downgrade" on the top of the window (see Figure 3).

☐ Upgrade ☐ Downgrade

Processor	EEPROM level: PN - EC - MCL	Upgrade Status
CBSP 2048 Available	Current: 43G3435 - D21455 - 002 New : 43G3435 - D22455 - 008	
ESCP 2112 Disconnected	Current: 43G3425 - D22455 - 007 New : 43G3425 - D22455 - 008	
ESCP 2167 Available	Current: 43G3435 - D22455 - 001 New : 43G3435 - D22455 - 008	
ESCP 2304 Active	Current: 43G3425 - D22455 - 037 New : 43G3425 - D22455 - 008	

1
2
3

Figure 3. Example of An EEPROM Upgrade Window

- 1** Gives the list of the 3746-9x0 processors in CDF-E with their status (available/disconnected/active).
 - 2** Gives the current and new EEPROM level: PN/EC/Level of each processor.
 - 3** Gives the status after the activation of the function.
- ___ 3. According to the action that you want to do, Select the **"Upgrade"** or **"Downgrade"** option on the top of the screen, then click on **OK**
An "EEPROM Upgrade" window informs you that the EEPROM upgrade or downgrade is in progress with its time duration.
At the end, a status is displayed for each processor.
- ___ 4. Check the result of your EEPROM upgrade/downgrade operation with the following table and take the appropriate action:

EEPROM Status	Action
Complete	Upgrade done without error continue with the next step.
Start failed	Call your support
Failed	Call your support
Completion failed	Call your support

- ___ 5. Return to the **3746-9x0 Menu**, then click on **Operation Management**.
- ___ 6. Double click on the **Perform General IML with Diagnostics**.
A Normal IML must be terminated by 00000000 displayed on the 3746-9x0 control panel.

10.5 Saving CDF-E on Diskette

- ___ 1. Double click on the SP icon.
- ___ 2. The **Service Processor Menu** window is displayed.
- ___ 3. Click on **Configuration Management**.
- ___ 4. Double click on **Manage 3745-3746-9x0 Installation**.
- ___ 5. The **Controller Installation** window is displayed.
- ___ 6. Click on the machine you are installing/removing the cassette.
- ___ 7. Click on **Save**.
- ___ 8. When requested, insert the *Installation Parameters Diskette* in the diskette drive of the SP.
- ___ 9. When the **Warning** window is displayed, remove the diskette and click on **OK**.
- ___ 10. The **Controller Installation** window is displayed.
- ___ 11. Click on **Cancel**.
- ___ 12. The **3746-9x0 Menu** window is displayed.

10.6 Re-setting 3746-9x0 Power Mode

- The **Power Control** is local (3).
If its original value was (1) Remote, do the following:
 - On the Control Panel, press the **Power Control** key until (1) is displayed in the Power Control window, then
 - Press the **Validate** key.

10.7 Logging OFF the Service Processor.

- 1. Return to the **3746-9x0 Menu** window,
- 2. Click on **Function**, then click on **Exit**.
- 3. On the **MOSS-E View** window, click on **Program**.
- 4. Click on **LOG OFF MOSS-E**.

11.0 Test Procedures

No Test Required.

12.0 Field Updating

None.

After Installation (steps 13-15)

13.0 Publications Update

None.

14.0 Parts Disposition

All replaced/removed parts become the property of IBM. You **MUST RETURN** these parts following the instructions given on the Returned Material Equipment Report (RMER) provided with this FFBM.

15.0 Machine Records

- Install the new **MACHINE HISTORY** supplied.
- Report installation and quality to existing procedures.

*** End of instructions ***

