

# SAILOR 33 Fleet+ Installation Check List

The check list is an aid in securing that all necessary settings have been made following the installation of SAILOR 33 Fleet+.

References are made to the SAILOR 33 Fleet+ **Getting Started** manual and the **User Guide** on the enclosed CD.

Configuration from PC is done by downloading the SAILOR vtLite program from the CD, see **Getting Started**>Installing the PC program.

**Check that all grounding conditions are according to the installation appendix in Getting Started!**

## Antenna Unit

When placing the antenna avoid obstructions and interference.

## Below Deck Equipment

Ensure a free space around the BDU of at least 10 cm for adequate cooling, and to allow removal of the unit.

Ref No	Action	Function	No	Comments/settings
1	<input type="checkbox"/> Switch ON SAILOR 33 Fleet+. (wait for initialization to finish)			Disregard alarm readouts
2	<input type="checkbox"/> Start satellite search, if needed. Signal strength: typically 540 (should be at least 500 when idle).	<b>Sat. Search</b>	HS menu	See <i>HANDSET</i> > <i>FUNCTIONS</i> > <i>Satellite search</i>
3	<input type="checkbox"/> Program the "Net service provider" for an Ocean Region.	<b>Set default</b>	HS menu	See <i>HANDSET</i> <i>FUNCTIONS</i> > <i>Selecting</i> <i>default Net service provider</i>
4	<input type="checkbox"/> Program Net service providers for all Ocean Regions	<b>Set default using SAILOR vtLite</b>	1	See <i>CONFIGURATION FROM PC</i> > <i>Set default net provider</i>
5	<input type="checkbox"/> Change to "Owner Level"	<b>Set access level</b>	2	See <i>CONFIGURATION FROM PC</i> > <i>Access level.</i>
6	<input type="checkbox"/> Set "Diagnostics" to ON	<b>Set diagnostics</b>	974	See <i>CONFIGURATION FROM PC</i> > <i>Configuration</i> > <i>set diagnostics.</i>
7	<input type="checkbox"/> The first SAILOR ISDN Handset will be given: MSN20 - terminal ID01, and MSN22 - terminal ID03		HS menu	Automatically selected. See handset settings, "Active MSN" to verify.
8	<input type="checkbox"/> Enable "Traffic log"	<b>Log</b> (see Main window)	Log	See <i>OPERATION FROM PC</i> > <i>Traffic log</i> > <i>Traffic log settings.</i>
9	<input type="checkbox"/> Configure all external TAs with MSN number.	Check with <b>Getting Started</b> manual		See the user instruction for the specific TA

<p><b>10</b> <input type="checkbox"/></p>	<p>Configure the BDU with MSN numbers (if beyond the pre-programmed MSN numbers)</p>	<p><b>Device manager</b> (select from Main window)</p>		<p>See <i>CONFIGURATION FROM PC &gt; Routing of incoming calls and/or MSN configuration.</i></p>
<p><b>11</b> <input type="checkbox"/></p>	<p>Make a 4.8 kbps voice call</p>	<p><b>Handset</b></p>		<p>See <i>OPERATION FROM HANDSET &gt; Making a call.</i></p>
<p><b>12</b> <input type="checkbox"/></p>	<p>Make a fax call</p>	<p>Via <b>TA</b></p>		<p>See <i>TELEFAX SERVICE</i></p>
<p><b>13</b> <input type="checkbox"/></p>	<p>Make a data call</p>			<p>See <i>CD &gt; Applications:</i>  <ul style="list-style-type: none"> <li>• <i>Mobile Data Service (RS-232/USB)</i></li> </ul> </p>
<p><b>14</b> <input type="checkbox"/></p>	<p>Check the traffic log performance after above calls</p>	<p><b>Log</b> (see Main window)</p>	<p>Log</p>	<p>See <i>OPERATION FROM PC &gt; Traffic log &gt; Traffic log readout.</i></p>
<p><b>15</b> <input type="checkbox"/></p>	<p>Check alarm list</p>	<p><b>Alarms and messages</b></p>	<p>941</p>	<p>See <i>CD &gt; Additional manuals &gt; Alarms and Messages</i></p>