

Agilent 86060C-Series Lightwave Switches

Please read the following messages before connecting cables to your Agilent 86060C-series lightwave switch.

WARNING! On Option 002 dual input instruments, any light on an unselected “A” channel will likely be output on one of the unselected “B” channels.

WARNING! On Option 002 dual input instruments, any light on an unselected “B” channel will likely be output on an unselected “A” channel.

WARNING! To avoid exposure to light energy, always cover all unused channels.

CAUTION! Failure to observe proper fiber-optic connection techniques could result in serious damage to the fiber-optic connectors on the Agilent 86060C-series lightwave switch. These connectors are not easily cleaned. Therefore, it is very important that you clean all fiber-optic cables before connecting them to the lightwave switch. Refer to “Care of Fiber-Optic Connectors” in Chapter 1 of the *Agilent 86060C-Series Lightwave Switches User’s Guide*.



