

## S E R V I C E N O T E

SUPERSEDES: None

**8664A Synthesized Signal Generator**

Serial Numbers: See Below

**Disconnect line power when connecting and disconnecting ribbon cables****Duplicate Service Notes:**

8644A-05 Serials: 0000A00000 / 9999Z99999

8644B-05 Serials: 0000A00000 / 9999Z99999

8645A-06 Serials: 0000A00000 / 9999Z99999

8664A-07 Serials: 0000A00000 / 9999Z99999

8665A-08 Serials: 0000A00000 / 9999Z99999

8665B-06 Serials: 0000A00000 / 9999Z99999

**To Be Performed By:** Agilent-Qualified Personnel**Situation:**

DC power is supplied to certain modules for heating and battery charging while line power is connected, even with power off. Connecting or disconnecting ribbon cables or modules plugged into the motherboard with line power connected can result in electrical damage to sensitive components in the instrument. It is recommended that instruments be unplugged for any service requiring the disconnection of ribbon cables or modules plugged into the motherboard.

DATE: August 1998

## ADMINISTRATIVE INFORMATION

SERVICE NOTE CLASSIFICATION:		
<b>INFORMATION ONLY</b>		
AUTHOR:	ENTITY:	ADDITIONAL INFORMATION:
MW	5320	NONE