




**Instant Setback Cubby  
(for PACE TD-100 Handpieces only)  
PACE PART NUMBER 6019-0071-P1  
Installation and Maintenance Instructions  
MANUAL NUMBER 5050-0561**

1. Turn power switch to the OFF position. Allow the TD-100 handpiece to cool before connecting the instant setback cubby.
2. Connect Cubby cable to receptacle located on the rear panel of the power supply.
3. Position the Cubby on workbench within operator reach.
4. Insert TD-100 with tip into Cubby.
5. Turn power switch to the on position.
6. When the TD-100 handpiece is inserted into the Cubby, the system will automatically go into the Setback Mode after 45 seconds of non-use. Once the Handpiece is removed from the Cubby, it will return to normal operation.



**WARNING**

Keep the Cubby's handpiece holder free of solder debris. Solder build up may prevent system from correctly sensing tip temperature.



Handpiece holder

**NOTE**

The Instant-Set Back Cubby will not operate with the TD-100N Nitrogen handpiece.



**PACE Incorporated**  
9030 Junction Drive  
Annapolis Junction,  
MD 20701  
Tel: (301) 490-9860  
Fax: (301) 498-3252

**PACE Europe Limited**  
13 Tanners Drive  
Blakelands  
Milton Keynes  
Tel: (44) 1908-277666  
Fax: (44) 1908-277777