

Technical Note

512-0043-01-01 Rev 1

Calculating Run Times of Your Battery**Overview**

How long your appliance will operate from a particular battery is dependent on the appliance's power consumption in watts (or AC amps x 115 V), and the battery capacity. Low inverter efficiency, and improper battery wiring during installation can also reduce run time.

Calculating run time

The following formula can be used to determine run time in most applications using a 12 V battery or bank:

$$\frac{10 \times (\text{Battery Capacity in Amp Hours})}{(\text{Load power in Watts})} = \text{Run time in hours}$$

Example:

How long will my 100 watt TV run with my PW150 from my car's engine start battery (60 Ah)?

The load is well within the PROwatt inverter's maximum power rating, therefore the inverter itself will not limit the run time.

$$\frac{10 \times (60 \text{ Ah})}{(100 \text{ W})} = 6 \text{ hours maximum run time before the battery is completely discharged, or 3 hours run time before the battery is 50\% discharged. You should still be able to start your car at this point.}$$

Estimated Run time for continuous operation using standard battery capacities						
Appliance power in Watts	BCI Group Size >	22NF	24	27	4D	8D
	Reserve Capacity >	90 minutes	140 min.	180 min.	325 min.	400 min.
	Appliance	50 amp hours	75 Ah	100 Ah	160 Ah	200 Ah
50	Stereo	9 hours	14 hrs	20 hrs	32 hrs	40 hrs
100	19" Color TV	4	6	10	16	20
200	Computer	2	3	4.5	7	10
300	Blender	1.3	2.2	3	4.5	6
400	Drill	1	1.5	2	3	4.5

Estimated Run time for continuous operation using standard battery capacities						
Appliance power in Watts	BCI Group Size >	22NF	24	27	4D	8D
	Reserve Capacity >	90 minutes	140 min.	180 min.	325 min.	400 min.
	Appliance	50 amp hours	75 Ah	100 Ah	160 Ah	200 Ah
600	Coffee Maker	N.R.	N.R.	1	2	2.5
800	Small Microwave	N.R.	N.R.	N.R.	1	1.5
1000	Toaster	N.R.	N.R.	N.R.	0.5	1
1500	Large Microwave	N.R.	N.R.	N.R.	N.R.	0.5

Tips

Engine start batteries should not be discharged below 90% remaining charge-state, and marine deep cycle batteries should not be discharged below 50% remaining charge state. Doing this will shorten the life of the battery based on most battery manufacturers' recommendations.

The PROwatt 250 is factory equipped with a lighter plug for easy connection of smaller loads. However, for loads above 100 W you will require direct connection to the battery terminals to eliminate a thin/long battery wire voltage loss that could drastically shorten the run time on a given system.

If you intend to use power tools for commercial use, or any load of 200 W for more than 1 hour regularly (between battery recharging) you should install an auxiliary battery to provide power to the inverter. This battery should be a deep cycle type and sized to meet your run time expectations with the engine off. Deep cycle batteries most commonly available are 27 (90 Ah), 4D (150 Ah), 8D (220 Ah) capacity. The auxiliary battery should be connected to the alternator through an isolator module to prevent the inverter from discharging the engine start battery when the engine is off.

See the Xantrex Web site, or your inverter manual for more information, or contact Xantrex Customer Support.

Xantrex is a registered trademark of Xantrex International.
© 2002 Xantrex International. All rights reserved.

Technical Note: *Calculating run Times of Your Battery* © March 1998 Xantrex International

UNLESS SPECIFICALLY AGREED TO IN WRITING, XANTREX TECHNOLOGY INC. ("XANTREX"):

(a) MAKES NO WARRANTY AS TO THE ACCURACY, SUFFICIENCY OR SUITABILITY OF ANY TECHNICAL OR OTHER INFORMATION PROVIDED IN ITS MANUALS OR OTHER DOCUMENTATION.

(b) ASSUMES NO RESPONSIBILITY OR LIABILITY FOR LOSS OR DAMAGE, WHETHER DIRECT, INDIRECT, CONSEQUENTIAL OR INCIDENTAL, WHICH MIGHT ARISE OUT OF THE USE OF SUCH INFORMATION. THE USE OF ANY SUCH INFORMATION WILL BE ENTIRELY AT THE USER'S RISK.

Part number: 512-0043-01-01 Rev 1

Contact information:

Phone: 1-800-670-0707 (toll-free in North America)

Phone: 1-604-422-2777 (direct)

Fax: 1-604-420-2145 (outside North America)

Email: CustomerService@xantrex.com

Web: www.xantrex.com