

GETTING STARTED


1

Insert CD, then choose Install NI-488.2 Software for Windows.



2

Shut down, then power off computer.



Power Off
Computer


(Continued)

3

Install hardware*.

- A. Select an unused 5 V bus master slot for the PXI-GPIB. **Note:** If you use a non-master slot, you must disable onboard DMA using `i.bdma`. Refer to the NI-488.2 online help, available through the Measurement & Automation Explorer help, for help using `i.bdma`.
- B. Insert the PXI-GPIB into the selected 5 V slot.

* **For Help** installing your hardware, refer to the GPIB Hardware Guide (available on the CD through View Documentation).



- C. Screw the front panel of the PXI-GPIB to the chassis's injector/ejector rail.

Key

- ① Injector/Ejector Handle (In down position)
- ② PXI-GPIB Board
- ③ PXI Chassis
- ④ Injector/Ejector Rail

4

Power on computer, then run NI-488.2 Getting Started Wizard.





www.natinst.com/support/
support@natinst.com

Tel: (512) 795-8248 • Fax: (512) 683-5678
Fax-on demand: (512) 418-1111 • [ftp.natinst.com](ftp://ftp.natinst.com)



322267A-01 020899