

# MIPS32 M4K<sup>TM</sup> Processor Core Software User's Manual

Document Number: MD00249 Revision 1.02 December 15, 2003

MIPS Technologies, Inc. 1225 Charleston Road Mountain View, CA 94043-1353

Copyright © 2000-2003 MIPS Technologies Inc. All rights reserved.

Copyright © 2000-2003 MIPS Technologies, Inc. All rights reserved.

Unpublished rights (if any) reserved under the copyright laws of the United States of America and other countries.

This document contains information that is proprietary to MIPS Technologies, Inc. ("MIPS Technologies"). Any copying, reproducing, modifying or use of this information (in whole or in part) that is not expressly permitted in writing by MIPS Technologies or an authorized third party is strictly prohibited. At a minimum, this information is protected under unfair competition and copyright laws. Violations thereof may result in criminal penalties and fines.

Any document provided in source format (i.e., in a modifiable form such as in FrameMaker or Microsoft Word format) is subject to use and distribution restrictions that are independent of and supplemental to any and all confidentiality restrictions. UNDER NO CIRCUMSTANCES MAY A DOCUMENT PROVIDED IN SOURCE FORMAT BE DISTRIBUTED TO A THIRD PARTY IN SOURCE FORMAT WITHOUT THE EXPRESS WRITTEN PERMISSION OF MIPS TECHNOLOGIES, INC.

MIPS Technologies reserves the right to change the information contained in this document to improve function, design or otherwise. MIPS Technologies does not assume any liability arising out of the application or use of this information, or of any error or omission in such information. Any warranties, whether express, statutory, implied or otherwise, including but not limited to the implied warranties of merchantability or fitness for a particular purpose, are excluded. Except as expressly provided in any written license agreement from MIPS Technologies or an authorized third party, the furnishing of this document does not give recipient any license to any intellectual property rights, including any patent rights, that cover the information in this document.

The information contained in this document shall not be exported, reexported, transferred, or released, directly or indirectly, in violation of the law of any country or international law, regulation, treaty, Executive Order, statute, amendments or supplements thereto. Should a conflict arise regarding the export, reexport, transfer, or release of the information contained in this document, the laws of the United States of America shall be the governing law.

The information contained in this document constitutes one or more of the following: commercial computer software, commercial computer software documentation or other commercial items. If the user of this information, or any related documentation of any kind, including related technical data or manuals, is an agency, department, or other entity of the United States government ("Government"), the use, duplication, reproduction, release, modification, disclosure, or transfer of this information, or any related documentation of any kind, is restricted in accordance with Federal Acquisition Regulation 12.212 for civilian agencies and Defense Federal Acquisition Regulation Supplement 227.7202 for military agencies. The use of this information by the Government is further restricted in accordance with the terms of the license agreement(s) and/or applicable contract terms and conditions covering this information from MIPS Technologies or an authorized third party.

MIPS, MIPS16, QuickMIPS, R3000 and R5000 are among the registered trademarks of MIPS Technologies, Inc. in the United States and other countries, and MIPS16e, MIPS32, MIPS64, MIPS-3D, MIPS-Based, MIPS I, MIPS II, MIPS III, MIPS IV, MIPS V, MIPS RISC Certified Power logo, MIPSsim, MIPS Technologies logo, R4000, 4K, 4Kc, 4Km, 4Kp, 4KE, 4KEc, 4KEm, 4KEp, 4KS, 4KSc, 4KSd, M4K, 5K, 5Kc, 5Kf, 20Kc, 24K, 24Kf, 24Kc, 25Kf, ASMACRO, ATLAS, At the Core of the User Experience., BusBridge, CorExtend, CoreFPGA, CoreLV, EC, FastMIPS, JALGO, MALTA, MDMX, MGB, PDtrace, The Pipeline, Pro Series, SEAD, SEAD-2, SmartMIPS, SOC-it and YAMON are among the trademarks of MIPS Technologies, Inc.

All other trademarks referred to herein are the property of their respective owners.

Template: B1.10, Built with tags: 2B MIPS32 PROC

# **Table of Contents**

Chapter 1 Introduction to the MIPS32 <sup>TM</sup> M4K <sup>TM</sup> Processor Core	2
1.1 Features	2
1.2 M4K <sup>TM</sup> Core Block Diagram	4
1.2.1 Required Logic Blocks	5
1.2.2 Optional Logic Blocks	9
Chapter 2 Pipeline of the M4K <sup>TM</sup> Core	12
2.1 Pipeline Stages	
2.1.1 I Stage: Instruction Fetch	
2.1.1 Stage: Histraction Fetch 2.1.2 E Stage: Execution	
2.1.2 E Stage: Execution 2.1.3 M Stage: Memory Fetch	
2.1.4 A Stage: Align	
2.1.4 A Stage: Aligh 2.1.5 W Stage: Writeback	
2.2 Multiply/Divide Operations	
2.3.1 32x16 Multiply (High-Performance MDU)	
2.3.2 32x32 Multiply (High-Performance MDU)	
2.3.3 Divide (High-Performance MDU)	
2.4 MDU Pipeline (Area-Efficient MDU)	
2.4.1 Multiply (Area-Efficient MDU)	
2.4.2 Multiply Accumulate (Area-Efficient MDU)	
2.4.3 Divide (Area-Efficient MDU)	
2.5 Branch Delay	
2.6 Data Bypassing	
2.6.1 Load Delay	
2.6.2 Move from HI/LO and CP0 Delay	
2.7 Coprocessor 2 instructions	
2.8 Interlock Handling	
2.9 Slip Conditions	
2.10 Instruction Interlocks	
2.11 Hazards	
2.11.1 Types of Hazards	
2.11.2 Instruction Listing	
2.11.3 Eliminating Hazards	29
Chapter 3 Memory Management of the M4K <sup>TM</sup> Core	32
3.1 Introduction	
3.2 Modes of Operation	32
3.2.1 Virtual Memory Segments	
3.2.2 User Mode	
3.2.3 Kernel Mode	36
3.2.4 Debug Mode	38
3.3 Fixed Mapping MMU	
3.4 System Control Coprocessor	
Chapter 4 Exceptions and Interrupts in the M4K <sup>TM</sup> Core	$\Delta\Delta$
4.1 Exception Conditions	
4.2 Exception Priority	
4.3 Interrupts	
4.3.1 Interrupt Modes	
4.3.2 Generation of Exception Vector Offsets for Vectored Interrupts	

4.4 GPR Shadow Registers	54
4.5 Exception Vector Locations	
4.6 General Exception Processing	
4.7 Debug Exception Processing	
4.8 Exceptions	
4.8.1 Reset Exception	
4.8.2 Soft Reset Exception	
4.8.3 Debug Single Step Exception	
4.8.4 Debug Interrupt Exception	
4.8.5 Non-Maskable Interrupt (NMI) Exception	
4.8.6 Interrupt Exception	
4.8.7 Debug Instruction Break Exception	
4.8.8 Address Error Exception — Instruction Fetch/Data Access	
4.8.9 Bus Error Exception — Instruction Fetch or Data Access	
4.8.10 Debug Software Breakpoint Exception	
4.8.11 Execution Exception — System Call	
4.8.12 Execution Exception — Breakpoint	
4.8.13 Execution Exception — Reserved Instruction	
4.8.14 Execution Exception — Coprocessor Unusable	
4.8.15 Execution Exception — Coprocessor 2 Exception	
4.8.16 Execution Exception — Implementation-Specific 1 exception	
4.8.17 Execution Exception — Implementation Specific 2 exception	
4.8.18 Execution Exception — Integer Overflow	
4.8.19 Execution Exception — Trap	
4.8.20 Debug Data Break Exception	
4.9 Exception Handling and Servicing Flowcharts	
Chapter 5 CP0 Registers of the M4K™ Core	73
5.1 CP0 Register Summary	74
5.2 CP0 Register Descriptions	75
5.2.1 HWREna Register (CP0 Register 7, Select 0)	77
5.2.2 BadVAddr Register (CP0 Register 8, Select 0)	78
5.2.3 Count Register (CP0 Register 9, Select 0)	79
5.2.4 Compare Register (CP0 Register 11, Select 0)	80
5.2.5 Status Register (CP0 Register 12, Select 0)	81
5.2.6 IntCtl Register (CP0 Register 12, Select 1)	86
5.2.7 SRSCtl Register (CP0 Register 12, Select 2)	88
5.2.8 SRSMap Register (CP0 Register 12, Select 3)	91
5.2.9 Cause Register (CP0 Register 13, Select 0)	92
5.2.10 Exception Program Counter (CP0 Register 14, Select 0)	
5.2.11 Processor Identification (CPO Register 15, Select 0)	
5.2.12 EBase Register (CP0 Register 15, Select 1)	
5.2.13 Config Register (CP0 Register 16, Select 0)	
5.2.14 Config1 Register (CP0 Register 16, Select 1)	
5.2.15 Config2 Register (CP0 Register 16, Select 2)	
5.2.16 Config3 Register (CP0 Register 16, Select 3)	
5.2.17 Debug Register (CP0 Register 23, Select 0)	
5.2.18 Trace Control Register (CP0 Register 23, Select 1)	
5.2.19 Trace Control2 Register (CP0 Register 23, Select 2)	
5.2.20 <i>User Trace Data</i> Register (CP0 Register 23, Select 3)	
5.2.21 TraceBPC Register (CP0 Register 23, Select 4)	
5.2.22 Debug Exception Program Counter Register (CP0 Register 24, Select 0)	
5.2.23 ErrorEPC (CP0 Register 30, Select 0)	
5.2.24 <i>DeSave</i> Register (CP0 Register 31, Select 0)	
Chapter 6 Hardware and Software Initialization of the M4K <sup>TM</sup> Core	121

6.1 Hardware-Initialized Processor State	121
6.1.1 Coprocessor 0 State	121
6.1.2 Bus State Machines	122
6.1.3 Static Configuration Inputs	122
6.1.4 Fetch Address	
6.2 Software Initialized Processor State	
6.2.1 Register File	
6.2.2 Coprocessor 0 State	
•	
Chapter 7 Power Management of the M4K <sup>TM</sup> Core	
7.1 Register-Controlled Power Management	
7.2 Instruction-Controlled Power Management	125
Chapter 8 EJTAG Debug Support in the M4K <sup>TM</sup> Core	129
8.1 Debug Control Register	
8.2 Hardware Breakpoints	
8.2.1 Features of Instruction Breakpoint	
8.2.2 Features of Data Breakpoint	
8.2.3 Instruction Breakpoint Registers Overview	
8.2.4 Data Breakpoint Registers Overview	
8.2.5 Conditions for Matching Breakpoints	
8.2.6 Debug Exceptions from Breakpoints	
8.2.7 Breakpoint used as TriggerPoint	
8.2.8 Instruction Breakpoint Registers	
8.2.9 Data Breakpoint Registers	
8.3 Test Access Port (TAP)	
8.3.1 EJTAG Internal and External Interfaces	
8.3.2 Test Access Port Operation	
8.3.3 Test Access Port (TAP) Instructions	
8.4 EJTAG TAP Registers	
8.4.1 Instruction Register	
8.4.2 Data Registers Overview	
8.4.3 Processor Access Address Register	
8.4.4 Fastdata Register (TAP Instruction FASTDATA)	
8.5 TAP Processor Accesses	
8.6 Fetch/Load and Store from/to the EJTAG Probe through dmseg	
8.7 EJTAG Trace	
8.7.1 Processor Modes	
8.7.2 Software versus Hardware control	
8.7.3 Trace information	
8.7.4 Load/Store address and data trace information	
8.7.5 Programmable processor trace mode options	
8.7.6 Programmable trace information options	
8.7.7 Enable trace to probe/on-chip memory	
8.7.8 TCB Trigger	
8.7.9 Cycle by cycle information	
8.7.10 Trace Message Format	
8.7.11 Trace Word Format	
8.8 PDtrace <sup>TM</sup> Registers (software control)	
8.9 Trace Control Block (TCB) Registers (hardware control)	
8.9.1 TCBCONTROLA Register	
8.9.2 TCBCONTROLB Register	
8.9.3 TCBDATA Register	
8.9.4 TCBCONFIG Register (Reg 0)	
8.9.5 TCBTW Register (Reg 4)	
8.9.6 TCBRDP Register (Reg 5)	183

8.9.7 TCBWRP Register (Reg 6)	183
8.9.8 TCBSTP Register (Reg 7)	
8.9.9 <i>TCBTRIGx</i> Register (Reg 16-23)	
8.9.10 Register Reset State	186
8.10 EJTAG Trace Enabling	187
8.10.1 Trace Trigger from EJTAG Hardware Instruction/Data Breakpoints	187
8.10.2 Turning On PDtrace <sup>TM</sup> Trace	187
8.10.3 Turning Off PDtrace <sup>TM</sup> Trace	188
8.10.4 TCB Trace Enabling	189
8.10.5 Tracing a reset exception	
8.11 TCB Trigger logic	
8.11.1 Trigger units overview	189
8.11.2 Trigger Source Unit	
8.11.3 Trigger Control Units	
8.11.4 Trigger Action Unit	
8.11.5 Simultaneous triggers	
8.12 EJTAG Trace cycle-by-cycle behavior	
8.12.1 Fifo logic in PDtrace and TCB modules	
8.12.2 Handling of Fifo overflow in the PDtrace module	
8.12.3 Handling of Fifo overflow in the TCB	
8.12.4 Adding cycle accurate information to the trace	
8.13 TCB On-Chip Trace Memory	
8.13.1 On-Chip Trace Memory size	
8.13.2 Trace-From Mode	
8.13.3 Trace-To Mode	194
Chapter 9 Instruction Set Overview	196
9.1 CPU Instruction Formats	196
9.2 Load and Store Instructions	197
9.2.1 Scheduling a Load Delay Slot	197
9.2.2 Defining Access Types	197
9.3 Computational Instructions	198
9.3.1 Cycle Timing for Multiply and Divide Instructions	
9.4 Jump and Branch Instructions	
9.4.1 Overview of Jump Instructions	
9.4.2 Overview of Branch Instructions	199
9.5 Control Instructions	
9.6 Coprocessor Instructions	199
Chapter 10 M4K <sup>TM</sup> Processor Core Instructions	202
10.1 Understanding the Instruction Descriptions	202
10.2 M4K <sup>TM</sup> Opcode Map	
10.3 MIPS32 <sup>TM</sup> Instruction Set for the M4K <sup>TM</sup> core	205
Chapter 11 MIPS16 Application-Specific Extension to the MIPS32 Instruction Set	228
11.1 Instruction Bit Encoding	
11.2 Instruction Listing	
Appendix A Revision History	234

# List of Figures

Figure 1-1: M4K <sup>TM</sup> Processor Core Block Diagram	5
Figure 1-2: Address Translation During a SRAM Access	7
Figure 2-1: M4K <sup>TM</sup> Core Pipeline Stages (with high-performance MDU)	13
Figure 2-2: M4K <sup>TM</sup> Core Pipeline Stages (with area-efficient MDU)	
Figure 2-3: MDU Pipeline Behavior During Multiply Operations	17
Figure 2-4: MDU Pipeline Flow During a 32x16 Multiply Operation	18
Figure 2-5: MDU Pipeline Flow During a 32x32 Multiply Operation	18
Figure 2-6: High-Performance MDU Pipeline Flow During a 8-bit Divide (DIV) Operation	18
Figure 2-7: High-Performance MDU Pipeline Flow During a 16-bit Divide (DIV) Operation	19
Figure 2-8: High-Performance MDU Pipeline Flow During a 24-bit Divide (DIV) Operation	19
Figure 2-9: High-Performance MDU Pipeline Flow During a 32-bit Divide (DIV) Operation	19
Figure 2-10: M4K <sup>™</sup> Area-Efficient MDU Pipeline Flow During a Multiply Operation	20
Figure 2-11: M4KC Area-Efficient MDU Pipeline Flow During a Multiply Accumulate Operation	21
Figure 2-12: M4K™ Area-Efficient MDU Pipeline Flow During a Divide (DIV) Operation	21
Figure 2-13: IU Pipeline Branch Delay	22
Figure 2-14: IU Pipeline Data bypass	22
Figure 2-15: IU Pipeline M to E bypass	23
Figure 2-16: IU Pipeline A to E Data bypass	
Figure 2-17: IU Pipeline Slip after a MFHI	24
Figure 2-18: Coprocessor 2 Interface Transactions	
Figure 2-19: Instruction Cache Miss Slip	
Figure 3-1: Address Translation During SRAM Access	
Figure 3-2: M4K <sup>TM</sup> processor core Virtual Memory Map.	
Figure 3-3: User Mode Virtual Address Space	
Figure 3-4: Kernel Mode Virtual Address Space	
Figure 3-5: Debug Mode Virtual Address Space	
Figure 3-6: FM Memory Map (ERL=0) in the M4K <sup>TM</sup> Processor Core	
Figure 3-7: FM Memory Map (ERL=1) in the M4K <sup>TM</sup> Processor Core	
Figure 4-1: Interrupt Generation for Vectored Interrupt Mode	
Figure 4-2: Interrupt Generation for External Interrupt Controller Interrupt Mode	
Figure 4-3: General Exception Handler (HW)	
Figure 4-4: General Exception Servicing Guidelines (SW)	
Figure 4-5: Reset, Soft Reset and NMI Exception Handling and Servicing Guidelines	
Figure 5-1: HWREna Register Format	
Figure 5-2: BadVAddr Register Format	
Figure 5-3: Count Register Format	
Figure 5-4: Compare Register Format	
	81
Figure 5-6: IntCtl Register Format	
Figure 5-7: SRSCtl Register Format	
Figure 5-8: SRSMap Register Format	
Figure 5-9: Cause Register Format	
Figure 5-10: EPC Register Format	
Figure 5-11: PRId Register Format	
Figure 5-12: EBase Register Format — Select 0.	
Figure 5-14: Config Register Field Descriptions	
Figure 5-15: Config Register Format — Select 1	
Figure 5-17: Config3 Register Format — Select 2.	
1 Iguio J. 17. Comiga Register i Unitat	, 104

Figure 5-18: <i>Debug</i> Register Format	106
Figure 5-19: Trace Control Register Format	109
Figure 5-20: Trace Control2 Register Format	112
Figure 5-21: User Trace Data Register Format	
Figure 5-22: Trace BPC Register Format	
Figure 5-23: DEPC Register Format	
Figure 5-24: ErrorEPC Register Format	
Figure 5-25: DeSave Register Format	118
Figure 8-1: TAP Controller State Diagram	
Figure 8-2: Concatenation of the EJTAG Address, Data and Control Registers	157
Figure 8-3: TDI to TDO Path when in Shift-DR State and FASTDATA Instruction is Selected	157
Figure 8-4: Endian Formats for the <i>PAD</i> Register	165
Figure 8-5: EJTAG Trace modules in the M4K <sup>TM</sup> core	169
Figure 8-6: TCB Trigger processing overview	190
Figure 9-1: Instruction Formats	

# List of Tables

Table 2-1: MDU Instruction Latencies (High-Performance MDU)	
Table 2-2: MDU Instruction Repeat Rates (High-Performance MDU)	
Table 2-3: M4K <sup>TM</sup> Core Instruction Latencies (Area-Efficient MDU)	
Table 2-4: Pipeline Interlocks	
Table 2-5: Instruction Interlocks	
Table 2-6: Execution Hazards	
Table 2-7: Instruction Hazards	
Table 2-8: Hazard Instruction Listing	
Table 3-1: User Mode Segments	
Table 3-2: Kernel Mode Segments	
Table 3-3: Physical Address and Cache Attributes for dseg, dmseg, and drseg Address Spaces	
Table 3-4: CPU Access to drseg Address Range	
Table 3-5: CPU Access to dmseg Address Range	
Table 3-6: Cache Coherency Attributes	40
Table 3-7: Cacheability of Segments with Block Address Translation	
Table 4-1: Priority of Exceptions	
Table 4-2: Interrupt Modes	
Table 4-3: Relative Interrupt Priority for Vectored Interrupt Mode	
Table 4-4: Exception Vector Offsets for Vectored Interrupts	
Table 4-5: Exception Vector Base Addresses	
Table 4-6: Exception Vector Offsets	
Table 4-7: Exception Vectors	
Table 4-8: Value Stored in EPC, ErrorEPC, or DEPC on an Exception	
Table 4-10: Register States an Interrupt Exception	
Table 4-11: CPO Register States on an Address Exception Error  Table 4-12: Register States on a Coprocessor Unusable Exception	
Table 5-1: CP0 Registers	
Table 5-1: CP0 Registers Field Types	
Table 5-4: HWREna Register Field Descriptions	
Table 5-5: BadVAddr Register Field Description	
Table 5-6: Count Register Field Description	
Table 5-7: Compare Register Field Description	
Table 5-8: Status Register Field Descriptions	
Table 5-9: IntCtl Register Field Descriptions	
Table 5-10: SRSCtl Register Field Descriptions	
Table 5-11: Sources for new SRSCtl <sub>CSS</sub> on an Exception or Interrupt	
Table 5-12: SRSMap Register Field Descriptions	
Table 5-13: Cause Register Field Descriptions	
Table 5-14: Cause Register ExcCode Field	
Table 5-15: EPC Register Field Description	
Table 5-16: <i>PRId</i> Register Field Descriptions.	
Table 5-17: EBase Register Field Descriptions	
Table 5-18: Cache Coherency Attributes	
Table 5-19: Config1 Register Field Descriptions — Select 1	
Table 5-20: Config1 Register Field Descriptions — Select 1	
Table 5-21: Config3 Register Field Descriptions	
Table 5-22: Debug Register Field Descriptions	
Table 5-23: TraceControl Register Field Descriptions	
Table 5-24: TraceControl2 Register Field Descriptions	

Table 5-25: UserTraceData Register Field Descriptions	114
Table 5-26: TraceBPC Register Field Descriptions	
Table 5-27: DEPC Register Formats	
Table 5-28: ErrorEPC Register Field Description	
Table 5-29: DeSave Register Field Description	
Table 8-1: Debug Control Register Field Descriptions	
Table 8-2: Overview of Status Register for Instruction Breakpoints	
Table 8-3: Overview of Registers for Each Instruction Breakpoint	
Table 8-4: Overview of Status Register for Data Breakpoints	
Table 8-5: Overview of Registers for each Data Breakpoint	
Table 8-6: Addresses for Instruction Breakpoint Registers	
Table 8-7: IBS Register Field Descriptions	
Table 8-8: <i>IBAn</i> Register Field Descriptions	
Table 8-9: <i>IBMn</i> Register Field Descriptions	
Table 8-10: <i>IBASIDn</i> Register Field Descriptions	
Table 8-11: <i>IBCn</i> Register Field Descriptions	
Table 8-12: Addresses for Data Breakpoint Registers	
Table 8-13: DBS Register Field Descriptions	
Table 8-14: <i>DBAn</i> Register Field Descriptions	
Table 8-15: <i>DBMn</i> Register Field Descriptions	
Table 8-16: <i>DBASIDn</i> Register Field Descriptions	
Table 8-17: DBCn Register Field Descriptions	
Table 8-18: <i>DBVn</i> Register Field Descriptions	
Table 8-19: EJTAG Interface Pins	
Table 8-20: Implemented EJTAG Instructions	
Table 8-21: Device Identification Register	
Table 8-22: Implementation Register Descriptions	
Table 8-23: EJTAG Control Register Descriptions	
Table 8-24: Fastdata Register Field Description	
Table 8-25: Operation of the FASTDATA access	
Table 8-26: A List of Coprocessor 0 Trace Registers	
Table 8-27: TCB EJTAG registers	
Table 8-28: Registers selected by TCBCONTROLB <sub>REG</sub>	
Table 8-29: TCBCONTROLA Register Field Descriptions	
Table 8-30: TCBCONTROLB Register Field Descriptions	
Table 8-31: Clock Ratio encoding of the CR field	
Table 8-32: TCBDATA Register Field Descriptions	
Table 8-33: TCBCONFIG Register Field Descriptions	
Table 8-34: TCBTW Register Field Descriptions	
Table 8-35: TCBRDP Register Field Descriptions	
Table 8-36: TCBWRP Register Field Descriptions	
Table 8-37: TCBSTP Register Field Descriptions	
Table 8-38: TCBTRIGx Register Field Descriptions	
Table 9-1: Byte Access Within a Word	
Table 10-1: Encoding of the <i>Opcode</i> Field	
Table 10-2: Special Opcode encoding of Function Field	
Table 10-3: Special2 Opcode Encoding of Function Field	
Table 10-4: Special3 Opcode Encoding of Function Field	
Table 10-5: RegImm Encoding of rt Field	
Table 10-6: COP2 Encoding of rs Field	
Table 10-7: COP2 Encoding of rt Field When rs=BC2	
Table 10-8: COP0 Encoding of rs Field	204
Table 10-9: COP0 Encoding of Function Field When rs=CO	
Table 10-10: Instruction Set	
Table 10-11: Values of the hint Field for the PREF Instruction	216

Table 11-1: Symbols Used in the Instruction Encoding Tables
Table 11-3: MIPS16 JAL(X) Encoding of the x Field
Table 11-4: MIPS16 SHIFT Encoding of the f Field
Table 11-5: MIPS16 RRI-A Encoding of the f Field
Table 11-6: MIPS16 I8 Encoding of the funct Field
Table 11-7: MIPS16 RRR Encoding of the f Field
Table 11-8: MIPS16 RR Encoding of the Funct Field
Table 11-9: MIPS16 I8 Encoding of the s Field when funct=SVRS
Table 11-10: MIPS16 RR Encoding of the ry Field when funct=J(AL)R(C)
Table 11-11: MIPS16 RR Encoding of the ry Field when funct=CNVT23
Table 11-12: MIPS16 Load and Store Instructions
Table 11-13: MIPS16 Save and Restore Instructions
Table 11-14: MIPS16 ALU Immediate Instructions
Table 11-15: MIPS16 Arithmetic Two or Three Operand Register Instructions
Table 11-16: MIPS16 Special Instructions
Table 11-17: MIPS16 Multiply and Divide Instructions
Table 11-18: MIPS16 Jump and Branch Instructions
Table 11-19: MIPS16 Shift Instructions
Table 11-19: MIPS16 Shift Instructions

# Introduction to the MIPS32<sup>TM</sup> M4K<sup>TM</sup> Processor Core

The MIPS32<sup>TM</sup> M4K<sup>TM</sup> core from MIPS Technologies is a high-performance, low-power, 32-bit MIPS RISC processor core intended for custom system-on-silicon applications. The core is designed for semiconductor manufacturing companies, ASIC developers, and system OEMs who want to rapidly integrate their own custom logic and peripherals with a high-performance RISC processor. A M4K core is fully synthesizable to allow maximum flexibility; it is highly portable across processes and can easily be integrated into full system-on-silicon designs. This allows developers to focus their attention on end-user specific characteristics of their product.

The M4K core is ideally positioned to support new products for emerging segments of the routing, network access, network storage, residential gateway, and smart mobile device markets. It is especially well-suited for applications where high performance density is critical, especially those requiring multiple processor cores on a single chip.

The core implements the MIPS32 Release 2 Instruction Set Architecture (ISA), and may optionally support the MIPS16e Application Specific Extension (ASE) for code compression. The MMU consists of a simple Fixed Mapping Translation (FMT) mechanism, for applications that do not require the full capabilities of a Translation Lookaside Buffer- (TLB-) based MMU available on other MIPS cores.

The M4K core is cacheless; in lieu of caches, it includes a simple interface to SRAM-style devices. This interface may be configured for independent instruction and data devices or combined into a unified interface. The SRAM interface allows deterministic latency to memory, while still maintaining high performance.

The core includes one of two different Multiply/Divide Unit (MDU) implementations, selectable at build-time, allowing the user to trade off performance and area for integer multiply and divide operations. The high-performance MDU option implements single cycle multiply and multiply-accumulate (MAC) instructions, which enable DSP algorithms to be performed efficiently. It allows 32-bit x 16-bit MAC instructions to be issued every cycle, while a 32-bit x 32-bit MAC instruction can be issued every other cycle. The area-efficient MDU option handles multiplies with a one-bit-per-clock iterative algorithm.

The basic Enhanced JTAG (EJTAG) features provide CPU run control with stop, single stepping and re-start, and with software breakpoints through the SDBBP instruction. Additional EJTAG features - instruction and data virtual address hardware breakpoints, connection to an external EJTAG probe through the Test Access Port (TAP), and PC/Data tracing, may optionally be included.

.The rest of this chapter provides an overview of the MIPS32 M4K processor core and consists of the following sections:

- Section 1.1, "Features"
- Section 1.2, "M4KTM Core Block Diagram"

#### 1.1 Features

- 5-stage pipeline
- 32-bit Address and Data Paths

- MIPS32-Compatible Instruction Set
  - Multiply-add and multiply-subtract instructions (MADD, MADDU, MSUB, MSUBU)
  - Targeted multiply instruction (MUL)
  - Zero and one detect instructions (CLZ, CLO)
  - Wait instruction (WAIT)
  - Conditional move instructions (MOVZ, MOVN)
  - Prefetch instruction (PREF)
- MIPS32 Enhanced Architecture (Release 2) Features
  - Vectored interrupts and support for an external interrupt controller
  - Programmable exception vector base
  - Atomic interrupt enable/disable
  - GPR shadow sets
  - Bit field manipulation instructions
- MIPS16e Application Specific Extension
  - 16 bit encodings of 32-bit instructions to improve code density
  - Special PC-relative instructions for efficient loading of addresses and constants
  - Data type conversion instructions (ZEB, SEB, ZEH, SEH)
  - Compact jumps (JRC, JALRC)
  - Stack frame set-up and tear down "macro" instructions (SAVE and RESTORE)
- Programmable Memory Management Unit
  - Simple Fixed Mapping Translation (FMT)
  - Address spaces mapped using register bits
- Simple SRAM-Style Interface
  - Cacheless operation enables deterministic response and reduces size
  - 32-bit address and data; input byte enables enable simple connection to narrower devices
  - Single or multi-cycle latencies
  - Configuration option for dual or unified instruction/data interfaces
  - Redirection mechanism on dual I/D interfaces permits D-side references to be handled by I-side
  - Transactions can be aborted
- Multi-Core Support
  - External lock indication enables multi-processor semaphores based on LL/SC instructions
  - External sync indication allows memory ordering
  - Debug support includes cross-core triggers

- CorExtend™ User Defined Instruction capability (access to this feature is available in the M4K Pro™ cores and requires a separate license)
  - Optional support for the CorExtend feature allows users to define and add instructions to the core (as a build-time option)
  - Single or multi-cycle instructions
  - Source operations from register, immediate field, or local state
  - Destination to a register or local state
- Full featured Coprocessor 2 Interface
  - Almost all I/Os registered
  - Separate unidirectional 32-bit instruction and data buses
  - Support for branch on Coprocessor condition
  - Processor to/from Coprocessor register data transfers
  - Direct memory to/from Coprocessor register data transfers
- Multiply-Divide Unit (High performance build-time option)
  - Maximum issue rate of one 32x16 multiply per clock
  - Maximum issue rate of one 32x32 multiply every other clock
  - Early-in divide control. Minimum 11, maximum 34 clock latency on divide
- Multiply-Divide Unit (Area-efficient build-time option)
  - Iterative multiply and divide. 32 or more cycles for each instruction.
- · Power Control
  - No minimum frequency
  - Power-down mode (triggered by WAIT instruction)
  - Support for software-controlled clock divider
  - Support for extensive use of fine-grain clock gating
- EJTAG Debug Support
  - CPU control with start, stop and single stepping
  - Software breakpoints via the SDBBP instruction
  - Optional hardware breakpoints on virtual addresses; 4 instruction and 2 data breakpoints, 2 instruction and 1 data breakpoint, or no breakpoints
  - Optional Test Access Port (TAP) facilitates high speed download of application code
  - Optional EJTAG Trace hardware to enable real-time tracing of executed code

# 1.2 M4K<sup>TM</sup> Core Block Diagram

The M4K core contains both required and optional blocks, as shown in the block diagram in Figure 1-1 on page 5. Required blocks are the lightly shaded areas of the block diagram and are always present in any core implementation. Optional blocks may be added to the base core, depending on the needs of a specific implementation. The required blocks are as follows:

• Execution Unit

- Multiply-Divide Unit (MDU)
- System Control Coprocessor (CP0)
- Memory Management Unit (MMU)
- · Cache Controller
- SRAM Interface
- Power Management

#### Optional blocks include:

- Enhanced JTAG (EJTAG) Controller
- MIPS16e support
- Coprocessor 2 Interface (CP2)
- CorExtend<sup>TM</sup> User Defined Instructions (UDI)

Figure 1-1 shows a block diagram of a M4K core.




Figure 1-1 M4K<sup>TM</sup> Processor Core Block Diagram

# 1.2.1 Required Logic Blocks

The following subsections describe the various required logic blocks of the M4K processor core.

#### 1.2.1.1 Execution Unit

The core execution unit implements a load-store architecture with single-cycle Arithmetic Logic Unit (ALU) operations (logical, shift, add, subtract) and an autonomous multiply-divide unit. The core contains thirty-two 32-bit general-purpose registers(GPRs) used for scalar integer operations and address calculation. Optionally, one or three additional register file shadow sets (each containing thirty-two registers) can be added to minimize context switching overhead during interrupt/exception processing. The register file consists of two read ports and one write port and is fully bypassed to minimize operation latency in the pipeline.

The execution unit includes:

- 32-bit adder used for calculating the data address
- Address unit for calculating the next instruction address
- Logic for branch determination and branch target address calculation
- · Load aligner
- Bypass multiplexers used to avoid stalls when executing instruction streams where data-producing instructions are followed closely by consumers of their results
- Zero/One detect unit for implementing the CLZ and CLO instructions
- ALU for performing bitwise logical operations
- Shifter and Store aligner

# 1.2.1.2 Multiply/Divide Unit (MDU)

The Multiply/Divide unit performs multiply divide operations. Two configuration options exist for the MDU, selectable at build time: an area-efficient iterative MDU and a higher performance 32x16 array. The MDU consists of an iterative or32x16 multiplier, result-accumulation registers (HI and LO), multiply and divide state machines, and all multiplexers and control logic required to perform these functions. The high-performance, pipelined MDU supports execution of a 16x16 or 32x16 multiply operation every clock cycle; 32x32 multiply operations can be issued every other clock cycle. Appropriate interlocks are implemented to stall the issue of back-to-back 32x32 multiply operations. Divide operations are implemented with a simple 1 bit per clock iterative algorithm and require 35 clock cycles in worst case to complete. Early-in to the algorithm detects sign extension of the dividend, if it is actual size is 24, 16 or 8 bit. the divider will skip 7, 15 or 23 of the 32 iterations. An attempt to issue a subsequent MDU instruction while a divide is still active causes a pipeline stall until the divide operation is completed.

The area-efficient, non-pipelined MDU consists of a 32-bit full-adder, result-accumulation registers (HI and LO), a combined multiply/divide state machine, and all multiplexers and control logic required to perform these functions. It performs any multiply using 32 cycles in an iterative 1 bit per clock algorithm. Divide operations are also implemented with a simple 1 bit per clock iterative algorithm (no early-in) and require 35 clock cycles to complete. An attempt to issue a subsequent MDU instruction while a multiply/divide is still active causes a pipeline stall until the operation is completed.

The M4K implements an additional multiply instruction, MUL, which specifies that lower 32-bits of the multiply result be placed in the register file instead of the HI/LO register pair. By avoiding the explicit move from LO (MFLO) instruction, required when using the LO register, and by supporting multiple destination registers, the throughput of multiply-intensive operations is increased.

Two instructions, multiply-add (MADD/MADDU) and multiply-subtract (MSUB/MSUBU), are used to perform the multiply-add and multiply-subtract operations. The MADD instruction multiplies two numbers and then adds the product to the current contents of the HI and LO registers. Similarly, the MSUB instruction multiplies two operands and then subtracts the product from the HI and LO registers. The MADD/MADDU and MSUB/MSUBU operations are commonly used in Digital Signal Processor (DSP) algorithms.

#### 1.2.1.3 System Control Coprocessor (CP0)

In the MIPS architecture, CP0 is responsible for the virtual-to-physical address translation, cache protocols, the exception control system, the processor's diagnostics capability, operating mode selection (kernel vs. user mode), and the enabling/disabling of interrupts. Configuration information such as presence of build-time options are available by accessing the CP0 registers. Refer to Chapter 5, "CP0 Registers of the M4K $^{\text{TM}}$  Core," on page 72 for more information on the CP0 registers. Refer to Chapter 8, "EJTAG Debug Support in the M4K $^{\text{TM}}$  Core," on page 127 for more information on EJTAG debug registers.

#### 1.2.1.4 Memory Management Unit (MMU)

The M4K core contains an MMU that interfaces between the execution unit and the SRAM controller, shown in Figure 1-2 on page 7.

The M4K implement a FMT-based MMU. The FMT performs a simple translation to get the physical address from the virtual address. Refer to Chapter 3, "Memory Management of the M4K<sup>TM</sup> Core," on page 31 for more information on the FMT.

Figure 1-2 on page 7 shows how the address translation mechanism interacts with SRAM access.




Figure 1-2 Address Translation During a SRAM Access

#### 1.2.1.5 SRAM Interface

Instead of caches, the M4K core contains an interface to SRAM-style memories that can be tightly coupled to the core. This permits deterministic response time with less area than is typically required for caches. The SRAM interface includes separate unidirectional 32-bit buses for address, read data, and write data.

#### **Dual or Unified Interfaces**

The SRAM interface includes a build-time option to select either dual or unified instruction and data interfaces. The dual interface enables independent connection to instruction and data devices. It generally yields the highest performance, since the pipeline can generate simultaneous I and D requests which are then serviced in parallel. For simpler or cost-sensitive systems, it is also possible to combine the I and D interfaces into a common interface that services both types of requests. If I and D requests occur simultaneously, priority is given to the D side.

#### **Backstalling**

Typically, read or write transactions will complete in a single cycle. If multi-cycle latency is desired, however, the interface can be stalled to allow connection to slower devices.

#### Redirection

When the dual I/D interface is present, a mechanism exists to divert D-side references to the I-side, if desired. The redirection is employed automatically in the case of PC-relative loads in MIPS16e mode. The mechanism can be explicitly invoked for any other D-side references, as well. When the *DS\_Redir* signal is asserted, a D-side request is diverted to the I-side interface in the following cycle, and the D-side will be stalled until the transaction is completed.

#### Transaction Abort

Because the core does not know whether loads or stores are re-startable, it cannot arbitrarily interrupt a request which has been initiated on the SRAM interface. However, cycles spent waiting for a multi-cycle transaction to complete can directly impact interrupt latency. In order to minimize this effect, the interface supports an abort mechanism. The core requests an abort whenever an interrupt is detected and a transaction is pending. The external system logic can choose to acknowledge the abort, if it wants to reduce interrupt latency.

#### MIPS16e Execution

When the core is operating in MIPS16e mode, instruction fetches only require 16-bits of data to be returned. For improved efficiency, however, the core will fetch 32-bits of instruction data whenever the address is word-aligned. Thus for sequential MIPS16e code, fetches only occur for every other instruction, resulting in better performance and reduced system power.

#### Connecting to Narrower Devices

The instruction and data read buses are always 32-bits in width. To facilitate connection to narrower memories, the SRAM interface protocol includes input byte enables that can be used by system logic to signal validity as partial read data becomes available. The input byte enables conditionally register the incoming read data bytes within the core, and thus eliminate the need for external registers to gather the entire 32-bits of data. External muxes are required to redirect the narrower data to the appropriate byte lanes.

#### Lock Mechanism

The SRAM interface includes a protocol to identify a locked sequence, and is used in conjunction with the LL/SC atomic read-modify-write semaphore instructions.

#### Sync Mechanism

The interface includes a protocol that externalizes the execution of the SYNC instruction. External logic might choose to use this information to enforce memory ordering between various elements in the system.

# 1.2.1.6 Power Management

The core offers a number of power management features, including low-power design, active power management, and power-down modes of operation. The core is a static design that supports a WAIT instruction designed to signal the rest of the device that execution and clocking should be halted, hence reducing system power consumption during idle periods.

The core provides two mechanisms for system-level, low-power support:

- Register-controlled power management
- Instruction-controlled power management

In register-controlled power management mode the core provides three bits in the CPO Status register for software control of the power management function and allows interrupts to be serviced even when the core is in power-down mode. In instruction-controlled power-down mode execution of the WAIT instruction is used to invoke low-power mode.

 $Refer to \ Chapter \ 7, "Power \ Management \ of the \ M4K^{TM} \ Core," \ on page \ 123 \ for \ more \ information \ on \ power \ management.$ 

#### 1.2.2 Optional Logic Blocks

The core consists of the following optional logic blocks as shown in the block diagram in Figure 1-1 on page 5.

# 1.2.2.1 MIPS16e<sup>TM</sup> Application Specific Extension

The M4K core includes optional support for the MIPS16e ASE. This ASE improves code density through the use of 16-bit encodings of MIPS32 instructions plus some MIPS16e-specific instructions. PC relative loads allow quick access to constants. Save/Restore macro instructions provide for single instruction stack frame setup/teardown for efficient subroutine entry/exit. Sign- and zero-extend instructions improve handling of 8bit and 16bit datatypes.

A decompressor converts the MIPS16e 16-bit instructions fetched from the external interface back into 32-bit instructions for execution by the core.

#### 1.2.2.2 EJTAG Controller

All cores provide basic EJTAG support with debug mode, run control, single step and software breakpoint instruction (SDBBP) as part of the core. These features allow for the basic software debug of user and kernel code.

Optional EJTAG features include hardware breakpoints. A M4K core may have four instruction breakpoints and two data breakpoints, two instruction breakpoints and one data breakpoint, or no breakpoints. The hardware instruction breakpoints can be configured to generate a debug exception when an instruction is executed anywhere in the virtual address space. Bit mask and Address Space Identifier (ASID) values may apply in the address compare. These breakpoints are not limited to code in RAM like the software instruction breakpoint (SDBBP). The data breakpoints can be configured to generate a debug exception on a data transaction. The data transaction may be qualified with both virtual address, data value, size and load/store transaction type. Bit mask and ASID values may apply in the address compare, and byte mask may apply in the value compare.

An optional TAP, enabling communication between an EJTAG probe and the CPU through a dedicated port, may also be applied to the core. This provides the possibility for debugging without debug code in the application, and for download of application code to the system.

Another optional block is EJTAG Trace which enables real-time tracing capability. The trace information can be stored to either an on-chip trace memory, or to an off-chip trace probe. The trace of program flow is highly flexible and can include instruction program counter as well as data addresses and data values. The trace features provides a powerful software debugging mechanism.

Refer to Chapter 8, "EJTAG Debug Support in the M4K<sup>TM</sup> Core," on page 127 for more information on the EJTAG features.

# 1.2.2.3 Coprocessor 2 Interface (CP2)

The optional coprocessor 2 (CP2) interface provides a full-featured interface for a coprocessor. It provides full support for all the MIPS32 COP2 instructions, with the exception of the 64-bit Load/Store instructions (LDC2/SDC2).

The CP2 interface can provide access to a graphics accelerator coprocessor or a simple register file. There is no support for the floating-point coprocessor COP1, which requires 64-bit data transfers.

Refer to Chapter 10, "M4K<sup>TM</sup> Processor Core Instructions," on page 200 for more information on the Coprocessor 2 supported instructions.

#### 1.2.2.4 CorExtend<sup>TM</sup> User Defined Instructions (UDI)

This optional module contains (if implemented) support for CorExtend user defined instructions. These instructions must be defined at build-time for the M4K core. Access to UDI requires a separate license from MIPS, and the core is then referred to as the M4K Pro<sup>TM</sup> core. When licensed, 16 instructions in the opcode map are available for UDI, and each instruction can have single or multi-cycle latency. A UDI instruction can operate on any one or two general-purpose registers or immediate data contained within the instruction, and can write the result of each instruction back to a general purpose register or local register. Implementation details for UDI can be found in other documents available from MIPS.

Refer to Section 10-3, "Special2 Opcode Encoding of Function Field" for a specification of the opcode map available for user defined instructions.

# Pipeline of the M4K TM Core

The M4K<sup>TM</sup> processor core implements a 5-stage pipeline similar to the original R3000 pipeline. The pipeline allows the processor to achieve high frequency while minimizing device complexity, reducing both cost and power consumption. This chapter contains the following sections:

- Section 2.1, "Pipeline Stages"
- Section 2.2, "Multiply/Divide Operations"
- Section 2.3, "MDU Pipeline (High-Performance MDU)"
- Section 2.4, "MDU Pipeline (Area-Efficient MDU)"
- Section 2.5, "Branch Delay"
- Section 2.6, "Data Bypassing"
- Section 2.8, "Interlock Handling"
- Section 2.9, "Slip Conditions"
- Section 2.10, "Instruction Interlocks"
- Section 2.11, "Hazards"

# 2.1 Pipeline Stages

The pipeline consists of five stages:

- Instruction (I stage)
- Execution (E stage)
- Memory (M stage)
- Align (A stage)
- Writeback (W stage)

A M4K core implements a "Bypass" mechanism that allows the result of an operation to be sent directly to the instruction that needs it without having to write the result to the register and then read it back.

The M4K soft core includes a build-time option that determines the type of multiply/divide unit (MDU) implemented. The MDU can be either a high-performance array or an iterative, area-efficient array. The MDU choice has a significant effect on the MDU pipeline, and the latency of multiply/divide instructions executed on the core. Software can query the type of MDU present on a specific implementation of the core by querying the MDU bit in the Config register (CP0 register 16, select 0); see Section 5.2.13, "Config Register (CP0 Register 16, Select 0)" for more details.

Figure 2-1 shows the operations performed in each pipeline stage of the M4K processor core, when the high-performance multiplier is present.




Figure 2-1 M4K<sup>TM</sup> Core Pipeline Stages (with high-performance MDU)

Figure 2-2 shows the operations performed in each pipeline stage of the M4K processor core, when the area-efficient multiplier is present.




Figure 2-2 M4K<sup>TM</sup> Core Pipeline Stages (with area-efficient MDU)

#### 2.1.1 I Stage: Instruction Fetch

During the Instruction fetch stage:

- An instruction is fetched from the instruction SRAM.
- MIPS16e instructions are converted into MIPS32-like instructions.

# 2.1.2 E Stage: Execution

During the Execution stage:

- Operands are fetched from the register file.
- Operands from the M and A stage are bypassed to this stage.
- The Arithmetic Logic Unit (ALU) begins the arithmetic or logical operation for register-to-register instructions.
- The ALU calculates the data virtual address for load and store instructions and the MMU performs the fixed virtual-to-physical address translation.

- The ALU determines whether the branch condition is true and calculates the virtual branch target address for branch instructions.
- Instruction logic selects an instruction address and the MMU performs the fixed virtual-to-physical address translation.
- All multiply divide operations begin in this stage.

# 2.1.3 M Stage: Memory Fetch

During the Memory Fetch stage:

- The arithmetic or logic ALU operation completes.
- The data SRAM access is performed for load and store instructions.
- A 16x16 or 32x16 MUL operation completes in the array and stalls for one clock in the M stage to complete the carry-propagate-add in the M stage (high-performance MDU option).
- A 32x32 MUL operation stalls for two clocks in the M stage to complete the second cycle of the array and the carry-propagate-add in the M stage (high-performance MDU option).
- A multiply operation stalls the MDU pipeline for 31 cycles in the M stage (area-efficient MDU option).
- Multiply and divide calculations proceed in the MDU. If the calculation completes before the IU moves the instruction past the M stage, then the MDU holds the result in a temporary register until the IU moves the instructions to the A stage (and it is consequently known that it won't be killed).

# 2.1.4 A Stage: Align

During the Align stage:

- A separate aligner aligns loaded data with its word boundary.
- A MUL operation makes the result available for writeback. The actual register writeback is performed in the W stage.
- From this stage load data or a result from the MDU are available in the E stage for bypassing.

# 2.1.5 W Stage: Writeback

During the Writeback stage:

• For register-to-register or load instructions, the result is written back to the register file.

#### 2.2 Multiply/Divide Operations

The M4K core implement the standard MIPS II<sup>TM</sup> multiply and divide instructions. Additionally, several new instructions were standardized in the MIPS32 architecture for enhanced performance.

The targeted multiply instruction, MUL, specifies that multiply results be placed in the general purpose register file instead of the HI/LO register pair. By avoiding the explicit MFLO instruction, required when using the LO register, and by supporting multiple destination registers, the throughput of multiply-intensive operations is increased.

Four instructions, multiply-add (MADD), multiply-add-unsigned (MADDU) multiply-subtract (MSUB), and multiply-subtract-unsigned (MSUBU), are used to perform the multiply-accumulate and multiply-subtract operations. The MADD/MADDU instruction multiplies two numbers and then adds the product to the current contents of the HI

and LO registers. Similarly, the MSUB/MSUBU instruction multiplies two operands and then subtracts the product from the HI and LO registers. The MADD/MADDU and MSUB/MSUBU operations are commonly used in DSP algorithms.

All multiply operations (except the MUL instruction) write to the HI/LO register pair. All integer operations write to the general purpose registers (GPR). Because MDU operations write to different registers than integer operations, following integer instructions can execute before the MDU operation has completed. The MFLO and MFHI instructions are used to move data from the HI/LO register pair to the GPR file. If a MFLO or MFHI instruction is issued before the MDU operation completes, it will stall to wait for the data.

# **2.3** MDU Pipeline (High-Performance MDU)

The M4Kprocessor core contains an autonomous multiply/divide unit (MDU) with a separate pipeline for multiply and divide operations. This pipeline operates in parallel with the integer unit (IU) pipeline and does not stall when the IU pipeline stalls. This allows multi-cycle MDU operations, such as a divide, to be partially masked by system stalls and/or other integer unit instructions.

The MDU consists of a 32x16 booth encoded multiplier array, a carry propagate adder, result/accumulation registers (HI and LO), multiply and divide state machines, and all necessary multiplexers and control logic. The first number shown ('32' of 32x16) represents the *rs* operand. The second number ('16' of 32x16) represents the *rt* operand. The core only checks the latter (*rt*) operand value to determine how many times the operation must pass through the multiplier array. The 16x16 and 32x16 operations pass through the multiplier array once. A 32x32 operation passes through the multiplier array twice.

The MDU supports execution of a 16x16 or 32x16 multiply operation every clock cycle; 32x32 multiply operations can be issued every other clock cycle. Appropriate interlocks are implemented to stall the issue of back-to-back 32x32 multiply operations. Multiply operand size is automatically determined by logic built into the MDU. Divide operations are implemented with a simple 1 bit per clock iterative algorithm with an early in detection of sign extension on the dividend (*rs*). Any attempt to issue a subsequent MDU instruction while a divide is still active causes an IU pipeline stall until the divide operation is completed.

Table 2-1 lists the latencies (number of cycles until a result is available) for multiply and divide instructions. The latencies are listed in terms of pipeline clocks. In this table 'latency' refers to the number of cycles necessary for the first instruction to produce the result needed by the second instruction.

Size of Operand 1st Instruction <sup>[1]</sup>	Instruction Sequence		Instruction	n Sequence	Latency
	1st Instruction	2nd Instruction	Clocks		
16 bit	MULT/MULTU, MADD/MADDU MSUB/MSUBU	MADD/MADDU, MSUB/MSUBU or MFHI/MFLO	1		
32 bit	MULT/MULTU, MADD/MADDU, or MSUB/MSUBU	MADD/MADDU, MSUB/MSUBU or MFHI/MFLO	2		
16 bit	MUL	Integer operation <sup>[2]</sup>	2 <sup>[3]</sup>		
32 bit	MUL	Integer operation <sup>[2]</sup>	2[3]		
8 bit	DIVU	MFHI/MFLO	9		
16 bit	DIVU	MFHI/MFLO	17		
24 bit	DIVU	MFHI/MFLO	25		

**Table 2-1 MDU Instruction Latencies (High-Performance MDU)** 

Table 2-1 MDU Instruction Latencies (High-Performance MDU)

Size of Operand	Instruction Sequence		Latency
1st Instruction <sup>[1]</sup>	1st Instruction	2nd Instruction	Clocks
32 bit	DIVU	MFHI/MFLO	33
8 bit	DIV	MFHI/MFLO	10 <sup>[4]</sup>
16 bit	DIV	MFHI/MFLO	18[4]
24 bit	DIV	MFHI/MFLO	26 <sup>[4]</sup>
32 bit	DIV	MFHI/MFLO	34 <sup>[4]</sup>
any	MFHI/MFLO	Integer operation <sup>[2]</sup>	2
any	MTHI/MTLO	MADD/MADDU or MSUB/MSUBU	1

Note: [1] For multiply operations, this is the rt operand. For divide operations, this is the rs operand.

Note: [2] Integer Operation refers to any integer instruction that uses the result of a previous MDU operation.

Note: [3] This does not include the 1 or 2 IU pipeline stalls (16 bit or 32 bit) that the MUL operation causes irrespective of the following instruction. These stalls do not add to the latency of 2.

Note: [4] If both operands are positive, then the Sign Adjust stage is bypassed. Latency is then the same as for DIVU.

In Table 2-1 a latency of one means that the first and second instructions can be issued back to back in the code without the MDU causing any stalls in the IU pipeline. A latency of two means that if issued back to back, the IU pipeline will be stalled for one cycle. MUL operations are special because it needs to stall the IU pipeline in order to maintain its register file write slot. Consequently the MUL 16x16 or 32x16 operation will always force a one cycle stall of the IU pipeline, and the MUL 32x32 will force a two cycle stall. If the integer instruction immediately following the MUL operation uses its result, an additional stall is forced on the IU pipeline.

Table 2-2 lists the repeat rates (peak issue rate of cycles until the operation can be reissued) for multiply accumulate/subtract instructions. The repeat rates are listed in terms of pipeline clocks. In this table 'repeat rate' refers to the case where the first MDU instruction (in the table below) if back-to-back with the second instruction.

**Table 2-2 MDU Instruction Repeat Rates (High-Performance MDU)** 

Operand Size of	Instruction Sequence		Repeat
1st Instruction	1st Instruction	2nd Instruction	Rate
16 bit	MULT/MULTU, MADD/MADDU, MSUB/MSUBU	MADD/MADDU, MSUB/MSUBU	1
32 bit	MULT/MULTU, MADD/MADDU, MSUB/MSUBU	MADD/MADDU, MSUB/MSUBU	2

Figure 2-3 below shows the pipeline flow for the following sequence:

- 1. 32x16 multiply (Mult<sub>1</sub>)
- 2. Add
- 3. 32x32 multiply (Mult<sub>2</sub>)
- 4. Subtract (Sub)

The 32x16 multiply operation requires one clock of each pipeline stage to complete. The 32x32 multiply operation requires two clocks in the  $M_{MDU}$  pipe-stage. The MDU pipeline is shown as the shaded areas of Figure 2-3 and always starts a computation in the final phase of the E stage. As shown in the figure, the  $M_{MDU}$  pipe-stage of the MDU pipeline occurs in parallel with the M stage of the IU pipeline, the  $A_{MDU}$  stage occurs in parallel with the A stage, and the  $W_{MDU}$  stage occurs in parallel with the W stage. In general this need not be the case. Following the 1st cycle of the M stages, the two pipelines need not be synchronized. This does not present a problem because results in the MDU pipeline are written to the HI and LO registers, while the integer pipeline results are written to the register file.




Figure 2-3 MDU Pipeline Behavior During Multiply Operations

The following is a cycle-by-cycle analysis of Figure 2-3.

- 1. The first 32x16 multiply operation (Mult<sub>1</sub>) is fetched from the instruction cache and enters the I stage.
- 2. An Add operation enters the I stage. The Mult<sub>1</sub> operation enters the E stage. The integer and MDU pipelines share the I and E pipeline stages. At the end of the E stage in cycle 2, the MDU pipeline starts processing the multiply operation (Mult<sub>1</sub>).
- 3. In cycle 3 a 32x32 multiply operation (Mult<sub>2</sub>) enters the I stage and is fetched from the instruction cache. Since the Add operation has not yet reached the M stage by cycle 3, there is no activity in the M stage of the integer pipeline at this time.
- 4. In cycle 4 the Subtract instruction enters I stage. The second multiply operation (Mult<sub>2</sub>) enters the E stage. And the Add operation enters M stage of the integer pipe. Since the Mult<sub>1</sub> multiply is a 32x16 operation, only one clock is required for the M<sub>MDU</sub> stage, hence the Mult<sub>1</sub> operation passes to the A<sub>MDU</sub> stage of the MDU pipeline.
- 5. In cycle 5 the Subtract instruction enters E stage. The Mult<sub>2</sub> multiply enters the M<sub>MDU</sub> stage. The Add operation enters the A stage of the integer pipeline. The Mult<sub>1</sub> operation completes and is written back in to the HI/LO register pair in the W<sub>MDU</sub> stage.
- 6. Since a 32x32 multiply requires two passes through the multiplier, with each pass requiring one clock, the 32x32 Mult<sub>2</sub> remains in the M<sub>MDU</sub> stage in cycle 6. The Sub instruction enters M stage in the integer pipeline. The Add operation completes and is written to the register file in the W stage of the integer pipeline.
- 7. The Mult<sub>2</sub> multiply operation progresses to the A<sub>MDU</sub> stage, and the Sub instruction progress to the A stage.
- 8. The Mult<sub>2</sub> operation completes and is written to the HI/LO registers pair the W<sub>MDU</sub> stage, while the Sub instruction write to the register file in the W stage.

# 2.3.1 32x16 Multiply (High-Performance MDU)

The 32x16 multiply operation begins in the last phase of the E stage, which is shared between the integer and MDU pipelines. In the latter phase of the E stage, the *rs* and *rt* operands arrive and the booth-recoding function occurs at this time. The multiply calculation requires one clock and occurs in the  $M_{MDU}$  stage. In the  $A_{MDU}$  stage, the carry-propagate-add (CPA) function occurs and the operation is completed. The result is ready to be read from the HI/LO registers in the  $W_{MDU}$  stage.

Figure 2-4 shows a diagram of a 32x16 multiply operation.




Figure 2-4 MDU Pipeline Flow During a 32x16 Multiply Operation

# 2.3.2 32x32 Multiply (High-Performance MDU)

The 32x32 multiply operation begins in the last phase of the E stage, which is shared between the integer and MDU pipelines. In the latter phase of the E stage, the rs and rt operands arrive and the booth recoding function occurs at this time. The multiply calculation requires two clocks and occurs in the  $M_{MDU}$  stage. In the  $A_{MDU}$  stage, the CPA function occurs and the operation is completed.

Figure 2-5 shows a diagram of a 32x32 multiply operation.




Figure 2-5 MDU Pipeline Flow During a 32x32 Multiply Operation

# 2.3.3 Divide (High-Performance MDU)

Divide operations are implemented using a simple non-restoring division algorithm. This algorithm works only for positive operands, hence the first cycle of the  $M_{MDU}$  stage is used to negate the rs operand (RS Adjust) if needed. Note that this cycle is spent even if the adjustment is not necessary. During the next maximum 32 cycles (3-34) an iterative add/subtract loop is executed. In cycle 3 an early-in detection is performed in parallel with the add/subtract. The adjusted rs operand is detected to be zero extended on the upper most 8, 16 or 24 bits. If this is the case the following 7, 15 or 23 cycles of the add/subtract iterations are skipped.

The remainder adjust (Rem Adjust) cycle is required if the remainder was negative. Note that this cycle is spent even if the remainder was positive. A sign adjust is performed on the quotient and/or remainder if necessary. The sign adjust stage is skipped if both operands are positive. In this case the Rem Adjust is moved to the  $A_{MDLI}$  stage.

Figure 2-6 on page 18, Figure 2-7 on page 19, Figure 2-8 on page 19 and Figure 2-9 on page 19 show the latency for 8, 16, 24 and 32 bit divide operations, respectively. The repeat rate is either 11, 19, 27 or 35 cycles (one less if the *sign adjust* stage is skipped) as a second divide can be in the *RS Adjust* stage when the first divide is in the *Reg WR* stage.




Figure 2-6 High-Performance MDU Pipeline Flow During a 8-bit Divide (DIV) Operation




Figure 2-7 High-Performance MDU Pipeline Flow During a 16-bit Divide (DIV) Operation




Figure 2-8 High-Performance MDU Pipeline Flow During a 24-bit Divide (DIV) Operation




Figure 2-9 High-Performance MDU Pipeline Flow During a 32-bit Divide (DIV) Operation

# 2.4 MDU Pipeline (Area-Efficient MDU)

The area-efficient multiply/divide unit (MDU) is a separate autonomous block for multiply and divide operations. The MDU is not pipelined, but rather performs the computations iteratively in parallel with the integer unit (IU) pipeline. It does not stall when the IU pipeline stalls. This allows the long-running MDU operations to be partially masked by system stalls and/or other integer unit instructions.

The MDU consists of one 32-bit adder result-accumulate registers (HI and LO), a combined multiply/divide state machine and all multiplexers and control logic. A simple 1-bit per clock recursive algorithm is used for both multiply and divide operations. Using booth's algorithm all multiply operations complete in 32 clocks. Two extra clocks are needed for multiply-accumulate. The non-restoring algorithm used for divide operations will not work with negative numbers. Adjustment before and after are thus required depending on the sign of the operands. All divide operations complete in 33 to 35 clocks.

Table 2-3 lists the latencies (number of cycles until a result is available) for multiply and divide instructions. The latencies are listed in terms of pipeline clocks. In this table 'latency' refers to the number of cycles necessary for the second instruction to use the results of the first.

Operand Signs of 1st Instruction (Rs,Rt)	Instruction Sequence		
	1st Instruction	2nd Instruction	Latency Clocks
any, any	MULT/MULTU	MADD/MADDU, MSUB/MSUBU, or MFHI/MFLO	32
any, any	MADD/MADDU, MSUB/MSUBU	MADD/MADDU, MSUB/MSUBU, or MFHI/MFLO	34
any, any	MUL	Integer operation <sup>[1]</sup>	32
any, any	DIVU	MFHI/MFLO	33
pos, pos	DIV	MFHI/MFLO	33
any, neg	DIV	MFHI/MFLO	34
neg, pos	DIV	MFHI/MFLO	35
any, any	MFHI/MFLO	Integer operation <sup>[1]</sup>	2
any, any	MTHI/MTLO	MADD/MADDU, MSUB/MSUBU	1

Table 2-3 M4K<sup>TM</sup> Core Instruction Latencies (Area-Efficient MDU)

# 2.4.1 Multiply (Area-Efficient MDU)

Multiply operations are executed using a simple iterative multiply algorithm. Using Booth's approach, this algorithm works for both positive and negative operands. The operation uses 32 cycles in  $M_{MDU}$  stage to complete a multiplication. The register writeback to HI and LO are done in the A stage. For MUL operations, the register file writeback is done in the  $W_{MDU}$  stage.

Figure 2-10 shows the latency for a multiply operation. The repeat rate is 33 cycles as a second multiply can be in the first  $M_{MDII}$  stage when the first multiply is in  $A_{MDII}$  stage.




Figure 2-10 M4K™ Area-Efficient MDU Pipeline Flow During a Multiply Operation

# 2.4.2 Multiply Accumulate (Area-Efficient MDU)

Multiply-accumulate operations use the same multiply machine as used for multiply only. Two extra stages are needed to perform the addition/subtraction. The operations uses 34 cycles in  $M_{\mbox{\scriptsize MDU}}$  stage to complete the multiply-accumulate. The register writeback to HI and LO are done in the A stage.

Figure 2-11 shows the latency for a multiply-accumulate operation. The repeat rate is 35 cycles as a second multiply-accumulate can be in the E stage when the first multiply is in the last  $M_{\mbox{\scriptsize MDU}}$  stage.




Figure 2-11 M4KC Area-Efficient MDU Pipeline Flow During a Multiply Accumulate Operation

# 2.4.3 Divide (Area-Efficient MDU)

Divide operations also implement a simple non-restoring algorithm. This algorithm works only for positive operands, hence the first cycle of the  $M_{MDU}$  stage is used to negate the rs operand (RS Adjust) if needed. Note that this cycle is executed even if negation is not needed. The next 32 cycle (3-34) executes an interactive add/subtract-shift function.

Two sign adjust (Sign Adjust 1/2) cycles are used to change the sign of one or both the quotient and the remainder. Note that one or both of these cycles are skipped if they are not needed. The rule is, if both operands were positive or if this is an unsigned division; both of the sign adjust cycles are skipped. If the *rs* operand was negative, one of the sign adjust cycles is skipped. If only the *rs* operand was negative, none of the sign adjust cycles are skipped. Register writeback to HI and LO are done in the A stage.

Figure 2-12 shows the pipeline flow for a divide operation. The repeat rate is either 34, 35 or 36 cycles (depending on how many sign adjust cycles are skipped) as a second divide can be in the E stage when the first divide is in the last  $M_{MDU}$  stage.




Figure 2-12 M4K<sup>TM</sup> Area-Efficient MDU Pipeline Flow During a Divide (DIV) Operation

# 2.5 Branch Delay

The pipeline has a branch delay of one cycle. The one-cycle branch delay is a result of the branch decision logic operating during the E pipeline stage. This allows the branch target address to be used in the I stage of the instruction following 2 cycles after the branch instruction. By executing the 1st instruction following the branch instruction sequentially before switching to the branch target, the intervening branch delay slot is utilized. This avoids bubbles being injected into the pipeline on branch instructions. Both the address calculation and the branch condition check are performed in the E stage.

The pipeline begins the fetch of either the branch path or the fall-through path in the cycle following the delay slot. After the branch decision is made, the processor continues with the fetch of either the branch path (for a taken branch) or the fall-through path (for the non-taken branch).

The branch delay means that the instruction immediately following a branch is always executed, regardless of the branch direction. If no useful instruction can be placed after the branch, then the compiler or assembler must insert a NOP instruction in the delay slot.

Figure 2-13 illustrates the branch delay.




Figure 2-13 IU Pipeline Branch Delay

# 2.6 Data Bypassing

Most MIPS32 instructions use one or two register values as source operands. These operands are fetched from the register file in the first part of E stage. The ALU straddles the E to M boundary, and can present the result early in M stage. The result is not written to the register file before the W stage however. If no precautions were made, it would take 3 cycles before the result was available for the following instructions. To avoid this, data bypassing is implemented.

Between the register file and the ALU a data bypass multiplexer is placed on both operands (see Figure 2-14 on page 22). This enables the M4K core to forward data from a preceding instruction whose target is a source register of a following instruction. An M to E bypass and an A to E bypass feed the bypass multiplexers. A W to E bypass is not needed, as the register file is capable of making an internal bypass of Rd write data directly to the Rs and Rt read ports.




Figure 2-14 IU Pipeline Data bypass

Figure 2-15 on page 23 shows the data bypass for an  $Add_1$  instruction followed by a  $Sub_2$  and another  $Add_3$  instruction. The  $Sub_2$  instruction uses the output from the  $Add_1$  instruction as one of the operands, and thus the M to E bypass is used. The following  $Add_3$  uses the result from both the first  $Add_1$  instruction and the  $Sub_2$  instruction. Since the  $Add_1$ 

data is now in A stage, the A to E bypass is used, and the M to E bypass is used to bypass the Sub<sub>2</sub> data to the Add<sub>2</sub> instruction.




Figure 2-15 IU Pipeline M to E bypass

#### 2.6.1 Load Delay

Load delay refers to the fact, that data fetched by a load instruction is not available in the integer pipeline until after the load aligner in A stage. All instructions need the source operands available in the E stage. An instruction immediately following a load instruction will, if it has the same source register as was the target of the load, cause an instruction interlock pipeline slip in the E stage (see Section 2.10, "Instruction Interlocks" on page 26). If an instruction following the load by 1 or 2 cycles uses the data from the load, the A to E bypass (see Figure 2-14) serves to reduce or avoid stall cycles. An instruction flow of this is shown in Figure 2-16.




Figure 2-16 IU Pipeline A to E Data bypass

# 2.6.2 Move from HI/LO and CP0 Delay

As indicated in Figure 2-14, not only load data, but also data moved from the HI or LO registers (MFHI/MFLO) and data moved from CP0 (MFC0) enters the IU-Pipeline in the A stage. That is, data is not available in the integer pipeline until early in the A stage. The A to E bypass is available for this data. But as for Loads, an instruction following immediately after one of these move instructions must be paused for one cycle if the target of the move is among the sources of that following instruction. This then causes an interlock slip in the E stage (see Section 2.10, "Instruction Interlocks" on page 26). An interlock slip after a MFHI is illustrated in Figure 2-17.




Figure 2-17 IU Pipeline Slip after a MFHI

# 2.7 Coprocessor 2 instructions

If a coprocessor 2 is attached to the M4K core, a number of transactions has to take place on the CP2 Interface, for each coprocessor 2 instruction. First of all if the CU[2] bit in the CP0 *Status* register is not set, then no coprocessor 2 related instruction will start a transaction on the CP2 Interface. Rather a Coprocessor Unusable exception will signaled. If the CU[2] bit is set, and a coprocessor 2 instruction is fetched, the following transactions will occur on the CP2 Interface:

- 1. The Instruction is presented on the instructions bus in E-stage. The coprocessor 2 can do a decode in the same cycle.
- 2. The Instruction is validated from the core in M-stage. From this point the core will accept control and data signals back from coprocessor 2. All control and data signals from the coprocessor 2 is captured on input latches to the core.
- 3. If all the expected control and data signals was presented to the core in the previous M-stage, the core will proceed executing the A-stage. If some return information is missing, the A-stage will not advance and cause a slip on all I, E and M-stage, see Section 2.9, "Slip Conditions" on page 25.

  If this instruction involved sending data from the core to the coprocessor 2, then this data is send in A-stage.
- 4. The instruction completion is signaled to the coprocessor 2 in the W-stage. Potential data from the coprocessor is written in the register file.

Figure 2-18 on page 24 Show the timing relationship between the M4K core and the coprocessor 2 for all coprocessor 2 instruction.




Figure 2-18 Coprocessor 2 Interface Transactions

As can be seen all control and data from the coprocessor must occur in the M-stage. If this is not the case, the A-stage will start slipping in the following cycle, and thus stall the I, E, M and A pipeline stages; but if all expected control and data is available in the M-stage, a Coprocessor 2 instructions can execute with no stalls on the pipeline.

There is only one exception to this, and that is the Branch on Coprocessor conditions (BC2) instruction. All branch instructions, including the regular BEQ, BNE... etc. must be resolved in E-stage. The M4K core does not have branch prediction logic, and thus the target address must be available before the end of E-stage. The BC2 instruction has to follow the same protocol as all other coprocessor 2 instructions on the CP2 Interface. All core interface operations belonging to the E, M and A stages will have to occur in the E-stage for BC2 instructions. This means that a BC2 instructions always slips for a minimum of 2 cycles in E-stage. Any delay in return of branch information from the Coprocessor 2 will add to the number of slip cycles. All other Coprocessor 2 instructions can operate without slips, provided that all control and data information from the Coprocessor 2 is transferred in the M-stage.

# 2.8 Interlock Handling

Smooth pipeline flow is interrupted when cache misses occur or when data dependencies are detected. Interruptions handled entirely in hardware, such as cache misses, are referred to as *interlocks*. At each cycle, interlock conditions are checked for all active instructions.

Table 2-4 lists the types of pipeline interlocks for the M4K processor core.

Interlock Type	Sources	Slip Stage	
I-side SRAM Stall	SRAM Access not complete	E Stage	
	Producer-consumer hazards	E/M Stage	
Instruction	Hardware Dependencies (MDU)	E Stage	
	BC2 waiting for COP2 Condition Check		
D-side SRAM Stall	SRAM Access not complete	A Stage	
Coprocessor 2 completion slip	Coprocessor 2 control and/or data delay from coprocessor	A Stage	

**Table 2-4 Pipeline Interlocks** 

In general, MIPS processors support two types of hardware interlocks:


- Stalls, which are resolved by halting the pipeline
- Slips, which allow one part of the pipeline to advance while another part of the pipeline is held static

In the M4K processor core, all interlocks are handled as slips.

# 2.9 Slip Conditions

On every clock internal logic determines whether each pipe stage is allowed to advance. These slip conditions propagate backwards down the pipe. For example, if the M stage does not advance, neither does the E or I stage.

Slipped instructions are retried on subsequent cycles until they issue. The back end of the pipeline advances normally during slips. This resolves the conflict when the slip was caused by a missing result. NOPs are inserted into the bubble in the pipeline. Figure 2-19 on page 26 shows an instruction cache miss.



(3) Execute E-stage

Figure 2-19 Instruction Cache Miss Slip

Figure 2-19 on page 26 shows a diagram of a two-cycle slip. In the first clock cycle, the pipeline is full and the cache miss is detected. Instruction I0 is in the A stage, instruction I1 is in the M stage, instruction I2 is in the E stage, and instruction I3 is in the I stage. The cache miss occurs in clock 2 when the I4 instruction fetch is attempted. I4 advances to the E-stage and waits for the instruction to be fetched from main memory. In this example it takes two clocks (3 and 4) to fetch the I4 instruction from memory. Once the cache miss is resolved in clock 4 and the instruction is bypassed to the E stage, the pipeline is restarted, causing the I4 instruction to finally execute it's E-stage operations.

### 2.10 Instruction Interlocks

Most instructions can be issued at a rate of one per clock cycle. In order to adhere to the sequential programming model, the issue of an instruction must sometimes be delayed. This to ensure that the result of a prior instruction is available. Table 2-5 details the instruction interactions that prevent an instruction from advancing in the processor pipeline.

**Instruction Interlocks** Issue Delay (in **First Instruction Second Instruction Clock Cycles**) Slip Stage LB/LBU/LH/LHU/LL/LW/LWL/LWR Consumer of load data E stage Consumer of destination MFC0 1 E stage register 16bx32b 0 MULTx/MADDx/MSUBx MFLO/MFHI (high-performance MDU) 32bx32b 1 M stage 2 16bx32b E stage Consumer of target data (high-performance MDU) 32bx32b 3 E stage

**Table 2-5 Instruction Interlocks** 

**Table 2-5 Instruction Interlocks** 

Instruction Interlocks					
First Instruction		Second Instruction	Issue Delay (in Clock Cycles)	Slip Stage	
MUL	16bx32b	Non Consumer of target data	1	E stage	
(high-performance MDU)	32bx32b	Non-Consumer of target data	2	E stage	
MFHI/MFLO		Consumer of target data	1	E stage	
MULTx/MADDx/MSUBx	16bx32b	MULT/MUL/MADD/MSUB	0[1]	E stage	
(high-performance MDU)	32bx32b	MTHI/MTLO/DIV	1 <sup>[1]</sup>	E stage	
DIV		MUL/MULTx/MADDx/ MSUBx/MTHI/MTLO/ MFHI/MFLO/DIV	Until DIV completes	E stage	
MULT/MUL/MADD/MSUB/MTHI/MTLO/MFHI/MFLO/DIV (area-efficient MDU)		MULT/MUL/MADD/MSUB /MTHI/MTLO/MFHI/MFL O/DIV	Until 1st MDU op completes	E stage	
MUL (area-efficient MDU)		Any Instruction	Until MUL completes	E stage	
MFC0/MFC2/CFC2		Consumer of target data	1	E stage	

### 2.11 Hazards

In general, the M4K core ensures that instructions are executed following a fully sequential program model. Each instruction in the program sees the results of the previous instruction. There are some deviations to this model. These deviations are referred to as *hazards*.

Prior to Release 2 of the MIPS32<sup>TM</sup> Architecture, hazards (primarily CP0 hazards) were relegated to implementation-dependent cycle-based solutions, primarily based on the SSNOP instruction. This has been an insufficient and error-prone practice that must be addressed with a firm compact between hardware and software. As such, new instructions have been added to Release 2 of the architecture which act as explicit barriers that eliminate hazards. To the extent that it was possible to do so, the new instructions have been added in such a way that they are backward-compatible with existing MIPS processors.

# 2.11.1 Types of Hazards

With one exception, all hazards were eliminated in Release 1 of the Architecture for unprivileged software. The exception occurs when unprivileged software writes a new instruction sequence and then wishes to jump to it. Such an operation remained a hazard, and is addressed by the capabilities of Release 2.

In privileged software, there are two different types of hazards: *execution hazards* and *instruction hazards*. Both are defined below.

### 2.11.1.1 Execution Hazards

Execution hazards are those created by the execution of one instruction, and seen by the execution of another instruction. Table 2-6 lists execution hazards.

**Table 2-6 Execution Hazards** 

Producer	$\rightarrow$	Consumer	Hazard On	Spacing (Instructions)
MTC0	$\rightarrow$	Coprocessor instruction execution depends on the new value of Status <sub>CU</sub>	Status <sub>CU</sub>	1
MTC0	$\rightarrow$	ERET	EPC DEPC ErrorEPC	1
MTC0	$\rightarrow$	ERET	Status	0
MTC0, EI, DI	$\rightarrow$	Interrupted Instruction	Status <sub>IE</sub>	1
MTC0	$\rightarrow$	Interrupted Instruction	Cause <sub>IP</sub>	3
MTC0	$\rightarrow$	RDPGPR WRPGPR	SRSCtl <sub>PSS</sub>	1
MTC0	$\rightarrow$	Instruction not seeing a Timer Interrupt	Compare update that clears Timer Interrupt	41
MTC0	$\rightarrow$	Instruction affected by change	Any other CP0 register	2

<sup>1.</sup> This is the minimum value. Actual value is system-dependent since it is a function of the sequential logic between the SI\_TimerInt output and the external logic which feeds SI\_TimerInt back into one of the SI\_Int inputs, or a function of the method for handling SI\_TimerInt in an external interrupt controller.

#### 2.11.1.2 Instruction Hazards

Instruction hazards are those created by the execution of one instruction, and seen by the instruction fetch of another instruction. Table 2-7 lists instruction hazards.

**Table 2-7 Instruction Hazards** 

Producer	$\rightarrow$	Consumer	Hazard On	Spacing (Instructions)
MTC0	$\rightarrow$	Instruction fetch seeing the new value (including a change to ERL followed by an instruction fetch from the useg segment)	Status	
Instruction stream write via redirected store	$\rightarrow$	Instruction fetch seeing the new instruction stream	Cache entries	3

# 2.11.2 Instruction Listing

Table 2-8 lists the instructions designed to eliminate hazards. See the document titled *MIPS32*<sup>TM</sup> *Architecture for Programmers Volume II: The MIPS32*<sup>TM</sup> *Instruction Set* (MD00086) for a more detailed description of these instructions.

**Table 2-8 Hazard Instruction Listing** 

Mnemonic	Function	
ЕНВ	Clear execution hazard	
JALR.HB	Clear both execution and instruction hazards	

**Table 2-8 Hazard Instruction Listing** 

Mnemonic	Function	
JR.HB	Clear both execution and instruction hazards	
SYNCI	Synchronize caches after instruction stream write	

### 2.11.2.1 Instruction Encoding

The EHB instruction is encoded using a variant of the NOP/SSNOP encoding. This encoding was chosen for compatibility with the Release 1 SSNOP instruction, such that existing software may be modified to be compatible with both Release 1 and Release 2 implementations. See the EHB instruction description for additional information.

The JALR.HB and JR.HB instructions are encoding using bit 10 of the *hint* field of the JALR and JR instructions. These encodings were chosen for compatibility with existing MIPS implementations, including many which pre-date the MIPS32 architecture. Because a pipeline flush clears hazards on most early implementations, the JALR.HB or JR.HB instructions can be included in existing software for backward and forward compatibility. See the JALR.HB and JR.HB instructions for additional information.

The SYNCI instruction is encoded using a new encoding of the REGIMM opcode. This encoding was chosen because it causes a Reserved Instruction exception on all Release 1 implementations. As such, kernel software running on processors that don't implement Release 2 can emulate the function using the CACHE instruction.

### 2.11.3 Eliminating Hazards

The Spacing column shown in Table 2-6 and Table 2-7 indicates the number of unrelated instructions (such as NOPs or SSNOPs) that, prior to the capabilities of Release 2, would need to be placed between the producer and consumer of the hazard in order to ensure that the effects of the first instruction are seen by the second instruction. Entries in the table that are listed as 0 are traditional MIPS hazards which are not hazards on the M4K core.

With the hazard elimination instructions available in Release 2, the preferred method to eliminate hazards is to place one of the instructions listed in Table 2-8 between the producer and consumer of the hazard. Execution hazards can be removed by using the EHB, JALR.HB, or JR.HB instructions. Instruction hazards can be removed by using the JALR.HB or JR.HB instructions, in conjunction with the SYNCI instruction. Since the M4K core does not contain caches, the SYNCI instruction is not strictly necessary, but is still recommended to create portable code that can be run on other MIPS processors that may contain caches.

# Memory Management of the M4K<sup>TM</sup> Core

The M4K<sup>TM</sup> processor core includes a Memory Management Unit (MMU) that interfaces between the execution unit and the cache controller. The core implements a simple Fixed Mapping (FM) style MMU.

This chapter contains the following sections:

- Section 3.1, "Introduction"
- Section 3.2, "Modes of Operation"
- Section 3.3, "Fixed Mapping MMU"
- Section 3.4, "System Control Coprocessor"

# 3.1 Introduction

The MMU will translate any virtual address to a physical address before a request is sent to the SRAM interface for an external memory reference.

In the M4K processor core, the MMU is based on a simple algorithm to translate virtual addresses into physical addresses via a Fixed Mapping (FM) mechanism. These translations are different for various regions of the virtual address space (useg/kuseg, kseg0, kseg1, kseg2/3).

Figure 3-1 shows how the memory management unit interacts with the SRAM access in the M4K core.




Figure 3-1 Address Translation During SRAM Access

# 3.2 Modes of Operation

A M4K processor core supports three modes of operation:

- User mode
- · Kernel mode
- · Debug mode

User mode is most often used for application programs. Kernel mode is typically used for handling exceptions and privileged operating system functions, including CP0 management and I/O device accesses. Debug mode is used for software debugging and most likely occurs within a software development tool.

The address translation performed by the MMU depends on the mode in which the processor is operating.

### 3.2.1 Virtual Memory Segments

The Virtual memory segments are different depending on the mode of operation. Figure 3-2 on page 34 shows the segmentation for the 4 GByte (2<sup>32</sup> bytes) virtual memory space addressed by a 32-bit virtual address, for the three modes of operation.

The core enters Kernel mode both at reset and when an exception is recognized. While in Kernel mode, software has access to the entire address space, as well as all CP0 registers. User mode accesses are limited to a subset of the virtual address space (0x0000\_0000 to 0x7FFF\_FFFF) and can be inhibited from accessing CP0 functions. In User mode, virtual addresses 0x8000\_0000 to 0xFFFF\_FFFF are invalid and cause an exception if accessed.

Debug mode is entered on a debug exception. While in Debug mode, the debug software has access to the same address space and CP0 registers as for Kernel mode. In addition, while in Debug mode the core has access to the debug segment dseg. This area overlays part of the kernel segment kseg3. dseg access in Debug mode can be turned on or off, allowing full access to the entire kseg3 in Debug mode, if so desired.




Figure 3-2 M4K<sup>TM</sup> processor core Virtual Memory Map.

Each of the segments shown in Figure 3-2 on page 34 are either mapped or unmapped. The following two sub-sections explain the distinction. Then sections Section 3.2.2, "User Mode", Section 3.2.3, "Kernel Mode" and Section 3.2.4, "Debug Mode" specify which segments are actually mapped and unmapped.

### 3.2.1.1 Unmapped Segments

An unmapped segment does not use the FM to translate from virtual-to-physical addresses. Especially after reset, it is important to have unmapped memory segments, because the TLB is not yet programmed to perform the translation.

Unmapped segments have a fixed simple translation from virtual to physical address. This is much like the translations the FM provides for the M4K core, but we will still make the distinction.

All segments, whether mapped or unmapped, are treated as uncached on the M4K core.

### 3.2.1.2 Mapped Segments

A mapped segment does use the FMto translate from virtual-to-physical addresses.

MIPS32 M4K™ Processor Core Software User's Manual, Revision 1.02

For the M4K core, the mapped segments have a fixed translation from virtual to physical address. All segments, whether mapped or unmapped, are treated as uncached on the M4K core. Write protection of segments is not possible during FM translation.

# 3.2.2 User Mode

In user mode, a single 2 GByte (2<sup>31</sup> bytes) uniform virtual address space called the user segment (useg) is available. Figure 3-3 on page 35 shows the location of user mode virtual address space.




Figure 3-3 User Mode Virtual Address Space

The user segment starts at address 0x0000\_0000 and ends at address 0x7FFF\_FFF. Accesses to all other addresses cause an address error exception.

The processor operates in User mode when the Status register contains the following bit values:

- UM = 1
- EXL = 0
- ERL = 0

In addition to the above values, the DM bit in the *Debug* register must be 0.

Table 3-1 lists the characteristics of the useg User mode segments.

0

1

useg

**Table 3-1 User Mode Segments** 

All valid user mode virtual addresses have their most significant bit cleared to 0, indicating that user mode can only access the lower half of the virtual memory map. Any attempt to reference an address with the most significant bit set while in user mode causes an address error exception.

The system maps all references to useg through the FM.

0

A(31) = 0

0x7FFF\_FFFF

2 GByte (2<sup>31</sup> bytes)

#### 3.2.3 Kernel Mode

The processor operates in Kernel mode when the DM bit in the *Debug* register is 0 and the *Status* register contains one or more of the following values:

- UM = 0
- ERL = 1
- EXL = 1

When a non-debug exception is detected, EXL or ERL will be set and the processor will enter Kernel mode. At the end of the exception handler routine, an Exception Return (ERET) instruction is generally executed. The ERET instruction jumps to the Exception PC, clears ERL, and clears EXL if ERL=0. This may return the processor to User mode.

Kernel mode virtual address space is divided into regions differentiated by the high-order bits of the virtual address, as shown in Figure 3-4 on page 36. Also, Table 3-2 lists the characteristics of the Kernel mode segments.




Figure 3-4 Kernel Mode Virtual Address Space

Address Bit	Status Register Is One of These Values		Segment		Segment	
Values	UM	EXL	ERL	Name	Address Range	Size
A(31) = 0				kuseg	0x0000_0000 through 0x7FFF_FFFF	2 GBytes (2 <sup>31</sup> bytes)
A(31:29) = 100 <sub>2</sub>		(UM = 0) or		kseg0	0x8000_0000 through 0x9FFF_FFFF	512 MBytes (2 <sup>29</sup> bytes)
A(31:29) = 101 <sub>2</sub>		EXL = 1 or $ERL = 1$ )		kseg1	0xA000_0000 through 0xBFFF_FFFF	512 MBytes (2 <sup>29</sup> bytes)
A(31:29) = 110 <sub>2</sub>		and $DM = 0$		kseg2	0xC000_0000 through 0xDFFF_FFFF	512 MBytes (2 <sup>29</sup> bytes)
A(31:29) = 111 <sub>2</sub>				kseg3	0xE000_0000 through 0xFFFF_FFFF	512 MBytes (2 <sup>29</sup> bytes)

### 3.2.3.1 Kernel Mode, User Space (kuseg)

In Kernel mode, when the most-significant bit of the virtual address (A31) is cleared, the 32-bit kuseg virtual address space is selected and covers the full 2<sup>31</sup> bytes (2 GBytes) of the current user address space mapped to addresses 0x0000\_0000 - 0x7FFF\_FFFF.

When ERL = 1 in the *Status* register, the user address region becomes a  $2^{31}$ -byte unmapped and uncached address space. While in this setting, the kuseg virtual address maps directly to the same physical address, and does not include the ASID field.

### 3.2.3.2 Kernel Mode, Kernel Space 0 (kseg0)

In Kernel mode, when the most-significant three bits of the virtual address are 100<sub>2</sub>, 32-bit kseg0 virtual address space is selected; it is the 2<sup>29</sup>-byte (512-MByte) kernel virtual space located at addresses 0x8000\_0000 - 0x9FFF\_FFFF. References to kseg0 are unmapped; the physical address selected is defined by subtracting 0x8000\_0000 from the virtual address. The K0 field of the *Config* register controls cacheability.

### 3.2.3.3 Kernel Mode, Kernel Space 1 (kseg1)

In Kernel mode, when the most-significant three bits of the 32-bit virtual address are  $101_2$ , 32-bit kseg1 virtual address space is selected. kseg1 is the  $2^{29}$ -byte (512-MByte) kernel virtual space located at addresses  $0xA000\_0000$  -  $0xBFFF\_FFF$ . References to kseg1 are unmapped; the physical address selected is defined by subtracting  $0xA000\_0000$  from the virtual address. Caches are disabled for accesses to these addresses, and physical memory (or memory-mapped I/O device registers) are accessed directly.

# 3.2.3.4 Kernel Mode, Kernel Space 2 (kseg2)

In Kernel mode, when UM = 0, ERL = 1, or EXL = 1 in the *Status* register, and DM = 0 in the *Debug* register, and the most-significant three bits of the 32-bit virtual address are  $110_2$ , 32-bit kseg2 virtual address space is selected. In the M4K core, this  $2^{29}$ -byte (512-MByte) kernel virtual space is located at physical addresses  $0xC000\_0000$  -  $0xDFFF\_FFFF$ .

### 3.2.3.5 Kernel Mode, Kernel Space 3 (kseg3)

In Kernel mode, when the most-significant three bits of the 32-bit virtual address are  $111_2$ , the kseg3 virtual address space is selected. In the M4K core, this  $2^{29}$ -byte (512-MByte) kernel virtual space is located at physical addresses  $0xE000\ 0000$  -  $0xFFFF\ FFFF$ .

### 3.2.4 Debug Mode

Debug mode address space is identical to Kernel mode address space with respect to mapped and unmapped areas, except for kseg3. In kseg3, a debug segment dseg co-exists in the virtual address range 0xFF20\_0000 to 0xFF3F\_FFF. The layout is shown in Figure 3-5 on page 38.




Figure 3-5 Debug Mode Virtual Address Space

The dseg is sub-divided into the dmseg segment at 0xFF20\_0000 to 0xFF2F\_FFFF which is used when the probe services the memory segment, and the drseg segment at 0xFF30\_0000 to 0xFF3F\_FFFF which is used when memory-mapped debug registers are accessed. The subdivision and attributes for the segments are shown in Table 3-3.

Accesses to memory that would normally cause an exception if tried from kernel mode cause the core to re-enter debug mode via a debug mode exception.

The unmapped kseg0 and kseg1 segments from kernel mode address space are available from debug mode, which allows the debug handler to be executed from uncached and unmapped memory.

Segment Name	Sub-Segment Name	Virtual Address	Generates Physical Address	Cache Attribute
		0xFF20_0000		
	dmseg	through	dmseg maps to addresses 0x0 0000 - 0xF FFFF in EJTAG	
1		0xFF2F_FFFF	probe memory space.	TT 1 1
dseg		0xFF30_0000		Uncached
	drseg	through	drseg maps to the breakpoint registers 0x0_0000 - 0xF_FFFF	
		0xFF3F_FFFF		

Table 3-3 Physical Address and Cache Attributes for dseg, dmseg, and drseg Address Spaces

### 3.2.4.1 Conditions and Behavior for Access to drseg, EJTAG Registers

The behavior of CPU access to the drseg address range at 0xFF30\_0000 to 0xFF3F\_FFFF is determined as shown in Table 3-4

Transaction	LSNM bit in Debug register	Access
Load / Store	1	Kernel mode address space (kseg3)
Fetch	Don't care	drseg see comments below
Load / Store	0	drseg, see comments below

Table 3-4 CPU Access to drseg Address Range

Debug software is expected to read the debug control register (DCR) to determine which other memory mapped registers exist in drseg. The value returned in response to a read of any unimplemented memory mapped register is unpredictable, and writes are ignored to any unimplemented register in the drseg. Refer to Chapter 8, "EJTAG Debug Support in the  $M4K^{TM}$  Core," for more information on the DCR.

The allowed access size is limited for the drseg. Only word size transactions are allowed. Operation of the processor is undefined for other transaction sizes.

### 3.2.4.2 Conditions and Behavior for Access to dmseg, EJTAG Memory

The behavior of CPU access to the dmseg address range at 0xFF20\_0000 to 0xFF2F\_FFFF is determined by the table shown in Table 3-5

Transaction	ProbEn bit in DCR register	LSNM bit in Debug register	Access
Load / Store	Don't care	1	Kernel mode address space (kseg3)
Fetch	1	Don't care	dmeag
Load / Store	1	0	dmseg
Fetch	0	Don't care	See comments below
Load / Store	0	0	See comments below

Table 3-5 CPU Access to dmseg Address Range

The case with access to the dmseg when the ProbEn bit in the DCR register is 0 is not expected to happen. Debug software is expected to check the state of the ProbEn bit in DCR register before attempting to reference dmseg. If such a reference does happen, the reference hangs until it is satisfied by the probe. The probe can not assume that there will never be a reference to dmseg if the ProbEn bit in the DCR register is 0 because there is an inherent race between the debug software sampling the ProbEn bit as 1 and the probe clearing it to 0.

# 3.3 Fixed Mapping MMU

The M4K core implements a simple Fixed Mapping (FM) memory management unit that is smaller than the a full translation lookaside buffer (TLB) and more easily synthesized. Like a TLB, the FM performs virtual-to-physical address translation and provides attributes for the different memory segments. Those memory segments which are unmapped in a TLB implementation (kseg0 and kseg1) are translated identically by the FM in the M4K MMU.

The FM also determines the cacheability of each segment. These attributes are controlled via bits in the *Config* register. Table 3-6 shows the encoding for the K23 (bits 30:28), KU (bits 27:25) and K0 (bits 2:0) of the *Config* register. Since the M4K core does not contain caches, these *Config* fields are read-only and contain a fixed value that is always interpreted as uncacheable by the core.

**Table 3-6 Cache Coherency Attributes** 

Config Register Fields K23, KU, and K0	Cache Coherency Attribute
2	Uncached. This field is read-only and always holds a static value of 2. No other values are possible in the M4K core.

In the M4K core, no translation exceptions can be taken, although address errors are still possible.

Table 3-7 Cacheability of Segments with Block Address Translation

Segment	Virtual Address Range	Cacheability	
uses /leuses	0x0000_0000-	Controlled by the KU field (bits 27:25) of the <i>Config</i> register. Refer to	
useg/kuseg	0x7FFF_FFFF	Table 3-6 for the encoding.	
lraag0	0x8000_0000-	Controlled by the K0 field (bits 2:0) of the <i>Config</i> register. See Table	
kseg0	0x9FFF_FFFF	3-6 for the encoding.	
kseg1	0xA000_0000-	Always year sheekla	
	0xBFFF_FFFF	Always uncacheable	
knog2	0xC000_0000-	Controlled by the K23 field (bits 30:28) of the <i>Config</i> register. Refer to	
kseg2	0xDFFF_FFFF	Table 3-6 for the encoding.	
kseg3	0xE000_0000-	Controlled by K23 field (bits 30:28) of the <i>Config</i> register. Refer to	
	0xFFFF_FFFF	Table 3-6 for the encoding.	

The FM performs a simple translation to map from virtual addresses to physical addresses. This mapping is shown in Figure 3-6 on page 41. When ERL=1, useg and kuseg become unmapped and uncached. The ERL behavior is the same as if there was a TLB. The ERL mapping is shown in Figure 3-7 on page 42.

The ERL bit is usually never asserted by software. It is asserted by hardware after a Reset, SoftReset or NMI. See Section 4.8, "Exceptions" on page 59 for further information on exceptions.




Figure 3-6 FM Memory Map (ERL=0) in the M4K  $^{\text{TM}}$  Processor Core




Figure 3-7 FM Memory Map (ERL=1) in the M4K<sup>TM</sup> Processor Core

# 3.4 System Control Coprocessor

The System Control Coprocessor (CP0) is implemented as an integral part of the M4K processor core and supports memory management, address translation, exception handling, and other privileged operations. Certain CP0 registers are used to support memory management. Refer to Chapter 5, "CP0 Registers of the M4K<sup>TM</sup> Core," on page 72 for more information on the CP0 register set.

# Exceptions and Interrupts in the M4K<sup>TM</sup> Core

The M4K<sup>TM</sup> processor core receives exceptions from a number of sources, including arithmetic overflows, I/O interrupts, and system calls. When the CPU detects one of these exceptions, the normal sequence of instruction execution is suspended and the processor enters kernel mode.

In kernel mode the core disables interrupts and forces execution of a software exception processor (called a handler) located at a specific address. The handler saves the context of the processor, including the contents of the program counter, the current operating mode, and the status of the interrupts (enabled or disabled). This context is saved so it can be restored when the exception has been serviced.

When an exception occurs, the core loads the *Exception Program Counter (EPC)* register with a location where execution can restart after the exception has been serviced. Most exceptions are *precise*, which mean that *EPC* can be used to identify the instruction that caused the exception. For precise exceptions the restart location in the *EPC* register is the address of the instruction that caused the exception or, if the instruction was executing in a branch delay slot, the address of the branch instruction immediately preceding the delay slot. To distinguish between the two, software must read the BD bit in the CPO *Cause* register. Bus error exceptions and CP2 exceptions may be imprecise. For imprecise exceptions the instruction that caused the exception can not be identified.

This chapter contains the following sections:

- Section 4.1, "Exception Conditions"
- Section 4.2, "Exception Priority"
- Section 4.3, "Interrupts"
- Section 4.4, "GPR Shadow Registers"
- Section 4.5, "Exception Vector Locations"
- Section 4.6, "General Exception Processing"
- Section 4.7, "Debug Exception Processing"
- Section 4.8, "Exceptions"
- Section 4.9, "Exception Handling and Servicing Flowcharts"

# 4.1 Exception Conditions

When an exception condition occurs, the relevant instruction and all those that follow it in the pipeline are cancelled. Accordingly, any stall conditions and any later exception conditions that may have referenced this instruction are inhibited; there is no benefit in servicing stalls for a cancelled instruction.

When an exception condition is detected on an instruction fetch, the core aborts that instruction and all instructions that follow. When this instruction reaches the W stage, the exception flag causes it to write various CPO registers with the exception state, change the current program counter (PC) to the appropriate exception vector address, and clear the exception bits of earlier pipeline stages.

This implementation allows all preceding instructions to complete execution and prevents all subsequent instructions from completing. Thus, the value in the *EPC* (*ErrorEPC* for errors, or *DEPC* for debug exceptions) is sufficient to restart

execution. It also ensures that exceptions are taken in the order of execution; an instruction taking an exception may itself be killed by an instruction further down the pipeline that takes an exception in a later cycle.

# **4.2 Exception Priority**

Table 4-1 lists all possible exceptions, and the relative priority of each, highest to lowest. Several of these exceptions can happen simultaneously, in that event the exception with the highest priority is the one taken.

**Table 4-1 Priority of Exceptions** 

Exception Description						
Reset	Assertion of SI_ColdReset signal.					
Soft Reset	Assertion of SI_Reset signal.					
DSS	EJTAG Debug Single Step.					
DINT	EJTAG Debug Interrupt. Caused by the assertion of the external EJ_DINT input, or by setting the EjtagBrk bit in the <i>ECR</i> register.					
NMI	Asserting edge of SI_NMI signal.					
Interrupt	Assertion of unmasked hardware or software interrupt signal.					
DIB	EJTAG debug hardware instruction break matched.					
AdEL	Fetch address alignment error.					
AULL	User mode fetch reference to kernel address.					
IBE	Instruction fetch bus error.					
DBp	EJTAG Breakpoint (execution of SDBBP instruction).					
Sys	Execution of SYSCALL instruction.					
Вр	Execution of BREAK instruction.					
CpU	Execution of a coprocessor instruction for a coprocessor that is not enabled					
RI	Execution of a Reserved Instruction.					
C2E	Execution of coprocessor 2 instruction which caused a general exception in the coprocessor.					
IS1	Execution of coprocessor 2 instruction which caused an Implementation Specific exception 1 in the coprocessor.					
IS2	Execution of coprocessor 2 instruction which caused an Implementation Specific exception 2 in the coprocessor.					
Ov	Execution of an arithmetic instruction that overflowed.					
Tr	Execution of a trap (when trap condition is true).					
DDBL / DDBS	EJTAG Data Address Break (address only) or EJTAG Data Value Break on Store (address and value).					
AdEL	Load address alignment error.					
AULL	User mode load reference to kernel address.					
AdES	Store address alignment error.					
/ MLD	User mode store to kernel address.					

**Table 4-1 Priority of Exceptions (Continued)** 

Exception	Description
DBE	Load or store bus error.
DDBL	EJTAG data hardware breakpoint matched in load data compare.

# 4.3 Interrupts

Older 32-bit cores available from MIPS that implemented Release 1 of the Architecture included support for two software interrupts, six hardware interrupts, and a special-purpose timer interrupt. (Note that the Architecture also defines a performance counter interrupt, but this is not implemented on the M4K core.) The timer interrupt was provided external to the core and typically combined with hardware interrupt 5 in an system-dependent manner. Interrupts were handled either through the general exception vector (offset 16#180) or the special interrupt vector (16#200), based on the value of Cause<sub>IV</sub>. Software was required to prioritize interrupts as a function of the Cause<sub>IP</sub> bits in the interrupt handler prologue.

Release 2 of the Architecture, implemented by the M4K core, adds an upward-compatible extension to the Release 1 interrupt architecture that supports vectored interrupts. In addition, Release 2 adds a new interrupt mode that supports the use of an external interrupt controller by changing the interrupt architecture.

### 4.3.1 Interrupt Modes

The M4K core includes support for three interrupt modes, as defined by Release 2 of the Architecture:

- Interrupt compatibility mode, which acts identically to that in an implementation of Release 1 of the Architecture.
- Vectored Interrupt (VI) mode, which adds the ability to prioritize and vector interrupts to a handler dedicated to that interrupt, and to assign a GPR shadow set for use during interrupt processing. The presence of this mode is denoted by the VInt bit in the *Config3* register. This mode is architecturally optional; but it is always present on the M4K core, so the VInt bit will always read as a 1 for the M4K core.
- External Interrupt Controller (EIC) mode, which redefines the way in which interrupts are handled to provide full support for an external interrupt controller handling prioritization and vectoring of interrupts. This presence of this mode denoted by the VEIC bit in the *Config3* register. Again, this mode is architecturally optional. On the M4K core, the VEIC bit is set externally by the static input, *SI\_EICPresent*, to allow system logic to indicate the presence of an external interrupt controller.

The reset state of the processor is to interrupt compatibility mode such that a processor supporting Release 2 of the Architecture, like the M4K core, is fully compatible with implementations of Release 1 of the Architecture.

Table 4-2 shows the current interrupt mode of the processor as a function of the coprocessor 0 register fields that can affect the mode.

**Table 4-2 Interrupt Modes** 

StatusBEV	Cause <sub>IV</sub>	IntCtl <sub>VS</sub>	Config3vINT	Config3VEIC	Interrupt Mode
1	х	Х	х	х	Compatibly
х	0	X	Х	Х	Compatibility

**Table 4-2 Interrupt Modes** 

StatusBEV	Cause <sub>IV</sub>	IntCtl <sub>VS</sub>	Config3vINT	Config3 <sub>VEIC</sub>	Interrupt Mode
Х	Х	=0	X	X	Compatibility
0	1	≠0	1	0	Vectored Interrupt
0	1	≠0	X	1	External Interrupt Controller
0	1	≠0	0	0	Can't happen - ${\rm IntCtl_{VS}}$ can not be non-zero if neither Vectored Interrupt nor External Interrupt Controller mode is implemented.
"x" denotes don't care			on't c	are	

### 4.3.1.1 Interrupt Compatibility Mode

This is the default interrupt mode for the processor and is entered when a Reset exception occurs. In this mode, interrupts are non-vectored and dispatched though exception vector offset 16#180 (if Cause<sub>IV</sub> = 0) or vector offset 16#200 (if Cause<sub>IV</sub> = 1). This mode is in effect if any of the following conditions are true:

- Cause<sub>IV</sub> = 0
- Status<sub>REV</sub> = 1
- $IntCtl_{VS} = 0$ , which would be the case if vectored interrupts are not implemented, or have been disabled.

A typical software handler for interrupt compatibility mode might look as follows:

```
* Assumptions:
   - Cause_{TV} = 1 (if it were zero, the interrupt exception would have to
                   be isolated from the general exception vector before getting
                   here)
   - GPRs k0 and k1 are available (no shadow register switches invoked in
                                     compatibility mode)
   - The software priority is IP7..IP0 (HW5..HW0, SW1..SW0)
 * Location: Offset 0x200 from exception base
IVexception:
   \mbox{mfc0} \mbox{k0, C0\_Cause} /* Read Cause register for IP bits */ mfc0 k1, C0_Status /* and Status register for IM bits */
   andi k0, k0, M_CauseIM /* Keep only IP bits from Cause */
          k0, k0, k1 /* and mask with IM bits */
   and
          kO, zero, Dismiss /* no bits set - spurious interrupt */
   beq
                             /* Find first bit set, IP7..IP0; k0 = 16..23 */
   clz
          k0, k0
          k0, k0, 0x17
                             /* 16..23 => 7..0 */
   xori
                              /* Shift to emulate software IntCtl_{VS} */
   sll
          k0, k0, VS
                              /* Get base of 8 interrupt vectors */
   la
          k1, VectorBase
   addu
          k0, k0, k1
                              /* Compute target from base and offset */
                               /* Jump to specific exception routine */
   jr
          k0
   nop
 * Each interrupt processing routine processes a specific interrupt, analogous
```

MIPS32 M4K™ Processor Core Software User's Manual, Revision 1.02

```
* to those reached in VI or EIC interrupt mode. Since each processing routine
 * is dedicated to a particular interrupt line, it has the context to know
 * which line was asserted. Each processing routine may need to look further
 * to determine the actual source of the interrupt if multiple interrupt requests
 * are ORed together on a single IP line. Once that task is performed, the
 * interrupt may be processed in one of two ways:
 * - Completely at interrupt level (e.g., a simply UART interrupt). The
    SimpleInterrupt routine below is an example of this type.
 * - By saving sufficient state and re-enabling other interrupts. In this
    case the software model determines which interrupts are disabled during
    the processing of this interrupt. Typically, this is either the single
    StatusIM bit that corresponds to the interrupt being processed, or some
    collection of other Status_{TM} bits so that "lower" priority interrupts are
     also disabled. The NestedInterrupt routine below is an example of this type.
 * /
SimpleInterrupt:
* Process the device interrupt here and clear the interupt request
* at the device. In order to do this, some registers may need to be
 * saved and restored. The coprocessor 0 state is such that an ERET
 * will simple return to the interrupted code.
   eret
                             /* Return to interrupted code */
NestedException:
* Nested exceptions typically require saving the EPC and Status registers,
* any GPRs that may be modified by the nested exception routine, disabling
* the appropriate IM bits in Status to prevent an interrupt loop, putting
 * the processor in kernel mode, and re-enabling interrupts. The sample code
 * below can not cover all nuances of this processing and is intended only
 * to demonstrate the concepts.
   /* Save GPRs here, and setup software context */
   mfc0 k0, C0_EPC /* Get restart address */
                            /* Save in memory */
   sw
         k0, EPCSave
                            /* Get Status value */
   mfc0 k0, C0_Status
                             /* Save in memory */
   SW
         k0, StatusSave
         kl, ~IMbitsToClear /* Get Im bits to clear for this interrupt */
   li
                              /*
                                 this must include at least the IM bit */
                              /*
                                 for the current interrupt, and may include */
                              /* others */
   and
         k0, k0, k1
                                /* Clear bits in copy of Status */
         kO, zero, S_StatusEXL, (W_StatusKSU+W_StatusERL+W_StatusEXL)
   ins
                                 /* Clear KSU, ERL, EXL bits in k0 */
   mtc0 k0, C0_Status
                                 /* Modify mask, switch to kernel mode, */
                                 /* re-enable interrupts */
    * Process interrupt here, including clearing device interrupt.
    ^{\star} In some environments this may be done with a thread running in
    * kernel or user mode. Such an environment is well beyond the scope of
    * this example.
    * /
 * To complete interrupt processing, the saved values must be restored
```

```
* and the original interrupted code restarted.
  di
                             /* Disable interrupts - may not be required */
  lw
                             /* Get saved Status (including EXL set) */
        k0, StatusSave
                                  and EPC */
  lw
        k1, EPCSave
        k0, C0_Status
                             /* Restore the original value */
 mtc0
 mtc0
        k1, C0_EPC
                             /*
                                 and EPC */
  /* Restore GPRs and software state */
  eret
                             /* Dismiss the interrupt */
```

### 4.3.1.2 Vectored Interrupt Mode

Vectored Interrupt mode builds on the interrupt compatibility mode by adding a priority encoder to prioritize pending interrupts and to generate a vector with which each interrupt can be directed to a dedicated handler routine. This mode also allows each interrupt to be mapped to a GPR shadow set for use by the interrupt handler. Vectored Interrupt mode is in effect if all of the following conditions are true:

- Config $3_{VInt} = 1$
- Config $3_{VEIC} = 0$
- IntCtl<sub>VS</sub>  $\neq$  0
- Cause<sub>IV</sub> = 1
- $Status_{BEV} = 0$

In VI interrupt mode, the six hardware interrupts are interpreted as individual hardware interrupt requests. The timer interrupt is combined in a system-dependent way (external to the core) with the hardware interrupts (the interrupt with which they are combined is indicated by the  $IntCtl_{IPTI}$  field) to provide the appropriate relative priority of the timer interrupt with that of the hardware interrupts. The processor interrupt logic ANDs each of the  $Cause_{IP}$  bits with the corresponding  $Status_{IM}$  bits. If any of these values is 1, and if interrupts are enabled ( $Status_{IE} = 1$ ,  $Status_{EXL} = 0$ , and  $Status_{ERL} = 0$ ), an interrupt is signaled and a priority encoder scans the values in the order shown in Table 4-3.

Relative Priority	Interrupt Type	Interrupt Source	Interrupt Request Calculated From	Vector Number Generated by Priority Encoder
Highest Priority		HW5	IP7 and IM7	7
		HW4	IP6 and IM6	6
	II	HW3	IP5 and IM5	5
	Hardware	HW2	IP4 and IM4	4
		HW1	IP3 and IM3	3
		HW0	IP2 and IM2	2

SW1

SW0

Software

Lowest Priority

Table 4-3 Relative Interrupt Priority for Vectored Interrupt Mode

The priority order places a relative priority on each hardware interrupt and places the software interrupts at a priority lower than all hardware interrupts. When the priority encoder finds the highest priority pending interrupt, it outputs an

IP1 and IM1

IP0 and IM0

0

encoded vector number that is used in the calculation of the handler for that interrupt, as described below. This is shown pictorially in Figure 4-1.

# Latch Mask Encode Generate




Figure 4-1 Interrupt Generation for Vectored Interrupt Mode

A typical software handler for vectored interrupt mode bypasses the entire sequence of code following the IVexception label shown for the compatibility mode handler above. Instead, the hardware performs the prioritization, dispatching directly to the interrupt processing routine. Unlike the compatibility mode examples, a vectored interrupt handler may take advantage of a dedicated GPR shadow set to avoid saving any registers. As such, the SimpleInterrupt code shown above need not save the GPRs.

A nested interrupt is similar to that shown for compatibility mode, but may also take advantage of running the nested exception routine in the GPR shadow set dedicated to the interrupt or in another shadow set. Such a routine might look as follows:

```
NestedException:
 * Nested exceptions typically require saving the EPC, Status and SRSCtl registers,
 * setting up the appropriate GPR shadow set for the routine, disabling
 * the appropriate IM bits in Status to prevent an interrupt loop, putting
 * the processor in kernel mode, and re-enabling interrupts. The sample code
 * below can not cover all nuances of this processing and is intended only
  to demonstrate the concepts.
 * /
   /* Use the current GPR shadow set, and setup software context */
          k0, C0_EPC
                              /* Get restart address */
   mfc0
   sw
          k0, EPCSave
                               /* Save in memory */
   mfc0
          k0, C0_Status
                              /* Get Status value */
          k0, StatusSave
                              /* Save in memory */
   SW
   mfc0
          k0, C0_SRSCtl
                              /* Save SRSCtl if changing shadow sets */
   SW
          k0, SRSCtlSave
          k1, ~IMbitsToClear
   li
                              /* Get Im bits to clear for this interrupt */
                                   this must include at least the IM bit */
```

```
/*
                                   for the current interrupt, and may include */
                                   others */
                                 /* Clear bits in copy of Status */
  and
         k0, k0, k1
  /* If switching shadow sets, write new value to {\tt SRSCtl}_{\tt PSS} here */
  ins
         k0, zero, S_StatusEXL, (W_StatusKSU+W_StatusERL+W_StatusEXL)
                                 /* Clear KSU, ERL, EXL bits in k0 */
                                 /* Modify mask, switch to kernel mode, */
  mtc0
         k0, C0_Status
                                 /*
                                      re-enable interrupts */
   * If switching shadow sets, clear only KSU above, write target
   * address to EPC, and do execute an eret to clear EXL, switch
   * shadow sets, and jump to routine
  /* Process interrupt here, including clearing device interrupt */
\mbox{\scriptsize \star} To complete interrupt processing, the saved values must be restored
* and the original interrupted code restarted.
  di
                              /* Disable interrupts - may not be required */
  lw
         k0, StatusSave
                            /* Get saved Status (including EXL set) */
                            /* and EPC */
         k1, EPCSave
  lw
  mtc0 k0, C0_Status
                            /* Restore the original value */
/* Get saved SRSCtl */
  lw
         k0, SRSCtlSave
                             /* and EPC */
  mtc0
         k1, C0_EPC
  mtc0
        k0, C0_SRSCtl
                             /* Restore shadow sets */
                              /* Clear hazard */
  ehb
                              /* Dismiss the interrupt */
  eret
```

### 4.3.1.3 External Interrupt Controller Mode

External Internal Interrupt Controller Mode redefines the way that the processor interrupt logic is configured to provide support for an external interrupt controller. The interrupt controller is responsible for prioritizing all interrupts, including hardware, software, timer, and performance counter interrupts, and directly supplying to the processor the vector number of the highest priority interrupt. EIC interrupt mode is in effect if all of the following conditions are true:

- Config $3_{VEIC} = 1$
- IntCtl<sub>VS</sub>  $\neq$  0
- Cause<sub>IV</sub> = 1
- $Status_{REV} = 0$

In EIC interrupt mode, the processor sends the state of the software interrupt requests ( $Cause_{IP1..IP0}$ ) and the timer interrupt request ( $Cause_{T1}$ ) to the external interrupt controller, where it prioritizes these interrupts in a system-dependent way with other hardware interrupts. The interrupt controller can be a hard-wired logic block, or it can be configurable based on control and status registers. This allows the interrupt controller to be more specific or more general as a function of the system environment and needs.

The external interrupt controller prioritizes its interrupt requests and produces the vector number of the highest priority interrupt to be serviced. The vector number, called the Requested Interrupt Priority Level (RIPL), is a 6-bit encoded value in the range 0..63, inclusive. A value of 0 indicates that no interrupt requests are pending. The values 1..63 represent the lowest (1) to highest (63) RIPL for the interrupt to be serviced. The interrupt controller passes this value on the 6 hardware interrupt line, which are treated as an encoded value in EIC interrupt mode.

Status<sub>IPL</sub> (which overlays  $Status_{IM7..IM2}$ ) is interpreted as the Interrupt Priority Level (IPL) at which the processor is currently operating (with a value of zero indicating that no interrupt is currently being serviced). When the interrupt controller requests service for an interrupt, the processor compares RIPL with  $Status_{IPL}$  to determine if the requested interrupt has higher priority than the current IPL. If RIPL is strictly greater than  $Status_{IPL}$ , and interrupts are enabled ( $Status_{IE} = 1$ ,  $Status_{EXL} = 0$ , and  $Status_{ERL} = 0$ ) an interrupt request is signaled to the pipeline. When the processor starts the interrupt exception, it loads RIPL into  $Status_{IPL}$  (which overlays  $Status_{IP1}$ ) and signals the external interrupt controller to notify it that the request is being serviced. The interrupt exception uses the value of  $Status_{IP1}$  as the vector number. Because  $Status_{IP1}$  is only loaded by the processor when an interrupt exception is signaled, it is available to software during interrupt processing.

In EIC interrupt mode, the external interrupt controller is also responsible for supplying the GPR shadow set number to use when servicing the interrupt. As such, the *SRSMap* register is not used in this mode, and the mapping of the vectored interrupt to a GPR shadow set is done by programming (or designing) the interrupt controller to provide the correct GPR shadow set number when an interrupt is requested. When the processor loads an interrupt request into Cause<sub>RIPL</sub>, it also loads the GPR shadow set number into SRSCtl<sub>EICSS</sub>, which is copied to SRSCtl<sub>CSS</sub> when the interrupt is serviced.

The operation of EIC interrupt mode is shown pictorially in Figure 4-2.




Figure 4-2 Interrupt Generation for External Interrupt Controller Interrupt Mode

A typical software handler for EIC interrupt mode bypasses the entire sequence of code following the IVexception label shown for the compatibility mode handler above. Instead, the hardware performs the prioritization, dispatching directly to the interrupt processing routine. Unlike the compatibility mode examples, an EIC interrupt handler may take advantage of a dedicated GPR shadow set to avoid saving any registers. As such, the SimpleInterrupt code shown above need not save the GPRs.

A nested interrupt is similar to that shown for compatibility mode, but may also take advantage of running the nested exception routine in the GPR shadow set dedicated to the interrupt or in another shadow set. It also need only copy Cause<sub>RIPL</sub> to Status<sub>IPL</sub> to prevent lower priority interrupts from interrupting the handler. Such a routine might look as follows:

```
NestedException:
/*
```

```
* Nested exceptions typically require saving the EPC, Status, and SRSCtl registers,
* setting up the appropriate GPR shadow set for the routine, disabling
* the appropriate IM bits in Status to prevent an interrupt loop, putting
* the processor in kernel mode, and re-enabling interrupts. The sample code
* below can not cover all nuances of this processing and is intended only
* to demonstrate the concepts.
  /* Use the current GPR shadow set, and setup software context */
 mfc0 k1, C0_Cause /* Read Cause to get RIPL value */
                          /* Get restart address */
  mfc0 k0, C0 EPC
        k1, k1, S_CauseRIPL /* Right justify RIPL field */
  srl
        k0, EPCSave /* Save in memory */
        mfc0 k0, C0_Status
  SW
        k0, k1, S_StatusIPL, 6 /* Set IPL to RIPL in copy of Status */
  ins
  mfc0 k1, C0_SRSCtl /* Save SRSCtl if changing shadow sets */
       k1, SRSCtlSave
  /* If switching shadow sets, write new value to SRSCtl<sub>PSS</sub> here */
  ins k0, zero, S_StatusEXL, (W_StatusKSU+W_StatusERL+W_StatusEXL)
                              /* Clear KSU, ERL, EXL bits in k0 */
  mtc0 k0, C0_Status
                              /* Modify IPL, switch to kernel mode, */
                              /* re-enable interrupts */
  * If switching shadow sets, clear only KSU above, write target
   * address to EPC, and do execute an eret to clear EXL, switch
   * shadow sets, and jump to routine
  /* Process interrupt here, including clearing device interrupt */
^{\star} The interrupt completion code is identical to that shown for VI mode above.
* /
```

### 4.3.2 Generation of Exception Vector Offsets for Vectored Interrupts

For vectored interrupts (in either VI or EIC interrupt mode), a vector number is produced by the interrupt control logic. This number is combined with  $\operatorname{IntCtl}_{VS}$  to create the interrupt offset, which is added to 16#200 to create the exception vector offset. For VI interrupt mode, the vector number is in the range 0..7, inclusive. For EIC interrupt mode, the vector number is in the range 1..63, inclusive (0 being the encoding for "no interrupt"). The  $\operatorname{IntCtl}_{VS}$  field specifies the spacing between vector locations. If this value is zero (the default reset state), the vector spacing is zero and the processor reverts to Interrupt Compatibility Mode. A non-zero value enables vectored interrupts, and Table 4-4 shows the exception vector offset for a representative subset of the vector numbers and values of the  $\operatorname{IntCtl}_{VS}$  field.

Value of IntCtlVS Field **Vector Number** 2#00001 2#00010 2#00100 2#01000 2#10000 16#0200 16#0200 16#0200 16#0200 16#0200 1 16#0220 16#0240 16#0280 16#0300 16#0400 2 16#0240 16#0280 16#0300 16#0400 16#0600 3 16#0260 16#02C0 16#0380 16#0500 16#0800 16#0300 4 16#0280 16#0400 16#0600 16#0A00 5 16#02A0 16#0340 16#0480 16#0700 16#0C00 6 16#02C0 16#0380 16#0500 16#0800 16#0E00 7 16#02E0 16#03C0 16#0580 16#0900 16#1000 16#09A0 16#1140 16#7C00 61 16#2080 16#3F00 16#09C0 16#1180 62 16#2100 16#4000 16#7E00 63 16#09E0 16#11C0 16#2180 16#4100 16#8000

**Table 4-4 Exception Vector Offsets for Vectored Interrupts** 

The general equation for the exception vector offset for a vectored interrupt is:

 $\texttt{vectorOffset} \leftarrow \texttt{16\#200} + (\texttt{vectorNumber} \times (\texttt{IntCtl}_{\texttt{VS}} \parallel \texttt{2\#00000}))$ 

### 4.4 GPR Shadow Registers

Release 2 of the Architecture optionally removes the need to save and restore GPRs on entry to high priority interrupts or exceptions, and to provide specified processor modes with the same capability. This is done by introducing multiple copies of the GPRs, called *shadow sets*, and allowing privileged software to associate a shadow set with entry to kernel mode via an interrupt vector or exception. The normal GPRs are logically considered shadow set zero.

The number of GPR shadow sets is a build-time option on the M4K core. Although Release 2 of the Architecture defines a maximum of 16 shadow sets, the core allows one (the normal GPRs), two, or four shadow sets. The highest number actually implemented is indicated by the SRSCtl<sub>HSS</sub> field. If this field is zero, only the normal GPRs are implemented.

Shadow sets are new copies of the GPRs that can be substituted for the normal GPRs on entry to kernel mode via an interrupt or exception. Once a shadow set is bound to a kernel mode entry condition, reference to GPRs work exactly as one would expect, but they are redirected to registers that are dedicated to that condition. Privileged software may need to reference all GPRs in the register file, even specific shadow registers that are not visible in the current mode. The RDPGPR and WRPGPR instructions are used for this purpose. The CSS field of the *SRSCtl* register provides the number of the current shadow register set, and the PSS field of the *SRSCtl* register provides the number of the previous shadow register set (that which was current before the last exception or interrupt occurred).

If the processor is operating in VI interrupt mode, binding of a vectored interrupt to a shadow set is done by writing to the *SRSMap* register. If the processor is operating in EIC interrupt mode, the binding of the interrupt to a specific shadow set is provided by the external interrupt controller, and is configured in an implementation-dependent way. Binding of an exception or non-vectored interrupt to a shadow set is done by writing to the ESS field of the *SRSCtl* register. When

an exception or interrupt occurs, the value of SRSCtl<sub>CSS</sub> is copied to SRSCtl<sub>PSS</sub>, and SRSCtl<sub>CSS</sub> is set to the value taken from the appropriate source. On an ERET, the value of SRSCtl<sub>PSS</sub> is copied back into SRSCtl<sub>CSS</sub> to restore the shadow set of the mode to which control returns. More precisely, the rules for updating the fields in the *SRSCtl* register on an interrupt or exception are as follows:

- 1. No field in the *SRSCtl* register is updated if any of the following conditions is true. In this case, steps 2 and 3 are skipped.
  - The exception is one that sets Status<sub>ERL</sub>: Reset, Soft Reset, or NMI.
  - The exception causes entry into EJTAG Debug Mode
  - Status<sub>BEV</sub> = 1
  - Status<sub>EXL</sub> = 1
- 2. SRSCtl<sub>CSS</sub> is copied to SRSCtl<sub>PSS</sub>
- 3. SRSCtl<sub>CSS</sub> is updated from one of the following sources:
  - The appropriate field of the *SRSMap* register, based on IPL, if the exception is an interrupt, Cause<sub>IV</sub> = 1, Config3<sub>VEIC</sub> = 0, and Config3<sub>VInt</sub> = 1. These are the conditions for a vectored interrupt.
  - The EICSS field of the *SRSCtl* register if the exception is an interrupt, Cause<sub>IV</sub> = 1, and Config3<sub>VEIC</sub> = 1. These are the conditions for a vectored EIC interrupt.
  - The ESS field of the SRSCtl register in any other case. This is the condition for a non-interrupt exception, or a non-vectored interrupt.

Similarly, the rules for updating the fields in the SRSCtl register at the end of an exception or interrupt are as follows:

- 1. No field in the SRSCtl register is updated if any of the following conditions is true. In this case, step 2 is skipped.
  - · A DERET is executed
  - An ERET is executed with Status<sub>ERL</sub> = 1
- 2. SRSCtl<sub>PSS</sub> is copied to SRSCtl<sub>CSS</sub>

These rules have the effect of preserving the SRSCtl register in any case of a nested exception or one which occurs before the processor has been fully initialize (Status<sub>BEV</sub> = 1).

Privileged software may switch the current shadow set by writing a new value into SRSCtl<sub>PSS</sub>, loading EPC with a target address, and doing an ERET.

## 4.5 Exception Vector Locations

The Reset, Soft Reset, and NMI exceptions are always vectored to location 16#BFC0.0000. EJTAG Debug exceptions are vectored to location 16#BFC0.0480, or to location 16#FF20.0200 if the ProbTrap bit is zero or one, respectively, in the EJTAG\_Control\_register. Addresses for all other exceptions are a combination of a vector offset and a vector base address. In Release 1 of the architecture, the vector base address was fixed. In Release 2 of the architecture, software is allowed to specify the vector base address via the *EBase* register for exceptions that occur when Status<sub>BEV</sub> equals 0. Table 4-5 gives the vector base address as a function of the exception and whether the BEV bit is set in the *Status* register. Table 4-6 gives the offsets from the vector base address as a function of the exception. Note that the IV bit in the *Cause* register causes Interrupts to use a dedicated exception vector offset, rather than the general exception vector. For implementations of Release 2 of the Architecture, Table 4-4 gives the offset from the base address in the case where Status<sub>BEV</sub> = 0 and Cause<sub>IV</sub> = 1. For implementations of Release 1 of the architecture in which Cause<sub>IV</sub> = 1, the vector offset is as if IntCtl<sub>VS</sub> were 0. Table 4-7 combines these two tables into one that contains all possible vector addresses as a function of the state that can affect the vector selection. To avoid complexity in the table, the vector address value assumes that the *EBase* register, as implemented in Release 2 devices, is not changed from its reset state and that IntCtl<sub>VS</sub> is 0.

**Table 4-5 Exception Vector Base Addresses** 

	Status <sub>BEV</sub>			
Exception	0	1		
Reset, Soft Reset, NMI	16#BFC0.0000			
EJTAG Debug (with ProbEn = 0 in the EJTAG_Control_register)	16#BFC0.0480			
EJTAG Debug (with ProbEn = 1 in the EJTAG_Control_register)	16#FF20.0200			
	For Release 1 of the architecture:			
	16#8000.0000			
Other	For Release 2 of the architecture:	16#BFC0.0200		
	EBase <sub>3112</sub>    16#000			
	Note that EBase <sub>3130</sub> have the fixed value 2#10			

**Table 4-6 Exception Vector Offsets** 

Exception	Vector Offset
General Exception	16#180
Interrupt, Cause <sub>IV</sub> = 1	16#200 (In Release 2 implementations, this is the base of the vectored interrupt table when $Status_{BEV} = 0$ )
Reset, Soft Reset, NMI	None (Uses Reset Base Address)

**Table 4-7 Exception Vectors** 

					Vector
Exception	Status <sub>BEV</sub>	Status <sub>EXL</sub>	Cause <sub>IV</sub>	EJTAG ProbEn	For Release 2 Implementations, assumes that EBase retains its reset state and that $IntCtl_{VS} = 0$
Reset, Soft Reset, NMI	X	X	Х	х	16#BFC0.0000
EJTAG Debug	X	X	X	0	16#BFC0.0480
EJTAG Debug	X	X	x	1	16#FF20.0200
Interrupt	0	0	0	x	16#8000.0180
Interrupt	0	0	1	X	16#8000.0200
Interrupt	1	0	0	X	16#BFC0.0380
Interrupt	1	0	1	X	16#BFC0.0400
All others	0	X	X	X	16#8000.0180

**Table 4-7 Exception Vectors** 

					Vector
Exception	Status <sub>BEV</sub>	Status <sub>EXL</sub>	Cause <sub>IV</sub>	EJTAG ProbEn	For Release 2 Implementations, assumes that EBase retains its reset state and that $IntCtl_{VS} = 0$
All others	1	X	Х	Х	16#BFC0.0380
'x' denotes don't care					

# 4.6 General Exception Processing

With the exception of Reset, Soft Reset, NMI, cache error, and EJTAG Debug exceptions, which have their own special processing as described below, exceptions have the same basic processing flow:

• If the EXL bit in the *Status* register is zero, the *EPC* register is loaded with the PC at which execution will be restarted and the BD bit is set appropriately in the *Cause* register (see Table 5-13 on page 91). The value loaded into the *EPC* register is dependent on whether the processor implements the MIPS16 ASE, and whether the instruction is in the delay slot of a branch or jump which has delay slots. Table 4-8 shows the value stored in each of the CP0 PC registers, including *EPC*. For implementations of Release 2 of the Architecture if Status<sub>BEV</sub> = 0, the CSS field in the *SRSCtl* register is copied to the PSS field, and the CSS value is loaded from the appropriate source.

If the EXL bit in the *Status* register is set, the *EPC* register is not loaded and the BD bit is not changed in the *Cause* register. For implementations of Release 2 of the Architecture, the *SRSCtl* register is not changed.

MIPS16 In Branch/Jump Implemented? **Delay Slot?** Value stored in EPC/ErrorEPC/DEPC No No Address of the instruction No Yes Address of the branch or jump instruction (PC-4) Upper 31 bits of the address of the instruction, combined Yes No with the ISA Mode bit Upper 31 bits of the branch or jump instruction (PC-2 in the MIPS16 ISA Mode and PC-4 in the 32-bit ISA Yes Yes Mode), combined with the ISA Mode bit

Table 4-8 Value Stored in EPC, ErrorEPC, or DEPC on an Exception

- The CE, and ExcCode fields of the *Cause* registers are loaded with the values appropriate to the exception. The CE field is loaded, but not defined, for any exception type other than a coprocessor unusable exception.
- The EXL bit is set in the *Status* register.
- The processor is started at the exception vector.

The value loaded into EPC represents the restart address for the exception and need not be modified by exception handler software in the normal case. Software need not look at the BD bit in the Cause register unless it wishes to identify the address of the instruction that actually caused the exception.

Note that individual exception types may load additional information into other registers. This is noted in the description of each exception type below.

#### **Operation:**

```
/* If Status_{	exttt{EXL}} is 1, all exceptions go through the general exception vector */
/* and neither EPC nor Cause<sub>BD</sub> nor SRSCtl are modified */
if Status_{EXL} = 1 then
    vectorOffset ← 16#180
else
    if InstructionInBranchDelaySlot then
        EPC ← restartPC/* PC of branch/jump */
        \texttt{Cause}_{\texttt{BD}} \, \leftarrow \, \mathbf{1}
    else
                                                /* PC of instruction */
         EPC \leftarrow restartPC
        Cause_{BD} \leftarrow 0
    endif
    /st Compute vector offsets as a function of the type of exception st/
    \texttt{NewShadowSet} \leftarrow \texttt{SRSCtl}_{\texttt{ESS}}
                                                 /* Assume exception, Release 2 only */
    if ExceptionType = TLBRefill then
        vectorOffset \leftarrow 16#000
    elseif (ExceptionType = Interrupt) then
         if (Cause_{IV} = 0) then
             vectorOffset ← 16#180
         else
             if (Status_{BEV} = 1) or (IntCtl_{VS} = 0) then
                  vectorOffset \leftarrow 16#200
             else
                  if Config3_{VEIC} = 1 then
                      \texttt{VecNum} \, \leftarrow \, \texttt{Cause}_{\texttt{RIPL}}
                      NewShadowSet \leftarrow SRSCtl_{ETCSS}
                  else
                      VecNum ← VIntPriorityEncoder()
                      \texttt{NewShadowSet} \leftarrow \texttt{SRSMap}_{\texttt{IPL}} \mathsf{X}_{4+3 \ldots \texttt{IPL}} \mathsf{X}_{4}
                  vectorOffset \leftarrow 16#200 + (VecNum \times (IntCtl<sub>VS</sub> || 2#00000))
             endif /* if (Status<sub>BEV</sub> = 1) or (IntCtl<sub>VS</sub> = 0) then */
         endif /* if (Cause<sub>TV</sub> = 0) then */
    endif /* elseif (ExceptionType = Interrupt) then */
    /* Update the shadow set information for an implementation of */
    /* Release 2 of the architecture */
    if ((ArchitectureRevision \geq 2) and (SRSCtl_{\rm HSS} > 0) and (Status_{\rm BEV} = 0) and
         (Status_{ERL} = 0)) then
         SRSCtl_{PSS} \leftarrow SRSCtl_{CSS}
         \texttt{SRSCtl}_{\texttt{CSS}} \leftarrow \texttt{NewShadowSet}
    endif
endif /* if Status_{EXL} = 1 then */
Cause_{CE} \leftarrow FaultingCoprocessorNumber
Cause_{ExcCode} \leftarrow ExceptionType
Status_{EXL} \leftarrow 1
/* Calculate the vector base address */
if Status_{BEV} = 1 then
    vectorBase ← 16#BFC0.0200
else
    if ArchitectureRevision ≥ 2 then
         /\!\!\!\!\!^{\star} The fixed value of \mathtt{EBase}_{31..30} forces the base to be in kseg0 or kseg1 ^{\star}/\!\!\!\!
         vectorBase \leftarrow EBase<sub>31..12</sub> || 16#000
    else
        vectorBase ← 16#8000.0000
```

```
endif endif  \begin{tabular}{ll} \begin{tabu
```

### 4.7 Debug Exception Processing

All debug exceptions have the same basic processing flow:

- The *DEPC* register is loaded with the program counter (PC) value at which execution will be restarted and the DBD bit is set appropriately in the *Debug* register. The value loaded into the *DEPC* register is the current PC if the instruction is not in the delay slot of a branch, or the PC-4 of the branch if the instruction is in the delay slot of a branch.
- The DSS, DBp, DDBL, DDBS, DIB and DINT bits (D\* bits at [5:0]) in the *Debug* register are updated appropriately depending on the debug exception type.
- Halt and Doze bits in the *Debug* register are updated appropriately.
- DM bit in the *Debug* register is set to 1.
- The processor is started at the debug exception vector.

The value loaded into *DEPC* represents the restart address for the debug exception and need not be modified by the debug exception handler software in the usual case. Debug software need not look at the DBD bit in the *Debug* register unless it wishes to identify the address of the instruction that actually caused the debug exception.

A unique debug exception is indicated through the DSS, DBp, DDBL, DDBS, DIB and DINT bits (D\* bits at [5:0]) in the *Debug* register.

No other CP0 registers or fields are changed due to the debug exception, thus no additional state is saved.

### **Operation:**

```
if InstructionInBranchDelaySlot then
      \texttt{DEPC} \, \leftarrow \, \texttt{PC-4}
      Debug_{DRD} \leftarrow 1
else
      \texttt{DEPC} \; \leftarrow \; \texttt{PC}
      Debug_{DBD} \leftarrow 0
endif
\texttt{Debug}_{\texttt{D* bits at at [5:0]}} \leftarrow \texttt{DebugExceptionType}
\texttt{Debug}_{\texttt{Halt}} \, \leftarrow \, \texttt{HaltStatusAtDebugException}
\texttt{Debug}_{\texttt{Doze}} \leftarrow \texttt{DozeStatusAtDebugException}
\texttt{Debug}_{\texttt{DM}} \, \leftarrow \, 1
if EJTAGControlRegister_{ProbTrap} = 1 then
      PC \leftarrow 0xFF20_0200
else
      PC ← 0xBFC0_0480
endif
```

The same debug exception vector location is used for all debug exceptions. The location is determined by the ProbTrap bit in the EJTAG Control register (ECR), as shown in Table 4-9.

**Table 4-9 Debug Exception Vector Addresses** 

ProbTrap bit in ECR Register	Debug Exception Vector Address
0	0xBFC0_0480
1	0xFF20_0200 in dmseg

# 4.8 Exceptions

The following subsections describe each of the exceptions listed in the same sequence as shown in Table 4-1.

# 4.8.1 Reset Exception

A reset exception occurs when the *SI\_ColdReset* signal is asserted to the processor. This exception is not maskable. When a Reset exception occurs, the processor performs a full reset initialization, including aborting state machines, establishing critical state, and generally placing the processor in a state in which it can execute instructions from uncached, unmapped address space. On a Reset exception, the state of the processor is not defined, with the following exceptions:

- The *Random* register is initialized to the number of TLB entries 1.
- The *Wired* register is initialized to zero.
- The Config register is initialized with its boot state.
- The RP, BEV, TS, SR, NMI, and ERL fields of the Status register are initialized to a specified state.
- The I, R, and W fields of the WatchLo register are initialized to 0.
- The *ErrorEPC* register is loaded with PC-4 if the state of the processor indicates that it was executing an instruction in the delay slot of a branch. Otherwise, the *ErrorEPC* register is loaded with PC. Note that this value may or may not be predictable.
- PC is loaded with 0xBFC0\_0000.

### Cause Register ExcCode Value:

None

### Additional State Saved:

None

### **Entry Vector Used:**

Reset (0xBFC0\_0000)

#### **Operation:**

```
\label{eq:random} \begin{array}{l} \text{Random} \leftarrow \text{TLBEntries} - 1 \\ \text{Wired} \leftarrow 0 \\ \text{Config} \leftarrow \text{ConfigurationState} \\ \text{Status}_{\text{RP}} \leftarrow 0 \\ \text{Status}_{\text{BEV}} \leftarrow 1 \\ \text{Status}_{\text{TS}} \leftarrow 0 \\ \text{Status}_{\text{SR}} \leftarrow 0 \\ \text{Status}_{\text{NMI}} \leftarrow 0 \\ \text{Status}_{\text{ERL}} \leftarrow 1 \\ \end{array}
```

```
\label{eq:watchLo} \begin{split} \text{WatchLo}_{\text{I}} &\leftarrow 0 \\ \text{WatchLo}_{\text{R}} &\leftarrow 0 \\ \text{WatchLo}_{\text{W}} &\leftarrow 0 \\ \text{if InstructionInBranchDelaySlot then} \\ &\quad \text{ErrorEPC} &\leftarrow \text{PC} - 4 \\ \text{else} \\ &\quad \text{ErrorEPC} &\leftarrow \text{PC} \\ \text{endif} \\ \text{PC} &\leftarrow 0 \\ \text{xBFCO} & 0000 \\ \end{split}
```

### 4.8.2 Soft Reset Exception

A soft reset exception occurs when the *SI\_Reset* signal is asserted to the processor. This exception is not maskable. When a soft reset exception occurs, the processor performs a subset of the full reset initialization. Although a soft reset exception does not unnecessarily change the state of the processor, it may be forced to do so in order to place the processor in a state in which it can execute instructions from uncached, unmapped address space. Since bus, cache, or other operations may be interrupted, portions of the cache, memory, or other processor state may be inconsistent. In addition to any hardware initialization required, the following state is established on a soft reset exception:

- The BEV, TS, SR, NMI, and ERL fields of the Status register are initialized to a specified state.
- The *ErrorEPC* register is loaded with PC-4 if the state of the processor indicates that it was executing an instruction in the delay slot of a branch. Otherwise, the *ErrorEPC* register is loaded with PC. Note that this value may or may not be predictable.
- PC is loaded with 0xBFC0\_0000.

### Cause Register ExcCode Value:

None

### **Additional State Saved:**

None

### **Entry Vector Used:**

Reset (0xBFC0\_0000)

#### **Operation:**

```
\begin{array}{l} {\rm Status_{BEV}} \leftarrow 1 \\ {\rm Status_{TS}} \leftarrow 0 \\ {\rm Status_{SR}} \leftarrow 1 \\ {\rm Status_{DMI}} \leftarrow 0 \\ {\rm Status_{ERL}} \leftarrow 1 \\ {\rm if\ InstructionInBranchDelaySlot\ then} \\ {\rm ErrorEPC} \leftarrow {\rm PC} - 4 \\ {\rm else} \\ {\rm ErrorEPC} \leftarrow {\rm PC} \\ {\rm endif} \\ {\rm PC} \leftarrow 0{\rm xBFCO\ 0000} \end{array}
```

#### 4.8.3 Debug Single Step Exception

A debug single step exception occurs after the CPU has executed one/two instructions in non-debug mode, when returning to non-debug mode after debug mode. One instruction is allowed to execute when returning to a non jump/branch instruction, otherwise two instructions are allowed to execute since the jump/branch and the instruction in the delay slot are executed as one step. Debug single step exceptions are enabled by the SSt bit in the Debug register, and are always disabled for the first one/two instructions after a DERET.

The DEPC register points to the instruction on which the debug single step exception occurred, which is also the next instruction to single step or execute when returning from debug mode. So the DEPC will not point to the instruction which has just been single stepped, but rather the following instruction. The DBD bit in the Debug register is never set for a debug single step exception, since the jump/branch and the instruction in the delay slot is executed in one step.

Exceptions occurring on the instruction(s) executed with debug single step exception enabled are taken even though debug single step was enabled. For a normal exception (other than reset), a debug single step exception is then taken on the first instruction in the normal exception handler. Debug exceptions are unaffected by single step mode, e.g. returning to a SDBBP instruction with debug single step exceptions enabled causes a debug software breakpoint exception, and the DEPC will point to the SDBBP instruction. However, returning to an instruction (not jump/branch) just before the SDBBP instruction, causes a debug single step exception with the DEPC pointing to the SDBBP instruction.

To ensure proper functionality of single step, the debug single step exception has priority over all other exceptions, except reset and soft reset.

**Debug Register Debug Status Bit Set** 

**DSS** 

Additional State Saved

None

**Entry Vector Used** 

Debug exception vector

## 4.8.4 Debug Interrupt Exception

A debug interrupt exception is either caused by the EjtagBrk bit in the *EJTAG Control register* (controlled through the TAP), or caused by the debug interrupt request signal to the CPU.

The debug interrupt exception is an asynchronous debug exception which is taken as soon as possible, but with no specific relation to the executed instructions. The *DEPC* register is set to the instruction where execution should continue after the debug handler is through. The DBD bit is set based on whether the interrupted instruction was executing in the delay slot of a branch.

Debug Register Debug Status Bit Set

DINT

Additional State Saved

None

**Entry Vector Used** 

Debug exception vector

## 4.8.5 Non-Maskable Interrupt (NMI) Exception

A non maskable interrupt exception occurs when the *SI\_NMI* signal is asserted to the processor. *SI\_NMI* is an edge sensitive signal - only one NMI exception will be taken each time it is asserted. An NMI exception occurs only at instruction boundaries, so it does not cause any reset or other hardware initialization. The state of the cache, memory, and other processor states are consistent and all registers are preserved, with the following exceptions:

• The BEV, TS, SR, NMI, and ERL fields of the *Status* register are initialized to a specified state.

- The *ErrorEPC* register is loaded with PC-4 if the state of the processor indicates that it was executing an instruction in the delay slot of a branch. Otherwise, the *ErrorEPC* register is loaded with PC.
- PC is loaded with 0xBFC0 0000.

#### Cause Register ExcCode Value:

None

#### Additional State Saved:

None

#### **Entry Vector Used:**

Reset (0xBFC0 0000)

#### **Operation:**

```
\begin{array}{l} {\rm Status_{BEV}} \leftarrow 1 \\ {\rm Status_{TS}} \leftarrow 0 \\ {\rm Status_{SR}} \leftarrow 0 \\ {\rm Status_{NMI}} \leftarrow 1 \\ {\rm Status_{ERL}} \leftarrow 1 \\ {\rm if\ InstructionInBranchDelaySlot\ then} \\ {\rm ErrorEPC} \leftarrow {\rm PC} - 4 \\ {\rm else} \\ {\rm ErrorEPC} \leftarrow {\rm PC} \\ {\rm endif} \\ {\rm PC} \leftarrow 0{\rm xBFC0\_0000} \end{array}
```

### 4.8.6 Interrupt Exception

The interrupt exception occurs when one or more of the six hardware, two software, or timer interrupt requests is enabled by the *Status* register and the interrupt input is asserted. See Section 4.3, "Interrupts" on page 46 for more details about the processing of interrupts.

#### Register ExcCode Value:

Int

#### **Additional State Saved:**

**Table 4-10 Register States an Interrupt Exception** 

Register State	Value
Cause <sub>IP</sub>	indicates the interrupts that are pending.

## **Entry Vector Used:**

See Section 4.3.2, "Generation of Exception Vector Offsets for Vectored Interrupts" on page 53 for the entry vector used, depending on the interrupt mode the processor is operating in.

## 4.8.7 Debug Instruction Break Exception

A debug instruction break exception occurs when an instruction hardware breakpoint matches an executed instruction. The *DEPC* register and DBD bit in the *Debug* register indicate the instruction that caused the instruction hardware breakpoint to match. This exception can only occur if instruction hardware breakpoints are implemented.

#### **Debug Register Debug Status Bit Set:**

DIB

#### **Additional State Saved:**

None

#### **Entry Vector Used:**

Debug exception vector

## 4.8.8 Address Error Exception — Instruction Fetch/Data Access

An address error exception occurs on an instruction or data access when an attempt is made to execute one of the following:

- Fetch an instruction, load a word, or store a word that is not aligned on a word boundary
- Load or store a halfword that is not aligned on a halfword boundary
- Reference the kernel address space from user mode

Note that in the case of an instruction fetch that is not aligned on a word boundary, PC is updated before the condition is detected. Therefore, both EPC and BadVAddr point to the unaligned instruction address. In the case of a data access the exception is taken if either an unaligned address or an address that was inaccessible in the current processor mode was referenced by a load or store instruction.

#### Cause Register ExcCode Value:

ADEL: Reference was a load or an instruction fetch

ADES: Reference was a store

#### Additional State Saved:

Table 4-11 CP0 Register States on an Address Exception Error

Register State	Value	
BadVAddr	failing address	

## **Entry Vector Used:**

General exception vector (offset 0x180)

## 4.8.9 Bus Error Exception — Instruction Fetch or Data Access

A bus error exception occurs when an instruction or data access makes a bus request and that request terminates in an error. The bus error exception can occur on either an instruction fetch or a data access. Bus error exceptions that occur on an instruction fetch have a higher priority than bus error exceptions that occur on a data access.

Bus errors taken on any external access on the M4K core are always precise.

#### Cause Register ExcCode Value:

IBE: Error on an instruction reference

DBE: Error on a data reference

#### **Additional State Saved:**

None

### **Entry Vector Used:**

General exception vector (offset 0x180)

## 4.8.10 Debug Software Breakpoint Exception

A debug software breakpoint exception occurs when an SDBBP instruction is executed. The *DEPC* register and DBD bit in the *Debug* register will indicate the SDBBP instruction that caused the debug exception.

### **Debug Register Debug Status Bit Set:**

DBp

#### **Additional State Saved:**

None

#### **Entry Vector Used:**

Debug exception vector

## 4.8.11 Execution Exception — System Call

The system call exception is one of the nine execution exceptions. All of these exceptions have the same priority. A system call exception occurs when a SYSCALL instruction is executed.

#### Cause Register ExcCode Value:

Sys

#### **Additional State Saved:**

None

## **Entry Vector Used:**

General exception vector (offset 0x180)

## 4.8.12 Execution Exception — Breakpoint

The breakpoint exception is one of the nine execution exceptions. All of these exceptions have the same priority. A breakpoint exception occurs when a BREAK instruction is executed.

## Cause Register ExcCode Value:

Вp

## **Additional State Saved:**

None

## **Entry Vector Used:**

General exception vector (offset 0x180)

## 4.8.13 Execution Exception — Reserved Instruction

The reserved instruction exception is one of the nine execution exceptions. All of these exceptions have the same priority. A reserved instruction exception occurs when a reserved or undefined major opcode or function field is executed. This includes Coprocessor 2 instructions which are decoded reserved in the Coprocessor 2.

#### Cause Register ExcCode Value:

RΙ

#### Additional State Saved:

None

#### **Entry Vector Used:**

General exception vector (offset 0x180)

## 4.8.14 Execution Exception — Coprocessor Unusable

The coprocessor unusable exception is one of the nine execution exceptions. All of these exceptions have the same priority. A coprocessor unusable exception occurs when an attempt is made to execute a coprocessor instruction for one of the following:

- a corresponding coprocessor unit that has not been marked usable by setting its CU bit in the Status register
- CP0 instructions, when the unit has not been marked usable, and the processor is executing in user mode

#### Cause Register ExcCode Value:

CpU

#### Additional State Saved:

Table 4-12 Register States on a Coprocessor Unusable Exception

Register State Value	
Cause <sub>CE</sub>	unit number of the coprocessor being referenced

#### **Entry Vector Used:**

General exception vector (offset 0x180)

#### 4.8.15 Execution Exception — Coprocessor 2 Exception

The Coprocessor 2 exception is one of the nine execution exceptions. All of these exceptions have the same priority. A Coprocessor 2 exception occurs when a valid Coprocessor 2 instruction cause a general exception in the Coprocessor 2.

#### Cause Register ExcCode Value:

C2E

#### Additional State Saved:

Depending on the Coprocessor 2 implementation, additional state information of the exception can be saved in a Coprocessor 2 control register.

#### **Entry Vector Used:**

General exception vector (offset 0x180)

## 4.8.16 Execution Exception — Implementation-Specific 1 exception

The Implementation-Specific 1 exception is one of the nine execution exceptions. All of these exceptions have the same priority. An implementation-specific 1 exception occurs when a valid coprocessor 2 instruction cause an implementation-specific 1 exception in the Coprocessor 2.

#### Cause Register ExcCode Value:

IS1

#### **Additional State Saved:**

Depending on the coprocessor 2 implementation, additional state information of the exception can be saved in a coprocessor 2 control register.

#### **Entry Vector Used:**

General exception vector (offset 0x180)

## 4.8.17 Execution Exception — Implementation Specific 2 exception

The Implementation-Specific 2 exception is one of the nine execution exceptions. All of these exceptions have the same priority. An implementation-specific 2 exception occurs when a valid Coprocessor 2 instruction cause an implementation-specific 2 exception in the Coprocessor 2.

#### Cause Register ExcCode Value:

IS2

#### **Additional State Saved:**

Depending on the Coprocessor 2 implementation, additional state information of the exception can be saved in a Coprocessor 2 control register.

#### **Entry Vector Used:**

General exception vector (offset 0x180)

## **4.8.18 Execution Exception — Integer Overflow**

The integer overflow exception is one of the nine execution exceptions. All of these exceptions have the same priority. An integer overflow exception occurs when selected integer instructions result in a 2's complement overflow.

## Cause Register ExcCode Value:

Ov

#### **Additional State Saved:**

None

#### **Entry Vector Used:**

General exception vector (offset 0x180)

## 4.8.19 Execution Exception — Trap

The trap exception is one of the nine execution exceptions. All of these exceptions have the same priority. A trap exception occurs when a trap instruction results in a TRUE value.

#### Cause Register ExcCode Value:

Tr

#### **Additional State Saved:**

None

#### **Entry Vector Used:**

General exception vector (offset 0x180)

## 4.8.20 Debug Data Break Exception

A debug data break exception occurs when a data hardware breakpoint matches the load/store transaction of an executed load/store instruction. The *DEPC* register and DBD bit in the *Debug* register will indicate the load/store instruction that caused the data hardware breakpoint to match. The load/store instruction that caused the debug exception has not completed e.g. not updated the register file, and the instruction can be re-executed after returning from the debug handler.

#### **Debug Register Debug Status Bit Set:**

DDBL for a load instruction or DDBS for a store instruction

#### **Additional State Saved:**

None

## **Entry Vector Used:**

Debug exception vector

## 4.9 Exception Handling and Servicing Flowcharts

The remainder of this chapter contains flowcharts for the following exceptions and guidelines for their handlers:

- · General exceptions and their exception handler
- Reset, soft reset and NMI exceptions, and a guideline to their handler.
- Debug exceptions

Generally speaking, the exceptions are handled by hardware; the exceptions are then serviced by software. Note that unexpected debug exceptions to the debug exception vector at 0xBFC0\_0200 may be viewed as a reserved instruction since uncontrolled execution of an SDBBP instruction caused the exception. The DERET instruction must be used at return from the debug exception handler, in order to leave debug mode and return to non-debug mode. The DERET instruction returns to the address in the *DEPC* register.




Figure 4-3 General Exception Handler (HW)




Figure 4-4 General Exception Servicing Guidelines (SW)




Figure 4-5 Reset, Soft Reset and NMI Exception Handling and Servicing Guidelines

# CP0 Registers of the M4K<sup>TM</sup> Core

The System Control Coprocessor (CP0) provides the register interface to the M4K<sup>TM</sup> processor core and supports memory management, address translation, exception handling, and other privileged operations. Each CP0 register has a unique number that identifies it; this number is referred to as the *register number*. For instance, the *PageMask* register is register number 5. For more information on the EJTAG registers, refer to Chapter 8, "EJTAG Debug Support in the M4K<sup>TM</sup> Core.".

After updating a CP0 register there is a hazard period of zero or more instructions from the update instruction (MTC0) and until the effect of the update has taken place in the core. Refer to Chapter 10, "M4K<sup>TM</sup> Processor Core Instructions," for further details on CP0 hazards.

The current chapter contains the following sections:

- Section 5.1, "CP0 Register Summary" on page 74
- Section 5.2, "CP0 Register Descriptions" on page 75

## 5.1 CP0 Register Summary

Table 5-1 lists the CP0 registers in numerical order. The individual registers are described throughout this chapter. Where more than one registers shares the same register number at different values of the "sel" field of the instruction, their names are listed using a slash (/) as separator.

**Table 5-1 CP0 Registers** 

Register Number	Register Name	Function
0-6	Reserved	Reserved in the M4K core.
7	HWREna	Enables access via the RDHWR instruction to selected hardware registers in non-privileged mode.
8	BadVAddr <sup>1</sup>	Reports the address for the most recent address-related exception.
9	Count <sup>1</sup>	Processor cycle count.
10	Reserved	Reserved in the M4K core.
11	Compare <sup>1</sup>	Timer interrupt control.
12	Status/ IntCtl/ SRSCtl/ SRSMap <sup>1</sup>	Processor status and control; interrupt control; and shadow set control.
13	Cause <sup>1</sup>	Cause of last exception.
14	EPC <sup>1</sup>	Program counter at last exception.
15	PRId/ EBase	Processor identification and revision; exception base address.
16	Config/ Config1/ Config2/ Config3	Configuration registers.
17-22	Reserved	Reserved in the M4K core.
23	Debug/ TraceControl/ TraceControl2/ UserTraceData/ TraceBPC <sup>2</sup>	Debug control/exception status and EJTAG trace control.
24	DEPC <sup>2</sup>	Program counter at last debug exception.
25-29	Reserved	Reserved in the M4K core.
30	ErrorEPC <sup>1</sup>	Program counter at last error.
31	DeSAVE <sup>2</sup>	Debug handler scratchpad register.

Note: 1. Registers used in exception processing.

Note: 2. Registers used in debug.

## **5.2 CP0 Register Descriptions**

The CP0 registers provide the interface between the ISA and the architecture. Each register is discussed below, with the registers presented in numerical order, first by register number, then by select field number.

For each register described below, field descriptions include the read/write properties of the field, and the reset state of the field. For the read/write properties of the field, the following notation is used:

**Table 5-2 CP0 Register Field Types** 

Read/Write Notation	Hardware Interpretation Software Interpretation			
	A field in which all bits are readable and writable by software and, potentially, by hardware.			
R/W	Hardware updates of this field are visible by software reads. Software updates of this field are visible by hardware reads.			
	If the reset state of this field is "Undefined," either before the first read will return a predictable value definition of UNDEFINED behavior.			
	A field that is either static or is updated only by hardware.	A field to which the value written by software is ignored by hardware. Software may write		
R	If the Reset State of this field is either "0" or "Preset", hardware initializes this field to zero or to the appropriate state, respectively, on	any value to this field without affecting hardware behavior. Software reads of this field return the last value updated by hardware.		
K	powerup.  If the Reset State of this field is "Undefined", hardware updates this field only under those conditions specified in the description of the field.	If the Reset State of this field is "Undefined," software reads of this field result in an UNPREDICTABLE value except after a hardware update done under the conditions specified in the description of the field.		
W	A field that can be written by software but which	n can not be read by software.		
W	Software reads of this field will return an UNDE	EFINED value.		
0	A field that hardware does not update, and for which hardware can assume a zero value.	A field to which the value written by software must be zero. Software writes of non-zero values to this field may result in UNDEFINED behavior of the hardware. Software reads of this field return zero as long as all previous software writes are zero.		
		If the Reset State of this field is "Undefined," software must write this field with zero before it is guaranteed to read as zero.		


MIPS32 M4K<sup>™</sup> Processor Core Software User's Manual, Revision 1.02

## 5.2.1 HWREna Register (CP0 Register 7, Select 0)

The HWREna register contains a bit mask that determines which hardware registers are accessible via the RDHWR instruction.

Figure 5-1 shows the format of the HWREna Register; Table 5-4 describes the HWREna register fields.

Figure 5-1 HWREna Register Format



**Table 5-4 HWREna Register Field Descriptions** 

Fields			Read/	
Name	Bits	Description	Write	Reset State
0	314	Must be written with zero; returns zero on read	0	0
Mask	30	Each bit in this field enables access by the RDHWR instruction to a particular hardware register (which may not be an actual register). If bit 'n' in this field is a 1, access is enabled to hardware register 'n'. If bit 'n' of this field is a 0, access is disabled.  See the RDHWR instruction for a list of valid hardware registers.	R/W	0

Privileged software may determine which of the hardware registers are accessible by the RDHWR instruction. In doing so, a register may be virtualized at the cost of handling a Reserved Instruction Exception, interpreting the instruction, and returning the virtualized value. For example, if it is not desirable to provide direct access to the *Count* register, access to that register may be individually disabled and the return value can be virtualized by the operating system.

## 5.2.2 BadVAddr Register (CP0 Register 8, Select 0)

The *BadVAddr* register is a read-only register that captures the most recent virtual address that caused the following exception:

• Address error (AdEL or AdES)

The BadVAddr register does not capture address information for bus errors, since they are not addressing errors.

Figure 5-2 BadVAddr Register Format




Table 5-5 BadVAddr Register Field Description

Fields			Read/	
Name	Bits	Description	Write	Reset State
BadVAddr	31:0	Bad virtual address.	R	Undefined


## 5.2.3 Count Register (CP0 Register 9, Select 0)

The *Count* register acts as a timer, incrementing at a constant rate, whether or not an instruction is executed, retired, or any forward progress is made through the pipeline. The counter increments every other clock, if the DC bit in the *Cause* register is 0.

The *Count* register can be written for functional or diagnostic purposes, including at reset or to synchronize processors.

By writing the CountDM bit in the *Debug* register, it is possible to control whether the *Count* register continues incrementing while the processor is in debug mode.

Figure 5-3 Count Register Format



**Table 5-6 Count Register Field Description** 

Fiel	ds		Read/	
Name	Bits	Description	Write	Reset State
Count	31:0	Interval counter.	R/W	Undefined

## **5.2.4** *Compare* Register (CP0 Register 11, Select 0)

The *Compare* register acts in conjunction with the *Count* register to implement a timer and timer interrupt function. The timer interrupt is an output of the cores. The *Compare* register maintains a stable value and does not change on its own.

When the value of the *Count* register equals the value of the *Compare* register, the SI\_TimerInt pin is asserted. This pin will remain asserted until the *Compare* register is written. The SI\_TimerInt pin can be fed back into the core on one of the interrupt pins to generate an interrupt. Traditionally, this has been done by multiplexing it with hardware interrupt 5 to set interrupt bit IP(7) in the *Cause* register.

For diagnostic purposes, the *Compare* register is a read/write register. In normal use, however, the *Compare* register is write-only. Writing a value to the *Compare* register, as a side effect, clears the timer interrupt.

Figure 5-4 Compare Register Format



Table 5-7 Compare Register Field Description

Fields			Read/	
Name	Bit(s)	Description	Write	Reset State
Compare	31:0	Interval count compare value.	R/W	Undefined

## 5.2.5 Status Register (CP0 Register 12, Select 0)

The *Status* register is a read/write register that contains the operating mode, interrupt enabling, and the diagnostic states of the processor. Fields of this register combine to create operating modes for the processor. Refer to Section 3.2, "Modes of Operation" on page 32 for a discussion of operating modes, and Section 4.3, "Interrupts" on page 46 for a discussion of interrupt modes.

**Interrupt Enable**: Interrupts are enabled when all of the following conditions are true:

- IE = 1
- EXL = 0
- ERL = 0
- DM = 0

If these conditions are met, then the settings of the IM and IE bits enable the interrupts.


**Operating Modes**: If the DM bit in the Debug register is 1, then the processor is in debug mode; otherwise the processor is in either kernel or user mode. The following CPU Status register bit settings determine user or kernel mode:

- User mode: UM = 1, EXL = 0, and ERL = 0
- Kernel mode: UM = 0, or EXL = 1, or ERL = 1

Coprocessor Accessibility: The *Status* register CU bits control coprocessor accessibility. If any coprocessor is unusable, then an instruction that accesses it generates an exception.

Figure 5-5 shows the format of the Status register; Table 5-8 describes the Status register fields.

## Figure 5-5 Status Register Format



**Table 5-8 Status Register Field Descriptions** 

Field	ls		Read/	
Name	Bits	Description	Write	Reset State
CU3	31	Controls access to coprocessor 3. COP3 is not supported. This bit cannot be written and will read as 0.	R	0
CU2	30	Controls access to coprocessor 2. This bit can only be written if coprocessor is attached to the COP2 interface. (C2 bit in Config1 is set). This bit will read as 0 if no coprocessor is present.	R/W	0
CU1	29	Controls access to Coprocessor 1. COP1 is not supported. This bit cannot be written and will read as 0.	R	0

**Table 5-8 Status Register Field Descriptions** 

Fiel	ds		Read/	
Name	Bits	Description	Write	Reset State
CU0	28	Controls access to coprocessor 0  0: access not allowed 1: access allowed  Coprocessor 0 is always usable when the processor is running in kernel mode, independent of the state of the CU0 bit.	R/W	Undefined
RP	27	Enables reduced power mode. The state of the RP bit is available on the external core interface as the <i>SI_RP</i> signal.	R/W	0 for Cold Reset only.
FR	26	This bit is related to floating point registers. Since the M4K core does not contain a floating point unit, this bit is ignored on write and read as zero.	R	0
RE	25	Used to enable reverse-endian memory references while the processor is running in user mode:    Encoding   Meaning     0   User mode uses configured endianness     1   User mode uses reversed endianness     Neither Debug Mode nor Kernel Mode nor Supervisor Mode references are affected by the state of this bit.	R/W	Undefined
R	24:23	Reserved. This field is ignored on write and read as 0.	R	0
BEV	22	Controls the location of exception vectors:    Encoding   Meaning	R/W	1
TS	21	TLB shutdown.  Since the M4K core does not contain a TLB, this bit is ignored on write and read as 0.	R/W	0
SR	20	Indicates that the entry through the reset exception vector was due to a Soft Reset:    Encoding   Meaning     0   Not Soft Reset (NMI or Reset)     1   Soft Reset     Software can only write a 0 to this bit to clear it and cannot force a 0-1 transition.	R/W	1 for Soft Reset; 0 otherwise

**Table 5-8 Status Register Field Descriptions** 

Field	ds		D 4/	
Name	Bits	Description	Read/ Write	Reset State
NMI	19	Indicates that the entry through the reset exception vector was due to an NMI:    Encoding   Meaning   0   Not NMI (Soft Reset or Reset)   1   NMI	R/W	1 for NMI; 0 otherwise
0	18	Must be written as zero; returns zero on read.	0	0
R	17:16	Reserved. Ignored on write and read as zero.	R	0
IM7IM2	1510	Interrupt Mask: Controls the enabling of each of the hardware interrupts. Refer to Section 4.3, "Interrupts" on page 46 for a complete discussion of enabled interrupts.  An interrupt is taken if interrupts are enabled and the corresponding bits are set in both the Interrupt Mask field of the Status register and the Interrupt Pending field of the Cause register and the IE bit is set in the Status register.    Encoding   Meaning	R/W	Undefined
IPL	1510	Interrupt Priority Level.  In implementations of Release 2 of the Architecture in which EIC interrupt mode is enabled (Config3 <sub>VEIC</sub> = 1), this field is the encoded (0.63) value of the current IPL. An interrupt will be signaled only if the requested IPL is higher than this value.  If EIC interrupt mode is not enabled (Config3 <sub>VEIC</sub> = 0), these bits take on a different meaning and are interpreted as the IM7IM2 bits, described above.	R/W	Undefined
IM1IM0	98	Interrupt Mask: Controls the enabling of each of the software interrupts. Refer to Section < <need crossref="">&gt; for a complete discussion of enabled interrupts.    Encoding   Meaning     0</need>	R/W	Undefined

**Table 5-8 Status Register Field Descriptions** 

Fiel	ds		Read/	
Name	Bits	Description	Write	Reset State
R	7:5	Reserved. This field is ignored on write and read as 0.	R	0
		This bit denotes the base operating mode of the processor. See Section 3.2, "Modes of Operation" on page 32 for a full discussion of operating modes. The encoding of this bit is:		
1111		<b>Encoding</b> Meaning	D /33/	11 1 6 1
UM	4	0 Base mode is Kernel Mode	R/W	Undefined
		1 Base mode is User Mode		
		Note that the processor can also be in kernel mode if ERL or EXL is set, regardless of the state of the UM bit.		
R	3	This bit is reserved. This bit is ignored on write and read as zero.	R	0
		Error Level; Set by the processor when a Reset, Soft Reset, NMI or Cache Error exception are taken.		
		<b>Encoding</b> Meaning		
		0 Normal level		
		1 Error level		
		When ERL is set:  • The processor is running in kernel mode		
ERL	2	Interrupts are disabled	R/W	1
		The ERET instruction will use the return address held in ErrorEPC instead of EPC		
		• The lower 2 <sup>29</sup> bytes of kuseg are treated as an		
		unmapped and uncached region. See Chapter 3, "Memory Management of the M4K <sup>TM</sup> Core," on page		
		32. This allows main memory to be accessed in the		
		presence of cache errors. The operation of the processor		
		is <b>UNDEFINED</b> if the ERL bit is set while the processor is executing instructions from kuseg.		
		Exception Level; Set by the processor when any exception		
		other than Reset, Soft Reset, or NMI exceptions is taken.		
		Encoding Meaning		
		0 Normal level		
EXL	1	1 Exception level	R/W	Undefined
EAL		When EXL is set:  The processor is running in Kernel Mode	IX/ VV	Ondenned
		Interrupts are disabled.		
		EPC, Cause <sub>BD</sub> and SRSCtl (implementations of Release 2 of the Architecture only) will not be updated if another exception is taken		

**Table 5-8 Status Register Field Descriptions** 

Field	ds			Read/	
Name	Bits		Description	Write	Reset State
		Interrupt Ena and hardwar	•		
IE	0	0	Interrupts are disabled	R/W	Undefined
			of the Architecture, this bit may be modified at the DI and EI instructions.		

## 5.2.6 *IntCtl* Register (CP0 Register 12, Select 1)

The *IntCtl* register controls the expanded interrupt capability added in Release 2 of the Architecture, including vectored interrupts and support for an external interrupt controller. This register does not exist in implementations of Release 1 of the Architecture.

Figure 5-6 shows the format of the *IntCtl* register; Table 5-9 describes the *IntCtl* register fields.

## Figure 5-6 IntCtl Register Format

31 29	28 26	25 10	9 5	4 0	
IPTI	IPPCI	0	VS	0	

**Table 5-9 IntCtl Register Field Descriptions** 

Field	ds					Read/	Reset
Name	Bits		Descri	ption		Write	State
IPTI	3129	modes, this field s Timer Interrupt resoftware to deterr for a potential interrupt resoftware to deterr for a potential interrupt resoftware to deterr  Encoding  2 3 4 5 6 7  The value of this SI_IPTI[2:0]. This communicate the pin to which the S The value of this Interrupt Controll	pecifies the quest is a mine whe errupt.  IP bit  2  3  4  5  6  7  bit is set bit is set bit is allows specific \$SI_TimerI field is not errupt.	SI_Int hardware intended in the signal is attached to meaningful if Exist enabled. The except to provide this	terrupt ed.	R	Externally Set
IPPCI	2826	For Interrupt Con modes, this field s Performance Cou and allows softwa Cause <sub>PCI</sub> for a po Since performanc the M4K core (Co write and returns	pecifies the nter Inter Inter re to determine the counter on fig 1 <sub>PC</sub> =	nich the rged, onsider nted on	R	0	
0	2510	Must be written a	s zero; re	turns zero on read		0	0

Table 5-9 IntCtl Register Field Descriptions

Field	ds				Read/	Reset
Name	Bits		Descripti	on	Write	State
		implement Config3 <sub>VE</sub> between vo	ecing. If vectored inted (as denoted by Conc.), this field specificationed interrupts.	onfig3 <sub>VInt</sub> or les the spacing		
		Encoding	Spacing Between Vectors (hex)	Spacing Between Vectors (decimal)		
		16#00	16#000	0		
VS	95	16#01	16#020	32	R/W	0
7.5	75	16#02	16#040	64	10 11	V
		16#04	16#080	128		
		16#08	16#100	256		
		16#10	16#200	512		
			is <b>UNDEFINED</b> if	The operation of the a reserved value is		
0	40	Must be w	ritten as zero; returr	ns zero on read.	0	0

## 5.2.7 SRSCtl Register (CP0 Register 12, Select 2)

The *SRSCtl* register controls the operation of GPR shadow sets in the processor. This register does not exist in implementations of the architecture prior to Release 2.

Figure 5-7 shows the format of the SRSCtl register; Table 5-10 describes the SRSCtl register fields.

## **Figure 5-7 SRSCtl Register Format**

31 3	0 29	26	25	22	21	18	17	16	15		12	11	10	9		6	5	4	3		0
00		HSS		0 00 00	EI	CSS	00	0		ESS		0	0		PSS		0	0		CSS	

## **Table 5-10 SRSCtl Register Field Descriptions**

Fiel	ds			Read/	Reset
Name	Bits		Description	Write	State
0	3130	Must be w	ritten as zeros; returns zero on read.	0	0
		shadow set processor. only the no Possible va are:	nadow Set. This field contains the highest that is implemented by this A value of zero in this field indicates that formal GPRs are implemented.  Alues of this field for the M4K processor		
		Encoding	Meaning		
		0	One shadow set (normal GPR set) is present.	_	_
HSS	2926	1	Two shadow sets are present.	R	Preset
		3	Four shadow sets are present.		
		2, 3-15	Reserved		
		value that of CSS fields SRSMap re UNDEFIN	in this field also represents the highest can be written to the ESS, EICSS, PSS, and of this register, or to any of the fields of the egister. The operation of the processor is <b>NED</b> if a value larger than the one in this tten to any of these other fields.		
0	2522	Must be w	ritten as zeros; returns zero on read.	0	0
EICSS	2118	(EIC interned from the eximterrupt register to interrupt.  See Section Mode" on mode. If C	upt mode shadow set. If Config3 <sub>VEIC</sub> is 1 rupt mode is enabled), this field is loaded xternal interrupt controller for each equest and is used in place of the <i>SRSMap</i> select the current shadow set for the n 4.3.1.3, "External Interrupt Controller page 51 for a discussion of EIC interrupt config3 <sub>VEIC</sub> is 0, this field must be written d returns zero on read.	R	Undefined
0	1716	Must be w	ritten as zeros; returns zero on read.	0	0

**Table 5-10 SRSCtl Register Field Descriptions** 

Field	ds		Read/	Reset
Name	Bits	Description	Write	State
ESS	1512	Exception Shadow Set. This field specifies the shadow set to use on entry to Kernel Mode caused by any exception other than a vectored interrupt.  The operation of the processor is <b>UNDEFINED</b> if software writes a value into this field that is greater than the value in the HSS field.	R/W	0
0	1110	Must be written as zeros; returns zero on read.	0	0
PSS	96	Previous Shadow Set. If GPR shadow registers are implemented, and with the exclusions noted in the next paragraph, this field is copied from the CSS field when an exception or interrupt occurs. An ERET instruction copies this value back into the CSS field if Status_{BEV} = 0.   This field is not updated on any exception which sets Status_{ERL} to 1 (i.e., Reset, Soft Reset, NMI, cache error), an entry into EJTAG Debug mode, or any exception or interrupt that occurs with Status_{EXL} = 1, or Status_{BEV} = 1. This field is not updated on an exception that occurs while Status_{ERL} = 1.   The operation of the processor is <b>UNDEFINED</b> if software writes a value into this field that is greater than the value in the HSS field.	R/W	0
0	54	Must be written as zeros; returns zero on read.	0	0
CSS	30	Current Shadow Set. If GPR shadow registers are implemented, this field is the number of the current GPR set. With the exclusions noted in the next paragraph, this field is updated with a new value on any interrupt or exception, and restored from the PSS field on an ERET. Table 5-11 describes the various sources from which the CSS field is updated on an exception or interrupt.  This field is not updated on any exception which sets Status <sub>ERL</sub> to 1 (i.e., Reset, Soft Reset, NMI, cache error), an entry into EJTAG Debug mode, or any exception or interrupt that occurs with Status <sub>EXL</sub> = 1, or Status <sub>BEV</sub> = 1. Neither is it updated on an ERET with Status <sub>ERL</sub> = 1 or Status <sub>BEV</sub> = 1. This field is not updated on an exception that occurs while Status <sub>ERL</sub> = 1.  The value of CSS can be changed directly by software only by writing the PSS field and executing an ERET instruction.	R	0

Table 5-11 Sources for new SRSCtl $_{\mbox{\footnotesize CSS}}$  on an Exception or Interrupt

<b>Exception Type</b>	Condition	SRSCtl <sub>CSS</sub> Source	Comment
Exception	All	SRSCtl <sub>ESS</sub>	
Non-Vectored Interrupt	Cause <sub>IV</sub> = 0	SRSCtl <sub>ESS</sub>	Treat as exception

Table 5-11 Sources for new SRSCtl $_{\mbox{\footnotesize CSS}}$  on an Exception or Interrupt

<b>Exception Type</b>	Condition	SRSCtl <sub>CSS</sub> Source	Comment
Vectored Interrupt	$\begin{aligned} \text{Cause}_{\text{IV}} &= 1 \text{ and} \\ \text{Config3}_{\text{VEIC}} &= 0 \text{ and} \end{aligned}$	SRSMap <sub>VECTNUM</sub> Source is internal map	
vectored interrupt	$Config3_{VInt} = 1$	SKOWIAPVECTNUM	(for VECTNUM see Table 4-3)
Vectored EIC Interrupt	Cause <sub>IV</sub> = 1 and Config3 <sub>VEIC</sub> = 1	SRSCtl <sub>EICSS</sub>	Source is external interrupt controller.

## 5.2.8 SRSMap Register (CP0 Register 12, Select 3)

The SRSMap register contains 8 4-bit fields that provide the mapping from an vector number to the shadow set number to use when servicing such an interrupt. The values from this register are not used for a non-interrupt exception, or a non-vectored interrupt (Cause<sub>IV</sub> = 0 or IntCtl<sub>VS</sub> = 0). In such cases, the shadow set number comes from SRSCtl<sub>ESS</sub>.

If SRSCtl<sub>HSS</sub> is zero, the results of a software read or write of this register are UNPREDICTABLE.

The operation of the processor is **UNDEFINED** if a value is written to any field in this register that is greater than the value of  $SRSCtl_{HSS}$ .

The *SRSMap* register contains the shadow register set numbers for vector numbers 7..0. The same shadow set number can be established for multiple interrupt vectors, creating a many-to-one mapping from a vector to a single shadow register set number.

Figure 5-8 shows the format of the SRSMap register; Table 5-12 describes the SRSMap register fields.

### Figure 5-8 SRSMap Register Format

31	28	27	2	24	23	2	0	19		16	15		12	11		8	7		4	3		0	
	SSV7		SSV6		S	SV5			SSV4			SSV3			SSV2			SSV1			SSV0		

**Table 5-12 SRSMap Register Field Descriptions** 

Fiel	lds		Read/	
Name	Bits	Description	Write	Reset State
SSV7	3128	Shadow register set number for Vector Number 7	R/W	0
SSV6	2724	Shadow register set number for Vector Number 6	R/W	0
SSV5	2320	Shadow register set number for Vector Number 5	R/W	0
SSV4	1916	Shadow register set number for Vector Number 4	R/W	0
SSV3	1512	Shadow register set number for Vector Number 3	R/W	0
SSV2	118	Shadow register set number for Vector Number 2	R/W	0
SSV1	74	Shadow register set number for Vector Number 1	R/W	0
SSV0	30	Shadow register set number for Vector Number 0	R/W	0

## 5.2.9 Cause Register (CP0 Register 13, Select 0)

The *Cause* register primarily describes the cause of the most recent exception. In addition, fields also control software interrupt requests and the vector through which interrupts are dispatched. With the exception of the  $IP_{1..0}$ , DC, IV, and WP fields, all fields in the *Cause* register are read-only. Release 2 of the Architecture added optional support for an External Interrupt Controller (EIC) interrupt mode, in which  $IP_{7..2}$  are interpreted as the Requested Interrupt Priority Level (RIPL).

Figure 5-9 shows the format of the Cause register; Table 5-13 describes the Cause register fields.

## Figure 5-9 Cause Register Format

31 30	29 28	3 27 26	25 24	23	22	21	16	15	10 9	8	7	6		2	1	0
BD TI	CE	DC PCI	0	IV	WP	0		IP7IP2	IP1.	.IP(	0		Exc Code		0	)
								RIPL								

**Table 5-13 Cause Register Field Descriptions** 

Fields				Read/		
Name	Name Bits		Description	Write	Reset State	
		Indicates v a branch d	whether the last exception taken occurred in elay slot:			
		Encoding	<b>Encoding</b> Meaning			
BD	31	0	Not in delay slot	R	Undefined	
	31	1	In delay slot			
		when the	ssor updates BD only if Status <sub>EXL</sub> was zero exception occurred.			
			pending (analogous to the IP bits for other		Undefined	
	20	Encoding	Meaning	R		
TI	30	0	No timer interrupt is pending			
		1	Timer interrupt is pending			
			f the TI bit is available on the external core s the SI_TimerInt signal			
СЕ	2928	Coprocess is loaded b UNPRED	or unit number referenced when a or Unusable exception is taken. This field by hardware on every exception, but is <b>ICTABLE</b> for all exceptions except for or Unusable.	R	Undefined	

**Table 5-13 Cause Register Field Descriptions** 

Fiel	ds		Read/		
Name	Bits	Description	Write	Reset State	
		Disable <i>Count</i> register. In some power-sensitive applications, the <i>Count</i> register is not used and is the source of meaningful power dissipation. This bit allows the <i>Count</i> register to be stopped in such situations.	R/W	0	
DC	27	<b>Encoding</b> Meaning			
		0 Enable counting of <i>Count</i> register			
		1 Disable counting of <i>Count</i> register			
		Performance Counter Interrupt. In an implementation of Release 2 of the Architecture, this bit denotes whether a performance counter interrupt is pending (analogous to the IP bits for other interrupt types):			
PCI	26	<b>Encoding</b> Meaning	R	0	
		0 No timer interrupt is pending			
		1 Timer interrupt is pending			
		Since performance counters are not implemented (Config $1_{PC} = 0$ ), this bit must be written as zero and returns zero on read.			
		Indicates whether an interrupt exception uses the general exception vector or a special interrupt vector:	R/W	Undefined	
	23	<b>Encoding</b> Meaning			
		0 Use the general exception vector (16#180)			
IV		1 Use the special interrupt vector (16#200)			
		In implementations of Release 2 of the architecture, if the $Cause_{IV}$ is 1 and $Status_{BEV}$ is 0, the special interrupt vector represents the base of the vectored interrupt table.			
WP	22	Indicates that a watch exception was deferred because Status <sub>EXL</sub> or Status <sub>ERL</sub> were a one at the time the watch exception was detected. This bit both indicates that the watch exception was deferred, and causes the exception to be initiated once Status <sub>EXL</sub> and Status <sub>ERL</sub> are both zero. As such, software must clear this bit as part of the watch exception handler to prevent a watch exception loop.  Software should not write a 1 to this bit when its value is a 0, thereby causing a 0-to-1 transition. If such a transition is caused by software, it is UNPREDICTABLE whether hardware ignores the write, accepts the write with no side effects, or accepts the write and initiates a watch exception once Status <sub>EXL</sub> and Status <sub>ERL</sub> are both zero.  Since watch registers are not implemented on the MMK core, this bit is ignored on write and read as	R/W	0	
		M4K core, this bit is ignored on write and read as zero.			

**Table 5-13 Cause Register Field Descriptions** 

Fields						Read/	
Name	Bits	-		Description	Write	Reset State	
		Indicates	an inter	rupt is pending:			
		Bit	Name	Meaning			
		15	IP7	Hardware interrupt 5			
		14	IP6	Hardware interrupt 4			
		13	IP5	Hardware interrupt 3			
		12	IP4	Hardware interrupt 2			
		11	IP3	Hardware interrupt 1			
IP7IP2	1510	10	IP2	Hardware interrupt 0		R	Undefined
		0), timer i system-de If EIC int these bits interprete See Section descriptio	nterrupt epender errupt r take on d as the on 4.3, ' n of int	node is not enabled (Config3 <sub>VI</sub> its are combined in a at way with any hardware internode is enabled (Config3 <sub>VEIC</sub> a different meaning and are PRIPL field, described below. Interrupts" on page 46 for a generupt processing.	rupt. = 1),		
RIPL	1510	If EIC intended this field interrupt.	Requested Interrupt Priority Level.  If EIC interrupt mode is enabled (Config3 <sub>VEIC</sub> = 1), this field is the encoded (063) value of the requested interrupt. A value of zero indicates that no interrupt is requested.  If EIC interrupt mode is not enabled (Config3 <sub>VEIC</sub> =		ested rupt	R	Undefined
		0), these bits take on a different meaning and are interpreted as the IP7IP2 bits, described above.					
		Controls t	he requ	nest for software interrupts:			
		Bit	Name	Meaning			
		9	IP1	Request software interrupt 1			Undefined
IP1IP0	98	8	IP0	Request software interrupt 0		R/W	
		These bits are exported to an external interrupt controller for prioritization in EIC interrupt mode with other interrupt sources. The state of these bits is available on the external core interface as the SI_SWInt[1:0] bus.					
ExcCode	62	Exception	code -	see Table 5-14		R	Undefined
0	2524, 2116, 7, 10 Must be written as zero; returns zero on read.					0	0

**Table 5-14 Cause Register ExcCode Field** 

Exception	Code Value					
Decimal	Decimal Hexadecimal		Description			
0	16#00	Int	Interrupt			
1-3	16#00-16#03	-	Reserved			
4	16#04	AdEL	Address error exception (load or instruction fetch)			
5	16#05	AdES	Address error exception (store)			
6	16#06	IBE	Bus error exception (instruction fetch)			
7	16#07	DBE	Bus error exception (data reference: load or store)			
8	16#08	Sys	Syscall exception			
9	16#09	Вр	Breakpoint exception			
10	16#0a	RI	Reserved instruction exception			
11	16#0b	CpU	Coprocessor Unusable exception			
12	16#0c	Ov	Arithmetic Overflow exception			
13	16#0d	Tr	Trap exception			
14-15	16#0e-16#0f	-	Reserved			
16	16#10	IS1	Implementation-Specific Exception 1 (COP2)			
17	16#11	IS2	Implementation-Specific Exception 2(COP2)			
18	16#12	C2E	Coprocessor 2 exceptions			
19-31	16#13-16#1f	-	Reserved			

## 5.2.10 Exception Program Counter (CP0 Register 14, Select 0)

The Exception Program Counter (*EPC*) is a read/write register that contains the address at which processing resumes after an exception has been serviced. All bits of the *EPC* register are significant and must be writable.

For synchronous (precise) exceptions, the EPC contains one of the following:

- The virtual address of the instruction that was the direct cause of the exception
- The virtual address of the immediately preceding branch or jump instruction, when the exception causing instruction is in a branch delay slot and the *Branch Delay* bit in the *Cause* register is set.

On new exceptions, the processor does not write to the *EPC* register when the EXL bit in the *Status* register is set, however, the register can still be written via the MTC0 instruction.

In processors that implement the MIPS16 ASE, a read of the EPC register (via MFC0) returns the following value in the destination GPR:

```
GPR[rt] \leftarrow ExceptionPC_{31...1} || ISAMode_0
```

That is, the upper 31 bits of the exception PC are combined with the lower bit of the ISAMode field and written to the GPR.

Similarly, a write to the EPC register (via MTC0) takes the value from the GPR and distributes that value to the exception PC and the ISAMode field, as follows

```
ExceptionPC \leftarrow GPR[rt]<sub>31..1</sub> || 0
ISAMode \leftarrow 2#0 || GPR[rt]<sub>0</sub>
```

That is, the upper 31 bits of the GPR are written to the upper 31 bits of the exception PC, and the lower bit of the exception PC is cleared. The upper bit of the ISAMode field is cleared and the lower bit is loaded from the lower bit of the GPR.

Figure 5-10 EPC Register Format




Table 5-15 EPC Register Field Description

Fields			Read/		
Name Bit(s)		Description	Write	Reset State	
EPC	31:0	Exception Program Counter.	R/W	Undefined	

# **5.2.11** Processor Identification (CP0 Register 15, Select 0)

The Processor Identification (*PRId*) register is a 32 bit read-only register that contains information identifying the manufacturer, manufacturer options, processor identification, and revision level of the processor.

Figure 5-11 PRId Register Format




Table 5-16 PRId Register Field Descriptions

Fields			Read/	
Name	Bit(s)	Description	Write	Reset State
R	31:24	Reserved. Must be ignored on write and read as zero	R	0
Company ID	23:16	Identifies the company that designed or manufactured the processor. In the M4K this field contains a value of 1 to indicate MIPS Technologies, Inc.	R	1
Processor ID	15:8	Identifies the type of processor. This field allows software to distinguish between the various types of MIPS Technologies processors.	R	0x87
Revision	7:0	Specifies the revision number of the processor. This field allows software to distinguish between one revision and another of the same processor type.  This field is broken up into the following three subfields	R	Preset
Major Revision	7:5	This number is increased on major revisions of the processor core	R	Preset
Minor Revision	4:2	This number is increased on each incremental revision of the processor and reset on each new major revision	R	Preset
Patch Level	1:0	If a patch is made to modify an older revision of the processor, this field will be incremented	R	Preset

### 5.2.12 EBase Register (CP0 Register 15, Select 1)

The *EBase* register is a read/write register containing the base address of the exception vectors used when Status<sub>BEV</sub> equals 0, and a read-only CPU number value that may be used by software to distinguish different processors in a multi-processor system.

The EBase register provides the ability for software to identify the specific processor within a multi-processor system, and allows the exception vectors for each processor to be different, especially in systems composed of heterogeneous processors. Bits 31..12 of the EBase register are concatenated with zeros to form the base of the exception vectors when Status<sub>BEV</sub> is 0. The exception vector base address comes from the fixed defaults (see Section 4.5, "Exception Vector Locations" on page 55) when Status<sub>BEV</sub> is 1, or for any EJTAG Debug exception. The reset state of bits 31..12 of the EBase register initialize the exception base register to 16#8000.0000, providing backward compatibility with Release 1 implementations.

Bits 31..30 of the *EBase* Register are fixed with the value 2#10 to force the exception base address to be in the kseg0 or kseg1 unmapped virtual address segments.

If the value of the exception base register is to be changed, this must be done with  $Status_{BEV}$  equal 1. The operation of the processor is **UNDEFINED** if the Exception Base field is written with a different value when  $Status_{BEV}$  is 0.

Combining bits 31..20 with the Exception Base field allows the base address of the exception vectors to be placed at any 4KBbyte page boundary.

Figure 5-12 shows the format of the *EBase* Register; Table 5-17 describes the *EBase* register fields.

Figure 5-12 EBase Register Format

31 30	29	12 11 10	9 0
1 0	Exception Base	0.0	CPUNum

**Table 5-17 EBase Register Field Descriptions** 

Fie	elds		Read/	
Name	Bits	Description	Write	Reset State
1	31	This bit is ignored on write and returns one on read.	R	1
0	30	This bit is ignored on write and returns zero on read.	R	0
Exception Base	2912	In conjunction with bits 3130, this field specifies the base address of the exception vectors when Status <sub>BEV</sub> is zero.	R/W	0
0	1110	Must be written as zero; returns zero on read.	0	0
CPUNum	90	This field specifies the number of the CPU in a multi-processor system and can be used by software to distinguish a particular processor from the others. The value in this field is set by the SI_CPUNum[9:0] static input pins to the core. In a single processor system, this value should be set to zero.	R	Externally Set

# 5.2.13 Config Register (CP0 Register 16, Select 0)

The *Config* register specifies various configuration and capabilities information. Most of the fields in the *Config* register are initialized by hardware during the Reset exception process, or are constant.

Figure 5-13 Config Register Format — Select 0

31	30 28	27 25	24 23	22	21	20	19 1	7 16	15	14 13	12 10	9 7	6 3	2	0
M	K23	KU	0	UDI	SB	MDU	0	DS	BE	AT	AR	MT	0	K0	

Figure 5-14 Config Register Field Descriptions

Fiel	lds		Read/W	PM: 010  FM: 010
Name	Bit(s)	Description	rite	Reset State
М	31	This bit is hardwired to '1' to indicate the presence of the Config1 register.	R	1
K23	30:28	This field controls the cacheability of the kseg2 and kseg3 address segments in FM implementations.  Refer to Table 5-18 for the field encoding.	FM: R	FM: 010
KU	27:25	This field controls the cacheability of the kuseg and useg address segments in FM implementations.  Refer to Table 5-18 for the field encoding.	FM: R	FM: 010
0	24:23	Must be written as 0. Returns zero on reads.	0	0
UDI	22	This bit indicates that CorExtend User Defined Instructions have been implemented.	R	Preset
		0 = No User Defined Instructions are implemented 1 = User Defined Instructions are implemented		Preset
SB	21	Indicates whether SimpleBE bus mode is enabled. Set via $SI\_SimpleBE[0]$ input pin.  0 = No reserved byte enables on SRAM interface 1 = Only simple byte enables allowed on SRAM interface	R	Externally Set
MDU	20	This bit indicates the type of Multiply/Divide Unit present.  0 = Fast, high-performance MDU  1 = Iterative, area-efficient MDU	R	Preset
0	19:17	Must be written as 0. Returns zero on reads.	0	0
DS	16	Dual SRAM interface.  0: Unified instruction/data SRAM interface 1: Dual instruction/data SRAM interfaces	R	Preset
BE	15	Indicates the endian mode in which the processor is running. Set via <i>SI_Endian</i> input pin.  0: Little endian 1: Big endian	R	Externally Set
АТ	14:13	Architecture type implemented by the processor. This field is always 00 to indicate the MIPS32 architecture.	R	00

Figure 5-14 Config Register Field Descriptions (Continued)

Fields			Read/W	
Name	Bit(s)	Description	rite	Reset State
AR	12:10	Architecture revision level. This field is always 001 to indicate MIPS32 Release 2.  0: Release 1 1: Release 2 2-7: Reserved	R	001
МТ	9:7	MMU Type: 3: Fixed Mapping 0-2, 4-7: Reserved	R	3
0	6:3	Must be written as zeros; returns zeros on reads.	0	0
K0	2:0	Kseg0 coherency algorithm. Refer to Table 5-18 for the field encoding.	R	010

**Table 5-18 Cache Coherency Attributes** 

<b>C(2:0) Value</b>	Cache Coherency Attribute
2	Uncached. This field is read-only and always holds a static value of 2. No other values are possible in the M4K core.

# 5.2.14 *Config1* Register (CP0 Register 16, Select 1)

The *Config1* register is an adjunct to the *Config* register and encodes additional information about capabilities present on the core. All fields in the *Config1* register are read-only.

Figure 5-15 Config1 Register Format — Select 1

31	30	25 24	22 21	19	18 16	15 13	12 10	9 7	6	5	4	3	2	1	0
M	MMU Size	IS		IL	IA	DS	DL	DA	C2	MD	PC	WR	CA	EP	FP

Table 5-19 Config1 Register Field Descriptions — Select 1

Fields			Read/	
Name	Bit(s)	Description	Write	Reset State
М	31	This bit is hardwired to '1' to indicate the presence of the Config2 register.	R	1
MMU Size	30:25	This field contains the number of entries in the TLB minus one. The field is read as 0 decimal in the M4K cores, since no TLB is present.	R	0
IS	24:22	This field contains the number of instruction cache sets per way. Since the M4K core does not include caches, this field is always read as 0.	R	0
IL	21:19	This field contains the instruction cache line size. Since the M4K core does not include caches, this field is always read as 0.	R	0
IA	18:16	This field contains the level of instruction cache associativity. Since the M4K core does not include caches, this field is always read as 0.	R	0
DS	15:13	This field contains the number of data cache sets per way. Since the M4K core does not include caches, this field is always read as 0.	R	0
DL	12:10	This field contains the data cache line size. Since the M4K core does not include caches, this field is always read as 0.	R	0
DA	9:7	This field contains the type of set associativity for the data cache. Since the M4K core does not include caches, this field is always read as 0.	R	0
C2	6	Coprocessor 2 present.  0: No coprocessor is attached to the COP2 interface 1: A coprocessor is attached to the COP2 interface If the Cop2 interface logic is not implemented, this bit will read 0.	R	Preset
MD	5	MDMX implemented. This bit always reads as 0 because MDMX is not supported.	R	0
PC	4	Performance Counter registers implemented. Always a 0 since the M4K core does not contain Performance Counters.	R	0

Table 5-19 Config1 Register Field Descriptions — Select 1 (Continued)

Fiel	lds		Read/	
Name	Bit(s)	Description	Write	Reset State
		Watch registers implemented.		
WR	3	No Watch registers are present     One or more Watch registers are present	R	0
		This bit is always read as 0 since the M4K core does not contain Watch registers.		
		Code compression (MIPS16) implemented.		
CA	2	0: No MIPS16 present 1: MIPS16 is implemented	R	Preset
EP	1	EJTAG present: This bit is always set to indicate that the core implements EJTAG.	R	1
FP	0	FPU implemented. This bit is always zero since the core does not contain a floating point unit.	R	0

# 5.2.15 Config2 Register (CP0 Register 16, Select 2)

The *Config2* register is an adjunct to the *Config* register and is reserved to encode additional capabilities information. *Config2* is allocated for showing the configuration of level 2/3 caches. These fields are reset to 0 because L2/L3 caches are not supported by the M4K core. All fields in the *Config2* register are read-only.

Figure 5-16 Config2 Register Format — Select 2




Table 5-20 Config1 Register Field Descriptions — Select 1

Fields			Read/	
Name	Bit(s)	Description	Write	Reset State
М	31	This bit is hardwired to '1' to indicate the presence of the Config3 register.	R	1
0	30:0	These bits are reserved.	R	0

# 5.2.16 Config3 Register (CP0 Register 16, Select 3)

The Config3 register encodes additional capabilities. All fields in the Config3 register are read-only.

Figure 5-17 shows the format of the *Config3* register; Table 5-21 describes the *Config3* register fields.

Figure 5-17 Config3 Register Format



**Table 5-21 Config3 Register Field Descriptions** 

Fie	lds		Read/	
Name	Bits	Description	Write	Reset State
M	31	This bit is reserved to indicate that a Config4 register is present. With the current architectural definition, this bit should always read as a 0.	R	0
0	30:7,3:2	Must be written as zeros; returns zeros on read	0	0
		Support for an external interrupt controller is implemented.		
		<b>Encoding</b> Meaning		
LIFLG		O Support for EIC interrupt mode is not implemented		Externally Set
VEIC	6	1 Support for EIC interrupt mode is implemented	R	
		The value of this bit is set by the static input, <i>SI_EICPresent</i> . This allows external logic to communicate whether an external interrupt controller is attached to the processor or not.		
		Vectored interrupts implemented. This bit indicates whether vectored interrupts are implemented.		
		<b>Encoding</b> Meaning		0 0 Externally Set
VInt	5	0 Vector interrupts are not implemented	R	1
		1 Vectored interrupts are implemented		
		On the M4K core, this bit is always a 1 since vectored interrupts are implemented.		
		Small (1KByte) page support is implemented, and the <i>PageGrain</i> register exists. This bit will always read as 0 on the M4K core, since no TLB is present.		
SP	4	<b>Encoding</b> Meaning	R	Preset
		0 Small page support is not implemented		
		1 Small page support is implemented		

**Table 5-21 Config3 Register Field Descriptions** 

Fields					Read/			
Name	Bits		Description		Write	Reset State		
SM	1	whether the S	ASE implemented. This bit indica martMIPS ASE is implemented. S s not present on the M4K core, this b	ince	R	0		
SIVI	1	Encoding	Meaning	]	K	U		
				0	SmartMIPS ASE is not implemented			
		1	SmartMIPS ASE is implemented	]				
TL	0		mplemented. This bit indicates who ce is implemented.  Meaning  Trace logic is not implemented  Trace logic is implemented	ether	R	Preset		

### 5.2.17 *Debug* Register (CP0 Register 23, Select 0)

The *Debug* register is used to control the debug exception and provide information about the cause of the debug exception and when re-entering at the debug exception vector due to a normal exception in debug mode. The read only information bits are updated every time the debug exception is taken or when a normal exception is taken when already in debug mode.

Only the DM bit and the EJTAGver field are valid when read from non-debug mode; the values of all other bits and fields are UNPREDICTABLE. Operation of the processor is UNDEFINED if the *Debug* register is written from non-debug mode.

Some of the bits and fields are only updated on debug exceptions and/or exceptions in debug mode, as shown below:

- DSS, DBp, DDBL, DDBS, DIB, DINT are updated on both debug exceptions and on exceptions in debug modes
- DExcCode is updated on exceptions in debug mode, and is undefined after a debug exception
- · Halt and Doze are updated on a debug exception, and are undefined after an exception in debug mode
- DBD is updated on both debug and on exceptions in debug modes

All bits and fields are undefined when read from normal mode, except those explicitly described to be defined, e.g. EJTAGver and DM.

31 30 29 28 27 26 25 24 23 22 21 20 19 DBD DM LSNM Doze Halt CountDM IBusEP MCheckP CacheEP DBusEP NoDCR **IEXI** DDBSImpr 18 **17** 15 14 10 9 8 7 6 5 4 3 2 1 DDBLImpr NoSSt SSt DINT DIB DDBS DDBL DBp DSS Ver DExcCode R

Figure 5-18 Debug Register Format

Table 5-22 Debug Register Field Descriptions

Fields				
Name	Bit(s)	Description	Read/ Write	Reset State
DBD	31	Indicates whether the last debug exception or exception in debug mode, occurred in a branch delay slot:  0: Not in delay slot 1: In delay slot	R	Undefined
DM	30	Indicates that the processor is operating in debug mode:  0: Processor is operating in non-debug mode  1: Processor is operating in debug mode	R	0
NoDCR	29	Indicates whether the dseg memory segment is present and the Debug Control Register is accessible:  0: dseg is present 1: No dseg present	R	0

**Table 5-22** *Debug* **Register Field Descriptions** (Continued)

Fields			- N		
Name	Bit(s)	Description	Read/ Write	Reset State	
LSNM	28	Controls access of load/store between dseg and main memory:  0: Load/stores in dseg address range goes to dseg. 1: Load/stores in dseg address range goes to main	R/W	0	
		memory.  Indicates that the processor was in any kind of low			
Doze	27	power mode when a debug exception occurred:  0: Processor not in low power mode when debug exception occurred  1: Processor in low power mode when debug exception occurred	R	Undefined	
Halt	26	Indicates that the internal system bus clock was stopped when the debug exception occurred:  0: Internal system bus clock stopped 1: Internal system bus clock running	R	Undefined	
CountDM	25	Indicates the Count register behavior in debug mode.  0: Count register stopped in debug mode 1: Count register is running in debug mode	R/W	1	
IBusEP	24	Instruction fetch Bus Error exception Pending. Set when an instruction fetch bus error event occurs or if a 1 is written to the bit by software. Cleared when a Bus Error exception on instruction fetch is taken by the processor, and by reset. If IBusEP is set when IEXI is cleared, a Bus Error exception on instruction fetch is taken by the processor, and IBusEP is cleared.	R/W1	0	
MCheckP	23	Indicates that an imprecise Machine Check exception is pending. All Machine Check exceptions are precise on the M4K processor so this bit will always read as 0.	R	0	
CacheEP	22	Indicates that an imprecise Cache Error is pending. Cache Errors cannot be taken by the M4K core so this bit will always read as 0	R	0	
DBusEP	21	Data access Bus Error exception Pending. Covers imprecise bus errors on data access, similar to behavior of IBusEP for imprecise bus errors on an instruction fetch.	R/W1	0	
IEXI	20	Imprecise Error eXception Inhibit controls exceptions taken due to imprecise error indications. Set when the processor takes a debug exception or exception in debug mode. Cleared by execution of the DERET instruction; otherwise modifiable by debug mode software. When IEXI is set, the imprecise error exception from a bus error on an instruction fetch or data access, cache error, or machine check is inhibited and deferred until the bit is cleared.	R/W	0	
DDBSImpr	19	Indicates that an imprecise Debug Data Break Store exception was taken. All data breaks are precise on the M4K core, so this bit will always read as 0.		0	
DDBLImpr	18	Indicates that an imprecise Debug Data Break Load exception was taken. All data breaks are precise on the M4K core, so this bit will always read as 0.	R	0	

**Table 5-22** *Debug* **Register Field Descriptions** (Continued)

Fields				
Name	Bit(s)	Description	Read/ Write	Reset State
Ver	17:15	EJTAG version.	R	010
DExcCode	14:10	Indicates the cause of the latest exception in debug mode. The field is encoded as the ExcCode field in the Cause register for those normal exceptions that may occur in debug mode.	R	Undefined
		Value is undefined after a debug exception.		
NoSST	9	Indicates whether the single-step feature controllable by the SSt bit is available in this implementation:	R	0
10331		0: Single-step feature available 1: No single-step feature available	K	
		Controls if debug single step exception is enabled:		
SSt	8	No debug single-step exception enabled     Debug single step exception enabled	R/W	0
R	7:6	Reserved. Must be written as zeros; returns zeros on reads.	R	0
	5	Indicates that a debug interrupt exception occurred. Cleared on exception in debug mode.	_	
DINT		No debug interrupt exception     Debug interrupt exception	R	Undefined
DID	4	Indicates that a debug instruction break exception occurred. Cleared on exception in debug mode.	R	H 16 1
DIB		No debug instruction exception     Debug instruction exception		Undefined
DDBS	3	Indicates that a debug data break exception occurred on a store. Cleared on exception in debug mode.	R	H. 1.C. 1
ровз	3	0: No debug data exception on a store 1: Debug instruction exception on a store	K	Undefined
DDDI	2	Indicates that a debug data break exception occurred on a load. Cleared on exception in debug mode.	D	H. I.C. I
DDBL	2	No debug data exception on a load     Debug instruction exception on a load	R	Undefined
DD		Indicates that a debug software breakpoint exception occurred. Cleared on exception in debug mode.	ъ	II 1 C
DBp	1	No debug software breakpoint exception     Debug software breakpoint exception	R	Undefined
D.C.C		Indicates that a debug single-step exception occurred. Cleared on exception in debug mode.	-	
DSS	0	0: No debug single-step exception 1: Debug single-step exception	R	Undefined
		I		I

# 5.2.18 Trace Control Register (CP0 Register 23, Select 1)

The *TraceControl* register configuration is shown below. Note the special behavior of the ASID\_M, ASID, and G fields for the M4K processor.

This register is only implemented if the EJTAG Trace capability is present.

Figure 5-19 Trace Control Register Format

31 30 29 28	27 26	25 2	4 23	22 2	1 20	13	12	5 4	3 1	0
TS UT 0	TB IO	D E		S	J	ASID_M	ASID	G	Mode	On

Table 5-23 TraceControl Register Field Descriptions

Fields			Read/	
Name	Bits	Description	Write	Reset State
TS	31	The trace select bit is used to select between the hardware and the software trace control bits. A value of zero selects the external hardware trace block signals, and a value of one selects the trace control bits in this software control register.	R/W	0
UT	30	This bit is used to indicate the type of user-triggered trace record. A value of zero implies a user type 1 and a value of one implies a user type 2.  The actual triggering of a user trace record happens on a write to the <i>UserTraceData</i> register.	R/W	Undefined
0	29:28	Reserved for future use; Must be written as zero; returns zero on read.	0	0
ТВ	27	Trace All Branch. When set to one, this tells the processor to trace the PC value for all taken branches, not just the ones whose branch target address is statically unpredictable.	R/W	Undefined
Ю	26	Inhibit Overflow. This signal is used to indicate to the core trace logic that slow but complete tracing is desired. When set to one, the core tracing logic does not allow a FIFO overflow or discard trace data. This is achieved by stalling the pipeline when the FIFO is nearly full, so that no trace records are ever lost.	R/W	Undefined
D	25	When set to one, this enables tracing in Debug Mode (see Section 8.7.1, "Processor Modes" on page 167). For trace to be enabled in Debug mode, the On bit must be one, and either the G bit must be one, or the current process ASID must match the ASID field in this register.	R/W	Undefined
		When set to zero, trace is disabled in Debug Mode, irrespective of other bits.		

 Table 5-23 TraceControl Register Field Descriptions (Continued)

Fields			Read/	
Name	Bits	Description	Write	Reset State
Е	24	When set to one, this enables tracing in Exception Mode (see Section 8.7.1, "Processor Modes" on page 167). For trace to be enabled in Exception mode, the On bit must be one, and either the G bit must be one, or the current process ASID must match the ASID field in this register.  When set to zero, trace is disabled in Exception Mode, irrespective of other bits.	R/W	Undefined
K	23	When set to one, this enables tracing in Kernel Mode (see Section 8.7.1, "Processor Modes" on page 167). For trace to be enabled in Kernel mode, the On bit must be one, and either the G bit must be one, or the current process ASID must match the ASID field in this register.  When set to zero, trace is disabled in Kernel Mode, irrespective of other bits.	R/W	Undefined
0	22	This bit is reserved. Must be written as zero; returns zero on read.	0	0
U	21	When set to one, this enables tracing in User Mode (see Section 8.7.1, "Processor Modes" on page 167). For trace to be enabled in User mode, the On bit must be one, and either the G bit must be one, or the current process ASID must match the ASID field in this register.  When set to zero, trace is disabled in User Mode, irrespective of other bits.	R/W	Undefined
ASID_M	20:13	This is a mask value applied to the ASID comparison (done when the G bit is zero). A "1" in any bit in this field inhibits the corresponding ASID bit from participating in the match. As such, a value of zero in this field compares all bits of ASID. Note that the ability to mask the ASID value is not available in the hardware signal bit; it is only available via the software control register.  In the M4K core where ASID is not supported, this field is ignored on write and returns zero on read.	R/W	0
ASID	12:5	The ASID field to match when the G bit is zero. When the G bit is one, this field is ignored.  In the M4K core where ASID is not supported, this field is ignored on write and returns zero on read.	R/W	0
G	4	Global bit. When set to one, tracing is to be enabled for all processes, provided that other enabling functions (like U, S, etc.,) are also true.  In the M4K core where ASID is not supported, this field is ignored on write and returns 1 on read. This causes all match equations to work correctly in the absence of an ASID.	R/W	0

Table 5-23 TraceControl Register Field Descriptions (Continued)

Fie	elds			Read/	
Name	Bits		Description	Write	Reset State
		These thre	be bits control the trace mode function.		
		Mode	Trace Mode		
		000	Trace PC		
		001	Trace PC and load address		
		010	Trace PC and store address		Undefined
		011	Trace PC and both load/store addresses	R/W	
		100	Trace PC and load data		
Mode	3:1	101	Trace PC and load address and data		
		110	Trace PC and store address and data		
		111	Trace PC and both load/store address and data		
		operation	Control2 <sub>ValidModes</sub> field determines which of dings are supported by the processor. The of the processor is <b>UNPREDICTABLE</b> if s set to a value which is not supported by the		
On	0	control. W set to one,	master trace enable switch in software Then zero, tracing is always disabled. When tracing is enabled whenever the other unctions are also true.	R/W	0

# 5.2.19 *Trace Control2* Register (CP0 Register 23, Select 2)

The *TraceControl2* register provides additional control and status information. Note that some fields in the *TraceControl2* register are read-only, but have a reset state of "Undefined". This is because these values are loaded from the Trace Control Block (TCB) (see Section 8.9, "Trace Control Block (TCB) Registers (hardware control)" on page 171). As such, these fields in the *TraceControl2* register will not have valid values until the TCB asserts these values.

This register is only implemented if the EJTAG Trace capability is present.

Figure 5-20 Trace Control2 Register Format




Table 5-24 TraceControl2 Register Field Descriptions

Field	ls			Read/			
Name	Bits		Description	Write	Reset State		
0	31:5	Reserved for returns zero	future use; Must be written as zero; on read.	0	0		
			ecifies the type of tracing that is supported ssor, as follows:	d			
		Encoding	Meaning				
77 11 13 6 1		00	PC tracing only		10		
ValidModes	6:5	01	PC and load and store address tracing only	R	10		
				10	PC, load and store address, and load and store data		
		11	Reserved				
			cates how many trace buffers are I by the TCB, as follows:				
		Encoding	Meaning				
ТВІ	4	4	0	Only one trace buffer is implemented, and the TBU bit of this register indicates which trace buffer is implemented	R	Per implementati on	
		1	Both on-chip and off-chip trace buffers are implemented by the TCB and the TBU bit of this register indicates to which trace buffer the trace is currently written.				
			the trace is currently written.				

Table 5-24 TraceControl2 Register Field Descriptions (Continued)

Fields						Read/	
Name	Bits		Description		Write	Reset State	
		currently bei	otes to which trace ng written and is us nterpretation of the	sed to select the			
TBU	3	Encoding	Me	aning		R	Undefined
		0	Trace data is being s buffer	ent to an on-chip trace	e		Chachinea
		1	Trace Data is being s buffer	ent to an off-chip trac	е		
SyP	2:0	SyP		Off-chip  2 <sup>7</sup> 2 <sup>8</sup> 2 <sup>9</sup> 2 <sup>10</sup> 2 <sup>11</sup> 2 <sup>12</sup>		R	Undefined
		110	28	2 <sup>13</sup>	1		
		111	29	214	]		
		data is being TraceControl column is use	written to an on-chil2 $_{TBU} = 0$ ). Converged when the trace of	used when the trac ip trace buffer (e.g sely, the "Off-chip" ata is being writter aceControl2 <sub>TBU</sub> = 1	; i to		

# 5.2.20 User Trace Data Register (CP0 Register 23, Select 3)

A software write to any bits in the *UserTraceData* register will trigger a trace record to be written indicating a type 1 or type 2 user format. The type is based on the UT bit in the *TraceControl* register. This register cannot be written in consecutive cycles. The trace output data is UNPREDICTABLE if this register is written in consecutive cycles.

This register is only implemented if the EJTAG Trace capability is present.

Figure 5-21 User Trace Data Register Format




Table 5-25 UserTraceData Register Field Descriptions

Fields			Read/	
Name	Bits	Description	Write	Reset State
Data	31:0	Software readable/writable data. When written, this triggers a user format trace record out of the PDtrace interface that transmits the Data field to trace memory.	R/W	0

# 5.2.21 TraceBPC Register (CP0 Register 23, Select 4)

This register is used to control start and stop of tracing using an EJTAG Hardware breakpoint. The Hardware breakpoint would then be set as a trigger source and optionally also as a Debug exception breakpoint.

This register is only implemented if both Hardware breakpoints and the EJTAG Trace capability are present.

Figure 5-22 Trace BPC Register Format




Table 5-26 TraceBPC Register Field Descriptions

Fields			Read/	
Name	Bits	Description	Write	Reset State
DE	31	Used to specify whether the trigger signal from EJTAG data breakpoint should trigger tracing functions or not:  0: disables trigger signals from data breakpoints  1: enables trigger signals from data breakpoints	R/W	0
0	30:18	Reserved	0	0
DBPOn	30:16	Each of the 2 bits corresponds to the 2 possible EJTAG hardware data breakpoints that may be implemented. For example, bit 16 corresponds to the first data breakpoint. If 2 data breakpoints are present in the EJTAG implementation, then they correspond to bits 16 and 17. The rest are always ignored by the tracing logic since they will never be triggered.  A value of one for each bit implies that a trigger from the corresponding data breakpoint should start tracing. And a value of zero implies that tracing should be turned off with the trigger signal.	R/W	0
IE	15	Used to specify whether the trigger signal from EJTAG instruction breakpoint should trigger tracing functions or not:  0: disables trigger signals from instruction breakpoints 1: enables trigger signals from instruction breakpoints	R/W	0
0	14:4	Reserved	0	0
IBPOn	3:0	Each of the 4 bits corresponds to the 4 possible EJTAG hardware instruction breakpoints that may be implemented. Bit 0 corresponds to the first instruction breakpoint, and so on. If only 2 instruction breakpoints are present in the EJTAG implementation, then only bits 0 and 1 are used. The rest are always ignored by the tracing logic since they will never be triggered.  A value of one for each bit implies that a trigger from the corresponding instruction breakpoint should start tracing. And a value of zero implies that tracing should be turned off with the trigger signal.	R/W	0

### 5.2.22 Debug Exception Program Counter Register (CP0 Register 24, Select 0)

The Debug Exception Program Counter (*DEPC*) register is a read/write register that contains the address at which processing resumes after a debug exception or debug mode exception has been serviced.

For synchronous (precise) debug and debug mode exceptions, the *DEPC* contains either:

- The virtual address of the instruction that was the direct cause of the debug exception, or
- The virtual address of the immediately preceding branch or jump instruction, when the debug exception causing instruction is in a branch delay slot, and the Debug Branch Delay (DBD) bit in the *Debug* register is set.

For asynchronous debug exceptions (debug interrupt), the *DEPC* contains the virtual address of the instruction where execution should resume after the debug handler code is executed.

In processors that implement the MIPS16 ASE, a read of the DEPC register (via MFC0) returns the following value in the destination GPR:

```
GPR[rt] \leftarrow DebugExceptionPC_{31...1} | ISAMode_0
```

That is, the upper 31 bits of the debug exception PC are combined with the lower bit of the ISAMode field and written to the GPR.

Similarly, a write to the DEPC register (via MTC0) takes the value from the GPR and distributes that value to the debug exception PC and the ISAMode field, as follows

```
DebugExceptionPC \leftarrow GPR[rt]<sub>31..1</sub> || 0 ISAMode \leftarrow 2#0 || GPR[rt]<sub>0</sub>
```

That is, the upper 31 bits of the GPR are written to the upper 31 bits of the debug exception PC, and the lower bit of the debug exception PC is cleared. The upper bit of the ISAMode field is cleared and the lower bit is loaded from the lower bit of the GPR.

Figure 5-23 DEPC Register Format



Table 5-27 DEPC Register Formats

Fields			Read/	
Name	Bit(s)	Description	Write	Reset
DEPC	31:0	The <i>DEPC</i> register is updated with the virtual address of the instruction that caused the debug exception. If the instruction is in the branch delay slot, then the virtual address of the immediately preceding branch or jump instruction is placed in this register.  Execution of the DERET instruction causes a jump to the address in the <i>DEPC</i> .	R/W	Undefined

### 5.2.23 ErrorEPC (CP0 Register 30, Select 0)

The *ErrorEPC* register is a read/write register, similar to the *EPC* register, except that *ErrorEPC* is used on error exceptions. All bits of the *ErrorEPC* register are significant and must be writable. It is also used to store the program counter on Reset, Soft Reset, and nonmaskable interrupt (NMI) exceptions.

The *ErrorEPC* register contains the virtual address at which instruction processing can resume after servicing an error. This address can be:

- The virtual address of the instruction that caused the exception
- The virtual address of the immediately preceding branch or jump instruction when the error causing instruction is in a branch delay slot

Unlike the EPC register, there is no corresponding branch delay slot indication for the ErrorEPC register.

In processors that implement the MIPS16 ASE, a read of the ErrorEPC register (via MFC0) returns the following value in the destination GPR:

```
GPR[rt] \leftarrow ErrorExceptionPC_{31...1} | ISAMode_0
```

That is, the upper 31 bits of the error exception PC are combined with the lower bit of the ISAMode field and written to the GPR.

Similarly, a write to the ErrorEPC register (via MTC0) takes the value from the GPR and distributes that value to the error exception PC and the ISAMode field, as follows

```
 \begin{split} & \texttt{ErrprExceptionPC} \leftarrow \texttt{GPR[rt]}_{31..1} \ || \ \texttt{0} \\ & \texttt{ISAMode} \leftarrow \texttt{2\#0} \ || \ \texttt{GPR[rt]}_{\texttt{0}} \end{aligned}
```

That is, the upper 31 bits of the GPR are written to the upper 31 bits of the error exception PC, and the lower bit of the error exception PC is cleared. The upper bit of the ISAMode field is cleared and the lower bit is loaded from the lower bit of the GPR.

Figure 5-24 ErrorEPC Register Format



Table 5-28 ErrorEPC Register Field Description

Fields			Read/	
Name	Bit(s)	Description	Write	Reset State
ErrorEPC	31:0	Error Exception Program Counter.	R/W	Undefined

# 5.2.24 *DeSave* Register (CP0 Register 31, Select 0)

The Debug Exception Save (*DeSave*) register is a read/write register that functions as a simple memory location. This register is used by the debug exception handler to save one of the GPRs that is then used to save the rest of the context to a pre-determined memory area (such as in the EJTAG Probe). This register allows the safe debugging of exception handlers and other types of code where the existence of a valid stack for context saving cannot be assumed.

Figure 5-25 DeSave Register Format



Table 5-29 DeSave Register Field Description

Fields			D 4/	
Name	Bit(s)	Description	Read/ Write	Reset State
DESAVE	31:0	Debug exception save contents.	R/W	Undefined

#### Chapter 6

# Hardware and Software Initialization of the M4K<sup>TM</sup> Core

A M4K<sup>TM</sup> processor core contains only a minimal amount of hardware initialization and relies on software to fully initialize the device.

This chapter contains the following sections:

- Section 6.1, "Hardware-Initialized Processor State"
- Section 6.2, "Software Initialized Processor State"

#### 6.1 Hardware-Initialized Processor State

A M4K processor core, like most other MIPS processors, is not fully initialized by hardware reset. Only a minimal subset of the processor state is cleared. This is enough to bring the core up while running in unmapped and uncached code space. All other processor state can then be initialized by software. *SI\_ColdReset* is asserted after power-up to bring the device into a known state. Soft reset can be forced by asserting the *SI\_Reset* pin. This distinction is made for compatibility with other MIPS processors. In practice, both resets are handled identically with the exception of the setting of *Status\_SR*.

#### 6.1.1 Coprocessor 0 State

Much of the hardware initialization occurs in Coprocessor 0.

- Status<sub>REV</sub> cleared to 1 on Reset/SoftReset
- Status<sub>TS</sub> cleared to 0 on Reset/SoftReset
- Status<sub>SR</sub> cleared to 0 on Reset, set to 1 on SoftReset
- Status<sub>NMI</sub> cleared to 0 on Reset/SoftReset
- Status<sub>ERL</sub> set to 1 on Reset/SoftReset
- Status<sub>RP</sub> cleared to 0 on Reset/SoftReset
- Config fields related to static inputs set to input value by Reset/SoftReset
- Config<sub>K0</sub> set to 010 (uncached) on Reset/SoftReset
- ConfigKU set to 010 (uncached) on Reset/SoftReset
- Config<sub>K23</sub> set to 010 (uncached) on Reset/SoftReset
- *DebugDM* cleared to 0 on Reset/SoftReset (unless EJTAGBOOT option is used to boot into DebugMode, see Chapter 8, "EJTAG Debug Support in the M4K<sup>TM</sup> Core." for details)
- *Debug<sub>LSNM</sub>* cleared to 0 on Reset/SoftReset
- Debug<sub>IBusEP</sub> cleared to 0 on Reset/SoftReset
- Debug<sub>DRusEP</sub> cleared to 0 on Reset/SoftReset
- *Debug<sub>IEXI</sub>* cleared to 0 on Reset/SoftReset
- Debug<sub>SSt</sub> cleared to 0 on Reset/SoftReset

#### **6.1.2** Bus State Machines

All pending bus transactions are aborted and the state machines in the SRAM interface unit are reset when a Reset or SoftReset exception is taken.

#### **6.1.3 Static Configuration Inputs**

All static configuration inputs should only be changed during Reset.

#### 6.1.4 Fetch Address

Upon Reset/SoftReset, unless the EJTAGBOOT option is used, the fetch is directed to VA 0xBFC00000 (PA 0x1FC00000). This address is in KSeg1,which is unmapped and uncached.

### **6.2 Software Initialized Processor State**

Software is required to initialize the following parts of the device.

# 6.2.1 Register File

The register file powers up in an unknown state with the exception of r0 which is always 0. Initializing the rest of the register file is not required for proper operation. Good code will generally not read a register before writing to it, but the boot code can initialize the register file for added safety.

#### 6.2.2 Coprocessor 0 State

Miscellaneous COP0 states need to be initialized prior to leaving the boot code. There are various exceptions which are blocked by ERL=1 or EXL=1 and which are not cleared by Reset. These can be cleared to avoid taking spurious exceptions when leaving the boot code.

- Cause: WP (Watch Pending), SW0/1 (Software Interrupts) should be cleared.
- *Config*: Typically, the K0, KU and K23 fields should be set to the desired Cache Coherency Algorithm (CCA) value prior to accessing the corresponding memory regions. But in the M4K core, all CCA values are treated identically, so the hardware reset value of these fields need not be modified.
- Count: Should be set to a known value if Timer Interrupts are used.
- *Compare*: Should be set to a known value if Timer Interrupts are used. The write to compare will also clear any pending Timer Interrupts (Thus, *Count* should be set before *Compare* to avoid any unexpected interrupts).
- Status: Desired state of the device should be set.
- Other COP0 state: Other registers should be written before they are read. Some registers are not explicitly writeable, and are only updated as a by-product of instruction execution or a taken exception. Uninitialized bits should be masked off after reading these registers.

# Power Management of the M4K<sup>TM</sup> Core

A M4K<sup>TM</sup> processor coreoffers a number of power management features, including low-power design, active power management and power-down modes of operation. The core is a static design that supports a WAIT instruction designed to signal the rest of the device that execution and clocking should be halted, reducing system power consumption during idle periods.

The core provides two mechanisms for system level low-power support discussed in the following sections.

- Section 7.1, "Register-Controlled Power Management"
- Section 7.2, "Instruction-Controlled Power Management"

# 7.1 Register-Controlled Power Management

The RP bit in the CP0 *Status* register enables a standard software mechanism for placing the system into a low power state. The state of the RP bit is available externally via the *SI\_RP* output signal. Three additional pins, *SI\_EXL*, *SI\_ERL*, and *EJ\_DebugM* support the power management function by allowing the user to change the power state if an exception or error occurs while the core is in a low power state.

Setting the RP bit of the CP0 *Status* register causes the core to assert the *SI\_RP* signal. The external agent can then decide whether to reduce the clock frequency and place the core into power down mode.

If an interrupt is taken while the device is in power down mode, that interrupt may need to be serviced depending on the needs of the application. The interrupt causes an exception which in turn causes the EXL bit to be set. The setting of the EXL bit causes the assertion of the  $SI\_EXL$  signal on the external bus, indicating to the external agent that an interrupt has occurred. At this time the external agent can choose to either speed up the clocks and service the interrupt or let it be serviced at the lower clock speed.

The setting of the ERL bit causes the assertion of the *SI\_ERL* signal on the external bus, indicating to the external agent that an error has occurred. At this time the external agent can choose to either speed up the clocks and service the error or let it be serviced at the lower clock speed.

Similarly, the *EJ\_DebugM* signal indicates that the processor is in debug mode. Debug mode is entered when the processor takes a debug exception. If fast handling of this is desired, the external agent can speed up the clocks.

The core provides four power down signals that are part of the system interface. Three of the pins change state as the corresponding bits in the CPO *Status* register are set or cleared. The fourth pin indicates that the processor is in debug mode:

- The SI\_RP signal represents the state of the RP bit (27) in the CP0 Status register.
- The SI\_EXL signal represents the state of the EXL bit (1) in the CPO Status register.
- The SI\_ERL signal represents the state of the ERL bit (2) in the CPO Status register.
- The *EJ\_DebugM* signal indicates that the processor has entered debug mode.

## 7.2 Instruction-Controlled Power Management

The second mechanism for invoking power down mode is through execution of the WAIT instruction. If the bus is idle at the time the WAIT instruction reaches the M stage of the pipeline the internal clocks are suspended and the pipeline is frozen. However, the internal timer and some of the input pins ( $SI\_Int[5:0]$ ,  $SI\_NMI$ ,  $SI\_Reset$ ,  $SI\_ColdReset$ , and  $EJ\_DINT$ ) continue to run. If the bus is not idle at the time the WAIT instruction reaches the M stage, the pipeline stalls until the bus becomes idle, at which time the clocks are stopped. Once the CPU is in instruction controlled power management mode, any enabled interrupt, NMI, debug interrupt, or reset condition causes the CPU to exit this mode and resume normal operation. While the part is in this low-power mode, the  $SI\_SLEEP$  signal is asserted to indicate to external agents what the state of the chip is.

# EJTAG Debug Support in the M4K<sup>TM</sup> Core

The EJTAG debug logic in the M4K<sup>TM</sup> processor core provides three optional modules:

- 1. Hardware breakpoints
- 2. Test Access Port (TAP) for a dedicated connection to a debug host
- 3. EJTAG Trace for program counter/data address/data value trace to On-chip memory or to Trace probe.

### This chapter contains the following sections:

- Section 8.1, "Debug Control Register" on page 130
- Section 8.2, "Hardware Breakpoints" on page 132
- Section 8.3, "Test Access Port (TAP)" on page 151
- Section 8.4, "EJTAG TAP Registers" on page 158
- Section 8.5, "TAP Processor Accesses" on page 167
- Section 8.7, "EJTAG Trace" on page 168
- Section 8.8, "PDtrace<sup>TM</sup> Registers (software control)" on page 172
- Section 8.9, "Trace Control Block (TCB) Registers (hardware control)" on page 173
- Section 8.10, "EJTAG Trace Enabling" on page 187
- Section 8.11, "TCB Trigger logic" on page 189
- Section 8.12, "EJTAG Trace cycle-by-cycle behavior" on page 192
- Section 8.13, "TCB On-Chip Trace Memory" on page 194

# 8.1 Debug Control Register

The Debug Control Register (*DCR*) register controls and provides information about debug issues, and is always provided with the CPU core. The register is memory-mapped in drseg at offset 0x0.

The DataBrk and InstBrk bits indicate if hardware breakpoints are included in the implementation, and debug software is expected to read hardware breakpoint registers for additional information.

Hardware and software interrupts are maskable for non-debug mode with the INTE bit, which works in addition to the other mechanisms for interrupt masking and enabling. NMI is maskable in non-debug mode with the NMIE bit, and a pending NMI is indicated through the NMIP bit.

The SRE bit allows implementation dependent masking of none, some or all sources for soft reset. The soft reset masking may only be applied to a soft reset source if that source can be efficiently masked in the system, thus resulting in no reset at all. If that is not possible, then that soft reset source should not be masked, since a partial soft reset may cause the system to fail or hang. There is no automatic indication of whether the SRE is effective, so the user must consult system documentation.

The PE bit reflects the ProbEn bit from the EJTAG Control register (*ECR*), whereby the probe can indicate to the debug software running on the CPU if the probe expects to service dmseg accesses. The reset value in the table below takes effect on both hard and soft resets.

#### **Debug Control Register** 28 18 17 16 15 5 0 31 30 29 3 2 INTE NMIE NMIP SRE Res **ENM** Res DB IΒ Res PE

Table 8-1 Debug Control Register Field Descriptions

Fields			Read/	
Name	Bit(s)	Description	Write	Reset State
Res	31:30	Reserved	R	0
ENM	29	Endianess in Kernel and Debug mode.  0: Little Endian 1: Big Endian	R	Preset
Res	28:18	Reserved	R	0
DB	17	Data Break Implemented.  0: No Data Break feature implemented 1: Data Break feature is implemented	R	Preset
IB	16	Instruction Break Implemented.  0: No Instruction Break feature implemented 1: Instruction Break feature is implemented	R	Preset
Res	15:5	Reserved	R	0

Table 8-1 Debug Control Register Field Descriptions (Continued)

Fields			Read/	
Name	Bit(s)	Description	Write	Reset State
INTE	4	Interrupt Enable in Normal Mode. This bit provides the hardware and software interrupt enable for non-debug mode, in addition to other masking mechanisms:  0: Interrupts disabled. 1: Interrupts enabled (depending on other enabling mechanisms).	R/W	1
NMIE	3	Non-Maskable Interrupt Enable for non-debug mode  0: NMI disabled. 1: NMI enabled.	R/W	1
NMIP	2	NMI Pending Indication.  0: No NMI pending. 1: NMI pending.	R	0
SRE	1	Soft Reset Enable  This bit allows the system to mask soft resets. The core does not internally mask soft resets. Rather the state of this bit appears on the <i>EJ_SRstE</i> external output signal, allowing the system to mask soft resets if desired.	R/W	1
PE	0	Probe Enable This bit reflects the ProbEn bit in the EJTAG Control register.  0: No accesses to dmseg allowed 1: EJTAG probe services accesses to dmseg	R	Same value as ProbEn in ECR (see Table 9-4)

## 8.2 Hardware Breakpoints

Hardware breakpoints provide for the comparison by hardware of executed instructions and data load/store transactions. It is possible to set instruction breakpoints on addresses even in ROM area,. Data breakpoints can be set to cause a debug exception on a specific data transaction. Instruction and data hardware breakpoints are alike for many aspects, and are thus described in parallel in the following. The term hardware is not applied to breakpoint, unless required to distinguish it from software breakpoint.

There are two types of simple hardware breakpoints implemented in the M4K core; Instruction breakpoints and Data breakpoints.

A core may be configured with the following breakpoint options:

- No data or instruction breakpoints
- · Two instruction and one data breakpoint
- Four instruction and two data breakpoints

## 8.2.1 Features of Instruction Breakpoint

Instruction breaks occur on instruction fetch operations and the break is set on the virtual address on the bus between the CPU and the instruction cache. Finally, a mask can be applied to the virtual address to set breakpoints on a range of instructions.

Instruction breakpoints compare the virtual address of the executed instructions (PC) with the registers for each instruction breakpoint including masking of address. When an instruction breakpoint matches, a debug exception and/or a trigger is generated. An internal bit in the instruction breakpoint registers is set to indicate that the match occurred.

#### **8.2.2** Features of Data Breakpoint

Data breakpoints occur on load/store transactions. Breakpoints are set on virtual address and ASID values, similar to the Instruction breakpoint. Data breakpoints can be set on a load, a store or both. Data breakpoints can also be set based on the value of the load/store operation. Finally, masks can be applied to both the virtual address and the load/store value.

Data breakpoints compare the transaction type (TYPE), which may be load or store, the virtual address of the transaction (ADDR), accessed bytes (BYTELANE) and data value (DATA), with the registers for each data breakpoint including masking or qualification on the transaction properties. When a data breakpoint matches, a debug exception and/or a trigger is generated, and an internal bit in the data breakpoint registers is set to indicate that the match occurred. The match is precise in that the debug exception or trigger occurs on the instruction that caused the breakpoint to match.

## 8.2.3 Instruction Breakpoint Registers Overview

The register with implementation indication and status for instruction breakpoints in general is shown in Table 8-2.

**Table 8-2 Overview of Status Register for Instruction Breakpoints** 

Register Mnemonic	Register Name and Description	
IBS	Instruction Breakpoint Status	

The four instruction breakpoints are numbered 0 to 3 for registers and breakpoints, and the number is indicated by n. The registers for each breakpoint are shown in Table 8-3.

Table 8-3 Overview of Registers for Each Instruction Breakpoint

Register Mnemonic	Register Name and Description	
IBAn	Instruction Breakpoint Address n	
IBMn	Instruction Breakpoint Address Mask n	
IBASIDn	Instruction Breakpoint ASID n	
IBCn	Cn Instruction Breakpoint Control n	

# 8.2.4 Data Breakpoint Registers Overview

The register with implementation indication and status for data breakpoints in general is shown in Table 8-4.

Table 8-4 Overview of Status Register for Data Breakpoints

Register Mnemonic	Register Name and Description	
DBS	Data Breakpoint Status	

The two data breakpoints are numbered 0 and 1 for registers and breakpoints, and the number is indicated by n. The registers for each breakpoint are shown in Table 8-5.

Table 8-5 Overview of Registers for each Data Breakpoint

Register Mnemonic	Register Name and Description	
DBAn	Data Breakpoint Address n	
DBMn	ata Breakpoint Address Mask n	
DBASIDn	Data Breakpoint ASID n	
DBCn	DBCn Data Breakpoint Control n	
DBVn	DBVn Data Breakpoint Value n	

## 8.2.5 Conditions for Matching Breakpoints

A number of conditions must be fulfilled in order for a breakpoint to match on an executed instruction or a data transaction, and the conditions for matching instruction and data breakpoints are described below. The breakpoints only match for instructions executed in non-debug mode, thus never on instructions executed in debug mode.

The match of an enabled breakpoint can either generate a debug exception or a trigger indication. The BE and/or TE bits in the *IBCn* or *DBCn* registers are used to enable the breakpoints.

Debug software should not configure breakpoints to compare on an ASID value unless a TLB is present in the implementation.

#### 8.2.5.1 Conditions for Matching Instruction Breakpoints

When an instruction breakpoint is enabled, that breakpoint is evaluated for the address of every executed instruction in non-debug mode, including execution of instructions at an address causing an address error on an instruction fetch. The breakpoint is not evaluated on instructions from a speculative fetch or execution, nor for addresses which are unaligned with an executed instruction.

A breakpoint match depends on the virtual address of the executed instruction (PC) which can be masked at bit level. The registers for each instruction breakpoint have the values and mask used in the compare, and the equation that determines the match is shown below in C-like notation.

```
\label{eq:ibmn} \mbox{IB\_match} = & ( \mbox{<all 1's>} == ( \mbox{$IBMn_{\rm IBM}$} \mid \sim ( \mbox{ PC $^{\mbox{}}$} \mbox{$IBAn_{\rm IBA}$} ) ) )
```

The match indication for instruction breakpoints is always precise, i.e. indicated on the instruction causing the IB\_match to be true.

### 8.2.5.2 Conditions for Matching Data Breakpoints

When a data breakpoint is enabled, that breakpoint is evaluated for every data transaction due to a load/store instruction executed in non-debug mode, including load/store for coprocessor, and transactions causing an address error on data access. The breakpoint is not evaluated due to a PREF instruction or other transactions which are not part of explicit load/store transactions in the execution flow, nor for addresses which are not the explicit load/store source or destination address.

A breakpoint match depends on the transaction type (TYPE) as load or store, the address, and optionally the data value of a transaction. The registers for each data breakpoint have the values and mask used in the compare, and the equation that determines the match is shown below in C-like notation.

The overall match equation is the DB match.

The match on the address part, DB\_addr\_match, depends on the virtual address of the transaction (ADDR), the ASID value, and the accessed bytes (BYTELANE) where BYTELANE[0] is 1 only if the byte at bits [7:0] on the bus is accessed, and BYTELANE[1] is 1 only if the byte at bits [15:8] is accessed, etc. The DB\_addr\_match is shown below.

The size of  $DBCn_{BAI}$  and BYTELANE is 4 bits.

Data value compare is included in the match condition for the data breakpoint depending on the bytes (BYTELANE as described above) accessed by the transaction, and the contents of breakpoint registers. The DB\_no\_value\_compare is shown below.

```
DB_no_value_compare =  ( <all 1's> == ( DBCn_{BIM} \mid DBCn_{BAT} \mid \sim BYTELANE ) ) )
```

The size of  $DBCn_{BLM}$ ,  $DBCn_{BAI}$  and BYTELANE is 4 bits.

In case a data value compare is required, DB\_no\_value\_compare is false, then the data value from the data bus (DATA) is compared and masked with the registers for the data breakpoint. The endianess is not considered in these match equations for value, as the compare uses the data bus value directly, thus debug software is responsible for setup of the breakpoint corresponding with endianess.

```
 \begin{split} \text{DB\_value\_match} &= \\ & ( \ ( \ \text{DATA}[7:0] \ == \ DBVn_{\text{DBV}[7:0]} \ ) \ | \ | \ ! \ \text{BYTELANE}[0] \ | \ DBCn_{\text{BLM}[0]} \ | \ DBCn_{\text{BAI}[0]} \ ) \ \&\& \\ & ( \ ( \ \text{DATA}[15:8] \ == \ DBVn_{\text{DBV}[15:8]} \ ) \ | \ | \ ! \ \text{BYTELANE}[1] \ | \ DBCn_{\text{BLM}[1]} \ | \ DBCn_{\text{BAI}[1]} \ ) \ \&\& \\ & ( \ ( \ \text{DATA}[23:16] \ == \ DBVn_{\text{DBV}[23:16]} \ ) \ | \ | \ ! \ \text{BYTELANE}[2] \ | \ DBCn_{\text{BLM}[2]} \ | \ DBCn_{\text{BAI}[2]} \ ) \&\& \\ & ( \ ( \ \text{DATA}[31:24] \ == \ DBVn_{\text{DBV}[31:24]} \ ) \ | \ | \ ! \ \text{BYTELANE}[3] \ | \ DBCn_{\text{BLM}[3]} \ | \ DBCn_{\text{BAI}[3]} \ ) \end{aligned}
```

The match for a data breakpoint is always precise, since the match expression is fully evaluated at the time the load/store instruction is executed. A true DB\_match can thereby be indicated on the very same instruction causing the DB\_match to be true.

## 8.2.6 Debug Exceptions from Breakpoints

Instruction and data breakpoints may be set up to generate a debug exception when the match condition is true, as described below.

### 8.2.6.1 Debug Exception by Instruction Breakpoint

If the breakpoint is enabled by BE bit in the *IBCn* register, then a debug instruction break exception occurs if the IB\_match equation is true. The corresponding BS[n] bit in the *IBS* register is set when the breakpoint generates the debug exception.

The debug instruction break exception is always precise, so the *DEPC* register and DBD bit in the *Debug* register point to the instruction that caused the IB\_match equation to be true.

The instruction receiving the debug exception does not update any registers due to the instruction, nor does any load or store by that instruction occur. Thus a debug exception from a data breakpoint can not occur for instructions receiving a debug instruction break exception.

The debug handler usually returns to the instruction causing the debug instruction break exception, whereby the instruction is executed. Debug software is responsible for disabling the breakpoint when returning to the instruction, otherwise the debug instruction break exception reoccurs.

#### 8.2.6.2 Debug Exception by Data Breakpoint

If the breakpoint is enabled by BE bit in the *DBCn* register, then a debug exception occurs when the DB\_match condition is true. The corresponding BS[n] bit in the *DBS* register is set when the breakpoint generates the debug exception.

A debug data break exception occurs when a data breakpoint indicates a match. In this case the *DEPC* register and DBD bit in the *Debug* register points to the instruction that caused the DB match equation to be true.

The instruction causing the debug data break exception does not update any registers due to the instruction, and the following applies to the load or store transaction causing the debug exception:

- A store transaction is not allowed to complete the store to the memory system.
- A load transaction with no data value compare, i.e. where the DB\_no\_value\_compare is true for the match, is not allowed to complete the load.
- A load transaction for a breakpoint with data value compare must occur from the memory system, since the value is required in order to evaluate the breakpoint.

The result of this is that the load or store instruction causing the debug data break exception appears as not executed, with the exception that a load from the memory system does occur for a breakpoint with data value compare, but the result of this load is discarded since the register file is not updated by the load.

If both data breakpoints without and with data value compare would match the same transaction and generate a debug exception, then the following rules apply with respect to updating the BS[n] bits.

- On both a load and store the BS[n] bits are required to be set for all matching breakpoints without a data value compare.
- On a store the BS[n] bits are allowed but not required to be set for all matching breakpoints with a data value compare, but either all or none of the BS[n] bits must be set for these breakpoints.
- On a load then no of the BS[n] bits are allowed to be set, since the load is not allowed to occur due to the debug exception from a breakpoint without a data value compare, and a valid data value is therefore not returned.

Any BS[n] bit set prior to the match and debug exception are kept set, since BS[n] bits are only cleared by debug software.

The debug handler usually returns to the instruction causing the debug data break exception, whereby the instruction is re-executed. This re-execution may result in a repeated load from system memory, since the load may have occurred previously in order to evaluate the breakpoint as described above. I/O devices with side effects on loads must be able to allow such reloads, or debug software should alternatively avoid setting data breakpoints with data value compares on such I/O devices. Debug software is responsible for disabling breakpoints when returning to the instruction, otherwise the debug data break exception will reoccur.

## 8.2.7 Breakpoint used as TriggerPoint

Both instruction and data hardware breakpoints can be setup by software so a matching breakpoint does not generate a debug exception, but only an indication through the BS[n] bit. The TE bit in the *IBCn* or *DBCn* register controls if an instruction or data breakpoint is used as a so-called triggerpoint. The triggerpoints are, like breakpoints, only compared for instructions executed in non-debug mode.

The BS[n] bit in the *IBS* or *DBS* register is set when the respective IB\_match or DB\_match bit is true.

The triggerpoint feature can be used to start and stop tracing. See Section 8.10, "EJTAG Trace Enabling" for details.

## 8.2.8 Instruction Breakpoint Registers

The registers for instruction breakpoints are described below. These registers have implementation information and are used to set up the instruction breakpoints. All registers are in drseg, and the addresses are shown in Table 8-6.

Offset in drseg	Register Mnemonic	Register Name and Description
0x1000	IBS	Instruction Breakpoint Status
0x1100 + n * 0x100	IBAn	Instruction Breakpoint Address n
0x1108 + n * 0x100	IBMn	Instruction Breakpoint Address Mask n
0x1110 + n * 0x100	IBASIDn	Instruction Breakpoint ASID n

**Table 8-6 Addresses for Instruction Breakpoint Registers** 

**Table 8-6 Addresses for Instruction Breakpoint Registers** 

Offset in drseg	Register Mnemonic	Register Name and Description			
0x1118 + n * 0x100					
Note: n is breakpoint number in range 0 to 3 (or 0 to 1, depending on the implemented hardware)					

An example of some of the registers; *IBA0* is at offset 0x1100 and *IBC2* is at offset 0x1318.

## 8.2.8.1 Instruction Breakpoint Status (IBS) Register

**Compliance Level:** Implemented only if instruction breakpoints are implemented.

The Instruction Breakpoint Status (*IBS*) register holds implementation and status information about the instruction breakpoints.

The ASID applies to all the instruction breakpoints.

## **IBS** Register Format



## Table 8-7 IBS Register Field Descriptions

Fields			Read/	
Name	Bit(s)	Description	Write	Reset State
Res	31	Must be written as zero; returns zero on read.	R	0
ASIDsup	30	Indicates that ASID compare is supported in instruction breakpoints.  0: No ASID compare.  1: ASID compare (IBASIDn register implemented).  1: Supported  0: Not supported	R	
Res	29:28	Must be written as zero; returns zero on read.	R	0
BCN	27:24	Number of instruction breakpoints implemented.	R	4 or 2 <sup>a</sup>
Res	23:4	Must be written as zero; returns zero on read.	R	0
BS	3:0	Break status for breakpoint n is at BS[n], with n from 0 to 3 <sup>b</sup> . The bit is set to 1 when the condition for the corresponding breakpoint has matched.	R/W	Undefined

Note: [a] Based on actual hardware implemented.

Note: [b] In case of only 2 Instruction breakpoints bit 2 and 3 become reserved.

## 8.2.8.2 Instruction Breakpoint Address n (IBAn) Register

**Compliance Level:** Implemented only for implemented instruction breakpoints.

The Instruction Breakpoint Address n (IBAn) register has the address used in the condition for instruction breakpoint n

# IBAn Register Format



## **Table 8-8** *IBAn* **Register Field Descriptions**

Fields			Read/	
Name	Bit(s)	Description	Write	Reset State
IBA	31:0	Instruction breakpoint address for condition.	R/W	Undefined

## 8.2.8.3 Instruction Breakpoint Address Mask n (IBMn) Register

Compliance Level: Implemented only for implemented instruction breakpoints.

The Instruction Breakpoint Address Mask n (IBMn) register has the mask for the address compare used in the condition for instruction breakpoint n.

# **IBMn** Register Format



Table 8-9 IBMn Register Field Descriptions


Fields			Read/	
Name	Bit(s)	Description	Write	Reset State
		Instruction breakpoint address mask for condition:		
IBM 31:0		0: Corresponding address bit not masked.	R/W	Undefined
		1: Corresponding address bit masked.		

## 8.2.8.4 Instruction Breakpoint ASID n (IBASIDn) Register

Compliance Level: Implemented only for implemented instruction breakpoints.

For processors with a TLB based MMU, this register is used to define an ASID value to be used in the match expression. On the M4K processor, this register is reserved and reads as 0.

## IBASIDn Register Format



# **Table 8-10 IBASIDn Register Field Descriptions**


Fields			Read/	
Name	Bit(s)	Description	Write	Reset State
Res	31:8	Must be written as zero; returns zero on read.	R	0
ASID	7:0	Instruction breakpoint ASID value for a compare.	R	0

## 8.2.8.5 Instruction Breakpoint Control n (IBCn) Register

Compliance Level: Implemented only for implemented instruction breakpoints.

The Instruction Breakpoint Control n (IBCn) register controls the setup of instruction breakpoint n.

# IBCn Register Format



# Table 8-11 IBCn Register Field Descriptions

Fields				
Name	Bits	Description	Read/Write	Reset State
Res	31:24	Must be written as zero; returns zero on read.	R	0
ASIDuse	23	Use ASID value in compare for instruction breakpoint n:  0: Don't use ASID value in compare  1: Use ASID value in compare		0
Res	22:3	Must be written as zero; returns zero on read. R 0		0
TE	2	Use instruction breakpoint n as triggerpoint:  0: Don't use it as triggerpoint  1: Use it as triggerpoint	R/W	0
Res	1	Must be written as zero; returns zero on read.	R	0
BE	0	Use instruction breakpoint n as breakpoint:  0: Don't use it as breakpoint  1: Use it as breakpoint	R/W	0

## 8.2.9 Data Breakpoint Registers

The registers for data breakpoints are described below. These registers have implementation information and are used the setup the data breakpoints. All registers are in drseg, and the addresses are shown in Table 8-12.

**Table 8-12 Addresses for Data Breakpoint Registers** 

Offset in drseg	Register Mnemonic	Register Name and Description		
0x2000	DBS	Data Breakpoint Status		
0x2100 + 0x100 * n	DBAn	Data Breakpoint Address n		
0x2108 + 0x100 * n	DBMn	Data Breakpoint Address Mask n		
0x2110 + 0x100 * n	DBASIDn	Data Breakpoint ASID n		
0x2118 + 0x100 * n	DBCn	Data Breakpoint Control n		
0x2120 + 0x100 * n	DBVn	Data Breakpoint Value n		
Note: n is breakpoint number as 0 or 1 (or just 0, depending on the implemented hardware)				

An example of some of the registers; *DBM0* is at offset 0x2108 and *DBV1* is at offset 0x2220.

## 8.2.9.1 Data Breakpoint Status (DBS) Register

**Compliance Level:** Implemented if data breakpoints are implemented.

The Data Breakpoint Status (DBS) register holds implementation and status information about the data breakpoints.

# **DBS** Register Format

31	30	29 28	27 24	23 2	1	0
Re	SASID	Res	BCN	Res	В	BS
	sup					

# Table 8-13 DBS Register Field Descriptions

Fields			Read/	
Name	Bit(s)	Description	Write	Reset State
Res	31	Must be written as zero; returns zero on read.	R	0
ASID	30	Indicates that ASID compares are supported in data breakpoints.  0: Not supported  1: Supported	R	0
Res	29:28	Must be written as zero; returns zero on read.	R	0
BCN	27:24	Number of data breakpoints implemented.	R	2 or 1 <sup>a</sup>
Res	23:2	Must be written as zero; returns zero on read.	R	0
BS	1:0	Break status for breakpoint n is at BS[n], with n from 0 to 1 <sup>b</sup> . The bit is set to 1 when the condition for the corresponding breakpoint has matched.	R/W0	Undefined

Note: [a] Based on actual hardware implemented.

Note: [b] In case of only 1 data breakpoint bit 1 become reserved.

## 8.2.9.2 Data Breakpoint Address n (DBAn) Register

**Compliance Level:** Implemented only for implemented data breakpoints.

The Data Breakpoint Address n (DBAn) register has the address used in the condition for data breakpoint n.

# **DBAn** Register Format



## **Table 8-14** *DBAn* **Register Field Descriptions**

Fie	lds		Read/	
Name	Bit(s)	Description	Write	Reset State
DBA	31:0	Data breakpoint address for condition.	R/W	Undefined

## 8.2.9.3 Data Breakpoint Address Mask n (DBMn) Register

Compliance Level: Implemented only for implemented data breakpoints.

The Data Breakpoint Address Mask n (*DBMn*) register has the mask for the address compare used in the condition for data breakpoint n.

# **DBMn** Register Format



Table 8-15 DBMn Register Field Descriptions

Fields			Read/	
Name	Bit(s)	Description	Write	Reset State
		Data breakpoint address mask for condition:		
DBM	31:0	0: Corresponding address bit not masked	R/W	Undefined
		1: Corresponding address bit masked		

## 8.2.9.4 Data Breakpoint ASID n (DBASIDn) Register

Compliance Level: Implemented only for implemented data breakpoints.

For processors with a TLB based MMU, this register is used to define an ASID value to be used in the match expression. On the M4K processor, this register is reserved and reads as 0.

## **DBASIDn** Register Format



## **Table 8-16** *DBASIDn* **Register Field Descriptions**


Fields			Read/	
Name	Bit(s)	Description	Write	Reset State
Res	31:8	Must be written as zero; returns zero on read.	R	0
ASID	7:0	Data breakpoint ASID value for compares.	R	0

## 8.2.9.5 Data Breakpoint Control n (DBCn) Register

**Compliance Level:** Implemented only for implemented data breakpoints.

The Data Breakpoint Control n (DBCn) register controls the setup of data breakpoint n.

# **DBCn** Register Format



# Table 8-17 DBCn Register Field Descriptions

Fields				
Name	Bits	Description	Read/Write	Reset State
Res	31:24	Must be written as zero; returns zero on reads.	R	0
		Use ASID value in compare for data breakpoint n:		
ASIDuse	23	0: Don't use ASID value in compare	R	0
		1: Use ASID value in compare		
Res	22:18	Must be written as zero; returns zero on reads.	R	0
BAI	17:14	Byte access ignore controls ignore of access to a specific byte. BAI[0] ignores access to byte at bits [7:0] of the data bus, BAI[1] ignores access to byte at bits [15:8], etc.	R/W	Undefined
		0: Condition depends on access to corresponding byte		
		1: Access for corresponding byte is ignored		
		Controls if condition for data breakpoint is not fulfilled on a store transaction:		
NoSB	13	0: Condition may be fulfilled on store transaction	R/W	Undefined
		1: Condition is never fulfilled on store transaction		
		Controls if condition for data breakpoint is not fulfilled on a load transaction:		
NoLB	12	0: Condition may be fulfilled on load transaction	R/W	Undefined
		1: Condition is never fulfilled on load transaction		
Res	11:8	Must be written as zero; returns zero on reads.	R	0
BLM	7:4	Byte lane mask for value compare on data breakpoint. BLM[0] masks byte at bits [7:0] of the data bus, BLM[1] masks byte at bits [15:8], etc.:	R/W	Undefined
		0: Compare corresponding byte lane		2
		1: Mask corresponding byte lane		
Res	3	Must be written as zero; returns zero on reads.	R	0

Table 8-17 DBCn Register Field Descriptions (Continued)


Fields				
Name Bits		Description	Read/Write	Reset State
		Use data breakpoint n as triggerpoint:		
TE	2	0: Don't use it as triggerpoint	R/W	0
		1: Use it as triggerpoint		
Res	1	Must be written as zero; returns zero on reads.		0
		Use data breakpoint n as breakpoint:		
BE	0	0: Don't use it as breakpoint	R/W	0
		1: Use it as breakpoint		

## 8.2.9.6 Data Breakpoint Value n (DBVn) Register

Compliance Level: Implemented only for implemented data breakpoints.

The Data Breakpoint Value n (DBVn) register has the value used in the condition for data breakpoint n.

# **DBVn** Register Format



## Table 8-18 DBVn Register Field Descriptions

Fie	lds		Read/	
Name	Bit(s)	Description	Write	Reset State
DBV	31:0	Data breakpoint value for condition.	R/W	Undefined

# 8.3 Test Access Port (TAP)

The following main features are supported by the TAP module:

- 5-pin industry standard JTAG Test Access Port (*TCK*, *TMS*, *TDI*, *TDO*, *TRST\_N*) interface which is compatible with IEEE Std. 1149.1.
- Target chip and EJTAG feature identification available through the Test Access Port (TAP) controller.
- The processor can access external memory on the EJTAG Probe serially through the EJTAG pins. This is achieved through Processor Access (PA), and is used to eliminate the use of the system memory for debug routines.
- Support for both ROM based debugger and debugging both through TAP.

### **8.3.1 EJTAG Internal and External Interfaces**

The external interface of the EJTAG module consists of the 5 signals defined by the IEEE standard.

**Table 8-19 EJTAG Interface Pins** 

Pin	Туре	Description
TCK	I	Test Clock Input  Input clock used to shift data into or out of the Instruction or data registers. The <i>TCK</i> clock is independent of the processor clock, so the EJTAG probe can drive <i>TCK</i> independently of the processor clock frequency.  The core signal for this is called <i>EJ_TCK</i>
TMS	I	Test Mode Select Input  The <i>TMS</i> input signal is decoded by the TAP controller to control test operation. <i>TMS</i> is sampled on the rising edge of <i>TCK</i> .  The core signal for this is called <i>EJ_TMS</i>
TDI	I	Test Data Input  Serial input data ( <i>TDI</i> ) is shifted into the Instruction register or data registers on the rising edge of the <i>TCK</i> clock, depending on the TAP controller state.  The core signal for this is called <i>EJ_TDI</i>
TDO	0	Test Data Output  Serial output data is shifted from the Instruction or data register to the <i>TDO</i> pin on the falling edge of the <i>TCK</i> clock. When no data is shifted out, the <i>TDO</i> is 3-stated.  The core signal for this is called <i>EJ_TDO</i> with output enable controlled by <i>EJ_TDOzstate</i> .

**Table 8-19 EJTAG Interface Pins (Continued)** 

Pin	Туре	Description
TRST N	ī	Test Reset Input (Optional pin)  The <i>TRST_N</i> pin is an active-low signal for asynchronous reset of the TAP controller and instruction in the TAP module, independent of the processor logic. The processor is not reset by the assertion of <i>TRST_N</i> .
TKST_IV	1	The core signal for this is called <i>EJ_TRST_N</i> This signal is optional, but power-on reset must apply a low pulse on this signal at power-on and then leave it high, in case the signal is not available as a pin on the chip. If available on the chip, then it must be low on the board when the EJTAG debug features are unused by the probe.

## 8.3.2 Test Access Port Operation

The TAP controller is controlled by the Test Clock (*TCK*) and Test Mode Select (*TMS*) inputs. These two inputs determine whether an the Instruction register scan or data register scan is performed. The TAP consists of a small controller, driven by the *TCK* input, which responds to the *TMS* input as shown in the state diagram in Figure 8-1 on page 153. The TAP uses both clock edges of *TCK*. *TMS* and *TDI* are sampled on the rising edge of *TCK*, while *TDO* changes on the falling edge of *TCK*.

At power-up the TAP is forced into the *Test-Logic-Reset* by low value on *TRST\_N*. The TAP instruction register is thereby reset to IDCODE. No other parts of the EJTAG hardware are reset through the *Test-Logic-Reset* state.

When test access is required, a protocol is applied via the *TMS* and *TCK* inputs, causing the TAP to exit the *Test-Logic-Reset* state and move through the appropriate states. From the *Run-Test/Idle* state, an Instruction register scan or a data register scan can be issued to transition the TAP through the appropriate states shown in Figure 8-1 on page 153.

The states of the data and instruction register scan blocks are mirror images of each other adding symmetry to the protocol sequences. The first action that occurs when either block is entered is a capture operation. For the data registers, the *Capture-DR* state is used to capture (or parallel load) the data into the selected serial data path. In the Instruction register, the *Capture-IR* state is used to capture status information into the Instruction register.

From the *Capture* states, the TAP transitions to either the *Shift* or *Exit1* states. Normally the *Shift* state follows the *Capture* state so that test data or status information can be shifted out for inspection and new data shifted in. Following the *Shift* state, the TAP either returns to the *Run-Test/Idle* state via the *Exit1* and *Update* states or enters the *Pause* state via *Exit1*. The reason for entering the *Pause* state is to temporarily suspend the shifting of data through either the Data or Instruction Register while a required operation, such as refilling a host memory buffer, is performed. From the Pause state shifting can resume by re-entering the *Shift* state via the *Exit2* state or terminate by entering the *Run-Test/Idle* state via the *Exit2* and *Update* states.

Upon entering the data or Instruction register scan blocks, shadow latches in the selected scan path are forced to hold their present state during the Capture and Shift operations. The data being shifted into the selected scan path is not output through the shadow latch until the TAP enters the *Update-DR* or *Update-IR* state. The *Update* state causes the shadow latches to update (or parallel load) with the new data that has been shifted into the selected scan path.




Figure 8-1 TAP Controller State Diagram

### 8.3.2.1 Test-Logic-Reset State

In the *Test-Logic-Reset* state the boundary scan test logic is disabled. The test logic enters the *Test-Logic-Reset* state when the *TMS* input is held HIGH for at least five rising edges of *TCK*. The BYPASS instruction is forced into the instruction register output latches during this state. The controller remains in the *Test-Logic-Reset* state as long as *TMS* is HIGH.

#### 8.3.2.2 Run-Test/Idle State

The controller enters the *Run-Test/Idle* state between scan operations. The controller remains in this state as long as *TMS* is held LOW. The instruction register and all test data registers retain their previous state. The instruction cannot change when the TAP controller is in this state.

When TMS is sampled HIGH on the rising edge of TCK, the controller transitions to the Select\_DR state.

### 8.3.2.3 Select DR Scan State

This is a temporary controller state in which all test data registers selected by the current instruction retain their previous state. If *TMS* is sampled LOW at the rising edge of *TCK*, then the controller transitions to the *Capture\_DR* state. A HIGH on *TMS* causes the controller to transition to the *Select\_IR* state. The instruction cannot change while the TAP controller is in this state.

#### 8.3.2.4 Select IR Scan State

This is a temporary controller state in which all test data registers selected by the current instruction retain their previous state. If *TMS* is sampled LOW on the rising edge of *TCK*, the controller transitions to the *Capture\_IR* state. A HIGH on *TMS* causes the controller to transition to the *Test-Reset-Logic* state. The instruction cannot change while the TAP controller is in this state.

#### 8.3.2.5 Capture\_DR State

In this state the boundary scan register captures the value of the register addressed by the Instruction register, and the value is then shifted out in the *Shift\_DR*. If *TMS* is sampled LOW at the rising edge of *TCK*, the controller transitions to the *Shift\_DR* state. A HIGH on *TMS* causes the controller to transition to the *Exit1\_DR* state. The instruction cannot change while the TAP controller is in this state.

### 8.3.2.6 Shift DR State

In this state the test data register connected between *TDI* and *TDO* as a result of the current instruction shifts data one stage toward its serial output on the rising edge of *TCK*. If *TMS* is sampled LOW on the rising edge of *TCK*, the controller remains in the *Shift\_DR* state. A HIGH on *TMS* causes the controller to transition to the *Exit1\_DR* state. The instruction cannot change while the TAP controller is in this state.

### 8.3.2.7 Exit1\_DR State

This is a temporary controller state in which all test data registers selected by the current instruction retain their previous state. If *TMS* is sampled LOW at the rising edge of *TCK*, the controller transitions to the *Pause\_DR* state. A HIGH on *TMS* causes the controller to transition to the *Update\_DR* state which terminates the scanning process. The instruction cannot change while the TAP controller is in this state.

#### 8.3.2.8 Pause\_DR State

The *Pause\_DR* state allows the controller to temporarily halt the shifting of data through the test data register in the serial path between *TDI* and *TDO*. All test data registers selected by the current instruction retain their previous state. If *TMS* is sampled LOW on the rising edge of *TCK*, the controller remains in the *Pause\_DR* state. A HIGH on *TMS* causes the controller to transition to the *Exit2\_DR* state. The instruction cannot change while the TAP controller is in this state.

#### 8.3.2.9 Exit2 DR State

This is a temporary controller state in which all test data registers selected by the current instruction retain their previous state. If *TMS* is sampled LOW at the rising edge of *TCK*, the controller transitions to the *Shift\_DR* state to allow another serial shift of data. A HIGH on *TMS* causes the controller to transition to the *Update\_DR* state which terminates the scanning process. The instruction cannot change while the TAP controller is in this state.

### 8.3.2.10 Update\_DR State

When the TAP controller is in this state the value shifted in during the *Shift\_DR* state takes effect on the rising edge of the *TCK* for the register indicated by the Instruction register.

If *TMS* is sampled LOW at the rising edge of *TCK*, the controller transitions to the *Run-Test/Idle* state. A HIGH on *TMS* causes the controller to transition to the *Select\_DR\_Scan* state. The instruction cannot change while the TAP controller is in this state and all shift register stages in the test data registers selected by the current instruction retain their previous state.

### 8.3.2.11 Capture\_IR State

In this state the shift register contained in the Instruction register loads a fixed pattern  $(00001_2)$  on the rising edge of TCK. The data registers selected by the current instruction retain their previous state.

If *TMS* is sampled LOW at the rising edge of *TCK*, the controller transitions to the *Shift\_IR* state. A HIGH on *TMS* causes the controller to transition to the *Exit1\_IR* state. The instruction cannot change while the TAP controller is in this state.

#### **8.3.2.12** Shift IR State

In this state the instruction register is connected between *TDI* and *TDO* and shifts data one stage toward its serial output on the rising edge of *TCK*. If *TMS* is sampled LOW at the rising edge of *TCK*, the controller remains in the *Shift\_IR* state. A HIGH on *TMS* causes the controller to transition to the *Exit1 IR* state.

### **8.3.2.13** Exit1\_IR State

This is a temporary controller state in which all registers retain their previous state. If *TMS* is sampled LOW at the rising edge of *TCK*, the controller transitions to the *Pause\_IR* state. A HIGH on *TMS* causes the controller to transition to the *Update\_IR* state which terminates the scanning process. The instruction cannot change while the TAP controller is in this state and the instruction register retains its previous state.

#### 8.3.2.14 Pause IR State

The *Pause\_IR* state allows the controller to temporarily halt the shifting of data through the instruction register in the serial path between *TDI* and *TDO*. If *TMS* is sampled LOW at the rising edge of *TCK*, the controller remains in the *Pause\_IR* state. A HIGH on *TMS* causes the controller to transition to the *Exit2\_IR* state. The instruction cannot change while the TAP controller is in this state.

#### 8.3.2.15 Exit2 IR State

This is a temporary controller state in which the instruction register retains its previous state. If *TMS* is sampled LOW at the rising edge of *TCK*, then the controller transitions to the *Shift\_IR* state to allow another serial shift of data. A HIGH on *TMS* causes the controller to transition to the *Update\_IR* state which terminates the scanning process. The instruction cannot change while the TAP controller is in this state.

### 8.3.2.16 Update\_IR State

The instruction shifted into the instruction register takes effect on the rising edge of TCK.

If *TMS* is sampled LOW at the rising edge of *TCK*, the controller transitions to the *Run-Test/Idle* state. A HIGH on *TMS* causes the controller to transition to the *Select\_DR\_Scan* state.

### **8.3.3** Test Access Port (TAP) Instructions

The TAP Instruction register allows instructions to be serially input into the device when TAP controller is in the *Shift-IR* state. Instructions are decoded and define the serial test data register path that is used to shift data between *TDI* and *TDO* during data register scanning.

The Instruction register is a 5-bit register. In the current EJTAG implementation only some instructions have been decoded; the unused instructions default to the BYPASS instruction.

Value	Instruction	Function
0x01	IDCODE	Select Chip Identification data register
0x03	IMPCODE	Select Implementation register
0x08	ADDRESS	Select Address register
0x09	DATA	Select Data register

**Table 8-20 Implemented EJTAG Instructions** 

**Table 8-20 Implemented EJTAG Instructions (Continued)** 

Value	Instruction	Function
0x0A	CONTROL	Select EJTAG Control register
0x0B	ALL	Select the Address, Data and EJTAG Control registers
0x0C	EJTAGBOOT	Set EjtagBrk, ProbEn and ProbTrap to 1 as reset value
0x0D	NORMALBOOT	Set EjtagBrk, ProbEn and ProbTrap to 0 as reset value
0x0E	FASTDATA	Selects the Data and Fastdata registers
0x10	TCBCONTROLA	Selects the TCBTCONTROLA register in the Trace Control Block
0x11	TCBCONTROLB	Selects the TCBTCONTROLB register in the Trace Control Block
0x12	TCBDATA	Selects the TCBDATA register in the Trace Control Block
0x1F	BYPASS	Bypass mode

#### 8.3.3.1 BYPASS Instruction

The required BYPASS instruction allows the processor to remain in a functional mode and selects the Bypass register to be connected between *TDI* and *TDO*. The BYPASS instruction allows serial data to be transferred through the processor from *TDI* to *TDO* without affecting its operation. The bit code of this instruction is defined to be all ones by the IEEE 1149.1 standard. Any unused instruction is defaulted to the BYPASS instruction.

### 8.3.3.2 IDCODE Instruction

The IDCODE instruction allows the processor to remain in its functional mode and selects the Device Identification (ID) register to be connected between *TDI* and *TDO*. The Device ID register is a 32-bit shift register containing information regarding the IC manufacturer, device type, and version code. Accessing the Identification Register does not interfere with the operation of the processor. Also, access to the Identification Register is immediately available, via a TAP data scan operation, after power-up when the TAP has been reset with on-chip power-on or through the optional *TRST\_N* pin.

### 8.3.3.3 IMPCODE Instruction

This instruction selects the Implementation register for output, which is always 32 bits.

#### 8.3.3.4 ADDRESS Instruction

This instruction is used to select the Address register to be connected between *TDI* and *TDO*. The EJTAG Probe shifts 32 bits through the *TDI* pin into the Address register and shifts out the captured address via the *TDO* pin.

### 8.3.3.5 DATA Instruction

This instruction is used to select the Data register to be connected between *TDI* and *TDO*. The EJTAG Probe shifts 32 bits of *TDI* data into the Data register and shifts out the captured data via the *TDO* pin.

### 8.3.3.6 CONTROL Instruction

This instruction is used to select the EJTAG Control register to be connected between *TDI* and *TDO*. The EJTAG Probe shifts 32 bits of *TDI* data into the EJTAG Control register and shifts out the EJTAG Control register bits via *TDO*.

#### 8.3.3.7 ALL Instruction

This instruction is used to select the concatenation of the Address and Data register, and the EJTAG Control register between *TDI* and *TDO*. It can be used in particular if switching instructions in the instruction register takes too many *TCK* cycles. The first bit shifted out is bit 0.




Figure 8-2 Concatenation of the EJTAG Address, Data and Control Registers

#### 8.3.3.8 EJTAGBOOT Instruction

When the EJTAGBOOT instruction is given and the Update-IR state is left, then the reset values of the ProbTrap, ProbEn and EjtagBrk bits in the EJTAG Control register are set to 1 after a hard or soft reset.

This EJTAGBOOT indication is effective until a NORMALBOOT instruction is given, *TRST\_N* is asserted or a rising edge of *TCK* occurs when the TAP controller is in Test-Logic-Reset state.

It is possible to make the CPU go into debug mode just after a hard or soft reset, without fetching or executing any instructions from the normal memory area. This can be used for download of code to a system which have no code in ROM.

The Bypass register is selected when the EJTAGBOOT instruction is given.

## 8.3.3.9 NORMALBOOT Instruction

When the NORMALBOOT instruction is given and the Update-IR state is left, then the reset value of the ProbTrap, ProbEn and EjtagBrk bits in the EJTAG Control register are set to 0 after hard or soft reset.

The Bypass register is selected when the NORMALBOOT instruction is given.

#### 8.3.3.10 FASTDATA Instruction

This selects the Data and the Fastdata registers at once, as shown in Figure 8-3.




Figure 8-3 TDI to TDO Path when in Shift-DR State and FASTDATA Instruction is Selected

### 8.3.3.11 TCBCONTROLA Instruction

This instruction is used to select the TCBCONTROLA register to be connected between *TDI* and *TDO*. This register is only implemented if the Trace Control Block is present. If no TCB is present, then this instruction will select the Bypass register.

#### 8.3.3.12 TCBCONTROLB Instruction

This instruction is used to select the TCBCONTROLB register to be connected between *TDI* and *TDO*. This register is only implemented if the Trace Control Block is present. If no TCB is present, then this instruction will select the Bypass register.

### 8.3.3.13 TCBDATA Instruction

This instruction is used to select the TCBDATA register to be connected between *TDI* and *TDO*. This register is only implemented if the Trace Control Block is present. If no TCB is present, then this instruction will select the Bypass register. It should be noted that the TCBDATA register is only an access register to other TCB registers. The width of the TCBDATA register is dependent on the specific TCB register.

## **8.4 EJTAG TAP Registers**

The EJTAG TAP Module has one Instruction register and a number of data registers, all accessible through the TAP:

### **8.4.1 Instruction Register**

The Instruction register is accessed when the TAP receives an Instruction register scan protocol. During an Instruction register scan operation the TAP controller selects the output of the Instruction register to drive the *TDO* pin. The shift register consists of a series of bits arranged to form a single scan path between *TDI* and *TDO*. During an Instruction register scan operations, the TAP controls the register to capture status information and shift data from *TDI* to *TDO*. Both the capture and shift operations occur on the rising edge of *TCK*. However, the data shifted out from the *TDO* occurs on the falling edge of *TCK*. In the Test-Logic-Reset and *Capture-IR* state, the instruction shift register is set to 00001<sub>2</sub>, as for the IDCODE instruction. This forces the device into the functional mode and selects the Device ID register. The Instruction register is 5 bits wide. The instruction shifted in takes effect for the following data register scan operation. A list of the implemented instructions are listed in Table 8-20.

## **8.4.2 Data Registers Overview**

The EJTAG uses several data registers, which are arranged in parallel from the primary *TDI* input to the primary *TDO* output. The Instruction register supplies the address that allows one of the data registers to be accessed during a data register scan operation. During a data register scan operation, the addressed scan register receives TAP control signals to capture the register and shift data from *TDI* to *TDO*. During a data register scan operation, the TAP selects the output of the data register to drive the *TDO* pin. The register is updated in the *Update-DR* state with respect to the write bits.

This description applies in general to the following data registers:

- Bypass Register
- Device Identification Register
- Implementation Register
- EJTAG Control Register (ECR)
- Processor Access Address Register
- Processor Access Data Register
- FastData Register


#### 8.4.2.1 Bypass Register

The *Bypass* register consists of a single scan register bit. When selected, the Bypass register provides a single bit scan path between *TDI* and *TDO*. The Bypass register allows abbreviating the scan path through devices that are not involved in the test. The Bypass register is selected when the Instruction register is loaded with a pattern of all ones to satisfy the IEEE 1149.1 Bypass instruction requirement.

#### 8.4.2.2 Device Identification (ID) Register

The *Device Identification* register is defined by IEEE 1149.1, to identify the device's manufacturer, part number, revision, and other device-specific information. Table 8-21 shows the bit assignments defined for the read-only Device Identification Register, and inputs to the core determine the value of these bits. These bits can be scanned out of the *ID* register after being selected. The register is selected when the Instruction register is loaded with the IDCODE instruction.

## **Device Identification Register Format**



**Table 8-21 Device Identification Register** 

Field	s		Read/	
Name	Bit(s)	Description	Write	Reset State
Version 31:28		Version (4 bits)  This field identifies the version number of the processor derivative.	R	EJ_Version[3:0]
PartNumber	27:12	Part Number (16 bits)  This field identifies the part number of the processor derivative.	R	EJ_PartNumber[15:0]
ManufID 11:1		Manufacturer Identity (11 bits)  Accordingly to IEEE 1149.1-1990, the manufacturer identity code shall be a compressed form of the JEDEC Publications 106-A.	R	EJ_ManufID[10:0]
R 0 reserved			R	1

## 8.4.2.3 Implementation Register

This 32-bit read-only register is used to identify the features of the EJTAG implementation. Some of the reset values are set by inputs to the core. The register is selected when the Instruction register is loaded with the IMPCODE instruction.

### Implementation Register Format

31 29	28 25	24	23 21	20 17	16	15	14	13 0
EJTAGver	reserved	DINTsup	ASIDsize	reserved	MIPS16	0	NoDMA	reserved

**Table 8-22 Implementation Register Descriptions** 

Field	ls		Read/	
Name	Bit(s)	Description	Write	Reset State
EJTAGver	31:29	EJTAG Version. 2: Version 2.6	R	2
reserved	28:25	reserved	R	0
DINTsup	24	DINT Signal Supported from Probe  This bit indicates if the DINT signal from the probe is supported:  0: DINT signal from the probe is not supported 1: Probe can use DINT signal to make debug interrupt.	R	EJ_DINTsup
ASIDsize	23:21	Size of ASID field in implementation:  0: No ASID in implementation 1: 6-bit ASID 2: 8-bit ASID 3: Reserved	R	20
reserved	20:17	reserved	R	0
MIPS16	16	Indicates whether MIPS16 is implemented  0: No MIPS16 support  1: MIPS16 implemented	R	
reserved	15	reserved	R	0
NoDMA	14	No EJTAG DMA Support	R	1
reserved	13:0	reserved	R	0

### **8.4.2.4 EJTAG Control Register**

This 32-bit register controls the various operations of the TAP modules. This register is selected by shifting in the CONTROL instruction. Bits in the EJTAG Control register can be set/cleared by shifting in data; status is read by shifting out the contents of this register. This EJTAG Control register can only be accessed by the TAP interface.

The EJTAG Control register is not updated in the *Update-DR* state unless the Reset occurred (Rocc) bit 31, is either 0 or written to 0. This is in order to ensure prober handling of processor accesses.

The value used for reset indicated in the table below takes effect on both hard and soft CPU resets, but not on TAP controller resets by e.g. *TRST\_N*. *TCK* clock is not required when the hard or soft CPU reset occurs, but the bits are still updated to the reset value when the *TCK* applies. The first 5 *TCK* clocks after hard or soft CPU resets may result in reset of the bits, due to synchronization between clock domains.

## **EJTAG Control Register Format**

31	30 29	28 23	22	21	20	19	18	17	16	15	14	13	12	11	4	3	2	0
Rocc	Psz	Res	Doze	Halt	PerRst	PRnW	PrAcc	Res	PrRst	ProbEn	ProbTrap	Res	EjtagBrk	Res	I	DM	Re	s

Table 8-23 EJTAG Control Register Descriptions

Fie	lds				Dood/	
Name	Bit(s)			Description	Read/ Write	Reset State
Rocc	31	0: No result is Reset of the Rocci soft reset. This bit is that the ir The EJTA Update-D	dicates i et occurred bit will is applie nust be c ncident w	f a hard or soft reset has occurred: ed since bit last cleared. since bit last cleared. keep the 1 value as long as a hard or d. leared by the probe, to acknowledge vas detected. rol register is not updated in the inless Rocc is 0, or written to 0. This is	R/W	1
Psz[1:0]	30:29	These bits address bits of a process when process will be processed as a process when process which process which process when process when process when process which proce	order to ensure proper handling of processor access.  occessor Access Transfer Size  lese bits are used in combination with the lower two dress bits of the Address register to determine the size a processor access transaction. The bits are only valid len processor access is pending.  A[1:0] Psz[1:0] Transfer Size  00 00 Byte (LE, byte 0; BE, byte 3)  01 00 Byte (LE, byte 1; BE, byte 2)  10 00 Byte (LE, byte 2; BE, byte 1)  11 00 Byte (LE, byte 3; BE, byte 0)  00 01 Halfword (LE, bytes 1:0; BE, bytes 3:2)  10 01 Halfword (LE, bytes 3:2; BE, bytes 1:0)  00 10 Word (LE, BE; bytes 3, 2, 1, 0)  00 11 Triple (LE, bytes 2, 1, 0; BE, bytes 3, 2, 1)			Undefined
Res	28:23	reserved			R	0
Doze	22	value is so controller 0: CPU no 1: CPU is	bit indicampled in the control of th	rates any kind of low power mode. The n the Capture-DR state of the TAP power mode. power mode  Reduced Power (RP) and WAIT modes.	R	0

 Table 8-23 EJTAG Control Register Descriptions (Continued)

Fie	elds		Read/	
Name	Bit(s)	Description	Write	Reset State
Halt	21	Halt state  The Halt bit indicates if the internal system bus clock is running or stopped. The value is sampled in the Capture-DR state of the TAP controller:  0: Internal system clock is running 1: Internal system clock is stopped	R	0
PerRst	20	Peripheral Reset  When the bit is set to 1, it is only guaranteed that the peripheral reset has occurred in the system when the read value of this bit is also 1. This is to ensure that the setting from the <i>TCK</i> clock domain gets effect in the CPU clock domain, and in peripherals.  When the bit is written to 0, then the bit must also be read as 0 before it is guaranteed that the indication is cleared in the CPU clock domain also.  This bit controls the <i>EJ_PerRst</i> signal on the core.	R/W	0
PRnW	19	Processor Access Read and Write  This bit indicates if the pending processor access is for a read or write transaction, and the bit is only valid while PrAcc is set:  0: Read transaction  1: Write transaction	R	Undefined
PrAcc	1: Write transaction  Processor Access (PA)  Read value of this bit indicates if a Processor Access (PA) to the EJTAG memory is pending: 0: No pending processor access 1: Pending processor access 1: Pending processor access The probe's software must clear this bit to 0 to indicate the end of the PA. Write of 1 is ignored.  A pending Processor Access is cleared when Rocc is set, but another PA may occur just after the reset if a debug exception occurs.  Finishing a Processor Access is not accepted while the Rocc bit is set. This is to avoid that a Processor Access occurring after the reset is finished due to indication of a Processor Access that occurred before the reset.  The FASTDATA access can clear this bit.		R/W0	0
Res	17	reserved	R	0
	1			

Table 8-23 EJTAG Control Register Descriptions (Continued)

Fie	lds		Read/	
Name	Bit(s)	Description	Write	Reset State
PrRst	16	Processor Reset (Implementation dependent behavior)  When the bit is set to 1, then it is only guaranteed that this setting has taken effect in the system when the read value of this bit is also 1. This is to ensure that the setting from the <i>TCK</i> clock domain gets effect in the CPU clock domain, and in peripherals.  When the bit is written to 0, then the bit must also be read as 0 before it is guaranteed that the indication is cleared in the CPU clock domain also.  This bit controls the <i>EJ_PrRst</i> signal. If the signal is used in the system, then it must be ensured that both the processor and all devices required for a reset are properly reset. Otherwise the system may fail or hang. The bit resets itself, since the EJTAG Control register is reset by hard or soft reset.	R/W	0
ProbEn	15	Probe Enable  This bit indicates to the CPU if the EJTAG memory is handled by the probe so processor accesses are answered:  0: The probe does not handle EJTAG memory transactions  1: The probe does handle EJTAG memory transactions  It is an error by the software controlling the probe if it sets the ProbTrap bit to 1, but resets the ProbEn to 0. The operation of the processor is UNDEFINED in this case.  The ProbEn bit is reflected as a read-only bit in the ProbEn bit, bit 0, in the Debug Control Register (DCR).  The read value indicates the effective value in the DCR, due to synchronization issues between TCK and CPU clock domains; however, it is ensured that change of the ProbEn prior to setting the EjtagBrk bit will have effect for the debug handler executed due to the debug exception.  The reset value of the bit depends on whether the EJTAGBOOT indication is given or not:  No EJTAGBOOT indication given: 1	R/W	0 or 1 from EJTAGBOOT

**Table 8-23** *EJTAG Control* **Register Descriptions** (Continued)

Fie	lds		Read/	
Name	Bit(s)	Description	Write	Reset State
ProbTrap	14	Probe Trap  This bit controls the location of the debug exception vector:  0: In normal memory 0xBFC0.0480 1: In EJTAG memory at 0xFF20.0200 in dmseg  Valid setting of the ProbTrap bit depends on the setting of the ProbEn bit, see comment under ProbEn bit.  The ProbTrap should not be set to 1, for debug exception vector in EJTAG memory, unless the ProbEn bit is also set to 1 to indicate that the EJTAG memory may be accessed.  The read value indicates the effective value to the CPU due to synchronization issues between TCK and CPU clock domains; however, it is ensured that change of the ProbTrap bit prior to setting the EjtagBrk bit will have effect for the EjtagBrk.  The reset value of the bit depends on whether the EJTAGBOOT indication is given or not: No EJTAGBOOT indication given: 0 EJTAGBOOT indication given: 1		0 or 1 from EJTAGBOOT
Res	13	reserved	R	0
EjtagBrk	12	EJTAG Break  Setting this bit to 1 causes a debug exception to the processor, unless the CPU was in debug mode or another debug exception occurred.  When the debug exception occurs, the processor core clock is restarted if the CPU was in low power mode. This bit is cleared by hardware when the debug exception is taken.  The reset value of the bit depends on whether the EJTAGBOOT indication is given or not:  No EJTAGBOOT indication given: 0  EJTAGBOOT indication given: 1	R/W1	0 or 1 from EJTAGBOOT
Res	11:4	reserved	R	0
DM	Debug Mode  This bit indicates the debug or non-debug mode: 0: Processor is in non-debug mode 1: Processor is in debug mode The bit is sampled in the <i>Capture-DR</i> state of the TAP controller.		R	0
Res	2:0	reserved	R	0

# 8.4.3 Processor Access Address Register

The Processor Access Address (*PAA*) register is used to provide the address of the processor access in the dmseg, and the register is only valid when a processor access is pending. The length of the Address register is 32 bits, and this register is selected by shifting in the ADDRESS instruction.

#### 8.4.3.1 Processor Access Data Register

The Processor Access Data (*PAD*) register is used to provide data value to and from a processor access. The length of the Data register is 32 bits, and this register is selected by shifting in the DATA instruction.

The register has the written value for a processor access write due to a CPU store to the dmseg, and the output from this register is only valid when a processor access write is pending. The register is used to provide the data value fora processor access read due to a CPU load or fetch from the dmseg, and the register should only be updated with a new value when a processor access write is pending.

The *PAD* register is 32 bits wide. Data alignment is not used for this register, so the value in the *PAD* register matches data on the internal bus. The undefined bytes for a PA write are undefined, and for a *PAD* read then 0 (zero) must be shifted in for the unused bytes.

The organization of bytes in the *PAD* register depends on the endianess of the core, as shown in Figure 8-4 on page 165. The endian mode for debug/kernel mode is determined by the state of the *SI Endian* input at power-up.




Figure 8-4 Endian Formats for the PAD Register

The size of the transaction and thus the number of bytes available/required for the *PAD* register is determined by the Psz field in the *ECR*.

### **8.4.4 Fastdata Register (TAP Instruction FASTDATA)**

The width of the Fastdata register is 1 bit. During a Fastdata access, the Fastdata register is written and read, i.e., a bit is shifted in and a bit is shifted out. During a Fastdata access, the Fastdata register value shifted in specifies whether the Fastdata access should be completed or not. The value shifted out is a flag that indicates whether the Fastdata access was successful or not (if completion was requested).

## Fastdata Register Format

O SPrAcc

**Table 8-24 Fastdata Register Field Description** 

Fiel	lds		Read/	Power-up	
Name	Bits	Description	Write	State	
SPrAcc	0	Shifting in a zero value requests completion of the Fastdata access. The PrAcc bit in the EJTAG Control register is overwritten with zero when the access succeeds. (The access succeeds if PrAcc is one and the operation address is in the legal dmseg Fastdata area.) When successful, a one is shifted out. Shifting out a zero indicates a Fastdata access failure.  Shifting in a one does not complete the Fastdata access and the PrAcc bit is unchanged. Shifting out a one indicates that the access would have been successful if allowed to complete and a zero indicates the access would not have successfully completed.	R/W	Undefined	

The FASTDATA access is used for efficient block transfers between dmseg (on the probe) and target memory (on the processor). An "upload" is defined as a sequence of processor loads from target memory and stores to dmseg. A "download" is a sequence of processor loads from dmseg and stores to target memory. The "Fastdata area" specifies the legal range of dmseg addresses (0xFF20.0000 - 0xFF20.000F) that can be used for uploads and downloads. The Data + Fastdata registers (selected with the FASTDATA instruction) allow efficient completion of pending Fastdata area accesses.

During Fastdata uploads and downloads, the processor will stall on accesses to the Fastdata area. The PrAcc (processor access pending bit) will be 1 indicating the probe is required to complete the access. Both upload and download accesses are attempted by shifting in a zero SPrAcc value (to request access completion) and shifting out SPrAcc to see if the attempt will be successful (i.e., there was an access pending and a legal Fastdata area address was used). Downloads will also shift in the data to be used to satisfy the load from dmseg's Fastdata area, while uploads will shift out the data being stored to dmseg's Fastdata area.

As noted above, two conditions must be true for the Fastdata access to succeed. These are:

- PrAcc must be 1, i.e., there must be a pending processor access.
- The Fastdata operation must use a valid Fastdata area address in dmseg (0xFF20.0000 to 0xFF20.000F).

Table 8-25 shows the values of the PrAcc and SPrAcc bits and the results of a Fastdata access.

Table 8-25 Operation of the FASTDATA access

Probe Operation	Address Match check	PrAccin the Control Register	LSB (SPrAcc) shifted in	Action in the Data Register	PrAcc changes to	LSB shifted out	Data shifted out
	Fails	Х	X	none	unchanged	0	invalid
D1		1	1	none	unchanged	1	invalid
Download using FASTDATA	Passes	1	0	write data	0 (SPrAcc)	1	valid (previous) data
		0	X	none	unchanged	0	invalid

Table 8-25 Operation of the FASTDATA access (Continued)

Probe Operation	Address Match check	PrAccin the Control Register	LSB (SPrAcc) shifted in	Action in the Data Register	PrAcc changes to	LSB shifted out	Data shifted out
	Fails	Х	X	none	unchanged	0	invalid
Upload		1	1	none	unchanged	1	invalid
using FASTDATA	Passes	1	0	read data	0 (SPrAcc)	1	valid data
		0	X	none	unchanged	0	invalid

There is no restriction on the contents of the Data register. It is expected that the transfer size is negotiated between the download/upload transfer code and the probe software. Note that the most efficient transfer size is a 32-bit word.

The Rocc bit of the Control register is not used for the FASTDATA operation.

#### **8.5 TAP Processor Accesses**

The TAP modules support handling of fetches, loads and stores from the CPU through the dmseg segment, whereby the TAP module can operate like a *slave unit* connected to the on-chip bus. The core can then execute code taken from the EJTAG Probe and it can access data (via a load or store) which is located on the EJTAG Probe. This occurs in a serial way through the EJTAG interface: the core can thus execute instructions e.g. debug monitor code, without occupying the memory.

Accessing the dmseg segment (EJTAG memory) can only occur when the processor accesses an address in the range from 0xFF20.0000 to 0xFF2F.FFFF, the ProbEn bit is set, and the processor is in debug mode (DM=1). In addition the LSNM bit in the CP0 Debug register controls transactions to/from the dmseg.

When a debug exception is taken, while the ProbTrap bit is set, the processor will start fetching instructions from address 0xFF20.0200.

A pending processor access can only finish if the probe writes 0 to PrAcc or by a soft or hard reset.

## 8.6 Fetch/Load and Store from/to the EJTAG Probe through dmseg

- 1. The internal hardware latches the requested address into the PA Address register (in case of the Debug exception: 0xFF20.0200).
- 2. The internal hardware sets the following bits in the EJTAG Control register:
  - PrAcc = 1 (selects Processor Access operation)
  - PRnW = 0 (selects processor read operation)
  - Psz[1:0] = value depending on the transfer size
- 3. The EJTAG Probe selects the EJTAG Control register, shifts out this control register's data and tests the PrAcc status bit (Processor Access): when the PrAcc bit is found 1, it means that the requested address is available and can be shifted out.
- 4. The EJTAG Probe checks the PRnW bit to determine the required access.
- 5. The EJTAG Probe selects the PA Address register and shifts out the requested address.
- 6. The EJTAG Probe selects the PA Data register and shifts in the instruction corresponding to this address.

- 7. The EJTAG Probe selects the EJTAG Control register and shifts a PrAcc = 0 bit into this register to indicate to the processor that the instruction is available.
- 8. The instruction becomes available in the instruction register and the processor starts executing.
- 9. The processor increments the program counter and outputs an instruction read request for the next instruction. This starts the whole sequence again.

Using the same protocol, the processor can also execute a load instruction to access the EJTAG Probe's memory. For this to happen, the processor must execute a load instruction (e.g. a LW, LH, LB) with the target address in the appropriate range.

Almost the same protocol is used to execute a store instruction to the EJTAG Probe's memory through dmseg. The store address must be in the range: 0xFF20.0000 to 0xFF2F.FFFF, the ProbEn bit must be set and the processor has to be in debug mode (DM=1). The sequence of actions is found below:

- 1. The internal hardware latches the requested address into the PA Address register
- 2. The internal hardware latches the data to be written into the PA Data register.
- 3. The internal hardware sets the following bits in the EJTAG Control register:

PrAcc = 1 (selects Processor Access operation)

PRnW = 1 (selects processor write operation)

Psz[1:0] = value depending on the transfer size

- 4. The EJTAG Probe selects the EJTAG Control register, shifts out this control register's data and tests the PrAcc status bit (Processor Access): when the PrAcc bit is found 1, it means that the requested address is available and can be shifted out.
- 5. The EJTAG Probe checks the PRnW bit to determine the required access.
- 6. The EJTAG Probe selects the PA Address register and shifts out the requested address.
- 7. The EJTAG Probe selects the PA Data register and shifts out the data to be written.
- 8. The EJTAG Probe selects the EJTAG Control register and shifts a PrAcc = 0 bit into this register to indicate to the processor that the write access is finished.
- 9. The EJTAG Probe writes the data to the requested address in its memory.
- 10. The processor detects that  $PrAcc\ bit = 0$ , which means that it is ready to handle a new access.

The above examples imply that no reset occurs during the operations, and that Rocc is cleared.

#### 8.7 EJTAG Trace

EJTAG Trace enables the ability to trace program flow, load/store addresses and load/store data. Several run-time options exist for the level of information which is traced, including tracing only when in specific processor modes (i.e. UserMode or KernelMode). EJTAG Trace is an optional block in the M4K core. If EJTAG Trace is not implemented, the rest of this chapter is irrelevant. If EJTAG Trace is implemented, the *CPO Config3<sub>TL</sub>* bit is set.

The pipeline specific part of EJTAG Trace is architecturally specified in the *PDtrace*<sup>TM</sup> *Interface Specification*. The PDtrace module extracts the trace information from the processor pipeline, and presents it to a pipeline-independent module called the Trace Control Block (TCB). The TCB is specified in the *EJTAG Trace Control Block Specification*. The collective implementation of the two is called *EJTAG Trace*.

When EJTAG Trace is implemented, the M4K core includes both the PDtrace and the Trace Control Block (TCB) modules. The two modules "talk" to each other on the generic pin-interface called the PDtrace<sup>TM</sup> Interface. This interface is embedded inside the M4K core, and will not be discussed in detail here (read the *PDtrace<sup>TM</sup> Interface Specification* 

for a detailed description). While working closely together, the two parts of EJTAG Trace are controlled separately by software. Figure 8-5 shows an overview of the EJTAG Trace modules within the core.




Figure 8-5 EJTAG Trace modules in the M4K™ core

To some extent, the two modules both provide similar trace control features, but the access to these features is quite different. The PDtrace controls can only be reached through access to CP0 registers. The TCB controls can only be reached through EJTAG TAP access. The TCB can then control what is traced through the PDtrace<sup>TM</sup> Interface.

Before describing the EJTAG Trace implemented in the M4K core, some common terminology and basic features are explained. The remaining sections of this chapter will then provide a more thorough explanation.

#### 8.7.1 Processor Modes

Tracing can be enabled or disabled based on various processor modes. This section precisely describes these modes. The terminology is then used elsewhere in the document.

```
\label{eq:debugMode} \begin{array}{l} \mbox{DebugMode} \leftarrow (\mbox{DebugMode}) \mbox{ and } ((\mbox{Status}_{\mbox{EXL}} = 1) \mbox{ or } (\mbox{Status}_{\mbox{ERL}} = 1)) \\ \mbox{KernelMode} \leftarrow (\mbox{not } (\mbox{DebugMode} \mbox{ or } \mbox{ExceptionMode})) \mbox{ and } (\mbox{Status}_{\mbox{UM}} = 0) \\ \mbox{UserMode} \leftarrow (\mbox{not } (\mbox{DebugMode} \mbox{ or } \mbox{ExceptionMode})) \mbox{ and } (\mbox{Status}_{\mbox{UM}} = 1) \\ \end{array}
```

#### 8.7.2 Software versus Hardware control

In some of the specifications and in this text, the terms "software control" and "hardware control" are used to refer to the method for how trace is controlled. Software control is when the CP0 register *TraceControl* is used to select the modes to trace, etc. Hardware control is when the EJTAG register *TCBCONTROLA* in the TCB, via the PDtrace interface, is used to select the trace modes. The *TraceControl.TS* bit determines whether software or hardware control is active.

#### 8.7.3 Trace information

The main object of trace is to show the exact program flow from a specific program execution or just a small window of the execution. In EJTAG Trace this is done by providing the minimal cycle-by-cycle information necessary on the PDtrace<sup>TM</sup> interface for trace regeneration software to reproduce the trace. The following is a summary of the type of information traced:

• Only instructions which complete at the end of the pipeline are traced, and indicated with a completion-flag. The PC is implicitly pointing to the next instruction.

- Load instructions are indicated with a load-flag.
- Store instructions are indicated with a store-flag<sup>1</sup>.
- Taken branches are indicated with a branch-taken-flag on the target instruction.
- New PC information for a branch is only traced if the branch target is unpredictable from the static program image.
- When branch targets are unpredictable, only the delta value from current PC is traced, if it is dynamically
  determined to reduce the number of bits necessary to indicate the new PC. Otherwise the full PC value is traced.
- When a completing instruction is executed in a different processor mode from the previous one, the new processor mode is traced.
- The first instruction is always traced as a branch target, with processor mode and full PC.
- Periodic synchronization instructions are identified with a sync-flag, and traced with the processor mode and full PC.

All the instruction flags above are combined into one 3-bit value, to minimize the bit information to trace. The possible processor modes are explained in Section 8.7.1, "Processor Modes" on page 169.

The target address is statically predictable for all branch and all jump-immediate instructions. If the branch is taken, then the branch-taken-flag will indicate this. All jump-register instructions and ERET/DERET are instructions which have an unpredictable target address. These will have full/delta PC values included in the trace information. Also treated as unpredictable are PC changes which occur due to exceptions, such as an interrupt, reset, etc.

Trace regeneration software is required to know the static program image in memory, in order to reproduce the dynamic flow with the above information. But this is usually not a problem. Only the virtual value of the PC is used. Physical memory location will typically differ.

It is possible to turn on PC delta/full information for all branches, but this should not normally be necessary. As a safety check for trace regeneration software, a periodic synchronization with a full PC is sent. The period of this synchronization is cycle based and programmable.

#### 8.7.4 Load/Store address and data trace information

In addition to PC flow, it is possible to get information on the load/store addresses, as well as the data read/written. When enabled, the following information is optionally added to the trace.

- When load-address tracing is on, the full load address of the first load instruction is traced (indicated by the load-flag). For subsequent loads, a dynamically-determined delta to the previous load address is traced to compress the information which must be sent.
- When store-address tracing is on, the full store address of the first store instruction is traced (indicated by the store-flag). For subsequent stores, a dynamically-determined delta to the previous store address is traced.
- When load-data tracing is on, the full load data read by each load instruction is traced (indicated by the load-flag). Only actual read bytes are traced.
- When store-data tracing is on, the full store data written by each store instruction is traced (indicated by the store-flag). Only written bytes are traced.

After each synchronization instruction, the first load address and the first store address following this are both traced with the full address if load/store address tracing is enabled.

<sup>&</sup>lt;sup>1</sup> A SC (Store Conditional) instruction is not flagged as a store instruction if the load-locked bit prevented the actual store.

#### 8.7.5 Programmable processor trace mode options

To enable tracing, a global Trace On signal must be set. When trace is on, it is possible to enable tracing in any combination of the processor modes described in Section 8.7.1, "Processor Modes" on page 169.

Additionally, an EJTAG Simple Break trigger point can override the processor mode and turn them all on. Another trigger point can disable this override again.

# 8.7.6 Programmable trace information options

The processor mode changes are always traced:

- On the first instruction.
- · On any synchronization instruction.
- When the mode changes and either the previous or the current processor mode is selected for trace.

The amount of extra information traced is programmable to include:

- PC information only.
- · PC and load address.
- · PC and store address.
- PC and load and store address.
- PC and load address and load data.
- PC and store address and store data.
- PC and load and store address and load and store data.
- PC and load data only.

The last option is helpful when used together with instruction accurate simulators. If the full internal state of the processor is known prior to trace start, PC and load data are the only information needed to recreate all register values on an instruction by instruction basis.

#### 8.7.6.1 User Data Trace

In addition to the above, a special CP0 register, *UserTraceData*, can generate a data trace. When this register is written, and the global Trace On is set, then the 32-bit data written is put in the trace as special User Data information.

Remark: The User Data is sent even if the processor is operating in an un-traced processor mode.

#### 8.7.7 Enable trace to probe/on-chip memory

When trace is On, based on the options listed in Section 8.7.5, "Programmable processor trace mode options", the trace information is continuously sent on the PDtrace<sup>TM</sup> interface to the TCB. The TCB must, however, be enabled to transmit the trace information to the Trace probe or to on-chip trace memory, by having the  $TCBCONTROLB_{EN}$  bit set. It is possible to enable and disable the TCB in two ways:

- Set/clear the  $TCBCONTROLB_{EN}$  bit via an EJTAG TAP operation.
- Initialize a TCB trigger to set/clear the  $TCBCONTROLB_{\rm EN}$  bit.

#### 8.7.8 TCB Trigger

The TCB can optionally include 0 to 8 triggers. A TCB trigger can be programmed to fire from any combination of:

- Probe Trigger Input to the TCB.
- Chip-level Trigger Input to the TCB.
- Processor entry into DebugMode.

When a trigger fires it can be programmed to have any combination of actions:

- Create Probe Trigger Output from TCB.
- Create Chip-level Trigger Output from TCB.
- Set, clear, or start countdown to clear the  $\textit{TCBCONTROLB}_{EN}$  bit (start/end/about trigger).
- Put an information byte into the trace stream.

### 8.7.9 Cycle by cycle information

All of the trace information listed in Section 8.7.3, "Trace information" and Section 8.7.4, "Load/Store address and data trace information", will be collected from the PDtrace<sup>TM</sup> interface by the TCB. The trace will then be compressed and aligned to fit in 64 bit trace words, with no loss of information. It is possible to exclude/include the exact cycle-by-cycle relationship between each instruction. If excluded, the number of bits required in the trace information from the TCB is reduced, and each trace word will only contain information from completing instructions.

### 8.7.10 Trace Message Format

The TCB collects trace information every cycle from the PDtrace<sup>TM</sup> interface. This information is collected into six different Trace Formats (TF1 to TF6). The definition of these Trace Formats is proprietary and will not be released at this time. One important feature is that all Trace Formats have at least one non-zero bit.

#### 8.7.11 Trace Word Format

After the PDtrace<sup>TM</sup> data has been turned into Trace Formats, the trace information must be streamed to either on-chip trace memory or to the trace probe. Each of the major Trace Formats are of different size. This complicates how to store this information into an on-chip memory of fixed width without too much wasted space. It also complicates how to transmit data through a fixed-width trace probe interface to off-chip memory. To minimize memory overhead and or bandwidth-loss, the Trace Formats are collected into Trace Words of fixed width.

A Trace Word (TW) is defined to be 64 bits wide. An empty/invalid TW is built of all zeros. A TW which contains one or more valid TF's is guaranteed to have a non-zero value on one of the four least significant bits [3:0]. During operation of the TCB, each TW is built from the TF's generated each clock cycle. When all 64 bits are used, the TW is full and can be sent to either on-chip trace memory or to the trace probe. The exact definition of the TW's is proprietary and will not be released at this time.

### 8.8 PDtrace<sup>TM</sup> Registers (software control)

The CP0 registers associated with PDtrace are listed in Table 8-26 and described in Chapter 5, "CP0 Registers of the M4K<sup>TM</sup> Core."

Table 8-26 A List of Coprocessor 0 Trace Registers

Register Number	Sel	Register Name	Reference
23	1	TraceControl	Section 5.2.18, "Trace Control Register (CP0 Register 23, Select 1)" on page 109
23	2 TraceControl2		Section 5.2.19, "Trace Control2 Register (CP0 Register 23, Select 2)" on page 112
23	3	UserTraceData	Section 5.2.20, "User Trace Data Register (CP0 Register 23, Select 3)" on page 114
23	4	TraceBPC	Section 5.2.21, "TraceBPC Register (CP0 Register 23, Select 4)" on page 115

# 8.9 Trace Control Block (TCB) Registers (hardware control)

The TCB registers used to control its operation are listed in Table 8-27 and Table 8-28. These registers are accessed via the EJTAG TAP interface.

**Table 8-27 TCB EJTAG registers** 

EJTAG Register	Name	Reference	Implemented
0x10	TCBCONTROLA	Section 8.9.1, "TCBCONTROLA Register" on page 173	Yes
0x11	TCBCONTROLB	Section 8.9.2, "TCBCONTROLB Register" on page 176	Yes
0x12	TCBDATA	Section 8.9.3, "TCBDATA Register" on page 180	Yes

Table 8-28 Registers selected by TCBCONTROLB REG

TCBCONTROLB REG field Name		Reference	Implemented
0	TCBCONFIG	Section 8.9.4, "TCBCONFIG Register (Reg 0)" on page 181	Yes
4	TCBTW	Section 8.9.5, "TCBTW Register (Reg 4)" on page 182	
5	TCBRDP	Section 8.9.6, "TCBRDP Register (Reg 5)" on page 183	Yes if on-chip memory
6	TCBWRP	Section 8.9.7, "TCBWRP Register (Reg 6)" on page 183	exists. Otherwise No
7	TCBSTP	Section 8.9.8, "TCBSTP Register (Reg 7)" on page 183	Other wise 140
16-23	TCBTRIGx	Section 8.9.9, "TCBTRIGx Register (Reg 16-23)" on page 184	Only the number indicated by TCBCONFIGTRIG are implemented.

#### 8.9.1 TCBCONTROLA Register

The TCB is responsible for asserting or de-asserting the trace input control signals on the PDtrace interface to the core's tracing logic. Most of the control is done using the *TCBCONTROLA* register.

The TCBCONTROLA register is written by an EJTAG TAP controller instruction, TCBCONTROLA (0x10).

The format of the TCBCONTROLA register is shown below, and the fields are described in Table 8-29.

# TCBCONTROLA Register Format

31	26	25	24	23	22 20	19	18	17	16	15	14	13	12	5	4	3 1	0
0		VM	odes	ADW	SyP	ТВ	Ю	D	Е	0	K	U	ASID		G	Mode	On

# Table 8-29 TCBCONTROLA Register Field Descriptions

Fields					Read/				
Name	Bits		Description	on	Write	Reset State			
0	31:26	Reserved. Must	be written as zero;	returns zero on read.	R	0			
		This field specific processor, as fo	This field specifies the type of tracing that is supported by the processor, as follows:						
		Encoding	Mea	ning					
		00	PC tracing only						
VModes	25:24	01	PC and Load and stor	e address tracing only	R	10			
		10	PC, load and store ad store data.	dress, and load and					
		11	Reserved						
		This field is pre	set to the value of <i>I</i>	PDO_ValidModes.					
		PDO_AD bus w	vidth.						
ADW	23		D bus is 16 bits wid D bus is 32 bits wid	R	0				
		synchronization in the table belo	ow, when the trace b	ch the periodic e sent is defined as shown suffer is either on-chip or eCONTROLB <sub>OfC</sub> bit).					
		000	2 <sup>2</sup>	2 <sup>7</sup>					
		001	2 <sup>3</sup>	28					
SyP	22:20	010	24	29	R/W	100			
		011	25	2 <sup>10</sup>					
		100	2 <sup>6</sup>	2 <sup>11</sup>					
		101	27	2 <sup>12</sup>					
		110	28	2 <sup>13</sup>					
		111	29	2 <sup>14</sup>					
		This field define	es the value on the I	PDI_SyncPeriod signal.					
ТВ	19	the core must tra	ace either full or inc	ne, this field indicates that remental PC values for all e unpredictable branches	R/W	Undefined			
		This field define signal.	es the value on the h	PDI_TraceAllBranch					

Table 8-29 TCBCONTROLA Register Field Descriptions (Continued)

Fie	lds		Read/	
Name	Bits	Description	Write	Reset State
IO	18	Inhibit Overflow. This bit is used to indicate to the core trace logic that slow but complete tracing is desired. Hence, the core tracing logic must not allow a FIFO overflow and discard trace data. This is achieved by stalling the pipeline when the FIFO is nearly full so that no trace records are ever lost.  This field defines the value on the PDI_InhibitOverflow	R/W	Undefined
		signal.		
		When set to one, this enables tracing in Debug mode, i.e., when the DM bit is one in the <i>Debug</i> register. For trace to be enabled in Debug mode, the On bit must be one.		
D	17	When set to zero, trace is disabled in Debug mode, irrespective of other bits.	R/W	Undefined
		This field defines the value on the <i>PDI_DM</i> signal.		
E	16	This controls when tracing is enabled. When set, tracing is enabled when either of the EXL or ERL bits in the <i>Status</i> register is one, provided that the On bit (bit 0) is also se.	R/W	Undefined
		This field defines the value on the <i>PDI_E</i> signal.		
0	15	Reserved. Must be written as zero; returns zero on read.	R	0
K	14	When set, this enables tracing when the On bit is set and the core is in Kernel mode. Unlike the usual definition of Kernel Mode, this bit enables tracing only when the ERL and EXL bits in the <i>Status</i> register are zero. This is provided the On bit (bit 0) is also set.	R/W	Undefined
		This field defines the value on the <i>PDI_K</i> signal.		
U	13	When set, this enables tracing when the core is in User mode as defined in the MIPS32 or MIPS64 architecture specification. This is provided the On bit (bit 0) is also set.	R/W	Undefined
		This field defines the value on the <i>PDI_U</i> signal.		
		The ASID field to match when the G bit is zero. When the G bit is one, this field is ignored.		
ASID	12:5	This field is ignored on the M4K core because there is no ASID.	R/W	Undefined
		This field defines the value on the PDI_ASID signal.		
		When set, this implies that tracing is to be enabled for all processes, provided that other enabling functions (like U, S, etc.,) are also true.		
G	4	This field is ignored on the M4K core because there is no ASID.	R/W	Undefined
		This field defines the value on the <i>PDI_G</i> signal.		

**Table 8-29** TCBCONTROLA Register Field Descriptions (Continued)

Fie	Fields			Read/		
Name	Bits		Description	Write	Reset State	
			g is turned on, this signal specifies what s to be traced by the core.			
		Mode	Mode Trace Mode			
		000	Trace PC			
		001	Trace PC and load address			
		010	Trace PC and store address			
		011 Trace PC and both	Trace PC and both load/store addresses	R/W		
Mode	3:1	100	Currently un-implemented		Undefined	
111000		101	Trace PC and load address and data	10,,,		
				110	Trace PC and store address and data	
		111	Trace PC and both load/store address and data			
		supported by UNPREDIC supported by	field determines which of these encodings are the processor. The operation of the processor is <b>TABLE</b> if Mode is set to a value which is not the processor fines the value on the <i>PDI_TraceMode</i> signal.			
		tracing from	obal trace enable switch to the core. When zero, the core is always disabled, unless enabled by software override of the <i>PDI</i> _* input pins.	Day		
On	0		one, tracing is enabled whenever the other ctions are also true.	R/W	0	
		This field def	ines the value on the <i>PDI_TraceOn</i> signal.			

# 8.9.2 TCBCONTROLB Register

The TCB includes a second control register, *TCBCONTROLB* (0x11). This register generally controls what to do with the trace information received.

The format of the TCBCONTROLB register is shown below, and the fields are described in Table 8-30.

# TCBCONTROLB Register Format

31	30 20	5 25	21 20	19 17	16 15	14	13 12	11	10 8	7	6	3	2	1	0
WE	0	REG	WR	. 0	RM TR	BF	TM	0	CR	Cal	0		CA	OfC	EN

Table 8-30 TCBCONTROLB Register Field Descriptions

Fields Name Bits Description			Read/		
		Description	Write	Reset State	
WE	31	Write Enable.  Only when set to 1 will the other bits be written in TCBCONTROLB.  This bit will always read 0.	R	0	

Table 8-30 TCBCONTROLB Register Field Descriptions (Continued)

Fiel	lds		Read/	
Name	Bits	Description	Write	Reset State
0	30:26	Reserved. Must be written as zero; returns zero on read.	R	0
REG	25:21	Register select: This field select the registers accessible through the <i>TCBDATA</i> register. Legal values are shown in Table 8-28.	R/W	0
WR	20	Write Registers: When set, the register selected by REG field is read and written when <i>TCBDATA</i> is accessed. Otherwise the selected register is only read.	R/W	0
0	19:17	Reserved. Must be written as zero; returns zero on read.	R	0
RM	16	Read on-chip trace memory.  When written to 1, the read address-pointer of the on-chip memory is set to point to the oldest memory location written since the last reset of pointers.  Subsequent access to the <i>TCBTW</i> register (through the <i>TCBDATA</i> register), will automatically increment the read pointer ( <i>TCBRDP</i> register) after each read. [Note: The read pointer does not auto-increment if the WR field is one.]  When the write pointer is reached, this bit is automatically reset to 0, and the <i>TCBTW</i> register will read all zeros.  Once set to 1, writing 1 again will have no effect. The bit is reset by setting the TR bit or by reading the last Trace word in <i>TCBTW</i> .  This bit is reserved if on-chip memory is not implemented.	R/W1	0
TR	15	Trace memory reset.  When written to one, the address pointers for the on-chip trace memory are reset to zero. Also the RM bit is reset to 0.  This bit is automatically de-asserted back to 0, when the reset is completed.  This bit is reserved if on-chip memory is not implemented.	R/W1	0
BF	14	Buffer Full indicator that the TCB uses to communicate to external software in the situation that the on-chip trace memory is being deployed in the <b>trace-from</b> and <b>trace-to</b> mode. (See Section 8.13, "TCB On-Chip Trace Memory")  This bit is cleared when writing 1 to the TR bit  This bit is reserved if on-chip memory is not implemented.	R	0

Table 8-30 TCBCONTROLB Register Field Descriptions (Continued)

Fields			Read/	
Name	Bits	Description	Write	Reset State
		Trace Mode. This field determines how the trace memory is filled when using the simple-break control in the PDtrace <sup>TM</sup> interface to start or stop trace.  TM Trace Mode  00 Trace-To  01 Trace-From  10 Reserved  11 Reserved		
TM	13:12	In Trace-To mode, the on-chip trace memory is filled, continuously wrapping around and overwriting older Trace Words, as long as there is trace data coming from the core.  In Trace-From mode, the on-chip trace memory is filled from the point that <i>PDO_lamTracing</i> is asserted, and until the on-chip trace memory is full.  In both cases, de-asserting the EN bit in this register will also stop fill to the trace memory.  If a <i>TCBTRIGx</i> trigger control register is used to start/stop tracing, then this field should be set to Trace-To mode.  This bit is reserved if on-chip memory is not implemented.	R/W	0
0	11	Reserved. Must be written as zero; returns zero on read.	R	0
CR	10:8	Off-chip Clock Ratio. Writing this field, sets the ratio of the core clock to the off-chip trace memory interface clock. The clock-ratio encoding is shown in Table 8-31 on page 180.  Remark: As the Probe interface works in double data rate (DDR) mode, a 1:2 ratio indicates one data packet sent per core clock rising edge.  This bit is reserved if off-chip trace option is not implemented.	R/W	100

Table 8-30 TCBCONTROLB Register Field Descriptions (Continued)

Fields			Read/	
Name	Bits	Description	Write	Reset State
Cal	7	Calibrate off-chip trace interface.  If set to one, the off-chip trace pins will produce the following pattern in consecutive trace clock cycles. If more than 4 data pins exist, the pattern is replicated for each set of 4 pins. The pattern repeats from top to bottom until the Cal bit is de-asserted.  Calibrations  pattern  3 2 1 0  Calibrations  pattern  3 2 1 0  Vigit 1 1 1 1 1  0 0 0 0 0  0 1 0 1  1 0 1 0  Pattern  Sind 1 0 1 0 0  Pattern  Sind 1 0 1 0 0  Pattern  O 0 0 0 0 0  O 1 0 1  O 1 0 1  O 0 0 0 0  Pattern  I I I I I I I I I I I I I I I I I I I	R/W	0
0	6:3	Reserved. Must be written as zero; returns zero on read.	R	0
CA	2	Cycle accurate trace.  When set to 1, the trace will include stall information. When set to 0, the trace will exclude stall information, and remove bit zero from all transmitted TF's.  The stall information included/excluded is:  • TF6 formats with TCBcode 0001 and 0101.  • All TF1 formats.	R/W	0
OfC	1	If set to 1, trace is sent to off-chip memory using <i>TR_DATA</i> pins.  If set to 0, trace info is sent to on-chip memory.  This bit is read only if a single memory option exists (either off-chip or on-chip only).	R/W	Preset

Table 8-30 TCBCONTROLB Register Field Descriptions (Continued)

Fields			Read/	
Name	Bits	Description	Write	Reset State
EN	0	Enable trace.  This is the master enable for trace to be generated from the TCB. This bit can be set or cleared, either by writing this register or from a start/stop/about trigger.  When set to 1, trace information is sampled on the PDO_* pins. Trace Words are generated and sent to either on-chip memory or to the Trace Probe. The target of the trace is selected by the OfC bit.  When set to 0, trace information on the PDO_* pins is ignored. A potential TF6-stop (from a stop trigger) is generated as the last information, the TCB pipe-line is flushed, and trace output is stopped.	R/W	0

Table 8-31 Clock Ratio encoding of the CR field

CR/CRMin/CRMax	Clock Ratio
000	8:1 (Trace clock is eight times that of core clock)
001	4:1 (Trace clock is four times that of core clock)
010	2:1 (Trace clock is double that of core clock)
011	1:1 (Trace clock is same as core clock)
100	1:2 (Trace clock is one half of core clock)
101	1:4 (Trace clock is one fourth of core clock)
110	1:6 (Trace clock is one sixth of core clock)
111	1:8 (Trace clock is one eighth of core clock)

# 8.9.3 TCBDATA Register

The TCBDATA register (0x12) is used to access the registers defined by the  $TCBCONTROLB_{REG}$  field; see Table 8-28. Regardless of which register or data entry is accessed through TCBDATA, the register is only written if the  $TCBCONTROLB_{WR}$  bit is set. For read-only registers, the  $TCBCONTROLB_{WR}$  is a don't care.

The format of the *TCBDATA* register is shown below, and the field is described in Table 8-32. The width of *TCBDATA* is 64 bits when on-chip trace words (TWs) are accessed (*TCBTW* access).

# **TCBDATA** Register Format




Table 8-32 TCBDATA Register Field Descriptions

Fields				Reset
Names	Bits	Description	Read/Write	State
Data	31:0 63:0	Register fields or data as defined by the TCBCONTROLB <sub>REG</sub> field	Only writable if TCBCONTROLB <sub>WR</sub> is set	0

# 8.9.4 TCBCONFIG Register (Reg 0)

The *TCBCONFIG* register holds information about the hardware configuration of the TCB. The format of the *TCBCONFIG* register is shown below, and the field is described in Table 8-33.

# **TCBCONFIG** Register Format

31	30	24 21	20 17		4 13	11	10 9	8	6 5	4	3	0
CF1	0	TRIG	SZ	CRMax	CRI	Min	PW	PiN	On'	ΓOfT	REV	

Table 8-33 TCBCONFIG Register Field Descriptions

Fiel	ds		Read/	
Name	Bits	Description	Write	Reset State
CF1	31	This bit is set if a <i>TCBCONFIG1</i> register exists. In this revision, <i>TCBCONFIG1</i> does not exist and this bit always reads zero.	R	0
0	30:25	Reserved. Must be written as zero; returns zero on read.	R	0
TRIG	24:21	Number of triggers implemented. This also indicates the number of <i>TCBTRIGx</i> registers that exist.	R	Legal values are 0 - 8
SZ	20:17	On-chip trace memory size. This field holds the encoded size of the on-chip trace memory.  The size in bytes is given by 2 <sup>(SZ+8)</sup> , implying that the minimum size is 256 bytes and the largest is 8Mb.  This bit is reserved if on-chip memory is not implemented.	R	Preset
CRMax	16:14	Off-chip Maximum Clock Ratio.  This field indicates the maximum ratio of the core clock to the off-chip trace memory interface clock. The clock-ratio encoding is shown in Table 8-31 on page 180.  This bit is reserved if off-chip trace option is not implemented.	R	Preset
CRMin	13:11	Off-chip Minimum Clock Ratio.  This field indicates the minimum ratio of the core clock to the off-chip trace memory interface clock. The clock-ratio encoding is shown in Table 8-31 on page 180.  This bit is reserved if off-chip trace option is not implemented.	R	Preset

Table 8-33 TCBCONFIG Register Field Descriptions (Continued)

Fields				Read/	
Name	Bits		Description	Write	Reset State
		interface TR_	Number of bits available on the off-chip trace <i>DATA</i> pins. The number of TR_DATA pins is shown in the table.		
		PW	Number of bits used on TR_DATA		
		00	4 bits		
PW	10:9	01	8 bits	R	Preset
1 **	10.7	10	16 bits	K	Tieset
		11	reserved		
		actual capabi	preset based on input signals to the TCB and the lity of the TCB.  Berved if off-chip trace option is not implemented.		
PiN	8:6	Pipe number. Indicates the	number of execution pipelines.	R	0
OnT	5		is bit indicates that on-chip trace memory is bit is preset based on the selected option when inplemented.	R	Preset
OfT	4	present. This the TCB is in	is bit indicates that off-chip trace interface is bit is preset based on the selected option when aplemented, and on the existence of a PIB module <i>ent</i> asserted).	R	Preset
REV	3:0		TCB. An implementation that conforms to the chitecture in this document must have revision 0.	R	0

# 8.9.5 TCBTW Register (Reg 4)

The *TCBTW* register is used to read Trace Words from the on-chip trace memory. The TW read is the one pointed to by the *TCBRDP* register. A side effect of reading the *TCBTW* register is that the *TCBRDP* register increments to the next TW in the on-chip trace memory. If *TCBRDP* is at the max size of the on-chip trace memory, the increment wraps back to address zero.

This register is reserved if on-chip trace memory is not implemented.

The format of the TCBTW register is shown below, and the field is described in Table 8-34.

#### **TCBTW** Register Format

63 0 Data

**Table 8-34** *TCBTW* **Register Field Descriptions** 

Fie	elds		Read/	Reset
Names	Bits	Description	Write	State
Data	63:0	Trace Word	R/W	0

### 8.9.6 TCBRDP Register (Reg 5)

The *TCBRDP* register is the address pointer to on-chip trace memory. It points to the TW read when reading the *TCBTW* register. When writing the *TCBCONTROLB*<sub>RM</sub> bit to 1, this pointer is reset to the current value of *TCBSTP*.

This register is reserved if on-chip trace memory is not implemented.

The format of the *TCBRDP* register is shown below, and the field is described in Table 8-35. The value of n depends on the size of the on-chip trace memory. As the address points to a 64-bit TW, lower three bits are always zero.

#### **TCBRDP** Register Format



Table 8-35 TCBRDP Register Field Descriptions

Fields			Read/	Reset
Names	Bits	Description	Write	State
Data	31:(n+1)	Reserved. Must be written zero, reads back zero.	0	0
Address	n:0	Byte address of on-chip trace memory word.	R/W	0

#### 8.9.7 TCBWRP Register (Reg 6)

The *TCBWRP* register is the address pointer to on-chip trace memory. It points to the location where the next new TW for on-chip trace will be written.

This register is reserved if on-chip trace memory is not implemented.

The format of the *TCBWRP* register is shown below, and the fields are described in Table 8-36. The value of n depends on the size of the on-chip trace memory. As the address points to a 64-bit TW, the lower three bits are always zero.

### **TCBWRP** Register Format



Table 8-36 TCBWRP Register Field Descriptions

Fields			Read/	Reset
Names	Bits	Description	Write	State
Data	31:(n+1)	Reserved. Must be written zero, reads back zero.	0	0
Address	n:0	Byte address of on-chip trace memory word.	R/W	0

# 8.9.8 TCBSTP Register (Reg 7)

The TCBSTP register is the start pointer register. This register points to the on-chip trace memory address at which the oldest TW is located. This pointer is reset to zero when the  $TCBCONTROLB_{TR}$  bit is written to 1. If a continuous trace to on-chip memory wraps around the on-chip memory, TSBSTP will have the same value as TCBWRP.

This register is reserved if on-chip trace memory is not implemented.

The format of the *TCBSTP* register is shown below, and the fields are described in Table 8-37. The value of n depends on the size of the on-chip trace memory. As the address points to a 64-bit TW, lower three bits are always zero.

### TCBSTP Register Format




Table 8-37 TCBSTP Register Field Descriptions

Fields			Read/	Reset
Names	Bits	Description	Write	State
Data	31:(n+1)	Reserved. Must be written zero, reads back zero.	0	0
Address	n:0	Byte address of on-chip trace memory word.	R/W	0

# 8.9.9 TCBTRIGx Register (Reg 16-23)

Up to eight Trigger Control registers are possible. Each register is named *TCBTRIGx*, where *x* is a single digit number from 0 to 7 (*TCBTRIG0* is Reg 16). The actual number of trigger registers implemented is defined in the *TCBCONFIG*<sub>TRIG</sub> field. An unimplemented register will read all zeros and writes are ignored.

Each Trigger Control register controls when an associated trigger is fired, and the action to be taken when the trigger occurs. Please also read Chapter 8, "EJTAG Debug Support in the M4K<sup>TM</sup> Core," on page 189, for detailed description of trigger logic issues.

The format of the TCBTRIGx register is shown below, and the fields are described in Table 8-38.

### TCBTRIGx Register Format




Table 8-38 TCBTRIGx Register Field Descriptions

Fields			Read/	Reset
Names	Bits	Description	Write	State
TCBinfo	31:24	TCBinfo to be used in a possible TF6 trace format when this trigger fires.	R/W	0
		When set, generate TF6 trace information when this trigger fires. Use TCBinfo field for the TCBinfo of TF6 and use Type field for the two MSB of the TCBtype of TF6. The two LSB of TCBtype are 00.		
Trace	23	The write value of this bit always controls the behavior of this trigger.  When this trigger fires, the read value will change to indicate if the TF6 format was ever suppressed by a simultaneous trigger. If so,	R/W	0
		the read value will be 0. If the write value was 0, the read value is always 0. This special read value is valid until the <i>TCBTRIGx</i> register is written.		

 Table 8-38 TCBTRIGx
 Register Field Descriptions (Continued)

Fields			Read/	Reset
Names	Bits	Description	Write	State
0	22:16	Reserved. Must be written as zero; returns zero on read.	R	0
CHTro	15	When set, generate a single cycle strobe on TC_ChipTrigOut when this trigger fires.	R/W	0
PDTro	14	When set, generate a single cycle strobe on TC_ProbeTrigOut when this trigger fires.	R/W	0
0	13:7	Reserved. Must be written as zero; returns zero on read.	R	0
DM	6	When set, this Trigger will fire when a rising edge on the Debug mode indication from the core is detected.  The write value of this bit always controls the behavior of this trigger.  When this trigger fires, the read value will change to indicate if this source was ever the cause of a trigger action (even if the action was suppressed). If so the read value will be 1. If the write value was 0 the read value is always 0. This special read value is valid until the <i>TCBTRIGx</i> register is written.	R/W	0
CHTri	5	When set, this Trigger will fire when a rising edge on $TC\_ChipTrigIn$ is detected.  The write value of this bit always controls the behavior of this trigger.  When this trigger fires, the read value will change to indicate if this source was ever the cause of a trigger action (even if the action was suppressed). If so the read value will be 1. If the write value was 0 the read value is always 0. This special read value is valid until the $TCBTRIGx$ register is written.	R/W	0
PDTri	4	When set, this Trigger will fire when a rising edge on <i>TC_ProbeTrigIn</i> is detected.  The write value of this bit always controls the behavior of this trigger.  When this trigger fires, the read value will change to indicate if this source was ever the cause of a trigger action (even if the action was suppressed). If so the read value will be 1. If the write value was 0 the read value is always 0. This special read value is valid until the <i>TCBTRIGx</i> register is written.	R/W	0

Table 8-38 TCBTRIGx Register Field Descriptions (Continued)

Fields			Read/	Reset	
Names	Bits	Write	State		
		Trigger Type: The Type indicates the action to take when this trigger fires. The table below show the Type values and the Trigger action.  Type Trigger action  00 Trigger Start: Trigger start-point of trace.			
		01 <b>Trigger End:</b> Trigger end-point of trace.			
		10 <b>Trigger About:</b> Trigger center-point of trace.			
		Trigger Info: No action trigger, only for trace info.			
Туре	3:2	The actual action is to set or clear the <i>TCBCONTROLB</i> <sub>EN</sub> bit. A Start trigger will set <i>TCBCONTROLB</i> <sub>EN</sub> , a End trigger will clear <i>TCBCONTROLB</i> <sub>EN</sub> . The About trigger will clear <i>TCBCONTROLB</i> <sub>EN</sub> half way through the trace memory, from the trigger. The size determined by the <i>TCBCONFIG</i> <sub>SZ</sub> field for on-chip memory. Or from the <i>TCBCONTROLA</i> <sub>SyP</sub> field for off-chip trace.  If Trace is set, then a TF6 format is added to the trace words. For Start and Info triggers this is done before any other TF's in that same cycle. For End and About triggers, the TF6 format is added after any other TF's in that same cycle.  If the <i>TCBCONTROLB</i> <sub>TM</sub> field is implemented it must be set to Trace-To mode (00), for the Type field to control on-chip trace fill. The write value of this bit always controls the behavior of this trigger.  When this trigger fires, the read value will change to indicate if the trigger action was ever suppressed. If so the read value will be 11. If the write value was 11 the read value is always 11. This special read value is valid until the <i>TCBTRIGx</i> register is written.	R/W	0	
FO	1	Fire Once. When set, this trigger will not re-fire until the TR bit is de-asserted. When de-asserted this trigger will fire each time one of the trigger sources indicates trigger.	R/W	0	
TR	0	Trigger happened. When set, this trigger fired since the TR bit was last written 0.  This bit is used to inspect whether the trigger fired since this bit was last written zero.  When set, all the trigger source bits (bit 4 to 13) will change their read value to indicate if the particular bit was the source to fire this trigger. Only enabled trigger sources can set the read value, but more than one is possible.  Also when set the Type field and the Trace field will have read values which indicate if the trigger action was ever suppressed by	R/W0	0	

# 8.9.10 Register Reset State

Reset state for all register fields is entered when either of the following occur:

- 1. TAP controller enters/is in Test-Logic-Reset state.
- 2. *EJ\_TRST\_N* input is asserted low.

# 8.10 EJTAG Trace Enabling

As there are several ways to enable tracing, it can be quite confusing to figure out how to turn tracing on and off. This section should help clarify the enabling of trace.

### 8.10.1 Trace Trigger from EJTAG Hardware Instruction/Data Breakpoints

If hardware instruction/data simple breakpoints are implemented in the M4K core, then these breakpoint can be used as triggers to start/stop trace. When used for this, the breakpoints need not also generate a debug exception, but are capable of only generating an internal trigger to the trace logic. This is done by only setting the TE bit and not the BE bit in the Breakpoint Control register. Please see Section 8.2.8.5, "Instruction Breakpoint Control n (IBCn) Register" on page 142 and Section 8.2.9.5, "Data Breakpoint Control n (DBCn) Register" on page 148, for details on breakpoint control.

In connection with the breakpoints, the Trace BreakPoint Control (*TraceBPC*) register is used to define the trace action when a trigger happens. When a breakpoint is enabled as a trigger (TE = 1), it can be selected to be either a start or a stop trigger to the trace logic. Please see Section 5.2.21, "TraceBPC Register (CP0 Register 23, Select 4)" on page 115 for detail in how to define a start/stop trigger.

### 8.10.2 Turning On PDtrace<sup>TM</sup> Trace

Trace enabling and disabling from software is similar to the hardware method, with the exception that the bits in the control register are used instead of the input enable signals from the TCB. The  $TraceControl_{TS}$  bit controls whether hardware (via the TCB), or software (via the TraceControl register) controls tracing functionality.

Trace is turned on when the following expression evaluates true:

```
(TraceControl_{TS} \text{ and } TraceControl_{On}) or
               ((not TraceControl_{TS}) and TCBCONTROLA_{On})
          (MatchEnable or TriggerEnable)
where,
      MatchEnable \leftarrow
      (
          TraceControl_{TS}
          and
              TraceControl_{G} or
               (((TraceControl_{ASID} xor EntryHi_{ASID}) and (not TraceControl_{ASID} M)) = 0)
          )
          and
               (TraceControl<sub>U</sub> and UserMode)
               (TraceControl_{K} and KernelMode)
               (TraceControl_{E} \text{ and ExceptionMode}) \text{ or }
               (TraceControl<sub>D</sub> and DebugMode)
      )
      or
          (not TraceControl<sub>TS</sub>)
```

```
and
            (TCBCONTROLA_{G} \text{ or } (TCBCONTROLA_{ASID} = EntryHi_{ASID}))
            and
            (
                  (TCBCONTROLA<sub>U</sub> and UserMode)
                                                                      or
                  (TCBCONTROLA_{K} and KernelMode)
                                                                      or
                  (TCBCONTROLA<sub>E</sub> and ExceptionMode) or
                  (TCBCONTROLA_{DM} and DebugMode)
            )
and where,
       TriggerEnable \leftarrow
            \mathtt{DBCi}_{\mathtt{TE}}
                                 and
            \mathtt{DBS}_{\mathtt{BS[i]}}
                                 and
            TraceBPC_{DE}
                                 and
            (TraceBPC_{DBPOn[i]} = 1)
       )
       or
            \mathtt{IBCi}_{\mathtt{TE}}
                                 and
                                 and
            IBS<sub>BS[i]</sub>
            {\tt TraceBPC_{IE}}
                                 and
            (TraceBPC_{IBPOn[i]} = 1)
       )
```

As seen in the expression above, trace can be turned on only if the master switch  $TraceControl_{On}$  or  $TCBCONTROLA_{On}$  is first asserted.

Once this is asserted, there are two ways to turn on tracing. The first way, the *MatchEnable* expression, uses the input enable signals from the TCB or the bits in the *TraceControl* register. This tracing is done over general program areas. For example, all of the user-level code, and so on.

The second way to turn on tracing, the *TriggerEnable* expression, is from the processor side using the EJTAG hardware breakpoint triggers. If EJTAG is implemented, and hardware breakpoints can be set, then using this method enables finer grain tracing control. It is possible to send a trigger signal that turns on tracing at a particular instruction. For example, it would be possible to trace a single procedure in a program by triggering on trace at the first instruction, and triggering off trace at the last instruction.

The easiest way to unconditionally turn on trace is to assert either hardware or software tracing and the corresponding trace on signal with other enables. For example, with  $TraceControl_{TS}=0$ , i.e., hardware controlled tracing, assert  $TCBCONTROLA_{On}$  and all the other signals in the second part of expression MatchEnable. When using the EJTAG hardware triggers to turn trace on and off, it is best if  $TCBCONTROLA_{On}$  is asserted and all the other processor mode selection bits in TCBCONTROLA are turned off. This would be the least confusing way to control tracing with the trigger signals. Tracing can be controlled via software with the TraceControl register in a similar manner.

# 8.10.3 Turning Off PDtrace<sup>TM</sup> Trace

Trace is turned off when the following expression evaluates true:

```
(  ({\tt TraceControl}_{\tt TS} \ {\tt and} \ ({\tt not} \ {\tt TraceControl}_{\tt On})) \ {\tt and} \ (({\tt not} \ {\tt TraceControl}_{\tt TS}) \ {\tt and} \ ({\tt not} \ {\tt TCBCONTROLA}_{\tt On}))  or (
```

```
(not MatchEnable)
                                                    and
             (not TriggerEnable)
             TriggerDisable
where,
        TriggerDisable \leftarrow
             \mathtt{DBCi}_{\mathtt{TE}}
                                   and
             DBS<sub>BS[i]</sub>
                                   and
             \mathtt{TraceBPC}_{\mathtt{DE}}
             (TraceBPC_{DBPOn[i]} = 0)
        )
       or
             \mathtt{IBCi}_{\mathtt{TE}}
                                   and
             IBS<sub>BS[i]</sub>
                                   and
             TraceBPC_{IE}
                                   and
             (TraceBPC_{IBPOn[i]} = 0)
```

Tracing can be unconditionally turned off by de-asserting the *TraceControl*<sub>On</sub> bit or the *TCBCONTROLA*<sub>On</sub> signal. When either of these are asserted, tracing can be turned off if all of the enables are de-asserted. EJTAG hardware breakpoints can be used to trigger trace off as well. Note that if simultaneous triggers are generated, and even one of them turns on tracing, then even if all of the others attempt to trigger trace off, then tracing will still be turned on. This condition is reflected in presence of the "(not TriggerEnable)" term in the expression above.

#### 8.10.4 TCB Trace Enabling

The TCB must be enabled in order to produce a trace on the probe or to on-chip memory, when trace information is sent on the PDtrace<sup>TM</sup> interface. The main switch for this is the  $TCBCONTROLB_{EN}$  bit. When set, the TCB will send trace information to either on-chip trace memory or to the Trace Probe, controlled by the setting of the  $TCBCONTROLB_{OfC}$  bit.

The TCB can optionally include trigger logic, which can control the *TCBCONTROLB*<sub>EN</sub> bit. Please see Section 8.11, "TCB Trigger logic" for details.

#### 8.10.5 Tracing a reset exception

Tracing a reset exception is possible. However, the  $TraceControl_{TS}$  bit is reset to 0 at core reset, so all the trace control must be from the TCB (using TCBCONTROLA and TCBCONTROLB). The PDtrace fifo and the entire TCB are reset based on an EJTAG reset. It is thus possible to set up the trace modes, etc., using the TAP controller, and then reset the processor core.

#### 8.11 TCB Trigger logic

The TCB is optionally implemented with trigger unit. If this is the case, then the TCBCONFIGTRIG field is non-zero. This section will explain some of the issues around triggers in the TCB.

#### 8.11.1 Trigger units overview

A TCB trigger logic features three main parts.

- 1. A common Trigger Source detection unit.
- 2. 1 to 8 separate Trigger Control units.
- 3. A common Trigger Action unit.

Figure 8-6 show the functional overview of the trigger flow in the TCB.




Figure 8-6 TCB Trigger processing overview

#### 8.11.2 Trigger Source Unit

The TCB has three trigger sources:

1.Chip-level trigger input (*TC\_ChipTrigIn*).

- 2. Probe trigger input (*TR\_TRIGIN*).
- 3. Debug Mode (DM) entry indication from the processor core.

The input triggers are all rising-edge triggers, and the Trigger Source Units convert the edge into a single cycle strobe to the Trigger Control Units.

#### **8.11.3** Trigger Control Units

Up to eight Trigger Control Units are possible. Each of them has it's own Trigger Control Register (TCBTRIGx,  $x=\{0..7\}$ ). Each of these registers controls the trigger fire mechanism for the unit. Each unit has all of the Trigger Sources as possible trigger event and they can fire one or more of the Trigger Actions. This is all defined in the Trigger Control register TCBTRIGx (see Section 8.9.9, "TCBTRIGx Register (Reg 16-23)" on page 184).

#### **8.11.4** Trigger Action Unit

The TCB has four possible trigger actions:

- 1. Chip-level trigger output (*TC\_ChipTrigOut*).
- 2. Probe trigger output (*TR\_TRIGOUT*).
- 3. Trace information. Put a programmable byte into the trace stream from the TCB.
- 4. Start, End or About (delayed end) control of the TCBCONTROLB<sub>EN</sub> bit.

The basic function of the trigger actions is explained in Section 8.9.9, "TCBTRIGx Register (Reg 16-23)" on page 184. Please also read the next Section 8.11.5, "Simultaneous triggers".

### 8.11.5 Simultaneous triggers

Two or more triggers can fire simultaneously. The resulting behavior depends on trigger action set for each of them, and whether they should produce a TF6 trace information output or not. There are two groups of trigger actions: Prioritized and OR'ed.

#### 8.11.5.1 Prioritized trigger actions

For prioritized simultaneous trigger actions, the trigger control unit which has the lowest number takes precedence over the higher numbered units. The *x* in *TCBTRIGx* registers defines the number. The oldest trigger takes precedence over everything.

The following trigger actions are prioritized when two or more units fire simultaneously:

- Trigger Start, End and About type triggers (*TCBTRIGx*<sub>Type</sub> field set to 00, 01 or 10), which will assert/de-assert the *TCBCONTROLB*<sub>EN</sub> bit. The About trigger is delayed and will always change *TCBCONTROLB*<sub>EN</sub> because it is the oldest trigger when it de-asserts *TCBCONTROLB*<sub>EN</sub>. An About trigger will not start the countdown if an even older About trigger is using the Trace Word counter.
- Triggers which produce TF6 trace information in the trace flow (Trace bit is set).

Regardless of priority, the  $TCBTRIGx_{TR}$  bit is set when the trigger fires. This is so even if a trigger action is suppressed by a higher priority trigger action. If the trigger is set to only fire once (the  $TCBTRIGx_{FO}$  bit is set), then the suppressed trigger action will not happen until after  $TCBTRIGx_{TR}$  is written 0.

If a Trigger action is suppressed by a higher priority trigger, then the read value, when the  $TCBTRIGx_{TR}$  bit is set, for the  $TCBTRIGx_{Trace}$  field will be 0 for suppressed TF6 trace information actions. The read value in the  $TCBTRIGx_{Type}$  field for suppressed Start/End/About triggers will be 11. This indication of a suppressed action is sticky. If any of the two actions (Trace and Type) are ever suppressed for a multi-fire trigger (the  $TCBTRIGx_{FO}$  bit is zero), then the read values in Trace and/or Type are set to indicate any suppressed action.

#### About trigger

The About triggers delayed de-assertion of the  $TCBCONTROLB_{EN}$  bit is always executed, regardless of priority from another Start trigger at the time of the  $TCBCONTROLB_{EN}$  change. This means that if a simultaneous About trigger action on the  $TCBCONTROLB_{EN}$  bit (n/2 Trace Words after the trigger) and a Start trigger hit the same cycle, then the About trigger wins, regardless of which trigger number it is. The oldest trigger takes precedence.

However, if an About trigger has started the count down from n/2, but not yet reached zero, then a new About trigger, will NOT be executed. Only one About trigger can have the cycle counter. This second About trigger will store 11 in the  $TCBTRIGx_{Type}$  field. But, if the  $TCBTRIGx_{Trace}$  bit is set, a TF6 trace information will still go in the trace.

#### 8.11.5.2 OR'ed trigger actions

The simple trigger actions CHTro and PDTro from each trigger unit, are effectively OR'ed together to produce the final trigger. One or more expected trigger strobes on i.e.  $TC\_ChipTrigOut$  can thus disappear. External logic should not rely on counting of strobes, to predict a specific event, unless simultaneous triggers are known not to occur.

## 8.12 EJTAG Trace cycle-by-cycle behavior

A key reason for using trace, and not single stepping to debug a software problem, is often to get a picture of the real-time behavior. However the trace logic itself can, when enabled, affect the exact cycle-by-cycle behavior,

### 8.12.1 Fifo logic in PDtrace and TCB modules

Both the PDtrace module and the TCB module contain a fifo. This might seem like extra overhead, but there are good reasons for this. The vast majority of the information compression happens in the PDtrace module. Any data information, like PC and load/store address values (delta or full), load/store data and processor mode changes, are all sent on the same 16 data bus to the TCB on the PDtrace<sup>TM</sup> interface. When an instruction requires more than 16 bits of information to be traced properly, the PDtrace fifo will buffer the information, and send it on subsequent clock cycles.

In the TCB, the on-chip trace memory is defined as a 64-bit wide synchronous memory running at core-clock speed. In this case the fifo is not needed. For off-chip trace through the Trace Probe, the fifo comes into play, because only a limited number of pins (4, 8 or 16) exist. Also the speed of the Trace Probe interface can be different (either faster or slower) from that of the M4K core. So for off-chip tracing, a specific TCB TW fifo is needed.

#### 8.12.2 Handling of Fifo overflow in the PDtrace module

Depending on the amount of trace information selected for trace, and the frequency with which the 16-bit data interface is needed, it is possible for the PDtrace fifo overflow from time to time. There are two ways to handle this case:

- 1. Allow the overflow to happen, and thereby lose some information from the trace data.
- 2. Prevent the overflow by back-stalling the core, until the fifo has enough empty slots to accept new trace data.

The PDtrace fifo option is controlled by either the  $TraceControl_{IO}$  or the  $TCBCONTROLA_{IO}$  bit, depending on the setting of  $TraceControl_{TS}$  bit.

The first option is free of any cycle-by-cycle change whether trace is turned on or not. This is achieved at the cost of potentially losing trace information. After an overflow, the fifo is completely emptied, and the next instruction is traced as if it was the start of the trace (processor mode and full PC are traced). This guarantees that only the un-traced fifo information is lost.

The second option guarantees that all the trace information is traced to the TCB. In some cases this is then achieved by back-stalling the core pipeline, giving the PDtrace fifo time to empty enough room in the fifo to accept new trace information from a new instruction. This option can obviously change the real-time behavior of the core when tracing is turned on.

If PC trace information is the only thing enabled (in  $TraceControl_{MODE}$  or  $TCBCONTROLA_{MODE}$ , depending on the setting of  $TraceControl_{TS}$ ), and Trace of all branches is turned off (via  $TraceControl_{TB}$  or  $TCBCONTROLA_{TB}$ , depending on the setting of  $TraceControl_{TS}$ ), then the fifo is unlikely to overflow very often, if at all. This is of course very dependent on the code executed, and the frequency of exception handler jumps, but with this setting there is very little information overhead.

#### 8.12.3 Handling of Fifo overflow in the TCB

The TCB also holds a fifo, used to buffer the TW's which are sent off-chip through the Trace Probe. The data width of the probe can be either 4, 8 or 16 pins, and the speed of these data pins can be from 16 times the core-clock to 1/4 of the core clock (the trace probe clock always runs at a double data rate multiple to the core-clock). See Section 8.12.3.1, "Probe width and Clock-ratio settings" for a description of probe width and clock-ratio options. The combination between the probe width (4, 8 or 16) and the data speed, allows for data rates through the trace probe from 256 bits per core-clock cycle down to only 1 bit per core-clock cycle. The high extreme is not likely to be supported in any implementation, but the low one might be.

The data rate is an important figure when the likelihood of a TCB fifo overflow is considered. The TCB will at maximum produce one full 64-bit TW per core-clock cycle. This is true for any selection of trace mode in  $TraceControl_{MODE}$  or  $TCBCONTROLA_{MODE}$ . The PDtrace module will guarantee the limited amount of data. If the TCB data rate cannot be matched by the off-chip probe width and data speed, then the TCB fifo can possibly overflow. There is only one way to handle this:

1. Prevent the overflow by asserting a stall-signal back to the core (*PDI\_StallSending*). This will in turn stall the core pipeline.

There is no way to guarantee that this back-stall from the TCB is never asserted, unless the effective data rate of the Trace Probe interface is at least 64-bits per core-clock cycle.

As a practical matter, the amount of data to the TCB can be minimized by only tracing PC information and excluding any cycle accurate information. This is explained in Section 8.12.2, "Handling of Fifo overflow in the PDtrace module" and below in Section 8.12.4, "Adding cycle accurate information to the trace". With this setting, a data rate of 8-bits per core-clock cycle is usually sufficient. No guarantees can be given here, however, as heavy interrupt activity can increase the number of unpredictable jumps considerably.

#### 8.12.3.1 Probe width and Clock-ratio settings

The actual number of data pins (4, 8 or 16) is defined by the *TCBCONFIG*<sub>PW</sub> field. Furthermore, the frequency of the Trace Probe can be different from the core-clock frequency. The trace clock (*TR\_CLK*) is a double data rate clock. This means that the data pins (*TR\_DATA*) change their value on both edges of the trace clock. When the trace clock is running at clock ratio of 1:2 (one half) of core clock, the data output registers are running a core-clock frequency. The clock ratio is set in the *TCBCONTROLB*<sub>CR</sub> field. The legal range for the clock ratio is defined in *TCBCONFIG*<sub>CRMax</sub> and *TCBCONFIG*<sub>CRMin</sub> (both values inclusive). If *TCBCONTROLB*<sub>CR</sub> is set to an unsupported value, the result is UNPREDICABLE. The maximum possible value for *TCBCONFIG*<sub>CRMax</sub> is 8:1 (*TR\_CLK* is running 8 times faster than core-clock). The minimum possible value for *TCBCONFIG*<sub>CRMin</sub> is 1:8 (*TR\_CLK* is running at one eighth of the core-clock). See Table 8-31 on page 180 for a description of the encoding of the clock ratio fields.

#### 8.12.4 Adding cycle accurate information to the trace

Depending on the trace regeneration software, it is possible to obtain the exact cycle time relationship between each instruction in the trace. This information is added to the trace, when the  $TCBCONTROLB_{CA}$  bit is set. The overhead on the trace information is a little more than one extra bit per core-clock cycle.

This setting only affects the TCB module and not the PDtrace module. The extra bit therefore only affects the likelihood of the TCB fifo overflowing.

# 8.13 TCB On-Chip Trace Memory

When on-chip trace memory is available ( $TCBCONFIG_{OnT}$  is set) the memory is typically of smaller size than if it were external in a trace probe. The assumption is that it is of some value to trace a smaller piece of the program.

With on-chip trace memory, the TCB can work in three possible modes:

- 1. Trace-From mode.
- 2. Trace-To mode.
- 3. Under Trigger unit control.

Software can select this mode using the  $TCBCONTROLB_{TM}$  field. If one or more trigger control registers (TCBTRIGx) are implemented, and they are using Start, End or About triggers, then the trace mode in  $TCBCONTROLB_{TM}$  should be set to Trace-To mode.

### 8.13.1 On-Chip Trace Memory size

The supported On-chip trace memory size can range from 256 byte to 8Mbytes, in powers of 2. The actual size is shown in the *TCBCONFIG*<sub>SZ</sub> field.

#### 8.13.2 Trace-From Mode

In the Trace-From mode, tracing begins when the processor enters into a processor mode/ASID value which is defined to be traced or when an EJTAG hardware breakpoint trace trigger turns on tracing. Trace collection is stopped when the buffer is full. The TCB then signals buffer full using  $TCBCONTROLB_{BF}$ . When external software polling this register finds the  $TCBCONTROLB_{BF}$  bit set, it can then read out the internal trace memory. Saving the trace into the internal buffer will re-commence again only when the  $TCBCONTROLB_{BF}$  bit is reset and if the core is sending valid trace data (i.e.,  $PDO\_IamTracing$  not equal 0).

## 8.13.3 Trace-To Mode

In the Trace-To mode, the TCB keeps writing into the internal trace memory, wrapping over and overwriting the oldest information, until the processor is reaches an end of trace condition. End of trace is reached by leaving the processor mode/ASID value which is traced, or when an EJTAG hardware breakpoint trace trigger turns tracing off. At this point, the on-chip trace buffer is then dumped out in a manner similar to that described above in Section 8.13.2, "Trace-From Mode".

# **Instruction Set Overview**


This chapter provides a general overview on the three CPU instruction set formats of the MIPS architecture: Immediate, Jump, and Register. Refer to Chapter 10, "M4K<sup>TM</sup> Processor Core Instructions," for a complete listing and description of instructions.

This chapter discusses the following topics

- Section 9.1, "CPU Instruction Formats" on page 196
- Section 9.2, "Load and Store Instructions" on page 197
- Section 9.3, "Computational Instructions" on page 198
- Section 9.4, "Jump and Branch Instructions" on page 199
- Section 9.5, "Control Instructions" on page 199
- Section 9.6, "Coprocessor Instructions" on page 199

#### 9.1 CPU Instruction Formats

Each CPU instruction consists of a single 32-bit word, aligned on a word boundary. There are three instruction formats immediate (I-type), jump (J-type), and register (R-type)—as shown in Figure 9-1 on page 197. The use of a small number of instruction formats simplifies instruction decoding, allowing the compiler to synthesize more complicated (and less frequently used) operations and addressing modes from these three formats as needed.



**Figure 9-1 Instruction Formats** 

# 9.2 Load and Store Instructions

#### 9.2.1 Scheduling a Load Delay Slot

A load instruction that does not allow its result to be used by the instruction immediately following is called a *delayed load instruction*. The instruction slot immediately following this delayed load instruction is referred to as the *load delay slot*.

In a M4K core, the instruction immediately following a load instruction can use the contents of the loaded register; however in such cases hardware interlocks insert additional real cycles. Although not required, the scheduling of load delay slots can be desirable, both for performance and R-Series processor compatibility.

### 9.2.2 Defining Access Types

Access type indicates the size of a core data item to be loaded or stored, set by the load or store instruction opcode.

Regardless of access type or byte ordering (endianness), the address given specifies the low-order byte in the addressed field. For a big-endian configuration, the low-order byte is the most-significant byte; for a little-endian configuration, the low-order byte is the least-significant byte.

The access type, together with the three low-order bits of the address, define the bytes accessed within the addressed word as shown in Table 9-1. Only the combinations shown in Table 9-1 are permissible; other combinations cause address error exceptions.

Table 9-1 Byte Access Within a Word

						В	ytes A	ccesse	d							
	Low Order Address Bits			Big Endian (310)			Little Endian (310)									
Access Type	2 1 0			Byte			Byte									
Word	0	0	0	0	1	2	3	3	2	1	0					
Triplebyte	0	0	0	0	1	2			2	1	0					
Triplebyte	0	0	1		1	2	3	3	2	1						
Halfword	0	0	0	0	1					1	0					
Hallword	0	1	0			2	3	3	2							
	0	0	0	0							0					
Byte	0	0	1		1					1						
Буш	0	1	0			2			2							
	0	1	1				3	3								

# 9.3 Computational Instructions

Computational instructions can be either in register (R-type) format, in which both operands are registers, or in immediate (I-type) format, in which one operand is a 16-bit immediate.

Computational instructions perform the following operations on register values:

- Arithmetic
- Logical
- Shift
- Multiply
- Divide

These operations fit in the following four categories of computational instructions:

- ALU Immediate instructions
- Three-operand Register-type Instructions
- Shift Instructions
- Multiply And Divide Instructions

### 9.3.1 Cycle Timing for Multiply and Divide Instructions

Any multiply instruction in the integer pipeline is transferred to the multiplier as remaining instructions continue through the pipeline; the product of the multiply instruction is saved in the HI and LO registers. If the multiply instruction is

followed by an MFHI or MFLO before the product is available, the pipeline interlocks until this product does become available. Refer to Chapter 2, "Pipeline of the M4K TMCore," on page 12 for more information on instruction latency and repeat rates.

# 9.4 Jump and Branch Instructions

Jump and branch instructions change the control flow of a program. All jump and branch instructions occur with a delay of one instruction: that is, the instruction immediately following the jump or branch (this is known as the instruction in the *delay slot*) always executes while the target instruction is being fetched from storage.

# 9.4.1 Overview of Jump Instructions

Subroutine calls in high-level languages are usually implemented with Jump or Jump and Link instructions, both of which are J-type instructions. In J-type format, the 26-bit target address shifts left 2 bits and combines with the high-order 4 bits of the current program counter to form an absolute address.

Returns, dispatches, and large cross-page jumps are usually implemented with the Jump Register or Jump and Link Register instructions. Both are R-type instructions that take the 32-bit byte address contained in one of the general purpose registers.

For more information about jump instructions, refer to the individual instructions in Section 10.3, "MIPS32<sup>TM</sup> Instruction Set for the M4K<sup>TM</sup> core" on page 203.

#### 9.4.2 Overview of Branch Instructions

All branch instruction target addresses are computed by adding the address of the instruction in the delay slot to the 16-bit *offset* (shifted left 2 bits and sign-extended to 32 bits). All branches occur with a delay of one instruction.

If a conditional branch likely is not taken, the instruction in the delay slot is nullified.

Branches, jumps, ERET, and DERET instructions should not be placed in the delay slot of a branch or jump.

#### 9.5 Control Instructions

Control instructions allow the software to initiate traps; they are always R-type.

# 9.6 Coprocessor Instructions

CP0 instructions perform operations on the System Control Coprocessor registers to manipulate the memory management and exception handling facilities of the processor. Refer to Chapter 10, "M4K<sup>TM</sup> Processor Core Instructions," on page 200 for a listing of CP0 instructions.

# M4K<sup>TM</sup> Processor Core Instructions

This chapter supplements the MIPS32 Architecture Reference Manual by describing instruction behavior that is specific to a MIPS32<sup>TM</sup> M4K<sup>TM</sup> processor core. The chapter is divided into the following sections:

- Section 10.1, "Understanding the Instruction Descriptions" on page 202
- Section 10.2, "M4KTM Opcode Map" on page 202
- Section 10.3, "MIPS32<sup>TM</sup> Instruction Set for the M4K<sup>TM</sup> core" on page 205

The M4K processor core also supports the MIPS16 ASE to the MIPS32 architecture. The MIPS16 ASE instruction set is described in Chapter 11, "MIPS16 Application-Specific Extension to the MIPS32 Instruction Set," on page 225.

# 10.1 Understanding the Instruction Descriptions

Refer to Volume II of the MIPS32 Architecture Reference Manual for more information about the instruction descriptions. There is a description of the instruction fields, definition of terms, and a description function notation available in that document.

# 10.2 M4K<sup>TM</sup> Opcode Map

111

SC

#### Key

- CAPITALIZED text indicates an opcode mnemonic
- Italicized text indicates to look at the specified opcode submap for further instruction bit decode
- Entries containing the α symbol indicate that a reserved instruction fault occurs if the core executes this instruction.
- Entries containing the β symbol indicate that a coprocessor unusable exception occurs if the core executes this
  instruction

opcode bits 28..26 0 1 2 3 4 5 7 6 000 001 010 100 111 bits 31..29 011 101 110 **BGTZ** 000 Special RegImm J JAL **BEO BNE BLEZ** 1 001 ADDI **ADDIU** SLTI **SLTIU ANDI** ORI **XORI** LUI 010 COP0 COP2 β **BEQL BNEL BLEZL BGTZL** β 011 Special2 **JALX** Special3 α α α α α 4 100 LB LH **LWL** LW LBU LHU **LWR** α 5 101 SBSH **SWL** SW **SWR CACHE** LL **PREF** 110 β LWC2 α β

SWC2

Table 10-1 Encoding of the Opcode Field

β

α

Table 10-2 Special Opcode encoding of Function Field

fun	ction	bits 20							
		0	1	2	3	4	5	6	7
bit	s 53	000	001	010	011	100	101	110	111
0	000	SLL	β	SRL/ ROTR	SRA	SLLV	α	SRLV/ ROTRV	SRAV
1	001	JR	JALR	MOVZ	MOVN	SYSCALL	BREAK	α	SYNC
2	010	MFHI	MTHI	MFLO	MTLO	α	α	α	α
3	011	MULT	MULTU	DIV	DIVU	α	α	α	α
4	100	ADD	ADDU	SUB	SUBU	AND	OR	XOR	NOR
5	101	α	α	SLT	SLTU	α	α	α	α
6	110	TGE	TGEU	TLT	TLTU	TEQ	α	TNE	α
7	111	α	α	α	α	α	α	α	α

Table 10-3 Special2 Opcode Encoding of Function Field

fun	ction	bits 20									
		0	1	2	3	4	5	6	7		
bit	s 53	000	001	010	011	100	101	110	111		
0	000	MADD	MADDU	MUL	α	MSUB	MSUBU	α	α		
1	001		α	α	α	α	α	α	α		
2	010		$UDI^1$ or $\alpha$								
3	011										
4	100	CLZ	CLO	α	α	α	α	α	α		
5	101	α	α	α	α	α	α	α	α		
6	110	α	α	α	α	α	α	α	α		
7	111	α	α	α	α	α	α	α	SDBBP		

CorExtend instructions are a build-time option of the M4K Pro core, if not implemented this instructions space will cause a reserved instruction exception. If assembler support exists, the mnemonics for CorExtend instructions are most likely UDI0, UDI1, ..., UDI15.

Table 10-4 Special3 Opcode Encoding of Function Field

fur	ction	bits 20							
		0	1	2	3	4	5	6	7
bit	s 53	000	001	010	011	100	101	110	111
0	000	EXT	α	α	α	INS	α	α	α
1	001	α	α	α	α	α	α	α	α
2	010	α	α	α	α	α	α	α	α
3	011	α	α	α	α	α	α	α	α
4	100	BSHFL	α	α	α	α	α	α	α
5	101	α	α	α	α	α	α	α	α
6	110	α	α	α	α	α	α	α	α
7	111	α	α	α	RDHWR	α	α	α	α

Table 10-5 RegImm Encoding of rt Field

	rt	bits 1816							
		0	1	2	3	4	5	6	7
bits	2019	000	001	010	011	100	101	110	111
0	00	BLTZ	BGEZ	BLTZL	BGEZL	α	α	α	α
1	01	TGEI	TGEIU	TLTI	TLTIU	TEQI	α	TNEI	α
2	10	BLTZAL	BGEZAL	BLTZALL	BGEZALL	α	α	α	α
3	11	α	α	α	α	α	α	α	SYNCI

## Table 10-6 COP2 Encoding of rs Field

	rs	bits 2321							
		0	1	2	3	4	5	6	7
bits	2524	000	001	010	011	100	101	110	111
0	00	MFC2	α	α CFC2 MFHC2 MTC2 α CTC2 MTHC2					
1	01	BC2		$BC2^1$					
2	10								
3	11	СО							

<sup>1.</sup> The core will treat the entire row as a *BC2* instruction. However compiler and assembler support only exists for the first one. Some compiler and assembler products may allow the user to add new instructions.

Table 10-7 COP2 Encoding of rt Field When rs=BC2

rt	bits 16	
bits 17	0	1
0	BC2F	BC2T
1	BC2FL	BC2TL

Table 10-8 COPO Encoding of rs Field

	rs	bits 2321							
		0	1	2	3	4	5	6	7
bits	2524	000	001	010	011	100	101	110	111
0	00	MFC0	α	α	α	MTC0	α	α	α
1	01	α	α	RDPGPR	MFMC0	α	α	WRPGPR	α
2	10								
3	11	СО							

Table 10-9 COPO Encoding of Function Field When rs=CO

fur	ction	bits 20							
		0	1	2	3	4	5	6	7
bit	s 53	000	001	010	011	100	101	110	111
0	000	α	α	α	α	α	α	α	α
1	001	α	α	α	α	α	α	α	α
2	010	α	α	α	α	α	α	α	α
3	011	ERET	IACK	α	α	α	α	α	DERET
4	100	WAIT	α	α	α	α	α	α	α
5	101	α	α	α	α	α	α	α	α
6	110	α	α	α	α	α	α	α	α
7	111	α	α	α	α	α	α	α	α

# 10.3 MIPS32<sup>TM</sup> Instruction Set for the M4K<sup>TM</sup> core

This section describes the MIPS32 instructions for the M4K cores. Table 10-10 lists the instructions in alphabetical order. Instructions that have implementation dependent behavior are described afterwards. The descriptions for other instructions exist in the architecture reference manual and are not duplicated here.

**Table 10-10 Instruction Set** 

Instruction	Description	Function	
ADD	Integer Add	Rd = Rs + Rt	
ADDI	Integer Add Immediate	Rt = Rs + Immed	
ADDIU	Unsigned Integer Add Immediate	$Rt = Rs +_{U} Immed$	
ADDU	Unsigned Integer Add	$Rd = Rs +_{U} Rt$	
AND	Logical AND	Rd = Rs & Rt	
ANDI	Logical AND Immediate	$Rt = Rs \& (0_{16}    Immed)$	
В	Unconditional Branch (Assembler idiom for: BEQ r0, r0, offset)	PC += (int)offset	
BAL Branch and Link (Assembler idiom for: BGEZAL r0, offset)		GPR[31] = PC + 8 PC += (int)offset	
BC2F	Branch On COP2 Condition False	if COP2Condition(cc) == 0 PC += (int)offset	
BC2FL	Branch On COP2 Condition False Likely	if COP2Condition(cc) == 0 PC += (int)offset else Ignore Next Instruction	
BC2T	Branch On COP2 Condition True	if COP2Condition(cc) == 1 PC += (int)offset	
BC2TL	Branch On COP2 Condition True Likely	if COP2Condition(cc) == 1 PC += (int)offset else Ignore Next Instruction	
BEQ	Branch On Equal	if Rs == Rt PC += (int)offset	

# **Table 10-10 Instruction Set (Continued)**

Instruction	Description	Function
BEQL	Branch On Equal Likely	if Rs == Rt PC += (int)offset else Ignore Next Instruction
BGEZ	Branch on Greater Than or Equal To Zero	if !Rs[31] PC += (int)offset
BGEZAL	Branch on Greater Than or Equal To Zero And Link	GPR[31] = PC + 8 if !Rs[31] PC += (int)offset
BGEZALL	Branch on Greater Than or Equal To Zero And Link Likely	GPR[31] = PC + 8 if !Rs[31] PC += (int)offset else Ignore Next Instruction
BGEZL	Branch on Greater Than or Equal To Zero Likely	if !Rs[31] PC += (int)offset else Ignore Next Instruction
BGTZ	Branch on Greater Than Zero	if !Rs[31] && Rs != 0 PC += (int)offset
BGTZL	Branch on Greater Than Zero Likely	if !Rs[31] && Rs != 0 PC += (int)offset else Ignore Next Instruction
BLEZ	Branch on Less Than or Equal to Zero	if Rs[31]    Rs == 0 PC += (int)offset
BLEZL	Branch on Less Than or Equal to Zero Likely	if Rs[31]    Rs == 0 PC += (int)offset else Ignore Next Instruction
BLTZ	Branch on Less Than Zero	if Rs[31] PC += (int)offset
BLTZAL	Branch on Less Than Zero And Link	GPR[31] = PC + 8 if Rs[31] PC += (int)offset
BLTZALL	Branch on Less Than Zero And Link Likely	GPR[31] = PC + 8 if Rs[31] PC += (int)offset else Ignore Next Instruction
BLTZL	Branch on Less Than Zero Likely	if Rs[31] PC += (int)offset else Ignore Next Instruction
BNE	Branch on Not Equal	if Rs != Rt PC += (int)offset
BNEL	Branch on Not Equal Likely	if Rs != Rt PC += (int)offset else Ignore Next Instruction
BREAK	Breakpoint	Break Exception

**Table 10-10 Instruction Set (Continued)** 

Instruction	Description	Function	
CACHE	Cache Operation	See Cache Description	
CFC2	Move Control Word From Coprocessor 2	Rt = CCR[2, n]	
CLO	Count Leading Ones	Rd = NumLeadingOnes(Rs)	
CLZ	Count Leading Zeroes	Rd = NumLeadingZeroes(Rs)	
COP0	Coprocessor 0 Operation	See Coprocessor Description	
COP2	Coprocessor 2 Operation	See Coprocessor 2 Description	
CTC2	Move Control Word To Coprocessor 2	CCR[2, n] = Rt	
DERET	Return from Debug Exception	PC = DEPC Exit Debug Mode	
DI	Disable Interrupts	Rt=Status	
Di	Disable interrupts	Status <sub>IE</sub> =0	
DIV	Divide	LO = (int)Rs / (int)Rt HI = (int)Rs % (int)Rt	
DIVU	Unsigned Divide	LO = (uns)Rs / (uns)Rt HI = (uns)Rs % (uns)Rt	
ЕНВ	Execution Hazard Barrier	Stall until execution hazards are cleared	
EI	Enable Interrupts	Rt=Status	
El	Enable Interrupts	Status <sub>IE</sub> =1	
ERET	Return from Exception	if SR[2] PC = ErrorEPC else PC = EPC SR[1] = 0 SR[2] = 0 LL = 0	
EXT	Extract Bit Field	Rt=ExtractField(Rs,msbd,lsb)	
INS	Insert Bit Field	Rt=InsertField(Rt,Rs,msb,lsb)	
J	Unconditional Jump	PC = PC[31:28]    offset<<2	
JAL	Jump and Link	GPR[31] = PC + 8 PC = PC[31:28]    offset<<2	
JALR	Jump and Link Register	Rd = PC + 8 PC = Rs	
JALR.HB	Jump and Link Register with Hazard Barrier	Rd = PC + 8 PC = Rs Stall until all execution and instruction hazards are cleared	
JR	Jump Register	PC = Rs	
JR.HB	Jump Register with Hazard Barrier	PC = Rs Stall until all execution and instruction hazards are cleared	

# **Table 10-10 Instruction Set (Continued)**

Instruction	Description	Function
LB	Load Byte	Rt = (byte)Mem[Rs+offset]
LBU	Unsigned Load Byte	Rt = (ubyte))Mem[Rs+offset]
LH	Load Halfword	Rt = (half)Mem[Rs+offset]
LHU	Unsigned Load Halfword	Rt = (uhalf)Mem[Rs+offset]
LL	Load Linked Word	$Rt = Mem[Rs+offset] \\ LL = 1 \\ LLAdr = Rs + offset$
LUI	Load Upper Immediate	Rt = immediate << 16
LW	Load Word	Rt = Mem[Rs+offset]
LWC2	Load Word To Coprocessor 2	CPR[2, n, 0] = Mem[Rs+offset]
LWL	Load Word Left	See LWL instruction.
LWR	Load Word Right	See LWR instruction.
MADD	Multiply-Add	HI, LO += (int)Rs * (int)Rt
MFC0	Move From Coprocessor 0	Rt = CPR[0, n, sel]
MFC2	Move From Coprocessor 2	$Rt = CPR[2, n, sel_{310}]$
MFHC2	Move From High Word Coprocessor2	Rt= CPR[2,n,sel] <sub>6332</sub>
MFHI	Move From HI	Rd = HI
MFLO	Move From LO	Rd = LO
MOVN	Move Conditional on Not Zero	if $GPR[rt] \neq 0$ then GPR[rd] = GPR[rs]
MOVZ	Move Conditional on Zero	if GPR[rt] = 0 then GPR[rd] = GPR[rs]
MSUB	Multiply-Subtract	HI, LO -= (int)Rs * (int)Rt
MSUBU	Multiply-Subtract Unsigned	HI, LO -= (uns)Rs * (uns)Rt
MTC0	Move To Coprocessor 0	CPR[0, n, sel] = Rt
MTC2	Move To Coprocessor 2	$CPR[2, n, sel]_{310} = Rt$
MTHC2	Move To High Word Coprocessor 2	$CPR[2, n, sel]_{6332} = Rt$
MTHI	Move To HI	HI = Rs
MTLO	Move To LO	LO = Rs
MUL	Multiply with register write	HI   LO =Unpredictable Rd = LO
MULT	Integer Multiply	$HI \mid LO = (int)Rs * (int)Rd$
NOP	No Operation (Assembler idiom for: SLL r0, r0, r0)	
NOR	Logical NOR	$Rd = \sim (Rs \mid Rt)$
OR	Logical OR	Rd = Rs   Rt

**Table 10-10 Instruction Set (Continued)** 

Instruction	Description	Function
ORI	Logical OR Immediate	Rt = Rs   Immed
PREF	Prefetch	Nop
RDHWR	Read HardWare Register	Rt=HWR[Rd]
RDPGPR	Read GPR from Previous Shadow Set	Rd=SGPR[SRSCtl <sub>PSS</sub> , Rt]
ROTR	Rotate Word Right	$Rd = Rt_{sa-10} \parallel Rt_{31sa}$
ROTRV	Rotate Word Right Variable	$Rd = Rt_{Rs-10} \parallel Rt_{31Rs}$
SB	Store Byte	(byte)Mem[Rs+offset] = Rt
SC	Store Conditional Word	if LL =1 mem[Rxoffs] = Rt Rt = LL
SDBBP	Software Debug Breakpoint	Trap to SW Debug Handler
SEB	Sign Extend Byte	Rd=SignExtend(Rt <sub>70</sub> )
SEH	Sign Extend Half	Rd=SignExtend(Rt <sub>150</sub> )
SH	Store Halfword	(half)Mem[Rs+offset] = Rt
SLL	Shift Left Logical	$Rd = Rt \ll sa$
SLLV	Shift Left Logical Variable	Rd = Rt << Rs[4:0]
SLT	Set on Less Than	if (int)Rs < (int)Rt Rd = 1 else Rd = 0
SLTI	Set on Less Than Immediate	
SLTIU	Set on Less Than Immediate Unsigned	$ if (uns)Rs < (uns)Immed \\ Rt = 1 \\ else \\ Rt = 0 $
SLTU	Set on Less Than Unsigned	$ if (uns)Rs < (uns)Immed \\ Rd = 1 \\ else \\ Rd = 0 $
SRA	Shift Right Arithmetic	Rd = (int)Rt >> sa
SRAV	Shift Right Arithmetic Variable	Rd = (int)Rt >> Rs[4:0]
SRL	Shift Right Logical	Rd = (uns)Rt >> sa
SRLV	Shift Right Logical Variable	Rd = (uns)Rt >> Rs[4:0]
SSNOP	Superscalar Inhibit No Operation	Nop
SUB	Integer Subtract	Rt = (int)Rs - (int)Rd
SUBU	Unsigned Subtract	Rt = (uns)Rs - (uns)Rd
SW	Store Word	Mem[Rs+offset] = Rt

# **Table 10-10 Instruction Set (Continued)**

Instruction	Description	Function
SWC2	Store Word From Coprocessor 2	Mem[Rs+offset] = CPR[2, n, 0]
SWL	Store Word Left	See SWL instruction description.
SWR	Store Word Right	See SWR instruction description.
SYNC	Synchronize	See SYNC instruction below.
SYNCI	Synchronize Caches to Make Instruction Writes Effective	Nop
SYSCALL	System Call	SystemCallException
TEQ	Trap if Equal	if Rs == Rt TrapException
TEQI	Trap if Equal Immediate	if Rs == (int)Immed TrapException
TGE	Trap if Greater Than or Equal	if (int)Rs >= (int)Rt TrapException
TGEI	Trap if Greater Than or Equal Immediate	if (int)Rs >= (int)Immed TrapException
TGEIU	Trap if Greater Than or Equal Immediate Unsigned	if (uns)Rs >= (uns)Immed TrapException
TGEU	Trap if Greater Than or Equal Unsigned	if (uns)Rs >= (uns)Rt TrapException
TLT	Trap if Less Than	if (int)Rs < (int)Rt TrapException
TLTI	Trap if Less Than Immediate	if (int)Rs < (int)Immed TrapException
TLTIU	Trap if Less Than Immediate Unsigned	if (uns)Rs < (uns)Immed TrapException
TLTU	Trap if Less Than Unsigned	if (uns)Rs < (uns)Rt TrapException
TNE	Trap if Not Equal	if Rs != Rt TrapException
TNEI	Trap if Not Equal Immediate	if Rs != (int)Immed TrapException
WAIT	Wait for Interrupts	Stall until interrupt occurs
WRPGPR	Write to GPR in Previous Shadow Set	SGPR[SRSCtl <sub>PSS</sub> ,Rd]=Rt
WSBH	Word Swap Bytes within Halfwords	Rd=SwapBytesWithinHalfs(Rt)
XOR	Exclusive OR	Rd = Rs ^ Rt
XORI	Exclusive OR Immediate	Rt = Rs ^ (uns)Immed

Perform	Perform Cache Operation						
31	26	25 21	20 16	15	0		
CAC	HE	base	on	offset			
1011	111	base	op	Offset			
6		5	5	16			

Format: CACHE op, offset(base) MIPS32

## **Purpose:**

To perform the cache operation specified by op.

# **Description:**

CACHE is always treated as a NOP on the M4K core (as long as access to Coprocessor 0 is enabled), since it does not contain caches.

Perform	Cache	Operation (	(cont.)	۱
I CIIUIIII	Caciic	Operation	COLLEG	,

**CACHE** 

# **Restrictions:**

If access to Coprocessor 0 is not enabled, a Coprocessor Unusable Exception is signaled.


# **Operation:**

None

# **Exceptions:**

Coprocessor Unusable Exception

Load Linked Word



Format: LL rt, offset(base) MIPS32

#### **Purpose:**

To load a word from memory for an atomic read-modify-write

**Description:** rt ← memory[base+offset]

The LL and SC instructions provide the primitives to implement atomic read-modify-write (RMW) operations for synchronizable memory locations.

The contents of the 32-bit word at the memory location specified by the aligned effective address are fetched and written into GPR *rt*. The 16-bit signed *offset* is added to the contents of GPR *base* to form an effective address.

This begins a RMW sequence on the current processor. There can be only one active RMW sequence per processor. When an LL is executed it starts an active RMW sequence replacing any other sequence that was active. The RMW sequence is completed by a subsequent SC instruction that either completes the RMW sequence atomically and succeeds, or does not and fails.

Executing LL on one processor does not cause an action that, by itself, causes an SC for the same block to fail on another processor.

An execution of LL does not have to be followed by execution of SC; a program is free to abandon the RMW sequence without attempting a write.

#### **Restrictions:**

The addressed location must be synchronizable by all processors and I/O devices sharing the location; if it is not, the result in **UNPREDICTABLE**. Which storage is synchronizable is a function of both CPU and system implementations. See the documentation of the SC instruction for the formal definition. The addressed location may be uncached for the M4K core.

The effective address must be naturally-aligned. If either of the 2 least-significant bits of the effective address is non-zero, an Address Error exception occurs.

#### **Operation:**

```
\label{eq:vAddr} \begin{array}{l} {\rm vAddr} \; \leftarrow \; {\rm sign\_extend(offset)} \; + \; {\rm GPR[base]} \\ {\rm if} \; {\rm vAddr}_{1...0} \; \neq \; 0^2 \; {\rm then} \\ \qquad {\rm SignalException(AddressError)} \\ {\rm endif} \\ ({\rm pAddr}, \; {\rm CCA}) \; \leftarrow \; {\rm AddressTranslation} \; ({\rm vAddr}, \; {\rm DATA}, \; {\rm LOAD}) \\ {\rm memword} \; \leftarrow \; {\rm LoadMemory} \; ({\rm CCA}, \; {\rm WORD}, \; {\rm pAddr}, \; {\rm vAddr}, \; {\rm DATA}) \\ {\rm GPR[rt]} \; \leftarrow \; {\rm memword} \\ {\rm LLbit} \; \leftarrow \; 1 \\ \end{array}
```

Load Linked Word (cont.)


## **Exceptions:**

TLB Refill, TLB Invalid, Address Error, Reserved Instruction, Watch

## **Programming Notes:**

There is no Load Linked Word Unsigned operation corresponding to Load Word Unsigned.

Prefetch PREF



Format: PREF hint, offset(base) MIPS32

## **Purpose:**

To move data between memory and cache.

**Description:** prefetch\_memory(base+offset)

PREF adds the 16-bit signed *offset* to the contents of GPR *base* to form an effective byte address. The *hint* field supplies information about the way that the data is expected to be used.

PREF is always treated as a NOP on the M4K core, since it does not contain caches.

Prefetch (cont.)

Table 10-11 Values of the hint Field for the PREF Instruction

Value	Name	Data Use and Desired Prefetch Action
0	load	Use: Prefetched data is expected to be read (not modified).  Action: Fetch data as if for a load.
1	store	Use: Prefetched data is expected to be stored or modified.  Action: Fetch data as if for a store.
2-3	Reserved	
4	load_streamed	Use: Prefetched data is expected to be read (not modified) but not reused extensively; it "streams" through cache.
5	store_streamed	Use: Prefetched data is expected to be stored or modified but not reused extensively; it "streams" through cache.
6	load_retained	Use: Prefetched data is expected to be read (not modified) and reused extensively; it should be "retained" in the cache.
7	store_retained	Use: Prefetched data is expected to be stored or modified and reused extensively; it should be "retained" in the cache.
8-24	Reserved	
25	writeback_invalidate (also known as "nudge")	
26-29		
30		

## Table 10-11 Values of the hint Field for the PREF Instruction

31	
----	--

Prefetch (cont.)

#### **Restrictions:**

None

## **Operation:**

```
vAddr 		GPR[base] + sign_extend(offset)
(pAddr, CCA) 		AddressTranslation(vAddr, DATA, LOAD)
Prefetch(CCA, pAddr, vAddr, DATA, hint)
```

## **Exceptions:**


Prefetch does not take any TLB-related or address-related exceptions under any circumstances.


### **Programming Notes:**

Prefetch cannot prefetch data from a mapped location unless the translation for that location is present in the TLB. Locations in memory pages that have not been accessed recently may not have translations in the TLB, so prefetch may not be effective for such locations.

Prefetch does not cause addressing exceptions. It does not cause an exception to prefetch using an address pointer value before the validity of a pointer is determined.

Prefetch operations have no effect on cache lines that were previously locked with the CACHE instruction.





Format: SC rt, offset(base) MIPS32

#### **Purpose:**

To store a word to memory to complete an atomic read-modify-write

**Description:** if atomic\_update then memory[base+offset]  $\leftarrow$  rt, rt  $\leftarrow$  1 else rt  $\leftarrow$  0

The LL and SC instructions provide primitives to implement atomic read-modify-write (RMW) operations for synchronizable memory locations.

The 32-bit word in GPR *rt* is conditionally stored in memory at the location specified by the aligned effective address. The 16-bit signed *offset* is added to the contents of GPR *base* to form an effective address.

The SC completes the RMW sequence begun by the preceding LL instruction executed on the processor. To complete the RMW sequence atomically, the following occur:

- The 32-bit word of GPR rt is stored into memory at the location specified by the aligned effective address.
- A 1, indicating success, is written into GPR rt.

Otherwise, memory is not modified and a 0, indicating failure, is written into GPR rt. On the M4K core, the SRAM interface supports a lock protocol and the success or failure can be indicated by external hardware.

If the following event occurs between the execution of LL and SC, the SC fails:

• An ERET instruction is executed.

If either of the following events occurs between the execution of LL and SC, the SC may succeed or it may fail; the success or failure is not predictable. Portable programs should not cause one of these events.

- A memory access instruction (load, store, or prefetch) is executed on the processor executing the LL/SC.
- The instructions executed starting with the LL and ending with the SC do not lie in a 2048-byte contiguous
  region of virtual memory. (The region does not have to be aligned, other than the alignment required for
  instruction words.)

The following conditions must be true or the result of the SC is **UNPREDICTABLE**:

- Execution of SC must have been preceded by execution of an LL instruction.
- An RMW sequence executed without intervening events that would cause the SC to fail must use the same
  address in the LL and SC. The address is the same if the virtual address, physical address, and cache-coherence
  algorithm are identical.

## **Restrictions:**

The effective address must be naturally-aligned. If either of the 2 least-significant bits of the address is non-zero, an Address Error exception occurs.

## **Operation:**

```
\label{eq:vAddr} $$ vAddr_{1..0} \neq 0^2$ then \\ SignalException(AddressError) $$ endif $$ (pAddr, CCA) \leftarrow AddressTranslation (vAddr, DATA, STORE)$$ dataword \leftarrow GPR[rt]$$ if LLbit then StoreMemory (CCA, WORD, dataword, pAddr, vAddr, DATA) $$ endif $$ GPR[rt] \leftarrow 0^{31} \mid LLbit$$ LLbit $$ LLbit$$ and $$ is $$ and $$ is $$ and $$ is $$ and $$ is $$ is $$ and $$ and $$ is $$ and $$ and $$ is $$ and $$
```

## **Exceptions:**

TLB Refill, TLB Invalid, TLB Modified, Address Error, Watch

## **Programming Notes:**

LL and SC are used to atomically update memory locations, as shown below.

```
L1:

LL T1, (T0) # load counter

ADDI T2, T1, 1 # increment

SC T2, (T0) # try to store, checking for atomicity

BEQ T2, 0, L1 # if not atomic (0), try again

NOP # branch-delay slot
```

Exceptions between the LL and SC cause SC to fail, so persistent exceptions must be avoided. Some examples of these are arithmetic operations that trap, system calls, and floating point operations that trap or require software emulation assistance.

LL and SC function on a single processor for *cached noncoherent* memory so that parallel programs can be run on uniprocessor systems that do not support *cached coherent* memory access types.

## **Synchronize Shared Memory**

#### **SYNC**

31	26	25	2	1 20		16 15	11	10	6	5		0		
SPECIAL					0			stypa					SYNC	
000000				00 00	000 0000	0000 0		stype			001111			
6					15			5			6			

Format: SYNC (stype = 0 implied) MIPS32

#### **Purpose:**

To order loads and stores.

## **Description:**

Simple Description:

- SYNC affects only *uncached* and *cached coherent* loads and stores. The loads and stores that occur before the SYNC must be completed before the loads and stores after the SYNC are allowed to start.
- Loads are completed when the destination register is written. Stores are completed when the stored value is visible to every other processor in the system.
- SYNC is required, potentially in conjunction with SSNOP, to guarantee that memory reference results are visible across operating mode changes. For example, a SYNC is required on entry to and exit from Debug Mode to guarantee that memory affects are handled correctly.

Detailed Description:

- SYNC does not guarantee the order in which instruction fetches are performed. The *stype* values 1-31 are reserved for future extensions to the architecture. A value of zero will always be defined such that it performs all defined synchronization operations. Non-zero values may be defined to remove some synchronization operations. As such, software should never use a non-zero value of the *stype* field, as this may inadvertently cause future failures if non-zero values remove synchronization operations.
- The SYNC instruction is externalized on the SRAM interface of the M4K core. External logic can use this information in a system-dependent manner to enforce memory ordering between various memory elements in the system.

# **Synchronize Shared Memory (cont.)**

**SYNC** 

## **Restrictions:**


The effect of SYNC on the global order of loads and stores for memory access types other than *uncached* and *cached coherent* is **UNPREDICTABLE**.

## **Operation:**

SyncOperation(stype)

## **Exceptions:**

None



Format: WAIT MIPS32

#### **Purpose:**

Wait for Event

## **Description:**

The WAIT instruction forces the core into low power mode. The pipeline is stalled and when all external requests are completed, the processor's main clock is stopped. The processor will restart when reset (SI\_Reset or SI\_ColdReset) is signaled, or a non-masked interrupt is taken (SI\_NMI, SI\_Int, or EJ\_DINT). Note that the M4K core does not use the code field in this instruction.

If the pipeline restarts as the result of an enabled interrupt, that interrupt is taken between the WAIT instruction and the following instruction (EPC for the interrupt points at the instruction following the WAIT instruction).

#### **Restrictions:**

The operation of the processor is **UNDEFINED** if a WAIT instruction is placed in the delay slot of a branch or a jump.

If access to Coprocessor 0 is not enabled, a Coprocessor Unusable Exception is signaled.

# **Enter Standby Mode (cont.)**

WAIT

# **Operation:**

```
I: Enter lower power mode
I+1:/* Potential interrupt taken here */
```

## **Exceptions:**

Coprocessor Unusable Exception

# MIPS16 Application-Specific Extension to the MIPS32 Instruction Set

This chapter describes the MIPS16 ASE as implemented in the M4K core. Refer to Volume IV-a of the MIPS32 Architecture Reference Manual for a general description of the MIPS16 ASE as well as instruction descriptions.

This chapter covers the following topics:

- Section 11.1, "Instruction Bit Encoding" on page 228
- Section 11.2, "Instruction Listing" on page 230

# 11.1 Instruction Bit Encoding

Table 11-2 through Table 11-9 describe the encoding used for the MIPS16 ASE. Table 11-1 describes the meaning of the symbols used in the tables.

**Table 11-1 Symbols Used in the Instruction Encoding Tables** 

Symbol	Meaning
*	Operation or field codes marked with this symbol are reserved for future use. Executing such an instruction cause a Reserved Instruction Exception.
δ	(Also <i>italic</i> field name.) Operation or field codes marked with this symbol denotes a field class. The instruction word must be further decoded by examining additional tables that show values for another instruction field.
β	Operation or field codes marked with this symbol represent a valid encoding for a higher-order MIPS ISA level. Executing such an instruction cause a Reserved Instruction Exception.
θ	Operation or field codes marked with this symbol are available to licensed MIPS partners. To avoid multiple conflicting instruction definitions, the partner must notify MIPS Technologies, Inc. when one of these encodings is used. If no instruction is encoded with this value, executing such an instruction must cause a Reserved Instruction Exception (SPECIAL2 encodings or coprocessor instruction encodings for a coprocessor to which access is allowed) or a Coprocessor Unusable Exception (coprocessor instruction encodings for a coprocessor to which access is not allowed).
σ	Field codes marked with this symbol represent an EJTAG support instruction and implementation of this encoding is optional for each implementation. If the encoding is not implemented, executing such an instruction must cause a Reserved Instruction Exception. If the encoding is implemented, it must match the instruction encoding as shown in the table.
ε	Operation or field codes marked with this symbol are reserved for MIPS Application Specific Extensions. If the ASE is not implemented, executing such an instruction must cause a Reserved Instruction Exception.
ф	Operation or field codes marked with this symbol are obsolete and will be removed from a future revision of the MIPS64 ISA. Software should avoid using these operation or field codes.

Table 11-2 MIPS16 Encoding of the Opcode Field

op	code	bits 1311							
		0	1	2	3	4	5	6	7
bits 1514		000	001	010	011	100	101	110	111
0	00	ADDIUSP <sup>1</sup>	ADDIUPC <sup>2</sup>	В	$JAL(X) \delta$	BEQZ	BNEZ	SHIFT δ	β
1	01	RRI-A δ	ADDIU8 <sup>3</sup>	SLTI	SLTIU	<i>I</i> 8 δ	LI	CMPI	β
2	10	LB	LH	LWSP <sup>4</sup>	LW	LBU	LHU	LWPC <sup>5</sup>	β
3	11	SB	SH	SWSP <sup>6</sup>	SW	RRR δ	RR δ	EXTEND δ	β

- 1. The ADDIUSP opcode is used by the ADDIU rx, sp, immediate instruction
- 2. The ADDIUPC opcode is used by the ADDIU rx, pc, immediate instruction
- 3. The ADDIU8 opcode is used by the ADDIU rx, immediate instruction
- 4. The LWSP opcode is used by the LW rx, offset(sp) instruction
- 5. The LWPC opcode is used by the LW rx, offset(pc) instruction
- 6. The SWSP opcode is used by the SW rx, offset(sp) instruction

Table 11-3 MIPS16 JAL(X) Encoding of the x Field

X	bit 26	
	0	1
	JAL	JALX

Table 11-4 MIPS16 SHIFT Encoding of the f Field

f	bits 10			
	0	1	2	3
	00	01	10	11
	SLL	β	SRL	SRA

Table 11-5 MIPS16 RRI-A Encoding of the f Field

f	bit 4	
	0	1
	ADDIU <sup>1</sup>	β

<sup>1.</sup> The ADDIU function is used by the ADDIU ry, rx, immediate instruction

Table 11-6 MIPS16 I8 Encoding of the funct Field

funct	bits 108							
	0	1	2	3	4	5	6	7
	000	001	010	011	100	101	110	111
	BTEQZ	BTNEZ	SWRASP <sup>1</sup>	ADJSP <sup>2</sup>	SVRS δ	MOV32R <sup>3</sup>	*	MOVR32 <sup>4</sup>

- 1. The SWRASP function is used by the SW ra, offset(sp) instruction
- 2. The ADJSP function is used by the ADDIU sp, immediate instruction
- 3. The MOV32R function is used by the MOVE r32, rz instruction
- 4. The MOVR32 function is used by the MOVE ry, r32 instruction

Table 11-7 MIPS16 RRR Encoding of the f Field

f	bits 10			
	0	1	2	3
	00	01	10	11
	β	ADDU	β	SUBU

Table 11-8 MIPS16 RR Encoding of the Funct Field

fu	ınct	bits 20							
		0	1	2	3	4	5	6	7
bit	s 43	000	001	010	011	100	101	110	111
0	00	$J(AL)R(C)\delta$	SDBBP	SLT	SLTU	SLLV	BREAK	SRLV	SRAV
1	01	β	*	CMP	NEG	AND	OR	XOR	NOT
2	10	MFHI	CNVT δ	MFLO	β	β	*	β	β
3	11	MULT	MULTU	DIV	DIVU	β	β	β	β

Table 11-9 MIPS16 I8 Encoding of the s Field when funct=SVRS

s	bit 7	
	0	1
	RESTORE	SAVE

Table 11-10 MIPS16 RR Encoding of the ry Field when funct=J(AL)R(C)

ry	bits 75							
	0	1	2	3	4	5	6	7
	000	001	010	011	100	101	110	111
	JR rx	JR ra	JALR	*	JRC rx	JRC ra	JALRC	*

Table 11-11 MIPS16 RR Encoding of the ry Field when funct=CNVT

ry	bits 75							
	0	1	2	3	4	5	6	7
	000	001	010	011	100	101	110	111
	ZEB	ZEH	β	*	SEB	SEH	β	*

# 11.2 Instruction Listing

Table 11-12 through 11-19 list the MIPS16 instruction set.

**Table 11-12 MIPS16 Load and Store Instructions** 

Mnemonic	Instruction	Extensible Instruction
LB	Load Byte	Yes
LBU	Load Byte Unsigned	Yes
LH	Load Halfword	Yes

**Table 11-12 MIPS16 Load and Store Instructions** 

Mnemonic	Instruction	Extensible Instruction
LHU	Load Halfword Unsigned	Yes
LW	Load Word	Yes
SB	Store Byte	Yes
SH	Store Halfword	Yes
SW	Store Word	Yes

**Table 11-13 MIPS16 Save and Restore Instructions** 

Mnemonic	Instruction	Extensible Instruction
RESTORE	Restore Registers and Deallocate Stack Frame	Yes
SAVE	Save Registers and Setup Stack Frame	Yes

**Table 11-14 MIPS16 ALU Immediate Instructions** 

Mnemonic	Instruction	Extensible Instruction
ADDIU	Add Immediate Unsigned	Yes
CMPI	Compare Immediate	Yes
LI	Load Immediate	Yes
SLTI	Set on Less Than Immediate	Yes
SLTIU	Set on Less Than Immediate Unsigned	Yes

Table 11-15 MIPS16 Arithmetic Two or Three Operand Register Instructions

Mnemonic	Instruction	Extensible Instruction
ADDU	Add Unsigned	No
AND	AND	No
CMP	Compare	No
MOVE	Move	No
NEG	Negate	No
NOT	Not	No
OR	OR	No
SEB	Sign-Extend Byte	No
SEH	Sign-Extend Halfword	No

Table 11-15 MIPS16 Arithmetic Two or Three Operand Register Instructions

Mnemonic	Instruction	Extensible Instruction
SLT	Set on Less Than	No
SLTU	Set on Less Than Unsigned	No
SUBU	Subtract Unsigned	No
XOR	Exclusive OR	No
ZEB	Zero-Extend Byte	No
ZEH	Zero-Extend Halfword	No

**Table 11-16 MIPS16 Special Instructions** 

Mnemonic	Instruction	Extensible Instruction
BREAK	Breakpoint	No
SDBBP	Software Debug Breakpoint	No
EXTEND	Extend	No

**Table 11-17 MIPS16 Multiply and Divide Instructions** 

Mnemonic	Instruction	Extensible Instruction
DIV	Divide	No
DIVU	Divide Unsigned	No
MFHI	Move From HI	No
MFLO	Move From LO	No
MULT	Multiply	No
MULTU	Multiply Unsigned	No

**Table 11-18 MIPS16 Jump and Branch Instructions** 

Mnemonic	Instruction	Extensible Instruction
В	Branch Unconditional	Yes
BEQZ	Branch on Equal to Zero	Yes
BNEZ	Branch on Not Equal to Zero	Yes
BTEQZ	Branch on T Equal to Zero	Yes
BTNEZ	Branch on T Not Equal to Zero	Yes
JAL	Jump and Link	No

**Table 11-18 MIPS16 Jump and Branch Instructions** 

Mnemonic	Instruction	Extensible Instruction
JALR	Jump and Link Register	No
JALRC	Jump and Link Register Compact	No
JALX	Jump and Link Exchange	No
JR	Jump Register No	
JRC	Jump Register Compact	No

**Table 11-19 MIPS16 Shift Instructions** 

Mnemonic	Instruction	Extensible Instruction
SRA	Shift Right Arithmetic	Yes
SRAV	Shift Right Arithmetic Variable	No
SLL	Shift Left Logical	Yes
SLLV	Shift Left Logical Variable No	
SRL	Shift Right Logical Yes	
SRLV	Shift Right Logical Variable	No

# **Revision History**

**Table A-1 Revision History** 

Revision	Date	Description
00.90	June 27, 2002	Preliminary release
01.00	August 28, 2002	<ul> <li>Initial commercial release.</li> <li>Removed TLB-related instruction descriptions from Chapter 10, "M4K<sup>TM</sup> Processor Core Instructions." The associated opcodes are shown as reserved in Table 10-9.</li> <li>Updated HSS field in <i>SRSCtl</i> register to show possible values.</li> <li>Added description of MT field in <i>Config</i> register that was previously missing.</li> <li>Changed K0, KU, and K23 fields in <i>Config</i> register to be read-only, with a static value of 2.</li> </ul>
01.01	August 29, 2002	Removed EIC field from <i>IntCtl</i> register, per change in MIPS32 Release 2 Architecture. External interrupt controller mode is specified by Config3 <sub>VEIC</sub> .
01.02	December 15, 2003	<ul> <li>CP0 Config1 register: Added CA field description, corrected typo in IS, IL, IA, DS, DL, DA field description.</li> <li>Trademark updates</li> <li>Replaced reference to obsolete MD00232 wtih MD00086</li> <li>Updated crossrefs in Status register description</li> </ul>