



Using the Enable Pin in a Linear Regulator as a Voltage Supervisor

Prepared by: William Lepkowski
ON Semiconductor

APPLICATION NOTE

INTRODUCTION

The combination of a voltage regulator and a voltage supervisor, shown in Figure 1, is a popular circuit configuration. The addition of the supervisor ensures that the regulated output turns on and off at sufficient input voltages, as well as giving the system the luxury of a safe and ordered startup. An inexpensive alternative, shown in Figure 2, uses the enable pin of a regulator and an external delay network to

provide a safe and ordered startup. Unlike the supervisor solution, this circuit does not immediately shutdown the output once it drops below an unacceptable level. Furthermore, since the delay starts directly after the enable pin goes high, there is no insurance that the output will be at the desired regulated output voltage. The circuit proposed in Figure 3 fixes the problems of Figure 2 by cleverly replacing the single resistor with a resistor divider network.




Figure 1. A voltage supervisor can be used with a voltage regulator to ensure a controlled regulated output.




Figure 2. Resistor R_1 , capacitor C_1 and diode D_1 provide a startup delay for the voltage regulator's enable pin.

AND8239/D




Figure 3. Resistor R_2 serves to raise the switching threshold of the voltage regulator's enable pin. This circuit also has the advantage of not requiring an interrupt pin on the microprocessor.

Circuit Description

The purpose of the resistor divider of Figure 3 is to “trick” the enable pin into turning on at a higher voltage. In most regulators, such as the NCP500, the enable pin is set to a voltage well below the nominal output. As a result, the output will track the input voltage when the enable pin switches from a logic low to logic high. The output and input voltages will be almost identical until the input voltages increases to a level above the dropout voltage of the regulator.

Figure 4 shows a simplified internal diagram of the NCP500 linear voltage regulator. The NCP500 uses a

P-channel MOSFET to achieve a low drop out voltage. In addition, the NCP500 contains overcurrent and thermal protection circuits, along with an enable circuit. The enable pin can be used to shutdown the output voltage for power saving modes and to control the powerup and powerdown characteristic of the device. The enable circuit consists of a voltage comparator that determines when the voltage at the enable pin is either larger or smaller than the magnitude of the reference voltage (V_{REF}). The two resistors of the enable circuit determine the hysteresis of the comparator and account for the difference in the switching threshold voltage between the rising and falling voltage.




Figure 4. Block Diagram of the NCP500 Voltage Regulator

The values of resistors R_1 and R_2 needed to change the threshold voltage of Figure 3's enable pin can be determined

$$V_{IN(TURN-ON)} = [(2 \times V_{EN(RISING)}) - V_{EN(FALLING)}] \times \left(1 + \frac{R_1}{R_2}\right) \quad (\text{eq. 1})$$

where:

$V_{IN(TURN-ON)}$ = The user defined turn-on voltage. It is suggested that minimum $V_{IN(TURN-ON)}$ should be set to $V_{OUT} + V_{DROPOUT}$ to prevent tracking.

$V_{EN(RISING)}$ = The enable pin's rising trip point.

$V_{EN(FALLING)}$ = The enable pin's falling trip point.

$V_{DROPOUT}$ = The regulators dropout voltage.

with the equation (1). Figure 3's circuit was tested with values of 27 k Ω and 8.0 k Ω for R_1 and R_2 respectively.

Example:

$V_{IN(TURN-ON)} = 4.0 \text{ V}$

$V_{EN(RISING)} = 0.89 \text{ V}$ (Taken from Figure 5)

$V_{EN(FALLING)} = 0.85 \text{ V}$ (Taken from Figure 5)

$$\frac{R_1}{R_2} \cong \frac{V_{IN(TURN-ON)}}{((2 \times V_{EN(RISING)}) - V_{EN(FALLING)})} - 1 = \frac{4.0}{((2 \times 0.89) - 0.85)} - 1 = 3.3 \quad (\text{eq. 2})$$

Select $R_2 = 8 \text{ k}\Omega$, then $R_1 = 3.3 \times R_2 \cong 27 \text{ k}\Omega$.

It is important to note that Equation 1 only approximates the value of the resistor divider. In the case of the NCP500, the approximation is fairly accurate. In other voltage regulators, the results may vary slightly. The only time a problem will be noticed though, is if the resistor divider is not large enough. This can be easily fixed by increasing the value of R_1 . However, it is also important to note that since $V_{IN(TURN-ON)}$ is directly proportional to R_1 , increasing R_1 will increase $V_{IN(TURN-ON)}$.

In the data sheet the enable thresholds are usually specified in one of two ways: a minimum and maximum range guaranteed by design or with typical values that go along with the minimum and maximum range. For most applications, the typical threshold values will be more applicable. If the threshold values are not specified, they can be easily found by testing a few parts beforehand. It should also be stressed that Equation 1 is not dependent on just the value of the rising threshold. The rising threshold itself does not take into account the hysteresis, $V_{EN(RISING)} - V_{EN(FALLING)}$, of the enable pin's comparator circuit. Without adding the value of the hysteresis to the value of the rising threshold, there would be no guarantee that the output would turn-off at the proper value.

The delayed input provided by the voltage supervisor is useful for applications dealing with microprocessors. It ensures that the system has a safe and ordered startup before turning on. The circuit in Figure 3 provides a similar function as a voltage supervisor IC by combining the external setup in Figure 2 with the resistor divider calculated in Equation 1. The user can define the appropriate delay time based on their application by using R_1 and C_D as the RC time constant. A diode is added in parallel across R_1 to quickly discharge C_D if the voltage falls below the "new" enable threshold formed by R_1 and R_2 .

Special attention in particular should be paid to R_1 , since it along with C_D will determine the turn-on delay time for the regulator. Ideally the value of C_D should be in the range of $0.01 \mu\text{F}$ and $0.47 \mu\text{F}$. A larger magnitude capacitor will increase the discharge time. Hence, a large capacitor reduces the effectiveness of this circuit to function as a voltage supervisor. Moreover, a smaller capacitance requires less board space.

The following table compares the features of four different controlled output solutions using a voltage regulator. Another possible solution, not shown, combines a voltage regulator with a voltage detector. Detectors are very similar to supervisors; however, a supervisor contains an integrated powerup delay circuit.

Table 1. Voltage Regulator Solutions

Circuit	Advantages	Disadvantages	Reference Figures
Voltage Regulator with enable pin	<ul style="list-style-type: none"> • Enable pin saves power consumption 	<ul style="list-style-type: none"> • No delay at powerup • V_{OUT} tracks V_{IN} on rising and falling edges 	Figure 5
Voltage Regulator with input delay (R_1 , C_D , and D_1)	<ul style="list-style-type: none"> • Turns on at $V_{OUT(NOMINAL)}$ (assuming sufficient delay time) 	<ul style="list-style-type: none"> • No safety feature to ensure that delay time is sufficient • V_{OUT} tracks V_{IN} on falling edge 	Figure 2 Figure 6
Voltage Regulator + Voltage Supervisor	<ul style="list-style-type: none"> • Turns on at $V_{OUT(NOMINAL)}$ • Delay at powerup • Warning signal prior to shutdown • Turns off immediately after insufficient V_{IN} 	<ul style="list-style-type: none"> • Requires an interrupt pin on the microprocessor • 2 IC solution 	Figure 1
Voltage Regulator with input delay and resistor divider (R_1 , R_2 , C_D , and D_1)	<ul style="list-style-type: none"> • Low cost solution • Does not require extra pin on microprocessor • Turns on at $V_{OUT(NOMINAL)}$ • Delay at powerup • Turns off immediately after insufficient V_{IN} 	<ul style="list-style-type: none"> • Requires four discrete parts • No warning signal prior to shutdown 	Figure 3 Figure 7

Test Results

Figure 5 shows the output of the NCP500 linear regulator configured with the enable pin connected to V_{IN} . The points of inflection on the output voltage curve represent the enable trip points. It is clear that the output is tracking the input on

both the rising and falling edges. Figure 6 shows the improvement of adding the external delay network on the rising edge. The falling edge of the output, nonetheless, still continues to track to the input voltage.




Figure 5. Regulator circuits that connect the enable pin to the input voltage have a problem. The output voltage will track the input voltage during the turn-on and turn-off time of the regulator.




Figure 6. Adding the circuitry in Figure 2 eliminates the problem of the output tracking on the rising edge.

AND8239/D

Figure 7 shows further improvement when resistor R_2 is added to the delay network. The schematic of this circuit is shown in Figure 3. It is evident that the output now turns on and off appropriately and that a sufficient delay has been provided. Furthermore, this solution offers the advantage of

eliminating the requirement of an extra pin on the microprocessor. The only thing that this circuit lacks in performance in comparison to the supervisor solution is its lack of a waning signal.




Figure 7. The circuit in Figure 3 turns on only after a sufficient input voltage is reached and shuts down immediately after the input becomes insufficient.

ON Semiconductor and  are registered trademarks of Semiconductor Components Industries, LLC (SCILLC). SCILLC reserves the right to make changes without further notice to any products herein. SCILLC makes no warranty, representation or guarantee regarding the suitability of its products for any particular purpose, nor does SCILLC assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation special, consequential or incidental damages. "Typical" parameters which may be provided in SCILLC data sheets and/or specifications can and do vary in different applications and actual performance may vary over time. All operating parameters, including "Typicals" must be validated for each customer application by customer's technical experts. SCILLC does not convey any license under its patent rights nor the rights of others. SCILLC products are not designed, intended, or authorized for use as components in systems intended for surgical implant into the body, or other applications intended to support or sustain life, or for any other application in which the failure of the SCILLC product could create a situation where personal injury or death may occur. Should Buyer purchase or use SCILLC products for any such unintended or unauthorized application, Buyer shall indemnify and hold SCILLC and its officers, employees, subsidiaries, affiliates, and distributors harmless against all claims, costs, damages, and expenses, and reasonable attorney fees arising out of, directly or indirectly, any claim of personal injury or death associated with such unintended or unauthorized use, even if such claim alleges that SCILLC was negligent regarding the design or manufacture of the part. SCILLC is an Equal Opportunity/Affirmative Action Employer. This literature is subject to all applicable copyright laws and is not for resale in any manner.

PUBLICATION ORDERING INFORMATION

LITERATURE FULFILLMENT:

Literature Distribution Center for ON Semiconductor
P.O. Box 61312, Phoenix, Arizona 85082-1312 USA
Phone: 480-829-7710 or 800-344-3860 Toll Free USA/Canada
Fax: 480-829-7709 or 800-344-3867 Toll Free USA/Canada
Email: orderlit@onsemi.com

N. American Technical Support: 800-282-9855 Toll Free
USA/Canada

Japan: ON Semiconductor, Japan Customer Focus Center
2-9-1 Kamimeguro, Meguro-ku, Tokyo, Japan 153-0051
Phone: 81-3-5773-3850

ON Semiconductor Website: <http://onsemi.com>

Order Literature: <http://www.onsemi.com/litorder>

For additional information, please contact your
local Sales Representative.