

LTI 40SA

Hall Voltage 160mV Thin-Type Package GaAs Hall Device

■ Features

- Small temperature coefficient of the Hall voltage
- Good linearity of the Hall voltage
- Small imbalance voltage
- Directly DC voltage applicable

■ Applications

- Brushless motors
- VCR, CD, CD-ROM, FDD
- Measuring equipment
 - Gauss meters, magnetic substance detectors
- Noncontact sensors
 - Microswitches, tape-end detection
 - Other magnetic detection

■ Absolute Maximum Ratings

Parameter	Symbol	Rating	Unit
Control voltage	V_C	12	V
Control current	I_C	15	mA
Power dissipation	P_D	150	mW
Operating temperature	T_{opr}	-20 to +125	°C
Storage temperature	T_{stg}	-55 to +150	°C
Soldering temperature ^{*1}	T_{sol}	260	°C

*1 Soldering time:10seconds

■ Electrical Characteristics

Parameter	Symbol	Conditions	MIN.	TYP.	MAX.	Unit
No-load Hall voltage ^{***1}	V_H	$V_C=6V, B=100mT$	145	160	175	mV
Imbalance ratio ^{*2}	Rank A	V_{HO}/V_H	2		12	%
	Rank B		-5	—	5	
	Rank C		-2		-12	
Input resistance	R_{IN}	$I_M=1mA, B=0mT$	650	800	950	Ω
Output resistance	R_{OUT}	$I_M=1mA, B=0mT$	1300	1600	1900	Ω
Drift of [rebalanced voltage vs. temperature]	ΔV_{HO}	$V_C=6V, B=0mT, T_a=-20°C \text{ to } 25°C$ $V_C=6V, B=0mT, T_a=25°C \text{ to } 125°C$	-	5	—	mv
Temperature coefficient of Hall voltage	β	$I_C=6mA, B=100mT, T_1=-20°C, T_2=125°C$	—	-0.04	—	%/°C
Temperature coefficient of input resistance	α	$I_M=1mA, B=0mT, T_1=-20°C, T_2=125°C$	—	0.2	—	'??'/°C
Linearity of Hall voltage	γ	$I_C=6mA, B_1=50mT, B_2=100mT$	—	0.3	—	%

*1 No-load Hall voltage is nearly proportional to V_C (within the range of 1 to 6V) at temperatures of -20°C to +125°C

Keep the voltage within the allowable power dissipation range.

*2 Imbalance ratio i. in +/-12% within the range of $V_C=1$ to 6V

$$V_H = V_M - V_{HO}$$

$$\beta = \frac{1}{V_H(T_1)} \times \frac{|V_H(T_2) - V_H(T_1)|}{(T_2 - T_1)} \times 100$$

V_M : Observed Hall voltage

$$\alpha = \frac{1}{R_{IN}(T_1)} \times \frac{|R_{IN}(T_2) - R_{IN}(T_1)|}{(T_2 - T_1)} \times 100$$


V_{HO} : Imbalance voltage

$$\gamma = \frac{|K_H(B_2) - K_H(B_1)|}{|K_H(B_1) + K_H(B_2)|} \times 2 \times 100, K_H = \frac{V_H}{(I_C \times B)}$$






K_H : Sensitivity

■ Outline Dimensions

(Unit : mm)



As for dimensions of tape-packaged products, refer to page 44.

Fig. 1 Hall Voltage vs. Ambient Temperature**Fig. 3 Hall Voltage vs. Magnetic Flux Density****Fig. 5 Hall Voltage vs. Control Voltage****Fig. 2 Input Resistance vs. Ambient Temperature****Fig. 4 Hall Voltage vs. Control Current****Fig. 6 Power Dissipation vs. Ambient Temperature**