

The image shows a large grid of 140 small, square panels arranged in 10 rows and 14 columns. Each panel contains text and graphical elements, but the text is too small and blurry to be legible. The panels appear to be part of a control interface or a data display system. The overall appearance is that of a technical manual or a control panel for a complex system.



This block contains a vertical column of 18 small, illegible data tables or charts. Each entry appears to be a small table with multiple columns and rows of text, possibly representing system parameters or test results. The text is too small to be read, but the layout suggests a structured list of data points.



B1

D e w w  
A [C

1

USER DOCUMENTATION

MACRO V05.03 Tuesday 28-Apr-87 09:02 Page 2

SEQ 000

.REM\_  
IDENTIFICATION

PRODUCT ID: AC-T099E-MC  
PRODUCT TITLE: CVTSDE0 TSV05 CTRL PART 4  
DEPARTMENT: COMPUTER SPECIAL SYSTEMS/PGG  
DATE: JUNE 04, 1987

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

NO RESPONSIBILITY IS ASSUMED FOR THE USE OR RELIABILITY OF SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL OR ITS AFFILIATED COMPANIES.

COPYRIGHT (C) 1982,1987 BY DIGITAL EQUIPMENT CORPORATION

THE FOLLOWING ARE TRADEMARKS OF DIGITAL EQUIPMENT CORPORATION:

DIGITAL  
DEC

PDP  
DECUS

UNIBUS  
DECTAPE

MASSBUS



TABLE OF CONTENTS

1.0	GENERAL INFORMATION
1.1	PROGRAM ABSTRACT
1.2	SYSTEM REQUIREMENTS
1.3	RELATED DOCUMENTS AND STANDARDS
1.4	DIAGNOSTIC HIERARCHY PREREQUISITES
1.5	ASSUMPTIONS
2.0	OPERATING INSTRUCTIONS
2.1	COMMANDS
2.2	SWITCHES
2.3	FLAGS
2.4	HARDWARE QUESTIONS
2.5	SOFTWARE QUESTIONS
2.6	EXTENDED P-TABLE DIALOGUE
2.7	QUICK STARTUP PROCEDURE
3.0	ERROR INFORMATION
4.0	PERFORMANCE AND PROGRESS REPORTS
5.0	DEVICE INFORMATION TABLES
6.0	TEST SUMMARIES
7.0	MAINTENANCE HISTORY



## 1.0 GENERAL INFORMATION

### 1.1 PROGRAM ABSTRACT

THIS IS A PDP-11/23 RESIDENT DIAGNOSTIC WHICH CHECKS THE FUNCTIONALITY OF A TSV05 MAGTAPE SUBSYSTEM WHILE CONNECTED TO A PDP-11/23 SYSTEM (Q-BUS). THE PROGRAM PROVIDES ERROR MESSAGES WHICH IDENTIFY FAILING FUNCTIONS THAT AID IN THE REPAIR OF THE DEVICE. THIS DIAGNOSTIC CONSIST OF EIGHT TEST WHICH ARE EXECUTED IN SEQUENCE.

THIS DIAGNOSTIC HAS BEEN WRITTEN FOR USE WITH THE DIAGNOSTIC RUNTIME SERVICES SOFTWARE (SUPERVISOR). THESE SERVICES PROVIDE THE INTERFACE TO THE OPERATOR AND TO THE SOFTWARE ENVIRONMENT. THIS PROGRAM CAN BE USED WITH XXDP+, ACT, APT, SLIDE AND PAPER TAPE. FOR A COMPLETE DESCRIPTION OF THE RUNTIME SERVICES, REFER TO THE XXDP+ USER'S MANUAL. THERE IS A BRIEF DESCRIPTION OF THE RUNTIME SERVICES IN SECTION 2 OF THIS DOCUMENT.

### 1.2 SYSTEM REQUIREMENTS

PDP-11/23 PROCESSOR AND MEMORY  
CAUTION:DIAGNOSTIC REQUIRES 32K WORDS OF MEMORY  
(28K USEABLE AND 4K RESERVED FOR I/O PAGE)  
TSV05 MAGTAPE SUBSYSTEM (DRIVE AND CONTROLLER)  
CONSOLE TERMINAL  
PDP-11 DIAGNOSTIC SUPERVISOR (HSA44.SYS VERSION 34 OR LATER)  
PDP-11 DIAGNOSTIC LOADER/MONITOR (XXDP+)

### 1.3 RELATED DOCUMENTS AND STANDARDS

#### DIGITAL EQUIPMENT CORPORATION DOCUMENTS:

1. CHQUS XXDP+ USERS MANUAL; DOCUMENT NUMBER AC-F348E-MC  
DATE: 14 JULY 1980.
2. TSV05 TRANSPORT SUBSYSTEM USER'S GUIDE; DOCUMENT NUMBER EK-TSV05-UG-001  
DATE: AUGUST 1982
3. TSV05 TRANSPORT SUBSYSTEM TECHNICAL MANUAL; DOCUMENT NUMBER EK-TSV05-TM-001  
DATE: AUGUST 1982
4. TSV05 TRANSPORT SUBSYSTEM INSTALLATION MANUAL; DOCUMENT NUMBER EK-TSV05-IN-001  
DATE: AUGUST 1982



#### 1.4 DIAGNOSTIC HIERARCY PREREQUISITES

FUNCTIONAL PDP-11/23 CENTRAL PROCESSOR AND MEMORY  
FUNCTIONAL CONSOLE TERMINAL  
FUNCTIONAL STANDALONE DIAGNOSTIC SUPERVISOR  
FUNCTIONAL DIAGNOSTIC LOADER/MONITOR (XXDP.)

#### 1.5 ASSUMPTIONS

ALL HARDWARE EXCEPT THE HARDWARE UNDER TEST IS ASSUMED TO WORK PROPERLY OR FALSE ERRORS CAN BE REPORTED.  
THE TAPE BEING USED ON THE TS05 TRANSPORT IS A KNOWN GOOD REEL OF TAPE.  
CVTSAA, CVTSBE AND CVTSCD HAVE SUCESSFULLY RUN.

#### 2.0 OPERATING INSTRUCTIONS

THIS SECTION CONTAINS A BRIEF DESCRIPTION OF THE RUNTIME SERVICES. FOR DETAILED INFORMATION, REFER TO THE XXDP. USER'S MANUAL (CHQUS).

#### 2.1 COMMANDS

THERE ARE ELEVEN LEGAL COMMANDS FOR THE DIAGNOSTIC RUNTIME SERVICES (SUPERVISOR). THIS SECTION LISTS THE COMMANDS AND GIVES A VERY BRIEF DESCRIPTION OF THEM. THE XXDP. USER'S MANUAL HAS MORE DETAILS.

COMMAND	EFFECT
-----	-----
START	START THE DIAGNOSTIC FROM AN INITIAL STATE
RESTART	START THE DIAGNOSTIC WITHOUT INITIALIZING
CONTINUE	CONTINUE AT TEST THAT WAS INTERRUPTED (AFTER ↑C)
PROCEED	CONTINUE FROM AN ERROR HALT
EXIT	RETURN TO XXDP. MONITOR (XXDP. OPERATION ONLY!)
ADD	ACTIVATE A UNIT FOR TESTING (ALL UNITS ARE CONSIDERED TO BE ACTIVE AT START TIME)
DROP	DEACTIVATE A UNIT
PRINT	PRINT STATISTICAL INFORMATION (IF IMPLEMENTED BY THE DIAGNOSTIC - SECTION 4.0)
DISPLAY	TYPE A LIST OF ALL DEVICE INFORMATION
FLAGS	TYPE THE STATE OF ALL FLAGS (SEE SECTION 2.3)
ZFLAGS	CLEAR ALL FLAGS (SEE SECTION 2.3)

A COMMAND CAN BE RECOGNIZED BY THE FIRST THREE CHARACTERS. SO YOU MAY, FOR EXAMPLE, TYPE "STA" INSTEAD OF "START".



### 2.1.1 OPERATOR COMMANDS

THE TSV05 DIAGNOSTIC IS A PDP-11/23 DIAGNOSTIC SUPERVISOR COMPATIBLE PROGRAM. ALL LOADING AND RUNTIME INSTRUCTIONS CAN BE REFERENCED IN THE CHQUS XXDP- USERS MANUAL, DOCUMENT NUMBER AC-F348E-MC. THE USER ENTRY IS IN QUOTES.

BOOT THE DIAGNOSTIC XXDP MEDIA

```
.R VTSD??  
DIAG. RUN-TIME SERVICES REV D. APR 79  
CVTSD-E-0  
****TSV05 LOGIC DIAGNOSTIC****  
UNIT IS TSV05  
>DR
```

### 2.2 SWITCHES

THERE ARE SEVERAL SWITCHES WHICH ARE USED TO MODIFY SUPERVISOR OPERATION. THESE SWITCHES ARE APPENDED TO THE LEGAL COMMANDS. ALL OF THE LEGAL SWITCHES ARE TABULATED BELOW WITH A BRIEF DESCRIPTION OF EACH. IN THE DESCRIPTIONS BELOW, A DECIMAL NUMBER IS DESIGNATED BY "DDDD".

SWITCH	EFFECT
/TESTS:LIST	EXECUTE ONLY THOSE TESTS SPECIFIED IN THE LIST. LIST IS A STRING OF TEST NUMBERS, FOR EXAMPLE - /TESTS:1:5:7-10. THIS LIST WILL CAUSE TESTS 1,5,7,8,9,10 TO BE RUN. ALL OTHER TESTS WILL NOT BE RUN.
/PASS:DDDD	EXECUTE DDDDD PASSES (DDDD = 1 TO 64000)
/FLAGS:FLGS	SET SPECIFIED FLAGS. FLAGS ARE DESCRIBED IN SECTION 2.3.
/EOP:DDDD	REPORT END OF PASS MESSAGE AFTER EVERY DDDDD PASSES ONLY. (DDDD = 1 TO 64000)
/UNITS:LIST	TEST/ADD/DROP ONLY THOSE UNITS SPECIFIED IN THE LIST. LIST EXAMPLE - /UNITS:0:5:10-12 USE UNITS 0,5,10,11,12 (UNIT NUMBERS = 0-63)

EXAMPLE OF SWITCH USAGE:

```
START/TESTS:1-5/PASS:1000/EOP:100
```

THE EFFECT OF THIS COMMAND WILL BE: 1) TESTS 1 THROUGH 5 WILL BE EXECUTED, 2) ALL UNITS WILL TESTED 1000 TIMES AND 3) THE END OF PASS MESSAGES WILL BE PRINTED AFTER EACH 100 PASSES ONLY. A SWITCH CAN BE RECOGNIZED BY THE FIRST THREE CHARACTERS. YOU MAY, FOR EXAMPLE, TYPE "/TES:1-5" INSTEAD OF "/TESTS:1-5".



BELOW IS A TABLE THAT SPECIFIES WHICH SWITCHES CAN BE USED BY EACH COMMAND.

	TESTS	PASS	FLAGS	EOP	UNITS
START	X	X	X	X	X
RESTART	X	X	X	X	X
CONTINUE		X	X	X	
PROCEED			X		
DROP					X
ADD					X
PRINT					
DISPLAY					X
FLAGS					
ZFLAGS					
EXIT					

### 2.3 FLAGS

FLAGS ARE USED TO SET UP CERTAIN OPERATIONAL PARAMETERS SUCH AS LOOPING ON ERROR. ALL FLAGS ARE CLEARED AT STARTUP AND REMAIN CLEARED UNTIL EXPLICITLY SET USING THE FLAGS SWITCH. FLAGS ARE ALSO CLEARED AFTER A START COMMAND UNLESS SET USING THE FLAG SWITCH. THE ZFLAGS COMMAND MAY ALSO BE USED TO CLEAR ALL FLAGS. WITH THE EXCEPTION OF THE START AND ZFLAGS COMMANDS, NO COMMANDS AFFECT THE STATE OF THE FLAGS; THEY REMAIN SET OR CLEARED AS SPECIFIED BY THE LAST FLAG SWITCH.

FLAG	EFFECT
HOE	HALT ON ERROR - CONTROL IS RETURNED TO RUNTIME SERVICES COMMAND MODE
LOE	LOOP ON ERROR
IER*	INHIBIT ALL ERROR REPORTS
IBR*	INHIBIT ALL ERROR REPORTS EXCEPT FIRST LEVEL (FIRST LEVEL CONTAINS ERROR TYPE, NUMBER, PC, TEST AND UNIT)
IXE*	INHIBIT EXTENDED ERROR REPORTS (THOSE CALLED BY PRINTX MACRO'S)
PRI	DIRECT MESSAGES TO LINE PRINTER
PNT	PRINT TEST NUMBER AS TEST EXECUTES
BOE	"BELL" ON ERROR
UAM	UNATTENDED MODE (NO MANUAL INTERVENTION)
ISR	INHIBIT STATISTICAL REPORTS (DOES NOT APPLY TO DIAGNOSTICS WHICH DO NOT SUPPORT STATISTICAL REPORTING)
IDR	INHIBIT PROGRAM DROPPING OF UNITS
ADR	EXECUTE AUTODROP CODE
LOT	LOOP ON TEST

\*ERROR MESSAGES ARE DESCRIBED IN SECTION 3.1



SEE THE XXDP\* USER'S MANUAL FOR MORE DETAILS ON FLAGS. YOU MAY SPECIFY MORE THAN ONE FLAG WITH THE FLAG SWITCH. FOR EXAMPLE, TO CAUSE THE PROGRAM TO LOOP ON ERROR, INHIBIT ERROR REPORTS AND TYPE A "BELL" ON ERROR, YOU MAY USE THE FOLLOWING STRING:

```
/FLAGS:LOE:IER:BOE
```

#### 2.4 HARDWARE QUESTIONS

WHEN A DIAGNOSTIC IS STARTED, THE RUNTIME SERVICES WILL PROMPT THE USER FOR HARDWARE INFORMATION BY TYPING "CHANGE HW (L) ?" YOU MUST ANSWER "Y" AFTER A START COMMAND UNLESS THE HARDWARE INFORMATION HAS BEEN "PRELOADED" USING THE SETUP UTILITY (SEE CHAPTER 14 OF THE XXDP\* USER'S MANUAL). WHEN YOU ANSWER THIS QUESTION WITH A "Y", THE RUNTIME SERVICES WILL ASK FOR THE NUMBER OF UNITS (IN DECIMAL).

AFTER INITIAL STARTING OF THE PROGRAM (START COMMAND TO THE DIAGNOSTIC SUPERVISOR), THE PROGRAM WILL ISSUE THE "CHANGE HW?" QUESTION TO ASK IF THE HARDWARE PARAMETERS ARE TO BE CHANGED (BY THE OPERATOR).

ON A "N" (NO) RESPONSE TO THE "CHANGE HW?" QUESTION, THE DIAGNOSTIC WILL RUN USING THE DEFAULT VALUES FOR ALL QUESTIONS. THE DEFAULT ADDRESS AND VECTOR ARE:

```
TSBA/TSDB = 172520, VECTOR = 224
```

ON A "Y" (YES) RESPONSE TO THE QUESTION, THE FOLLOWING QUESTIONS WILL THEN BE ASKED TO ALLOW THE OPERATOR TO SELECT THE UNITS TO BE TESTED. A VALUE, IF PRESENT, LOCATED TO THE LEFT OF THE QUESTION MARK IS THE DEFAULT VALUE THAT WILL BE TAKEN IF ONLY A CARRIAGE RETURN IS TYPED AS A RESPONSE. A "(D)" IN A QUESTION INDICATES THAT A DECIMAL NUMBER IS REQUIRED AS A RESPONSE. AN "(O)" INDICATES AN OCTAL NUMBER IS BEING SOLICITED. AN "(L)" INDICATES THAT A LOGICAL RESPONSE IS TO BE MADE: "Y" FOR YES, "N" FOR NO.

```
# UNITS (D) ? <ENTER THE NUMBER OF M7196 CONTROLLERS
PRESENT TO BE TESTED>
```

```
UNIT 0
```

```
DEVICE ADDRESS (O) 172520 ? <ENTER THE ADDRESS OF THE
TSBA/TSDB REGISTER>
```

```
VECTOR (O) 224 ? <ENTER ADDRESS OF INTERRUPT
VECTOR>
```

THE ADDRESS AND VECTOR QUESTIONS WILL BE ASKED FOR EACH OF THE NUMBER OF UNITS (CONTROLLERS) SPECIFIED IN THE "# UNITS?" QUESTION. LOGICAL UNIT NUMBERS ARE ASSIGNED IN ORDER, BEGINNING AT 0. UP TO FOUR UNITS CAN BE SELECTED FOR TESTING AS FOLLOWS:  
UP TO 4 TSV05 CONTROLLERS PER 11/23 AND UP TO 2 DRIVES PER CONTROLLER



## 2.5 SOFTWARE QUESTIONS

AFTER YOU HAVE ANSWERED THE HARDWARE QUESTIONS OR AFTER A RESTART OR CONTINUE COMMAND, THE RUNTIME SERVICES WILL ASK FOR SOFTWARE PARAMETERS. THESE PARAMETERS WILL GOVERN SOME DIAGNOSTIC SPECIFIC OPERATION MODES. YOU WILL BE PROMPTED BY "CHANGE SW (L) ?" IF YOU WISH TO CHANGE ANY PARAMETERS, ANSWER BY TYPING "Y". THE SOFTWARE QUESTIONS AND THE DEFAULT VALUES ARE DESCRIBED IN THE NEXT PARAGRAPH(S).

THE FOLLOWING QUESTIONS ARE ASKED ON A START, RESTART, OR CONTINUE. THEY ALLOW FLEXIBILITY IN THE WAY THE PROGRAM BEHAVES.

CHANGE SW (L) ? <TYPE Y TO CAUSE THE FOLLOWING  
QUESTIONS TO BE ASKED>

INHIBIT ITERATIONS (L) N ? <TYPE "Y" TO PREVENT MULTIPLE  
ITERATIONS OF CERTAIN TESTS.  
THIS CAUSES EACH TEST PASS TO  
RUN AS QUICKLY AS POSSIBLE.  
ONLY QUICK-RUNNING LOGIC  
TESTS USE MULTIPLE  
ITERATIONS.>

## 2.6 EXTENDED P-TABLE DIALOGUE

WHEN YOU ANSWER THE HARDWARE QUESTIONS, YOU ARE BUILDING ENTRIES IN A TABLE THAT DESCRIBES THE DEVICES UNDER TEST. THE SIMPLEST WAY TO BUILD THIS TABLE IS TO ANSWER ALL QUESTIONS FOR EACH UNIT TO BE TESTED. IF YOU HAVE A MULTIPLEXED DEVICE SUCH AS A MASS STORAGE CONTROLLER WITH SEVERAL DRIVES OR A COMMUNICATION DEVICE WITH SEVERAL LINES, THIS BECOMES TEDIOUS SINCE MOST OF THE ANSWERS ARE REPETITIOUS.

TO ILLUSTRATE A MORE EFFICIENT METHOD, SUPPOSE YOU ARE TESTING A DEVICE, THE XY11. SUPPOSE THIS DEVICE CONSISTS OF A CONTROL MODULE WITH EIGHT UNITS (SUB-DEVICES) ATTACHED TO IT. THESE UNITS ARE DESCRIBED BY THE OCTAL NUMBERS 0 THROUGH 7. THERE IS ONE HARDWARE PARAMETER THAT CAN VARY AMONG UNITS CALLED THE Q-FACTOR. THIS Q-FACTOR MAY BE 0 OR 1. BELOW IS A SIMPLE WAY TO BUILD A TABLE FOR ONE XY11 WITH EIGHT UNITS.

# UNITS (D) ? 8<CR>

UNIT 1  
CSR ADDRESS (0) ? 160000<CR>  
SUB-DEVICE # (0) ? 0<CR>  
Q-FACTOR (0) 0 ? 1<CR>

UNIT 2  
CSR ADDRESS (0) ? 160000<CR>  
SUB-DEVICE # (0) ? 1<CR>  
Q-FACTOR (0) 1 ? 0<CR>

UNIT 3  
CSR ADDRESS (0) ? 160000<CR>  
SUB-DEVICE # (0) ? 2<CR>



```
Q-FACTOR (0) 0 ? <CR>
UNIT 4
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 3<CR>
Q-FACTOR (0) 0 ? <CR>
UNIT 5
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 4<CR>
Q-FACTOR (0) 0 ? <CR>
UNIT 6
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 5<CR>
Q-FACTOR (0) 0 ? <CR>
UNIT 7
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 6<CR>
Q-FACTOR (0) 0 ? 1<CR>
UNIT 8
CSR ADDRESS (0) 160000<CR>
SUB-DEVICE # (0) ? 7<CR>
Q-FACTOR (0) 1 ? <CR>
```

NOTICE THAT THE DEFAULT VALUE FOR THE Q-FACTOR CHANGES WHEN A NON-DEFAULT RESPONSE IS GIVEN. BE CAREFUL WHEN SPECIFYING MULTIPLE UNITS!

AS YOU CAN SEE FROM THE ABOVE EXAMPLE, THE HARDWARE PARAMETERS DO NOT VARY SIGNIFICANTLY FROM UNIT TO UNIT. THE PROCEDURE SHOWN IS NOT VERY EFFICIENT.

THE RUNTIME SERVICES CAN TAKE MULTIPLE UNIT SPECIFICATIONS HOWEVER. LET'S BUILD THE SAME TABLE USING THE MULTIPLE SPECIFICATION FEATURE.

```
# UNITS (0) ? 8<CR>
UNIT 1
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 0,1<CR>
Q-FACTOR (0) 0 ? 1,0<CR>
UNIT 3
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 2-5<CR>
Q-FACTOR (0) 0 ? 0<CR>
UNIT 7
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 6,7<CR>
Q-FACTOR (0) 0 ? 1<CR>
```

AS YOU CAN SEE IN THE ABOVE DIALOGUE, THE RUNTIME SERVICES WILL



BUILD AS MANY ENTRIES AS IT CAN WITH THE INFORMATION GIVEN IN ANY ONE PASS THROUGH THE QUESTIONS. IN THE FIRST PASS, TWO ENTRIES ARE BUILT SINCE TWO SUB-DEVICES AND Q-FACTORS WERE SPECIFIED. THE SERVICES ASSUME THAT THE CSR ADDRESS IS 160000 FOR BOTH SINCE IT WAS SPECIFIED ONLY ONCE. IN THE SECOND PASS, FOUR ENTRIES WERE BUILT. THIS IS BECAUSE FOUR SUB-DEVICES WERE SPECIFIED. THE "-" CONSTRUCT TELLS THE RUNTIME SERVICES TO INCREMENT THE DATA FROM THE FIRST NUMBER TO THE SECOND. IN THIS CASE, SUB-DEVICES 2, 3, 4 AND 5 WERE SPECIFIED. (IF THE SUB-DEVICE WERE SPECIFIED BY ADDRESSES, THE INCREMENT WOULD BE BY 2 SINCE ADDRESSES MUST BE ON AN EVEN BOUNDARY.) THE CSR ADDRESSES AND Q-FACTORS FOR THE FOUR ENTRIES ARE ASSUMED TO BE 160000 AND 0 RESPECTIVELY SINCE THEY WERE ONLY SPECIFIED ONCE. THE LAST TWO UNITS ARE SPECIFIED IN THE THIRD PASS.

THE WHOLE PROCESS COULD HAVE BEEN ACCOMPLISHED IN ONE PASS AS SHOWN BELOW.

```
# UNITS (D) ? 8<CR>
UNIT 1
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 0-7<CR>
Q-FACTOR (0) 0 ? 0.1,0,....1,1<CR>
```

AS YOU CAN SEE FROM THIS EXAMPLE, NULL REPLIES (COMMAS ENCLOSING A NULL FIELD) TELL THE RUNTIME SERVICES TO REPEAT THE LAST REPLY.



## 2.7 QUICK START-UP PROCEDURE (XXDP\*)

TO START-UP THIS PROGRAM:

1. BOOT XXDP\*
2. GIVE THE DATE AND ANSWER THE LSI AND 50HZ (IF THERE IS A CLOCK) QUESTIONS
3. TYPE "R NAME", WHERE NAME IS THE NAME OF THE BIN OR BIC FILE FOR THIS PROGRAM
4. TYPE "START"
5. ANSWER THE "CHANGE HW" QUESTION WITH "Y"
6. ANSWER ALL THE HARDWARE QUESTIONS
7. ANSWER THE "CHANGE SW" QUESTION WITH "N"

WHEN YOU FOLLOW THIS PROCEDURE YOU WILL BE USING ONLY THE DEFAULTS FOR FLAGS AND SOFTWARE PARAMETERS. THESE DEFAULTS ARE DESCRIBED IN SECTIONS 2.3 AND 2.5.

## 3.0 ERROR INFORMATION

### 3.1 TYPES OF ERROR MESSAGES

THERE ARE THREE LEVELS OF ERROR MESSAGES THAT MAY BE ISSUED BY A DIAGNOSTIC: GENERAL, BASIC AND EXTENDED. GENERAL ERROR MESSAGES ARE ALWAYS PRINTED UNLESS THE "IER" FLAG IS SET (SECTION 2.3). THE GENERAL ERROR MESSAGE IS OF THE FORM:

NAME TYPE NUMBER ON UNIT NUMBER TST NUMBER PC:XXXXXX  
ERROR MESSAGE

WHERE: NAME = DIAGNOSTIC NAME  
TYPE = ERROR TYPE (SYS FATAL, DEV FATAL, HARD OR SOFT)  
NUMBER = ERROR NUMBER  
UNIT NUMBER = 0 - N (N IS LAST UNIT IN PTABLE)  
TST NUMBER = TEST AND SUBTEST WHERE ERROR OCCURRED  
PC:XXXXXX = ADDRESS OF ERROR MESSAGE CALL

BASIC ERROR MESSAGES ARE MESSAGES THAT CONTAIN SOME ADDITIONAL INFORMATION ABOUT THE ERROR. THESE ARE ALWAYS PRINTED UNLESS THE "IER" OR "IBR" FLAGS ARE SET (SECTION 2.3). THESE MESSAGES ARE PRINTED AFTER THE ASSOCIATED GENERAL MESSAGE.

EXTENDED ERROR MESSAGES CONTAIN SUPPLEMENTARY ERROR INFORMATION SUCH AS REGISTER CONTENTS OR GOOD/BAD DATA. THESE ARE ALWAYS PRINTED UNLESS THE "IER", "IBR" OR "IXE" FLAGS ARE SET (SECTION 2.3). THESE MESSAGES ARE PRINTED AFTER THE ASSOCIATED GENERAL ERROR MESSAGE AND ANY ASSOCIATED BASIC ERROR MESSAGES.

### 3.2 SPECIFIC ERROR MESSAGES

BELOW ARE SAMPLE ERROR MESSAGES. EACH ERROR MESSAGE REPRESENTS DIFFERENT TYPES OF ERRORS DETECTED BY THIS DIAGNOSTIC.

#### ERROR MESSAGE EXAMPLE 1

THIS ERROR IS INDICATIVE OF AN INCORRECT REGISTER OR STATUS WORD RETURNED TO THE DIAGNOSTIC. THE FIRST PART DEFINES THE TEST FUNCTION AND UNIT THAT FAILED. THE SECOND PART PROVIDES THE REGISTER BITS AND THEIR MNEMONICS FOR THE INCORRECT REGISTER OR STATUS WORDS. THE THIRD PART IS THE EXPECTED AND RECEIVED DATA.

TST: 016 FIFO EXERCISER TEST  
CVTSD HRD ERR 01610 ON UNIT 00 TST 016 SUB 002 PC: 040624  
FIFO STATUS (IN WORD 9) INCORRECT AFTER WRITE FIFO

TAPE BUS SIGNALS IN WORD #8: - DESIGNATOR <BIT #>  
PARERR<15> IEOT <12> IFMK <9> IRDY<6> IRWD<2>  
IRESV2<14> IIDENT<11> IHER <8> IONL<5> IFBY<1>  
IRESV1<13> ICER <10> ISPEED<7> ILDP<4> IFPT<0>

TAPE BUS SIGNALS IN WORD #9:  
DATMIS<7> ILW<6> OUTRDY<5> INRDY<4>

MESSAGE BUFFER ADDRESS = 047352

MESSAGE BUFFER CONTENTS:

WORD #0	EXPD: 100020	RECV: 100020	XOR: 000000
WORD #1	EXPD: 000012	RECV: 000012	XOR: 000000
WORD #2	EXPD: 000000	RECV: 000000	XOR: 000000
WORD #3	EXPD: 000010	RECV: 000010	XOR: 000000
WORD #4	EXPD: 000000	RECV: 000000	XOR: 000000
WORD #5	EXPD: 000000	RECV: 000000	XOR: 000000
WORD #6	EXPD: 000000	RECV: 000000	XOR: 000000
WORD #7	EXPD: 000000	RECV: 000000	XOR: 000000
WORD #8	EXPD: 070217	RECV: 070217	XOR: 000000
WORD #9	EXPD: 000074	RECV: 000034	XOR: 000040

#### ERROR MESSAGE EXAMPLE 2

THIS ERROR SHOWS A FATAL FUNCTION ERROR FROM THE TAPE DRIVE. IN THIS INSTANCE A UNRECOVERABLE ERROR OCCURED WHICH INDICATES THAT THE CONTROLLER MAY BE DEFECTIVE.

CVTSD HRD ERR 00159 ON UNIT 00 TST 001 SUB 005 PC: 026202  
TSSR NOT CORRECT AFTER SPACE RECORDS COMMAND  
TSSR = 100214  
TSSR BITS SET: SC,SSR  
TERMINATION CLASS CODE = UNRECOVERABLE ERROR  
PACKET ADDRESS = 026420  
PACKET WORD # = 140010  
PACKET WORD # = 000010  
PACKET WORD # = 000000  
PACKET WORD # = 000024



ERROR MESSAGE EXAMPLE 3

THIS ERROR SHOWS THAT THE MOTION BIT DID NOT GET SET WHILE DOING A REWIND  
WITH EXTENDED FEATURES MODE ENABLED.

CVTSD HRD ERR 00121 ON UNIT 00 TST 001 SUB 002 PC: 023306  
MOT BIT (XSTO) NOT SET DURING REWIND (EXTENDED FEATURES MODE)  
EXPD: 000312 RECV: 000112 XOR: 000200

## 4.0 PERFORMANCE AND PROGRESS REPORTS

AT THE END OF EACH PASS, THE PASS COUNT IS GIVEN ALONG WITH THE TOTAL NUMBER OF ERRORS REPORTED SINCE THE DIAGNOSTIC WAS STARTED. THE "EOP" SWITCH CAN BE USED TO CONTROL HOW OFTEN THE END OF PASS MESSAGE IS PRINTED. SECTION 2.2 DESCRIBES SWITCHES.

## SUCCESSFUL RUN EXAMPLE (PDP-11/23)

```
DR>STA/FLA:PNT:HOE
UNITS (D) ? 1
UNIT 0
DEVICE ADDRESS (0) 172520 ? <CR>
VECTOR (0) 224 ? <CR>
CHANGE SW (L) ? N<CR>
```

THE ABOVE COMMAND WILL START THE DIAGNOSTIC. THE COMMAND HAS TWO SWITCHES ON WHICH ARE "PRINT EACH TEST NBR AS EXECUTED" AND "HALT ON ERROR".

```
TST: 001 SKIP TAPE MARKS TEST
TST: 002 NO-OP AND INITIALIZE TEST
TST: 003 ERASE AND OPERATION INCOMPLETE TEST
TST: 004 DATA PARITY TEST
TST: 005 TEST OF OPERATIONS AT EOT TEST
TST: 006 EXTENDED-MODE FUNCTIONS TEST
TST: 007 RECORD BUFFERING TEST
TST: 008 FUNCTION TIMING TEST
```

0 ERRORS

NOTE: THE DIAGNOSTIC WILL RUN CONTINUOUSLY UNLESS A PASS NUMBER LIMIT HAS BEEN SPECIFIED WITH THE "/PASS:" SWITCH.

## PROGRAM RUN TIMES

THE AVERAGE RUN TIMES OF THE PROGRAM ARE LISTED BELOW. THESE FIGURES ARE TO BE USED AS A GUIDE. THE TIMING WAS DONE ON A PDP-11/23 PROCESSOR WITH A LA34 CONSOLE.

THE PROGRAM RUNS IN TWO MODES; NO ITERATIONS AND DEFAULT MODE. IN THE NO ITERATIONS MODE, EACH TEST IS RUN ONCE, WITH NO ITERATIONS. IN THE DEFAULT MODE EACH TEST IS REPEATED BY THE NUMBER OF TIMES INDICATED BY THE ITERATION COUNT. NO ITERATIONS MODE IS SELECTED BY ANSWERING THE INHIBIT ITERATIONS QUESTION WITH A "Y" (YES).

TEST NUMBER	N/I SECS.	NUMBER ITER	DEF SECS.
1	1	2	1
2	1	1	0



3	1	1	0
4	1	1	0
5	1	1	0
6	1	1	0
7	1	1	0
8	1	1	0

THE TIMES REQUIRED TO RUN TESTS 1 THROUGH 37 IN ONE COMMAND:

Q.V.	15 SECONDS
DEFAULT	16 SECONDS

### 5.0 DEVICE INFORMATION TABLES

WHENEVER THE PROGRAM IS STARTED, VIA THE STA(RT) COMMAND, THE SUPERVISOR REQUESTS THE FOLLOWING P-TABLES PARAMETER CHANGES:

CHANGE HW (L) ?

# UNITS (D) ? <ENTER THE NUMBER OF M7196 CONTROLLERS  
PRESENT TO BE TESTED>

UNIT 0

DEVICE ADDRESS (O) 172520 ? <ENTER THE ADDRESS OF THE  
TSBA/TSDB REGISTER>

VECTOR (O) 224 ? <ENTER ADDRESS OF INTERRUPT  
VECTOR>

THE ADDRESS AND VECTOR QUESTIONS WILL BE ASKED FOR EACH OF THE NUMBER OF UNITS (CONTROLLERS) SPECIFIED IN THE "# UNITS?" QUESTION. LOGICAL UNIT NUMBERS ARE ASSIGNED IN ORDER, BEGINNING AT 0. UP TO FOUR UNITS CAN BE SELECTED FOR TESTING.

IN ADDITION, ON A START, RESTART OR CONTINUE THE SUPERVISOR REQUESTS CHANGES TO THE SOFTWARE OPERATING PARAMETERS, AS FOLLOWS:

CHANGE SW (L) ?

INHIBIT ITERATIONS (L) N ?

## 6.0 TEST SUMMARIES

## TEST 1: WRITE TAPE MARK RETRY

THIS TEST VERIFIES PROPER OPERATION OF THE WRITE TAPE MARK RETRY COMMAND (SPACE REVERSE, ERASE, WRITE TAPE MARK).

## TEST 2: SKIP TAPE MARKS

THIS TEST VERIFIES PROPER OPERATION OF THE SKIP TAPE MARKS FORWARD AND SKIP TAPE MARKS REVERSE COMMANDS. PROPER OPERATION UNDER CONTROL OF ALL COMBINATIONS OF THE ENABLE SKIP TAPE MARKS STOP (ESS) AND ENABLE TAPE MARKS STOP OFF BOT (ENB) BITS SPECIFIED BY THE WRITE CHARACTERISTICS COMMAND.

## TEST 3: NO-OP ("CLEAN TAPE") AND INITIALIZE

THIS TEST VERIFIES PROPER OPERATION OF THE NO-OP ("CLEAN TAPE") AND INITIALIZE COMMAND (SPACE REVERSE, ERASE, WRITE DATA)

## TEST 4: ERASE AND OPERATION INCOMPLETE

VERIFIES THAT AN ERASE COMMAND ISSUED WHEN THE TAPE IS POSITIONED AT BOT OPERATES PROPERLY AND ACTUALLY ERASES TAPE.

## TEST 5: DATA PARITY TEST

This test verifies that the data parity circuitry in both the controller and the transport is operating properly by forcing data records with wrong parity to be written onto tape and checking the results obtained when the data is read.

## TEST 6: OPERATIONS AT EOT

THIS TEST VERIFIES PROPER OPERATION OF THE WRITE DATA RETRY COMMAND (SPACE REVERSE, ERASE, WRITE DATA)

## TEST 7: EXTENDED MODE FEATURES

THIS TEST VERIFIES THE OPERATION OF COMMANDS ONLY AVAILABLE WHEN THE CONTROLLER IS IN THE EXTENDED FEATURES MODE. THESE COMMANDS ARE:

REWIND WITH IMMEDIATE INTERRUPT

IF THE CONTROLLER IS NOT ALREADY IN EXTENDED FEATURES MODE, IT IS PLACED THERE VIA A WRITE SUBSYSTEM MEMORY COMMAND.



**TEST 8: RECORD BUFFERING**

THIS TEST VERIFIES THAT RECORD BUFFERING, USED FOR WRITE DATA AND READ NEXT COMMANDS, OPERATES PROPERLY AND IS PROPERLY CONTROLLED BY THE EXTENDED CHARACTERISTICS DATA WORD. IF THE M7196 CONTROLLER MODULE IS NOT ALREADY IN EXTENDED FEATURES MODE (AS CONTROLLED BY THE DIP SWITCH ON THE MODULE), IT IS PLACED INTO THAT MODE BY INVERTING THE SENSE OF THE SWITCH USING THE WRITE SUBSYSTEM MEMORY COMMAND. NOTE THAT RECORD BUFFERING HAS BEEN ENABLED IN PREVIOUS TESTS OF READ AND WRITE AND SO HAS BEEN PARTIALLY TESTED ALREADY. THIS TEST VERIFIES THAT BUFFERING IS ACTUALLY OPERATING.

**TEST 9: FUNCTION TIMING**

THIS TEST VERIFIES THAT THE TAPE TRANSPORT SEEMS TO BE WRITING RECORDS, GAPS, AND EXTENDED GAPS OF THE PROPER LENGTH. BOTH LOW AND HIGH SPEED MODES ARE TESTED. IT IS ALSO VERIFIED THAT A SKIP TAPE MARKS COMMAND WITH A COUNT OF 6 OR MORE, OPERATE THE TAPE IN HIGH-SPEED MODE. THIS TEST CAN ONLY BE RUN IF A REAL-TIME CLOCK IS AVAILABLE ON THE SYSTEM. THE TEST OPERATES BY TIMING VARIOUS TAPE-MOTION OPERATIONS, USING A NUMBER OF DIFFERENT TEST RECORD LENGTHS.

**7.0 MAINTENANCE HISTORY**

REVISION A - MARCH 1982

REVISION B - APRIL 1983

- FIXED TWO PROBLEMS, ONE IN TEST 1 AND THE OTHER IN TEST 8.  
REF. DOYLE TO GRASKY "TSV05 CVTSDB DIAGNOSTIC PATCH"; 23-DEC-82.

REVISION C - JUNE 1984

MINOR CHANGES FOR "ORION" CPU  
ELIMINATED CPU ID MESSAGE.

REVISION D - JUNE 1985

CHANGES MADE TO ALLOW DIAGNOSTICS TO WORK WITH  
XXDP- V2.1 (DRSX1) EXTENDED MONITOR.

REVISION E - APRIL 1987

CHANGES MADE TO ALLOW DIAGNOSTICS TO WORK WITH  
THE NEW TSV05 MICROCODE (REVISION 2). THE NEW  
TSV05 MICROCODE ALWAYS IN EXTENDED FEATURE MODE.

```

817 .TITLE TSV2 - PROGRAM HEADER
818 .SBTTL PROGRAM HEADER
819
825 .MCALL SVC
826 000000 SVC ; INITIALIZE SUPERVISOR MACROS
827
828 .ENABLE LC
834 000000 .NLIST BEX,CND
835 002000 002000 .ENABL A2S,AMA
836 002000 .=2000
      BGNMOD TSV2
837 TSV2::
838
839 ;**
840 ; THE PROGRAM HEADER IS THE INTERFACE BETWEEN
841 ; THE DIAGNOSTIC PROGRAM AND THE SUPERVISOR.
842 ;--
843 002000 POINTER BGNSW,BGNSFT,BGNAU,BGNDU,BGNRPT
844 002000 HEADER CVTSD,E,0,655,,0
      L#NAME:: ;DIAGNOSTIC NAME
      .ASCII /C/
      .ASCII /V/
      .ASCII /T/
      .ASCII /S/
      .ASCII /D/
      .BYTE 0
      .BYTE 0
      .BYTE 0
      L#REV:: ;REVISION LEVEL
      .ASCII /E/
      L#DEPO:: ;0
      .ASCII /0/
      L#UNIT:: ;NUMBER OF UNITS
      .WORD 0
      L#TIML:: ;LONGEST TEST TIME
      .WORD 655.
      L#HPCP:: ;PTR. TO H.W. QUES.
      .WORD L#HARD
      L#SPCP:: ;PTR. TO S.W. QUES.
      .WORD L#SOFT
      L#HPTP:: ;PTR. TO DEF. H.W. PTABLE
      .WORD L#HW
      L#SPTP:: ;PTR. TO S.W. PTABLE
      .WORD L#SW
      L#LADP:: ;DIAG. END ADDRESS
      .WORD L#LAST
      L#STA:: ;RESERVED FOR APT STATS
      .WORD 0
      L#CO::
      .WORD 0
      L#DTYP:: ;DIAGNOSTIC TYPE
      .WORD 0
      L#APT:: ;APT EXPANSION
      .WORD 0
      L#DTP:: ;PTR. TO DISPATCH TABLE
      .WORD L#DISPATCH
      L#PRIO:: ;DIAGNOSTIC RUN PRIORITY

```



## PROGRAM HEADER

002042	000000	L#ENVI::	.WORD	0		
002044						;FLAGS DESCRIBE HOW IT WAS SETUP
002044	000000	L#EXP1::	.WORD	0		
002046						;EXPANSION WORD
002046	000000	L#MREV::	.WORD	0		
002050						;SVC REV AND EDIT #
002050	003		.BYTE		C#REVISION	
002051	003		.BYTE		C#EDIT	
002052		L#EF::				
002052	000000		.WORD	0		
002054	000000		.WORD	0		
002056		L#SPC::				
002056	000000		.WORD	0		
002060		L#DEVP::				
002060	003376		.WORD	0		; POINTER TO DEVICE TYPE LIST
002062		L#REPP::	.WORD	L#DVTYP		
002062	022700					;PTR. TO REPORT CODE
002064		L#EXP4::	.WORD	L#RPT		
002064	000000		.WORD	0		
002066		L#EXP5::	.WORD	0		
002066	000000		.WORD	0		
002070		L#AUT::				
002070	022366		.WORD	L#AU		;PTR. TO ADD UNIT CODE
002072		L#DUT::	.WORD	L#DU		
002072	022464					;PTR. TO DROP UNIT CODE
002074		L#LUN::	.WORD	0		
002074	000000					;LUN FOR EXERCISERS TO FILL
002076		L#DESP::	.WORD	0		
002076	003404				L#DESC	;POINTER TO DIAG. DESCRIPTION
002100		L#LOAD::	.WORD	L#DESC		
002100	104035		EMT	E#LOAD		;GENERATE SPECIAL AUTOLOAD EMT
002102		L#ETP::	.WORD	0		
002102	000000					;POINTER TO ERRtbl
002104		L#ICP::	.WORD	0		
002104	021572				L#INIT	;PTR. TO INIT CODE
002106		L#CCP::	.WORD	L#INIT		
002106	022652				L#CLEAN	;PTR. TO CLEAN-UP CODE
002110		L#ACP::	.WORD	L#CLEAN		
002110	022572				L#AUTO	;PTR. TO AUTO CODE
002112		L#PRT::	.WORD	L#AUTO		
002112	021562				L#PROT	;PTR. TO PROTECT TABLE
002114		L#TEST::	.WORD	L#PROT		
002114	000000					;TEST NUMBER
002116		L#DLY::	.WORD	0		
002116	000000					;DELAY COUNT
002120		L#HIME::	.WORD	0		
002120	000000					;PTR. TO HIGH MEM

H2

DISPATCH TABLE

846  
847  
848  
849  
850  
851  
852  
853 002122  
002122 000011  
002124  
002124 023462  
002126 032264  
002130 041362  
002132 046720  
002134 052776  
002136 055772  
002140 063344  
002142 073274  
002144 101100  
854

.SBTTL DISPATCH TABLE

;\*  
; THE DISPATCH TABLE CONTAINS THE STARTING ADDRESS OF EACH TEST.  
; IT IS USED BY THE SUPERVISOR TO DISPATCH TO EACH TEST.  
;--

DISPATCH 9  
.WORD 9  
L#DISPATCH:;  
.WORD T1  
.WORD T2  
.WORD T3  
.WORD T4  
.WORD T5  
.WORD T6  
.WORD T7  
.WORD T8  
.WORD T9



DEFAULT HARDWARE P-TABLE

```

856                                     .SBTTL  DEFAULT HARDWARE P-TABLE
857
858                                     ;**
859                                     ; THE DEFAULT HARDWARE P-TABLE CONTAINS DEFAULT VALUES OF
860                                     ; THE TEST-DEVICE PARAMETERS.  THE STRUCTURE OF THIS TABLE
861                                     ; IS IDENTICAL TO THE STRUCTURE OF THE RUN-TIME P-TABLE.
862                                     ;--
863 002146                                BGNHW  DFPTBL  ;DEFAULT HARD-P-TABLE
      002146 000003                      .WORD  L10000-L#HW/2
      002150                                L#HW::
      002150                                DFPTBL::
864
865 002150 172520                          .WORD  172520      ; 1ST (OF 2) REGISTERS.
866 002152 000224                          .WORD  224        ; INTERRUPT VECTOR
867 002154 000200                          .WORD  PRI04     ; INTERRUPT PRIORITY.
868 002156                                ENDHW
      002156                                L10000:

```

## SOFTWARE P-TABLE

```

870          .SBTTL  SOFTWARE P-TABLE
871
872          ;**
873          ; THE SOFTWARE P-TABLE CONTAINS THE VALUES OF THE PROGRAM
874          ; PARAMETERS THAT CAN BE CHANGED BY THE OPERATOR.
875          ;--
876 002156    BGNSW  SFPTBL
          002156 000004 .WORD  L10001-L1SW/2
          002160
          002160
877
878 002160    000000  TRANSTST:: .WORD  0      ; ENABLE TEST OF TRANSPORT(S) IF =1
879 002162    000000  NOITS::   .WORD  0      ; INHIBIT ITERATION OPTION.
880          ; ... 0 = ITERATE.
881          ; ... NZ = INHIBIT ITERATE.
882 002164    000017  LERRMAX:: .WORD  15.   ; LOCAL (PER TEST) ERROR LIMIT
883 002166    000310  GERRMAX:: .WORD  200.  ; GLOBAL (PER UNIT) ERROR LIMIT
884 002170
          002170          ENDSW
885          L10001:
886 002170          ENDMOD

```



SOFTWARE P-TABLE

896  
 897  
 902  
 908  
 909 002170  
       002170  
 910  
 911  
 912  
 913  
 914  
 915  
 916  
 917  
 921 002170

```

.TITLE TSV3 - GLOBAL AREAS
.SBTTL GLOBAL EQUATES SECTION

BGNMOD TSV3
TSV3::

.SBTTL GLOBAL EQUATES SECTION

; **
; THE GLOBAL EQUATES SECTION CONTAINS PROGRAM EQUATES THAT
; ARE USED IN MORE THAN ONE TEST.
; --

EQUALS          ; GET STANDARD EQUATES.

; BIT DIFINITIONS
;
BIT15== 100000
BIT14== 40000
BIT13== 20000
BIT12== 10000
BIT11== 4000
BIT10== 2000
BIT09== 1000
BIT08== 400
BIT07== 200
BIT06== 100
BIT05== 40
BIT04== 20
BIT03== 10
BIT02== 4
BIT01== 2
BIT00== 1

;
BIT9== BIT09
BIT8== BIT08
BIT7== BIT07
BIT6== BIT06
BIT5== BIT05
BIT4== BIT04
BIT3== BIT03
BIT2== BIT02
BIT1== BIT01
BIT0== BIT00

; EVENT FLAG DEFINITIONS
; EF32:EF17 RESERVED FOR SUPERVISOR TO PROGRAM COMMUNICATION
;
EF.START==      32.          ; START COMMAND WAS ISSUED
EF.RESTART==    31.          ; RESTART COMMAND WAS ISSUED
EF.CONTINUE==   30.          ; CONTINUE COMMAND WAS ISSUED
EF.NEW==        29.          ; A NEW PASS HAS BEEN STARTED
EF.PWR==        28.          ; A POWER-FAIL/POWER-UP OCCURRED

;
; PRIORITY LEVEL DEFINITIONS

```

100000  
 040000  
 020000  
 010000  
 004000  
 002000  
 001000  
 000400  
 000200  
 000100  
 000040  
 000020  
 000010  
 000004  
 000002  
 000001

001000  
 000400  
 000200  
 000100  
 000040  
 000020  
 000010  
 000004  
 000002  
 000001

000040  
 000037  
 000036  
 000035  
 000034

L2

GLOBAL EQUATES SECTION

000340  
000300  
000240  
000200  
000140  
000100  
000040  
000000

!  
PRI07== 340  
PRI06== 300  
PRI05== 240  
PRI04== 200  
PRI03== 140  
PRI02== 100  
PRI01== 40  
PRI00== 0

!  
;OPERATOR FLAG BITS

000004  
000010  
000020  
000040  
000100  
000200  
000400  
001000  
002000  
004000  
010000  
020000  
040000  
100000

!  
EVL== 4  
LOT== 10  
ADR== 20  
IDU== 40  
ISR== 100  
UAM== 200  
BOE== 400  
PNT== 1000  
PRI== 2000  
IXE== 4000  
IBE== 10000  
IER== 20000  
LOE== 40000  
HOE== 100000

922  
923 002170

000250  
177572  
177574  
177576  
172516

KT11  
.SBTTL MEMORY MANAGEMENT DEFINITIONS  
;\*KT11 VECTOR ADDRESS  
MMVEC= 250  
;\*KT11 STATUS REGISTER ADDRESSES  
SR0= 177572  
SR1= 177574  
SR2= 177576  
SR3= 172516  
.IF NB  
;\*USER "I" PAGE DESCRIPTOR REGISTERS  
UIPDR0= 177600  
UIPDR1= 177602  
UIPDR2= 177604  
UIPDR3= 177606  
UIPDR4= 177610  
UIPDR5= 177612  
UIPDR6= 177614  
UIPDR7= 177616  
.IF NB  
;\*USER "D" PAGE DESCRIPTOR REGISTERS  
UDPDR0= 177620  
UDPDR1= 177622  
UDPDR2= 177624  
UDPDR3= 177626  
UDPDR4= 177630  
UDPDR5= 177632  
UDPDR6= 177634  
UDPDR7= 177636  
.ENDC

;DEFINE MEMORY MANAGEMENT REGISTERS



## MEMORY MANAGEMENT DEFINITIONS

```
;*USER "I" PAGE ADDRESS REGISTERS
UIPAR0= 177640
UIPAR1= 177642
UIPAR2= 177644
UIPAR3= 177646
UIPAR4= 177650
UIPAR5= 177652
UIPAR6= 177654
UIPAR7= 177656
. IF NB
;*USER "D" PAGE ADDRESS REGISTERS
UDPAR0= 177660
UDPAR1= 177662
UDPAR2= 177664
UDPAR3= 177666
UDPAR4= 177670
UDPAR5= 177672
UDPAR6= 177674
UDPAR7= 177676
. ENDC
. ENDC
. IF NB
;*SUPERVISOR "I" PAGE DESCRIPTOR REGISTERS
SIPDR0= 172200
SIPDR1= 172202
SIPDR2= 172204
SIPDR3= 172206
SIPDR4= 172210
SIPDR5= 172212
SIPDR6= 172214
SIPDR7= 172216
. IF NB
;*SUPERVISOR "D" PAGE DESCRIPTOR REGISTERS
SDPDR0= 172220
SDPDR1= 172222
SDPDR2= 172224
SDPDR3= 172226
SDPDR4= 172230
SDPDR5= 172232
SDPDR6= 172234
SDPDR7= 172236
. ENDC
;*SUPERVISOR "I" PAGE ADDRESS REGISTERS
SIPAR0= 172240
SIPAR1= 172242
SIPAR2= 172244
SIPAR3= 172246
SIPAR4= 172250
SIPAR5= 172252
SIPAR6= 172254
SIPAR7= 172256
. IF NB
;*SUPERVISOR "D" PAGE ADDRESS REGISTERS
SDPAR0= 172260
SDPAR1= 172262
SDPAR2= 172264
SDPAR3= 172266
```

## MEMORY MANAGEMENT DEFINITIONS

```
SDPAR4= 172270
SDPAR5= 172272
SDPAR6= 172274
SDPAR7= 172276
.ENDC
.ENDC
;*KERNEL "I" PAGE DESCRIPTOR REGISTERS
172300 KIPDR0= 172300
172302 KIPDR1= 172302
172304 KIPDR2= 172304
172306 KIPDR3= 172306
172310 KIPDR4= 172310
172312 KIPDR5= 172312
172314 KIPDR6= 172314
172316 KIPDR7= 172316
.IF NB
;*KERNEL "D" PAGE
DESCRIPTOR REGISTERS
KDPDR0= 172320
KDPDR1= 172322
KDPDR2= 172324
KDPDR3= 172326
KDPDR4= 172330
KDPDR5= 172332
KDPDR6= 172334
KDPDR7= 172336
.ENDC
;*KERNEL "I" PAGE ADDRESS REGISTERS
172340 KIPAR0= 172340
172342 KIPAR1= 172342
172344 KIPAR2= 172344
172346 KIPAR3= 172346
172350 KIPAR4= 172350
172352 KIPAR5= 172352
172354 KIPAR6= 172354
172356 KIPAR7= 172356
.IF NB
;*KERNEL "D" PAGE ADDRESS REGISTERS
KDPAR0= 172360
KDPAR1= 172362
KDPAR2= 172364
KDPAR3= 172366
KDPAR4= 172370
KDPAR5= 172372
KDPAR6= 172374
KDPAR7= 172376
.ENDC
```



TSV05 REGISTER AND PACKET DEFINITIONS

```

928                                     .SBTTL TSV05 REGISTER AND PACKET DEFINITIONS
929
930                                     ;
931                                     ; SOME GENERAL EQUATES.
932                                     ;
933
934         000004      ERRVEC==      4           ; POINTER TO ERROR VECTOR FOR BUS TIME OUT.
935         000060      TTIVEC==     60           ; INTERRUPT VECTOR FOR CONSOLE INPUT
936         177560      TTICSR==    177560        ; BUS ADDRESS OF CONSOLE INPUT
937         177562      TTIBFR==    177562        ; CONSOLE INPUT DATA BUFFER
938         177520      BDVPCR==    177520        ; BDV11 PAGE CONTROL REGISTER
939
940                                     ;*
941                                     ;BIT DEFINITIONS FOR TSSR REGISTER
942                                     ;-
943
944         100000      SC=          BIT15        ;SPECIAL CONDITION
945         040000      BIE=          BIT14        ;BUS INTERFACE ERROR
946         020000      SCE=          BIT13        ;SANITY CHECK ERROR
947         010000      RMR=          BIT12        ;MODIFICATION REFUSED
948         004000      NXM=          BIT11        ;NONEXISTANT MEMORY ERROR
949         002000      NBA=          BIT10        ;NEED BUFFER ADDRESS
950         001400      HIADDR=     BIT9:BIT8      ;EXTENDED ADDRESS BITS
951         000200      SSR=          BIT7         ;SUB SYSTEM READY
952         000100      OFL=          BIT6         ;OFF LINE BIT
953         000060      FATERR=     BIT4:BITS      ;FATAL TERMINATION ERROR CODES
954         000016      TERCLS=     BIT3:BIT2:BIT1 ;TERMINATION CODES
955
956                                     ;*
957                                     ;
958                                     ;BIT DEFINITIONS FOR EXTENDED STATUS REGISTER 0
959                                     ;(XST0)
960                                     ;
961                                     ;-
962
963         100000      XSOTMK=     BIT15        ;TAPE MARK DETECTED
964         040000      XSORLS=     BIT14        ;RECORD LENGTH SHORT
965         020000      XSOLET=     BIT13        ;LOGICAL END OF TAPE
966         010000      XSORLL=     BIT12        ;RECORD LENGTH LONG
967         004000      XSOMLE=     BIT11        ;WRITE LOCK ERROR
968         002000      XSONEF=     BIT10        ;NON EXECUTABLE FUNCTION
969         001000      XSOILC=     BIT9         ;ILLEGAL COMMAND
970         000400      XSOILA=     BIT8         ;ILLEGAL ADDRESS
971         000200      XSOMOT=     BIT7         ;TAPE IN MOTION
972         000100      XSOONL=     BIT6         ;TRANSPORT ON LINE
973         000040      XSOIE=     BITS          ;INTERRUPT ENABLE
974         000020      XSOVCK=     BIT4         ;VOLUME CHECK BIT
975         000010      XSOPED=     BIT3         ;PHASE ENCODED DRIVE
976         000004      XSOMLK=     BIT2         ;WRITE LOCKED
977         000002      XSOMOT=     BIT1         ;BEGINNING OF TAPE
978         000001      XS0EOT=     BIT0         ;END OF TAPE

```

## TSV05 REGISTER AND PACKET DEFINITIONS

```

980
981      ;*
982      ;BIT DEFINITIONS FOR EXTENDED STATUS REGISTER 1
983      ;(XST1)
984      ;-
985      100000 X1.DLT = BIT15      ;DATA LATE
986      040000 X1.SPARE= BIT14      ;NOT USED
987      020000 X1.COR = BIT13      ;CORRECTABLE DATA ERROR
988      017375 X1.MBZ = BIT12-BIT11-BIT10-BIT9-BIT7-BIT6-BIT5-BIT4-BIT3-BIT2-BIT0 ;ALWAYS 0
989      000400 X1.RBP = BIT8      ;READ BUS PARITY ERROR
990      000002 X1.UNC = BIT1      ;UNCORRECTABLE DATA OR HARD ERROR
991
992      ;*
993      ;BIT DEFINITIONS FOR EXTENDED STATUS REGISTER 2
994      ;(XST2)
995      ;-
996      100000 X2.OPM = BIT15      ;OPERATION IN PROGRESS (TAPE MOVING)
997      040000 X2.RCE = BIT14      ;RAM CHECKSUM ERROR
998      035400 X2.SPARE= BIT13-BIT12-BIT11-BIT9-BIT8      ;NOT USED BY TSV05 (ALWAYS=0)
999      002000 X2.WCF = BIT10      ;WRITE CLOCK FAILURE (FIFO NOT EMPTIED BY TRANSPORT)
1000     000200 X2.EXTF = BIT7      ;IF WRITE CHAR CMD THEN = EXTENDED FEATURES ENABLED
1001     000100 X2.BUFE = BIT6      ;IF WRITE CHAR CMD THEN = BUFFERING ENABLED
1002     000077 X2.REV = 000077      ;IF WRITE CHAR CMD THEN = MICROCODE REVISION LEVEL
1003     000007 X2.UNIT = BIT2-BIT1-BIT0 ;IF GET STATUS THEN = CURRENTLY SELECTED UNIT NO.
1004
1005      ;*
1006      ;BIT DEFINITIONS FOR EXTENDED STATUS REGISTER 3
1007      ;(XST3)
1008      ;-
1009     177400 X3.MDE = 177400      ;MICRO-DIAGNOSTIC ERROR CODE
1010     000200 X3.SPARE= BIT7      ;NOT USED BY TSV05
1011     000100 X3.OPI = BIT6      ;OPERATION INCOMPLETE
1012     000040 X3.REV = BIT5      ;REVERSE
1013     000020 X3.TRF = BIT4      ;TRANSPORT RESPONSE FAILURE
1014     000010 X3.DCK = BIT3      ;DENSITY CHECK
1015     000006 X3.MBZ =BIT2-BIT1      ;NOT USED ALWAYS 0
1016     000001 X3.RIB = BIT0      ;REVERSE INTO BOT
1017
1018      ;*
1019      ;BIT DEFINITIONS FOR EXTENDED STATUS REGISTER 4
1020      ;(XST4)
1021      ;-
1022     100000 X4.HSP = BIT15      ;HIGH SPEED
1023     040000 X4.RCE = BIT14      ;RETRY COUNT EXCEEDED
1024     020000 X4.TSM = BIT13      ;TRANSPORT SPECIAL MODE
1025     017400 X4.MBZ = BIT12-BIT11-BIT10-BIT9-BIT8      ;NOT USED ALWAYS 0
1026     000377 X4.WRC = 000377      ;WRITE RETRY COUNT FIELD
1027
1028      ;*
1029      ;TSSR TERMINATION CODES (BIT 0-2)
1030      ;-
1031
1032
1033     000006 TSREJ= 3*2      ;COMMAND REJECTED
1034     000006 UNREC= 6      ;UNRECOVERABLE ERROR

```



TSV05 REGISTER AND PACKET DEFINITIONS

```

1036
1037
1038 ;*
1039 ; DEVICE REGISTER OFFSETS
1040 ;
1041 ;-
1042 000000 TSBA== 0
1043 000000 TSDB== 0 ;TSDB/TSBA REGISTER
1044 000001 TSBAH== 1
1045 000001 TSDBH== 1 ;TSDB/TSBA REGISTER HIGH BYTE
1046 000002 TSSR== 2 ;TSSR REGISTER
1047 000003 TSSRH== 3 ;TSSR REGISTER HIGH BYTE
1048
1049 ;*
1050 ; TSDB ADDRESS BIT DEFINITIONS
1051 ;-
1052 000003 A1716 = BIT1-BIT0 ;ADDRESS BITS 17:16 ARE IN 1:0
1053
1054 ;*
1055 ; COMMAND DEFINITIONS
1056 ;-
1057 000017 P.GETSTAT = 17 ;GET STATUS
1058 000013 P.INIT = 13 ;INITIALIZE
1059 000012 P.CONTROL = 12 ;CONTROL COMMANDS
1060 000011 P.FORMAT = 11 ;FORMAT
1061 000010 P.POSITION = 10 ;POSITION
1062 000006 P.WRTSUB = 6 ;SUBSYSTEM WRITE
1063 000005 P.WRITE = 5 ;WRITE
1064 000004 P.WRTCHAR = 4 ;WRITE CHARACTERISTICS
1065 000001 P.READ = 1 ;READ
1066
1067 ;*
1068 ; COMMAND PACKET HEADER WORD BIT DEFINITIONS
1069 ;-
1070 100000 P.ACK = BIT15 ;BUFFER AVAIL FOR CONTROLLER
1071 040000 P.CVC = BIT14 ;CLEAR VOLUME CHECK
1072 020000 P.OPP = BIT13 ;REVERSE SEQUENCE OF DATA BITS
1073 010000 P.SWB = BIT12 ;SWAP BYTES IN MEMORY
1074 007400 P.MODE = BIT11:BIT10:BIT9:BIT8 ;EXTENDED COMMAND MODE FIELD
1075 000200 P.IE = BIT7 ;INTERRUPT ENABLE
1076 000140 P.FMT= BIT6:BITS ;PACKET HEADER TYPE (ALWAYS=0)
1077 000037 P.CMD = 37 ;MAJOR COMMAND FIELD
1078
1079 ;*
1080 ; CONTROL COMMAND MODE CODES
1081 ;-
1081 000000 PC.RELEASE = 0*256. ;RELEASE BUFFER
1082 000400 PC.REWIND = 1*256. ;REWIND
1083 001000 PC.NOOP = 2*256. ;NO-OP
1084 002000 PC.IEREW = 4*256. ;REWIND IMMEDIATE INTERRUPT
1085 002400 PC.ERASE = 5*256. ;SECURITY ERASE

```

TSV05 REGISTER AND PACKET DEFINITIONS

```

1087
1088      ;*
1089      ; CONTROLLER RAM DEFINITIONS
1090      ;-
1091      000167 RMCHBEG = 167      ; CHARACTERISTICS IO DATA BEGIN RAM ADDRESS
1092      000200 RMCHEND = 200     ; CHARACTERISTICS IO DATA END RAM ADDRESS
1093      000201 RMPKTBEGBEG = 201 ; COMMAND PACKET BEGIN RAM ADDRESS
1094      000210 RMPKTBEGETD = 210 ; COMMAND PACKET END RAM ADDRESS
1095      000215 RMMSGBEG = 215    ; MESSAGE BUFFER BEGIN RAM ADDRESS
1096      000234 RMMSGEND = 234    ; MESSAGE BUFFER END RAM ADDRESS
1097      ;*
1098      ; REGISTER DEFINITIONS IN THE MESSAGE BUFFER
1099      ;-
1100
1101
1102      000006 XST0 = 6           ; EXTENDED STATUS REGISTER 0 (WORD 4)
1103      000010 XST1 = 8           ; EXTENDED STATUS REGISTER 1 (WORD 5)
1104      000012 XST2 = 10          ; EXTENDED STATUS REGISTER 2 (WORD 6)
1105      000014 XST3 = 12          ; EXTENDED STATUS REGISTER 3 (WORD 7)
1106      000016 XST4 = 14          ; EXTENDED STATUS REGISTER 4 (WORD 8)
1107
1108      ;*
1109      ; OFFSETS TO WORD LOCATIONS IN PACKET DEFINITIONS
1110      ;-
1111
1112
1113
1114      000002 PKLOW = 2           ; LOW ORDER CHARACTERISTIC DATA POINTER
1115      000004 PKHI = 4           ; HIGH ORDER CHARACTERISTIC DATA POINTER
1116      000006 PKBCNT = 6         ; NUMBER OF BYTES IN DATA PACKET
1117
1118      000010 EXBCNT = 10         ; NUMBER OF BYTES IN EXTENDED DATA PACKET
1119
1120      ;*
1121      ; DATA PACKET OFFSETS FOR WRITE SUBSYSTEM COMMAND
1122      ;-
1123      000000 BSEL0 = 0           ; BYTE 0
1124      000001 BSEL1 = 1           ; BYTE 1
1125      000002 SEL2 = 2           ; WORD 2
1126      000004 SELDATA = 4        ; WORD 3

```



TSV05 REGISTER AND PACKET DEFINITIONS

```

1128
1129 ;BSEL0 SELECT CODES FOR WRITE SUBSYSTEM COMMAND
1130 ;
1131 000000 PW.NOP = 0 ;NO-OP
1132 000001 PW.RDRAM = 1 ;READ RAM
1133 000002 PW.WTRAM = 2 ;WRITE RAM
1134 000003 PW.RFIFO = 3 ;READ FIFO
1135 000004 PW.WFIFO = 4 ;WRITE FIFO
1136 000005 PW.RDSTAT = 5 ;READ STATUS
1137 000006 PW.WCTL = 6 ;WRITE TAPE CONTROL
1138 000007 PW.WFMT = 7 ;WRITE TAPE FORMAT
1139 000010 PW.WMISC = 10 ;WRITE MISCELLANEOUS
1140 000011 PW.WNPR = 11 ;WRITE NPR CONTROL
1141 000020 PW.D22 = 20 ;DO MICROTEST 22
1142 000021 PW.D11 = 21 ;DO MICROTEST 11
1143 000022 PW.D13 = 22 ;DO MICROTEST 13
1144 000023 PW.NO1311 = 23 ;DISABLE MICROTEST 11 AND 13
1145 000024 PW.RDXT = 24 ;READ EXT. TAPE STATUS (NOT SUPPORTED BY ALL TRANSPORTS)
1146
1147 ;
1148 ;BSEL1 CODES FOR WRITE TAPE CONTROL
1149 ;
1150 000200 WC.IFAD = BIT7 ;IFAD - FORMATTER ADDRESS
1151 000100 WC.IOTAD = BIT6 ;ITADO - TRANSPORT ADDRESS BIT 0
1152 000040 WC.I1TAD = BIT5 ;ITAD1 - TRANSPORT ADDRESS BIT 1
1153 000020 WC.ISRESV = BIT4 ;IRESV5 - RESERVED #5
1154 000010 WC.IREW = BIT3 ;IREW - REWIND
1155 000004 WC.IRWU = BIT2 ;IRWU - REWIND AND UNLOAD
1156 000002 WC.IFEN = BIT1 ;IFEN - FORMATTER ENABLE
1157 000001 WC.IGO = BIT0 ;GO
1158
1159 ;
1160 ;BSEL1 CODES FOR WRITE FORMAT
1161 ;
1162 000200 WF.IHISP = BIT7 ;IHISP - HIGH SPEED
1163 000100 WF.IWRT = BIT6 ;IWRT - WRITE
1164 000040 WF.IREV = BIT5 ;IREV - REVERSE
1165 000020 WF.IWFM = BIT4 ;IWFM - WRITE FILE MARK
1166 000010 WF.IEDIT = BIT3 ;IEDIT - EDIT
1167 000004 WF.IERASE = BIT2 ;IERASE - ERASE
1168 000002 WF.I3RESV = BIT1 ;IRESV3 - RESERVED #3
1169 000001 WF.I4RESV = BIT0 ;IRESV4 - RESERVED #4
1170
1171 ;
1172 ;BSEL1 CODES FOR WRITE MISCELLANEOUS SUBCOMMAND
1173 ;
1174 000200 MS.EXT = BIT7 ;INVERT SENSE OF EXTENDED FEATURES SWITCH
1175 000020 MS.RSFIFO = BIT4 ;RESET FIFO AND INPUT PARITY ERRORR
1176 000010 MS.RSTAPE = BIT3 ;RESET TAPE STATUS IN 2 FLIP-FLOPS
1177 000006 MS.ATTN = BIT2!BIT1 ;ATTENTION TRIGGER FIELD
1178 000001 MS.RSD = BIT0 ;RESET TIMER A,B THEN DELAY TIMES IN SEL2

```

TSV05 REGISTER AND PACKET DEFINITIONS

```

1180
1181      ;*
1182      ; MS.ATTN SUBCODES
1183      ;-
1183      000000      MSA.NOP = 0*2      ;NO-OP (NOTHING TRIGGERED)
1184      000002      MSA.VOL = 1*2      ;SIMULATE ON-LINE/OFF-LINE TRANSISTION
1185      000004      MSA.NRAM= 2*2      ;FORCE NON-FATAL RAM ERROR (FORCES ERRCODE 54)
1186      000006      MSA.FRAME= 3*2     ;FORCE FATAL RAM ERROR (CAUSES SCE TO SET)
1187
1188      ;*
1188      ; WRITE SUBSYSTEM WRITE NPR BSEL1 BIT DEFINITIONS
1189      ;-
1190      000200      NP.IR      = BIT7      ;INTERRUPT REQUEST (0-1 TRANSITION)
1191      000100      NP.OUT     = BIT6      ;TAPE DATA DIRECTION OUT (0= IN)
1192      000040      NP.LOOP   = BIT5      ;ENABLE TRANSPORT LOOPBACK
1193      000020      NP.WRP    = BIT4      ;WRITE CORRECT PARITY (SET=0 TO WRITE WRONG)
1194
1195      ;*
1195      ; READ STATUS MESSAGE BUFFER BIT DEFINITIONS
1196      ;-
1197
1198      000200      S2.DIM      = BIT7      ;WORD #9 BYTE 2 DATA IN MISS
1199      000100      S2.ILW     = BIT6      ;ILW H
1200      000040      S2.OUTRDY  = BIT5      ;OUT RDY H
1201      000020      S2.INRDY   = BIT4      ;IN RDY H
1202      000010      S2.ATIMR   = BIT3      ;TIMER A FLAG H
1203      000004      S2.BTIMR   = BIT2      ;TIMER B FLAG H
1204      000003      S2.UNDEF   = BIT1-BIT0 ;(UNDEFINED)
1205      100000      S1.PARIN   = BIT15     ;WORD #8 BYTE 1 PARIN H
1206      040000      S1.I2RESV  = BIT14     ;IRESV2
1207      020000      S1.I1RESV  = BIT13     ;IRESV1
1208      010000      S1.IEOT    = BIT12     ;IEOT L
1209      004000      S1.IIDENT  = BIT11     ;IIDENT H
1210      002000      S1.ICER    = BIT10     ;ICER H
1211      001000      S1.IFMK    = BIT9      ;IFMK H
1212      000400      S1.IHER    = BIT8      ;IHER H
1213      000200      S0.ISPEED  = BIT7      ;WORD #8 BYTE 0 ISPEED H
1214      000100      S0.IRDY   = BIT6      ;IRDY L
1215      000040      S0.IONL   = BIT5      ;IONL L
1216      000020      S0.ILDP   = BIT4      ;ILDP L
1217      000010      S0.IDBY   = BIT3      ;IDBY L
1218      000004      S0.IRWD   = BIT2      ;IRWD L
1219      000002      S0.IFBY   = BIT1      ;IFBY L
1220      000001      S0.IFPT   = BIT0      ;IFPT L

```



## SPECIAL MACROS AND OPDEFS.

```

1222             .SBTTL SPECIAL MACROS AND OPDEFS.
1223
1224             ;*
1225             ;SAVE GENERAL REGS 1 TO 5
1226             ;-
1227
1228             .MACRO SAVREG
1229             JSR     R5,REGSAV
1230             .ENDM
1231
1232             ;*
1233             ; MACRO TO FORCE AN ERROR
1234             ;-
1235             .MACRO FORCERROR TAG,NOTSSR
1236             .NLIST
1237             .IIF NDF LISTALL, .NLIST
1238             .LIST
1239             .IF B NOTSSR
1240             MOV     TSSR(R5),R1      ;READ TSSR
1241             .ENDC
1242             MOV     FORCER,FORCER   ;IS FORCER SET? (LEAVE C BIT ALONE)
1243             BNE    TAG              ;BR IF YES
1244             .NLIST
1245             .IIF NDF LISTALL, .LIST
1246             .LIST
1247             .ENDM
1248
1249             ;*
1250             ; MACRO TO FORCE AN EXIT TO AVOID SECTION ITERATIONS
1251             ; WILL EXIT TO A LABEL IF FORCER IS NEGATIVE
1252             ; SO TO FORCE ERRORS AND EXIT ON 1 ERROR SET
1253             ; FORCER TO 177777
1254             ; TO FORCE ERRORS AND ITERATIONS SET FORCER TO 1.
1255             ;-
1256             .MACRO FORCEEXIT TAG
1257             .NLIST
1258             .IIF NDF LISTALL, .NLIST
1259             .LIST
1260             MOV     FORCER,FORCER   ;IS FORCER NEGATIVE?
1261             BMI    TAG              ;BR IF YES
1262             .NLIST
1263             .IIF NDF LISTALL, .LIST
1264             .LIST
1265             .ENDM
1266             ;*
1267             ; MACRO TO INCREMENT ERROR COUNTS
1268             ;-
1269             .MACRO NEXT.ERRNO
1270             .NLIST
1271             ;;;.IIF NDF LISTALL, .NLIST
1272             ERRNO=ERRNO+1
1273             ;;;.IIF NDF LISTALL, .LIST
1274             .LIST
1275             .ENDM

```

SPECIAL MACROS AND OPDEFS.

```

1277
1278
1279
1280
1281
1282
1283
1284
1285
1286
1287
1288          000000
1289
1290
1291
1292
1293
1294
1295
1296 002170  000000
1297
1298

```

```

;
;MACRO TO PERFORM XOR
;-
      .MACRO XOR      A,B
      MOV      A,-(SP)
      BIC      B,(SP)
      BIC      A,B
      BIS      (SP)-.B
      .ENDM

EN=0          ; INITIALIZE ERROR NUMBER
.SBTTL FORCER - FORCE ERROR FLAG

;
; THE FOLLOWING LOCATIONS MAY BE PATCHED BY THE USER
; TO OBTAIN THE RESULTS DESCRIBED FOR EACH.
;
FORCER::      0          ; FORCE TYPE ALL HARD ERRORS (THE ONES CALLED -
; - BY THE MACRO "IFERROR"). AN ERROR NEED NOT -
; - EXIST, JUST ASSUME AND TYPE THE MESSAGE.

```



GLOBAL DATA SECTION

.SBTTL GLOBAL DATA SECTION

1300  
1301  
1302  
1303  
1304  
1305  
1306  
1307  
1308  
1309  
1310  
1311 002172 000000  
1312 002174 000000  
1313 002176 000000  
1314 002200 000000  
1315 002202 000224  
1316 002204 000200  
1317 002206 000000  
1318 002210 000000  
1319 002212 000000  
1320 002214 000000  
1321 002216 000000  
1322 002220 000000  
1323 002222 000000  
1324 002224 000000  
1325 002226 000000  
1326 002230 000000  
1327 002232 000000  
1328 002234 000000  
1329 002236 000000  
1330 002276 000000  
1331 002300 000000  
1332 002302 000000  
1333 002304 000000  
1334 002306 000000  
1335 002310 000000  
1336 002312 000000  
1337 002314 000000  
1338 002316 000000  
1339 002462 000000  
1340 002626 000000

```

; **
; THE GLOBAL DATA SECTION CONTAINS DATA THAT ARE USED
; IN MORE THAN ONE TEST.
; --
;
; THE FOLLOWING DATA ARE SET FOR EACH UNIT AT INIT TIME.
; SINGLE UNIT DEFAULTS (LISTED) ARE IN THE DEFAULT P-TABLE.
;
EPRTSW::      .WORD 0      ;PRINT SWITCH
UNITN::      .WORD 0      ;UNIT # UNDER TEST.
QVP::        .WORD 0      ;QUICK VERIFY FLAG.
CSRADDR::    .WORD 0      ;ADDRESS OF CSR FOR CURRENT DEVICE
IVEC::       .WORD 224    ;INTERRUPT VECTOR
IPRI::       .WORD PRI04  ;INTERRUPT PRIORITY.
TSTCNT::     .WORD 0      ;NUMBER OF TESTS RUN IN THIS PASS
LOOPCNT::    .WORD 0      ;REMAINING ITERATION COUNT FOR TEST
DEVcnt::     .WORD 0      ;NUMBER OF DEVICE UNDER TEST
FATFLG::     .WORD 0      ;SET IF FATAL ERROR IS DETECTED IN TEST
INTRECV::    .WORD 0      ;SET IF TAPE INTERRUPT WAS RECEIVED
EXTFEA::     .WORD 0      ;EXTENDED FEATURES SOFTWARE SW 0=OFF;1=ON
REV::        .WORD 0      ;MICROCODE REVISION LEVEL
BENBSW::     .WORD 0      ;BUFFER ENABLE SWITCH SW 0=OFF;1=ON
EXPD::       .WORD 0      ;EXPECTED RAM DATA FOR PRAMPKT ROUTINE
RCV::        .WORD 0      ;RECEIVED RAM DATA FOR PRAMPKT ROUTINE
ERRHI::      .WORD 0      ;HIGH ADDRESS MEMORY ERROR
ERRLO::      .WORD 0      ;LOW ADDRESS MEMORY ERROR
RAMDATA::    .BLKW 16.    ;DATA READ FROM RAM PACKET OR MESSAGE BUF AREA
RAMSIZ::     .WORD 0      ;RAM DATA SIZE FOR PRAMPKT ROUTINE
RCVHIADD::   .WORD 0      ;RECEIVED BUFFER HIGH ADDRESS
RCVLOADD::   .WORD 0      ;RECEIVED BUFFER LOW ADDRESS
COUNT::     .WORD 0      ;TEST COUNT PATTERN
DATA::       .WORD 0      ;TEST DATA
TSTFLAG::    .WORD 0      ;TEST FLAG WORD
TSTPTR::     .WORD 0      ;TSTBLK POINTER
PRMNO::      .WORD 0      ;PRINT ROUTINE TEMP
EXPMSG::     .BLKB 100.   ;EXPECTED MESSAGE BUFFER DATA
RCMSG::      .BLKB 100.   ;RECEIVED MESSAGE BUFFER DATA
TMPBFR::     .BLKB 80.    ;TEMPORARY STORAGE FOR PRINT
```

K3

TSTBLK - TEST DATA TABLE

```

1342
1343
1344
1345
1346
1347
1348
1349
1350
1351
1352
1353
1354
1355
1356
1357
1358 002746
1359 002746 000000
1360 002750 177777
1361 002752 000001
1362 002754 000002
1363 002756 000004
1364 002760 000010
1365 002762 000020
1366 002764 000040
1367 002766 000100
1368 002770 000200
1369 002772 000400
1370 002774 001000
1371 002776 002000
1372 003000 004000
1373 003002 010000
1374 003004 020000
1375 003006 040000
1376 003010 100000
1377 003012 177776
1378 003014 177775
1379 003016 177773
1380 003020 177767
1381 003022 177757
1382 003024 177737
1383 003026 177677
1384 003030 177577
1385 003032 177377
1386 003034 176777
1387 003036 175777
1388 003040 173777
1389 003042 167777
1390 003044 157777
1391 003046 137777
1392 003050 077777
1393 003052 125252
1394 003054 052525
1395 003056 003056

```

```

.SBTTL TSTBLK - TEST DATA TABLE
;*
;THIS TABLE CONTAINS TEST DATA USED IN SEVERAL TESTS
;IN SEQUENCE THE DATA IS:
;
;   ALL ZEROS
;   ALL ONES
;   WALKING ONES
;   WALKING ZEROS
;   ALTERNATING ONES AND ZEROS
;-
TSTBLK:
.WORD 0 ;ALL ZEROS
.WORD 177777 ;ALL ONES
.WORD BIT0 ;DATA FOR WALKING ONES
.WORD BIT1
.WORD BIT2
.WORD BIT3
.WORD BIT4
.WORD BIT5
.WORD BIT6
.WORD BIT7
.WORD BIT8
.WORD BIT9
.WORD BIT10
.WORD BIT11
.WORD BIT12
.WORD BIT13
.WORD BIT14
.WORD BIT15 ;DATA FOR WALKING ZEROS
.WORD †CBIT0
.WORD †CBIT1
.WORD †CBIT2
.WORD †CBIT3
.WORD †CBIT4
.WORD †CBIT5
.WORD †CBIT6
.WORD †CBIT7
.WORD †CBIT8
.WORD †CBIT9
.WORD †CBIT10
.WORD †CBIT11
.WORD †CBIT12
.WORD †CBIT13
.WORD †CBIT14
.WORD †CBIT15 ;ALTERNATING ONES, ZEROS
.WORD 125252 ;ALTERNATING ONES, ZERO OPPOSITE FROM ABOVE
.WORD 052525
TBLEND==.

```



## GLOBAL ENVIRONMENT STORAGE

```

1397          .SBTTL GLOBAL ENVIRONMENT STORAGE
1398          ;
1399          ; STORAGE FOR DEVICE REGISTERS
1400          ;
1401 003056 000000 100000 000000 DUMMY: 0,100000,0,0 ; DUMMY DEVICE REGISTERS...
1402 003066 000000 000000 000000      0,0,0,0,0,0,0,0,0 ; ...FOR MULTI-UNIT CHECKOUT.
1403
1404
1405 003106 000000 DUFLG::          .WORD 0          ; "DROPPED UNIT" FLAG.
1406          ; INHIBITS CODE IN "CLEAN-UP".
1407 003110 000000 NODEV::          .WORD 0          ; FLAG TO SAY NO DEVICE.
1408
1409 003112 000000 TEMP1::          .WORD 0          ; SOME TEMP LOCATIONS.
1410 003114 000000 TEMP2::          .WORD 0
1411 003116 000000 XXCOMM::         .WORD 0          ; XXDP, COMM BLOCK POINTER.
1412 003120 000000 FREE::          .WORD 0          ; 1ST FREE MEMORY ADDRESS...
1413 003122 000000 FRESIZ::         .WORD 0          ; ...AND SIZE (IN WORDS).
1414 003124 000000 FREEHI: .WORD 0          ; LAST WORD IN FREE SPACE
1415 003126 000000 KTFLG::          .WORD 0          ; KT11, MEM AVAIL FLAG -
1416          ; - .WORD 0 = <24K OR NO KT -
1417          ; - NZ = >24K AND KT.
1418 003130 000000 KTENABLE::       .WORD 0          ; SET BY TEST ROUTINES TO FLAG >28K UNDER TEST
1419 003132 000000 NXMFLG::         .WORD 0          ; SET IF WE CAN TEST CLEARED OTHERWISE
1420 003134 000000 NXMLO::          .WORD 0          ; NXM LO ADDRESS BITS
1421 003136 000000 NXMHI::          .WORD 0          ; NXM HI ADDRESS BITS FOR DAL'S 16-21
1422 003140 000000 T23A::          .WORD 0          ; 11/23A FLAG
1423 003142 000000 T23B::          .WORD 0          ; 11/23B FLAG
1424 003144 000000 T3BFLG::         .WORD 0          ; TEST 3B FLAG +0
1425 003146 002000 PST32W::         .WORD 2000       ; 32W BLOCK ADDRESS FOR 32K START
1426 003150 000000 STFLAG::         .WORD 0
1427 003152 000000 BADDAT::         .WORD 0          ; ACTUAL DATA
1428 003154 000000 GDDAT::          .WORD 0          ; EXPECTED DATA
1429 003156 000000 LOOPFL::         .WORD 0
1430 003160 CTAB::          ; CONFIGURATION TABLES.
1431 003160 000000 CTABM::          .WORD 0          ; CONFIG WORK.
1432 003162 000000
1433 003164 000000
1434 003166 000000
1435 003170 177777 .WORD -1          ; END OF MEM TABLE.
1436 003172 CTABE::
1437          ; ERROR STATISTICS TABLE (1 WORD PER UNIT), 64 UNITS MAX:
1438          ;
1439          ; 0 = UNIT NOT TESTED
1440          ; 100000 = UNIT ONLINE, NO ERRORS
1441          ; 10XXXX = UNIT ONLINE, ENCOUNTERED XXXX ERRORS
1442          ; 160000 = UNIT DROPPED, NON-EXISTENT DEVICE REGISTER
1443          ; 160001 = UNIT DROPPED, NOT IDLE AT START
1444          ; 14XXXX = UNIT DROPPED, ENCOUNTERED XXXX ERRORS
1445          ;
1446 003172 ERTABL:          .BLKW 64.
1447 003372 000000 ERTABE:          .WORD 0
1448
1449 003374 000000 SKIPT: .WORD 0          ; 1=SKIP SUBTEST 0=NO SKIP OF SUBTEST

```

GLOBAL TEXT MESSAGES

1451  
1452  
1453  
1454  
1455  
1456  
1457  
1458  
1459  
1460  
  
1461  
1482  
1483  
1484  
1485  
  
1487  
1488  
1489  
1490  
1491  
1492  
1493  
1494  
1495  
1496  
1497  
1498  
1499  
1500  
1501  
1502  
1503  
1504  
1505  
1506  
1507  
1508  
1509  
1510  
1511  
1512  
1513  
1514  
1515  
1516  
1517  
1518  
1519  
1520  
1521  
1522

003376  
003376  
003376  
  
124 123 126  
  
003404  
003404  
003404  
  
052 052 052  
  
003500 003540 003543 003547  
003520 003601 003605 003611  
123 103 000  
102 111 105  
123 103 105  
122 115 122  
116 130 115  
116 102 101  
102 111 124  
102 111 124  
123 123 122  
117 106 114  
102 111 124  
102 111 124  
102 111 124  
102 111 124  
102 111 124  
102 111 124  
102 111 124  
124 123 123  
124 123 123  
040 040 116  
045 101 040  
045 101 040  
045 101 040  
045 116 045  
040 040 125  
040 040 111  
045 116 045  
040 040 116  
040 040 111  
045 101 040

.SBTTL GLOBAL TEXT MESSAGES  
; \*\*  
; THE GLOBAL TEXT SECTION CONTAINS FORMAT STATEMENTS,  
; MESSAGES, AND ASCII INFORMATION THAT ARE USED IN  
; MORE THAN ONE TEST.  
; --  
; \*  
; NAMES OF DEVICES SUPPORTED  
; -  
DEV TYP <TSV05>  
L#DVTYP: .ASCIZ /TSV05/  
.EVEN  
  
; \*  
; TEST DESCRIPTION  
; -  
DESCRIP <\*\*\*\* TSV05 LOGIC DIAGNOSTIC - CHECK TRANSPORT IF ERROR \*\*\*\*>  
L#DESC: .ASCIZ /\*\*\*\* TSV05 LOGIC DIAGNOSTIC - CHECK TRANSPORT IF ERROR \*\*\*\*/  
.EVEN  
  
; \*  
; BIT TO ASCII CONVERSION FOR TSSR REGISTER  
; -  
TSSRBIT: .WORD 1#,2#,3#,4#,5#,6#,7#,8#  
.WORD 9#,10#,11#,12#,13#,14#,15#,16#  
1#: .ASCIZ 'SC'  
2#: .ASCIZ 'BIE'  
3#: .ASCIZ 'SCE'  
4#: .ASCIZ 'RMR'  
5#: .ASCIZ 'NXM'  
6#: .ASCIZ 'NBA'  
7#: .ASCIZ 'BIT9'  
8#: .ASCIZ 'BIT8'  
9#: .ASCIZ 'SSR'  
10#: .ASCIZ 'OFL'  
11#: .ASCIZ 'BITS'  
12#: .ASCIZ 'BIT4'  
13#: .ASCIZ 'BIT3'  
14#: .ASCIZ 'BIT2'  
15#: .ASCIZ 'BIT1'  
16#: .ASCIZ 'BIT0'  
.EVEN  
SFIERR: .ASCIZ 'TSSR ERROR AFTER SOFT INIT'  
SFHERR: .ASCIZ 'TSSR ERROR AFTER BUS RESET'  
NXR: .ASCIZ / NON-EXISTANT DEVICE REGISTER/  
NXRX: .ASCIZ /#A ADDRESS: #06/  
TSSX: .ASCII /#A TSBA,TSSR EXP'D: #06#A,#06#N/  
.ASCIZ /#A TSBA,TSSR REC'D: #06#A,#06/  
FUSI: .ASCII /#N#A/  
USI: .ASCIZ / UNEXPECTED INTERRUPT/  
NSI: .ASCIZ / INTERRUPT EXPECTED, NOT RECEIVED/  
FNINTR: .ASCII /#N#A/  
NOINTR: .ASCIZ / NO INTERRUPT WAS GENERATED/  
IFALT: .ASCIZ / INTERRUPT FAULT/  
INTX: .ASCIZ /#A CPU PC: #06#A TSBA: #06/



GLOBAL TEXT MESSAGES

```

1523 004333 040 040 042 NOINIT: .ASCIZ / "BUS-INIT" DIDN'T INITIALIZE CONTROLLER/
1524 004405 040 040 042 NSINIT: .ASCIZ / "SOFT-INIT" DIDN'T INITIALIZE THE DPU/
1525 004455 040 040 042 BRINIT: .ASCIZ / "BUS-RESET" DIDN'T INITIALIZE THE DPU/
1526 004525 000 NUL: .ASCIZ //
1527 004526 045 116 000 NULCR: .ASCIZ /#N/
1528 004531 045 101 040 EXPGOT: .ASCIZ /#A EXP'D: #06#A, REC'D: #06/
1529 004565 045 116 045 EXPGT2: .ASCIZ /#N#A EXP'D: #06#A, #06#N#A REC'D: #0#A, #06/
1530 004641 045 101 040 DUAD12: .ASCIZ /#A REG(W) WRITTEN TO: #06#A REG(R) READ; EXP'D: #06#A, REC'D: #06/
1531 004743 122 101 115 PKTRAM: .ASCIZ 'RAM Contents Do Not Match Packet Sent'
1532 005011 040 040 103 SCME: .ASCIZ / CONFIG DOESN'T MATCH MFG. MASTER/
1533 005054 127 122 111 WRTMSG: .ASCIZ 'WRITE CHARACTERISTICS Failed'
1534 005111 124 123 123 WRTERR: .ASCIZ 'TSSR Incorrect After WRITE Command, More Bits Set Than SSR'
1535 005204 124 123 123 RDERR: .ASCIZ 'TSSR Incorrect After READ Command, More Bits Set Than SSR'
1536 005276 106 101 124 SCHERR: .ASCIZ 'FATAL ERROR IN SUBTEST - CHECK TAPE,CABLES,TRANSPORT etc.'
1537 005370 105 122 122 RETERR: .ASCIZ 'ERROR IN SUBTEST - WRITE DATA RETRY FIVE TIMES FAILED'
1538 005456 045 116 045 NOMEM: .ASCIZ '#N#A ***** NO NXM ADDRESS--CANNOT TEST NXM TIMEOUT. *****#N'
1539 005552 045 116 045 M8186: .ASCIZ '#N#A ***** 11/23A SYSTEM *****#N'
1540 005643 045 116 045 M8189: .ASCIZ '#N#A ***** 11/23B SYSTEM *****#N'
1541 .EVEN
1542 .SBTTL GLOBAL ERROR REPORT SECTION
1543
1544
1545
1546
1547
1548
1549

```

```

; **
; THE GLOBAL ERROR REPORT SECTION CONTAINS THE PRINTB AND PRINTX
; CALLS THAT ARE USED IN MORE THAN ONE TEST.
; ASCII TEXT STRINGS ARE FOUND IN THE GLOBAL TEXT SECTION.
; --

```

```

;--
; BGNMSG NXRRERR ;NON-EXISTANT DEVICE REGISTER.
NXRRERR:
; PRINTX #NXRX,NODEV ;NODEV = NEXM ADDRESS.
; MOV NODEV,-(SP)
; MOV #NXRX,-(SP)
; MOV #2,-(SP)
; MOV SP,RO
; TRAP C#PNTX
; ADD #6,SP
; JSR PC,EXTEND ; PRINT EXTENSION IF REQUIRED.
; ENDMMSG

```

```

L10002:
; TRAP C#MSG
;
; THIS ROUTINE APPENDS A UNIQUE EXTENSION (IF REQUIRED)
; TO ANY OF THE ABOVE ERROR SIGNATURES.
;

```

```

; EXTEND: TST (PC)-
; EXTA: 0 ; 0 = NO EXTENSION.
; BEG 1#
; JSR PC,EXTA ; APPEND EXTENSION TEXT.
; PRINTX #NULCR ; PRINT A BLANK LINE
; MOV #NULCR,-(SP)
; MOV #1,-(SP)
; MOV SP,RO
; TRAP C#PNTX
; ADD #4,SP
; RTS PC

```

```

1550 005734 013746 003110
005734 012746 003775
005740 012746 000002
005744 010600
005750 104415
005752 062706 000006
005754 004737 005766
1551 005760 004737 005766
1552 005764
005764
005764 104423
1553
1554
1555
1556
1557 005766 005727
1558 005770 000000
1559 005772 001402
1560 005774 004777 177770
1561 006000
006000 012746 004526
006004 012746 000001
006010 010600
006012 104415
006014 062706 000004
1562 006020 000207

```

PRITSSR - PRINT TSSR CONTENTS

```

1564
1565
1566
1567
1568
1569
1570
1571
1572
1573
1574
1575
1576
1577
1578
1579
1580
1581
1582 006022
1583 006022
1584 006026 010104
1585 006030
      006030 010446
      006032 012746 006475
      006036 012746 000002
      006042 010600
      006044 104414
      006046 062706 000006
1586 006052 010400
1587 006054 004737 016154
1588 006060 103410
1589 006062
      006062 012746 006715
      006066 012746 000001
      006072 010600
      006074 104415
      006076 062706 000004
1590 006102 010403
1591 006104 042703 001476
1592 006110 001434
1593 006112 012702 002626
1594 006116 012701 003500
1595 006122 005703
1596 006124 001413
1597 006126 000241
1598 006130 006103
1599 006132 103006
1600 006134 011100
1601 006136 112022
1602 006140 001376
1603 006142 112762 000054 177777
1604 006150 005721
1605 006152 000763
1606 006154 105042
1607 006156
      006156 012746 002626
      006162 012746 006666
    
```

```

.SBTTL PRITSSR - PRINT TSSR CONTENTS
;*
;ROUTINE TO DISPLAY THE CONTENTS, AND BIT DEFINITIONS, OF
;THE TSSR REGISTER. THIS ROUTINE IS NORMALLY CALLED ONLY
;BY A MESSAGE PRINTING ROUTINE
;
;INPUTS:
;
;   R1      CONTENTS OF TSSR
;
;SUBORDINATE ROUTINES:
;
;   CHKAMB  CHECK FOR AMBIGUOUS CONTENTS
;
;-
PRITSSR:
  SAVREG                ;SAVE GENERAL REGISTERS
  MOV R1,R4             ;SAVE THE TSSR CONTENTS
  PRINTB @TSSRFOR,R4   ;PRINT THE CONTENTS OF TSSR
  MOV R4,-(SP)
  MOV @TSSRFOR,-(SP)
  MOV @2,-(SP)
  MOV SP,R0
  TRAP C:PNTB
  ADD @6,SP
  MOV R4,R0             ;GET TSSR BACK FOR CHKAMB
  JSR PC,CHKAMB        ;ARE CONTENTS AMBIGUOUS ?
  BCS 5$               ;BRANCH IF NOT
  PRINTX @AMBTSSR      ;SHOW CONTENTS ARE AMBIGUOUS
  MOV @AMBTSSR,-(SP)
  MOV @1,-(SP)
  MOV SP,R0
  TRAP C:PNTX
  ADD @4,SP
5$: MOV R4,R3           ;CONTENTS OF TSSR
   BIC @HIADDR!FATERR!TERCLS,R3 ;CLEAR ALL MULTIPLE BIT FIELDS
   BEQ 20$             ;NO BITS ARE SET
   MOV @TMPBFR,R2     ;TEMPORARY ASCII BUFFER
   MOV @TSSRBIT,R1   ;ASCII EQUIVALENT OF BITS
10$: TST R3           ;REMAINING BITS TO CONVERT
   BEQ 15$           ;BRANCH WHEN ALL ARE DONE
   CLC              ;CLEAR CARRY FOR SHIFT
   ROL R3          ;SHIFT NEXT BIT TO CARRY
   BCC 13$        ;BRANCH IF BIT NOT SET
   MOV (R1),R0    ;POINTER TO BIT DEFINITION
11$: MOVB (R0),-(R2) ;MOVE ASCII TO BUFFER
   BNE 11$       ;MOVE ALL BITS
   MOVB @'-1(R2) ;INSERT A COMMA TO TERMINATE
13$: TST (R1)    ;POINT TO NEXT DESCRIPTION
   BR 10$       ;GET THE REMAINING BITS
15$: CLRB -(R2) ;TERMINATE THE LINE
   PRINTX @TSSDEF,@TMPBFR ;PRINT THE BIT DEFINITIONS
   MOV @TMPBFR,-(SP)
   MOV @TSSDEF,-(SP)
    
```



## PRITSSR - PRINT TSSR CONTENTS

	006166	012746	000002		MOV	#2,-(SP)	
	006172	010600			MOV	SP,R0	
	006174	104415			TRAP	C#PNTX	
	006176	062706	000006		ADD	#6,SP	
1608							
1609	006202	010403		204:	MOV	R4,R3	;GET THE TSSR CONTENTS
1610	006204	042703	177761		BIC	#1#TERCLS,R3	;CLEAR ALL BUT TERMINATION
1611	006210	016303	006756		MOV	TCOCOD(R3),R3	;GET THE TERMINATION CODE MEANING
1612	006214				PRINTX	#TCOASC,R3	;PRINT THE TERMINATION CODE
	006214	010346			MOV	R3,-(SP)	
	006216	012746	006556		MOV	#TCOASC,-(SP)	
	006222	012746	000002		MOV	#2,-(SP)	
	006226	010600			MOV	SP,R0	
	006230	104415			TRAP	C#PNTX	
	006232	062706	000006		ADD	#6,SP	
1613	006236	010403			MOV	R4,R3	;TSSR CONTENTS AGAIN
1614	006240	042703	177717		BIC	#1#FATERR,R3	;CLEAR ALL BUT FATAL TERMINATION
1615	006244	001416			BEQ	254	;DON'T PRINT IF ZERO
1616	006246	006203			ASR	R3	
1617	006250	006203			ASR	R3	
1618	006252	006203			ASR	R3	
1619	006254	016303	007316		MOV	TSFCOD(R3),R3	;ALINE TERMINATION CODE FOR INDEX
1620	006260				PRINTX	#TFCASC,R3	;GET THE FATAL TERMINATION CODE
	006260	010346			MOV	R3,-(SP)	;PRINT THE FATAL TERMINATION CODE
	006262	012746	006617		MOV	#TFCASC,-(SP)	
	006266	012746	000002		MOV	#2,-(SP)	
	006272	010600			MOV	SP,R0	
	006274	104415			TRAP	C#PNTX	
	006276	062706	000006		ADD	#6,SP	
1621	006302	042704	176377	254:	BIC	#1#HIADDR,R4	;CLEAR ALL BUT EXTENDED ADDRESS
1622	006306	001411			BEQ	304	;DON'T PRINT IF ZERO
1623	006310				PRINTX	#TEXASC,R4	;PRINT THE EXTENDED ADDRESS BITS
	006310	010446			MOV	R4,-(SP)	
	006312	012746	006515		MOV	#TEXASC,-(SP)	
	006316	012746	000002		MOV	#2,-(SP)	
	006322	010600			MOV	SP,R0	
	006324	104415			TRAP	C#PNTX	
	006326	062706	000006		ADD	#6,SP	
1624	006332	013703	002172	304:	MOV	EPRTSW,R3	;PRINT MESSAGE BUFFER ADDRESS
1625	006336				PRINTX	R3	;PRINT PROPER MESSAGE
	006336	010346			MOV	R3,-(SP)	
	006340	012746	000001		MOV	#1,-(SP)	
	006344	010600			MOV	SP,R0	
	006346	104415			TRAP	C#PNTX	
	006350	062706	000004		ADD	#4,SP	
1626	006354	000207			RTS	PC	;RETURN TO CALLER

## PRITSSR - PRINT TSSR CONTENTS

1642	006356	045	116	045	EPRT1:	.ASCIZ	'#N#A *****CHECK TRANSPORT*****'
1643	006415	045	116	045	EPRT2:	.ASCIZ	'#N#A *****CHECK PARITY SWITCH IN TRANSPORT*****'
1645	006475	045	116	045	TSSRFOR:	.ASCIZ	'#N#A TSSR = #06'
1646	006515	045	116	045	TEXASC:	.ASCIZ	'#N#A Extended Address Bits = #06'
1647	006556	045	116	045	TCOASC:	.ASCIZ	'#N#A Termination Class Code = #T'
1648	006617	045	116	045	TFCASC:	.ASCIZ	'#N#A Fatal Termination Class Code = #T'
1649	006666	045	116	045	TSSDEF:	.ASCIZ	'#N#A TSSR Bits Set: #T'
1650	006715	045	116	045	AMBTSSR:	.ASCIZ	'#N#A TSSR Contents Are Ambiguous'
1651						.EVEN	
1652	006756	006776	007021	007047	TCOCOD:	.WORD	1#,2#,3#,4#,5#,6#,7#,8#
1653	006776	116	157	162	1#:	.ASCIZ	'Normal Termination'
1654	007021	124	145	162	2#:	.ASCIZ	'Termination Condition'
1655	007047	124	141	160	3#:	.ASCIZ	'Tape Status Alert'
1656	007071	106	165	156	4#:	.ASCIZ	'Function Reject'
1657	007111	122	145	143	5#:	.ASCIZ	'Recoverable Error - Tape Position One Record Down'
1658	007173	122	145	143	6#:	.ASCIZ	'Recoverable Error - Tape Was Not Moved'
1659	007242	125	156	162	7#:	.ASCIZ	'Unrecoverable Error'
1660	007266	106	141	164	8#:	.ASCIZ	'Fatal Controller Error'
1661						.EVEN	
1662							
1663	007316	007326	007362	007373	TSFCOD:	.WORD	1#,2#,3#,4#
1664	007326	111	156	164	1#:	.ASCIZ	'Internal Diagnostic Failure'
1665	007362	122	145	163	2#:	.ASCIZ	'Reserved'
1666	007373	102	165	163	3#:	.ASCIZ	'Bus Interface or Sanity Check Error'
1667	007437	122	145	163	4#:	.ASCIZ	'Reserved'
1668						.EVEN	



E4

PRIPKT - PRINT THE ADDRESS/CONTENTS OF COMMAND PACKET

.SBTTL PRIPKT - PRINT THE ADDRESS/CONTENTS OF COMMAND PACKET

1670  
1671  
1672  
1673  
1674  
1675  
1676  
1677  
1678  
1679  
1680  
1681  
1682  
1683  
1684  
1685  
1686  
1687  
1688  
1689  
1690  
1691  
1692  
1693  
1694  
1695  
1696  
1697  
1698  
1699  
1700  
1701  
1702  
1703  
1704  
1705  
1706  
1707  
1708  
1709  
1710  
1711

007450  
007450  
007454 010005 003130  
007456 005737  
007462 001001  
007464 005003  
007466 010301  
007470 010400  
007472 006100  
007474 006101  
007476 010446  
007500 010146  
007502 012746 007634  
007506 012746 000003  
007512 010600  
007514 104414  
007516 062706 000010  
007522 010300  
007524 001404  
007526 010401  
007530 004737 017426  
007534 010004  
007536 005001  
007540 012402  
007542 010246  
007544 010146  
007546 012746 007576  
007552 012746 000003  
007556 010600  
007560 104414  
007562 062706 000010  
007566 005201  
007570 020105  
007572 002762  
007574 000207  
045 116  
045 116

```

; THIS ROUTINE PRINTS THE ADDRESS AND CONTENTS OF A COMMAND PACKET.
; THIS ROUTINE IS NORMALLY ONLY CALLED FROM A PRINT ROUTINE.
; INPUT:
;
; R0      NUMBER OF WORDS IN PACKET
; R3      HIGH ORDER COMMAND PACKET ADDRESS
; R4      ADDRESS OF COMMAND PACKET
;
; NOTE:   R3 IS IGNORED IF THE KTENABLE FLAG IS CLEAR.
;-
PRIPKT::
  SAVREG                                ;SAVE THE REGISTERS
  MOV  R0,R5                             ;SAVE NO. OF WORDS IN PACKET
  TST  KTENABLE                          ;ABOVE 28K UNDER TEST?
  BNE  10$                               ;BR IF YES
  CLR  R3                                 ;SET HIGH ORDER ADDRESS TO 0
  MOV  R3,R1                             ;COPY HIGH ORDER ADDRESS
  MOV  R4,R0                             ;GET LOWER ADDRESS
  ROL  R0                                 ;SHIFT BIT 15 INTO C BIT
  ROL  R1                                 ;AND INTO HIGH ORDER.
  PRINTB #PKTADD,R1,R4                  ;PRINT PACKET ADDRESS
  MOV  R4,-(SP)
  MOV  R1,-(SP)
  MOV  #PKTADD,-(SP)
  MOV  #3,-(SP)
  MOV  SP,R0
  TRAP C:PNTB
  ADD  #10,SP
  15$: MOV  R3,R0                         ;GET HIGH ORDER ADDRESS
  BEQ  20$                               ;BR IF NOT ABOVE 28K.
  MOV  R4,R1                             ;GET LOW ORDER ADDRESS
  JSR  PC,SETMAP                         ;SETUP PAR6 MAPPING FOR 18 BIT ADDRESS
  MOV  R0,R4                             ;GET RETURNED PAR6 ADDRESS BIAS
  20$: CLR  R1                           ;SAVE WORD NUMBER
  25$: MOV  (R4),R2                       ;GET PACKET CONTENTS
  PRINTB #PKTFRM,R1,R2                  ;PRINT THE DATA
  MOV  R2,-(SP)
  MOV  R1,-(SP)
  MOV  #PKTFRM,-(SP)
  MOV  #3,-(SP)
  MOV  SP,R0
  TRAP C:PNTB
  ADD  #10,SP
  INC  R1                                 ;NEXT WORD NUMBER
  CMP  R1,R5                             ;DONE ALL PACKET WORDS?
  BLT  25$                               ;LOOP TILL ALL DONE
  RTS  PC                                 ;RETURN
;
;#N#A Packet Word #D1#A = #06'
;#N#A Packet Address = #01#05'
.EVEN
```

PRIBXOR - PRINT EXPD, RECV AND XOR BYTE

```

1713
1714
1715
1716
1717
1718
1719
1720
1721
1722
1723
1724
1725
1726
1727
1728 007672
1729 007672
1730 007676 010203
1731 007700
1732 007710 012700 177400
1733 007714 040001
1734 007716 040002
1735 007720 040003
1736 007722
    007722 010346
    007724 010146
    007726 010246
    007730 012746 007754
    007734 012746 000004
    007740 010600
    007742 104414
    007744 062706 000012
1737 007750 010300
1738 007752 000207
1739
1740 007754 045 116 045
1741
1742
1743
1744
1745
1746
1747
1748
1749
1750
1751
1752
1753
1754
1755
1756
1757 010022
1758 010022
1759 010026 010203
1760 010030
1761 010040
    
```

```

.SBTTL PRIBXOR - PRINT EXPD, RECV AND XOR BYTE
;*
;PRINT EXPECTED DATA, RECEIVED DATA, AND XOR OF THE DATA BYTE
;THIS ROUTINE IS NORMALLY CALLED ONLY FOR PRINT ROUTINES.
;
;INPUTS:
;
;   R1   RECEIVED DATA
;   R2   EXPECTED DATA
;
;OUTPUT:
;
;   R0   XOR OF EXPECTED/RECEIVED DATA
;-
PRIBXOR:
    SAVREG                ;SAVE THE REGISTERS
    MOV     R2,R3          ;EXPECTED DATA
    XOR     R1,R3          ;FORM THE EXCLUSIVE OR
    MOV     #1C<377>,R0   ;BYTE MASK
    BIC     R0,R1          ;SAVE LOW BYTE RECV
    BIC     R0,R2          ;SAVE LOW BYTE EXPD
    BIC     R0,R3          ;SAVE LOW BYTE XOR
    PRINTB @XORBFOR,R2,R1,R3 ;PRINT THE MESSAGE
    MOV     R3,-(SP)
    MOV     R1,-(SP)
    MOV     R2,-(SP)
    MOV     @XORBFOR,-(SP)
    MOV     #4,-(SP)
    MOV     SP,R0
    TRAP   C#PNTB
    ADD    #12,SP
    MOV    R3,R0          ;R0 HAS XOR ON RETURN
    RTS    PC             ;RETURN TO CALLER

045 XORBFOR: .ASCIZ '#N#A EXPD: #03#A RECV: #03#A XOR: #03'
.EVEN
.SBTTL PRIBXOR - PRINT EXPD, RECV AND XOR
;*
;PRINT EXPECTED DATA, RECEIVED DATA, AND XOR OF THE TWO
;THIS ROUTINE IS NORMALLY CALLED ONLY FOR PRINT ROUTINES.
;
;INPUTS:
;
;   R1   RECEIVED DATA
;   R2   EXPECTED DATA
;
;OUTPUT:
;
;   R0   XOR OF EXPECTED/RECEIVED DATA
;-
PRIBXOR:
    SAVREG                ;SAVE THE REGISTERS
    MOV     R2,R3          ;EXPECTED DATA
    XOR     R1,R3          ;FORM THE EXCLUSIVE OR
    PRINTB @XORBFOR,R2,R1,R3 ;PRINT THE MESSAGE
    
```



G4

PRIXOR - PRINT EXPD, RECV AND XOR

```

010040 010346      MOV      R3,-(SP)
010042 010146      MOV      R1,-(SP)
010044 010246      MOV      R2,-(SP)
010046 012746 010072  MOV      @XORFOR,-(SP)
010052 012746 000004  MOV      #4,-(SP)
010056 010600      MOV      SP,RO
010060 104414      TRAP     C#PNTB
010062 062706 000012  ADD      #12,SP
1762 010066 010300      MOV      R3,RO      ;RO HAS XOR ON RETURN
1763 010070 000207      RTS         ;RETURN TO CALLER
1764
1765 010072      045      116      045 XORFOR: .ASCIZ '#N#A EXPD: #06#A RECV: #06#A XOR: #06#
1766                      .EVEN

```

PRIEQU - PRINT BIT NUMBERS AS ASCII EQUIVALENT

1768  
1769  
1770  
1771  
1772  
1773  
1774  
1775  
1776  
1777  
1778  
1779  
1780  
1781  
1782  
1783  
1784  
1785  
1786  
1787  
1788  
1789  
1790  
1791  
1792  
1793  
1794  
1795  
1796  
1797  
1798  
1799  
1800  
1801  
1802  
1803

010140  
010140  
010144 000207  
  
  
  
  
  
  
  
  
  
  
  
  
010146  
010146  
010152  
010152 010446  
010154 012746 010176  
010160 012746 000002  
010164 010600  
010166 104414  
010170 062706 000006  
010174 000207  
  
  
045 116 045

```

.SBTTL PRIEQU - PRINT BIT NUMBERS AS ASCII EQUIVALENT
;*
;
;ROUTINE TO CONVERT BIT VALUES TO ASCII AND PRINT THE STRING
;THIS ROUTINE IS NORMALLY CALLED FROM A PRINT ROUTINE
;
;INPUTS:
;
;      R0      OCTAL VALUE TO CONVERT
;      R1      TABLE OF POINTERS TO ASCII EQUIVALENT
;
;-
PRIEQU:
      SAVREG          ;SAVE THE REGISTERS
      RTS            PC          ;RETURN TO CALLER

.SBTTL PRIRAM - PRINT RAM ADDRESS
;*
;
;PRINT CONTROLLER RAM ADDRESS.
;THIS ROUTINE IS NORMALLY CALLED ONLY FROM PRINT ROUTINES.
;
;INPUTS:
;
;      R4      RAM ADDRESS
;
;-
PRIRAM:
      SAVREG          ;SAVE R1-R5 UNTIL NEXT RETURN
      PRINTB         #RAMFOR,R4 ;PRINT RAM ADDRESS IN ERROR
      MOV            R4,-(SP)
      MOV            #RAMFOR,-(SP)
      MOV            #2,-(SP)
      MOV            SP,R0
      TRAP          C#PNTB
      ADD            #6,SP
      RTS            PC          ;RETURN

RAMFOR: .ASCIZ 'N/A CONTROLLER RAM ADDRESS = #06'
.EVEN

```



PRIADD - PRINT MEMORY ERROR ADDRESS

```

1805          .SBTTL PRIADD - PRINT MEMORY ERROR ADDRESS
1806          ;*
1807          ;
1808          ;PRINT MEMORY ADDRESS
1809          ;THIS ROUTINE IS NORMALLY CALLED ONLY FROM PRINT ROUTINES.
1810          ;
1811          ; IMPLICIT INPUTS
1812          ;
1813          ;     ERRHI  - HIGH ORDER ADDRESS
1814          ;     ERRLO  - LOW ORDER ADDRESS
1815          ;
1816          ;-
1817          PRIADD:
1818          SAVREG          ;SAVE R1-R5 UNTIL NEXT RETURN
1819          MOV     ERRHI,R0 ;GET HIGH ADDRESS
1820          MOV     ERRLO,R1 ;GET LOW ADDRESS
1821          MOV     R1,R2    ;COPY LOW ADDRESS
1822          ROL    R1       ;SHIFT BIT 15 TO C BIT
1823          ROL    R0       ;SHIFT INTO HIGH ORDER
1824          PRINTB @PRIA0,R0,R2 ;PRINT MEMORY ADDRESS IN ERROR
          MOV     R2,-(SP)
          MOV     R0,-(SP)
          MOV     @PRIA0,-(SP)
          MOV     @3,-(SP)
          MOV     SP,R0
          TRAP   C#PNTB
          ADD    @10,SP
          RTS    PC          ;RETURN

```

```

1825          010240
1826          010240
1827          010244 013700 002232
1828          010250 013701 002234
1829          010254 010102
1830          010256 006101
1831          010260 006100
1832          010262 010246
1833          010264 010046
1834          010266 012746 010310
1835          010272 012746 000003
1836          010276 010600
1837          010300 104414
1838          010302 062706 000010
1839          010306 000207
1840          010310 045 116 045 PRIA0: .ASCIZ 'MEMA MEMORY ERROR ADDRESS = #01#05'
1841          .EVEN

```

.SBTTL PRITADD - PRINT MEMORY TEST ADDRESS

```

1831          ;*
1832          ;
1833          ;PRINT MEMORY ADDRESS
1834          ;THIS ROUTINE IS NORMALLY CALLED ONLY FROM PRINT ROUTINES.
1835          ;
1836          ; IMPLICIT INPUTS
1837          ;
1838          ;     ERRHI  - HIGH ORDER ADDRESS
1839          ;     ERRLO  - LOW ORDER ADDRESS
1840          ;
1841          ;-
1842          PRITADD:
1843          SAVREG          ;SAVE R1-R5 UNTIL NEXT RETURN
1844          MOV     ERRHI,R2 ;GET HIGH ADDRESS
1845          MOV     ERRLO,R1 ;GET LOW ADDRESS
1846          MOV     R1,R2    ;COPY LOW ADDRESS
1847          ROL    R1       ;SHIFT BIT 15 TO C BIT
1848          ROL    R0       ;SHIFT INTO HIGH ORDER
1849          PRINTB @PRIT0,R1 ;PRINT MEMORY ADDRESS LOW IN ERROR
          MOV     R1,-(SP)
          MOV     @PRIT0,-(SP)
          MOV     @2,-(SP)
          MOV     SP,R0
          TRAP   C#PNTB

```

J4

PRITADD - PRINT MEMORY TEST ADDRESS

```

1850 010406 062706 000006      ADD     #6,SP
010412      PRINTB  #PRIT1,R2      ;PRINT MEMORY ADDRESS HIGH IN ERROR
010414 010246      MOV     R2,-(SP)
010414 012746 010501      MOV     #PRIT1,-(SP)
010420 012746 000002      MOV     #2,-(SP)
010424 010600      MOV     SP,R0
010426 104414      TRAP   C:PNTB
1851 010430 062706 000006      ADD     #6,SP
010434 000207      RTS     PC      ;RETURN
1852
1853 010436      045     116     045 PRIT0: .ASCIZ 'N/A MEMORY TEST ADDRESS LOW = #06'
1854 010501      045     116     045 PRIT1: .ASCIZ 'N/A MEMORY TEST ADDRESS HIGH = #06'
1855      .EVEN

```



SPACE - SPACE RECORDS (FORWARD AND REVERSE) COMMAND

.SBTTL SPACE - SPACE RECORDS (FORWARD AND REVERSE) COMMAND

```

1857
1858
1859
1860
1861
1862
1863
1864
1865
1866
1867
1868
1869
1870
1871
1872
1873
1874
1875
1876
1877
1878
1879
1880
1881
1882
1883
1884
1885
1886
1887
1888
1889
1890
1891

```

```

;
;
;ROUTINE TO ISSUE A SPACE RECORDS
;COMMAND (FORWARD OR REVERSE)
;
;INPUT:
;
;   R3   NUMBER OF RECORDS TO BE SPACED OVER
;        BIT15 CONTROLS DIRECTION
;        BIT15 = 0 IS FORWARD
;        BIT15 = 1 IS REVERSE
;   R5   FIRST DEVICE UNIBUS ADDRESS
;
;   REQUIRES A WRITE CHARACTERISTICS DONE PREVIOUSLY
;
;OUTPUT:
;
;   CARRY SET - SPACE RECORDS COMMAND OK
;         CLR - SPACE RECORDS FAILED
;
;   R0   THE CONTENTS OF R4 IS MOVED TO R0
;
;IMPLICIT OUTPUT:
;
;   TAPE HAS BEEN MOVED
;
;SIDE EFFECTS:
;
;
;-

```

```

1892 010546
1893 010546
1894 010552 012737 000764 010740
1895 010560 012737 140010 010730
1896 010566 005703
1897 010570 100403
1898 010572 010337 010732
1899 010576 000407
1900 010600 042703 100000
1901 010604 010337 010732
1902 010610 052737 000400 010730
1903 010616 012704 010730
1904 010622 010465 000000
1905 010626 004737 016360
1906 010632 103420
1907 010634
    010634 012727 000250
    010640 000000
    010642 013727 002116
    010646 000000
    010650 005367 177772
    010654 001375

```

```

SPACE::
    SAVREG
    MOV     #500.,SDELAY
    MOV     #140010,804
    TST     R3
    BMI     54
    MOV     R3,904
    BR      104
54:    BIC     #BIT15,R3
    MOV     R3,904
    BIS     #BIT8,804
104:   MOV     #804,R4
    MOV     R4,TSDB(R5)
154:   JSR     PC,WAITF
    BCS     204
    DELAY   250
    MOV     #250,(PC)+
    .WORD   0
    MOV     L#DLY,(PC)+
    .WORD   0
    DEC     -6(PC)
    BNE     -4
;SAVE THE GENERAL REGISTERS
;SET UP DELAY
;SET UP COMMAND, SPACE FORWARD
;CHECK FOR DIRECTION
;BR, IF REVERSE INDICATED
;LOAD UP NUMBER OF RECORDS TO SPACE
;GO DO COMMAND
;CLEAR DIRECTION BIT
;LOAD UP NUMBER OF RECORDS TO SPACE
;SET REVERSE BIT IN COMMAND PACKET
;SET UP R4 WITH PACKET ADDRESS
;SEND OUT COMMAND
;WAIT FOR SSR
;BR, IF SSR IS SET AND OK
;DELAY ABOUT .25 SECONDS

```

L4

SPACE - SPACE RECORDS (FORWARD AND REVERSE) COMMAND

```

010656 005367 177756          DEC    -22(PC)
010662 001367                BNE    .-20
1908 010664 005337 010740     DEC    SDELAY          ;BUMP DELAY COUNTER DOWN
1909 010670 001356                BNE    15$            ;BR, IF MORE DELAY
1910 010672 000411                BR     60$            ;BR IF TROUBLE CARRY = CLEAR
1911 010674 016501 000002     20$:  MOV    TSSR(R5),R1 ;READ TSSR
1912 010700 012702 000200     MOV    #SSR,R2        ;SET UP EXPECTED
1913 010704 020201                25$:  CMP    R2,R1      ;ARE THEY OK
1914 010706 001401                BEQ    40$            ;BR, IF EQUAL = OK
1915 010710 000402                BR     60$            ;TROUBLE EXIT
1916 010712 000261                40$:  SEC                    ;SET CARRY NO TROUBLE
1917 010714 000401                BR     70$            ;EXIT
1918 010716 000241                60$:  CLC                    ;CARRY CLEAR = ERROR
1919 010720 000207                70$:  MOV    R4,R0        ;PASS PACKET ADDRESS
1920 010720 010400                RTS    PC              ;RETURN
1921 010722 000207
1922
1923
1924
1925          ;PACKET FOR SPACE COMMAND
1926
1928          010730
1930          ;
1931          ;COMMAND WORD
1932 010730 000000     80$:  .WORD
1933          ;NUMBER OF RECORDS TO BE SPACED OVER WORD
1934 010732 000000     90$:  .WORD
1935 010734 000000          .WORD
1936 010736 000000          .WORD
1937 010740 000000     SDELAY: .WORD    0          ;DELAY COUNTER
1938          .EVEN
1939          .SBTTL WRTCHR - WRITE CHARACTERISTICS COMMAND

```



WRTCHR - WRITE CHARACTERISTICS COMMAND

```

1941
1942 ;*
1943 ;ROUTINE TO ISSUE A WRITE CHARACTERISTICS
1944 ;COMMAND SO THAT OTHER COMMANDS WILL BE ACCEPTED
1945
1946 ;INPUT:
1947 ; R4 ADDRESS OF PACKET FROM TEST
1948 ; R5 FIRST DEVICE UNIBUS ADDRESS
1949 ; REQUIRES A CALL TO SOFINIT BE DONE PREVIOUSLY
1950
1951 ;OUTPUT:
1952 ; R0 TSSR CONTENTS
1953 ; CARRY SET - WRITE CHARACTERISTICS COMMAND OK
1954 ; CLR - WRITE CHARACTERISTICS FAILED
1955
1956 ;IMPLICIT OUTPUT:
1957 ;
1958 ; MESSAGE BUFFER AND OTHER BUFFERS ALL SET UP
1959 ; SOFTWARE SWITCHES SET AS FOLLOWS:
1960 ; EXTFEA = EXTENDED FEATURES PRESENT
1961 ; BENBSW = BUFFER ENABLE SWITCH ON OR OFF
1962
1963 ;SIDE EFFECTS:
1964 ;-
1965 WRTCHR::
1966 ; SAVREG
1967 ; CLR BENBSW ;SAVE THE GENERAL REGISTERS
1968 ; CLR EXTFEA ;CLEAR BUFFER ENABLE SWITCH
1969 104: MOV R4,TSDB(R5) ;CLEAR EXTENDED FEATURES SW SWITCH
1970 JSR PC,CHKTSSR ;SEND OUT COMMAND
1971 BCS 204 ;WAIT FOR SSR
1972 BR 604 ;BR, IF SSR IS SET AND OK
1973 204: MOV TSSR(R5),R1 ;BR IF TROUBLE CARRY = CLEAR
1974 MOV #SSR,R2 ;READ TSSR
1975 BIT #OFL,R1 ;SET UP EXPECTED
1976 BEQ 254 ;WAS OFF LINE SET IN TSSR
1977 BIS #OFL,R2 ;BR, IF NO OFL SET
1978 254: CMP R2,R1 ;MAKE THEM LOOK ALIKE
1979 BEQ 404 ;ARE THEY OK
1980 BR 604 ;BR, IF EQUAL = OK
1981 404: ADD #8,R4 ;TROUBLE EXIT
1982 MOV (R4),R3 ;POINT TO WRT CHARA DATA PACKET
1983 BIT #X2.EXTF,XST2(R3) ;GET ADDRESS OF MESSAGE BUFFER
1984 BEQ 454 ;EXTENDED FEATURES BIT SET?
1985 INC EXTFEA ;BR IF NO
1986 454: BIT #X2.BUFE,XST2(R3) ;SET EXTENDED FEATURES SW SWITCH
1987 BEQ 504 ;BUFFER ENABLE SWITCH SET
1988 INC BENBSW ;BR, IF SWITCH NOT SET
1989 504: MOV XST2(R3),REV ;SET SOFTWARE SWITCH FOR ENABLED
1990 BIC #17700,REV ;MICROCODE REV LEVEL
1991 CMP #1,REV ;CLEAR UNWANTED BITS
1992 BEQ 554 ;IS IT A NEW MICROCODE
1993 MOV #1,EXTFEA ;NO BR
1994 554: SEC ;ALWAY EXTENDED FEATURE FOR NEW
1995 BR 704 ;MICROCODE
1996 ;SET CARRY NO TROUBLE
1997 ;EXIT

```

N4

WRTCHR - WRITE CHARACTERISTICS COMMAND

1998 011116 000241  
1999 011120 016500 000002  
2000 011124 000207

604:    CLC  
704:    MOV    TSSR(R5),R0  
         RTS    PC

;CARRY CLEAR = ERROR  
;RETURN TSSR CONTENTS  
;RETURN



REWIND - POSITION TAPE (REWIND) COMMAND

2002  
2003  
2004  
2005  
2006  
2007  
2008  
2009  
2010  
2011  
2012  
2013  
2014  
2015  
2016  
2017  
2018  
2019  
2020  
2021  
2022  
2023  
2024  
2025  
2026  
2027  
2028

2029 011126  
2030 011126  
2031 011132 012704 011220  
2032 011136 010465 000000  
2033 011142 012703 000550  
2034 011146 004737 016360  
2035 011152 103417  
2036 011154  
011154 012727 000372  
011160 000000  
011162 013727 002116  
011166 000000  
011170 005367 177772  
011174 001375  
011176 005367 177756  
2037 011204 005303  
2038 011206 001357  
2039 011210 000241  
2040 011212 010400  
2041 011214 000207  
2042  
2044 011220  
2046 011220  
2047 011220 102010  
2048 011222 000000

```

.SBTTL REWIND - POSITION TAPE (REWIND) COMMAND
;
; THIS ROUTINE WILL REWIND THE SELECTED TAPE.
;
; CAUTION: THE ROUTINE DOES NOT WAIT FOR BOT
; TO ARRIVE. ALSO THE CALLER MUST CHECK FOR
; SSR TO SET IN THE TSSR
;
; CALLING SEQUENCE:
;
; DO A SOFT INIT
; DO A WRITE CHARACTERISTICS
; JSR PC,REWIND
;
; INPUT:
;
; R5 FIRST DEVICE UNIBUS ADDRESS
;
; OUTPUT
;
; R0 THE CONTENTS OF R4 IS PASSED TO R0
;
; -
REWIND::
    SAVREG                                ;SAVE R1-R5 UNTIL NEXT RETURN
    MOV #RMPACK,R4                        ;GET PACKET ADDRESS
    MOV R4,TSDB(R5)                       ;SEND PACKET ADDRESS TO EXECUTE
    MOV #360,R3                            ;ENOUGH TIME FOR 2400' REEL TO REWIND
10$: JSR PC,WAITF                          ;WAIT FOR SSR TO SET
    BCS 20$                                ;LEAVE WHEN SSR IS SET
    DELAY 250                              ;WAIT FOR .25 SECONDS
    MOV #250,.(PC)-
    .WORD 0
    MOV L#DLY,.(PC)-
    .WORD 0
    DEC -6(PC)
    BNE -.4
    DEC -22(PC)
    BNE -.20
    DEC R3                                  ;BUMP COUNTER DOWN
    BNE 10$                                ;KEEP GOING
    CLC                                     ;CLEAR CARRY TO SET ERROR
20$: MOV R4,R0                             ;PASS THE PACKET ADDRESS
    RTS PC                                  ;RETURN
;
RMPACK: .=< .10>E177770
    .WORD 102010                           ;POSTION COMMAND (REWIND)
    .WORD 0                                ;NOT USED

```

CKRAM - COMPARE RAM TO I/O PACKET

2050  
2051  
2052  
2053  
2054  
2055  
2056  
2057  
2058  
2059  
2060  
2061  
2062  
2063  
2064  
2065  
2066  
2067  
2068  
2069  
2070  
2071  
2072  
2073  
2074  
2075  
2076  
2077

.SBTTL CKRAM - COMPARE RAM TO I/O PACKET

```

; *
; ROUTINE TO READ THE FIRST 8 BYTES FROM RAM
; MEMORY AND COMPARE THIS DATA TO A COMMAND PACKET.
; INPUT:
; R4 ADDRESS OF THE COMMAND PACKET
; R5 FIRST DEVICE UNIBUS ADDRESS
; OUTPUT:
; CARRY SET - RAM MATCHES PACKET
; CLR - RAM DOES NOT MATCH PACKET
; IMPLICIT OUTPUT:
; THE TABLE RAMDATA IS FILLED WITH THE
; DATA HELD IN RAM.
; RAMSIZ IS SET TO 8. FOR PRAMPKT ROUTINE
; SIDE EFFECTS:
; THE SUBSYSTEM IS LEFT IN MAINTENANCE MODE
; -
    
```

2078 011224  
2079 011224  
2080 011230 012701 002236  
2081 011234 012702 000201  
2082 011240 005003  
2083 011242 004737 016446  
2084 011246 112765 000000 000000  
2085 011254 004737 016446 10:  
2086 011260 010265 000000  
2087 011264 004737 016446  
2088 011270 116511 000000  
2089 011274 122124  
2090 011276 001401  
2091 011300 005203  
2092 011302 005202  
2093 011304 020227 000210  
2094 011310 003761  
2095 011312 005703  
2096 011314 001402  
2097 011316 000241  
2098 011320 000401  
2099 011322 000261 30:  
2100 011324 012737 000010 002276 50:  
2101 011332 000207

```

CKRAM::
    SAVREG
    MOV #RAMDATA,R1 ;SAVE THE GENERAL REGISTERS
    MOV #RMPKTBEG,R2 ;ADDRESS TO SAVE THE RAM DATA
    CLR R3 ;BYTE ADDRESS OF FIRST RAM DATA
    JSR PC,CHKTSSR ;CLEAR THE ERROR FLAG
    MOVB #0,TSDB(R5) ;WAIT FOR SSR
    JSR PC,CHKTSSR ;SET MAINTENANCE MODE
    MOV R2,TSDB(R5) ;WAIT FOR SSR TO SET
    JSR PC,CHKTSSR ;SELECT NEXT RAM ADDRESS
    MOVB TSBA(R5),(R1) ;WAIT FOR SSR TO SET
    CMPB (R1),-(R4) ;READ THE RAM DATA
    BEQ 20$ ;COMPARE TO EXPECTED
    INC R3 ;BRANCH IF OK
    INC R2 ;SET ERROR FLAG
    CMP R2,#RMPKTEND ;ADDRESS OF NEXT RAM LOCATION
    BLE 10$ ;REACHED END YET ?
    TST R3 ;BRANCH TILL ALL READ
    BEQ 30$ ;WAS AN ERROR FOUND ?
    CLC ;BRANCH IF NOT
    BR 50$ ;CLEAR CARRY TO SHOW ERROR
    SEC ;AND EXIT
    MOV #8,RAMSIZ ;SHOW GOOD COMPARE
    RTS PC ;SETUP RAMSIZ FOR PRAMPKT ROUTINE
    ;RETURN
    
```



## CKRAM2 - COMPARE RAM TO I/O CHARACTERISTICS DATA

```

2103          .SBTTL CKRAM2 - COMPARE RAM TO I/O CHARACTERISTICS DATA
2104          ;*
2105          ;
2106          ;ROUTINE TO READ THE FIRST 8 OR 10 BYTES FROM RAM
2107          ;MEMORY AND COMPARE THIS DATA TO A CHARACTERISTICS DATA BLOCK.
2108          ;
2109          ;INPUT:
2110          ;
2111          ;      R4      ADDRESS OF THE CHARACTERISTICS DATA
2112          ;      R5      FIRST DEVICE UNIBUS ADDRESS
2113          ;
2114          ;OUTPUT:
2115          ;
2116          ;      CARRY   SET - RAM MATCHES PACKET
2117          ;             CLR - RAM DOES NOT MATCH PACKET
2118          ;
2119          ;IMPLICIT OUTPUT:
2120          ;
2121          ;      THE TABLE RAMDATA IS FILLED WITH THE
2122          ;      DATA HELD IN RAM.
2123          ;      RAMSIZ IS SET TO 8. OR 10. FOR PRAMPKT ROUTINE
2124          ;
2125          ;SIDE EFFECTS:
2126          ;
2127          ;      THE SUBSYSTEM IS LEFT IN MAINTENANCE MODE
2128          ;
2129          CKRAM2::
2130          SAVREG          ;SAVE THE GENERAL REGISTERS
2131          MOV             #RAMDATA,R1      ;ADDRESS TO SAVE THE RAM DATA
2132          MOV             #RAMCHBEG,R2    ;BYTE ADDRESS OF FIRST RAM DATA
2133          CLR             R3              ;CLEAR THE ERROR FLAG
2134          JSR             PC,CHKTSSR      ;WAIT FOR SSR
2135          MOV             #0,TSDB(R5)     ;SET MAINTENANCE MODE
2136          JSR             PC,CHKTSSR      ;WAIT FOR SSR TO SET
2137          MOV             R2,TSDB(R5)     ;SELECT NEXT RAM ADDRESS
2138          JSR             PC,CHKTSSR      ;WAIT FOR SSR TO SET
2139          MOV             TSBA(R5),(R1)   ;READ THE RAM DATA
2140          MOV             122124,R1      ;COMPARE TO EXPECTED
2141          CMPB            (R1),.(R4).     ;BRANCH IF OK
2142          BEQ             20$            ;SET ERROR FLAG
2143          INC             R3              ;ADDRESS OF NEXT RAM LOCATION
2144          INC             R2              ;ASSUME EXTFEA NOT SET
2145          MOV             #8,,RAMSIZ     ;IS THE SOFTWARE EXTENDED FEATURES SET
2146          TST             EXTFEA         ;BR, IF NOT SET
2147          BEQ             25$            ;SET RAMSIZ FOR EXTEND FEATURES
2148          MOV             #10,,RAMSIZ    ;AT END OF EXTENDED BUFFER
2149          CMP             R2,#RAMCHEND   ;BR, IF NOT AT END YET
2150          BLE            10$            ;AT END BRANCH
2151          BR              27$            ;REACHED END YET ?
2152          CMP             R2,#RAMCHEND-2 ;BRANCH TILL ALL READ
2153          BLE            10$            ;WAS AN ERROR FOUND ?
2154          TST             R3              ;BRANCH IF NOT
2155          BEQ             30$            ;CLEAR CARRY TO SHOW ERROR
2156          CLC              ;AND EXIT
2157          BR              50$            ;SHOW GOOD COMPARE
2158          SEC              ;RETURN
2159          RTS              PC

```

E5

CKMSG - COMPARE WRITE CHAR. MESSAGE BUFFERS

```

2160 .SBTTL CKMSG - COMPARE WRITE CHAR. MESSAGE BUFFERS
2161 ;*
2162 ;
2163 ;ROUTINE TO COMPARE A WRITE CHARACTERISTICS EXPD AND RECV
2164 ;BUFFER. THE EXPECTED AND RECEIVED BUFFERS ARE STORED FOR
2165 ;ERROR PRINT ROUTINES.
2166 ;
2167 ;INPUT:
2168 ;
2169 ; R0 RECV MESSAGE BUFFER HIGH ORDER ADDRESS
2170 ; R1 RECV MESSAGE BUFFER LOW ORDER ADDRESS
2171 ; R2 EXPD MESSAGE BUFFER ADDRESS
2172 ;OUTPUT:
2173 ;
2174 ; CARRY SET - MESSAGE BUFFERS MATCH
2175 ; CLR -MESSAGE BUFFERS DON'T MATCH
2176 ;
2177 ;IMPLICIT OUTPUT:
2178 ;
2179 ; EXPMSG BUFFER IS SET TO EXPD DATA
2180 ; RECVMSG BUFFER IS SET TO RECV DATA
2181 ; RCVHIADD SET TO HIGH ORDER ADDRESS OF RECV
2182 ; RCVLOAD SET TO LOW ORDER ADDRESS OF RECV
2183 ;
2184 ;-
2185 CKMSG::
2186 SAVREG ;SAVE R1-R5 UNTIL NEXT RETURN
2187 MOV R0,RCVHIADD ;SAVE RECV HIGH ADDRESS
2188 MOV R1,RCVLOAD ;SAVE RECV LOW ADDRESS
2189 TST KTENABLE ;TESTING ABOVE 28K?
2190 BEQ 104 ;BR IF NO
2191 JSR PC,SETMAP ;RETURN ADDRESS BIASED TO PAR6 IN R0
2192 MOV R0,R1 ;GET RETURNED ADDRESS BIASED TO PAR6
2193 104: CLR R4 ;WORD IN BUFFER
2194 CLR R3 ;CLEAR ERROR SEEN FLAG
2195 MOV R2,R5 ;GET EXPD BUFFER ADDRESS
2196 154: MOV (R2),EXPMSG(R4) ;SAVE EXPD FOR ERROR REPORT
2197 MOV (R1),RECVMSG(R4) ;SAVE RECV FOR ERROR REPORT
2198 CMP (R2),.(R1) ;EXPD EQUAL RECV?
2199 BEQ 254 ;BR IF YES
2200 INC R3 ;SET ERROR SEEN FLAG
2201 254: ADD #2,R4 ;POINT TO NEXT WORD ADDRESS
2202 CMP R4,#14 ;DONE FIRST 7 WORDS?
2203 BLE 154 ;BR IF NO
2204 000200 000012 BIT #X2.EXTF,XST2(R5) ;IS EXTENDED FEATURES SET IN EXPD?
2205 BEQ 504 ;BR IF NO
2206 CMP R4,#16 ;DONE EXTENDED FEATURES WORD?
2207 BLE 154 ;BR IF NO
2208 504: TST R3 ;ANY ERRORS SEEN?
2209 BEQ 554 ;BR IF NO
2210 CLC ;SET FAILURE
2211 BR 604 ;
2212 554: SEC ;SET SUCCESS
2213 604: RTS PC ;RETURN

```



CKMSG2 - COMPARE EXPD RECV MESSAGE BUFFERS

```

2215 .SBTTL CKMSG2 - COMPARE EXPD RECV MESSAGE BUFFERS
2216
2217 ;*
2218 ;ROUTINE TO COMPARE AN EXPECTED AND RECEIVED MESSAGE
2219 ;BUFFER. THE EXPECTED AND RECEIVED BUFFERS ARE STORED FOR
2220 ;ERROR PRINT ROUTINES.
2221 ;INPUT:
2222 ; R0 RECV MESSAGE BUFFER HIGH ORDER ADDRESS
2223 ; R1 RECV MESSAGE BUFFER LOW ORDER ADDRESS
2224 ; R2 EXPD MESSAGE BUFFER ADDRESS
2225 ; R3 NUMBER OF BYTES TO COMPARE
2226
2227 ;OUTPUT:
2228 ; CARRY SET - MESSAGE BUFFERS MATCH
2229 ; CLR - MESSAGE BUFFERS DON'T MATCH
2230
2231 ;IMPLICIT OUTPUT:
2232 ; EXPMSG BUFFER IS SET TO EXPD DATA
2233 ; RECVMSG BUFFER IS SET TO RECV DATA
2234 ; RCVHIADD SET TO HIGH ORDER ADDRESS OF RECV
2235 ; RCVLOAD SET TO LOW ORDER ADDRESS OF RECV
2236
2237 CKMSG2::
2238 SAVREG ;SAVE R1-R5 UNTIL NEXT RETURN
2239 CMP R3,#RECVMSG-EXPMSG,#0 ;IS COUNT ABOVE MAX ALLOWED?
2240 BLE 5# ;AND BR IF NO
2241 MOV #RECVMSG-EXPMSG,R3 ;AND
2242 PRINTF #DEBUGMSG ;AND
2243 MOV #DEBUGMSG,-(SP)
2244 MOV #1,-(SP)
2245 MOV SP,R0
2246 TRAP C#PNTF
2247 ADD #4,SP
2248 5#: MOV R0,RCVHIADD ;SAVE RECV HIGH ADDRESS
2249 MOV R1,RCVLOAD ;SAVE RECV LOW ADDRESS
2250 TST KTENABLE ;TESTING ABOVE 28K?
2251 BEQ 10# ;BR IF NO
2252 JSR PC,SETMAP ;RETURN ADDRESS BIASED TO PAR6 IN R0
2253 MOV R0,R1 ;GET RETURNED ADDRESS BIASED TO PAR6
2254 10#: CLR R4 ;WORD IN BUFFER
2255 CLR R5 ;CLEAR ERROR SEEN FLAG
2256 15#: MOV (R2),EXPMSG(R4) ;SAVE EXPD FOR ERROR REPORT
2257 MOV (R1),RECVMSG(R4) ;SAVE RECV FOR ERROR REPORT
2258 CPB (R2)*,(R1)* ;EXPD EQUAL RECV?
2259 BEQ 25# ;BR IF YES
2260 INC R5 ;SET ERROR SEEN FLAG
2261 25#: ADD #1,R4 ;POINT TO NEXT BYTE
2262 CMP R4,R3 ;DONE ALL BYTES?
2263 BGE 50# ;BR IF YES
2264 BR 15# ;DO NEXT BYTE
2265 50#: TST R5 ;ANY ERRORS SEEN?
2266 BEQ 55# ;BR IF NO
2267 CLC ;SET FAILURE
2268 BR 60#
2269 55#: SEC ;SET SUCCESS
2270 60#: RTS PC ;RETURN

```

G5

CKMSG2 - COMPARE EXPD RECV MESSAGE BUFFERS

```

2267 011742      120      122      117  DEBUGMSG: .ASCIZ 'PROGRAM INTERNAL ERROR -CKMSG2 MESSAGE BUFFER EXCEEDED-' ;@ad
2268 012032      045      116      045  FERCM:  .ASCII /#N#A ***/
2269 012043      040      040      124  ERCM:  .ASCIZ / TSSR ERROR CODE REC'D = /
2270 012076      056      056      056  SIMSG: .ASCIZ /... AFTER DOING SOFT INIT/
2271 012131      124      105      123  TINERR: .ASCIZ /TEST: .../
2272                                     .EVEN
2273                                     ;*
2274                                     ;
2275                                     ;PRINT ROUTINE TO FATAL SOFT INIT ERRORS
2276                                     ;
2277                                     ;INPUT:
2278                                     ;
2279                                     ;      R1      CONTENTS OF TSSR AT ERROR
2280                                     ;
2281                                     ;SIDE EFFECTS:
2282                                     ;
2283                                     ;      EXECUTES DROP UNIT TO CEASE TESTING
2284                                     ;
2285                                     ;
2286                                     ;-
2287 012144      BGNMSG  SFMSG
      012144      SFMSG::
2288 012144      004737  006022      JSR      PC,PRITSSR      ;PRINT CONTENTS OF TSSR REGISTER
2289 012150      004737  017312      JSR      PC,CKDROP      ;DROP UNIT, IF ALLOWED
2290 012154      ENDMSG
      012154      L10003:
      012154      104423      TRAP      C#MSG

2291
2292                                     ;*
2293                                     ;PRINT ROUTINE TO PRINT THE CONTENTS OF
2294                                     ;TSSR AND A COMMAND PACKET OTHER THAN GET STATUS COMMAND PACKET.
2295                                     ;
2296                                     ;INPUTS:
2297                                     ;
2298                                     ;      R1      TSSR CONTENTS
2299                                     ;      R4      ADDRESS OF COMMAND PACKET
2300                                     ;
2301                                     ;-
2302
2303 012156      BGNMSG  PKTSSR
      012156      PKTSSR::
2304 012156      004737  006022      JSR      PC,PRITSSR      ;PRINT THE CONTENTS OF TSSR REGISTER
2305 012162      012700  000004      MOV      #4,R0          ;NO. OF WORDS IN PACKET
2306 012166      004737  007450      JSR      PC,PRIPKT      ;PRINT THE CONTENTS OF COMMAND PACKET
2307 012172      ENDMSG
      012172      L10004:
      012172      104423      TRAP      C#MSG

```



H5

CKMSG2 - COMPARE EXPD RECV MESSAGE BUFFERS

```

2309
2310 ;PRINT ROUTINE TO PRINT THE CONTENTS OF
2311 ;TSSR AND A GET STATUS COMMAND PACKET.
2312 ;
2313 ;INPUTS:
2314 ;
2315 ; R1 TSSR CONTENTS
2316 ; R4 ADDRESS OF COMMAND PACKET
2317 ;
2318 012174 BGNMSG PKTGETS
012174
2319 012174 004737 006022 PKTGETS:
2320 012200 012700 000002 JSR PC,PRITSSR ;PRINT THE CONTENTS OF TSSR REGISTER
2321 012204 004737 007450 MOV #2,R0 ;NO. OF WORDS IN GET STATUS PACKET
2322 012210 JSR PC,PRIPKT ;PRINT THE CONTENTS OF COMMAND PACKET
012210 ENDMSG
012210 104423 L10005:
TRAP C#MSG

2323 ;
2324 ;PRINT TSSR ERRORS FOR INITIALIZATION TESTS
2325 ;
2326 ;INPUTS:
2327 ; R1 TSSR CONTENTS
2328 ; R4 ADDRESS OF COMMAND PACKET
2329 ;
2330 012212 BGNMSG SFFMSG
012212
2331 012212 004737 006022 SFFMSG:
2332 012216 JSR PC,PRITSSR ;PRINT CONTENTS OF TSSR REGISTER
012216 ENDMSG
012216 104423 L10006:
TRAP C#MSG
.SBTTL PKTMES - PRINT TSSR AND MESSAGE BUFFER

2333 ;
2334 ;PRINT ROUTINE TO PRINT THE CONTENTS OF TSSR AND MESSAGE
2335 ;BUFFER FOR ERROR REPORTS
2336 ;
2337 ;INPUTS:
2338 ;
2339 ; R1 CONTENTS OF TSSR
2340 ; R2 LOW ORDER MESSAGE BUFFER
2341 ; R3 HIGH ORDER MESSAGE BUFFER ADDRESS
2342 ; NOTE: R3 IS IGNORED IF KTENABLE FLAG IS CLEAR
2343 ;
2344 ;
2345 012220 BGNMSG PKTMES
012220
2346 012220 004737 006022 PKTMES:
2347 012224 010200 JSR PC,PRITSSR ;PRINT CONTENTS OF TSSR
2348 012226 010301 MOV R2,R0 ;LOW ORDER ADDRESS
2349 012230 004737 014352 MOV R3,R1 ;HIGH ORDER ADDRESS
2350 012234 JSR PC,PRMESS ;PRINT THE MESSAGE BUFFER
012234 ENDMSG
012234 104423 L10007:
TRAP C#MSG

```

ADDSSR - PRINT TEST ADDRESS AND TSSR

```

2352 .SBTTL ADDSSR - PRINT TEST ADDRESS AND TSSR
2353 ;*
2354 ;PRINT ROUTINE TO PRINT THE CONTENTS OF
2355 ;TSSR AND A MEMORY TEST ADDRESS
2356 ;
2357 ;INPUTS:
2358 ;
2359 ; R5 FIRST DEVICE UNIBUS ADDRESS
2360 ; ERRHI HIGH ORDER MEMORY TEST ADDRESS
2361 ; ERRLO LOW ORDER MEMORY TEST ADDRESS
2362 ;
2363 ;-
2364 012236 BGNMSG ADDSSR
012236 ADDSSR::
2365 012236 004737 010354 JSR PC,PRITADD ;PRINT MEMORY TEST ADDRESS
2366 012242 016501 000002 MOV TSSR(R5),R1 ;GET CURRENT TSSR
2367 012246 004737 006022 JSR PC,PRITSSR ;PRINT THE CONTENTS OF TSSR REGISTER
2368 012252 ENDMMSG
012252 L10010:
012252 104423 TRAP C#MSG

2369 .SBTTL MSGEXP - PRINT WRITE CHAR. EXPD-RCV MESSAGE BUFFERS
2370 ;*
2371 ;PRINT ROUTINE TO PRINT WRITE CHARACTERISTIC MESSAGE BUFFER
2372 ;
2373 ;IMPLICIT INPUTS:
2374 ;
2375 ; EXPMSG - EXPECTED MESSAGE BUFFER
2376 ; RECMMSG - RECEIVED MESSAGE BUFFER
2377 ; RCVHIADD- RECEIVED MESSAGE BUFFER HIGH ORDER ADDRESS
2378 ; RCVLOADD- RECEIVED MESSAGE BUFFER LOW ORDER ADDRESS
2379 ;
2380 ;-
2381 012254 BGNMSG MSGEXP
2382 012254 MSGEXP::
2383 012254 012700 000007 MOV #7,R0 ;ASSUME NO EXT FEATURES
2384 012260 005737 002220 TST EXTFEA ;EXT FEATURES SET?
2385 012264 001402 BEQ 5$ ;BR IF NO
2386 012266 012700 000010 MOV #8,R0 ;EXT FEATURE BUFFER IS 8 WORDS
2387 012272 004737 014662 JSR PC,PRMSGEXP ;PRINT EXPD/RCV MESSAGE BUFFERS
2388 012276 ENDMMSG
012276 L10011:
012276 104423 TRAP C#MSG

```



FIFEXP - PRINT FIFO EXP/RECV DATA

```

2390
2391
2392
2393
2394
2395
2396
2397
2398
2399
2400
2401
2402 012300
      012300
2403 012300
      012300 010146
      012302 012746 012352
      012306 012746 000002
      012312 010600
      012314 104415
      012316 062706 000006
2404 012322
      012322 012746 012421
      012326 012746 000001
      012332 010600
      012334 104415
      012336 062706 000004
2405 012342 010100
2406 012344 004737 015232
2407 012350
      012350
      012350 104423
2408 012352 045 116
2409 012421 045 116
2410

```

```

.SBTTL FIFEXP - PRINT FIFO EXP/REC DATA
;
;PRINT ROUTINE TO PRINT FIFO EXP/REC DATA
;
; R1 - BYTE COUNT
;
;IMPLICIT INPUTS:
;
; EXPMSG - EXPECTED MESSAGE BUFFER (CONTAINS FIFO DATA ONLY)
; RECMSG - RECEIVED MESSAGE BUFFER (CONTAINS FIFO DATA ONLY)
;
;--
;BGNMSG FIFEXP
FIFEXP::
PRINTX #FIF1MSG,R1 ;PRINT BYTES TRANSFERRED
MOV R1,-(SP)
MOV #FIF1MSG,-(SP)
MOV #2,-(SP)
MOV SP,R0
TRAP C:PNTX
ADD #6,SP
PRINTX #FIF2MSG ;PRINT HEADER MSG
MOV #FIF2MSG,-(SP)
MOV #1,-(SP)
MOV SP,R0
TRAP C:PNTX
ADD #4,SP
MOV R1,R0 ;GET BYTE COUNT
JSR PC,PRBYTEXP ;PRINT FIFO BYTES IN ERROR
ENDMSG
L10012:
TRAP C:MSG
;FIF1MSG: .ASCIZ '#N#A NUMBER OF BYTES TRANSFERRED = #D2'
;FIF2MSG: .ASCIZ '#N#A FIFO DATA BYTES IN ERROR:'
.EVEN

```

MSGSTAT - PRINT STATUS HEADER AND MESSAGE BUFFERS

```

2412          .SBTTL MSGSTAT - PRINT STATUS HEADER AND MESSAGE BUFFERS
2413          ;*
2414          ;PRINT ROUTINE TO PRINT MESSAGE BUFFER EXPD/RECV
2415          ;
2416          ;
2417          ;
2418          ;IMPLICIT INPUTS:
2419          ;
2420          ;   EXPMSG - EXPECTED MESSAGE BUFFER
2421          ;   RECMSG - RECEIVED MESSAGE BUFFER
2422          ;   RCVHIADD- RECEIVED MESSAGE BUFFER HIGH ORDER ADDRESS
2423          ;   RCVLOADD- RECEIVED MESSAGE BUFFER LOW ORDER ADDRESS
2424          ;-
2425          BGNMSG MSGSTAT
MSGSTAT:
2426          012460 012701 012522
2427          012460 012100
2428          012466 001410
2429          012470
           012470 010046
           012472 012746 000001
           012476 010600
           012500 104415
           012502 062706 000004
2430          012506 000766
2431          012510 012700 000012
2432          012514 004737 014662
2433          012520
           012520 104423
2434          012520 104423
           TRAP C#MSG
2435          012522 012540 012602 012673 STATCOD: .WORD 1#,2#,3#,4#,5#,6#,0
2436          012540 045 116 045 1#:.ASCIZ '##NA Tape Bus Signals in Word #8:'
2437          012602 045 116 045 2#:.ASCIZ '##NA PARERR<15> IEOT <12> IFMK <9> IRDY<6> IRWD<2>'
2438          012673 045 116 045 3#:.ASCIZ '##NA IRESV2<14> IIDENT<11> IHER <8> IONL<5> IFBY<1>'
2439          012764 045 116 045 4#:.ASCIZ '##NA IRESV1<13> ICER <10> ISPEED<7> ILDP<4> IFPT<0>'
2440          013055 045 116 045 5#:.ASCIZ '##NA Tape Bus Signals in Word #9:'
2441          013117 045 116 045 6#:.ASCIZ '##NA DATMIS<7> ILW<6> OUTRDY<5> INRDY<4>'
2442          .EVEN
2443

```



L5

MSGLOOP - PRINT LOOPBACK HEADER AND MESSAGE BUFFERS

```

2445 .SBTTL MSGLOOP - PRINT LOOPBACK HEADER AND MESSAGE BUFFERS
2446 ;*
2447 ;PRINT ROUTINE TO PRINT MESSAGE BUFFER EXPD/RCV
2448 ;
2449 ;IMPLICIT INPUTS:
2450 ;
2451 ; EXPMSG - EXPECTED MESSAGE BUFFER
2452 ; RCMSG - RECEIVED MESSAGE BUFFER
2453 ; RCVHIADD- RECEIVED MESSAGE BUFFER HIGH ORDER ADDRESS
2454 ; RCVLOADD- RECEIVED MESSAGE BUFFER LOW ORDER ADDRESS
2455 ;
2456 ;-
2457 013174 BGNMSG MSGLOOP
013174 MSGLOOP:
2458 013174 012701 013236 10$: MOV #LOOPCOD,R1 ;ASCII ADDRESS TABLE
2459 013200 012100 MOV (R1),R0 ;DONE ALL MSG LINES?
2460 013202 001410 BEQ 20$ ;BR IF YES
2461 013204 PRINTX R0 ;PRINT STATUS BIT NAMES
013204 010046 MOV R0,-(SP)
013206 012746 000001 MOV #1,-(SP)
013212 010600 MOV SP,R0
013214 104415 TRAP C#PNTX
013216 062706 000004 ADD #4,SP
2462 013222 000766 BR 10$ ;DO ANOTHER MSG LINE
2463 013224 012700 000012 20$: MOV #10,R0 ;NUMBER OF WORDS IN A READ STATUS BUFFER
2464 013230 004737 014662 JSR PC,PRMSGEXP ;PRINT EXPD/RCV MESSAGE BUFFERS
2465 013234 ENDMSG
013234 L10014:
013234 104423 TRAP C#MSG
2466
2467 013236 013256 013331 013430 LOOPCOD: .WORD 1$,2$,3$,4$,5$,6$,7$,0
2468 013256 045 116 045 1$: .ASCIZ 'N/A Tape Bus Loopback Signals in Word #8:'
2469 013331 045 116 045 2$: .ASCIZ 'N/A PARERR<15> IRESV2<14>
2470 013430 045 116 045 3$: .ASCIZ 'N/A IHISP=>IEOT<12> IWRT=>IIDENT<11> IREV =>ICER <10>'
2471 013527 045 116 045 4$: .ASCIZ 'N/A IWM =>IFMK<09> IEDIT=>IHER <08> IFAD =>ISPEED<07>'
2472 013626 045 116 045 5$: .ASCIZ 'N/A ITADO=>IRDY<06> ITAD1=>IONL <05> IERASE=>ILDLP <04>'
2473 013725 045 116 045 6$: .ASCIZ 'N/A IREW =>IDBY<03> IRMU =>IRMD <02> IFEN =>IFBY <01>'
2474 014024 045 116 045 7$: .ASCIZ 'N/A IGO =>IFPT<00>'
2475 .EVEN

```

MSGSUB - PRINT WRITE SUBSYSTEM MESSAGE BUFFER

```

2477          .SBTTL MSGSUB - PRINT WRITE SUBSYSTEM MESSAGE BUFFER
2478          ;*
2479          ;PRINT ROUTINE TO PRINT MESSAGE BUFFER EXPD/RCV
2480          ;
2481          ;IMPLICIT INPUTS:
2482          ;
2483          ;   EXPMSG - EXPECTED MESSAGE BUFFER
2484          ;   RECMSG - RECEIVED MESSAGE BUFFER
2485          ;   RCVHIADD- RECEIVED MESSAGE BUFFER HIGH ORDER ADDRESS
2486          ;   RCVLOADD- RECEIVED MESSAGE BUFFER LOW ORDER ADDRESS
2487          ;
2488          ;-
2489          BGNMSG MSGSUB
2490 014052 MSGSUB::
2491 014052 012700 000012   MOV     #10.,R0      ;SIZE OF WRITE SUBSYSTEM BUFFER
2492 014056 004737 014662   JSR    PC,PRMSGEXP  ;PRINT EXPD/RCV MESSAGE BUFFERS
2493 014062   ENDMSG
2494          L10015:
2495          TRAP    C#MSG
2496          ;
2497          .SBTTL MEMADD - PRINT MEMORY ADDRESS DATA ERROR
2498          ;*
2499          ;PRINT ROUTINE TO PRINT MEMORY ADDRESS DATA COMPARE ERROR
2500          ;
2501          ;IMPLICIT INPUTS:
2502          ;
2503          ;   ERRHI  - MEMORY ERROR HIGH ORDER ADDRESS
2504          ;   ERRLO  - MEMORY ERROR LOW ORDER ADDRESS
2505          ;   EXP    - EXPECTED DATA
2506          ;   RECV   - RECEIVED DATA
2507          ;-
2508          BGNMSG MEMADD
2509 014064 MEMADD::
2510 014070 013701 002226   JSR    PC,PRIADD    ;PRINT MEMORY ADDRESS IN ERROR
2511 014074 013702 002230   MOV    EXPD,R1      ;GET EXPD DATA
2512 014100 004737 010022   MOV    RECV,R2      ;GET RECEIVED DATA
2513 014104   JSR    PC,PRIXOR  ;PRINT EXPD/RCV
2514 014104   ENDMSG
2515          L10016:
2516          TRAP    C#MSG

```



PRAMPKT - PRINT RAM AND PACKET DATA

```

2514
2515
2516
2517
2518
2519
2520
2521
2522
2523
2524
2525
2526
2527
2528
2529
2530 014106
2531 014106
2532 014112 012701 002236
2533 014116 005002
2534 014120 122124
2535 014122 001005
2536 014124
2537 014134 000436
2538 014136 116105 177777
2539 014142 116403 177777
2540 014146
2541 014156 042703 177400
2542 014162 116137 177777 002230
2543 014170 116437 177777 002226
2544 014176
    014176 010346
    014200 013746 002226
    014204 013746 002230
    014210 010246
    014212 012746 014266
    014216 012746 000005
    014222 010600
    014224 104414
    014226 062706 000014
2545 014232 005202
2546 014234 005737 002276
2547 014240 001404
2548 014242 020237 002276
2549 014246 003724
2550 014250 000403
2551 014252 020227 000010
2552 014256 002720
2553 014260 005037 002276
2554 014264 000207
2555
2556 014266 045 116 045 RAMASC: .ASCIZ ' #N#A BYTE: #D2#A RAM: #03#A Packet: #03#A XOR:#03'
2557

```

```

.SBTTL PRAMPKT - PRINT RAM AND PACKET DATA
;*
;PRINT ROUTINE TO DISPLAY RAM/PACKET DATA
;WHEN THE RAM DATA DOES NOT MATCH.
;
;INPUTS:
;
; R4 POINTER TO COMMAND PACKET
;IMPLICIT INPUTS:
; RAMDATA DATA AS READ FROM THE RAM
; RAMSIZ NUMBER OF BYTES IN PACKET
; IF RAMSIZ=0 THEN DEFAULT TO 8.
;
;IMPLICIT OUTPUTS:
; RAMSIZ SET TO 0
;-
PRAMPKT:
    SAVREG                                ;SAVE R1-R5 UNTIL NEXT RETURN
    MOV #RAMDATA,R1                       ;DATA FROM THE RAM
    CLR R2                                  ;INIT BYTE NUMBER
5$:   CMPB (R1)+,(R4)+                      ;COMPARE EXPECTED, RECEIVED
    BNE 7$                                  ;BR IF NO MATCH
    FORCERROR 7$,NOTSSR
    BR 10$
7$:   MOVB -1(R1),R5                       ;@8D
    MOVB -1(R4),R3                         ;GET RECV RAM DATA
    XOR R5,R3                              ;GET EXPD PACKET DATA
    BIC #177400,R3                         ;XOR EXPD/RECV
    MOVB -1(R1),RECV                       ;LOW BYTE ONLY
    MOVB -1(R4),EXPD                       ;GET RECEIVED RAM DATA
    PRINTB #RAMASC,R2,RECV,EXPD,R3        ;GET EXPECTED RAM DATA
    MOV R3,-(SP)
    MOV EXPD,-(SP)
    MOV RECV,-(SP)
    MOV R2,-(SP)
    MOV #RAMASC,-(SP)
    MOV #5,-(SP)
    MOV SP,R0
    TRAP C#PNTB
    ADD #14,SP
10$:  INC R2                                ;UPDATE BYTE COUNT
    TST RAMSIZ                             ;DEFAULT TO 8.?
    BEQ 15$                                 ;BR IF YES
    CMP R2,RAMSIZ                          ;DONE ALL BYTES?
    BLE 5$                                  ;BR IF NO
    BR 25$
15$:  CMP R2,#8.
20$:  BLT 5$
25$:  CLR RAMSIZ
    RTS PC
;RETURN

```

PRMESS - PRINT CONTENTS OF MESSAGE BUFFER

```

2559 .SBTTL PRMESS - PRINT CONTENTS OF MESSAGE BUFFER
2560 ;*
2561 ;THIS ROUTINE PRINTS THE CONTENTS OF
2562 ;THE 7 OR 8 WORD MESSAGE BUFFER RETURNED BY THE TSV-05.
2563 ;
2564 ;INPUT:
2565 ; R0 LOW ORDER ADDRESS OF MESSAGE BUFFER
2566 ; R1 HIGH ORDER ADDRESS OF MESSAGE BUFFER
2567 ; NOTE: R1 IS IGNORED IF KTENABLE FLAG IS CLEAR
2568 ;THIS ROUTINE IS NORMALLY CALLED FROM A PRINT ROUTINE
2569 ;-
2570 PRMESS: SAVREG ;SAVE THE REGISTERS
2571 MOV RO,R5 ;SAVE LOW ORDER ADDRESS
2572 TST KTENABLE ;ADDRESS ABOVE 28K?
2573 BNE 10$ ;BR IF YES
2574 CLR R1 ;SET HIGH ORDER ADDRESS TO 0
2575 10$: MOV R1,R3 ;SAVE HIGH ORDER ADDRESS
2576 ROL RO ;SHIFT BIT15 TO C BIT
2577 ROL R1 ;SHIFT TO HIGH ORDER FOR PRINTOUT
2578 PRINTX @PROASC,R1,R5 ;PRINT MESSAGE BUFFER ADDRESS
    MOV R5,-(SP)
    MOV R1,-(SP)
    MOV @PROASC,-(SP)
    MOV @3,-(SP)
    MOV SP,RO
    TRAP C$PNTX
2579 014376 010546
    014400 010146
    014402 012746 014530
    014406 012746 000003
    014412 010600
    014414 104415
    014416 062706 000010
    014422
2579 014422 012746 014575
    014426 012746 000001
    014432 010600
    014434 104415
    014436 062706 000004
2580 014442 005004
2581 014444 010501
2582 014446 010300
2583 014450 001403
2584 014452 004737 017426
2585 014456 010005
2586 014460
2586 014460 012546
    014462 010446
    014464 012746 014633
    014470 012746 000003
    014474 010600
    014476 104415
    014500 062706 000010
2587 014504 005204
2588 014506 020427 000007
2589 014512 003005
2590 014514 002761
2591 014516 032763 000200 000012
2592 014524 001355
2593 014526 000207
2594 014530 045 116 045
2595 014575 045 116 045
2596 014633 045 116 045
    SAVREG
    MOV RO,R5
    TST KTENABLE
    BNE 10$
    CLR R1
    10$: MOV R1,R3
    ROL RO
    ROL R1
    PRINTX @PROASC,R1,R5
    MOV R5,-(SP)
    MOV R1,-(SP)
    MOV @PROASC,-(SP)
    MOV @3,-(SP)
    MOV SP,RO
    TRAP C$PNTX
    ADD #10,SP
    PRINTX @PRIASC ;PRINT HEADER FOR CONTENTS
    MOV @PRIASC,-(SP)
    MOV #1,-(SP)
    MOV SP,RO
    TRAP C$PNTX
    ADD #4,SP
    CLR R4 ;NUMBER OF THE NEXT WORD
    MOV R5,R1 ;COPY LOW ORDER ADDRESS
    MOV R3,RO ;COPY HIGH ORDER ADDRESS
    BEQ 20$ ;BR IF NOT ABOVE 28K
    JSR PC,SETMAP ;SETUP PAR ADDRESS IN RO
    MOV RO,R5 ;GET PAR FORMAT ADDRESS ABOVE 28K
    20$: PRINTX @PRASC,R4,(R5) ;PRINT THE CONTENTS OF MEMORY BUFFER
    MOV (R5),-(SP)
    MOV R4,-(SP)
    MOV @PRASC,-(SP)
    MOV @3,-(SP)
    MOV SP,RO
    TRAP C$PNTX
    ADD #10,SP
    INC R4 ;NUMBER OF THE NEXT
    CMP R4,#7 ;DONE ALL YET ?
    BGT 50$ ;BRANCH IF ALL DONE
    BLT 20$ ;PRINT FIRST 7 WORDS
    BIT @X2.EXTF,XST2(R3);EXTENDED FEATUTES ON ?
    BNE 20$ ;PRINT EXTENDED STATUS WORD
    PC ;RETURN
    50$:
    RTS
    PROASC: .ASCIZ '#N#A Message Buffer Address = #01#05'
    PRIASC: .ASCIZ '#N#A Message Buffer Contents:'
    PRASC: .ASCIZ '#N#A Word#D1#A: #0'

```



C6

PRMESS - PRINT CONTENTS OF MESSAGE BUFFER

```

2598 .EVEN
2599 .SBTTL PRMSGEXP - PRINT EXPD/RCV MESSAGE BUFFERS
2600 ;*
2601 ;ROUTINE TO PRINT EXPECTED AND RECEIVED MESSAGE BUFFERS
2602 ;RO - NUMBER OF WORDS IN BUFFER
2603 ;IMPLICIT INPUTS:
2604 ; EXPMSG - EXPECTED MESSAGE BUFFER
2605 ; RECMMSG - RECEIVED MESSAGE BUFFER
2606 ; RCVHIADD- RECEIVED MESSAGE BUFFER HIGH ORDER ADDRESS
2607 ; RCVLOADD- RECEIVED MESSAGE BUFFER LOW ORDER ADDRESS
2608 ;-
2609 PRMSGEXP::
2610 SAVREG ;SAVE R1-R5 UNTIL NEXT RETURN
2611 MOV RO,R5 ;SAVE NUMBER OF WORDS
2612 MOV RCVLOADD,RO ;GET RECV LOW ADDRESS
2613 MOV RO,R4 ;COPY LOW ADDRESS
2614 MOV RCVHIADD,R1 ;GET RECV HIGH ADDRESS
2615 ROL RO ;SHIFT BIT15 TO C BIT
2616 ROL R1 ;SHIFT TO HIGH ORDER FOR PRINTOUT
2617 PRINTX #PRMSG0,R1,R4 ;PRINT MESSAGE BUFFER ADDRESS
      MOV R4,-(SP)
      MOV R1,-(SP)
      MOV #PRMSG0,-(SP)
      MOV #3,-(SP)
      MOV SP,RO
      TRAP C#PNTX
      ADD #10,SP
2618 PRINTX #PRMSG1 ;PRINT HEADER FOR CONTENTS
      MOV #PRMSG1,-(SP)
      MOV #1,-(SP)
      MOV SP,RO
      TRAP C#PNTX
      ADD #4,SP
2619 CLR R4 ;NUMBER OF THE CURRENT WORD
2620 MOV #EXPMSG,R1 ;GET EXPD BUFFER ADDRESS
2621 MOV #RCMMSG,R2 ;GET RECV BUFFER ADDRESS
20: MOV (R1),R0 ;GET EXPD
      MOV (R2),R3 ;GET RECV
      XOR R0,R3 ;XOR EXPD/RCV
      PRINTX #PRMSG2,R4,(R1)+,(R2)+,R3
      MOV R3,-(SP)
      MOV (R2)+,-(SP)
      MOV (R1)+,-(SP)
      MOV R4,-(SP)
      MOV #PRMSG2,-(SP)
      MOV #5,-(SP)
      MOV SP,RO
      TRAP C#PNTX
      ADD #14,SP
2626 INC R4 ;NUMBER OF THE NEXT
2627 CMP R4,R5 ;DONE ALL YET?
2628 BGE 50: ;BR IF YES
2629 BR 20: ;DO ANOTHER
2630 RTS PC ;RETURN
2631 045 PRMSG0: .ASCIZ '#N#A Message Buffer Address = #01#05'
2632 045 PRMSG1: .ASCIZ '#N#A Message Buffer Contents:'
2633 045 PRMSG2: .ASCIZ '#N#A WORD #D2#A EXPD: #06#A RECV: #06#A XOR: #06'

```

PRMSGEXP - PRINT EXPD/RCV MESSAGE BUFFERS

```

2635 .EVEN
2636 .SBTTL PRBYTEXP - PRINT ERROR BYTES IN EXP/REC MESSAGE BUFFER
2637
2638 ;*
2639 ;ROUTINE TO PRINT ERROR BYTES IN MESSAGE BUFFERS
2640 ; ONLY THE FIRST 8 ERRORS ENCOUNTERED ARE PRINTED DUE TO SCREEN SPACE
2641 ;
2642 ; R0 - NUMBER OF BYTES IN BUFFER
2643 ;
2644 ;IMPLICIT INPUTS:
2645 ;
2646 ; EXPMSG - EXPECTED MESSAGE BUFFER
2647 ; RECMMSG - RECEIVED MESSAGE BUFFER
2648 ;-
2649 PRBYTEXP::
2650 SAVREG ;SAVE R1-R5 UNTIL NEXT RETURN
2651 MOV R0,R5 ;SAVE NUMBER OF BYTES
2652 CLR PRMNO ;INIT ERROR COUNT
2653 CLR R4 ;NUMBER OF THE CURRENT BYTE
2654 MOV @EXPMSG,R1 ;GET EXPD BUFFER ADDRESS
2655 MOV @RCMMSG,R2 ;GET RCV BUFFER ADDRESS
2656 20$: MOVB (R1),R0 ;GET EXPD BYTE
2657 BIC @C<377>,R0 ;CLEAR UPPER BYTE
2658 MOVB R0,PRBEXP ;SAVE FOR ERROR REPORT
2659 MOVB (R2),R3 ;GET RCV BYTE
2660 BIC @C<377>,R3 ;CLEAR UPPER BYTE
2661 MOVB R3,PRBREC ;FOR ERROR REPORT
2662 XOR R0,R3 ;XOR EXPD/RCV
2663 CMPB (R1)-,(R2)- ;EXPD = RCV?
2664 BEQ 30$ ;BR IF YES
2665 INC PRMNO ;UPDATE ERROR COUNT
2666 CMP PRMNO,#8 ;PRINTED 8?
2667 BHI 30$ ;BR IF YES
2668 27$: PRINTX @PRBMSG,R4,PRBEXP,PRBREC,R3
2669 MOV R3,-(SP)
2670 MOV PRBREC,-(SP)
2671 MOV PRBEXP,-(SP)
2672 MOV R4,-(SP)
2673 MOV @PRBMSG,-(SP)
2674 MOV #5,-(SP)
2675 MOV SP,R0
2676 TRAP C:PNTX
2677 ADD #14,SP
2678 FORCEXIT 50$ ;22D
2679 BR 35$ ;22D
2680 30$:
2681 FORCERROR 27$,NOTSSR ;22D
2682 35$:
2683 INC R4 ;NUMBER OF THE NEXT
2684 CMP R4,R5 ;DONE ALL YET?
2685 BGE 50$ ;BR IF YES
2686 BR 20$ ;DO ANOTHER
2687 50$: PRINTX @PRBTOT,PRMNO ;PRINT TOTAL ERROR COUNT
2688 MOV PRMNO,-(SP)
2689 MOV @PRBTOT,-(SP)
2690 MOV #2,-(SP)
2691 MOV SP,R0

```

2649	015232			
2650	015232			
2651	015236	010005		
2652	015240	005037	002314	
2653	015244	005004		
2654	015246	012701	002316	
2655	015252	012702	002462	
2656	015256	111100		
2657	015260	042700	177400	
2658	015264	110037	015600	
2659	015270	111203		
2660	015272	042703	177400	
2661	015276	110337	015602	
2662	015302			
2663	015312	122122		
2664	015314	001431		
2665	015316	005237	002314	
2666	015322	023727	002314	000010
2667	015330	101023		
2668	015332			
	015332	010346		
	015334	013746	015602	
	015340	013746	015600	
	015344	010446		
	015346	012746	015446	
	015352	012746	000005	
	015356	010600		
	015360	104415		
	015362	062706	000014	
2669	015366			
2670	015376	000404		
2671	015400			
2672	015400			
2673	015410			
2674	015410	005204		
2675	015412	020405		
2676	015414	002001		
2677	015416	000717		
2678	015420			
	015420	013746	002314	
	015424	012746	015533	
	015430	012746	000002	
	015434	010600		



E6

PRBYTEXP - PRINT ERROR BYTES IN EXP/REC MESSAGE BUFFER

```

015436 104415 TRAP C#PNTX
015440 062706 000006 ADD #6,SP
2679 015444 000207 RTS PC ;RETURN
2680
2681 015446 045 116 045 PRBMSG: .ASCIZ '#N#A BYTE #D2#A EXPD: #03#A RECV: #03#A XOR: #03#A'
2682 015533 045 116 045 PRBTOT: .ASCIZ '#N#A NUMBER OF BYTES IN ERROR = #D2#A'
2683 .EVEN
2684 015600 000000 PRBEXP: .WORD 0 ;EXPD
2685 015602 000000 PRBREC: .WORD 0 ;RECV
2686 .SBTTL EXPREC - PRINT EXPD/RECV WORD DATA
2687 ;*
2688 ;
2689 ;PRINT ROUTINE TO DISPLAY EXPD/RECV DATA
2690 ;
2691 ;INPUTS:
2692 ;
2693 ; R1 RECEIVED DATA
2694 ; R2 EXPECTED DATA
2695 ;
2696 ;-
2697
2698 015604 BGNMSG EXPREC
015604
2699 015604 004737 010022 EXPREC:: JSR PC,PRIXOR ;PRINT THE DATA
2700 015610 ENDMSG
015610
2701 015610 104423 L10017: TRAP C#MSG
015610 .SBTTL EXPBREC - PRINT EXPD/RECV BYTE DATA
2702 ;*
2703 ;
2704 ;PRINT ROUTINE TO DISPLAY BYTE EXPD/RECV DATA
2705 ;
2706 ;INPUTS:
2707 ;
2708 ; R1 RECEIVED DATA BYTE
2709 ; R2 EXPECTED DATA BYTE
2710 ;
2711 ;-
2712
2713
2714 015612 BGNMSG EXPBREC
015612
2715 015612 004737 007672 EXPBREC:: JSR PC,PRIBXOR ;PRINT THE DATA
2716 015616 ENDMSG
015616
2717 015616 104423 L10020: TRAP C#MSG
2718 .SBTTL RAMERR - PRINT RAM AND PACKET DATA
2719 ;*
2720 ;
2721 ;PRINT ROUTINE TO DISPLAY RAM/PACKET DATA
2722 ;
2723 ;INPUTS:
2724 ;
2725 ; R4 POINTER TO COMMAND PACKET
2726 ;
2727 ;

```

F6

RAMERR - PRINT RAM AND PACKET DATA

2728  
 2729  
 2730  
 2731  
 2732  
 2733  
 2734  
 2735  
 2736  
 2737  
 2738  
 2739 015620  
 015620  
 2740 015620 004737 014106  
 2741 015624  
 015624  
 015624 104423

2742  
 2743  
 2744  
 2745  
 2746  
 2747  
 2748  
 2749  
 2750  
 2751  
 2752  
 2753  
 2754  
 2755  
 2756  
 2757  
 2758  
 2759  
 2760  
 2761  
 2762  
 2763  
 2764  
 2765 015626  
 015626  
 2766 015626 004737 010354  
 2767 015632 004737 014106  
 2768 015636  
 015636  
 015636 104423

2769  
 2770  
 2771  
 2772  
 2773  
 2774  
 2775  
 2776  
 2777  
 2778

```

;IMPLICIT INPUTS:
;
;   RAMDATA      DATA AS READ FROM THE RAM
;   RAMSIZ       NUMBER OF BYTES IN PACKET
;               IF RAMSIZ=0 THEN DEFAULT TO 8.
;
;IMPLICIT OUTPUTS:
;
;   RAMSIZ SET TO 0
;
;
;BGNMSG RAMERR
RAMERR:: JSR   PC,PRAMPKT      ;PRINT RAM/PACKET DATA
         ENDMSG
L10021: TRAP  C#MSG
        .SBTTL RAMTADD - PRINT TEST ADDRESS, RAM AND PACKET DATA
;
;PRINT ROUTINE TO DISPLAY RAM/PACKET DATA
;
;INPUTS:
;
;   R4          POINTER TO COMMAND PACKET
;
;IMPLICIT INPUTS:
;
;   RAMDATA      DATA AS READ FROM THE RAM
;   RAMSIZ       NUMBER OF BYTES IN PACKET
;               IF RAMSIZ=0 THEN DEFAULT TO 8.
;   ERRHI        HIGH ORDER TEST ADDRESS
;   ERRLO        LOW ORDER TEST ADDRESS
;
;IMPLICIT OUTPUTS:
;
;   RAMSIZ SET TO 0
;
;
;BGNMSG RAMTADD
RAMTADD:: JSR   PC,PRITADD     ;PRINT TEST ADDRESS
         JSR   PC,PRAMPKT     ;PRINT RAM/PACKET DATA
         ENDMSG
L10022: TRAP  C#MSG
        .SBTTL RAMEXP - PRINT RAM EXPD/RECV DATA
;
;PRINT ROUTINE TO DISPLAY EXPD/RECV DATA
;
;INPUTS:
;
;   R1          RECEIVED DATA
;   R2          EXPECTED DATA

```



G6

## RAMEXP - PRINT RAM EXPD/RECV DATA

```

2779      ;      R4      CONTROLLER RAM ADDRESS
2780      ; -
2781
2782 015640      BGNMSG  RAMEXP
      015640
2783 015640 042701 177400      RAMEXP::
2784 015644 042702 177400      BIC      #C<377>,R1      ;SAVE EXPD RAM DATA BYTE
2785 015650 004737 010146      BIC      #C<377>,R2      ;SAVE EXPD RAM DATA BYTE
2786 015654 004737 010022      JSR      PC,PRIRAM      ;PRINT THE RAM ADDRESS
2787 015660      JSR      PC,PRIXOR      ;PRINT THE DATA
      015660      ENDMSG
      015660 104423
2788
2789      ;
2790      ;
2791      ;PRINT ROUTINE TO DISPLAY EXPD/RECV DATA
2792      ;AND TIMER A,B HEADER MESSAGE
2793      ;
2794      ;
2795      ;INPUTS:
2796      ;
2797      ;      R1      RECEIVED DATA
2798      ;      R2      EXPECTED DATA
2799      ; -
2800
2801 015662      BGNMSG  TIMEXP
      015662
2802 015662      TIMEXP::
      015662 012746 015710      PRINTX  #TIMSGO      ;PRINT HEADER
      015666 012746 000001      MOV      #TIMSGO,-(SP)
      015672 010600      MOV      #1,-(SP)
      015674 104415      MOV      SP,R0
      015676 062706 000004      TRAP    C#PNTX
2803 015702 004737 010022      ADD      #4,SP
2804 015706      JSR      PC,PRIXOR      ;PRINT THE DATA
      015706      ENDMSG
      015706 104423
2805
2806 015710      045      116      045 TIMSGO: .ASCIZ 'N#A TIMER A STATUS IS IN BIT 3#N#A TIMER B STATUS IS IN BIT 2'
2807      .EVEN
2808      ;
2809      ;
2810      ;PRINT ROUTINE FOR TSSR ERRORS ON DATA TRANSFERS
2811      ;
2812      ;
2813      ;INPUTS:
2814      ;
2815      ;
2816      ;      R1      CONTENTS OF TSSR
2817      ;      R2      DATA WRITTEN (8 BITS)
2818      ;
2819      ; -
2820
2821 016010      BGNMSG  BADSSR
      016010
2822 016010 010246      BADSSR::
2823 016012 042702 177400      MOV      R2,-(SP)      ;SAVE DATA TRANSFERRED
      BIC      #177400,R2      ;GET JUST ONE BYTE

```

H6

BADSSR - PRINT TSSR ERRORS ON DATA TRANSFERS

```

2824 016016          PRINTB  #XFERASC,R2
      016016 010246      MOV      R2,-(SP)
      016020 012746 016050  MOV      #XFERASC,-(SP)
      016024 012746 000002  MOV      #2,-(SP)
      016030 010600      MOV      SP,R0
      016032 104414      TRAP     C#PNTB
      016034 062706 000006  ADD      #6,SP
2825 016040 012602      MOV      (SP)+,R2          ;RESTORE R2
2826 016042 004737 006022  JSR      PC,PRITSSR      ;DECODE TSSR CONTENTS
2827 016046          ENDMSG
      016046          L10025:
      016046 104423      TRAP     C#MSG
2828 016050 045 116 045 XFERASC: .ASCIZ  '#N#A Data Transferred = #03'

```



GLOBAL SUBROUTINES SECTION

```

2830 .SBTTL GLOBAL SUBROUTINES SECTION
2831
2832
2833 ;**
2834 ; THE GLOBAL SUBROUTINES SECTION CONTAINS THE SUBROUTINES
2835 ; THAT ARE USED IN MORE THAN ONE TEST.
2836 ;--
2837 .SBTTL SOFINIT - SOFT INITIALIZE OF CONTROLLER
2838
2839 ;*
2840 ; ROUTINE TO DO A SOFT INITIALIZE OF THE CONTROLLER
2841 ; BY WRITING INTO THE TSSR REGISTER. AFTER THE INIT,
2842 ; THE TSSR REGISTER IS TESTED FOR ERRORS. ANY ERRORS
2843 ; DETECTED SHOULD BE TREATED AS DEVICE FATAL ERRORS.
2844
2845 ; INPUTS:
2846 ;
2847 ; R5 ADDRESS OF FIRST REGISTER
2848
2849 ; OUTPUTS:
2850 ;
2851 ; R0 CONTENTS OF TSSR, IF ERROR
2852 ; CARRY SET IF INIT WAS OKAY
2853 ; CLEAR IF FATAL ERROR
2854
2855 ; CALLING SEQUENCE:
2856 ;
2857 ; MOV @ADDRESS,R5
2858 ; JSR PC,SOFINIT
2859 ; BCS CONTINUE
2860 ; ERRDF ;REPORT FATAL ERROR
2861 ;
2862 ;-
2863
2864 016104 SOFINIT:: SAVREG ; SAVE THE REGISTERS
2865 016104 MOV #0,TSSR(R5) ; DO THE INIT.
2866 016110 JSR PC,WAITF ; WAIT FOR SSR
2867 016116 012765 000000 000002 MOV TSSR(R5),R0 ; GET THE TSSR REGISTER
2868 016122 004737 016360 MOV R0,R4 ; TSSR CONTENTS
2869 016126 016500 000002 BIC #1<HIADDR:OFL>,R4
2870 016130 042704 176277 BIC #SSR!NBA,R4 ; R4 HAS EXPECTED CONTENTS
2871 016134 052704 002200 BIC #SSR!NBA,R4 ; ONLY EXPECTED BITS SET ?
2872 016140 020400 CMP R4,R0 ; BRANCH IF OKAY
2873 016142 001402 BEQ 5$ ; CLEAR THE CARRY FOR ERROR
2874 016144 000241 CLC ; GO TO EXIT
2875 016146 000401 BR 10$ ; SET THE CARRY BIT
2876 016150 000261 5$: SEC ; RETURN TO CALLER
2877 016152 000207 10$: RTS PC

```

CHKAMB - CHECK TSSR FOR AMBIGUITY

```

2879      .SBTTL  CHKAMB - CHECK TSSR FOR AMBIGUITY
2880
2881      ;*
2882      ;
2883      ;THIS ROUTINE TESTS THE CONTENTS OF THE TSSR REGISTER
2884      ;FOR AMBIGUITY
2885      ;
2886      ;INPUT:
2887      ;
2888      ;      RO      CONTENTS OF TSSR
2889      ;
2890      ;OUTPUT:
2891      ;
2892      ;      RO      CONTENTS OF TSSR
2893      ;
2894      ;      CARRY   SET - NO AMBIGUITY
2895      ;              CLR - AMBIGUOUS CONTENTS
2896      ;
2897      ;-
2898
2899      CHKAMB:
2900      SAVREG      ;SAVE THE GENERAL REGISTERS
2901      MOV        RO,R4      ;CONTENTS OF TSSR
2902      BIT        @SC,RO     ;IS BIT 15 SET ?
2903      BNE        5$        ;BRANCH IF YES
2904      BIT        @1C<NBA!OFL!SSR!HIADDR>,RO ;ANY OTHER BITS SET ?
2905      BNE        40$      ;MUST BE AN ERROR
2906      BR         45$      ;RETURN WITH SUCCESS
2907      5$:      BIT        @SSR,RO ;IS READY BIT SET ?
2908      BNE        10$      ;BRANCH IF READY BIT IS SET.
2909      BIT        @BITS,RO  ;IS FATAL ERROR BIT SET ?
2910      BEQ        40$      ;ERROR IF NOT
2911      BIC        @1CTERCLS,R4 ;CLEAR ALL BUT TERMINATION CODE
2912      CMP        R4,#16   ;ALL THREE BITS MUST BE SET
2913      BNE        40$      ;ERROR IF NOT SET
2914      BR         45$      ;OK IF ALL ARE SET
2915      10$:     BIT        @BITS,RO ;IS FATAL ERROR BIT SET ?
2916      BEQ        45$      ;ERROR IF BIT IS SET WITH SSR
2917      BIT        @BIT2!BIT1,RO ;IS THIS A FUNCTION REJECT
2918      BNE        45$      ;BR, IF TSSR IS OK
2919      40$:     CLC          ;AMBIGUOUS CONTENTS
2920      BR         50$
2921      45$:     SEC          ;SHOW SUCCESS - NO AMBIGUITY
2922      50$:     RTS        PC ;RETURN TO CALLER

```



## ENAIN,DSBINT - ENABLE/DISABLE INTERRUPTS

```

2924 .SBTTL ENAIN,DSBINT - ENABLE/DISABLE INTERRUPTS
2925 ;
2926 ; DEFAULT DISPLAY INTERRUPT HANDLERS.
2927 ; IF DISPLAY TIME-OUT, REPORT DEV FATAL, AND ABORT PASS.
2928 ; OTHERWISE, SAVE DPU REGISTERS AND DISMISS.
2929 ;
2930 ;
2931 ; BIT DEFINITIONS FOR "INTMASK" AND "INTFLAG" BYTES:
2932 ;
2933 ; IOKCKIN=BIT7 ; DON'T CHECK FOR BAD INTERRUPTS -- TEST WILL.
2934 ; IOKSTP=BIT0 ; EXPECT "STOP" INTERRUPT.
2935 ;
2936 ; INTERRUPT MASK -- SAYS EXPECTING INTERRUPTS
2937 016254 000 INTMASK: .BYTE 0
2938 ; INTERRUPT FLAG -- SAYS WE GOT ONE (IF POSITIVE)
2939 016255 000 INTFLAG: .BYTE 0
2940 ;
2941 ; SAVED INTERRUPT VECTOR:
2942 016256 000000 INTVEC: .WORD 0
2943 ; SAVE CPU PC
2944 016260 000000 INTCPC: .WORD 0
2945 ;
2946 ; SUBROUTINE TO ENABLE INTERRUPTS:
2947 016262 010046 ENAIN: MOV RO,-(SP) ;SAVE RO
2948 016264 013700 002202 MOV IVEC,RO ;GET POINTER TO VECTORS
2949 016270 012720 016326 MOV @INTR,(RO) ;SET UP INTERRUPT VECTOR
2950 016274 012720 000340 MOV @PRI07,(RO)
2951 016300 012600 MOV (SP)+,RO ;RESTORE RO
2952 016302 011646 MOV (SP),-(SP)
2953 016304 012766 000000 000002 MOV @0,2(SP) ;SET CPU TO LEVEL 0
2954 016312 000002 RTI
2955 ;
2956 ; SUBROUTINE TO DISABLE INTERRUPTS (RAISE PRIORITY TO LEVEL 7)
2957 016314 011646 DSBINT: MOV (SP),-(SP)
2958 016316 012766 000340 000002 MOV @PRI07,2(SP)
2959 016324 000002 RTI
2960 ;
2961 .SBTTL INTR - INTERRUPT HANDLERS
2962 016326 BGNSRV INTR ;DEFINE INTERRUPT ENTRY
2963 016326 012737 000001 002216 INTR:: MOV @1,INTRECV ;SET FLAG TO SHOW INTERRUPT RECEIVED
2964 016334 105037 016255 CLRB INTFLAG ;CLEAR FLAG TO SAY WE GOT INTERRUPT
2965 016340 132737 000001 016254 BITB @IOKSTP,INTMASK ;EXPECTING STOP INTERRUPT?
2966 016346 001003 BNE 1$ ;BR IF YES
2967 016350 152737 000001 016255 BISB @IOKSTP,INTFLAG ;NO. SET THE ERROR FLAG.
2968 ;
2969 ; SAVE REGISTERS, MSG BUFFER, ETC.
2970 016356 1$: ENDSRV
2971 016356 L10026: RTI
016356 000002

```

WAITF - WAIT FOR SUBSYSTEM READY

```

2973          .SBTTL WAITF - WAIT FOR SUBSYSTEM READY
2974          ;
2975          ; SUBROUTINE TO WAIT FOR THE SUBSYSTEM READY FLAG
2976          ;
2977          ; INPUTS:
2978          ;
2979          ; R5 ADDRESS OF FIRST DEVICE REGISTER
2980          ;
2981          ; OUTPUTS:
2982          ;
2983          ; R0 CONTENTS OF LAST TSSR READ
2984          ; CARRY SET - READY BIT SET
2985          ; CLR - TIMEOUT WAITING FOR READY
2986          ;
2987 016360 000401 WAITF:: BR 1# ;NOP WHEN SUPER FIXED
2988 016362 104422 BREAK ; DO A SUPVSR BREAK FIRST.
          016362 104422 TRAP C#BRK
2989 016364 012746 011000 1#: MOV #11000,-(SP) ;25-APRIL-83 REV B - 1100 MSEC TIMER
2990 016370 016500 000002 2#: MOV TSSR(R5),R0 ;READ THE TSSR REGISTER
2991 016374 105700 TSTB R0 ;TEST FOR READY BIT SET
2992
2993 016376 100420 BMI 3# ; EXIT ON STOP FLAG.
2994 016400 DELAY 1 ; WAIT 100 USEC
          016400 012727 000001 MOV #1,(PC)-
          016404 000000 .WORD 0
          016406 013727 002116 MOV L#DLY,(PC)-
          016412 000000 .WORD 0
          016414 005367 177772 DEC -6(PC)
          016420 001375 BNE --4
          016422 005367 177756 DEC -22(PC)
          016426 001367 BNE --20
2995 016430 005316 DEC (SP) ;REDUCE DELAY COUNT
2996 016432 001356 BNE 2# ;RETRY UNTIL TIMER EXPIRES
2997 016434 000241 CLC ; C = 0, CONTROLLER STILL RUNNING...
2998 016436 000401 BR 4# ;...OR HUNG-UP AFTER 300 MSEC.
2999 016440 000261 3#: SEC ; C = 1, CONTROLLER IS STOPPED.
3000 016442 005326 4#: DEC (SP)- ;RESTORE STACK WITHOUT CHANGING CARRY BIT
3001 016444 000207 RTS PC

```



CHKTSSR - CHECK TSSR FOR READY

```

3003      .SBTTL  CHKTSSR - CHECK TSSR FOR READY
3004      ;*
3005      ;THIS ROUTINE WAITS FOR READY IN THE TSSR
3006      ;AND TESTS FOR AMBIGUOUS BIT SETTINGS IN TSSR.
3007      ;
3008      ;INPUT:
3009      ;      R5      ADDRESS OF CSR REGISTERS
3010      ;
3011      ;OUTPUT:
3012      ;      R0      CONTENTS OF TSSR
3013      ;      CARRY   SET - OKAY
3014      ;              CLR - NOT READY AMBIGUOUS, OR SC SET
3015      ;-
3016      CHKTSSR:
3017      JSR      PC, WAITF      ;WAIT FOR READY
3018      BCC      20$           ;BRANCH IF TIME OUT
3019      JSR      PC, CHKAMB     ;TSSR AMBIGUOUS?
3020      BCC      10$           ;BR IF YES
3021      BIT      #SC,R0        ;SPECIAL CONDITION SET?
3022      BEQ      15$           ;BR IF NO
3023      BIT      #<SCE!BIE!RMR!NXM>,R0 ;ANY ERROR BITS SET?
3024      BEQ      15$           ;BR IF NO
3025      10$:    CLC              ;SET FAILURE
3026      BR       20$           ;
3027      15$:    SEC              ;SET SUCCESS
3028      20$:    RTS      PC      ;RETURN TO CALLER
3029      .SBTTL  XNXM - CHECK FOR NONEXISTENT MEMORY
3030      ;*
3031      ; ROUTINE TO TEST FOR A NEXM IN THE RANGE (R1) THRU (R2).
3032      ; ON RETURN, IF "C" = 1, (R1) = NEXM ADDRESS.
3033      ;              "C" = 0, ALL ADDRESSES OK.
3034      ;
3035      ;CALL:  MOV  ADR1,R1
3036      ;        MOV  ADR2,R2
3037      ;        JSR  PC,NXM
3038      ;        RETURN      ;TEST "C" AND PROCEED.
3039      XNXM:  MOV   #2$,@#4     ; SET BUSERR VECTOR.
3040      MOV   #PRI04,@#6
3041      CLR   R3
3042      1$:   TST   (R1)        ;FLAG.
3043      ;      TEST THE ADDRESS(ES).
3044      ;      IF ANY TRAP, CONTINUE AT 2$.
3045      ;      OTHERWISE, CONTINUE HERE.
3046      CMP   R1,R2            ;BR IF FINISHED (NO NEXM'S).
3047      BEQ   3$              ;SET NEXT ADDRESS...
3048      ADD   #2,R1           ;...AND CONTINUE.
3049      BR    1$              ;GOT ONE, SET FLAG...
3050      2$:   COM   R3
3051      MOV   #3$, (SP)       ;...AND DISMISS INTERRUPT...
3052      RTI
3053      CLRVEC #4             ;...AND GIVE BACK THE VECTOR.
3054      MOV   #4,R0
3055      TRAP  C#CVEC
3056      TST   R3
3057      BEQ   .+4
3058      SEC
3059      RTS   PC
3060      ;DID WE CATCH ONE ??
3061      ;NO, "C" = 0, SKIP NEXT.
3062      ;YES, "C" = 1, (R1) = NEXM ADDR.

```

TSTLOOP - CHECK ITERATION COUNT

```

3057
3058
3059
3060
3061
3062
3063
3064
3065 016566
3066 016566 005737 002162
3067 016572 001006
3068 016574 005737 002176
3069 016600 100403
3070 016602 005337 002210
3071 016606 001002
3072 016610 000241
3073 016612 000401
3074 016614 000261
3075 016616 000207
3076
3077
3078
3079
3080
3081
3082
3083
3084
3085
3086
3087
3088
3089
3090
3091
3092
3093
3094
3095
3096
3097
3098
3099
3100
3101
3102
3103 016620
3104 016620 010046
3105 016622 005037 003150
3106 016626 005037 017066
3107 016632 005037 005770
3108 016636 105037 016254
3109 016642 013700 002174
3110 016646 006300
3111 016650 005737 003110
3112 016654 001430
3113 016656 100010
    
```

```

.SBTTL TSTLOOP - CHECK ITERATION COUNT
;*
; SUBROUTINE TO EXECUTE TEST ITERATIONS.
; EXIT WITH "C" SET IF LOOPS ALLOWED AND LOOP COUNT NON-ZERO.
; LOOP COUNTER IS SET BY "BEGIN.TEST" MACRO.
;
; CALL: LOOPTO ARG
;
TSTLOOP::
    TST     NOITS      ; ITERATIONS INHIBITED?
    BNE     1$         ; YES.
    TST     QVP        ; NO.
    BMI     1$         ; LOOPS DISALLOWED IN QUICK PASS.
    DEC     LOOPCNT    ; BUMP LOOP COUNTER.
    BNE     2$
1$:      CLC          ; LOOP DISALLOWED, OR DONE.
    BR     3$
2$:      SEC          ; LOOP ENABLED.
3$:      RTS         PC

.SBTTL TSTSETUP - PRINT TEST NAME AND INIT ERROR COUNTS
;*
; PRINT THE NUMBER AND NAME OF EACH TEST AS WE GO ALONG.
; INCREMENT "TESTK" TO INDICATE THE NUMBER OF TESTS
; IN THE CURRENT RUN SEQUENCE.
; CLEAR THE ERROR COUNTER AND SIGNATURE EXTENSION FLAGS.
;
; INPUT:
;
;     R0     POINTER TO TEST ID ASCIZ STRING
;
; OUTPUT:
;
;     R5     ADDRESS OF FIRST DEVICE REGISTER
;
; IMPLICIT OUTPUTS:
;
;     TSTCNT UPDATED TO COUNT TESTS PERFORMED SINCE START OR RESTART
;
; SIDE EFFECTS:
;
;     INTERRUPT LEVEL IS RASIED TO LEVEL OF
;     THE DEVICE UNDER TEST
;
; -
TSTSETUP::
    MOV     R0, -(SP) ; SAVE THE TEST ID MESSAGE
    CLR     SIFLAG    ; CLEAR "SOFT INIT" FLAG
    CLR     ERRK      ; CLEAR LOCAL ERROR COUNTER.
    CLR     EXTA      ; CLEAR ERROR EXTENSION FLAG.
    CLR     INTMASK   ; CLEAR INTERRUPT MASK (CHECK ERROR)
    MOV     UNITN, R0 ; GET THE UNIT NUMBER.
    ASL     R0        ; ... AND MAKE IT A WORD OFFSET.
    TST     NDEV     ; DID STARTUP FIND THE DEVICE?
    BEQ     4$       ; BR IF YES
    BPL     3$       ; BR IF NOT IDLE
    
```



B7

TSTSETUP - PRINT TEST NAME AND INIT ERROR COUNTS

```

3114 016660 052760 160000 003172      BIS      #160000,ERTABL(R0) ; FLAG ERROR IN THE ERROR TABLE
3115 016666      104455      ERRDF    1,NXR,NXRERR      ; NO DEVICE HERE -- PRINT IT
      016670 000001      TRAP     C#ERDF
      016672 003736      .WORD   1
      016674 005734      .WORD   NXR
3116 016676 000407      .WORD   NXRERR
3117 016700 052760 160001 003172 3$:    BR       2$
3118 016706      104455      BIS      #160001,ERTABL(R0) ; FLAG ERROR IN THE ERROR TABLE
      016710 000002      ERRDF    2,NOINIT      ; DEVICE NOT IDLE
      016712 004333      TRAP     C#ERDF
      016714 000000      .WORD   2
3119 016716 012737 177777 003106 2$:    .WORD   NOINIT
3120 016724      013700 002174      MOV     #-1,DUFLG      ; DROP THE UNIT
      016730 104451      DODU     UNITN
      016732 104444      MOV     UNITN,R0
3121 016732 000423      TRAP     C#DODU
      016734 000423      DOCLN
3122 016734      000423      TRAP     C#DCLN      ; ABORT THE PASS
3123
3124 016736      104421      BR       5$
3125 016740 032700 001000      RFLAGS  RO      ; GET THE OPERATOR FLAGS.
3126 016744 001412      TRAP     C#RFLA
3127 016746 011600      BIT     #PNT,R0      ; PRINT THE TEST NUMBERS?
3128 016750      010046      BEQ     1$          ; BR IF NO
      016752 012746 017014      MOV     (SP),R0      ;GET THE ID MESSAGE
      016754 012746 000002      PRINTF  #TNAM,R0      ;DISPLAY THE TEST ID
      016762 010600      MOV     RO,-(SP)
      016764 104417      MOV     #TNAM,-(SP)
      016766 062706 000006      MOV     #2,-(SP)
3129 016772 005237 002206      MOV     SP,R0
3130 016776 013700 002204      TRAP     C#PNTF
      017002 104441      ADD     #6,SP
      017004 005726      INC     TSTCNT      ; BUMP TEST COUNTER.
3131 017006 013705 002200      SETPRI  IPRI      ;PRIORITY THAT OF DEVICE
3132 017012 000207      MOV     IPRI,R0
3133 017014      045      TRAP     C#SPRI
3134 017014      045      TST     (SP)      ;FIX UP THE STACK
3135      045      MOV     CSRADDR,R5 ; ADDRESS OF TSV REGISTERS ON UNIBUS
3136      045      RTS     PC
3137      045      .ASCIZ  '#S#T#A Test'
3138      045      .EVEN
3139      045      .SBTTL  TSTEND - PRINT ERRORS RECEIVED
3140
3141      045      ; AT END OF EACH TEST, PRINT THE NUMBER OF ERRORS RECEIVED
3142      045      ; IF NORMAL ERROR REPORTING IS DISABLED (FLA:IER).
3143      045      ;
3144      045      TSTEND: RFLAGS RO
      017030 104421      TRAP     C#RFLA
      017032 030027 020000      BIT     RO,#IER
      017036 001412      BEQ     1$          ; BR IF "IER" NOT SET.
      017040      013746 017066      PRINTF  #ESUM,ERRK      ; PRINT ERROR COUNT.
      017044 012746 017070      MOV     ERRK,-(SP)
      017050 012746 000002      MOV     #ESUM,-(SP)
      017054 010600      MOV     #2,-(SP)
      017056 104417      MOV     SP,R0
      TRAP     C#PNTF

```





D7

INCERK - INCREMENT LOCAL ERROR COUNT

```

3152                                     .SBTTL  INCERK - INCREMENT LOCAL ERROR COUNT
3153                                     ;*
3154                                     ; ROUTINES TO INCREMENT LOCAL ERROR COUNT AND CHECK FOR LIMIT:
3155                                     ;
3156 017154 005237 017066 INCERK: INC  ERRK          ; INCREMENT LOCAL ERROR COUNT
3157 017160 010046      MOV  RO,-(SP)      ; SAVE RO
3158 017162 013700 002174      MOV  UNITN,RO     ; GET UNIT NUMBER,
3159 017166 006300      ASL  RO              ; ... AND MAKE IT A WORD OFFSET.
3160 017170 062700 003172      ADD  @ERTABL,RO   ; RO GETS ADDRESS OF ERROR TABLE ENTRY.
3161 017174 005210      INC  (RO)           ; INCREMENT THE DEVICE ERROR COUNT
3162 017176 032710 007777      BIT  @7777,(RO)   ; DID WE OVERFLOW THE FIELD?
3163 017202 001001      BNE  1$              ; BR IF NO.
3164 017204 005310      DEC  (RO)           ; YES -- BACK IT UP TO 7777.
3165 017206 012600      1$: MOV  (SP)+,RO     ; RESTORE RO
3166 017210 000207      RTS   PC              ; RETURN TO CALLER.
3167
3168 017212 010046      CKEMAX: MOV  RO,-(SP)      ; SAVE RO
3169 017214 013700 002174      MOV  UNITN,RO     ; GET UNIT NUMBER
3170 017220 006300      ASL  RO              ; ... AND MAKE IT A WORD OFFSET
3171 017222 016000 003172      MOV  ERTABL(RO),RO ; GET ERROR TABLE ENTRY
3172 017226 042700 170000      BIC  @170000,RO   ; EXTRACT ERROR COUNT FIELD
3173 017232 020037 002166      CMP  RO,GERRMAX  ; IS GLOBAL LIMIT EXCEEDED FOR THIS UNIT?
3174 017236 103004      BHIS 1$              ; BR IF YES
3175 017240 023737 017066 002164      CMP  ERRK,LERRMAX ; IS LOCAL LIMIT EXCEEDED FOR THIS TEST?
3176 017246 103417      BLO  2$              ; BR IF NO
3177 017250      1$: RFLAGS RO          ; GET OPERATOR FLAGS
3178 017252 032700 000040      TRAP C#RFLA
3179 017256 001013      BIT  @IDU,RO     ; IS DROPPING INHIBITED?
3180 017260 012737 177777 003106      BNE  2$              ; BR IF YES.
3181 017266      MOV  @-1,DUFLG   ; NO -- DROP THE UNIT
3181 017266 104455      ERRDF 4,EMAXDU
3181 017270 000004      TRAP C#ERDF
3181 017272 017107      .WORD 4
3181 017274 000000      .WORD EMAXDU
3182 017276      .WORD 0
3182 017276 013700 002174      DODU UNITN
3182 017302 104451      MOV  UNITN,RO
3182 017304      TRAP C#DODU
3183 017304      DOCLN
3183 017304 104444      TRAP C#DCLN
3184 017306 012600      2$: MOV  (SP)+,RO     ; RESTORE RO
3185 017310 000207      RTS   PC              ; RETURN TO CALLER

```

E7

CKDROP - CHECK IF UNIT SHOULD BE DROPPED

```

3187          .SBTTL CKDROP - CHECK IF UNIT SHOULD BE DROPPED
3188
3189          ; CHECK IF UNIT SHOULD BE DROPPED
3190          ;
3191 017312 010046          CKDROP: MOV     RO, -(SP)
3192 017314          FORCERROR 1$,NOTSSR
3193 017324          RFLAGS    RO
3194 017324 104421          TRAP     C#RFLA
3195 017326 032700 000040          BIT     @IDU,RO
3196 017332 001010          BNE     1$
3197 017334 011600          MOV     (SP),RO
3198 017336 012737 177777 003106          MOV     #-1,DUFLG
3199 017344          DODU     UNITN
3200 017344 013700 002174          MOV     UNITN,RO
3201 017350 104451          TRAP     C#DODU
3202          ;ABORT THE PASS
3203          TRAP     C#DCLN
3204          1$: MOV     (SP)-,RO
3205          RTS     PC
3206
3207          .SBTTL CONFIG - DETERMINE CONFIGURATION OF SYSTEM
3208          ;
3209          ; SUBROUTINE - DETERMINE CONFIGURATION OF TSV05 SYSTEM.
3210          ;
3211          ; CONFIG:
3212          JSR     PC,SOFINIT
3213          RTS     PC
3214          .SBTTL KTON,KTOFF - ENABLE/DISABLE MEMORY MANAGEMENT
3215          ;
3216          ; SUBROUTINE - ENABLE MEM MGT.
3217          ;
3218          ; KTON: TST     KTFLG          ; GOT KT?
3219          BEQ     1$                  ; NO.
3220          MOV     @1,SRO              ; YES. ENABLE KT11.
3221          1$: RTS     PC
3222          ;
3223          ; SUBROUTINE - DISABLE MEM MGT.
3224          ;
3225          ; KTOFF: TST     KTFLG          ; GOT KT11?
3226          BEQ     1$                  ; NO.
3227          NOP
3228          MOV     @0,SRO              ; DISABLE KT.
3229          1$: RTS     PC

```



SETMAP - SETUP PAR6 MAPPING

```

3230 .SBTTL SETMAP - SETUP PAR6 MAPPING
3231
3232
3233
3234 ; THIS ROUTINE SETS UP KERNEL PAR6 TP HANDLE
3235 ; AN 18 BIT ADDRESS. THE OFFSET INTO THE PAGE
3236 ; IS RETURNED BIASED TO PAR6.
3237
3238 ; INPUTS:
3239
3240 ; R0 HIGH ORDER ADDRESS BITS
3241 ; R1 LOW ORDER ADDRESS BITS
3242
3243 ; OUTPUTS:
3244
3245 ; R0 OFFSET INTO BLOCK WITH PAR6 BIAS (I.E. THE ADDRESS)
3246 ; CARRY SET IF SUCCESS
3247 ; CLR IF ERROR
3248
3249 ; SETMAP:
3250 ; SAVREG
3251 ; TST KTFLG ; SAVE R1-R4 UNTIL NEXT RETURN
3252 ; BEQ 104 ; SYSTEM HAVE ABOVE 28K?
3253 ; MOV R1,R2 ; BR IF NO
3254 ; .REPT 6 ; SAVE LOW ORDER BITS
3255 ; ASR R0 ; CONVERT WORD ADDRESS TO 32W BLOCKS
3256 ; ROR R1 ; MAKE IT DOUBLE PRECISION
3257 ; .ENDR
3258 ; BIC #177,R1 ; ALINE FOR LOWER 4K BOUNDARY
3259 ; CMP R1,#6000 ; HIGHER THAN EXISTING MEMORY?
3260 ; BHIS 104 ; BR IF YES
3261 ; MOV R1,#KIPAR5 ; SETUP MAPPING REGISTER PAR5
3262 ; BIC #160000,R2 ; SETUP DISPLACEMENT IN PAGE
3263 ; ADD #120000,R2 ; ADD IN PAR5 BIAS
3264 ; MOV R2,R0 ; RETURN IN R0
3265 ; SEC ; SET SUCCESS
3266 ; BR 154
3267 104: CLC ; SET FAILURE
3268 154: RTS PC ; RETURN
3269 .SBTTL FILLMEM - FILL MEMORY WITH BACKGROUND PATTERN
3270
3271 ; FILL MEMORY WITH A BACKGROUND PATTERN
3272
3273 ; INPUTS:
3274
3275 ; R0 = BACKGROUND PATTERN
3276 ; FREE = FIRST LOCATION AVAILABLE TO DIAGNOSTIC
3277 ; KTFLG = SET TO HIGHEST MEMORY LOCATION IF > 28K.
3278
3279 ; OUTPUTS:
3280
3281 ; NONE
3282
3283 ; FILLMEM:
3284 ; SAVREG
3285 ; JSR PC,KTOFF ; SAVE R1-R5 UNTIL NEXT RETURN
3286 ; ; DISABLE KT.

```

G7

SEQ 0084

## FILLMEM - FILL MEMORY WITH BACKGROUND PATTERN

```

3287 017542 010003          MOV      R0,R3          ;COPY TEST PATTERN
3288 017544 013701 003120  MOV      FREE,R1       ;GET FIRST FREE LOCATION
3289 017550 013702 003122  MOV      FRESIZ,R2     ;SIZE OF FREE SPACE BELOW 28K.
3290 017554 010321          MOV      R3,(R1)+     ;STORE A BACKGROUND WORD
3291 017556 005302          DEC      R2           ;DONE ALL MEMORY IN FREE SPACE?
3292 017560 003375          BGT     10$           ;BR IF NO
3293 017562 005737 003126  TST     KTFLG         ; GOT KT?
3294 017566 001477          BEQ     55$          ; NO. GET OUT.
3295 017570 004737 017366  JSR     PC,KTON       ; YES. ENABLE KT.
3296 017574 005000          CLR     RO           ;HIGH ORDER ADDRESS START
3297 017576 013701 003146  MOV     PST32W,R1     ;GET >28K START ADDRESS (IN 32W BLOCKS)
3298          000006          .REPT    6
3299          CLC
3300          ROL     R1           ;CLEAR C BIT
3301          ROL     R0           ;CONVERT BLOCKS TO WORDS
3302          .ENDR          ;MAKE IT DOUBLE PRECISION
3303 017646 004737 017426  JSR     PC,SETMAP     ;SETUP PAR6 MAPPING REGISTER
3304 017652 010320          MOV     R3,(R0)+     ;STORE TEST PATTERN IN >28K ADDRESS
3305 017654 020027 140000  CMP     RO,#140000    ;END OF PARS MAPPING AREA?
3306 017660 103774          BLO     30$           ;BR IF NO
3307 017662 162700 020000  SUB     #20000,R0     ;BACKUP INTO PARS MAPPING BEGIN
3308 017666 062737 000200 172352  ADD     #200,@#KIPARS ;POINT TO NEXT 4K BLOCK >28K.
3309 017674 023727 172352 006000  CMP     @#KIPARS,#6000 ;END OF MEMORY?
3310 017702 001427          BEQ     50$           ;BR IF YES
3311 017704 005737 003140  TST     T23A         ;11/23A?
3312 017710 001407          BEQ     35$          ;NO KEEP GOING
3313 017712 013704 177572  MOV     SRO,R4        ;GET SRO CONTENTS
3314 017716 042704 177761  BIC     #177761,R4    ;CLEAR ALL BUT PAGE NUMBER
3315 017722 022704 000016  CMP     #16,R4        ;SEE IF PAGE 7
3316 017726 001415          BEQ     50$          ;EXIT IF THERE
3317 017730 005737 003142  TST     T23B         ;11/23B?
3318 017734 001410          BEQ     45$          ;NO KEEP GOING
3319 017736 023727 172352 007600  CMP     @#KIPARS,#7600 ;REACHED 18 BITS?
3320 017744 103001          BHIS   40$           ;YES
3321 017746 000403          BR     45$           ;NO KEEP GOING
3322 017750 012737 000020 172516 40$:  MOV     #20,S3       ;SET 22 BIT RELOCATION
3323 017756 000137 017652 45$:  JMP     30$          ;KEEP GOING ON ETC.
3324 017762 004737 017404 50$:  JSR     PC,KTOFF     ; DISABLE KT.
3325 017766 000207          55$:  RTS     PC

```



CMPMEM - COMPARE MEMORY TO BACKGROUND PATTERN

```

3327          .SBTTL  CMPMEM - COMPARE MEMORY TO BACKGROUND PATTERN
3328
3329          ;*
3330          ; COMPARE MEMORY WITH A BACKGROUND PATTERN
3331          ;
3332          ; INPUTS:
3333          ;
3334          ;     RO = BACKGROUND PATTERN
3335          ;     FREE  = FIRST LOCATION AVAILABLE TO DIAGNOSTIC
3336          ;     KTFLG  = SET TO HIGHEST MEMORY LOCATION IF > 28K.
3337          ;
3338          ; OUTPUTS:
3339          ;
3340          ;     CARRY  - SET IF NO ERROR
3341          ;     CARRY  - CLR IF ERROR
3342          ;
3343          ; IMPLICIT OUTPUTS:
3344          ;
3345          ;     ERRHI  - ERROR HIGH ADDRESS
3346          ;     ERRLO  - ERROR LOW ADDRESS
3347          ;     EXPD   - EXPECTED DATA
3348          ;     RECV   - RECEIVED DATA
3349          ;-
3349 017770  CMPMEM:
3350 017770          SAVREG          ;SAVE R1-R5 UNTIL NEXT RETURN
3351 017774 010003  MOV          R0,R3          ;COPY TEST PATTERN
3352 017776 004737 017404  JSR          PC,KTOFF        ;DISABLE KT.
3353 020002 013701 003120  MOV          FREE,R1         ;GET FIRST FREE LOCATION
3354 020006 013702 003122  MOV          FRESIZ,R2       ;SIZE OF FREE SPACE BELOW 28K.
3355 020012 020311          10+:  CMP          R3,(R1)        ;FREE SPACE LOCATION EQUAL TO EXPD?
3356 020014 001411          BEQ          15+           ;BR IF YES
3357 020016 010137 002234  MOV          R1,ERRLO        ;SAVE ADDRESS IN ERROR
3358 020022 005037 002232  CLR          ERRHI          ;NO HIGH ADDRESS
3359 020026 010337 002226  MOV          R3,EXPD         ;SAVE EXPD FOR ERROR REPORT
3360 020032 011137 002230  MOV          (R1),RECV       ;SAVE RECV FOR ERROR REPORT
3361 020036 000474          BR          50+           ;
3362 020040 005721          15+:  TST          (R1)+         ;POINT TO NEXT ADDRESS
3363 020042 005302          DEC          R2           ;DONE ALL MEMORY IN FREE SPACE?
3364 020044 003362          BGT          10+           ;BR IF NO
3365 020046 005737 003126  TST          KTFLG          ; GOT KT?
3366 020052 001472          BEQ          55+           ; NO. GET OUT.
3367 020054 004737 017366  JSR          PC,KTON         ; YES. ENABLE KT.
3368 020060 005000          CLR          R0           ;HIGH ORDER ADDRESS START
3369 020062 013701 003146  MOV          PST32W,R1       ;GET >28K START ADDRESS (IN 32W BLOCKS)
3370          .REPT          6
3371          ROL          R1           ;CONVERT BLOCKS TO WORDS
3372          ROL          R0           ;MAKE IT DOUBLE PRECISION
3373          .ENDR
3374 020116 042701 000177  BIC          #177,R1         ;ALINE 4K BOUNDARY
3375 020122 010046          MOV          R0,-(SP)       ;SAVE HIGH ORDER
3376 020124 010146          MOV          R1,-(SP)       ;SAVE LOW ORDER
3377 020126 004737 017426  JSR          PC,SETMAP       ;SETUP PAR6 MAPPING REGISTER
3378 020132 010004          MOV          R0,R4         ;COPY ADDRESS BIASED TO PAR6
3379 020134 012601          MOV          (SP)+,R1       ;RESTORE LOW ORDER IN NON PAR6 FORMAT
3380 020136 012600          MOV          (SP)+,R0       ;RESTORE HIGH ORDER IN NON PAR6 FORMAT
3381 020140 020314          30+:  CMP          R3,(R4)        ;ABOVE 28K LOCATION EQUAL EXPD?
3382 020142 001411          BEQ          32+           ;BR IF YES
3383 020144 010037 002232  MOV          R0,ERRHI        ;SAVE HIGH ORDER IN ERROR

```

## CMPMEM - COMPARE MEMORY TO BACKGROUND PATTERN

```

3384 020150 010137 002234      MOV      R1,ERRLO      ;SAVE LOW ORDER IN ERROR
3385 020154 010337 002226      MOV      R3,EXPD      ;SAVE EXPD FOR ERROR REPORT
3386 020160 011437 002230      MOV      (R4),RECV    ;SAVE RECV FOR ERROR REPORT
3387 020164 000421              BR       50$          ;
3388 020166 062701 000002      32$:    ADD      #2,R1      ;UPDATE NON PAR6 ADDRESS
3389 020172 005500              ADC      R0          ;MAKE IT DOUBLE PRECISION ADD
3390 020174 062704 000002      ADD      #2,R4      ;UPDATE PAR FORMAT ADDRESS
3391 020200 020427 140000      CMP      R4,#140000  ;END OF PARS MAPPING AREA?
3392 020204 103755              BLO     30$          ;BR IF NO
3393 020206 162704 020000      SUB      #2000,R4    ;BACKUP INTO PAR6 MAPPING BEGIN
3394 020212 062737 000200 172352  ADD      #200,@#KIPAR5 ;POINT TO NEXT 4K BLOCK >28K.
3395 020220 023737 172352 003126  CMP      @#KIPAR5,KTFLG ;END OF MEMORY?
3396 020226 101744              BLOS   30$          ;BR IF NO
3397 020230 004737 017404      50$:    JSR      PC,KTOFF   ;TURN OFF MEMORY MAPPING
3398 020234 000241              CLC                    ;SET FAILURE
3399 020236 000403              BR       60$          ;
3400 020240 004737 017404      55$:    JSR      PC,KTOFF   ;TURN OFF MEMORY MAPPING
3401 020244 000261              SEC                    ;SET SUCCESS
3402 020246 000207      60$:    RTS      PC
3403              .SBTTL  REGSAV - SAVE R1-R5 ON STACK
3404              ;*
3405              ;
3406              ;ROUTINE TO
3407              ;SAVE R1 THROUGH R5 ON THE STACK
3408              ;
3409              ;CALLING SEQUENCE:
3410              ;
3411              ;      JSR      R5,REGSAV
3412              ;
3413              ;THIS IS A COOROUTINE WHICH TRANSFER CONTROL BACK TO
3414              ;THE CALLING ROUTINE. AT THE END OF THE CALLING ROUTINE,
3415              ;THE RTS PC RETURNS CONTROL TO THIS ROUTINE TO RESTORE
3416              ;REGISTERS.
3417              ;
3418              ;THIS ROUTINE SHOULD ONLY BE CALLED FROM ROUTINES WHICH ARE
3419              ;CALLED VIA A JSR PC INSTRUCTION
3420              ;
3421              ;-
3422              ;
3423 020250      REGSAV:
3424 020250 010446      MOV      R4,-(SP)
3425 020252 010346      MOV      R3,-(SP)
3426 020254 010246      MOV      R2,-(SP)
3427 020256 010146      MOV      R1,-(SP)
3428 020260 010546      MOV      R5,-(SP)
3429 020262 016605 000012  MOV      10.(SP),R5
3430 020266 004736      JSR      PC,@(SP)+
3431 020270 012601      MOV      (SP)+,R1
3432 020272 012602      MOV      (SP)+,R2
3433 020274 012603      MOV      (SP)+,R3
3434 020276 012604      MOV      (SP)+,R4
3435 020300 012605      MOV      (SP)+,R5
3436 020302 000207      RTS      PC

```



J7

GETPAT - GET 8 BIT PATTERN FROM OPERATOR

```

3438 .SBTTL GETPAT - GET 8 BIT PATTERN FROM OPERATOR
3439 ;*
3440 ;ROUTINE TO REQUEST AN 8 BIT DATA PATTERN FROM THE OPERATOR
3441 ;
3442 ;INPUTS: NONE.
3443 ;
3444 ;OUTPUTS:
3445 ; RO OCTAL NUMBER FROM THE OPERATOR
3446 ;
3447 ;CALLING SEQUENCE:
3448 ; JSR PC,GETPAT
3449 ;-
3450 GETPAT::
3451 020304 ; SAVREG ;SAVE THE GENERAL REGISTERS
3452 020304 14: GMANID DATASC,PATDAT,0,377,0,377,NO
020310 104443 TRAP C#GMAN
020312 000406 BR 10000$
020314 020340 .WORD PATDAT
020316 000022 .WORD T#CODE
020320 020342 .WORD DATASC
020322 000377 .WORD 377
020324 000000 .WORD T#LOLIM
020326 000377 .WORD T#HILIM
020330 10000$:
3453 020330 BNCOMPLETE 14 ;RETRY IF ERROR
020330 103367 BCC 1$
3454 020332 013700 020340 MOV PATDAT,RO ;DATA PATTERN FROM OPERATOR
3455 020336 000207 RTS PC ;RETURN TO CALLER
3456
3457 ;*
3458 ;LOCAL DATA AREA
3459 ;-
3460
3461 020340 000000 PATDAT: .WORD 0 ;TEMPORARY STORAGE FOR DATA
3462 020342 105 116 124 DATASC: .ASCIZ 'ENTER DATA PATTERN'
3463 .EVEN

```

GETSEL - ISSUE MENU AND GET OPERATOR RESPONSE

```

3465 .SBTTL GETSEL - ISSUE MENU AND GET OPERATOR RESPONSE
3466 ;*
3467 ;ROUTINE TO ISSUE A MENU AND GET THE OPERATOR'S RESPONSE.
3468 ;
3469 ;INPUTS:
3470 ; R0 ADDRESS OF ASCIZ STRING OF MENU
3471 ; R1 MAXIMUM ALLOWABLE OPERATOR RESPONSE
3472 ;
3473 ;OUTPUTS:
3474 ; R0 NUMBER OF THE OPERATOR'S SELECTION
3475 ;-
3476 GETSEL::
3477 SAVREG ;SAVE GENERAL REGISTERS
3478 MOV R0,R2 ;SAVE THE MENU ADDRESS
3479 MOV R2,R3 ;START OF MENU STRING
3480 TST (R3) ;END OF ASCII ?
3481 BEQ 3$ ;BRANCH IF ALL LINES DISPLAYED
3482 PRINTF @SELASC,(R3)+ ;DISPLAY THE MENU
3483 MOV (R3)+,-(SP)
3484 MOV @SELASC,-(SP)
3485 MOV @2,-(SP)
3486 MOV SP,R0
3487 TRAP C#PNTF
3488 ADD #6,SP
3489 BR 2$
3490 3$: GMANID MENASC,MENRES,D,-1,0,-1,NO
3491 TRAP C#GMAN
3492 BR 10001$
3493 .WORD MENRES
3494 .WORD T#CODE
3495 .WORD MENASC
3496 .WORD -1
3497 .WORD T#LOLIM
3498 .WORD T#HILIM
3499 10001$: BNCOMPLETE 1$ ;RETRY IF ERROR
3500 BCC 1$
3501 MOV MENRES,R0 ;GET THE OPERATOR'S REPLY
3502 CMP R0,R1 ;COMPARE TO MAXIMUM ALLOWED
3503 BLOS 5$ ;BRANCH IF OK
3504 PRINTF #MENERR ;DISPLAY ERROR MESSAGE
3505 MOV #MENERR,-(SP)
3506 MOV #1,-(SP)
3507 MOV SP,R0
3508 TRAP C#PNTF
3509 ADD #4,SP
3510 BR 1$ ;RETRY
3511 RTS PC ;RETURN TO CALLER
3512 5$: MENERR: .ASCIZ '#N/A *** Menu Selection Too Large ***'
3513 SELASC: .ASCIZ '#N/T'
3514 MENASC: .ASCIZ 'Enter Menu Selection: '
3515 .EVEN
3516 MENRES: .WORD 0

```



L7

CHKMAN - CHECK MANUAL INTERVENTION LEGALITY

```

3498 .SBTTL CHKMAN - CHECK MANUAL INTERVENTION LEGALITY
3499
3500 ;*
3501 ;ROUTINE TO TEST FOR MANUAL INTERVENTION LEGALITY.
3502 ;
3503 ;INPUT:
3504 ;
3505 ; NONE.
3506 ;
3507 ;OUTPUT:
3508 ;
3509 ; CARRY 0 MANUAL INTERVENTION NOT ALLOWED
3510 ; 1 MANUAL INTERVENTION IS OK
3511 ;
3512 ;SIDE EFFECTS:
3513 ;
3514 ; A MESSAGE IS DISPLAYED WARNING THAT TEST IS
3515 ; NOT EXECUTED IF MANUAL INTERVENTION IS NOT
3516 ; ALLOWED.
3517 ;
3518 ;-
3519
3520 020610 CHKMAN:: SAVREG ;SAVE THE REGISTERS
3521 020610 MANUAL ;SEE IF MANUAL INTERVENTION OK
3522 020614 104450 TRAP C#MANI
3523 020616 020616 BCOMPLETE 1# ;BRANCH IF ALLOWED
3524 020620 103411 BCS 1#
3525 020620 012746 020644 PRINTF #NOMAN ;PRINT THE WARNING MESSAGE
3526 020624 012746 000001 MOV #NOMAN,-(SP)
3527 020630 010600 MOV #1,-(SP)
3528 020632 104417 TRAP C#PNTF
3529 020634 062706 000004 ADD #4,SP
3525 020640 000241 CLC ;CLEAR CARRY FOR ERROR
3526 020642 000207 1#: RTS PC ;RETURN
3528 020644 045 116 045 NOMAN: .ASCIZ '#N#A *** Manual Intervention not Allowed - Test Aborted ***'
3529 .even

```

ENVIRN - SETUP FREE DIAGNOSTIC SPACE

```

3531          .SBTTL  ENVIRN  - SETUP FREE DIAGNOSTIC SPACE
3532          ;
3533          ; SUBROUTINE TO SET-UP VARIOUS ENVIRONMENTAL PARAMETERS.
3534          ;
3535          ENVIRN: MEMORY  R0
020740      TRAP          C$MEM
3536 020742 010037 003120      MOV          R0,FREE          ; GET 1ST FREE ADDRESS...
3537 020746 062737 000002 003120      ADD          #2,FREE
3538 020754 011037 003122      MOV          (R0),FRESIZ      ; ...AND WORD COUNT.
3539 020760 162737 000004 003122      SUB          #4,FRESIZ
3540 020766 013702 002012      MOV          L$UNIT,R2      ; GET NUMBER OF UNITS
3541 020772 162737 000007 003122 10$:  SUB          #7,FRESIZ      ; TAKE AWAY 7 WORDS PER UNIT
3542 021000 005302      DEC          R2
3543 021002 001373      BNE          10$
3544 021004 013700 003120      MOV          FREE,R0          ;GET FIRST FREE ADDRESS
3545 021010 063700 003122      ADD          FRESIZ,R0      ;POINT TO LAST FREE ADDRESS
3546 021014 162700 000002      SUB          #2,R0          ;BACKUP 1 WORD
3547 021020 010037 003124      MOV          R0,FREEHI      ;STORE LAST FREE ADDRESS
3548 021024 000240      NOP
3549 021026 012701 177520      MOV          #BDVPCR,R1      ;GET BDV11 PCR ADDRESS
3550 021032 010102      MOV          R1,R2          ;COPY TO R2
3551 021034 062702 000002      ADD          #2,R2          ;SET THE RANGE
3552 021040 004737 016506      JSR          PC,XNXM        ;SEE IF WE HAVE ONE
3553 021044 103001      BCC          15$          ;OK TO SET FLAGS
3554 021046 000423      BR          40$          ;RETURN WITH FLAGS CLEAR
3555 021050 013701 177520 15$:      MOV          BDVPCR,R1      ;SAVE PCR CONTENTS
3556 021054 062701 000001      ADD          #1,R1          ;ADD ONE TO IT
3557 021060 012702 177520      MOV          #BDVPCR,R2      ;GET BDV11 PCR ADDRESS
3558 021064 005212      INC          (R2)          ;TRY TO WRITE TO IT
3559 021066 013703 177520      MOV          BDVPCR,R3      ;GET RESULTS
3560 021072 020103      CMP          R1,R3          ;DID IT CHANGE?
3561 021074 001006      BNE          20$          ;NO, MUST BE 11/23B
3562 021076 005237 003140      INC          T23A          ;SET THE FLAG
3563 021102 042737 170000 002120      BIC          #170000,L$HIME ;SUPERVISOR COULD BE WRONG
3564          NOP
3565          ;
3566 021110 000402      PRINTF      #M8186          ;TELL THE SYSTEM TYPE
3567 021112 005237 003142 20$:      BR          40$          ;RETURN
3568          ;
3569          ;
3570 021116          PRINTF      #M8189          ;TELL THE SYSTEM TYPE
3571 021116 000207      RTS          PC          ;RETURN

```



KTINIT - SETUP KT11 MEMORY MANAGEMENT REGISTERS

```

3573                                     .SBTTL KTINIT - SETUP KT11 MEMORY MANAGEMENT REGISTERS .
3574                                     ;*
3575                                     ;
3576                                     ;ROUTINE TO INIT KT-11
3577                                     ;
3578                                     ;-
3579
3580 021120                               KTINIT:
3581 021120 005037 003126                 CLR    KTFLG           ; INIT >28K MEMORY FLAG
3582 021124 005037 003130                 CLR    KTENABLE       ; INIT TEST >28K FLAG
3583 021130 023727 002120 001577         CMP    L#HIME,#1577   ; GOT ENOUGH MEMORY (>28K)?
3584 021136 101454                        9#     ; NO.
3585 021140 013700 000004                 MOV    @#ERRVEC,RO    ; SAVE OLD ERR VEC PTR.
3586 021144 012737 021256 000004         MOV    #2#,@#ERRVEC  ; SET ERR VEC PTR.
3587 021152 005737 177572                 TST    @#SRO          ; GOT KT11?
3588 021156 000240                        NOP                    ; (TRAP IF NO).
3589 021160 013737 002120 003126         MOV    L#HIME,KTFLG  ; YES. SET KT FLAG.
3590 021166 022737 007777 003126         CMP    #7777,KTFLG   ; GOT 22 BIT MACHINE?
3591 021174 100404                        4#     ; NO
3592 021176 042737 003777 003126         BIC    #3777,KTFLG   ; ALIGN ON BOUNDARY
3593 021204 000403                        BR     5#
3594 021206 042737 000177 003126 4#:    BIC    #177,KTFLG    ;
3595 021214 010037 000004 5#:          MOV    RO,@#ERRVEC   ; RESTORE OLD ERR VEC PTR.
3596 021220 005000                        CLR    RO             ; RO = AR DATA.
3597 021222 012701 172340                 MOV    #KIPAR0,R1    ; R1 = KI REGS PTR.
3598 021226 012761 077406 177740 1#:    MOV    #77406,-40(R1) ; SET DESCRIPTOR REG.
3599 021234 010021                        MOV    RO,(R1)-      ; SET KIPAR REG.
3600 021236 062700 000200                 ADD    #200,RO        ; BUMP AR DATA BY "4K".
3601 021242 020027 002000                 CMP    RO,#2000       ; AT "I/O"?
3602 021246 001367                        BNE    1#             ; NO.
3603 021250 012741 177600                 MOV    #177600,-(R1) ; YES. SET KTPAR7 FOR I/O.
3604 021254 000405                        BR     9#
3605
3606 021256 012716 021264                 2#:    MOV    #6#,(SP)    ; SET UP RETURN
3607 021262 000002                        RTI                    ; RTI TO NEXT LOCATION
3608
3609 021264 010037 000004                 6#:    MOV    RO,@#ERRVEC ; RESTORE OLD ERR VEC PTR.
3610
3611 021270 000207                 9#:    RTS    PC

```

## KTINIT - SETUP KT11 MEMORY MANAGEMENT REGISTERS

```

3613
3614
3615
3616
3617
3618
3619
3620
3621
3622
3623
3624
3625
3626
3627
3628
3629
3630
3631
3632
3633
3634
3635
3636
3637
3638
3639
3640
3641
3642
3643
3644
3645
3646
3647
3648
3649
3650
3651
3652
3653
3654
3655
3656
3657
3658
3659
3660
3661
3662
3663
3664
3665
3666
3667
3668
3669

```

```

;*
; SUBROUTINE TO SET EXTENDED FEATURES SWITCH
;
; Requires that SOFINIT and WRTCHR have been done previous to call.
;
; INPUTS:
; R5 CURRENT UNIT NUMBER
; OUTPUTS:
; The Extended Features Switch is set.
;-

; COMMAND PACKET.
;
; = <..+3>&177774 ;MUST BE ON MOD 4 BOUNDRY.
;
; CNDPKT:: 0 ;1ST WORD IS TS05 COMMAND.
; 0 ;2ND WORD IS THE BUFFER LOW ADDRESS.
; 0 ;3RD WORD IS THE BUFFER HIGH ADDRESS.
; 0 ;4TH WORD IS THE BYTE/RECORD/FILE COUNT.
;
; WRITE SUB-SYSTEM MEMORY CHARACTERISTIC BLOCK.
;
; WSMBK:: 0 ;1ST WORD:: SEL 0
; 0 ;2ND WORD:: SEL 2
; 0 ;3RD WORD:: SEL 4
; .EVEN

;*
; SUBROUTINE TO CHECK WETHER OR NOT WE'LL TEST NXM
;
; INPUTS:
; OUTPUTS:
; The NXMFLG is set if we can test.
; The NXMLO and NXMHI addresses are setup.
;-

MEMCK::

; SAVREG
; CLR NXMFLG ;SAVE THE REGISTERS
; CLR NXMLO ;CLEAR THE FLAG
; CLR NXMHI ;CLEAR THE TEST ADDRESS LO
; TST T23B ;CLEAR THE TEST ADDRESS HI
; BEQ 14 ;IS IT A 11/23B?
; CMP L#HIME,#7777 ;NO
; BLO 24 ; GREATER THAN 128K
; JSR PC,NXMTST ; NO
; BR 13 ;SETUP THE ADDRESS
; TST T23A ;SET THE FLAG AND EXIT
; BEQ 4 ;IS IT A 11/23A?
; CMP L#HIME,#5777 ;NO
; BHI 14 ;GREATER THAN 96K
; CMP L#HIME,#3777 ;YES, 23A/23B WITH 128K MEMORY
; BLO 4 ;GREATER THAN 64K BUT LESS THAN 92K?
; ;NO, CHECK 24K

```

021274	000000				
021276	000000				
021300	000000				
021302	000000				
021304	000000				
021306	000000				
021310	000000				
021312					
021312					
021316	005037	003132			
021322	005037	003134			
021326	005037	003136			
021332	005737	003142			
021336	001407				
021340	023727	002120	007777		
021346	103406				
021350	004737	021466			
021354	000427				
021356	005737	003140		14:	
021362	001413				
021364	023727	002120	005777	24:	
021372	101023				
021374	023727	002120	003777		
021402	103403				



KTINIT - SETUP KT11 MEMORY MANAGEMENT REGISTERS

```

3670 021404 004737 021466 JSR PC,NXMTST ;SETUP THE ADDRESS
3671 021410 000411 BR 13 ;SET THE FLAG AND EXIT
3672 021412 023727 002120 001577 4: CMP L#HIME,#1577 ;GREATER THAN 24K BUT LESS THAN 64K?
3673 021420 103410 BLO 14 ;NO, TELL THEM AND EXIT WITH FLAG CLEAR
3674 021422 004737 021466 JSR PC,NXMTST ;SETUP THE ADDRESS
3675 021426 062737 000077 003136 ADD #77,NXMHI ;FOOL THE 11/02 & 11/03
3676 021434 005237 003132 13: INC NXMFLG ;SET THE FLAG
3677 021440 000411 BR 15 ;EXIT
3678 021442 000410 14: BR 15 ;NOP FOR PRINTOUT
3679 021444 PRINTF #NOMEM ;TELL THEM & EXIT ***NO PRINT*****
021444 012746 005456 MOV #NOMEM,-(SP)
021450 012746 000001 MOV #1,-(SP)
021454 010600 MOV SP,R0
021456 104417 TRAP C#PNTF
021460 062706 000004 ADD #4,SP
3680 021464 000207 15: RTS PC ;RETURN

```

```

3681
3682 ;*
3683 ; SUBROUTINE TO SETUP THE NXM ADDRESS FOR TESTING
3684 ;
3685 ; OUTPUTS: NXMLO, NXMHI ; SETUP WITH NXM ADDRESS
3686 ;
3687 ;-
3688

```

```

3689 021466 013701 002120 NXMTST: MOV L#HIME,R1 ;GET TOP OF MEMORY
3690 021472 062701 000200 ADD #200,R1 ;MAKE IT I/O BLOCK OR OTHER NXM
3691 021476 042701 000177 BIC #177,R1
3692 021502 010102 MOV R1,R2 ;RESAVE RESULTS
3693 000006 .REPT 6
3694 ASL R1 ;PUT IN PLACE FOR XFER
3695 .ENDR
3696 021520 010137 003134 MOV R1,NXMLO ;SAVE TEST ADDRESS LOW
3697 000012 .REPT 10
3698 ASR R2 ;PUT IN PLACE FOR XFER
3699 .ENDR
3700 021550 042702 177700 BIC #177700,R2 ;DON'T WANT ILA!
3701 021554 010237 003136 MOV R2,NXMHI ;SAVE TEST ADDRESS HIGH
3702 021560 000207 RTS PC ;RETURN
3703

```

```

3704 021562 ENDMOD
3713 .TITLE TSV4 - MISCELLANEOUS SECTIONS
3714

```

```

3715 021562 BGNMOD TSV4
021562 TSV4::

```

```

3716
3722
3723
3724
3725 .SBTTL PROTECTION TABLE
3726 021562 BGNPROT
021562 L#PROT::
3727 021562 177777 177777 177777 .WORD -1, -1, -1, -1 ;NO DEVICE PROTECTION REQUIRED.
3728 021572 ENDPROT

```

## INITIALIZE SECTION

```

3730                                     .SBTTL INITIALIZE SECTION
3731
3732                                     ;**
3733                                     ;THE INITIALIZE SECTION CONTAINS THE CODING THAT IS PERFORMED
3734                                     ;AT THE BEGINNING OF EACH PASS.
3735
3736                                     ;
3737                                     ;IF "START" OR "RESTART", SET QUICK-PASS FLAG AND BUS-INIT.
3738                                     ;IF "CONTINUE", NOTHING IS REQUIRED.
3739                                     ;
3740                                     ;--
3741                                     ;*
3742                                     ;INSERT TEMPORARY JUMP TO ODT
3743                                     ;-
3743 021572                                     BGNINIT
3744 021572                                     L#INIT::
3744 021572 005037 002220                                     40$: CLR     EXTFEA
3745 021576 005037 003132                                     CLR     NXMFLG
3746 021602 012737 006356 002172                                     MOV     #EPRT1,EPRTSW           ;SET UP PRIMARY MESSAGE FOR REPLACEMENT
3747 021610 005037 003150                                     CLR     SIFLAG                 ;CLEAR "SOFT INIT" FLAG
3748 021614 005037 003130                                     CLR     KTENABLE              ;CLEAR TEST ABOVE 28K FLAG
3749 021620 005037 002276                                     CLR     RAMSIZ                ;CLEAR RAM SIZE FOR RAMERR ROUTINE
3750 021624                                     READEF  #EF.CONTINUE
3750 021624 012700 000036                                     MOV     #EF.CONTINUE,R0
3750 021630 104447                                     TRAP   C#REFG
3751 021632                                     BNCOMPLETE 1$
3751 021632 103023                                     BCC    1$
3752 021634 023737 002174 002012                                     CMP     UNITN,L#UNIT           ;UNIT IN RANGE?
3753 021642 103070                                     BHIS   4$                     ;BR IF NO.
3754 021644 005737 003106                                     TST    DUFLG                  ;DROPPED UNIT?
3755 021650 100472                                     BMI    NXTU                   ;BR IF YES
3756 021652 013701 002174                                     MOV     UNITN,R1
3757 021656 006301                                     ASL    R1
3758 021660 005761 003172                                     TST    ERTABL(R1)
3759 021664 001516                                     BEQ    SETU
3760 021666 032761 040000 003172                                     BIT    #BIT14,ERTABL(R1)      ;DROPPED?
3761 021674 001060                                     BNE    NXTU
3762 021676                                     EXIT  INIT                    ;DO NOTHING IF "CONTINUE".
3762 021676 104432                                     TRAP   C#EXIT
3762 021700 000416                                     .WORD  L10030-.
3763 021702                                     1$: READEF  #EF.NEW
3763 021702 012700 000035                                     MOV     #EF.NEW,R0
3763 021706 104447                                     TRAP   C#REFG
3764 021710                                     BNCOMPLETE NXTU              ;TAKE NEXT UNIT IF NOT NEW PASS.
3764 021710 103052                                     BCC    NXTU
3765 021712                                     READEF  #EF.START
3765 021712 012700 000040                                     MOV     #EF.START,R0
3765 021716 104447                                     TRAP   C#REFG
3766 021720                                     BCOMPLETE 2$
3766 021720 103404                                     BCS    2$
3767 021722                                     READEF  #EF.RESTART
3767 021722 012700 000037                                     MOV     #EF.RESTART,R0
3767 021726 104447                                     TRAP   C#REFG
3768 021730                                     BNCOMPLETE 31$
3768 021730 103031                                     BCC    31$
3769 021732                                     2$: BRESET
3770 021732 104433                                     TRAP   C#RESET           ;1ST PASS, BUS-INIT...
                                     ;BUS RESET.

```



## INITIALIZE SECTION

```

3771 021734 005037 002206      CLR      TSTCNT      ;NUMBER OF TESTS RUN IN PASS
3772 021740 005037 002214      CLR      FATFLG     ;CLEAR FATAL ERROR COUNT
3773 021744 005037 003140      CLR      T23A      ;CLEAR 11/23A FLAG
3774 021750 005037 003142      CLR      T23B      ;CLEAR 11/23B FLAG
3775          :      MOV      #340,-(SP)
3776          :      MOV      #20,-(SP)      ;RETURN TO DEBUGGER
3777          :      JMP      0.001      ;ENTER THE DEBUGGER
3778 021754 005037 003374      CLR      SKIPT      ;CLEAR THE SUBTEST "SKIPPER"
3779 021760          :
3780 021760 012737 177777 002176 20$:      MOV      #-1,QVP
3781 021766 004737 020740          JSR      PC,ENVIRN   ;...QUICK VERIFY...
3782 021772 004737 021120          JSR      PC,KTINIT  ;SET ENVIRONMENT.
3783 021776 012700 003172          MOV      #ERTABL,RO ;INITIALIZE KT MEMORY MANAGEMENT
3784 022002 005020          CLR      (RO)      ;CLEAR THE ERROR TABLE
3785 022004 020027 003372          CMP      RO,#ERTABE
3786 022010 103774          BLO     30$
3787 022012 000404          BR      4$
3788 022014 005037 002176          CLR      QVP
3789 022020 000137 022070          JMP      PASRPT     ;GO REPORT THE STATUS
3790
3791 022024          :
3792 022024 012737 177777 002174 4$:      NEWPAS: MOV      #-1,UNITN   ;INIT UNIT NUMBER...
3793 022032 005037 002212          CLR      DEVCNT    ;CLEAR COUNT OF DEVICES RUNNING
3794 022036          :
3795 022036 104422          :
3796 022040 005237 002174          :
3797 022044 023737 002174 002012 11$:      NEXTU: BREAK
3798 022052 103423          TRAP    C#BRK
3799 022054 012737 177777 003106          INC     UNITN
3800 022062 000401          CMP     UNITN,L#UNIT ;...AND SET NEXT UNIT NUMBER.
3801 022064 104444          BLO    SETU
3802 022066 000240          MOV    #-1,DUFLG
3803 022070 023727 002012 000001 11$:      PASRPT: BR      11$
3804 022076 101752          DOCLN
3805 022100 005737 002212          TRAP  C#DCLN
3806 022104 001747          NOP
3807 022106 104421          CMP    L#UNIT,#1
3808 022110 032700 000100          BLOS   NEWPAS
3809 022114 001343          TST   DEVCNT
3810          BEQ   NEWPAS
3811 022116          RFLAGS RO
3812 022116 104424          TRAP  C#RFLA
3813 022120 000741          BIT   #ISR,RO
3814 022122          BNE   NEWPAS
3815 022122          :
3816 022122 013700 002174          DORPT
3817 022126 104442          TRAP  C#DRPT
3818 022130          BR    NEWPAS
3819 022130 103342          :
3820 022132 005037 003106          SETU: GPHARD UNITN,RO ;GET UNIT N P-TABLE POINTER.
3821 022136 005237 002212          MOV   UNITN,RO
3822 022142 012001          TRAP  C#GPHRD
3823 022144 010137 002200          BNCOMPLETE NEXTU ;BR IF UNIT NOT AVAILABLE.
3824          BCC  NXTU
3825          CLR  DUFLG ;CLEAR "DROPPED" FLAG.
3826          INC  DEVCNT
3827          MOV  (RO),R1 ;GET 1ST REGISTER ADDRESS.
3828          MOV  R1,CSRADDR ;ADDRESS OF REGISTERS OF UNIT UNDER TEST

```

## INITIALIZE SECTION

```

3821
3822 022150 012001          MOV      (R0),R1          ;GET VECTOR ADDRESS.
3823                      ;MOV      (R0),R2          ;GET INTERRUPT PRIORITY
3824                      ;MOV      R2,IPRI        ;SET INTERRUPT PRIORITY.
3825 022152 010137 002202  MOV      R1,IVEC        ;SET INTERRUPT VECTOR POINTER...
3826 022156 012721 016326  MOV      #INTR,(R1)+    ;...VECTOR...
3827 022162 013721 002204  MOV      IPRI,(R1)+    ;...AND PRIORITY.
3828
3829 022166                1$:
3830                      ; TST      QVP          ;1ST PASS ??
3831                      ; BEQ      5$          ;NO, SKIP THE PASS 1 STUFF.
3832
3833                      ;
3834                      ;1ST PASS, CHECK THAT DEVICE ADDRESSES ARE VALID, AND
3835                      ;THAT THE DISPLAY STATUS IS PROPERLY INITIALIZED.
3836                      ;
3837 022166 013701 002174          MOV      UNITN,R1
3838 022172 006301                ASL      R1
3839 022174 052761 100000 003172  BIS      #BIT15,ERTABL(R1) ;SAY DEVICE RUNNING
3840 022202 005037 005770                CLR      EXTA          ;CLEAR ERROR EXTENSION FLAG.
3841 022206 023727 002012 000001  CMP      L#UNIT,#1     ;ARE WE TESTING MULTIPLE UNITS?
3842 022214 101416                BLOS    10$           ;BR IF NO.
3843 022216                RFLAGS   RO          ;YES -- GET OPERATOR FLAGS.
3844 022220 032700 001000          TRAP    C#RFLA
3845 022224 001412                BIT      #PNT,RO       ;SHOULD WE PRINT UNIT #?
3846 022226                BEQ      10$           ;BR IF NOT.
3847 022226 013746 002174          PRINTF #PUNIT,UNITN   ;PRINT THE UNIT #
3848 022232 012746 022320          MOV      UNITN,-(SP)
3849 022236 012746 000002          MOV      #PUNIT,-(SP)
3850 022242 010600                MOV      #2,-(SP)
3851 022244 104417                MOV      SP,RO
3852 022246 062706 000006          TRAP    C#PNTF
3853 022252                ADD      #6,SP
3854 022252 005037 003110          10$:
3855 022256 013701 002200          CLR      NODEV
3856 022262 010102                MOV      CSRADDR,R1   ;ADDRESS OF FIRST REGISTER
3857 022264 062702 000002          MOV      R1,R2       ;START OF REGISTERS
3858 022270 004737 016506          ADD      #TSSR,R2    ;ADDRESS OF TSSR REGISTER
3859 022274 103005                JSR      PC,XNXM      ;TEST BOTH CONTROLLER REGISTERS...
3860 022276 010137 003110          BCC     2$           ;...AND BR IF ALL OK.
3861 022302 012737 177777 003106  MOV      R1,NODEV    ;FLAG DEVICE AS NON-EXISTENT
3862 022310                MOV      #-1,DUFLG   ;DROP THIS UNIT.
3863
3864                      ;
3865                      ;FINALLY, SET CPU PRIORITY AND WE'RE DONE.
3866 022310 012700 000000          5$:
3867 022314 104441                SETPRI  #PRI00        ;ENABLE INTERRUPTS.
3868 022316                MOV      #PRI00,RO
3869 022316 104411                TRAP    C#SPRI
3870 022316                ENDINIT
3871 022316 104411                L10030:
3872 022320 045 116 045 PUNIT: TRAP    C#INIT
3873                      .ASCIZ  /#N#N#A***** TESTING UNIT #D2#A *****/
3874                      .EVEN

```



ADD AND DROP UNITS SECTIONS

```

3866 .SBTTL ADD AND DROP UNITS SECTIONS
3867
3868
3869 ;**
3870 ; THE ADD-UNIT SECTION CONTAINS THE CODING THAT CAUSES A DEVICE
3871 ; TO BE (A) ADDED TO THE TEST LIST FOR THE FIRST TIME,
3872 ; OR (B) RE-INSERTED IF IT HAD BEEN PREVIOUSLY DROPPED.
3873 ;--
022366 BGNAU
3874 022366 010001 L$AU::
3875 022370 006301 MOV RO,R1 ; GET UNIT TO BE ADDED (RO)
3876 022372 052761 100000 003172 ASL R1 ; MAKE IT A WORD INDEX
3877 022400 042761 040000 003172 BIS #100000,ERTABL(R1) ; SET THE "ACTIVE" BIT
3878 022406 PRINTF #1$,RO ; CLEAR THE "DROPPED" BIT
022406 010046 MOV RO,-(SP)
022410 012746 022434 MOV #1,-(SP)
022414 012746 000002 MOV #2,-(SP)
022420 010600 MOV SP,RO
022422 104417 TRAP C$PNTF
022424 062706 000006 ADD #6,SP
3879 022430 EXIT AU
022430 000167 .WORD J$JMP
022432 000026 .WORD L10031-2-.
3880 022434 045 116 045 1$: .ASCIZ /#N#A UNIT #D#A ADDED/
3881 .EVEN
3882
3883 022462 ENDAU ; UNUSED.
022462 104452 L10031: TRAP C$AU
3884
3885 ;**
3886 ; THE DROP-UNIT SECTION CONTAINS THE CODING THAT CAUSES A DEVICE
3887 ; TO BE REMOVED FROM THE TEST LIST.
3888 ;
3889 ; SUPVSR DOES THE "DROPPING". THIS IS JUST TO TELL THE MAN.
3890 ; "DROPPED" UNITS ARE RE-SELECTED ON OPERATOR "STA" OR "ADD"
3891 ; COMMAND, OTHERWISE REMAIN INACTIVE. THE "DISPLAY" COMMAND
3892 ; WILL PRINT ALL DROPPED UNITS, AND THE P-TABLES OF THOSE
3893 ; WHICH ARE STILL ACTIVE.
3894 ; UPON ENTRY, RO CONTAINS THE UNIT TO BE DROPPED.
3895
022464 BGNDU
3896 022464 012737 177777 003106 L$DU::
3897 022472 010001 MOV #-1,DUFLG
3898 022474 006301 MOV RO,R1
3899 022476 052761 140000 003172 ASL R1
3900 022504 000240 000240 000240 BIS #140000,ERTABL(R1) ; SAY DROPPED
3901 022512 PRINTF #1$,RO ; ??????????
022512 010046 MOV RO,-(SP)
022514 012746 022540 MOV #1,-(SP)
022520 012746 000002 MOV #2,-(SP)
022524 010600 MOV SP,RO
022526 104417 TRAP C$PNTF
022530 062706 000006 ADD #6,SP
3902 022534 EXIT DU
022534 000167 .WORD J$JMP
022536 000030 .WORD L10032-2-.

```

H8

ADD AND DROP UNITS SECTIONS

```

3903 022540      045      116      045 14:      .ASCIZ  /%N%A UNIT %D%A DROPPED/
3904                                     .EVEN
3905 022570                                     ENDDU
      022570                                     L10032:
      022570 104453                               TRAP    C#DU
3906                                     ;**
3907                                     ; AUTO-DROP CODE SECTION.
3908                                     ;--
3909 022572                                     BGNAUTO
      022572                                     L#AUTO::
3910 022572 013705 002200                               MOV    CSRADDR,R5           ;POINT TO DEVICE REGISTER
3911 022576 012703 000550                               MOV    #360.,R3           ;ENOUGH TIME FOR 2400' REEL TO REWIND
3912 022602 004737 016360                               JSR    PC,WAITF           ;WAIT FOR SSR TO SET
3913 022606 103420                               BCS    20#                ;LEAVE WHEN SSR IS SET
3914 022610                               DELAY  250.               ;WAIT FOR .25 SECONDS
      022610 012727 000372                               MOV    #250.,(PC)+
      022614 000000                               .WORD  0
      022616 013727 002116                               MOV    L#DLY,(PC)+
      022622 000000                               .WORD  0
      022624 005367 177772                               DEC    -6(PC)
      022630 001375                               BNE    -4
      022632 005367 177756                               DEC    -22(PC)
      022636 001367                               BNE    -20
3915 022640 005303                               DEC    R3                 ;BUMP COUNTER DOWN
3916 022642 001357                               BNE    10#                ;KEEP GOING
3917 022644 004737 017312                               JSR    PC,CKDROP         ;TRY AND DROP UNIT
3918 022650
3919 022650
      022650                                     20#:
      022650 104461                               ENDAUTO                   ; UNUSED.
      022650                                     L10033:
      022650                                     TRAP    C#AUTO

```





CLEAN-UP AND REPORT CODING SECTIONS

```

023016 012746 000002      MOV      #2,-(SP)
023022 010600      MOV      SP,R0
023024 104416      TRAP     C#PNTS
023026 062706 000006      ADD      #6,SP
3960 023032 000431      BR       4#
3961 023034 020227 160001      3# :    CMP      R2,#160001      ; WAS UNIT NOT READY AT STARTUP?
3962 023040 001012      BNE     30#      ; BR IF NO.
3963 023042      PRINTS  #DEVNRD,R3
023042 010346      MOV      R3,-(SP)
023044 012746 023331      MOV      #DEVNRD,-(SP)
023050 012746 000002      MOV      #2,-(SP)
023054 010600      MOV      SP,R0
023056 104416      TRAP     C#PNTS
023060 062706 000006      ADD      #6,SP
3964 023064 000414      BR       4#
3965 023066 042702 170000      30# :    BIC     #C7777,R2
3966 023072      PRINTS  #DEVDR0,R3,R2
023072 010246      MOV      R2,-(SP)
023074 010346      MOV      R3,-(SP)
023076 012746 023412      MOV      #DEVDR0,-(SP)
023102 012746 000003      MOV      #3,-(SP)
023106 010600      MOV      SP,R0
023110 104416      TRAP     C#PNTS
023112 062706 000010      ADD      #10,SP
3967 023116 062704 000002      4# :    ADD      #2,R4
3968 023122 005203      INC      R3
3969 023124 020427 003372      CMP      R4,#ERTABE
3970 023130 103701      BLO     1#
3971 023132 012604      MOV      (SP)+,R4
3972 023134 012603      MOV      (SP)+,R3
3973 023136 012602      MOV      (SP)+,R2
3974 023140      ENDRPT      ; UNUSED.
023140      L10035:
023140 104425      TRAP     C#RPT
3975
3976 023142      045      116      045  DEVSUM: .ASCIZ /#N#ADEVICE STATUS SUMMARY:#N/
3977 023177      045      101      040  DEVONL: .ASCIZ /#A UNIT #D3#A ONLINE, ERRORS = #D#N/
3978 023247      045      101      040  DEVNXR: .ASCIZ /#A UNIT #D3#A DROPPED, NON-EXISTENT REGISTER#N/
3979 023331      045      101      040  DEVNRD: .ASCIZ /#A UNIT #D3#A DROPPED, NOT READY AT STARTUP#N/
3980 023412      045      101      040  DEVDR0: .ASCIZ /#A UNIT #D3#A DROPPED, ERRORS = #D#N/
3981      .EVEN
3982
3983 023462      ENDMOD
3984

```



K8

CLEAN-UP AND REPORT CODING SECTIONS

3988  
3989  
3990  
3997

.TITLE TEST 1 - HARDWARE TEST 1-8 TESTS

3998 023462  
023462

BGNMOD TSV7B

TSV7B::

4004













TEST 1: WRITE TAPE MARK RETRY

```

024424 027574 .WORD T29MLK
024426 012144 .WORD SFIMSG
4211 024430 DOCLN ;DROP IT
024430 104444 TRAP C#DCLN
4212 024432 005237 002214 41#: INC FATFLG ;ERROR COUNT
4216 024436 005237 002214 41#: ERRHRD ERRNO,T29WRT,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
024436 104456 TRAP C#ERHRD
024440 000160 .WORD 112
024442 027661 .WORD T29WRT
024444 012156 .WORD PKTSSR
4217 024446 75#: CKLOOP ;LOOP IF SELECTED
024446 104406 TRAP C#CLP1
4218 024450 012737 000001 026372 MOV #1,T29RB ;NUMBER OF RECORDS TO SPACE OVER
4219 024456 012737 140410 026370 MOV #140410,T29PK3 ;SET UP COMMAND IN APCKET ;SET
UP SPACE REVERSE
4220 024464 012704 026370 MOV #T29PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
4221 024470 010465 000000 MOV R4,TSDB(R5) ;ISSUE COMMAND
4222 024474 004737 016360 JSR PC,WAITF ;WAIT FOR SSR TO SET
4223 024500 016501 000002 MOV TSSR(R5),R1 ;GET TSSR CONTENTS
4224 024504 012702 000200 MOV #SSR,R2 ;SET UP EXPECTED
4225 024510 020102 CMP R1,R2 ;ARE THEY EQUAL
4226 024512 001406 BEQ 175# ;BR, IF OK
4227 024514 005237 002214 INC FATFLG ;ERROR COUNT
4231 024520 005237 002214 ERRHRD ERRNO,T29WDE,PKTSSR ;TSSR INCORRECT AFTER READ DATA
024520 104456 TRAP C#ERHRD
024522 000161 .WORD 113
024524 027512 .WORD T29WDE
024526 012156 .WORD PKTSSR
4232 024530 175#: CKLOOP ;LOOP IF SELECTED
024530 104406 TRAP C#CLP1
4233 024532 013737 003120 026372 MOV FREE,T29RB ;ADDRESS OF BUFFER
4234 024540 012737 141011 026370 MOV #141011,T29PK3 ;WRITE TAPE MARK RETRY,ACK,CVC=1 COMD.
4235 024546 012704 026370 MOV #T29PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
4236 024552 010465 000000 MOV R4,TSDB(R5) ;ISSUE COMMAND
4237 024556 004737 016360 JSR PC,WAITF ;WAIT FOR SSR TO SET
4238 024562 016501 000002 MOV TSSR(R5),R1 ;GET TSSR CONTENTS
4239 024566 012702 100204 MOV #SSR!SC!BIT2,R2 ;SET UP EXPECTED
4240 024572 020102 CMP R1,R2 ;ARE THEY EQUAL
4241 024574 001406 BEQ 180# ;BR, IF OK
4242 024576 005237 002214 INC FATFLG ;ERROR COUNT
4246 024602 005237 002214 ERRHRD ERRNO,T29WDE,PKTSSR ;TSSR INCORRECT AFTER READ DATA
024602 104456 TRAP C#ERHRD
024604 000162 .WORD 114
024606 027512 .WORD T29WDE
024610 012156 .WORD PKTSSR
4247 024612 180#: CKLOOP ;LOOP IF SELECTED
024612 104406 TRAP C#CLP1
4248 024614 013701 026306 MOV T29RFR+14,R1 ;GET XST3 STATUS WORD
4249 024620 010102 MOV R1,R2 ;SET UP EXPECTED
4250 024622 052702 000001 BIS #BIT0,R2 ;SET THE RIB BIT
4251 024626 020102 CMP R1,R2 ;ARE THEY EQUAL
4252 024630 001406 BEQ 190# ;BR, IF EQUAL (GOOD)
4253 024632 005237 002214 INC FATFLG ;ERROR COUNT
4257 024636 005237 002214 ERRHRD ERRNO,T29RIB,EXPREC ;NEF SHOULD BE SET
024636 104456 TRAP C#ERHRD
024640 000163 .WORD 115
024642 031654 .WORD T29RIB
024644 015604 .WORD EXPREC

```















## TEST 1: WRITE TAPE MARK RETRY

```

4440 025644 012737 140011 026370      MOV      #140011,T29PK3      ;WRITE TAPE MARK,ACK,CVC=1 COMMAND
4441 025652 012704 026370      MOV      #T29PK3,R4        ;SET UP R4 WITH PACKET ADDRESS
4442 025656 010465 000000      MOV      R4,TSDB(R5)       ;ISSUE COMMAND
4443 025662 004737 016360      JSR      PC,WAITF          ;WAIT FOR SSR TO SET
4444 025666 016501 000002      MOV      TSSR(R5),R1       ;GET TSSR CONTENTS
4445 025672 012702 000200      MOV      #SSR,R2          ;SET UP EXPECTED
4446 025676 020102      CMP      R1,R2             ;ARE THEY EQUAL
4447 025700 001406      BEQ      70$               ;BR, IF OK
4448 025702 005237 002214      INC      FATFLG            ;ERROR COUNT
4452 025706      ERRHRD  ERRNO,T29WDC,PKTSSR ;TSSR INCORRECT AFTER WRITE TAPE MARK
                                TRAP      C$ERHRD
                                .WORD    128
                                .WORD    T29WDC
                                .WORD    PKTSSR
                                TRAP      C$CLP1
025706 104456
025710 000200
025712 030627
025714 012156
4453 025716      70$:  CKLOOP                ;LOOP IF SELECTED
025716 104406
4454 025720 012703 000012      150$:  MOV      #10,R3      ;NUMBER OF RECORDS TO WRITE TM
4455 025724 012737 000001 026372      MOV      #1,T29RB          ;SET UP PACKET
4456 025732 012737 141011 026370      MOV      #141011,T29PK3   ;WRITE TAPE MARK RETRY,ACK,CVC=1 COMMAND
4457 025740 012704 026370      MOV      #T29PK3,R4       ;SET UP R4 WITH PACKET ADDRESS
4458 025744 010465 000000      155$:  MOV      R4,TSDB(R5)   ;ISSUE COMMAND
4459 025750 004737 016360      JSR      PC,WAITF          ;WAIT FOR SSR TO SET
4460 025754 016501 000002      MOV      TSSR(R5),R1       ;PICK UP TSSR
4461 025760 012702 000200      MOV      #SSR,R2          ;SET UP EXPECTED (SSR ONLY)
4462 025764 020102      CMP      R1,R2             ;WAS STATUS GOOD
4463 025766 001406      BEQ      165$              ;BR, IF TERMINATION WAS GOOD
4464 025770 005237 002214      INC      FATFLG            ;ERROR COUNT
4468 025774      ERRHRD  ERRNO,T29WDC,PKTSSR ;TSSR NOT CORRECT AFTER WRT TAPE M.
                                TRAP      C$ERHRD
                                .WORD    129
                                .WORD    T29WDC
                                .WORD    PKTSSR
                                TRAP      C$CLP1
025774 104456
025776 000201
026000 030627
026002 012156
4469 026004      165$:  CKLOOP                ;LOOP IF SELECTED
026004 104406
4470 026006 005303      DEC      R3                ;BUMP COUNTER DOWN
4471 026010 001355      BNE      155$              ;BR, IF LESS THAN 10 TAPE MARKS
4472 026012 012737 140410 026370      MOV      #140410,T29PK3   ;SPACE REVERSE,ACK,CVC=1, COMMAND
4473 026020 012737 000001 026372      MOV      #1,T29RB          ;NUMBER OF RECORDS TO SPACE BACK
4474 026026 012704 026370      MOV      #T29PK3,R4       ;SET UP R4 WITH PACKET ADDRESS
4475 026032 010465 000000      MOV      R4,TSDB(R5)       ;ISSUE COMMAND
4476 026036 004737 016360      JSR      PC,WAITF          ;WAIT FOR SSR TO SET
4477 026042 016501 000002      MOV      TSSR(R5),R1       ;GET TSSR CONTENTS
4478 026046 012702 100204      MOV      #SSR!SC!BIT2,R2   ;SET UP EXPECTED
4479 026052 020102      CMP      R1,R2             ;ARE THEY EQUAL
4480 026054 001406      BEQ      222$              ;BR, IF OK
4481 026056 005237 002214      INC      FATFLG            ;ERROR COUNT
4485 026062      ERRHRD  ERRNO,T29WDE,PKTSSR ;TSSR INCORRECT AFTER SPACE CMD.
                                TRAP      C$ERHRD
                                .WORD    130
                                .WORD    T29WDE
                                .WORD    PKTSSR
                                TRAP      C$CLP1
026062 104456
026064 000202
026066 027512
026070 012156
4486 026072      222$:  CKLOOP                ;LOOP IF SELECTED
026072 104406
4487 026074 012737 100410 026370      MOV      #100410,T29PK3   ;SPACE REVERSE,ACK, COMMAND
4488 026102 012737 000005 026372      MOV      #5,T29RB          ;NUMBER OF RECORDS TO SPACE BACK
4489 026110 012704 026370      MOV      #T29PK3,R4       ;SET UP R4 WITH PACKET ADDRESS
4490 026114 010465 000000      MOV      R4,TSDB(R5)       ;ISSUE COMMAND

```





## TEST 1: WRITE TAPE MARK RETRY

```

4542 026270 000000 T29DSW: .WORD 0 ;SELECT DRIVE 0
4543 026272 T29BFR: .BLKW 25. ;MESSAGE BUFFER
4544
4545 ;WRITE SUBSYSTEM MEMORY COMMAND PACKET
4546
4548 026360 T29PK2: .=<.10>&177770
4550 026360 T29PK2: .WORD 100006 ;WRITE SUB SYS MEM COMMAND, AND ACK
4551 026360 100006 T29PK2: .WORD T29BF2 ;ADDRESS OF SELECT BLOCK DATA
4552 026362 026400 T29PK2: .WORD 0
4553 026364 000000 T29PK2: .WORD 6. ;SIZE OF DATA PACKET
4554 026366 000006
4555
4559 026370 T29PK3: .WORD 140005 ;WRITE TAPE MARK RETRY COMMAND, CVC=1 AND ACK
4560 026370 140005
4561 026372 T29RB: .WORD FREE ;ADDRESS OF WRITE BUFFER
4562 026372 003120 T29WB: .WORD 0
4563 026374 000000 T29SZ: .WORD 0 ;SIZE OF BUFFER (EXTENT)
4564 026376 000000 T29SZ: .EVEN
4565
4566
4567
4568
4569 026400 T29BF2:
4570 026400 010 T29BS0: .BYTE 10 ;BSELO AREA
4571 026401 200 T29BS1: .BYTE 200 ;BSEL1 AREA
4572 026402 000000 T29S2: .WORD 0 ;SEL 2 AREA
4573 026404 000000 T29S3: .WORD 0 ;DATA AREA
4574
4575
4576 ;EVEN
4577 ;TAPE MOTION PACKET COMMAND VALUES
4578
4579 026406 140001 T29RN: .WORD 140001 ;READ DATA
4580 026410 140401 T29WDR: .WORD 140401 ;READ DATA REVERSE
4581 026412 141001 T29CON: .WORD 141001 ;READ PREVIOUS OPP=0
4582 026414 161001 .WORD 161001 ;READ PREVIOUS OPP=1
4583 026416 141401 .WORD 141401 ;WRITE TAPE MARK RETRY NEXT OPP=0
4584 026420 161401 .WORD 161401 ;WRITE TAPE MARK RETRY NEXT OPP=1
4585 026422 177777 .WORD 177777 ;END OF DATA
4586
4587
4588 026424 000000 T29CNT: .WORD 0 ;TAPE RECORD COUNTER STORAGE AREA
4589
4590 026426 000000 T29RSZ: .WORD 0 ;RECORD STORAGE SIZE AREA
4591 026430 000000 T29DLY: .WORD ;DELAY COUNTER STORAGE AREA
4592
4593 ;LOCAL TEXT MESSAGES FOR TEST
4594 ;-
4595
4596 026432 104 162 151 T29OFL: .ASCIZ 'Drive is OFFLINE'
4597 026453 124 141 160 T29WNG: .ASCIZ 'Tape Position Incorrect After WRITE TAPE MARK RETRY Previous (OPP=1)'
4598 026560 127 122 111 T29NEF: .ASCIZ 'WRITE TAPE MARK RETRY, At BOT, Failed To Set NEF (XST0)'
4599 026650 124 123 123 T29RDF: .ASCIZ 'TSSR Incorrect After READ DATA Command'
4600 026717 127 122 111 T29RRF: .ASCIZ 'WRITE TAPE MARK RETRY Previous (Space Reverse, Read Forward) Command Failed'
4601 027033 127 122 111 T29RRG: .ASCIZ 'WRITE TAPE MARK RETRY Previous (Read Forward, Space Reverse) Command Failed'
4602 027147 120 117 123 T29SC: .ASCIZ 'POSITION (Space Command) Failed, TSSR Not Correct'
4603 027231 122 111 102 T29LOR: .ASCIZ 'RIB NOT SET AFTER READ REVERSE INTO BOT'

```

TEST 1: WRITE TAPE MARK RETRY

4604	027301	124	123	123	T29WDF:	.ASCIZ	'TSSR Not Correct After Illegal Mode Bits Set'
4605	027356	111	154	154	T29LOQ:	.ASCIZ	'Illegal Mode Bits, Failed To Set ILC Bit In XST0'
4606	027437	127	122	111	T29SSR:	.ASCIZ	'WRITE TAPE MARK RETRY COMMAND Not Accepted'
4607	027512	124	123	123	T29WDE:	.ASCIZ	'TSSR Not Correct After SPACE REVERSE DATA Command'
4608	027574	052	052	052	T29WLK:	.ASCIZ	'*****TAPE IS WRITE-LOCKED AND WILL CAUSE ERRORS*****'
4609	027661	124	123	123	T29WRT:	.ASCIZ	'TSSR Not Correct After WRITE Command'
4610	027726	124	141	160	T29BOT:	.ASCIZ	'Tape Not At BOT After REWIND Command'
4611	027773	104	141	164	T29DTA:	.ASCIZ	'Data Written To Tape Not Equal To Data Read From Tape'
4612	030061	127	122	111	T29EOT:	.ASCIZ	'WRITE TAPE MARK RETRY DATA OVER EOT GAVE NO TAPE STATUS ALERT'
4613	030157	124	123	123	T29TM:	.ASCIZ	'TSSR Not Correct After SPACE REVERSE Into BOT'
4614	030235	122	145	167	T29RWN:	.ASCIZ	'Rewind (POSITION) Command Not Accepted'
4615	030304	122	101	115	T29RNC:	.ASCIZ	'RAM Error, Correct Data Pattern Not In Ram'
4616	030357	124	123	123	T29AM3:	.ASCIZ	'TSSR Init. Failed After WRITE TAPE MARK RETRY COMMAND'
4617	030445	104	162	151	T29OF7:	.ASCIZ	'Drive 7 Select Failed To Set "OFL" In TSSR'
4618	030520	124	123	123	T29WDD:	.ASCIZ	'TSSR Not Correct After WRITE TAPE MARK RETRY DATA Command, SWB Bit Set'
4619	030627	124	123	123	T29WDC:	.ASCIZ	'TSSR Not Correct After WRITE TAPE MARK RETRY DATA Command'
4620	030721	103	126	103	T29VCK:	.ASCIZ	'CVC Set, Didn't Reset VCK In Message Buffer'
4621	030774	124	123	102	T29BA:	.ASCIZ	'TSBA Not Correct After WRITE TAPE MARK RETRY DATA Command'
4622	031066	127	122	111	T29WSS:	.ASCIZ	'WRITE SUBSYSTEM MEMORY Command Not Accepted (RAM Read)'
4623	031155	122	145	141	T29LON:	.ASCIZ	'Reading Long Record Failed To Set RLL Bit In XST0'
4624	031237	122	145	141	T29LOP:	.ASCIZ	'Reading Long Record Failed To Set RLS Bit In XST0'
4625	031321	122	145	163	T29PBP:	.ASCIZ	'Residual Byte Count Incorrect After Short Record Read'
4626	031407	122	145	141	T29TRL:	.ASCIZ	'Reading Long Record Failed To Give Tape Status Alert'
4627	031475	104	141	164	T29NEQ:	.ASCIZ	'Data WRITE TAPE MARK RETRY From Tape Not Correct, After SWB=1'
4628	031573	124	123	123	T29RDG:	.ASCIZ	'TSSR Incorrect After READ REVERSE Into Tape Mark'
4629	031654	127	122	111	T29RIB:	.ASCIZ	'WRITE TAPE MARK RETRY At First Record, Failed To Set RIB (XST3)'
4630	031754	124	115	113	T29RRN:	.ASCIZ	'TMK (XST0) Failed To Set After READ REVERSE Into Tape Mark'
4631	032047	127	162	151	T29ID:	.ASCIZ	'Write Tape Mark Retry'
4632						.EVEN	
4633							
4634							
4635							
4636							
4637							
4638							
4639							
4640	032076				T29REST:		
4641	032076				SAVREG		;SAVE THE REGISTERS
4642	032102	012701	026250		MOV	#T29PACKET,R1	;START OF THE PACKET
4643	032106	012721	140004		MOV	#140004,(R1)	;WRITE SUBSYSTEM MEM. WITH ACK, CVC=1
4644	032112	012721	026260		MOV	#T29DATA,(R1)	;ADDRESS OF CHARACTERISTICS DATA BLOCK
4645	032116	005021			CLR	(R1)	;EXTENDED ADDRESS
4646	032120	012721	000012		MOV	#10,(R1)	;SIZE OF DATA BLOCK IN BYTES
4647	032124	012721	026272		MOV	#T29BFR,(R1)	;ADDRESS OF MESSAGE BUFFER
4648	032130	005021			CLR	(R1)	
4649	032132	012721	000024		MOV	#20,(R1)	;LENGTH OF MESSAGE BUFFER
4650	032136	005021			CLR	(R1)	
4651	032140	012711	000000		MOV	#0,(R1)	;SELECT DRIVE ZERO (0)
4652	032144	012702	000030		MOV	#24,R2	;NUMBER OF LOCATIONS TO BE CLEARED
4653	032150	012762	177777	026272 64:	MOV	#177777,T29BFR(R2)	;ALL ONES TO MESSAGE BUFFER
4654	032156	005742			TST	-(R2)	;NEXT LOCATION
4655	032160	020227	000000		CMF	R2,#0	;CHECK FOR END OF LOOP
4656	032164	001371			BNE	64:	;KEEP GOING UNTIL DONE
4657	032166	000207			RTS	PC	;RETURN
4658							
4659	032170				T29RT2:		
4660	032170				SAVREG		;SAVE THE REGISTERS



TEST 1: WRITE TAPE MARK RETRY

```

4661 032174 012701 026360      MOV      #T29PK2,R1          ;START OF THE PACKET
4662 032200 012721 140006      MOV      #140006,(R1)+      ;WRITE SUBSYSTEM MEM. WITH ACK,CVC=1.
4663 032204 012721 026400      MOV      #T29BF2,(R1)+     ;ADDRESS OF DATA BLOCK
4664 032210 005021              CLR      (R1)+              ;EXTENDED ADDRESS
4665 032212 012721 000006      MOV      #6,(R1)+          ;SIZE OF DATA BLOCK IN BYTES
4666 032216 005021              CLR      (R1)+
4667 032220 012701 026400      MOV      #T29BF2,R1        ;POINT TO DATA SEL AREA
4668 032224 005021              CLR      (R1)+
4669 032226 005011              CLR      (R1)
4670 032230 000207              RTS      PC                  ;RETURN
4671 032232
4672 032232
T29RT3: SAVREG                ;SAVE THE REGISTERS
4673 032236 012701 026370      MOV      #T29PK3,R1        ;START OF THE PACKET
4674 032242 012721 000000      MOV      #0,(R1)+          ;WRITE SUBSYSTEM MEM. WITH ACK,
4675 032246 012721 000000      MOV      #0,(R1)+          ;ADDRESS OF DATA BLOCK
4676 032252 005021              CLR      (R1)+              ;EXTENDED ADDRESS
4677 032254 012711 000000      MOV      #0,(R1)+          ;SIZE OF DATA BLOCK IN BYTES
4678 032260 000207              RTS      PC                  ;RETURN
4679 032262
      032262
      032262 104401

```

L10036: TRAP C#ETST

.SBTTL TEST 2: SKIP TAPE MARKS

```

4680
4681
4682
4683
4684
4685
4686
4687
4688
4689
4690
4691
4692
4693
4694
4695
4696
4697
4698

```

```

;
; THIS TEST VERIFIES PROPER OPERATION OF THE SKIP TAPE MARKS
; FORWARD AND SKIP TAPE MARKS REVERSE COMMANDS. PROPER OPERATION
; UNDER CONTROL OF ALL COMBINATIONS OF THE ENABLE SKIP TAPE MARKS
; STOP (ESS) AND ENABLE TAPE MARKS STOP OFF BOT (ENB) BITS SPECIFIED
; BY THE WRITE CHARACTERISTICS COMMAND. THE TEST CONSISTS OF THE
; FOLLOWING SUBTESTS (FOR EACH SUBTEST, THE TAPE IS FIRST WRITTEN
; WITH AN APPROPRIATE SERIES OF DATA RECORDS AND/OR TAPE MARKS
; AND/OR DOUBLE TAPE MARKS.
;
; THE TEST CONSISTS OF THE FOLLOWING 11 SUBTESTS
;
;
;
;
;

```

```

4698 032264
      032264
4699 032264 012737 006356 002172      MOV      #EPRT1,EPRTSW      T2::
4704 032272 012700 041161              MOV      #TST30ID,R0        ;PRIMARY ERROR MESSAGE
4705 032276 004737 016620              JSR      PC,TSTSETUP        ;ASCII MESSAGE TO IDENTIFY TEST
4706 032302 012737 000005 002210      MOV      #5,LOOPCNT        ;DO INITIAL TEST SETUP
                                      ;PERFORM 5 ITERATIONS
4707
4708
4709
4710
4711

```

```

;
; TEST 2. SUBTEST 1
;
; VERIFIES THAT A SKIP TAPE MARKS FORWARD COMMAND WITH
; A TAPE MARK COUNT OF 1 OPERATES PROPERLY. THE TAPE
; IS FIRST REWOUND, THEN WRITTEN WITH SEVERAL "FILES";
; EACH FILE CONSISTS OF A NUMBER OF DATA RECORDS
; FOLLOWED BY A TAPE MARK. THE FINAL FILE IS
; TERMINATED BY A DOUBLE TAPE MARK. EACH DATA RECORD
; CONTAINS A FILE NUMBER AND THE RECORD NUMBER WITHIN

```

4712  
4713  
4714  
4715  
4716  
4717  
4718





TEST 2: SKIP TAPE MARKS

```

4768 032446 010001          MOV    R0,R1          ;SAVE CONTENTS OF TSSR
4769 032450          ERRHRD  ERRNO,WRTMSG,SFMSG ;WRITE CHAF/ACTERISTISC FAILED
      032450 104456          TRAP   C#ERHRD
      032452 000312          .WORD  202
      032454 005054          .WORD  WRTMSG
      032456 012144          .WORD  SFMSG
4770 032460          23$:   CKLOOP          ;LOOP IF SELECTED          TRAP   C#CLP1
      032460 104406
4771
4772          ;*****
4773          ;
4774          ;ISSUE A REWIND TO TAPE DRIVE AND WAIT FOR SSR TO SET
4775          ;
4776          ;*****
4777
4778 032462 004737 011126          JSR    PC,REWIND          ;CALL TAPE REWIND COMMAND
4779 032466 103411          BCS   30$                ;BR, IF NO PROBLEM
4780 032470 010004          MOV    R0,R4            ;GET PACKET ADDRESS
4781 032472 016501 000002          MOV    TSSR(R5),R1       ;GET STATUS REGISTER
4782 032476 005237 002214          INC   FATFLG            ;ERROR COUNT
4786 032502          ERRHRD  ERRNO,T3ORWN,PKTSSR ;REWIND NOT ACCEPTED
      032502 104456          TRAP   C#ERHRD
      032504 000313          .WORD  203
      032506 040170          .WORD  T3ORWN
      032510 012156          .WORD  PKTSSR
4787 032512          30$:   CKLOOP          ;LOOP IF SELECTED          TRAP   C#CLP1
      032512 104406
4788
4789          ;*****
4790          ;
4791          ;GET EXTENDED STATUS REGISTER ZERO (XSTO) FROM MESSAGE BUFFER
4792          ;
4793          ;*****
4794
4795 032514 013701 036460          MOV    T3OBF+6,R1        ;PICK UP XSTO
4796 032520 010102          MOV    R1,R2            ;SET UP EXPECTED
4797 032522 052702 000002          BIS   @BIT1,R2          ;SET BOT BIT IN EXPECTED
4798 032526 020102          CMP   R1,R2            ;DOES EXP = REC'D
4799 032530 001406          BEQ   40$                ;BR, IF EQUAL (OK)
4800 032532 005237 002214          INC   FATFLG            ;ERROR COUNT
4804 032536          ERRHRD  ERRNO,T3OBOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
      032536 104456          TRAP   C#ERHRD
      032540 000314          .WORD  204
      032542 037771          .WORD  T3OBOT
      032544 015604          .WORD  EXPREC
4805 032546          40$:   CKLOOP          ;LOOP IF SELECTED          TRAP   C#CLP1
      032546 104406
4806 032550 012737 000001 036604          MOV    @1.,T3OFCN        ;SET "FILE" COUNTER AT 1 DECIMAL
4807 032556 012703 000001          MOV    @1,R3            ;ONE RECORD PER "FILE"
4808 032562 013737 003120 036552          MOV    FREE,T3OMB       ;SET UP PACKETS'S WRITE BUFFER
4809 032570 012737 003720 036556          MOV    @2000.,T3OSZ     ;SET RECORD SIZE AT 2000 BYTES
4810
4811          ;*****
4812          ;
4813          ;WRITE DATA,ACK,CVC=1 COMMAND
4814          ;
4815          ;*****

```

TEST 2: SKIP TAPE MARKS

```

4816
4817 032576 012737 140005 036550      MOV      #140005,T30PK3      ;WRITE DATA,ACK,CVC=1 COMMAND
4818 032604 012704 036550              MOV      #T30PK3,R4         ;SET UP R4 WITH PACKET ADDRESS
4819 032610 013702 036604              MOV      T30FCN,R2         ;GET FILE COUNTER
4820 032614 000302                      SWAB     R2                 ;MOVE TO UPPER BYTE
4821 032616 010301                      MOV      R3,R1             ;GET RECORD COUNTER
4822 032620 060201                      ADD      R2,R1             ;FILE COUNTER IN UPPER, RECORD # LOW
4823 032622 010177 150272              MOV      R1,@FREE          ;MOV TO OUT PUT BUFFER
4824 032626 010465 000000              MOV      R4,TSDB(R5)       ;ISSUE COMMAND
4825 032632 004737 016360              JSR      PC,WAITF          ;WAIT FOR SSR TO SET
4826 032636 016501 000002              MOV      TSSR(R5),R1       ;GET TSSR CONTENTS
4827 032642 012702 000200              MOV      #SSR,R2          ;SET UP EXPECTED
4828 032646 020102                      CMP      R1,R2             ;ARE THEY EQUAL
4829 032650 001406                      BEQ      70$               ;BR, IF OK
4830 032652 005237 002214              INC      FATFLG            ;ERROR COUNT
4834 032656                      ERRHRD  ERRNO,T30WDD,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
                                TRAP      C$ERHRD
                                .WORD    205
                                .WORD    T30WDD
                                .WORD    PKTSSR
                                TRAP      C$CLP1
                                .WORD    206
                                .WORD    T30WDC
                                .WORD    PKTSSR
4835 032666 104456                      70$:  CKLOOP              ;LOOP IF SELECTED
                                TRAP      C$CLP1
                                .WORD    206
                                .WORD    T30WDC
                                .WORD    PKTSSR
4836 032666 104406                      INC      R3                 ;COUNT THE RECORD COUNTER DOWN
4837 032672 005203                      CMP      R3,#21            ;AT 20 YET
4838 032676 001331                      BNE     65$               ;BR, IF NOT AT 20 RECORDS WRITTEN
4839
4840 ;*****
4841 ;
4842 ;WRITE TAPE MARK,ACK,CVC=1 COMMAND
4843 ;
4844 ;*****
4845
4846 032700 012737 141011 036550      MOV      #141011,T30PK3    ;WRITE TAPE MARK,ACK,CVC=1 COMMAND
4847 032706 012704 036550              MOV      #T30PK3,R4         ;SET UP R4 WITH PACKET ADDRESS
4848 032712 010465 000000              MOV      R4,TSDB(R5)       ;ISSUE COMMAND
4849 032716 004737 016360              JSR      PC,WAITF          ;WAIT FOR SSR TO SET
4850 032722 016501 000002              MOV      TSSR(R5),R1       ;PICK UP TSSR
4851 032726 012702 000200              MOV      #SSR,R2          ;SET UP EXPECTED (SSR ONLY)
4852 032732 020102                      CMP      R1,R2             ;WAS STATUS GOOD
4853 032734 001406                      BEQ      160$              ;BR, IF TERMINATION WAS GOOD
4854 032736 005237 002214              INC      FATFLG            ;ERROR COUNT
4858 032742                      ERRHRD  ERRNO,T30WDC,PKTSSR ;TSSR NOT CORRECT AFTER WRT TAPE M.
                                TRAP      C$ERHRD
                                .WORD    206
                                .WORD    T30WDC
                                .WORD    PKTSSR
                                TRAP      C$CLP1
                                .WORD    206
                                .WORD    T30WDC
                                .WORD    PKTSSR
4859 032752                      160$: CKLOOP              ;LOOP IF SELECTED
                                TRAP      C$CLP1
                                .WORD    206
                                .WORD    T30WDC
                                .WORD    PKTSSR
4860 032752 104406                      INC      T30FCN            ;COUNT THE "FILE" COUNTER DOWN
4861 032754 005237 036604              CMP      T30FCN,#6         ;WRITE 5 FILE TO TAPE
4862 032760 023727 036604 000006      BNE     64$               ;BR, IF NOT AT 5 FILES WRITTEN
4863
4864 ;*****
4865 ;
4866 ;WRITE TAPE MARK,ACK,CVC=1 COMMAND
4867 ;
4868 ;*****

```



TEST 2: SKIP TAPE MARKS

```

4869
4870 032770 012737 141011 036550      MOV      #141011,T3OPK3      ;WRITE TAPE MARK,ACK,CVC=1 COMMAND
4871 032776 012704 036550      MOV      #T3OPK3,R4        ;SET UP R4 WITH PACKET ADDRESS
4872 033002 010465 000000      MOV      R4,T30DB(R5)      ;ISSUE COMMAND
4873 033006 004737 016360      JSR      PC,WAITF          ;WAIT FOR SSR TO SET
4874 033012 016501 000002      MOV      TSSR(R5),R1      ;PICK UP TSSR
4875 033016 012702 000200      MOV      #SSR,R2          ;SET UP EXPECTED (SSR ONLY)
4876 033022 020102      CMP      R1,R2            ;WAS STATUS GOOD
4877 033024 001406      BEQ      165$             ;BR, IF TERMINATION WAS GOOD
4878 033026 005237 002214      INC      FATFLG            ;ERROR COUNT
4882 033032      ERRHRD  ERRNO,T30WDC,PKTSSR ;TSSR NOT CORRECT AFTER WRT TAPE M.
                                TRAP      C$ERHRD
                                .WORD     207
                                .WORD     T30WDC
                                .WORD     PKTSSR
4883 033042      165$:  CKLOOP          ;LOOP IF SELECTED
                                TRAP      C$CLP1
4884 033042      104406
4885
4886      ;*****
4887      ;ISSUE A REWIND TO TAPE DRIVE AND WAIT FOR SSR TO SET
4888      ;
4889      ;*****
4890
4891 033044 004737 011126      JSR      PC,REWIND        ;CALL TAPE REWIND COMMAND
4892 033050 103411      BCS     170$             ;BR, IF NO PROBLEM
4893 033052 010004      MOV      R0,R4            ;GET PACKET ADDRESS
4894 033054 016501 000002      MOV      TSSR(R5),R1      ;GET STATUS REGISTER
4895 033060 005237 002214      INC      FATFLG            ;ERROR COUNT
4899 033064      ERRHRD  ERRNO,T30RWN,PKTSSR ;REWIND NOT ACCEPTED
                                TRAP      C$ERHRD
                                .WORD     208
                                .WORD     T30RWN
                                .WORD     PKTSSR
4900 033074      170$:  CKLOOP          ;LOOP IF SELECTED
                                TRAP      C$CLP1
4901 033074      104406
4902
4903      ;*****
4904      ;GET EXTENDED STATUS REGISTER ZERO (XST0) FROM MESSAGE BUFFER
4905      ;
4906      ;*****
4907
4908 033076 013701 036460      MOV      T30BFR-6,R1      ;PICK UP XST0
4909 033102 010102      MOV      R1,R2            ;SET UP EXPECTED
4910 033104 052702 000002      BIS      #BIT1,R2         ;SET BOT BIT IN EXPECTED
4911 033110 020102      CMP      R1,R2            ;DOES EXP = REC'D
4912 033112 001406      BEQ      180$             ;BR, IF EQUAL (OK)
4913 033114 005237 002214      INC      FATFLG            ;ERROR COUNT
4917 033120      ERRHRD  ERRNO,T30BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
                                TRAP      C$ERHRD
                                .WORD     209
                                .WORD     T30BOT
                                .WORD     EXPREC
4918 033130      180$:  CKLOOP          ;LOOP IF SELECTED
                                TRAP      C$CLP1
4919 033132 012703 036566      MOV      #T30IMV,R3       ;SET UP POINTER TO COMMAND TABLE

```

TEST 2: SKIP TAPE MARKS

```

4920 033136 013737 002174 036450      MOV    UNITN,T30DSW      ;SET UP UNIT NUMBER
4921 033144 011337 036446      182$: MOV    (R3),T30ETM  ;GET NEXT COMMAND
4922 033150 012704 036430      MOV    @T30PACKET,R4   ;SUBROUTINE NEEDS PACKET ADDRESS
4923
4924      ;*****
4925      ;
4926      ;ISSUE WRITE CHARACTERISTICS COMMAND
4927      ;
4928      ;*****
4929
4930 033154 004737 010742      JSR    PC,WRTCHR        ;ISSUE WRITE CHARACTERISTICS
4931 033160 103407                BCS    188$             ;BR, IF COMMAND ISSUED OK
4932 033162 005237 002214      INC    FATFLG           ;ERROR COUNT
4936 033166 010001                MOV    R0,R1           ;SAVE CONTENTS OF TSSR
4937 033170                ERRHRD ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTIC FAILED
                                TRAP    C4ERHRD
                                .WORD   210
                                .WORD   WRTMSG
                                .WORD   SFIMSG
                                TRAP    C4CLP1
                                C4CLP1
033170 104456
033172 000322
033174 005054
033176 012144
4938 033200 188$: CKLOOP                ;LOOP IF SELECTED
033200 104406
4939
4940      ;*****
4941      ;
4942      ;SKIP TAPE MARK,ACK,CVC=1 COMMAND
4943      ;
4944      ;*****
4945
4946 033202 012737 141010 036550      MOV    @141010,T30PK3  ;SKIP TAPE MARK,ACK,CVC=1 COMMAND
4947 033210 012737 000001 036552      MOV    @1,T30RB        ;SET UP NUMBER TO SKIP
4948 033216 012704 036550      MOV    @T30PK3,R4     ;SET UP R4 WITH PACKET ADDRESS
4949 033222 010465 000000      189$: MOV    R4,TSDB(R5) ;ISSUE COMMAND
4950 033226 012737 176750 036606      190$: MOV    @65000,T30DLY ;SET UP DELAY COUNTER
4951 033234 004737 016360      JSR    PC,WAITF        ;WAIT FOR SSR TO SET
4952 033240 016501 000002      MOV    TSSR(R5),R1    ;PICK UP TSSR
4953 033244 032701 000200      BIT    @SSR,R1        ;IS SSR SET YET
4954 033250 001017      BNE    191$           ;BR, IF SSR IS SET
4955 033252      DELAY 250           ;CALL DELAY ROUTINE
                                MOV    @250,(PC)+
                                .WORD   0
                                MOV    L#DLY,(PC)+
                                .WORD   0
                                DEC    -6(PC)
                                BNE    .-4
                                DEC    -22(PC)
                                BNE    .-20
033252 012727 000250
033256 000000
033260 013727 002116
033264 000000
033266 005367 177772
033272 001375
033274 005367 177756
033300 001367
4956 033302 005337 036606      DEC    T30DLY         ;BUMP DELAY ROUTINE
4957 033306 001352      BNE    190$           ;BR, IF MORE DELAY TO GO
4958 033310 012702 000200      191$: MOV    @SSR,R2    ;SET UP EXPECTED (SSR ONLY)
4959 033314 020102      CMP    R1,R2          ;WAS STATUS GOOD
4960 033316 001406      BEQ    192$           ;BR, IF TERMINATION WAS GOOD
4961 033320 005237 002214      INC    FATFLG         ;ERROR COUNT
4965 033324      ERRHRD ERRNO,T30SKM,PKTSSR ;TSSR NOT CORRECT AFTER SKIP TAPE M.
                                TRAP    C4ERHRD
                                .WORD   211
                                .WORD   T30SKM
                                .WORD   PKTSSR
033324 104456
033326 000323
033330 037044
033332 012156

```



TEST 2: SKIP TAPE MARKS

```

4966 033334      192:  CKLOOP                ;LOOP IF SELECTED          TRAP  C#CLP1
      033334 104406
4967
4968 ;*****
4969 ;
4970 ;GET EXTENDED STATUS REGISTER ZERO (XSTO) FROM MESSAGE BUFFER
4971 ;
4972 ;*****
4973
4974 033336 013701 036460      MOV      T30BFR-6,R1      ;PICK UP XSTO
4975 033342 010102      MOV      R1,R2           ;SET UP EXPECTED
4976 033344 052702 100000     BIS      @BIT15,R2       ;SET TMK BIT IN EXPECTED
4977 033350 020102      CMP      R1,R2           ;DOES EXP = REC'D
4978 033352 001406      BEQ     195:            ;BR, IF EQUAL (OK)
4979 033354 005237 002214     INC     FATFLG           ;ERROR COUNT
4983 033360      ERRHRD  ERRNO,T30TMK,EXPREC ;TMK NOT SET AFTER WRT TAPE MARK
      033360 104456      TRAP   C#ERHRD
      033362 000324      .WORD 212
      033364 040444      .WORD T30TMK
      033366 015604      .WORD EXPREC
4984 033370      195:  CKLOOP                ;LOOP IF SELECTED          TRAP  C#CLP1
      033370 104406
4985 033372 012700 177777     MOV     #177777,R0       ;VALUE TO WRITTEN TO MEMORY
4986 033376 004737 017532     JSR    PC,FILLMEM       ;FILL MEM WITH ALL ONES
4987 033402 013737 003120 036552  MOV     FREE,T30RB       ;STARTING READ BUFFER ADDRESS
4988
4989 ;*****
4990 ;
4991 ;READ FORWARD,ACK,CVC-1 COMMAND
4992 ;
4993 ;*****
4994
4995 033410 012737 140001 036550     MOV     #140001,T30PK3   ;READ FORWARD,ACK,CVC-1 COMMAND
4996 033416 012704 036550     MOV     @T30PK3,R4       ;SET UP R4 WITH PACKET ADDRESS
4997 033422 012737 003720 036556     MOV     #2000.,T30SZ     ;SET UP RECORD SIZE IN PACKET
4998 033430 010465 000000     MOV     R4,TSD8(R5)      ;ISSUE COMMAND
4999 033434 004737 016360     JSR    PC,WAITF          ;WAIT FOR SSR TO SET
5000 033440 016501 000002     MOV     TSSR(R5),R1      ;GET TSSR CONTENTS
5001 033444 012702 000200     MOV     @SSR,R2          ;SET UP EXPECTED
5002 033450 020102      CMP     R1,R2           ;ARE THEY EQUAL
5003 033452 001406      BEQ     200:            ;BR, IF OK
5004 033454 005237 002214     INC     FATFLG           ;ERROR COUNT
5008 033460      ERRHRD  ERRNO,T30RDF,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
      033460 104456      TRAP   C#ERHRD
      033462 000325      .WORD 213
      033464 037343      .WORD T30RDF
      033466 012156      .WORD PKTSSR
5009 033470      200:  CKLOOP                ;LOOP IF SELECTED          TRAP  C#CLP1
      033470 104406
5010 033472 017701 147422     MOV     @FREE,R1         ;FIRST LOC IN READ BUFFER
5011 033476 012702 177777     MOV     #177777,R2       ;EXPECTED IF NO DATA TRANS.
5012 033502 020102      CMP     R1,R2           ;DID ANY DATA GET TRANSFERRED
5013 033504 001006      BNE     220:            ;BR, IF NO DATA TRANS (GOOD)
5014 033506 005237 002214     INC     FATFLG           ;ERROR COUNT
5018 033512      ERRHRD  ERRNO,T30DTR,EXPREC ;DATA TRANSFERRED ON READ TAPE MARK
      033512 104456      TRAP   C#ERHRD
      033514 000326      .WORD 214

```

TEST 2: SKIP TAPE MARKS

```

033516 041020 .WORD T30DTR
033520 015604 .WORD EXPREC
5019 033522 2204: CKLOOP ;LOOP IF SELECTED TRAP C4CLP1
033522 104406 ;SET UP RECORD NUMBER EXPECTED (FILE 2)
5020 033524 012702 001001 MOV #1001,R2 ;GET INFO FROM BUFFER
5021 033530 017701 147364 MOV @FREE,R1 ;ARE THEY EQUAL
5022 033534 020201 CMP R2,R1 ;BR, IF EQUAL (OK)
5023 033536 001406 BEQ 2284 ;ERROR COUNT
5024 033540 005237 002214 INC FATFLG ;RECORD POSITION WAS NOT CORRECT
5028 033544 ERRHRD ERRNO,T30PTB,EXPREC ;RECORD POSITION WAS NOT CORRECT
033544 104456 TRAP C4ERHRD
033546 000327 .WORD 215
033550 037172 .WORD T30PTB
033552 015604 .WORD EXPREC
5029 033554 2284: CKLOOP ;LOOP IF SELECTED TRAP C4CLP1
033554 104406

;*****
;ISSUE A REWIND TO TAPE DRIVE AND WAIT FOR SSR TO SET
;*****
5037 033556 004737 011126 JSR PC,REWIND ;CALL TAPE REWIND COMMAND
5038 033562 103411 BCS 2304 ;BR, IF NO PROBLEM
5039 033564 010004 MOV R0,R4 ;SAVE PACKET ADDRESS
5040 033566 016501 000002 MOV TSSR(R5),R1 ;GET TSSR STATUS
5041 033572 005237 002214 INC FATFLG ;ERROR COUNT
5045 033576 ERRHRD ERRNO,T30RWN,PKTSSR ;REWIND NOT ACCEPTED
033576 104456 TRAP C4ERHRD
033600 000330 .WORD 216
033602 040170 .WORD T30RWN
033604 012156 .WORD PKTSSR
5046 033606 2304: CKLOOP ;LOOP IF SELECTED TRAP C4CLP1
033606 104406

;*****
;GET EXTENDED STATUS REGISTER ZERO (XSTO) FROM MESSAGE BUFFER
;*****
5054 033610 013701 036460 MOV T30BFR-6,R1 ;PICK UP XSTO
5055 033614 010102 MOV R1,R2 ;SET UP EXPECTED
5056 033616 052702 000002 BIS @BIT1,R2 ;SET BOT BIT IN EXPECTED
5057 033622 020102 CMP R1,R2 ;DOES EXP = REC'D
5058 033624 001406 BEQ 2404 ;BR, IF EQUAL (OK)
5059 033626 005237 002214 INC FATFLG ;ERROR COUNT
5063 033632 ERRHRD ERRNO,T30BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
033632 104456 TRAP C4ERHRD
033634 000331 .WORD 217
033636 037771 .WORD T30BOT
033640 015604 .WORD EXPREC
5064 033642 2404: CKLOOP ;LOOP IF SELECTED TRAP C4CLP1
033642 104406
5065 033644 005723 TST (R3)+ ;POINT TO NEXT POSITION
5066 033646 011301 MOV (R3),R1 ;GET NEXT COMMAND ETC.

```





TEST 2: SKIP TAPE MARKS

```

5110 ;*****
5111 ;
5112 ;ISSUE WRITE CHARACTERISTICS COMMAND
5113 ;
5114 ;*****
5115
5116 034026 004737 010742 JSR PC,WRTCHR ;ISSUE WRITE CHARACTERISTICS
5117 034032 103407 BCS 23$ ;BR, IF COMMAND ISSUED OK
5118 034034 005237 002214 INC FATFLG ;ERROR COUNT
5122 034040 010001 MOV RO,R1 ;SAVE CONTENTS OF TSSR
5123 034042 ERRHRD ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTICSC FAILED
; TRAP C$ERHRD
; .WORD 219
; .WORD WRTMSG
; .WORD SFIMSG
5124 034052 23$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
5125 034052 104406
5126 ;*****
5127 ;
5128 ;ISSUE A REWIND TO TAPE DRIVE AND WAIT FOR SSR TO SET
5129 ;
5130 ;*****
5131
5132 034054 004737 011126 JSR PC,REWIND ;CALL TAPE REWIND COMMAND
5133 034060 103411 BCS 30$ ;BR, IF NO PROBLEM
5134 034062 010004 MOV RO,R4 ;GET PACKET ADDRESS
5135 034064 016501 000002 MOV TSSR(R5),R1 ;GET STATUS REGISTER
5136 034070 005237 002214 INC FATFLG ;ERROR COUNT
5140 034074 ERRHRD ERRNO,T3ORWN,PKTSSR ;REWIND NOT ACCEPTED
; TRAP C$ERHRD
; .WORD 220
; .WORD T3ORWN
; .WORD PKTSSR
5141 034104 30$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
5142 034104 104406
5143 ;*****
5144 ;
5145 ;GET EXTENDED STATUS REGISTER ZERO (XSTO) FROM MESSAGE BUFFER
5146 ;
5147 ;*****
5148
5149 034106 013701 036460 MOV T30BFR-6,R1 ;PICK UP XSTO
5150 034112 010102 MOV R1,R2 ;SET UP EXPECTED
5151 034114 052702 000002 BIS #BIT1,R2 ;SET BOT BIT IN EXPECTED
5152 034120 020102 CMP R1,R2 ;DOES EXP = REC'D
5153 034122 001406 BEQ 40$ ;BR, IF EQUAL (OK)
5154 034124 005237 002214 INC FATFLG ;ERROR COUNT
5158 034130 ERRHRD ERRNO,T30BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
; TRAP C$ERHRD
; .WORD 221
; .WORD T30BOT
; .WORD EXPREC
5159 034140 40$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
5160 034142 012737 000001 036604 MOV #1.,T30FCN ;SET "FILE" COUNTER AT 1 DECIMAL

```



TEST 2: SKIP TAPE MARKS

```

5161 034150 012703 000001      644:  MOV    #1,R3           ;ONE RECORD PER "FILE"
5162 034154 013737 003120 036552 654:  MOV    FREE,T30WB        ;SET UP PACKETS'S WRITE BUFFER
5163 034162 012737 000024 036556  MOV    #20.,T30SZ       ;SET RECORD SIZE AT 2000 BYTES
5164
5165 ;*****
5166 ;
5167 ;WRITE DATA,ACK,CVC=1 COMMAND
5168 ;
5169 ;*****
5170
5171 034170 012737 140005 036550      MOV    #140005,T30PK3    ;WRITE DATA,ACK,CVC=1 COMMAND
5172 034176 012704 036550          MOV    #T30PK3,R4       ;SET UP R4 WITH PACKET ADDRESS
5173 034202 013702 036604          MOV    T30FCN,R2        ;GET FILE COUNTER
5174 034206 000302          SWAB   R2               ;MOVE TO UPPER BYTE
5175 034210 010301          MOV    R3,R1           ;GET RECORD COUNTER
5176 034212 060201          ADD    R2,R1           ;FILE COUNTER IN UPPER, RECORD # LOW
5177 034214 010177 146700          MOV    R1,@FREE        ;MOV TO OUT PUT BUFFER
5178 034220 010465 000000          MOV    R4,TSDB(R5)     ;ISSUE COMMAND
5179 034224 004737 016360          JSR   PC,WAITF         ;WAIT FOR SSR TO SET
5180 034230 016501 000002          MOV    TSSR(R5),R1     ;GET TSSR CONTENTS
5181 034234 012702 000200          MOV    #SSR,R2        ;SET UP EXPECTED
5182 034240 020102          CMP    R1,R2           ;ARE THEY EQUAL
5183 034242 001406          BEQ   704              ;BR, IF OK
5184 034244 005237 002214          INC    FATFLG          ;ERROR COUNT
5188 034250          ERRHRD ERRNO,T30WDD,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
      034250 104456          TRAP  C4ERHRD
      034252 000336          .WORD 222
      034254 037120          .WORD T30WDD
      034256 012156          .WORD PKTSSR
5189 034260          704:  CKLOOP           ;LOOP IF SELECTED
      034260 104406          TRAP  C4CLP1
5190 034262 005203          INC    R3              ;COUNT THE RECORD COUNTER DOWN
5191 034264 020327 000021          CMP    R3,#21         ;AT 20 YET
5192 034270 001331          BNE   654              ;BR, IF NOT AT 20 RECORDS WRITTEN
5193
5194 ;*****
5195 ;
5196 ;WRITE TAPE MARK,ACK,CVC=1 COMMAND
5197 ;
5198 ;*****
5199
5200 034272 012737 141011 036550      MOV    #141011,T30PK3    ;WRITE TAPE MARK,ACK,CVC=1 COMMAND
5201 034300 012704 036550          MOV    #T30PK3,R4       ;SET UP R4 WITH PACKET ADDRESS
5202 034304 010465 000000          MOV    R4,TSDB(R5)     ;ISSUE COMMAND
5203 034310 004737 016360          JSR   PC,WAITF         ;WAIT FOR SSR TO SET
5204 034314 016501 000002          MOV    TSSR(R5),R1     ;PICK UP TSSR
5205 034320 012702 000200          MOV    #SSR,R2        ;SET UP EXPECTED (SSR ONLY)
5206 034324 020102          CMP    R1,R2           ;WAS STATUS GOOD
5207 034326 001406          BEQ   1604             ;BR, IF TERMINATION WAS GOOD
5208 034330 005237 002214          INC    FATFLG          ;ERROR COUNT
5212 034334          ERRHRD ERRNO,T30WDC,PKTSSR ;TSSR NOT CORRECT AFTER WRT TAPE M.
      034334 104456          TRAP  C4ERHRD
      034336 000337          .WORD 223
      034340 040312          .WORD T30WDC
      034342 012156          .WORD PKTSSR
5213 034344          1604: CKLOOP           ;LOOP IF SELECTED
      034344 104406          TRAP  C4CLP1

```

TEST 2: SKIP TAPE MARKS

```

5214 034346 005237 036604          INC      T30FCN          ;COUNT THE "FILE" COUNTER DOWN
5215 034352 023727 036604 000031  CMP      T30FCN,#25.    ;WRITE 25 FILES TO TAPE
5216 034360 001273          BNE      64$            ;BR, IF NOT AT 25 FILES WRITTEN
5217
5218 ;*****
5219 ;
5220 ;WRITE TAPE MARK,ACK,CVC=1 COMMAND
5221 ;
5222 ;*****
5223
5224 034362 012737 141011 036550          MOV      #141011,T30PK3 ;WRITE TAPE MARK,ACK,CVC=1 COMMAND
5225 034370 012704 036550          MOV      #T30PK3,R4     ;SET UP R4 WITH PACKET ADDRESS
5226 034374 010465 000000          MOV      R4,TSDB(R5)    ;ISSUE COMMAND
5227 034400 004737 016360          JSR      PC,WAITF       ;WAIT FOR SSR TO SET
5228 034404 016501 000002          MOV      TSSR(R5),R1    ;PICK UP TSSR
5229 034410 012702 000200          MOV      #SSR,R2       ;SET UP EXPECTED (SSR ONLY)
5230 034414 020102          CMP      R1,R2         ;WAS STATUS GOOD
5231 034416 001406          BEQ      165$          ;BR, IF TERMINATION WAS GOOD
5232 034420 005237 002214          INC      FATFLG         ;ERROR COUNT
5236 034424          ERRHRD  ERRNO,T30WDC,PKTSSR ;TSSR NOT CORRECT AFTER WRT TAPE M.
                                TRAP      C#ERHRD
                                .WORD     224
                                .WORD     T30WDC
                                .WORD     PKTSSR
5237 034434 104406          165$:  CKLOOP          ;LOOP IF SELECTED
                                TRAP      C#CLP1
5238
5239 ;*****
5240 ;
5241 ;ISSUE A REWIND TO TAPE DRIVE AND WAIT FOR SSR TO SET
5242 ;
5243 ;*****
5244
5245 034436 004737 011126          JSR      PC,REWIND      ;CALL TAPE REWIND COMMAND
5246 034442 103411          BCS      170$          ;BR, IF NO PROBLEM
5247 034444 010004          MOV      R0,R4         ;GET PACKET ADDRESS
5248 034446 016501 000002          MOV      TSSR(R5),R1    ;GET STATUS REGISTER
5249 034452 005237 002214          INC      FATFLG         ;ERROR COUNT
5253 034456          ERRHRD  ERRNO,T30RWN,PKTSSR ;REWIND NOT ACCEPTED
                                TRAP      C#ERHRD
                                .WORD     225
                                .WORD     T30RWN
                                .WORD     PKTSSR
5254 034466 104406          170$:  CKLOOP          ;LOOP IF SELECTED
                                TRAP      C#CLP1
5255
5256 ;*****
5257 ;
5258 ;GET EXTENDED STATUS REGISTER ZERO (XST0) FROM MESSAGE BUFFER
5259 ;
5260 ;*****
5261
5262 034470 013701 036460          MOV      T30BFR+6,R1    ;PICK UP XST0
5263 034474 010102          MOV      R1,R2         ;SET UP EXPECTED
5264 034476 052702 000002          BIS      #BIT1,R2       ;SET BOT BIT IN EXPECTED
5265 034502 020102          CMP      R1,R2         ;DOES EXP = REC'D
5266 034504 001406          BEQ      180$          ;BR, IF EQUAL (OK)

```



TEST 2: SKIP TAPE MARKS

```

5267 034506 005237 002214          INC      FATFLG          ;ERROR COUNT
5271 034512          ERRHRD  ERRNO,T30BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
      034512 104456          TRAP      C#ERHRD
      034514 000342          .WORD    226
      034516 037771          .WORD    T30BOT
      034520 015604          .WORD    EXPREC
5272 034522          180$:  CKLOOP          ;LOOP IF SELECTED
      034522 104406          TRAP      C#CLP1
5273 034524 012737 000002 036604  MOV      #2,T30FCN      ;SET TO NUMBER OF SKIP "FILES"
5274 034532 012703 036566          MOV      #T30IMV,R3    ;SET UP POINTER TO COMMAND TABLE
5275 034536 013737 002174 036450  MOV      UNITN,T30DSW   ;SET UP UNIT NUMBER
5276 034544 011337 036446 182$:  MOV      (R3),T30ETM ;GET NEXT COMMAND
5277 034550 012704 036430  MOV      #T30PACKET,R4 ;SUBROUTINE NEEDS PACKET ADDRESS
5278
5279
5280
5281 ;*****
5282 ;ISSUE WRITE CHARACTERISTICS COMMAND
5283 ;
5284 ;*****
5285 034554 004737 010742          JSR      PC,WRTCHR      ;ISSUE WRITE CHARACTERISTICS
5286 034560 103407          BCS      188$          ;BR, IF COMMAND ISSUED OK
5287 034562 005237 002214          INC      FATFLG          ;ERROR COUNT
5291 034566 010001          MOV      R0,R1          ;SAVE CONTENTS OF TSSR
5292 034570          ERRHRD  ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTICSC
      034570 104456          TRAP      C#ERHRD
      034572 000343          .WORD    227
      034574 005054          .WORD    WRTMSG
      034576 012144          .WORD    SFIMSG
5293 034600          188$:  CKLOOP          ;LOOP IF SELECTED
      034600 104406          TRAP      C#CLP1
5294
5295
5296
5297 ;*****
5298 ;SKIP TAPE MARK,ACK,CVC=1 COMMAND
5299 ;
5300 ;*****
5301 034602 012737 141010 036550  MOV      #141010,T30PK3 ;SKIP TAPE MARK,ACK,CVC=1 COMMAND
5302 034610 013737 036604 036552  MOV      T30FCN,T30RB   ;SET UP NUMBER TO SKIP
5303 034616 012704 036550          MOV      #T30PK3,R4    ;SET UP R4 WITH PACKET ADDRESS
5304 034622 010465 000000 189$:  MOV      R4,TSD8(R5)  ;ISSUE COMMAND
5305 034626 012737 176750 036606  MOV      #65000,T30DLY ;SET UP DELAY COUNTER
5306 034634 004737 016360 190$:  JSR      PC,WAITF      ;WAIT FOR SSR TO SET
5307 034640 016501 000002  MOV      TSSR(R5),R1   ;PICK UP TSSR
5308 034644 032701 000200  BIT      #SSR,R1       ;IS SSR SET YET
5309 034650 001017          BNE      191$          ;BR, IF SSR IS SET
5310 034652          DELAY  250          ;CALL DELAY ROUTINE
      034652 012727 000250          MOV      #250,(PC)-
      034656 000000          .WORD    0
      034660 013727 002116          MOV      L#DLY,(PC)-
      034664 000000          .WORD    0
      034666 005367 177772          DEC      -6(PC)
      034672 001375          BNE      -.4
      034674 005367 177756          DEC      -22(PC)
      034700 001367          BNE      -.20
5311 034702 005337 036606          DEC      T30DLY        ;BUMP DELAY ROUTINE

```

TEST 2: SKIP TAPE MARKS

```

5312 034706 001352
5313 034710 012702 000200      1914:  BNE      1904      ;BR, IF MORE DELAY TO GO
5314 034714 020102              MOV      @SSR,R2      ;SET UP EXPECTED (SSR ONLY)
5315 034716 001406              CMP      R1,R2        ;WAS STATUS GOOD
5316 034720 005237 002214      BEQ      1924      ;BR, IF TERMINATION WAS GOOD
5320 034724              INC      FATFLG        ;ERROR COUNT
                    ERRHRD  ERRNO,T30SKM,PKTSSR ;TSSR NOT CORRECT AFTER SKIP TAPE M.
                    TRAP    C#ERHRD
                    .WORD   228
                    .WORD   T30SKM
                    .WORD   PKTSSR
                    TRAP    C#CLP1
5321 034734 104406      1924:  CKLOOP              ;LOOP IF SELECTED
5322
5323      ;*****
5324      ;
5325      ;GET EXTENDED STATUS REGISTER ZERO (XSTO) FROM MESSAGE BUFFER
5326      ;
5327      ;*****
5328
5329 034736 013701 036460      MOV      T30BFR+6,R1 ;PICK UP XSTO
5330 034742 010102      MOV      R1,R2        ;SET UP EXPECTED
5331 034744 052702 100000      BIS      @BIT15,R2   ;SET TMK BIT IN EXPECTED
5332 034750 020102      CMP      R1,R2        ;DOES EXP = REC'D
5333 034752 001406      BEQ      1954      ;BR, IF EQUAL (OK)
5334 034754 005237 002214      INC      FATFLG        ;ERROR COUNT
5338 034760              ERRHRD  ERRNO,T30TMK,EXPREC ;TMK NOT SET AFTER WRT TAPE MARK
                    TRAP    C#ERHRD
                    .WORD   229
                    .WORD   T30TMK
                    .WORD   EXPREC
5339 034770              1954:  CKLOOP              ;LOOP IF SELECTED
                    TRAP    C#CLP1
5340 034772 012700 177777      MOV      @177777,R0   ;VALUE TO WRITTEN TO MEMORY
5341 034776 004737 017532      JSR      PC,FILLMEM   ;FILL MEM WITH ALL ONES
5342 035002 013737 003120 036552      MOV      FREE,T30RB   ;STARTING READ BUFFER ADDRESS
5343
5344      ;*****
5345      ;
5346      ;READ FORWARD,ACK,CVC=1 COMMAND
5347      ;
5348      ;*****
5349
5350 035010 012737 140001 036550      MOV      @140001,T30PK3 ;READ FORWARD,ACK,CVC=1 COMMAND
5351 035016 012704 036550      MOV      @T30PK3,R4   ;SET UP R4 WITH PACKET ADDRESS
5352 035022 012737 000024 036556      MOV      @20.,T30SZ   ;SET UP RECORD SIZE IN PACKET
5353 035030 010465 000000      MOV      R4,T30DB(R5) ;ISSUE COMMAND
5354 035034 004737 016360      JSR      PC,WAITF     ;WAIT FOR SSR TO SET
5355 035040 016501 000002      MOV      TSSR(R5),R1  ;GET TSSR CONTENTS
5356 035044 012702 000200      MOV      @SSR,R2      ;SET UP EXPECTED
5357 035050 020102      CMP      R1,R2        ;ARE THEY EQUAL
5358 035052 001406      BEQ      2004      ;BR, IF OK
5359 035054 005237 002214      INC      FATFLG        ;ERROR COUNT
5363 035060              ERRHRD  ERRNO,T30RDF,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
                    TRAP    C#ERHRD
                    .WORD   230
                    .WORD   T30RDF
                    .WORD   PKTSSR
035060 104456
035062 000346
035064 037343
035066 012156

```



TEST 2: SKIP TAPE MARKS

```

5364 035070          200+:  CKLOOP          ;LOOP IF SELECTED          TRAP      C4CLP1
      035070 104406          ;FIRST LOC IN READ BUFFER
5365 035072 017701 146022      MOV      @FREE,R1          ;EXPECTED IF NO DATA TRANS.
5366 035076 012702 177777      MOV      @177777,R2       ;DID ANY DATA GET TRANSFERRED
5367 035102 020102          CMP      R1,R2           ;BR, IF NO DATA TRANS (GOOD)
5368 035104 001006          BNE     220$             ;ERROR COUNT
5369 035106 005237 002214      INC     FATFLG           ;DATA TRANSFERRED ON READ TAPE MARK
5373 035112          ERRHRD  ERRNO,T30DTR,EXPREC ;
      035112 104456          TRAP     C4ERHRD
      035114 000347          .WORD   231
      035116 041020          .WORD   T30DTR
      035120 015604          .WORD   EXPREC

5374 035122          220+:  CKLOOP          ;LOOP IF SELECTED          TRAP      C4CLP1
      035122 104406          ;GET NUMBER OF SKIPS
5375 035124 013702 036604      MOV     T30FCN,R2        ;SET TO CORRECT FILE VALUE
5376 035130 005202          INC     R2               ;SWAP BYTE HALVES
5377 035132 000302          SWAB   R2               ;SET FOR RECORD #1
5378 035134 052702 000001      BIS     @P10,R2         ;GET INFO FROM BUFFER
5379 035140 017701 145754      MOV     @FREE,R1        ;ARE THEY EQUAL
5380 035144 020201          CMP     R2,R1           ;BR, IF EQUAL (OK)
5381 035146 001406          BEQ    228$             ;ERROR COUNT
5382 035150 005237 002214      INC     FATFLG           ;RECORD POSITION WAS NOT CORRECT
5386 035154          ERRHRD  ERRNO,T30PTB,EXPREC ;
      035154 104456          TRAP     C4ERHRD
      035156 000350          .WORD   232
      035160 037172          .WORD   T30PTB
      035162 015604          .WORD   EXPREC

5387 035164          228+:  CKLOOP          ;LOOP IF SELECTED          TRAP      C4CLP1
      035164 104406          ;

5388
5389          ;*****
5390          ;
5391          ;ISSUE A REWIND TO TAPE DRIVE AND WAIT FOR SSR TO SET
5392          ;
5393          ;*****
5394
5395 035166 004737 011126      JSR     PC,REVIND        ;CALL TAPE REWIND COMMAND
5396 035172 103411          BCS    230$             ;BR, IF NO PROBLEM
5397 035174 010004          MOV     R0,R4           ;SAVE PACKET ADDRESS
5398 035176 016501 000002      MOV     TSSR(R5),R1     ;GET TSSR STATUS
5399 035202 005237 002214      INC     FATFLG           ;ERROR COUNT
5403 035206          ERRHRD  ERRNO,T30RWN,PKTSSR ;REWIND NOT ACCEPTED
      035206 104456          TRAP     C4ERHRD
      035210 000351          .WORD   233
      035212 040170          .WORD   T30RWN
      035214 012156          .WORD   PKTSSR

5404 035216          230+:  CKLOOP          ;LOOP IF SELECTED          TRAP      C4CLP1
      035216 104406          ;

5405
5406          ;*****
5407          ;
5408          ;GET EXTENDED STATUS REGISTER ZERO (XSTO) FROM MESSAGE BUFFER
5409          ;
5410          ;*****
5411
5412 035220 013701 036460      MOV     T30BFR+6,R1     ;PICK UP XSTO
5413 035224 010102          MOV     R1,R2           ;SET UP EXPECTED

```





TEST 2: SKIP TAPE MARKS

```

035372 013727 002116
035376 000000
035400 005367 177772
035404 001375
035406 005367 177756
035412 001367
5462 035414 005337 036606
5463 035420 001356
5464 035422 005237 002214
5468 035426 010001
5469 035430
035430 104455
035432 000353
035434 003650
035436 012144
5470 035440
5471 035440 013737 002174 036450
5472 035446 012704 036430
5473
5474
5475
5476
5477
5478
5479
5480 035452 004737 010742
5481 035456 103407
5482 035460 005237 002214
5486 035464 010001
5487 035466
035466 104456
035470 000354
035472 005054
035474 012144
5488 035476
035476 104406
5489
5490
5491
5492
5493
5494
5495
5496 035500 004737 011126
5497 035504 103411
5498 035506 010004
5499 035510 016501 000002
5500 035514 005237 002214
5504 035520
035520 104456
035522 000355
035524 040170
035526 012156
5505 035530
035530 104406
5506
5507

```

```

MOV L#DLY,(PC)+
.WORD 0
DEC -6(PC)
BNE -.4
DEC -22(PC)
BNE -.20
DEC T30DLY ;BUMP COUNTER
BNE 10$ ;BR, IF MORE COUNTING TO DO
INC FATFLG ;ERROR COUNT
MOV RO,R1 ;CONTENTS OF TSSR REGISTER
ERRDF ERRNO,SFIERR,SFIMSG ;FATAL ERROR TSSR WAS NOT OK
TRAP C#ERDF
.WORD 235
.WORD SFIERR
.WORD SFIMSG
MOV UNITN,T30DSW ;SET UP UNIT NUMBER
MOV #T30PACKET,R4 ;SUBROUTINE NEEDS PACKET ADDRESS
;*****
;ISSUE WRITE CHARACTERISTICS COMMAND
;*****
JSR PC,WRTCHR ;ISSUE WRITE CHARACTERISTICS
BCS 23$ ;BR, IF COMMAND ISSUED OK
INC FATFLG ;ERROR COUNT
MOV RO,R1 ;SAVE CONTENTS OF TSSR
ERRHRD ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTICS FAILED
TRAP C#ERHRD
.WORD 236
.WORD WRTMSG
.WORD SFIMSG
23$: CKLOOP ;LOOP IF SELECTED
TRAP C#CLP1
;*****
;ISSUE A REWIND TO TAPE DRIVE AND WAIT FOR SSR TO SET
;*****
JSR PC,REWIND ;CALL TAPE REWIND COMMAND
BCS 30$ ;BR, IF NO PROBLEM
MOV RO,R4 ;GET PACKET ADDRESS
MOV TSSR(R5),R1 ;GET STATUS REGISTER
INC FATFLG ;ERROR COUNT
ERRHRD ERRNO,T30RWN,PKTSSR ;REWIND NOT ACCEPTED
TRAP C#ERHRD
.WORD 237
.WORD T30RWN
.WORD PKTSSR
30$: CKLOOP ;LOOP IF SELECTED
TRAP C#CLP1
;*****

```

TEST 2: SKIP TAPE MARKS

```

5508
5509 ;GET EXTENDED STATUS REGISTER ZERO (XSTO) FROM MESSAGE BUFFER
5510 ;
5511 ;*****
5512
5513 035532 013701 036460          MOV    T30BFR+6,R1      ;PICK UP XSTO
5514 035536 010102                MOV    R1,R2           ;SET UP EXPECTED
5515 035540 052702 000002        BIS    #BIT1,R2        ;SET BOT BIT IN EXPECTED
5516 035544 020102                CMP    R1,R2           ;DOES EXP = REC'D
5517 035546 001406                BEQ    40$             ;BR, IF EQUAL (OK)
5518 035550 005237 002214        INC    FATFLG          ;ERROR COUNT
5522 035554                ERRHRD ERRNO,T30BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
                                TRAP    C$ERHRD
                                .WORD   238
                                .WORD   T30BOT
                                .WORD   EXPREC
5523 035564                40$: CKLOOP           ;LOOP IF SELECTED
                                TRAP    C$CLP1
5524 035566 012737 000001 036552  MOV    #1,T30WB        ;SET # OF TM TO SKIP
5525
5526 ;*****
5527 ;SKIP TAPE MARK REVERSE,ACK,CVC=1 COMMAND
5528 ;
5529 ;*****
5530
5531
5532 035574 012737 141410 036550  MOV    #141410,T30PK3  ;SKIP TAPE MARK REVERSE,ACK,CVC=1 CMD
5533 035602 012704 036550        MOV    #T30PK3,R4     ;SET UP R4 WITH PACKET ADDRESS
5534 035606 010465 000000        MOV    R4,TSDB(R5)    ;ISSUE COMMAND
5535 035612 004737 016360        JSR    PC,WAITF        ;WAIT FOR SSR TO SET
5536 035616 016501 000002        MOV    TSSR(R5),R1    ;GET TSSR CONTENTS
5537 035622 012702 100206        MOV    #SSR!SC!BIT1!BIT2,R2 ;SET UP EXPECTED
5538 035626 020102                CMP    R1,R2           ;ARE THEY EQUAL
5539 035630 001406                BEQ    70$             ;BR, IF OK
5540 035632 005237 002214        INC    FATFLG          ;ERROR COUNT
5544 035636                ERRHRD ERRNO,T30IBT,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
                                TRAP    C$ERHRD
                                .WORD   239
                                .WORD   T30IBT
                                .WORD   PKTSSR
5545 035646                70$: CKLOOP           ;LOOP IF SELECTED
                                TRAP    C$CLP1
5546
5547 ;*****
5548 ;GET EXTENDED STATUS REGISTER ZERO (XSTO) FROM MESSAGE BUFFER
5549 ;
5550 ;*****
5551
5552
5553 035650 013701 036460          MOV    T30BFR+6,R1      ;PICK UP XSTO
5554 035654 010102                MOV    R1,R2           ;SET UP EXPECTED
5555 035656 052702 002000        BIS    #BIT10,R2      ;SET NEF BIT IN EXPECTED
5556 035662 020102                CMP    R1,R2           ;DOES EXP = REC'D
5557 035664 001406                BEQ    180$           ;BR, IF EQUAL (OK)
5558 035666 005237 002214        INC    FATFLG          ;ERROR COUNT
5562 035672                ERRHRD ERRNO,T30NEF,EXPREC ;TAPE NOT AT NEF
                                TRAP    C$ERHRD
                                .WORD   239
                                .WORD   T30NEF
                                .WORD   EXPREC

```





E11

TEST 2: SKIP TAPE MARKS

```

5603 036034 013737 002174 036450      MOV    UNITN,T30DSW      ;SET UP UNIT NUMBER
5604 036042 012704 036430      MOV    @T30PACKET,R4    ;SUBROUTINE NEEDS PACKET ADDRESS
5605
5606      ;*****
5607      ;
5608      ;ISSUE WRITE CHARACTERISTICS COMMAND
5609      ;
5610      ;*****
5611
5612 036046 004737 010742      JSR    PC,WRTCHR        ;ISSUE WRITE CHARACTERISTICS
5613 036052 103407              BCS    23$              ;BR, IF COMMAND ISSUED OK
5614 036054 005237 002214      INC    FATFLG           ;ERROR COUNT
5618 036060 010001              MOV    R0,R1            ;SAVE CONTENTS OF TSSR
5619 036062              ERRHRD ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTIC FAILED
                                TRAP    C$ERHRD
                                .WORD   242
                                .WORD   WRTMSG
                                .WORD   SFIMSG
5620 036072              23$:  CKLOOP           ;LOOP IF SELECTED
                                TRAP    C$CLP1
5621
5622      ;*****
5623      ;
5624      ;ISSUE A REWIND TO TAPE DRIVE AND WAIT FOR SSR TO SET
5625      ;
5626      ;*****
5627
5628 036074 004737 011126      JSR    PC,REWIND        ;CALL TAPE REWIND COMMAND
5629 036100 103411              BCS    30$              ;BR, IF NO PROBLEM
5630 036102 010004              MOV    R0,R4            ;GET PACKET ADDRESS
5631 036104 016501 000002      MOV    TSSR(R5),R1     ;GET STATUS REGISTER
5632 036110 005237 002214      INC    FATFLG           ;ERROR COUNT
5636 036114              ERRHRD ERRNO,T30RWN,PKTSSR ;REWIND NOT ACCEPTED
                                TRAP    C$ERHRD
                                .WORD   243
                                .WORD   T30RWN
                                .WORD   PKTSSR
5637 036124              30$:  CKLOOP           ;LOOP IF SELECTED
                                TRAP    C$CLP1
5638
5639      ;*****
5640      ;
5641      ;GET EXTENDED STATUS REGISTER ZERO (XSTO) FROM MESSAGE BUFFER
5642      ;
5643      ;*****
5644
5645 036126 013701 036460      MOV    T30BFR+6,R1     ;PICK UP XSTO
5646 036132 010102              MOV    R1,R2            ;SET UP EXPECTED
5647 036134 052702 000002      BIS    @BIT1,R2        ;SET BOT BIT IN EXPECTED
5648 036140 020102              CMP    R1,R2            ;DOES EXP = REC'D
5649 036142 001406              BEQ    40$              ;BR, IF EQUAL (OK)
5650 036144 005237 002214      INC    FATFLG           ;ERROR COUNT
5654 036150              ERRHRD ERRNO,T30BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
                                TRAP    C$ERHRD
                                .WORD   244
                                .WORD   T30BOT
                                .WORD   EXPREC
5654 036150 104456
5654 036152 000364
5654 036154 037771
5654 036156 015604

```



F11

SEQ 0135

TEST 2: SKIP TAPE MARKS

```

5655 036160          404:  CKLOOP                ;LOOP IF SELECTED
      036160 104406          ;                               TRAP  C4CLP1
5656 036162 013737 003120 036552      MOV  FREE,T30WB          ;SET UP GOOD WRITE BUFFER
5657 036170 012737 000400 036556      MOV  #256.,T30SZ        ;SET UP SIZE
5658
5659 ;*****
5660 ;
5661 ;WRITE DATA,ACK,CVC=1 COMMAND
5662 ;
5663 ;*****
5664
5665 036176 012737 140005 036550      MOV  #140005,T30PK3     ;WRITE DATA,ACK,CVC=1 COMMAND
5666 036204 012704 036550          MOV  #T30PK3,R4        ;SET UP R4 WITH PACKET ADDRESS
5667 036210 010465 000000          MOV  R4,TSD8(R5)       ;ISSUE COMMAND
5668 036214 004737 016360          JSR  PC,WAITF          ;WAIT FOR SSR TO SET
5669 036220 016501 000002          MOV  TSSR(R5),R1       ;GET TSSR CONTENTS
5670 036224 012702 000200          MOV  #SSR,R2          ;SET UP EXPECTED
5671 036230 020102          CMP  R1,R2            ;ARE THEY EQUAL
5672 036232 001406          BEQ  704              ;BR, IF OK
5673 036234 005237 002214          INC  FATFLG           ;ERROR COUNT
5677 036240          ERRHRD  ERRNO,T30WDD,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
      036240 104456          ;                               TRAP  C4ERHRD
      036242 000365          ;                               .WORD 245
      036244 037120          ;                               .WORD T30WDD
      036246 012156          ;                               .WORD  PKTSSR
5678 036250          704:  CKLOOP                ;LOOP IF SELECTED
      036250 104406          ;                               TRAP  C4CLP1
5679
5680 ;*****
5681 ;
5682 ;SKIP TAPE MARK REVERSE,ACK,CVC=1 COMMAND
5683 ;
5684 ;*****
5685
5686 036252 012737 000001 036552      MOV  #1,T30WB          ;# OF TM TO SKIP
5687 036260 012737 141410 036550      MOV  #141410,T30PK3    ;SKIP TAPE MARK REVERSE,ACK,CVC=1 CMD
5688 036266 012704 036550          MOV  #T30PK3,R4        ;SET UP R4 WITH PACKET ADDRESS
5689 036272 010465 000000          MOV  R4,TSD8(R5)       ;ISSUE COMMAND
5690 036276 004737 016360          JSR  PC,WAITF          ;WAIT FOR SSR TO SET
5691 036302 016501 000002          MOV  TSSR(R5),R1       ;PICK UP TSSR
5692 036306 012702 100204          MOV  #SSR!BIT2!SC,R2   ;SET UP EXPECTED (SSR AND SC ONLY)
5693 036312 020102          CMP  R1,R2            ;WAS STATUS GOOD
5694 036314 001406          BEQ  1604             ;BR, IF TERMINATION WAS GOOD
5695 036316 005237 002214          INC  FATFLG           ;ERROR COUNT
5699 036322          ERRHRD  ERRNO,T30IBU,PKTSSR ;TSSR NOT CORRECT AFTER WRT TAPE M.
      036322 104456          ;                               TRAP  C4ERHRD
      036324 000366          ;                               .WORD 246
      036326 036610          ;                               .WORD T30IBU
      036330 012156          ;                               .WORD  PKTSSR
5700 036332          1604: CKLOOP                ;LOOP IF SELECTED
      036332 104406          ;                               TRAP  C4CLP1
5701
5702 ;*****
5703 ;
5704 ;GET EXTENDED STATUS REGISTER ZERO (XST3) FROM MESSAGE BUFFER
5705 ;
5706 ;*****

```







TEST 2: SKIP TAPE MARKS

5822	040526	123	113	111	T3ONEF: .ASCIZ	'SKIP TAPE MARKS, At BOT, Failed To Set NEF Bit'
5823	040605	124	115	113	T3ORRM: .ASCIZ	'TMK Not Set After READ REVERSE Into TAPE MARK'
5824	040663	124	115	113	T3ORRN: .ASCIZ	'TMK Not Set After SPACE REVERSE Into TAPE MARK'
5825	040742	124	115	113	T3ORRP: .ASCIZ	'TMK Not Set After READ FORWARD Into TAPE MARK'
5826	041020	116	117	040	T3ODTR: .ASCIZ	'NO Data Transferred On READ FORWARD'
5827	041064	104	141	164	T3ODTA: .ASCIZ	'Data Compare Error, Data Read From Tape Not Equal To Written'
5828	041161	123	153	151	TST30ID: .ASCIZ	'Skip Tape Marks'
5829					.EVEN	

```

5830 ;*
5831 ;
5832 ;ROUTINE TO RESTORE COMMAND PACKET TO START-UP (DEFAULT) VALUES
5833 ;WRITE SUBSYSTEM MEMORY COMMAND
5834 ;
5835 ;-
5836 ;

```

5837	041202				T3OREST:		
5838	041202				SAVREG		;SAVE THE REGISTERS
5839	041206	012701	036430		MOV	#T3OPACKET,R1	;START OF THE PACKET
5840	041212	012721	100004		MOV	#100004,(R1)-	;WRITE SUBSYSTEM MEM. WITH ACK,
5841	041216	012721	036440		MOV	#T30DATA,(R1)-	;ADDRESS OF CHARACTERISTICS DATA BLOCK
5842	041222	005021			CLR	(R1)-	;EXTENDED ADDRESS
5843	041224	012721	000012		MOV	#10,(R1)-	;SIZE OF DATA BLOCK IN BYTES
5844	041230	012721	036452		MOV	#T30BFR,(R1)-	;ADDRESS OF MESSAGE BUFFER
5845	041234	005021			CLR	(R1)-	
5846	041236	012721	000024		MOV	#20,(R1)-	;LENGTH OF MESSAGE BUFFER
5847	041242	005021			CLR	(R1)-	
5848	041244	012711	000000		MOV	#0,(R1)	;SELECT DRIVE ZERO
5849	041250	012702	000030		MOV	#24,R2	;NUMBER OF LOCATIONS TO BE CLEARED
5850	041254	012762	177777	036452 64:	MOV	#177777,T30BFR(R2)	;ALL ONES TO MESSAGE BUFFER
5851	041262	005742			TST	-(R2)	;NEXT LOCATION
5852	041264	022702	000000		CMP	#0,R2	;CHECK R2 FOR DONE
5853	041270	001371			BNE	64:	;KEEP GOING UNTIL DONE
5854	041272	000207			RTS	PC	;RETURN

5855							
5856	041274				T3ORT2:		
5857	041274				SAVREG		;SAVE THE REGISTERS
5858	041300	012701	036540		MOV	#T30PK2,R1	;START OF THE PACKET
5859	041304	012721	100006		MOV	#100006,(R1)-	;WRITE SUBSYSTEM MEM. WITH ACK,
5860	041310	012721	036560		MOV	#T30BF2,(R1)-	;ADDRESS OF DATA BLOCK
5861	041314	005021			CLR	(R1)-	;EXTENDED ADDRESS
5862	041316	012721	000006		MOV	#6,(R1)-	;SIZE OF DATA BLOCK IN BYTES
5863	041322	005021			CLR	(R1)-	
5864	041324	012701	036560		MOV	#T30BF2,R1	;POINT TO DATA SEL AREA
5865	041330	005021			CLR	(R1)-	
5866	041332	005011			CLR	(R1)	
5867	041334	000207			RTS	PC	;RETURN

5868	041336				T3ORT3:		
5869	041336				SAVREG		;SAVE REGISTERS
5870	041342	012701	036550		MOV	#T30PK3,R1	;SET UP POINTER ADDRESS
5871	041346	005021			CLR	(R1)-	;COMMAND SPACE
5872	041350	005021			CLR	(R1)-	;ADDRESS OF DATA BLOCK
5873	041352	005021			CLR	(R1)-	;EXTENDED ADDRESS
5874	041354	005011			CLR	(R1)	;SIZE OF DATA TRANSFER BLOCK
5875	041356	000207			RTS	PC	;RETURN
5876	041360				ENDTST		

L10043: TRAP C4ETST

041360 104401









## TEST 3: NO-OP ("CLEAN TAPE") AND INITIALIZE

5977	041700	010465	000000			MOV	R4,TSDB(R5)		;ISSUE COMMAND		
5978	041704	004737	016360			JSR	PC,WAITF		;WAIT FOR SSR TO SET		
5979	041710	016501	000002			MOV	TSSR(R5),R1		;GET TSSR CONTENTS		
5980	041714	012702	000200			MOV	#SSR,R2		;SET UP EXPECTED		
5981	041720	020102				CMP	R1,R2		;ARE THEY EQUAL		
5982	041722	001406				BEQ	804		;BR, IF OK		
5983	041724	005237	002214			INC	FATFLG		;ERROR COUNT		
5987	041730					ERRHRD	ERRNO,T31WDC,PKTSSR		;TSSR INCORRECT AFTER WRITE DATA		
	041730	104456								TRAP	C4ERHRD
	041732	000461								.WORD	305
	041734	045160								.WORD	T31WDC
	041736	012156								.WORD	PKTSSR
5988	041740				804:	CKLOOP			;LOOP IF SELECTED		
	041740	104406								TRAP	C4CLP1
5989	041742	004737	011126			JSR	PC,REWIND		;CALL TAPE REWIND COMMAND		
5990	041746	103407				BCS	2304		;BR, IF NO PROBLEM		
5991	041750	010001				MOV	R0,R1		;SAVE TSSR		
5992	041752	005237	002214			INC	FATFLG		;ERROR COUNT		
5996	041756					ERRHRD	ERRNO,T31RWN,EXPREC		;REWIND NOT ACCEPTED		
	041756	104456								TRAP	C4ERHRD
	041760	000462								.WORD	306
	041762	044624								.WORD	T31RWN
	041764	015604								.WORD	EXPREC
5997	041766				2304:	CKLOOP			;LOOP IF SELECTED		
	041766	104406								TRAP	C4CLP1
5998	041770	013701	043150			MOV	T31BFR-6,R1		;PICK UP XSTO		
5999	041774	010102				MOV	R1,R2		;SET UP EXPECTED		
6000	041776	052702	000002			BIS	#BIT1,R2		;SET BOT BIT IN EXPECTED		
6001	042002	020102				CMP	R1,R2		;DOES EXP = REC'D		
6002	042004	001406				BEQ	2404		;BR, IF EQUAL (OK)		
6003	042006	005237	002214			INC	FATFLG		;ERROR COUNT		
6007	042012					ERRHRD	ERRNO,T31BOT,EXPREC		;TAPE NOT AT BOT AFTER REWIND		
	042012	104456								TRAP	C4ERHRD
	042014	000463								.WORD	307
	042016	044275								.WORD	T31BOT
	042020	015604								.WORD	EXPREC
6008	042022				2404:	CKLOOP			;LOOP IF SELECTED		
	042022	104406								TRAP	C4CLP1
6009	042024	012737	041012	043240	2654:	MOV	#041012,T31PK3		;NO-OP,CVC-1 COMMAND		
6010	042032	012704	043240			MOV	#T31PK3,R4		;SET UP R4 WITH PACKET ADDRESS		
6011	042036	010337	043246			MOV	R3,T31S2		;SET UP RECORD SIZE IN PACKET		
6012	042042	010465	000000			MOV	R4,TSDB(R5)		;ISSUE COMMAND		
6013	042046	004737	016360			JSR	PC,WAITF		;WAIT FOR SSR TO SET		
6014	042052	016501	000002			MOV	TSSR(R5),R1		;GET TSSR CONTENTS		
6015	042056	012702	000200			MOV	#SSR,R2		;SET UP EXPECTED		
6016	042062	020102				CMP	R1,R2		;ARE THEY EQUAL		
6017	042064	001406				BEQ	2804		;BR, IF OK		
6018	042066	005237	002214			INC	FATFLG		;ERROR COUNT		
6022	042072					ERRHRD	ERRNO,T31RDF,PKTSSR		;TSSR INCORRECT AFTER READ DATA		
	042072	104456								TRAP	C4ERHRD
	042074	000464								.WORD	308
	042076	043473								.WORD	T31RDF
	042100	012156								.WORD	PKTSSR
6023	042102				2804:	CKLOOP			;LOOP IF SELECTED		
	042102	104406								TRAP	C4CLP1
6024	042104	013701	043150			MOV	T31BFR-6,R1		;PICK UP XSTO		
6025	042110	010102				MOV	R1,R2		;SET UP EXPECTED		













## TEST 3: NO-OP ("CLEAN TAPE") AND INITIALIZE

```

043116 003600 .WORD L10050-.
6222
6223 ;*
6224 ;LOCAL STORAGE FOR THIS TEST
6228 043120
6229 043120 100004 T31PACKET: ;COMMAND PACKET FOR TEST
6230 043122 043130 .WORD 100004 ;WRITE CHARACTERISTICS COMMAND, WITH . ACK
6231 043124 000000 .WORD T31DATA ;ADDRESS OF CHARACTERISTICS BLOCK
6232 043126 000012 .WORD 0
6233 043130 T31DATA: ;STARTING VALUE OF BLOCK SIZE
6234 043130 043142 .WORD 10. ;CHARACTERISTICS DATA BLOCK
6235 043132 000000 .WORD T31BFR ;ADDRESS OF MESSAGE BUFFER
6236 043134 000024 .WORD 0
6237 043136 000000 .WORD 20. ;LENGTH OF MESSAGE BUFFER
6238 043140 000000 .WORD 0
6239 043142 T31DSW: .WORD 0 ;SELECT DRIVE 0
T31BFR: .BLKW 25. ;MESSAGE BUFFER
6240
6241 ;WRITE SUBSYSTEM MEMORY COMMAND PACKET
6242
6244 043230
6246 043230 043230 T31PK2: .-<..10>&177770
6247 043230 100006 .WORD 100006 ;WRITE SUB SYS MEM COMMAND, AND ACK
6248 043232 043250 .WORD T31BF2 ;ADDRESS OF SELECT BLOCK DATA
6249 043234 000000 .WORD 0
6250 043236 000006 .WORD 6. ;SIZE OF DATA PACKET
6251
6255 043240
6256 043240 100005 T31PK3: .WORD 100005 ;REREAD COMMAND, AND ACK
6257 043242
6258 043242 003120 T31RB: .WORD FREE ;ADDRESS OF WRITE BUFFER
6259 043244 000000 T31WB: .WORD 0
6260 043246 000000 T31SZ: .WORD 0 ;SIZE OF BUFFER (EXTENT)
6261 .EVEN
6262
6263
6264
6265 043250
6266 043250 010 T31BF2:
6267 043251 200 T31BS0: .BYTE 10 ;BSELO AREA
6268 043252 000000 T31BS1: .BYTE 200 ;BSEL1 AREA
6269 043254 000000 T31S2: .WORD 0 ;SEL 2 AREA
6270 T31S3: .WORD 0 ;DATA AREA
6271
6272
6273 .EVEN
6274 ;TAPE MOTION PACKET COMMAND VALUES
6275 043256 100205 T31RN: .WORD 100205 ;REREAD DATA (NEXT)
6276 043260 100605 T31WDR: .WORD 100605 ;REREAD DATA RETRY
6277 043262 102205 T31CON: .WORD 102205 ;WRITE CONTINOUS
6278 043264 177777 .WORD 177777 ;END OF DATA
6279
6280
6281 043266 000000 T31CNT: .WORD 0 ;TAPE TIMER COUNTER STORAGE AREA
6282 043270 000000 T31CNU: .WORD 0 ;TAPE TIMER COUNTER STORAGE AREA
6283 043272 000000 T31DLY: .WORD 0 ;DELAY COUNTER
6284
6285 ;*
;LOCAL TEXT MESSAGES FOR TEST

```



E12

TEST 3: NO-OP ("CLEAN TAPE") AND INITIALIZE

```

6286
6287
6288 043274 124 123 123 T31RDE: .ASCIZ 'TSSR Not Correct After READ Command'
6289 043340 124 141 160 T31WNH: .ASCIZ 'Tape Position Incorrect After INITIALIZE Command'
6290 043421 124 141 160 T31WNG: .ASCIZ 'Tape Position Incorrect After NOP Command'
6291 043473 124 123 123 T31RDF: .ASCIZ 'TSSR Incorrect After READ DATA Command'
6292 043542 122 105 122 T31RRF: .ASCIZ 'REREAD Previous (Space Reverse, Read Forward) Command Failed'
6293 043637 120 117 123 T31SC: .ASCIZ 'POSITION (Space Command) Failed, TSSR Not Correct'
6294 043721 122 111 102 T31LOR: .ASCIZ 'RIB NOT SET AFTER READ REVERSE INTO BOT'
6295 043771 124 123 123 T31WDF: .ASCIZ 'TSSR Not Correct After Illegal Mode Bits Set'
6296 044046 111 154 154 T31LOQ: .ASCIZ 'Illegal Mode Bits, Failed To Set ILC Bit In XSTO'
6297 044127 122 105 122 T31SSR: .ASCIZ 'REREAD COMMAND Not Accepted'
6298 044163 124 123 123 T31WDE: .ASCIZ 'TSSR Not Correct After NO-OP ("CLEAN TAPE") AND INITIALIZE Command, At BOT'
6299 044275 124 141 160 T31BOT: .ASCIZ 'Tape Not At BOT After REWIND Command (BOT Not Set In XSTO)'
6300 044370 116 117 055 T31TIM: .ASCIZ 'NO-OP ("CLEAN TAPE") AND INITIALIZE'S Erase Tape Not Long Enough'
6301 044470 122 105 122 T31EOT: .ASCIZ 'REREAD DATA OVER EOT GAVE NO TAPE STATUS ALERT'
6302 044547 124 123 123 T31TM: .ASCIZ 'TSSR Not Correct After REREAD COMMAND Reject'
6303 044624 122 145 167 T31RWN: .ASCIZ 'Rewind (POSITION) Command Not Accepted'
6304 044673 122 101 115 T31RNC: .ASCIZ 'RAM Error, Correct Data Pattern Not In Ram'
6305 044746 124 123 123 T31AM3: .ASCIZ 'TSSR Init. Failed After REREAD COMMAND'
6306 045015 104 162 151 T31OFL: .ASCIZ 'Drive 7 Select Failed To Set "OFL" In TSSR'
6307 045070 124 123 123 T31WDD: .ASCIZ 'TSSR Not Correct After REREAD DATA Command, SWB Bit Set'
6308 045160 124 123 123 T31WDC: .ASCIZ 'TSSR Not Correct After REREAD DATA Command'
6309 045233 103 126 103 T31VCK: .ASCIZ 'CVC Set, Didn't Reset VCK In Message Buffer'
6310 045306 124 123 102 T31BA: .ASCIZ 'TSBA Not Correct After REREAD DATA Command'
6311 045361 127 122 111 T31WSS: .ASCIZ 'WRITE SUBSYSTEM MEMORY Command Not Accepted (RAM Read)'
6312 045450 122 145 141 T31LON: .ASCIZ 'Reading Long Record Failed To Set RLL Bit In XSTO'
6313 045532 122 145 141 T31LOP: .ASCIZ 'Reading Long Record Failed To Set RLS Bit In XSTO'
6314 045614 122 145 163 T31PBP: .ASCIZ 'Residual Byte Count Incorrect After Short Record Read'
6315 045702 122 145 141 T31TRL: .ASCIZ 'Reading Long Record Failed To Give Tape Status Alert'
6316 045770 116 117 055 T31NEF: .ASCIZ 'NO-OP ("CLEAN TAPE") AND INITIALIZE, At First Record, Failed To Set RIB Bit

X
6317 046111 124 123 123 T31SCF: .ASCIZ 'TSSR Not Correct After SPACE RECORDS Command'
6318 046166 124 123 123 T31TSA: .ASCIZ 'TSSR Not Correct After NO-OP ("CLEAN TAPE") AND INITIALIZE, Into BOT'
6319 046273 124 123 123 T31WRF: .ASCIZ 'TSSR Not Correct After NO-OP ("CLEAN TAPE") AND INITIALIZE Command'
6320 046376 104 141 164 T31DTA: .ASCIZ 'Data Compare Error, Data Read From Tape Not Equal To Written'
6321 046473 116 117 055 TST31ID: .ASCIZ 'NO-OP ("Clean Tape") And INITIALIZE'
6322
6323 .EVEN
6324
6325 ;
6326 ;ROUTINE TO RESTORE COMMAND PACKET TO START-UP (DEFAULT) VALUES
6327 ;WRITE SUBSYSTEM MEMORY COMMAND
6328 ;
6329 ;-
6330 T31REST:
6331 046540 SAVREG
6332 046544 012701 043120 MOV #T31PACKET,R1 ;SAVE THE REGISTERS
6333 046550 012721 100004 MOV #100004,(R1) ;START OF THE PACKET
6334 046554 012721 043130 MOV #T31DATA,(R1) ;WRITE SUBSYSTEM MEM. WITH ACK,
6335 046560 005021 CLR (R1) ;ADDRESS OF CHARACTERISTICS DATA BLOCK
6336 046562 012721 000012 MOV #10,(R1) ;EXTENDED ADDRESS
6337 046566 012721 043142 MOV #T31BFR,(R1) ;SIZE OF DATA BLOCK IN BYTES
6338 046572 005021 CLR (R1) ;ADDRESS OF MESSAGE BUFFER
6339 046574 012721 000024 MOV #20,(R1) ;LENGTH OF MESSAGE BUFFER
6340 046600 005021 CLR (R1)
6341 046602 012711 000000 MOV #0,(R1) ;SELECT DRIVE ZERO
6342 046606 012702 000030 MOV #24,,R2 ;NUMBER OF LOCATIONS TO BE CLEARED

```

TEST 3: NO-OP ("CLEAN TAPE") AND INITIALIZE

```

6343 046612 012762 177777 043142 64:  MOV    @177777,T31BFR(R2)  ;ALL ONES TO MESSAGE BUFFER
6344 046620 005742                    TST    -(R2)              ;NEXT LOCATION
6345 046622 022702 000000          CMP    #0,R2             ;AT END OF LOOP YET
6346 046626 001371                    BNE   64:                ;KEEP GOING UNTIL DONE
6347 046630 000207                    RTS    PC                ;RETURN
6348
6349 046632                    T31RT2:
6350 046632                    SAVREG                   ;SAVE THE REGISTERS
6351 046636 012701 043230          MOV    @T31PK2,R1        ;START OF THE PACKET
6352 046642 012721 100006          MOV    @100006,(R1)+     ;WRITE SUBSYSTEM MEM. WITH ACK.
6353 046646 012721 043250          MOV    @T31BF2,(R1)+    ;ADDRESS OF DATA BLOCK
6354 046652 005021                    CLR    (R1)+             ;EXTENDED ADDRESS
6355 046654 012721 000006          MOV    #6,(R1)+         ;SIZE OF DATA BLOCK IN BYTES
6356 046660 005021                    CLR    (R1)+
6357 046662 012701 043250          MOV    @T31BF2,R1       ;POINT TO DATA SEL AREA
6358 046666 005021                    CLR    (R1)+
6359 046670 005011                    CLR    (R1)
6360 046672 000207                    RTS    PC                ;RETURN
6361 046674                    T31RT3:
6362 046674                    SAVREG                   ;SAVE REGISTERS
6363 046700 012701 043240          MOV    @T31PK3,R1        ;SET UP POINTER ADDRESS
6364 046704 005021                    CLR    (R1)+
6365 046706 005021                    CLR    (R1)+
6366 046710 005021                    CLR    (R1)+
6367 046712 005011                    CLR    (R1)
6368 046714 000207                    RTS    PC                ;RETURN
6369 046716                    ENDTST
046716                    L10050: TRAP    C#ETST
046716 104401

```

6370  
6371  
6372  
6373  
6374  
6375  
6376  
6377  
6378  
6379  
6380  
6381  
6382  
6383  
6384  
6385  
6386  
6387  
6388  
6389  
6390  
6391  
6392  
6393  
6394  
6395  
6396  
6397

.SBTTL TEST 4: Erase And Operation Incomplete

VERIFIES THAT AN ERASE COMMAND ISSUED WHEN THE TAPE IS POSITIONED AT BOT OPERATES PROPERLY AND ACTUALLY ERASES TAPE. THE FOLLOWING TEST SEQUENCE IS PERFORMED:

1. THE TAPE IS FIRST REWOUND, SEVERAL TEST RECORDS ARE WRITTEN, AND THE TAPE IS REWOUND AGAIN.
2. AN ERASE COMMAND IS ISSUED, WHICH SHOULD ERASE A NUMBER OF THE TEST RECORDS.
3. NORMAL TERMINATION IS VERIFIED AND STATUS IS CHECKED (BOT SHOULD BE 0).
4. A READ REVERSE COMMAND IS ISSUED. IT IS VERIFIED THAT THE COMMAND TERMINATES WITH TAPE STATUS ALERT, THAT THE REVERSE INTO BOT (RIB) STATUS BIT IS SET, AND THAT NO DATA IS TRANSFERRED. THIS DEMONSTRATES THAT NO DATA WAS ENCOUNTERED IN THE AREA ERASED BY THE ERASE COMMAND.









## TEST 4: Erase And Operation Incomplete

```

047300 012156
6498 047302 304: CKLOOP ;LOOP IF SELECTED .WORD PKTSSR
047302 104406 TRAP C4CLP1
6499 047304 013701 051310 MOV T32BFR+6,R1 ;PICK UP XSTO
6500 047310 010102 MOV R1,R2 ;SET UP EXPECTED
6501 047312 052702 000002 BIS #BIT1,R2 ;SET BOT BIT IN EXPECTED
6502 047316 020102 CMP R1,R2 ;DOES EXP = REC'D
6503 047320 001406 BEQ 404 ;BR, IF EQUAL (OK)
6504 047322 005237 002214 INC FATFLG ;ERROR COUNT
6508 047326 ERRHRD ERRNO,T32BOE,EXPREC ;TAPE AT BOT AFTER ERASE
047326 104456 TRAP C4ERHRD
047330 000626 .WORD 406
047332 052316 .WORD T32BOE
047334 015604 .WORD EXPREC
6509 047336 404: CKLOOP ;LOOP IF SELECTED TRAP C4CLP1
047336 104406 TRAP C4CLP1
6510 047340 012737 140411 051400 MOV #140411,T32PK3 ;ERASE TAPE,CVC=1,ACK COMMAND
6511 047346 012704 051400 MOV #T32PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
6512 047352 010465 000000 MOV R4,TSDB(R5) ;ISSUE COMMAND
6513 047356 004737 016360 JSR PC,WAITF ;WAIT FOR SSR TO SET
6514 047362 016501 000002 MOV TSSR(R5),R1 ;GET TSSR CONTENTS
6515 047366 012702 000200 MOV #SSR,R2 ;SET UP EXPECTED
6516 047372 020102 CMP R1,R2 ;ARE THEY EQUAL
6517 047374 001406 BEQ 504 ;BR, IF OK
6518 047376 005237 002214 INC FATFLG ;ERROR COUNT
6522 047402 ERRHRD ERRNO,T32ERA,PKTSSR ;TSSR INCORRECT AFTER ERASE DATA
047402 104456 TRAP C4ERHRD
047404 000627 .WORD 407
047406 051746 .WORD T32ERA
047410 012156 .WORD PKTSSR
6523 047412 504: CKLOOP ;LOOP IF SELECTED TRAP C4CLP1
047412 104406 TRAP C4CLP1
6524 047414 013701 051310 MOV T32BFR+6,R1 ;PICK UP XSTO
6525 047420 010102 MOV R1,R2 ;SET UP EXPECTED
6526 047422 042702 000002 BIC #BIT1,R2 ;SET BOT BIT IN EXPECTED
6527 047426 020102 CMP R1,R2 ;DOES EXP = REC'D
6528 047430 001406 BEQ 554 ;BR, IF EQUAL (OK)
6529 047432 005237 002214 INC FATFLG ;ERROR COUNT
6533 047436 ERRHRD ERRNO,T32BOE,EXPREC ;TAPE NOT AT BOT AFTER REWIND
047436 104456 TRAP C4ERHRD
047440 000630 .WORD 408
047442 052316 .WORD T32BOE
047444 015604 .WORD EXPREC
6534 047446 554: CKLOOP ;LOOP IF SELECTED TRAP C4CLP1
047446 104406 TRAP C4CLP1
6535 047450 013737 003120 051402 MOV FREE,T32RB ;ADDRESS OF BUFFER
6536 047456 012737 140401 051400 MOV #140401,T32PK3 ;READ REVERSE,ACK,CVC=1 COMMAND
6537 047464 012737 000400 051406 MOV #256,T32SZ ;SET UP THE SIZE OF RECORD
6538 047472 012704 051400 MOV #T32PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
6539 047476 010465 000000 MOV R4,TSDB(R5) ;ISSUE COMMAND
6540 047502 004737 016360 JSR PC,WAITF ;WAIT FOR SSR TO SET
6541 047506 016501 000002 MOV TSSR(R5),R1 ;GET TSSR CONTENTS
6542 047512 012702 100204 MOV #SSR:SC:BIT2,R2 ;SET UP EXPECTED TAPE STATUS ALERT
6543 047516 020102 CMP R1,R2 ;ARE THEY EQUAL
6544 047520 001406 BEQ 1804 ;BR, IF OK
6545 047522 005237 002214 INC FATFLG ;ERROR COUNT
6549 047526 ERRHRD ERRNO,T32TSA,PKTSSR ;TSSR INCORRECT AFTER READ DATA

```





TEST 4: Erase And Operation Incomplete

```

6599
6600
6601 047610      ;
      047610      ;
      047610      ;
      047610      104402
6602 047612      004737 052630      JSR      PC,T32REST      ;SET COMMAND PACKET      TRAP      C4BSUB
6603 047616      004737 052722      JSR      PC,T32RT2      ;SET UP OTHER COMMAND PACKET
6604 047622      004737 052752      JSR      PC,T32RT3      ;SET UP OTHER COMMAND PACKET
6605 047626      004737 016104      JSR      PC,SOFINIT      ;DO INITIALIZE ON CONTROLLER
6606 047632      103407      BCS      204      ;BR IF INIT WAS OK
6607 047634      005237 002214      INC      FATFLG      ;ERROR COUNT
6611 047640      010001      MOV      R0,R1      ;CONTENTS OF TSSR REGISTER
6612 047642      ERRDF      ERRNO,SFIERR,SFIMSG      ;FATAL ERROR TSSR WAS NOT OK
      047642      104455      TRAP      C4ERDF
      047644      000633      .WORD      411
      047646      003650      .WORD      SFIERR
      047650      012144      .WORD      SFIMSG
6613 047652      013737 002174 051300 204:      MOV      UNITN,T32DSW      ;SET UP UNIT NUMBER IN PACKET
6614 047660      012704 051260      MOV      #T32PACKET,R4      ;SUBROUTINE NEEDS PACKET ADDRESS
6615 047664      004737 010742      JSR      PC,WRTCHR      ;ISSUE WRITE CHARACTERISTICS
6616 047670      103407      BCS      234      ;BR, IF COMMAND ISSUED OK
6617 047672      005237 002214      INC      FATFLG      ;ERROR COUNT
6621 047676      010001      MOV      R0,R1      ;SAVE CONTENTS OF TSSR
6622 047700      ERRHRD      ERRNO,WRTMSG,SFIMSG      ;WRITE CHARACTERISTIC FAILED
      047700      104456      TRAP      C4ERHRD
      047702      000634      .WORD      412
      047704      005054      .WORD      WRTMSG
      047706      012144      .WORD      SFIMSG
6623 047710      234:      CKLOOP      ;LOOP IF SELECTED
      047710      104406      TRAP      C4CLP1
6624 047712      004737 011126      JSR      PC,REWIND      ;CALL TAPE REWIND COMMAND
6625 047716      103407      BCS      304      ;BR, IF NO PROBLEM
6626 047720      010004      MOV      R0,R4      ;SET UP REWIND PACKET ADDRESS
6627 047722      005237 002214      INC      FATFLG      ;ERROR COUNT
6631 047726      ERRHRD      ERRNO,T32RWN,PKTSSR      ;REWIND NOT ACCEPTED
      047726      104456      TRAP      C4ERHRD
      047730      000635      .WORD      413
      047732      051630      .WORD      T32RWN
      047734      012156      .WORD      PKTSSR
6632 047736      304:      CKLOOP      ;LOOP IF SELECTED
      047736      104406      TRAP      C4CLP1
6633 047740      013701 051310      MOV      T32BFR-6,R1      ;PICK UP XSTO
6634 047744      010102      MOV      R1,R2      ;SET UP EXPECTED
6635 047746      052702 000002      BIS      #BIT1,R2      ;SET BOT BIT IN EXPECTED
6636 047752      020102      CMP      R1,R2      ;DOES EXP = REC'D
6637 047754      001406      BEQ      404      ;BR, IF EQUAL (OK)
6638 047756      005237 002214      INC      FATFLG      ;ERROR COUNT
6642 047762      ERRHRD      ERRNO,T32BOT,EXPREC      ;TAPE NOT AT BOT AFTER REWIND
      047762      104456      TRAP      C4ERHRD
      047764      000636      .WORD      414
      047766      051446      .WORD      T32BOT
      047770      015604      .WORD      EXPREC
6643 047772      404:      CKLOOP      ;LOOP IF SELECTED
      047772      104406      TRAP      C4CLP1
6644 047774      012703 000144      MOV      #100.,R3      ;STARTING RECORD SIZE
6645 050000      010300      MOV      R3,R0      ;SET UP MEMORY FILL
6646 050002      004737 017532      JSR      PC,FILLMEM      ;CALL MEMORY FILLER

```

## TEST 4: Erase And Operation Incomplete

```

6647 050006 013737 003120 051402      MOV      FREE,T32WB      ;STARTING WRITE BUFFER ADDRESS
6648 050014 012737 140005 051400 654:  MOV      @140005,T32PK3  ;WRITE DATA,CVC=1,ACK COMMAND
6649 050022 012704 051400      MOV      @T32PK3,R4     ;SET UP R4 WITH PACKET ADDRESS
6650 050026 010300      MOV      R3,R0         ;SET PATTERN IN CORRECT REGISTER
6651 050030 004737 017532      JSR      PC,FILLMEM     ;FILL MEMORY WITH RECORD SIZE
6652 050034 010337 051406      MOV      R3,T32SZ      ;SET UP RECORD SIZE IN PACKET
6653 050040 010465 000000      MOV      R4,TSDB(R5)   ;ISSUE COMMAND
6654 050044 004737 016360      JSR      PC,WAITF      ;WAIT FOR SSR TO SET
6655 050050 016501 000002      MOV      TSSR(R5),R1  ;GET TSSR CONTENTS
6656 050054 012702 000200      MOV      @SSR,R2      ;SET UP EXPECTED
6657 050060 020102      CMP      R1,R2        ;ARE THEY EQUAL
6658 050062 001406      BEQ      804          ;BR, IF OK
6659 050064 005237 002214      INC      FATFLG       ;ERROR COUNT
6663 050070      ERRHRD  ERRNO,T32MDC,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
        050070 104456      TRAP      C#ERHRD
        050072 000637      .WORD    415
        050074 052466      .WORD    T32MDC
        050076 012156      .WORD    PKTSSR
6664 050100      804:  CKLOOP          ;LOOP IF SELECTED
        050100 104406      TRAP      C#CLP1
6665 050102 005723      TST      (R3).        ;BUMP RECORD SIZE COUNTER
6666 050104 020327 000156      CMP      R3,#110.     ;AT 160 SIZE YET
6667 050110 001341      BNE      654          ;BR, IF MORE RECORDS TO WRITE
6668 050112 004737 011126      JSR      PC,REWIND    ;CALL TAPE REWIND COMMAND
6669 050116 103407      BCS      2304         ;BR, IF NO PROBLEM
6670 050120 010001      MOV      R0,R1        ;SAVE TSSR
6671 050122 005237 002214      INC      FATFLG       ;ERROR COUNT
6675 050126      ERRHRD  ERRNO,T32RMN,EXPREC ;REWIND NOT ACCEPTED
        050126 104456      TRAP      C#ERHRD
        050130 000640      .WORD    416
        050132 051630      .WORD    T32RMN
        050134 015604      .WORD    EXPREC
6676 050136      2304: CKLOOP          ;LOOP IF SELECTED
        050136 104406      TRAP      C#CLP1
6677 050140 013701 051310      MOV      T32BFR-6,R1  ;PICK UP XSTO
6678 050144 010102      MOV      R1,R2        ;SET UP EXPECTED
6679 050146 052702 000002      BIS      @BIT1,R2     ;SET BOT BIT IN EXPECTED
6680 050152 020102      CMP      R1,R2        ;DOES EXP = REC'D
6681 050154 001406      BEQ      2404         ;BR, IF EQUAL (OK)
6682 050156 005237 002214      INC      FATFLG       ;ERROR COUNT
6686 050162      ERRHRD  ERRNO,T32BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
        050162 104456      TRAP      C#ERHRD
        050164 000641      .WORD    417
        050166 051446      .WORD    T32BOT
        050170 015604      .WORD    EXPREC
6687 050172      2404: CKLOOP          ;LOOP IF SELECTED
        050172 104406      TRAP      C#CLP1
6688 050174 012703 000001      MOV      #1,R3        ;SET UP FOR SPACE COMMAND
6689 050200 004737 010546      JSR      PC,SPACE     ;ISSUE SPACE COMMAND 1 FORWARD
6690 050204 012737 140411 051400 2654:  MOV      @140411,T32PK3 ;ERASE DATA,ACK COMMAND
6691 050212 012704 051400      MOV      @T32PK3,R4   ;SET UP R4 WITH PACKET ADDRESS
6692 050216 010465 000000      MOV      R4,TSDB(R5)  ;ISSUE COMMAND
6693 050222 004737 016360      JSR      PC,WAITF     ;WAIT FOR SSR TO SET
6694 050226 016501 000002      MOV      TSSR(R5),R1  ;GET TSSR CONTENTS
6695 050232 012702 000200      MOV      @SSR,R2      ;SET UP EXPECTED
6696 050236 020102      CMP      R1,R2        ;ARE THEY EQUAL
6697 050240 001406      BEQ      2804         ;BR, IF OK

```









TEST 4: Erase And Operation Incomplete

6793	050546	004737	010742		JSR	PC,WRTCHR		;ISSUE WRITE CHARACTERISTICS		
6794	050552	103407			BCS	23		;BR, IF COMMAND ISSUED OK		
6795	050554	005237	002214		INC	FATFLG		;ERROR COUNT		
6799	050560	010001			MOV	R0,R1		;SAVE CONTENTS OF TSSR		
6800	050562				ERRHRD	ERRNO,WRTMSG,SFIMSG		;WRITE CHARACTERISTIC FAILED		
	050562	104456						TRAP	C#ERHRD	
	050564	000646						.WORD	422	
	050566	005054						.WORD	WRTMSG	
	050570	012144						.WORD	SFIMSG	
6801	050572			23:	CKLOOP			;LOOP IF SELECTED		
	050572	104406						TRAP	C#CLP1	
6802	050574	004737	011126		JSR	PC,REWIND		;CALL TAPE REWIND COMMAND		
6803	050600	103411			BCS	30		;BR, IF NO PROBLEM		
6804	050602	016501	000002		MOV	TSSR(R5),R1		;GET TSSR CONTENTS		
6805	050606	010004			MOV	R0,R4		;GET PACKET ADDRESS		
6806	050610	005237	002214		INC	FATFLG		;ERROR COUNT		
6810	050614				ERRHRD	ERRNO,T32RWN,PKTSSR		;REWIND NOT ACCEPTED		
	050614	104456						TRAP	C#ERHRD	
	050616	000647						.WORD	423	
	050620	051630						.WORD	T32RWN	
	050622	012156						.WORD	PKTSSR	
6811	050624			30:	CKLOOP			;LOOP IF SELECTED		
	050624	104406						TRAP	C#CLP1	
6812	050626	013701	051310		MOV	T32BFR-6,R1		;PICK UP XSTO		
6813	050632	010102			MOV	R1,R2		;SET UP EXPECTED		
6814	050634	052702	000002		BIS	#BIT1,R2		;SET BOT BIT IN EXPECTED		
6815	050640	020102			CMF	R1,R2		;DOES EXP = REC'D		
6816	050642	001406			BEQ	40		;BR, IF EQUAL (OK)		
6817	050644	005237	002214		INC	FATFLG		;ERROR COUNT		
6821	050650				ERRHRD	ERRNO,T32BOT,EXPREC		;TAPE NOT AT BOT AFTER REWIND		
	050650	104456						TRAP	C#ERHRD	
	050652	000650						.WORD	424	
	050654	051446						.WORD	T32BOT	
	050656	015604						.WORD	EXPREC	
6822	050660			40:	CKLOOP			;LOOP IF SELECTED		
	050660	104406						TRAP	C#CLP1	
6823	050662	012737	140411	051400	65:	MOV	#140411,T32PK3	;ERASE DATA,CVC-1,ACK COMMAND		
6824	050670	012704	051400		MOV	#T32PK3,R4		;SET UP R4 WITH PACKET ADDRESS		
6825	050674	010337	051406		MOV	R3,T32SZ		;SET UP RECORD SIZE IN PACKET		
6826	050700	010465	000000		MOV	R4,TSD8(R5)		;ISSUE COMMAND		
6827	050704	004737	016360		JSR	PC,WAITF		;WAIT FOR SSR TO SET		
6828	050710	016501	000002		MOV	TSSR(R5),R1		;GET TSSR CONTENTS		
6829	050714	012702	000200		MOV	#SSR,R2		;SET UP EXPECTED		
6830	050720	020102			CMF	R1,R2		;ARE THEY EQUAL		
6831	050722	001757			BEQ	65		;BR, IF OK		
6832	050724	032701	000004		BIT	#BIT2,R1		;CHECK FOR TAPE STATUS ALERT		
6833	050730	001006			BNE	80		;BR, IF TAPE STATUS ALERT SET		
6834	050732	005237	002214		INC	FATFLG		;ERROR COUNT		
6838	050736				ERRHRD	ERRNO,T32WDC,PKTSSR		;TSSR INCORRECT AFTER WRITE DATA		
	050736	104456						TRAP	C#ERHRD	
	050740	000651						.WORD	425	
	050742	052466						.WORD	T32WDC	
	050744	012156						.WORD	PKTSSR	
6839	050746			80:	CKLOOP			;LOOP IF SELECTED		
	050746	104406						TRAP	C#CLP1	
6840	050750	013701	051310		MOV	T32BFR-6,R1		;PICK UP XSTO		
6841	050754	010102			MOV	R1,R2		;SET UP EXPECTED		

## TEST 4: Erase And Operation Incomplete

```

6842 050756 052702 000001      BIS      #BIT0,R2      ;SET EOT BIT IN EXPECTED
6843 050762 020102              CMP      R1,R2        ;DOES EXP = REC'D
6844 050764 001406              BEQ     240$          ;BR, IF EQUAL (OK)
6845 050766 005237 002214      INC     FATFLG        ;ERROR COUNT
6849 050772              ERRHRD  ERRNO,T32EOT,EXPREC ;TAPE NOT AT EOT AFTER ERASE COMMANDS
        050772 104456              TRAP   C$ERHRD
        050774 000652              .WORD  426
        050776 051541              .WORD  T32EOT
        051000 015604              .WORD  EXPREC
6850 051002              240$:  CKLOOP        ;LOOP IF SELECTED
        051002 104406              TRAP   C$CLP1
6851 051004 012703 051410      MOV     #T32CMD,R3    ;STARTING RECORD SIZE
6852 051010 013737 003120 051402      MOV     FREE,T32RB    ;STARTING READ BUFFER ADDRESS
6853 051016 011337 051400      265$:  MOV     (R3),T32PK3 ;READ DATA,ACK COMMAND
6854 051022 012704 051400      MOV     #T32PK3,R4    ;SET UP R4 WITH PACKET ADDRESS
6855 051026 012700 177777      MOV     #177777,R0    ;SET PATTERN IN CORRECT REGISTER
6856 051032 004737 017532      JSR    PC,FILLMEM     ;FILL MEMORY WITH ALL ONES
6857 051036 012737 000144 051406      MOV     #100.,T32SZ   ;SET UP RECORD SIZE IN PACKET
6858 051044 010465 000000      MOV     R4,T32DB(R5)  ;ISSUE COMMAND
6859 051050 012737 000062 051444      MOV     #50.,T32DLY   ;SET UP DELAY COUNTER
6860 051056 004737 016360      270$:  JSR    PC,WAITF     ;WAIT FOR SSR TO SET
6861 051062 016501 000002      MOV     TSSR(R5),R1  ;GET TSSR CONTENTS
6862 051066 012702 100214      MOV     #SSR!SC!BIT2!BIT3,R2 ;SET UP EXPECTED
6863 051072 020102              CMP     R1,R2        ;ARE THEY EQUAL
6864 051074 001425              BEQ     280$          ;BR, IF OK
6865 051076              DELAY   250          ;DELAY FOR SSR TO BE SET
        051076 012727 000250              MOV     #250.(PC)-0
        051102 000000              .WORD  0
        051104 013727 002116              MOV     L$DLY,(PC)-0
        051110 000000              .WORD  0
        051112 005367 177772              DEC     -6(PC)
        051116 001375              BNE    .-4
        051120 005367 177756              DEC     -22(PC)
        051124 001367              BNE    .-20
6866 051126 005337 051444      DEC     T32DLY        ;COUNT DELAY ROUTINE DOWN
6867 051132 001351              BNE    270$          ;BR, IF DELAY HAS NOT ENDED
6868 051134 005237 002214      INC     FATFLG        ;ERROR COUNT
6872 051140              ERRHRD  ERRNO,T32ECF,PKTSSR ;TSSR INCORRECT AFTER READ DATA
        051140 104456              TRAP   C$ERHRD
        051142 000653              .WORD  427
        051144 052405              .WORD  T32ECF
        051146 012156              .WORD  PKTSSR
6873 051150              280$:  CKLOOP        ;LOOP IF SELECTED
        051150 104406              TRAP   C$CLP1
6874 051152 013701 051316      MOV     T32BFR+14,R1  ;PICK UP XST3
6875 051156 010102              MOV     R1,R2        ;SET UP EXPECTED
6876 051160 052702 000100      BIS     #BIT6,R2     ;SET OPI BIT IN EXPECTED
6877 051164 020102              CMP     R1,R2        ;IS OPI BIT SET
6878 051166 001406              BEQ     290$          ;BR, IF BIT IS SET
6879 051170 005237 002214      INC     FATFLG        ;ERROR COUNT
6883 051174              ERRHRD  ERRNO,T32OPI,EXPREC ;OPI BIT NOT SET
        051174 104456              TRAP   C$ERHRD
        051176 000654              .WORD  428
        051200 052533              .WORD  T32OPI
        051202 015604              .WORD  EXPREC
6884 051204              290$:  CKLOOP        ;LOOP IF SELECTED
        051204 104406              TRAP   C$CLP1

```





## TEST 4: Erase And Operation Incomplete

```

6945
6946
6947
6948 051410
6949 051410 140410
6950 051412 141410
6951 051414 140401
6952 051416 141001
6953 051420 161401
6954 051422 161001
6955 051424 141401
6956 051426 140001
6957 051430 141410
6958 051432 141010
6959 051434 141005
6960 051436 177777
6961
6962
6963 051440 000000
6964 051442 000000
6965 051444 000000
6966
6967
6968
6969
6970 051446 124 141 160
6971 051541 124 141 160
6972 051630 122 145 167
6973 051677 124 123 123
6974 051746 124 123 123
6975 052013 124 123 102
6976 052066 122 105 101
6977 052164 124 123 123
6978 052241 124 123 123
6979 052316 102 117 124
6980 052405 105 122 101
6981 052466 124 123 123
6982 052533 117 120 111
6983 052570 105 162 -141
6984
6985
6986
6987
6988
6989
6990
6991
6992 052630
6993 052630
6994 052634 012701 051260
6995 052640 012721 100004
6996 052644 012721 051270
6997 052650 005021
6998 052652 012721 000012
6999 052656 012721 051302
7000 052662 005021
7001 052664 012721 000024

```

```

      .EVEN
;TAPE MOTION PACKET COMMAND VALUES
T32CMD:
      .WORD 140410 ;SPACE RECORDS REVERSE
      .WORD 141410 ;SKIP TAPE MARKS REVERSE
      .WORD 140401 ;READ REVERSE
      .WORD 141001 ;REREAD PREVIOUS (OPP=0)
      .WORD 161401 ;REREAD NEXT (OPP=1)
      .WORD 161001 ;REREAD PREVIOUS (OPP=1)
      .WORD 141401 ;REREAD NEXT (OPP=0)
      .WORD 140001 ;READ NEXT
      .WORD 141410 ;SKIP TAPE MARKS REVERSE
      .WORD 141010 ;SKIP RECORDS FORWARD
      .WORD 141005 ;WRITE DATA RETRY
      .WORD 177777 ;END OF DATA

T32CNT: .WORD 0 ;TAPE TIMER COUNTER STORAGE AREA
T32CNU: .WORD 0 ;TAPE TIMER COUNTER STORAGE AREA
T32DLY: .WORD 0 ;DELAY COUNTER
;
;LOCAL TEXT MESSAGES FOR TEST
;-
T32BOT: .ASCIZ 'Tape Not At BOT After REWIND Command (BOT Not Set In XST0)'
T32EOT: .ASCIZ 'Tape Status Alert During Erase To EOT, But EOT Not Set'
T32RMN: .ASCIZ 'Rewind (POSITION) Command Not Accepted'
T32AM3: .ASCIZ 'TSSR Init. Failed After REREAD COMMAND'
T32ERA: .ASCIZ 'TSSR Not Correct After ERASE Command'
T32BA: .ASCIZ 'TSBA Not Correct After REREAD DATA Command'
T32RIB: .ASCIZ 'READ REVERSE, After ERASE From BOT, Failed To Set RIB In XST3'
T32SCF: .ASCIZ 'TSSR Not Correct After SPACE RECORDS Command'
T32TSA: .ASCIZ 'TSSR Not Correct After READ REVERSE Into BOT'
T32BOE: .ASCIZ 'BOT (XST0) Still Set After Erase From Tape's BOT Marker'
T32ECF: .ASCIZ 'ERASE Failed To Clear Tape (Erase) Tape Properly'
T32WDC: .ASCIZ 'TSSR Not Correct After ERASE Command'
T32OPI: .ASCIZ 'OPI Bit (XST3) Failed To Set'
TST32ID: .ASCIZ 'Erase And Operation Incomplete'
      .EVEN
;
;ROUTINE TO RESTORE COMMAND PACKET TO START-UP (DEFAULT) VALUES
;WRITE SUBSYSTEM MEMORY COMMAND
;-
T32REST:
      SAVREG ;SAVE THE REGISTERS
      MOV #T32PACKET,R1 ;START OF THE PACKET
      MOV #100004,(R1). ;WRITE SUBSYSTEM MEM. WITH ACK.
      MOV #T32DATA,(R1). ;ADDRESS OF CHARAISTICS DATA BLOCK
      CLR (R1). ;EXTENDED ADDRESS
      MOV #10,(R1). ;SIZE OF DATA BLOCK IN BYTES
      MOV #T32BFR,(R1). ;ADDRESS OF MESSAGE BUFFER
      CLR (R1).
      MOV #20,(R1). ;LENGTH OF MESSAGE BUFFER

```



TEST 4: Erase And Operation Incomplete

```

7002 052670 005021          CLR      (R1)+
7003 052672 012711 000000  MOV      #0,(R1)          ;SELECT DRIVE ZERO
7004 052676 012702 000030  MOV      #24,R2          ;NUMBER OF LOCATIONS TO BE CLEARED
7005 052702 012762 177777 051302 64#  MOV      #177777,T32BFR(R2) ;ALL ONES TO MESSAGE BUFFER
7006 052710 005742          TST      -(R2)          ;NEXT LOCATION
7007 052712 022702 000000  CMP      #0,R2          ;AT END OF LOOP YET
7008 052716 001371          BNE      64#          ;KEEP GOING UNTIL DONE
7009 052720 000207          RTS      PC          ;RETURN
7010
7011 052722          T32RT2:
7012 052722          SAVREG          ;SAVE THE REGISTERS
7013 052726 012701 051370  MOV      #T32PK2,R1      ;START OF THE PACKET
7014 052732 012721 100006  MOV      #100006,(R1)+  ;WRITE SUBSYSTEM MEM. WITH ACK.
7015 052736 005021          CLR      (R1)+          ;ADDRESS OF DATA BLOCK
7016 052740 005021          CLR      (R1)+          ;EXTENDED ADDRESS
7017 052742 012721 000006  MOV      #6,(R1)+       ;SIZE OF DATA BLOCK IN BYTES
7018 052746 005021          CLR      (R1)+
7019 052750 000207          RTS      PC          ;RETURN
7020 052752          T32RT3:
7021 052752          SAVREG          ;SAVE REGISTERS
7022 052756 012701 051400  MOV      #T32PK3,R1      ;SET UP POINTER ADDRESS
7023 052762 005021          CLR      (R1)+          ;COMMAND SPACE
7024 052764 005021          CLR      (R1)+          ;ADDRESS OF DATA BLOCK
7025 052766 005021          CLR      (R1)+          ;EXTENDED ADDRESS
7026 052770 005011          CLR      (R1)+          ;SIZE OF DATA TRANSFER BLOCK
7027 052772 000207          RTS      PC          ;RETURN
7028 052774          ENDTST
7029 052774 104401          L10053: TRAP      C#ETST

```

.SBTTL TEST 5: DATA PARITY TEST

```

7030 ;*
7031 ;
7032 ;
7033 ;
7034 ;
7035 ;
7036 ;TEST 5 -- Data Parity Test
7037 ;
7038 ;
7039 ;This test verifies that the data parity circuitry in both the controller and the
7040 ;transport is operating properly by forcing data records with wrong parity to be
7041 ;written onto tape and checking the results obtained when the data is read. The
7042 ;following test sequence is performed:
7043 ;
7044 ;
7045 ; 1. A Write Characteristics command is issued and the resulting status is
7046 ; examined to determine the states of the Extended Features and Buffering
7047 ; Enable switches on the controller module. If buffering is disabled, no
7048 ; further actions need be taken in this step and the program proceeds to
7049 ; the next step. If buffering is enabled, it is disabled via the Buffer
7050 ; Control field in the extended characteristics data word supplied by a
7051 ; Write Characteristics command. (The module must be in Extended mode,
7052 ; so if it is not already, a Write Subsystem Memory command is issued to
7053 ; change the logical sense of the Extended Features switch.)
7054 ;
7055 ; 2. The Write Subsystem Memory command is used to set the Force Wrong
7056 ; Parity control flip-flop.

```





H13

TEST 5: DATA PARITY TEST

```

7115 053072 103426          BCS      204          ;BR IF INIT WAS OK
7116 053074          DELAY    250          ;DELAY ABOUT .25 SEC
      053074 012727 000250          MOV      #250,(PC)+
      053100 000000          .WORD   0
      053102 013727 002116          MOV      L#DLY,(PC)+
      053106 000000          .WORD   0
      053110 005367 177772          DEC      -6(PC)
      053114 001375          BNE     -4
      053116 005367 177756          DEC     -22(PC)
      053122 001367          BNE     -20
7117 053124 005337 054652          DEC      T33DLY          ;BUMP COUNTER
7118 053130 001356          BNE     104             ;BR, IF COUNTER NOT DONE
7119 053132 005237 002214          INC      FATFLG          ;ERROR COUNT
7123 053136 010001          MOV      R0,R1          ;CONTENTS OF TSSR REGISTER
7124 053140          ERRDF   ERRNO,SFIERR,SFIMSG ;FATAL ERROR TSSR WAS NOT OK
      053140 104455          TRAP    C#ERDF
      053142 000765          .WORD   501
      053144 003650          .WORD   SFIERR
      053146 012144          .WORD   SFIMSG
7125 053150 013737 002174 054520 204:  MOV      UNITN,T33DSW          ;SET UP UNIT NUMBER
7126 053156 012704 054500          MOV      #T33PACKET,R4          ;SUBROUTINE NEEDS PACKET ADDRESS
7127 053162 004737 010742          JSR     PC,WRTCHR          ;ISSUE WRITE CHARACTERISTICS
7128 053166 103407          BCS     234             ;BR, IF COMMAND ISSUED OK
7129 053170 005237 002214          INC      FATFLG          ;ERROR COUNT
7134 053174 010001          MOV      R0,R1          ;SAVE CONTENTS OF TSSR
7135 053176          ERRHRD  ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTIC FAILED
      053176 104456          TRAP    C#ERHRD
      053200 000766          .WORD   502
      053202 005054          .WORD   WRTMSG
      053204 012144          .WORD   SFIMSG
7136 053206          234:  CKLOOP          ;LOOP IF SELECTED
      053206 104406          TRAP    C#CLP1
7137 053210 004737 011126          JSR     PC,REWIND          ;CALL TAPE REWIND COMMAND
7138 053214 103411          BCS     304             ;BR, IF NO PROBLEM
7139 053216 016501 000002          MOV      TSSR(R5),R1          ;GET TSSR CONTENTS
7140 053222 010004          MOV      R0,R4          ;GET PACKET ADDRESS
7141 053224 005237 002214          INC      FATFLG          ;ERROR COUNT
7145 053230          ERRHRD  ERRNO,T33RWN,PKTSSR ;REWIND NOT ACCEPTED
      053230 104456          TRAP    C#ERHRD
      053232 000767          .WORD   503
      053234 055350          .WORD   T33RWN
      053236 012156          .WORD   PKTSSR
7146 053240          304:  CKLOOP          ;LOOP IF SELECTED
      053240 104406          TRAP    C#CLP1
7147 053242 013701 054530          MOV      T33BFR-6,R1          ;PICK UP XSTO
7148 053246 010102          MOV      R1,R2          ;SET UP EXPECTED
7149 053250 052702 000002          BIS     #BIT1,R2          ;SET BOT BIT IN EXPECTED
7150 053254 020102          CMP     R1,R2          ;DOES EXP = REC'D
7151 053256 001406          BEQ     404             ;BR, IF EQUAL (OK)
7152 053260 005237 002214          INC      FATFLG          ;ERROR COUNT
7156 053264          ERRHRD  ERRNO,T33BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
      053264 104456          TRAP    C#ERHRD
      053266 000770          .WORD   504
      053270 055255          .WORD   T33BOT
      053272 015604          .WORD   EXPREC
7157 053274          404:  CKLOOP          ;LOOP IF SELECTED

```

## TEST 5: DATA PARITY TEST

```

7158 053274 104406
7159 053276 005737 002220      424:  TST      EXTFEA      ;CHECK FOR EXTENDED FEATURES SW SWITCH
7159 053302 001025      BNE      554      ;BR IF SWITCH IS ON
7160 053304 112737 000200 054631  MOVB    #200,T33BS1 ;WRITE MISCELLANEOUS CONT/READ STATUS
7161 053312 112737 000010 054630  MOVB    #10,T33BS0 ;FUNC. SEL. BIT (TURN ON EXTFEA SWITCH)
7162 053320 012704 054610  MOV      #T33PK2,R4 ;WRITE SUBSYS MEM PACKET
7163 053324 010465 000000  MOV      R4,TSDB(R5) ;ISSUE COMMAND
7164 053330 004737 016446  JSR      PC,CHKTSSR ;WAIT FOR SSR
7165 053334 103407  BCS     504      ;BR, IF NO ERROR
7166 053336 010001  MOV      R0,R1      ;ERROR, SAVE TSSR
7167 053340 005237 002214  INC     FATFLG      ;ERROR COUNT
7171 053344      ERRHRD  ERRNO,T33SSR,PKTSSR ;TSSR NOT CORRECT AFTER WRT. MISCELLANEOUS
      053344 104456      TRAP    C4ERHRD
      053346 000771      .WORD  505
      053350 055171      .WORD  T33SSR
      053352 012156      .WORD  PKTSSR
7172 053354      504:  CKLOOP      ;LOOP IF SELECTED
      053354 104406      TRAP    C4CLP1
7173 053356 005737 002224      554:  TST      BENBSW      ;CHECK FOR BUFFER ENABLED
7174 053362 001426      BEQ     704      ;BR, IF BUFFERING NOT ENABLED
7175 053364 013737 002174 054520  MOV      UNITN,T33DSW ;SET UP UNIT NUMBER
7176 053372 042737 000020 054520  BIC     #BIT4,T33DSW ;BUFFER DISABLE
7177 053400 052737 000010 054520  BIS     #BIT3,T33DSW ;BUFFER DISABLE SEND 01 TO BITS 4 AND 3
7178 053406 012704 054500  MOV      #T33PACKET,R4 ;SUBROUTINE NEEDS PACKET ADDRESS
7179 053412 004737 010742  JSR      PC,WRTCHR   ;ISSUE WRITE CHARACTERISTICS
7180 053416 103407  BCS     604      ;BR, IF COMMAND ISSUED OK
7181 053420 005237 002214  INC     FATFLG      ;ERROR COUNT
7185 053424 010001  MOV      R0,R1      ;SAVE CONTENTS OF TSSR
7186 053426      ERRHRD  ERRNO,WRTMSG,SFMSG ;WRITE CHARACTERISTIC FAILED
      053426 104456      TRAP    C4ERHRD
      053430 000772      .WORD  506
      053432 005054      .WORD  WRTMSG
      053434 012144      .WORD  SFMSG
7187 053436      604:  CKLOOP      ;LOOP IF SELECTED
      053436 104406      TRAP    C4CLP1
7188 053440      704:
7189 053440 112737 000100 054631  MOVB    #100,T33BS1 ;WRITE MISCELLANEOUS CONT/READ STATUS
7190 053446 112737 000011 054630  MOVB    #11,T33BS0 ;FUNC. SEL. BIT (SET WRONG PARITY)
7191 053454 012704 054610  MOV      #T33PK2,R4 ;WRITE SUBSYS MEM PACKET
7192 053460 010465 000000  MOV      R4,TSDB(R5) ;ISSUE COMMAND
7193 053464 004737 016446  JSR      PC,CHKTSSR ;WAIT FOR SSR
7194 053470 103407  BCS     804      ;BR, IF NO ERROR
7195 053472 010001  MOV      R0,R1      ;ERROR, SAVE TSSR
7196 053474 005237 002214  INC     FATFLG      ;ERROR COUNT
7200 053500      ERRHRD  ERRNO,T33SSR,PKTSSR ;TSSR NOT CORRECT AFTER WRT. MISCELLANEOUS
      053500 104456      TRAP    C4ERHRD
      053502 000773      .WORD  507
      053504 055171      .WORD  T33SSR
      053506 012156      .WORD  PKTSSR
7201 053510      804:  CKLOOP      ;LOOP IF SELECTED
      053510 104406      TRAP    C4CLP1
7202 053512 012703 000026      MOV      #22.,R3      ;NUMBER OF RECORDS TO BE WRITTEN
7203 053516 013737 003120 054622  MOV      FREE,T33WB  ;STARTING WRITE BUFFER ADDRESS
7204 053524 005037 054650  CLR     T33CNU      ;MAKE SURE ITS CLEAR
7205 053530 012737 140005 054620 1104:  MOV      #140005,T33PK3 ;WRITE DATA,ACK,CVC-1 COMMAND
7206 053536 012704 054620  MOV      #T33PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
7207 053542 012737 000024 054626  MOV      #20.,T33SZ  ;SET UP RECORD SIZE IN PACKET

```



## TEST 5: DATA PARITY TEST

7208	053550	013777	054650	127342	MOV	T33CNU,@FREE	:MEMORY FILLED WITH DATA IN RECORD		
7209	053556	005237	054650		INC	T33CNU	:READY FOR NEXT RECORD		
7210	053562	010465	000000		MOV	R4,TSD8(R5)	:ISSUE COMMAND		
7211	053566	004737	016360		JSR	PC,WAITF	:WAIT FOR SSR TO SET		
7212	053572	016501	000002		MOV	TSSR(R5),R1	:GET TSSR CONTENTS		
7213	053576	012702	100210		MOV	@SSR!SC!BIT3,R2	:SET UP EXPECTED		
7214	053602	020102			CMP	R1,R2	:ARE THEY EQUAL		
7215	053604	001406			BEQ	1204	:BR, IF OK		
7216	053606	005237	002214		INC	FATFLG	:ERROR COUNT		
7220	053612				ERRHRD	ERRNO,T33WPW,PKTSSR	:TSSR INCORRECT AFTER WRITE DATA		
	053612	104456						TRAP	C#ERHRD
	053614	000774						.WORD	508
	053616	054732						.WORD	T33WPW
	053620	012156						.WORD	PKTSSR
7221	053622			1204:	CKLOOP		:LOOP IF SELECTED		
	053622	104406						TRAP	C#CLP1
7222	053624	013701	054532		MOV	T33BFR-10,R1	:PICK UP XST1		
7223	053630	010102			MOV	R1,R2	:SET UP EXPECTED		
7224	053632	052702	000002		BIS	@BIT1,R2	:SET UNC BIT IN EXPECTED		
7225	053636	020102			CMP	R1,R2	:DOES EXP = REC'D		
7226	053640	001406			BEQ	1304	:BR, IF EQUAL (OK)		
7227	053642	005237	002214		INC	FATFLG	:ERROR COUNT		
7231	053646				ERRHRD	ERRNO,T33UNC,EXPREC	:TAPE NOT AT BOT AFTER REWIND		
	053646	104456						TRAP	C#ERHRD
	053650	000775						.WORD	509
	053652	055012						.WORD	T33UNC
	053654	015604						.WORD	EXPREC
7232	053656			1304:	CKLOOP		:LOOP IF SELECTED		
	053656	104406						TRAP	C#CLP1
7233	053660	005303			DEC	R3	:DEC RECORD COUNTER		
7234	053662	001322			BNE	1104	:BR, IF MORE RECORDS TO WRITE		
7235	053664	004737	011126		JSR	PC,REWIND	:CALL TAPE REWIND COMMAND		
7236	053670	103411			BCS	1404	:BR, IF NO PROBLEM		
7237	053672	016501	000002		MOV	TSSR(R5),R1	:GET TSSR CONTENTS		
7238	053676	010004			MOV	RO,R4	:GET PACKET ADDRESS		
7239	053700	005237	002214		INC	FATFLG	:ERROR COUNT		
7243	053704				ERRHRD	ERRNO,T33RWV,PKTSSR	:REWIND NOT ACCEPTED		
	053704	104456						TRAP	C#ERHRD
	053706	000776						.WORD	510
	053710	055350						.WORD	T33RWV
	053712	012156						.WORD	PKTSSR
7244	053714			1404:	CKLOOP		:LOOP IF SELECTED		
	053714	104406						TRAP	C#CLP1
7245	053716	013701	054530		MOV	T33BFR-6,R1	:PICK UP XST0		
7246	053722	010102			MOV	R1,R2	:SET UP EXPECTED		
7247	053724	052702	000002		BIS	@BIT1,R2	:SET BOT BIT IN EXPECTED		
7248	053730	020102			CMP	R1,R2	:DOES EXP = REC'D		
7249	053732	001406			BEQ	1504	:BR, IF EQUAL (OK)		
7250	053734	005237	002214		INC	FATFLG	:ERROR COUNT		
7254	053740				ERRHRD	ERRNO,T33BOT,EXPREC	:TAPE NOT AT BOT AFTER REWIND		
	053740	104456						TRAP	C#ERHRD
	053742	000777						.WORD	511
	053744	055255						.WORD	T33BOT
	053746	015604						.WORD	EXPREC
7255	053750			1504:	CKLOOP		:LOOP IF SELECTED		
	053750	104406						TRAP	C#CLP1
7256	053752	005037	054650		CLR	T33CNU	:CLEAR DATA VALUE IN RECORD		

TEST 5: DATA PARITY TEST

7257	053756	012703	000024		MOV	@20.,R3		;RECORD SIZE
7258	053762	013737	003120	054622	1554:	MOV	FREE,T33RB	;STARTING WRITE BUFFER ADDRESS
7259	053770	012737	140001	054620		MOV	@140001,T33PK3	;READ DATA,CVC=1,ACK COMMAND
7260	053776	012704	054620		MOV	@T33PK3,R4		;SET UP R4 WITH PACKET ADDRESS
7261	054002	012737	000024	054626		MOV	@20.,T33SZ	;SET UP RECORD SIZE IN PACKET
7262	054010	010465	000000		MOV	R4,T5DB(R5)		;ISSUE COMMAND
7263	054014	004737	016360		JSR	PC,WAITF		;WAIT FOR SSR TO SET
7264	054020	016501	000002		MOV	TSSR(R5),R1		;GET TSSR CONTENTS
7265	054024	012702	100210		MOV	@SSR!SC!BIT3,R2		;SET UP EXPECTED
7266	054030	020102			CMP	R1,R2		;ARE THEY EQUAL
7267	054032	001406			BEQ	1604		;BR, IF OK
7268	054034	005237	002214		INC	FATFLG		;ERROR COUNT
7272	054040				ERRHRD	ERRNO,T33WDC,PKTSSR		;TSSR INCORRECT AFTER WRITE DATA
	054040	104456						TRAP C4ERHRD
	054042	001000						.WORD 512
	054044	055417						.WORD T33WDC
	054046	012156						.WORD PKTSSR
7273	054050				1604:	CKLOOP		;LOOP IF SELECTED
	054050	104406						TRAP C4CLP1
7274	054052	013701	054532		MOV	T33BFR+10,R1		;PICK UP XST1
7275	054056	010102			MOV	R1,R2		;SET UP EXPECTED
7276	054060	052702	000002		BIS	@BIT1,R2		;SET UNC BIT IN EXPECTED
7277	054064	020102			CMP	R1,R2		;DOES EXP = REC'D
7278	054066	001406			BEQ	1704		;BR, IF EQUAL (OK)
7279	054070	005237	002214		INC	FATFLG		;ERROR COUNT
7283	054074				ERRHRD	ERRNO,T33UND,EXPREC		;UNC BIT NOT SET AFTER READ CMD.
	054074	104456						TRAP C4ERHRD
	054076	001001						.WORD 513
	054100	055102						.WORD T33UND
	054102	015604						.WORD EXPREC
7284	054104				1704:	CKLOOP		;LOOP IF SELECTED
	054104	104406						TRAP C4CLP1
7285	054106	013701	054532		MOV	T33BFR+10,R1		;PICK UP XST1
7286	054112	010102			MOV	R1,R2		;SET UP EXPECTED
7287	054114	052702	000400		BIS	@BIT8,R2		;SET RBP BIT IN EXPECTED
7288	054120	020102			CMP	R1,R2		;DOES EXP = REC'D
7289	054122	001406			BEQ	1804		;BR, IF EQUAL (OK)
7290	054124	005237	002214		INC	FATFLG		;ERROR COUNT
7294	054130				ERRHRD	ERRNO,T33RBP,EXPREC		;READ BUS PARITY ERROR BIT NOT SET
	054130	104456						TRAP C4ERHRD
	054132	001002						.WORD 514
	054134	054654						.WORD T33RBP
	054136	015604						.WORD EXPREC
7295	054140				1804:	CKLOOP		;LOOP IF SELECTED
	054140	104406						TRAP C4CLP1
7296	054142	017701	126752		MOV	@FREE,R1		;GET DATA READ
7297	054146	013702	054650		MOV	T33CNU,R2		;GET PATTERN
7298	054152	020102			CMP	R1,R2		;ARE THEY EQUAL
7299	054154	001406			BEQ	1824		;BR, IF OK
7300	054156	005237	002214		INC	FATFLG		;ERROR COUNT
7304	054162				ERRHRD	ERRNO,T33DTA,EXPREC		;DATA NOT CORRECT
	054162	104456						TRAP C4ERHRD
	054164	001003						.WORD 515
	054166	055500						.WORD T33DTA
	054170	015604						.WORD EXPREC
7305	054172				1824:	CKLOOP		;LOOP IF SELECTED
	054172	104406						TRAP C4CLP1



L13

TEST 5: DATA PARITY TEST

7306	054174	013737	003120	054622		MOV	FREE,T33WB		;STARTING WRITE BUFFER ADDRESS
7307	054202	012737	140401	054620	1954:	MOV	#140401,T33PK3		;READ REVERSE DATA RETRY,ACK COMMAND
7308	054210	012704	054620			MOV	#T33PK3,R4		;SET UP R4 WITH PACKET ADDRESS
7309	054214	012737	000024	054626		MOV	#20,T33SZ		;SET UP RECORD SIZE IN PACKET
7310	054222	010465	000000			MOV	R4,T5DB(R5)		;ISSUE COMMAND
7311	054226	004737	016360			JSR	PC,WAITF		;WAIT FOR SSR TO SET
7312	054232	016501	000002			MOV	T5SR(R5),R1		;GET T5SR CONTENTS
7313	054236	012702	100210			MOV	#SC!SSR!BIT3,R2		;SET UP EXPECTED
7314	054242	020102				CMP	R1,R2		;ARE THEY EQUAL
7315	054244	001406				BEQ	1904		;BR, IF OK
7316	054246	005237	002214			INC	FATFLG		;ERROR COUNT
7320	054252					ERRHRD	ERRNO,T33WDC,PKTSSR		;T5SR INCORRECT AFTER WRITE DATA
	054252	104456							TRAP C#ERHRD
	054254	001004							.WORD 516
	054256	055417							.WORD T33WDC
	054260	012156							.WORD PKTSSR
7321	054262				1904:	CKLOOP			;LOOP IF SELECTED
	054262	104406							TRAP C#CLP1
7322	054264	013701	054532			MOV	T33BFR-10,R1		;PICK UP XST1
7323	054270	010102				MOV	R1,R2		;SET UP EXPECTED
7324	054272	052702	000002			BIS	#BIT1,R2		;SET UNC BIT IN EXPECTED
7325	054276	020102				CMP	R1,R2		;DOES EXP = REC'D
7326	054300	001406				BEQ	2004		;BR, IF EQUAL (OK)
7327	054302	005237	002214			INC	FATFLG		;ERROR COUNT
7331	054306					ERRHRD	ERRNO,T33UND,EXPREC		;TAPE NOT AT BOT AFTER REWIND
	054306	104456							TRAP C#ERHRD
	054310	001005							.WORD 517
	054312	055102							.WORD T33UND
	054314	015604							.WORD EXPREC
7332	054316				2004:	CKLOOP			;LOOP IF SELECTED
	054316	104406							TRAP C#CLP1
7333	054320	013701	054532			MOV	T33BFR-10,R1		;PICK UP XST0
7334	054324	010102				MOV	R1,R2		;SET UP EXPECTED
7335	054326	052702	000400			BIS	#BIT8,R2		;SET RBP BIT IN EXPECTED
7336	054332	020102				CMP	R1,R2		;DOES EXP = REC'D
7337	054334	001406				BEQ	2104		;BR, IF EQUAL (OK)
7338	054336	005237	002214			INC	FATFLG		;ERROR COUNT
7342	054342					ERRHRD	ERRNO,T33RBP,EXPREC		;READ BUS PARITY ERROR BIT NOT SET
	054342	104456							TRAP C#ERHRD
	054344	001006							.WORD 518
	054346	054654							.WORD T33RBP
	054350	015604							.WORD EXPREC
7343	054352				2104:	CKLOOP			;LOOP IF SELECTED
	054352	104406							TRAP C#CLP1
7344	054354	017701	126540			MOV	#FREE,R1		;GET DATA READ
7345	054360	013702	054650			MOV	T33CNU,R2		;GET PATTERN
7346	054364	020102				CMP	R1,R2		;ARE THEY EQUAL
7347	054366	001406				BEQ	2154		;BR, IF OK
7348	054370	005237	002214			INC	FATFLG		;ERROR COUNT
7352	054374					ERRHRD	ERRNO,T33DTA,EXPREC		;DATA NOT CORRECT
	054374	104456							TRAP C#ERHRD
	054376	001007							.WORD 519
	054400	055500							.WORD T33DTA
	054402	015604							.WORD EXPREC
7353	054404				2154:	CKLOOP			;LOOP IF SELECTED
	054404	104406							TRAP C#CLP1
7354	054406	010302				MOV	R3,R2		;SAVE R3 FOR A MOMENT





TEST 5: DATA PARITY TEST

```

7415
7416
7417
7418 054630
7419 054630      010
7420 054631      200
7421 054632 000000
7422 054634 000000
7423
7424
7425
7426
7427
7428 054636 100205
7429 054640 100605
7430 054642 102205
7431 054644 177777
7432
7433
7434 054646 000000
7435 054650 000000
7436 054652 000000
7437
7438
7439
7440
7441 054654      122      145      141
7442 054732      124      123      123
7443 055012      125      116      103
7444 055102      125      116      103
7445 055171      127      122      111
7446 055255      124      141      160
7447 055350      122      145      167
7448 055417      124      123      123
7449 055500      104      141      164
7450 055575      104      141      164
7451
7452
7453
7454
7455
7456
7457
7458
7459 055612
7460 055612
7461 055616 012701 054500
7462 055622 012721 100004
7463 055626 012721 054510
7464 055632 005021
7465 055634 012721 000012
7466 055640 012721 054522
7467 055644 005021
7468 055646 012721 000024
7469 055652 005021
7470 055654 012711 000000
7471 055660 012702 000030

```

```

;
;
;T33BF2:
T33BS0: .BYTE 10 ;BSELO AREA
T33BS1: .BYTE 200 ;BSEL1 AREA
T33S2: .WORD 0 ;SEL 2 AREA
T33S3: .WORD 0 ;DATA AREA
;
;
; .EVEN
;TAPE MOTION PACKET COMMAND VALUES
T33RN: .WORD 100205 ;REREAD DATA (NEXT)
T33WDR: .WORD 100605 ;REREAD DATA RETRY
T33CON: .WORD 102205 ;WRITE CONTINUOUS
; .WORD 177777 ;END OF DATA
;
;T33CNT: .WORD 0 ;TAPE TIMER COUNTER STORAGE AREA
T33CNU: .WORD 0 ;TAPE TIMER COUNTER STORAGE AREA
T33DLY: .WORD 0 ;DELAY COUNTER
;
;*
;LOCAL TEXT MESSAGES FOR TEST
;
;
141 T33RBP: .ASCIZ 'Read Bus Parity Bit Not Set (XST1), Should Be'
123 T33WPW: .ASCIZ 'TSSR Incorrect After Wrong Parity Write Command'
103 T33UNC: .ASCIZ 'UNC Bit (XST1) Not Set After Wrong Parity WRITE Command'
103 T33UND: .ASCIZ 'UNC Bit (XST1) Not Set After Wrong Parity READ Command'
111 T33SSR: .ASCIZ 'WRITE MISCELLANEOUS CONT/READ COMMAND Not Accepted'
160 T33BOT: .ASCIZ 'Tape Not At BOT After REWIND Command (BOT Not Set In XST0)'
167 T33RMN: .ASCIZ 'Rewind (POSITION) Command Not Accepted'
123 T33WDC: .ASCIZ 'TSSR Not Correct After READ Wrong Parity Command'
164 T33DTA: .ASCIZ 'Data Compare Error, Data Read From Tape Not Equal To Written'
164 TST33ID: .ASCIZ 'Data Parity'
; .EVEN
;
;*
;ROUTINE TO RESTORE COMMAND PACKET TO START-UP (DEFAULT) VALUES
;WRITE SUBSYSTEM MEMORY COMMAND
;
;
;
T33REST:
SAVREG
MOV #T33PACKET,R1 ;SAVE THE REGISTERS
MOV #100004,(R1)- ;START OF THE PACKET
MOV #T33DATA,(R1)- ;WRITE SUBSYSTEM MEM. WITH ACK,
;ADDRESS OF CHARAISTICS DATA BLOCK
CLR (R1)- ;EXTENDED ADDRESS
MOV #10,(R1)- ;SIZE OF DATA BLOCK IN BYTES
MOV #T33BFR,(R1)- ;ADDRESS OF MESSAGE BUFFER
CLR (R1)-
MOV #20,(R1)- ;LENGTH OF MESSAGE BUFFER
CLR (R1)-
MOV #0,(R1) ;SELECT DRIVE ZERO
MOV #24,,R2 ;NUMBER OF LOCATIONS TO BE CLEARED

```

TEST 5: DATA PARITY TEST

```

7472 055664 012762 177777 054522 64:  MOV    #177777,T33BFR(R2)    ;ALL ONES TO MESSAGE BUFFER
7473 055672 005742                TST    -(R2)                ;NEXT LOCATION
7474 055674 022702 000000          CMP    #0,R2                ;AT END OF LOOP YET
7475 055700 001371                BNE   64:                   ;KEEP GOING UNTIL DONE
7476 055702 000207                RTS    PC                    ;RETURN
7477
7478 055704                T33RT2:
7479 055704                SAVREG                       ;SAVE THE REGISTERS
7480 055710 012701 054610          MOV    #T33PK2,R1           ;START OF THE PACKET
7481 055714 012721 100006          MOV    #100006,(R1)+        ;WRITE SUBSYSTEM MEM. WITH ACK,
7482 055720 012721 054630          MOV    #T33BF2,(R1)+        ;ADDRESS OF DATA BLOCK
7483 055724 005021                CLR    (R1)+                ;EXTENDED ADDRESS
7484 055726 012721 000006          MOV    #6,(R1)+            ;SIZE OF DATA BLOCK IN BYTES
7485 055732 005021                CLR    (R1)+
7486 055734 012701 054630          MOV    #T33BF2,R1           ;POINT TO DATA SEL AREA
7487 055740 005021                CLR    (R1)+
7488 055742 005011                CLR    (R1)
7489 055744 000207                RTS    PC                    ;RETURN
7490 055746                T33RT3:
7491 055746                SAVREG                       ;SAVE REGISTERS
7492 055752 012701 054620          MOV    #T33PK3,R1           ;SET UP POINTER ADDRESS
7493 055756 005021                CLR    (R1)+                ;COMMAND SPACE
7494 055760 005021                CLR    (R1)+                ;ADDRESS OF DATA BLOCK
7495 055762 005021                CLR    (R1)+                ;EXTENDED ADDRESS
7496 055764 005011                CLR    (R1)                 ;SIZE OF DATA TRANSFER BLOCK
7497 055766 000207                RTS    PC                    ;RETURN
7498 055770                ENDTST
7499 055770                L10057: TRAP    C#ETST
7500 055770                104401

```

.SBTTL TEST 6: OPERATIONS AT EOT

```

7501 ;*
7502 ;
7503 ;THIS TEST VERIFIES PROPER OPERATION OF THE WRITE DATA RETRY
7504 ;COMMAND (SPACE REVERSE, ERASE, WRITE DATA)
7505 ;
7506 ;THE TEST CONSISTS OF THE FOLLOWING 1 SUBTEST
7507 ;
7508 ;
7509 ;
7510 ;-
7511 BGNTST
7512 055772 012737 006356 002172          MOV    #EPRT1,EPRTSW        T6::
7517 056000 012700 063137          MOV    #TST34ID,R0          ;PRIMARY ERROR MESSAGE
7518 056004 004737 016620          JSR    PC,TSTSETUP          ;ASCII MESSAGE TO IDENTIFY TEST
7519 056010 012737 000005 002210          MOV    #5,LOOPCNT          ;DO INITIAL TEST SETUP
7520 056016 005037 060622          CLR    T34CNT              ;PERFORM 5 ITERATIONS
7521 ;*
7522 ;
7523 ;TEST 6. SUBTEST 1
7524 ;
7525 ;
7526 ; THIS TEST VERIFIES THAT THE EOT STATUS IS HANDLED PROPERLY BY
7527 ; THE VARIOUS TAPE MOTION COMMANDS. THE FOLLOWING TEST SEQUENCE
7528 ; IS PERFORMED:
7529 ;

```









E14

TEST 6: OPERATIONS AT EOT

```

7632 056170 103407          BCS      304          ;BR. IF COMMAND ISSUED OK
7633 056172 005237 002214  INC      FATFLG      ;ERROR COUNT
7637 056176 010001          MOV      RO,R1        ;SAVE CONTENTS OF TSSR
7638 056200          ERRHRD  ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTIC FAILED
                                TRAP      C4ERHRD
                                .WORD     602
                                .WORD     WRTMSG
                                .WORD     SFIMSG
7639 056210          304:   CKLOOP      ;LOOP IF SELECTED
                                TRAP      C4CLP1
7640 056210 104406          JSR      PC,REWIND    ;REWIND CALL
7641 056216 103411          BCS      354          ;BR. IF TSSR IS OK (GOOD)
7642 056220 016501 000002  MOV      TSSR(R5),R1 ;GET TSSR
7643 056224 010004          MOV      RO,R4        ;SET UP PACKET
7644 056226 005237 002214  INC      FATFLG      ;ERROR COUNT
7648 056232          ERRHRD  ERRNO,T34RWN,PKTSSR ;TSSR IS INCORRECT AFTER REWIND
                                TRAP      C4ERHRD
                                .WORD     603
                                .WORD     T34RWN
                                .WORD     PKTSSR
7649 056242          354:   CKLOOP      ;LOOP IF SELECTED
                                TRAP      C4CLP1
7650 056244 012737 140005 060610  MOV      #140005,T34PK3 ;WRITE DATA, ACK, CVC=1
7651 056252 012703 176750          MOV      #65000.,R3    ;SET MAX NUMBER OF WRITES
7652 056256 013737 003120 060612  MOV      FREE,T34WB    ;SET UP WRITE BUFFER ADDRESS
7653 056264 012737 006654 060616  MOV      #3500.,T34SZ  ;SET UP BUFFER SIZE (4K BYTES)
7654 056272 012704 060610          MOV      #T34PK3,R4   ;R4 = POINTER TO PACKET
7655 056276 010465 000000          MOV      R4,TSDB(R5)  ;ISSUE COMMAND
7656 056302 004737 016360          JSR      PC,WAITF     ;WAIT FOR SSR TO SET
7657 056306 016501 000002  MOV      TSSR(R5),R1  ;GET TSSR CONTENTS
7658 056312 012702 000200          MOV      #SSR,R2     ;SET UP EXPECTED
7659 056316 020102          CMP      R1,R2       ;ARE THEY EQUAL
7660 056320 001010          BNE      504         ;BR. IT MIGHT BE END OF TAPE
7661 056322 005303          DEC      R3         ;DEC RECORD COUNTER
7662 056324 001364          BNE      404         ;BR. IF MORE TO GO
7663 056326 005237 002214  INC      FATFLG      ;ERROR COUNT
7667 056332          ERRDF  ERRNO,T34ET,PKTSSR ;EOT NOT FOUND (USE SHORTER TAPE?)
                                TRAP      C4ERDF
                                .WORD     604
                                .WORD     T34ET
                                .WORD     PKTSSR
7668 056342 032701 000004          504:   BIT      #BIT2,R1 ;CHECK FOR TAPE STATUS ALERT
7669 056346 001001          BNE      604         ;BR. IF SET
7670 056350 000752          BR       404         ;KEEP GOING
7671 056352 013701 060520          604:   MOV      T34BFR-6,R1 ;PICK UP XSTO
7672 056356 010102          MOV      R1,R2       ;SET UP EXPECTED
7673 056360 052702 000001          BIS      #BIT0,R2    ;SET THE EOT BIT ON IN EXPECTED
7674 056364 020102          CMP      R1,R2       ;WAS THE BIT ON
7675 056366 001402          BEQ      804         ;BR. IF EOT WAS FOUND
7676 056370 000137 056276          JMP      404         ;KEEP LOOKING
7677 056374          804:   CKLOOP      ;LOOP IF SELECTED
                                TRAP      C4CLP1
7678 056376 012737 140005 060610  MOV      #140005,T34PK3 ;WRITE DATA, ACK, CVC=1
7679 056404 013737 003120 060612  MOV      FREE,T34WB    ;SET UP WRITE BUFFER ADDRESS
7680 056412 012737 006654 060616  MOV      #3500.,T34SZ  ;SET UP BUFFER SIZE (4K BYTES)
7681 056420 012704 060610          MOV      #T34PK3,R4   ;R4 = POINTER TO PACKET
7682 056424 010465 000000          MOV      R4,TSDB(R5)  ;ISSUE COMMAND

```





TEST 6: OPERATIONS AT EOT

```

7732 056646 012704 060610      MOV      #T34PK3,R4      ;R4 = POINTER TO PACKET
7733 056652 010465 000000      MOV      R4,TSDB(R5)    ;ISSUE COMMAND
7734 056656 004737 016360      JSR      PC,WAITF      ;WAIT FOR SSR TO SET
7735 056662 016501 000002      MOV      TSSR(R5),R1   ;GET TSSR CONTENTS
7736 056666 012702 000200      MOV      #SSR,R2      ;SET UP EXPECTED
7737 056672 020102      CMP      R1,R2        ;ARE THEY EQUAL
7738 056674 001406      BEQ     130$         ;BR, IF STATUS IS GOOD (OK)
7739 056676 005237 002214      INC      FATFLG        ;ERROR COUNT
7743 056702      ERRHRD  ERRNO,T34STM,PKTSSR ;SKIP TAPE MARK REV. DIDN'T SET TSA
                                TRAP      C$ERHRD
                                .WORD    609
                                .WORD    T34STM
                                .WORD    PKTSSR
7744 056712      130$:  CKLOOP          ;LOOP IF SELECTED
                                TRAP      C$CLP1
7745 056714 013701 060520      MOV      T34BFR+6,R1   ;PICK UP XSTO
7746 056720 010102      MOV      R1,R2        ;SET UP EXPECTED
7747 056722 052702 000001      BIS      #BIT0,R2     ;SET THE EOT BIT ON IN EXPECTED
7748 056726 020102      CMP      R1,R2        ;WAS THE BIT ON
7749 056730 001406      BEQ     140$         ;BR, IF EOT WAS FOUND
7750 056732 005237 002214      INC      FATFLG        ;ERROR COUNT
7754 056736      ERRHRD  ERRNO,T34ETN,EXPREC ;EOT BIT (XSTO) NOT SET
                                TRAP      C$ERHRD
                                .WORD    610
                                .WORD    T34ETN
                                .WORD    EXPREC
7755 056746      140$:  CKLOOP          ;LOOP IF SELECTED
                                TRAP      C$CLP1
7756 056750 013701 060520      MOV      T34BFR+6,R1   ;PICK UP XSTO
7757 056754 010102      MOV      R1,R2        ;SET UP EXPECTED
7758 056756 052702 100000      BIS      #BIT15,R2    ;SET THE TMK BIT ON IN EXPECTED
7759 056762 020102      CMP      R1,R2        ;WAS THE BIT ON
7760 056764 001406      BEQ     150$         ;BR, IF TMK WAS FOUND
7761 056766 005237 002214      INC      FATFLG        ;ERROR COUNT
7765 056772      ERRHRD  ERRNO,T34TMK,EXPREC ;EOT BIT (XSTO) NOT SET
                                TRAP      C$ERHRD
                                .WORD    611
                                .WORD    T34TMK
                                .WORD    EXPREC
7766 057002      150$:  CKLOOP          ;LOOP IF SELECTED
                                TRAP      C$CLP1
7767 057004 012737 140410 060610      MOV      #140410,T34PK3 ;SPACE RECORDS REVERSE, ACK, CVC-1 CMD
7768 057012 012737 000001 060612      MOV      #1,T34WB      ;SPACE ONE RECORD REVERSE
7769 057020 012704 060610      MOV      #T34PK3,R4   ;R4 = POINTER TO PACKET
7770 057024 010465 000000      MOV      R4,TSDB(R5)  ;ISSUE COMMAND
7771 057030 004737 016360      JSR      PC,WAITF      ;WAIT FOR SSR TO SET
7772 057034 016501 000002      MOV      TSSR(R5),R1  ;GET TSSR CONTENTS
7773 057040 012702 100204      MOV      #SC!SSR!BIT2,R2 ;SET UP EXPECTED
7774 057044 020102      CMP      R1,R2        ;ARE THEY EQUAL
7775 057046 001006      BNE     160$         ;BR, IT MIGHT BE END OF TAPE
7776 057050 005237 002214      INC      FATFLG        ;ERROR COUNT
7780 057054      ERRHRD  ERRNO,T34POS,PKTSSR ;EOT NOT FOUND (USE SHORTER TAPE?)
                                TRAP      C$ERHRD
                                .WORD    612
                                .WORD    T34POS
                                .WORD    PKTSSR
7781 057064      160$:  CKLOOP          ;LOOP IF SELECTED

```

TEST 6: OPERATIONS AT EOT

```

7782 057064 104406 060520      MOV      T34BFR+6,R1      ;PICK UP XSTO          TRAP      C#CLP1
7783 057066 013701 060520      MOV      R1,R2           ;SET UP EXPECTED
7784 057074 052702 000001      BIS      @BIT0,R2        ;SET THE EOT BIT ON IN EXPECTED
7785 057100 020102 000001      CMP      R1,R2          ;WAS THE BIT ON
7786 057102 001406 000001      BEQ      1634           ;BR, IF EOT WAS FOUND
7787 057104 005237 002214      INC      FATFLG          ;ERROR COUNT
7791 057110 015604 002214      ERRHRD  ERRNO,T34ETN,EXPREC ;EOT BIT (XSTO) NOT SET
                                TRAP      C#ERHRD
                                .WORD    613
                                .WORD    T34ETN
                                .WORD    EXPREC
7792 057120 104456 060520      1634:   CKLOOP          ;LOOP IF SELECTED          TRAP      C#CLP1
                                .WORD    613
                                .WORD    T34ETN
                                .WORD    EXPREC
7793 057122 013701 060520      MOV      T34BFR+6,R1      ;PICK UP XSTO
7794 057126 010102 060520      MOV      R1,R2           ;SET UP EXPECTED
7795 057130 042702 100000      BIC      @BIT15,R2       ;CLEAR THE TMK BIT ON IN EXPECTED
7796 057134 020102 100000      CMP      R1,R2          ;WAS THE BIT ON
7797 057136 001406 100000      BEQ      1654           ;BR, IF TMK WAS FOUND
7798 057140 005237 002214      INC      FATFLG          ;ERROR COUNT
7802 057144 015604 002214      ERRHRD  ERRNO,T34TMK,EXPREC ;EOT BIT (XSTO) NOT SET
                                TRAP      C#ERHRD
                                .WORD    614
                                .WORD    T34TMK
                                .WORD    EXPREC
7803 057154 104456 060520      1654:   CKLOOP          ;LOOP IF SELECTED
                                TRAP      C#CLP1
7804 057156 012737 140410 060610      MOV      @140410,T34PK3   ;SPACE RECORDS REVERSE, ACK, CVC-1 CMD
7805 057164 012737 000001 060612      MOV      @1,T34WB        ;SPACE ONE RECORD REVERSE
7806 057172 012704 060610      MOV      @T34PK3,R4      ;R4 = POINTER TO PACKET
7807 057176 010465 000000      MOV      R4,TSDB(R5)     ;ISSUE COMMAND
7808 057202 004737 016360      JSR      PC,WAITF        ;WAIT FOR SSR TO SET
7809 057206 016501 000002      MOV      TSSR(R5),R1     ;GET TSSR CONTENTS
7810 057212 012702 000200      MOV      @SSR,R2         ;SET UP EXPECTED
7811 057216 020102 000200      CMP      R1,R2          ;ARE THEY EQUAL
7812 057220 001406 000200      BEQ      1674           ;BR, IT MIGHT BE END OF TAPE
7813 057222 005237 002214      INC      FATFLG          ;ERROR COUNT
7817 057226 015604 002214      ERRHRD  ERRNO,T34POS,PKTSSR ;EOT NOT FOUND (USE SHORTER TAPE?)
                                TRAP      C#ERHRD
                                .WORD    615
                                .WORD    T34POS
                                .WORD    PKTSSR
7818 057236 104456 060520      1674:   CKLOOP          ;LOOP IF SELECTED          TRAP      C#CLP1
                                .WORD    615
                                .WORD    T34POS
                                .WORD    PKTSSR
7819 057240 013701 060520      MOV      T34BFR+6,R1      ;PICK UP XSTO
7820 057244 010102 060520      MOV      R1,R2           ;SET UP EXPECTED
7821 057246 042702 000001      BIC      @BIT0,R2        ;CLEAR THE EOT BIT ON IN EXPECTED
7822 057252 020102 000001      CMP      R1,R2          ;WAS THE BIT OFF
7823 057254 001400 000001      BEQ      1704           ;BR, IF EOT WAS FOUND
7824 057256 015604 000001      1704:   CKLOOP          ;LOOP IF SELECTED
                                TRAP      C#CLP1
7825 057260 012737 140010 060610      MOV      @140010,T34PK3   ;SPACE RECORDS FORWARD, ACK, CVC-1
7826 057266 012737 000002 060612      MOV      @2,T34WB        ;SPACE TWO RECORDS
7827 057274 012704 060610      MOV      @T34PK3,R4      ;R4 = POINTER TO PACKET
7828 057300 010465 000000      MOV      R4,TSDB(R5)     ;ISSUE COMMAND
7829 057304 004737 016360      JSR      PC,WAITF        ;WAIT FOR SSR TO SET
7830 057310 016501 000002      MOV      TSSR(R5),R1     ;GET TSSR CONTENTS

```



## TEST 6: OPERATIONS AT EOT

```

7831 057314 012702 000200      MOV    #SSR,R2      ;SET UP EXPECTED
7832 057320 020102      CMP    R1,R2       ;ARE THEY EQUAL
7833 057322 001406      BEQ    1904        ;BR. IT MIGHT BE END OF TAPE
7834 057324 005237 002214      INC    FATFLG      ;ERROR COUNT
7838 057330      ERRHRD ERRNO,T34POS,PKTSSR ;EOT NOT FOUND (USE SHORTER TAPE?)
      057330 104456      TRAP   C4ERHRD
      057332 001150      .WORD 616
      057334 060644      .WORD T34POS
      057336 012156      .WORD PKTSSR
7839 057340      1904:  CKLOOP      ;LOOP IF SELECTED      TRAP   C4CLP1
      057340 104406
7840 057342 013701 060520      MOV    T34FR+6,R1 ;PICK UP XSTO
7841 057346 010102      MOV    R1,R2       ;SET UP EXPECTED
7842 057350 052702 000001      BIS    #BIT0,R2    ;SET THE EOT BIT ON IN EXPECTED
7843 057354 020102      CMP    R1,R2       ;WAS THE BIT ON
7844 057356 001406      BEQ    2004        ;BR. IF EOT WAS FOUND
7845 057360 005237 002214      INC    FATFLG      ;ERROR COUNT
7849 057364      ERRHRD ERRNO,T34ETS,EXPREC ;EOT BIT (XSTO) NOT SET
      057364 104456      TRAP   C4ERHRD
      057366 001151      .WORD 617
      057370 061460      .WORD T34ETS
      057372 015604      .WORD EXPREC
7850 057374      2004:  CKLOOP      ;LOOP IF SELECTED      TRAP   C4CLP1
      057374 104406
7851 057376 012737 140401 060610      MOV    #140401,T34PK3 ;READ REVERSE, ACK, CVC=1
7852 057404 013737 003120 060612      MOV    FREE,T34RB   ;SET UP WRITE BUFFER ADDRESS
7853 057412 012704 060610      MOV    #T34PK3,R4  ;R4 = POINTER TO PACKET
7854 057416 010465 000000      MOV    R4,TSD8(R5) ;ISSUE COMMAND
7855 057422 004737 016360      JSR    PC,WAITF     ;WAIT FOR SSR TO SET
7856 057426 016501 000002      MOV    TSSR(R5),R1 ;GET TSSR CONTENTS
7857 057432 012702 000200      MOV    #SSR,R2     ;SET UP EXPECTED
7858 057436 020102      CMP    R1,R2       ;ARE THEY EQUAL
7859 057440 001406      BEQ    2054        ;BR. ONLY SSR IS SET
7860 057442 005237 002214      INC    FATFLG      ;ERROR COUNT
7864 057446      ERRHRD ERRNO,T34RRE,PKTSSR ;EOT NOT FOUND (USE SHORTER TAPE?)
      057446 104456      TRAP   C4ERHRD
      057450 001152      .WORD 618
      057452 061016      .WORD T34RRE
      057454 012156      .WORD PKTSSR
7865 057456      2054:  CKLOOP      ;LOOP IF SELECTED      TRAP   C4CLP1
      057456 104406
7866 057460 012737 140401 060610      MOV    #140401,T34PK3 ;READ REVERSE, ACK, CVC=1
7867 057466 013737 003120 060612      MOV    FREE,T34RB   ;SET UP WRITE BUFFER ADDRESS
7868 057474 012704 060610      MOV    #T34PK3,R4  ;R4 = POINTER TO PACKET
7869 057500 010465 000000      MOV    R4,TSD8(R5) ;ISSUE COMMAND
7870 057504 004737 016360      JSR    PC,WAITF     ;WAIT FOR SSR TO SET
7871 057510 016501 000002      MOV    TSSR(R5),R1 ;GET TSSR CONTENTS
7872 057514 012702 000200      MOV    #SSR,R2     ;SET UP EXPECTED
7873 057520 020102      CMP    R1,R2       ;ARE THEY EQUAL
7874 057522 001406      BEQ    2104        ;BR. IT MIGHT BE END OF TAPE
7875 057524 005237 002214      INC    FATFLG      ;ERROR COUNT
7879 057530      ERRHRD ERRNO,T34RRE,PKTSSR ;EOT NOT FOUND (USE SHORTER TAPE?)
      057530 104456      TRAP   C4ERHRD
      057532 001153      .WORD 619
      057534 061016      .WORD T34RRE
      057536 012156      .WORD PKTSSR
7880 057540      2104:  CKLOOP      ;LOOP IF SELECTED

```







TEST 6: OPERATIONS AT EOT

060246	012727	000250				MOV	#250,(PC)-	
060252	000000					.WORD	0	
060254	013727	002116				MOV	L#DLY,(PC)-	
060260	000000					.WORD	0	
060262	005367	177772				DEC	-6(PC)	
060266	001375					BNE	-.4	
060270	005367	177756				DEC	-22(PC)	
060274	001367					BNE	.-20	
7981	060276	005337	060624					
7982	060302	001352						
7983	060304	012702	000200	286:	DEC	T34DLY		:BUMP COUNTER
7984	060310	020102			BNE	285:		:BR, IF MORE TO COUNT
7985	060312	001007			MOV	#SSR,R2		:SET UP EXPECTED
7986	060314	005303			CMP	R1,R2		:ARE THEY EQUAL
7987	060316	005237	002214		BNE	290:		:BR, IT MIGHT BE END OF TAPE
7991	060322				DEC	R3		:DEC RECORD COUNTER
	060322	104456			INC	FATFLG		:ERROR COUNT
	060324	001162			ERRHRD	ERRNO,T34ET,PKTSSR		:EOT NOT FOUND (USE SHORTER TAPE?)
	060326	062046						TRAP
	060330	012156						.WORD
7992	060332	032701	000004	290:	BIT	#BIT2,R1		C#ERHRD
7993	060336	013701	060520		MOV	T34BFR-6,R1		.WORD
7994	060342	010102			MOV	R1,R2		626
7995	060344	042702	000001		BIC	#BIT0,R2		T34ET
7996	060350	020102			CMP	R1,R2		.WORD
7997	060352	001406			BEQ	300:		PKTSSR
7998	060354	005237	002214		INC	FATFLG		
8002	060360				ERRHRD	ERRNO,T34ETC,EXPREC		
	060360	104456						
	060362	001163						
	060364	061107						
	060366	015604						
8003	060370			300:	CKLOOP			
	060370	104406						
8004	060372	013701	060520		MOV	T34BFR-6,R1		TRAP
8005	060376	010102			MOV	R1,R2		C#CLP1
8006	060400	052702	000002		BIS	#BIT1,R2		
8007	060404	020102			CMP	R1,R2		
8008	060406	001406			BEQ	320:		
8009	060410	005237	002214		INC	FATFLG		
8013	060414				ERRHRD	ERRNO,T34BOT,EXPREC		
	060414	104456						
	060416	001164						
	060420	061164						
	060422	015604						
8014	060424			320:	CKLOOP			
	060424	104406						
8015	060426			600:	ENDSUB			
8016	060426							
	060426							
	060426	104403						
8017	060430	023727	002214	000017	CMP	FATFLG,#15.		TRAP
8018	060436	103402			BLO	999:		C#ESUB
8019	060440	004737	017312		JSR	PC,CKDROP		
8020	060444							
8021	060444	004737	016566	999:	JSR	PC,TSTLOOP		
8022	060450	103002			BCC	163:		



## TEST 6: OPERATIONS AT EOT

```

8023 060452 000137 056022
8024 060456
      060456 104432
      060460 002662
8025
8026
8027
8029      060470
8031 060470
8032 060470 100004
8033 060472 060500
8034 060474 000000
8035 060476 000010
8036 060500
8037 060500 060512
8038 060502 000000
8039 060504 000012
8040 060506 000000
8041 060510 000000
8042 060512
8043
8044
8045
8047      060600
8049 060600
8050 060600 100006
8051 060602 060626
8052 060604 000000
8053 060606 000006
8054
8058 060610
8059 060610 100005
8060 060612
8061 060612 000000
8062 060614 000000
8063 060616 000000
8064
8065
8066 060620 000000
8067 060622 000000
8068 060624 000000
8069
8070
8071 060626
8072 060626      010
8073 060627      200
8074 060630 000000
8075 060632 000000
8076
8077
8078
8079
8080
8081 060634 100005
8082 060636 100405
8083 060640 102005
8084 060642 177777

      JMP      T34LOOP
      EXIT     TST
1634:
;EXECUTE AGAIN
;ALL DONE THIS TEST
      TRAP     C$EXIT
      .WORD    L10061-.

;*
;LOCAL STORAGE FOR THIS TEST
;-
      .=<..10>E177770
T34PACKET:
      .WORD    100004
      .WORD    T34DATA
      .WORD    0
      .WORD    8.
T34DATA:
      .WORD    T34BFR
      .WORD    0
      .WORD    10.
      .WORD    0
T34DSW: .WORD 0
T34BFR: .BLKW 25.
;WRITE SUBSYSTEM MEMORY COMMAND PACKET
;
      .=<..10>E177770
T34PK2:
      .WORD    100006
      .WORD    T34BF2
      .WORD    0
      .WORD    6.
;WRITE SUB SYS MEM COMMAND, AND ACK
;ADDRESS OF SELECT BLOCK DATA
;SIZE OF DATA PACKET
T34PK3:
      .WORD    100005
;WRITE COMMAND, AND ACK
T34RB:
T34WB: .WORD 0
;ADDRESS OF WRITE/READ BUFFER
      .WORD 0
T34SZ: .WORD 0
;SIZE OF BUFFER (EXTENT)
      .EVEN
;
T34RSZ: .WORD 0
;LARGEST TAPE RECORD IN BYTES
T34CNT: .WORD 0
;TAPE RECORD COUNTER
T34DLY: .WORD 0
;DELAY COUNTER
;
;
T34BF2:
T34BS0: .BYTE 10
;BSELO AREA
T34BS1: .BYTE 200
;BSEL1 AREA
T34S2: .WORD 0
;SEL 2 AREA
T34S3: .WORD 0
;DATA AREA
;
;
      .EVEN
;TAPE MOTION PACKET COMMAND VALUES
T34WD: .WORD 100005
;WRITE DATA (NEXT)
T34WDR: .WORD 100405
;WRITE DATA RETRY
T34CON: .WORD 102005
;WRITE CONTINUOUS
      .WORD 177777
;END OF DATA

```

TEST 6: OPERATIONS AT EOT

```

8085
8086
8087
8088
8089 060644      124      123      123  T34POS: .ASCIZ  'TSSR Incorrect After Position (SPACE RECORDS) Command'
8090 060732      127      122      111  T34ETO: .ASCIZ  'WRITE TAPE MARK At EOT Failed To Set EOT Bit (XSTO)'
8091 061016      122      105      101  T34RRE: .ASCIZ  'READ Command At EOT Didn't Give Normal Termination (TSSR)'
8092 061107      125      156      141  T34ETC: .ASCIZ  'Unable To Clear EOT Indication, (XSTO) Bit 0'
8093 061164      122      105      127  T34BOT: .ASCIZ  'REWIND Failed To Set BOT (XSTO) Bit'
8094 061230      127      122      111  T34WTH: .ASCIZ  'WRITE TAPE MARK At EOT Failed To Set Tape Status Alert'
8095 061317      127      122      111  T34ET2: .ASCIZ  'WRITE DATA At EOT Failed To Set Tape Status Alert'
8096 061401      127      122      111  T34ETN: .ASCIZ  'WRITE DATA At EOT Failed To Set EOT Bit (XSTO)'
8097 061460      123      120      101  T34ETS: .ASCIZ  'SPACE RECORDS FORWARD At EOT Failed To Set EOT Bit (XSTO)'
8098 061552      122      105      101  T34ETZ: .ASCIZ  'READ DATA At EOT Failed To Set EOT Bit (XSTO)'
8099 061630      124      123      123  T34STM: .ASCIZ  'TSSR Incorrect After SKIP TAPE MARK REVERSE At EOT'
8100 061713      120      117      123  T34TMK: .ASCIZ  'POSITION Command At EOT Onto Tape Mark Failed To Set TMK (XSTO)'
8101 062013      127      122      111  T34SSR: .ASCIZ  'WRITE Command Not Accepted'
8102 062046      105      117      124  T34ET:  .ASCIZ  'EOT Not Found In 65000 3.5K Writes, (Use Shorter Tape)'
8103 062135      127      122      111  T34EOT: .ASCIZ  'WRITE DATA OVER EOT GAVE NO TAPE STATUS ALERT'
8104 062213      124      123      123  T34TM:  .ASCIZ  'TSSR Not Correct After WRITE Command Reject'
8105 062267      122      145      167  T34RWN: .ASCIZ  'Rewind (POSITION) Command Not Accepted'
8106 062336      122      101      115  T34RNC: .ASCIZ  'RAM Error, Correct Data Pattern Not In Ram'
8107 062411      124      123      123  T34AM3: .ASCIZ  'TSSR Init. Failed After WRITE Command'
8108 062457      104      162      151  T34OFL: .ASCIZ  'Drive 7 Select Failed To Set "OFL" In TSSR'
8109 062532      124      123      123  T34WDD: .ASCIZ  'TSSR Not Correct After WRITE DATA Command, SWB Bit Set'
8110 062621      124      123      123  T34WDC: .ASCIZ  'TSSR Not Correct After WRITE DATA Command, Check For Tape Offline'
8111 062723      103      126      103  T34VCK: .ASCIZ  'CVC Set, Didn't Reset VCK In Message Buffer'
8112 062776      124      123      102  T34BA:  .ASCIZ  'TSBA Not Correct After WRITE DATA Command'
8113 063050      127      122      111  T34WSS: .ASCIZ  'WRITE SUBSYSTEM MEMORY Command Not Accepted (RAM Read)'
8114 063137      117      160      145  TST34ID: .ASCIZ  'Operations At EOT'
8115
8116
8117
8118
8119
8120
8121
8122
8123 063162
8124 063162
8125 063166      012701  060470
8126 063172      012721  100004
8127 063176      012721  060500
8128 063202      005021
8129 063204      012721  000012
8130 063210      012721  060512
8131 063214      005021
8132 063216      012721  000024
8133 063222      005021
8134 063224      012711  000000
8135 063230      012702  000030
8136 063234      012762  177777  060512  64:
8137 063242      005742
8138 063244      020227  000000
8139 063250      001371
8140 063252      000207
8141
;*
;LOCAL TEXT MESSAGES FOR TEST
;-

;ROUTINE TO RESTORE COMMAND PACKET TO START-UP (DEFAULT) VALUES
;WRITE SUBSYSTEM MEMORY COMMAND
;-

T34REST:
      SAVREG
      MOV      #T34PACKET,R1
      MOV      #100004,(R1)
      MOV      #T34DATA,(R1)
      CLR      (R1)
      MOV      #10,(R1)
      MOV      #T34BFR,(R1)
      CLR      (R1)
      MOV      #20,(R1)
      CLR      (R1)
      MOV      #0,(R1)
      MOV      #24,R2
      MOV      #177777,T34BFR(R2)
      TST     -(R2)
      CMP     R2,#0
      BNE    64:
      RTS     PC

;SAVE THE REGISTERS
;START OF THE PACKET
;WRITE SUBSYSTEM MEM. WITH ACK
;ADDRESS OF CHARAISTICS DATA BLOCK
;EXTENDED ADDRESS
;SIZE OF DATA BLOCK IN BYTES
;ADDRESS OF MESSAGE BUFFER

;LENGTH OF MESSAGE BUFFER

;SELECT DRIVE ZERO
;NUMBER OF LOCATIONS TO BE CLEARED
;ALL ONES TO MESSAGE BUFFER
;BUMP DOWN TO NEXT LOCATION
;R2 AT ZERO YET
;KEEP GOING UNTIL DONE
;RETURN

```











TEST 7: EXTENDED MODE FEATURES

```

8247 063572          ERRHRD  ERRNO,T35RWN,PKTSSR      ;REWIND NOT ACCEPTED
      063572 104456
      063574 001277          TRAP      C4ERHRD
      063576 070574          .WORD    703
      063600 012156          .WORD    T35RWN
      063602          .WORD    PKTSSR
8248 063602          304:   CKLOOP                    ;LOOP IF SELECTED          TRAP      C4CLP1
      063602 104406
8249 063604 013701 067350      MOV      T35BFR-6,R1      ;PICK UP XSTO
8250 063610 010102          MOV      R1,R2          ;SET UP EXPECTED
8251 063612 052702 000002      BIS      #BIT1,R2      ;SET BOT BIT IN EXPECTED
8252 063616 020102          CMP      R1,R2          ;DOES EXP = REC'D
8253 063620 001406          BEQ     404             ;BR, IF EQUAL (OK)
8254 063622 005237 002214      INC      FATFLG          ;ERROR COUNT
8258 063626          ERRHRD  ERRNO,T35BOT,EXPREC      ;TAPE NOT AT BOT AFTER REWIND
      063626 104456          TRAP      C4ERHRD
      063630 001300          .WORD    704
      063632 070270          .WORD    T35BOT
      063634 015604          .WORD    EXPREC
8259 063636          404:   CKLOOP                    ;LOOP IF SELECTED          TRAP      C4CLP1
      063636 104406
8260 063640 012703 000024      MOV      #20.,R3        ;NUMBER OF RECORDS
8261 063644 012737 000400 067446  MOV      #256.,T35SZ     ;SET UP RECORD SIZE
8262 063652 013737 003120 067442  MOV      FREE,T35WB     ;ADDRESS OF WRITE BUFFER
8263
8264          ;*****
8265          ;
8266          ;WRITE DATA,ACK,CVC=1 COMMAND
8267          ;
8268          ;*****
8269
8270 063660 012737 140005 067440      MOV      #140005,T35PK3 ;WRITE DATA,ACK,CVC=1 COMMAND
8271 063666 012704 067440          MOV      #T35PK3,R4     ;SET UP R4 WITH PACKET ADDRESS
8272 063672 010465 000000          504:   MOV      R4,TSD8(R5) ;ISSUE COMMAND
8273 063676 004737 016360          JSR     PC,WAITF        ;WAIT FOR SSR TO SET
8274 063702 016501 000002          MOV      TSSR(R5),R1   ;GET TSSR CONTENTS
8275 063706 012702 000200          MOV      #SSR,R2       ;SET UP EXPECTED
8276 063712 020102          CMP      R1,R2         ;ARE THEY EQUAL
8277 063714 001406          BEQ     604             ;BR, IF OK
8278 063716 005237 002214      INC      FATFLG          ;ERROR COUNT
8282 063722          ERRHRD  ERRNO,T35WDE,PKTSSR      ;TSSR INCORRECT AFTER WRITE DATA
      063722 104456          TRAP      C4ERHRD
      063724 001301          .WORD    705
      063726 070216          .WORD    T35WDE
      063730 012156          .WORD    PKTSSR
8283 063732          604:   CKLOOP                    ;LOOP IF SELECTED          TRAP      C4CLP1
      063732 104406
8284 063734 005303          DEC      R3             ;BUMP RECORD COUNTER
8285 063736 001355          BNE     504             ;BR, IF MORE RRECORDS TO COUNT
8286
8287          ;*****
8288          ;
8289          ;WAIT FOR TAPE TO STOP ALL MOTION
8290          ;
8291          ;*****
8292
8293 063740 012737 000012 067472      704:   MOV      #10.,T35DLY ;SET UP DELAY COUNTER
8294 063746          DELAY  250             ;WAIT ABOUT .25 SEC

```

TEST 7: EXTENDED MODE FEATURES

```

063746 012727 000250
063752 000000
063754 013727 002116
063760 000000
063762 005367 177772
063766 001375
063770 005367 177756
063774 001367
8295 063776 005337 067472
8296 064002 001361
8297 064004 005737 002220
8298 064010 001042
8299 064012 112737 000200 067451
8300 064020 112737 000010 067450
8301 064026 012704 067430
8302 064032 010465 000000
8303 064036 004737 016446
8304 064042 103407
8305 064044 010001
8306 064046 005237 002214
8310 064052
064052 104456
064054 001302
064056 072352
064060 012156
8311 064062
064062 104406
8312 064064 012704 067320
8313 064070 004737 010742
8314 064074 103407
8315 064076 005237 002214
8319 064102 010001
8320 064104
064104 104456
064106 001303
064110 005054
064112 012144
8321 064114
064114 104406
8322 064116 012737 176750 067472
8323 064124 005037 067466
8324
8325
8326
8327
8328
8329
8330
8331 064130 012737 142012 067440
8332 064136 012704 067440
8333 064142 010465 000000
8334 064146 016501 000002
8335 064152 032701 000200
8336 064156 001021
8337 064160 005237 067466
8338 064164
064164 012727 000001

MOV #250,(PC)+
.WORD 0
MOV L#DLY,(PC)+
.WORD 0
DEC -6(PC)
BNE -4
DEC -22(PC)
BNE -20

DEC T35DLY
BNE 70#
TST EXTFEA
BNE 110#
MOV #200,T35BS1
MOV #10,T35BS0
MOV #T35PK2,R4
MOV R4,TSDB(R5)
JSR PC,CHKTSSR
BCS 90#
MOV R0,R1
INC FATFLG
ERRHRD ERRNO,T35SSR,PKTSSR

;BUMP COUNTER DOWN
;BR, IF MORE TO DELAY
;CHECK FOR EXTENDED FEATURES SW SWITCH
;BR IF SWITCH IS ON
;WRITE MISCELLANEOUS CONT/READ STATUS
;FUNCTION SELECTION BIT (TURN ON EXTFEA HW SWITCH)
;WRITE SUBSYS MEM PACKET
;ISSUE COMMAND
;WAIT FOR SSR
;BR, IF NO ERROR
;ERROR, SAVE TSSR
;ERROR COUNT
;TSSR NOT CORRECT AFTER WRT. MISCELLANEOUS
TRAP C#ERHRD
.WORD 706
.WORD T35SSR
.WORD PKTSSR

90#: CKLOOP ;LOOP IF SELECTED
TRAP C#CLP1

MOV #T35PACKET,R4 ;SUBROUTINE NEEDS PACKET ADDRESS
JSR PC,WRTCHR ;ISSUE WRITE CHARACTERISTICS
BCS 100# ;BR, IF COMMAND ISSUED OK
INC FATFLG ;ERROR COUNT
MOV R0,R1 ;SAVE CONTENTS OF TSSR
ERRHRD ERRNO,WRTMSG,SFMSG ;WRITE CHARACTERISTIC FAILED
TRAP C#ERHRD
.WORD 707
.WORD WRTMSG
.WORD SFMSG

100#: CKLOOP ;SCOPE LOOP
TRAP C#CLP1

110#: MOV #65000.,T35DLY ;SET UP DELAY COUNTER
CLR T35CNT ;DELAY COUNTER

;*****
;REWIND IMED. INTERRUPT,ACK,CVC=1,IE=0 COMMAND
;*****

MOV #142012,T35PK3 ;REWIND IMED. INTERRUPT,ACK,CVC=1,IE=0 COMMAND
MOV #T35PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
MOV R4,TSDB(R5) ;ISSUE COMMAND
MOV TSSR(R5),R1 ;GET TSSR CONTENTS
BIT #SSR,R1 ;CHECK FOR SSR SET
BNE 130# ;BR, WHEN SSR IS SET
INC T35CNT ;BUMP THE CYCLE COUNTER
DELAY 1 ;DELAY TO KEEP COUNTER DOWN
MOV #1,(PC)+

```



TEST 7: EXTENDED MODE FEATURES

```

064170 000000
064172 013727 002116
064176 000000
064200 005367 177772
064204 001375
064206 005367 177756
064212 001367
8339 064214 005337 067472
8340 064220 001352
8341 064222 012702 000200
8342 064226 020102
8343 064230 001406
8344 064232 005237 002214
8348 064236
      064236 104456
      064240 001304
      064242 072720
      064244 012156
8349 064246
      064246 104406
8350 064250 005737 002216
8351 064254 001410
8352 064256 016501 000002
8353 064262 005237 002214
8357 064266
      064266 104456
      064270 001305
      064272 072531
      064274 012156
8358 064276
      064276 104406
8359
8360
8361
8362
8363
8364
8365
8366 064300 013701 067350
8367 064304 010102
8368 064306 052702 000200
8369 064312 020102
8370 064314 001406
8371 064316 005237 002214
8375 064322
      064322 104456
      064324 001306
      064326 072433
      064330 015604
8376 064332
      064332 104406
8377 064334 013701 067354
8378 064340 010102
8379 064342 052702 100000
8380 064346 020102
8381 064350 001406
8382 064352 005237 002214

      .WORD 0
      MOV L#DLY,(PC)+
      .WORD 0
      DEC -6(PC)
      BNE -4
      DEC -22(PC)
      BNE -20
      ;DROP DEAD TIMER BUMP DOWN
      ;BR, IF MORE TIME TO GO
1304:  MOV #SSR,R2 ;SET UP EXPECTED
      CMP R1,R2 ;ARE THEY EQUAL
      BEQ 1404 ;BR, IF OK
      INC FATFLG ;ERROR COUNT
      ERRHRD ERRNO,T3SRWE,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
      TRAP C#ERHRD
      .WORD 708
      .WORD T3SRWE
      .WORD PKTSSR
1404:  CKLOOP ;LOOP IF SELECTED
      TRAP C#CLP1
      TST INTRECV ;CHECK FOR INTERRUPTS
      BEQ 1504 ;BR, IF NO INTERRUPTS DETECTED
      MOV TSSR(R5),R1 ;GET TSSR STATUS FOR PRINTOUT
      INC FATFLG ;ERROR COUNT
      ERRHRD ERRNO,T3SINT,PKTSSR ;INTERRUPT RECEIVED (BAD)
      TRAP C#ERHRD
      .WORD 709
      .WORD T3SINT
      .WORD PKTSSR
1504:  CKLOOP ;LOOP IF SELECTED
      TRAP C#CLP1
;*****
;
;NOW CHECK FOR THE MOTION BITS SET
;
;*****
      MOV T35BFR-6,R1 ;PICK UP XST0
      MOV R1,R2 ;SET UP EXPECTED
      BIS #BIT7,R2 ;SET MOT BIT IN EXPECTED
      CMP R1,R2 ;DOES EXP = REC'D
      BEQ 1604 ;BR, IF EQUAL (OK)
      INC FATFLG ;ERROR COUNT
      ERRHRD ERRNO,T3SMOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
      TRAP C#ERHRD
      .WORD 710
      .WORD T3SMOT
      .WORD EXPREC
1604:  CKLOOP ;LOOP IF SELECTED
      TRAP C#CLP1
      MOV T35BFR-12,R1 ;PICK UP XST2
      MOV R1,R2 ;SET UP EXPECTED
      BIS #BIT15,R2 ;SET OPM BIT IN EXPECTED
      CMP R1,R2 ;DOES EXP = REC'D
      BEQ 1704 ;BR, IF EQUAL (OK)
      INC FATFLG ;ERROR COUNT

```





TEST 7: EXTENDED MODE FEATURES

```

064522 012727 000250
064526 000000
064530 013727 002116
064534 000000
064536 005367 177772
064542 001375
064544 005367 177756
064550 001367
8424 064552 005337 067472
8425 064556 001356
8426 064560 005237 002214
8430 064564 010001
8431 064566
064566 104455
064570 001310
064572 003650
064574 012144
8432 064576 013737 002174 067340 20$:
8433 064604 012704 067320
8434 064610 004737 010742
8435 064614 103407
8436 064616 005237 002214
8440 064622 010001
8441 064624
064624 104456
064626 001311
064630 005054
064632 012144
8442 064634
064634 104406 25$:
8443 064636 004737 011126
8444 064642 103411
8445 064644 010004
8446 064646 016501 000002
8447 064652 005237 002214
8451 064656
064656 104456
064660 001312
064662 070574
064664 012156
8452 064666
064666 104406 30$:
8453 064670 013701 067350
8454 064674 010102
8455 064676 052702 000002
8456 064702 020102
8457 064704 001406
8458 064706 005237 002214
8462 064712
064712 104456
064714 001313
064716 070270
064720 015604
8463 064722
064722 104406 40$:
8464 064724 012703 000024
8465 064730 012737 000400 067446

```

```

DEC T35DLY
BNE 10$
INC FATFLG
MOV R0,R1
ERRDF ERRNO,SFIERR,SFIMSG

```

```

MOV #250,(PC)+
.WORD 0
MOV L$DLY,(PC)+
.WORD 0
DEC -6(PC)
BNE -4
DEC -22(PC)
BNE -20
;BUMP COUNTER
;BR, IF COUNTER NOT DONE
;ERROR COUNT
;CONTENTS OF TSSR REGISTER
;FATAL ERROR TSSR WAS NOT OK

```

```

MOV UNITN,T35DSW
MOV #T35PACKET,R4
JSR PC,WRTCHR
BCS 25$
INC FATFLG
MOV R0,R1
ERRHRD ERRNO,WRTMSG,SFIMSG

```

```

TRAP C$ERDF
.WORD 712
.WORD SFIERR
.WORD SFIMSG
;SET UP DRIVE NUMBER
;SUBROUTINE NEEDS PACKET ADDRESS
;ISSUE WRITE CHARACTERISTICS
;BR, IF COMMAND ISSUED OK
;ERROR COUNT
;SAVE CONTENTS OF TSSR
;WRITE CHARACTERISTICSC FAILED

```

```

CKLOOP
JSR PC,REWIND
BCS 30$
MOV R0,R4
MOV TSSR(R5),R1
INC FATFLG
ERRHRD ERRNO,T35RWV,PKTSSR

```

```

TRAP C$ERHRD
.WORD 713
.WORD WRTMSG
.WORD SFIMSG
;LOOP IF SELECTED
TRAP C$CLP1
;CALL TAPE REWIND COMMAND
;BR, IF NO PROBLEM
;SET UP REWIND PACKET ADDRESS
;GET TSSR CONTENTS
;ERROR COUNT
;REWIND NOT ACCEPTED

```

```

CKLOOP
MOV T35BFR+6,R1
MOV R1,R2
BIS #BIT1,R2
CMP R1,R2
BEQ 40$
INC FATFLG
ERRHRD ERRNO,T35BOT,EXPREC

```

```

TRAP C$ERHRD
.WORD 714
.WORD T35RWV
.WORD PKTSSR
;LOOP IF SELECTED
TRAP C$CLP1
;PICK UP XSTO
;SET UP EXPECTED
;SET BOT BIT IN EXPECTED
;DOES EXP = REC'D
;BR, IF EQUAL (OK)
;ERROR COUNT
;TAPE NOT AT BOT AFTER REWIND

```

```

CKLOOP
MOV #20.,R3
MOV #256.,T35SZ

```

```

TRAP C$CLP1
;LOOP IF SELECTED
TRAP C$CLP1
;NUMBER OF RECORDS
;SET UP RECORD SIZE

```

TEST 7: EXTENDED MODE FEATURES

```

8466 064736 013737 003120 067442      MOV      FREE,T35WB      ;ADDRESS OF WRITE BUFFER
8467
8468      ;*****
8469      ;
8470      ;WRITE DATA,ACK,CVC=1 COMMAND
8471      ;
8472      ;*****
8473
8474 064744 012737 140005 067440      MOV      #140005,T35PK3  ;WRITE DATA,ACK,CVC=1 COMMAND
8475 064752 012704 067440      MOV      @T35PK3,R4      ;SET UP R4 WITH PACKET ADDRESS
8476 064756 010465 000000      50$:    MOV      R4,TSDB(R5)    ;ISSUE COMMAND
8477 064762 004737 016360      JSR      PC,WAITF        ;WAIT FOR SSR TO SET
8478 064766 016501 000002      MOV      TSSR(R5),R1     ;GET TSSR CONTENTS
8479 064772 012702 000200      MOV      @SSR,R2        ;SET UP EXPECTED
8480 064776 020102      CMP      R1,R2          ;ARE THEY EQUAL
8481 065000 001406      BEQ      60$            ;BR, IF OK
8482 065002 005237 002214      INC      FATFLG          ;ERROR COUNT
8486 065006      ERRHRD  ERRNO,T35WDE,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
                                TRAP      C$ERHRD
                                .WORD    716
                                .WORD    T35WDE
                                .WORD    PKTSSR
                                TRAP      C$CLP1
                                TRAP      C$CLP1
065006 104456
065010 001314
065012 070216
065014 012156
8487 065016      60$:    CKLOOP          ;LOOP IF SELECTED
065016 104406
8488
8489      ;*****
8490      ;
8491      ;WAIT FOR TAPE TO STOP ALL MOTION
8492      ;
8493      ;*****
8494
8495 065020 012737 000012 067472      70$:    MOV      #10.,T35DLY ;SET UP DELAY COUNTER
8496 065026      DELAY  250            ;WAIT ABOUT .25 SEC
                                MOV      #250,(PC)-
                                .WORD    0
                                MOV      L$DLY,(PC)-
                                .WORD    0
                                DEC      -6(PC)
                                BNE     -4
                                DEC     -22(PC)
                                BNE     -20
065026 012727 000250
065032 000000
065034 013727 002116
065040 000000
065042 005367 177772
065046 001375
065050 005367 177756
065054 001367
8497 065056 005337 067472      DEC      T35DLY          ;BUMP COUNTER DOWN
8498 065062 001361      BNE     70$            ;BR, IF MORE TO DELAY
8499 065064 005737 002220      TST     EXTFEA         ;CHECK FOR EXTENDED FEATURES SW SWITCH
8500 065070 001042      BNE     110$          ;BR IF SWITCH IS ON
8501 065072 112737 000200 067451      MOV     B      @200,T35BS1 ;WRITE MISCELLANEOUS CONT/READ STATUS
8502 065100 112737 000010 067450      MOV     B      @10,T35BS0 ;FUNCTION SELECTION BIT (TURN ON EXTFEA HW SWITCH)
8503 065106 012704 067430      MOV     @T35PK2,R4      ;WRITE SUBSYS MEM PACKET
8504 065112 010465 000000      MOV     R4,TSDB(R5)    ;ISSUE COMMAND
8505 065116 004737 016446      JSR     PC,CHKTSSR     ;WAIT FOR SSR
8506 065122 103407      BCS    90$            ;BR, IF NO ERROR
8507 065124 010001      MOV     R0,R1          ;ERROR, SAVE TSSR
8508 065126 005237 002214      INC     FATFLG          ;ERROR COUNT
8512 065132      ERRHRD  ERRNO,T35SSR,PKTSSR ;TSSR NOT CORRECT AFTER WRT. MISCELLANEOUS
                                TRAP      C$ERHRD
                                .WORD    717
                                .WORD    T35SSR
065132 104456
065134 001315
065136 072352

```



TEST 7: EXTENDED MODE FEATURES

```

065140 012156
8513 065142 104406          904:  CKLOOP                ;LOOP IF SELECTED          .WORD  PKTSSR
      065142 012704 067320          MOV    #T3SPACKET,R4      ;SUBROUTINE NEEDS PACKET ADDRESS
      065144 012704 010742          JSR    PC,WRTCHR          ;ISSUE WRITE CHARACTERISTICS
8514 065144 012704 067320          BCS   1004                ;BR, IF COMMAND ISSUED OK
8515 065150 004737 010742          INC   FATFLG              ;ERROR COUNT
8516 065154 103407
8517 065156 005237 002214          MOV   RO,R1               ;SAVE CONTENTS OF TSSR
8521 065162 010001          ERRHRD ERRNO,WRTMSG,SFMSG ;WRITE CHARACTERISTICS FAILED
8522 065164
      065164 104456          TRAP  C4ERHRD
      065166 001316          .WORD 718
      065170 005054          .WORD WRTMSG
      065172 012144          .WORD SFMSG
8523 065174
      065174 104406          1004: CKLOOP              ;SCOPE LOOP                TRAP  C4CLP1
8524 065176 012737 176750 067472 1104: MOV    #65000.,T3SDLY      ;SET UP DELAY COUNTER
8525 065204 005037 067466          CLR   T3SCNT              ;DELAY COUNTER
8526
8527
8528
8529
8530
8531
8532
      ;*****
      ;REWIND IMMEDIATE,ACK,CVC=1,IE=1 COMMAND
      ;*****
8533 065210 012737 142212 067440          MOV   #142212,T3SPK3      ;REWIND IMMEDIATE,ACK,CVC=1,IE=1 COMMAND
8534 065216 012704 067440          MOV   #T3SPK3,R4         ;SET UP R4 WITH PACKET ADDRESS
8535 065222 010465 000000          MOV   R4,TSD8(R5)        ;ISSUE COMMAND
8536 065226 016501 000002          1204: MOV   TSSR(R5),R1    ;GET TSSR CONTENTS
8537 065232 032701 000200          BIT   #SSR,R1            ;CHECK FOR SSR SET
8538 065236 001021
8539 065240 005237 067466          BNE   1304                ;BR, WHEN SSR IS SET
8540 065244
      DELAY 1                ;BUMP THE CYCLE COUNTER
      ;DELAY TO KEEP COUNTER DOWN
      MOV   #1,(PC)-0
      .WORD 0
      MOV   L4DLY,(PC)-0
      .WORD 0
      DEC   -6(PC)
      BNE   -4
      DEC   -22(PC)
      BNE   -20
8541 065274 005337 067472          DEC   T3SDLY              ;DROP DEAD TIMER BUMP DOWN
8542 065300 001352          BNE   1204                ;BR, IF MORE TIME TO GO
8543 065302 012702 000200          1304: MOV   #SSR,R2        ;SET UP EXPECTED
8544 065306 020102          CMP   R1,R2              ;ARE THEY EQUAL
8545 065310 001406          BEQ   1404                ;BR, IF OK
8546 065312 005237 002214          INC   FATFLG              ;ERROR COUNT
8550 065316          ERRHRD ERRNO,T3SRME,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
      TRAP  C4ERHRD
      .WORD 719
      .WORD T3SRME
      .WORD PKTSSR
      065316 104456          TRAP  C4ERHRD
      065320 001317          .WORD 719
      065322 072720          .WORD T3SRME
      065324 012156          .WORD PKTSSR
8551 065326
      065326 104406          1404: CKLOOP              ;LOOP IF SELECTED          TRAP  C4CLP1
8552 065330 005737 002216          TST   INTRECV             ;CHECK FOR INTERRUPTS
8553 065334 001010          BNE   1504                ;BR, IF INTERRUPTS DETECTED
8554 065336 016501 000002          MOV   TSSR(R5),R1        ;GET TSSR STATUS FOR PRINTOUT
8555 065342 005237 002214          INC   FATFLG              ;ERROR COUNT

```

TEST 7: EXTENDED MODE FEATURES

```

8559 065346          ERRHRD  ERRNO,T35NIN,PKTSSR  ;INTERRUPT NOT RECEIVED (BAD)
      065346 104456          TRAP          C#ERHRD
      065350 001320          .WORD          720
      065352 073006          .WORD          T35NIN
      065354 012156          .WORD          PKTSSR
8560 065356          1504:  CKLOOP          ;LOOP IF SELECTED          TRAP          C#CLP1
      065356 104406
8561
8562          ;*****
8563          ;
8564          ;NOW CHECK FOR THE MOTION BITS SET
8565          ;
8566          ;*****
8567
8568 065360 013701 067350          MOV          T35BFR+6,R1          ;PICK UP XST0
8569 065364 010102          MOV          R1,R2          ;SET UP EXPECTED
8570 065366 052702 000200          BIS          @BIT7,R2          ;SET MOT BIT IN EXPECTED
8571 065372 020102          CMP          R1,R2          ;DOES EXP = REC'D
8572 065374 001406          BEQ          1604          ;BR, IF EQUAL (OK)
8573 065376 005237 002214          INC          FATFLG          ;ERROR COUNT
8577 065402          ERRHRD  ERRNO,T35MOT,EXPREC  ;TAPE NOT AT BOT AFTER REWIND
      065402 104456          TRAP          C#ERHRD
      065404 001321          .WORD          721
      065406 072433          .WORD          T35MOT
      065410 015604          .WORD          EXPREC
8578 065412          1604:  CKLOOP          ;LOOP IF SELECTED          TRAP          C#CLP1
      065412 104406
8579 065414 013701 067354          MOV          T35BFR+12,R1         ;PICK UP XST2
8580 065420 010102          MOV          R1,R2          ;SET UP EXPECTED
8581 065422 052702 100000          BIS          @BIT15,R2         ;SET OPM BIT IN EXPECTED
8582 065426 020102          CMP          R1,R2          ;DOES EXP = REC'D
8583 065430 001406          BEQ          1704          ;BR, IF EQUAL (OK)
8584 065432 005237 002214          INC          FATFLG          ;ERROR COUNT
8588 065436          ERRHRD  ERRNO,T35OPM,EXPREC  ;OPM BIT NOT SET
      065436 104456          TRAP          C#ERHRD
      065440 001322          .WORD          722
      065442 072622          .WORD          T35OPM
      065444 015604          .WORD          EXPREC
8589 065446          1704:  CKLOOP          ;LOOP IF SELECTED          TRAP          C#CLP1
      065446 104406
8590 065450 012737 000027 067472          MOV          @23..T35DLY         ;SET UP DELAY COUNTER
8591 065456          1754:  DELAY          250          ;START DELAY
      065456 012727 000250          MOV          @250,(PC)-
      065462 000000          .WORD          0
      065464 013727 002116          MOV          L#DLY,(PC)-
      065470 000000          .WORD          0
      065472 005367 177772          DEC          -6(PC)
      065476 001375          BNE          -4
      065500 005367 177756          DEC          -22(PC)
      065504 001367          BNE          -20
8592 065506 005337 067472          DEC          T35DLY          ;BUMP DELAY COUNTER
8593 065512 001361          BNE          1754          ;BR, IF MORE DELAY
8594 065514          ENDSUB
      065514 104403          L10065:  TRAP          C#ESUB
8595 065516 023727 002214 000017          CMP          FATFLG,#15.
8596 065524 103402          BLO          9996          ;IS ERROR COUNT AT 25
                          ;BR, IF LESS THAN 25

```







TEST 7: EXTENDED MODE FEATURES

```

065656 001325
065660 070574
065662 012156
8651 065664 104406 304: CKLOOP ;LOOP IF SELECTED .WORD 725
065664 104406 TRAP C4CLP1 .WORD T35RWN
8652 065666 013701 067350 MOV T35BFR-6,R1 ;PICK UP XSTO .WORD PKTSSR
8653 065672 010102 MOV R1,R2 ;SET UP EXPECTED
8654 065674 052702 000002 BIS #BIT1,R2 ;SET BOT BIT IN EXPECTED
8655 065700 020102 CMP R1,R2 ;DOES EXP = REC'D
8656 065702 001406 BEQ 404 ;BR, IF EQUAL (OK)
8657 065704 005237 002214 INC FATFLG ;ERROR COUNT
8661 065710 ERRHRD ERRNO,T35BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
065710 104456 TRAP C4ERHRD
065712 001326 .WORD 726
065714 070270 .WORD T35BOT
065716 015604 .WORD EXPREC
8662 065720 404: CKLOOP ;LOOP IF SELECTED TRAP C4CLP1
065720 104406
8663 065722 012703 000024 MOV #20.,R3 ;STARTING RECORD SIZE
8664 065726 013737 003120 067442 MOV FREE,T35WB ;STARTING WRITE BUFFER ADDRESS
8665
8666 ;*****
8667 ;
8668 ;WRITE DATA,CVC=1,ACK COMMAND
8669 ;
8670 ;*****
8671
8672 065734 012737 140005 067440 654: MOV #140005,T35PK3 ;WRITE DATA,CVC=1,ACK COMMAND
8673 065742 012704 067440 MOV #T35PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
8674 065746 010300 MOV R3,R0 ;SET PATTERN IN CORRECT REGISTER
8675 065750 004737 017532 JSR PC,FILLMEM ;FILL MEMORY WITH RECORD SIZE
8676 065754 010337 067446 MOV R3,T35SZ ;SET UP RECORD SIZE IN PACKET
8677 065760 010465 000000 MOV R4,TSDB(R5) ;ISSUE COMMAND
8678 065764 004737 016360 JSR PC,WAITF ;WAIT FOR SSR TO SET
8679 065770 016501 000002 MOV TSSR(R5),R1 ;GET TSSR CONTENTS
8680 065774 012702 000200 MOV #SSR,R2 ;SET UP EXPECTED
8681 066000 020102 CMP R1,R2 ;ARE THEY EQUAL
8682 066002 001406 BEQ 804 ;BR, IF OK
8683 066004 005237 002214 INC FATFLG ;ERROR COUNT
8687 066010 ERRHRD ERRNO,T35WDC,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
066010 104456 TRAP C4ERHRD
066012 001327 .WORD 727
066014 071130 .WORD T35WDC
066016 012156 .WORD PKTSSR
8688 066020 804: CKLOOP ;LOOP IF SELECTED TRAP C4CLP1
066020 104406
8689
8690 ;*****
8691 ;
8692 ;WRITE DATA RETRY,CVC=1,ACK COMMAND
8693 ;
8694 ;*****
8695
8696 066022 012737 141005 067440 MOV #141005,T35PK3 ;WRITE DATA RETRY,CVC=1,ACK COMMAND
8697 066030 010465 000000 MOV R4,TSDB(R5) ;ISSUE COMMAND
8698 066034 004737 016360 JSR PC,WAITF ;WAIT FOR SSR TO SET
8699 066040 016501 000002 MOV TSSR(R5),R1 ;GET TSSR CONTENTS

```



TEST 7: EXTENDED MODE FEATURES

```

8700 066044 012702 000200      MOV    #SSR,R2      ;SET UP EXPECTED
8701 066050 020102      CMP    R1,R2       ;ARE THEY EQUAL
8702 066052 001406      BEQ    90$         ;BR, IF OK
8703 066054 005237 002214      INC    FATFLG      ;ERROR COUNT
8707 066060      ERRHRD ERRNO,T35WRF,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA RETRY
      066060 104456      TRAP  C4ERHRD
      066062 001330      .WORD 728
      066064 072175      .WORD T35WRF
      066066 012156      .WORD PKTSSR
8708 066070      90$:  CKLOOP      ;LOOP IF SELECTED
      066070 104406      TRAP  C4CLP1
8709 066072 005723      TST    (R3)+       ;BUMP RECORD SIZE COUNTER
8710 066074 020327 000052      CMP    R3,#42.    ;AT 42 SIZE YET
8711 066100 001315      BNE    65$         ;BR, IF MORE RECORDS TO WRITE
8712 066102 004737 011126      JSR    PC,REWIND  ;CALL TAPE REWIND COMMAND
8713 066106 103411      BCS    230$        ;BR, IF NO PROBLEM
8714 066110 010001      MOV    R0,R1       ;SAVE TSSR
8715 066112 016501 000002      MOV    TSSR(R5),R1 ;GET TSSR CONTENTS
8716 066116 005237 002214      INC    FATFLG      ;ERROR COUNT
8720 066122      ERRHRD ERRNO,T35RW,EXPREC ;REWIND NOT ACCEPTED
      066122 104456      TRAP  C4ERHRD
      066124 001331      .WORD 729
      066126 070574      .WORD T35RW
      066130 015604      .WORD EXPREC
8721 066132      230$: CKLOOP      ;LOOP IF SELECTED
      066132 104406      TRAP  C4CLP1
8722 066134 013701 067350      MOV    T35BFR+6,R1 ;PICK UP XSTO
8723 066140 010102      MOV    R1,R2       ;SET UP EXPECTED
8724 066142 052702 000002      BIS    #BIT1,R2    ;SET BOT BIT IN EXPECTED
8725 066146 020102      CMP    R1,R2       ;DOES EXP = REC'D
8726 066150 001406      BEQ    240$        ;BR, IF EQUAL (OK)
8727 066152 005237 002214      INC    FATFLG      ;ERROR COUNT
8731 066156      ERRHRD ERRNO,T35BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
      066156 104456      TRAP  C4ERHRD
      066160 001332      .WORD 730
      066162 070270      .WORD T35BOT
      066164 015604      .WORD EXPREC
8732 066166      240$: CKLOOP      ;LOOP IF SELECTED
      066166 104406      TRAP  C4CLP1
8733 066170 012703 000024      MOV    #20.,R3     ;STARTING RECORD SIZE
8734 066174 013737 003120 067442      MOV    FREE,T35RB  ;STARTING READ BUFFER ADDRESS
8735
8736 ;*****
8737 ;
8738 ;READ DATA,ACK COMMAND
8739 ;
8740 ;*****
8741
8742 066202 012737 100001 067440 265$: MOV    #100001,T35PK3 ;READ DATA,ACK COMMAND
8743 066210 012704 067440      MOV    #T35PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
8744 066214 012700 177777      MOV    #177777,R0 ;SET PATTERN IN CORRECT REGISTER
8745 066220 004737 017532      JSR    PC,FILLMEM ;FILL MEMORY WITH RECORD SIZE
8746 066224 010337 067446      MOV    R3,T35S2   ;SET UP RECORD SIZE IN PACKET
8747 066230 010465 000000      MOV    R4,TSDB(R5) ;ISSUE COMMAND
8748 066234 004737 016360      JSR    PC,WAITF   ;WAIT FOR SSR TO SET
8749 066240 016501 000002      MOV    TSSR(R5),R1 ;GET TSSR CONTENTS
8750 066244 012702 000200      MOV    #SSR,R2    ;SET UP EXPECTED

```











D16

TEST 7: EXTENDED MODE FEATURES

```

066616 104456
066620 001340
066622 070270
066624 015604
8846 066626 104406 000024 067442 40$: CKLOOP ;LOOP IF SELECTED TRAP C4ERHRD
066626 104406 ;STARTING RECORD SIZE .WORD 736
8847 066630 012703 000024 MOV #20,R3 ;STARTING WRITE BUFFER ADDRESS TRAP C4CLP1
8848 066634 013737 003120 067442 MOV FREE,T35WB
8849
8850 ;*****
8851 ;WRITE DATA,CVC=1,ACK COMMAND
8852 ;
8853 ;*****
8854
8855
8856 066642 012737 140005 067440 65$: MOV #140005,T35PK3 ;WRITE DATA,CVC=1,ACK COMMAND
8857 066650 012704 067440 MOV #T35PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
8858 066654 010300 MOV R3,R0 ;SET PATTERN IN CORRECT REGISTER
8859 066656 004737 017532 JSR PC,FILLMEM ;FILL MEMORY WITH RECORD SIZE
8860 066662 010337 067446 MOV R3,T35SZ ;SET UP RECORD SIZE IN PACKET
8861 066666 010465 000000 MOV R4,T35DB(R5) ;ISSUE COMMAND
8862 066672 004737 016360 JSR PC,WAITF ;WAIT FOR SSR TO SET
8863 066676 016501 000002 MOV T35R(R5),R1 ;GET T35R CONTENTS
8864 066702 012702 000200 MOV #SSR,R2 ;SET UP EXPECTED
8865 066706 020102 CMP R1,R2 ;ARE THEY EQUAL
8866 066710 001406 BEQ 80$ ;BR, IF OK
8867 066712 005237 002214 INC FATFLG ;ERROR COUNT
8871 066716 ERRHRD ERRNO,T35WDC,PKTSSR ;T35R INCORRECT AFTER WRITE DATA
066716 104456 TRAP C4ERHRD
066720 001341 .WORD 737
066722 071130 .WORD T35WDC
066724 012156 .WORD PKTSSR
8872 066726 104406 80$: CKLOOP ;LOOP IF SELECTED TRAP C4CLP1
066726 104406
8873
8874 ;*****
8875 ;WRITE DATA RETRY,ACK,SWB=1 COMMAND
8876 ;
8877 ;*****
8878
8879
8880 066730 012737 111005 067440 MOV #111005,T35PK3 ;WRITE DATA RETRY,ACK,SWB=1 COMMAND
8881 066736 010465 000000 MOV R4,T35DB(R5) ;ISSUE COMMAND
8882 066742 004737 016360 JSR PC,WAITF ;WAIT FOR SSR TO SET
8883 066746 016501 000002 MOV T35R(R5),R1 ;GET T35R CONTENTS
8884 066752 012702 000200 MOV #SSR,R2 ;SET UP EXPECTED
8885 066756 020102 CMP R1,R2 ;ARE THEY EQUAL
8886 066760 001406 BEQ 90$ ;BR, IF OK
8887 066762 005237 002214 INC FATFLG ;ERROR COUNT
8891 066766 ERRHRD ERRNO,T35WRF,EXPREC ;T35R INCORRECT AFTER WRITE DATA RETRY
066766 104456 TRAP C4ERHRD
066770 001342 .WORD 738
066772 072175 .WORD T35WRF
066774 015604 .WORD EXPREC
8892 066776 104406 90$: CKLOOP ;LOOP IF SELECTED TRAP C4CLP1
066776 104406 ;BUMP RECORD SIZE COUNTER
8893 067000 005723 TST (R3)+

```



TEST 7: EXTENDED MODE FEATURES

```

8894 067002 020327 000052          CMP      R3,#42.          ;AT 42 SIZE YET
8895 067006 001315          BNE      65$              ;BR, IF MORE RECORDS TO WRITE
8896 067010 004737 011126          JSR      PC,REWIND        ;CALL TAPE REWIND COMMAND
8897 067014 103411          BCS      230$             ;BR, IF NO PROBLEM
8898 067016 016501 000002          MOV      TSSR(R5),R1     ;GET TSSR CONTENTS
8899 067022 010004          MOV      R0,R4           ;GET PACKET ADDRESS
8900 067024 005237 002214          INC      FATFLG          ;ERROR COUNT
8904 067030          ERRHRD  ERRNO,T35RWN,PKTSSR ;REWIND NOT ACCEPTED
      067030 104456          TRAP    C$ERHRD
      067032 001343          .WORD  739
      067034 070574          .WORD  T35RWN
      067036 012156          .WORD  PKTSSR
8905 067040          230$:  CKLOOP           ;LOOP IF SELECTED          TRAP    C$CLP1
      067040 104406          MOV      T35BFR+6,R1     ;PICK UP XSTO
8906 067042 013701 067350          MOV      R1,R2           ;SET UP EXPECTED
8907 067046 010102          MOV      #8IT1,R2       ;SET BOT BIT IN EXPECTED
8908 067050 052702 000002          BIS      R1,R2           ;DOES EXP = REC'D
8909 067054 020102          CMP      R1,R2           ;BR, IF EQUAL (OK)
8910 067056 001406          BEQ     240$             ;ERROR COUNT
8911 067060 005237 002214          INC      FATFLG          ;TAPE NOT AT BOT AFTER REWIND
8915 067064          ERRHRD  ERRNO,T35BOT,EXPREC ;ERROR COUNT
      067064 104456          TRAP    C$ERHRD
      067066 001344          .WORD  740
      067070 070270          .WORD  T35BOT
      067072 015604          .WORD  EXPREC
8916 067074          240$:  CKLOOP           ;LOOP IF SELECTED          TRAP    C$CLP1
      067074 104406          MOV      #20.,R3        ;STARTING RECORD SIZE
8917 067076 012703 000024          MOV      FREE,T35RB     ;STARTING READ BUFFER ADDRESS
8918 067102 013737 003120 067442
8919
8920 ;*****
8921 ;
8922 ;READ DATA,ACK COMMAND
8923 ;
8924 ;*****
8925
8926 067110 012737 100001 067440 265$:  MOV      #100001,T35PK3 ;READ DATA,ACK COMMAND
8927 067116 012704 067440          MOV      #T35PK3,R4    ;SET UP R4 WITH PACKET ADDRESS
8928 067122 010337 067446          MOV      R3,T35SZ      ;SET UP RECORD SIZE IN PACKET
8929 067126 010465 000000          MOV      R4,TSDB(R5)   ;ISSUE COMMAND
8930 067132 004737 016360          JSR      PC,WAITF       ;WAIT FOR SSR TO SET
8931 067136 016501 000002          MOV      TSSR(R5),R1   ;GET TSSR CONTENTS
8932 067142 012702 000200          MOV      #SSR,R2       ;SET UP EXPECTED
8933 067146 020102          CMP      R1,R2         ;ARE THEY EQUAL
8934 067150 001406          BEQ     280$             ;BR, IF OK
8935 067152 005237 002214          INC      FATFLG          ;ERROR COUNT
8939 067156          ERRHRD  ERRNO,T35RDF,PKTSSR ;TSSR INCORRECT AFTER READ DATA
      067156 104456          TRAP    C$ERHRD
      067160 001345          .WORD  741
      067162 067562          .WORD  T35RDF
      067164 012156          .WORD  PKTSSR
8940 067166          280$:  CKLOOP           ;LOOP IF SELECTED          TRAP    C$CLP1
      067166 104406          MOV      FREE,R2        ;GET BUFFER ADDRESS
8941 067170 013702 003120          MOV      R3,R4         ;GET RECORD SIZE
8942 067174 010304          SUB     #20.,R4        ;POINT BACK TO 1ST RECORD
8943 067176 162704 000024          ADD     R2,R4          ;POINT TO 1ST LOC IN BUFFER
8944 067202 060204

```







TEST 7: EXTENDED MODE FEATURES

```

8997
8999      067430
9001 067430      100006
9002 067430      067450
9003 067432      000000
9004 067434      000006
9005 067436
9006
9010 067440
9011 067440      100005
9012 067442
9013 067442      003120
9014 067444      000000
9015 067446      000000
9016
9017
9018
9019
9020 067450
9021 067450      010
9022 067451      200
9023 067452      000000
9024 067454      000000
9025
9026
9027
9028
9029
9030 067456      100205
9031 067460      100605
9032 067462      102205
9033 067464      177777
9034
9035
9036 067466      000000
9037 067470      000000
9038 067472      000000
9039
9040
9041
9042
9043 067474      124      141      160
9044 067562      124      123      123
9045 067631      122      105      122
9046 067726      120      117      123
9047 070010      122      111      102
9048 070060      124      123      123
9049 070135      111      154      154
9050 070216      124      123      123
9051 070270      124      141      160
9052 070363      127      122      111
9053 070440      122      105      122
9054 070517      124      123      123
9055 070574      122      145      167
9056 070643      122      101      115
9057 070716      124      123      123
9058 070765      104      162      151

;
T35PK2:  .=<.10>&177770
          .WORD  100006      ;WRITE SUB SYS MEM COMMAND, AND ACK
          .WORD  T35BF2      ;ADDRESS OF SELECT BLOCK DATA
          .WORD  0           ;
          .WORD  6.         ;SIZE OF DATA PACKET
;
T35PK3:
          .WORD  100005      ;REREAD COMMAND, AND ACK
T35RB:   .WORD  FREE        ;ADDRESS OF WRITE BUFFER
T35WB:   .WORD  0           ;
          .WORD  0           ;SIZE OF BUFFER (EXTENT)
          .EVEN
;
;
T35BF2:
T35BS0:  .BYTE  10         ;BSELO AREA
T35BS1:  .BYTE  200       ;BSEL1 AREA
T35S2:   .WORD  0         ;SEL 2 AREA
T35S3:   .WORD  0         ;DATA AREA
;
;
          .EVEN
;TAPE MOTION PACKET COMMAND VALUES
T35RN:   .WORD  100205     ;REREAD DATA (NEXT)
T35WDR:  .WORD  100605     ;REREAD DATA RETRY
T35CON:  .WORD  102205     ;WRITE CONTINUOUS
          .WORD  177777     ;END OF DATA
;
;
T35CNT:  .WORD  0         ;TAPE TIMER COUNTER STORAGE AREA
T35CNU:  .WORD  0         ;TAPE TIMER COUNTER STORAGE AREA
T35DLY:  .WORD  0         ;DELAY COUNTER
;
;*
;LOCAL TEXT MESSAGES FOR TEST
;-
T35WNG:  .ASCIZ  'Tape Position Incorrect After REREAD Previous (OPP=1)'
T35RDF:  .ASCIZ  'TSSR Incorrect After READ DATA Command'
T35RRF:  .ASCIZ  'REREAD Previous (Space Reverse, Read Forward) Command Failed'
T35SC:   .ASCIZ  'POSITION (Space Command) Failed, TSSR Not Correct'
T35LOR:  .ASCIZ  'RIB NOT SET AFTER READ REVERSE INTO BOT'
T35WDF:  .ASCIZ  'TSSR Not Correct After Illegal Mode Bits Set'
T35LOQ:  .ASCIZ  'Illegal Mode Bits, Failed To Set ILC Bit In XST0'
T35WDE:  .ASCIZ  'TSSR Not Correct After WRITE DATA Command'
T35BOT:  .ASCIZ  'Tape Not At BOT After REWIND Command (BOT Not Set In XST0)'
T35TIM:  .ASCIZ  'WRITE DATA RETRY'S Erase Tape Not Long Enough'
T35EOT:  .ASCIZ  'REREAD DATA OVER EOT GAVE NO TAPE STATUS ALERT'
T35TM:   .ASCIZ  'TSSR Not Correct After REREAD COMMAND Reject'
T35RW:   .ASCIZ  'Rewind (POSITION) Command Not Accepted'
T35RNC:  .ASCIZ  'RAM Error, Correct Data Pattern Not In Ram'
T35AM3:  .ASCIZ  'TSSR Init. Failed After REREAD COMMAND'
T35OFL:  .ASCIZ  'Drive 7 Select Failed To Set "OFL" In TSSR'

```



TEST 7: EXTENDED MODE FEATURES

9059	071040	124	123	123	T35WDD:	.ASCIZ	'TSSR Not Correct After REREAD DATA Command, SWB Bit Set'
9060	071130	124	123	123	T35WDC:	.ASCIZ	'TSSR Not Correct After REREAD DATA Command'
9061	071203	103	126	103	T35VCK:	.ASCIZ	'CVC Set, Didn't Reset VCK In Message Buffer'
9062	071256	124	123	102	T35BA:	.ASCIZ	'TSBA Not Correct After REREAD DATA Command'
9063	071331	127	122	111	T35WSS:	.ASCIZ	'WRITE SUBSYSTEM MEMORY Command Not Accepted (RAM Read)'
9064	071420	122	145	141	T35LON:	.ASCIZ	'Reading Long Record Failed To Set RLL Bit In XST0'
9065	071502	122	145	141	T35LOP:	.ASCIZ	'Reading Long Record Failed To Set RLS Bit In XST0'
9066	071564	122	145	163	T35PBP:	.ASCIZ	'Residual Byte Count Incorrect After Short Record Read'
9067	071652	122	145	141	T35TRL:	.ASCIZ	'Reading Long Record Failed To Give Tape Status Alert'
9068	071740	127	122	111	T35NEF:	.ASCIZ	'WRITE DATA RETRY, At First Record, Failed To Set RIB Bit XST3'
9069	072036	124	123	123	T35SCF:	.ASCIZ	'TSSR Not Correct After SPACE RECORDS Command'
9070	072113	124	123	123	T35TSA:	.ASCIZ	'TSSR Not Correct After WRITE DATA RETRY, Into BOT'
9071	072175	124	123	123	T35WRF:	.ASCIZ	'TSSR Not Correct After WRITE DATA RETRY Command'
9072	072255	104	141	164	T35DTA:	.ASCIZ	'Data Compare Error, Data Read From Tape Not Equal To Written'
9073	072352	124	123	123	T35SSR:	.ASCIZ	'TSSR Incorrect After WRITE MISCELLANEOUS Command'
9074	072433	115	117	124	T35MOT:	.ASCIZ	'MOT Bit (XST0) Not Set During Rewind (Extended Features Mode)'
9075	072531	111	156	164	T35INT:	.ASCIZ	'Interrupt Received After REWIND Command (IE Bit Not Set)'
9076	072622	117	120	115	T35OPM:	.ASCIZ	'OPM Bit (XST2) Not Set During Rewind (Extended Features Mode)'
9077	072720	124	123	123	T35RWE:	.ASCIZ	'TSSR Incorrect After Extended Features REWIND Command'
9078	073006	116	157	040	T35NIN:	.ASCIZ	'No Interrupt Detected After REWIND IMMEDIATE'
9079	073063	105	170	164	TST35ID:	.ASCIZ	'Extended Mode Functions'
9080						.EVEN	
9081							
9082							
9083							
9084							
9085							
9086							
9087							
9088	073114						
9089	073114						
9090	073120	012701	067320				
9091	073124	012721	100004				
9092	073130	012721	067330				
9093	073134	005021					
9094	073136	012721	000012				
9095	073142	012721	067342				
9096	073146	005021					
9097	073150	012721	000024				
9098	073154	005021					
9099	073156	012711	000000				
9100	073162	012702	000030				
9101	073166	012762	177777	067342	64:		
9102	073174	005742					
9103	073176	022702	000000				
9104	073202	001371					
9105	073204	000207					
9106							
9107	073206						
9108	073206						
9109	073212	012701	067430				
9110	073216	012721	100006				
9111	073222	012721	067450				
9112	073226	005021					
9113	073230	012721	000006				
9114	073234	005021					
9115	073236	012701	067450				

```

;
;ROUTINE TO RESTORE COMMAND PACKET TO START-UP (DEFAULT) VALUES
;WRITE SUBSYSTEM MEMORY COMMAND
;
;
T35REST:
    SAVREG
    MOV     #T35PACKET,R1
    MOV     #100004,(R1)+
    MOV     #T35DATA,(R1)+
    CLR     (R1)+
    MOV     #10,(R1)+
    MOV     #T35BFR,(R1)+
    CLR     (R1)+
    MOV     #20,(R1)+
    CLR     (R1)+
    MOV     #0,(R1)
    MOV     #24,R2
    MOV     #177777,T35BFR(R2)
    TST     -(R2)
    CMP     #0,R2
    BNE     64:
    RTS     PC
;SAVE THE REGISTERS
;START OF THE PACKET
;WRITE SUBSYSTEM MEM. WITH ACK,
;ADDRESS OF CHARACTERISTICS DATA BLOCK
;EXTENDED ADDRESS
;SIZE OF DATA BLOCK IN BYTES
;ADDRESS OF MESSAGE BUFFER
;LENGTH OF MESSAGE BUFFER
;SELECT DRIVE ZERO
;NUMBER OF LOCATIONS TO BE CLEARED
;ALL ONES TO MESSAGE BUFFER
;NEXT LOCATION
;AT END OF LOOP YET
;KEEP GOING UNTIL DONE
;RETURN

T35RT2:
    SAVREG
    MOV     #T35PK2,R1
    MOV     #100006,(R1)+
    MOV     #T35BF2,(R1)+
    CLR     (R1)+
    MOV     #6,(R1)+
    CLR     (R1)+
    MOV     #T35BF2,R1
;SAVE THE REGISTERS
;START OF THE PACKET
;WRITE SUBSYSTEM MEM. WITH ACK,
;ADDRESS OF DATA BLOCK
;EXTENDED ADDRESS
;SIZE OF DATA BLOCK IN BYTES
;POINT TO DATA SEL AREA

```









## TEST 8: RECORD BUFFERING

```

9221 073424 005237 002214          INC    FATFLG          ;ERROR COUNT
9225 073430 010001          MOV    RO,R1          ;CONTENTS OF TSSR REGISTER
9226 073432          ERRDF  ERRNO,SFIERR,SFIMSG ;FATAL ERROR TSSR WAS NOT OK
                                TRAP    C$ERDF
                                .WORD   801
                                .WORD   SFIERR
                                .WORD   SFIMSG
9227 073442 013737 002174 075560 20$:  MOV    UNITN,T36DSW   ;SET UP DRIVE NUMBER
9228 073450 012704 075540          MOV    @T36PACKET,R4 ;SUBROUTINE NEEDS PACKET ADDRESS
9229 073454 004737 010742          JSR    PC,WRTCHR     ;ISSUE WRITE CHARACTERISTICS
9230 073460 103407          BCS    25$          ;BR, IF COMMAND ISSUED OK
9231 073462 005237 002214          INC    FATFLG          ;ERROR COUNT
9235 073466 010001          MOV    RO,R1          ;SAVE CONTENTS OF TSSR
9236 073470          ERRHRD ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTIC FAILED
                                TRAP    C$ERHRD
                                .WORD   802
                                .WORD   WRTMSG
                                .WORD   SFIMSG
9237 073500          25$:  CKLOOP          ;LOOP IF SELECTED
                                TRAP    C$CLP1
9238 073502 004737 011126          JSR    PC,REWIND     ;CALL TAPE REWIND COMMAND
9239 073506 103407          BCS    30$          ;BR, IF NO PROBLEM
9240 073510 010004          MOV    RO,R4          ;SET UP REWIND PACKET ADDRESS
9241 073512 005237 002214          INC    FATFLG          ;ERROR COUNT
9245 073516          ERRHRD ERRNO,T36RWN,PKTSSR ;REWIND NOT ACCEPTED
                                TRAP    C$ERHRD
                                .WORD   803
                                .WORD   T36RWN
                                .WORD   PKTSSR
9246 073526          30$:  CKLOOP          ;LOOP IF SELECTED
                                TRAP    C$CLP1
9247 073530 013701 075570          MOV    T36BFR+6,R1   ;PICK UP XSTO
9248 073534 010102          MOV    R1,R2          ;SET UP EXPECTED
9249 073536 052702 000002          BIS    @BIT1,R2     ;SET BOT BIT IN EXPECTED
9250 073542 020102          CMP    R1,R2          ;DOES EXP = REC'D
9251 073544 001406          BEQ    40$          ;BR, IF EQUAL (OK)
9252 073546 005237 002214          INC    FATFLG          ;ERROR COUNT
9256 073552          ERRHRD ERRNO,T36BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
                                TRAP    C$ERHRD
                                .WORD   804
                                .WORD   T36BOT
                                .WORD   EXPREC
9257 073562          40$:  CKLOOP          ;LOOP IF SELECTED
                                TRAP    C$CLP1
9258 073564 013737 002174 075560          MOV    UNITN,T36DSW   ;SET UP DRIVE NUMBER
9259 073572 052737 000030 075560          BIS    @BIT3!BIT4,T36DSW ;25-APR-83 REV B - TURN ON THE BUFFERING
9260 073600 012704 075540          MOV    @T36PACKET,R4 ;SUBROUTINE NEEDS PACKET ADDRESS
9261 073604 004737 010742          JSR    PC,WRTCHR     ;ISSUE WRITE CHARACTERISTICS
9262 073610 103407          BCS    50$          ;BR, IF COMMAND ISSUED OK
9263 073612 005237 002214          INC    FATFLG          ;ERROR COUNT
9267 073616 010001          MOV    RO,R1          ;SAVE CONTENTS OF TSSR
9268 073620          ERRHRD ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTIC FAILED
                                TRAP    C$ERHRD
                                .WORD   805
                                .WORD   WRTMSG
                                .WORD   SFIMSG
9269 073630          50$:  CKLOOP          ;LOOP IF SELECTED

```







TEST 8: RECORD BUFFERING

```

9308 074122 001406
9309 074124 005237 002214
9313 074130
      074130 104456
      074132 001447
      074134 076543
      074136 012156
9314 074140
      074140 104406
9315 074142 013737 002174 075560
9316 074150 052737 000010 075560
9317 074156 012704 075540
9318 074162 004737 010742
9319 074166 103407
9320 074170 005237 002214
9324 074174 010001
9325 074176
      074176 104456
      074200 001450
      074202 005054
      074204 012144
9326 074206
      074206 104406
9327 074210 012737 006642 075666
9328 074216 012737 140005 075660
9329 074224 012704 075660
9330 074230 005037 075710
9331 074234 012737 001750 075712
9332 074242 010465 000000
9333 074246 016501 000002
9334 074252 032701 000200
9335 074256 001021
9336 074260 005237 075710
9337 074264
      074264 012727 000001
      074270 000000
      074272 013727 002116
      074276 000000
      074300 005367 177772
      074304 001375
      074306 005367 177756
      074312 001367
9338 074314 005337 075712
9339 074320 001352
9340 074322 012702 000200
9341 074326 020102
9342 074330 001406
9343 074332 005237 002214
9347 074336
      074336 104456
      074340 001451
      074342 005111
      074344 012156
9348 074346
      074346 104406
9349 074350 013701 075706
9350 074354 013702 075710

```

```

      BEQ      100$
      INC     FATFLG
      ERRHRD  ERRNO,T36WDE,PKTSSR
      ;BR, IF OK
      ;ERROR COUNT
      ;TSSR INCORRECT AFTER READ DATA
      TRAP    C$ERHRD
      .WORD   807
      .WORD   T36WDE
      .WORD   PKTSSR
100$:  CKLOOP
      ;LOOP IF SELECTED
      TRAP    C$CLP1
      MOV     UNITN,T36DSW
      BIS     #BIT3,T36DSW
      MOV     #T36PACKET,R4
      JSR     PC,WRTCHR
      BCS     110$
      INC     FATFLG
      MOV     R0,R1
      ERRHRD  ERRNO,WRTMSG,SFMSG
      ;SET UP DRIVE NUMBER
      ;25-APR-83 REV B - TURN OFF BUFFERING
      ;SUBROUTINE NEEDS PACKET ADDRESS
      ;ISSUE WRITE CHARACTERISTICS
      ;BR, IF COMMAND ISSUED OK
      ;ERROR COUNT
      ;SAVE CONTENTS OF TSSR
      ;WRITE CHARACTERISTIC FAILED
      TRAP    C$ERHRD
      .WORD   808
      .WORD   WRTMSG
      .WORD   SFMSG
110$:  CKLOOP
      ;LOOP IF SELECTED
      TRAP    C$CLP1
      MOV     #3490.,T36SZ
      MOV     #140005,T36PK3
      MOV     #T36PK3,R4
      CLR     T36CNU
      MOV     #1000.,T36DLY
      MOV     R4,TSDB(R5)
120$:  MOV     TSSR(R5),R1
      BIT     #SSR,R1
      BNE     130$
      INC     T36CNU
      DELAY   1
      ;SET SIZE OF TRANSFER
      ;WRITE DATA,ACK,CVC=1 COMMAND
      ;SET UP R4 WITH PACKET ADDRESS
      ;CLEAR COUNTER
      ;SET DROP DEAD COUNTER VALUE
      ;ISSUE COMMAND
      ;GET TSSR CONTENTS
      ;CHECK FOR SSR SET
      ;BR, IF SSR IS SE.
      ;BUMP CYCLE COUNTER
      ;CUT NUMBER OF LOOPS DOWN
      MOV     #1,(PC)+
      .WORD   0
      MOV     L$DLY,(PC)+
      .WORD   0
      DEC     -6(PC)
      BNE     -.4
      DEC     -22(PC)
      BNE     -.20
130$:  DEC     T36DLY
      BNE     120$
      MOV     #SSR,R2
      CMP     R1,R2
      BEQ     140$
      INC     FATFLG
      ERRHRD  ERRNO,WRTERR,PKTSSR
      ;BUMP DROP DEAD COUNTER
      ;BR, IF THERE IS STILL TIME
      ;SET UP EXPECTED
      ;ARE THEY EQUAL
      ;BR, IF OK
      ;ERROR COUNT
      ;TSSR INCORRECT AFTER WRITE DATA
      TRAP    C$ERHRD
      .WORD   809
      .WORD   WRTERR
      .WORD   PKTSSR
140$:  CKLOOP
      ;LOOP IF SELECTED
      TRAP    C$CLP1
      MOV     T36CNT,R1
      MOV     T36CNU,R2
      ;GET FIRST COUNTER
      ;GET SECOND COUNTER

```



B1

TEST 8: RECORD BUFFERING

```

9351 074360 020102          CMP      R1,R2          ;25-APR-83 REV B - COMPARE EM
9352 074362 003406          BLE      300$          ;BR, IF VALUES ARE CORRECT (OK)
9353 074364 005237 002214  INC      FATFLG        ;ERROR COUNT
9357 074370          ERRHRD  ERRNO,T36NAS,EXPREC ;TAPE NOT AT CORRECT SPEED
          074370 104456          TRAP      C$ERHRD
          074372 001452          .WORD    810
          074374 075714          .WORD    T36NAS
          074376 015604          .WORD    EXPREC
9358 074400          300$:  CKLOOP          ;LOOP IF SELECTED
          074400 104406          TRAP      C$CLP1
9359 074402          350$:
9360 074402          ENDSUB
          074402 104403          L10071:  TRAP      C$ESUB
9361 074404 023727 002214 000017  CMP      FATFLG,#15.  ;IS ERROR COUNT AT 25
9362 074412 103402          BLO     999$          ;BR, IF LESS THAN 25
9363 074414 004737 017312  JSR     PC,CKDROP    ;TRY TO DROP THE UNIT
9364 074420          999$:

```

TEST 8, SUBTEST 2

THIS TEST VERIFIES THAT RECORD BUFFERING, USED FOR WRITE DATA AND READ NEXT COMMANDS, OPERATES PROPERLY AND IS PROPERLY CONTROLLED BY THE EXTENDED CHARACTERISTICS DATA WORD. IF THE M7196 CONTROLLER MODULE IS NOT ALREADY IN EXTENDED FEATURES MODE (AS CONTROLLED BY THE DIP SWITCH ON THE MODULE), IT IS PLACED INTO THAT MODE BY INVERTING THE SENSE OF THE SWITCH USING THE WRITE SUBSYSTEM MEMORY COMMAND. NOTE THAT RECORD BUFFERING HAS BEEN ENABLED IN PREVIOUS TESTS OF READ AND WRITE AND SO HAS BEEN PARTIALLY TESTED ALREADY. THIS TEST VERIFIES THAT BUFFERING IS ACTUALLY OPERATING. THE FOLLOWING SUBTESTS ARE PERFORMED:

VERIFIES THAT NORMAL BUFFERING ON WRITE DATA COMMANDS OPERATES PROPERLY AT LOW TAPE SPEED. THE FOLLOWING SEQUENCE IS PERFORMED:

1. THE TAPE IS REWOUND.
2. BUFFERING IS DISABLED AND LOW TAPE SPEED IS SELECTED (VIA WRITE CHARACTERISTICS COMMAND).
3. AN INITIAL RECORD IS WRITTEN ONTO THE TAPE IN ORDER TO MOVE THE TAPE OFF BOT.
4. THE PROGRAM DELAYS FOR A TIME SUFFICIENT TO ALLOW THE TAPE TO REPOSITION AND COME TO REST.
5. A WRITE DATA COMMAND, WITH A BYTE COUNT LESS THAN 3.5K, IS ISSUED, AND THE PROGRAM COUNTS, IN A WAIT LOOP, THE TIME IT TAKES TO RECEIVE COMMAND TERMINATION. THIS SHOULD BE A RELATIVELY LONG TIME SINCE BUFFERING IS DISABLED.
6. BUFFERING IS ENABLED.

9365  
9366  
9367  
9368  
9369  
9370  
9371  
9372  
9373  
9374  
9375  
9376  
9377  
9378  
9379  
9380  
9381  
9382  
9383  
9384  
9385  
9386  
9387  
9388  
9389  
9390  
9391  
9392  
9393  
9394  
9395  
9396  
9397  
9398  
9399  
9400  
9401  
9402  
9403











E1

TEST 8: RECORD BUFFERING

9497	075020	012737	000005	075712		MOV	#05.,T36DLY		;25-APR-83 REV B - DELAY FOR TAPE TO STOP
9498	075026				70\$:	DELAY	1		;25-APR-83 REV B - DELAY ROUTINE CALL
	075026	012727	000001						MOV #1,(PC)+
	075032	000000							.WORD 0
	075034	013727	002116						MOV L\$DLY,(PC)+
	075040	000000							.WORD 0
	075042	005367	177772						DEC -6(PC)
	075046	001375							BNE -4
	075050	005367	177756						DEC -22(PC)
	075054	001367							BNE -20
9499	075056	005337	075712			DEC	T36DLY		;BUMP COUNTER DOWN
9500	075062	001361				BNE	70\$		;BR, IF MORE DELAY TO GO
9501	075064	022737	000001	002222		CMP	#1,REV		;IS IT A NEW MICROCODE?
9502	075072	001402				BEQ	75\$		;NO BR
9503	075074	000137	075500			JMP	350\$		;YES JUMP
9504	075100	012737	006642	075666	75\$:	MOV	#3490.,T36SZ		;SET SIZE OF TRANSFER
9505	075106	012737	140005	075660		MOV	#140005,T36PK3		;WRITE DATA,ACK,CVC=1 COMMAND
9506	075114	012704	075660			MOV	#T36PK3,R4		;SET UP R4 WITH PACKET ADDRESS
9507	075120	005037	075706			CLR	T36CNT		;CLEAR COUNTER
9508	075124	012737	001750	075712		MOV	#1000.,T36DLY		;SET DROP DEAD COUNTER VALUE
9509	075132	010465	000000			MOV	R4,TSDB(R5)		;ISSUE COMMAND
9510	075136	016501	000002		80\$:	MOV	TSSR(R5),R1		;GET TSSR CONTENTS
9511	075142	032701	000200			BIT	#SSR,R1		;CHECK FOR SSR SET
9512	075146	001021				BNE	90\$		;BR, IF SSR IS SET
9513	075150	005237	075706			INC	T36CNT		;BUMP CYCLE COUNTER
9514	075154					DELAY	1		;CUT NUMBER OF LOOPS DOWN
	075154	012727	000001						MOV #1,(PC)+
	075160	000000							.WORD 0
	075162	013727	002116						MOV L\$DLY,(PC)+
	075166	000000							.WORD 0
	075170	005367	177772						DEC -6(PC)
	075174	001375							BNE -4
	075176	005367	177756						DEC -22(PC)
	075202	001367							BNE -20
9515	075204	005337	075712			DEC	T36DLY		;BUMP DROP DEAD COUNTER
9516	075210	001352				BNE	80\$		;BR, IF THERE IS STILL TIME
9517	075212	012702	000200		90\$:	MOV	#SSR,R2		;SET UP EXPECTED
9518	075216	020102				CMP	R1,R2		;ARE THEY EQUAL
9519	075220	001406				BEQ	100\$		;BR, IF OK
9520	075222	005237	002214			INC	FATFLG		;ERROR COUNT
9524	075226					ERRHRD	ERRNO,T36WDE,PKTSSR		;TSSR INCORRECT AFTER READ DATA
	075226	104456							TRAP C\$ERHRD
	075230	001461							.WORD 817
	075232	076543							.WORD T36WDE
	075234	012156							.WORD PKTSSR
9525	075236				100\$:	CKLOOP			;LOOP IF SELECTED
	075236	104406							TRAP C\$CLP1
9526	075240	013737	002174	075560		MOV	UNITN,T36DSW		;SET UP DRIVE NUMBER
9527	075246	052737	000010	075560		BIS	#BIT3,T36DSW		;25-APR-83 REV B - TURN OFF BUFFERING
9528	075254	012704	075540			MOV	#T36PACKET,R4		;SUBROUTINE NEEDS PACKET ADDRESS
9529	075260	004737	010742			JSR	PC,WRTCHR		;ISSUE WRITE CHARACTERISTICS
9530	075264	103407				BCS	110\$		;BR, IF COMMAND ISSUED OK
9531	075266	005237	002214			INC	FATFLG		;ERROR COUNT
9535	075272	010001				MOV	R0,R1		;SAVE CONTENTS OF TSSR
9536	075274					ERRHRD	ERRNO,WRTMSG,SFIMSG		;WRITE CHARACTERISTICS FAILED
	075274	104456							TRAP C\$ERHRD
	075276	001462							.WORD 818



F1

TEST 8: RECORD BUFFERING

```

075300 005054 .WORD WRTMSG
075302 012144 .WORD SFIMSG
9537 075304 110$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
075304 104406 ;SET SIZE OF TRANSFER
9538 075306 012737 006642 075666 MOV #3490.,T36SZ ;WRITE DATA,ACK,CVC=1 COMMAND
9539 075314 012737 140005 075660 MOV #140005,T36PK3 ;SET UP R4 WITH PACKET ADDRESS
9540 075322 012704 075660 MOV T36PK3,R4 ;CLEAR COUNTER
9541 075326 005037 075710 CLR T36CNU ;SET DROP DEAD COUNTER VALUE
9542 075332 012737 001750 075712 MOV #1000.,T36DLY ;ISSUE COMMAND
9543 075340 010465 000000 MOV R4,TSD8(R5) ;GET TSSR CONTENTS
9544 075344 016501 000002 120$: MOV TSSR(R5),R1 ;CHECK FOR SSR SET
9545 075350 032701 000200 BIT #SSR,R1 ;BR, IF SSR IS SET
9546 075354 001021 BNE 130$ ;BUMP CYCLE COUNTER
9547 075356 005237 075710 INC T36CNU ;CUT NUMBER OF LOOPS DOWN
9548 075362 DELAY 1
075362 012727 000001 MOV #1,(PC)+
075366 000000 .WORD 0
075370 013727 002116 MOV L$DLY,(PC)+
075374 000000 .WORD 0
075376 005367 177772 DEC -6(PC)
075402 001375 BNE -.4
075404 005367 177756 DEC -22(PC)
075410 001367 BNE .-20
9549 075412 005337 075712 DEC T36DLY ;BUMP DROP DEAD COUNTER
9550 075416 001352 BNE 120$ ;BR, IF THERE IS STILL TIME
9551 075420 012702 000200 130$: MOV #SSR,R2 ;SET UP EXPECTED
9552 075424 020102 CMP R1,R2 ;ARE THEY EQUAL
9553 075426 001406 BEQ 140$ ;BR, IF OK
9554 075430 005237 002214 INC FATFLG ;ERROR COUNT
9555 075434 ERRHRD ERRNO,WRTERR,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
075434 104456 TRAP C$ERHRD
075436 001463 .WORD 819
075440 005111 .WORD WRTERR
075442 012156 .WORD PKTSSR
9559 075444 140$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
075444 104406 ;GET FIRST COUNTER
9560 075446 013701 075706 MOV T36CNT,R1 ;GET SECOND COUNTER
9561 075452 013702 075710 MOV T36CNU,R2 ;25-APR-83 REV B - COMPARE EM
9562 075456 020102 CMP R1,R2 ;BR, IF VALUES ARE CORRECT (OK)
9563 075460 003406 BLE 300$ ;ERROR COUNT
9564 075462 005237 002214 INC FATFLG ;TAPE NOT AT CORRECT SPEED
9568 075466 ERRHRD ERRNO,T36NAS,EXPREC TRAP C$ERHRD
075466 104456 .WORD 820
075470 001464 .WORD T36NAS
075472 075714 .WORD EXPREC
075474 015604
9569 075476 300$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
075476 104406
9570 075500 350$: ENDSUB
075500
075500 104403 L10072: TRAP C$ESUB
9571 075502 023727 002214 000017 CMP FATFLG,#15. ;IS ERROR COUNT AT 25
9572 075510 103402 BLO 999$ ;BR, IF LESS THAN 25
9573 075512 004737 017312 JSR PC,CKDROP ;TRY TO DROP THE UNIT
9574 075516
9575
9576

```



G1

TEST 8: RECORD BUFFERING

```

9577
9578 075516 004737 016566      ;      JSR      PC,TSTLOOP      ;DO WE NEED TO ITERATE TEST
9579 075522 103002              ;      BCC      163$           ;BR, IF NO LOOP REQUIRED
9580 075524 000137 073330      ;      JMP      T36LOOP        ;EXECUTE AGAIN
9581 075530
9582 075530      163$:      EXIT      TST      ;ALL DONE THIS TEST
          075530 104432              TRAP      C$EXIT
          075532 003344              .WORD    L10070-.
9583
9584      ;*
9585      ;LOCAL STORAGE FOR THIS TEST
9586      ;-
9587      ;=<..+10>&177770
9589 075540      T36PACKET:
9590 075540 100004      .WORD    100004      ;COMMAND PACKET FOR TEST
9591 075542 075550      .WORD    T36DATA    ;WRITE CHARACTERISTICS COMMAND, WITH , ACK
9592 075544 000000      .WORD    0           ;ADDRESS OF CHARACTERISTICS BLOCK
9593 075546 000012      .WORD    10.        ;STARTING VALUE OF BLOCK SIZE
9594 075550      T36DATA:
9595 075550 075562      .WORD    T36BFR     ;CHARACTERISTICS DATA BLOCK
9596 075552 000000      .WORD    0           ;ADDRESS OF MESSAGE BUFFER
9597 075554 000024      .WORD    20.       ;LENGTH OF MESSAGE BUFFER
9598 075556 000000      .WORD    0           ;SELECT DRIVE 0
9599 075560 000000      T36DSW: .WORD    0   ;MESSAGE BUFFER
9600 075562      T36BFR: .BLKW   25.
9601
9602      ;WRITE SUBSYSTEM MEMORY COMMAND PACKET
9603
9605      ;=<..+10>&177770
9607 075650      T36PK2:
9608 075650 100006      .WORD    100006     ;WRITE SUB SYS MEM COMMAND, AND ACK
9609 075652 075670      .WORD    T36BF2     ;ADDRESS OF SELECT BLOCK DATA
9610 075654 000000      .WORD    0           ;SIZE OF DATA PACKET
9611 075656 000006      .WORD    6.
9612
9616 075660      T36PK3:
9617 075660 100005      .WORD    100005     ;REREAD COMMAND, AND ACK
9618 075662      T36RB:
9619 075662 003120      T36WB: .WORD    FREE  ;ADDRESS OF WRITE BUFFER
9620 075664 000000      .WORD    0           ;SIZE OF BUFFER (EXTENT)
9621 075666 000000      T36SZ: .WORD    0
          .EVEN
9622
9623
9624
9625
9626 075670      T36BF2:
9627 075670 010          T36BS0: .BYTE    10   ;BSELO AREA
9628 075671 200          T36BS1: .BYTE    200  ;BSEL1 AREA
9629 075672 000000      T36S2: .WORD    0   ;SEL 2 AREA
9630 075674 000000      T36S3: .WORD    0   ;DATA AREA
9631
9632
9633      ;
          .EVEN
9634      ;TAPE MOTION PACKET COMMAND VALUES
9635
9636 075676 100205      T36RN: .WORD    100205 ;REREAD DATA (NEXT)
9637 075700 100605      T36WDR: .WORD    100605 ;REREAD DATA RETRY
9638 075702 102205      T36CON: .WORD    102205 ;WRITE CONTINOUS

```

H1

TEST 8: RECORD BUFFERING

```

9639 075704 177777          .WORD 177777          ;END OF DATA
9640
9641
9642 075706 000000          T36CNT: .WORD 0          ;TAPE TIMER COUNTER STORAGE AREA
9643 075710 000000          T36CNU: .WORD 0          ;TAPE TIMER COUNTER STORAGE AREA
9644 075712 000000          T36DLY: .WORD 0          ;DELAY COUNTER
9645
9646                          ;*
9647                          ;LOCAL TEXT MESSAGES FOR TEST
9648                          ;-
9649 075714      111      155      160 T36NAS: .ASCIZ 'Improper Tape Controller Buffering Speed'
9650 075765      124      141      160 T36WNG: .ASCIZ 'Tape Position Incorrect After REREAD Previous (OPP=1)'
9651 076053      124      123      123 T36RDF: .ASCIZ 'TSSR Incorrect After READ DATA Command'
9652 076122      122      105      122 T36RRF: .ASCIZ 'REREAD Previous (Space Reverse, Read Forward) Command Failed'
9653 076217      120      117      123 T36SC: .ASCIZ 'POSITION (Space Command) Failed, TSSR Not Correct'
9654 076301      122      111      102 T36LOR: .ASCIZ 'RIB NOT SET AFTER READ REVERSE INTO BOT'
9655 076351      124      123      123 T36WDF: .ASCIZ 'TSSR Not Correct After Illegal Mode Bits Set'
9656 076426      111      154      154 T36LOQ: .ASCIZ 'Illegal Mode Bits, Failed To Set ILC Bit In XST0'
9657 076507      122      105      122 T36SSR: .ASCIZ 'REREAD COMMAND Not Accepted'
9658 076543      124      123      123 T36WDE: .ASCIZ 'TSSR Not Correct After WRITE DATA Command'
9659 076615      124      141      160 T36BOT: .ASCIZ 'Tape Not At BOT After REWIND Command (BOT Not Set In XST0)'
9660 076710      127      122      111 T36TIM: .ASCIZ 'WRITE DATA RETRY'S Erase Tape Not Long Enough'
9661 076765      122      105      122 T36EOT: .ASCIZ 'REREAD DATA OVER EOT GAVE NO TAPE STATUS ALERT'
9662 077044      124      123      123 T36TM: .ASCIZ 'TSSR Not Correct After REREAD COMMAND Reject'
9663 077121      122      145      167 T36RWN: .ASCIZ 'Rewind (POSITION) Command Not Accepted'
9664 077170      122      101      115 T36RNC: .ASCIZ 'RAM Error, Correct Data Pattern Not In Ram'
9665 077243      124      123      123 T36AM3: .ASCIZ 'TSSR Init. Failed After REREAD COMMAND'
9666 077312      104      162      151 T36OFL: .ASCIZ 'Drive 7 Select Failed To Set "OFL" In TSSR'
9667 077365      124      123      123 T36WDD: .ASCIZ 'TSSR Not Correct After REREAD DATA Command, SWB Bit Set'
9668 077455      124      123      123 T36WDC: .ASCIZ 'TSSR Not Correct After REREAD DATA Command'
9669 077530      103      126      103 T36VCK: .ASCIZ 'CVC Set, Didn't Reset VCK In Message Buffer'
9670 077603      124      123      102 T36BA: .ASCIZ 'TSBA Not Correct After REREAD DATA Command'
9671 077656      127      122      111 T36WSS: .ASCIZ 'WRITE SUBSYSTEM MEMORY Command Not Accepted (RAM Read)'
9672 077745      122      145      141 T36LON: .ASCIZ 'Reading Long Record Failed To Set RLL Bit In XST0'
9673 100027      122      145      141 T36LOP: .ASCIZ 'Reading Long Record Failed To Set RLS Bit In XST0'
9674 100111      122      145      163 T36PBP: .ASCIZ 'Residual Byte Count Incorrect After Short Record Read'
9675 100177      122      145      141 T36TRL: .ASCIZ 'Reading Long Record Failed To Give Tape Status Alert'
9676 100265      127      122      111 T36NEF: .ASCIZ 'WRITE DATA RETRY, At First Record, Failed To Set RIB Bit XST3'
9677 100363      124      123      123 T36SCF: .ASCIZ 'TSSR Not Correct After SPACE RECORDS Command'
9678 100440      124      123      123 T36TSA: .ASCIZ 'TSSR Not Correct After WRITE DATA RETRY, Into BOT'
9679 100522      124      123      123 T36WRF: .ASCIZ 'TSSR Not Correct After WRITE DATA RETRY Command'
9680 100602      104      141      164 T36DTA: .ASCIZ 'Data Compare Error, Data Read From Tape Not Equal To Written'
9681 100677      122      145      143 TST36ID: .ASCIZ 'Record Buffering'
9682                          .EVEN
9683                          ;*
9684                          ;
9685                          ;ROUTINE TO RESTORE COMMAND PACKET TO START-UP (DEFAULT) VALUES
9686                          ;WRITE SUBSYSTEM MEMORY COMMAND
9687                          ;
9688                          ;-
9689
9690 100720          T36REST:
9691 100720          SAVREG
9692 100724 012701 075540      MOV #T36PACKET,R1          ;SAVE THE REGISTERS
9693 100730 012721 100004      MOV #100004,(R1)+         ;START OF THE PACKET
9694 100734 012721 075550      MOV #T36DATA,(R1)+       ;WRITE SUBSYSTEM MEM. WITH ACK,
9695 100740 005021          CLR (R1)+                 ;ADDRESS OF CHARAISTICS DATA BLOCK
                          ;EXTENDED ADDRESS

```



TEST 8: RECORD BUFFERING

```

9696 100742 012721 000012      MOV      #10.,(R1)+          ;SIZE OF DATA BLOCK IN BYTES
9697 100746 012721 075562      MOV      #T36BFR,(R1)+     ;ADDRESS OF MESSAGE BUFFER
9698 100752 005021              CLR      (R1)+             ;
9699 100754 012721 000024      MOV      #20.,(R1)+       ;LENGTH OF MESSAGE BUFFER
9700 100760 005021              CLR      (R1)+             ;
9701 100762 012711 000000      MOV      #0,(R1)          ;SELECT DRIVE ZERO
9702 100766 012702 000030      MOV      #24.,R2          ;NUMBER OF LOCATIONS TO BE CLEARED
9703 100772 012762 177777 075562 64$: MOV      #177777,T36BFR(R2) ;ALL ONES TO MESSAGE BUFFER
9704 101000 005742              TST      -(R2)             ;NEXT LOCATION
9705 101002 022702 000000      CMP      #0,R2            ;AT END OF LOOP YET
9706 101006 001371              BNE      64$              ;KEEP GOING UNTIL DONE
9707 101010 000207              RTS      PC                ;RETURN
9708
9709 101012              T36RT2:
9710 101012              SAVREG                    ;SAVE THE REGISTERS
9711 101016 012701 075650      MOV      #T36PK2,R1       ;START OF THE PACKET
9712 101022 012721 100006      MOV      #100006,(R1)+    ;WRITE SUBSYSTEM MEM. WITH ACK,
9713 101026 012721 075670      MOV      #T36BF2,(R1)+    ;ADDRESS OF DATA BLOCK
9714 101032 005021              CLR      (R1)+            ;EXTENDED ADDRESS
9715 101034 012721 000006      MOV      #6.,(R1)+        ;SIZE OF DATA BLOCK IN BYTES
9716 101040 005021              CLR      (R1)+            ;
9717 101042 012701 075670      MOV      #T36BF2,R1       ;POINT TO DATA SEL AREA
9718 101046 005021              CLR      (R1)+            ;
9719 101050 005011              CLR      (R1)             ;
9720 101052 000207              RTS      PC                ;RETURN
9721 101054              T36RT3:
9722 101054              SAVREG                    ;SAVE REGISTERS
9723 101060 012701 075660      MOV      #T36PK3,R1       ;SET UP POINTER ADDRESS
9724 101064 005021              CLR      (R1)+            ;COMMAND SPACE
9725 101066 005021              CLR      (R1)+            ;ADDRESS OF DATA BLOCK
9726 101070 005021              CLR      (R1)+            ;EXTENDED ADDRESS
9727 101072 005011              CLR      (R1)             ;SIZE OF DATA TRANSFER BLOCK
9728 101074 000207              RTS      PC                ;RETURN
9729 101076              ENDTST
101076              L10070: TRAP      C$ETST
101076 104401
9730              .SBTTL TEST 9: FUNCTION TIMING
9731              ;*
9732              ;
9733              ;THIS TEST VERIFIES THAT THE TAPE TRANSPORT SEEMS TO BE WRITING
9734              ;RECORDS, GAPS, AND EXTENDED GAPS OF THE PROPER LENGTH. BOTH LOW
9735              ;AND HIGH SPEED MODES ARE TESTED. IT IS ALSO VERIFIED THAT A
9736              ;SPACE RECORDS COMMAND WITH A RECORD COUNT OF 80 OR MORE, AND A
9737              ;SKIP TAPE MARKS COMMAND WITH A COUNT OF 2 OF MORE, OPERATE THE
9738              ;TAPE IN HIGH-SPEED MODE. THIS TEST CAN ONLY BE RUN IF A
9739              ;REAL-TIME CLOCK IS AVAILIABLE ON THE SYSTEM. THE TEST OPERATES BY
9740              ;TIMING VARIOUS TAPE-MOTION OPERATIONS, USING A NUMBER OF
9741              ;DIFFERENT TEST RECORD LENGTHS.
9742              ;
9743              ;
9744              ;-
9745 101100              BGNTST
101100
9746 101100 012737 006356 002172      MOV      #EPRT1,EPRTSW    ;PRIMARY ERROR MESSAGE
9747 101106 004737 017404              JSR      PC,KTOFF         ;TURN KT OFF
9752 101112 012700 105323              MOV      #TST37ID,R0     ;ASCII MESSAGE TO IDENTIFY TEST
9753 101116 004737 016620              JSR      PC,TSTSETUP     ;DO INITIAL TEST SETUP

```







L1

TEST 9: FUNCTION TIMING

9847	101536	013701	102250		MOV	T37BFR+6,R1		;PICK UP XSTO	
9848	101542	010102			MOV	R1,R2		;SET UP EXPECTED	
9849	101544	052702	000002		BIS	#BIT1,R2		;SET BOT BIT IN EXPECTED	
9850	101550	020102			CMP	R1,R2		;DOES EXP = REC'D	
9851	101552	001406			BEQ	140\$		;BR, IF EQUAL (OK)	
9852	101554	005237	002214		INC	FATFLG		;ERROR COUNT	
9856	101560				ERRHRD	ERRNO,T37BOT,EXPREC		;TAPE NOT AT BOT AFTER REWIND	
	101560	104456						TRAP	C\$ERHRD
	101562	001613						.WORD	907
	101564	103241						.WORD	T37BOT
	101566	015604						.WORD	EXPREC
9857	101570			140\$:	CKLOOP			;LOOP IF SELECTED	
	101570	104406						TRAP	C\$CLP1
9858	101572	012704	102340		MOV	#T37PK3,R4		;SET UP PACKET ADDRESS	
9859	101576	012737	000037	102342	MOV	#31,T37RB		;SET UP RECORDS TO SPACE OVER	
9860	101604	012737	140010	102340	MOV	#140010,T37PK3		;ACK,CVC=1,SPACE FORWARD COMMAND	
9861	101612	010465	000000		MOV	R4,TSDB(R5)		;ISSUE COMMAND	
9862	101616	005237	102366	150\$:	INC	T37CNT		;BUMP TIMER	
9863	101622			152\$:	DELAY	1		;DELAY ABOUT 100US	
	101622	012727	000001					MOV	#1,(PC)+
	101626	000000						.WORD	0
	101630	013727	002116					MOV	L\$DLY,(PC)+
	101634	000000						.WORD	0
	101636	005367	177772					DEC	-6(PC)
	101642	001375						BNE	-.4
	101644	005367	177756					DEC	-22(PC)
	101650	001367						BNE	.-20
9864	101652	016501	000002		MOV	TSSR(R5),R1		;GET TSSR	
9865	101656	032701	000200		BIT	#SSR,R1		;CHECK FOR TSSR'S SSR SET	
9866	101662	001755			BEQ	152\$		;KEEP COUNTING UNTIL SET	
9867	101664	012702	000200		MOV	#SSR,R2		;SET UP EXPECTED	
9868	101670	020201			CMP	R2,R1		;WAS EVERYTHING OK	
9869	101672	001406			BEQ	160\$		;BR, IF ALL IS WELL	
9870	101674	005237	002214		INC	FATFLG		;ERROR COUNT	
9874	101700				ERRHRD	ERRNO,T37SCF,PKTSSR		;SPACE FORWARD DIDN'T WORK OUT	
	101700	104456						TRAP	C\$ERHRD
	101702	001614						.WORD	908
	101704	105007						.WORD	T37SCF
	101706	012156						.WORD	PKTSSR
9875	101710			160\$:	CKLOOP			;LOOP IF SELECTED	
	101710	104406						TRAP	C\$CLP1
9876	101712	004737	011126		JSR	PC,REWIND		;CALL TAPE REWIND COMMAND	
9877	101716	103411			BCS	170\$		;BR, IF NO PROBLEM	
9878	101720	010004			MOV	R0,R4		;GET PACKET ADDRESS	
9879	101722	016501	000002		MOV	TSSR(R5),R1		;GET STATUS FROM TSSR	
9880	101726	005237	002214		INC	FATFLG		;ERROR COUNT	
9884	101732				ERRHRD	ERRNO,T37RWN,PKTSSR		;REWIND NOT ACCEPTED	
	101732	104456						TRAP	C\$ERHRD
	101734	001615						.WORD	909
	101736	103545						.WORD	T37RWN
	101740	012156						.WORD	PKTSSR
9885	101742			170\$:	CKLOOP			;LOOP IF SELECTED	
	101742	104406						TRAP	C\$CLP1
9886	101744	013701	102250		MOV	T37BFR+6,R1		;PICK UP XSTO	
9887	101750	010102			MOV	R1,R2		;SET UP EXPECTED	
9888	101752	052702	000002		BIS	#BIT1,R2		;SET BOT BIT IN EXPECTED	
9889	101756	020102			CMP	R1,R2		;DOES EXP = REC'D	





N1

TEST 9: FUNCTION TIMING

```

9931 102200
9932
9933
9934
9935 102200 004737 016566
9936 102204 103002
9937 102206 000137 101134
9938 102212
9939 102212
      102212 104432
      102214 003306

9940
9941
9942
9944      102220
9946 102220
9947 102220 100004
9948 102222 102230
9949 102224 000000
9950 102226 000012
9951 102230
9952 102230 102242
9953 102232 000000
9954 102234 000024
9955 102236 000000
9956 102240 000000
9957 102242
9958
9959
9960
9962      102330
9964 102330
9965 102330 100006
9966 102332 102350
9967 102334 000000
9968 102336 000006
9969
9973 102340
9974 102340 100005
9975 102342
9976 102342 003120
9977 102344 000000
9978 102346 000000
9979
9980
9981
9982
9983 102350
9984 102350      010
9985 102351      200
9986 102352 000000
9987 102354 000000
9988
9989
9990
9991
9992

9994:
:
:
:
      JSR      PC,TSTLOOP      ;DO WE NEED TO ITERATE TEST
      BCC      163$            ;BR, IF NO LOOP REQUIRED
      JMP      T37LOOP         ;EXECUTE AGAIN
163$:
      EXIT      TST            ;ALL DONE THIS TEST
                                      TRAP      C$EXIT
                                      .WORD     L10073-.

;+
;LOCAL STORAGE FOR THIS TEST
;-
      .=<..+10>&177770
T37PACKET:
      .WORD     100004          ;COMMAND PACKET FOR TEST
      .WORD     T37DATA        ;WRITE CHARACTERISTICS COMMAND, WITH . ACK
      .WORD     0              ;ADDRESS OF CHARACTERISTICS BLOCK
      .WORD     10.           ;STARTING VALUE OF BLOCK SIZE
T37DATA:
      .WORD     T37BFR         ;CHARACTERISTICS DATA BLOCK
      .WORD     0              ;ADDRESS OF MESSAGE BUFFER
      .WORD     20.           ;LENGTH OF MESSAGE BUFFER
T37DSW: .WORD 0              ;SELECT DRIVE 0
T37BFR: .BLKW 25.           ;MESSAGE BUFFER

;WRITE SUBSYSTEM MEMORY COMMAND PACKET
:
      .=<..+10>&177770
T37PK2:
      .WORD     100006          ;WRITE SUB SYS MEM COMMAND, AND ACK
      .WORD     T37BF2        ;ADDRESS OF SELECT BLOCK DATA
      .WORD     0              ;SIZE OF DATA PACKET
T37PK3:
      .WORD     100005          ;REREAD COMMAND, AND ACK
T37RB:
T37WB: .WORD FREE          ;ADDRESS OF WRITE BUFFER
      .WORD     0              ;SIZE OF BUFFER (EXTENT)
T37SZ: .WORD 0
      .EVEN

:
:
:
T37BF2:
T37BS0: .BYTE 10           ;BSEL0 AREA
T37BS1: .BYTE 200         ;BSEL1 AREA
T37S2: .WORD 0            ;SEL 2 AREA
T37S3: .WORD 0            ;DATA AREA

:
:
      .EVEN
;TAPE MOTION PACKET COMMAND VALUES

```



TEST 9: FUNCTION TIMING

```

9993 102356 100205      T37RN: .WORD 100205      ;REREAD DATA (NEXT)
9994 102360 100605      T37WDR: .WORD 100605      ;REREAD DATA RETRY
9995 102362 102205      T37CON: .WORD 102205      ;WRITE CONTINUOUS
9996 102364 177777      .WORD 177777      ;END OF DATA
9997
9998
9999 102366 000000      T37CNT: .WORD 0          ;TAPE TIMER COUNTER STORAGE AREA
10000 102370 000000      T37CNU: .WORD 0          ;TAPE TIMER COUNTER STORAGE AREA
10001 102372 000000      T37DLY: .WORD 0          ;DELAY COUNTER
10002
10003      ;*
10004      ;LOCAL TEXT MESSAGES FOR TEST
10005      ;-
10006 102374      124      141      160      T37WNG: .ASCIZ 'Tape Position Incorrect After REREAD Previous (OPP=1)'
10007 102462      124      123      123      T37RDF: .ASCIZ 'TSSR Incorrect After READ DATA Command'
10008 102531      122      105      122      T37RRF: .ASCIZ 'REREAD Previous (Space Reverse, Read Forward) Command Failed'
10009 102626      120      117      123      T37SC: .ASCIZ 'POSITION (Space Command) Failed, TSSR Not Correct'
10010 102710      122      111      102      T37LOR: .ASCIZ 'RIB NOT SET AFTER READ REVERSE INTO BOT'
10011 102760      124      123      123      T37WDF: .ASCIZ 'TSSR Not Correct After Illegal Mode Bits Set'
10012 103035      111      154      154      T37LOQ: .ASCIZ 'Illegal Mode Bits, Failed To Set ILC Bit In XST0'
10013 103116      122      105      122      T37SSR: .ASCIZ 'REREAD COMMAND Not Accepted'
10014 103152      124      123      123      T37WDE: .ASCIZ 'TSSR Not Correct After WRITE DATA RETRY Command, At BOT'
10015 103241      124      141      160      T37BOT: .ASCIZ 'Tape Not At BOT After REWIND Command (BOT Not Set In XST0)'
10016 103334      127      122      111      T37TIM: .ASCIZ 'WRITE DATA RETRY'S Erase Tape Not Long Enough'
10017 103411      122      105      122      T37EOT: .ASCIZ 'REREAD DATA OVER EOT GAVE NO TAPE STATUS ALERT'
10018 103470      124      123      123      T37TM: .ASCIZ 'TSSR Not Correct After REREAD COMMAND Reject'
10019 103545      122      145      167      T37RWN: .ASCIZ 'Rewind (POSITION) Command Not Accepted'
10020 103614      122      101      115      T37RNC: .ASCIZ 'RAM Error, Correct Data Pattern Not In Ram'
10021 103667      124      123      123      T37AM3: .ASCIZ 'TSSR Init. Failed After REREAD COMMAND'
10022 103736      104      162      151      T37OFL: .ASCIZ 'Drive 7 Select Failed To Set "OFL" In TSSR'
10023 104011      124      123      123      T37WDD: .ASCIZ 'TSSR Not Correct After REREAD DATA Command, SWB Bit Set'
10024 104101      124      123      123      T37WDC: .ASCIZ 'TSSR Not Correct After REREAD DATA Command'
10025 104154      103      126      103      T37VCK: .ASCIZ 'CVC Set, Didn't Reset VCK In Message Buffer'
10026 104227      124      123      102      T37BA: .ASCIZ 'TSBA Not Correct After REREAD DATA Command'
10027 104302      127      122      111      T37WSS: .ASCIZ 'WRITE SUBSYSTEM MEMORY Command Not Accepted (RAM Read)'
10028 104371      122      145      141      T37LON: .ASCIZ 'Reading Long Record Failed To Set RLL Bit In XST0'
10029 104453      122      145      141      T37LOP: .ASCIZ 'Reading Long Record Failed To Set RLS Bit In XST0'
10030 104535      122      145      163      T37PBP: .ASCIZ 'Residual Byte Count Incorrect After Short Record Read'
10031 104623      122      145      141      T37TRL: .ASCIZ 'Reading Long Record Failed To Give Tape Status Alert'
10032 104711      127      122      111      T37NEF: .ASCIZ 'WRITE DATA RETRY, At First Record, Failed To Set RIB Bit XST3'
10033 105007      124      123      123      T37SCF: .ASCIZ 'TSSR Not Correct After SPACE RECORDS Command'
10034 105064      124      123      123      T37TSA: .ASCIZ 'TSSR Not Correct After WRITE DATA RETRY, Into BOT'
10035 105146      124      123      123      T37WRF: .ASCIZ 'TSSR Not Correct After WRITE DATA RETRY Command'
10036 105226      104      141      164      T37DTA: .ASCIZ 'Data Compare Error, Data Read From Tape Not Equal To Written'
10037 105323      106      165      156      TST37ID: .ASCIZ 'Function Timing'
10038
10039      .EVEN
10040
10041      ;*
10042      ;ROUTINE TO RESTORE COMMAND PACKET TO START-UP (DEFAULT) VALUES
10043      ;WRITE SUBSYSTEM MEMORY COMMAND
10044      ;
10045      ;-
10046 105344      T37REST:
10047 105344      SAVREG      ;SAVE THE REGISTERS
10048 105350      MOV          #T37PACKET,R1 ;START OF THE PACKET
10049 105354      MOV          #100004,(R1)  ;WRITE SUBSYSTEM MEM. WITH ACK,

```



## TEST 9: FUNCTION TIMING

```

10050 105360 012721 102230      MOV    #T37DATA,(R1)+      ;ADDRESS OF CHARAISTICS DATA BLOCK
10051 105364 005021             CLR    (R1)+              ;EXTENDED ADDRESS
10052 105366 012721 000012      MOV    #10,(R1)+         ;SIZE OF DATA BLOCK IN BYTES
10053 105372 012721 102242      MOV    #T37BFR,(R1)+     ;ADDRESS OF MESSAGE BUFFER
10054 105376 005021             CLR    (R1)+              ;
10055 105400 012721 000024      MOV    #20,(R1)+         ;LENGTH OF MESSAGE BUFFER
10056 105404 005021             CLR    (R1)+              ;
10057 105406 012711 000000      MOV    #0,(R1)           ;SELECT DRIVE ZERO
10058 105412 012702 000030      MOV    #24,R2            ;NUMBER OF LOCATIONS TO BE CLEARED
10059 105416 012762 177777 102242 64$: MOV    #177777,T37BFR(R2) ;ALL ONES TO MESSAGE BUFFER
10060 105424 005742             TST    -(R2)              ;NEXT LOCATION
10061 105426 022702 000000      CMP    #0,R2             ;AT END OF LOOP YET
10062 105432 001371             BNE    64$                ;KEEP GOING UNTIL DONE
10063 105434 000207             RTS    PC                 ;RETURN
10064
10065 105436             T37RT2:
10066 105436             SAVREG                    ;SAVE THE REGISTERS
10067 105442 012701 102330      MOV    #T37PK2,R1        ;START OF THE PACKET
10068 105446 012721 100006      MOV    #100006,(R1)+     ;WRITE SUBSYSTEM MEM. WITH ACK,
10069 105452 012721 102350      MOV    #T37BF2,(R1)+     ;ADDRESS OF DATA BLOCK
10070 105456 005021             CLR    (R1)+              ;EXTENDED ADDRESS
10071 105460 012721 000006      MOV    #6,(R1)+         ;SIZE OF DATA BLOCK IN BYTES
10072 105464 005021             CLR    (R1)+              ;
10073 105466 012701 102350      MOV    #T37BF2,R1        ;POINT TO DATA SEL AREA
10074 105472 005021             CLR    (R1)+              ;
10075 105474 005011             CLR    (R1)              ;
10076 105476 000207             RTS    PC                 ;RETURN
10077 105500             T37RT3:
10078 105500             SAVREG                    ;SAVE REGISTERS
10079 105504 012701 102340      MOV    #T37PK3,R1        ;SET UP POINTER ADDRESS
10080 105510 005021             CLR    (R1)+              ;COMMAND SPACE
10081 105512 005021             CLR    (R1)+              ;ADDRESS OF DATA BLOCK
10082 105514 005021             CLR    (R1)+              ;EXTENDED ADDRESS
10083 105516 005011             CLR    (R1)              ;SIZE OF DATA TRANSFER BLOCK
10084 105520 000207             RTS    PC                 ;RETURN
10085 105522             ENDTST
10086 105524             L10073: TRAP    C#ETST
10087
10093
10098
10104
10105 105524             ENDMOD    TSV6
10106 105524             .TITLE    TSV6 - PARAMETER CODING
10107
10108
10109
10110             TSV6::
10111             .SBTTL    HARDWARE PARAMETER CODING SECTION
10112
10113             ;**
10114             ; THE HARDWARE PARAMETER CODING SECTION CONTAINS MACROS
10115             ; THAT ARE USED BY THE SUPERVISOR TO BUILD P-TABLES. THE
10116             ; MACROS ARE NOT EXECUTED AS MACHINE INSTRUCTIONS BUT ARE
10117             ; INTERPRETED BY THE SUPERVISOR AS DATA STRUCTURES. THE
10118             ; MACROS ALLOW THE SUPERVISOR TO ESTABLISH COMMUNICATIONS
10119             ; WITH THE OPERATOR.
10120             ;--
10121             BGNHRD

```



HARDWARE PARAMETER CODING SECTION

```

105524 000010          .WORD L10075-L#HARD/2
105526          L#HARD::
10118
10119 105526          GPRMA  HPM1,0,0,160010,177776,YES      ;GET TSBA/TSDB REGISTER ADDRESS.
105526 000031          .WORD  T#CODE
105530 105546          .WORD  HPM1
105532 160010          .WORD  T#LOLIM
105534 177776          .WORD  T#HILIM
10120 105536          GPRMA  HPM2,2,0,0,776,YES      ;GET VECTOR ADDRESS.
105536 001031          .WORD  T#CODE
105540 105602          .WORD  HPM2
105542 000000          .WORD  T#LOLIM
105544 000776          .WORD  T#HILIM
10121
10122 105546          ;GPRMD HPM3,4,0,340,0,7,YES      ;GET INTERRUPT PRIORITY.
ENDHRD
.EVEN
105546          L10075:
10123 105546          104      105      126  HPM1:  .ASCIZ  'DEVICE ADDRESS (TSBA/TSDB) '
10124 105602          111      116      124  HPM2:  .ASCIZ  'INTERRUPT VECTOR '
10125 105626          111      116      124  HPM3:  .ASCIZ  'INTERRUPT PRIORITY '
10126          .EVEN

```

SOFTWARE PARAMETER CODING SECTION

```

10128                                     .SBTTL SOFTWARE PARAMETER CODING SECTION
10129
10130
10131                                     ;**
10132                                     ; THE SOFTWARE PARAMETER CODING SECTION CONTAINS MACROS
10133                                     ; THAT ARE USED BY THE SUPERVISOR TO BUILD P-TABLES. THE
10134                                     ; MACROS ARE NOT EXECUTED AS MACHINE INSTRUCTIONS BUT ARE
10135                                     ; INTERPRETED BY THE SUPERVISOR AS DATA STRUCTURES. THE
10136                                     ; MACROS ALLOW THE SUPERVISOR TO ESTABLISH COMMUNICATIONS
10137                                     ; WITH THE OPERATOR.
10138                                     ;--
10138 105656                                     BGNSFT
10139 105656 000003                             .WORD L10076-L$SOFT/2
10140 105660
10141                                     L$SOFT::
10142                                     ; GPRML SPM1,0,-1,YES ; GET TRANSPORT TEST FLAG.
10143 105660 001130                             ; GPRML SPM4,2,-1,YES ; GET ITERATION CONTROL.
10144 105662 105716                             .WORD T$CODE
10145 105664 177777                             .WORD SPM4
10146                                     .WORD -1
10147                                     ; GPRMD SPM6,4,D,7777,0,7777,YES ; GET LOCAL ERROR LIMIT
10148                                     ; GPRMD SPM7,6,D,7777,0,7777,YES ; GET GLOBAL ERROR LIMIT
10149                                     ENDSFT
10150                                     .EVEN
10151                                     L10076:
10152 10145 105666 105 116 101 SPM1: .ASCIZ 'ENABLE TRANSPORT TESTS '
10153 10146 105716 111 116 110 SPM4: .ASCIZ 'INHIBIT ITERATIONS '
10154 10147 105746 120 105 122 SPM6: .ASCIZ 'PER TEST ERROR LIMIT '
10155 10148 105776 120 105 122 SPM7: .ASCIZ 'PER UNIT ERROR LIMIT '
10156                                     .SBTTL PATCH AREA
10157
10158                                     ;
10159                                     ; FINALLY A GENEROUS PATCH AREA.
10160                                     ;
10161                                     ; AND AN ADJUSTMENT TO ACCOUNT FOR THE "LASTAD BIT7" HACK
10162                                     ; DESCRIBED IN "SUPPRG.MEM" (FOR REV C).
10163                                     ;
10164                                     PATCH::
10165                                     .BLKW 32.
10166                                     .=.!377*1
10167 106400 106400 LASTAD ;SET LAST USED ADDRESS.
10168 106400 000000 .EVEN
10169 106402 000000 .WORD 0
10170 106404 .WORD 0
10171 L$LAST::
10172 10166 106404 ENDMOD
10173 10167 000001 .END

```



## Symbol table

ADDSSR	012236	G	C#AU	=	000052	DEVDR0	023412	FRESIZ	003122	G	INTFLA	016255						
ADR	=	000020	G	C#AUTO	=	000061	DEVNRD	023331	FUSI	004115	INTMAS	016254						
AMBTSS	006715		C#BRK	=	000022	DEVNXR	023247	F#AU	=	000015	INTR	016326	G					
ASSEMB	=	000010	C#BSEG	=	000004	DEVONL	023177	F#AUTO	=	000020	INTREC	002216	G					
A1716	=	000003	C#BSUB	=	000002	DEVSUM	023142	F#BGN	=	000040	INTVEC	016256						
BADDAT	003152	G	C#CEFG	=	000045	DFPTBL	002150	F#CLEA	=	000007	INTX	004276						
BADSSR	016010	G	C#CLCK	=	000062	DIAGMC	=	000000	F#DU	=	000016	IOKCKI	=	000200				
BDVPCR	=	177520	G	C#CLEA	=	000012	DICED	=	000001	F#END	=	000041	IOKSTP	=	000001			
BENBSW	002224	G	C#CLOS	=	000035	DSBINT	016314	F#HARD	=	000004	IPRI	002204	G					
BIE	=	040000	C#CLP1	=	000006	DUAD12	004641	F#HW	=	000013	ISR	=	000100	G				
BIT0	=	000001	G	C#CVEC	=	000036	DUFLG	003106	F#INIT	=	000006	IVEC	=	002202	G			
BIT00	=	000001	G	C#DCLN	=	000044	DUMMY	003056	F#JMP	=	000050	IXE	=	004000	G			
BIT01	=	000002	G	C#DODU	=	000051	EF.CON	=	000036	G	F#MOD	=	000000	I#AU	=	000041		
BIT02	=	000004	G	C#DRPT	=	000024	EF.NEW	=	000035	G	F#MSG	=	000011	I#AUTO	=	000041		
BIT03	=	000010	G	C#DU	=	000053	EF.PWR	=	000034	G	F#PROT	=	000021	I#CLN	=	000041		
BIT04	=	000020	G	C#EDIT	=	000003	EF.RES	=	000037	G	F#PWR	=	000017	I#DU	=	000041		
BIT05	=	000040	G	C#ERDF	=	000055	EF.STA	=	000040	G	F#RPT	=	000012	I#HRD	=	000041		
BIT06	=	000100	G	C#ERHR	=	000056	EMAXDU	017107	F#SEG	=	000003	I#INIT	=	000041				
BIT07	=	000200	G	C#ERRO	=	000060	EN	=	000000	F#SOFT	=	000005	I#MOD	=	000041			
BIT08	=	000400	G	C#ERSF	=	000054	ENAIN	016262	F#SRV	=	000010	I#MSG	=	000041				
BIT09	=	001000	G	C#ERSO	=	000057	ENVIRN	020740	F#SUB	=	000002	I#PROT	=	000040				
BIT1	=	000002	G	C#ESCA	=	000010	EPRTSW	002172	F#SW	=	000014	I#PTAB	=	000041				
BIT10	=	002000	G	C#ESEG	=	000005	EPRT1	006356	F#TEST	=	000001	I#PMR	=	000041				
BIT11	=	004000	G	C#ESUB	=	000003	EPRT2	006415	GDDAT	003154	G	I#RPT	=	000041				
BIT12	=	010000	G	C#ETST	=	000001	ERCM	012043	GERRMA	002166	G	I#SEG	=	000041				
BIT13	=	020000	G	C#EXIT	=	000032	ERRHI	002232	GETPAT	020304	G	I#SETU	=	000041				
BIT14	=	040000	G	C#GETB	=	000026	ERRK	017066	GETSEL	020366	G	I#SFT	=	000041				
BIT15	=	100000	G	C#GETW	=	000027	ERRLO	002234	G#CNT0	=	000200	I#SRV	=	000041				
BIT2	=	000004	G	C#GMAN	=	000043	ERRNO	=	001620	G#DELM	=	000372	I#SUB	=	000041			
BIT3	=	000010	G	C#GPHR	=	000042	ERRVEC	=	000004	G	G#DISP	=	000003	I#TST	=	000041		
BIT4	=	000020	G	C#GPLO	=	000030	ERTABE	003372	G#EXCP	=	000400	J#JMP	=	000167				
BIT5	=	000040	G	C#GPRI	=	000040	ERTABL	003172	G#HILI	=	000002	KIPAR0	=	172340				
BIT6	=	000100	G	C#INIT	=	000011	ESUM	017070	G#LOLI	=	000001	KIPAR1	=	172342				
BIT7	=	000200	G	C#INLP	=	000020	EVL	=	000004	G	G#NO	=	000000	KIPAR2	=	172344		
BIT8	=	000400	G	C#MANI	=	000050	EXBCNT	=	000010	G#OFFS	=	000400	KIPAR3	=	172346			
BIT9	=	001000	G	C#MEM	=	000031	EXPBRE	015612	G#OF SI	=	000376	KIPAR4	=	172350				
BOE	=	000400	G	C#MSG	=	000023	EXPD	002226	G#PRMA	=	000001	KIPAR5	=	172352				
BRINIT	004455		C#OPEN	=	000034	EXPGOT	004531	G#PRMD	=	000002	KIPAR6	=	172354					
BSELO	=	000000	C#PNTB	=	000014	EXPGT2	004565	G#PRML	=	000000	KIPAR7	=	172356					
BSEL1	=	000001	C#PNTF	=	000017	EXPMSG	002316	G#RADA	=	000140	KIPDR0	=	172300					
CHKAMB	016154		C#PNTS	=	000016	EXPREC	015604	G#RADB	=	000000	KIPDR1	=	172302					
CHKMAN	020610	G	C#PNTX	=	000015	EXTA	005770	G#RADD	=	000040	KIPDR2	=	172304					
CHKTSS	016446		C#QIO	=	000377	EXTEND	005766	G#RADL	=	000120	KIPDR3	=	172306					
CKDROP	017312		C#RDBU	=	000007	EXTFEA	002220	G#RADO	=	000020	KIPDR4	=	172310					
CKEMAX	017212		C#REFG	=	000047	E#END	=	002100	G#XFER	=	000004	KIPDR5	=	172312				
CKMSG	011470	G	C#RESE	=	000033	E#LOAD	=	000035	G#YES	=	000010	KIPDR6	=	172314				
CKMSG2	011610	G	C#REVI	=	000003	FATERR	=	000060	HIADDR	=	001400	KIPDR7	=	172316				
CKRAM	011224	G	C#RFLA	=	000021	FATFLG	002214	G	HOE	=	100000	KTENAB	003130	G				
CKRAM2	011334	G	C#RPT	=	000025	FERCH	012032	HPM1	105546	KTFLG	003126	G						
CNDPKT	021274	G	C#SEFG	=	000046	FIFEXP	012300	G	HPM2	105602	KTINIT	021120						
CMPMEM	017770		C#SPRI	=	000041	FIF1MS	012352		HPM3	105626	KTOFF	017404						
CONFIG	017360		C#SVEC	=	000037	FIF2MS	012421		IBE	=	010000	G	KTON	017366				
COUNT	002304	G	C#TPRI	=	000013	FILLME	017532		IDU	=	000040	G	LERRMA	002164	G			
CSRADD	002200	G	DATA	002306	G	FNOINT	004213		IER	=	020000	G	LISTAL	=	000001			
CTAB	003160	G	DATASC	020342		FORCER	002170	G	IFAU	004254	LOE	=	040000	G				
CTABE	003172	G	DEBUGM	011742		FREE	003120	G	INCRK	017154	LOOPCN	002210	G					
CTABM	003160	G	DEVcnt	002212	G	FREEHI	003124		INTCPC	016260	LOOPCO	013236						



## Symbol table

LOOPFL	003156	G	L10002	005764	L10074	102162	04GNSW=	000001	PUNIT	022320
LOT	000010	G	L10003	012154	L10075	105546	04POIN=	000001	PW.D11=	000021
L\$ACP	002110	G	L10004	012172	L10076	105666	04SETU=	000000	PW.D13=	000022
L\$APT	002036	G	L10005	012210	MEMADD	014064	PASRPT	022070	PW.D22=	000020
L\$AU	022366	G	L10006	012216	MEMCK	021312	PATCH	106026	PW.NOP=	000000
L\$AUT	002070	G	L10007	012234	MEMASC	020557	PATDAT	020340	PW.NO1=	000023
L\$AUTO	022572	G	L10010	012252	MENERR	020504	PC.ERA=	002400	PW.RDE=	000024
L\$CCP	002106	G	L10011	012276	MENRES	020606	PC.IER=	002000	PW.RDR=	000001
L\$CLEA	022652	G	L10012	012350	MMVEC =	000250	PC.NOO=	001000	PW.RDS=	000005
L\$CO	002032	G	L10013	012520	MSA.FR=	000006	PC.REL=	000000	PW.RFI=	000003
L\$DEPO	002011	G	L10014	013234	MSA.NO=	000000	PC.REW=	000400	PW.WCT=	000006
L\$DESC	003404	G	L10015	014062	MSA.NR=	000004	PKBCNT=	000006	PW.WFI=	000004
L\$DESP	002076	G	L10016	014104	MSA.VO=	000002	PKHI =	000004	PW.WFM=	000007
L\$DEVP	002060	G	L10017	015610	MSGEXP	012254	PKLOW =	000002	PW.WMI=	000010
L\$DISP	002124	G	L10020	015616	MSGLOO	013174	PKTADD	007634	PW.WNP=	000011
L\$DLY	002116	G	L10021	015624	MSGSTA	012460	PKTFRM	007576	PW.WTR=	000002
L\$DTP	002040	G	L10022	015636	MSGSUB	014052	PKTGET	012174	P.ACK =	100000
L\$DTYP	002034	G	L10023	015660	MS.ATT=	000006	PKTMES	012220	P.CMD =	000037
L\$DU	022464	G	L10024	015706	MS.EXT=	000200	PKTRAM	004743	P.CONT=	000012
L\$DUT	002072	G	L10025	016046	MS.RSD=	000001	PKTSSR	012156	P.CVC =	040000
L\$DVTY	003376	G	L10026	016356	MS.RSF=	000020	PNT =	001000	P.FMT =	000140
L\$EF	002052	G	L10030	022316	MS.RST=	000010	PRAMPK	014106	P.FORM=	000011
L\$ENVI	002044	G	L10031	022462	M8186	005552	PRASC	014633	P.GETS=	000017
L\$ETP	002102	G	L10032	022570	M8189	005643	PRBEXP	015600	P.IE =	000200
L\$EXP1	002046	G	L10033	022650	NBA =	002000	PRBMSG	015446	P.INIT=	000013
L\$EXP4	002064	G	L10034	022676	NEWPAS	022024	PRBREC	015602	P.MODE=	007400
L\$EXP5	002066	G	L10035	023140	NODEV	003110	PRBTOT	015533	P.OPP =	020000
L\$HARD	105526	G	L10036	032262	NOINIT	004333	PRBYTE	015232	P.POSI=	000010
L\$HIME	002120	G	L10037	024124	NOINTR	004217	PRI =	002000	P.READ=	000001
L\$HPCP	002016	G	L10040	024646	NOITS	002162	PRIADD	010240	P.SWB =	010000
L\$HPTP	002022	G	L10041	025372	NOMAN	020644	PRIAO	010310	P.WRIT=	000005
L\$HW	002150	G	L10042	026214	NOMEM	005456	PRIBX0	007672	P.WRTC=	000004
L\$ICP	002104	G	L10043	041360	NP.IR =	000200	PRIEQU	010140	P.WRTS=	000006
L\$INIT	021572	G	L10044	033664	NP.L00=	000040	PRIPKT	007450	QVP	002176
L\$LADP	002026	G	L10045	035310	NP.OUT=	000100	PRIRAM	010146	RAMASC	014266
L\$LAST	106404	G	L10046	035704	NP.WRP=	000020	PRITAD	010354	RAMDAT	002236
L\$LOAD	002100	G	L10047	036370	NSI	004150	PRITSS	006022	RAMERR	015620
L\$LUN	002074	G	L10050	046716	NSINIT	004405	PRIT0	010436	RAMEXP	015640
L\$MREV	002050	G	L10051	042252	NUL	004525	PRIT1	010501	RAMFOR	010176
L\$NAME	002000	G	L10052	043064	NULCR	004526	PRIXOR	010022	RAMSIZ	002276
L\$PRIO	002042	G	L10053	052774	NXM =	004000	PRI00 =	000000	RAMTAD	015626
L\$PROT	021562	G	L10054	047572	NXMFLG	003132	PRI01 =	000040	RCVHIA	002300
L\$PRT	002112	G	L10055	050402	NXMHI	003136	PRI02 =	000100	RCVLOA	002302
L\$REPP	002062	G	L10056	051216	NXMLO	003134	PRI03 =	000140	RDERR	005204
L\$REV	002010	G	L10057	055770	NXMTST	021466	PRI04 =	000200	RECMG	002462
L\$RPT	022700	G	L10060	054436	NXR	003736	PRI05 =	000240	RECV	002230
L\$SOFT	105660	G	L10061	063342	NXRERR	005734	PRI06 =	000300	REGSAV	020250
L\$SPC	002056	G	L10062	060426	NXRX	003775	PRI07 =	000340	RETERR	005370
L\$SPCP	002020	G	L10063	073272	NXTU	022036	PRMESS	014352	REV	002222
L\$SPTP	002024	G	L10064	064434	OFL =	000100	PRMNO	002314	REWIND	011126
L\$STA	002030	G	L10065	065514	ONEFIL=	000000	PRMSGE	014662	RMCHBE=	000167
L\$SW	002160	G	L10066	066356	04APTS=	000000	PRMSG0	015042	RMCHEN=	000200
L\$TEST	002114	G	L10067	067260	04AU =	000001	PRMSG1	015107	RMMSGB=	000215
L\$TIML	002014	G	L10070	101076	04BGNR=	000001	PRMSG2	015145	RMMSGE=	000234
L\$UNIT	002012	G	L10071	074402	04BGNS=	000001	PROASC	014530	RMPKTB=	000201
L10000	002156		L10072	075500	04DU =	000001	PR1ASC	014575	RMPKTE=	000210
L10001	002170		L10073	105522	04ERRT=	000000	PST32W	003146	RMR =	010000



Symbol table

RWPACK	011220	S2.INR=	000020	T\$EXCP=	000000	T29CON	026412	T30BOT	037771
SC	= 100000	S2.OUT=	000040	T\$FLAG=	000040	T29DAT	026260	T30BS0	036560
SCE	= 020000	S2.UND=	000003	T\$GMAN=	000000	T29DLY	026430	T30BS1	036561
SCHERR	005276	TBLEND=	003056 G	T\$HILI=	000776	T29DSW	026270	T30CNT	036600
SCME	005011	TCOASC	006556	T\$LAST=	000001	T29DTA	027773	T30CNU	036602
SDELAY	010740	TCOCOD	006756	T\$LOLI=	000000	T29EOT	030061	T30DAT	036440
SELASC	020552	TEMP1	003112 G	T\$LSYM=	010000	T29LON	031155	T30DLY	036606
SELDAT=	000004	TEMP2	003114 G	T\$LTNO=	000011	T29LOO	023512	T30DSW	036450
SEL2	= 000002	TERCLS=	000016	T\$NEST=	177777	T29LOP	031237	T30DTA	041064
SETMAP	017426	TESTNO=	000011	T\$NSO =	000000	T29LOQ	027356	T30DTR	041020
SETU	022122	TEXASC	006515	T\$NS1 =	000005	T29LOR	027231	T30ETM	036446
SFFMSG	012212 G	TFCASC	006617	T\$NS2 =	000002	T29NEF	026560	T30FCN	036604
SFHERR	003703	TIMEXP	015662 G	T\$PTNU=	000000	T29NEQ	031475	T30IBT	036761
SFIERR	003650	TIMSGO	015710	T\$SAVL=	177777	T29OFL	026432	T30IBU	036610
SFIMSG	012144 G	TINERR	012131	T\$SEGL=	177777	T29OF7	030445	T30IMV	036566
SFPTBL	002160 G	TMPBFR	002626 G	T\$SUBN=	000001	T29PAC	026250	T30LOO	032310
SIFLAG	003150 G	TNAM	017014	T\$TAGL=	177777	T29PBP	031321	T30LOQ	037560
SIMSG	012076	TRANST	002160 G	T\$TAGN=	010077	T29PK2	026360	T30NEF	040526
SKIPT	003374	TSBA =	000000 G	T\$TEMP=	000000	T29PK3	026370	T30OFL	040237
SOFINI	016104 G	TSBAH =	000001 G	T\$TEST=	000011	T29RB	026372	T30PAC	036430
SPACE	010546 G	TSDB =	000000 G	T\$TSTM=	177777	T29RDF	026650	T30PK2	036540
SPM1	105666	TSDBH =	000001 G	T\$TSTS=	000001	T29RDG	031573	T30PK3	036550
SPM4	105716	TSFCOD	007316	T\$AU =	010031	T29RES	032076	T30PTB	037172
SPM6	105746	TSREJ =	000006	T\$AUT=	010033	T29RIB	031654	T30RB	036552
SPM7	105776	TSSDEF	006666	T\$CLE=	010034	T29RN	026406	T30RDF	037343
SRO	= 177572	TSSR =	000002 G	T\$DU =	010032	T29RNC	030304	T30RDG	037421
SR1	= 177574	TSSRBI	003500 G	T\$HAR=	010075	T29RRF	026717	T30RES	041202
SR2	= 177576	TSSRFO	006475	T\$HW =	010000	T29RRG	027033	T30RIB	036675
SR3	= 172516	TSSRH =	000003 G	T\$INI=	010030	T29RRN	031754	T3ORN	036566
SSR	= 000200	TSSX	004016	T\$MSG=	010025	T29RSZ	026426	T3ORRM	040605
STATCO	012522	TSTBLK	002746 G	T\$PRO=	010027	T29RT2	032170	T3ORRN	040663
SVCGBL=	000000	TSTCNT	002206 G	T\$RPT=	010035	T29RT3	032232	T3ORRP	040742
SVCINS=	000000	TSTEND	017030	T\$SOF=	010076	T29RWN	030235	T30RT2	041274
SVCSUB=	000001	TSTFLA	002310 G	T\$SRV=	010026	T29SC	027147	T30RT3	041336
SVCTAG=	000000	TSTLOO	016566 G	T\$SUB=	010074	T29SSR	027437	T3ORWN	040170
SVCTST=	000001	TSTPTR	002312 G	T\$SW =	010001	T29SZ	026376	T3OSKM	037044
S\$LSYM=	010000	TSTSET	016620 G	T\$TES=	010073	T29S2	026402	T30SSR	037641
SO.IDB=	000010	TST29I	032047	T1	023462 G	T29S3	026404	T30SZ	036556
SO.IFB=	000002	TST30I	041161	T1.1	023512	T29TM	030157	T30S2	036562
SO.IFP=	000001	TST31I	046473	T1.2	024142	T29TRL	031407	T30S3	036564
SO.ILD=	000020	TST32I	052570	T1.3	024664	T29VCK	030721	T30TM	040036
SO.ION=	000040	TST33I	055575	T1.4	025410	T29WB	026372	T30TMK	040444
SO.IRD=	000100	TST34I	063137	T2	032264 G	T29WDC	030627	T30TM2	040113
SO.IRW=	000004	TST35I	073063	T2.1	032310	T29WDD	030520	T30TPB	037263
SO.ISP=	000200	TST36I	100677	T2.2	033702	T29WDE	027512	T30VCK	040371
S1.ICE=	002000	TST37I	105323	T2.3	035326	T29WDF	027301	T30WB	036552
S1.IE0=	010000	TSV2	002000 G	T2.4	035722	T29WDR	026410	T30WDC	040312
S1.IFM=	001000	TSV3	002170 G	T23A	003140 G	T29WLK	027574	T30WDD	037120
S1.IHE=	000400	TSV4	021562 G	T23B	003142 G	T29WNG	026453	T30WDE	037712
S1.IID=	004000	TSV6	105524 G	T29AM3	030357	T29WRT	027661	T30WDF	037503
S1.I1R=	020000	TSV7B	023462 G	T29BA	030774	T29WSS	031066	T31AM3	044746
S1.I2R=	040000	TTIBFR=	177562 G	T29BF	026272	T3	041362 G	T31BA	045306
S1.PAR=	100000	TTICSR=	177560 G	T29BF2	026400	T3BFLG	003144 G	T31BFR	043142
S2.ATI=	000010	TTIVEC=	000060 G	T29BOT	027726	T3.1	041412	T31BF2	043250
S2.BTI=	000004	T\$ARGC=	000003	T29BS0	026400	T3.2	042270	T31BOT	044275
S2.DIM=	000200	T\$CODE=	001130	T29BS1	026401	T30BFR	036452	T31BS0	043250
S2.ILW=	000100	T\$ERRN=	001620	T29CNT	026424	T30BF2	036560	T31BS1	043251



## Symbol table

T31CNT	043266	T32CNU	051442	T34BA	062776	T35CON	067462	T36BS1	075671
T31CNU	043270	T32DAT	051270	T34BFR	060512	T35DAT	067330	T36CNT	075706
T31CON	043262	T32DLY	051444	T34BF2	060626	T35DLY	067472	T36CNU	075710
T31DAT	043130	T32DSW	051300	T34B0T	061164	T35DSW	067340	T36CON	075702
T31DLY	043272	T32ECF	052405	T34BS0	060626	T35DTA	072255	T36DAT	075550
T31DSW	043140	T32E0T	051541	T34BS1	060627	T35E0T	070440	T36DLY	075712
T31DTA	046376	T32ERA	051746	T34CNT	060622	T35INT	072531	T36DSW	075560
T31E0T	044470	T32L00	046750	T34CON	060640	T35LON	071420	T36DTA	100602
T31LON	045450	T320PI	052533	T34DAT	060500	T35L00	063374	T36E0T	076765
T31L00	041412	T32PAC	051260	T34DLY	060624	T35L0P	071502	T36LON	077745
T31L0P	045532	T32PK2	051370	T34DSW	060510	T35L0Q	070135	T36L00	073330
T31L0Q	044046	T32PK3	051400	T34E0T	062135	T35L0R	070010	T36L0P	100027
T31L0R	043721	T32RB	051402	T34ET	062046	T35M0T	072433	T36L0Q	076426
T31NEF	045770	T32RES	052630	T34ETC	061107	T35NEF	071740	T36L0R	076301
T31OFL	045015	T32RIB	052066	T34ETN	061401	T35NIN	073006	T36NAS	075714
T31PAC	043120	T32RT2	052722	T34ET0	060732	T35OFL	070765	T36NEF	100265
T31PBP	045614	T32RT3	052752	T34ETS	061460	T35OPM	072622	T36OFL	077312
T31PK2	043230	T32RWN	051630	T34ETZ	061552	T35PAC	067320	T36PAC	075540
T31PK3	043240	T32SCF	052164	T34ET2	061317	T35PBP	071564	T36PBP	100111
T31RB	043242	T32SZ	051406	T34L00	056022	T35PK2	067430	T36PK2	075650
T31RDE	043274	T32TSA	052241	T34OFL	062457	T35PK3	067440	T36PK3	075660
T31RDF	043473	T32WB	051402	T34PAC	060470	T35RB	067442	T36RB	075662
T31RES	046540	T32WDC	052466	T34PK2	060600	T35RDF	067562	T36RDF	076053
T31RN	043256	T33BFR	054522	T34PK3	060610	T35RES	073114	T36RES	100720
T31RNC	044673	T33BF2	054630	T34POS	060644	T35RN	067456	T36RN	075676
T31RRF	043542	T33B0T	055255	T34RB	060612	T35RNC	070643	T36RNC	077170
T31RT2	046632	T33BS0	054630	T34RES	063162	T35RRF	067631	T36RRF	076122
T31RT3	046674	T33BS1	054631	T34RNC	062336	T35RT2	073206	T36RT2	101012
T31RWN	044624	T33CNT	054646	T34RRE	061016	T35RT3	073250	T36RT3	101054
T31SC	043637	T33CNU	054650	T34RSZ	060620	T35RWE	072720	T36RWN	077121
T31SCF	046111	T33CON	054642	T34RT2	063254	T35RWN	070574	T36SC	076217
T31SSR	044127	T33DAT	054510	T34RT3	063316	T35SC	067726	T36SCF	100363
T31SZ	043246	T33DLY	054652	T34RWN	062267	T35SCF	072036	T36SSR	076507
T31S2	043252	T33DSW	054520	T34SSR	062013	T35SSR	072352	T36SZ	075666
T31S3	043254	T33DTA	055500	T34STM	061630	T35SZ	067446	T36S2	075672
T31TIM	044370	T33L00	053026	T34SZ	060616	T35S2	067452	T36S3	075674
T31TM	044547	T33PAC	054500	T34S2	060630	T35S3	067454	T36TIM	076710
T31TRL	045702	T33PK2	054610	T34S3	060632	T35TIM	070363	T36TM	077044
T31TSA	046166	T33PK3	054620	T34TM	062213	T35TM	070517	T36TRL	100177
T31VCK	045233	T33RB	054622	T34TMK	061713	T35TRL	071652	T36TSA	100440
T31WB	043242	T33RBP	054654	T34VCK	062723	T35TSA	072113	T36VCK	077530
T31WDC	045160	T33RES	055612	T34WB	060612	T35VCK	071203	T36WB	075662
T31WDD	045070	T33RN	054636	T34WD	060634	T35WB	067442	T36WDC	077455
T31WDE	044163	T33RT2	055704	T34WDC	062621	T35WDC	071130	T36WDD	077365
T31WDF	043771	T33RT3	055746	T34WDD	062532	T35WDD	071040	T36WDE	076543
T31WDR	043260	T33RWN	055350	T34WDR	060636	T35WDE	070216	T36WDF	076351
T31WNG	043421	T33SSR	055171	T34WSS	063050	T35WDF	070060	T36WDR	075700
T31WNH	043340	T33SZ	054626	T34WTH	061230	T35WDR	067460	T36WNG	075765
T31WRF	046273	T33S2	054632	T35AM3	070716	T35WNG	067474	T36WRF	100522
T31WSS	045361	T33S3	054634	T35BA	071256	T35WRF	072175	T36WSS	077656
T32AM3	051677	T33UNC	055012	T35BFR	067342	T35WSS	071331	T37AM3	103667
T32BA	052013	T33UND	055102	T35BF2	067450	T36AM3	077243	T37BA	104227
T32BFR	051302	T33WB	054622	T35B0T	070270	T36BA	077603	T37BFR	102242
T32B0E	052316	T33WDC	055417	T35BS0	067450	T36BFR	075562	T37BF2	102350
T32B0T	051446	T33WDR	054640	T35BS1	067451	T36BF2	075670	T37B0T	103241
T32CMD	051410	T33WPW	054732	T35CNT	067466	T36B0T	076615	T37BS0	102350
T32CNT	051440	T34AM3	062411	T35CNU	067470	T36BS0	075670	T37BS1	102351



Symbol table

T37CNT	102366	T37SSR	103116	T7.4	066374	WSMBK	021304	G	X\$OFFS=	000400
T37CNU	102370	T37SZ	102346	T8	073274	XFERAS	016050		X\$TRUE=	000020
T37CON	102362	T37S2	102352	T8.1	073330	XNXM	016506		X1.COR=	020000
T37DAT	102230	T37S3	102354	T8.2	074420	XORBFO	007754		X1.DLT=	100000
T37DLY	102372	T37TIM	103334	T9	101100	XORFOR	010072		X1.MBZ=	017375
T37DSW	102240	T37TM	103470	T9.1	101134	XST0	= 000006	G	X1.RBP=	000400
T37DTA	105226	T37TRL	104623	UAM	= 000200	XST1	= 000010	G	X1.SPA=	040000
T37EOT	103411	T37TSA	105064	UNITN	= 002174	XST2	= 000012	G	X1.UNC=	000002
T37LON	104371	T37VCK	104154	UNREC	= 000006	XST3	= 000014	G	X2.BUF=	000100
T37LOO	101134	T37WB	102342	USI	004121	XST4	= 000016	G	X2.EXT=	000200
T37LOP	104453	T37WDC	104101	WAITF	016360	XS0B0T=	000002		X2.OPM=	100000
T37LOQ	103035	T37WDD	104011	WC.IFA=	000200	XSOEOT=	000001		X2.RCE=	040000
T37LOR	102710	T37WDE	103152	WC.IFE=	000002	XSOIE	= 000040		X2.REV=	000077
T37NEF	104711	T37WDF	102760	WC.IGO=	000001	XSOILA=	000400		X2.SPA=	035400
T37OFL	103736	T37WDR	102360	WC.IRE=	000010	XSOILC=	001000		X2.UNI=	000007
T37PAC	102220	T37WNG	102374	WC.IRW=	000004	XSOLET=	020000		X2.WCF=	002000
T37PBP	104535	T37WRF	105146	WC.IOT=	000100	XSOMOT=	000200		X3.DCK=	000010
T37PK2	102330	T37WSS	104302	WC.IIT=	000040	XSONEF=	002000		X3.MBZ=	000006
T37PK3	102340	T4	046720	WC.ISR=	000020	XSOONL=	000100		X3.MDE=	177400
T37RB	102342	T4.1	046750	WF.IED=	000010	XSOPED=	000010		X3.OPI=	000100
T37RDF	102462	T4.2	047610	WF.IER=	000004	XSORLL=	010000		X3.REV=	000040
T37RES	105344	T4.3	050420	WF.IHI=	000200	XSORLS=	040000		X3.RIB=	000001
T37RN	102356	T5	052776	WF.IRE=	000040	XSOTMK=	100000		X3.SPA=	000200
T37RNC	103614	T5.1	053026	WF.IWF=	000020	XSOVCK=	000020		X3.TRF=	000020
T37RRF	102531	T6	055772	WF.IWR=	000100	XSOWLE=	004000		X4.HSP=	100000
T37RT2	105436	T6.1	056022	WF.I3R=	000002	XSOWLK=	000004		X4.MBZ=	017400
T37RT3	105500	T7	063344	WF.I4R=	000001	XXCOMM	003116	G	X4.RCE=	040000
T37RWN	103545	T7.1	063374	WRCHR	010742	X\$ALWA=	000000		X4.TSM=	020000
T37SC	102626	T7.2	064452	WRTERR	005111	X\$FALS=	000040		X4.WRC=	000377
T37SCF	105007	T7.3	065532	WRTMSG	005054					

. ABS. 106404 000 (RW,I,GBL,ABS,OVR)  
 000000 001 (RW,I,LCL,REL,CON)

Errors detected: 0

\*\*\* Assembler statistics

Work file reads: 308  
 Work file writes: 296  
 Size of work file: 31544 Words ( 124 Pages)  
 Size of core pool: 19684 Words ( 75 Pages)  
 Operating system: RSX-11M/PLUS (Under VAX/VMS)

Elapsed time: 00:07:32.75  
 CVTSDE,CVTSDE/-SP=SVC/PL,CVTSDE