

DMP-11, DMR-11,  
M8207

M8207

STATIC DIAG#1  
CZDMPCO

AH-E226C-MC  
FICHE 1 OF 2

OCT 1981  
COPYRIGHT © 79-81  
MADE IN USA



DMP-11, DMR-11,  
M8207

M8207 STATIC DIAG#1  
CZDMPCO

AH-E226C-MC  
FICHE 2 OF 2

OCT 1981  
COPYRIGHT © 79-81  
MADE IN USA



2197  
2198  
2199  
2200  
2201  
2202  
2203  
2204  
2205  
2206  
2207  
2208  
2209  
2210  
2211  
2212  
2213  
2214  
2215  
2216  
2217  
2218  
2219  
2220  
2221  
2222  
2223  
2224  
2225  
2226  
2227  
2228  
2229  
2230  
2231

.REM @

IDENTIFICATION

PRODUCT CODE: AC-E225C-MC  
PRODUCT NAME: CZDMP0 M8207 STATIC DIAG #1  
PRODUCT DATE: JULY 1981  
MAINTAINER: DIAGNOSTICS MERRIMACK  
AUTHOR: ED BADGER

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

NO RESPONSIBILITY IS ASSUMED FOR THE USE OR RELIABILITY OF SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL OR ITS AFFILIATED COMPANIES.

COPYRIGHT (C) 1979,1981 BY DIGITAL EQUIPMENT CORPORATION

THE FOLLOWING ARE TRADEMARKS OF DIGITAL EQUIPMENT CORPORATION:

DIGITAL	PDP	UNIBUS	MASSBUS
DEC	DECUS	DECTAPE	

2233  
2234  
2235  
2236  
2237  
2238  
2239  
2240  
2241  
2242  
2243  
2244  
2245  
2246  
2247  
2248  
2249  
2250  
2251  
2252  
2253  
2254  
2255  
2256  
2257  
2258  
2259  
2260  
2261  
2262  
2263  
2264  
2265  
2266  
2267  
2268  
2269  
2270  
2271  
2272  
2273  
2274  
2275  
2276  
2277  
2278  
2279  
2280  
2281  
2282  
2283

TABLE OF CONTENTS

- 1.0 INTRODUCTION
  - 1.1 PROGRAM ABSTRACT
  - 1.2 HARDWARE INTRODUCTION
- 2.0 HARDWARE REQUIREMENTS
- 3.0 PRELIMINARY PROGRAM REQUIREMENTS
- 4.0 GENERAL PROGRAM CONSIDERATIONS
  - 4.1 DIAGNOSTIC SUPERVISOR
  - 4.2 EXECUTION TIME
- 5.0 PROGRAM LOAD MEDIA
- 6.0 OPERATING INSTRUCTIONS
  - 6.1 LOADING AND STARTING PROCEDURES
    - 6.1.1 LOADING PROCEDURES
    - 6.1.2 STARTING PROCEDURES
    - 6.1.3 STEPS FOR QUICK AND SIMPLE EXECUTION
  - 6.2 INITIAL DIALOGUE
  - 6.3 PROGRAM OPTIONS
    - 6.3.1 START COMMAND
    - 6.3.2 RESTART COMMAND
    - 6.3.3 CONTINUE COMMAND
    - 6.3.4 PROCEED COMMAND
    - 6.3.5 ADD COMMAND
    - 6.3.6 DROP COMMAND
    - 6.3.7 PRINT COMMAND
    - 6.3.8 DISPLAY COMMAND
    - 6.3.9 FLAGS COMMAND
    - 6.3.10 ZFLAGS COMMAND
    - 6.3.11 CONTROL CHARACTERS
    - 6.3.12 HARDWARE PARAMETERS
    - 6.3.13 SOFTWARE PARAMETERS
    - 6.3.14 EXTENDED DISCUSSION OF P-TABLE DIALOGUE
- 7.0 TEST DESCRIPTIONS
- 8.0 ERROR INFORMATION
  - 8.1 ERROR REPORTING

2285  
2286  
2287  
2288  
2289  
2290  
2291  
2292  
2293  
2294  
2295  
2296  
2297  
2298  
2299  
2300  
2301  
2302  
2303  
2304  
2305  
2306  
2307  
2308  
2309  
2310  
2311  
2312  
2313  
2314  
2315  
2316  
2317  
2318  
2319  
2320  
2321  
2322  
2323  
2324  
2325  
2326  
2327  
2328  
2329  
2330  
2331  
2332  
2333  
2334  
2335  
2336  
2337  
2338  
2339  
2340

## 1.0 INTRODUCTION

### 1.1 PROGRAM ABSTRACT

THIS DIAGNOSTIC WAS DESIGNED TO TEST OUT THE M8200, M8204, OR M8207 MICROPROCESSOR. IT IS THE FIRST OF TWO DIAGNOSTICS FOR THESE OPTIONS.

THE PROGRAM WAS IMPLEMENTED USING THE DIAGNOSTIC SUPERVISOR.

THROUGH DIALOGUE WITH THE OPERATOR, THE PROGRAM WILL ALLOW MODIFICATION OF DEVICE PARAMETERS, SUCH AS UNIBUS ADDRESS, VECTOR ADDRESS, AND PROCESSOR TYPE.

### 1.2 HARDWARE INTRODUCTION

THE M820X MICROPROCESSOR USES AN EIGHT BIT DATA PATH WITH A SIXTEEN BIT INSTRUCTION MEMORY. THE INSTRUCTION MEMORY AND DATA MEMORY ARE TWO SEPARATE MEMORIES. THE MICROPROCESSOR IS DESIGNED FOR MOVING DATA AT HIGH RATES TO WORK AS A HIGH SPEED LINK BETWEEN PROCESSORS WHEN USED WITH A LINE UNIT. THE M8200 AND M8207 HAVE PROM INSTRUCTION MEMORIES. THE M8204 HAS WRITEABLE CONTROL STORE. THE MEMORY SIZES BETWEEN ALL THREE PROCESSORS VARY ALSO.

## 2.0 HARDWARE REQUIREMENTS

THE FOLLOWING HARDWARE IS REQUIRED TO RUN THE M8207 STATIC LOGIC TESTS:

PDP-11/04,05,10,20,30,34,35,40,45,50,60, OR 70  
16K MEMORY  
CONSOLE TERMINAL

## 3.0 PRELIMINARY PROGRAM REQUIREMENTS

THE PROCESSOR AND MEMORY SHOULD BE THOROUGHLY TESTED PREVIOUS TO RUNNING THIS DIAGNOSTIC.

## 4.0 GENERAL PROGRAM CONSIDERATIONS

### 4.1 DIAGNOSTIC SUPERVISOR

THIS PROGRAM IS COMPATIBLE WITH THE STANDALONE DIAGNOSTIC

CZDMPG MB207 STATIC DIAG. #1  
CZDMPG.P11 13-JUL-81 15:46

MACY11 30A(1052) 13-JUL-81 16:06 <sup>E 1</sup> PAGE 4-1  
PROGRAM DOCUMENT

SEQ 0004

2341

SUPERVISOR, AND MUST BE LOADED TO BE CO-RESIDENT WITH THE

2343  
2344  
2345  
2346  
2347  
2348  
2349  
2350  
2351  
2352  
2353  
2354  
2355  
2356  
2357  
2358  
2359  
2360  
2361  
2362  
2363  
2364  
2365  
2366  
2367  
2368  
2369  
2370  
2371  
2372  
2373  
2374  
2375  
2376  
2377  
2378  
2379  
2380  
2381  
2382  
2383  
2384  
2385  
2386  
2387  
2388  
2389  
2390  
2391  
2392  
2393  
2394  
2395  
2396  
2397

SUPERVISOR, OR BE PREVIOUSLY COMBINED WITH THE SUPERVISOR AND LOADED AS A SINGLE FILE. IN EITHER CASE, THE COMBINED PROGRAM WILL NOT EXCEED 16K OF MEMORY.

#### 4.2 EXECUTION TIME

THE TOTAL TIME REQUIRED TO RUN THE M8207 STATIC TESTS IS ABOUT 30 SECONDS PER PASS FOR EACH UNIT.

#### 4.3 XXDP+

THIS PROGRAM MAY BE LOADED UNDER XXDP+, AND MAY BE RUN IN DUMP MODE OR CHAIN MODE.

#### 4.4 ACT/SLIDE

THIS PROGRAM MAY BE LOADED UNDER ACT OR SLIDE AND MAY BE RUN IN DUMP MODE OR CHAIN MODE.

#### 4.5 APT

THIS PROGRAM MAY BE LOADED BY THE APT SYSTEM (INCLUDING APT-RD) AND RUN IN PROGRAM MODE OR SCRIPT MODE.

#### 4.6 MEMORY MANAGEMENT

MEMORY MANAGEMENT IS NOT UTILIZED IN THIS PROGRAM. IF IT IS INSTALLED, IT IS DISABLED BY THE PROGRAM.

#### 4.7 MEMORY PARITY OPTION

IF PARITY MEMORY IS INSTALLED, MEMORY PARITY TRAPS ARE DISABLED BY THE PROGRAM.

#### 4.8 ERROR LOGGING

THE NUMBER OF ERRORS WHICH HAVE OCCURRED ON EACH DEVICE UNDER TEST SINCE THE LAST START OR RESTART COMMAND IS KEPT IN AN ERROR LOG. THIS LOG MAY BE PRINTED BY USING THE 'PRINT' COMMAND (SEE SECTION 6.3.8).

#### 5.0 PROGRAM LOAD MEDIA

2399  
2400  
2401  
2402  
2403  
2404  
2405  
2406  
2407  
2408  
2409  
2410  
2411  
2412  
2413  
2414  
2415  
2416  
2417  
2418  
2419  
2420  
2421  
2422  
2423  
2424  
2425  
2426  
2427  
2428  
2429  
2430  
2431  
2432  
2433  
2434  
2435  
2436  
2437  
2438  
2439  
2440  
2441  
2442  
2443  
2444  
2445  
2446  
2447  
2448  
2449  
2450  
2451  
2452  
2453  
2454

THIS PROGRAM CAN BE LOADED FROM PAPER TAPE USING THE ABSOLUTE LOADER OR FROM ACT, SLIDE, OR APT SYSTEMS, OR FROM ANY MEDIA SUPPORTED BY XXDP+. WHEN USING THE PAPER TAPE ABSOLUTE LOADER, THE PROGRAM SHOULD BE LOADED FIRST, FOLLOWED BY THE DIAGNOSTIC SUPERVISOR. WHEN USING XXDP+, THE DIAGNOSTIC SUPERVISOR SHOULD BE LOADED FIRST, FOLLOWED BY THE DIAGNOSTIC PROGRAM.

## 6.0 OPERATING INSTRUCTIONS

### 6.1 LOADING AND STARTING PROCEDURES

#### 6.1.1 LOADING PROCEDURES

THIS PROGRAM MAY BE LOADED FROM PAPER TAPE USING THE ABSOLUTE LOADER. IT MAY ALSO BE LOADED FROM ANY XXDP+ LOAD MEDIA. WHEN LOADED UNDER XXDP+, THE DIAGNOSTIC SUPERVISOR WILL BE LOADED AUTOMATICALLY.

#### 6.1.2 STARTING PROCEDURES

THE PROGRAM STARTS AT LOCATION 200. USE STANDARD DEC PROCEDURES TO START THE PROGRAM.

#### 6.1.3 STEPS FOR QUICK AND SIMPLE EXECUTION

THE DIAGNOSTIC CAN BE EXECUTED STANDALONE UNDER XXDP+, WITHOUT READING THE REMAINDER OF THIS DOCUMENT, AS FOLLOWS:

- A) LOAD AND START DIAGNOSTIC USING RUN COMMAND
- B) RECEIVE DIAGNOSTIC SUPERVISOR IDENTIFICATION AND PROMPT (DR>)
- C) ENTER STA<CR>
- D) ANSWER HARDWARE AND SOFTWARE QUESTIONS
- E) GET END OF PASS MESSAGES OR ERROR MESSAGES
- F) TO END EXECUTION, ENTER CONTROL/C

### 6.2 INITIAL DIALOGUE

AFTER THE PROGRAM AND THE SUPERVISOR ARE LOADED AND THE PROGRAM IS STARTED THE FOLLOWING IDENTIFICATION IS TYPED:

DRS LOADED  
DIAG. RUN-TIME SERVICES  
CZDMP-C-0



CZDMP C M8207 STATIC DIAG. #1  
CZDMP C.P11 13-JUL-81 15:46

MACY11 30A(1052) 13-JUL-81 16:06 <sup>H 1</sup> PAGE 6-1  
PROGRAM DOCUMENT

SEQ 0007

2455

M8207 DIAG.#1 OF 2

2457  
2458  
2459  
2460  
2461  
2462  
2463  
2464  
2465  
2466  
2467  
2468  
2469  
2470  
2471  
2472  
2473  
2474  
2475  
2476  
2477  
2478  
2479  
2480  
2481  
2482  
2483  
2484  
2485  
2486  
2487  
2488  
2489  
2490  
2491  
2492  
2493  
2494  
2495  
2496  
2497  
2498  
2499  
2500  
2501  
2502  
2503  
2504  
2505  
2506  
2507  
2508  
2509  
2510  
2511  
2512

UNIT IS M8200,M8204,OR M8207  
DR>

THE OPERATOR THEN PROCEEDS BY TYPING ONE OR MORE OF THE  
COMMANDS DESCRIBED IN THE FOLLOWING SECTION 6.3. (FOR MORE  
DETAILED INFORMATION, REFER TO THE DIAGNOSTIC SUPERVISOR  
FUNCTIONAL SPECIFICATION).

### 6.3 PROGRAM OPTIONS

#### 6.3.1 START COMMAND

```
*****  
STA(RT)/TESTS:<TEST-LIST>/PASS:<PASS-CNT>/FLAGS:  
<FLAG-LIST>/EOP:<INCR>  
*****
```

##### 6.3.1.1 TESTS SWITCH (/TESTS:<TEST-LIST>)

<TEST-LIST> IS A SEQUENCE OF DECIMAL NUMBERS (1:2 ETC.) OR  
RANGES OF DECIMAL NUMBERS (1-5:8-10 ETC.) THAT SPECIFY THE  
TESTS TO BE EXECUTED. THE NUMBERS ARE SEPARATED BY COLONS.  
THE NUMBERS RANGE FROM 1 TO THE LARGEST TEST NUMBER IN THE  
DIAGNOSTIC. THEY MAY BE SPECIFIED IN ANY ORDER. TESTS WILL  
BE EXECUTED IN NUMERICAL ORDER REGARDLESS OF THE ORDER OF  
SPECIFICATION. THE DEFAULT IS TO EXECUTE ALL TESTS. ON  
THIS AND ALL SWITCHES, THE ANGLE BRACKETS <> ARE PUNCTUATION  
USED IN THE DEFINITION ONLY, AND ARE NOT TO BE TYPED BY THE  
OPERATOR. SEE EXAMPLE AT END OF 6.3.1.5.

##### 6.3.1.2 PASS SWITCH (/PASS:<PASS-CNT>)

<PASS-CNT> IS A DECIMAL NUMBER INDICATING THE DESIRED NUMBER  
OF PASSES. A PASS IS DEFINED AS THE EXECUTION OF THE FULL  
DIAGNOSTIC (ALL SELECTED TESTS) AGAINST ALL UNITS SUBMITTED.  
THE DEFAULT IS NON-ENDING EXECUTION. IN THIS CASE EXIT FROM  
THE PROGRAM IS ACCOMPLISHED EITHER BY TYPING A CONTROL/C OR  
BY OCCURANCE OF AN ERROR WITH THE HALT ON ERROR FLAG BEING  
SET. THE EXIT IS A RETURN TO COMMAND MODE. SEE EXAMPLE AT  
END OF 6.3.1.5.

##### 6.3.1.3 FLAGS SWITCH (/FLAGS:<FLAG-LIST>)

<FLAG-LIST> IS A SEQUENCE OF ELEMENTS OF THE FORM <FLAG>,  
<FLAG=1>, OR <FLAG=0>, SEPARATED BY COLONS, WHERE <FLAG> HAS  
ONE OF THE FOLLOWING VALUES:

2514  
2515  
2516  
2517  
2518  
2519  
2520  
2521  
2522  
2523  
2524  
2525  
2526  
2527  
2528  
2529  
2530  
2531  
2532  
2533  
2534  
2535  
2536  
2537  
2538  
2539  
2540  
2541  
2542  
2543  
2544  
2545  
2546  
2547  
2548  
2549  
2550  
2551  
2552  
2553  
2554  
2555  
2556  
2557  
2558  
2559  
2560  
2561  
2562  
2563  
2564  
2565  
2566  
2567  
2568  
2569

HOE HALT ON ERROR, CAUSING COMMAND MODE TO BE  
ENTERED WHEN AN ERROR IS ENCOUNTERED  
LOE LOOP ON ERROR, CAUSING THE DIAGNOSTIC TO LOOP  
CONTINUOUSLY WITHIN THE SMALLEST DEFINED BLOCK  
OF CODING (SEGMENT, SUBTEST, OR TEST) CONTAIN-  
ING THE ERROR  
IER INHIBIT ERROR REPORTING  
IBE INHIBIT BASIC ERROR REPORTS  
IXE INHIBIT EXTENDED ERROR REPORTS  
PRI DIRECT ALL MESSAGES TO A LINE PRINTER  
PNT PRINT NUMBER OF TEST BEING EXECUTED  
BOE BELL ON ERROR  
UAM RUN IN UNATTENDED MODE, BYPASSING MANUAL  
INTERVENTION TESTS  
ISR INHIBIT STATISTICAL REPORTS  
IDU INHIBIT DROPPING OF UNITS BY DIAGNOSTIC  
LOT LOOP ON TEST

THE FLAGS NAMED OR EQUATED TO 1 ARE SET, THOSE EQUATED TO 0  
ARE CLEARED. A FLAG NOT SPECIFIED IS CLEARED. IF THE FLAGS  
SWITCH IS NOT GIVEN ALL FLAGS ARE CLEARED. SEE EXAMPLE AT  
END OF 6.3.1.5.

#### 6.3.1.4 END OF PASS SWITCH (/EOP:<INCR>)

<INCR> IS A DECIMAL NUMBER INDICATING HOW OFTEN (IN TERMS OF  
PASSES) IT IS DESIRED THAT THE END OF PASS MESSAGE BE  
PRINTED. THE DEFAULT IS AT THE END OF EVERY PASS. SEE  
EXAMPLE AT END OF 6.3.1.5.

#### 6.3.1.5 EFFECT OF START COMMAND

THE EFFECT OF THE START COMMAND IS TO INITIATE THE HARDWARE  
PARAMETER DIALOGUE, THE SOFTWARE PARAMETER DIALOGUE, AND  
THEN THE DIAGNOSTIC TESTS THEMSELVES.

THE HARDWARE PARAMETER DIALOGUE COMMENCES WITH THE QUESTION  
"# UNITS?" TO WHICH THE OPERATOR REPLIES WITH A DECIMAL  
NUMBER N FROM 1 TO 16. THE TERM "UNIT" REFERS TO THE DEVICE  
TO WHICH THIS SERIES OF DIAGNOSTICS IS DEDICATED. FOLLOWING  
THIS ARE THE QUESTIONS WHEREBY THE P-TABLES THEMSELVES WILL  
BE BUILT. EACH P-TABLE IS A CORE-RESIDENT TABLE CONTAINING  
ALL THE HARDWARE INFORMATION FOR ONE UNIT. THE OPERATOR  
MUST SUPPLY N (NUMBER OF UNITS) VALUES FOR EACH QUESTION.  
HE MAY DO THIS BY GIVING ONE ANSWER TO EACH QUESTION (IN  
WHICH CASE THE SERIES OF QUESTIONS WILL BE POSED N TIMES) OR  
BY GIVING N VALUES, SEPARATED BY COMMAS, TO EACH QUESTION  
(SERIES WILL BE POSED ONCE). EACH QUESTION IS FOLLOWED BY  
THE RESPONSE RADIX (D FOR DECIMAL, B FOR BINARY, O FOR

CZDMPC M8207 STATIC DIAG. #1  
CZDMPC.P11 13-JUL-81 15:46

MACY11 30A(1052) 13-JUL-81 16:06 <sup>K 1</sup> PAGE 8-1  
PROGRAM DOCUMENT

SEQ 0010

2570

OCTAL, L FOR YES/NO) IN PARENTHESES AND THE DEFAULT VALUE

2572  
2573  
2574  
2575  
2576  
2577  
2578  
2579  
2580  
2581  
2582  
2583  
2584  
2585  
2586  
2587  
2588  
2589  
2590  
2591  
2592  
2593  
2594  
2595  
2596  
2597  
2598  
2599  
2600  
2601  
2602  
2603  
2604  
2605  
2606  
2607  
2608  
2609  
2610  
2611  
2612  
2613  
2614  
2615  
2616  
2617  
2618  
2619  
2620  
2621  
2622  
2623  
2624  
2625  
2626  
2627

AFTER THE PARENTHESES.

FOLLOWING THE HARDWARE QUESTIONS ARE THE SOFTWARE QUESTIONS TO BUILD THE SOFTWARE TABLES, WHICH DEFINE THE MODE (QUICK VERIFY ETC.) THAT THE DIAGNOSTIC WILL EXECUTE IN.

WHEN THE QUESTION '# UNITS?' IS ANSWERED, MEMORY STORAGE IS ALLOCATED FOR THE P-TABLES, AND IF THERE IS NOT ENOUGH TO ACCOMMODATE THEM THE MESSAGE 'TOO MANY UNITS' IS ISSUED. IN THIS CASE THE DIAGNOSTIC MUST BE EXECUTED MORE THAN ONCE TO TEST ALL UNITS.

EXAMPLE:

STA/TESTS:1:2-4:6:8-10/PASS:3/FLAGS:IER:HOE=1:UAM:LOE

THIS COMMAND WILL CAUSE THREE PASSES TO BE MADE, EACH PASS CONSISTING OF TESTS 1,2,3,4,6,8,9, AND 10 EXECUTED AGAINST ALL UNITS. THERE IS NO DIFFERENCE BETWEEN SAYING <FLAG> AND SAYING <FLAG=1>. THE NOTATION <FLAG=0> IS MEANINGFUL ONLY ON A COMMAND OTHER THAN START TO CLEAR A FLAG THAT WAS PREVIOUSLY SET. NOTE THAT ON ALL COMMANDS ONLY THE FIRST THREE LETTERS ARE SCANNED.

### 6.3.2 RESTART COMMAND

\*\*\*\*\*  
RES(TART)/TESTS:<TEST-LIST>/PASS:<PASS-CNT>/FLAGS:  
<FLAG-LIST>/UNITS:<UNIT-LIST>  
\*\*\*\*\*

#### 6.3.2.1 TESTS, PASS, AND FLAGS SWITCHES

<TEST-LIST>, <PASS-CNT>, AND <FLAG-LIST> ARE AS IN THE START COMMAND.

#### 6.3.2.2 UNITS SWITCH (/UNITS:<UNIT-LIST>)

<UNIT-LIST> IS A SEQUENCE OF DECIMAL NUMBERS (0,1 ETC.) OR RANGES OF DECIMAL NUMBERS (0-5, 8-10 ETC.) THAT SPECIFY THE UNITS TO BE TESTED. THE NUMBERS ARE SEPARATED BY COLONS. THE NUMBERS MAY RANGE FROM 0 THRU N-1 (N IS THE NUMBER OF UNITS SPECIFIED IN THE PREVIOUS START COMMAND). THE NUMBER INDICATES THE POSITION OF THE P-TABLE AS THE DATA WAS ENTERED DURING THE HARDWARE DIAGLOGUE. THE UNITS WHICH ARE SELECTED MUST NOT HAVE BEEN DROPPED BY THE DROP COMMAND. SEE THE DISCUSSION OF ADD AND DROP COMMANDS BELOW. DEFAULT IS TO TEST ALL UNITS WHICH HAVE NOT BEEN DROPPED BY A DROP

CZDMPC M8207 STATIC DIAG. #1  
CZDMPC.P11 13-JUL-81 15:46

MACY11 30A(1052) 13-JUL-81 16:06 M 1  
PROGRAM DOCUMENT PAGE 9-1

SEQ 0012

2628

COMMAND.

2630  
2631  
2632  
2633  
2634  
2635  
2636  
2637  
2638  
2639  
2640  
2641  
2642  
2643  
2644  
2645  
2646  
2647  
2648  
2649  
2650  
2651  
2652  
2653  
2654  
2655  
2656  
2657  
2658  
2659  
2660  
2661  
2662  
2663  
2664  
2665  
2666  
2667  
2668  
2669  
2670  
2671  
2672  
2673  
2674  
2675  
2676  
2677  
2678  
2679  
2680  
2681  
2682  
2683

### 6.3.2.3 EFFECT OF RESTART COMMAND

THE RESTART COMMAND DIFFERS FROM THE START COMMAND IN THAT THE P-TABLES FROM THE PREVIOUS START COMMAND (THERE MUST HAVE BEEN ONE) ARE USED, INSTEAD OF NEW ONES BEING BUILT. THE UNITS SWITCH GIVES THE ABILITY TO SELECT A SUBSET OF THESE. THE SOFTWARE DIALOGUE MAY OPTIONALLY BE REEXECUTED (OPERATOR WILL BE ASKED). THE COMMAND CAN BE USED AFTER COMMAND MODE HAS BEEN REENTERED IN ANY OF THE THREE NORMAL WAYS: A) THE REQUESTED NUMBER OF PASSES HAVE BEEN MADE B) AN ERROR WAS ENCOUNTERED WITH THE HALT ON ERROR FLAG SET C) A CONTROL/C WAS ENTERED BY THE OPERATOR.

### 6.3.3 CONTINUE COMMAND

```
*****  
CON(TINUE)/PASS:<PASS-CNT/FLAGS:<FLAG-LIST>  
*****
```

#### 6.3.3.1 PASS SWITCH (/PASS:<PASS-CNT>)

<PASS-CNT> IS SAME AS IN START COMMAND, BUT THE DEFAULT IS THE UNSATISFIED PASS-CNT FROM THE PREVIOUS START OR RESTART. IF NONE REMAINS, THE DEFAULT IS NON-ENDING EXECUTION.

#### 6.3.3.2 FLAG SWITCH (/FLAGS:<FLAG-LIST>)

<FLAG-LIST> IS SAME AS IN START COMMAND, BUT UNSPECIFIED FLAGS RETAIN THEIR CURRENT VALUE.

#### 6.3.3.3 EFFECT OF CONTINUE COMMAND

CONTINUE MUST FOLLOW A START OR RESTART, AND COMMAND MODE MUST HAVE BEEN ENTERED DUE TO A HALT ON ERROR OR A CONTROL/C. THE EFFECT OF THE COMMAND IS TO GO TO THE BEGINNING OF THE TEST THAT WAS BEING EXECUTED WHEN THE HALT OR CONTROL/C TOOK PLACE. SOFTWARE DIALOGUE MAY OPTIONALLY BE REEXECUTED. HARDWARE PARAMETERS MAY NOT BE CHANGED.

### 6.3.4 PROCEED COMMAND

```
*****  
PRO(CEED)/FLAGS:<FLAG-LIST>  
*****
```

2685  
2686  
2687  
2688  
2689  
2690  
2691  
2692  
2693  
2694  
2695  
2696  
2697  
2698  
2699  
2700  
2701  
2702  
2703  
2704  
2705  
2706  
2707  
2708  
2709  
2710  
2711  
2712  
2713  
2714  
2715  
2716  
2717  
2718  
2719  
2720  
2721  
2722  
2723  
2724  
2725  
2726  
2727  
2728  
2729  
2730  
2731  
2732  
2733  
2734  
2735  
2736  
2737  
2738  
2739

6.3.4.1 FLAGS SWITCH (/FLAGS:<FLAG-LIST>)

<FLAG-LIST> IS AS IN THE START COMMAND, BUT UNSPECIFIED  
FLAGS RETAIN THEIR CURRENT VALUE.

6.3.4.2 EFFECT OF PROCEED COMMAND

PROCEED MUST FOLLOW A START, RESTART, OR CONTINUE. COMMAND  
MODE MUST HAVE BEEN ENTERED VIA A HALT ON ERROR. THE EFFECT  
OF THE COMMAND IS TO BEGIN EXECUTION AT THE LOCATION  
FOLLOWING THE ERROR CALL. NEITHER HARDWARE NOR SOFTWARE  
PARAMETERS MAY BE ALTERED.

6.3.5 ADD COMMAND

\*\*\*\*\*  
ADD/UNITS:<UNIT-LIST>  
\*\*\*\*\*

6.3.5.1 UNITS SWITCH (/UNITS:<UNIT-LIST>)

<UNIT-LIST> IS AS IN THE RESTART COMMAND.

6.3.5.2 EFFECT OF ADD COMMAND

THE UNITS SPECIFIED ARE ADDED TO THE TEST SEQUENCE. EACH  
UNIT MUST HAVE A P-TABLE IN MEMORY DUE TO AN EARLIER  
HARDWARE DIALOGUE. THIS COMMAND MUST BE FOLLOWED BY A  
RESTART OR CONTINUE. THE UNITS SWITCH MUST BE SPECIFIED.  
THE ADD COMMAND IS MEANINGFUL ONLY FOR UNITS THAT WERE  
PREVIOUSLY DROPPED.

6.3.6 DROP COMMAND

\*\*\*\*\*  
DRO(P)/UNITS:<UNIT-LIST>  
\*\*\*\*\*

6.3.6.1 UNITS SWITCH (/UNITS:<UNIT-LIST>)

<UNIT-LIST> IS AS IN THE RESTART COMMAND.

6.3.6.2 EFFECT OF DROP COMMAND



2741  
2742  
2743  
2744  
2745  
2746  
2747  
2748  
2749  
2750  
2751  
2752  
2753  
2754  
2755  
2756  
2757  
2758  
2759  
2760  
2761  
2762  
2763  
2764  
2765  
2766  
2767  
2768  
2769  
2770  
2771  
2772  
2773  
2774  
2775  
2776  
2777  
2778  
2779  
2780  
2781  
2782  
2783  
2784  
2785  
2786  
2787  
2788  
2789  
2790  
2791  
2792  
2793  
2794  
2795

THE UNITS SPECIFIED WILL BE DROPPED FROM TESTING. THE UNITS WILL BE RESELECTED ONLY BY THE EXECUTION OF AN ADD OR START COMMAND. THE UNITS SWITCH MUST BE ENTERED. THIS COMMAND MUST BE FOLLOWED BY A RESTART OR A CONTINUE COMMAND.

### 6.3.7 PRINT COMMAND

\*\*\*\*\*  
PRI(NT)  
\*\*\*\*\*

#### 6.3.7.1 EFFECT OF PRINT COMMAND

THE TOTAL NUMBER OF ERRORS FOR EACH UNIT SINCE THE LAST START OR RESTART COMMAND ARE PRINTED. THE ISR (INHIBIT STATISTICAL REPORTING) FLAG IS CLEARED.

### 6.3.8 DISPLAY COMMAND

\*\*\*\*\*  
DIS(PLAY)/UNITS:<UNIT-LIST>  
\*\*\*\*\*

#### 6.3.8.1 UNITS SWITCH (/UNITS:<UNIT-LIST>)

<UNIT-LIST> IS AS IN THE RESTART COMMAND.

#### 6.3.8.2 EFFECT OF DISPLAY COMMAND

THE HARDWARE P-TABLES FOR ALL UNITS UNDER TEST ARE PRINTED OUT IN THE FORMAT IN WHICH THEY WERE ENTERED. ANY UNITS THAT WERE DROPPED BY THE OPERATOR 'DROP' COMMAND ARE SO DESIGNATED.

### 6.3.9 FLAGS COMMAND

\*\*\*\*\*  
FLA(GS)  
\*\*\*\*\*

#### 6.3.9.1 EFFECT OF FLAGS COMMAND

THE CURRENT SETTINGS OF ALL FLAGS ARE PRINTED.

2797  
2798  
2799  
2800  
2801  
2802  
2803  
2804  
2805  
2806  
2807  
2808  
2809  
2810  
2811  
2812  
2813  
2814  
2815  
2816  
2817  
2818  
2819  
2820  
2821  
2822  
2823  
2824  
2825  
2826  
2827  
2828  
2829  
2830  
2831  
2832  
2833  
2834  
2835  
2836  
2837  
2838  
2839  
2840  
2841  
2842  
2843  
2844  
2845  
2846  
2847  
2848  
2849  
2850

### 6.3.10 ZFLAGS COMMAND

\*\*\*\*\*  
ZFL(AGS)  
\*\*\*\*\*

#### 6.3.10.1 EFFECT OF ZFLAGS COMMAND

ALL FLAGS ARE CLEARED.

#### 6.3.11 CONTROL CHARACTERS

A CONTROL C (C) ENTERED DURING THE EXECUTION OF A DIAGNOSTIC CAUSES A RETURN TO COMMAND MODE.

A CONTROL Z (Z) ENTERED DURING ONE OF THE THREE OPERATOR DIALOGUES- INITAIL DIALOGUE (SEE 6.2), HARDWARE DIALOGUE (SEE 6.3.1.5), OR SOFTWARE DIALOGUE (SEE 6.3.1.5) CAUSES THE DEFAULTS TO BE TAKEN FOR THE REMAINDER OF THAT DIALOGUE.

A CONTROL O (O) ENTERED DURING THE EXECUTION OF A DIAGNOSTIC CAUSES ALL TELETYPE OUTPUT TO BE SURPRESSED FOR THE REMAINDER OF THE DIAGNOSTIC OR UNTIL ANOTHER O IS TYPED, WHICH RESTORES NORMAL TELETYPE OUTPUT.

#### 6.3.12 HARDWARE PARAMETERS

THE FOLLOWING 4 QUESTION WILL BE ASKED ON A START COMMAND. THE VALUE LOCATED TO THE LEFT OF THE QUESTICN MARK IS THE DEFAULT VALUE THAT WILL BE TAKEN ON A CARRIGE RETURN RESPONSE.

1. WHICH MICRO-PROCESSOR: (O) 7?

THE ALLOWABLE RESPONSES ARE 0 (M8200), 4 (M8204), AND THE DEFAULT 7 (M8207).

2. MICRO-PROCESSOR CSR ADDRESS: (O) 160170?

THIS IS THE ADDRESS AT WHICH THE CSR REGISTERS (SELO) RESIDE ON THE UNIBUS. THE ALLOWABLE RANGE IS 160000-177776 (OCTAL), AND THE DEFAULT VALUE IS 160170.

2852  
2853  
2854  
2855  
2856  
2857  
2858  
2859  
2860  
2861  
2862  
2863  
2864  
2865  
2866  
2867  
2868  
2869  
2870  
2871  
2872  
2873  
2874  
2875  
2876  
2877  
2878  
2879  
2880  
2881  
2882  
2883  
2884  
2885  
2886  
2887  
2888  
2889  
2890  
2891  
2892  
2893  
2894  
2895  
2896  
2897  
2898  
2899  
2900  
2901  
2902  
2903  
2904  
2905  
2906  
2907

3. MICRO-PROCESSOR VECTOR ADDRESS: (0) 300?

THIS IS THE ADDRESS OF THE INPUT INTERRUPT VECTOR FOR THIS DEVICE. THE ALLOWABLE RANGE IS 000-770 (OCTAL), AND THE DEFAULT VALUE IS 300.

4. MICRO-PROCESSOR PRIORITY LEVEL: (0) 5?

THIS IS THE CPU PRIORITY AT WHICH THE INTERRUPT HANDLERS OF THE DEVICE WILL BE EXECUTED. THE ALLOWABLE RANGE IS 0-7, AND THE DEFAULT VALUE IS 5.

#### 6.3.13 SOFTWARE PARAMETERS

NO SOFTWARE PARAMETER QUESTIONS ARE ASKED BY PART 1 OF THE STATIC LOGIC TESTS.

#### 6.3.14 EXTENDED DISCUSSION OF P-TABLE DIALOGUE

THE FULL CAPABILITY OF THE HARDWARE DIALOGUE IS REVEALED BY THE FOLLOWING DISCUSSION OF WHAT HAPPENS INTERNALLY.

AS SOON AS THE QUESTION "'# UNITS?'" IS ANSWERED (WITH THE NUMBER N, SAY) SPACE IN CORE IS ALLOCATED FOR N P-TABLES. ALL OF THE P-TABLES ARE OF THE SAME FORMAT, AND THERE IS A ONE-TO ONE CORRESPONDENCE BETWEEN THE HARDWARE PARAMETER QUESTIONS AND THE SLOTS IN THE P-TABLE FORMAT.

ON THE FIRST TRIP THRU THE QUESTIONS, ALL OF THE SLOTS IN ALL OF THE P-TABLES ARE FILLED. IF THE OPERATOR TYPES IN LESS THAN N EXPLICIT VALUES IN RESPONSE TO A PARTICULAR QUESTION, THESE VALUES ARE PLACED IN THE P-TABLES (ONE VALUE GOING INTO THE PROPER SLOT OF EACH P-TABLE BEGINNING WITH THE FIRST P-TABLE) UNTIL THE STRING OF VALUES IS EXHAUSTED. THE LAST VALUE IN THE STRING BECOMES THE NEW DEFAULT AND IS USED TO FILL THAT SLOT IN THE REMAINING P-TABLES.

ON SUBSEQUENT TRIPS THRU THE QUESTIONS, THE SAME PROCESS IS CARRIED OUT, EXCEPT THAT THE EARLIEST P-TABLE NOT TO HAVE RECEIVED AN EXPLICIT VALUE IN ANY OF ITS SLOTS NOW ASSUMES THE ROLE THAT TABLE NUMBER ONE PLAYED IN THE FIRST TRIP.

THE SERIES OF QUESTIONS IS REISSUED UNTIL AT LEAST ONE QUESTION HAS RECEIVED N EXPLICIT VALUES FROM THE OPERATOR.

IN GIVING A STRING OF VALUES, COMMAS WITHOUT INTERVENING VALUES MAY BE USED TO INDICATE A REPETITION OF THE LAST NAMED VALUE.

2909  
2910  
2911  
2912  
2913  
2914  
2915  
2916  
2917  
2918  
2919  
2920  
2921  
2922  
2923  
2924  
2925  
2926  
2927  
2928  
2929  
2930  
2931  
2932  
2933  
2934  
2935  
2936  
2937  
2938  
2939  
2940  
2941  
2942  
2943  
2944  
2945  
2946  
2947  
2948  
2949  
2950  
2951  
2952  
2953  
2954  
2955  
2956  
2957  
2958  
2959  
2960  
2961  
2962  
2963

A STRING OF VALUES MAY BE GIVEN AS A RANGE (6-10 FOR EXAMPLE). IF THE VALUES REPRESENT PURE NUMERICAL DATA, THIS SAMPLE RANGE TRANSLATES TO THE STRING 6,7,8,9,10 (AN INCREMENT OF 1). IF THE VALUES ARE ADDRESSES, THE SAMPLE RANGE TRANSLATES TO THE STRING 6,8,10 (AN INCREMENT OF 2).

NOW LET US SEE HOW WE COULD USE THESE CAPABILITIES TO CONSTRUCT A SET OF P-TABLES. ASSUME THAT WE HAVE 16 UNITS, AND THAT THERE ARE THREE HARDWARE PARAMETERS FOR EACH (THREE SLOTS IN THE P-TABLE, THREE HARDWARE QUESTIONS IN THE DIALOGUE). LET THE DESIRED VALUE FOR THE FIRST PARAMETER BE THE NUMBER 75 FOR ALL 16 TABLES. LET THE DESIRED VALUE FOR THE SECOND PARAMETER BE EQUAL TO THE UNIT NUMBER (0,1,2,...,15) EXCEPT FOR UNIT 12, WHICH SHOULD RECEIVE THE VALUE 11. LET THE DESIRED VALUE FOR THE THIRD PARAMETER BE THE NUMBER 76 FOR THE FIRST 7 UNITS AND THE NUMBER 77 FOR THE LAST 9 UNITS.

THE FOLLOWING DIALOGUE WOULD ACCOMPLISH THIS GOAL:

# UNITS (D) ? 16

UNIT 1

<QUESTION 1> ? 75

<QUESTION 2> ? 0-6

<QUESTION 3> ? 76

UNIT 21

<QUESTION 1> ?

<QUESTION 2> ? 7-11,,13-15

<QUESTION 3> ? 77

THE FIRST TIME THE SERIES IS ASKED, SLOT ONE RECEIVES A 75 IN ALL 16 TABLES. SLOT TWO RECEIVES THE VALUES 0,1,2,...,6 IN TABLES 0 THRU 6 AND A CONSTANT 6 IN TABLES 7 THRU 15. SLOT THREE RECEIVES A CONSTANT 76 IN ALL 16 TABLES.

THE SECOND TIME THRU THE SERIES, TABLES 7 THRU THE END ARE GOING TO BE AFFECTED (NOTE THAT THIS PIECE OF INFORMATION IS PRINTED OUT FOR THE THE OPERATOR IN THE FORM "UNIT XX" AT THE BEGINNING OF EACH SERIES). QUESTION 1 IS RESPONDED TO BY A <CR>, SO SLOT ONE STAYS AT CONSTANT 75 IN TABLES 7 THRU 15, SINCE NO NEW EXPLICIT VALUES ARE TYPED IN. SLOT TWO GETS THE VALUES 7,8,9,10,11 IN TABLES 7 THRU 11, AND GETS A 11 IN SLOT 12, AND GETS THE VALUES 13,14,15 IN TABLES 13 THRU 15. SLOT THREE GETS THE VALUE 77 IN TABLES 7 THRU 15.

THE DIALOGUE IS TERMINATED WHEN THE SOFTWARE RECOGNIZES THAT 16 EXPLICIT VALUES HAVE BEEN GIVEN FOR AT LEAST ONE QUESTION (NAMELY QUESTION 2).

2965  
2966  
2967  
2968  
2969  
2970  
2971  
2972  
2973  
2974  
2975  
2976  
2977  
2978  
2979  
2980  
2981  
2982  
2983  
2984  
2985  
2986  
2987  
2988  
2989  
2990  
2991  
2992  
2993  
2994  
2995  
2996  
2997  
2998  
2999  
3000  
3001  
3002  
3003  
3004  
3005  
3006  
3007  
3008  
3009  
3010  
3011  
3012  
3013  
3014  
3015  
3016  
3017  
3018  
3019  
3020

7.0 TEST DESCRIPTION

\*\*\*\*\* TEST 1 \*\*\*\*\*  
\*VERIFY THAT REFERENCING UNIBUS DEVICE REGISTERS  
\*DOES NOT CAUSE A TIMEOUT TRAP  
\*\*\*\*\*

\*\*\*\*\* TEST 2 \*\*\*\*\*  
\*VERIFY THAT RUN CAN BE CLEARED  
\*\*\*\*\*

\*\*\*\*\* TEST 3 \*\*\*\*\*  
\*UNIBUS REGISTER WORD DUAL ADDRESSING TEST  
\*LOAD ALL REGISTERS WITH INCREMENTING PATTERN  
\*READ BACK ALL REGISTERS TO VERIFY CORRECT ADDRESSING  
\*THE SEQUENCE:  
\* 1. CLEAR REGISTER  
\* 2. WRITE PATTERN  
\* 3. VERIFY PATTERN  
\* 4. DO ALL 4 REGISTERS  
\* 5. READ ALL BACK IF ERRORS,  
\* DUAL ADDRESS PROBLEM.  
\*  
\* 1 IN REG 0  
\* 2 IN REG 2  
\* 3 IN REG 4  
\* 4 IN REG 6  
\*\*\*\*\*

\*\*\*\*\* TEST 4 \*\*\*\*\*  
\*CONTROL STATUS REGISTER WRITE/READ TEST  
\*FLOAT A ONE THROUGH BSEL 0  
\*CLEAR BIT0, VERIFY BIT0 WAS CLEARED  
\*\*\*\*\*

\*\*\*\*\* TEST 5 \*\*\*\*\*  
\*CONTROL STATUS REGISTER WRITE/READ TEST  
\*SET BIT9, VERIFY BIT9 WAS SET  
\*CLEAR BIT9, VERIFY BIT9 WAS CLEARED  
\*\*\*\*\*

\*\*\*\*\* TEST 6 \*\*\*\*\*  
\*CONTROL STATUS REGISTER WRITE/READ TEST  
\*SET BIT11, VERIFY BIT11 WAS SET  
\*CLEAR BIT11, VERIFY BIT11 WAS CLEARED

CZDMP C M8207 STATIC DIAG. #1  
CZDMP C.P11 13-JUL-81 15:46

MACY11 30A(1052) 13-JUL-81 16:06 <sup>H 2</sup> PAGE 16-1  
PROGRAM DOCUMENT

SEQ 0020

3021

\*\*\*\*\*

3023  
3024  
3025  
3026  
3027  
3028  
3029  
3030  
3031  
3032  
3033  
3034  
3035  
3036  
3037  
3038  
3039  
3040  
3041  
3042  
3043  
3044  
3045  
3046  
3047  
3048  
3049  
3050  
3051  
3052  
3053  
3054  
3055  
3056  
3057  
3058  
3059  
3060  
3061  
3062  
3063  
3064  
3065  
3066  
3067  
3068  
3069  
3070  
3071  
3072  
3073  
3074  
3075  
3076  
3077  
3078

\*\*\*\*\* TEST 7 \*\*\*\*\*  
\*CONTROL STATUS REGISTER WRITE/READ TEST  
\*SET BIT12, VERIFY BIT12 WAS SET  
\*CLEAR BIT 12, VERIFY BIT 12 WAS CLEARED  
\*\*\*\*\*

\*\*\*\*\* TEST 8 \*\*\*\*\*  
\*CONTROL OUT REGISTER WRITE/READ TEST  
\*FLOAT A ONE THROUGH SEL2  
\*\*\*\*\*

\*\*\*\*\* TEST 9 \*\*\*\*\*  
\*PORT4 REGISTER WRITE/READ TEST  
\*FLOAT A ONE THROUGH PORT4 REGISTER  
\*FLOAT A ZERO THROUGH PORT4 REGISTER  
\*\*\*\*\*

\*\*\*\*\* TEST 10 \*\*\*\*\*  
\*PORT6 REGISTER WRITE/READ TEST  
\*FLOAT A ONE THROUGH PORT6 REGISTER  
\*FLOAT A ZERO THROUGH PORT6 REGISTER  
\*\*\*\*\*

\*\*\*\*\* TEST 11 \*\*\*\*\*  
\*UNIBUS REGISTER BYTE DUAL ADDRESSING TEST  
\*LOAD ALL REGISTERS WITH INCREMENTING PATTERN  
\*READ BACK ALL REGISTERS TO VERIFY CORRECT ADDRESSING  
\*\*\*\*\*

\*\*\*\*\* TEST 12 \*\*\*\*\*  
\*MAINTENANCE INSTRUCTION REGISTER TEST  
\*VERIFY THAT THE MAINT IR CAN BE WRITTEN TO ALL ZEROS'  
\*AND ALL ONES'. VERIFY THAT IS IS CLEARED ON A BUS RESET.  
\*\*\*\*\*

\*\*\*\*\* TEST 13 \*\*\*\*\*  
\*MICRO PROCESSOR TEST  
\*LOAD KMP06 WITH A MICRO-PROCESSOR INSTRUCTION, CLOCK IT  
\*VERIFY INSTRUCTION EXECUTED PROPERLY  
\*INSTRUCTION SHOULD MOVE IBUS\*4 TO IBUS\*5, IBUS\*4 IS ALL 1'S  
\*AND IBUS\*5 IS ALL 0'S. RESULT SHOULD BE ALL 1'S IN SEL4  
\*\*\*\*\*

CZDMPC M820/ SIATIC DIAG. #1  
CZDMPC.P11 13-JUL-81 15:46

MACY11 30A(1052) 13-JUL-81 16:06 J 2  
PROGRAM DOCUMENT PAGE 17-1

SEQ 0022

3079



3081  
3082  
3083  
3084  
3085  
3086  
3087  
3088  
3089  
3090  
3091  
3092  
3093  
3094  
3095  
3096  
3097  
3098  
3099  
3100  
3101  
3102  
3103  
3104  
3105  
3106  
3107  
3108  
3109  
3110  
3111  
3112  
3113  
3114  
3115  
3116  
3117  
3118  
3119  
3120  
3121  
3122  
3123  
3124  
3125  
3126  
3127  
3128  
3129  
3130  
3131  
3132  
3133  
3134  
3135  
3136

\*\*\*\*\* TEST 14 \*\*\*\*\*  
\*MICRO PROCESSOR IBUS\* REGISTER WRITE/READ TEST  
\*FLOAT A 1 THROUGH IBUS\* REGISTER 0  
\*FLOAT A 0 THROUGH IBUS\* REGISTER 0  
\*\*\*\*\*

\*\*\*\*\* TEST 15 \*\*\*\*\*  
\*MICRO PROCESSOR IBUS\* REGISTER WRITE/READ TEST  
\*FLOAT A 1 THROUGH IBUS\* REGISTER 2  
\*FLOAT A 0 THROUGH IBUS\* REGISTER 2  
\*\*\*\*\*

\*\*\*\*\* TEST 16 \*\*\*\*\*  
\*MICRO PROCESSOR IBUS\* REGISTER WRITE/READ TEST  
\*FLOAT A 1 THROUGH IBUS\* REGISTER 4  
\*FLOAT A 0 THROUGH IBUS\* REGISTER 4  
\*\*\*\*\*

\*\*\*\*\* TEST 17 \*\*\*\*\*  
\*MICRO PROCESSOR IBUS\* REGISTER WRITE/READ TEST  
\*FLOAT A 1 THROUGH IBUS\* REGISTER 5  
\*FLOAT A 0 THROUGH IBUS\* REGISTER 5  
\*\*\*\*\*

\*\*\*\*\* TEST 18 \*\*\*\*\*  
\*MICRO PROCESSOR IBUS\* REGISTER WRITE/READ TEST  
\*FLOAT A 1 THROUGH IBUS\* REGISTER 10  
\*FLOAT A 0 THROUGH IBUS\* REGISTER 10  
\*\*\*\*\*

\*\*\*\*\* TEST 19 \*\*\*\*\*  
\*MICRO PROCESSOR IBUS\* REGISTER WRITE/READ TEST  
\*FLOAT A 1 THROUGH IBUS\* REGISTER 11  
\*FLOAT A 0 THROUGH IBUS\* REGISTER 11  
\*\*\*\*\*

\*\*\*\*\* TEST 20 \*\*\*\*\*  
\*MICRO PROCESSOR IBUS REBISTER WRITE/READ TEST  
\*FLOAT A 1 THROUGH IBUS REGISTER 0  
\*FLOAT A 0 THROUGH IBUS REGISTER 0  
\*\*\*\*\*

\*\*\*\*\* TEST 21 \*\*\*\*\*  
\*MICRO PROCESSOR IBUS REGISTER WRITE/READ TEST

CZDMPC M8207 STATIC DIAG. #1  
CZDMPL P11 13-JUL-81 15:46

MACY11 30A(1052) 13-JUL-81 16:06 L 2 PAGE 18-1  
PROGRAM DOCUMENT

SEQ 0024

3137

\*FLOAT A 1 THROUGH IBUS REGISTER 1

3139  
3140  
3141  
3142  
3143  
3144  
3145  
3146  
3147  
3148  
3149  
3150  
3151  
3152  
3153  
3154  
3155  
3156  
3157  
3158  
3159  
3160  
3161  
3162  
3163  
3164  
3165  
3166  
3167  
3168  
3169  
3170  
3171  
3172  
3173  
3174  
3175  
3176  
3177  
3178  
3179  
3180  
3181  
3182  
3183  
3184  
3185  
3186  
3187  
3188  
3189  
3190  
3191  
3192  
3193  
3194

\*FLOAT A 0 THROUGH IBUS REGISTER 1  
\*\*\*\*\*

\*\*\*\*\* TEST 22 \*\*\*\*\*  
\*MICRO PROCESSOR IBUS REGISTER WRITE/READ TEST  
\*FLOAT A 1 THROUGH IBUS REGISTER 2  
\*FLOAT A 0 THROUGH IBUS REGISTER 2  
\*\*\*\*\*

\*\*\*\*\* TEST 23 \*\*\*\*\*  
\*MICRO PROCESSOR IBUS REGISTER WRITE/READ TEST  
\*FLOAT A 1 THROUGH IBUS REGISTER 3  
\*FLOAT A 0 THROUGH IBUS REGISTER 3  
\*\*\*\*\*

\*\*\*\*\* TEST 24 \*\*\*\*\*  
\*MICRO PROCESSOR IBUS REGISTER WRITE/READ TEST  
\*FLOAT A 1 THROUGH IBUS REGISTER 4  
\*FLOAT A 0 THROUGH IBUS REGISTER 4  
\*\*\*\*\*

\*\*\*\*\* TEST 25 \*\*\*\*\*  
\*MICRO PROCESSOR IBUS REGISTER WRITE/READ TEST  
\*FLOAT A 1 THROUGH IBUS REGISTER 5  
\*FLOAT A 0 THROUGH IBUS REGISTER 5  
\*\*\*\*\*

\*\*\*\*\* TEST 26 \*\*\*\*\*  
\*MICRO PROCESSOR IBUS REGISTER WRITE/READ TEST  
\*FLOAT A 1 THROUGH IBUS REGISTER 6  
\*FLOAT A 0 THROUGH IBUS REGISTER 6  
\*\*\*\*\*

\*\*\*\*\* TEST 27 \*\*\*\*\*  
\*MICRO PROCESSOR IBUS\* REGISTER WRITE/READ TEST  
\*FLOAT A 1 THROUGH IBUS\* REGISTER 7  
\*FLOAT A 0 THROUGH IBUS\* REGISTER 7  
\*\*\*\*\*

\*\*\*\*\* TEST 28 \*\*\*\*\*  
\*MICRO PROCESSOR IBUS DUAL ADDRESS TEST  
\*WRITE ALL IBUS REGISTERS WITH INCREMENTING PATTERN  
\*READ ALL IBUS REGISTERS TO VERIFY CORRECT ADDRESSING  
\*\*\*\*\*

CZDMPC M8207 STATIC DIAG. #1  
CZDMPC.P11 13-JUL-81 15:46

MACY11 30A(1052) 13-JUL-81 16:06 N 2  
PROGRAM DOCUMENT PAGE 19-1

SEQ 0026

3195

3197  
3198  
3199  
3200  
3201  
3202  
3203  
3204  
3205  
3206  
3207  
3208  
3209  
3210  
3211  
3212  
3213  
3214  
3215  
3216  
3217  
3218  
3219  
3220  
3221  
3222  
3223  
3224  
3225  
3226  
3227  
3228  
3229  
3230  
3231  
3232  
3233  
3234  
3235  
3236  
3237  
3238  
3239  
3240  
3241  
3242  
3243  
3244  
3245  
3246  
3247  
3248  
3249  
3250  
3251  
3252

\*\*\*\*\* TEST 29 \*\*\*\*\*  
\*MICRO PROCESSOR BR REGISTER TEST  
\*FLOAT A 1 THROUGH THE BR  
\*FLOAT A 0 THROUGH THE BR  
\*\*\*\*\*

\*\*\*\*\* TEST 30 \*\*\*\*\*  
\*SCRATCH PAD TEST  
\*FLOAT A 1 THROUGH EACH SCRATCH PAD LOCATION  
\*FLOAT A 0 THROUGH EACH SCRATCH PAD LOCATION  
\*\*\*\*\*

\*\*\*\*\* TEST 31 \*\*\*\*\*  
\*SCRATCH PAD DUAL ADDRESSING TEST  
\*WRITE AN INCREMENTING PATTERN IN ALL SP LOCATIONS  
\*READ ALL SP LOCATIONS TO VERIFY CORRECT ADDRESSING  
\*\*\*\*\*

\*\*\*\*\* TEST 32 \*\*\*\*\*  
\*INTERRUPT TEST  
\*TEST THAT DEVICE CAN INTERRUPT TO VECTOR A  
\*\*\*\*\*

\*\*\*\*\* TEST 33 \*\*\*\*\*  
\*INTERRUPT TEST  
\*TEST THAT DEVICE CAN INTERRUPT TO VECTOR B  
\*\*\*\*\*

\*\*\*\*\* TEST 34 \*\*\*\*\*  
\*PRIORITY INTERRUPT TEST  
\*SET PS TO ALL BR LEVELS EQUAL OR GREATER THAN  
\*THE M8200,4,7 LEVEL, VERIFY THAT M8200,4,7 DOES NOT INTERRUPT  
\*\*\*\*\*

\*\*\*\*\* TEST 35 \*\*\*\*\*  
\*PRIORITY INTERRUPT TESTS  
\*SET PS TO ALL BR LEVELS LESS THAN THE M8200,4,7 LEVEL  
\*VERIFY THAT ALL M8200,4,7 WILL INTERRUPT  
\*\*\*\*\*

\*\*\*\*\* TEST 36 \*\*\*\*\*  
\*NPR TEST  
\*TEST OF DAT0, 1 WORD FROM UPROC TO 11 MEMORY

CZDMPG MB207 STATIC DIAG. #1  
CZDMPG.P11 13-JUL-81 15:46

MACY11 30A(1052) 13-JUL-81 16:06 <sup>C 3</sup> PAGE 20-1  
PROGRAM DOCUMENT

SEQ 0028

3253

.....

3255  
3256  
3257  
3258  
3259  
3260  
3261  
3262  
3263  
3264  
3265  
3266  
3267  
3268  
3269  
3270  
3271  
3272  
3273  
3274  
3275  
3276  
3277  
3278  
3279  
3280  
3281  
3282  
3283  
3284  
3285  
3286  
3287  
3288  
3289  
3290  
3291  
3292  
3293  
3294  
3295  
3296  
3297  
3298  
3299  
3300  
3301  
3302  
3303  
3304  
3305  
3306  
3307  
3308  
3309  
3310

\*\*\*\*\* TEST 37 \*\*\*\*\*  
\*NPR TEST  
\*TEST OF DATI, 1 WORD FROM 11 MEMORY TO UPROC  
\*\*\*\*\*

\*\*\*\*\* TEST 38 \*\*\*\*\*  
\*NPR TEST  
\*TEST OF DATOB, 1 BYTE FROM UPROC TO 11 MEMORY  
\*\*\*\*\*

\*\*\*\*\* TEST 39 \*\*\*\*\*  
\*TEST OF EA BITS 16 AND 17  
\*DO A DATO TO AN ADDRESS USING OUT BA BITS 16 AND 17  
\*VERIFY CORRECT RESULTS  
\*\*\*\*\*

\*\*\*\*\* TEST 40 \*\*\*\*\*  
\*TEST OF EA BITS 16 AND 17  
\*DO A DATI USING IN BA BITS 16 AND 17  
\*VERIFY CORRECT RESULTS  
\*IN ORDER TO DO THIS TEST, WE WILL READ THE DATA FROM THE  
\*CONSOL TTY CSR IF ONE EXISTS  
\*IF NO COSOL TTY CSR AT ADDRESS 177560, THIS TEST  
\*WILL BE SKIPPED  
\*\*\*\*\*

\*\*\*\*\* TEST 41 \*\*\*\*\*  
\*NPR NON-EXISTENT MEMORY TEST  
\*DO A DATO TO A NON -EXISTENT ADDRESS  
\*VERIFY THAT THE NON-EXISTENT BIT SET IN IBUS REG 11  
\*\*\*\*\*

\*\*\*\*\* TEST 42 \*\*\*\*\*  
\*NPR NON-EXISTENT MEMORY TEST  
\*DO A DATI FROM A NON-EXISTENT ADDRESS  
\*VERIFY THAT THE NON-EXISTENT BIT SET IN IBUS REG 11  
\*\*\*\*\*

\*\*\*\*\* TEST 43 \*\*\*\*\*  
\*NPR TEST  
\*USING DATO, NPR A BINARY COUNT (0-377)  
\*FROM MICRO-PROCESSOR TO ALL AVAILABLE MEMORY  
\*\*\*\*\*

3311



3313  
3314  
3315  
3316  
3317  
3318  
3319  
3320  
3321  
3322  
3323  
3324  
3325  
3326  
3327  
3328  
3329  
3330  
3331  
3332  
3333  
3334  
3335  
3336  
3337  
3338  
3339  
3340  
3341  
3342  
3343  
3344  
3345  
3346  
3347  
3348  
3349  
3350  
3351  
3352  
3353  
3354  
3355  
3356  
3357  
3358  
3359  
3360  
3361  
3362  
3363  
3364  
3365  
3366  
3367  
3368

\*\*\*\*\* TEST 44 \*\*\*\*\*  
\*ALU C BIT TEST  
\*TEST THAT AN ADD OF 377 AND 377 WILL SET THE C BIT  
\*\*\*\*\*

\*\*\*\*\* TEST 45 \*\*\*\*\*  
\*ALU TEST  
\*TEST OF ALU FUNCTION SEL B WITH C BIT CLEARED  
\*ALU FUNCTION (B) CODE=11  
\*LOAD MAIN MEM AND SP WITH 8 WORDS OF DATA  
\*PERFORM THE FUNCTION, VERIFY THE RESULTS  
\*\*\*\*\*

\*\*\*\*\* TEST 46 \*\*\*\*\*  
\*ALU TEST  
\*TEST OF ALU FUNCTION SEL A WITH C BIT CLEARED  
\*ALU FUNCTION (A) CODE=10  
\*LOAD MAIN MEM AND SP WITH 8 WORDS OF DATA  
\*PERFORM THE FUNCTION, VERIFY THE RESULTS  
\*\*\*\*\*

\*\*\*\*\* TEST 47 \*\*\*\*\*  
\*ALU TEST  
\*TEST OF ALU FUNCTION A OR NOTB WITH C BIT CLEARED  
\*ALU FUNCTION (A OR NOTB) CODE=12  
\*LOAD MAIN MEM AND SP WITH 8 WORDS OF DATA  
\*PERFORM THE FUNCTION, VERIFY THE RESULTS  
\*\*\*\*\*

\*\*\*\*\* TEST 48 \*\*\*\*\*  
\*ALU TEST  
\*TEST OF ALU FUNCTION A AND B WITH C BIT CLEARED  
\*ALU FUNCTION (A AND B) CODE=13  
\*LOAD MAIN MEM AND SP WITH 8 WORDS OF DATA  
\*PERFORM THE FUNCTION, VERIFY THE RESULTS  
\*\*\*\*\*

\*\*\*\*\* TEST 49 \*\*\*\*\*  
\*ALU TEST  
\*TEST OF ALU FUNCTION A OR B WITH C BIT CLEARED  
\*ALU FUNCTION (A OR B) CODE=14  
\*LOAD MAIN MEM AND SP WITH 8 WORDS OF DATA  
\*PERFORM THE FUNCTION, VERIFY THE RESULTS  
\*\*\*\*\*

CZDMPG M8207 STATIC DIAG. #1  
CZDMPG.P11 13-JUL-81 15:46

MACY11 30A(1052) 13-JUL-81 16:06 <sup>6 3</sup>PAGE 22-1  
PROGRAM DOCUMENT

SEQ 0032

3369

3371  
3372  
3373  
3374  
3375  
3376  
3377  
3378  
3379  
3380  
3381  
3382  
3383  
3384  
3385  
3386  
3387  
3388  
3389  
3390  
3391  
3392  
3393  
3394  
3395  
3396  
3397  
3398  
3399  
3400  
3401  
3402  
3403  
3404  
3405  
3406  
3407  
3408  
3409  
3410  
3411  
3412  
3413  
3414  
3415  
3416  
3417  
3418  
3419  
3420  
3421  
3422  
3423  
3424  
3425  
3426

\*\*\*\*\* TEST 50 \*\*\*\*\*  
\*ALU TEST  
\*TEST OF ALU FUNCTION A XOR B WITH C BIT  
\*ALU FUNCTION (A XOR B) CODE=15  
\*LOAD MAIN MEM AND SP WITH 8 WORDS OF DATA  
\*PERFORM THE FUNCTION, VERIFY THE RESULTS  
\*\*\*\*\*

\*\*\*\*\* TEST 51 \*\*\*\*\*  
\*ALU TEST  
\*TEST OF ALU FUNCTION ADD WITH C BIT CLEARED  
\*ALU FUNCTION (A PLUS B) CODE=00  
\*LOAD MAIN MEM AND SP WITH 8 WORDS OF DATA  
\*PERFORM THE FUNCTION, VERIFY THE RESULTS  
\*\*\*\*\*

\*\*\*\*\* TEST 52 \*\*\*\*\*  
\*ALU TEST  
\*TEST OF ALU FUNCTION 2A W.C WITH C BIT CLEARED  
\*ALU FUNCTION (A PLUS A PLUS C) CODE=6  
\*LOAD MAIN MEM AND SP WITH 8 WORDS OF DATA  
\*PERFORM THE FUNCTION, VERIFY THE RESULTS  
\*\*\*\*\*

\*\*\*\*\* TEST 53 \*\*\*\*\*  
\*ALU TEST  
\*TEST OF ALU FUNCTION SUB WITH C BIT CLEARED  
\*ALU FUNCTION (A-B) CODE=16  
\*LOAD MAIN MEM AND SP WITH 8 WORDS OF DATA  
\*PERFORM THE FUNCTION, VERIFY THE RESULTS  
\*\*\*\*\*

\*\*\*\*\* TEST 54 \*\*\*\*\*  
\*ALU TEST  
\*TEST OF ALU FUNCTION ADD W/C WITH C BIT CLEARED  
\*ALU FUNCTION (A PLUS B PLUS C) CODE=01  
\*LOAD MAIN MEM AND SP WITH 8 WORDS OF DATA  
\*PERFORM THE FUNCTION, VERIFY THE RESULTS  
\*\*\*\*\*

\*\*\*\*\* TEST 55 \*\*\*\*\*  
\*ALU TEST  
\*TEST OF ALU FUNCTION SUB W/C WITH C BIT CLEARED  
\*ALU FUNCTION (A-B-C) CODE=2  
\*LOAD MAIN MEM AND SP WITH 8 WORDS OF DATA  
\*PERFORM THE FUNCTION. VERIFY THE RESULTS

CZDMPC M8207 STATIC DIAG. #1  
CZDMPC.P11 13-JUL-81 15:46

MACY11 30A(1052) 13-JUL-81 16:06 I 3  
PAGE 23-1  
PROGRAM DOCUMENT

SEQ 0034

3427

\*\*\*\*\*

3429  
3430  
3431  
3432  
3433  
3434  
3435  
3436  
3437  
3438  
3439  
3440  
3441  
3442  
3443  
3444  
3445  
3446  
3447  
3448  
3449  
3450  
3451  
3452  
3453  
3454  
3455  
3456  
3457  
3458  
3459  
3460  
3461  
3462  
3463  
3464  
3465  
3466  
3467  
3468  
3469  
3470  
3471  
3472  
3473  
3474  
3475  
3476  
3477  
3478  
3479  
3480  
3481  
3482  
3483  
3484

\*\*\*\*\* TEST 56 \*\*\*\*\*

\*ALU TEST  
\*TEST OF ALU FUNCTION INC A WITH C BIT CLEARED  
\*ALU FUNCTION (A PLUS 1) CODE =3  
\*LOAD MAIN MEM AND SP WITH 8 WORDS OF DATA  
\*PERFORM THE FUNCTION, VERIFY THE RESULTS  
\*\*\*\*\*

\*\*\*\*\* TEST 57 \*\*\*\*\*

\*ALU TEST  
\*TEST OF ALU FUNCTION 2A WITH C BIT CLEARED  
\*ALU FUNCTION (A PLUS A) CODE=5  
\*LOAD MAIN MEM AND SP WITH 8 WORDS OF DATA  
\*PERFORM THE FUNCTION, VERIFY THE RESULTS  
\*\*\*\*\*

\*\*\*\*\* TEST 58 \*\*\*\*\*

\*ALU TEST  
\*TEST OF ALU FUNCTION A PLUS C WITH C BIT CLEARED  
\*ALU FUNCTION (A PLUS C) CODE=4  
\*LOAD MAIN MEM AND SP WITH 8 WORDS OF DATA  
\*PERFORM THE FUNCTION, VERIFY THE RESULTS  
\*\*\*\*\*

\*\*\*\*\* TEST 59 \*\*\*\*\*

\*ALU TEST  
\*TEST OF ALU FUNCTION 2'S COMP SUB WITH C BIT CLEARED  
\*ALU FUNCTION (A-B-1) CODE=17  
\*LOAD MAIN MEM AND SP WITH 8 WORDS OF DATA  
\*PERFORM THE FUNCTION, VERIFY THE RESULTS  
\*\*\*\*\*

\*\*\*\*\* TEST 60 \*\*\*\*\*

\*ALU TEST  
\*TEST OF ALU FUNCTION DEC A WITH C BIT CLEARED  
\*ALU FUNCTION (A-1) CODE=7  
\*LOAD MAIN MEM AND SP WITH 8 WORDS OF DATA  
\*PERFORM THE FUNCTION, VERIFY THE RESULTS  
\*\*\*\*\*

\*\*\*\*\* TEST 61 \*\*\*\*\*

\*ALU TEST  
\*TEST OF ALU FUNCTION SEL B WITH C BIT SET  
\*ALU FUNCTION (B) CODE=11

CZDMPC M8207 STATIC DIAG. #1  
CZDMPC.P11 13-JUL-81 15:46

MACY11 30A(1052) 13-JUL-81 16:06 <sup>K 3</sup> PAGE 24-1  
PROGRAM DOCUMENT

SEQ 0036

3485

\*LOAD MAIN MEM AND SP WITH 8 WORDS OF DATA

3487  
3488  
3489  
3490  
3491  
3492  
3493  
3494  
3495  
3496  
3497  
3498  
3499  
3500  
3501  
3502  
3503  
3504  
3505  
3506  
3507  
3508  
3509  
3510  
3511  
3512  
3513  
3514  
3515  
3516  
3517  
3518  
3519  
3520  
3521  
3522  
3523  
3524  
3525  
3526  
3527  
3528  
3529  
3530  
3531  
3532  
3533  
3534  
3535  
3536  
3537  
3538  
3539  
3540  
3541  
3542

\*PERFORM THE FUNCTION, VERIFY THE RESULTS  
\*\*\*\*\*

\*\*\*\*\* TEST 62 \*\*\*\*\*

\*ALU TEST  
\*TEST OF ALU FUNCTION SEL A WITH C BIT SET  
\*ALU FUNCTION (A) CODE=10  
\*LOAD MAIN MEM AND SP WITH 8 WORDS OF DATA  
\*PERFORM THE FUNCTION, VERIFY THE RESULTS  
\*\*\*\*\*

\*\*\*\*\* TEST 63 \*\*\*\*\*

\*ALU TEST  
\*TEST OF ALU FUNCTION A OR NOTB WITH C BIT SET  
\*ALU FUNCTION (A OR NOTB) CODE=12  
\*LOAD MAIN MEM AND SP WITH 8 WORDS OF DATA  
\*PERFORM THE FUNCTION, VERIFY THE RESULTS  
\*\*\*\*\*

\*\*\*\*\* TEST 64 \*\*\*\*\*

\*ALU TEST  
\*TEST OF ALU FUNCTION A AND B WITH C BIT SET  
\*ALU FUNCTION (A AND B) CODE=13  
\*LOAD MAIN MEM AND SP WITH 8 WORDS OF DATA  
\*PERFORM THE FUNCTION, VERIFY THE RESULTS  
\*\*\*\*\*

\*\*\*\*\* TEST 65 \*\*\*\*\*

\*ALU TEST  
\*TEST OF ALU FUNCTION A OR B WITH C BIT SET  
\*ALU FUNCTION (A OR B) CODE=14  
\*LOAD MAIN MEM AND SP WITH 8 WORDS OF DATA  
\*PERFORM THE FUNCTION, VERIFY THE RESULTS  
\*\*\*\*\*

\*\*\*\*\* TEST 66 \*\*\*\*\*

\*ALU TEST  
\*TEST OF ALU FUNCTION A XOR B WITH C BIT SET  
\*ALU FUNCTION (A XOR B) CODE=15  
\*LOAD MAIN MEM AND SP WITH 8 WORDS OF DATA  
\*PERFORM THE FUNCTION, VERIFY THE RESULTS  
\*\*\*\*\*

\*\*\*\*\* TEST 67 \*\*\*\*\*

\*ALU TEST

CZDMP C M8207 STATIC DIAG. #1  
CZDMP C.P11 13-JUL-81 15:46

M 3  
MACY11 30A(1052) 13-JUL-81 16:06 PAGE 25-1  
PROGRAM DOCUMENT

SEQ 0038

3543

\*TEST OF ALU FUNCTION ADD WITH C BIT SET



3545  
3546  
3547  
3548  
3549  
3550  
3551  
3552  
3553  
3554  
3555  
3556  
3557  
3558  
3559  
3560  
3561  
3562  
3563  
3564  
3565  
3566  
3567  
3568  
3569  
3570  
3571  
3572  
3573  
3574  
3575  
3576  
3577  
3578  
3579  
3580  
3581  
3582  
3583  
3584  
3585  
3586  
3587  
3588  
3589  
3590  
3591  
3592  
3593  
3594  
3595  
3596  
3597  
3598  
3599  
3600

\*ALU FUNCTION (A PLUS B) CODE=00  
\*LOAD MAIN MEM AND SP WITH 8 WORDS OF DATA  
\*PERFORM THE FUNCTION, VERIFY THE RESULTS  
\*\*\*\*\*

\*\*\*\*\* TEST 68 \*\*\*\*\*

\*ALU TEST  
\*TEST OF ALU FUNCTION 2A W/C WITH C BIT SET  
\*ALU FUNCTION (A PLUS A PLUS C) CODE=6  
\*LOAD MAIN MEM AND SP WITH 8 WORDS OF DATA  
\*PERFORM THE FUNCTION, VERIFY THE RESULTS  
\*\*\*\*\*

\*\*\*\*\* TEST 69 \*\*\*\*\*

\*ALU TEST  
\*TEST OF ALU FUNCTION SUB WITH C BIT SET  
\*ALU FUNCTION (A-B) CODE=16  
\*LOAD MAIN MEM AND SP WITH 8 WORDS OF DATA  
\*PERFORM THE FUNCTION, VERIFY THE RESULTS  
\*\*\*\*\*

\*\*\*\*\* TEST 70 \*\*\*\*\*

\*ALU TEST  
\*TEST OF ALU FUNCTION ADD W/C WITH C BIT SET  
\*ALU FUNCTION (A PLUS B PLUS C) CODE=01  
\*LOAD MAIN MEM AND SP WITH 8 WORDS OF DATA  
\*PERFORM THE FUNCTION, VERIFY THE RESULTS  
\*\*\*\*\*

\*\*\*\*\* TEST 71 \*\*\*\*\*

\*ALU TEST  
\*TEST OF ALU FUNCTION SUB W/C WITH C BIT SET  
\*ALU FUNCTION (A-B-C) CODE=2  
\*LOAD MAIN MEM AND SP WITH 8 WORDS OF DATA  
\*PERFORM THE FUNCTION, VERIFY THE RESULTS  
\*\*\*\*\*

\*\*\*\*\* TEST 72 \*\*\*\*\*

\*ALU TEST  
\*TEST OF ALU FUNCTION INC A WITH C BIT SET  
\*ALU FUNCTION (A PLUS 1) CODE=3  
\*LOAD MAIN MEM AND SP WITH 8 WORDS OF DATA  
\*PERFORM THE FUNCTION, VERIFY THE RESULTS  
\*\*\*\*\*

CZDMPC M8207 STATIC DIAG. #1  
CZDMPC.P11 13-JUL-81 15:46

MACY11 30A(1052) 13-JUL-81 16:06 <sup>B 4</sup> PAGE 26-1  
PROGRAM DOCUMENT

SEQ 0040

3601

\*\*\*\*\* TEST 73 \*\*\*\*\*

3603  
3604  
3605  
3606  
3607  
3608  
3609  
3610  
3611  
3612  
3613  
3614  
3615  
3616  
3617  
3618  
3619  
3620  
3621  
3622  
3623  
3624  
3625  
3626  
3627  
3628  
3629  
3630  
3631  
3632  
3633  
3634  
3635  
3636  
3637  
3638  
3639  
3640  
3641  
3642  
3643

\*ALU TEST  
\*TEST OF ALU FUNCTION 2A WITH C BIT SET  
\*ALU FUNCTION (A PLUS A) CODE=5  
\*LOAD MAIN MEM AND SP WITH 8 WORDS OF DATA  
\*PERFORM THE FUNCTION, VERIFY THE RESULTS  
\*\*\*\*\*

\*\*\*\*\* TEST 74 \*\*\*\*\*  
\*ALU TEST  
\*TEST OF ALU FUNCTION A PLUS C WITH C BIT SET  
\*ALU FUNCTION (A PLUS C) CODE=4  
\*LOAD MAIN MEM AND SP WITH 8 WORDS OF DATA  
\*PERFORM THE FUNCTION, VERIFY THE RESULTS  
\*\*\*\*\*

\*\*\*\*\* TEST 75 \*\*\*\*\*  
\*ALU TEST  
\*TEST OF ALU FUNCTION 2'S COMP SUB WITH C BIT SET  
\*ALU FUNCTION (A-B-1) CODE=17  
\*LOAD MAIN MEM AND SP WITH 8 WORDS OF DATA  
\*PERFORM THE FUNCTION, VERIFY THE RESULTS  
\*\*\*\*\*

\*\*\*\*\* TEST 76 \*\*\*\*\*  
\*ALU TEST  
\*TEST OF ALU FUNCTION DEC A WITH C BIT SET  
\*ALU FUNCTION (A-1) CODE=7  
\*LOAD MAIN MEM AND SP WITH 8 WORDS OF DATA  
\*PERFORM THE FUNCTION, VERIFY THE RESULT  
\*\*\*\*\*

3645  
3646  
3647  
3648  
3649  
3650  
3651  
3652  
3653  
3654  
3655  
3656  
3657  
3658  
3659  
3660  
3661  
3662  
3663  
3664  
3665  
3666  
3667  
3668  
3669  
3670  
3671  
3672  
3673  
3674  
3675  
3676  
3677  
3678  
3679  
3680  
3681  
3682

## 8.0 ERROR INFORMATION

### 8.1 ERROR REPORTING

ERRORS ARE REPORTED BY THE PROGRAM AS THEY OCCUR (IF NOT INHIBITED). THE REPORT CONFORMS TO THE DIAGNOSTIC SUPERVISOR ERROR REPORT FORMAT, AND CONSISTS OF A DESCRIPTION OF THE ERROR, THE TEST NUMBER, SUBTEST NUMBER, PC OF THE ERROR CALL, DEVICE ADDRESS, AND BASIC AND EXTENDED ERROR INFORMATION.

THE FOLLOWING EXAMPLE PROVIDES A TYPICAL ERROR REPORT.

CZDMP DVC FTL ERR 00003 TST 029 SUB 000 PC:022626

BR REGISTER DATA TEST  
UNIT=00; FAILING UNIT ADDRESS=160170

GOOD	BAD
177776	000011

FOR ALL OTHER ERRORS, THE REPORT MAY BE MORE EXTENSIVE AND REQUIRE ADDITIONAL DATA TO BE REPORTED.

@

CZDMPC M8207 STATIC DIAG. #1  
CZDMPC.P11 13-JUL-81 15:46

MACY11 30A(1052) 13-JUL-81 16:06 <sup>E 4</sup> PAGE 29  
PROGRAM DOCUMENT

SEQ 0043

3684  
3685  
3686  
3687  
3688

```
3690  
3698          002000  
3699  
3700  
3701  
3702  
3703  
3704  
3705          .MCALL SVC  
3706 002000          SVC          ; INITIALIZE SUPERVISOR MACROS  
3707  
3708  
3709  
3710  
3711  
3712 002000          BGNMOD CZDMP  
3713  
3714  
3715          000000  
3716          000000  
3717          000000  
3718          000000  
3719          000000  
3720          000000  
3721          000000  
3722  
3723          : CHANGE THE VALUES OF THE SVC... SYMBOLS TO BE ZERO IF YOU WISH  
3724          : TO ALIGN THE MACRO CALLS AND THEIR EXPANSIONS. CHANGE THE  
3725          : SYMBOLS TO BE MINUS-ONE TO NOT LIST THE EXPANSIONS. YOU MAY  
3726          : CHANGE THE SYMBOLS AT ANY POINT IN YOUR PROGRAM.  
3727  
3728  
3729          .ENABL AMA
```

.TITLE CZDMPCO M8207 STATIC DIAG #1  
.=2000

.MCALL SVC  
SVC

; INITIALIZE SUPERVISOR MACROS

BGNMOD CZDMP

\$LSTIN= 0  
\$LSTTAG= 0  
SVCINS= 0 ; LIST INSTRUCTIONS, SHIFTED RIGHT  
SVCTST= 0 ; LIST TEST TAGS, SHIFTED RIGHT  
SVCSUB= 0 ; LIST SUBTEST TAGS, SHIFTED RIGHT  
SVCGBL= 0 ; LIST GLOBAL TAGS, SHIFTED RIGHT  
SVCTAG= 0 ; LIST OTHER TAGS, SHIFTED RIGHT

: CHANGE THE VALUES OF THE SVC... SYMBOLS TO BE ZERO IF YOU WISH  
: TO ALIGN THE MACRO CALLS AND THEIR EXPANSIONS. CHANGE THE  
: SYMBOLS TO BE MINUS-ONE TO NOT LIST THE EXPANSIONS. YOU MAY  
: CHANGE THE SYMBOLS AT ANY POINT IN YOUR PROGRAM.

.ENABL AMA

3731  
 3732  
 3733  
 3734  
 3735  
 3736  
 3737 002000  
 3738  
 3746  
 3747 002000  
 (4) 002000  
 (4) 002000 103  
 (4) 002001 132  
 (4) 002002 104  
 (4) 002003 115  
 (4) 002004 120  
 (6) 002005 000  
 (6) 002006 000  
 (5) 002007 000  
 (5) 002010  
 (4) 002010 103  
 (5) 002011  
 (4) 002011 060  
 (5) 002012  
 (4) 002012 000000  
 (5) 002014  
 (4) 002014 000170  
 (5) 002016  
 (4) 002016 034640  
 (5) 002020  
 (4) 002020 000000  
 (5) 002022  
 (4) 002022 002364  
 (5) 002024  
 (4) 002024 000000  
 (5) 002026  
 (4) 002026 040004  
 (5) 002030  
 (4) 002030 000000  
 (5) 002032  
 (4) 002032 000000  
 (5) 002034  
 (4) 002034 000000  
 (5) 002036  
 (4) 002036 000000  
 (5) 002040  
 (4) 002040 002132  
 (5) 002042  
 (4) 002042 000000  
 (5) 002044  
 (4) 002044 000000  
 (5) 002046  
 (4) 002046 000000  
 (5) 002050  
 (4) 002050 003  
 (3) 002051 003

```

.SBTTL PROGRAM HEADER
:++
: THE PROGRAM HEADER IS THE INTERFACE BETWEEN
: THE DIAGNOSTIC PROGRAM AND THE SUPERVISOR.
:--

        POINTER BGNAU,BGNDU

        HEADER CZDMP,C,0,120.,0
L$NAME:: ;DIAGNOSTIC NAME
        .ASCII /C/
        .ASCII /Z/
        .ASCII /D/
        .ASCII /M/
        .ASCII /P/
        .BYTE 0
        .BYTE 0
        .BYTE 0

L$REV:: ;REVISION LEVEL
        .ASCII /C/

L$DEPO:: ;0
        .ASCII /0/

L$UNIT:: ;NUMBER OF UNITS
        .WORD 0

L$TIML:: ;LONGEST TEST TIME
        .WORD 120.

L$HPCP:: ;POINTER TO H.W. QUES.
        .WORD L$HARD

L$SPCP:: ;POINTER TO S.W. QUES.
        .WORD 0

L$HPTP:: ;PTR. TO DEF. H.W. PTABLE
        .WORD L$HW

L$SPTP:: ;PTR. TO S.W. PTABLE
        .WORD 0

L$LADP:: ;DIAG. END ADDRESS
        .WORD L$LAST

L$STA:: ;RESERVED FOR APT STATS
        .WORD 0

L$CO::
        .WORD 0

L$DTYP:: ;DIAGNOSTIC TYPE
        .WORD 0

L$APT:: ;APT EXPANSION
        .WORD 0

L$DTP:: ;PTR. TO DISPATCH TABLE
        .WORD L$DISPATCH

L$PRIO:: ;DIAGNOSTIC RUN PRIORITY
        .WORD 0

L$ENVI:: ;FLAGS DESCRIBE HOW IT WAS SETUP
        .WORD 0

L$EXP1:: ;EXPANSION WORD
        .WORD 0

L$MREV:: ;SVC REV AND EDIT #
        .BYTE C$REVISION
        .BYTE C$EDIT
  
```

```
(5) 002052          L$EF::          ;DIAG. EVENT FLAGS
(4) 002052 000000          .WORD 0
(5) 002054 000000          .WORD 0
(5) 002056          L$SPC::          ;
(4) 002056 000000          .WORD 0
(5) 002060          L$DEVP::          ; POINTER TO DEVICE TYPE LIST
(4) 002060 003130          .WORD L$DV TYP
(5) 002062          L$REPP::          ;PTR. TO REPORT CODE
(4) 002062 000000          .WORD 0
(5) 002064          L$EXP4::          ;
(4) 002064 000000          .WORD 0
(5) 002066          L$EXP5::          ;
(4) 002066 000000          .WORD 0
(5) 002070          L$AUT::          ;PTR. TO ADD UNIT CODE
(4) 002070 011364          .WORD L$AU
(5) 002072          L$DUT::          ;PTR. TO DROP UNIT CODE
(4) 002072 011360          .WORD L$DU
(5) 002074          L$LUN::          ;LUN FOR EXERCISERS TO FILL
(4) 002074 000000          .WORD 0
(5) 002076          L$DESP::          ;POINTER TO DIAG. DESCRIPTION
(4) 002076 002414          .WORD L$DESC
(5) 002100          L$LOAD::          ;GENERATE SPECIAL AUTOLOAD EMT
(4) 002100 104035          EMT E$LOAD
(5) 002102          L$ETP::          ;POINTER TO ERR TBL
(4) 002102 000000          .WORD 0
(5) 002104          L$IICP::          ;PTR. TO INIT CODE
(4) 002104 010570          .WORD L$INIT
(5) 002106          L$CCP::          ;PTR. TO CLEAN-UP CODE
(4) 002106 011354          .WORD L$CLEAN
(5) 002110          L$ACP::          ;PTR. TO AUTO CODE
(4) 002110 011256          .WORD L$AUTO
(5) 002112          L$PRT::          ;PTR. TO PROTECT TABLE
(4) 002112 002122          .WORD L$PROT
(5) 002114          L$TEST::          ;TEST NUMBER
(4) 002114 000000          .WORD 0
(5) 002116          L$DLY::          ;DELAY COUNT
(4) 002116 000000          .WORD 0
(5) 002120          L$HIME::          ;PTR. TO HIGH MEM
(4) 002120 000000          .WORD 0

3748
3749
3755
3756 002122          BGNPROT
(3) 002122          L$PROT::          ;
3757 002122 177777          .WORD -1
3758 002124 177777          .WORD -1
3759 002126 177777          .WORD -1
3760 002130          ENDPROT
3761
```



3763  
3764  
3765  
3766  
3767  
3768  
3769  
3770 002130  
(4) 002130 000114  
(3) 002132  
(6) 002132 011366  
(6) 002134 011514  
(6) 002136 011560  
(6) 002140 011746  
(6) 002142 012112  
(6) 002144 012246  
(6) 002146 012376  
(6) 002150 012526  
(6) 002152 012670  
(6) 002154 013054  
(6) 002156 013240  
(6) 002160 013426  
(6) 002162 013576  
(6) 002164 013704  
(6) 002166 014134  
(6) 002170 014364  
(6) 002172 014614  
(6) 002174 015044  
(6) 002176 015340  
(6) 002200 015634  
(6) 002202 016064  
(6) 002204 016314  
(6) 002206 016544  
(6) 002210 016774  
(6) 002212 017224  
(6) 002214 017454  
(6) 002216 017704  
(6) 002220 020134  
(6) 002222 020432  
(6) 002224 020662  
(6) 002226 021226  
(6) 002230 021540  
(6) 002232 021702  
(6) 002234 022044  
(6) 002236 022220  
(6) 002240 022424  
(6) 002242 022570  
(6) 002244 022740  
(6) 002246 023104  
(6) 002250 023272  
(6) 002252 023506  
(6) 002254 023724  
(6) 002256 024056  
(6) 002260 024274  
(6) 002262 024434  
(6) 002264 024640

.SBTTL DISPATCH TABLE

:/ THE DISPATCH TABLE CONTAINS THE STARTING ADDRESS OF EACH TEST.  
:/ IT IS USED BY THE SUPERVISOR TO DISPATCH TO EACH TEST.

DISPATCH 76.  
.WORD 76  
LSDISPATCH::  
.WORD T1  
.WORD T2  
.WORD T3  
.WORD T4  
.WORD T5  
.WORD T6  
.WORD T7  
.WORD T8  
.WORD T9  
.WORD T10  
.WORD T11  
.WORD T12  
.WORD T13  
.WORD T14  
.WORD T15  
.WORD T16  
.WORD T17  
.WORD T18  
.WORD T19  
.WORD T20  
.WORD T21  
.WORD T22  
.WORD T23  
.WORD T24  
.WORD T25  
.WORD T26  
.WORD T27  
.WORD T28  
.WORD T29  
.WORD T30  
.WORD T31  
.WORD T32  
.WORD T33  
.WORD T34  
.WORD T35  
.WORD T36  
.WORD T37  
.WORD T38  
.WORD T39  
.WORD T40  
.WORD T41  
.WORD T42  
.WORD T43  
.WORD T44  
.WORD T45  
.WORD T46

(6)	002266	025044	.WORD	T47
(6)	002270	025250	.WORD	T48
(6)	002272	025454	.WORD	T49
(6)	002274	025660	.WORD	T50
(6)	002276	026064	.WORD	T51
(6)	002300	026270	.WORD	T52
(6)	002302	026474	.WORD	T53
(6)	002304	026702	.WORD	T54
(6)	002306	027106	.WORD	T55
(6)	002310	027312	.WORD	T56
(6)	002312	027516	.WORD	T57
(6)	002314	027722	.WORD	T58
(6)	002316	030126	.WORD	T59
(6)	002320	030332	.WORD	T60
(6)	002322	030536	.WORD	T61
(6)	002324	030742	.WORD	T62
(6)	002326	031146	.WORD	T63
(6)	002330	031352	.WORD	T64
(6)	002332	031556	.WORD	T65
(6)	002334	031762	.WORD	T66
(6)	002336	032166	.WORD	T67
(6)	002340	032372	.WORD	T68
(6)	002342	032576	.WORD	T69
(6)	002344	033002	.WORD	T70
(6)	002346	033206	.WORD	T71
(6)	002350	033412	.WORD	T72
(6)	002352	033616	.WORD	T73
(6)	002354	034022	.WORD	T74
(6)	002356	034226	.WORD	T75
(6)	002360	034432	.WORD	T76

3771  
3772  
3779  
3780  
3781  
3782  
3783

:LNT.ED DIFINED AT END OF PROGRAM TO BE LAST TEST NUMBER.

3785  
3786  
3787  
3788  
3789  
3790  
3791  
3792  
3793 002362  
(3) 002362 000013  
(3) 002364  
(3) 002364  
3794  
3795 002364 000007  
3796 002366 160170  
3797 002370 000300  
3798 002372 005000  
3799 002374 000003  
3800 002376 000056  
3801 002400 000000  
3802 002402 000000  
3803 002404 000000  
3804 002406 000004  
3805  
3806  
3807 002410 000000  
3808 002412  
(3) 002412  
3809  
3810  
3811  
3812  
3813

.SBTTL DEFAULT HARDWARE P-TABLE

:/ THE DEFAULT HARDWARE P-TABLE CONTAINS DEFAULT VALUES OF  
:/ THE TEST-DEVICE PARAMETERS. THE STRUCTURE OF THIS TABLE  
:/ IS IDENTICAL TO THE STRUCTURE OF THE RUN-TIME P-TABLE.

BGNHW DFPTBL  
.WORD L10001-L\$HW/2  
L\$HW::  
DFPTBL::

.WORD 7  
.WORD 160170  
.WORD 300  
.WORD 5000  
.WORD 3  
.WORD 56  
.WORD 0  
.WORD 0  
.WORD 0  
.WORD 4

:MICRO CPU TYPE  
:M8200,4,7 CSR ADDRESS  
:M8200,4,7 VECTOR ADDRESS  
:INTERRUPT PRIORITY LEVEL  
:LINE UNIT TYPE  
:SWITCH PACK #1 (DDCMP LINE #)  
:SWITCH PACK #2 (BM873 BOOT ADDRESS)  
:SWITCH PACK #3  
:TEST CONNECTOR INSTALLED FLAG  
:CONTAINS BAUD RATE 4=56K BAUD DEFAULT  
:0=2.4K , 1=4.8K , 2=9.6K , 3=19.2K , 4=56K  
:5=250K , 6=500K , 7=1 MEG BAUD  
:0=RUN SW OFF, 1=SW ON

L10001:

.WORD 0  
ENDHW

3815  
3816  
3817  
3818  
3819  
3820  
3821  
3822 002412  
(3) 002412 000000  
(3) 002414  
(3) 002414  
3823  
3824  
3825 002414  
(3) 002414  
3826  
3827  
3828  
3829  
3830  
3831

```
.SBTTL SOFTWARE P-TABLE  
:////////////////////  
:/ THE SOFTWARE P-TABLE CONTAINS THE VALUES OF THE PROGRAM  
:/ PARAMETERS THAT CAN BE CHANGED BY THE OPERATOR.  
:////////////////////  
          BGNSW  SFPTBL  
          .WORD  L10002-L$SW/2  
L$SW::  
SFPTBL::  
  
          ENDSW  
L10002:
```



(1) 000036  
(1) 000035  
(1) 000034  
(1)  
(1)  
(1)  
(1)  
(1) 000340  
(1) 000300  
(1) 000240  
(1) 000200  
(1) 000140  
(1) 000100  
(1) 000040  
(1) 000000  
(1)  
(1)  
(1) 000004  
(1) 000010  
(1) 000020  
(1) 000040  
(1) 000100  
(1) 000200  
(1) 000400  
(1) 001000  
(1) 002000  
(1) 004000  
(1) 010000  
(1) 020000  
(1) 040000  
(1) 100000

EF.CONTINUE== 30.  
EF.NEW== 29.  
EF.PWR== 28.

: CONTINUE COMMAND WAS ISSUED  
: A NEW PASS HAS BEEN STARTED  
: A POWER-FAIL/POWER-UP OCCURRED

: PRIORITY LEVEL DEFINITIONS

PRI07== 340  
PRI06== 300  
PRI05== 240  
PRI04== 200  
PRI03== 140  
PRI02== 100  
PRI01== 40  
PRI00== 0

: OPERATOR FLAG BITS

EVL== 4  
LOT== 10  
ADR== 20  
IDU== 40  
ISR== 100  
UAM== 200  
BOE== 400  
FNT== 1000  
PRI== 2000  
IXE== 4000  
IBE== 10000  
IER== 20000  
LOE== 40000  
HOE== 100000

3853  
3854  
3855  
3856  
3857  
3858  
3859  
3860  
3861  
3862  
3863  
3864  
3865  
3866  
3867  
3868  
3869  
3870

022626

:\*\*\*\*\*  
:\* INSTRUCTION DEFINITIONS  
:\*\*\*\*\*  
POP2SP=22626 ; INCREMENT STACK TWICE

:\*\*\*\*\*  
:\* PROGRAM EVENT FLAG DEFINITIONS  
:\*\*\*\*\*



3922 002620 000000  
3923 002622 000000  
3924 002624 000000  
3925 002626 000000  
3926 002630 000000  
3927 002632 000000  
3928 002634 000000  
3929 002636 000000  
3930 002640 000000  
3931 002642 000000  
3932 002644 000000  
3933 002646 000000  
3934 002650 000000  
3935 002652 000000

FLAG: .WORD 0 ;SCRATCH STORAGE  
RUN: .WORD 0 ;POINTER TO RUNNING DEVICES  
MRO: .WORD 0  
WTYPE: .WORD 0  
TYPE: .WORD 0  
\$GDADR: .WORD 0 ;CONTAINS ADDRESS OF 'GOOD' DATA  
\$BDADR: .WORD 0 ;CONTAINS ADDRESS OF 'BAD' DATA  
\$GDDAT: .WORD 0 ;CONTAINS 'GOOD' DATA  
\$BDDAT: .WORD 0 ;CONTAINS 'BAD' DATA  
          .WORD 0 ;RESERVED--NOT TO BE USED  
          .WORD 0  
FTIME: .WORD 0  
SAVE4: .WORD 0  
SAVE6: .WORD 0

3936  
3937  
3938  
3939  
3940 002654 000 377 000  
          002657 377 125 252  
          002662 125 252  
3941 002664 000 000 377  
          002667 377 125 125  
          002672 252 252

\*\*\*\*\*  
;\* DATA PATTERNS  
\*\*\*\*\*  
MEMDAT: .BYTE 0,-1,0,-1,125,252,125,252  
  
SPDAT: .BYTE 0,0,-1,-1,125,125,252,252  
  
.EVEN

3942  
3943  
3944  
3945  
3946  
3947 002674 000  
          002676  
3948  
3949 002676 000  
3950 002677 000

\*\*\*\*\*  
;\* PROGRAM CONTROL FLAGS  
\*\*\*\*\*  
INIFLG: .BYTE 0 ;PROGRAM INITIALIZING FLAG  
          .EVEN  
LOKFLG: .BYTE 0 ;LOCK ON CURRENT TEST FLAG  
QV.FLG: .BYTE 0 ;QUICK VERIFY FLAG  
          .EVEN

3951  
3952  
3953  
3954  
3955  
3956  
3957  
3958  
3959  
3960  
3961  
3962  
3963  
3964  
3965  
3966  
3967  
3968  
3969  
3970  
3971  
3972 002700 000000  
3973 002702 000000

\*\*\*\*\*  
;\* DEFINITION OF M8200,4,7 STATUS WORDS - STAT1,STAT2,STAT3  
\*\*\*\*\*  
;\*  
;\* STAT1 - BITS 00-08 IS M8200,4,7 VECTOR ADDRESS  
;\* BIT15=1 LINE UNIT IS AN M8203  
;\* BIT14=0 NO TEST CONNECTOR(S) USED  
;\* BIT14=1 H-XXX TEST CONNECTOR WILL BE USED  
;\* BIT13=0 LINE UNIT IS AN M8201  
;\* BIT13=1 LINE UNIT IS AN M8202  
;\* BIT12=1 NO LINE UNIT  
;\* BITS 09-11 IS M8200,4,7 PRIORITY LEVEL  
;\*  
;\* STAT2 - LOW BYTE IS SWITCH PACK #1 (DDCMP LINE NUMBER)  
;\* HIGH BYTE IS SWITCH PACK #2 (BM873 BOOT ADDRESS)  
;\*  
;\* STAT3 - BIT0=1 DO FREE RUNNING TESTS ON M8200,4,7  
\*\*\*\*\*  
STAT1: .WORD 0  
STAT2: .WORD 0



3974 002704 000000  
3975  
3976  
3977  
3978  
3979 002706 000000  
3980 002710 000000  
3981 002712 000000  
3982 002714 000000  
3983 002716 000000  
3984 002720 000000  
3985 002722 000000  
3986 002724 000000  
3987 002726 000000  
3988  
3989  
3990  
3991 002730  
3992  
3993  
3994 002730 000100  
3995 003130  
3996  
3997  
3998  
3999  
4000  
4001  
4002

STAT3: .WORD 0

\*\*\*\*\*  
;\* POINTERS TO M8200,4,7 VECTORS AND REGISTERS  
\*\*\*\*\*

KMRVEC: 0 ;POINTER TO M8200,4,7 RCV INTRPT VECTOR  
KMRLVL: 0 ;POINTER TO M8200,4,7 RCV INTRPT SERVICE PS  
KMTVEC: 0 ;POINTER TO M8200,4,7 TX INTRPT VECTOR  
KMTLVL: 0 ;POINTER TO M8200,4,7 TX INTRPT SERVICE PS  
KMCSR: 0 ;POINTER TO M8200,4,7 CONTROL STATUS REGISTER  
KMCSRH: 0 ;POINTER TO M8200,4,7 CONTROL STATUS REGISTER HIGH BYTE  
KMCTL: 0 ;POINTER TO M8200,4,7 CONTROL OUT REGISTER  
KMPO4: 0  
KMPO6: 0 ;POINTER TO M8200,4,7 PORT REGISTER - SEL6

::\*\*\*\* PRIMARY REG ADRS STORAGE FOR THIS UNIT \*\*\*\*\*  
;THESE LOCATIONS WILL BE LOADED FOR THE CURRENT UNIT, IN INIT CODE  
REGADR:

::\*\*\*\* STACK USED FOR SUBROUTINE LINKAGE \*\*\*\*\*  
.BLKW 100  
SSTACK:

4004  
4005  
4006  
4007  
4008  
4009  
4010  
4011  
4012  
4013  
4014  
4015  
(4)  
(3)  
(3)  
(3)  
(3)  
(2)  
4016  
4017  
4018  
4019  
4020  
4021  
4028  
4029  
4030  
4031  
4032

003130  
003130  
003130 034115 030062 026060  
003136 034115 030062 026064  
003144 051117 046440 031070  
003152 033460 000  
003156

```
.SBTTL GLOBAL TEXT SECTION
:XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX
:% THE GLOBAL TEXT SECTION CONTAINS FORMAT STATEMENTS,
:% MESSAGES, AND ASCII INFORMATION THAT ARE USED IN
:% MORE THAN ONE TEST.
:XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX
:*****
:* NAMES OF DEVICES SUPPORTED BY PROGRAM
:*****
DEV TYP <M8200,M8204,OR M8207>
LSDVTYP::
.ASCIZ /M8200,M8204,OR M8207/

.EVEN

:
: FORMAT STATEMENTS USED IN PRINT CALLS
:
```

4034  
4035  
4036  
4037  
4038  
4039  
4040  
4041  
4042  
4043  
4044  
4045  
4046  
4047  
4048  
4049  
4050  
4051  
4052  
4053  
4054  
4055  
4056  
4057  
4058  
4059  
4060  
4061  
4062  
4063  
4064  
4065  
4066  
4067  
4068  
4069  
4070  
4071  
4072  
4073  
4074  
4075  
4076  
4077  
4078  
4079  
4080  
4081  
4082  
4083  
4084  
4085  
4086  
4087  
4088  
4089

```
.SBTTL GLOBAL SUBROUTINES
://////
:/ THE GLOBAL SUBROUTINES ARE CALLED BY MORE THAN ONE TEST
://////

:-----
: MACRO'S NEEDED TO CALL SUBROUTINES
:-----

.MACRO ERROR,XYX,ZZ
MOV R4,$BDDAT
.IF B ZZ
MOV R2,$GDDAT
.ENDC
MOV MRO,$BDADR
ERRDF XYX',EM'XYX',ERR'XYX'
.ENDM

.MACRO RERROR XXX
MOV R4,$BDDAT
CLRB $BDDAT+1
CLRB $GDDAT+1
MOV R2,$GDADR
ERRDF XXX',EM'XXX',ERR'XXX'
.ENDM

.MACRO BERROR XXX
MOV R4,$BDDAT
MOV R5,$GDDAT
CLRB $BDDAT+1
CLRB $GDDAT+1
ERRDF XXX',EM'XXX',ERR'XXX'
.ENDM

.MACRO ED$CALL XY
.LIST
:***** TEST 'XY' *****
.NLIST
.ENDM
.MACRO BADHEAD
.RADIX 10
ED$CALL \T$TESTNUM+1
.RADIX 8
.ENDM
.MACRO K4ONLY ?N2
.LIST
:DON'T DO TEST IF M8200 OR M8204
.NLIST
CMP MEMSZ,#2000
BNE N2
EXIT TST
N2:
.ENDM
.MACRO MYINT
.LIST
MOV KMCSR,R1 ;GET DEVICE ADDRESS.
```

```

4090
4091
4092
4093
4094
4095
4096
4097
4098
4099
4100
4101
4102
4103
4104
4105 003156
4106 003156 112777 000100 177534
4107 003164 142777 000300 177526
4108 003172 000205
4109
4110
4111 003174 000024
4112
4113
4114
4115 003244
4116
4117
4118
4119
4120 003244
4121 003244 152777 000002 177446
4122 003252 012577 177450
4123 003256 152777 000003 177434
4124 003264 142777 000007 177426
4125 003272 000205
4126
4127 003274
4128
4129 003274
4130 (1) 003274 004537 003244
4131 003300 000400
4132 (1) 003302 004537 003244
4133 003306 063220
4134 (1) 003310 004537 003244
4135 003314 060400
4136 003316 000207
4137 003320
4138
4139 003320
4140 (1) 003320 004537 003244
4141 003324 000401
4142 003326 000207

```

```

.NLIST
.ENDM
.MACRO ROMCLK
.LIST
JSR R5,.ROMCLK ;CLOCK INSTRUCTION
.NLIST
.ENDM
.MACRO MSTCLR
.LIST
JSR R5,.MSTCLR ;CLEAR M8200,4,7
.NLIST
.ENDM
.MSTCLR:
MOV B #BIT6,@KMCSRH ;SET INST.
BIC B #BIT6!BIT7,@KMCSRH
RTS R5
;
.BLKW 20. ;PATCH AREA.
ENDBUG:
; UNSAFE TO PATCH ANY OTHER AREA.
.ROMCLK:
BIS B #BIT1,@KMCSRH
MOV (R5)+,@KMP06
BIS B #BIT1!BIT0,@KMCSRH
BIC B #BIT2!BIT1!BIT0,@KMCSRH
RTS R5
CLRALL:
;CLEARS C & Z BITS AND BR
ROMCLK
JSR R5,.ROMCLK ;CLOCK INSTRUCTION
400 ;0 TO BR
ROMCLK
JSR R5,.ROMCLK ;CLOCK INSTRUCTION
63220 ;SP(0) TO BR
ROMCLK
JSR R5,.ROMCLK ;CLOCK INSTRUCTION
60400 ;BR,SP(0) + BR
RTS PC
SETBRO:
;SETS BRO BIT
ROMCLK
JSR R5,.ROMCLK ;CLOCK INSTRUCTION
401 ;1 TO BR
RTS PC

```

```

4142
4143 003330      SETBR1:
4144              ;THIS SUBROUTINE SETS BR1 BIT
4145
4146 003330      ROMCLK
4147 (1) 003330 004537 003244      ;NEXT WORD IS INSTRUCTION
4148 003334 000402      JSR R5,,ROMCLK ;CLOCK INSTRUCTION
4149 003336 000207      RTS PC ;BR_002
4150 003340      SETBR4:
4151              ;THIS SUBROUTINE SETS BR4 BIT
4152
4153 003340      ROMCLK
4154 (1) 003340 004537 003244      ;NEXT WORD IS INSTRUCTION
4155 003344 000402      JSR R5,,ROMCLK ;CLOCK INSTRUCTION
4156 003346 000207      RTS PC
4157 003350      SETBR7:
4158              ;THIS SUBROUTINE SETS BR7 BIT
4159
4160 003350      ROMCLK
4161 (1) 003350 004537 003244      ;NEXT WORD IS INSTRUCTION
4162 003354 000600      JSR R5,,ROMCLK ;CLOCK INSTRUCTION
4163 003356 000207      RTS PC
4164
4165 003360      SETZ:
4166              ;THIS SUBROUTINE SETS THE Z BIT
4167
4168 003360      ROMCLK
4169 (1) 003360 004537 003244      ;NEXT WORD IS INSTRUCTION
4170 003364 000777      JSR R5,,ROMCLK ;CLOCK INSTRUCTION
4171 003366 000207      RTS PC ;BR_377
4172 003370      RAMDAT:
4173              ;THIS SUBROUTINE LOADS R4 WITH THE LOWEST
4174              ;8 BITS OF THE CRAM PC.
4175
4176 003370 017605 000000      MOV @ (SP),R5 ;GOOD DATA
4177 003374 062716 000002      ADD #2,(SP) ;ADJUST STACK
4178 003400 005011      CLR (R1) ;CLEAR BIT10
4179 003402 052711 000400      BIS #BIT8,(R1) ;CLOCK INSTRUCTION IN CRAM THAT
4180              ;JUMPED TO, IT LOADS BR WITH IT
4181 003406 005011      CLR (R1) ;CLR BIT8
4182 003410      ROMCLK
4183 (1) 003410 004537 003244      ;NEXT WORD IS INSTRUCTION
4184 003414 061225      JSR R5,,ROMCLK ;CLOCK INSTRUCTION
4185 003416 116104 000005      MOVB 5(R1),R4 ;MOV BR TO PORT 5
4186 003422 000207      RTS PC ;PUT 'FOUND' IN R4
4187              ;RETURN
4188 003424      MEMSET:
4189              ;THIS SUBROUTINE LOADS CRAM WITH SPECIAL INSTRUCTIONS
4190              ;FOR THE CRAM JUMP TEST. ALL CRAM LOCATIONS ARE LOADED
4191              ;WITH INSTRUCTIONS THAT MOVE A 37 TO THE BR, EXCEPT THE
4192              ;FOLLOWING CRAM ADDRESSES: 0,1,4,7,525,1777. THESE LOCATIONS

```

```

4193                                     ;CONTAIN INSTRUCTIONS WHICH LOAD THE BR WITH THE LOWEST
4194                                     ;8 BITS OF THAT CRAM ADDRESS.
4195
4196 003424 005000                       CLR      R0                ;R0 = CRAM ADDRESS
4197 003426 012711 002000                1$:  MOV      #BIT10,(R1)      ;SET ROMO
4198 003432 010061 000004                MOV      R0,4(R1)        ;LOAD CRAM ADDRESS
4199 003436 012761 000437 000006        MOV      #437,6(R1)     ;LOAD INSTRUCTION
4200 003444 052711 020000                BIS      #BIT13,(R1)    ;WRITE INSTRUCTION IN CRAM
4201 003450 005200                       INC      R0                ;NEXT ADDRESS
4202 003452 022700 002000                CMP      #2000,R0       ;DONE YET?
4203 003456 001363                       BNE      1$              ;BR IF NO
4204 003460 005000                       CLR      R0                ;INDEX REGISTER
4205 003462 012711 002000                2$:  MOV      #BIT10,(R1)      ;SET ROMO
4206 003466 016061 003522 000004        MOV      CRAMA(R0),4(R1) ;LOAD CRAM ADDRESS IN SEL4
4207 003474 016061 003536 000006        MOV      INSTU(R0),6(R1) ;LOAD INSTRUCTION TO BE WRITTEN
4208 003502 052711 020000                BIS      #BIT13,(R1)    ;WRITE CRAM!
4209 003506 005720                       TST      (R0)+           ;NEXT
4210 003510 022700 000014                CMP      #14,R0         ;DONE YET?
4211 003514 001362                       BNE      2$              ;BR IF NO
4212 003516 005011                       CLR      (R1)            ;CLEAR ALL BITS
4213 003520 000207                       RTS      PC                ;RETURN
4214
4215 003522 000000 000001 000004 000004  CRAMA: .WORD 0,1,4,7,1777,525
4216 003530 000007 001777 000525
4217 003536 000400                       INSTU: 000400            ;BR_0
4218 003540 000401                       000401                ;BR_1
4219 003542 000404                       000404                ;BR_4
4220 003544 000407                       000407                ;BR_7
4221 003546 000777                       000777                ;BR_377
4222 003550 000525                       000525                ;BR_125
4223
4224 003552                       SETVEC:
4225                                     ;THIS SUBROUTINE LOADS THE VECTORS AND VECTOR LEVELS
4226
4227 003552 012577 177130                MOV      (R5)+,@KMRVEC   ;LOAD BASE VECTOR
4228 003556 012577 177130                MOV      (R5)+,@KMTVEC   ;LOAD VECTOR + 2
4229 003562 012577 177122                MOV      (R5)+,@KMRLVL   ;LOAD VECTOR + 4
4230 003566 012577 177122                MOV      (R5)+,@KMTLVL   ;LOAD VECTOR + 6
4231 003572 000205                       RTS      R5                ;RETURN
4232
4233
4234 003574                       NPRSET:
4235                                     ;THIS SUBROUTINE LOADS IBUS REGISTERS 0-7
4236                                     ;WITH NPR INFORMATION (INBA, OUTBA, OUT DATA)
4237
4238 003574 010246                       MOV      R2,-(SP)        ;SAVE R2
4239 003576 005002                       CLR      R2                ;START AT IBUS REG 0
4240 003600 112561 000004                1$:  MOVB   (R5)+,4(R1)    ;LOAD PORT4
4241 003604 042737 000017 003622        BIC      #17,2$          ;CLEAR ADDRESS FIELD OF INSTRUCTION
4242 003612 050237 003622                BIS      R2,2$           ;ADD ADDRESS TO INSTRUCTION
4243 003616
4244 (1) 003616 004537 003244                ROMCLK JSR      R5,ROMCLK       ;CLOCK INSTRUCTION
4244 003622 122100                2$:  122100                ;MOVE PORT4 TO IBUS REG
4245 003624 005202                       INC      R2                ;NEXT ADDRESS
4246 003626 022702 000010                CMP      #10,R2          ;ALL DONE?

```

```

4247 003632 001362      BNE      1$           :BR IF NO
4248 003634 012602      MOV      (SP)+,R2     :RESTORE R2
4249 003636 000205      RTS      R5           :RETURN
4250
4251
4252 003640      MEMLD:
4253                :THIS SUBROUTINE LOADS THE FIRST 8 LOCATIONS OF MAIN
4254                :MEMORY WITH THIS DATA: 0,-1,,0,-1,125,252,125,252
4255
4256 003640 013637 002550  MOV      @(SP)+,$TMP0 :PUT POINTER TO DATA IN R0
4257 003644 062746 000002  ADD      #2,-(SP)     :ADJUST STACK
4258
4259 003650 013700 002550  MEMLD2: MOV      $TMP0,R0 :GET ADDR.
4260 003654 012704 000010  MOV      #10,R4       :DO 8 LOADS
4261 003660      ROMCLK
4262 (1) 003660 004537 003244  JSR      R5,ROMCLK    :CLOCK INSTRUCTION
4263 003664 010000      010000 :MAR < 0
4264 003666      ROMCLK :CLR      MAR HI
4265 (1) 003666 004537 003244  JSR      R5,ROMCLK    :CLOCK INSTRUCTION
4266 003672 004000      004000
4267 003674 112077 177024  1$:  MOVB    (R0)+,@KMP04 :LOAD PORT4
4268 003700      ROMCLK
4269 (1) 003700 004537 003244  JSR      R5,ROMCLK    :CLOCK INSTRUCTION
4270 003704 136500      136500 :MOV DATA TO MEM, AUTO INC MAR
4271 003706 005304      DEC      R4           :DECREMENT COUNT
4272 003710 001371      BNE      1$           :BR IF NOT DONE
4273
4274 003712      ROMCLK :LOAD MEM ADDR. 0
4275 (1) 003712 004537 003244  JSR      R5,ROMCLK    :CLOCK INSTRUCTION
4276 003716 010000      10000
4277 003720 012703 000010  MOV      #10,R3       :CHECK 8. MEM LOCS.
4278 003724 013700 002550  MOV      $TMP0,R0
4279 003730      ROMCLK :READ FROM MEM,PUT INTO PORT 4
4280 (1) 003730 004537 003244  JSR      R5,ROMCLK    :CLOCK INSTRUCTION
4281 003734 055224      55224
4282 003736 112037 002636  MOVB    (R0)+,$GDDAT :EXPECTED.
4283 003742 117704 176756  MOVB    @KMP04,R4     :RECIEVED.
4284 003746 123704 002636  CMPB    $GDDAT,R4    :OK?
4285 003752 001414      BEQ      3$
4286 003754      ERROR  36
4287 (5) 003772 104455      TRAP    C$ERDF
4288 (6) 003774 000044      .WORD  36
4289 (6) 003776 005640      .WORD  EM36
4290 (6) 004000 010432      .WORD  ERR36
4291 004002 000402      BR      4$
4292 004004 005303      3$:  DEC      R3           :CHECKED ALL?
4293 004006 001350      BNE      2$           :NO-DO NEXT ONE.
4294 004010      4$:
4295 004010 000207      RTS      PC           :RETURN
4296
4297
4298
4299 004012      SPLD:
4300                :THIS SUBROUTINE LOADS THE FIRST 8 SCRATCH PAD
4301                :LOCATIONS WITH: 0,0,-1,-1,125,125,252,252
4302

```

```

4296 004012 013600          MOV    @ (SP)+,R0      ;PUT POINTER TO DATA IN R5
4297 004014 062746 000002    ADD    #2,-(SP)      ;ADJUST STACK
4298 004020 005004          CLR    R4            ;START AT SP ADDRESS 0
4299 004022 112077 176676    004044 1$:  MOVB  (R0)+,@KMP04   ;LOAD PORT4 WITH DATA
4300 004026 042737 000017    BIC   #17,2$        ;CLEAR ADDRESS FIELD OF INSTRUCTION
4301 004034 050437 004044    BIS   R4,2$         ;ADD ADDRESS TO INSTRUCTION
4302 004040          ROMCLK
(1) 004040 004537 003244    JSR   R5,..ROMCLK   ;CLOCK INSTRUCTION
4303 004044 123100          2$: 123100          ;MOVE DATA TO SP
4304 004046 005204          INC   R4            ;INCREMENT COUNT
4305 004050 022704 000010    CMP   #10,R4        ;DONE YET?
4306 004054 001362          BNE  1$            ;BR IF NO
4307 004056 000207          RTS   PC            ;RETURN
4308
4309
4310 004060          CLRC:              ;THIS SUBROUTINE CLEARS THE MICRO PROCESSOR C BIT
4311
4312
4313 004060          ROMCLK
(1) 004060 004537 003244    JSR   R5,..ROMCLK   ;CLOCK INSTRUCTION
4314 004064 010000          010000          ;MAR_0
4315 004066          ROMCLK
(1) 004066 004537 003244    JSR   R5,..ROMCLK   ;CLOCK INSTRUCTION
4316 004072 040400          040400!<0*20>   ;CLEAR C BIT
4317 004074 000207          RTS   PC            ;RETURN
4318
4319
4320 004076          SETC:              ;THIS SUBROUTINE SETS THE MICRO PROCESSOR C BIT
4321
4322
4323 004076          ROMCLK
(1) 004076 004537 003244    JSR   R5,..ROMCLK   ;CLOCK INSTRUCTION
4324 004102 010003          010003          ;MAR_3
4325 004104          ROMCLK
(1) 004104 004537 003244    JSR   R5,..ROMCLK   ;CLOCK INSTRUCTION
4326 004110 040403          040403!<0*20>   ;SET C BIT
4327 004112 000207          RTS   PC            ;RETURN
4328
4329
4330
4331

```



4333  
4334  
4335  
4336  
4337  
4338

.SBTTL GLOBAL ERROR REPORT SECTION

:/   
:/ THE GLOBAL ERROR REPORT SECTION CONTAINS ERROR MESSAGES  
:/ THAT ARE USED IN MORE THAN ONE TEST.  
:/

4340  
4341  
4342  
4343 004114 047045 052045 047045 FM1: .ASCIZ /%N%T%N/  
004122 000  
4344 004123 045 031517 051445 TFM1: .ASCIZ /%03%S5%03%S5%03%N2/  
004130 022465 031517 051445  
004136 022465 031517 047045  
004144 000062  
4345 004146 047445 022466 031123 TFM2: .ASCIZ /%06%S2%06%N2/  
004154 047445 022466 031116  
004162 000  
4346 004163 045 031517 051445 TFM5: .ASCIZ /%03%S5%03%N2/  
004170 022465 031517 047045  
004176 000062  
4347 004200 047045 047445 022463 TFM27: .ASCIZ /%N%03%S5%06%S7%06%N2/  
004206 032523 047445 022466  
004214 033523 047445 022466  
004222 031116 000  
4348 004225 045 022516 043101 TFM37: .ASCIZ /%N%AFAILING ADDRESS IS: %06/  
004232 044501 044514 043516  
004240 040440 042104 042522  
004246 051523 044440 035123  
004254 022440 033117 000  
4349  
4350

4352					
4353					
4354	004261	122	043505	051511	EM1: .ASCIZ &REGISTER ADDRESS TEST&
	004266	042524	020122	042101	
	004274	051104	051505	020123	
	004302	042524	052123	000	
4355	004307	111	052502	025123	EM2: .ASCIZ &IBUS* REGISTER DUAL ADDRESSING TEST&
	004314	051040	043505	051511	
	004322	042524	020122	052504	
	004330	046101	040440	042104	
	004336	042522	051523	047111	
	004344	020107	042524	052123	
	004352	000			
4356	004353	111	052502	020123	EM30: .ASCIZ ''IBUS REGISTER DUAL ADDRESSING TEST''
	004360	042522	044507	052123	
	004366	051105	042040	040525	
	004374	020114	042101	051104	
	004402	051505	044523	043516	
	004410	052040	051505	000124	
4357	004416	051102	051040	043505	EM3: .ASCIZ /BR REGISTER DATA TEST/
	004424	051511	042524	020122	
	004432	040504	040524	052040	
	004440	051505	000124		

CZDMPCO M8207 STATIC DIAG #1  
CZDMP.C.P11 13-JUL-81 15:46

MACY11 30A(1052) 13-JUL-81 16:06 <sup>B 6</sup> PAGE 32  
GLOBAL ERROR REPORT SECTION

SEQ 0066

4359 004444 041523 040522 041524 EM4: .ASCIZ /SCRATCH PAD DATA TEST/  
004452 020110 040520 020104  
004460 040504 040524 052040  
004466 051505 000124

CZDMPCO M8207 STATIC DIAG #1  
CZDMPC.P11 13-JUL-81 15:46

MACY11 30A(1052) 13-JUL-81 16:06 <sup>C 6</sup> PAGE 33  
GLOBAL ERROR REPORT SECTION

SEQ 0067

4361	004472	041523	040522	041524	EMS: .ASCIZ /SCRATCH PAD DUAL ADDRESSING TEST/
	004500	020110	040520	020104	
	004506	052504	046101	040440	
	004514	042104	042522	051523	
	004522	047111	020107	042524	
	004530	052123	000		

4363	004533	115	044501	020116	EM6:	.ASCIZ /MAIN MEMORY DATA TEST/
	004540	042515	047515	054522		
	004546	042040	052101	020101		
	004554	042524	052123	000		
4364	004561	115	044501	020116	EM7:	.ASCIZ /MAIN MEMORY DUAL ADDRESSING TEST/
	004566	042515	047515	054522		
	004574	042040	040525	020114		
	004602	042101	051104	051505		
	004610	044523	043516	052040		
	004616	051505	000124			

4366	004622	052501	047524	046440	EM10:	.ASCIZ	/AUTO MARINC FUNCTION TEST/
	004630	051101	047111	020103			
	004636	052506	041516	044524			
	004644	047117	052040	051505			
	004652	000124					
4367	004654	050116	020122	042524	EM11:	.ASCIZ	/NPR TEST/
	004662	052123	000				
4368	004665	115	046125	044524	EM12:	.ASCIZ	/MULTIPLE NPR TEST/
	004672	046120	020105	050116			
	004700	020122	042524	052123			
	004706	000					
4369	004707	116	047117	042440	EM13:	.ASCIZ	/NON EX MEM FAILED/
	004714	020130	042515	020115			
	004722	040506	046111	042105			
	004730	000					
4370	004731	120	047522	051107	EM14:	.ASCIZ	/PROGRAM CLOCK TEST/
	004736	046501	041440	047514			
	004744	045503	052040	051505			
	004752	000124					
4371	004754	046101	020125	052506	EM15:	.ASCIZ	/ALU FUNCTION WITH C BIT CLEAR TEST/
	004762	041516	044524	047117			
	004770	053440	052111	020110			
	004776	020103	044502	020124			
	005004	046103	040505	020122			
	005012	042524	052123	000			

Address	Code	Hex	Hex	Hex	Description
4373	005017	12C	053517	051105	EM16: .ASCIZ /POWER FAIL: BUS INIT WAS NOT BLOCKED/
	005024	043040	044501	035114	
	005032	041040	051525	044440	
	005040	044516	020124	040527	
	005046	020123	047516	020124	
	005054	046102	041517	042513	
	005062	000104			
4374	005064				EM35:
4375	005064	047506	041522	020105	EM17: .ASCIZ /FORCE POWER FAIL ERROR/
	005072	047520	042527	020122	
	005100	040506	046111	042440	
	005106	051122	051117	000	
4376	005113	116	044517	042523	EM20: .ASCIZ /NOISE TEST ON IBUS*,IBUS,SPAD,MEMORY/
	005120	052040	051505	020124	
	005126	047117	044440	052502	
	005134	025123	044454	052502	
	005142	026123	050123	042101	
	005150	046454	046505	051117	
	005156	000131			
4377	005160	046101	020125	020103	EM21: .ASCIZ /ALU C BIT TEST FAILURE/
	005166	044502	020124	042524	
	005174	052123	043040	044501	
	005202	052514	042522	000	
4378	005207	124	046511	020105	EM22: .ASCIZ /TIME OUT ERROR/
	005214	052517	020124	051105	
	005222	047522	000122		
4379	005226	046101	020125	052506	EM23: .ASCIZ /ALU FUNCTION TEST WITH C BIT SET/
	005234	041516	044524	047117	
	005242	052040	051505	020124	
	005250	044527	044124	041440	
	005256	041040	052111	051440	
	005264	052105	000		
4380	005267	125	041520	051440	EM24: .ASCIZ /UPC SEQUENCE ERROR/
	005274	050505	042525	041516	
	005302	020105	051105	047522	
	005310	000122			
4381	005312	050125	043040	044501	EM31: .ASCIZ "UP FAILED TO INTERRUPT"
	005320	042514	020104	047524	
	005326	044440	052116	051105	
	005334	052522	052120	000	
4382	005341	125	020120	047111	EM32: .ASCIZ "UP INTERRUPTED TO WRONG VECTOR"
	005346	042524	051122	050125	
	005354	042524	020104	047524	
	005362	053440	047522	043516	
	005370	053040	041505	047524	
	005376	000122			
4383	005400	047125	054105	042520	EM33: .ASCIZ "UNEXPECTED INTERRUPT FROM UP"
	005406	052103	042105	044440	
	005414	052116	051105	052522	
	005422	052120	043040	047522	
	005430	020115	050125	000	
4384	005435	101	052514	043040	EM34: .ASCIZ "ALU FLAG TEST"
	005442	040514	020107	042524	
	005450	052123	000		
4385	005453	110	046105	020114	EM25: .ASCIZ /HELL RAISER TEST/
	005460	040522	051511	051105	



4386	005466	052040	051505	000124		
	005474	040515	047111	040524	EM26:	.ASCIZ /MAINTANCE REGISTER ERROR/
	005502	041516	020105	042522		
	005510	044507	052123	051105		
	005516	042440	051122	051117		
	005524	000				
4387	005525	111	052502	025123	EM27:	.ASCIZ '*IBUS* WRITE/READ ERROR'
	005532	053440	044522	042524		
	005540	051057	040505	020104		
4388	005546	051105	047522	000122	EM28:	.ASCIZ /INSTRUCTION TEST FAILURE/
	005554	047111	052123	052522		
	005562	052103	047511	020116		
	005570	042524	052123	043040		
	005576	044501	052514	042522		
	005604	000				
4389	005605	111	052502	027523	EM29:	.ASCIZ '*IBUS/OBUS WRITE/READ ERROR'
	005612	041117	051525	053440		
	005620	044522	042524	051057		
	005626	040505	020104	051105		
	005634	047522	000122			
4390						
4391	005640	047511	020120	040515	EM36:	.ASCIZ '*IOP MAIN MEM. LOAD ERROR-RUN MCPU MEM. DIAG.*
	005646	047111	046440	046505		
	005654	020056	047514	042101		
	005662	042440	051122	051117		
	005670	051055	047125	046440		
	005676	050103	020125	042515		
	005704	027115	042040	040511		
	005712	027107	000			
4392	005715	000			EM37:	.ASCIZ //
4393						
4394						

4396

CZDMPCO M8207 STATIC DIAG #1  
CZDMPC.P11 13-JUL-81 15:46

MACY11 30A(1052) 13-JUL-81 16:06 I 6 PAGE 38  
GLOBAL ERROR REPORT SECTION

SEQ 0073

4398 005716 000

DHO: .ASCIZ //

4400	005717	107	047517	020104	DH1:	.ASCIZ	/GOOD	BAD	REGISTER/
	005724	020040	041040	042101					
	005732	020040	020040	051040					
	005740	043505	051511	042524					
	005746	000122							
4401	005750	047507	042117	020040	DH2:	.ASCIZ	/GOOD	BAD/	
	005756	020040	040502	000104					
4402	005764	047507	042117	020040	DH3:	.ASCIZ	/GOOD	BAD	ADDRESS/
	005772	020040	040502	020104					
	006000	020040	020040	042101					
	006006	051104	051505	000123					
4403	006014	047507	042117	020040	DH4:	.ASCIZ	/GOOD	BAD/	
	006022	020040	040502	000104					
4404	006030	042522	027107	042440	DH27:	.ASCIZ	/REG. EXPECTED FOUND/		
	006036	050130	041505	042524					
	006044	020104	047506	047125					
	006052	000104							

4405  
4406  
4407  
4408  
4409

.EVEN

CZDMPCO MB207 STATIC DIAG #1  
CZDMPCC.P11 13-JUL-81 15:46

MACY11 30A(1052) 13-JUL-81 16:06 <sup>K 6</sup> PAGE 40  
GLOBAL ERROR REPORT SECTION

SEQ 0075

4411  
4412  
4413

CZDMPCO MB207 STATIC DIAG #1  
CZDMPC.P11 13-JUL-81 15:46

MACY11 30A(1052) 13-JUL-81 16:06 L 6 PAGE 41  
GLOBAL ERROR REPORT SECTION

SEQ 0076

4415  
4416

-----  
: MACRO'S NEEDED TO REPORT ERRORS

4418  
4419  
4420  
4421  
4422  
4423  
4424  
4425  
4426

```
-----  
.MACRO MDT0  
.ENDM  
  
.MACRO MDT1  
PRINTB #TFM1,$GDDAT,$BDDAT,$GDADR  
.ENDM  
  
.MACRO MDT2
```

4428  
4429  
4430  
4431  
4432  
4433

PRINTB #TFM2,\$GDDAT,\$BDDAT  
.ENDM  
.MACRO MDT5  
PRINTB #TFM5,\$GDDAT,\$BDDAT  
.ENDM



4435  
4436  
4437  
4438  
4439  
4440  
4441  
4442  
4443  
4444  
4445  
4446  
4447  
4448

```
.MACRO MDT27  
PRINTB #TFM27,MRO,$GDDAT,$BDDAT  
.ENDM  
  
.MACRO $MD,ERNB,ERHM,ERFM  
.NLIST  
: ERNB = ERROR NUMBER  
: ERFM = FORMAT NUMBER  
: ERHM = HEADER NUMBER  
.LIST  
BGNMSG ERR'ERNB'  
PRINTB #FM1,#DH'ERHM'  
MDT'ERFM'  
ENDMSG
```

```
4450 .ENDM
4451
4452
4453
4454
4455 006054
(4) 006054
(9) 006054 012746 005750
(8) 006060 012746 004114
(7) 006064 012746 000002
(4) 006070 010600
(5) 006072 104414
(5) 006074 062706 000006
(11) 006100 013746 002640
(10) 006104 013746 002636
(9) 006110 012746 004146
(8) 006114 012746 000003
(5) 006120 010600
(6) 006122 104414
(6) 006124 062706 000010
(4) 006130
(4) 006130 104423
4456 006132
(4) 006132
(9) 006132 012746 005750
(8) 006136 012746 004114
(7) 006142 012746 000002
(4) 006146 010600
(5) 006150 104414
(5) 006152 062706 000006
(11) 006156 013746 002640
(10) 006162 013746 002636
(9) 006166 012746 004146
(8) 006172 012746 000003
(5) 006176 010600
(6) 006200 104414
(6) 006202 062706 000010
(4) 006206
(4) 006206 104423
4457 006210
(4) 006210
(9) 006210 012746 005750
(8) 006214 012746 004114
(7) 006220 012746 000002
(4) 006224 010600
(5) 006226 104414
(5) 006230 062706 000006
(11) 006234 013746 002640
(10) 006240 013746 002636
(9) 006244 012746 004146
(8) 006250 012746 000003
(5) 006254 010600
(6) 006256 104414
(6) 006260 062706 000010
(4) 006264
(4) 006264 104423
```

```
ERR1:: $MD 1,2,2
MOV #DH2,-(SP)
MOV #FM1,-(SP)
MOV #2,-(SP)
MOV SP,R0
TRAP C$PNTB
ADD #6,SP
MOV $BDDAT,-(SP)
MOV $GDDAT,-(SP)
MOV #TFM2,-(SP)
MOV #3,-(SP)
MOV SP,R0
TRAP C$PNTB
ADD #10,SP
L10003: TRAP C$MSG
$MD 2,2,2
ERR2:: MOV #DH2,-(SP)
MOV #FM1,-(SP)
MOV #2,-(SP)
MOV SP,R0
TRAP C$PNTB
ADD #6,SP
MOV $BDDAT,-(SP)
MOV $GDDAT,-(SP)
MOV #TFM2,-(SP)
MOV #3,-(SP)
MOV SP,R0
TRAP C$PNTB
ADD #10,SP
L10004: TRAP C$MSG
$MD 3,2,2
ERR3:: MOV #DH2,-(SP)
MOV #FM1,-(SP)
MOV #2,-(SP)
MOV SP,R0
TRAP C$PNTB
ADD #6,SP
MOV $BDDAT,-(SP)
MOV $GDDAT,-(SP)
MOV #TFM2,-(SP)
MOV #3,-(SP)
MOV SP,R0
TRAP C$PNTB
ADD #10,SP
L10005: TRAP C$MSG
```

4458 006266  
(4) 006266  
(9) 006266 012746 005717  
(8) 006272 012746 004114  
(7) 006276 012746 000002  
(4) 006302 010600  
(5) 006304 104414  
(5) 006306 062706 000006  
(12) 006312 013746 002632  
(11) 006316 013746 002640  
(10) 006322 013746 002636  
(9) 006326 012746 004123  
(8) 006332 012746 000004  
(5) 006336 010600  
(6) 006340 104414  
(6) 006342 062706 000012  
(4) 006346  
(4) 006346 104423  
4459 006350  
(4) 006350  
(9) 006350 012746 005717  
(8) 006354 012746 004114  
(7) 006360 012746 000002  
(4) 006364 010600  
(5) 006366 104414  
(5) 006370 062706 000006  
(12) 006374 013746 002632  
(11) 006400 013746 002640  
(10) 006404 013746 002636  
(9) 006410 012746 004123  
(8) 006414 012746 000004  
(5) 006420 010600  
(6) 006422 104414  
(6) 006424 062706 000012  
(4) 006430  
(4) 006430 104423  
4460 006432  
(4) 006432  
(9) 006432 012746 005764  
(8) 006436 012746 004114  
(7) 006442 012746 000002  
(4) 006446 010600  
(5) 006450 104414  
(5) 006452 062706 000006  
(12) 006456 013746 002632  
(11) 006462 013746 002640  
(10) 006466 013746 002636  
(9) 006472 012746 004123  
(8) 006476 012746 000004  
(5) 006502 010600  
(6) 006504 104414  
(6) 006506 062706 000012  
(4) 006512  
(4) 006512 104423  
4461 006514  
(4) 006514

ERR4:: SMD 4,1,1  
MOV #DH1,-(SP)  
MOV #FM1,-(SP)  
MOV #2,-(SP)  
MOV SP,R0  
TRAP C\$PNTB  
ADD #6,SP  
MOV \$GDADR,-(SP)  
MOV \$BDDAT,-(SP)  
MOV \$GDDAT,-(SP)  
MOV #TFM1,-(SP)  
MOV #4,-(SP)  
MOV SP,R0  
TRAP C\$PNTB  
ADD #12,SP  
L10006: TRAP C\$MSG  
ERR5:: SMD 5,1,1  
MOV #DH1,-(SP)  
MOV #FM1,-(SP)  
MOV #2,-(SP)  
MOV SP,R0  
TRAP C\$PNTB  
ADD #6,SP  
MOV \$GDADR,-(SP)  
MOV \$BDDAT,-(SP)  
MOV \$GDDAT,-(SP)  
MOV #TFM1,-(SP)  
MOV #4,-(SP)  
MOV SP,R0  
TRAP C\$PNTB  
ADD #12,SP  
L10007: TRAP C\$MSG  
ERR6:: SMD 6,3,1  
MOV #DH3,-(SP)  
MOV #FM1,-(SP)  
MOV #2,-(SP)  
MOV SP,R0  
TRAP C\$PNTB  
ADD #6,SP  
MOV \$GDADR,-(SP)  
MOV \$BDDAT,-(SP)  
MOV \$GDDAT,-(SP)  
MOV #TFM1,-(SP)  
MOV #4,-(SP)  
MOV SP,R0  
TRAP C\$PNTB  
ADD #12,SP  
L10010: TRAP C\$MSG  
ERR7:: SMD 7,3,1

(9)	006514	012746	005764	MOV	#DH3,-(SP)
(8)	006520	012746	004114	MOV	#FM1,-(SP)
(7)	006524	012746	000002	MOV	#2,-(SP)
(4)	006530	010600		MOV	SP,R0
(5)	006532	104414		TRAP	C\$PNTB
(5)	006534	062706	000006	ADD	#6,SP
(12)	006540	013746	002632	MOV	\$GDADR,-(SP)
(11)	006544	013746	002640	MOV	\$BDDAT,-(SP)
(10)	006550	013746	002636	MOV	\$GDDAT,-(SP)
(9)	006554	012746	004123	MOV	#TFM1,-(SP)
(8)	006560	012746	000004	MOV	#4,-(SP)
(5)	006564	010600		MOV	SP,R0
(6)	006566	104414		TRAP	C\$PNTB
(6)	006570	062706	000012	ADD	#12,SP
(4)	006574			L10011:	
(4)	006574	104423		TRAP	C\$MSG
4462	006576			\$MD	10,3,1
(4)	006576			ERR10::	
(9)	006576	012746	005764	MOV	#DH3,-(SP)
(8)	006602	012746	004114	MOV	#FM1,-(SP)
(7)	006606	012746	000002	MOV	#2,-(SP)
(4)	006612	010600		MOV	SP,R0
(5)	006614	104414		TRAP	C\$PNTB
(5)	006616	062706	000006	ADD	#6,SP
(12)	006622	013746	002632	MOV	\$GDADR,-(SP)
(11)	006626	013746	002640	MOV	\$BDDAT,-(SP)
(10)	006632	013746	002636	MOV	\$GDDAT,-(SP)
(9)	006636	012746	004123	MOV	#TFM1,-(SP)
(8)	006642	012746	000004	MOV	#4,-(SP)
(5)	006646	010600		MOV	SP,R0
(6)	006650	104414		TRAP	C\$PNTB
(6)	006652	062706	000012	ADD	#12,SP
(4)	006656			L10012:	
(4)	006656	104423		TRAP	C\$MSG
4463	006660			\$MD	11,2,2
(4)	006660			ERR11::	
(9)	006660	012746	005750	MOV	#DH2,-(SP)
(8)	006664	012746	004114	MOV	#FM1,-(SP)
(7)	006670	012746	000002	MOV	#2,-(SP)
(4)	006674	010600		MOV	SP,R0
(5)	006676	104414		TRAP	C\$PNTB
(5)	006700	062706	000006	ADD	#6,SP
(11)	006704	013746	002640	MOV	\$BDDAT,-(SP)
(10)	006710	013746	002636	MOV	\$GDDAT,-(SP)
(9)	006714	012746	004146	MOV	#TFM2,-(SP)
(8)	006720	012746	000003	MOV	#3,-(SP)
(5)	006724	010600		MOV	SP,R0
(6)	006726	104414		TRAP	C\$PNTB
(6)	006730	062706	000010	ADD	#10,SP
(4)	006734			L10013:	
(4)	006734	104423		TRAP	C\$MSG
4464	006736			\$MD	12,2,2
(4)	006736			ERR12::	
(9)	006736	012746	005750	MOV	#DH2,-(SP)
(8)	006742	012746	004114	MOV	#FM1,-(SP)
(7)	006746	012746	000002	MOV	#2,-(SP)

(4)	006752	010600		MOV	SP,R0
(5)	006754	104414		TRAP	C\$PNTB
(5)	006756	062706	000006	ADD	#6,SP
(11)	006762	013746	002640	MOV	\$BDDAT,-(SP)
(10)	006766	013746	002636	MOV	\$GDDAT,-(SP)
(9)	006772	012746	004146	MOV	#TFM2,-(SP)
(8)	006776	012746	000003	MOV	#3,-(SP)
(5)	007002	010600		MOV	SP,R0
(6)	007004	104414		TRAP	C\$PNTB
(6)	007006	062706	000010	ADD	#10,SP
(4)	007012				
(4)	007012	104423		L10014:	TRAP C\$MSG
4465	007014				\$MD 13,0,0
(4)	007014			ERR13::	
(9)	007014	012746	005716	MOV	#DH0,-(SP)
(8)	007020	012746	004114	MOV	#FM1,-(SP)
(7)	007024	012746	000002	MOV	#2,-(SP)
(4)	007030	010600		MOV	SP,R0
(5)	007032	104414		TRAP	C\$PNTB
(5)	007034	062706	000006	ADD	#6,SP
(4)	007040				
(4)	007040	104423		L10015:	TRAP C\$MSG

4467 007042  
(4) 007042  
(9) 007042 012746 005750  
(8) 007046 012746 004114  
(7) 007052 012746 000002  
(4) 007056 010600  
(5) 007060 104414  
(5) 007062 062706 000006  
(11) 007066 013746 002640  
(10) 007072 013746 002636  
(9) 007076 012746 004146  
(8) 007102 012746 000003  
(5) 007106 010600  
(6) 007110 104414  
(6) 007112 062706 000010  
(4) 007116  
(4) 007116 104423

SMD 14,2,2  
ERR14::  
MOV #DH2,-(SP)  
MOV #FM1,-(SP)  
MOV #2,-(SP)  
MOV SP,R0  
TRAP C\$PNTB  
ADD #6,SP  
MOV \$BDDAT,-(SP)  
MOV \$GDDAT,-(SP)  
MOV #TFM2,-(SP)  
MOV #3,-(SP)  
MOV SP,R0  
TRAP C\$PNTB  
ADD #10,SP  
L10016:  
TRAP C\$MSG

4469 007120  
(4) 007120  
(9) 007120 012746 006014  
(8) 007124 012746 004114  
(7) 007130 012746 000002  
(4) 007134 010600  
(5) 007136 104414  
(5) 007140 062706 000006  
(11) 007144 013746 002640  
(10) 007150 013746 002636  
(9) 007154 012746 004163  
(8) 007160 012746 000003  
(5) 007164 010600  
(6) 007166 104414  
(6) 007170 062706 000010  
(4) 007174  
(4) 007174 104423  
4470 007176  
(4) 007176  
(9) 007176 012746 005716  
(8) 007202 012746 004114  
(7) 007206 012746 000002  
(4) 007212 010600  
(5) 007214 104414  
(5) 007216 062706 000006  
(4) 007222  
(4) 007222 104423  
4471 007224  
(4) 007224  
(9) 007224 012746 005716  
(8) 007230 012746 004114  
(7) 007234 012746 000002  
(4) 007240 010600  
(5) 007242 104414  
(5) 007244 062706 000006  
(4) 007250  
(4) 007250 104423  
4472 007252  
(4) 007252  
(9) 007252 012746 005750  
(8) 007256 012746 004114  
(7) 007262 012746 000002  
(4) 007266 010600  
(5) 007270 104414  
(5) 007272 062706 000006  
(11) 007276 013746 002640  
(10) 007302 013746 002636  
(9) 007306 012746 004146  
(8) 007312 012746 000003  
(5) 007316 010600  
(6) 007320 104414  
(6) 007322 062706 000010  
(4) 007326  
(4) 007326 104423  
4473 007330  
(4) 007330

ERR15:: SMD 15,4,5  
MOV #DH4,-(SP)  
MOV #FM1,-(SP)  
MOV #2,-(SP)  
MOV SP,R0  
TRAP C\$PNTB  
ADD #6,SP  
MOV \$BDDAT,-(SP)  
MOV \$GDDAT,-(SP)  
MOV #TFM5,-(SP)  
MOV #3,-(SP)  
MOV SP,R0  
TRAP C\$PNTB  
ADD #10,SP  
L10017: TRAP C\$MSG  
SMD 16,0,0  
ERR16:: MOV #DH0,-(SP)  
MOV #FM1,-(SP)  
MOV #2,-(SP)  
MOV SP,R0  
TRAP C\$PNTB  
ADD #6,SP  
L10020: TRAP C\$MSG  
SMD 17,0,0  
ERR17:: MOV #DH0,-(SP)  
MOV #FM1,-(SP)  
MOV #2,-(SP)  
MOV SP,R0  
TRAP C\$PNTB  
ADD #6,SP  
L10021: TRAP C\$MSG  
SMD 20,2,2  
ERR20:: MOV #DH2,-(SP)  
MOV #FM1,-(SP)  
MOV #2,-(SP)  
MOV SP,R0  
TRAP C\$PNTB  
ADD #6,SP  
MOV \$BDDAT,-(SP)  
MOV \$GDDAT,-(SP)  
MOV #TFM2,-(SP)  
MOV #3,-(SP)  
MOV SP,R0  
TRAP C\$PNTB  
ADD #10,SP  
L10022: TRAP C\$MSG  
SMD 21,0,0  
ERR21::

(9)	007330	012746	005716	MOV	#DH0,-(SP)
(8)	007334	012746	004114	MOV	#FM1,-(SP)
(7)	007340	012746	000002	MOV	#2,-(SP)
(4)	007344	010600		MOV	SP,R0
(5)	007346	104414		TRAP	C\$PNTB
(5)	007350	062706	000006	ADD	#6,SP
(4)	007354			L10023:	
(4)	007354	104423		TRAP	C\$MSG
4474	007356			\$MD	22,0,0
(4)	007356			ERR22::	
(9)	007356	012746	005716	MOV	#DH0,-(SP)
(8)	007362	012746	004114	MOV	#FM1,-(SP)
(7)	007366	012746	000002	MOV	#2,-(SP)
(4)	007372	010600		MOV	SP,R0
(5)	007374	104414		TRAP	C\$PNTB
(5)	007376	062706	000006	ADD	#6,SP
(4)	007402			L10024:	
(4)	007402	104423		TRAP	C\$MSG
4475	007404			\$MD	23,4,5
(4)	007404			ERR23::	
(9)	007404	012746	006014	MOV	#DH4,-(SP)
(8)	007410	012746	004114	MOV	#FM1,-(SP)
(7)	007414	012746	000002	MOV	#2,-(SP)
(4)	007420	010600		MOV	SP,R0
(5)	007422	104414		TRAP	C\$PNTB
(5)	007424	062706	000006	ADD	#6,SP
(11)	007430	013746	002640	MOV	\$BDDAT,-(SP)
(10)	007434	013746	002636	MOV	\$GDDAT,-(SP)
(9)	007440	012746	004163	MOV	#TFM5,-(SP)
(8)	007444	012746	000003	MOV	#3,-(SP)
(5)	007450	010600		MOV	SP,R0
(6)	007452	104414		TRAP	C\$PNTB
(6)	007454	062706	000010	ADD	#10,SP
(4)	007460			L10025:	
(4)	007460	104423		TRAP	C\$MSG
4476	007462			\$MD	24,0,0
(4)	007462			ERR24::	
(9)	007462	012746	005716	MOV	#DH0,-(SP)
(8)	007466	012746	004114	MOV	#FM1,-(SP)
(7)	007472	012746	000002	MOV	#2,-(SP)
(4)	007476	010600		MOV	SP,R0
(5)	007500	104414		TRAP	C\$PNTB
(5)	007502	062706	000006	ADD	#6,SP
(4)	007506			L10026:	
(4)	007506	104423		TRAP	C\$MSG
4477	007510			\$MD	25,2,2
(4)	007510			ERR25::	
(9)	007510	012746	005750	MOV	#DH2,-(SP)
(8)	007514	012746	004114	MOV	#FM1,-(SP)
(7)	007520	012746	000002	MOV	#2,-(SP)
(4)	007524	010600		MOV	SP,R0
(5)	007526	104414		TRAP	C\$PNTB
(5)	007530	062706	000006	ADD	#6,SP
(11)	007534	013746	002640	MOV	\$BDDAT,-(SP)
(10)	007540	013746	002636	MOV	\$GDDAT,-(SP)
(9)	007544	012746	004146	MOV	#TFM2,-(SP)



(8)	007550	012746	000003		MOV	#3,-(SP)
(5)	007554	010600			MOV	SP,R0
(6)	007556	104414			TRAP	C\$PNTB
(6)	007560	062706	000010		ADD	#10,SP
(4)	007564			L10027:		
(4)	007564	104423			TRAP	C\$MSG
4478	007566				\$MD	26,2,2
(4)	007566			ERR26::		
(9)	007566	012746	005750		MOV	#DH2,-(SP)
(8)	007572	012746	004114		MOV	#FM1,-(SP)
(7)	007576	012746	000002		MOV	#2,-(SP)
(4)	007602	010600			MOV	SP,R0
(5)	007604	104414			TRAP	C\$PNTB
(5)	007606	062706	000006		ADD	#6,SP
(11)	007612	013746	002640		MOV	\$BDDAT,-(SP)
(10)	007616	013746	002636		MOV	\$GDDAT,-(SP)
(9)	007622	012746	004146		MOV	#TFM2,-(SP)
(8)	007626	012746	000003		MOV	#3,-(SP)
(5)	007632	010600			MOV	SP,R0
(6)	007634	104414			TRAP	C\$PNTB
(6)	007636	062706	000010		ADD	#10,SP
(4)	007642			L10030:		
(4)	007642	104423			TRAP	C\$MSG
4479	007644				\$MD	27,27,27
(4)	007644			ERR27::		
(9)	007644	012746	006030		MOV	#DH27,-(SP)
(8)	007650	012746	004114		MOV	#FM1,-(SP)
(7)	007654	012746	000002		MOV	#2,-(SP)
(4)	007660	010600			MOV	SP,R0
(5)	007662	104414			TRAP	C\$PNTB
(5)	007664	062706	000006		ADD	#6,SP
(12)	007670	013746	002640		MOV	\$BDDAT,-(SP)
(11)	007674	013746	002636		MOV	\$GDDAT,-(SP)
(10)	007700	013746	002624		MOV	MRO,-(SP)
(9)	007704	012746	004200		MOV	#TFM27,-(SP)
(8)	007710	012746	000004		MOV	#4,-(SP)
(5)	007714	010600			MOV	SP,R0
(6)	007716	104414			TRAP	C\$PNTB
(6)	007720	062706	000012		ADD	#12,SP
(4)	007724			L10031:		
(4)	007724	104423			TRAP	C\$MSG
4480	007726				\$MD	28,2,2
(4)	007726			ERR28::		
(9)	007726	012746	005750		MOV	#DH2,-(SP)
(8)	007732	012746	004114		MOV	#FM1,-(SP)
(7)	007736	012746	000002		MOV	#2,-(SP)
(4)	007742	010600			MOV	SP,R0
(5)	007744	104414			TRAP	C\$PNTB
(5)	007746	062706	000006		ADD	#6,SP
(11)	007752	013746	002640		MOV	\$BDDAT,-(SP)
(10)	007756	013746	002636		MOV	\$GDDAT,-(SP)
(9)	007762	012746	004146		MOV	#TFM2,-(SP)
(8)	007766	012746	000003		MOV	#3,-(SP)
(5)	007772	010600			MOV	SP,R0
(6)	007774	104414			TRAP	C\$PNTB
(6)	007776	062706	000010		ADD	#10,SP

(4) 010002  
(4) 010002 104423  
4481 010004  
(4) 010004  
(9) 010004 012746 006030  
(8) 010010 012746 004114  
(7) 010014 012746 000002  
(4) 010020 010600  
(5) 010022 104414  
(5) 010024 062706 000006  
(12) 010030 013746 002640  
(11) 010034 013746 002636  
(10) 010040 013746 002624  
(9) 010044 012746 004200  
(8) 010050 012746 000004  
(5) 010054 010600  
(6) 010056 104414  
(6) 010060 062706 000012  
(4) 010064  
(4) 010064 104423  
4482 010066  
(4) 010066  
(9) 010066 012746 005750  
(8) 010072 012746 004114  
(7) 010076 012746 000002  
(4) 010102 010600  
(5) 010104 104414  
(5) 010106 062706 000006  
(11) 010112 013746 002640  
(10) 010116 013746 002636  
(9) 010122 012746 004146  
(8) 010126 012746 000003  
(5) 010132 010600  
(6) 010134 104414  
(6) 010136 062706 000010  
(4) 010142  
(4) 010142 104423  
4483 010144  
(4) 010144  
(9) 010144 012746 005716  
(8) 010150 012746 004114  
(7) 010154 012746 000002  
(4) 010160 010600  
(5) 010162 104414  
(5) 010164 062706 000006  
(4) 010170  
(4) 010170 104423  
4484 010172  
(4) 010172  
(9) 010172 012746 005716  
(8) 010176 012746 004114  
(7) 010202 012746 000002  
(4) 010206 010600  
(5) 010210 104414  
(5) 010212 062706 000006  
(4) 010216

L10032:  
TRAP C\$MSG  
\$MD 29,27,27  
ERR29::  
MOV #DH27,-(SP)  
MOV #FM1,-(SP)  
MOV #2,-(SP)  
MOV SP,R0  
TRAP C\$PNTB  
ADD #6,SP  
MOV \$BDDAT,-(SP)  
MOV \$GDDAT,-(SP)  
MOV MRO,-(SP)  
MOV #TFM27,-(SP)  
MOV #4,-(SP)  
MOV SP,R0  
TRAP C\$PNTB  
ADD #12,SP  
L10033:  
TRAP C\$MSG  
\$MD 30,2,2  
ERR30::  
MOV #DH2,-(SP)  
MOV #FM1,-(SP)  
MOV #2,-(SP)  
MOV SP,R0  
TRAP C\$PNTB  
ADD #6,SP  
MOV \$BDDAT,-(SP)  
MOV \$GDDAT,-(SP)  
MOV #TFM2,-(SP)  
MOV #3,-(SP)  
MOV SP,R0  
TRAP C\$PNTB  
ADD #10,SP  
L10034:  
TRAP C\$MSG  
\$MD 31,0,0  
ERR31::  
MOV #DH0,-(SP)  
MOV #FM1,-(SP)  
MOV #2,-(SP)  
MOV SP,R0  
TRAP C\$PNTB  
ADD #6,SP  
L10035:  
TRAP C\$MSG  
\$MD 32,0,0  
ERR32::  
MOV #DH0,-(SP)  
MOV #FM1,-(SP)  
MOV #2,-(SP)  
MOV SP,R0  
TRAP C\$PNTB  
ADD #6,SP  
L10036:

(4)	010216	104423		TRAP	C\$MSG
4485	010220			\$MD	33,2,2
(4)	010220			ERR33::	
(9)	010220	012746	005750	MOV	#DH2,-(SP)
(8)	010224	012746	004114	MOV	#FM1,-(SP)
(7)	010230	012746	000002	MOV	#2,-(SP)
(4)	010234	010600		MOV	SP,R0
(5)	010236	104414		TRAP	C\$PNTB
(5)	010240	062706	000006	ADD	#6,SP
(11)	010244	013746	002640	MOV	\$BDDAT,-(SP)
(10)	010250	013746	002636	MOV	\$GDDAT,-(SP)
(9)	010254	012746	004146	MOV	#TFM2,-(SP)
(8)	010260	012746	000003	MOV	#3,-(SP)
(5)	010264	010600		MOV	SP,R0
(6)	010266	104414		TRAP	C\$PNTB
(6)	010270	062706	000010	ADD	#10,SP
(4)	010274			L10037:	
(4)	010274	104423		TRAP	C\$MSG
4486	010276			\$MD	34,2,2
(4)	010276			ERR34::	
(9)	010276	012746	005750	MOV	#DH2,-(SP)
(8)	010302	012746	004114	MOV	#FM1,-(SP)
(7)	010306	012746	000002	MOV	#2,-(SP)
(4)	010312	010600		MOV	SP,R0
(5)	010314	104414		TRAP	C\$PNTB
(5)	010316	062706	000006	ADD	#6,SP
(11)	010322	013746	002640	MOV	\$BDDAT,-(SP)
(10)	010326	013746	002636	MOV	\$GDDAT,-(SP)
(9)	010332	012746	004146	MOV	#TFM2,-(SP)
(8)	010336	012746	000003	MOV	#3,-(SP)
(5)	010342	010600		MOV	SP,R0
(6)	010344	104414		TRAP	C\$PNTB
(6)	010346	062706	000010	ADD	#10,SP
(4)	010352			L10040:	
(4)	010352	104423		TRAP	C\$MSG
4487	010354			\$MD	35,2,2
(4)	010354			ERR35::	
(9)	010354	012746	005750	MOV	#DH2,-(SP)
(8)	010360	012746	004114	MOV	#FM1,-(SP)
(7)	010364	012746	000002	MOV	#2,-(SP)
(4)	010370	010600		MOV	SP,R0
(5)	010372	104414		TRAP	C\$PNTB
(5)	010374	062706	000006	ADD	#6,SP
(11)	010400	013746	002640	MOV	\$BDDAT,-(SP)
(10)	010404	013746	002636	MOV	\$GDDAT,-(SP)
(9)	010410	012746	004146	MOV	#TFM2,-(SP)
(8)	010414	012746	000003	MOV	#3,-(SP)
(5)	010420	010600		MOV	SP,R0
(6)	010422	104414		TRAP	C\$PNTB
(6)	010424	062706	000010	ADD	#10,SP
(4)	010430			L10041:	
(4)	010430	104423		TRAP	C\$MSG
4488	010432			\$MD	36,2,2
(4)	010432			ERR36::	
(9)	010432	012746	005750	MOV	#DH2,-(SP)
(8)	010436	012746	004114	MOV	#FM1,-(SP)

(7)	010442	012746	000002	MOV	#2,-(SP)
(4)	010446	010600		MOV	SP,R0
(5)	010450	104414		TRAP	C\$PNTB
(5)	010452	062706	000006	ADD	#6,SP
(11)	010456	013746	002640	MOV	\$BDDAT,-(SP)
(10)	010462	013746	002636	MOV	\$GDDAT,-(SP)
(9)	010466	012746	004146	MOV	#TFM2,-(SP)
(8)	010472	012746	000003	MOV	#3,-(SP)
(5)	010476	010600		MOV	SP,R0
(6)	010500	104414		TRAP	C\$PNTB
(6)	010502	062706	000010	ADD	#10,SP
(4)	010506				
(4)	010506	104423		L10042:	TRAP C\$MSG
4489					
4490	010510			BGNMSG	ERR37
(3)	010510			ERR37::	
4491	010510			PRINTF	#FM1,#EM1
(8)	010510	012746	004261	MOV	#EM1,-(SP)
(7)	010514	012746	004114	MOV	#FM1,-(SP)
(6)	010520	012746	000002	MOV	#2,-(SP)
(3)	010524	010600		MOV	SP,R0
(4)	010526	104417		TRAP	C\$PNTF
(4)	010530	062706	000006	ADD	#6,SP
4492	010534			PRINTF	#TFM37,\$GDADR
(8)	010534	013746	002632	MOV	\$GDADR,-(SP)
(7)	010540	012746	004225	MOV	#TFM37,-(SP)
(6)	010544	012746	000002	MOV	#2,-(SP)
(3)	010550	010600		MOV	SP,R0
(4)	010552	104417		TRAP	C\$PNTF
(4)	010554	062706	000006	ADD	#6,SP
4493	010560			ENDMSG	
(3)	010560			L10043:	
(3)	010560	104423		TRAP	C\$MSG
4494					
4495					
4496					

4498  
4499  
4500  
4501  
4502  
4503  
4504  
4505  
4506  
(3)  
4507  
4513  
4514  
(4)  
(3)  
4515  
4522  
4523  
(3)  
(3)  
4524  
4525  
4526  
4527  
4528

010562  
010562  
  
010562  
010562 000167  
010564 000000  
  
010566  
010566  
010566 104425

.SBTTL REPORT CODING SECTION

+++  
: THE REPORT CODING SECTION CONTAINS THE  
: 'PRINTS' CALLS THAT GENERATE STATISTICAL REPORTS.  
:--

LSRPT:: BGNRPT

EXIT RPT  
.WORD JSJMP  
.WORD L10044-2-

ENDRPT  
L10044: TRAP CSRPT

4530  
4531  
4532  
4533  
4534  
4535  
4536  
4537 010570  
(3) 010570  
4538  
4539  
4540 010570 012705 003130  
4541  
4542 010574 010637 002554  
4543 010600 005737 002646  
4544 010604 001011  
4545 010606 013737 000004 002650  
4546 010614 013737 000006 002652  
4547 010622 012737 000001 002646  
4548 010630 013737 002650 000004  
4549 010636 013737 002652 000006  
4550  
4551 010644  
(3) 010644 012700 000040  
(3) 010650 104447  
4552 010652  
(2) 010652 103414  
4553  
4554 010654  
(3) 010654 012700 000035  
(3) 010660 104447  
4555 010662  
(2) 010662 103410  
4556  
4557 010664  
(3) 010664 012700 000036  
(3) 010670 104447  
4558 010672  
(2) 010672 103570  
4559  
4560  
4561 010674  
(3) 010674 012700 000037  
(3) 010700 104447  
4562 010702  
(2) 010702 103003  
4563 010704  
4564  
4565 010704 012737 177777 002552  
4566  
4567  
4568  
4569  
4570 010712  
4571 010712 005237 002552  
4572 010716 023737 002552 002012

```
.SBTTL INITIALIZE SECTION
://////
:/ THE INITIALIZE SECTION CONTAINS THE CODING THAT IS PERFORMED
:/ AT THE BEGINNING OF EACH PASS.
://////

      BGNINIT
L$INIT::

;INITIALIZE SUBROUTINE STACK
      MOV      #SSTACK,R5
;STORE BASE LEVEL PROGRAM STACK POINTER
      MOV      SP,PSTACK
      TST      FTIME
      BNE      1$
      MOV      @#4,SAVE4
      MOV      @#6,SAVE6
      MOV      #1,FTIME
1$:    MOV      SAVE4,@#4
      MOV      SAVE6,@#6
;SEE IF PROGRAM JUST STARTED, BR IF YES
      READEF   #EF.START
      MOV      #EF.START,R0
      TRAP     C$REFG
      BCOMPLETE NEWST
      BCS      NEWST
;SEE IF THIS IS A NEW PASS, BR IF YES
      READEF   #EF.NEW
      MOV      #EF.NEW,R0
      TRAP     C$REFG
      BCOMPLETE NEWST
      BCS      NEWST
;SEE IF PROGRAM WAS JUST CONTINUED
      READEF   #EF.CONTINUE
      MOV      #EF.CONTINUE,R0
      TRAP     C$REFG
      BCOMPLETE ENDIT
      BCS      ENDIT
;SEE IF PROGRAM JUST RESTARTED, BR IF NOT
      READEF   #EF.RESTART
      MOV      #EF.RESTART,R0
      TRAP     C$REFG
      BNCOMPLETE GETPRM
      BCC      GETPRM
NEWST:
;RESET LOGICAL DEVICE TO -1
      MOV      #-1,LOGDEV

;GET UNIBUS ADRS, VECTOR, PRIORITY LEVEL, LINE UNIT, SWITCH
;PACKS, TEST CONNECTOR INFO. FOR THIS M8200,4,7 (CURRENT LOGICAL
;DEVICE).
GETPRM:
      INC      LOGDEV
      CMP      LOGDEV,L$UNIT
```

4573	010724	002367			BGE	NEWST
4574	010726				GPHARD	LOGDEV,R1
(3)	010726	013700	002552		MOV	LOGDEV,R0
(3)	010732	104442			TRAP	C\$GPHRD
(3)	010734	010001			MOV	R0,R1
4575	010736				BNCOMPLETE	GETPRM
(2)	010736	103365			BCC	GETPRM
4576					;GET ADDRESS OF M8200,4,7	
4577	010740	012137	002626		MOV	(R1)+,WTYPE
4578	010744	011137	002716		MOV	(R1),KMCSR
4579					;GET POINTER TO M8200,4,7 CSR HI BYTE	
4580	010750	011137	002720		MOV	(R1),KMCSRH
4581	010754	005237	002720		INC	KMCSRH
4582					;GET POINTER TO M8200,4,7 CTL OUT REG	
4583	010760	011137	002722		MOV	(R1),KMCTL
4584	010764	062737	000002	002722	ADD	#2,KMCTL
4585					;GET POINTER TO M8200,4,7 PORT REG - SEL 4	
4586	010772	011137	002724		MOV	(R1),KMPO4
4587	010776	062737	000004	002724	ADD	#4,KMPO4
4588					;GET POINTER TO M8200,4,7 PORT REG - SEL 6	
4589	011004	012137	002726		MOV	(R1)+,KMPO6
4590	011010	062737	000006	002726	ADD	#6,KMPO6
4591					;GET POINTER TO RCV VECTOR	
4592	011016	011137	002706		MOV	(R1),KMRVEC
4593					;GET POINTER TO RCV PRIORITY LEVEL	
4594	011022	011137	002710		MOV	(R1),KMRLVL
4595	011026	062737	000002	002710	ADD	#2,KMRLVL
4596					;GET POINTER TO TX VECTOR	
4597	011034	011137	002712		MOV	(R1),KMTVEC
4598	011040	062737	000004	002712	ADD	#4,KMTVEC
4599					;GET POINTER TO TX PRIORITY LEVEL	
4600	011046	011137	002714		MOV	(R1),KMTLVL
4601	011052	062737	000006	002714	ADD	#6,KMTLVL
4602					;PUT VECTOR INTO STAT1	
4603	011060	012137	002700		MOV	(R1)+,STAT1
4604					;PUT PRIORITY INTO STAT1	
4605	011064	052137	002700		BIS	(R1)+,STAT1
4606					;SEE IF NO LINE UNIT, SET BIT IF YES	
4607	011070	005711			TST	(R1)
4608	011072	001004			BNE	50000\$
4609	011074	052737	010000	002700	BIS	#BIT12,STAT1
4610	011102	000416			BR	4\$
4611	011104				50000\$:	
4612					;SEE IF M8201 LINE UNIT, SET BIT IF YES	
4613	011104	021127	000001		CMP	(R1),#1
4614	011110	001001			BNE	50001\$
4615	011112	000412			BR	4\$
4616	011114				50001\$:	
4617					;SEE IF M8202 LINE UNIT, SET BIT IF YES	
4618	011114	021127	000002		CMP	(R1),#2
4619	011120	001004			BNE	50002\$
4620	011122	052737	020000	002700	BIS	#BIT13,STAT1
4621	011130	000403			BR	4\$
4622	011132				50002\$:	
4623					;SET BIT FOR M8203 LINE UNIT	
4624	011132	052737	100000	002700	BIS	#BIT15,STAT1

```
4625 011140
4626
4627 011140 056137 000006 002700
4628 011146 062701 000002
4629
4630 011152 012137 002702
4631
4632 011156 111137 002703
4633
4634
4635
4636 011162 000240
4637 011164 000240
4638
4639 011166 012737 002000 002606
4640 011174 005037 002630
4641 011200 123727 002626 000000
4642 011206 001422
4643 011210 123727 002626 000004
4644 011216 001004
4645 011220 012737 000001 002630
4646 011226 000412
4647 011230 012737 003777 002606 5$:
4648 011236 123727 002626 000006
4649 011244 001003
4650 011246 012737 000001 002630
4651 011254
4652 011254
(3) 011254
(3) 011254 104411
4653
4654
4655 011256
(3) 011256
4656
4657 011256 013701 002716
4658 011262 012705 000004
4659 011266 012737 011320 000004
4660 011274 012737 000340 000006
4661 011302 005711
4662 011304 000240
4663 011306 062701 000002
4664 011312 005305
4665 011314 001372
4666 011316 000407
4667 011320 062706 000004
4668 011324 010137 002632
4669 011330
(3) 011330 013700 002552
(3) 011334 104451
4670
4671 011336 013737 002650 000004 3$:
4672 011344 013737 002652 000006
4673 011352
(3) 011352
(3) 011352 104461
```

4\$:  
:SET BIT IN STAT1 FOR TEST CONNECTOR  
BIS 6(R1),STAT1  
ADD #2,R1  
:SET SWITCH PACK #1 IN STAT2 LOW BYTE  
MOV (R1)+,STAT2  
:SET SWITCH PACK #2 IN STAT2 HIGH BYTE  
MOVB (R1),STAT2+1  
:INCREMENT LOGICAL UNIT (DEVICE) NUMBER  
: INC LOGDEV  
: NOP  
: MOV #2000,MEMSZ  
: CLR TYPE  
: CMPB WTYPE,#0  
: BEQ ENDIT  
: CMPB WTYPE,#4 ;KMC?  
: BNE 5\$  
: MOV #1,TYPE  
: BR ENDIT  
5\$:  
: MOV #3777,MEMSZ  
: CMPB WTYPE,#6  
: BNE ENDIT  
: MOV #1,TYPE  
ENDIT:  
ENDINIT  
L10045:  
TRAP C\$INIT  
:EVEN  
BGNAUTO  
L\$AUTO: :  
:DEVICE DOES NOT HAVE A 'READY'  
:MOV KMCSR,R1 ;R1 CONTAINS BASE M8200,4,7 ADDRESS  
:MOV #4,R5 ;4 REGISTERS TO BE TESTED  
:MOV #2\$,4 ;SET UP TIMEOUT TRAP  
:MOV #340,6 ;LEVEL 7  
1\$: TST (R1) ;REFERENCE DEVICE REGISTER  
:NOP  
:ADD #2,R1 ;NEXT REGISTER  
:DEC R5 ;DEC REGISTER COUNT  
:BNE 1\$ ;BR IF NOT LAST REGISTER  
:BR 3\$  
2\$: ADD #4,SP  
:MOV R1,\$GDADR  
:DODU LOGDEV  
:MOV LOGDEV,R0  
:TRAP C\$DODU  
3\$: MOV SAVE4,4  
:MOV SAVE6,6  
:ENDAUTO  
L10046:  
TRAP C\$AUTO



CZDMPCO M8207 STATIC DIAG #1  
CZDMP.C.P11 13-JUL-81 15:46

MACY11 30A(1052) 13-JUL-81 16:06 E 8  
INITIALIZE SECTION PAGE 47-10

SEQ 0095

4674

4676  
4677  
4678  
4679  
4680  
4681  
4682  
4683  
4684  
4685  
4686  
4687  
4688  
4689  
4690  
4691

011354  
(3) 011354  
011354 104433  
(3) 011354  
011356  
(3) 011356  
(3) 011356 104412

```
.SBTTL CLEANUP CODING SECTION  
:////////////////////  
:/ THE CLEANUP CODING SECTION CONTAINS THE CODING THAT IS PERFORMED  
:/ AT THE END OF EACH PASS.  
:////////////////////  
                BGNCLN  
L$CLEAN::      BRESET  
                TRAP   C$RESET  
  
                ENDCLN  
L10047:        TRAP   C$CLEAN
```

4693  
4694  
4695  
4696  
4697  
4698  
4699  
4700 011360  
(3) 011360  
4701  
4702 011360  
(3) 011360 104433  
4703 011362  
(3) 011362  
(3) 011362 104453  
4704  
4705  
4706  
4707  
4708

.SBTTL DROP UNIT SECTION

:/ THE DROP-UNIT SECTION CONTAINS THE CODING THAT CAUSES A DEVICE  
:/ TO NO LONGER BE TESTED.

          BGNDU  
L\$DU::  
:ISSUE UNIBUS RESET TO CLEAN UP  
          BRESET  
          TRAP  C\$RESET  
          ENDDU  
L10050:  
          TRAP  C\$DU

4710  
4711  
4712  
4713  
4714  
4715  
4716  
4717  
4718 011364  
(3) 011364  
4719 011364  
(3) 011364  
(3) 011364 104452  
4720  
4721  
4722  
4723  
4724  
4725

.SBTTL ADD UNIT SECTION

:/ THE ADD-UNIT SECTION CONTAINS THE CODING THAT CAUSES A DEVICE  
:/ TO BE (A) TESTED FOR THE FIRST TIME, OR (B) RESUMED IN TESTING. IF  
:/ 'EF.AUNIT' IS SET, THE UNIT WILL BE TESTED AS A NEW UNIT.

LSAU:: BGAU  
L10051: ENDAU  
TRAP CSAU

4727  
4728  
4729  
4730  
4731  
4732 011366  
(2)  
4733  
4734  
4735 011366  
(2)  
4736  
4737 011366  
(3) 011366  
4738 011366 013701 002716  
4739 011372 012705 000004  
4740 011376 012737 011434 000004  
4741 011404 012737 000340 000006  
4742 011412 005711  
4743 011414 000240  
4744 011416  
(3) 011416 104410  
(3) 011420 000072  
4745 011422 062701 000002  
4746 011426 005305  
4747 011430 001370  
4748 011432 000417  
4749 011434 062706 000004  
4750 011440 010137 002632  
4751 011444  
(5) 011462 104455  
(6) 011464 000045  
(6) 011466 005715  
(6) 011470 010510  
4752  
4753 011472 013737 002650 000004  
4754 011500 013737 002652 000006  
4755 011506  
(3) 011506 104410  
(3) 011510 000002  
4756 011512  
(3) 011512  
(3) 011512 104401  
4757  
4758 011514  
(2)  
4759  
4760 011514  
(2)  
4761  
4762 011514  
(3) 011514  
4763 011514  
(1) 011514 013701 002716  
4764 011520 005011  
4765 011522 005002

.SBTTL HARDWARE TESTS

BADHEAD

:\*\*\*\*\* TEST 1 \*\*\*\*\*  
:\*VERIFY THAT REFERENCING UNIBUS DEVICE REGISTERS  
:\*DOES NOT CAUSE A TIME OUT TRAP  
BADHEAD  
:\*\*\*\*\* TEST 1 \*\*\*\*\*

BGNTST  
T1::

MOV KMCSR,R1 ;R1 CONTAINS BASE M8200,4,7 ADDRESS  
MOV #4,R5 ;4 REGISTERS TO BE TESTED  
MOV #2\$,4 ;SET UP TIMEOUT TRAP  
MOV #340,6 ;LEVEL 7  
1\$: TST (R1) ;REFERENCE DEVICE REGISTER  
NOP

ESCAPE TST  
TRAP C\$ESCAPE  
.WORD L10052-  
ADD #2,R1 ;NEXT REGISTER  
DEC R5 ;DEC REGISTER COUNT  
BNE 1\$ ;BR IF NOT LAST REGISTER  
BR 3\$

2\$:

ADD #4,SP  
MOV R1,\$GDADR ;TIME-OUT ERROR  
ERROR 37  
TRAP C\$ERDF  
.WORD 37  
.WORD EM37  
.WORD ERR37

3\$:

MOV SAVE4,4  
MOV SAVE6,6  
ESCAPE TST  
TRAP C\$ESCAPE  
.WORD L10052-

ENDTST  
L10052:

TRAP C\$ETST

BADHEAD

:\*\*\*\*\* TEST 2 \*\*\*\*\*  
:\*VERIFY THAT RUN CAN BE CLEARED  
BADHEAD  
:\*\*\*\*\* TEST 2 \*\*\*\*\*

BGNTST  
T2::

MYINT  
MOV KMCSR,R1 ;GET DEVICE ADDRESS.  
CLR (R1) ;CLEAR KMCSR  
CLR R2 ;CLEAR 'EXPECTED'

```
4766 011524 011104      MOV      (R1),R4      ;PUT KMCSR IN 'FOUND'
4767 011526 001413      BEQ      1$           ;BR IF CLEARED
4768 011530              ERROR    26           ;ERROR KMCSR NOT CLEARED
(5) 011546 104455      TRAP     C$ERDF
(6) 011550 000032      .WORD   26
(6) 011552 005474      .WORD   EM26
(6) 011554 007566      .WORD   ERR26
4769 011556              1$:
4770 011556              ENDTST
(3) 011556              L10053:
(3) 011556 104401      TRAP     C$ETST
4771
4772 011560              BADHEAD
(2)                      ;***** TEST 3 *****
4773                      ;*UNIBUS REGISTER WORD DUAL ADDRESSING TEST
4774                      ;*LOAD ALL REGISTERS WITH INCREMENTING PATTERN
4775                      ;*READ BACK ALL REGISTERS TO VERIFY CORRECT ADDRESSING
4776                      ;*THE SEQUENCE:
4777                      ;*      1. CLEAR REGISTER
4778                      ;*      2. WRITE PATTERN
4779                      ;*      3. VERIFY PATTERN
4780                      ;*      4. DO ALL 4 REGISTERS
4781                      ;*      5. READ ALL BACK IF ERRORS,
4782                      ;*          DUAL ADDRESS PROBLEM.
4783                      ;*
4784                      ;*      1 IN REG 0
4785                      ;*      2 IN REG 2
4786                      ;*      3 IN REG 4
4787                      ;*      4 IN REG 6
4788 011560              BADHEAD
(2)                      ;***** TEST 3 *****
4789
4790 011560              BGNTST
(3) 011560              T3::
4791 011560              MYINT
(1) 011560 013701 002716  MOV      KMCSR,R1      ;GET DEVICE ADDRESS.
4792                      ;R1 CONTAINS BASE M8200,4,7 ADDRESS
4793 011564              MSTCLR
(1) 011564 004537 003156  JSR      R5,,MSTCLR    ;MASTER CLEAR M8200,4,7
4794 011570 012702 000001  MOV      #1,R2         ;CLEAR M8200,4,7
4795 011574              BGNSEG
(3) 011574 104404      TRAP     C$BSEG
4796 011576 005011      1$: CLR      (R1)         ;CLEAR REGISTER
4797 011600 010211      MOV      R2,(R1)       ;WRITE M8200,4,7 REGISTER WITH PATTERN
4798 011602 011104      MOV      (R1),R4       ;READ M8200,4,7 REGISTER INTO 'FOUND'
4799 011604 020204      CMP      R2,R4         ;IS DATA CORRECT
4800 011606 001413      BEQ      2$           ;BR IS YES
4801 011610              ERROR    26           ;DATA ERROR
(5) 011626 104455      TRAP     C$ERDF
(6) 011630 000032      .WORD   26
(6) 011632 005474      .WORD   EM26
(6) 011634 007566      .WORD   ERR26
4802 011636              2$: ESCAPE   SEG
(3) 011636 104410      TRAP     C$ESCAPE
(3) 011640 000014      .WORD   10000$-
4803 011642 005721      TST      (R1)+         ;NEXT REGISTER
```

```
4804 011644 005202          INC      R2          ;INCREMENT DATA PATTERN
4805 011646 022702 000005   CMP      #5,R2       ;LAST REGISTER?
4806 011652 001351          BNE      1$          ;BR IF NO
4807 011654          ENDSEG
(3) 011654          10000$:
(3) 011654 104405          TRAP     C$ESEG
4808 011656 013701 002716   MOV      KMCSR,R1    ;BASE M8200,4,7 ADDRESS TO R1
4809 011662 012702 000001   MOV      #1,R2      ;RESTART PATTERN AT 1
4810 011666          BGNSEG
(3) 011666 104404          TRAP     C$BSEG
4811 011670          3$:
4812 011670 011104          MOV      (R1),R4    ;READ COMM. MICR-PROCESSOR FAMILY REGISTER INTO 'FOUND'
4813 011672 020204          CMP      R2,R4      ;IS DATA CORRECT
4814 011674 001413          BEQ      4$          ;BR IF YES
4815 011676          ERROR     2          ;DUAL ADDRESSING ERROR
(5) 011714 104455          TRAP     C$ERDF
(6) 011716 000002          .WORD    2
(6) 011720 004307          .WORD    EM2
(6) 011722 006132          .WORD    ERR2
4816 011724          4$:
(3) 011724 104410          ESCAPE   SEG
(3) 011726 000014          TRAP     C$ESCAPE
4817 011730 005721          .WORD    10001$-
4818 011732 005202          TST      (R1)+      ;NEXT REGISTER
4819 011734 022702 000005   INC      R2          ;INCREMENT PATTERN
4820 011740 001353          CMP      #5,R2      ;LAST REGISTER?
4821 011742          BNE      3$          ;BR IF NO
(3) 011742          ENDSEG
(3) 011742 104405          10001$:
4822 011744          TRAP     C$ESEG
(3) 011744          ENDTST
(3) 011744 104401          L10054:
4823          TRAP     C$ETST
4824 011746          BADHEAD
(2)          ;***** TEST 4 *****
4825          ;*CONTROL STATUS REGISTER WRITE/READ TEST
4826          ;*FLOAT A ONE THROUGH BSEL 0
4827          ;*CLEAR BIT0, VERIFY BIT0 WAS CLEARED
4828 011746          BADHEAD
(2)          ;***** TEST 4 *****
4829          ;*****
4830 011746          BGNTST
(3) 011746          T4::
4831 011746          MSTCLR          ;MASTER CLEAR M8200,4,7
(1) 011746 004537 003156   JSR      R5,,MSTCLR ;CLEAR M8200,4,7
4832 011752 005037 002624   CLR      MRO
4833 011756 012702 000001   MOV      #BIT0,R2   ;INDICATE BSEL0
4834 011762          BGNSEG
(3) 011762 104404          TRAP     C$BSEG
4835 011764 013701 002716   MOV      KMCSR,R1   ;PUT REGISTER ADDRESS IN R1
4836 011770 010237 002636   MOV      R2,$GDDAT
4837 011774 013711 002636   MOV      $GDDAT,(R1) ;WRITE BIT 0
4838 012000 011104          MOV      (R1),R4    ;READ CONTROL STATUS REGISTER
4839 012002 023704 002636   CMP      $GDDAT,R4  ;IS DATA CORRECT
4840 012006 001411          BEQ      2$          ;BR IF YES
4841 012010          ERROR     27,YES   ;DATA ERROR
```

(5)	012022	104455		TRAP	C\$ERDF	
(6)	012024	000033		.WORD	27	
(6)	012026	005525		.WORD	EM27	
(6)	012030	007644		.WORD	ERR27	
4842	012032		2\$:	ESCAPE	SEG	
(3)	012032	104410		TRAP	C\$ESCAPE	
(3)	012034	000052		.WORD	10000\$-	
4843	012036	040211	3\$:	BIC	R2,(R1)	:CLEAR BSELO
4844	012040	005037		CLR	\$GDDAT	:CLEAR 'EXPECTED'
4845	012044	011104		MOV	(R1),R4	:READ CONTROL STATUS REGISTER
4846	012046	001413		BEQ	4\$	:BR IF ZERO
4847	012050			ERROR	2	:DATA ERROR BSEL NOT CLEARED
(5)	012066	104455		TRAP	C\$ERDF	
(6)	012070	000002		.WORD	2	
(6)	012072	004307		.WORD	EM2	
(6)	012074	006132		.WORD	ERR2	
4848	012076		4\$:	ESCAPE	SEG	
(3)	012076	104410		TRAP	C\$ESCAPE	
(3)	012100	000006		.WORD	10000\$-	
4849	012102	106302		ASLB	R2	
4850	012104	001327		BNE	1\$	
4851	012106			ENDSEG		
(3)	012106		10000\$:			
(3)	012106	104405		TRAP	C\$ESEG	
4852	012110		ENDTST			
(3)	012110		L10055:			
(3)	012110	104401		TRAP	C\$ETST	
4853						
4854						



```

4856
4857
4858
4859
4860
4861 012112          BADHEAD
(2)                  :***** TEST 5 *****
4862                  :*CONTROL STATUS REGISTER WRITE/READ TEST
4863                  :*SET BIT9, VERIFY BIT9 WAS SET
4864                  :*CLEAR BIT9, VERIFY BIT9 WAS CLEARED
4865 012112          BADHEAD
(2)                  :***** TEST 5 *****
4866
4867 012112          BGNTST
(3) 012112          T5::
4868 012112          MSTCLR          :MASTER CLEAR M8200,4,7
(1) 012112 004537 003156          JSR      R5, .MSTCLR          :CLEAR M8200,4,7
4869 012116          BGNSEG
(3) 012116 104404          TRAP     C$BSEG
4870 012120 013701 002716          1$: MOV     KMCSR, R1          :PUT REGISTER ADDRESS IN R1
4871 012124 012702 001000          MOV     #BIT9, R2          :PUT DATA IN 'EXPECTED'
4872 012130 010211          MOV     R2, (R1)          :WRITE BIT 9
4873 012132 011104          MOV     (R1), R4          :READ CONTROL STATUS REGISTER
4874 012134 020204          CMP     R2, R4            :IS DATA CORRECT
4875 012136 001413          BEQ     2$                :BR IF YES
4876 012140          ERROR     26                :DATA ERROR
(5) 012156 104455          TRAP     C$ERDF
(6) 012160 000032          .WORD   26
(6) 012162 005474          .WORD   EM26
(6) 012164 007566          .WORD   ERR26
4877 012166          2$: ESCAPE  SEG
(3) 012166 104410          TRAP     C$ESCAPE
(3) 012170 000002          .WORD   10000$-.
4878 012172          ENDSEG
(3) 012172          10000$:
(3) 012172 104405          TRAP     C$ESEG
4879 012174          BGNSEG
(3) 012174 104404          TRAP     C$BSEG
4880 012176 042711 001000          3$: BIC     #BIT9, (R1)          :CLEAR BIT 9
4881 012202 005002          CLR     R2                :CLEAR 'EXPECTED'
4882 012204 011104          MOV     (R1), R4          :READ CONTROL STATUS REGISTER
4883 012206 001416          BEQ     4$                :BR IF ZERO
4884 012210          ERROR     26                :DATA ERROR BIT9 NOT CLEARED
(5) 012226 104455          TRAP     C$ERDF
(6) 012230 000032          .WORD   26
(6) 012232 005474          .WORD   EM26
(6) 012234 007566          .WORD   ERR26
4885 012236          ESCAPE  SEG
(3) 012236 104410          TRAP     C$ESCAPE
(3) 012240 000002          .WORD   10001$-.
4886 012242          ENDSEG
(3) 012242          10001$:
(3) 012242 104405          TRAP     C$ESEG
4887 012244          4$:
4888 012244          ENDTST
(3) 012244          L10056:

```

```
(3) 012244 104401 TRAP C$ETST
4889
4890 012246 BADHEAD
(2) ;***** TEST 6 *****
4891 ;*CONTROL STATUS REGISTER WRITE/READ TEST
4892 ;*SET BIT11, VERIFY BIT11 WAS SET
4893 ;*CLEAR BIT11, VERIFY BIT11 WAS CLEARED
4894 012246 BADHEAD
(2) ;***** TEST 6 *****
4895
4896 012246 BGNTST
(3) 012246 T6::
4897 012246 MSTCLR ;MASTER CLEAR M8200,4,7
(1) 012246 004537 003156 JSR R5,.MSTCLR ;CLEAR M8200,4,7
4898 012252 BGNSEG
(3) 012252 104404 TRAP C$BSEG
4899 012254 013701 002716 1$: MOV KMCSR,R1 ;PUT REGISTER ADDRESS IN R1
4900 012260 012702 004000 MOV #BIT11,R2 ;PUT DATA IN 'EXPECTED'
4901 012264 010211 MOV R2,(R1) ;WRITE BIT 11
4902 012266 011104 MOV (R1),R4 ;READ CONTROL STATUS REGISTER
4903 012270 020204 CMP R2,R4 ;IS DATA CORRECT
4904 012272 001413 BEQ 2$ ;BR IF YES
4905 012274 ERROR 26 ;DATA ERROR
(5) 012312 104455 TRAP C$ERDF
(6) 012314 000032 .WORD 26
(6) 012316 005474 .WORD EM26
(6) 012320 007566 .WORD ERR26
4906 012322 2$: ESCAPE SEG
(3) 012322 104410 TRAP C$ESCAPE
(3) 012324 000002 .WORD 10000$-.
4907 012326 ENDSEG
(3) 012326 10000$: TRAP C$ESEG
4908 012330 BGNSEG
(3) 012330 104404 TRAP C$BSEG
4909 012332 042711 004000 3$: BIC #BIT11,(R1) ;CLEAR BIT 11
4910 012336 005002 CLR R2 ;CLEAR 'EXPECTED'
4911 012340 011104 MOV (R1),R4 ;READ CONTROL STATUS REGISTER
4912 012342 001414 BEQ 4$ ;BR IF ZERO
4913 012344 ERROR 26 ;DATA ERROR BIT11 NOT CLEARED
(5) 012362 104455 TRAP C$ERDF
(6) 012364 000032 .WORD 26
(6) 012366 005474 .WORD EM26
(6) 012370 007566 .WORD ERR26
4914 012372 ENDSEG
(3) 012372 10001$: TRAP C$ESEG
4915 012374 4$:
4916 012374 ENDTST
(3) 012374 L10057: TRAP C$ETST
(3) 012374 104401
4917
4918 012376 BADHEAD
(2) ;***** TEST 7 *****
4919 ;*CONTROL STATUS REGISTER WRITE/READ TEST
4920 ;*SET BIT12, VERIFY BIT12 WAS SET
```

```
4921                                     ;*CLEAR BIT12, VERIFY BIT12 WAS CLEARED
4922 012376                               BADHEAD
(2)                                       ;***** TEST 7 *****
4923
4924 012376                               BGNTST
(3) 012376                               T7::
4925 012376                               MSTCLR                               ;MASTER CLEAR M8200,4,7
(1) 012376 004537 003156                 JSR R5,,MSTCLR                               ;CLEAR M8200,4,7
4926 012402                               BGNSEG
(3) 012402 104404                       TRAP C$BSEG
4927 012404 013701 002716                 1$: MOV KMCSR,R1                               ;PUT REGISTER ADDRESS IN R1
4928 012410 012702 010000                 MOV #BIT12,R2                               ;PUT DATA IN 'EXPECTED'
4929 012414 010211                       MOV R2,(R1)                                 ;WRITE BIT 12
4930 012416 011104                       MOV (R1),R4                                 ;READ CONTROL STATUS REGISTER
4931 012420 020204                       CMP R2,R4                                   ;IS DATA CORRECT
4932 012422 001413                       BEQ 2$                                     ;BR IF YES
4933 012424                               ERROR 26                                    ;DATA ERROR
(5) 012442 104455                       TRAP C$ERDF
(6) 012444 000032                       .WORD 26
(6) 012446 005474                       .WORD EM26
(6) 012450 007566                       .WORD ERR26
4934 012452                               2$: ESCAPE SEG
(3) 012452 104410                       TRAP C$ESCAPE
(3) 012454 000002                       .WORD 10000$-
4935 012456                               10000$:
(3) 012456 104405                       TRAP C$ESEG
4936 012460                               BGNSEG
(3) 012460 104404                       TRAP C$BSEG
4937 012462 042711 010000                 3$: BIC #BIT12,(R1)                          ;CLEAR BIT 12
4938 012466 005002                       CLR R2                                       ;CLEAR 'EXPECTED'
4939 012470 011104                       MOV (R1),R4                                 ;READ CONTROL STATUS REGISTER
4940 012472 001414                       BEQ 4$                                       ;BR IF ZERO
4941 012474                               ERROR 26                                    ;DATA ERROR BIT12 NOT CLEARED
(5) 012512 104455                       TRAP C$ERDF
(6) 012514 000032                       .WORD 26
(6) 012516 005474                       .WORD EM26
(6) 012520 007566                       .WORD ERR26
4942 012522                               10001$:
(3) 012522 104405                       TRAP C$ESEG
4943 012524                               4$:
4944 012524                               ENDTST
(3) 012524                               L10060:
(3) 012524 104401                       TRAP C$ETST
4945
4946 012526                               BADHEAD
(2)                                       ;***** TEST 8 *****
4947                                     ;*CONTROL OUT REGISTER WRITE/READ TEST
4948                                     ;*FLOAT A ONE THROUGH SEL2
4949 012526                               BADHEAD
(2)                                       ;***** TEST 8 *****
4950
4951 012526                               BGNTST
(3) 012526                               T8::
4952 012526                               MSTCLR                               ;MASTER CLEAR M8200,4,7
```

```
(1) 012526 004537 003156 JSR R5, .MSTCLR ;CLEAR M8200,4,7
4953 012532 012737 000002 002624 MOV #2, MRO
4954 012540 012702 000001 MOV #1, R2
4955 012544 BGNSEG
(3) 012544 104404 TRAP C$BSEG
4956
4957 012546 013701 002722 1$: MOV KMCTL, R1 ;PUT REGISTER ADDRESS IN R1
4958 012552 010237 002636 MOV R2, $GDDAT ;PUT DATA IN 'EXPECTED'
4959 012556 013711 002636 MOV $GDDAT, (R1) ;WRITE BIT 0
4960 012562 011104 MOV (R1), R4 ;READ CONTROL OUT REGISTER
4961 012564 023704 002636 CMP $GDDAT, R4 ;IS DATA CORRECT
4962 012570 001411 BEQ 2$ ;BR IF YES
4963 012572 ERROR 27, YES ;DATA ERROR
(5) 012604 104455 TRAP C$ERDF
(6) 012606 000033 .WORD 27
(6) 012610 005525 .WORD EM27
(6) 012612 007644 .WORD ERR27
4964 012614 2$: ESCAPE SEG
(3) 012614 104410 TRAP C$ESCAPE
(3) 012616 000046 .WORD 10000$-
4965 012620 040211 3$: BIC R2, (R1) ;CLEAR BIT
4966 012622 005037 002636 CLR $GDDAT ;CLEAR 'EXPECTED'
4967 012626 011104 MOV (R1), R4 ;READ CONTROL OUT REGISTER
4968 012630 001411 BEQ 4$ ;BR IF ZERO
4969 012632 ERROR 27, YES ;DATA ERROR BIT0 NOT CLEARED
(5) 012644 104455 TRAP C$ERDF
(6) 012646 000033 .WORD 27
(6) 012650 005525 .WORD EM27
(6) 012652 007644 .WORD ERR27
4970 012654 4$: ESCAPEE SEG
(3) 012654 104410 TRAP C$ESCAPE
(3) 012656 000006 .WORD 10000$-
4971 012660 006302 ASL R2
4972 012662 001331 BNE 1$
4973 012664 ENDSEG
(3) 012664 10000$: TRAP C$ESEG
(3) 012664 104405
4974 012666 ENDTST
(3) 012666 L10061: TRAP C$ETST
(3) 012666 104401
4975
4976
4977
4978
4979
4980
4981 012670 BADHEAD
(2) ;***** TEST 9 *****
4982 ;*PORT4 REGISTER WRITE/READ TEST
4983 ;*FLOAT A ONE THROUGH PORT4 REGISTER
4984 ;*FLOAT A ZERO THROUGH PORT4 REGISTER
4985 012670 BADHEAD
(2) ;***** TEST 9 *****
4986
4987
4988 012670 BGNTST
```

```

(3) 012670          T9::
4989 012670 012737 000004 002624      MOV      #4,MRO
4990 012676          MSTCLR          ;MASTER CLEAR M8200,4,7
(1) 012676 004537 003156          JSR      R5,.MSTCLR          ;CLEAR M8200,4,7
4991 012702 013701 002724          MOV      KMP04,R1          ;PUT REGISTER ADDRESS IN R1
4992 012706 012702 000001          MOV      #1,R2          ;START WITH BIT0
4993 012712          BGNSEG
(3) 012712 104404          TRAP     C$BSEG
4994 012714          64$:
4995 012714 010211          MOV      R2,(R1)          ;WRITE PORT4 REGISTER
4996 012716 011104          MOV      (R1),R4          ;READ PORT4 REGISTER
4997 012720 020204          CMP      R2,R4          ;COMPARE EXPECTED AND FOUND
4998 012722 001413          BEQ     65$              ;BR IF OK
4999 012724          ERROR  27              ;WRITE/READ ERROR
(5) 012742 104455          TRAP     C$ERDF
(6) 012744 000033          .WORD   27
(6) 012746 005525          .WORD   EM27
(6) 012750 007644          .WORD   ERR27
5000 012752          65$:
(3) 012752 104410          ESCAPE  SEG
(3) 012754 000010          TRAP     C$ESCAPE
(3) 012754 000010          .WORD   10000$-.
5001 012756 000241          CLC
5002 012760 006102          ROL     R2          ;CLEAR CARRY
5003 012762 001354          BNE     64$          ;SHIFT TO NEXT BIT
5004 012764          ENDSEG          ;BR IF NOT DONE YET?
(3) 012764          10000$:
(3) 012764 104405          TRAP     C$ESEG
5005 012766 012702 000001          MOV      #1,R2          ;START WITH BIT0
5006 012772          BGNSEG
(3) 012772 104404          TRAP     C$BSEG
5007 012774          66$:
5008 012774 005102          COM     R2          ;CHANGE TO A FLOATING ZERO
5009 012776 010211          MOV      R2,(R1)          ;WRITE PORT4 REGISTER
5010 013000 011104          MOV      (R1),R4
5011 013002 020204          CMP      R2,R4          ;COMPARE EXPECTED AND FOUND
5012 013004 001413          BEQ     67$              ;BR IF OK
5013 013006          ERROR  27              ;WRITE/READ ERROR
(5) 013024 104455          TRAP     C$ERDF
(6) 013026 000033          .WORD   27
(6) 013030 005525          .WORD   EM27
(6) 013032 007644          .WORD   ERR27
5014 013034          67$:
(3) 013034 104410          ESCAPE  SEG
(3) 013036 000012          TRAP     C$ESCAPE
(3) 013036 000012          .WORD   10001$-.
5015 013040 005102          COM     R2          ;CHANGE BACK TO A FLOATING ONE
5016 013042 000241          CLC          ;CLEAR CARRY
5017 013044 006102          ROL     R2          ;SHIFT TO NEXT BIT
5018 013046 001352          BNE     66$          ;BR IF NOT DONE YET?
5019 013050          ENDSEG
(3) 013050          10001$:
(3) 013050 104405          TRAP     C$ESEG
5020 013052          ENDTST
(3) 013052          L10062:
(3) 013052 104401          TRAP     C$ETST
5021
5022 013054          BADHEAD
  
```

```
(2)
5023
5024
5025
5026 013054
(2)
5027
5028 013054
(3) 013054
5029 013054 012737 000006 002624
5030 013062
(1) 013062 004537 003156
5031 013066 013701 002726
5032 013072 012702 000001
5033 013076
(3) 013076 104404
5034 013100
5035 013100 010211
5036 013102 011104
5037 013104 020204
5038 013106 001413
5039 013110
(5) 013126 104455
(6) 013130 000033
(6) 013132 005525
(6) 013134 007644
5040 013136
(3) 013136 104410
(3) 013140 000010
5041 013142 000241
5042 013144 006105
5043 013146 001354
5044 013150
(3) 013150
(3) 013150 104405
5045 013152 012702 000001
5046 013156
(3) 013156 104404
5047 013160
5048 013160 005102
5049
5050 013162 010211
5051 013164 011104
5052 013166 020204
5053 013170 001413
5054 013172
(5) 013210 104455
(6) 013212 000033
(6) 013214 005525
(6) 013216 007644
5055 013220
(3) 013220 104410
(3) 013222 000012
5056 013224 005102
5057 013226 000241
5058 013230 006102

:***** TEST 10 *****
:*PORT6 REGISTER WRITE/READ TEST
:*FLOAT A ONE THROUGH PORT6 REGISTER
:*FLOAT A ZERO THROUGH PORT6 REGISTER
BADHEAD
:***** TEST 10 *****

BGNTST
T10::
MOV #6,MRO
MSTCLR ;MASTER CLEAR M8200.4,7
JSR R5,,MSTCLR ;CLEAR M8200.4,7
MOV KMP06,R1 ;PUT REGISTER ADDRESS IN R1
MOV #1,R2 ;START WITH BIT0
BGNSEG
TRAP C$BSEG
64$:
MOV R2,(R1) ;WRITE PORT6 REGISTER
MOV (R1),R4 ;READ PORT6 REGISTER
CMP R2,R4 ;COMPARE EXPECTED AND FOUND
BEQ 65$ ;BR IF OK
ERROR 27 ;WRITE/READ ERROR
TRAP C$ERDF
.WORD 27
.WORD EM27
.WORD ERR27
65$:
ESCAPE SEG
TRAP C$ESCAPE
.WORD 10000$-.
CLC ;CLEAR CARRY
ROL R5 ;SHIFT TO NEXT BIT
BNE 64$ ;BR IF NOT DONE YET?
ENDSEG
10000$:
TRAP C$ESEG
MOV #1,R2 ;START WITH BIT0
BGNSEG
TRAP C$BSEG
66$:
COM R2 ;CHANGE TO A FLOATING ZERO
MOV R2,(R1) ;WRITE PORT6 REGISTER
MOV (R1),R4 ;READ PORT6 REGISTER
CMP R2,R4 ;COMPARE EXPECTED AND FOUND
BEQ 67$ ;BR IF OK
ERROR 27 ;WRITE/READ ERROR
TRAP C$ERDF
.WORD 27
.WORD EM27
.WORD ERR27
67$:
ESCAPE SEG
TRAP C$ESCAPE
.WORD 10001$-.
COM R2 ;CHANGE BACK TO A FLOATING ONE
CLC ;CLEAR CARRY
ROL R2 ;SHIFT TO NEXT BIT
```

```
5059 013232 001352          BNE      66$          ;BR IF NOT DONE YET?
5060 013234          ENDSEG
(3) 013234          10001$:
(3) 013234 104405          TRAP     C$ESEG
5061 013236          ENDTST
(3) 013236          L10063:
(3) 013236 104401          TRAP     C$ETST
5062
5063 013240          BADHEAD
(2)
5064          :***** TEST 11 *****
5065          :*UNIBUS REGISTER BYTE DUAL ADDRESSING TEST
5066          :*LOAD ALL REGISTERS WITH INCREMENTING PATTERN
5067 013240          :*READ BACK ALL REGISTERS TO VERIFY CORRECT ADDRESSING
(2)          BADHEAD
5068          :***** TEST 11 *****
5069 013240          BGNTST
(3) 013240          T11::
5070 013240          MYINT
(1) 013240 013701 002716      MOV      KMCSR,R1      ;GET DEVICE ADDRESS.
5071 013244          MSTCLR          ;MASTER CLEAR M8200,4,7
(1) 013244 004537 003156      JSR      R5,,MSTCLR    ;CLEAR M8200,4,7
5072 013250          MOV      #1,R2        ;START PATTERN AT 1
5073 013254          BGNSEG
(3) 013254 104404          TRAP     C$BSEG
5074 013256          1$:          CLR      (R1)          ;CLEAR REGISTER
5075 013260          MOV      R2,(R1)      ;WRITE M8200,4,7 REGISTER WITH PATTERN
5076 013262          MOV      (R1),R4      ;READ M8200,4,7 REGISTER INTO 'FOUND'
5077 013264          CMP      R2,R4        ;IS DATA CORRECT
5078 013266          BEQ      2$          ;BR IF YES
5079 013270          ERROR      2          ;DATA ERROR
(5) 013306 104455          TRAP     C$ERDF
(6) 013310          .WORD      2
(6) 013312          .WORD      EM2
(6) 013314          .WORD      ERR2
5080 013316          2$:          ESCAPE   SEG
(3) 013316 104410          TRAP     C$ESCAPE
(3) 013320          .WORD      10000$-
5081 013322          TST      (R1)+          ;NEXT REGISTER
5082 013324          INC      R2            ;INCREMENT DATA PATTERN
5083 013326          CMP      #11,R2       ;LAST REGISTER?
5084 013332          BNE      1$          ;BR IF NO
5085 013334          MOV      KMCSR,R1     ;BASE M8200,4,7 ADDRESS TO R1
5086 013340          MOV      #1,R2        ;RESTART PATTERN AT 1
5087 013344          ENDSEG
(3) 013344          10000$:
(3) 013344 104405          TRAP     C$ESEG
5088 013346          BGNSEG
(3) 013346 104404          TRAP     C$BSEG
5089 013350          3$:
5090 013350          MOV      (R1),R4      ;READ COMM.MICRO-PROCESSOR FAMILY REGISTER INTO 'FOUND'
5091 013352          CMP      R2,R4        ;IS DATA CORRECT
5092 013354          BEQ      4$          ;BR IF YES
5093 013356          ERROR      2          ;DUAL ADDRESSING ERROR
(5) 013374 104455          TRAP     C$ERDF
(6) 013376          .WORD      2
```

```

(6) 013400 004307
(6) 013402 006132
5094 013404 104410
(3) 013404 104410
(3) 013406 000014
5095 013410 105721
5096 013412 005202
5097 013414 022702 000011
5098 013420 001353
5099 013422
(3) 013422
(3) 013422 104405
5100 013424
(3) 013424
(3) 013424 104401
5101
5102 013426
(2)
5103
5104
5105
5106 013426
(2)
5107
5108 013426
(3) 013426
5109
5110 013426 004537 003156
(1) 013426 004537 003156
5111 013432 013701 002716
(1) 013432 013701 002716
5112 013436 104404
(3) 013436 104404
5113 013440 012711 003000
5114 013444 005002
5115 013446 010261 000006
5116 013452 016104 000006
5117 013456 020204
5118 013460 001413
5119 013462
(5) 013500 104455
(6) 013502 000032
(6) 013504 005474
(6) 013506 007566
5120 013510
(3) 013510 104410
(3) 013512 000002
5121 013514
(3) 013514
(3) 013514 104405
5122 013516 012702 177777
5123 013522
(3) 013522 104404
5124 013524 010261 000006
5125 013530 016104 000006
5126 013534 020204

4$: .WORD EM2
      .WORD ERR2
      ESCAPE SEG
      TRAP C$ESCAPE
      .WORD 10001$-.
      TSTB (R1)+ ;NEXT REGISTER
      INC R2 ;INCREMENT PATTERN
      CMP #11,R2 ;LAST REGISTER?
      BNE 3$ ;BR IF NO
      ENDSEG

10001$: TRAP C$ESEG

ENDTST
L10064: TRAP C$ETST

BADHEAD
:***** TEST 12 *****
:*MAINTENANCE INSTRUCTION REGISTER TEST
:*VERIFY THAT THE MAINT IR CAN BE WRITTEN TO ALL ZEROS*
:*AND ALL ONES*. VERIFY THAT IT IS CLEARED ON A BUS RESET.
BADHEAD
:***** TEST 12 *****

BGNTST
112::

MSTCLR ;R1 CONTAINS BASE M8200.4,7 ADDRESS
JSR R5,.MSTCLR ;MASTER CLEAR M8200.4,7
MYINT ;CLEAR M8200.4,7
MOV KMCSR,R1 ;GET DEVICE ADDRESS.
BGNSEG
TRAP C$BSEG
MOV #BIT9:BIT10,(R1) ;SEL6 IS NOW THE IR
CLR R2 ;PUT 'EXPECTED' IN $GDDAT
1$: MOV R2,6(R1) ;CLEAR THE IR
     MOV 6(R1),R4 ;READ THE IR
     CMP R2,R4 ;IS IT CLEARED?
     BEQ 2$ ;BR IF YES
     ERROR 26 ;ERROR IR IS NOT CLEAR
     TRAP C$ERDF
     .WORD 26
     .WORD EM26
     .WORD ERR26
2$: ESCAPE SEG
     TRAP C$ESCAPE
     .WORD 10000$-.
     ENDSEG

10000$: TRAP C$ESEG
        MOV #-1,R2 ;PUT 'EXPECTED' IN $GDDAT
        BGNSEG
3$: TRAP C$BSEG
     MOV R2,6(R1) ;WRITE ALL ONES TO THE IR
     MOV 6(R1),R4 ;READ THE IR
     CMP R2,R4 ;IS IT ALL ONES?
  
```



5127 013536 001413  
5128 013540  
(5) 013556 104455  
(6) 013560 000032  
(6) 013562 005474  
(6) 013564 007566  
5129 013566  
(3) 013566 104410  
(3) 013570 000002  
5130 013572  
(3) 013572  
(3) 013572 104405  
5131 013574  
(3) 013574  
(3) 013574 104401  
5132  
5133

BEG 4\$  
ERROR 26  
TRAP C\$ERDF  
.WORD 26  
.WORD EM26  
.WORD ERR26  
4\$: ESCAPE SEG  
TRAP C\$ESCAPE  
.WORD 10001\$-  
ENDSEG  
10001\$:  
TRAP C\$ESEG  
ENDTST  
L10065:  
TRAP C\$ETST

:BR IF YES  
:ERROR IR IS NOT = ALL ONES

```
5135
5136 013576          BADHEAD
(2)                :***** TEST 13 *****
5137                :*MICRO PROCESSOR TEST
5138                :*LOAD KMPO6 WITH A MICRO-PROCESSOR INSTRUCTION, CLOCK IT
5139                :*VERIFY INSTRUCTION EXECUTED PROPERLY
5140                :*INSTRUCTION SHOULD MOVE IBUS*4 TO IBUS*5, IBUS*4 IS ALL 1'S
5141                :*AND IBUS*5 IS ALL 0'S. RESULT SHOULD BE ALL 1'S IN SEL4
5142 013576          BADHEAD
(2)                :***** TEST 13 *****
5143
5144 013576          BGNTST
(3) 013576          T13::
5145 013576          MYINT
(1) 013576 013701 002716  MOV      KMCSR,R1          ;GET DEVICE ADDRESS.
5146 013602          MSTCLR
(1) 013602 004537 003156  JSR      R5,,MSTCLR        ;CLEAR M8200,4,7
5147 013606 012761 000377 000004  MOV      #377,4(R1)        ;PORT4 HI BYTE=1'S
5148 013614 012711 001000          MOV      #BIT9,(R1)        ;SET ROMI
5149 013620 012761 121105 000006  MOV      #121105,6(R1)     ;INSTR TO PORT 6.
5150 013626 052711 001400          BIS      #BIT8!BIT9,(R1)  ;CLK INSTR.
5151 013632 000240          NOP
5152 013634 012702 177777          MOV      #-1,R2           ;EXPECT ALL ONES.
5153 013640 116104 000004          MOV      4(R1),R4         ;READ FOUND.
5154 013644 020204          CMP      R2,R4           ;DATA CORRECT?
5155 013646 001413          BEQ     1$
5156 013650          ERROR 28
(5) 013666 104455          TRAP   C$ERDF
(6) 013670 000034          .WORD 28
(6) 013672 005554          .WORD EM28
(6) 013674 007726          .WORD ERR28
5157
5158 013676          1$:  ESCAPE TST
(3) 013676 104410          TRAP   C$ESCAPE
(3) 013700 000002          .WORD L10066-.
5159
5160 013702          ENDTST
(3) 013702          L10066:
(3) 013702 104401          TRAP   C$SETST
5161
5162 013704          BADHEAD
(2)                :***** TEST 14 *****
5163                :*MICRO PROCESSOR IBUS* REGISTER WRITE/READ TEST
5164                :*FLOAT A 1 THROUGH IBUS* REGISTER 0
5165                :*FLOAT A 0 THROUGH IBUS* REGISTER 0
5166 013704          BADHEAD
(2)                :***** TEST 14 *****
5167
5168 013704          BGNTST
(3) 013704          T14::
5169 013704          MSTCLR          ;MASTER CLEAR M8200,4,7
(1) 013704 004537 003156  JSR      R5,,MSTCLR        ;CLEAR M8200,4,7
5170 013710 012737 000000 002624  MOV      #0,MRO          ;SAVE REGISTER ADDRESS FOR TYPEOUT
5171 013716 012705 000001          MOV      #1,R5           ;START WITH BIT 0
5172
5173 013722          MYINT
```

```

(1) 013722 013701 002716      MOV      KMCSR,R1      ;GET DEVICE ADDRESS.
5174 013726                    BGNSEG
(3) 013726 104404              TRAP      C$BSEG
5175 013730                    64$:
5176 013730 010561 000004      MOV      R5,4(R1)      ;PUT PATTERN INTO PORT4
5177 013734                    ROMCLK      ;NEXT WORD IS INSTRUCTION, BBN
(1) 013734 004537 003244      JSR      R5,ROMCLK     ;CLOCK INSTRUCTION
5178 013740 121100            121100      ;MOV DATA TO IBUS* REGISTER 0
5179 013742                    ROMCLK      ;NEXT WORD IS INSTRUCTION, BBN
(1) 013742 004537 003244      JSR      R5,ROMCLK     ;CLOCK INSTRUCTION
5180 013746 121005            121005      ;READ FROM IBUS* REGISTER 0
5181 013750 116104 000005      MOVB     5(R1),R4      ;PUT 'FOUND' INTO R4
5182 013754 120504            CMPB     R5,R4         ;DATA CORRECT?
5183 013756 001414            BEQ      65$          ;BR IF YES
5184 013760                    BERROR     27         ;ERROR
(5) 014000 104455            TRAP     C$ERDF
(6) 014002 000033            .WORD   27
(6) 014004 005525            .WORD   EM27
(6) 014006 007644            .WORD   ERR27
5185 014010                    65$:
(3) 014010 104410            ESCAPE   SEG
(3) 014012 000010            TRAP     C$ESCAPE
5186 014014 000241            .WORD   10000$-
5187 014016 106105            CLC
5188 014020 001343            ROLB    R5            ;CLEAR CARRY
5189 014022                    BNE     64$          ;SHIFT BIT IN R5
(3) 014022                    ENDSEG      ;IF R2=0 THEN DONE
(3) 014022 104405            10000$:
5190 014024 012705 000001      TRAP     C$ESEG
5191 014030                    :69$:
5192 014030 104404            COM      #1,R5        ;START WITH BIT 0
5193 014032                    BGNSEG      ;CHANGE TO FLOATING ZERO
5194 014032 005105            TRAP     C$BSEG
5195 014034 010561 000004      COM      R5
5196 014040                    67$:
(1) 014040 004537 003244      MOV      R5,4(R1)      ;PUT PATTERN INTO PORT4
5197 014044 121100            ROMCLK      ;NEXT WORD IS INSTRUCTION, BBN
(1) 014044 004537 003244      JSR      R5,ROMCLK     ;CLOCK INSTRUCTION
5198 014046 121100            121100      ;MCV DATA TO IBUS* REGISTER 0
5199 014052 121005            ROMCLK      ;NEXT WORD IS INSTRUCTION, BBN
(1) 014052 004537 003244      JSR      R5,ROMCLK     ;CLOCK INSTRUCTION
5200 014054 116104 000005      MOVB     5(R1),R4      ;READ FROM IBUS* REGISTER 0
5201 014060 120504            CMPB     R5,R4         ;PUT 'FOUND' INTO R4
5202 014062 001414            BEQ      68$          ;DATA CORRECT?
5203 014064                    BERROR     27         ;BR IF YES
(5) 014104 104455            TRAP     C$ERDF      ;ERROR
(6) 014106 000033            .WORD   27
(6) 014110 005525            .WORD   EM27
(6) 014112 007644            .WORD   ERR27
5204 014114                    68$:
(3) 014114 104410            ESCAPE   SEG
(3) 014116 000012            TRAP     C$ESCAPE
5205 014120 005105            .WORD   10001$-
5206 014122 000241            COM      R5            ;CHANGE TO FLOATING 1
5207 014124 106105            CLC
5208 014126 001343            ROLB    R5            ;CLEAR CARRY
                                BNE     67$          ;SHIFT BIT IN R5
                                ;IF R2=0 THEN DONE
  
```

```
5209 014130          ENDSEG
(3) 014130          10001$:
(3) 014130 104405    TRAP    C$ESEG
5210 014132          ENDTST
(3) 014132          L10067:
(3) 014132 104401    TRAP    C$ETST
5211
5212 014134          BADHEAD
(2)
5213                ;***** TEST 15 *****
5214                ;*MICRO PROCESSOR IBUS* REGISTER WRITE/READ TEST
5215                ;*FLOAT A 1 THROUGH IBUS* REGISTER 2
5216 014134          ;*FLOAT A 0 THROUGH IBUS* REGISTER 2
(2)                BADHEAD
5217                ;***** TEST 15 *****
5218 014134          BGNTST
(3) 014134          T15::
5219 014134          MSTCLR          ;MASTER CLEAR M8200,4,7
(1) 014134 004537 003156          JSR    R5, .MSTCLR          ;CLEAR M8200,4,7
5220 014140 012737 000002 002624          MOV    #2, MRO          ;SAVE REGISTER ADDRESS FOR TYPEOUT
5221 014146 012705 000001          MOV    #1, R5          ;START WITH BIT 0
5222 014152          MYINT
(1) 014152 013701 002716          MOV    KMCSR, R1          ;GET DEVICE ADDRESS.
5223 014156          BGNSEG
(3) 014156 104404          TRAP    C$BSEG
5224 014160          64$:
5225 014160 010561 000004          MOV    R5, 4(R1)          ;PUT PATTERN INTO PORT4
5226 014164          ROMCLK          ;NEXT WORD IS INSTRUCTION, BBN
(1) 014164 004537 003244          JSR    R5, .ROMCLK          ;CLOCK INSTRUCTION
5227 014170 121102          121100!2          ;MOV DATA TO IBUS* REGISTER 0
5228 014172          ROMCLK          ;NEXT WORD IS INSTRUCTION, BBN
(1) 014172 004537 003244          JSR    R5, .ROMCLK          ;CLOCK INSTRUCTION
5229 014176 121045          121005!<2*20>          ;READ FROM IBUS* REGISTER 2
5230 014200 116104 000005          MOV    5(R1), R4          ;PUT 'FOUND' INTO R4
5231 014204 120504          CMP    R5, R4          ;DATA CORRECT?
5232 014206 001414          BEQ    65$          ;BR IF YES
5233 014210          BERROR 27          ;ERROR
(5) 014230 104455          TRAP    C$ERDF
(6) 014232 000033          .WORD 27
(6) 014234 005525          .WORD EM27
(6) 014236 007644          .WORD ERR27
5234 014240          65$:
(3) 014240 104410          ESCAPE SEG
(3) 014242 000010          TRAP    C$ESCAPE
5235 014244 000241          .WORD 10000$-.
5236 014246 106105          CLC          ;CLEAR CARRY
5237 014250 001343          ROLB    R5          ;SHIFT BIT IN R2
5238 014252          BNE    64$          ;IF R2=0 THEN DONE
(3) 014252          ENDSEG
(3) 014252 104405          10000$:
5239 014254 012705 000001          TRAP    C$ESEG
5240          MOV    #1, R5          ;START WITH BIT 0
5241          COM    R5          ;CHANGE TO FLOATING ZERO
5241 014260          69$:
(3) 014260 104404          BGNSEG
5242 014262          TRAP    C$BSEG
5243 014262 005105          67$:
COM    R5
```

```
5244 014264 010561 000004      MOV      R5,4(R1)      ;PUT PATTERN INTO PORT4
5245 014270      ROMCLK      ;NEXT WORD IS INSTRUCTION, BBN
(1) 014270 004537 003244      JSR      R5,..ROMCLK  ;CLOCK INSTRUCTION
5246 014274 121102      121100!2      ;MOV DATA TO IBUS* REGISTER 2
5247 014276      ROMCLK      ;NEXT WORD IS INSTRUCTION, BBN
(1) 014276 004537 003244      JSR      R5,..ROMCLK  ;CLOCK INSTRUCTION
5248 014302 121045      121005!<2*20> ;READ FROM IBUS* REGISTER 2
5249 014304 116104 000005      MOV      5(R1),R4     ;PUT 'FOUND' INTO R4
5250 014310 120504      CMP      R5,R4       ;DATA CORRECT?
5251 014312 001414      BEQ      68$         ;BR IF YES
5252 014314      BERROR      27       ;ERROR
(5) 014334 104455      TRAP     C$ERDF
(6) 014336 000033      .WORD    27
(6) 014340 005525      .WORD    EM27
(6) 014342 007644      .WORD    ERR27
5253 014344      68$: ESCAPE      SEG
(3) 014344 104410      TRAP     C$ESCAPE
(3) 014346 000012      .WORD    10001$-
5254 014350 005105      COM      R5          ;CHANGE TO FLOATING 1
5255 014352 000241      CLC
5256 014354 106105      ROL      R5          ;CLEAR CARRY
5257 014356 001341      BNE      67$         ;SHIFT BIT IN R2
5258 014360      ENDSEG          ;IF R2=0 THEN DONE
(3) 014360      10001$: TRAP     C$ESEG
(3) 014360 104405      ENDTST
5259 014362      L10070: TRAP     C$ETST
(3) 014362 104401
5260
5261 014364      BADHEAD
(2)
5262      ;***** TEST 16 *****
5263      ;*MICRO PROCESSOR IBUS* REGISTER WRITE/READ TEST
5264      ;*FLOAT A 1 THROUGH IBUS* REGISTER 4
5265 014364      ;*FLOAT A 0 THROUGH IBUS* REGISTER 4
(2)      BADHEAD
5266      ;***** TEST 16 *****
5267 014364      BGNTST
(3) 014364      T16::
5268 014364      MSTCLR      ;MASTER CLEAR M8200.4,7
(1) 014364 004537 003156      JSR      R5,..MSTCLR ;CLEAR M8200.4,7
5269 014370 012737 000004 002624      MOV      #4,MRO     ;SAVE REGISTER ADDRESS FOR TYPEOUT
5270 014376 012705 000001      MOV      #1,R5      ;START WITH BIT 0
5271 014402      MYINT
(1) 014402 013701 002716      MOV      KMCSR,R1   ;GET DEVICE ADDRESS.
5272 014406      BGNSEG
(3) 014406 104404      TRAP     C$BSEG
5273 014410      64$:
5274 014410 010561 000004      MOV      R5,4(R1)   ;PUT PATTERN INTO PORT4
5275 014414      ROMCLK      ;NEXT WORD IS INSTRUCTION, BBN
(1) 014414 004537 003244      JSR      R5,..ROMCLK ;CLOCK INSTRUCTION
5276 014420 121104      121100!4      ;MOV DATA TO IBUS* REGISTER 4
5277 014422      ROMCLK      ;NEXT WORD IS INSTRUCTION, BBN
(1) 014422 004537 003244      JSR      R5,..ROMCLK ;CLOCK INSTRUCTION
5278 014426 121105      121005!<4*20> ;READ FROM IBUS* REGISTER 4
5279 014430 116104 000005      MOV      5(R1),R4   ;PUT 'FOUND' INTO R4
```

```
5280 014434 120504      CMPB   R5,R4      ;DATA CORRECT?
5281 014436 001414      BEQ    65$        ;BR IF YES
5282 014440              BERROR 27         ;ERROR
(5) 014460 104455      TRAP   C$ERDF
(6) 014462 000033      .WORD 27
(6) 014464 005525      .WORD EM27
(6) 014466 007644      .WORD ERR27
5283 014470              65$:  ESCAPE  SEG
(3) 014470 104410      TRAP   C$ESCAPE
(3) 014472 000010      .WORD 10000$-.
5284 014474 000241      CLC
5285 014476 106105      ROLB   R5         ;CLEAR CARRY
5286 014500 001343      BNE    64$        ;SHIFT BIT IN R2
5287 014502              ENDSEG           ;IF R2=0 THEN DONE
(3) 014502              10000$:
(3) 014502 104405      TRAP   C$ESEG
5288 014504 012705 000001  MOV    #1,R5      ;START WITH BIT 0
5289              ;69$:  COM     R5      ;CHANGE TO FLOATING ZERO
5290 014510              BGNSEG
(3) 014510 104404      TRAP   C$BSEG
5291 014512              67$:
5292 014512 005105      COM    R5
5293 014514 010561 000004  MOV    R5,4(R1)   ;PUT PATTERN INTO PORT4
5294 014520              ROMCLK           ;NEXT WORD IS INSTRUCTION, BBN
(1) 014520 004537 003244  JSR    R5,.ROMCLK ;CLOCK INSTRUCTION
5295 014524 121104      121100!4         ;MOV DATA TO IBUS* REGISTER 4
5296 014526              ROMCLK           ;NEXT WORD IS INSTRUCTION, BBN
(1) 014526 004537 003244  JSR    R5,.ROMCLK ;CLOCK INSTRUCTION
5297 014532 121105      121005!<4*20>   ;READ FROM IBUS* REGISTER 4
5298 014534 116104 000005  MOVB   5(R1),R4  ;PUT 'FOUND' INTO R4
5299 014540 120504      CMPB   R5,R4     ;DATA CORRECT?
5300 014542 001414      BEQ    68$        ;BR IF YES
5301 014544              BERROR 27         ;ERROR
(5) 014564 104455      TRAP   C$ERDF
(6) 014566 000033      .WORD 27
(6) 014570 005525      .WORD EM27
(6) 014572 007644      .WORD ERR27
5302 014574              68$:  ESCAPE  SEG
(3) 014574 104410      TRAP   C$ESCAPE
(3) 014576 000012      .WORD 10001$-.
5303 014600 005105      COM    R5         ;CHANGE TO FLOATING 1
5304 014602 000241      CLC
5305 014604 106105      ROLB   R5         ;CLEAR CARRY
5306 014606 001341      BNE    67$        ;SHIFT BIT IN R2
5307 014610              ENDSEG           ;IF R2=0 THEN DONE
(3) 014610              10001$:
(3) 014610 104405      TRAP   C$ESEG
5308 014612              ENDTST
(3) 014612              L10071:
(3) 014612 104401      TRAP   C$ETST
5309
5310 014614      BADHEAD
(2)
5311      ;***** TEST 17 *****
5312      ;*MICRO PROCESSOR IBUS* REGISTER WRITE/READ TEST
5313      ;*FLOAT A 1 THROUGH IBUS* REGISTER 5
5313      ;*FLOAT A 0 THROUGH IBUS* REGISTER 5
```

```

5314 014614          BADHEAD
      (2)             ;***** TEST 17 *****
5315
5316 014614          BGNTST
      (3) 014614      T17::
5317 014614          MSTCLR          ;MASTER CLEAR M8200,4,7
      (1) 014614 004537 003156      JSR      R5, .MSTCLR          ;CLEAR M8200,4,7
5318 014620 012737 000005 002624    MOV      #5, MR0          ;SAVE REGISTER ADDRESS FOR TYPEOUT
5319 014626 012705 000001          MOV      #1, R5          ;START WITH BIT 0
5320 014632          MYINT
      (1) 014632 013701 002716      MOV      KMCSR, R1        ;GET DEVICE ADDRESS.
5321 014636          BGNSEG
      (3) 014636 104404          TRAP     C$BSEG
5322 014640          64$:
5323 014640 010561 000004          MOV      R5, 4(R1)        ;PUT PATTERN INTO PORT4
5324 014644          ROMCLK          ;NEXT WORD IS INSTRUCTION, BBN
      (1) 014644 004537 003244      JSR      R5, .ROMCLK      ;CLOCK INSTRUCTION
5325 014650 121105          121100!5 ;MOV DATA TO IBUS* REGISTER 5
5326 014652          ROMCLK          ;NEXT WORD IS INSTRUCTION, BBN
      (1) 014652 004537 003244      JSR      R5, .ROMCLK      ;CLOCK INSTRUCTION
5327 014656 121125          121005!<5*20> ;READ FROM IBUS* REGISTER 5
5328 014660 116104 000005          MOV      5(R1), R4        ;PUT 'FOUND' INTO R4
5329 014664 120504          CMPB    R5, R4          ;DATA CORRECT?
5330 014666 001414          BEQ     65$            ;BR IF YES
5331 014670          BERROR 27          ;ERROR
      (5) 014710 104455          TRAP     C$ERDF
      (6) 014712 000033          .WORD   27
      (6) 014714 005525          .WORD   EM27
      (6) 014716 007644          .WORD   ERR27
5332 014720          65$:
      (3) 014720 104410          ESCAPE  SEG
      (3) 014722 000010          TRAP     C$ESCAPE
      (3) 014724 000241          .WORD   10000$-
5333 014724 000241          CLC
5334 014726 106105          ROLB    R5              ;CLEAR CARRY
5335 014730 001343          BNE     64$            ;SHIFT BIT IN R5
5336 014732          ENDSEG          ;IF R5=0 THEN DONE
      (3) 014732 104405          10000$:
5337 014734 012705 000001          TRAP     C$ESEG
5338          :69$:
5339 014740          COM      R5          ;START WITH BIT 0
      (3) 014740 104404          BGNSSEG ;CHANGE TO FLOATING ZERO
5340 014742          TRAP     C$BSEG
5341 014742 005105          67$:
5342 014744 010561 000004          COM      R5
5343 014750          MOV      R5, 4(R1)        ;PUT PATTERN INTO PORT4
      (1) 014750 004537 003244      ROMCLK ;NEXT WORD IS INSTRUCTION, BBN
5344 014754 121105          JSR      R5, .ROMCLK      ;CLOCK INSTRUCTION
5345 014756          121100!5 ;MOV DATA TO IBUS* REGISTER 5
      (1) 014756 004537 003244      ROMCLK ;NEXT WORD IS INSTRUCTION, BBN
5346 014762 121125          121005!<5*20> ;READ FROM IBUS* REGISTER 5
5347 014764 116104 000005          MOV      5(R1), R4        ;PUT 'FOUND' INTO R4
5348 014770 120504          CMPB    R5, R4          ;DATA CORRECT?
5349 014772 001414          BEQ     68$            ;BR IF YES
5350 014774          BERROR 27          ;ERROR
      (5) 015014 104455          TRAP     C$ERDF
  
```

```
(6) 015016 000033 .WORD 27
(6) 015020 005525 .WORD EM27
(6) 015022 007644 .WORD ERR27
5351 015024 68$: ESCAPE SEG
(3) 015024 104410 TRAP C$ESCAPE
(3) 015026 000012 .WORD 10001$-.
5352 015030 005105 COM R5 ;CHANGE TO FLOATING 1
5353 015032 000241 CLC ;CLEAR CARRY
5354 015034 106105 ROLB R5 ;SHIFT BIT IN R5
5355 015036 001341 BNE 67$ ;IF R5=0 THEN DONE
5356 015040 ENDSEG
(3) 015040 10001$: TRAP C$ESEG
5357 015042 ENDTST
(3) 015042 L10072: TRAP C$ETST
5358 015044 BADHEAD
5359 (2) ;***** TEST 18 *****
5360 ;*MICRO PROCESSOR IBUS* REGISTER WRITE/READ TEST
5361 ;*FLOAT A 1 THROUGH IBUS* REGISTER 10
5362 ;*FLOAT A 0 THROUGH IBUS* REGISTER 10
5363 015044 BADHEAD
5364 (2) ;***** TEST 18 *****
5365 015044 BGNST
(3) 015044 T18::
5366 015044 MSTCLR ;MASTER CLEAR M8200,4,7
(1) 015044 004537 003156 JSR R5, MSTCLR ;CLEAR M8200,4,7
5367 015050 012737 000010 002624 MOV #10, MRO ;SAVE REGISTER ADDRESS FOR TYPEOUT
5368 015056 012705 000001 MOV #1, R5 ;START WITH BIT 0
5369 015062 MYINT
(1) 015062 013701 002716 MOV KMCSR, R1 ;GET DEVICE ADDRESS.
5370 015066 BGNSEG
(3) 015066 104404 TRAP C$BSEG
5371 015070 64$:
5372 015070 010561 000004 MOV R5, 4(R1) ;PUT PATTERN INTO PORT4
5373 015074 042761 000141 000004 BIC #141, 4(R1) ;CLEAR UNWANTED BITS
5374 015102 ROMCLK ;NEXT WORD IS INSTRUCTION, BBN
(1) 015102 004537 003244 JSR R5, ROMCLK ;CLOCK INSTRUCTION
5375 015106 121110 121100!10 ;MOV DATA TO IBUS* REGISTER 10
5376 015110 ROMCLK ;NEXT WORD IS INSTRUCTION, BBN
(1) 015110 004537 003244 JSR R5, ROMCLK ;CLOCK INSTRUCTION
5377 015114 121205 121005!<10*20> ;READ FROM IBUS* REGISTER 10
5378 015116 010502 MOV R5, R2
5379 015120 042705 000141 BIC #141, R5 ;CLEAR UNWANTED BITS
5380 015124 116104 000005 MOVB 5(R1), R4 ;PUT 'FOUND' INTO R4
5381 015130 042704 000140 BIC #140, R4 ;CLEAR UNWANTED BITS
5382 015134 120504 CMPB R5, R4 ;DATA CORRECT?
5383 015136 001414 BEQ 65$ ;BR IF YES
5384 015140 BERROR 27 ;ERROR
(5) 015160 104455 TRAP C$ERDF
(6) 015162 000033 .WORD 27
(6) 015164 005525 .WORD EM27
(6) 015166 007644 .WORD ERR27
5385 015170 65$: ESCAPE SEG
```



```
(3) 015170 104410 TRAP C$ESCAPE
(3) 015172 000012 .WORD 10000$-.
5386 015174 010205 MOV R2,R5
5387 015176 000241 CLC ;CLEAR CARRY
5388 015200 106105 ROLB R5 ;SHIFT BIT IN R5
5389 015202 001332 BNE 64$ ;IF R5=0 THEN DONE
5390 015204 ENDSEG
(3) 015204 10000$: TRAP C$ESEG
(3) 015204 104405 MOV #1,R5 ;START WITH BIT 0
5391 015206 012705 000001 :69$: COM R5 ;CHANGE TO FLOATING ZERO
5392 015212 BGNSEG
5393 (3) 015212 104404 TRAP C$BSEG
5394 015214 67$: COM R5
5395 015214 005105 MOV R5,4(R1) ;PUT PATTERN INTO PORT4
5396 015216 010561 000004 BIC #141,4(R1) ;CLEAR UNWANTED BITS
5397 015222 042761 000141 000004 ROMCLK ;NEXT WORD IS INSTRUCTION, BBN
5398 015230 JSR R5,,ROMCLK ;CLOCK INSTRUCTION
(1) 015230 004537 003244 121100!10 ;MOV DATA TO IBUS* REGISTER 10
5399 015234 121110 ROMCLK ;NEXT WORD IS INSTRUCTION, BBN
5400 015236 (1) 015236 004537 003244 JSR R5,,ROMCLK ;CLOCK INSTRUCTION
5401 015242 121205 121005!<10*20> ;READ FROM IBUS* REGISTER 10
5402 015244 010502 MOV R5,R2
5403 015246 042705 000141 BIC #141,R5 ;CLEAR UNWANTED BITS
5404 015252 116104 000005 MOVB 5(R1),R4 ;PUT 'FOUND' INTO R4
5405 015256 042704 000140 BIC #140,R4 ;CLEAR UNWANTED BITS
5406 015262 120504 CMPB R5,R4 ;DATA CORRECT?
5407 015264 001414 BEQ 68$ ;BR IF YES
5408 015266 BERROR 27 ;ERROR
(5) 015306 104455 TRAP C$ERDF
(6) 015310 000033 .WORD 27
(6) 015312 005525 .WORD EM27
(6) 015314 007644 .WORD ERR27
5409 015316 68$: ESCAPE SEG
(3) 015316 104410 TRAP C$ESCAPE
(3) 015320 000014 .WORD 10001$-.
5410 015322 010205 MOV R2,R5
5411 015324 005105 COM R5 ;CHANGE TO FLOATING 1
5412 015326 000241 CLC ;CLEAR CARRY
5413 015330 106105 ROLB R5 ;SHIFT BIT IN R5
5414 015332 001330 BNE 67$ ;IF R5=0 THEN DONE
5415 015334 ENDSEG
(3) 015334 10001$: TRAP C$ESEG
(3) 015334 104405 ENDTST
(3) 015336 L10073: TRAP C$ETST
5417 015340 BADHEAD
(2) ;***** TEST 19 *****
5419 ;*MICRO PROCESSOR IBUS* REGISTER WRITE/READ TEST
5420 ;*FLOAT A 1 THROUGH IBUS* REGISTER 11
5421 ;*FLOAT A 0 THROUGH IBUS* REGISTER 11
5422 015340 BADHEAD
(2) ;***** TEST 19 *****
```

5423									
5424	015340					BGNTST			
(3)	015340					T19::			
5425	015340					MSTCLR			:MASTER CLEAR M8200.4.7
(1)	015340	004537	003156			JSR R5, .MSTCLR			:CLEAR M8200.4.7
5426	015344	012737	000011	002624		MOV #11, MRO			:SAVE REGISTER ADDRESS FOR TYPEOUT
5427	015352	012705	000001			MOV #1, R5			:START WITH BIT 0
5428	015356					MYINT			
(1)	015356	013701	002716			MOV KMCSR, R1			:GET DEVICE ADDRESS.
5429	015362					BGNSEG			
(3)	015362	104404				TRAP C\$BSEG			
5430	015364								
5431	015364	010561	000004			64\$: MOV R5, 4(R1)			:PUT PATTERN INTO PORT4
5432	015370	042761	000262	000004		BIC #262, 4(R1)			:CLEAR UNWANTED BITS
5433	015376					ROMCLK			:NEXT WORD IS INSTRUCTION, BBN
(1)	015376	004537	003244			JSR R5, .ROMCLK			:CLOCK INSTRUCTION
5434	015402	121111				121100!11			:MOV DATA TO IBUS* REGISTER 11
5435	015404					ROMCLK			:NEXT WORD IS INSTRUCTION, BBN
(1)	015404	004537	003244			JSR R5, .ROMCLK			:CLOCK INSTRUCTION
5436	015410	121225				121005!<11*20>			:READ FROM IBUS* REGISTER 11
5437	015412	010502				MOV R5, R2			
5438	015414	042705	000262			BIC #262, R5			:CLEAR UNWANTED BITS
5439	015420	116104	000005			MOV B 5(R1), R4			:PUT 'FOUND' INTO R4
5440	015424	042704	000020			BIC #20, R4			
5441	015430	120504				CMP B R5, R4			:DATA CORRECT?
5442	015432	001414				BEQ 65\$			:BR IF YES
5443	015434					BERROR 27			:ERROR
(5)	015454	104455				TRAP C\$ERDF			
(6)	015456	000033				.WORD 27			
(6)	015460	005525				.WORD EM27			
(6)	015462	007644				.WORD ERR27			

5445	015464			65\$:	ESCAPE	SEG		
(3)	015464	104410			TRAP	C\$ESCAPE		
(3)	015466	000012			.WORD	10000\$-		
5446	015470	010205			MOV	R2,R5		
5447	015472	000241			CLC			:CLEAR CARRY
5448	015474	106105			ROLB	R5		:SHIFT BIT IN R5
5449	015476	001332			BNE	64\$		:IF R5=0 THEN DONE
5450	015500				ENDSEG			
(3)	015500			10000\$:				
(3)	015500	104405			TRAP	C\$ESEG		
5451	015502	012705	000001		MOV	#1,R5		:START WITH BIT 0
5452				:69\$:	COM	R5		:CHANGE TO FLOATING ZERO
5453	015506				BGNSEG			
(3)	015506	104404			TRAP	C\$BSEG		
5454	015510			67\$:				
5455	015510	005105			COM	R5		
5456	015512	010561	000004		MOV	R5,4(R1)		:PUT PATTERN INTO PORT4
5457	015516	042761	000262	000004	BIC	#2,4(R1)		:CLEAR UNWANTED BITS
5458	015524				ROMCLK			:NEXT WORD IS INSTRUCTION, BBN
(1)	015524	004537	003244		JSR	R5,..ROMCLK		:CLOCK INSTRUCTION
5459	015530	121111			121100!11			:MOV DATA TO IBUS* REGISTER 11
5460	015532				ROMCLK			:NEXT WORD IS INSTRUCTION, BBN
(1)	015532	004537	003244		JSR	R5,..ROMCLK		:CLOCK INSTRUCTION
5461	015536	121225			121005!<11*20>			:READ FROM IBUS* REGISTER 11

```
5463 015540 010502          MOV      R5,R2
5464 015542 042705 000262    BIC      #262,R5          ;CLEAR UNWANTED BITS
5465 015546 052705 000020    BIS      #20,R5          ;ADD THESE BITS
5466 015552 116104 000005    MOVVB   5(R1),R4        ;PUT 'FOUND' INTO R4
5467 015556 120504          CMPB    R5,R4          ;DATA CORRECT?
5468 015560 001414          BEQ     68$            ;BR IF YES
5469 015562          BERROR  27            ;ERROR
(5) 015602 104455          TRAP   C$ERDF
(6) 015604 000033          .WORD  27
(6) 015606 005525          .WORD  EM27
(6) 015610 007644          .WORD  ERR27
5470 015612          68$:  ESCAPE  SEG
(3) 015612 104410          TRAP   C$ESCAPE
(3) 015614 000014          .WORD  10001$-
5471 015616 010205          MOV     R2,R5
5472 015620 005105          COM    R5              ;CHANGE TO FLOATING 1
5473 015622 000241          CLC
5474 015624 106105          ROLB  R5              ;CLEAR CARRY
5475 015626 001330          BNE   67$            ;SHIFT BIT IN R5
5476 015630          ENDSEG              ;IF R5=0 THEN DONE
(3) 015630          10001$:
(3) 015630 104405          TRAP   C$ESEG
5477 015632          ENDTST
(3) 015632          L10074:
(3) 015632 104401          TRAP   C$ETST
5478
5479 015634          BADHEAD
(2)
5480          ;***** TEST 20 *****
5481          ;*MICRO PROCESSOR IBUS REGISTER WRITE/READ TEST
5482          ;*FLOAT A 1 THROUGH IBUS REGISTER 0
5483 015634          ;*FLOAT A 0 THROUGH IBUS REGISTER 0
(2)          BADHEAD
5484          ;***** TEST 20 *****
5485 015634          BGNTST
(3) 015634          T20::
5486 015634          MSTCLR          ;MASTER CLEAR M8200.4,7
(1) 015634 004537 003156          JSR     R5,,MSTCLR      ;CLEAR M8200.4,7
5487 015640 012737 000000 002624    MOV     #0,MRO          ;SAVE REGISTER ADDRESS FOR TYPEOUT
5488 015646 012705 000001          MOV     #1,R5          ;START WITH BIT 0
5489 015652          MYINT
(1) 015652 013701 002716          MOV     KMCSR,R1       ;GET DEVICE ADDRESS.
5490 015656          BGNSEG
(3) 015656 104404          TRAP   C$BSEG
5491 015660          64$:
5492 015660 010561 000004          MOV     R5,4(R1)       ;PUT PATTERN INTO PORT4
5493 015664          ROMCLK          ;NEXT WORD IS INSTRUCTION, BBN
(1) 015664 004537 003244          JSR     R5,,ROMCLK     ;CLOCK INSTRUCTION
5494 015670 122100          122100          ;MOV DATA TO IBUS* REGISTER 0
5495 015672          ROMCLK          ;NEXT WORD IS INSTRUCTION, BBN
(1) 015672 004537 003244          JSR     R5,,ROMCLK     ;CLOCK INSTRUCTION
5496 015676 021005          21005          ;READ FROM IBUS* REGISTER 0
5497 015700 116104 000005          MOVVB   5(R1),R4        ;PUT 'FOUND' INTO R4
5498 015704 120504          CMPB    R5,R4          ;DATA CORRECT?
5499 015706 001414          BEQ     65$            ;BR IF YES
5500 015710          BERROR  29            ;ERROR
```

```
(5) 015730 104455 TRAP C$ERDF
(6) 015732 000035 .WORD 29
(6) 015734 005605 .WORD EM29
(6) 015736 010004 .WORD ERR29
5501 015740 65$: ESCAPE SEG
(3) 015740 104410 TRAP C$ESCAPE
(3) 015742 000010 .WORD 10000$-.
5502 015744 000241 CLC ;CLEAR CARRY
5503 015746 106105 ROLB R5 ;SHIFT BIT IN R5
5504 015750 001343 BNE 64$ ;IF R5=0 THEN DONE
5505 015752 ENDSEG
(3) 015752 10000$: TRAP C$ESEG
(3) 015752 104405 MOV #1,R5 ;START WITH BIT 0
5506 015754 012705 000001 ;69$: COM R5 ;CHANGE TO FLOATING ZERO
5507 015754 012705 000001 ;69$: COM R5 ;CHANGE TO FLOATING ZERO
5508 015760 67$: TRAP C$BSEG
(3) 015760 104404
5509 015762
5510 015762 005105 COM R5
5511 015764 010561 000004 MOV R5,4(R1) ;PUT PATTERN INTO PORT4
5512 015770 ROMCLK ;NEXT WORD IS INSTRUCTION, BBN
(1) 015770 004537 003244 JSR R5,..ROMCLK ;CLOCK INSTRUCTION
5513 015774 122100 122100 ;MOV DATA TO IBUS* REGISTER 0
5514 015776 ROMCLK ;NEXT WORD IS INSTRUCTION, BBN
(1) 015776 004537 003244 JSR R5,..ROMCLK ;CLOCK INSTRUCTION
5515 016002 021005 21005 ;READ FROM IBUS* REGISTER 0
5516 016004 116104 000005 MOVB 5(R1),R4 ;PUT 'FOUND' INTO R4
5517 016010 120504 CMPB R5,R4 ;DATA CORRECT?
5518 016012 001414 BEQ 68$ ;BR IF YES
5519 016014 BERROR 29 ;ERROR
(5) 016034 104455 TRAP C$ERDF
(6) 016036 000035 .WORD 29
(6) 016040 005605 .WORD EM29
(6) 016042 010004 .WORD ERR29
5520 016044 68$: ESCAPE SEG
(3) 016044 104410 TRAP C$ESCAPE
(3) 016046 000012 .WORD 10001$-.
5521 016050 005105 COM R5 ;CHANGE TO FLOATING 1
5522 016052 000241 CLC ;CLEAR CARRY
5523 016054 106105 ROLB R5 ;SHIFT BIT IN R5
5524 016056 001341 BNE 67$ ;IF R5=0 THEN DONE
5525 016060 ENDSEG
(3) 016060 10001$: TRAP C$ESEG
(3) 016060 104405
5526 016062 ENDTST
(3) 016062 L10075: TRAP C$ETST
(3) 016062 104401
5527
5528 016064 BADHEAD
(2) ;***** TEST 21 *****
5529 ;*MICRO PROCESSOR IBUS REGISTER WRITE/READ TEST
5530 ;*FLOAT A 1 THROUGH IBUS REGISTER 1
5531 ;*FLOAT A 0 THROUGH IBUS REGISTER 1
5532 016064 BADHEAD
(2) ;***** TEST 21 *****
5533
```

5534	016064			BGNTST		
(3)	016064			T21::		
5535	016064			MSTCLR		:MASTER CLEAR M8200.4.7
(1)	016064	004537	003156	JSR	R5, MSTCLR	:CLEAR M8200.4.7
5536	016070	012737	000001	MOV	#1, MRO	:SAVE REGISTER ADDRESS FOR TYPEOUT
5537	016076	012705	000001	MOV	#1, R5	:START WITH BIT 0
5538	016102			MYINT		
(1)	016102	013701	002716	MOV	KMCSR, R1	:GET DEVICE ADDRESS.
5539	016106			BGNSEG		
(3)	016106	104404		TRAP	C\$BSEG	
5540	016110					
5541	016110	010561	000004	MOV	R5, 4(R1)	:PUT PATTERN INTO PORT4
5542	016114			ROMCLK		:NEXT WORD IS INSTRUCTION, BBN
(1)	016114	004537	003244	JSR	R5, ROMCLK	:CLOCK INSTRUCTION
5543	016120	122101		122100!1		:MOV DATA TO IBUS* REGISTER 1
5544	016122			ROMCLK		:NEXT WORD IS INSTRUCTION, BBN
(1)	016122	004537	003244	JSR	R5, ROMCLK	:CLOCK INSTRUCTION
5545	016126	021025		21005!<1*20>		:READ FROM IBUS* REGISTER 1
5546	016130	116104	000005	MOVB	5(R1), R4	:PUT 'FOUND' INTO R4
5547	016134	120504		CMPB	R5, R4	:DATA CORRECT?
5548	016136	001414		BEQ	65\$	:BR IF YES
5549	016140			BERROR	29	:ERROR
(5)	016160	104455		TRAP	C\$ERDF	
(6)	016162	000035		.WORD	29	
(6)	016164	005605		.WORD	EM29	
(6)	016166	010004		.WORD	ERR29	
5550	016170			ESCAPE	SEG	
(3)	016170	104410		TRAP	C\$ESCAPE	
(3)	016172	000010		.WORD	10000\$-	
5551	016174	000241		CLC		:CLEAR CARRY
5552	016176	106105		ROLB	R5	:SHIFT BIT IN R5
5553	016200	001343		BNE	64\$	:IF R5=0 THEN DONE
5554	016202			ENDSEG		
(3)	016202					
(3)	016202	104405		10000\$:		
5555	016204	012705	000001	TRAP	C\$ESEG	
5556				MOV	#1, R5	:START WITH BIT 0
5557	016210			COM	R5	:CHANGE TO FLOATING ZERO
(3)	016210	104404		BGNSEG		
5558	016212			TRAP	C\$BSEG	
5559	016212	005105				
5560	016214	010561	000004	COM	R5	
5561	016220			MOV	R5, 4(R1)	:PUT PATTERN INTO PORT4
(1)	016220	004537	003244	ROMCLK		:NEXT WORD IS INSTRUCTION, BBN
5562	016224	122101		JSR	R5, ROMCLK	:CLOCK INSTRUCTION
5563	016226			122100!1		:MOV DATA TO IBUS* REGISTER 1
(1)	016226	004537	003244	ROMCLK		:NEXT WORD IS INSTRUCTION, BBN
5564	016232	021025		JSR	R5, ROMCLK	:CLOCK INSTRUCTION
5565	016234	116104	000005	21005!<1*20>		:READ FROM IBUS* REGISTER 1
5566	016240	120504		MOVB	5(R1), R4	:PUT 'FOUND' INTO R4
5567	016242	001414		CMPB	R5, R4	:DATA CORRECT?
5568	016244			BEQ	68\$	:BR IF YES
(5)	016264	104455		BERROR	29	:ERROR
(6)	016266	000035		TRAP	C\$ERDF	
(6)	016270	005605		.WORD	29	
(6)	016272	010004		.WORD	EM29	
				.WORD	ERR29	

```
5569 016274 68$: ESCAPE SEG
(3) 016274 104410 TRAP C$ESCAPE
(3) 016276 000012 .WORD 10001$-.
5570 016300 005105 COM R5 ;CHANGE TO FLOATING 1
5571 016302 000241 CLC ;CLEAR CARRY
5572 016304 106105 ROLB R5 ;SHIFT BIT IN R5
5573 016306 001341 BNE 67$ ;IF R5=0 THEN DONE
5574 016310 ENDSEG
(3) 016310 10001$: TRAP C$ESEG
(3) 016310 104405
5575 016312 ENDTST
(3) 016312 L10076: TRAP C$ETST
(3) 016312 104401

5576 016314 BADHEAD
5577 (2) ;***** TEST 22 *****
5578 ;*MICRO PROCESSOR IBUS REGISTER WRITE/READ TEST
5579 ;*FLOAT A 1 THROUGH IBUS REGISTER 2
5580 ;*FLOAT A 0 THROUGH IBUS REGISTER 2
5581 016314 BADHEAD
5582 (2) ;***** TEST 22 *****
5583 016314 BGNTST
(3) 016314 T22::
5584 016314 MSTCLR ;MASTER CLEAR M8200,4,7
(1) 016314 004537 003156 JSR R5, MSTCLR ;CLEAR M8200,4,7
5585 016320 012737 000002 002624 MOV #2, MRO ;SAVE REGISTER ADDRESS FOR TYPEOUT
5586 016326 012705 000001 MOV #1, R5 ;START WITH BIT 0
5587 016332 MYINT
(1) 016332 013701 002716 MOV KMCSR, R1 ;GET DEVICE ADDRESS.
5588 016336 BGNSEG
(3) 016336 104404 TRAP C$BSEG

5589 016340 64$: MOV R5, 4(R1) ;PUT PATTERN INTO PORT4
5590 016340 010561 000004 ROMCLK ;NEXT WORD IS INSTRUCTION, BBN
5591 016344 (1) 016344 004537 003244 JSR R5, ROMCLK ;CLOCK INSTRUCTION
5592 016350 122102 122100!2 ;MOV DATA TO IBUS* REGISTER 2
5593 016352 ROMCLK ;NEXT WORD IS INSTRUCTION, BBN
(1) 016352 004537 003244 JSR R5, ROMCLK ;CLOCK INSTRUCTION
5594 016356 021045 21005!<2*20> ;READ FROM IBUS* REGISTER 2
5595 016360 116104 000005 MOVB 5(R1), R4 ;PUT 'FOUND' INTO R4
5596 016364 120504 CMPB R5, R4 ;DATA CORRECT?
5597 016366 001414 BEQ 65$ ;BR IF YES
5598 016370 BERROR 29 ;ERROR
(5) 016410 104455 TRAP C$ERDF
(6) 016412 000035 .WORD 29
(6) 016414 005605 .WORD EM29
(6) 016416 010004 .WORD ERR29

5599 016420 65$: ESCAPE SEG
(3) 016420 104410 TRAP C$ESCAPE
(3) 016422 000010 .WORD 10000$-.
5600 016424 000241 CLC ;CLEAR CARRY
5601 016426 106105 ROLB R5 ;SHIFT BIT IN R5
5602 016430 001343 BNE 64$ ;IF R5=0 THEN DONE
5603 016432 ENDSEG
(3) 016432 10000$:
```

```
(3) 016432 104405 TRAP C$ESEG
5604 016434 012705 000001 :69$: MOV #1,R5 ;START WITH BIT 0
5605 COM R5 ;CHANGE TO FLOATING ZERO
5606 016440 BGNSEG
(3) 016440 104404 TRAP C$BSEG
5607 016442 67$: COM R5
5608 016442 005105 MOV R5,4(R1) ;PUT PATTERN INTO PORT4
5609 016444 010561 000004 ROMCLK ;NEXT WORD IS INSTRUCTION, BBN
5610 016450 JSR R5,..ROMCLK ;CLOCK INSTRUCTION
(1) 016450 004537 003244 122100!2 ;MOV DATA TO IBUS* REGISTER 2
5611 016454 122102 ROMCLK ;NEXT WORD IS INSTRUCTION, BBN
5612 016456 (1) 016456 004537 003244 JSR R5,..ROMCLK ;CLOCK INSTRUCTION
5613 016462 021045 21005!<2*20> ;READ FROM IBUS* REGISTER 2
5614 016464 116104 000005 MOVB 5(R1),R4 ;PUT 'FOUND' INTO R4
5615 016470 120504 CMPB R5,R4 ;DATA CORRECT?
5616 016472 001414 BEQ 68$ ;BR IF YES
5617 016474 BERROR 29 ;ERROR
(5) 016514 104455 TRAP C$ERDF
(6) 016516 000035 .WORD 29
(6) 016520 005605 .WORD EM29
(6) 016522 010004 .WORD ERR29
5618 016524 68$: ESCAPE SEG
(3) 016524 104410 TRAP C$ESCAPE
(3) 016526 000012 .WORD 10001$-.
5619 016530 005105 COM R5 ;CHANGE TO FLOATING 1
5620 016532 000241 CLC ;CLEAR CARRY
5621 016534 106105 ROLB R5 ;SHIFT BIT IN R5
5622 016536 001341 BNE 67$ ;IF R5=0 THEN DONE
5623 016540 ENDSEG
(3) 016540 10001$: TRAP C$ESEG
(3) 016540 104405 TRAP C$ESEG
5624 016542 ENDTST
(3) 016542 104401 L10077: TRAP C$ETST
5625 016544 BADHEAD
5626 (2) :***** TEST 23 *****
5627 :*MICRO PROCESSOR IBUS REGISTER WRITE/READ TEST
5628 :*FLOAT A 1 THROUGH IBUS REGISTER 3
5629 :*FLOAT A 0 THROUGH IBUS REGISTER 3
5630 016544 BADHEAD
(2) :***** TEST 23 *****
5631 BGNTST
5632 016544 T23::
(3) 016544 MSTCLR ;MASTER CLEAR M8200,4,7
5633 016544 JSR R5,..MSTCLR ;CLEAR M8200,4,7
(1) 016544 004537 003156 002624 MOV #3,MRO ;SAVE REGISTER ADDRESS FOR TYPEOUT
5634 016550 012737 000003 MOV #1,R5 ;START WITH BIT 0
5635 016556 012705 000001 MYINT
5636 016562 (1) 016562 013701 002716 MOV KMCSR,R1 ;GET DEVICE ADDRESS.
5637 016566 (3) 016566 104404 BGNSEG
5638 016570 64$: TRAP C$BSEG
5639 016570 010561 000004 MOV R5,4(R1) ;PUT PATTERN INTO PORT4
```



5640	016574			ROMCLK		:NEXT WORD IS INSTRUCTION, BBN
(1)	016574	004537	003244	JSR R5,ROMCLK		:CLOCK INSTRUCTION
5641	016600	122103		122100!3		:MOV DATA TO IBUS* REGISTER 3
5642	016602			ROMCLK		:NEXT WORD IS INSTRUCTION, BBN
(1)	016602	004537	003244	JSR R5,ROMCLK		:CLOCK INSTRUCTION
5643	016606	021065		21005!<3*20>		:READ FROM IBUS* REGISTER 3
5644	016610	116104	000005	MOVB 5(R1),R4		:PUT 'FOUND' INTO R4
5645	016614	120504		CMPB R5,R4		:DATA CORRECT?
5646	016616	001414		BEQ 65\$		:BR IF YES
5647	016620			BERROR 29		:ERROR
(5)	016640	104455		TRAP C\$ERDF		
(6)	016642	000035		.WORD 29		
(6)	016644	005605		.WORD EM29		
(6)	016646	010004		.WORD ERR29		
5648	016650			65\$: ESCAPE SEG		
(3)	016650	104410		TRAP C\$ESCAPE		
(3)	016652	000010		.WORD 10000\$-		
5649	016654	000241		CLC		:CLEAR CARRY
5650	016656	106105		ROLB R5		:SHIFT BIT IN R5
5651	016660	001343		BNE 64\$		:IF R5=0 THEN DONE
5652	016662			ENDSEG		
(3)	016662			10000\$: TRAP C\$ESEG		
(3)	016662	104405		MOV #1,R5		:START WITH BIT 0
5653	016664	012705	000001	:69\$: COM R5		:CHANGE TO FLOATING ZERO
5654				BGNSEG		
5655	016670			TRAP C\$BSEG		
(3)	016670	104404				
5656	016672			67\$: COM R5		
5657	016672	005105		MOV R5,4(R1)		:PUT PATTERN INTO PORT4
5658	016674	010561	000004	ROMCLK		:NEXT WORD IS INSTRUCTION, BBN
5659	016700			JSR R5,ROMCLK		:CLOCK INSTRUCTION
(1)	016700	004537	003244	122100!3		:MOV DATA TO IBUS* REGISTER 3
5660	016704	122103		ROMCLK		:NEXT WORD IS INSTRUCTION, BBN
5661	016706			JSR R5,ROMCLK		:CLOCK INSTRUCTION
(1)	016706	004537	003244	21005!<3*20>		:READ FROM IBUS* REGISTER 3
5662	016712	021065		MOVB 5(R1),R4		:PUT 'FOUND' INTO R4
5663	016714	116104	000005	CMPB R5,R4		:DATA CORRECT?
5664	016720	120504		BEQ 68\$		:BR IF YES
5665	016722	001414		BERROR 29		:ERROR
5666	016724			TRAP C\$ERDF		
(5)	016744	104455		.WORD 29		
(6)	016746	000035		.WORD EM29		
(6)	016750	005605		.WORD ERR29		
(6)	016752	010004		68\$: ESCAPE SEG		
5667	016754			TRAP C\$ESCAPE		
(3)	016754	104410		.WORD 10001\$-		
(3)	016756	000012		COM R5		:CHANGE TO FLOATING 1
5668	016760	005105		CLC		:CLEAR CARRY
5669	016762	000241		ROLB R5		:SHIFT BIT IN R5
5670	016764	106105		BNE 67\$		:IF R5=0 THEN DONE
5671	016766	001341		ENDSEG		
5672	016770			10001\$: TRAP C\$ESEG		
(3)	016770	104405				
(3)	016770			ENDTST		
5673	016772			L10100:		
(3)	016772					

```
(3) 016772 104401 TRAP C$ETST
5674
5675 016774 BADHEAD
(2) :***** TEST 24 *****
5676 :*MICRO PROCESSOR IBUS REGISTER WRITE/READ TEST
5677 :*FLOAT A 1 THROUGH IBUS REGISTER 4
5678 :*FLOAT A 0 THROUGH IBUS REGISTER 4
5679 016774 BADHEAD
(2) :***** TEST 24 *****
5680
5681 016774 BGNTST
(3) 016774 T24::
5682 016774 MSTCLR ;MASTER CLEAR M8200.4.7
(1) 016774 004537 003156 JSR R5,.MSTCLR ;CLEAR M8200.4.7
5683 017000 012737 000004 002624 MOV #4,MRO ;SAVE REGISTER ADDRESS FOR TYPEOUT
5684 017006 012705 000001 MOV #1,R5 ;START WITH BIT 0
5685 017012 MYINT
(1) 017012 013701 002716 MOV KMCSR,R1 ;GET DEVICE ADDRESS.
5686 017016 BGNSEG
(3) 017016 104404 TRAP C$BSEG
5687 017020 64$:
5688 017020 010561 000004 MOV R5,4(R1) ;PUT PATTERN INTO PORT4
5689 017024 ROMCLK ;NEXT WORD IS INSTRUCTION, BBN
(1) 017024 004537 003244 JSR R5,.ROMCLK ;CLOCK INSTRUCTION
5690 017030 122104 122100!4 ;MOV DATA TO IBUS* REGISTER 4
5691 017032 ROMCLK ;NEXT WORD IS INSTRUCTION, BBN
(1) 017032 004537 003244 JSR R5,.ROMCLK ;CLOCK INSTRUCTION
5692 017036 021105 21005!<4*20> ;READ FROM IBUS* REGISTER 4
5693 017040 116104 000005 MOVB 5(R1),R4 ;PUT 'FOUND' INTO R4
5694 017044 120504 CMPB R5,R4 ;DATA CORRECT?
5695 017046 001414 BEQ 65$ ;BR IF YES
5696 017050 BERROR 29 ;ERROR
(5) 017070 104455 TRAP C$ERDF
(6) 017072 000035 .WORD 29
(6) 017074 005605 .WORD EM29
(6) 017076 010004 .WORD ERR29
5697 017100 65$:
(3) 017100 104410 ESCAPE SEG
(3) 017102 000010 TRAP C$ESCAPE
5698 017104 000241 .WORD 10000$-
5699 017106 106105 CLC ;CLEAR CARRY
5700 017110 001343 ROLB R5 ;SHIFT BIT IN R5
5701 017112 BNE 64$ ;IF R5=0 THEN DONE
(3) 017112 ENDSEG
(3) 017112 104405 10000$:
5702 017114 012705 000001 TRAP C$ESEG
5703 017120 69$:
(3) 017120 104404 COM #1,R5 ;START WITH BIT 0
5704 017122 BGNSEG ;CHANGE TO FLOATING ZERO
(3) 017122 104404 TRAP C$BSEG
5705 017122 67$:
5706 017122 005105 COM R5
5707 017124 010561 000004 MOV R5,4(R1) ;PUT PATTERN INTO PORT4
5708 017130 ROMCLK ;NEXT WORD IS INSTRUCTION, BBN
(1) 017130 004537 003244 JSR R5,.ROMCLK ;CLOCK INSTRUCTION
5709 017134 122104 122100!4 ;MOV DATA TO IBUS* REGISTER 4
5710 017136 ROMCLK ;NEXT WORD IS INSTRUCTION, BBN
```

```
(1) 017136 004537 003244 JSR R5,.ROMCLK ;CLOCK INSTRUCTION
5711 017142 021105 21005!<4*20> ;READ FROM IBUS* REGISTER 4
5712 017144 116104 000005 MOVB 5(R1),R4 ;PUT 'FOUND' INTO R4
5713 017150 120504 CMPB R5,R4 ;DATA CORRECT?
5714 017152 001414 BEQ 68$ ;BR IF YES
5715 017154 BERROR 29 ;ERROR
(5) 017174 104455 TRAP C$ERDF
(6) 017176 000035 .WORD 29
(6) 017200 005605 .WORD EM29
(6) 017202 010004 .WORD ERR29
5716 017204 68$: ESCAPE SEG
(3) 017204 104410 TRAP C$ESCAPE
(3) 017206 000012 .WORD 10001$-
5717 017210 005105 COM R5 ;CHANGE TO FLOATING 1
5718 017212 000241 CLC ;CLEAR CARRY
5719 017214 106105 ROLB R5 ;SHIFT BIT IN R5
5720 017216 001341 BNE 67$ ;IF R5=0 THEN DONE
5721 017220 ENDSEG
(3) 017220 10001$: TRAP C$ESEG
5722 017222 ENDTST
(3) 017222 L10101: TRAP C$ETST
5723 017224 BADHEAD
5724 017224 :***** TEST 25 *****
(2) 5725 :*MICRO PROCESSOR IBUS REGISTER WRITE/READ TEST
5726 :*FLOAT A 1 THROUGH IBUS REGISTER 5
5727 :*FLOAT A 0 THROUGH IBUS REGISTER 5
5728 017224 BADHEAD
(2) 5729 :***** TEST 25 *****
5730 017224 BGNTST
(3) 017224 T25::
5731 017224 MSTCLR ;MASTER CLEAR M8200,4,7
(1) 017224 004537 003156 JSR R5,.MSTCLR ;CLEAR M8200,4,7
5732 017230 012737 000005 002624 MOV #5,MRO ;SAVE REGISTER ADDRESS FOR TYPEOUT
5733 017236 012705 000001 MOV #1,R5 ;START WITH BIT 0
5734 017242 MYINT
(1) 017242 013701 002716 MOV KMCSR,R1 ;GET DEVICE ADDRESS.
5735 017246 BGNSEG
(3) 017246 104404 TRAP C$BSEG
5736 017250 64$: MOV R5,4(R1) ;PUT PATTERN INTO PORT4
5737 017250 010561 000004 ROMCLK ;NEXT WORD IS INSTRUCTION, BBN
5738 017254 (1) 017254 004537 003244 JSR R5,.ROMCLK ;CLOCK INSTRUCTION
5739 017260 122105 122100!5 ;MOV DATA TO IBUS* REGISTER 5
5740 017262 ROMCLK ;NEXT WORD IS INSTRUCTION, BBN
(1) 017262 004537 003244 JSR R5,.ROMCLK ;CLOCK INSTRUCTION
5741 017266 021125 21005!<5*20> ;READ FROM IBUS* REGISTER 5
5742 017270 116104 000005 MOVB 5(R1),R4 ;PUT 'FOUND' INTO R4
5743 017274 120504 CMPB R5,R4 ;DATA CORRECT?
5744 017276 001414 BEQ 65$ ;BR IF YES
5745 017300 BERROR 29 ;ERROR
(5) 017320 104455 TRAP C$ERDF
(6) 017322 000035 .WORD 29
```

```
(6) 017324 005605 .WORD EM29
(6) 017326 010004 .WORD ERR29
5746 017330 65$: ESCAPE SEG
(3) 017330 104410 TRAP C$ESCAPE
(3) 017332 000010 .WORD 10000$-.
5747 017334 000241 CLC ;CLEAR CARRY
5748 017336 106105 ROLB R5 ;SHIFT BIT IN R5
5749 017340 001343 BNE 64$ ;IF R5=0 THEN DONE
5750 017342 ENDSEG
(3) 017342 10000$: TRAP C$ESEG
(3) 017342 104405 MOV #1,R5 ;START WITH BIT 0
5751 017344 012705 000001 :69$: COM R5 ;CHANGE TO FLOATING ZERO
5752 017344 012705 000001 BGNSEG
5753 017350 67$: TRAP C$BSEG
(3) 017350 104404 COM R5
5754 017352 67$: MOV R5,4(R1) ;PUT PATTERN INTO PORT4
5755 017352 005105 ROMCLK ;NEXT WORD IS INSTRUCTION, BBN
5756 017354 010561 000004 JSR R5,,ROMCLK ;CLOCK INSTRUCTION
5757 017360 ROMCLK 122100!5 ;MOV DATA TO IBUS* REGISTER 5
(1) 017360 004537 003244 JSR R5,,ROMCLK ;NEXT WORD IS INSTRUCTION, BBN
5758 017364 122105 ROMCLK 21005!<5*20> ;READ FROM IBUS* REGISTER 5
5759 017366 004537 003244 JSR R5,,ROMCLK ;CLOCK INSTRUCTION
5760 017372 021125 MOVB 5(R1),R4 ;PUT "FOUND" INTO R4
5761 017374 116104 000005 CMPB R5,R4 ;DATA CORRECT?
5762 017400 120504 BEQ 68$ ;BR IF YES
5763 017402 001414 BERROR 29 ;ERROR
5764 017404 TRAP C$ERDF
(5) 017424 104455 .WORD 29
(6) 017426 000035 .WORD EM29
(6) 017430 005605 .WORD ERR29
(6) 017432 010004 68$: ESCAPE SEG
5765 017434 68$: TRAP C$ESCAPE
(3) 017434 104410 .WORD 10001$-.
(3) 017436 000012 COM R5 ;CHANGE TO FLOATING 1
5766 017440 005105 CLC ;CLEAR CARRY
5767 017442 000241 ROLB R5 ;SHIFT BIT IN R5
5768 017444 106105 BNE 67$ ;IF R5=0 THEN DONE
5769 017446 001341 ENDSEG
5770 017450 10001$: TRAP C$ESEG
(3) 017450 104405 ENDTST
(3) 017452 L10102: TRAP C$ETST
(3) 017452 104401
5772 017454 BADHEAD
5773 017454 (2) :***** TEST 26 *****
5774 :*MICRO PROCESSOR IBUS REGISTER WRITE/READ TEST
5775 :*FLOAT A 1 THROUGH IBUS REGISTER 6
5776 :*FLOAT A 0 THROUGH IBUS REGISTER 6
5777 017454 BADHEAD
(2) :***** TEST 26 *****
5778 :
5779 017454 BGNTST
(3) 017454 T26::
```



```
(3) 017666 000012 .WORD 10001$-.
5815 017670 005105 COM R5 ;CHANGE TO FLOATING 1
5816 017672 000241 CLC ;CLEAR CARRY
5817 017674 106105 ROLB R5 ;SHIFT BIT IN R5
5818 017676 001341 BNE 67$ ;IF R5=0 THEN DONE
5819 017700 ENDSEG
(3) 017700 10001$: TRAP C$ESEG
(3) 017700 104405 ENDTST
5820 017702 L10103: TRAP C$ESETST
(3) 017702 104401
5821 017704 BADHEAD
5822 017704 ;***** TEST 27 *****
(2) ;*MICRO PROCEOR IBUS* REGISTER WRITE/READ TEST
5823 ;*FLOAT A 1 THOUGH IBUS* REGISTER 7
5824 ;*FLOAT A 0 THROUGH IBUS* REGISTER 7
5825 BADHEAD
5826 017704 ;***** TEST 27 *****
(2)
5827
5828 017704 BGNTST
(3) 017704 T27::
5829 017704 MSTCLR ;MASTER CLEAR M8200,4,7
(1) 017704 004537 003156 JSR R5, MSTCLR ;CLEAR M8200,4,7
5830 017710 012737 000007 002624 MOV #7, MRO ;SAVE REGISTER ADDRESS FOR TYPEOUT
5831 017716 012705 000001 MOV #1, R5 ;START WITH BIT 0
5832 017722 MYINT
(1) 017722 013701 002716 MOV KMCSR, R1 ;GET DEVICE ADDRESS.
5833 017726 BGNSEG
(3) 017726 104404 TRAP C$BSEG
5834 017730 64$: MOV R5, 4(R1) ;PUT PATTERN INTO PORT4
5835 017730 010561 000004 ROMCLK ;NEXT WORD IS INSTRUCTION, BBN
5836 017734 (1) 017734 004537 003244 JSR R5, ROMCLK ;CLOCK INSTRUCTION
5837 017740 122107 122100!7 ;MOV DATA TO IBUS* REGISTER 7
5838 017742 ROMCLK ;NEXT WORD IS INSTRUCTION, BBN
(1) 017742 004537 003244 JSR R5, ROMCLK ;CLOCK INSTRUCTION
5839 017746 021165 21005!<7*20> ;READ FROM IBUS* REGISTER 7
5840 017750 116104 000005 MOVB 5(R1), R4 ;PUT 'FOUND' INTO R4
5841 017754 120504 CMPB R5, R4 ;DATA CORRECT?
5842 017756 001414 BEQ 65$ ;BR IF YES
5843 017760 BERROR 29 ;ERROR
(5) 020000 104455 TRAP C$ERDF
(6) 020002 000035 .WORD 29
(6) 020004 005605 .WORD EM29
(6) 020006 010004 .WORD ERR29
5844 020010 65$: ESCAPE SEG
(3) 020010 104410 TRAP C$ESCAPE
(3) 020012 000010 .WORD 10000$-.
5845 020014 000241 CLC ;CLEAR CARRY
5846 020016 106105 ROLB R5 ;SHIFT BIT IN R5
5847 020020 001343 BNE 64$ ;IF R5=0 THEN DONE
5848 020022 ENDSEG
(3) 020022 10000$: TRAP C$ESEG
(3) 020022 104405 MOV #1, R5 ;START WITH BIT 0
5849 020024 012705 000001
```

```
5850 ;69$: COM R5 ;CHANGE TO FLOATING ZERO
5851 020030 BGNSEG
(3) 020030 104404 TRAP C$BSEG
5852 020032
5853 020032 005105
5854 020034 010561 000004
5855 020040
(1) 020040 004537 003244
5856 020044 122107
5857 020046
(1) 020046 004537 003244
5858 020052 021165
5859 020054 116104 000005
5860 020060 120504
5861 020062 001414
5862 020064
(5) 020104 104455
(6) 020106 000035
(6) 020110 005605
(6) 020112 010004
5863 020114
(3) 020114 104410
(3) 020116 000012
5864 020120 005105
5865 020122 000241
5866 020124 106105
5867 020126 001341
5868 020130
(3) 020130
(3) 020130 104405
5869 020132
(3) 020132
(3) 020132 104401
5870
5871 020134
(2)
5872
5873
5874
5875 020134
(2)
5876
5877 020134
(3) 020134
5878 020134
(1) 020134 004537 003156
5879 020140 012705 000001
5880 020144 005002
5881 020146
(1) 020146 013701 002716
5882 020152
(3) 020152 104404
5883 020154 010203
5884 020156 010561 000004
5885 020162 042737 000017 020200
5886 020170 050337 020200

;67$: COM R5 ;PUT PATTERN INTO PORT4
BGNSEG ;NEXT WORD IS INSTRUCTION, BBN
TRAP C$BSEG ;CLOCK INSTRUCTION
;MOV DATA TO IBUS* REGISTER 7
;NEXT WORD IS INSTRUCTION, BBN
;CLOCK INSTRUCTION
;READ FROM IBUS* REGISTER 7
;PUT "FOUND" INTO R4
;DATA CORRECT?
;BR IF YES
;ERROR

68$: ESCAPE SEG
TRAP C$ESCAPE
.WORD 10001$-
COM R5 ;CHANGE TO FLOATING 1
CLC ;CLEAR CARRY
ROLB R5 ;SHIFT BIT IN R5
BNE 67$ ;IF R5=0 THEN DONE
ENDSEG

10001$: TRAP C$ESEG
ENDTST
L10104: TRAP C$ETST

BADHEAD
:***** TEST 28 *****
:*MICRO PROCESSOR IBUS DUAL ADDRESS TEST
:*WRITE ALL IBUS REGISTERS WITH INCREMENTING PATTERN
:*READ ALL IBUS REGISTERS TO VERIFY CORRECT ADDRESSING
BADHEAD
:***** TEST 28 *****

BGNTST
T28:: MSTCLR ;MASTER CLEAR M8200,4,7
JSR R5,.MSTCLR ;CLEAR M8200,4,7
MOV #1,R5 ;START WITH A ONE
CLR R2 ;R2 CONTAINS ADDRESS OF REGISTER
MYINT
MOV KMCSR,R1 ;GET DEVICE ADDRESS.
BGNSEG
TRAP C$BSEG
1$: MOV R2,R3 ;R3=REGISTER ADDRESS
MOV R5,4(R1) ;WRITE DATA TO PORT4
BIC #17,5$ ;CLEAR ADDRESS FIELD OF INSTRUCTION
BIS R3,5$ ;ADD ADDRESS TO INSTRUCTION
```





```
5925 020426          ENDSEG
(3) 020426          10001$: TRAP C$ESEG
(3) 020426 104405
5926 020430          ENDTST
(3) 020430          L10105: TRAP C$ETST
(3) 020430 104401
5927
5928 020432          BADHEAD
(2)                  :***** TEST 29 *****
5929                  :*MICRO PROCESSOR BR REGISTER TEST
5930                  :*FLOAT A 1 THOUGH THE BR
5931                  :*FLOAT A 0 THOUGH THE BR
5932 020432          BADHEAD
(2)                  :***** TEST 29 *****
5933
5934 020432          BGNTST
(3) 020432          T29::
5935                  ;R1 CONTAINS BASE M8200,4,7 ADDRESS
5936 020432          MSTCLR          ;MASTER CLEAR COMM. MICRO-PROCESSOR FAMILY
(1) 020432 004537 003156      JSR R5,,MSTCLR          ;CLEAR M8200,4,7
5937 020436 012702 000001      MOV #1,R2              ;START PATTERN WITH BIT0
5938 020442          MYINT
(1) 020442 013701 002716      MOV KMCSR,R1          ;GET DEVICE ADDRESS.
5939 020446          BGNSEG
(3) 020446 104404          TRAP C$BSEG
5940 020450          64$:
5941 020450 010261 000004      MOV R2,4(R1)          ;WRITE PATTERN IN PORT4
5942 020454          ROMCLK          ;NEXT WORD IS INSTRUCTION, BBN
(1) 020454 004537 003244      JSR R5,,ROMCLK          ;CLOCK INSTRUCTION
5943 020460 120500          120500 ;MOVE DATA TO THE BR REGISTER
5944 020462          ROMCLK          ;NEXT WORD IS INSTRUCTION, BBN
(1) 020462 004537 003244      JSR R5,,ROMCLK          ;CLOCK INSTRUCTION
5945 020466 061225          061225 ;MOVE BR TO PORT 5
5946 020470 116104 000005      MOVB 5(R1),R4         ;PUT 'FOUND' IN R4
5947 020474 120204          CMPB R2,R4            ;IS DATA CORRECT?
5948 020476 001414          BEQ 65$              ;BR IF YES
5949 020500          BERROR          ;DATA ERROR
(5) 020520 104455          TRAP C$ERDF
(6) 020522 000003          .WORD 3
(6) 020524 004416          .WORD EM3
(6) 020526 006210          .WORD ERR3
5950 020530          65$:
(3) 020530 104410          ESCAPE SEG
(3) 020532 000010          TRAP C$ESCAPE
(3) 020534 000241          .WORD 10000$-
5951 020536 106102          CLC                  ;CLEAR CARRY
5952 020540 001343          ROLB R2              ;SHIFT BIT IN R2
5953 020542          BNE 64$              ;DONE IF R2=0
(3) 020544          ENDSEG
(3) 020544 104405          10000$: TRAP C$ESEG
5954 020544 012702 000001      MOV #1,R2              ;START PATTERN WITH BIT0
5955 020550          69$:
(3) 020550 104404          BGNSEG
5956 020552          TRAP C$BSEG
5957 020552          67$:
(3) 020552 005102          COM R2
```

```
5960 020554 010261 000004      MOV      R2,4(R1)      ;WRITE PATTERN IN PORT4
5961 020560      ROMCLK      ;NEXT WORD IS INSTRUCTION, BBN
(1) 020560 004537 003244      JSR      R5,,ROMCLK   ;CLOCK INSTRUCTION
5962 020564 120500      120500      ;MOVE DATA TO THE BR REGISTER
5963 020566      ROMCLK      ;NEXT WORD IS INSTRUCTION, BBN
(1) 020566 004537 003244      JSR      R5,,ROMCLK   ;CLOCK INSTRUCTION
5964 020572 061225      061225      ;MOVE DR TO PORT 5
5965 020574 116104 000005      MOV      5(R1),R4     ;PUT 'FOUND' IN $GDDAT
5966 020600 010205      MOV      R2,R5
5967 020602 120204      CMP      R2,R4        ;DATA CORRECT?
5968 020604 001414      BEQ      68$          ;BR IF YES
5969 020606      BERROR      3          ;DATA ERROR
(5) 020626 104455      TRAP     C$ERDF
(6) 020630 000003      .WORD    3
(5) 020632 004416      .WORD    EM3
(6) 020634 006210      .WORD    ERR3
5970 020636      68$:      ESCAPE     SEG
(3) 020636 104410      TRAP     C$ESCAPE
(3) 020640 000016      .WORD    10001$-.
5971      ;FAILED TO CLEAR
5972 020642 105061 000001      70$:      CLRB     1(R1)      ;BRG
5973 020646 005102      COM      R2          ;CHANGE BACK TO A ONE
5974 020650 000241      CLC      ;CLEAR CARRY
5975 020652 106102      ROLB     R2          ;SHIFT BIT IN R5
5976 020654 001336      BNE      67$          ;DONE IF R5=0
5977 020656      ENDSEG
(3) 020656      10001$:   TRAP     C$ESEG
(3) 020656 104405      ENDTST
(3) 020660      L10106:   TRAP     C$ETST
(3) 020660 104401
5979
5980 020662      BADHEAD
(2)      ;***** TEST 30 *****
5981      ;*SCRATCH PAD TEST
5982      ;*FLOAT A 1 THOUGH EACH SCRATCH PAD LOCATION
5983      ;*FLOAT A 0 THOUGH EACH SCRATCH PAD LOCATION
5984 020662      BADHEAD
(2)      ;***** TEST 30 *****
5985
5986 020662      BGNTST
(3) 020662      T30::
5987 020662      MYINT
(1) 020662 013701 002716      MOV      KMCSR,R1     ;GET DEVICE ADDRESS.
5988 020666      MSTCLR      ;MASTER CLEAR M8200,4,7
(1) 020666 004537 003156      JSR      R5,,MSTCLR   ;CLEAR M8200,4,7
5989 020672 005002      CLR      R2          ;START AT ADDRESS ZERO
5990 020674 012705 000001      MOV      #1,R5       ;START WITH BIT0
5991 020700      BGNSUB
(3) 020700      T30.1:   TRAP     C$BSUB
(3) 020700 104402      1$:      BGNSEG
(3) 020702 104404      TRAP     C$BSEG
5993 020704 042737 000017 020726 64$:      BIC      #17,65$     ;CLEAR ADDRESS FIELD OF INSTRUCTION
5994 020712 050237 020726      BIS      R2,65$      ;ADD ADDRESS TO INSTRUCTION
5995 020716 010561 000004      MOV      R5,4(R1)    ;WRITE PATTERN IN PORT4
```

5996	020722				ROMCLK				:NEXT WORD IS INSTRUCTION, BBN
(1)	020722	004537	003244		JSR	R5,ROMCLK			:CLOCK INSTRUCTION
5997	020726	123100		020746	65\$:	123100			:WRITE SCRATCH PAD(ADDRESS IN R2)
5998	020730	042737	000017		BIC	#17,66\$			:CLEAR ADDRESS FIELD OF INSTRUCTION
5999	020736	050237	020746		BIS	R2,66\$			:ADD ADDRESS TO INSTRUCTION
6000	020742				ROMCLK				:NEXT WORD IS INSTRUCTION, BBN
(1)	020742	004537	003244		JSR	R5,ROMCLK			:CLOCK INSTRUCTION
6001	020746	040600			66\$:	040600			:MOVE SP TO BR
6002	020750				ROMCLK				:NEXT WORD IS INSTRUCTION, BBN
(1)	020750	004537	003244		JSR	R5,ROMCLK			:CLOCK INSTRUCTION
6003	020754	061225			MOV	R5,\$GDDAT			:MOVE BR TO PORT5
6004	020756	010537	002636		MOVB	5(R1),R4			:PUT 'EXPECTED' IN \$GDDAT
6005	020762	116104	000005		CMPB	\$GDDAT,R4			:PUT 'FOUND' IN R4
6006	020766	123704	002636		BEQ	67\$			:DATA CORRECT
6007	020772	001414			RERROR	4			:BR IF YES
6008	020774				TRAP	C\$ERDF			:DATA ERROR
(5)	021014	104455			.WORD	4			
(6)	021016	000004			.WORD	EM4			
(6)	021020	004444			.WORD	ERR4			
(6)	021022	006266			67\$:	ESCAPE	SEG		
6009	021024				TRAP	C\$ESCAPE			
(3)	021024	104410			.WORD	10000\$-			
(3)	021026	000010			CLC				:CLEAR CARRY
6010	021030	000241			ROLB	R5			:SHIFT BIT IN R5
6011	021032	106105			BNE	64\$			:DONE IF R5=0
6012	021034	001323			ENDSEG				
6013	021036				10000\$:	TRAP	C\$ESEG		
(3)	021036	104405			MOV	#1,R5			:START WITH BIT0
6014	021040	012705	000001		BGNSEG				
6015	021044				TRAP	C\$BSEG			
(3)	021044	104404							
6016									
6017	021046	005105			73\$:	COM	R5		:CHANGE TO FLOATING ZERO
6018	021050	042737	000017	021072	69\$:	BIC	#17,70\$		:CLEAR ADDRESS FIELD OF INSTRUCTION
6019	021056	050237	021072		BIS	R2,70\$			:ADD ADDRESS TO INSTRUCTION
6020	021062	010561	000004		MOV	R5,4(R1)			:WRITE PATTERN IN PORT4
6021	021066				ROMCLK				:NEXT WORD IS INSTRUCTION, BBN
(1)	021066	004537	003244		JSR	R5,ROMCLK			:CLOCK INSTRUCTION
6022	021072	123100			70\$:	123100			:WRITE SCRATCH PAD(ADDRESS IN R2)
6023	021074	042737	000017	021112	BIC	#17,71\$			:CLEAR ADDRESS FIELD OF INSTRUCTION
6024	021102	050237	021112		BIS	R2,71\$			:ADD ADDRESS TO INSTRUCTION
6025	021106				ROMCLK				:NEXT WORD IS INSTRUCTION, BBN
(1)	021106	004537	003244		JSR	R5,ROMCLK			:CLOCK INSTRUCTION
6026	021112	040600			71\$:	040600			:MOVE SP TO BR
6027	021114				ROMCLK				:NEXT WORD IS INSTRUCTION, BBN
(1)	021114	004537	003244		JSR	R5,ROMCLK			:CLOCK INSTRUCTION
6028	021120	061225			MOV	R5,\$GDDAT			:MOVE BR TO PORT5
6029	021122	010537	002636		MOVB	5(R1),R4			:PUT 'EXPECTED' IN \$GDDAT
6030	021126	116104	000005		CMPB	\$GDDAT,R4			:PUT 'FOUND' IN \$GDDAT
6031	021132	123704	002636		BEQ	72\$			:DATA CORRECT?
6032	021136	001414			RERROR	4			:BR IF YES
6033	021140				TRAP	C\$ERDF			:DATA ERROR
(5)	021160	104455			.WORD	4			
(6)	021162	000004			.WORD	EM4			
(6)	021164	004444							

```
(6) 021166 006266
6034 021170
(3) 021170 104410
(3) 021172 000032
6035 021174 005105
6036 021176 000241
6037 021200 106105
6038 021202 001321
6039 021204
(3) 021204
(3) 021204 104405
6040 021206 012705 000001
6041 021212 005202
6042 021214 022702 000020
6043 021220 001230
6044 021222
(3) 021222
(3) 021222 104403
6045 021224
(3) 021224
(3) 021224 104401
6046
6047 021226
(2)
6048
6049
6050
6051 021226
(2)
6052
6053 021226
(3) 021226
6054 021226
(1) 021226 004537 003156
6055 021232 012705 000001
6056 021236 005003
6057 021240
(1) 021240 013701 002716
6058 021244
(3) 021244 104404
6059 021246 010302
6060 021250 042737 000017 021272
6061 021256 050237 021272
6062 021262 010561 000004
6063 021266
(1) 021266 004537 003244
6064 021272 123100
6065 021274 042737 000017 021312
```

```
72$: .WORD ERR4
      ESCAPE TST
      TRAP C$ESCAPE
      .WORD L10107-
      COM R5 ;CHANGE BACK TO A ONE
      CLC ;CLEAR CARRY
      ROLB R5 ;SHIFT BIT IN R5
      BNE 73$ ;DONE IF R5=0

ENDSEG
10001$: TRAP C$ESEG
        MOV #1,R5 ;RESTART AT BIT 0
        INC R2 ;NEXT SP ADDRESS
        CMP #20,R2 ;LAST ADDRESS?
        BNE 1$ ;BR IF NO
        ENDSUB

L10110: TRAP C$ESUB

ENDTST
L10107: TRAP C$ETST

BADHEAD
:***** TEST 31 *****
:*SCRATCH PAD DUAL ADDRESSING TEST
:*WRITE AN INCREMENTING PATTERN IN ALL SP LOCATIONS
:*READ ALL SP LOCATIONS TO VERIFY CORRECT ADDRESSING
BADHEAD
:***** TEST 31 *****

BGNTST
T31:: MSTCLR ;MASTER CLEAR M8200,4,7
      JSR R5,,MSTCLR ;CLEAR M8200,4,7
      MOV #1,R5 ;START WITH A 1
      CLR R3 ;ADDRESS 0
      MYINT
      MOV KMCSR,R1 ;GET DEVICE ADDRESS.
      BGNSEG
      TRAP C$BSEG
      MOV R3,R2 ;MOVE ADDRESS TO R2
      BIC #17,2$ ;CLEAR ADDRESS FIELD
      BIS R2,2$ ;ADD ADDRESS TO INSTRUCTION
      MOV R5,4(R1) ;WRITE PATTERN IN PORT4
      ROMCLK ;NEXT WORD IS INSTRUCTION, BBN
      JSR R5,,ROMCLK ;CLOCK INSTRUCTION
      123100 ;WRITE SP(ADDRESS IN R2)
      BIC #17,3$ ;CLEAR ADDRESS FIELD OF INSTRUCTION
```

CZDMPCO M8207 STATIC DIAG #1  
CZDMPC.P11 13-JUL-81 15:46

MACY11 30A(1052) 13-JUL-81 16:06 PAGE 52  
HARDWARE TESTS

J 11

SEQ 0139

6067 021302 050237 021312  
6068 021306  
(1) 021306 004537 003244

BIS R2,3\$  
ROMCLK  
JSR R5,ROMCLK

;ADD ADDRESS TO INSTRUCTION  
;NEXT WORD IS INSTRUCTION, BBN  
;CLOCK INSTRUCTION



(3) 021536  
(3) 021536 104401  
6106  
6107 021540  
(2)  
6108  
6109  
6110 021540  
(2)  
6111  
6112 021540  
(3) 021540  
6113 021540  
(1) 021540 013701 002716  
6114 021544  
(3) 021544 104433  
6115 021546 005011  
6116 021550 004537 003552  
6117 021554 021674  
6118 021556 021646  
6119 021560 000340 000340  
6120 021564  
(3) 021564 012700 000340  
(3) 021570 104441  
6121 021572 012761 000200 000004  
6122 021600  
(1) 021600 004537 003244  
6123 021604 121111  
6124 021606  
(3) 021606 012700 000000  
(3) 021612 104441  
6125 021614 000240  
6126 021616  
(5) 021634 104455  
(6) 021636 000037  
(6) 021640 005312  
(6) 021642 010144  
6127 021644 000415  
6128 021646  
(5) 021664 104455  
(6) 021666 000040  
(6) 021670 005341  
(6) 021672 010172  
6129 021674 062706 000004  
6130 021700  
6131 021700  
(3) 021700  
(3) 021700 104401  
6132  
6133 021702  
(2)  
6134  
6135  
6136 021702  
(2)  
6137

L10111:  
TRAP C\$ETST  
  
BADHEAD  
:\*\*\*\*\* TEST 32 \*\*\*\*\*  
:\*INTERRUPT TEST  
:\*TEST THAT DEVICE CAN INTERRUPT TO VECTOR A  
BADHEAD  
:\*\*\*\*\* TEST 32 \*\*\*\*\*  
  
BGNTST  
T32::  
MYINT  
MOV KMCSR,R1 ;GET DEVICE ADDRESS.  
BRESET ;BUS RESET  
TRAP C\$RESET  
CLR (R1) ;CLEAR RUN  
JSR R5,SETVEC ;SET UP VECTORS  
3\$ ;XX0  
2\$ ;XX4  
.WORD 340,340 ;LEVEL 7  
1\$: SETPRI #PRI07 ;PS = LEVEL 7  
MOV #PRI07,R0  
TRAP C\$SPRI  
MOV #200,4(R1) ;WRITE PORT4  
ROMCLK ;NEXT WORD IS INSTRUCTION, BBN  
JSR R5,.ROMCLK ;CLOCK INSTRUCTION  
121111 ;SET BR RQ IN IBUS\* REG 11  
SETPRI #PRI00 ;ALLOW INTERRUPT  
MOV #PRI00,R0  
TRAP C\$SPRI  
NOP  
ERROR 31 ;NO INTERRUPT  
TRAP C\$ERDF  
.WORD 31  
.WORD EM31  
.WORD ERR31  
BR 4\$  
2\$: ERROR 32 ;WRONG VECTOR  
TRAP C\$ERDF  
.WORD 32  
.WORD EM32  
.WORD ERR32  
3\$: ADD #4,SP ;RESET STACK  
4\$:  
ENDTST  
L10112:  
TRAP C\$ETST  
  
BADHEAD  
:\*\*\*\*\* TEST 33 \*\*\*\*\*  
:\*INTERRUPT TEST  
:\*TEST THAT DEVICE CAN INTERRUPT TO VECTOR B  
BADHEAD  
:\*\*\*\*\* TEST 33 \*\*\*\*\*

```
6138 021702          BGNTST
(3) 021702          T33::
6139 021702          MYINT
(1) 021702 013701 002716  MOV KMCSR,R1      ;GET DEVICE ADDRESS.
6140 021706          MSTCLR           ;MASTER CLEAR M8200,4,7
(1) 021706 004537 003156  JSR R5,,MSTCLR   ;CLEAR M8200,4,7
6141 021712 004537 003552  JSR R5,SETVEC   ;SET UP VECTORS
6142 021716 022010          2$           ;XX0
6143 021720 022036          3$           ;XX4
6144 021722 000340 000340  .WORD 340,340   ;LEVEL 7
6145 021726          1$: SETPRI #PRI07    ;PS = LEVEL 7
(3) 021726 012700 000340  MOV #PRI07,R0
(3) 021732 104441          TRAP C$SPRI
6146 021734 012761 000300 000004  MOV #300,4(R1)  ;WRITE PORT4
6147 021742          ROMCLK           ;NEXT WORD IS INSTRUCTION, BBN
(1) 021742 004537 003244  JSR R5,,ROMCLK  ;CLOCK INSTRUCTION
6148 021746 121111          SETPRI #PRI00   ;SET BR RQ IN IBUS* REG 11
6149 021750          MOV #PRI00,R0    ;ALLOW INTERRUPT
(3) 021750 012700 000000  TRAP C$SPRI
(3) 021754 104441          NOP
6150 021756 000240          ERROR 31        ;NO INTERRUPT
6151 021760          TRAP C$ERDF
(5) 021776 104455          .WORD 31
(6) 022000 000037          .WORD EM31
(6) 022002 005312          .WORD ERR31
(6) 022004 010144          BR 4$
6152 022006 000415          2$: ERROR 32        ;WRONG VECTOR
(5) 022026 104455          TRAP C$ERDF
(6) 022030 000040          .WORD 32
(6) 022032 005341          .WORD EM32
(6) 022034 010172          .WORD ERR32
6154 022036 062706 000004  3$: ADD #4,SP    ;RESET STACK
6155 022042          4$:
6156 022042          ENDTST
(3) 022042          L10113:
(3) 022042 104401          TRAP C$ETST
6157
6158 022044          BADHEAD
(2)          ;***** TEST 34 *****
6159          ;*PRIORITY INTERRUPT TEST
6160          ;*SET PS TO ALL BR LEVELS EQUAL OR GREATER THAN
6161          ;*THE M8200,4,7 LEVEL, VERIFY THAT M8200,4,7 DOES NOT INTERRUPT
6162 022044          BADHEAD
(2)          ;***** TEST 34 *****
6163
6164 022044          BGNTST
(3) 022044          T34::
6165 022044          MYINT
(1) 022044 013701 002716  MOV KMCSR,R1      ;GET DEVICE ADDRESS.
6166 022050          MSTCLR           ;MASTER CLEAR M8200,4,7
(1) 022050 004537 003156  JSR R5,,MSTCLR   ;CLEAR M8200,4,7
6167 022054 012704 000340  MOV #340,R4      ;PUT LEVEL 7 IN R2
6168 022060          SETPRI R4        ;SET PRIORITY TO 7
(3) 022060 010400          MOV R4,R0
(3) 022062 104441          TRAP C$SPRI
```



```
6169 022064 013705 002700      MOV     STAT1,R5      ;GET BR LEVEL OF M8200,4,7
6170 022070 006205              ASR     R5            ;SHIFT R5 4 TIMES
6171 022072 006205              ASR     R5            ;TO GET PROPER LEVEL
6172 022074 006205              ASR     R5
6173 022076 006205              ASR     R5
6174 022100 042705 177437      BIC     #177437,R5    ;CLEAR UNWANTED BITS
6175 022104 010537 002636      MOV     R5,$GDDAT
6176 022110 004537 003552      JSR     R5,SETVEC    ;SET UP VECTORS
6177 022114 022160              2$
6178 022116 022160              2$
6179 022120 000340 000340      .WORD  340,340      ;A VECTOR
6180 022124 012761 000200 000004 4$:  MOV     #200,4(R1)   ;B VECTOR
6181 022132              ROMCLK              ;PRIORITY 7
(1) 022132 004537 003244      JSR     R5,ROMCLK    ;LOAD PORT4
6182 022136 121111              121111              ;NEXT WORD IS INSTRUCTION, BBN
6183 022140              5$:  SETPRI  R4            ;CLOCK INSTRUCTION
(3) 022140 010400              MOV     R4,R0        ;SET BR REQUEST
(3) 022142 104441              TRAP   C$SPRI        ;PUT LEVEL IN R2 IN PS
6184 022144 000240              NOP
6185 022146 020504              CMP     R5,R4        ;IS PRESENT PS LEVEL = TO M8200,4,7 LEVEL
6186 022150 001420              BEQ    1$            ;BR IF YES
6187 022152 162704 000040      SUB     #40,R4       ;NO GET NEXT LOWER LEVEL IN R2
6188 022156 000770              BR     5$            ;AND CONTINUE WITH TEST
6189 022160              2$:  BRESET
(3) 022160 104433              TRAP   C$RESET
6190 022162              ERROR  33            ;ERROR UNEXPECTED INTERRUPT
(5) 022200 104455              TRAP   C$ERDF
(6) 022202 000041              .WORD  33
(6) 022204 005400              .WORD  EM33
(6) 022206 010220              .WORD  ERR33
6191 022210 000002              RTI
6192 022212              1$:  MSTCLR
(1) 022212 004537 003156      JSR     R5,MSTCLR    ;CLEAR M8200,4,7
6193 022216              ENDTST
(3) 022216              L10114:
(3) 022216 104401              TRAP   C$ETST
6194
6195 022220              BADHEAD
(2)
6196              ;***** TEST 35 *****
6197              ;*PRIORITY INTERRUPT TESTS
6198              ;*SET PS TO ALL BR LEVELS LESS THAN THE M8200,4,7 LEVEL
6199 022220              ;*VERIFY THAT M8200,4,7 WILL INTERRUPT
(2)              BADHEAD
6200              ;***** TEST 35 *****
6201 022220              BGNTST
(3) 022220              T35::
6202 022220              MYINT
(1) 022220 013701 002716      MOV     KMCSR,R1     ;GET DEVICE ADDRESS.
6203 022224              MSTCLR              ;MASTER CLEAR M8200,4,7
(1) 022224 004537 003156      JSR     R5,MSTCLR    ;CLEAR M8200,4,7
6204 022230 012704 000340      MOV     #340,R4      ;PUT LEVEL 7 IN R2
6205 022234              SETPRI  R4            ;SET PRIORITY TO 7
(3) 022234 010400              MOV     R4,R0
(3) 022236 104441              TRAP   C$SPRI
6206 022240 013705 002700      MOV     STAT1,R5     ;GET BR LEVEL OF M8200,4,7
```

6207	022244	006205			ASR	R5		:SHIFT R5 4 TIMES
6208	022246	006205			ASR	R5		:TO GET PROPER LEVEL
6209	022250	006205			ASR	R5		
6210	022252	006205			ASR	R5		
6211	022254	042705	177437		BIC	#177437,R5		:CLEAR UNWANTED BITS
6212	022260	010502			MOV	R5,R2		:PUT M8200,4,7 LEVEL IN R2
6213	022262	162702	000040		SUB	#40,R2		:GET NEXT LOWER LEVEL IN R2
6214	022266	004537	003552		JSR	R5,SETVEC		:SET UP VECTORS
6215	022272	022354			2\$			:A VECTOR
6216	022274	022362			3\$			:B VECTOR
6217	022276	000340	000340		.WORD	340,340		:PRIORITY 7
6218	022302	012761	000200	000004	4\$:	MOV	#200,4(R1)	:LOAD PORT4
6219	022310				ROMCLK			:NEXT WORD IS INSTRUCTION, BBN
(1)	022310	004537	003244		JSR	R5,.ROMCLK		:CLOCK INSTRUCTION
6220	022314	121111			121111			:SET BR REQUEST
6221	022316				5\$:	SETPRI	R2	:PUT LEVEL IN R2 IN PS
(3)	022316	010200			MCV	R2,R0		
(3)	022320	104441			TRAP	C\$SPRI		
6222	022322	000240			NOP			
6223	022324				ERROR	31		:ERROR, NO INTERRUPT
(5)	022324	104455			TRAP	C\$ERDF		
(6)	022344	000037			.WORD	31		
(6)	022346	005312			.WORD	EM31		
(6)	022350	010144			.WORD	ERR31		
6224	022352	000421			6\$:	BR	1\$	
6225	022354	012716	022352		2\$:	MOV	#6\$(SP)	:SET UP FOR RTI
6226	022360	000002			RTI			
6227	022362				3\$:	ERROR	32	:ERROR, WRONG VECTOR
(5)	022400	104455			TRAP	C\$ERDF		
(6)	022402	000040			.WORD	32		
(6)	022404	005341			.WORD	EM32		
(6)	022406	010172			.WORD	ERR32		
6228	022410	012716	022416		MOV	#1\$(SP)		:SET UP FOR RTI
6229	022414	000002			RTI			
6230	022416				1\$:	MSTCLR		
(1)	022416	004537	003156		JSR	R5,.MSTCLR		:CLEAR M8200,4,7
6231	022422				ENDTST			
(3)	022422				L10115:			
(3)	022422	104401			TRAP	C\$ETST		
6232								
6233	022424				BADHEAD			
(2)					:***** TEST 36 *****			
6234					:*NPR TEST			
6235					:*TEST OF DATO, 1 WORD FROM UPROC TO 11 MEMORY			
6236	022424				BADHEAD			
(2)					:***** TEST 36 *****			
6237								
6238	022424				BUNTST			
(3)	022424				T36::			
6239	022424				BRESET			:BUS RESET
(3)	022424	104433			TRAP	C\$RESET		
6240								
6241	022426				MYINT			
(1)	022426	013701	002716		MOV	KMCSR,R1		:GET DEVICE ADDRESS.
6242	022432	005011			CLR	(R1)		:CLEAR RUN
6243	022434	005061	000004		CLR	4(R1)		:CLR PORT4

6244	022440	004537	003574		JSR	R5,NPRSET	:SET UP IBUS REG 0-7
6245	022444	000000			0		:IN DATA
6246	022446	177777			-1		:OUT DATA
6247	022450	022564			3\$		:IN BA
6248	022452	022562			2\$		:OUT BA
6249	022454	005037	022562		CLR	2\$	:CLEAR 2\$
6250	022460	005061	000004		CLR	4(R1)	:CLEAR PORT 4
6251	022464				ROMCLK		:NOW MOVE TO IBUS*<11>
(1)	022464	004537	003244		JSR	R5,.ROMCLK	:CLOCK INSTRUCTION
6252	022470	121111			121111		
6253	022472	012761	000021	000004	MOV	#21,4(R1)	:WRITE PORT4
6254	022500				ROMCLK		:NEXT WORD IS INSTRUCTION, BBN
(1)	022500	004537	003244		JSR	R5,.ROMCLK	:CLOCK INSTRUCTION
6255	022504	121110			121110		:SET NPR BITS IN IBUS* REG 10
6256	022506	000240			NOP		
6257	022510	012737	177777	002636	MOV	#-1,\$GDDAT	:PUT 'EXPECTED' IN \$GDDAT
6258	022516	013704	022562		MOV	2\$,R4	:PUT 'FOUND' IN R4
6259	022522	023704	002636		CMP	\$GDDAT,R4	:DATA CORRECT?
6260	022526	001413			BEQ	4\$	:BR IF YES
6261	022530				ERROR	11,YES	:ERROR NPR FAILED
(5)	022542	104455			TRAP	C\$ERDF	
(6)	022544	000013			.WORD	11	
(6)	022546	004654			.WORD	EM11	
(6)	022550	006660			.WORD	ERR11	
6262	022552				ESCAPE	TST	
(3)	022552	104410			TRAP	C\$ESCAPE	
(3)	022554	000012			.WORD	L10116-	
6263	022556			4\$:	EXIT	TST	
(3)	022556	104432			TRAP	C\$EXIT	
(3)	022560	000006			.WORD	L10116-	
6264	022562	000000			0		:OUT BA
6265	022564	000000		2\$:	0		:IN BA
6266	022566			3\$:	0		
(3)	022566			ENDTST			
(3)	022566	104401		L10116:	TRAP	C\$ETST	
6267							
6268	022570				BADHEAD		
(2)					:***** TEST 37 *****		
6269					:*NPR TEST		
6270					:*TEST OF DATI, 1 WORD FROM 11 MEMORY TO UPROC		
6271	022570				BADHEAD		
(2)					:***** TEST 37 *****		
6272							
6273	022570			BGNTST			
(3)	022570			T37::			
6274	022570				MYINT		
(1)	022570	013701	002716		MOV	KMCSR,R1	:GET DEVICE ADDRESS.
6275	022574				MSTCLR		:MASTER CLEAR M8200,4,7
(1)	022574	004537	003156		JSR	R5,.MSTCLR	:CLEAR M8200,4,7
6276	022600	005061	000004		CLR	4(R1)	:CLR PORT4
6277	022604	004537	003574		JSR	R5,NPRSET	:SET UP IBUS REG 0-7
6278	022610	000000			0		:IN DATA
6279	022612	177777			-1		:OUT DATA
6280	022614	022734			3\$		:IN BA
6281	022616	022732			2\$		:OUT BA
6282	022620	012737	177777	022734	MOV	#-1,3\$	:PUT DATA IN 3\$

```
6283 022626 012761 000001 000004      MOV      #1,4(R1)      ;WRITE PORT4
6284 022634      ROMCLK      ;NEXT WORD IS INSTRUCTION, BBN
(1) 022634 004537 003244      JSR      R5,ROMCLK    ;CLOCK INSTRUCTION
6285 022640 121110      121110      ;SET NPR BITS IN IBUS* REG 11
6286 022642 000240      NOP
6287 022644 012737 177777 002636      MOV      #-1,$GDDAT   ;PUT 'EXPECTED' IN $GDDAT
6288 022652      ROMCLK      ;NEXT WORD IS INSTRUCTION, BBN
(1) 022652 004537 003244      JSR      R5,ROMCLK    ;CLOCK INSTRUCTION
6289 022656 021004      021004      ;MOVE IN DATA LOW BYTE TO PORT4
6290 022660      ROMCLK      ;NEXT WORD IS INSTRUCTION, BBN
(1) 022660 004537 003244      JSR      R5,ROMCLK    ;CLOCK INSTRUCTION
6291 022664 021025      021025      ;MOVE IN DATA HIGH BYTE TO PORT5
6292 022666 016104 000004      MOV      4(R1),R4     ;PUT 'FOUND' IN R4
6293 022672 023704 002636      CMP      $GDDAT,R4   ;DATA CORRECT?
6294 022676 001413      BEQ      4$          ;BR IF YES
6295 022700      ERROR      11,YES    ;ERROR NPR FAILED
(5) 022712 104455      TRAP     C$ERDF
(6) 022714 000013      .WORD    11
(6) 022716 004654      .WORD    EM11
(6) 022720 006660      .WORD    ERR11
6296 022722      ESCAPE     TST
(3) 022722 104410      TRAP     C$ESCAPE
(3) 022724 000012      .WORD    L10117-
6297 022726      4$:      EXIT      TST
(3) 022726 104432      TRAP     C$EXIT
(3) 022730 000006      .WORD    L10117-
6298 022732 000000      2$:      0          ;OUT BA
6299 022734 000000      3$:      0          ;IN BA
6300 022736      ENDTST
(3) 022736      L10117:
(3) 022736 104401      TRAP     C$ETST
6301
6302 022740      BADHEAD
(2)
6303      ;***** TEST 38 *****
6304      ;*NPR TEST
6305 022740      ;*TEST OF DATOB, 1 BYTE FROM UPROC TO 11 MEMORY
(2)      BADHEAD
6306      ;***** TEST 38 *****
6307 022740      BGNTST
(3) 022740      T38::
6308 022740      MYINT
(1) 022740 013701 002716      MOV      KMCSR,R1    ;GET DEVICE ADDRESS.
6309 022744      MSTCLR     ;MASTER CLEAR M8200,4,7
(1) 022744 004537 003156      JSR      R5,MSTCLR   ;CLEAR M8200,4,7
6310 022750 005061 000004      CLR      4(R1)       ;CLR PORT4
6311 022754 004537 003574      JSR      R5,NPRSET   ;SET UP IBUS REG 0-7
6312 022760 000000      0          ;IN DATA
6313 022762 177777      -1        ;OUT DATA
6314 022764 023100      3$        ;IN BA
6315 022766 023077      2$+1     ;OUT BA
6316 022770 005037 023076      CLR      2$          ;CLEAR 2$
6317 022774 005061 000004      CLR      4(R1)       ;CLEAR PORT 4
6318 023000      ROMCLK
(1) 023000 004537 003244      JSR      R5,ROMCLK   ;NOW MOVE IT TO IBUS*<11>
6319 023004 121111      121111      ;CLOCK INSTRUCTION
```

```
6320 023006 012761 000221 000004      MOV      #221,4(R1)      ;WRITE PORT4
6321 023014      ROMCLK      ;NEXT WORD IS INSTRUCTION, BBN
(1) 023014 004537 003244      JSR      R5,.,ROMCLK    ;CLOCK INSTRUCTION
6322 023020 121110      121110      ;SET NPR BITS IN IBUS* REG 11
6323 023022 000240      NOP
6324 023024 012737 177400 002636      MOV      #177400,$GDDAT ;PUT 'EXPECTED' IN $GDDAT
6325 023032 013704 023076      MOV      2$,R4          ;PUT 'FOUND' IN R4
6326 023036 023704 002636      CMP      $GDDAT,R4      ;DATA CORRECT?
6327 023042 001413      BEQ      4$            ;BR IF YES
6328 023044      ERROR     11,YES        ;ERROR NPR FAILED
(5) 023056 104455      TRAP     C$ERDF
(6) 023060 000013      .WORD    11
(6) 023062 004654      .WORD    EM11
(6) 023064 006660      .WORD    ERR11
6329 023066      ESCAPE    TST
(3) 023066 104410      TRAP     C$ESCAPE
(3) 023070 000012      .WORD    L10120-.
6330 023072      4$:      EXIT     TST
(3) 023072 104432      TRAP     C$EXIT
(3) 023074 000006      .WORD    L10120-.
6331 023076 000000      2$:      0                ;OUT BA
6332 023100 000000      3$:      0                ;IN BA
6333 023102      ENDTST
(3) 023102      L10120:
(3) 023102 104401      TRAP     C$ETST
6334
6335 023104      BADHEAD
(2)
6336      ;***** TEST 39 *****
6337      ;*TEST OF EA BITS 16 AND 17
6338      ;*DO A DATO TO AN ADDRESS USING OUT BA BITS 16 AND 17
6339 023104      ;*VERIFY CORRECT RESULTS
(2)      BADHEAD
6340      ;***** TEST 39 *****
6341 023104      BGNTST
(3) 023104      T39::
6342 023104      MSTCLR    ;MASTER CLEAR M8200,4,7
(1) 023104 004537 003156      JSR      R5,.,MSTCLR    ;CLEAR M8200,4,7
6343 023110      MYINT
(1) 023110 013701 002716      MOV      KMCSR,R1      ;GET DEVICE ADDRESS.
6344 023114 013737 002726 023142      MOV      KMP06,1$      ;USE SEL4 FOR ADDRESS
6345 023122 013737 002726 023140      MOV      KMP06,2$      ;USE SEL4 FOR ADDRESS
6346 023130 004537 003574      JSR      R5,NPRSET     ;LOAD BA AND DATA
6347 023134 000000      0          ;IN DATA
6348 023136 125252      125252     ;OUT DATA
6349 023140 000000      2$:      0          ;IN BA
6350 023142 000000      1$:      0          ;OUT BA
6351 023144 012761 000014 000004      MOV      #14,4(R1)     ;LOAD SEL 4 WITH OUT BA16 AND 17
6352 023152      ROMCLK    ;NEXT WORD IS INSTRUCTION, BBN
(1) 023152 004537 003244      JSR      R5,.,ROMCLK    ;CLOCK INSTRUCTION
6353 023156 121111      121111     ;SET OUTBA 16 AND 17
6354 023160 012761 000021 000004      MOV      #21,4(R1)     ;LOAD SEL4
6355 023166 012711 003000      MOV      #BIT9!BIT10,(R1)
6356 023172 012761 121110 000006      MOV      #121110,6(R1) ;PUT INSTRUCTION IN SEL6
6357 023200 052711 000400      BIS      #BIT8,(R1)    ;CLOCK IT!
6358 023204 000240      NOP          ;WAIT FOR NPR
```

```
6359 023206 012737 121110 002636      MOV      #121110,$GDDAT ;PUT 'EXPECTED' IN $GDDAT
6360 023214 000240                      NOP
6361 023216 000240                      NOP
6362                                     ;OK,LISTEN UP!EXPLANATION TIME.
6363                                     ;
6364                                     ;ON THE NPR OUT,THE DATA ENDED UP
6365                                     ;IN THE IBUS(NOT IBUS*) SENCE SEL A
6366                                     ;WAS ONLY SELECTED IN THE NPR CYCLE.
6367                                     ;THAT IS,WE DIDN'T REALLY DO AN NPR TO
6368                                     ;PORT 6,THE NPR OUT REALLY ENDED UP IN
6369                                     ;OUT DATA LOW,AND OUT DATA HIGH
6370                                     ;(IBUS <2> AND IBUS <3>).
6371
6372                                     ;WHAT WE'RE DOING NEXT IS READING IBUS 2&3
6373                                     ;TO SEE IF THE DATA GOT XFERRED CORRECTLY.
6374 023220                      ROMCLK
(1) 023220 004537 003244      JSR      R5,ROMCLK ;CLOCK INSTRUCTION
6375 023224 021044                      021044 ;READ IBUS <2> PUT IN PORT 4
6376 023226                      ROMCLK
(1) 023226 004537 003244      JSR      R5,ROMCLK ;CLOCK INSTRUCTION
6377 023232 021065                      021065 ;READ IBUS <3> PUT IN PORT 5
6378 023234 016104 000004      MOV      4(R1),R4 ;PUT 'FOUND' IN R4
6379 023240 023704 002636      CMP      $GDDAT,R4 ;CORRECT RESULTS?
6380 023244 001411                      BEQ      3$ ;BR IF YES
6381 023246                      ERROR 11,YES ;ERROR BA 16 AND 17 FAILED
(5) 023260 104455                      TRAP    C$ERDF
(6) 023262 000013                      .WORD  11
(6) 023264 004654                      .WORD  EM11
(6) 023266 006660                      .WORD  ERR11
6382 023270
6383 023270                      3$:
(3) 023270                      ENDTST
(3) 023270 104401                      L10121:
6384                                     TRAP    C$ETST
6385 023272                      BADHEAD
(2)                                     ;***** TEST 40 *****
6386                                     ;*TEST OF EA BITS 16 AND 17
6387                                     ;*DO A DATI USING IN BA BITS 16 AND 17
6388                                     ;*VERIFY CORRECT RESULTS
6389                                     ;*IN ORDER TO DO THIS TEST, WE WILL READ THE DATA FROM THE
6390                                     ;*CONSOL TTY CSR IF ONE EXSITS
6391                                     ;*IF NO CONSOL TTY CSR AT ADDRESS 177560, THIS TEST
6392                                     ;*WILL BE SKIPPED
6393 023272                      BADHEAD
(2)                                     ;***** TEST 40 *****
6394
6395 023272                      BGNTST
(3) 023272                      T40::
6396 023272                      MYINT
(1) 023272 013701 002716      MOV      KMCSR,R1 ;GET DEVICE ADDRESS.
6397 023276                      MSTCLR ;MASTER CLEAR M8200,4,7
(1) 023276 004537 003156      JSR      R5,MSTCLR ;CLEAR M8200,4,7
6398 023302 012737 023464 000004 STOP: MOV      #TOUTT,4 ;SET UP FOR TRAP IN CASE IF NO
6399 023310 012737 000340 000006      MOV      #340,6 ;TTY AT ADDRESS 177560
6400 023316 005737 177560                      TST      177560 ;ADDRESS THE TTY-TRAPS HERE IF NONE.
6401 023322 012737 177560 023350      MOV      #177560,1$ ;USE SEL4 FOR ADDRESS
```

```
6402 023330 012737 177560 023346      MOV    #177560,2$      :USE SEL4 FOR ADDRESS
6403 023336 004537 003574                JSR    R5,NPRSET      :LOAD BA AND DATA
6404 023342 000000                        0                :IN DATA
6405 023344 125252                        125252           :OUT DATA
6406 023346 000000                2$: 0                :IN BA
6407 023350 000000                1$: 0                :OUT BA
6408 023352 012761 000015 000004      MOV    #15,4(R1)
6409 023360 012711 003000                MOV    #BIT9:BIT10,(R1):SET CROMI AND CROMO!!
6410 023364 012761 121110 000006      MOV    #121110,6(R1) :PUT INSTR INTO SEL6 NW*
6411 023372 052711 000400                BIS    #BIT8,(R1)    :CLOCK IT!
6412 023376 000240                NOP                :WAIT FOR NPR
6413 023400                ROMCLK            :NEXT WORD IS INSTRUCTION, BBN
(1) 023400 004537 003244                JSR    R5,.ROMCLK   :CLOCK INSTRUCTION
6414 023404 021004                021004           :MOVE OUT DATA LB TO SEL4
6415 023406                ROMCLK            :NEXT WORD IS INSTRUCTION, BBN
(1) 023406 004537 003244                JSR    R5,.ROMCLK   :CLOCK INSTRUCTION
6416 023412 021025                021025           :MOVE OUT DATA HB TO SEL5
6417 023414 016104 000004                MOV    4(R1),R4     :PUT 'FOUND' IN R4
6418 023420 013737 177560 002636      MOV    177560,$GDDAT
6419 023426 042737 000200 002636      BIC    #200,$GDDAT
6420 023434 023704 002636                CMP    $GDDAT,R4   :CORRECT RESULTS?
6421 023440 001413                BEQ    TOUTP        :BR IF YES
6422 023442                ERROR 11,YES      :ERROR BA 16 AND 17 FAILED
(5) 023454 104455                TRAP  C$ERDF
(6) 023456 000013                .WORD 11
(6) 023460 004654                .WORD EM11
(6) 023462 006660                .WORD ERR11
6423 023464                3$:
6424 023464 062706 000004                TOUTT: ADD #4,SP    :UPDATE STACK POITNTER
6425 023470 013737 002652 000006      TOUTP: MOV SAVE6,6  :RESTORE TRAP VECTOR
6426 023476 013737 002650 000004      MOV    SAVE4,4
6427 023504                ENDTST
(3) 023504                L10122:
(3) 023504 104401                TRAP  C$ETST
6428
6429 023506                BADHEAD
(2)                :***** TEST 41 *****
```

```
6431 ;*NPR NON-EXISTENT MEMORY TEST
6432 ;*DO A DATO TO A NON-EXISTENT ADDRESS
6433 ;*VERIFY THAT THE NON-EXISTENT BIT SET IN IBUS REG 11
6434 023506 BADHEAD
(2) ;***** TEST 41 *****
6435
6436 023506 BGNTST
(3) 023506 T41::
6437 023506 MYINT
(1) 023506 013701 002716 MOV KMCSR,R1 ;GET DEVICE ADDRESS.
6438 023512 MSTCLR ;MASTER CLEAR M8200.4,7
(1) 023512 004537 003156 JSR R5,,MSTCLR ;CLEAR M8200.4,7
6439 023516 004537 003574 JSR R5,NPRSET ;LOAD IBUS REGISTERS 0-7
6440 023522 000000 0 ;IN DATA
6441 023524 000000 0 ;OUT DATA
6442 023526 177320 0 ;IN BA
6443 023530 177320 0 ;IN BA
6444 023532 012761 000014 000004 MOV #14,4(R1) ;SET OUT BA BITS 16+17 IN PORT4
```





6483	023734	004537	003574		JSR	R5,NPRSET	:LOAD IBUS REGISTERS 0-7
6484	023740	000000			0		:IN DATA
6485	023742	000000			0		:OUT DATA
6486	023744	177320			177320		:IN BA
6487	023746	177320			177320		:OUT BA
6488	023750	005061	000004		CLR	4(R1)	
6489	023754				ROMCLK		:NEXT WORD IS INSTRUCTION, BBN
(1)	023754	004537	003244		JSR	R5,.ROMCLK	:CLOCK INSTRUCTION
6490	023760	121111			121111		:CLEAR NON-EXISTENT BIT
6491	023762	012761	000015	000004	MOV	#15,4(R1)	:SET NPR REQUEST BITS IN PORT4
6492	023770				ROMCLK		:NEXT WORD IS INSTRUCTION, BBN
(1)	023770	004537	003244		JSR	R5,.ROMCLK	:CLOCK INSTRUCTION
6493	023774	121110			121110		:MOV IBUS* 4 TO IBUS* 10
6494	023776	000240			NOP		
6495	024000				ROMCLK		:NEXT WORD IS INSTRUCTION, BBN
(1)	024000	004537	003244		JSR	R5,.ROMCLK	:CLOCK INSTRUCTION
6496	024004	121225			121225		:MOV IBUS*11 TO IBUS*5
6497	024006	012737	000001	002636	MOV	#1,\$GDDAT	:PUT 'EXPECTED' IN \$GDDAT
6498	024014	116104	000005		MOVB	5(R1),R4	:PUT 'FOUND' IN R4
6499	024020	042704	177776		BIC	#177776,R4	:CLEAR UNWANTED BITS
6500	024024	023704	002636		CMP	\$GDDAT,R4	:DATA CORRECT?
6501	024030	001411			BEQ	1\$	:BR IF YES
6502	024032				ERROR	13,YES	:ERROR NON-EXISTENT MEM BIT FAILED TO SET
(5)	024044	104455			TRAP	C\$ERDF	
(6)	024046	000015			.WORD	13	
(6)	024050	004707			.WORD	EM13	
(6)	024052	007014			.WORD	ERR13	
6503	024054						
6504	024054			1\$: ENDTST L10124:			
(3)	024054						
(3)	024054	104401			TRAP	C\$ETST	
6505							
6506	024056				BADHEAD		
(2)					:***** TEST 43 *****		
6507					:*NPR TEST		
6508					:*USING DATO, NPR A BINARY COUNT (0-377)		
6509					:*FROM MICRO-PROCESSOR TO ALL AVAILABLE MEMORY		
6510	024056				BADHEAD		
(2)					:***** TEST 43 *****		
6511							
6512	024056			BGNTST T43::			
(3)	024056						
6513	024056				MYINT		
(1)	024056	013701	002716		MOV	KMCSR,R1	:GET DEVICE ADDRESS.
6514	024062				MSTCLR		:MASTER CLEAR M8200,4,7
(1)	024062	004537	003156		JSR	R5,.MSTCLR	:CLEAR M8200,4,7
6515	024066	005037	024270		CLR	5\$	:START FLAG AT 0
6516	024072	005005			CLR	R5	:DATA
6517	024074	012702	035404		MOV	#CORMAX,R2	:ADDRESS
6518	024100			1\$:			
6519	024100	010537	024130		MOV	R5,2\$	:LOAD DATA
6520	024104	010237	024134		MOV	R2,4\$	:LOAD BA
6521	024110	032702	000001		BIT	#BIT0,R2	:IS BA ODD?
6522	024114	001402			BEQ	.+6	:BR IF NO
6523	024116	000337	024130		SWAB	2\$	:IF ODD PUT DATA IN HI-BYTE
6524	024122	004537	003574		JSR	R5,NPRSET	:LOAD NPR REGISTERS

```
6525 024126 000000          0          ;IN DATA
6526 024130 000000      2$: 0          ;OUT DATA
6527 024132 000000          0          ;IN BA
6528 024134 000000      4$: 0          ;OUT BA
6529 024136 105012          CLRB      (R2)      ;CLEAR MEMORY LOCATION
6530 024140 012761 000221 000004 MOV      #221,4(R1) ;LOAD PORT4
6531 024146          ROMCLK          ;NEXT WORD IS INSTRUCTION, BBN
(1) 024146 004537 003244 JSR      R5,ROMCLK ;CLOCK INSTRUCTION
6532 024152 121110          121110          ;DO THE NPR
6533 024154 000240          NOP
6534 024156 010537 002636 MOV      R5,$GDDAT ;PUT 'EXPECTED' IN $GDDAT
6535 024162 111204          MOVB     (R2),R4 ;PUT 'FOUND' IN R4
6536 024164 123704 002636 CMPB     $GDDAT,R4 ;IS DATA CORRECT?
6537 024170 001411          BEQ      3$          ;BR IF YES
6538 024172          ERROR          11,YES ;ERROR, DATA INCORRECT
(5) 024204 104455          TRAP     C$ERDF
(6) 024206 000013          .WORD   11
(6) 024210 004654          .WORD   EM11
(6) 024212 006660          .WORD   ERR11
6539 024214          3$: ESCAPE TST
(3) 024214 104410          TRAP     C$ESCAPE
(3) 024216 000054          .WORD   L10125-.
6540 024220 005205          INC      R5          ;NEXT CHARACTER
6541 024222 042705 177400 BIC      #177400,R5 ;USE ONLY LOW BYTE
6542 024226 005737 024270 TST      5$          ;HAS MAX MEMORY BEEN REACHED YET?
6543 024232 001402          BEQ      6$          ;BR IF NO
6544 024234 005705          TST      R5          ;DONE PATTERN?
6545 024236 001412          BEQ      7$          ;BR IF YES
6546 024240          6$: INC      R2          ;INC BA
6547 024242 023702 002604 CMP      MEMLIM,R2 ;REACHED MEMORY LIMIT YET?
6548 024246 001314          BNE      1$          ;BR IF NOT
6549 024250 012702 035404 MOV      #CORMAX,R2 ;RESTART BA AT FIRST ADDRESS
6550 024254 012737 177777 024270 MOV      #-1,5$      ;SET FLAG TO END TEST AT END OF DATA PATTERN
6551 024262 000706          BR      1$          ;CONTINUE
6552 024264          7$: EXIT      TST
6553 024264          TRAP     C$EXIT
(3) 024264 104432          .WORD   L10125-.
(3) 024266 000004          5$: 0          ;THIS LOCATION IS A FLAG, IT STARTS AT 0,
6554 024270 000000          ;AND IS SET TO -1 WHEN LAST MEMORY ADDRESS
6555          ;IS USED, TEST IS THEN ENDED WHEN PATTERN IS FINISHED
6556
6557 024272          ENDTST
(3) 024272          L10125:
(3) 024272 104401          TRAP     C$ETST
6558          ;$MEM1
6559          ;$MEM0
6560          ;$MEM2 1K
6561          ;$MEM3 1K
6562
6563 024274          BADHEAD
(2)          ;***** TEST 44 *****
6564          ;*ALU C BIT TEST
6565          ;*TEST THAT AN ADD OF 377 AND 377 WILL SET THE C BIT
6566 024274          BADHEAD
(2)          ;***** TEST 44 *****
6567
```

```
6568 024274          BGNTST
(3) 024274          T44::
6569 024274          MYINT
(1) 024274 013701 002716  MOV      KMCSR,R1      ;GET DEVICE ADDRESS.
6570 024300          MSTCLR      ;MASTER CLEAR M8200,4,7
(1) 024300 004537 003156  JSR      R5,.,MSTCLR   ;CLEAR M8200,4,7
6571 024304 004737 003640  JSR      PC,MEMLD     ;LOAD MAINMEM DATA
6572 024310 024424          TDATA      ;POINTER TO DATA
6573 024312 004737 004012  JSR      PC,SPLD     ;LOAD SP DATA
6574 024316 024424          TDATA      ;POINTER TO DATA
6575 024320          BGNSEG
(3) 024320 104404          TRAP      C$BSEG
6576 024322          1$:
6577 024322          ROMCLK      ;NEXT WORD IS INSTRUCTION, BBN
(1) 024322 004537 003244  JSR      R5,.,ROMCLK   ;CLOCK INSTRUCTION
6578 024326 010000          010000      ;MAR 0
6579 024330          ROMCLK      ;NEXT WORD IS INSTRUCTION, BBN
(1) 024330 004537 003244  JSR      R5,.,ROMCLK   ;CLOCK INSTRUCTION
6580 024334 054400          054400!<0*20> ;ADD 377 AND 377, TO SET C BIT
6581 024336          ROMCLK      ;NEXT WORD IS INSTRUCTION, BBN
(1) 024336 004537 003244  JSR      R5,.,ROMCLK   ;CLOCK INSTRUCTION
6582 024342 040421          040401!<1*20> ;ADD 0 AND 0 AND THE C BIT
6583 024344          ROMCLK      ;NEXT WORD IS INSTRUCTION, BBN
(1) 024344 004537 003244  JSR      R5,.,ROMCLK   ;CLOCK INSTRUCTION
6584 024350 061224          61224      ;PUT RESULTS IN PORT4
6585 024352 012737 000001 002636  MOV      #1,$GDDAT    ;PUT 'EXPECTED' IN $GDDAT
6586 024360 016104 000004          MOV      4(R1),R4     ;PUT 'FOUND' IN R4
6587 024364 123704 002636          CMPB     $GDDAT,R4    ;DATA CORRECT?
6588 024370 001411          BEQ      2$          ;BR IF YES
6589 024372          ERROR      34,YES ;ERROR C BIT NOT SET
(5) 024404 104455          TRAP      C$ERDF
(6) 024406 000042          .WORD    34
(6) 024410 005435          .WORD    EM34
(6) 024412 010276          .WORD    ERR34
6590 024414          ESCAPE      SEG
(3) 024414 104410          TRAP      C$ESCAPE
(3) 024416 000002          .WORD    10000$-.
6591 024420          10000$:
(3) 024420 104405          TRAP      C$ESEG
6592 024422          ENDTST
(3) 024422          L10126:
(3) 024422 104401          TRAP      C$ETST
6593 024424          TDATA: .BYTE  -1,0,0,0,0,0,0,0
      024427          000      000      000
      024432          000      000
6594
6595          .EVEN
6596
6597 024434          BADHEAD
(2)          ;***** TEST 45 *****
6598          ;*ALU TEST
6599          ;*TEST OF ALU FUNCTION SEL B WITH C BIT CLEARED
6600          ;*ALU FUNCTION (B) CODE=11
6601          ;*LOAD MAIN MEM AND SP WITH 8 WORDS OF DATA
6602          ;*PERFORM THE FUNCTION, VERIFY THE RESULTS
```

```
6603 024434          BADHEAD
(2)
6604
6605 024434          BGNTST
(3) 024434          T45::
6606 024434          MYINT
(1) 024434 013701 002716 MOV KMCSR,R1 ;GET DEVICE ADDRESS.
6607 024440          MSTCLR ;MASTER CLEAR M8200,4,7
(1) 024440 004537 003156 JSR R5,.MSTCLR ;CLEAR M8200,4,7
6608 024444          CLR R5 ;MEM + SP ADDRESS
6609 024446 012702 024626 MOV #5$,R2 ;POINTER TO CORRECT DATA
6610 024452 004737 003640 JSR PC,MEMLD ;LOAD 8 WORDS OF MAIN MEMORY
6611 024456 002654 MEMDAT ;POINTER TO DATA
6612 024460 004737 004012 JSR PC,SPLD ;LOAD 8 WORDS OF SP
6613 024464 002664 SPDAT ;POINTER TO DATA
6614 024466          BGNSEG
(3) 024466 104404 TRAP C$BSEG
6615 024470 004737 004060 1$: JSR PC,CLRC ;CLEAR C BIT!
6616 024474 042737 000017 024512 BIC #17,2$ ;CLEAR ADDRESS FIELD OF INSTRUCTION
6617 024502 050537 024512 BIS R5,2$ ;ADD ADDRESS TO INSTRUCTION
6618 024506          ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
(1) 024506 004537 003244 JSR R5,.ROMCLK ;CLOCK INSTRUCTION
6619 024512 010000 2$: 010000 ;LOAD MAR
6620 024514 042737 000017 024532 BIC #17,3$ ;CLEAR ADDRESS OF INSTRUCTION
6621 024522 050537 024532 BIS R5,3$ ;ADD ADDRESS TO INSTRUCTION
6622 024526          ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
(1) 024526 004537 003244 JSR R5,.ROMCLK ;CLOCK INSTRUCTION
6623 024532 040620 3$: 040400!<11*20> ;BR SEL B
6624 024534          ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
(1) 024534 004537 003244 JSR R5,.ROMCLK ;CLOCK INSTRUCTION
6625 024540 061224 61224 ;MOVE BR TO PORT4
6626 024542 111237 002636 MOVB (R2), $GDDAT ;PUT 'EXPECTED' IN $GDDAT
6627 024546 116104 000004 MOVB 4(R1), R4 ;PUT 'FOUND' IN R4
6628 024552 123704 002636 CMPB $GDDAT, R4 ;DATA CORRECT?
6629 024556 001411 BEQ 4$ ;BR IF YES
6630 024560          ERROR 15, YES ;ALU ERROR
(5) 024572 104455 TRAP C$ERDF
(6) 024574 000017 .WORD 15
(6) 024576 004754 .WORD EM15
(6) 024600 007120 .WORD ERR15
6631 024602          4$: ESCAPE SEG
(3) 024602 104410 TRAP C$ESCAPE
(3) 024604 000014 .WORD 10000$-.
6632 024606 005202 INC R2 ;NEXT DATA
6633 024610 005205 INC R5 ;NEXT ADDRESS
6634 024612 022705 000010 CMP #10, R5 ;DONE YET?
6635 024616 001324 BNE 1$ ;BR IF NO
6636 024620          10000$: ENDSEG
(3) 024620 TRAP C$ESEG
(3) 024620 104405 EXIT TST
6637 024622          3$: TRAP C$EXIT
(3) 024622 104432 .WORD L10127-.
(3) 024624 000012 .BYTE 0,-1,0,-1,125,252,125,252
6638 024626 000 377 000 5$:
024631 377 125 252
024634 125 252
```

6639  
6640  
6641 024636  
(3) 024636  
(3) 024636 104401  
6642  
6643 024640  
(2)  
6644  
6645  
6646  
6647  
6648  
6649 024640  
(2)  
6650  
6651 024640  
(3) 024640  
6652 024640  
(1) 024640 013701 002716  
6653 024644  
(1) 024644 004537 003156  
6654 024650 005005  
6655 024652 012702 025032  
6656 024656 004737 003640  
6657 024662 002654  
6658 024664 004737 004012  
6659 024670 002664  
6660 024672  
(3) 024672 104404  
6661 024674 004737 004060  
6662 024700 042737 000017 024716  
6663 024706 050537 024716  
6664 024712  
(1) 024712 004537 003244  
6665 024716 010000  
6666 024720 042737 000017 024736  
6667 024726 050537 024736  
6668 024732  
(1) 024732 004537 003244  
6669 024736 040600  
6670 024740  
(1) 024740 004537 003244  
6671 024744 061224  
6672 024746 111237 002636  
6673 024752 116104 000004  
6674 024756 123704 002636  
6675 024762 001411  
6676 024764  
(5) 024776 104455  
(6) 025000 000017  
(6) 025002 004754  
(6) 025004 007120  
6677 025006  
(3) 025006 104410  
(3) 025010 000014

.EVEN  
ENDTST  
L10127:

TRAP C\$ETST

BADHEAD

:\*\*\*\*\* TEST 46 \*\*\*\*\*

:\*ALU TEST  
:\*TEST OF ALU FUNCTION SEL A WITH C BIT CLEARED  
:\*ALU FUNCTION (A) CODE=10  
:\*LOAD MAIN MEM AND SP WITH 8 WORDS OF DATA  
:\*PERFORM THE FUNCTION, VERIFY THE RESULTS

BADHEAD

:\*\*\*\*\* TEST 46 \*\*\*\*\*

BGNTST  
T46::

MYINT

MOV KMCSR,R1

:GET DEVICE ADDRESS.

MSTCLR

:MASTER CLEAR M8200,4,7

JSR R5,.,MSTCLR

:CLEAR M8200,4,7

CLR R5

:MEM + SP ADDRESS

MOV #5\$,R2

:POINTER TO CORRECT DATA

JSR PC,MEMLD

:LOAD 8 WORDS OF MAIN MEMORY

MEMDAT

:POINTER TO DATA

JSR PC,SPLD

:LOAD 8 WORDS OF SP

SPDAT

:POINTER TO DATA

BGNSEG

TRAP C\$BSEG

JSR PC,CLRC

:CLEAR C BIT!

BIC #17,2\$

:CLEAR ADDRESS FIELD OF INSTRUCTION

BIS R5,2\$

:ADD ADDRESS TO INSTRUCTION

ROMCLK

:NEXT WORD IS INSTRUCTION, ROMCLK PC=5304

JSR R5,.,ROMCLK

:CLOCK INSTRUCTION

010000

:LOAD MAR

BIC #17,3\$

:CLEAR ADDRESS OF INSTRUCTION

BIS R5,3\$

:ADD ADDRESS TO INSTRUCTION

ROMCLK

:NEXT WORD IS INSTRUCTION, ROMCLK PC=5304

JSR R5,.,ROMCLK

:CLOCK INSTRUCTION

040400!<10\*20>

:BR SEL A

ROMCLK

:NEXT WORD IS INSTRUCTION, ROMCLK PC=5304

JSR R5,.,ROMCLK

:CLOCK INSTRUCTION

61224

:MOVE ER TO PORT4

MOVB (R2), \$GDDAT

:PUT 'EXPECTED' IN \$GDDAT

MOVB 4(R1), R4

:PUT 'FOUND' IN R4

CMPB \$GDDAT, R4

:DATA CORRECT?

BEQ 4\$

:BR IF YES

ERROR 15, YES

:ALU ERROR

TRAP C\$ERDF

.WORD 15

.WORD EM15

.WORD ERR15

4\$:

ESCAPE SEG

TRAP C\$ESCAPE

.WORD 10000\$-

6678	025012	005202				INC	R2	:NEXT DATA
6679	025014	005205				INC	R5	:NEXT DATA
6680	025016	022705	000010			CMP	#10,R5	:DONE YET?
6681	025022	001324				BNE	1\$	:BR IF NO
6682	025024					ENDSEG		
(3)	025024			10000\$:				
(3)	025024	104405				TRAP	C\$ESEG	
6683	025026					EXIT	TST	
(3)	025026	104432				TRAP	C\$EXIT	
(3)	025030	000012				.WORD	L10130-	
6684	025032	000	000	377	5\$:	.BYTE	0,0,-1,-1,125,125,252,252	
	025035	377	125	125				
	025040	252	252					
6685								
6686						.EVEN		
6687	025042					ENDTST		
(3)	025042					L10130:		
(3)	025042	104401				TRAP	C\$ETST	
6688								
6689	025044					BADHEAD		
(2)						:*****	TEST 47	*****
6690						:*ALU TEST		
6691						:*TEST OF ALU FUNCTION A OR NOTB WITH C BIT CLEARED		
6692						:*ALU FUNCTION (A OR NOTB) CODE=12		
6693						:*LOAD MAIN MEM AND SP WITH 8 WORDS OF DATA		
6694						:*PERFORM THE FUNCTION, VERIFY THE RESULTS		
6695	025044					BADHEAD		
(2)						:*****	TEST 47	*****
6696								
6697	025044					BGNTST		
(3)	025044					T47::		
6698	025044					MYINT		
(1)	025044	013701	002716			MOV	KMCSR,R1	:GET DEVICE ADDRESS.
6699	025050					MSTCLR		:MASTER CLEAR M8200,4,7
(1)	025050	004537	003156			JSR	R5,.MSTCLR	:CLEAR M8200,4,7
6700	025054	005005				CLR	R5	:MEM + SP ADDRESS
6701	025056	012702	025236			MOV	#5\$,R2	:POINTER TO CORRECT DATA
6702	025062	004737	003640			JSR	PC,MEMLD	:LOAD 8 WORDS OF MAIN MEMORY
6703	025066	002654				MEMDAT		:POINTER TO DATA
6704	025070	004737	004012			JSR	PC,SPLD	:LOAD 8 WORDS OF SP
6705	025074	002664				SPDAT		:POINTER TO DATA
6706	025076					BGNSEG		
(3)	025076	104404				TRAP	C\$BSEG	
6707	025100	004737	004060			JSR	PC,CLRC	:CLEAR C BIT!
6708	025104	042737	000017	025122	1\$:	BIC	#17,2\$	:CLEAR ADDRESS FIELD OF INSTRUCTION
6709	025112	050537	025122			BIS	R5,2\$	:ADD ADDRESS TO INSTRUCTION
6710	025116					ROMCLK		:NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
(1)	025116	004537	003244			JSR	R5,.ROMCLK	:CLOCK INSTRUCTION
6711	025122	010000				010000		:LOAD MAR
6712	025124	042737	000017	025142	2\$:	BIC	#17,3\$	:CLEAR ADDRESS OF INSTRUCTION
6713	025132	050537	025142			BIS	R5,3\$	:ADD ADDRESS TO INSTRUCTION
6714	025136					ROMCLK		:NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
(1)	025136	004537	003244			JSR	R5,.ROMCLK	:CLOCK INSTRUCTION
6715	025142	040640			3\$:	040400!	<12*20>	:BR A OR NOTB
6716	025144					ROMCLK		:NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
(1)	025144	004537	003244			JSR	R5,.ROMCLK	:CLOCK INSTRUCTION

```
6717 025150 061224          61224          :MOVE BR TO PORT4
6718 025152 111237 002636    MOVB      (R2), $GDDAT      :PUT 'EXPECTED' IN $GDDAT
6719 025156 116104 000004    MOVB      4(R1), R4        :PUT 'FOUND' IN R4
6720 025162 123704 002636    CMPB      $GDDAT, R4       :DATA CORRECT?
6721 025166 001411          BEQ       4$                :BR IF YES
6722 025170          ERROR    15, YES          :ALU ERROR
      (5) 025202 104455          TRAP     C$ERDF
      (6) 025204 000017          .WORD   15
      (6) 025206 004754          .WORD   EM15
      (6) 025210 007120          .WORD   ERR15
6723 025212          4$:  ESCAPE  SEG
      (3) 025212 104410          TRAP     C$ESCAPE
      (3) 025214 000014          .WORD   10000$-.
6724 025216 005202          INC      R2                :NEXT DATA
6725 025220 005205          INC      R5                :NEXT DATA
6726 025222 022705 000010    CMP      #10, R5          :DONE YET?
6727 025226 001324          BNE     1$                :BR IF NO
6728 025230          ENDSEG
      (3) 025230          10000$:
      (3) 025230 104405          TRAP     C$ESEG
6729 025232          EXIT  TST
      (3) 025232 104432          TRAP     C$EXIT
      (3) 025234 000012          .WORD   L10131-.
6730 025236 377 000 377 377 5$: .BYTE  -1, 0, -1, -1, -1, 125, 252, -1
      025241 377 377 125
      025244 252 377

6731
6732          .EVEN
6733 025246          ENDTST
      (3) 025246          L10131:
      (3) 025246 104401          TRAP     C$ETST
6734
6735 025250          BADHEAD
      (2)          :***** TEST 48 *****
6736          :*ALU TEST
6737          :*TEST OF ALU FUNCTION A AND B WITH C BIT CLEARED
6738          :*ALU FUNCTION (A AND B) CODE=13
6739          :*LOAD MAIN MEM AND SP WITH 8 WORDS OF DATA
6740          :*PERFORM THE FUNCTION, VERIFY THE RESULTS
6741 025250          BADHEAD
      (2)          :***** TEST 48 *****
6742
6743 025250          BGNTST
      (3) 025250          T48::
6744 025250          MYINT
      (1) 025250 013701 002716    MOV      KMCSR, R1        :GET DEVICE ADDRESS.
6745 025254          MSTCLR      :MASTER CLEAR M8200, 4, 7
      (1) 025254 004537 003156    JSR     R5, .MSTCLR      :CLEAR M8200, 4, 7
6746 025260 005005          CLR     R5                :MEM + SP ADDRESS
6747 025262 012702 025442    MOV     #5$, R2          :POINTER TO CORRECT DATA
6748 025266 004737 003640    JSR     PC, MEMLD        :LOAD 8 WORDS OF MAIN MEMORY
6749 025272 002654          MEMDAT      :POINTER TO DATA
6750 025274 004737 004012    JSR     PC, SPLD        :LOAD 8 WORDS OF SP
6751 025300 002664          SPDAT      :POINTER TO DATA
6752 025302          BGNSEG
      (3) 025302 104404          TRAP     C$BSEG
```



```

6753 025304 004737 004060 1$: JSR PC,CLRC ;CLEAR C BIT!
6754 025310 042737 000017 025326 BIC #17,2$ ;CLEAR ADDRESS FIELD OF INSTRUCTION
6755 025316 050537 025326 BIS R5,2$ ;ADD ADDRESS TO INSTRUCTION
6756 025322 ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
(1) 025322 004537 003244 JSR R5,.ROMCLK ;CLOCK INSTRUCTION
6757 025326 010000 2$: 010000 ;LOAD MAR
6758 025330 042737 000017 025346 BIC #17,3$ ;CLEAR ADDRESS OF INSTRUCTION
6759 025336 050537 025346 BIS R5,3$ ;ADD ADDRESS TO INSTRUCTION
6760 025342 ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
(1) 025342 004537 003244 JSR R5,.ROMCLK ;CLOCK INSTRUCTION
6761 025346 040660 3$: 040400!<13*20> ;BR A AND B
6762 025350 ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
(1) 025350 004537 003244 JSR R5,.ROMCLK ;CLOCK INSTRUCTION
6763 025354 061224 61224 ;MOVE BR TO PORT4
6764 025356 111237 002636 MOVB (R2), $GDDAT ;PUT 'EXPECTED' IN $GDDAT
6765 025362 116104 000004 MOVB 4(R1), R4 ;PUT 'FOUND' IN R4
6766 025366 123704 002636 CMPB $GDDAT, R4 ;DATA CORRECT?
6767 025372 001411 BEQ 4$ ;BR IF YES
6768 025374 ERROR 15, YES ;ALU ERROR
(5) 025406 104455 TRAP C$ERDF
(6) 025410 000017 .WORD 15
(6) 025412 004754 .WORD EM15
(6) 025414 007120 .WORD ERR15
6769 025416 4$: ESCAPE SEG
(3) 025416 104410 TRAP C$ESCAPE
(3) 025420 000014 .WORD 10000$-.
6770 025422 005202 INC R2 ;NEXT DATA
6771 025424 005205 INC R5 ;NEXT DATA
6772 025426 022705 000010 CMP #10, R5 ;DONE YET?
6773 025432 001324 BNE 1$ ;BR IF NO
6774 025434 ENDSEG
(3) 025434 10000$: TRAP C$ESEG
(3) 025434 104405 EXIT TST
6775 025436 104432 TRAP C$EXIT
(3) 025440 000012 .WORD L10132-.
6776 025442 000 000 000 5$: .BYTE 0,0,0,-1,125,0,0,252
025445 377 125 000
025450 000 252

6777
6778 .EVEN
6779 025452 ENDTST
(3) 025452 L10132: TRAP C$ETST
(3) 025452 104401

6780
6781 025454 BADHEAD
(2) ;***** TEST 49 *****
6782 ;*ALU TEST
6783 ;*TEST OF ALU FUNCTION A OR B WITH C BIT CLEARED
6784 ;*ALU FUNCTION (A OR B) CODE=14
6785 ;*LOAD MAIN MEM AND SP WITH 8 WORDS OF DATA
6786 ;*PERFORM THE FUNCTION, VERIFY THE RESULTS
6787 025454 BADHEAD
(2) ;***** TEST 49 *****
6788
6789 025454 BGNTST

```

```

(3) 025454          T49::
6790 025454          MYINT
(1) 025454 013701 002716  MOV      KMCSR,R1      ;GET DEVICE ADDRESS.
6791 025460          MSTCLR      ;MASTER CLEAR M8200,4,7
(1) 025460 004537 003156  JSR      R5, .MSTCLR   ;CLEAR M8200,4,7
6792 025464 005005          CLR      R5            ;MEM + SP ADDRESS
6793 025466 012702 025646  MOV      #5$,R2        ;POINTER TO CORRECT DATA
6794 025472 004737 003640  JSR      PC, MEMLD     ;LOAD 8 WORDS OF MAIN MEMORY
6795 025476 002654          MEMDAT          ;POINTER TO DATA
6796 025500 004737 004012  JSR      PC, SPLD     ;LOAD 8 WORDS OF SP
6797 025504 002664          SPDAT          ;POINTER TO DATA
6798 025506          BGNSEG
(3) 025506 104404          TRAP      C$BSEG
6799 025510 004737 004060  JSR      PC, CLRC     ;CLEAR C BIT!
6800 025514 042737 000017 255532 BIC      #17, 2$      ;CLEAR ADDRESS FIELD OF INSTRUCTION
6801 025522 050537 025532  BIS      R5, 2$      ;ADD ADDRESS TO INSTRUCTION
6802 025526          ROMCLK          ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
(1) 025526 004537 003244  JSR      R5, .ROMCLK  ;CLOCK INSTRUCTION
6803 025532 010000          010000          ;LOAD MAR
6804 025534 042737 000017 255552 BIC      #17, 3$      ;CLEAR ADDRESS OF INSTRUCTION
6805 025542 050537 025552  BIS      R5, 3$      ;ADD ADDRESS TO INSTRUCTION
6806 025546          ROMCLK          ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
(1) 025546 004537 003244  JSR      R5, .ROMCLK  ;CLOCK INSTRUCTION
6807 025552 040700          3$: 040400! <14*20> ;BR A OR B
6808 025554          ROMCLK          ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
(1) 025554 004537 003244  JSR      R5, .ROMCLK  ;CLOCK INSTRUCTION
6809 025560 061224          61224          ;MOVE BR TO PORT4
6810 025562 111237 002636  MOVB    (R2), $GDDAT  ;PUT 'EXPECTED' IN $GDDAT
6811 025566 116104 000004          MOVB    4(R1), R4     ;PUT 'FOUND' IN R4
6812 025572 123704 002636  CMPB    $GDDAT, R4   ;DATA CORRECT?
6813 025576 001411          BEQ     4$           ;BR IF YES
6814 025600          ERROR    15, YES ;ALU ERROR
(5) 025612 104455          TRAP    C$ERDF
(6) 025614 000017          .WORD  15
(6) 025616 004754          .WORD  EM15
(6) 025620 007120          .WORD  ERR15
6815 025622          4$: ESCAPE  SEG
(3) 025622 104410          TRAP    C$ESCAPE
(3) 025624 000014          .WORD  10000$-
6816 025626 005202          INC     R2           ;NEXT DATA
6817 025630 005205          INC     R5           ;NEXT DATA
6818 025632 022705 000010  CMP     #10, R5      ;DONE YET?
6819 025636 001324          BNE    1$           ;BR IF NO
6820 025640          ENDSEG
(3) 025640          10000$:
(3) 025640 104405          TRAP    C$ESEG
6821 025642          EXIT    TST
(3) 025642 104432          TRAP    C$EXIT
(3) 025644 000012          .WORD  L10133-
6822 025646 000 377 377 5$: .BYTE  0, -1, -1, -1, 125, -1, -1, 252
    025651 377 125 377
    025654 377 252

6823
6824          .EVEN
6825 025656          ENDTST
(3) 025656          L10133:
  
```

```

(3) 025656 104401
6826
6827 025650
(2)
6828
6829
6830
6831
6832
6833 025660
(2)
6834
6835 025660
(3) 025660
6836 025660
(1) 025660 013701 002716
6837 025664
(1) 025664 004537 003156
6838 025670 005005
6839 025672 012702 026052
6840 025676 004737 003640
6841 025702 002654
6842 025704 004737 004012
6843 025710 002664
6844 025712
(3) 025712 104404
6845 025714 004737 004060
6846 025720 042737 000017 025736
6847 025726 050537 025736
6848 025732
(1) 025732 004537 003244
6849 025736 010000
6850 025740 042737 000017 025756
6851 025746 050537 025756
6852 025752
(1) 025752 004537 003244
6853 025756 040720
6854 025760
(1) 025760 004537 003244
6855 025764 061224
6856 025766 111237 002636
6857 025772 116104 000004
6858 025776 123704 002636
6859 026002 001411
6860 026004
(5) 026016 104455
(6) 026020 000017
(6) 026022 004754
(6) 026024 007120
6861 026026
(3) 026026 104410
(3) 026030 000014
6862 026032 005202
6863 026034 005205
6864 026036 022705 000010
6865 026042 001324

```

```

TRAP C$ETST
BADHEAD
:***** TEST 50 *****
:*ALU TEST
:*TEST OF ALU FUNCTION A XOR B WITH C BIT CLEARED
:*ALU FUNCTION (A XOR B) CODE=15
:*LOAD MAIN MEM AND SP WITH 8 WORDS OF DATA
:*PERFORM THE FUNCTION, VERIFY THE RESULTS
BADHEAD
:***** TEST 50 *****

BGNTST
T50::
MYINT
MOV KMCSR,R1 ;GET DEVICE ADDRESS.
MSTCLR ;MASTER CLEAR M8200,4,7
JSR R5,.MSTCLR ;CLEAR M8200,4,7
CLR R5 ;MEM + SP ADDRESS
MOV #5$,R2 ;POINTER TO CORRECT DATA
JSR PC,MEMLD ;LOAD 8 WORDS OF MAIN MEMORY
MEMDAT ;POINTER TO DATA
JSR PC,SPLD ;LOAD 8 WORDS OF SP
SPDAT ;POINTER TO DATA
BGNSEG
TRAP C$BSEG
JSR PC,CLRC ;CLEAR C BIT!
BIC #17,2$ ;CLEAR ADDRESS FIELD OF INSTRUCTION
BIS R5,2$ ;ADD ADDRESS TO INSTRUCTION
ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
JSR R5,.ROMCLK ;CLOCK INSTRUCTION
1$:
010000 ;LOAD MAR
BIC #17,3$ ;CLEAR ADDRESS OF INSTRUCTION
BIS R5,3$ ;ADD ADDRESS TO INSTRUCTION
ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
JSR R5,.ROMCLK ;CLOCK INSTRUCTION
3$:
040400!<15*20> ;BR A XOR B
ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
JSR R5,.ROMCLK ;CLOCK INSTRUCTION
61224 ;MOVE BR TO PORT4
MOVB (R2), $GDDAT ;PUT 'EXPECTED' IN $GDDAT
MOVB 4(R1), R4 ;PUT 'FOUND' IN R4
CMPB $GDDAT, R4 ;DATA CORRECT?
BEQ 4$ ;BR IF YES
ERROR 15, YES ;ALU ERROR
TRAP C$ERDF
.WORD 15
.WORD EM15
.WORD ERR15
4$:
ESCAPE SEG
TRAP C$ESCAPE
.WORD 10000$-.
INC R2 ;NEXT DATA
INC R5 ;NEXT DATA
CMP #10, R5 ;DONE YET?
BNE 1$ ;BR IF NO

```

```
6866 026044          ENDSEG
(3) 026044          10000$:
(3) 026044 104405   TRAP   C$ESEG
6867 026046          EXIT   TST
(3) 026046 104432   TRAP   C$EXIT
(3) 026050 000012   .WORD  L10134-
6868 026052          377    377  5$: .BYTE  0,-1,-1,0,0,-1,-1,0
      026055          000    377
      026060          377    000

6869
6870
6871 026062          .EVEN
(3) 026062          FNDTST
(3) 026062 104401   L10134:
6872
6873 026064          TRAP   C$ETST

6874
6875
6876
6877
6878
6879 026064          BADHEAD
(2)
6880
6881 026064          :***** TEST 51 *****
(3) 026064          :*ALU TEST
6882 026064          :*TEST OF ALU FUNCTION ADD WITH C BIT CLEARED
(1) 026064 013701 002716   :*ALU FUNCTION (A PLUS B)   CODE=00
6883 026070          :*LOAD MAIN MEM AND SP WITH 8 WORDS OF DATA
(1) 026070 004537 003156   :*PERFORM THE FUNCTION, VERIFY THE RESULTS
6884 026074 005005          BADHEAD
6885 026076 012702 026256   :***** TEST 51 *****
6886 026102 004737 003640
6887 026106 002654
6888 026110 004737 004012
6889 026114 002664
6890 026116          BGNST
(3) 026116 104404          T51::
6891 026120 004737 004060   MYINT
6892 026124 042737 000017 026142 1$: MOV   KMCSR,R1      ;GET DEVICE ADDRESS.
6893 026132 050537 026142   MSTCLR ;MASTER CLEAR M8200,4,7
6894 026136          004537 003244   JSR   R5, .MSTCLR   ;CLEAR M8200,4,7
(1) 026136 010000          CLR   R5            ;MEM + SP ADDRESS
6895 026142 010000          MOV   #5$,R2       ;POINTER TO CORRECT DATA
6896 026144 042737 000017 026162 2$: JSR   PC, MEMLD    ;LOAD 8 WORDS OF MAIN MEMORY
6897 026152 050537 026162   MEMDAT ;POINTER TO DATA
(1) 026156 004537 003244   JSR   PC, SPLD     ;LOAD 8 WORDS OF SP
6898 026156          SPDAT ;POINTER TO DATA
6899 026162 040400          3$: TRAP  C$BSEG
6900 026164          010000          JSR   PC, CLRC     ;CLEAR C BIT!
(1) 026164 004537 003244   BIC   #17, 2$      ;CLEAR ADDRESS FIELD OF INSTRUCTION
6901 026170 061224          ROMCLK ;ADD ADDRESS TO INSTRUCTION
(1) 026170 061224          JSR   R5, .ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
6902 026172 111237 002636   010000 ;CLOCK INSTRUCTION
6903 026176 116104 000004   BIC   #17, 3$     ;LOAD MAR
6904 026202 123704 002636   BIS   R5, 3$      ;CLEAR ADDRESS OF INSTRUCTION
                          ROMCLK ;ADD ADDRESS TO INSTRUCTION
                          JSR   R5, .ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
                          040400!<00*20> ;CLOCK INSTRUCTION
                          ;BR   ADD
                          ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
                          ;MOVE BR TO PORT4
                          ;PUT 'EXPECTED' IN $GDDAT
                          ;PUT 'FOUND' IN R4
                          ;DATA CORRECT?
```



```
(1) 026342 004537 003244 JSR R5,,ROMCLK ;CLOCK INSTRUCTION
6941 026346 010000 2$: 010000 ;LOAD MAR
6942 026350 042737 000017 026366 BIC #17,3$ ;CLEAR ADDRESS OF INSTRUCTION
6943 026356 050537 026366 BIS R5,3$ ;ADD ADDRESS TO INSTRUCTION
6944 026362 ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
(1) 026362 004537 003244 JSR R5,,ROMCLK ;CLOCK INSTRUCTION
6945 026366 040540 3$: 040400!<6*20> ;BR 2A W/C
6946 026370 ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
(1) 026370 004537 003244 JSR R5,,ROMCLK ;CLOCK INSTRUCTION
6947 026374 061224 61224 ;MOVE BSR TO PORT4
6948 026376 111237 002636 MOVB (R2),%GDDAT ;PUT 'EXPECTED' IN %GDDAT
6949 026402 116104 000004 MOVB 4(R1),R4 ;PUT 'FOUND' IN R4
6950 026406 123704 002636 CMPB %GDDAT,R4 ;DATA CORRECT?
6951 026412 001411 BEQ 4$ ;BR IF YES
6952 026414 ERROR 15,YES ;ALU ERROR
(5) 026426 104455 TRAP C$ERDF
(6) 026430 000017 .WORD 15
(6) 026432 004754 .WORD EM15
(6) 026434 007120 .WORD ERR15
6953 026436 4$: ESCAPE SEG
(3) 026436 104410 TRAP C$ESCAPE
(3) 026440 000014 .WORD 10000$-.
6954 026442 005202 INC R2 ;NEXT DATA
6955 026444 005205 INC R5 ;NEXT ADDRESS
6956 026446 022705 000010 CMP #10,R5 ;DONE YET?
6957 026452 001324 BNE 1$ ;BR IF NO
6958 026454 ENDSEG
(3) 026454 10000$: TRAP C$ESEG
(3) 026454 104405 EXIT TST
6959 026456 TRAP C$EXIT
(3) 026456 104432 .WORD L10136-.
(3) 026460 000012 .BYTE 0,0,376,376,252,252,124,124
6960 026462 000 000 376 5$:
026465 376 252
026470 124 124
6961
6962 .EVEN
6963 026472 ENDTST
(3) 026472 L10136: TRAP C$ETST
(3) 026472 104401
6964
6965 026474 BADHEAD
(2) ;***** TEST 53 *****
6966 ;*ALU TEST
6967 ;*TEST OF ALU FUNCTION SUB WITH C BIT CLEARED
6968 ;*ALU FUNCTION (A-B) CODE=16
6969 ;*LOAD MAIN MEM AND SP WITH 8 WORDS OF DATA
6970 ;*PERFORM THE FUNCTION, VERIFY THE RESULTS
6971 026474 BADHEAD
(2) ;***** TEST 53 *****
6972
6973 026474 BGNTST
(3) 026474 T53::
6974 026474 MYINT
(1) 026474 013701 002716 MOV KMCSR,R1 ;GET DEVICE ADDRESS.
6975 026500 MSTCLR ;MASTER CLEAR M8200,4,7
```

(1)	026500	004537	003156		JSR	R5, .MSTCLR		:CLEAR M8200,4,7
6976	026504	005005			CLR	R5		:MEM + SP ADDRESS
6977	026506	012702	026670		MOV	#5\$,R2		:POINTER TO CORRECT DATA
6978	026512	004737	003640		JSR	PC, MEMLD		:LOAD 8 WORDS OF MAIN MEMORY
6979	026516	002654			MEMDAT			:POINTER TO DATA
6980	026520	004737	004012		JSR	PC, SPLD		:LOAD 8 WORDS OF SP
6981	026524	002664			SPDAT			:POINTER TO DATA
6982	026526				BGNSEG			
(3)	026526	104404			TRAP	C\$BSEG		
6983	026530	004737	004060		JSR	PC, CLRC	1\$:	:CLEAR C BIT!
6984	026534	042737	000017	026552	BIC	#17,2\$		:CLEAR ADDRESS FIELD OF INSTRUCTION
6985	026542	050537	026552		BIS	R5,2\$		:ADD ADDRESS TO INSTRUCTION
6986	026546				ROMCLK			:NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
(1)	026546	004537	003244		JSR	R5, .ROMCLK		:CLOCK INSTRUCTION
6987	026552	010000			010000		2\$:	:LOAD MAR
6988	026554	042737	000017	026572	BIC	#17,3\$		:CLEAR ADDRESS OF INSTRUCTION
6989	026562	050537	026572		BIS	R5,3\$		:ADD ADDRESS TO INSTRUCTION
6990	026566				ROMCLK			:NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
(1)	026566	004537	003244		JSR	R5, .ROMCLK		:CLOCK INSTRUCTION
6991	026572	040740			040400!	<16*20>	3\$:	:BR - SUB
6992	026574				ROMCLK			
(1)	026574	004537	003244		JSR	R5, .ROMCLK		:CLOCK INSTRUCTION
6993	026600	061224			61224			:MOVE BR TO PORT4
6994	026602	111237	002636		MOVB	(R2), \$GDDAT		:PUT 'EXPECTED' IN \$GDDAT
6995	026606	116104	000004		MOVB	4(R1), R4		:PUT 'FOUND' IN R4
6996	026612	123737	002636	002636	CMPB	\$GDDAT, \$GDDAT		:DATA CORRECT?
6997	026620	001411			BEQ	4\$		:BR IF YES
6998	026622				ERROR	15, YES		:ALU ERROR
(5)	026634	104455			TRAP	C\$ERDF		
(6)	026636	000017			.WORD	15		
(6)	026640	004754			.WORD	EM15		
(6)	026642	007120			.WORD	ERR15		
6999	026644				ESCAPE	SEG	4\$:	
(3)	026644	104410			TRAP	C\$ESCAPE		
(3)	026646	000014			.WORD	10000\$-		
7000	026650	005202			INC	R2		:NEXT DATA
7001	026652	005205			INC	R5		:NEXT ADDRESS
7002	026654	022705	000010		CMP	#10, R5		:DONE YET?
7003	026660	001323			BNE	1\$		:BR IF NO
7004	026662				ENDSEG			
(3)	026662						10000\$:	
(3)	026662	104405			TRAP	C\$ESEG		
7005	026664				EXIT	TST		
(3)	026664	104432			TRAP	C\$EXIT		
(3)	026666	000012			.WORD	L10137-		
7006	026670	000	001	377	.BYTE	0,1,-1,0,0,253,125,0	5\$:	
	026673	000	000	253				
	026676	125	000					
7007								
7008								
7009								
7010	026700				.EVEN			
(3)	026700				ENDTST			
(3)	026700	104401			L10137:			
7011					TRAP	C\$ETST		
7012								

7013 026702

(2)

7014

7015

7016

7017

7018

7019 026702

(2)

7020

7021 026702

(3) 026702

7022 026702

(1) 026702 013701 002716

7023 026706 (1) 026706 004537 003156

7024 026712 005005

7025 026714 012702 027074

7026 026720 004737 003640

7027 026724 002654

7028 026726 004737 004012

7029 026732 002664

7030 026734

(3) 026734 104404

7031 026736 004737 004060

7032 026742 042737 000017 026760 1\$:

7033 026750 050537 026760

7034 026754

(1) 026754 004537 003244

7035 026760 010000

7036 026762 042737 000017 027000 2\$:

7037 026770 050537 027000

7038 026774

(1) 026774 004537 003244

7039 027000 040420 3\$:

7040 027002

(1) 027002 004537 003244

7041 027006 061224

7042 027010 111237 002636

7043 027014 116104 000004

7044 027020 123704 002636

7045 027024 001411

7046 027026

(5) 027040 104455

(6) 027042 000017

(6) 027044 004754

(6) 027046 007120

7047 027050

(3) 027050 104410

(3) 027052 000014

7048 027054 005202

7049 027056 005205

7050 027060 022705 000010

7051 027064 001324

7052 027066

(3) 027066

BGNTST  
T54::

BADHEAD

:\*\*\*\*\* TEST 54 \*\*\*\*\*

:\*ALU TEST

:\*TEST OF ALU FUNCTION ADD W/C WITH C BIT CLEARED

:\*ALU FUNCTION (A PLUS B PLUS C) CODE=01

:\*LOAD MAIN MEM AND SP WITH 8 WORDS OF DATA

:\*PERFORM THE FUNCTION, VERIFY THE RESULTS

BADHEAD

:\*\*\*\*\* TEST 54 \*\*\*\*\*

MYINT

MOV KMCSR,R1 ;GET DEVICE ADDRESS.

MSTCLR R5 ;MASTER CLEAR M8200,4,7

JSR R5,.MSTCLR ;CLEAR M8200,4,7

CLR R5 ;MEM + SP ADDRESS

MOV #5\$,R2 ;POINTER TO CORRECT DATA

JSR PC,MEMLD ;LOAD 8 WORDS OF MAIN MEMORY

MEMDAT ;POINTER TO DATA

JSR PC,SPLD ;LOAD 8 WORDS OF SP

SPDAT ;POINTER TO DATA

BGNSEG

TRAP C\$BSEG

JSR PC,CLRC ;CLEAR C BIT!

BIC #17,2\$ ;CLEAR ADDRESS FIELD OF INSTRUCTION

BIS R5,2\$ ;ADD ADDRESS TO INSTRUCTION

ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304

JSR R5,.ROMCLK ;CLOCK INSTRUCTION

010000 ;LOAD MAR

BIC #17,3\$ ;CLEAR ADDRESS OF INSTRUCTION

BIS R5,3\$ ;ADD ADDRESS TO INSTRUCTION

ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304

JSR R5,.ROMCLK ;CLOCK INSTRUCTION

040400!<01\*20> ;BR ADD W/C

ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304

JSR R5,.ROMCLK ;CLOCK INSTRUCTION

61224 ;MOVE BR TO PORT4

MOVB (R2), \$GDDAT ;PUT 'EXPECTED' IN \$GDDAT

MOVB 4(R1), R4 ;PUT 'FOUND' IN R4

CMPB \$GDDAT, R4 ;DATA CORRECT?

BEQ 4\$ ;BR IS YES

ERROR 15, YES ;ALU ERROR

TRAP C\$ERDF

.WORD 15

.WORD EM15

.WORD ERR15

4\$: ESCAPE SEG

TRAP C\$ESCAPE

.WORD 10000\$-

INC R2 ;NEXT DATA

INC R5 ;NEXT ADDRESS

CMP #10, R5 ;DONE YET?

BNE 1\$ ;BR IF NO

ENDSEG

10000\$:



(3) 027066 104405 TRAP C\$ESEG  
7053 027070 EXIT TST  
(3) 027070 104432 TRAP C\$EXIT  
(3) 027072 000012 .WORD L10140-  
7054 027074 000 377 377 5\$: .BYTE 0,-1,-1,376,252,-1,-1,124  
027077 376 252 377  
027102 377 124

7055  
7056 .EVEN  
7057 027104 ENDTST  
(3) 027104 L10140:  
(3) 027104 104401 TRAP C\$ETST  
7058  
7059

7060 027106 BADHEAD  
(2) :\*\*\*\*\* TEST 55 \*\*\*\*\*  
7061 :\*ALU TEST  
7062 :\*TEST OF ALU FUNCTION SUB W/C WITH C BIT CLEARED  
7063 :\*ALU FUNCTION (A-B-C) CODE=2  
7064 :\*LOAD MAIN MEM AND SP WITH 8 WORDS OF DATA  
7065 :\*PERFORM THE FUNCTION, VERIFY THE RESULTS  
7066 027106 BADHEAD  
(2) :\*\*\*\*\* TEST 55 \*\*\*\*\*  
7067

7068 027106 BGNTST  
(3) 027106 T55::  
7069 027106 MYINT  
(1) 027106 013701 002716 MOV KMCSR,R1 ;GET DEVICE ADDRESS.



7108  
7109 027312  
(2)  
7110  
7111  
7112  
7113  
7114  
7115 027312  
(2)  
7116  
7117 027312  
(3) 027312  
7118 027312  
(1) 027312 013701 002716  
7119 027316  
(1) 027316 004537 003156  
7120 027322 012702 027504  
7121 027326 005005  
7122 027330 004737 003640  
7123 027334 002654  
7124 027336 004737 004012  
7125 027342 002664  
7126 027344  
(3) 027344 104404  
7127 027346 004737 004060  
7128 027352 042737 000017 027370  
7129 027360 050537 027370  
7130 027364  
(1) 027364 004537 003244  
7131 027370 010000  
7132 027372 042737 000017 027410  
7133 027400 050537 027410  
7134 027404  
(1) 027404 004537 003244  
7135 027410 040460  
7136 027412  
(1) 027412 004537 003244  
7137 027416 061224  
7138 027420 111237 002636  
7139 027424 116104 000004  
7140 027430 123704 002636  
7141 027434 001411  
7142 027436  
(5) 027450 104455  
(6) 027452 000017  
(6) 027454 004754  
(6) 027456 007120  
7143 027460  
(3) 027460 104410  
(3) 027462 000014  
7144 027464 005202  
7145 027466 005205  
7146 027470 022705 000010  
7147 027474 001324  
7148 027476

BADHEAD  
:\*\*\*\*\* TEST 56 \*\*\*\*\*  
:\*ALU TEST  
:\*TEST OF ALU FUNCTION INC A WITH C BIT CLEARED  
:\*ALU FUNCTION (A PLUS 1) CODE=3  
:\*LOAD MAIN MEM AND SP WITH 8 WORDS OF DATA  
:\*PERFORM THE FUNCTION, VERIFY THE RESULTS  
BADHEAD  
:\*\*\*\*\* TEST 56 \*\*\*\*\*

BGNTST  
T56::

MYINT  
MOV KMCSR,R1 ;GET DEVICE ADDRESS.  
MSTCLR ;MASTER CLEAR M8200,4,7  
JSR R5,.MSTCLR ;CLEAR M8200,4,7  
MOV #5\$,R2 ;POINTER TO CORRECT DATA  
CLR R5  
JSR PC,MEMLD ;LOAD 8 WORDS OF MAIN MEMRY  
MEMDAT ;POINTER TO DATA  
JSR PC,SPLD ;LOAD 8 WORDS OF SP  
SPDAT ;POINTER TO DATA  
BGNSEG  
TRAP C\$BSEG  
JSR PC,CLRC ;CLEAR C BIT!  
BIC #17,2\$ ;CLEAR ADDRESS FIELD OF INSTRUCTION  
BIS R5,2\$ ;ADD ADDRESS TO INSTRUCTION  
ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304  
JSR R5,.ROMCLK ;CLOCK INSTRUCTION  
010000 ;LOAD MAR  
BIC #17,3\$ ;CLEAR ADDRESS OF INSTRUCTION  
BIS R5,3\$ ;ADD ADDRESS TO INSTRUCTION  
ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304  
JSR R5,.ROMCLK ;CLOCK INSTRUCTION  
040400!<3\*20> ;BR INC A  
ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304  
JSR R5,.ROMCLK ;CLOCK INSTRUCTION  
61224 ;MOVE BR TO PORT4  
MOVB (R2), \$GDDAT ;PUT 'EXPECTED' IN \$GDDAT  
MOVB 4(R1), R4 ;PUT 'FOUND' IN R4  
CMPB \$GDDAT, R4 ;DATA CORRECT?  
BEQ 4\$ ;BR IF YES  
ERROR 15, YES ;ALU ERROR  
TRAP C\$ERDF  
.WORD 15  
.WORD EM15  
.WORD ERR15  
4\$: ESCAPE SEG  
TRAP C\$ESCAPE  
.WORD 10000\$-.  
INC R2 ;NEXT DATA  
INC R5  
CMP #10, R5 ;DONE YET?  
BNE 1\$ ;BR IF NO  
ENDSEG

```
(3) 027476 104405 10000$: TRAP C$ESEG
(3) 027476 104405 EXIT TST
7149 027500 104432 TRAP C$EXIT
(3) 027500 104432 .WORD L10142-
(3) 027502 000012 .BYTE 1,1,0,0,126,126,253,253
7150 027504 001 001 000 5$:
027507 000 126 126
027512 253 253

7151
7152
7153 027514 .EVEN
(3) 027514 ENDTST
(3) 027514 104401 L10142: TRAP C$ETST

7154
7155
7156 027516 BADHEAD
(2) :***** TEST 57 *****
7157 :*ALU TEST
7158 :*TEST OF ALU FUNCTION 2A WITH C BIT CLEARED
7159 :*ALU FUNCTION (A PLUS A) CODE=5
7160 :*LOAD MAIN MEM AND SP WITH 8 WORDS OF DATA
7161 :*PERFORM THE FUNCTION, VERIFY THE RESULTS
7162 027516 BADHEAD
(2) :***** TEST 57 *****
7163

7164 027516 BGNSTST
(3) 027516 T57::
7165 027516 MYINT
(1) 027516 013701 002716 MOV KMCSR,R1 ;GET DEVICE ADDRESS.
7166 027522 MSTCLR ;MASTER CLEAR DMC11
(1) 027522 004537 003156 JSR R5,.MSTCLR ;CLEAR M8200,4,7
7167 027526 005005 CLR R5 ;MEM * SP ADDRESS
7168 027530 012702 027710 MOV #5$,R2 ;POINTER TO CORRECT DATA
7169 027534 004737 003640 JSR PC,MEMLD ;LOAD 8 WORDS OF MAIN MEMORY
7170 027540 002654 MEMDAT ;POINTER TO DATA
7171 027542 004737 004012 JSR PC,SPLD ;LOAD 8 WORDS OF SP
7172 027546 002664 SPDAT ;POINTER TO DATA
7173 027550 BGNSEG
(3) 027550 104404 TRAP C$BSEG
7174 027552 004737 004060 027574 1$: JSR PC,CLRC ;CLEAR C BIT!
7175 027556 042737 000017 BIC #17,2$ ;CLEAR ADDRESS FIELD OF INSTRUCTION
7176 027564 050537 027574 BIS R5,2$ ;ADD ADDRESS TO INSTRUCTION
7177 027570 ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
(1) 027570 004537 003244 JSR R5,.ROMCLK ;CLOCK INSTRUCTION
7178 027574 010000 027614 2$: JSR R5,.ROMCLK ;LOAD MAR
7179 027576 042737 000017 BIC #17,3$ ;CLEAR ADDRESS OF INSTRUCTION
7180 027604 050537 027614 BIS R5,3$ ;ADD ADDRESS TO INSTRUCTION
7181 027610 ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
(1) 027610 004537 003244 JSR R5,.ROMCLK ;CLOCK INSTRUCTION
7182 027614 040520 3$: JSR R5,.ROMCLK ;BR 2A
7183 027616 ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
(1) 027616 004537 003244 JSR R5,.ROMCLK ;CLOCK INSTRUCTION
7184 027622 061224 61224 ;MOVE BR TO PORT4
7185 027624 111237 002636 MOVB (R2), $GDDAT ;PUT 'EXPECTED' IN $GDDAT
7186 027630 116104 000004 MOVB 4(R1), R4 ;PUT 'FOUND' IN R4
7187 027634 123704 002636 CMPB $GDDAT, R4 ;DATA CORRECT?
```

7188	027640	001411							BEQ	4\$		:BR IF YES
7189	027642								ERROR	15,YES		:ALU ERROR
(5)	027654	104455							TRAP	C\$ERDF		
(6)	027656	000017							.WORD	15		
(6)	027660	004754							.WORD	EM15		
(6)	027662	007120							.WORD	ERR15		
7190	027664							4\$:	ESCAPE	SEG		
(3)	027664	104410							TRAP	C\$ESCAPE		
(3)	027666	000014							.WORD	10000\$-		
7191	027670	005202							INC	R2		:NEXT DATA
7192	027672	005205							INC	R5		:NEXT ADDRESS
7193	027674	022705	000010						CMP	#10,R5		:DONE YET?
7194	027700	001324							BNE	1\$		:BR IF NO
7195	027702								ENDSEG			
(3)	027702							10000\$:				
(3)	027702	104405							TRAP	C\$ESEG		
7196	027704								EXIT	TST		
(3)	027704	104432							TRAP	C\$EXIT		
(3)	027706	000012							.WORD	L10143-		
7197	027710	000	000	376	5\$:				.BYTE	0,0,376,376,252,252,124,124		
	027713	376	252	252								
	027716	124	124									
7198												
7199												
7200	027720								.EVEN			
(3)	027720								ENDTST			
(3)	027720	104401							L10143:			
7201									TRAP	C\$ETST		
7202												
7203	027722								BADHEAD			
(2)									:*****			
7204									:***** TEST 58 *****			
7205									:*ALU TEST			
7206									:*TEST OF ALU FUNCTION A PLUS C WITH C BIT CLEARED			
7207									:*ALU FUNCTION (A PLUS C) CODE=4			
7208									:*LOAD MAIN MEM AND SP WITH 8 WORDS OF DATA			
7209	027722								:*PERFORM THE FUNCTION, VERIFY THE RESULTS			
(2)									BADHEAD			
7210									:*****			
7211	027722								:***** TEST 58 *****			
(3)	027722											
7212	027722								BGNTST			
(1)	027722	013701	002716						T58::			
7213	027726								MYINT			
(1)	027726	004537	003156						MOV	KMCSR,R1		:GET DEVICE ADDRESS.
7214	027732	005005							MSTCLR			:MASTER CLEAR M8200,4,7
7215	027734	012702	030114						JSR	R5,.MSTCLR		:CLEAR M8200,4,7
7216	027740	004737	003640						CLR	R5		:MEM + SP ADDRESS
7217	027744	002654							MOV	#5\$,R2		:POINTER TO CORRECT DATA
7218	027746	004737	004012						JSR	PC,MEMLD		:LOAD 8 WORDS OF MAIN MEMORY
7219	027752	002664							MEMDAT			:POINTER TO DATA
7220	027754								JSR	PC,SPLD		:LOAD 8 WORDS OF SP
(3)	027754	104404							SPDAT			:POINTER TO DATA
7221	027756	004737	004060						BGNSEG			
7222	027762	042737	000017	030000	1\$:				TRAP	C\$BSEG		:CLEAR C BIT!
7223	027770	050537	030000						JSR	PC,CLRC		:CLEAR ADDRESS FIELD OF INSTRUCTION
									BIC	#17,2\$		:ADD ADDRESS TO INSTRUCTION
									BIS	R5,2\$		



(1)	030126	013701	002716			MOV	KMCSR,R1	:GET DEVICE ADDRESS.
7260	030132					MSTCLR		:MASTER CLEAR M8200,4,7
(1)	030132	004537	003156			JSR	R5,.MSTCLR	:CLEAR M8200,4,7
7261	030136	005005				CLR	R5	:MEM + SP ADDRESS
7262	030140	012702	030320			MOV	#5\$,R2	:POINTER TO CORRECT DATA
7263	030144	004737	003640			JSR	PC,MEMLD	:LOAD 8 WORDS OF MAIN MEMORY
7264	030150	002654				MEMDAT		:POINTER TO DATA
7265	030152	004737	004012			JSR	PC,SPLD	:LOAD 8 WORDS OF SP
7266	030156	002664				SPDAT		:POINTER TO DATA
7267	030160					BGNSEG		
(3)	030160	104404				TRAP	C\$BSEG	
7268	030162	004737	004060			JSR	PC,CLRC	:CLEAR C BIT!
7269	030166	042737	000017	030204	1\$:	BIC	#17,2\$	:CLEAR ADDRESS FIELD OF INSTRUCTION
7270	030174	050537	030204			BIS	R5,2\$	:ADD ADDRESS TO INSTRUCTION
7271	030200					ROMCLK		:NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
(1)	030200	004537	003244			JSR	R5,.ROMCLK	:CLOCK INSTRUCTION
7272	030204	010000				010000		:LOAD MAR
7273	030206	042737	000017	030224	2\$:	BIC	#17,3\$	:CLEAR ADDRESS OF INSTRUCTION
7274	030214	050537	030224			BIS	R5,3\$	:ADD ADDRESS TO INSTRUCTION
7275	030220					ROMCLK		:NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
(1)	030220	004537	003244			JSR	R5,.ROMCLK	:CLOCK INSTRUCTION
7276	030224	040760			3\$:	040400!	<17*20>	:BR 2'S COMP SUB
7277	030226					ROMCLK		:NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
(1)	030226	004537	003244			JSR	R5,.ROMCLK	:CLOCK INSTRUCTION
7278	030232	061224				61224		:MOVE BR TO PORT4
7279	030234	111237	002636			MOVW	(R2), \$GDDAT	:PUT 'EXPECTED' IN \$GDDAT
7280	030240	116104	000004			MOVW	4(R1), R4	:PUT 'FOUND' IN R4
7281	030244	123704	002636			CMPB	\$GDDAT, R4	:DATA CORRECT?
7282	030250	001411				BEQ	4\$	:BR IS YES
7283	030252					ERROR	15, YES	:ALU ERROR
(5)	030264	104455				TRAP	C\$ERDF	
(6)	030266	000017				.WORD	15	
(6)	030270	004754				.WORD	EM15	
(6)	030272	007120				.WORD	ERR15	
7284	030274				4\$:	ESCAPE	SEG	
(3)	030274	104410				TRAP	C\$ESCAPE	
(3)	030276	000014				.WORD	10000\$-	
7285	030300	005202				INC	R2	:NEXT DATA
7286	030302	005205				INC	R5	:NEXT ADDRESS
7287	030304	022705	000010			CMP	#10, R5	:DONE YET?
7288	030310	001324				BNE	1\$	:BR IF NO
7289	030312					ENDSEG		
(3)	030312				10000\$:			
(3)	030312	104405				TRAP	C\$ESEG	
7290	030314					EXIT	TST	
(3)	030314	104432				TRAP	C\$EXIT	
(3)	030316	000012				.WORD	L10145-	
7291	030320	377	000	376	5\$:	.BYTE	-1,0,376,-1,-1,252,124,-1	
	030323	377	377	252				
	030326	124	377					
7292								
7293								
7294	030330					.EVEN		
(3)	030330					ENDTST		
(3)	030330	104401				L10145:		
7295						TRAP	C\$ETST	

7296										
7297	030332									
(2)										
7298										
7299										
7300										
7301										
7302										
7303										
7304	030332									
(2)										
7305										
7306	030332									
(3)	030332									
7307	030332									
(1)	030332	013701	002716							
7308	030336									
(1)	030336	004537	003156							
7309	030342	005005								
7310	030344	012702	030524							
7311	030350	004737	003640							
7312	030354	002654								
7313	030356	004737	004012							
7314	030362	002664								
7315	030364									
(3)	030364	104404								
7316	030366	004737	004060							
7317	030372	042737	000017	030410	1\$:					
7318	030400	050537	030410							
7319	030404									
(1)	030404	004537	003244							
7320	030410	010000								
7321	030412	042737	000017	030430	2\$:					
7322	030420	050537	030430							
7323	030424									
(1)	030424	004537	003244							
7324	030430	040560			3\$:					
7325	030432									
(1)	030432	004537	003244							
7326	030436	061224								
7327	030440	111237	002636							
7328	030444	116104	000004							
7329	030450	123704	002636							
7330	030454	001411								
7331	030456									
(5)	030470	104455								
(6)	030472	000017								
(6)	030474	004754								
(6)	030476	007120								
7332	030500				4\$:					
(3)	030500	104410								
(3)	030502	000014								
7333	030504	005202								
7334	030506	005205								
7335	030510	022705	000010							
7336	030514	001324								

BADHEAD  
 :\*\*\*\*\* TEST 60 \*\*\*\*\*  
 :\*ALU TEST  
 :\*TEST OF ALU FUNCTION DEC A WITH C BIT CLEARED  
 :\*ALU FUNCTION (A-1) CODE=7  
 :\*LOAD MAIN MEM AND SP WITH 8 WORDS OF DATA  
 :\*PERFORM THE FUNCTION, VERIFY THE RESULTS

BADHEAD  
 :\*\*\*\*\* TEST 60 \*\*\*\*\*

BGNTST  
 T60::

MYINT  
 MOV KMCSR,R1 ;GET DEVICE ADDRESS.  
 MSTCLR ;MASTER CLEAR DMC11  
 JSR R5,.MSTCLR ;CLEAR M8200,4,7  
 CLR R5 ;MEM + SP ADDRESS  
 MOV #5\$,R2 ;POINTER TO CORRECT DATA  
 JSR PC,MEMLD ;LOAD 8 WORDS OF MAIN MEMMOR  
 MEMDAT ;POINTER TO DATA  
 JSR PC,SPLD ;LOAD 8 WORDS OF SP  
 SPDAT ;POINTER TO DATA  
 BGNSEG  
 TRAP C\$BSEG  
 JSR PC,CLRC ;CLEAR C BIT!  
 BIC #17,2\$ ;CLEAR ADDRESS FIELD OF INSTRUCTION  
 BIS R5,2\$ ;ADD ADDRESS TO INSTRUCTION  
 ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304  
 JSR R5,.ROMCLK ;CLOCK INSTRUCTION  
 010000 ;LOAD MAR  
 BIC #17,3\$ ;CLEAR ADDRESS OF INSTRUCTION  
 BIS R5,3\$ ;ADD ADDRESS TO INSTRUCTION  
 ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304  
 JSR R5,.ROMCLK ;CLOCK INSTRUCTION  
 040400!<7\*20> ;BR DEC A  
 ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304  
 JSR R5,.ROMCLK ;CLOCK INSTRUCTION  
 61224 ;MOVE BR TO PORT4  
 MOVB (R2), \$GDDAT ;PUT 'EXPECTED' IN \$GDDAT  
 MOVB 4(R1), R4 ;PUT 'FOUND' IN R4  
 CMPB \$GDDAT, R4 ;DATA CORRECT?  
 BEQ 4\$ ;BR IF YES  
 ERROR 15, YES ;ALU ERROR  
 TRAP C\$ERDF  
 .WORD 15  
 .WORD EM15  
 .WORD ERR15  
 ESCAPE SEG  
 TRAP C\$ESCAPE  
 .WORD 10000\$-  
 INC R2 ;NEXT DATA  
 INC R5 ;NEXT ADDRESS  
 CMP #10, R5 ;DONE YET?  
 BNE 1\$ ;BR IF NO



```
7337 030516          ENDSEG
(3) 030516          10000$:
(3) 030516 104405   TRAP   C$ESEG
7338 030520          EXIT   TST
(3) 030520 104432   TRAP   C$EXIT
(3) 030522 000012   .WORD  L10146-
7339 030524      377   377   376  5$:  .BYTE  -1,-1,376,376,124,124,251,251
      030527      376   124   124
      030532      251   251

7340
7341
7342 030534          .EVEN
(3) 030534          ENDTST
(3) 030534 104401   L10146:
      TRAP   C$ETST

7343
7344
7345 030536          BADHEAD
(2)
7346          :***** TEST 61 *****
7347          :*ALU TEST
7348          :*TEST OF ALU FUNCTION SEL B WITH C BIT SET
7349          :*ALU FUNCTION (B)      CODE=11
7350          :*LOAD MAIN MEM AND SP WITH 8 WORDS OF DATA
7351          :*PERFORM THE FUNCTION, VERIFY THE RESULTS
(2)          BADHEAD
7352          :***** TEST 61 *****
7353 030536          BGNTST
(3) 030536          T61::
7354 030536          MYINT
(1) 030536 013701 002716  MOV   KMCSR,R1      ;GET DEVICE ADDRESS.
7355 030542          MSTCLR  MOV   M8200,4,7     ;MASTER CLEAR M8200,4,7
(1) 030542 004537 003156  JSR   R5,.,MSTCLR   ;CLEAR M8200,4,7
7356 030546 005005          CLR   R5             ;MEM + SP ADDRESS
7357 030550 012702 030730  MOV   #5$,R2        ;POINTER TO CORRECT DATA
7358 030554 004737 003640  JSR   PC,MEMLD      ;LOAD 8 WORDS OF MAIN MEMORY
7359 030560 002654          MEMDAT  JSR   PC,SPLD       ;LOAD 8 WORDS OF SP
7360 030562 004737 004012  SPDAT  JSR   PC,SPLD       ;POINTET TO DATA
7361 030566 002664          BGNSEG
7362 030570          TRAP   C$BSEG
(3) 030570 104404          JSR   PC,SETC      ;SET C BIT!
7363 030572 004737 004076  BIC   #17,2$        ;CLEAR ADDRESS FIELD OF INSTRUCTION
7364 030576 042737 000017 030614  BIS   R5,2$         ;ADD ADDRESS TO INSTRUCTION
7365 030604 050537 030614  ROMCLK JSR   R5,.,ROMCLK  ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
(1) 030610 004737 003244          ;CLOCK INSTRUCTION
7367 030614 010000          :LOAD MAR
7368 030616 042737 000017 030634  BIC   #17,3$        ;CLEAR ADDRESS OF INSTRUCTION
7369 030624 050537 030634  BIS   R5,3$         ;ADD ADDRESS TO INSTRUCTION
7370 030630          ROMCLK  JSR   R5,.,ROMCLK  ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
(1) 030630 004537 003244          ;CLOCK INSTRUCTION
7371 030634 040620          3$:  040400!<11*20>  ;BR   SEL B
7372 030636          ROMCLK  JSR   R5,.,ROMCLK  ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
(1) 030636 004537 003244          ;CLOCK INSTRUCTION
7373 030642 061224          61224  ;MOVE BR TO PORT4
7374 030644 111237 002636  MOVB  (R2), $GDDAT  ;PUT 'EXPECTED' IN $GDDAT
7375 030650 116104 000004  MOVB  4(R1),R4     ;PUT 'FOUND' IN R4
```





7437  
7438 031144  
(3) 031144  
(3) 031144 104401  
7439  
7440  
7441 031146  
(2)  
7442  
7443  
7444  
7445  
7446  
7447 031146  
(2)  
7448  
7449 031146  
(3) 031146  
7450 031146  
(1) 031146 013701 002716  
7451 031152  
(1) 031152 004537 003156  
7452 031156 005005  
7453 031160 012702 031340  
7454 031164 004737 003640  
7455 031170 002654  
7456 031172 004737 004012  
7457 031176 002664  
7458 031200  
(3) 031200 104404  
7459 031202 004737 004076  
7460 031206 042737 000017 031224  
7461 031214 050537 031224  
7462 031220  
(1) 031220 004537 003244  
7463 031224 010000  
7464 031226 042737 000017 031244  
7465 031234 050537 031244  
7466 031240  
(1) 031240 004537 003244  
7467 031244 040640  
7468 031246  
(1) 031246 004537 003244  
7469 031252 061224  
7470 031254 111237 002636  
7471 031260 116104 000004  
7472 031264 123704 002636  
7473 031270 001411  
7474 031272  
(5) 031304 104455  
(6) 031306 000017  
(6) 031310 004754  
(6) 031312 007120  
7475 031314  
(3) 031314 104410  
(3) 031316 000014

.EVEN  
ENDTST  
L10150:  
TRAP C\$ETST

BADHEAD  
:\*\*\*\*\* TEST 63 \*\*\*\*\*  
:\*ALU TEST  
:\*TEST OF ALU FUNCTION A OR NOTB WITH C BIT SET  
:\*ALU FUNCTION (A OR NOTB) CODE=12  
:\*LOAD MAIN MEM AND SP WITH 8 WORDS OF DATA  
:\*PERFORM THE FUNCTION, VERIFY THE RESULTS  
BADHEAD  
:\*\*\*\*\* TEST 63 \*\*\*\*\*

BGNTST  
T63::

MYINT  
MOV KMCSR,R1 ;GET DEVICE ADDRESS.  
MSTCLR ;MASTER CLEAR M8200,4,7  
JSR R5,.MSTCLR ;CLEAR M8200,4,7  
CLR R5 ;MEM + SP ADDRESS  
MOV #5\$,R2 ;POINTER TO CORRECT DATA  
JSR PC,MEMLD ;LOAD 8 WORDS OF MAIN MEMORY  
MEMDAT ;POINTER TO DATA  
JSR PC,SPLD ;LOAD 8 WORDS OF SP  
SPDAT ;POINTER TO DATA  
BGNSEG  
TRAP C\$BSEG  
JSR PC,SETC ;SET C BIT!  
BIC #17,2\$ ;CLEAR ADDRESS FIELD OF INSTRUCTION  
BIS R5,2\$ ;ADD ADDRESS TO INSTRUCTION  
ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304  
JSR R5,.ROMCLK ;CLOCK INSTRUCTION  
010000 ;LOAD MAR  
BIC #17,3\$ ;CLEAR ADDRESS OF INSTRUCTION  
BIS R5,3\$ ;ADD ADDRESS TO INSTRUCTION  
ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304  
JSR R5,.ROMCLK ;CLOCK INSTRUCTION  
040400!<12\*20> ;BR A OR NOTB  
ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304  
JSR R5,.ROMCLK ;CLOCK INSTRUCTION  
61224 ;MOVE BR TO PORT4  
MOVB (R2), \$GDDAT ;PUT 'EXPECTED' IN \$GDDAT  
MOVB 4(R1), R4 ;PUT 'FOUND' IN R4  
CMPB \$GDDAT, R4 ;DATA CORRECT?  
BEQ 4\$ ;BR IF YES  
ERROR 15, YES ;ALU ERROR  
TRAP C\$ERDF  
.WORD 15  
.WORD EM15  
.WORD ERR15  
ESCAPE SEG  
TRAP C\$ESCAPE  
.WORD 10000\$-

7476	031320	005202				INC	R2	:NEXT DATA
7477	031322	005205				INC	R5	:NEXT ADDRESS
7478	031324	022705	000010			CMP	#10,R5	:DONE YET?
7479	031330	001324				BNE	1\$	:BR IF NO
7480	031332					ENDSEG		
(3)	031332				10000\$:			
(3)	031332	104405				TRAP	C\$ESEG	
7481	031334					EXIT	TST	
(3)	031334	104432				TRAP	C\$EXIT	
(3)	031336	000012				.WORD	L10151-	
7482	031340	377	000	377	5\$:	.BYTE	-1,0,-1,-1,-1,125,252,-1	
	031343	377		125				
	031346	252	377					
7483								
7484					.EVEN			
7485	031350				ENDTST			
(3)	031350				L10151:			
(3)	031350	104401				TRAP	C\$ETST	
7486								
7487								
7488	031352					BADHEAD		
(2)						:***** TEST 64 *****		
7489						:*ALU TEST		
7490						:*TEST OF ALU FUNCTION A AND B WITH C BIT SET		
7491						:ALU FUNCTION (A AND B) CODE=13		
7492						:*LOAD MAIN MEM AND SP WITH 8 WORDS OF DATA		
7493						:*PERFORM THE FUNCTION, VERIFY THE RESULTS		
7494	031352					BADHEAD		
(2)						:***** TEST 64 *****		
7495								
7496	031352				BGNTST			
(3)	031352				T64::			
7497	031352					MYINT		
(1)	031352	013701	002716			MOV	KMCSR,R1	:GET DEVICE ADDRESS.
7498	031356					MSTCLR		:MASTER CLEAR M8200,4,7
(1)	031356	004537	003156			JSR	R5,.MSTCLR	:CLEAR M8200,4,7
7499	031362	005005				CLR	R5	:MEM + SP ADDRESS
7500	031364	012702	031544			MOV	#5\$,R2	:POINTER TO CORRECT ADDRESS
7501	031370	004737	003640			JSR	PC,MEMLD	:LOAD 8 WORDS OF MAIN MEMORY
7502	031374	002654				MEMDAT		:POINTER TO DATA
7503	031376	004737	004012			JSR	PC,SPLD	:LOAD 8 WORDS OF SP
7504	031402	002664				SPDAT		:POINTER TO DATA
7505	031404					BGNSEG		
(3)	031404	104404				TRAP	C\$BSEG	
7506	031406	004737	004076		1\$:	JSR	PC,SETC	:SET C BIT!
7507	031412	042737	000017	031430		BIC	#17,2\$	:CLEAR ADDRESS FIELD OF INSTRUCTION
7508	031420	050537	031430			BIS	R5,2\$	:ADD ADDRESS TO INSTRUCTION
7509	031424					ROMCLK		:NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
(1)	031424	004537	003244			JSR	R5,.ROMCLK	:CLOCK INSTRUCTION
7510	031430	010000			2\$:	010000		:LOAD MAR
7511	031432	042737	000017	031450		BIC	#17,3\$	:CLEAR ADDRESS OF INSTRUCTION
7512	031440	050537	031450			BIS	R5,3\$	:ADD ADDRESS TO INSTRUCTION
7513	031444					ROMCLK		:NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
(1)	031444	004537	003244			JSR	R5,.ROMCLK	:CLOCK INSTRUCTION
7514	031450	040660			3\$:	040400!	<13*20>	:BR A AND B
7515	031452					ROMCLK		:NEXT WORD IS INSTRUCTION, ROMCLK PC=5304

```

(1) 031452 004537 003244 JSR R5,ROMCLK ;CLOCK INSTRUCTION
7516 031456 061224 61224 ;MOVE BR TO PORT4
7517 031460 111237 002636 MOVB (R2),SGDDAT ;PUT 'EXPECTED' IN SGDDAT
7518 031464 116104 000004 MOVB 4(R1),R4 ;PUT 'FOUND' IN R4
7519 031470 123704 002636 CMPB SGDDAT,R4 ;DATA CORRECT?
7520 031474 001411 BEQ 4$ ;BR IF YES
7521 031476 ERROR 23,YES ;ALU ERROR
(5) 031510 104455 TRAP C$ERDF
(6) 031512 000027 .WORD 23
(6) 031514 005226 .WORD EM23
(6) 031516 007404 .WORD ERR23
7522 031520 4$: ESCAPE SEG
(3) 031520 104410 TRAP C$ESCAPE
(3) 031522 000014 .WORD 10000$-
7523 031524 005202 INC R2 ;NEXT DATA
7524 031526 005205 INC R5 ;NEXT ADDRESS
7525 031530 022705 000010 CMP #10,R5 ;DONE YET?
7526 031534 001324 BNE 1$ ;BR IF NO
7527 031536 ENLSEG
(3) 031536 10000$: TRAP C$ESEG
(3) 031536 104405 EXIT TST
7528 031540 TRAP C$EXIT
(3) 031540 104432 .WORD L10152-
(3) 031542 000012 5$: .BYTE 0,0,0,-1,125,0,0,252
7529 031544 000 000 000 000
031547 377 125 000
031552 000 252

7530
7531 .EVEN
7532 031554 ENDTST
(3) 031554 L10152:
(3) 031554 104401 TRAP C$ETST
7533
7534
7535 031556 BADHEAD
(2) :***** TEST 65 *****
7536 :*ALU TEST
7537 :*TEST OF ALU FUNCTION A OR B WITH C BIT SET
7538 :*ALU FUNCTION (A OR B) CODE=14
7539 :*LOAD MAIN MEM AND SP WITH 8 WORDS OF DATA
7540 :*PERFORM THE FUNCTION, VERIFY THE RESULTS
7541 031556 BADHEAD
(2) :***** TEST 65 *****
7542
7543 031556 BGNTST
(3) 031556 T65::
7544 031556 MYINT
(1) 031556 013701 002716 MOV KMCSR,R1 ;GET DEVICE ADDRESS.
7545 031562 MSTCLR MOVB R5,MSTCLR ;MASTER CLEAR M8200,4,7
(1) 031562 004537 003156 JSR R5,MSTCLR ;CLEAR M8200,4,7
7546 031566 005005 CLR R5 ;MEM + SP ADDRESS
7547 031570 012702 031750 MOV #5$,R2 ;POINTER TO CORRECT DATA
7548 031574 004737 003640 JSR PC,MEMLD ;LOAD 8 WORDS OF MAIN MEMORY
7549 031600 002654 MEMDAT ;POINTER TO DATA
7550 031602 004737 004012 JSR PC,SPLD ;LOAD 8 WORDS OF SP
7551 031606 002664 SPDAT ;POINTER TO DATA
  
```

7552	031610					BGNSEG		
(3)	031610	104404				TRAP	C\$BSEG	
7553	031612	004737	004076		1\$:	JSR	PC,SETC	:SET C BIT!
7554	031616	042737	000017	031634		BIC #17,2\$		:CLEAR ADDRESS FIELD OF INSTRUCTION
7555	031624	050537	031634			BIS	R5,2\$	:ADD ADDRESS TO INSTRUCTION
7556	031630					ROMCLK		:NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
(1)	031630	004537	003244			JSR	R5,.ROMCLK	:CLOCK INSTRUCTION
7557	031634	010000			2\$:	010000		:LOAD MAR
7558	031636	042737	000017	031654		BIC	#17,3\$	:CLEAR ADDRESS OF INSTRUCTION
7559	031644	050537	031654			BIS	R5,3\$	:ADD ADDRESS TO INSTRUCTION
7560	031650					ROMCLK		:NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
(1)	031650	004537	003244			JSR	R5,.ROMCLK	:CLOCK INSTRUCTION
7561	031654	040700			3\$:	040400!<14*20>		:BR A OR B
7562	031656					ROMCLK		:NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
(1)	031656	004537	003244			JSR	R5,.ROMCLK	:CLOCK INSTRUCTION
7563	031662	061224				61224		:MOVE BR TO PORT4
7564	031664	111237	002636			MOVB	(R2), \$GDDAT	:PUT 'EXPECTED' IN R4
7565	031670	116104	000004			MOVB	4(R1), R4	:PUT 'FOUND' IN R4
7566	031674	123704	002636			CMPB	\$GDDAT, R4	:DATA CORRECT?
7567	031700	001411				BEQ	4\$	:BR IF YES
7568	031702					ERROR	23, YES	:ALU ERROR
(5)	031714	104455				TRAP	C\$ERDF	
(6)	031716	000027				.WORD	23	
(6)	031720	005226				.WORD	EM23	
(6)	031722	007404				.WORD	ERR23	
7569	031724				4\$:	ESCAPE	SEG	
(3)	031724	104410				TRAP	C\$ESCAPE	
(3)	031726	000014				.WORD	10000\$-	
7570	031730	005202				INC	R2	:NEXT DATA
7571	031732	005205				INC	R5	:NEXT ADDRESS
7572	031734	022705	000010			CMP	#10, R5	:DONE YET?
7573	031740	001324				BNE	1\$	:BR IF NO
7574	031742					ENDSEG		
(3)	031742				10000\$:			
(3)	031742	104405				TRAP	C\$ESEG	
7575	031744					EXIT	TST	
(3)	031744	104432				TRAP	C\$EXIT	
(3)	031746	000012				.WORD	L10153-	
7576	031750	000	377	377	5\$:	.BYTE	0,-1,-1,-1,125,-1,-1,252	
	031753	377	125	377				
	031756	377	252					
7577								
7578								
7579	031760					.EVEN		
(3)	031760					ENDTST		
(3)	031760	104401				L10153:		
7580						TRAP	C\$ETST	
7581								
7582	031762					BADHEAD		
(2)						:***** TEST 66 *****		
7583						:*ALU TEST		
7584						:*TEST OF ALU FUNCTION A XOR B WITH C BIT SET		
7585						:*ALU FUNCTION (A XOR B) CODE=15		
7586						:*LOAD MAIN MEM AND SP WITH 8 WORDS OF DATA		
7587						:*PERFORM THE FUNCTION, VERIFY THE RESULTS		
7588								

```
7589 031762          BADHEAD
(2)                ;***** TEST 66 *****
7590 031762          BGNTST
(3) 031762          T66::
7591 031762          MYINT
(1) 031762 013701 002716 MOV KMCSR,R1 ;GET DEVICE ADDRESS.
7592 031766          MSTCLR ;MASTER CLEAR M8200,4,7
(1) 031766 004537 003156 JSR R5,.,MSTCLR ;CLEAR M8200,4,7
7593 031772 005005 CLR R5 ;MEM + SP ADDRESS
7594 031774 012702 032154 MOV #5$,R2 ;POINTER TO CORRECT DATA
7595 032000 004737 003640 JSR PC,MEMLD ;LOAD 8 WORDS OF MAIN MEMORY
7596 032004 002654 MEMDAT ;POINTER TO DATA
7597 032006 004737 004012 JSR PC,SPLD ;LOAD 8 WORDS OF SP
7598 032012 002664 SPDAT ;POINTER TO DATA
7599 032014          BGNSEG
(3) 032014 104404 TRAP C$BSEG
7600 032016 004737 004076 1$: JSR PC,SETC ;SET C BIT!
7601 032022 042737 000017 032040 BIC #17,2$ ;CLEAR ADDRESS FIELD OF INSTRUCTION
7602 032030 050537 032040 BIS R5,2$ ;ADD ADDRESS TO INSTRUCTION
7603 032034          ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
(1) 032034 004537 003244 JSR R5,.,ROMCLK ;CLOCK INSTRUCTION
7604 032040 010000 2$: 010000 ;LOAD MAR
7605 032042 042737 000017 032060 BIC #17,3$ ;CLEAR ADDRESS OF INSTRUCTION
7606 032050 050537 032060 BIS R5,3$ ;ADD ADDRESS TO INSTRUCTION
7607 032054          ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
(1) 032054 004537 003244 JSR R5,.,ROMCLK ;CLOCK INSTRUCTION
7608 032060 040720 3$: 040400!<15*20> ;BR A XOR B
7609 032062          ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
(1) 032062 004537 003244 JSR R5,.,ROMCLK ;CLOCK INSTRUCTION
7610 032066 061224 61224 ;MOVE BR TO PORT4
7611 032070 111237 002636 MOVB (R2), $GDDAT ;PUT 'EXPECTED' IN $GDDAT
7612 032074 116104 000004 MOVB 4(R1), R4 ;PUT 'FOUND' IN R4
7613 032100 123704 002636 CMPB $GDDAT, R4 ;DATA CORRECT?
7614 032104 001411 BEQ 4$ ;BR IF YES
7615 032106          ERROR 23, YES ;ALU ERROR
(5) 032120 104455 TRAP C$ERDF
(6) 032122 000027 .WORD 23
(6) 032124 005226 .WORD EM23
(6) 032126 007404 .WORD ERR23
7616 032130          4$: ESCAPE SEG
(3) 032130 104410 TRAP C$ESCAPE
(3) 032132 000014 .WORD 10000$-.
7617 032134 005202 INC R2 ;NEXT DATA
7618 032136 005205 INC R5 ;NEXT ADDRESS
7619 032140 022705 000010 CMP #10, R5 ;DONE YET?
7620 032144 001324 BNE 1$ ;BR IF NO
7621 032146          10000$: ENDSEG
(3) 032146          TRAP C$ESEG
(3) 032146 104405 EXIT TST
7622 032150          TRAP C$EXIT
(3) 032150 104432 .WORD L10154-.
(3) 032152 000012 .BYTE 0,-1,-1,0,0,-1,-1,0
7623 032154 000 377 377 5$:
032157 000 000 377
032162 377 000
7624
```



7625  
7626 032164  
(3) 032164  
(3) 032164 104401  
7627  
7628  
7629 032166  
(2)  
7630  
7631  
7632  
7633  
7634  
7635 032166  
(2)  
7636  
7637 032166  
(3) 032166  
7638 032166  
(1) 032166 013701 002716  
7639 032172  
(1) 032172 004537 003156  
7640 032176 005005  
7641 032200 012702 032360  
7642 032204 004737 003640  
7643 032210 002654  
7644 032212 004737 004012  
7645 032216 002664  
7646 032220  
(3) 032220 104404  
7647 032222 004737 004076  
7648 032226 042737 000017 032244  
7649 032234 050537 032244  
7650 032240  
(1) 032240 004537 003244  
7651 032244 010000  
7652 032246 042737 000017 032264  
7653 032254 050537 032264  
7654 032260  
(1) 032260 004537 003244  
7655 032264 040400  
7656 032266  
(1) 032266 004537 003244  
7657 032272 061224  
7658 032274 111237 002636  
7659 032300 116104 000004  
7660 032304 123704 002636  
7661 032310 001411  
7662 032312  
(5) 032324 104455  
(6) 032326 000027  
(6) 032330 005226  
(6) 032332 007404  
7663 032334  
(3) 032334 104410  
(3) 032336 000014

.EVEN  
ENDTST  
L10154:  
TRAP C\$ETST

BADHEAD  
:\*\*\*\*\* TEST 67 \*\*\*\*\*  
:\*ALU TEST  
:\*TEST OF ALU FUNCTION ADD WITH C BIT SET  
:\*ALU FUNCTION (A PLUS B) CODE=00  
:\*LOAD MAIN MEM AND SP WITH 8 WORDS OF DATA  
:\*PERFORM THE FUNCTION, VERIFY THE RESULTS  
BADHEAD  
:\*\*\*\*\* TEST 67 \*\*\*\*\*

BGNTST  
T67::

MYINT  
MOV KMCSR,R1 ;GET DEVICE ADDRESS.  
MSTCLR ;MASTER CLEAR M8200,4,7  
JSR R5, .MSTCLR ;CLEAR M8200,4,7  
CLR R5 ;MEM + SP ADDRESS  
MOV #5\$,R2 ;POINTER TO CORRECT DATA  
JSR PC, MEMLD ;LOAD 8 WORDS OF MAIN MEMORY  
MEMDAT ;POINTER TO DATA  
JSR PC, SPLD ;LOAD 8 WORDS OF SP  
SPDAT ;POINTER TO DATA  
BGNSEG  
TRAP C\$BSEG  
JSR PC, SETC ;SET C BIT!  
BIC #17,2\$ ;CLEAR ADDRESS FIELD OF INSTRUCTION  
BIS R5,2\$ ;ADD ADDRESS TO INSTRUCTION  
ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304  
JSR R5, .ROMCLK ;CLOCK INSTRUCTION  
010000 ;LOAD MAR  
BIC #17,3\$ ;CLEAR ADDRESS OF INSTRUCTION  
BIS R5,3\$ ;ADD ADDRESS TO INSTRUCTION  
ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304  
JSR R5, .ROMCLK ;CLOCK INSTRUCTION  
040400!<00\*20> ;BR ADD  
ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304  
JSR R5, .ROMCLK ;CLOCK INSTRUCTION  
61224 ;MOVE BR TO PORT4  
MOVB (R2), \$GDDAT ;PUT 'EXPECTED' IN \$GDDAT  
MOVB 4(R1), R4 ;PUT 'FOUND' IN R4  
CMPB \$GDDAT, R4 ;DATA CORRECT?  
BEQ 4\$ ;BR IF YES  
ERROR 23, YES ;ALU ERROR  
TRAP C\$ERDF  
.WORD 23  
.WORD EM23  
.WORD ERR23  
4\$:  
ESCAPE SEG  
TRAP C\$ESCAPE  
.WORD 10000\$-

```

7664 032340 005202          INC      R2          ;NEXT DATA
7665 032342 005205          INC      R5          ;NEXT ADDRESS
7666 032344 022705 000010  CMP     #10,R5      ;DONE YET?
7667 032350 001324          BNE     1$          ;BR IF NO
7668 032352          ENDSEG
(3) 032352          10000$:
(3) 032352 104405          TRAP   C$ESEG
7669 032354          EXIT   TST
(3) 032354 104432          TRAP   C$EXIT
(3) 032356 000012          .WORD  L10155-
7670 032360 000          377    377 5$: .BYTE  0,-1,-1,376,252,-1,-1,124
      032363 376          377
      032366 377          124

7671
7672
7673 032370          .EVEN
(3) 032370          ENDTST
(3) 032370 104401          L10155:
7674          TRAP   C$ETST
7675
7676 032372          BADHEAD
(2)          :***** TEST 68 *****
7677          :*ALU TEST
7678          :*TEST OF ALU FUNCTION 2A W/C WITH CBIT SET
7679          :*ALU FUNCTION (A PLUS A PLUS C)      CODE=6
7680          :*LOAD MAIN MEM AND SP WITH 8 WORDS OF DATA
7681          :*PERFORM THE FUNCTION, VERIFY THE RESULTS
7682 032372          BADHEAD
(2)          :***** TEST 68 *****
7683
7684 032372          BGNTST
(3) 032372          T68::
7685 032372          MYINT
(1) 032372 013701 002716  MOV     KMCSR,R1    ;GET DEVICE ADDRESS.
7686 032376          MSTCLR          ;MASTER CLEAR M8200,4,7
(1) 032376 004537 003156  JSR     R5,.,MSTCLR ;CLEAR M8200,4,7
7687 032402 005005          CLR     R5          ;MEM + SP ADDRESS
7688 032404 012702 032564  MOV     #5$,R2      ;POINTER TO CORRECT DATA
7689 032410 004737 003640  JSR     PC,MEMLD    ;LOAD 8 WORDS OF MAIN MEMORY
7690 032414 002654          MEMDAT          ;POINTER TO DATA
7691 032416 004737 004012  JSR     PC,SPLD     ;LOAD 8 WORDS OF SP
7692 032422 002664          SPDAT          ;POINTER TO DATA
7693 032424          BGNSEG
(3) 032424 104404          TRAP   C$BSEG
7694 032426 004737 004076  JSR     PC,SETC     ;SET C BIT!
7695 032432 042737 000017 032450  BIC     #17,2$      ;CLEAR ADDRESS FIELD OF INSTRUCTION
7696 032440 050537 032450  BIS     R5,2$       ;ADD ADDRESS TO INSTRUCTION
7697 032444          ROMCLK          ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
(1) 032444 004537 003244  JSR     R5,.,ROMCLK ;CLOCK INSTRUCTION
7698 032450 010000          010000          ;LOAD MAR
7699 032452 042737 000017 032470  BIC     #17,3$      ;CLEAR ADDRESS OF INSTRUCTION
7700 032460 050537 032470  BIS     R5,3$       ;ADD ADDRESS TO INSTRUCTION
7701 032464          ROMCLK          ;NEXT WORD IS INSTRUCTION, ROMCLK PC=55304
(1) 032464 004537 003244  JSR     R5,.,ROMCLK ;CLOCK INSTRUCTION
7702 032470 040540          040400! <6*20> ;BR 2A W/C
7703 032472          ROMCLK          ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304

```

```
(1) 032472 004537 003244 JSR R5,ROMCLK ;CLOCK INSTRUCTION
7704 032476 061224 61224 ;MOVE BR TO PORT4
7705 032500 111237 002636 MOVB (R2),SGDDAT ;PUT 'WXPECTED' IN SGDDAT
7706 032504 116104 000004 MOVB 4(R1),R4 ;PUT 'FOUND' IN R4
7707 032510 123704 002636 CMPB $GDDAT,R4 ;DATA CORRECT?
7708 032514 001411 BEQ 4$ ;BR IF YES
7709 032516 ERROR 23,YES ;ALU ERROR
(5) 032530 104455 TRAP C$ERDF
(6) 032532 000027 .WORD 23
(6) 032534 005226 .WORD EM23
(6) 032536 007404 .WORD ERR23
7710 032540 4$: ESCAPE SEG
(3) 032540 104410 TRAP C$ESCAPE
(3) 032542 000014 .WORD 10000$-
7711 032544 005202 INC R2 ;NEXT DATA
7712 032546 005205 INC R5 ;NEXT ADDRESS
7713 032550 022705 000010 CMP #10,R5 ;DONE YET?
7714 032554 001324 BNE 1$ ;BR IF NO
7715 032556 ENDSEG
(3) 032556 10000$: TRAP C$ESEG
7716 032560 EXIT TST
(3) 032560 104432 TRAP C$EXIT
(3) 032562 000012 .WORD L10156-
7717 032564 001 001 377 5$: .BYTE 1,1,-1,-1,253,253,125,125
032567 377 253
032572 125 125
7718
7719 .EVEN
7720 032574 ENDTST
(3) 032574 L10156:
(3) 032574 104401 TRAP C$ETST
7721
7722
7723 032576 BADHEAD
(2) :***** TEST 69 *****
7724 :*ALU TEST
7725 :*TEST OF ALU FUNCTION SUB WITH C BIT SET
7726 :*ALU FUNCTION (A-B) CODE=16
7727 :*LOAD MAIN MEM AND SP WITH 8 WORDS OF DATA
7728 :*PERFORM THE FUNCTION, VERIFY THE RESULTS
7729 032576 BADHEAD
(2) :***** TEST 69 *****
7730
7731 032576 BGNTST
(3) 032576 T69::
7732 032576 MYINT
(1) 032576 013701 002716 MOV KMCSR,R1 ;GET DEVICE ADDRESS.
7733 032602 MSTCLR ;MASTER CLEAR M8200,4,7
(1) 032602 004537 003156 JSR R5,MSTCLR ;CLEAR M8200,4,7
7734 032606 005005 CLR R5 ;MEM + SP ADDRESS
7735 032610 012702 032770 MOV #5$,R2 ;POINTER TO CORRECT DATA
7736 032614 004737 003640 JSR PC,MEMLD ;LOAD 8 WORDS OF MAIN MEMORY
7737 032620 002654 MEMDAT ;POINTER TO DATA
7738 032622 004737 004012 JSR PC,SPLD ;LOAD 8 WORDS OF SP
7739 032626 002664 SPDAT ;POINTER TO DATA
```

```
7740 032630          BGNSEG
(3) 032630 104404    TRAP    C$BSEG
7741 032632 004737 004076 1$:    JSR    PC,SETC    ;SET C BIT!
7742 032636 042737 000017 032654 BIC    #17,2$    ;CLEAR ADDRESS FIELD OF INSTRUCTION
7743 032644 050537 032654    BIS    R5,2$    ;ADD ADDRESS TO INSTRUCTION
7744 032650          ROMCLK    ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
(1) 032650 004537 003244    JSR    R5,,ROMCLK ;CLOCK INSTRUCTION
7745 032654 010000    2$:    010000    ;LOAD MAR
7746 032656 042737 000017 032674 BIC    #17,3$    ;CLEAR ADDRESS OF INSTRUCTION
7747 032664 050537 032674    BIS    R5,3$    ;ADD ADDRESS TO INSTRUCTION
7748 032670          ROMCLK    ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
(1) 032670 004537 003244    JSR    R5,,ROMCLK ;CLOCK INSTRUCTION
7749 032674 040740    3$:    040400!<16*20> ;BR SUB
7750 032676          ROMCLK    ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
(1) 032676 004537 003244    JSR    R5,,ROMCLK ;CLOCK INSTRUCTION
7751 032702 061224    61224    ;MOVE BR TO PORT4
7752 032704 111237 002636    MOVB   (R2), $GDDAT ;PUT 'EXPECTED' IN $GDDAT
7753 032710 116104 000004    MOVB   4(R1), R4    ;PUT 'FOUND' IN R4
7754 032714 123704 002636    CMPB   $GDDAT, R4   ;DATA CORRECT?
7755 032720 001411    BEQ    4$          ;BR IF YES
7756 032722          ERROR    23, YES ;ALU ERROR
(5) 032734 104455    TRAP   C$ERDF
(6) 032736 000027    .WORD 23
(6) 032740 005226    .WORD EM23
(6) 032742 007404    .WORD ERR23
7757 032744          4$:    ESCAPE SEG
(3) 032744 104410    TRAP   C$ESCAPE
(3) 032746 000014    .WORD 10000$-
7758 032750 005202    INC    R2          ;NEXT DATA
7759 032752 005205    INC    R5          ;NEXT ADDRESS
7760 032754 022705 000010    CMP    #10, R5    ;DONE YET?
7761 032760 001324    BNE    1$          ;BR IF NO
7762 032762          ENDSEG
(3) 032762          10000$:
(3) 032762 104405    TRAP   C$ESEG
7763 032764          EXIT    TST
(3) 032764 104432    TRAP   C$EXIT
(3) 032766 000012    .WORD L10157-
7764 032770 000 001 377 5$:    .BYTE 0,1,-1,0,0,253,125,0
032773 000 000 253
032776 025 000

7765
7766
7767 033000          .EVEN
(3) 033000          ENDTST
(3) 033000 104401    L10157: TRAP   C$ETST
7768
7769
7770 033002          BADHEAD
(2)
7771          ;***** TEST 70 *****
7772          ;*ALU TEST
7773          ;*TEST OF ALU FUNCTION ADD W/C WITH C BIT SET
7774          ;*ALU FUNCTION (A PLUS B PLUS C) CODE=01
7775          ;*LOAD MAIN MEM AND SP WITH 8 WORDS OF DATA
7776 033002          ;*PERFORM THE FUNCTION, VERIFY THE RESULTS
          BADHEAD
```

\*\*\*\*\* TEST 70 \*\*\*\*\*

```
(2)
7777
7778 033002          BGNTST
(3) 033002          T70::
7779 033002
(1) 033002 013701 002716      MYINT
7780 033006          MOV      KMCSR,R1      ;GET DEVICE ADDRESS.
(1) 033006 004537 003156      MSTCLR      ;MASTER CLEAR M8200,4,7
7781 033012 005005          JSR      R5,.,MSTCLR      ;CLEAR M8200,4,7
7782 033014 012702 033174      CLR      R5      ;MEM +SP ADDRESS
7783 033020 004737 003640      MOV      #5$,R2      ;POINTER TO CORRECT DATA
7784 033024 002654          JSR      PC,MEMLD      ;LOAD 8 WORDS OF MAIN MEMORY
7785 033026 004737 004012      MEMDAT     ;POINTER TO DATA
7786 033032 002664          JSR      PC,SPLD      ;LOAD 8 WORDS OF SP
7787 033034          SPDAT     ;POINTER TO DATA
(3) 033034 104404          BGNSEG
7788 033036 004737 004076      TRAP     C$BSEG
7789 033042 042737 000017 033060 1$: JSR      PC,SETC      ;SET C BIT!
7790 033050 050537 033060      BIC      #17,2$      ;CLEAR ADDRESS FIELD OF INSTRUCTION
7791 033054          BIS      R5,2$      ;ADD ADDRESS TO INSTRUCTION
(1) 033054 004537 003244      ROMCLK    ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
7792 033060 010000          JSR      R5,.,ROMCLK    ;CLOCK INSTRUCTION
7793 033062 042737 000017 033100 2$: 010000      ;LOAD MAR
7794 033070 050537 033100      BIC      #17,3$      ;CLEAR ADDRESS OF INSTRUCTION
7795 033074          BIS      R5,3$      ;ADD ADDRESS TO INSTRUCTION
(1) 033074 004537 003244      ROMCLK    ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
7796 033100 040420          JSR      R5,.,ROMCLK    ;CLOCK INSTRUCTION
7797 033102          040400!<01*20> 3$: ROMCLK    ;BR - ADD W/C
(1) 033102 004537 003244      JSR      R5,.,ROMCLK    ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
7798 033106 061224          61224      ;CLOCK INSTRUCTION
7799 033110 111237 002636      MOVB     (R2), $GDDAT   ;MOVE BR TO PORT4
7800 033114 116104 000004          MOVB     4(R1), R4      ;PUT 'EXPECTED' IN $GDDAT
7801 033120 123704 002636      CMPB     $GDDAT, R4     ;PUT 'FOUND' IN R4
7802 033124 001411          BEQ      4$            ;DATA CORRECT?
7803 033126          ERROR    23, YES    ;BR IF YES
(5) 033140 104455          TRAP     C$ERDF        ;ALU ERROR
(6) 033142 000027          .WORD   23
(6) 033144 005226          .WORD   EM23
(6) 033146 007404          .WORD   ERR23
7804 033150          4$: ESCAPE    SEG
(3) 033150 104410          TRAP     C$ESCAPE
(3) 033152 000014          .WORD   10000$-
7805 033154 005202          INC      R2            ;NEXT DATA
7806 033156 005205          INC      R5            ;NEXT ADDRESS
7807 033160 022705 000010      CMP      #10, R5       ;DONE YET?
7808 033164 001324          BNE     1$            ;BR IF NO
7809 033166          ENDSEG
(3) 033166          10000$:
(3) 033166 104405          TRAP     C$ESEG
7810 033170          EXIT     TST
(3) 033170 104432          TRAP     C$EXIT
(3) 033172 000012          .WORD   L10160-
7811 033174          001      000          000 5$: .BYTE   1,0,0,-1,253,0,0,125
      033177          377      253          000
      033202          000      125
7812
```

7813  
7814 033204  
(3) 033204  
(3) 033204 104401  
7815  
7816  
7817 033206  
(2)  
7818  
7819  
7820  
7821  
7822  
7823 033206  
(2)  
7824  
7825  
7826 033206  
(3) 033206  
7827 033206 013701 002716  
(1) 033206  
7828 033212 004537 003156  
(1) 033212  
7829 033216 005005  
7830 033220 012702 033400  
7831 033224 004737 003640  
7832 033230 002654  
7833 033232 004737 004012  
7834 033236 002664  
7835 033240  
(3) 033240 104404  
7836 033242 004737 004076  
7837 033246 042737 000017 033264  
7838 033254 050537 033264  
7839 033260  
(1) 033260 004537 003244  
7840 033264 010000  
7841 033266 042737 000017 033304  
7842 033274 050537 033304  
7843 033300  
(1) 033300 004537 003244  
7844 033304 040440  
7845 033306  
(1) 033306 004537 003244  
7846 033312 061224  
7847 033314 111237 002636  
7848 033320 116104 000004  
7849 033324 123704 002636  
7850 033330 001411  
7851 033332  
(5) 033344 104455  
(6) 033346 000027  
(6) 033350 005226  
(6) 033352 007404  
7852 033354  
(3) 033354 104410

.EVEN  
ENDTST  
L10160:  
TRAP C\$ETST

BADHEAD  
:\*\*\*\*\* TEST 71 \*\*\*\*\*  
:\*ALU TEST  
:\*TEST OF ALU FUNCTION SUB W/C WITH C BIT SET  
:\*ALU FUNCTION (A-B-C) CODE=2  
:\*LOAD MAIN MEM AND SP WITH 8 WORDS OF DATA  
:\*PERFORM THE FUNCTION, VERIFY THE RESULTS  
BADHEAD  
:\*\*\*\*\* TEST 71 \*\*\*\*\*

BGNTST  
T71::

MYINT  
MOV KMCSR,R1 ;GET DEVICE ADDRESS.  
MSTCLR ;MASTER CLEAR M8200,4,7  
JSR R5,.MSTCLR ;CLEAR M8200,4,7  
CLR R5 ;MEM + SP ADDRESS  
MOV #5\$,R2 ;POINTER TO CORRECT DATA  
JSR PC,MEMLD ;LOAD 8 WORDS OF MAIN MEMORY  
MEMDAT ;POINTER TO DATA  
JSR PC,SPLD ;LOAD 8 WORDS OF SP  
SPDAT ;POINTER TO DATA  
BGNSEG  
TRAP C\$BSEG  
1\$: JSR PC,SETC ;SET C BIT!  
BIC #17,2\$ ;CLEAR ADDRESS FIELD OF INSTRUCTION  
BIS R5,2\$ ;ADD ADDRESS TO INSTRUCTION  
ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304  
JSR R5,.ROMCLK ;CLOCK INSTRUCTION  
2\$: 010000 ;LOAD MAR  
BIC #17,3\$ ;CLEAR ADDRESS OF INSTRUCTION  
BIS R5,3\$ ;ADD ADDRESS TO INSTRUCTION  
ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=55304  
JSR R5,.ROMCLK ;CLOCK INSTRUCTION  
3\$: 040400! <2\*20> ;BR SUB W/C  
ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304  
JSR R5,.ROMCLK ;CLOCK INSTRUCTION  
61224 ;MOVE BR TO PORT4  
MOVB (R2), \$GDDAT ;PUT 'EXPECTED' IN \$GDDAT  
MOVB 4(R1), R4 ;PUT 'FOUND' IN R4  
CMPB \$GDDAT, R4 ;DATA CORRECT?  
BEQ 4\$ ;BR IF YES  
ERROR 23, YES ;ALU ERROR  
TRAP C\$ERDF  
. WORD 23  
. WORD EM23  
. WORD ERR23  
4\$: ESCAPE SEG  
TRAP C\$ESCAPE

```

(3) 033356 000014 .WORD 10000$.
7853 033360 005202 INC R2 ;NEXT DATA
7854 033362 005205 INC R5 ;NEXT ADDRESS
7855 033364 022705 000010 CMP #10,R5 ;DONE YET?
7856 033370 001324 BNE 1$ ;BR IF NO
7857 033372 ENDSEG
(3) 033372 10000$:
(3) 033372 104405 TRAP C$ESEG
7858 033374 EXIT TST
(3) 033374 104432 TRAP C$EXIT
(3) 033376 000012 .WORD L10161-
7859 033400 000 001 377 5$: .BYTE 0,1,-1,0,0,253,125,0
033403 000 000 253
033406 125 000

7860
7861 .EVEN
7862 033410 ENDTST
(3) 033410 L10161:
(3) 033410 104401 TRAP C$ETST
7863
7864
7865 033412 BADHEAD
(2) :***** TEST 72 *****
7866 :*ALU TEST
7867 :*TEST OF ALU FUNCTION INC A WITH C BIT SET
7868 :*ALU FUNCTION (A PLUS 1) CODE=3
7869 :*LOAD MAIN MEM AND SP WITH 8 WORDS OF DATA
7870 :*PERFORM THE FUNCTION, VERIFY THE RESULTS
7871 033412 BADHEAD
(2) :***** TEST 72 *****
7872
7873 033412 BGNTST
(3) 033412 T72::
7874 033412 MYINT
(1) 033412 013701 002716 MOV KMCSR,R1 ;GET DEVICE ADDRESS.
7875 033416 MSTCLR ;MASTER CLEAR M8200,4,7
(1) 033416 004537 003156 JSR R5,.MSTCLR ;CLEAR M8200,4,7
7876 033422 005005 CLR R5 ;MEM + SP ADDRESS
7877 033424 012702 033604 MOV #5$,R2 ;POINTER TO CORRECT DATA
7878 033430 004737 003640 JSR PC,MEMLD ;LOAD 8 WORDS OF MAIN MEMORY
7879 033434 002654 MEMDAT ;POINTER TO DATA
7880 033436 004737 004012 JSR PC,SPLD ;LOAD 8 WORDS OF SP
7881 033442 002664 SPDAT ;POINTER TO DATA
7882 033444 BGNSEG
(3) 033444 104404 TRAP C$BSEG
7883 033446 004737 004076 1$: JSR PC,SETC ;SET C BIT!
7884 033452 042737 000017 033470 BIC #17,2$ ;CLEAR ADDRESS FIELD OF INSTRUCTION
7885 033460 050537 033470 BIS R5,2$ ;ADD ADDRESS TO INSTRUCTION
7886 033464 ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
(1) 033464 004537 003244 JSR R5,.ROMCLK ;CLOCK INSTRUCTION
7887 033470 010000 2$: 010000 ;LOAD MAR
7888 033472 042737 000017 033510 BIC #17,3$ ;CLEAR ADDRESS OF INSTRUCTION
7889 033500 050537 033510 BIS R5,3$ ;ADD ADDRESS TO INSTRUCTION
7890 033504 ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
(1) 033504 004537 003244 JSR R5,.ROMCLK ;CLOCK INSTRUCTION
7891 033510 040460 3$: 040400!<3*20> ;BR _ INC A

```

```
7892 033512 ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
(1) 033512 004537 003244 JSR R5,,ROMCLK ;CLOCK INSTRUCTION
7893 033516 061224 61224 ;MOVE BR TO PORT4
7894 033520 111237 002636 MOVB (R2), $GDDAT ;PUT 'EXPECTED' IN $GDDAT
7895 033524 116104 000004 MOVB 4(R1), R4 ;PUT 'FOUND IN R4
7896 033530 123704 002636 CMPB $GDDAT, R4 ;DATA CORRECT?
7897 033534 001411 BEQ 4$ ;BR IF YES
7898 033536 ERROR 23, YES ;ALU ERROR
(5) 033550 104455 TRAP C$ERDF
(6) 033552 000027 .WORD 23
(6) 033554 005226 .WORD EM23
(6) 033556 007404 .WORD ERR23
7899 033560 4$: ESCAPE SEG
(3) 033560 104410 TRAP C$ESCAPE
(3) 033562 000014 .WORD 10000$-
7900 033564 005202 INC R2 ;NEXT DATA
7901 033566 005205 INC R5 ;NEXT ADDRESS
7902 033570 022705 000010 CMP #10, R5 ;DONE YET?
7903 033574 001324 BNE 1$ ;BR IF NO
7904 033576 ENDSEG
(3) 033576 10000$: TRAP C$ESEG
7905 033600 EXIT TST
(3) 033600 104432 TRAP C$EXIT
(3) 033602 000012 .WORD L10162-
7906 033604 001 001 000 5$: .BYTE 1,1,0,0,126,126,253,253
033607 000 126 126
033612 253 253

7907
7908 .EVEN
7909 033614 ENDTST
(3) 033614 L10162: TRAP C$ETST
(3) 033614 104401

7910
7911
7912 033616 BADHEAD
(2) ;***** TEST 73 *****
7913 ;*ALU TEST
7914 ;*TEST OF ALU FUNCTION 2A WITH C BIT SET
7915 ;*ALU FUNCTION (A PLUS A) CODE=5
7916 ;*LOAD MAIN MEM AND SP WITH 8 WORDS OF DATA
7917 ;*PERFORM THE FUNCTION, VERIFY THE RESULTS
7918 033616 BADHEAD
(2) ;***** TEST 73 *****
7919

7920 033616 BGNTST
(3) 033616 T73::
7921 033616 MYINT
(1) 033616 013701 002716 MOV KMCSR, R1 ;GET DEVICE ADDRESS.
7922 033622 MSTCLR ;MASTER CLEAR M8200,4,7
(1) 033622 004537 003156 JSR R5,,MSTCLR ;CLEAR M8200,4,7
7923 033626 005005 CLR R5 ;MEM + SP ADDRESS
7924 033630 012702 034010 MOV #5$, R2 ;POINTER TO CORRECT DATA
7925 033634 004737 003640 JSR PC, MEMLD ;LOAD 8 WORDS OF MAIN MEMORY
7926 033640 002654 MEMDAT ;POINTER TO DATA
7927 033642 004737 004012 JSR PC, SPLD ;LOAD 8 WORDS OF SP
```



```

7928 033646 002664          SPDAT          ;POINTER TO DATA
7929 033650          BGNSEG
(3) 033650 104404          TRAP C$BSEG
7930 033652 004737 004076 1$: JSR PC,SETC ;SET C BIT!
7931 033656 042737 000017 033674 BIC #17,2$ ;CLEAR ADDRESS FIELD OF INSTRUCTION
7932 033664 050537 033674 BIS R5,2$ ;ADD ADDRESS TO INSTRUCTION
7933 033670          ROMCLK          ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
(1) 033670 004537 003244 JSR R5,.ROMCLK ;CLOCK INSTRUCTION
7934 033674 010000 2$: JSR 010000 ;LOAD MAR
7935 033676 042737 000017 033714 BIC #17,3$ ;CLEAR ADDRESS OF INSTRUCTION
7936 033704 050537 033714 BIS R5,3$ ;ADD ADDRESS TO INSTRUCTION
7937 033710          ROMCLK          ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
(1) 033710 004537 003244 JSR R5,.ROMCLK ;CLOCK INSTRUCTION
7938 033714 040520 3$: JSR 040400!<5*20> ;BR 2A
7939 033716          ROMCLK          ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
(1) 033716 004537 003244 JSR R5,.ROMCLK ;CLOCK INSTRUCTION
7940 033722 061224 61224 ;MOVE BR TO PORT4
7941 033724 111237 002636 MCVB (R2), $GDDAT ;PUT 'EXPECTED' IN $GDDAT
7942 033730 116104 000004 MOVB 4(R1), R4 ;PUT 'FOUND IN R4
7943 033734 123704 002636 CMPB $GDDAT, R4 ;DATA CORRECT?
7944 033740 001411 BEQ 4$ ;BR IF YES
7945 033742          ERROR          ;ALU ERROR
(5) 033754 104455 TRAP C$ERDF
(6) 033756 000027 .WORD 23
(6) 033760 005226 .WORD EM23
(6) 033762 007404 .WORD ERR23
7946 033764          ESCAPE          4$:
(3) 033764 104410 TRAP C$ESCAPE
(3) 033766 000014 .WORD 10000$-.
7947 033770 005202 INC R2 ;NEXT DATA
7948 033772 005205 INC R5 ;NEXT ADDRESS
7949 033774 022705 000010 CMP #10, R5 ;DONE YET?
7950 034000 001324 BNE 1$ ;BR IF NO
7951 034002          ENDSEG
(3) 034002 10000$:
(3) 034002 104405 TRAP C$ESEG
7952 034004          EXIT          EXIT TST
(3) 034004 104432 TRAP C$EXIT
(3) 034006 000012 .WORD L10163-.
7953 034010 000 000 376 5$: .BYTE 0,0,376,376,252,252,124,124
034013 376 252 252
034016 124 124

7954
7955          .EVEN
7956 034020          ENDTST
(3) 034020          L10163:
(3) 034020 104401 TRAP C$ETST

7957
7958
7959 034022          BADHEAD
(2) ;***** TEST 74 *****
7960 ;*ALU TEST
7961 ;*TEST OF ALU FUNCTION A PLUS C WITH C BIT SET
7962 ;*ALU FUNCTION (A PLUS C) CODE=4
7963 ;*LOAD MAIN MEM AND SP WITH 8 WORDS OF DATA
7964 ;*PERFORM THE FUNCTION, VERIFY THE RESULTS
  
```

```

7965 034022          BADHEAD
(2)
7966
7967 034022          BGNTST
(3) 034022          T74::
7968 034022          MYINT
(1) 034022 013701 002716 MOV KMCSR,R1 ;GET DEVICE ADDRESS.
7969 034026          MSTCLR ;MASTER CLEAR M8200,4,7
(1) 034026 004537 003156 JSR R5,.,MSTCLR ;CLEAR M8200,4,7
7970 034032          CLR R5 ;MEM + SP ADDRESS
7971 034034 012702 034214 MOV #5$,R2 ;POINTER TO CORRECT DATA
7972 034040 004737 003640 JSR PC,MEMLD ;LOAD 8 WORDS OF MAIN MEMORY
7973 034044 002654 MEMDAT ;POINTER TO DATA
7974 034046 004737 004012 JSR PC,SPLD ;LOAD 8 WORDS OF SP
7975 034052 002664 SPDAT ;POINTER TO DATA
7976 034054          BGNSEG
(3) 034054 104404 TRAP C$BSEG
7977 034056 004737 004076 1$: JSR PC,SETC ;SET C BIT!
7978 034062 042737 000017 034100 BIC #17,2$ ;CLEAR ADDRESS FIELD OF INSTRUCTION
7979 034070 050537 034100 BIS R5,2$ ;ADD ADDRESS TO INSTRUCTION
7980 034074          ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
(1) 034074 004537 003244 JSR R5,.,ROMCLK ;CLOCK INSTRUCTION
7981 034100 010000 010000 2$: ;LOAD MAR
7982 034102 042737 000017 034120 BIC #17,3$ ;CLEAR ADDRESS OF INSTRUCTION
7983 034110 050537 034120 BIS R5,3$ ;ADD ADDRESS TO INSTRUCTION
7984 034114          ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
(1) 034114 004537 003244 JSR R5,.,ROMCLK ;CLOCK INSTRUCTION
7985 034120 040500 040400!<4*20> 3$: ;BR A PLUS C
7986 034122          ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
(1) 034122 004537 003244 JSR R5,.,ROMCLK ;CLOCK INSTRUCTION
7987 034126 061224 61224 ;MOVE BR TO PORT4
7988 034130 111237 002636 MOVB (R2), $GDDAT ;PUT 'EXPECTED' IN $GDDAT
7989 034134 116104 000004 MOVB 4(R1), R4 ;PUT 'FOUND IN R4
7990 034140 123704 002636 CMPB $GDDAT, R4 ;DATA CORRECT?
7991 034144 001411 BEQ 4$ ;BR IF YES
7992 034146          ERROR 23, YES ;ALU ERROR
(5) 034160 104455 TRAP C$ERDF
(6) 034162 000027 .WORD 23
(6) 034164 005226 .WORD EM23
(6) 034166 007404 .WORD ERR23
7993 034170          4$: ESCAPE SEG
(3) 034170 104410 TRAP C$ESCAPE
(3) 034172 000014 .WORD 10000$-.
7994 034174 005202 INC R2 ;NEXT DATA
7995 034176 005205 INC R5 ;NEXT ADDRESS
7996 034200 022705 000010 CMP #10, R5 ;DONE YET?
7997 034204 001324 BNE 1$ ;BR IF NO
7998 034206          10000$: ENDSEG
(3) 034206 TRAP C$ESEG
(3) 034206 104405 EXIT TST
7999 034210          TRAP C$EXIT
(3) 034210 104432 .WORD L10164-.
(3) 034212 000012 .BYTE 1,1,0,0,126,126,253,253
8000 034214 001 001 000 5$:
034217 000 126 126
034222 253 253

```

8001  
8002  
8003 034224  
(3) 034224  
(3) 034224 104401  
8004  
8005 034226  
(2)  
8006  
8007  
8008  
8009  
8010  
8011 034226  
(2)  
8012  
8013 034226  
(3) 034226

.EVEN  
ENDTST  
L10164:

TRAP C\$ETST

BADHEAD

:\*\*\*\*\* TEST 75 \*\*\*\*\*

:\*ALU TEST

:\*TEST OF ALU FUNCTION 2'S COMP SUB WITH C BIT SET

:\*ALU FUNCTION (A-B-1) CODE=17

:\*LOAD MAIN MEM AND SP WITH 8 WORDS OF DATA

:\*PERFORM THE FUNCTION, VERIFY THE RESULTS

BADHEAD

:\*\*\*\*\* TEST 75 \*\*\*\*\*

BGNTST  
T75::

8015	034226					MYINT		
(1)	034226	013701	002716			MOV	KMCSR,R1	:GET DEVICE ADDRESS.
8016	034232					MSTCLR		:MASTER CLEAR M8200,4,7
(1)	034232	004537	003156			JSR	R5,.MSTCLR	:CLEAR M8200,4,7
8017	034236	005005				CLR	R5	:MEM + SP ADDRESS
8018	034240	012702	034420			MOV	#5\$,R2	:POINTER TO CORRECT DATA
8019	034244	004737	003640			JSR	PC,MEMLD	:LOAD 3 WORDS OF MAIN MEMORY
8020	034250	002654				MEMDAT		:POINTER TO DATA
8021	034252	004737	004012			JSR	PC,SPLD	:LOAD 8 WORDS OF SP
8022	034256	002664				SPDAT		:POINTER TO DATA
8023	034260					BGNSEG		
(3)	034260	104404				TRAP	C\$BSEG	
8024	034262	004737	004076			JSR	PC,SETC	:SET C BIT!
8025	034266	042737	000017	034304	1\$:	BIC	#17,2\$	:CLEAR ADDRESS FIELD OF INSTRUCTION
8026	034274	050537	034304			BIS	R5,2\$	:ADD ADDRESS TO INSTRUCTION
8027	034300					ROMCLK		:NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
(1)	034300	004537	003244			JSR	R5,.ROMCLK	:CLOCK INSTRUCTION
8028	034304	010000					010000	:LOAD MAR
8029	034306	042737	000017	034324	2\$:	BIC	#17,3\$	:CLEAR ADDRESS OF INSTRUCTION
8030	034314	050537	034324			BIS	R5,3\$	:ADD ADDRESS TO INSTRUCTION
8031	034320					ROMCLK		:NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
(1)	034320	004537	003244			JSR	R5,.ROMCLK	:CLOCK INSTRUCTION
8032	034324	040760			3\$:		040400!<17*20>	:BR 2'S COMP SUB
8033	034326					ROMCLK		:NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
(1)	034326	004537	003244			JSR	R5,.ROMCLK	:CLOCK INSTRUCTION
8034	034332	061224					61224	:MOVE BR TO PORT4
8035	034334	111237	002636			MOVB	(R2), \$GDDAT	:PUT 'EXPECTED' IN \$GDDAT
8036	034340	116104	000004			MOVB	4(R1), R4	:PUT 'FOUND IN R4
8037	034344	123704	002636			CMPB	\$GDDAT, R4	:DATA CORRECT?
8038	034350	001411				BEQ	4\$	:BR IF YES
8039	034352					ERROR	23, YES	:ALU ERROR
(5)	034364	104455				TRAP	C\$ERDF	
(6)	034366	000027				.WORD	23	
(6)	034370	005226				.WORD	EM23	
(6)	034372	007404				.WORD	ERR23	
8040	034374				4\$:	ESCAPE	SEG	
(3)	034374	104410				TRAP	C\$ESCAPE	
(3)	034376	000014				.WORD	10000\$-	
8041	034400	005202				INC	R2	:NEXT DATA
8042	034402	005205				INC	R5	:NEXT ADDRESS
8043	034404	022705	000010			CMP	#10, R5	:DONE YET?
8044	034410	001324				BNE	1\$	:BR IF NO
8045	034412					ENDSEG		
(3)	034412				10000\$:			
(3)	034412	104405				TRAP	C\$ESEG	
8046	034414					EXIT	TST	
(3)	034414	104432				TRAP	C\$EXIT	
(3)	034416	000012				.WORD	L10165-	
8047	034420	377	000	376	5\$:	.BYTE	-1,0,376,-1,-1,252,124,-1	
	034423	377	377	252				
	034426	124	377					
8048								
8049						.EVEN		
8050	034430					ENDTST		
(3)	034430					L10165:		
(3)	034430	104401				TRAP	C\$ETST	

8051  
8052  
8053 034432  
(2)  
8054  
8055  
8056  
8057  
8058  
8059 034432  
(2)  
8060  
8061 034432  
(3) 034432  
8062 034432  
(1) 034432 013701 002716  
8063 034436  
(1) 034436 004537 003156  
8064 034442 005005  
8065 034444 012702 034624  
8066 034450 004737 003640  
8067 034454 002654  
8068 034456 004737 004012  
8069 034462 002664  
8070 034464  
(3) 034464 104404  
8071 034466 004737 004076  
8072 034472 042737 000017 034510  
8073 034500 050537 034510  
8074 034504  
(1) 034504 004537 003244  
8075 034510 010000  
8076 034512 042737 000017 034530  
8077 034520 050537 034530  
8078 034524  
(1) 034524 004537 003244  
8079 034530 040560  
8080 034532  
(1) 034532 004537 003244  
8081 034536 061224  
8082 034540 111237 002636  
8083 034544 116104 000004  
8084 034550 123704 002636  
8085 034554 001411  
8086 034556  
(5) 034570 104455  
(6) 034572 000027  
(6) 034574 005226  
(6) 034576 007404  
8087 034600  
(3) 034600 104410  
(3) 034602 000014  
8088 034604 005202  
8089 034606 005205  
8090 034610 022705 000010  
8091 034614 001324

BGNTST  
T76::

BADHEAD  
:\*\*\*\*\* TEST 76 \*\*\*\*\*  
:\*ALU TEST  
:\*TEST OF ALU FUNCTION DEC A WITH C BIT SET  
:\*ALU FUNCTION (A-1) CODE=7  
:\*LOAD MAIN MEM AND SP WITH 8 WORDS OF DATA  
:\*PERFORM THE FUNCTION, VERIFY THE RESULTS  
BADHEAD  
:\*\*\*\*\* TEST 76 \*\*\*\*\*

MYINT  
MOV KMCSR,R1 ;GET DEVICE ADDRESS.  
MSTCLR ;MASTER CLEAR M8200,4,7  
JSR R5, .MSTCLR ;CLEAR M8200,4,7  
CLR R5 ;MEM + SP ADDRESS  
MOV #5\$,R2 ;POINTER TO CORRECT DATA  
JSR PC,MEMLD ;LOAD 8 WORDS OF MAIN MEMORY  
MEMDAT ;POINTER TO DATA  
JSR PC,SPLD ;LOAD 8 WORDS OF SP  
SPDAT ;POINTER TO DATA  
BGNSEG  
TRAP C\$BSEG  
JSR PC,SETC ;SET C BIT!  
BIC #17,2\$ ;CLEAR ADDRESS FIELD OF INSTRUCTION  
BIS R5,2\$ ;ADD ADDRESS TO INSTRUCTION  
ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304  
JSR R5, .ROMCLK ;CLOCK INSTRUCTION  
010000 ;LOAD MAR  
BIC #17,3\$ ;CLEAR ADDRESS OF INSTRUCTION  
BIS R5,3\$ ;ADD ADDRESS TO INSTRUCTION  
ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304  
JSR R5, .ROMCLK ;CLOCK INSTRUCTION  
040400!<7\*20> ;BR DEC A  
ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304  
JSR R5, .ROMCLK ;CLOCK INSTRUCTION  
61224 ;MOVE BR TO PORT4  
MOVB (R2), \$GDDAT ;PUT 'EXPECTED' IN \$GDDAT  
MOVB 4(R1), R4 ;PUT 'FOUND IN R4  
CMPB \$GDDAT, R4 ;DATA CORRECT?  
BEQ 4\$ ;BR IF YES  
ERROR 23, YES ;ALU ERROR  
TRAP C\$ERDF  
.WORD 23  
.WORD EM23  
.WORD ERR23  
4\$: ESCAPE SEG  
TRAP C\$ESCAPE  
.WORD 10000\$-.  
INC R2 ;NEXT DATA  
INC R5 ;NEXT ADDRESS  
CMP #10, R5 ;DONE YET?  
BNE 1\$ ;BR IF NO

8092	034616						ENDSEG	
(3)	034616					10000\$:		
(3)	034616	104405					TRAP	C\$ESEG
8093	034620						EXIT	TST
(3)	034620	104432					TRAP	C\$EXIT
(3)	034622	000012					.WORD	L10166-
8094	034624	377	377	376	5\$:		.BYTE	-1,-1,376,376,124,124,251,251
	034627	376	124	124				
	034632	251	251					
8095								
8096							.FVEN	
8097	034634						ENDTST	
(3)	034634						L10166:	
(3)	034634	104401					TRAP	C\$ETST
8098								
8099								

CZDMPCO M8207 STATIC DIAG #1  
CZDMPC.P11 13-JUL-81 15:46

MACY11 30A(1052) 13-JUL-81 16:06 C 16  
HARDWARE TESTS PAGE 59

SEQ 0197

8101  
8102  
8103  
8104  
8105  
8106

.SBTTL HARDWARE PARAMETER CODING SECTION

:/ THE HARDWARE PARAMETER CODING SECTION CONTAINS MACROS  
:/ THAT ARE USED BY THE SUPERVISOR TO BUILD P-TABLES. THE  
:/ MACROS ARE NOT EXECUTED AS MACHINE INSTRUCTIONS BUT ARE  
:/ INTERPRETED BY THE SUPERVISOR AS DATA STRUCTURES. THE  
:/ MACROS ALLOW THE SUPERVISOR TO ESTABLISH COMMUNICATIONS  
:/ WITH THE OPERATOR.

8108  
8109  
8110  
8111  
8112  
8113  
8114  
8115  
8116  
8117  
8118  
8119  
8120  
8121 034636  
(3) 034636 000022  
(3) 034640  
8122  
8123 034640  
(4) 034640 000032  
(4) 034642 034704  
(4) 034644 000007  
(4) 034646 000000  
(4) 034650 000007  
8124 034652  
(4) 034652 001031  
(4) 034654 034763  
(4) 034656 160000  
(4) 034660 177776  
8125 034662  
(4) 034662 002031  
(4) 034664 035022  
(4) 034666 000000  
(4) 034670 000770  
8126 034672  
(4) 034672 003032  
(4) 034674 035064  
(4) 034676 007000  
(4) 034700 000004  
(4) 034702 000007

BGNHRD  
.WORD L10167-L\$HARD/2  
L\$HARD::  
GPRMD WMP,0,0,7,0,7,YES  
.WORD T\$CODE  
.WORD WMP  
.WORD 7  
.WORD T\$LLOLIM  
.WORD T\$HILIM  
GPRMA ADDRES,2,0,160000,177776,YES  
.WORD T\$CODE  
.WORD ADDRES  
.WORD T\$LLOLIM  
.WORD T\$HILIM  
GPRMA VECTOR,4,0,0,770,YES  
.WORD T\$CODE  
.WORD VECTOR  
.WORD T\$LLOLIM  
.WORD T\$HILIM  
GPRMD PRIRTY,6,0,7000,4,7,YES  
.WORD T\$CODE  
.WORD PRIRTY  
.WORD 7000  
.WORD T\$LLOLIM  
.WORD T\$HILIM  
: GPRMD LNUNIT,10,0,3,0,3,YES  
: GPRMD SWPAC1,12,0,377,0,377,YES  
: GPRMD SWPAC2,14,0,377,0,377,YES  
: GPRMD LOOPBK,16,0,40000,0,1,YES

8127  
8128  
8129  
8130  
8131  
8132 034704  
(2)  
(3) 034704  
8133  
8134 034704 044127 041511 020110 WMP: .ASCIZ 'WHICH MICRO-PROCESSOR:'  
034712 044515 051103 026517  
034720 051120 041517 051505  
034726 047523 035122 000  
8135 034733 060 046475 031070 .ASCIZ '0=M8200,4=M8204,7=M8207'  
034740 030060 032054 046475  
034746 031070 032060 033454  
034754 046475 031070 033460

ENDHRD  
.EVEN  
L10167:



8136	034762	000				
	034763	115	041511	047522	ADDRES: .ASCIZ	/MICRO-PROCESSOR CSR ADDRESS : /
	034770	050055	047522	042503		
	034776	051523	051117	041440		
	035004	051123	040440	042104		
	035012	042522	051523	035040		
	035020	000040				
8137	035022	044515	051103	026517	VECTOR: .ASCIZ	/MICRO-PROCESSOR VECTOR ADDRESS : /
	035030	051120	041517	051505		
	035036	047523	020122	042526		
	035044	052103	051117	040440		
	035052	042104	042522	051523		
	035060	035040	000040			
8138	035064	044515	051103	026517	PRIPTY: .ASCIZ	/MICRO-PROCESSOR PRIORITY LEVEL : /
	035072	051120	041517	051505		
	035100	047523	020122	051120		
	035106	047511	044522	054524		
	035114	046040	053105	046105		
	035122	035040	000040			
8139	035126	044127	041511	020110	LNUNIT: .ASCIZ	/WHICH LINE UNIT (0-3)? 0=NONE,1=M8201,2=M8202,3=M8203 : /
	035134	044514	042516	052440		
	035142	044516	020124	030050		
	035150	031455	037451	030040		
	035156	047075	047117	026105		
	035164	036461	034115	030062		
	035172	026061	036462	034115		
	035200	030062	026062	036463		
	035206	034115	030062	020063		
	035214	020072	000			
8140	035217	123	044527	041524	SWPAC1: .ASCIZ	/SWITCH PACK #1 (DDCMP LINE #) : /
	035224	020110	040520	045503		
	035232	021440	020061	042050		
	035240	041504	050115	046040		
	035246	047111	020105	024443		
	035254	035040	000040			
8141	035260	053523	052111	044103	SWPAC2: .ASCIZ	/SWITCH PACK #2 (BM873 BOOT ADR) : /
	035266	050040	041501	020113		
	035274	031043	024040	046502		
	035302	033470	020063	047502		
	035310	052117	040440	051104		
	035316	020051	020072	000		
8142	035323	127	046111	020114	LOOPBK: .ASCIZ	/WILL TEST CONNECTOR(S) BE USED ? 0=NO,1=YES : /
	035330	042524	052123	041440		
	035336	047117	042516	052103		
	035344	051117	051450	020051		
	035352	042502	052440	042523		
	035360	020104	020077	036460		
	035366	047516	030454	054475		
	035374	051505	035040	000040		

8143  
8144  
8145  
8146  
8147  
8148  
8149

.EVEN

CZDMPCO M8207 STATIC DIAG #1  
CZDMP.C.P11 13-JUL-81 15:46

MACY11 30A(1052) 13-JUL-81 16:06 F 16 PAGE 59-3  
HARDWARE PARAMETER CODING SECTION

SEQ 0200

8150

8152  
8153  
8154  
8155  
8156  
8157  
8158  
8159  
8160  
8161  
8162  
8163  
8164 035402  
(3) 035402 000000  
(3) 035404  
8165  
8166  
8167 035404  
(2)  
(3) 035404  
8168  
8169  
8170  
8171  
8172  
8173  
8174  
8175 035404  
8176  
8177  
8178 035404  
8179  
8180 035404 000000  
8181 037776  
8182 037776 000000  
8183 040000  
(2)  
(4) 040000 000000  
(4) 040002 000000  
(3) 040004  
8184 000114  
8185  
8186  
8187  
8188  
8189  
8190  
8191  
8192  
8193  
8194  
8195  
8196  
8197  
8198 000001

```
.SBTTL SOFTWARE PARAMETER CODING SECTION

://////
:/ THE SOFTWARE PARAMETER CODING SECTION CONTAINS MACROS
:/ THAT ARE USED BY THE SUPERVISOR TO BUILD P-TABLES. THE
:/ MACROS ARE NOT EXECUTED AS MACHINE INSTRUCTIONS BUT ARE
:/ INTERPRETED BY THE SUPERVISOR AS DATA STRUCTURES. THE
:/ MACROS ALLOW THE SUPERVISOR TO ESTABLISH COMMUNICATIONS
:/ WITH THE OPERATOR.
://////

          BGNSFT
          .WORD L10170-L$SOFT/2
L$SOFT::

          ENDSFT
          .EVEN
L10170:

          .EVEN

          ENDMOD

CORMAX:

          .WORD 0 ;START OF NPR AREA (TEST 55)
          .=37776
MEMEND: .WORD 0 ;END OF NPR AREA
          LASTAD
          .EVEN
          .WORD 0
          .WORD 0
L$LAST::
          LTN.ED=T$TESTNUM

          ; W A R N I N G < < < <

          ;AREA BETWEEN CORMAX AND MEMEND USED BY TESTS IN DIAGNOSTIC.
          ; NO PATCHS OR DATA MY BE STORED IN THIS AREA.
          ;A SMALL PATCH AREA IS PROVIDED NEAR AREA 'DEBUG' FOR YOUR USE.
          ;ALSO THE AREA ABOVE ADDRESS 077776 MAY BE USED.
          ;
          ;ANYONE FOOLISH ENOUGH TO IGNOR THIS WARNING WILL BE DESTROYED!
          ;

.END
```



C\$DRPT= 000024	3706#													
C\$DU = 000053	3706#	4703												
C\$EDIT= 000003	3706#	3747												
C\$ERDF= 000055	3706#	4282	4751	4768	4801	4815	4841	4847	4876	4884	4905	4913	4933	
	4941	4963	4969	4999	5013	5039	5054	5079	5093	5119	5128	5156	5184	
	5203	5233	5252	5282	5301	5331	5350	5384	5408	5443	5469	5500	5519	
	5549	5568	5598	5617	5647	5666	5696	5715	5745	5764	5794	5813	5843	
	5862	5900	5918	5949	5969	6008	6033	6077	6098	6126	6128	6151	6153	
	6190	6223	6227	6261	6295	6328	6381	6422	6459	6469	6502	6538	6589	
	6630	6676	6722	6768	6814	6860	6906	6952	6998	7046	7094	7142	7189	
	7236	7283	7331	7378	7427	7474	7521	7568	7615	7662	7709	7756	7803	
	7851	7898	7945	7992	8039	8086								
C\$ERHR= 000056	3706#													
C\$ERRO= 000060	3706#													
C\$ERSF= 000054	3706#													
C\$ERSO= 000057	3706#													
C\$ESCA= 000010	3706#	4744	4755	4802	4816	4842	4848	4877	4885	4906	4934	4964	4970	
	5000	5014	5040	5055	5080	5094	5120	5129	5158	5185	5204	5234	5253	
	5283	5302	5332	5351	5385	5409	5445	5470	5501	5520	5550	5569	5599	
	5618	5648	5667	5697	5716	5746	5765	5795	5814	5844	5863	5901	5919	
	5950	5970	6009	6034	6078	6099	6262	6296	6329	6539	6590	6631	6677	
	6723	6769	6815	6861	6907	6953	6999	7047	7095	7143	7190	7237	7284	
	7332	7379	7428	7475	7522	7569	7616	7663	7710	7757	7804	7852	7899	
	7946	7993	8040	8087										
C\$ESEG= 000005	3706#	4807	4821	4851	4878	4886	4907	4914	4935	4942	4973	5004	5019	
	5044	5060	5087	5099	5121	5130	5189	5209	5238	5258	5287	5307	5336	
	5356	5390	5415	5450	5476	5505	5525	5554	5574	5603	5623	5652	5672	
	5701	5721	5750	5770	5799	5819	5848	5868	5906	5925	5954	5977	6013	
	6039	6083	6104	6591	6636	6682	6728	6774	6820	6866	6912	6958	7004	
	7052	7100	7148	7195	7242	7289	7337	7384	7433	7480	7527	7574	7621	
	7668	7715	7762	7809	7857	7904	7951	7998	8045	8092				
C\$ESUB= 000003	3706#	6044												
C\$ETST= 000001	3706#	4756	4770	4822	4852	4888	4916	4944	4974	5020	5061	5100	5131	
	5160	5210	5259	5308	5357	5416	5477	5526	5575	5624	5673	5722	5771	
	5820	5869	5926	5978	6045	6105	6131	6156	6193	6231	6266	6300	6333	
	6383	6427	6472	6504	6557	6592	6641	6687	6733	6779	6825	6871	6917	
	6963	7010	7057	7106	7153	7200	7247	7294	7342	7389	7438	7485	7532	
	7579	7626	7673	7720	7767	7814	7862	7909	7956	8003	8050	8097		
C\$EXIT= 000032	3706#	6263	6297	6330	6553	6637	6683	6729	6775	6821	6867	6913	6959	
	7005	7053	7101	7149	7196	7243	7290	7338	7385	7434	7481	7528	7575	
	7622	7669	7716	7763	7810	7858	7905	7952	7999	8046	8093			
C\$GETB= 000026	3706#													
C\$GETW= 000027	3706#													
C\$GMAN= 000043	3706#													
C\$GPHR= 000042	3706#	4574												
C\$GPLO= 000030	3706#													
C\$GPRI= 000040	3706#													
C\$INIT= 000011	3706#	4652												
C\$INLP= 000020	3706#													
C\$MANI= 000050	3706#													
C\$MEM = 000031	3706#													
C\$MSG = 000023	3706#	4455	4456	4457	4458	4459	4460	4461	4462	4463	4464	4465	4467	
	4469	4470	4471	4472	4473	4474	4475	4476	4477	4478	4479	4480	4481	
	4482	4483	4484	4485	4486	4487	4488	4493						
C\$OPEN= 000034	3706#													
C\$PNTB= 000014	3706#	4455	4456	4457	4458	4459	4460	4461	4462	4463	4464	4465	4467	



CZDMPCO M8207 STATIC DIAG #1  
CZDMPC.P11 13-JUL-81 15:46

MACY11 30A(1052) 13-JUL-81 16:06 PAGE 60-3  
CROSS REFERENCE TABLE -- USER SYMBOLS

SEQ 0205

EM31	005312	4381#	6126	6151	6223														
EM32	005341	4382#	6128	6153	6227														
EM33	005400	4383#	6190																
EM34	005435	4384#	6589																
EM35	005064	4374#																	
EM36	005640	4282	4391#																
EM37	005715	4392#	4751																
EM4	004444	4359#	6008	6033	6077														
EM5	004472	4361#	6098																
EM6	004533	4363#																	
EM7	004561	4364#																	
ENDBUG	003244	4115#																	
ENDIT	011254	4558	4642	4646	4649	4651#													
ERRFLG	002560	3905#																	
ERR1	006054 G	4455#																	
ERR10	006576 G	4462#																	
ERR11	006660 G	4463#	6261	6295	6328	6381	6422	6538											
ERR12	006736 G	4464#																	
ERR13	007014 G	4465#	6459	6469	6502														
ERR14	007042 G	4467#																	
ERR15	007120 G	4469#	6630	6676	6722	6768	6814	6860	6906	6952	6998	7046	7094	7142					
		7189	7236	7283	7331	7474													
ERR16	007176 G	4470#																	
ERR17	007224 G	4471#																	
ERR2	006132 G	4456#	4815	4847	5079	5093													
ERR20	007252 G	4472#																	
ERR21	007330 G	4473#																	
ERR22	007356 G	4474#																	
ERR23	007404 G	4475#	7378	7427	7521	7568	7615	7662	7709	7756	7803	7851	7898	7945					
		7992	8039	8086															
ERR24	007462 G	4476#																	
ERR25	007510 G	4477#																	
ERR26	007566 G	4478#	4768	4801	4876	4884	4905	4913	4933	4941	5119	5128							
ERR27	007644 G	4479#	4841	4963	4969	4999	5013	5039	5054	5184	5203	5233	5252	5282					
		5301	5331	5350	5384	5408	5443	5469											
ERR28	007726 G	4480#	5156																
ERR29	010004 G	4481#	5500	5519	5549	5568	5598	5617	5647	5666	5696	5715	5745	5764					
		5794	5813	5843	5862	5900													
ERR3	006210 G	4457#	5949	5969															
ERR30	010066 G	4482#	5918																
ERR31	010144 G	4483#	6126	6151	6223														
ERR32	010172 G	4484#	6128	6153	6227														
ERR33	010220 G	4485#	6190																
ERR34	010276 G	4486#	6589																
ERR35	010354 G	4487#																	
ERR36	010432 G	4282	4488#																
ERR37	010510 G	4490#	4751																
ERR4	006266 G	4458#	6008	6033	6077														
ERR5	006350 G	4459#	6098																
ERR6	006432 G	4460#																	
ERR7	006514 G	4461#																	
EVL =	000004 G	3852#																	
E\$END =	002100	3706#																	
E\$LOAD=	000035	3706#	3747																
FLAG	002620	3922#																	
FM1	004114	4343#	4455	4456	4457	4458	4459	4460	4461	4462	4463	4464	4465	4467					

CZDMPCO M8207 STATIC DIAG #1  
CZDMPC.P11 13-JUL-81 15:46

MACY11 30A(1052) 13-JUL-81 16:06 PAGE 60-4  
CROSS REFERENCE TABLE -- USER SYMBOLS

SEQ 0206

FTIME 002646  
F\$AU = 000015  
F\$AUTO= 000020  
F\$BGN = 000040

4469	4470	4471	4472	4473	4474	4475	4476	4477	4478	4479	4480	4481
4482	4483	4484	4485	4486	4487	4488	4491					
3933#	4543	4547*										
3706#	4718	4719										
3706#	4655	4673										
3706#	3712	3756	4455	4456	4457	4458	4459	4460	4461	4462	4463	4464
4465	4467	4469	4470	4471	4472	4473	4474	4475	4476	4477	4478	4479
4480	4481	4482	4483	4484	4485	4486	4487	4488	4490	4506	4514	4537
4655	4683	4700	4718	4737	4744	4755	4756	4762	4770	4790	4795	4802
4810	4816	4822	4830	4834	4842	4848	4852	4867	4869	4877	4879	4885
4888	4896	4898	4906	4908	4916	4924	4926	4934	4936	4944	4951	4955
4964	4970	4974	4988	4993	5000	5006	5014	5020	5028	5033	5040	5046
5055	5061	5069	5073	5080	5088	5094	5100	5108	5112	5120	5123	5129
5131	5144	5158	5160	5168	5174	5185	5192	5204	5210	5218	5223	5234
5241	5253	5259	5267	5272	5283	5290	5302	5308	5316	5321	5332	5339
5351	5357	5365	5370	5385	5393	5409	5416	5424	5429	5445	5453	5470
5477	5485	5490	5501	5508	5520	5526	5534	5539	5550	5557	5569	5575
5583	5588	5599	5606	5618	5624	5632	5637	5648	5655	5667	5673	5681
5686	5697	5704	5716	5722	5730	5735	5746	5753	5765	5771	5779	5784
5795	5802	5814	5820	5828	5833	5844	5851	5863	5869	5877	5882	5901
5909	5919	5926	5934	5939	5950	5957	5970	5978	5986	5991	5992	6009
6015	6034	6044	6045	6053	6058	6078	6086	6099	6105	6112	6131	6138
6156	6164	6193	6201	6231	6238	6262	6263	6266	6273	6296	6297	6300
6307	6329	6330	6333	6341	6383	6395	6427	6436	6472	6480	6504	6512
6539	6553	6557	6568	6575	6590	6592	6605	6614	6631	6637	6641	6651
6660	6677	6683	6687	6697	6706	6723	6729	6733	6743	6752	6769	6775
6779	6789	6798	6815	6821	6825	6835	6844	6861	6867	6871	6881	6890
6907	6913	6917	6927	6936	6953	6959	6963	6973	6982	6999	7005	7010
7021	7030	7047	7053	7057	7068	7078	7095	7101	7106	7117	7126	7143
7149	7153	7164	7173	7190	7196	7200	7211	7220	7237	7243	7247	7258
7267	7284	7290	7294	7306	7315	7332	7338	7342	7353	7362	7379	7385
7389	7402	7411	7428	7434	7438	7449	7458	7475	7481	7485	7496	7505
7522	7528	7532	7543	7552	7569	7575	7579	7590	7599	7616	7622	7626
7637	7646	7663	7669	7673	7684	7693	7710	7716	7720	7731	7740	7757
7763	7767	7778	7787	7804	7810	7814	7826	7835	7852	7858	7862	7873
7882	7899	7905	7909	7920	7929	7946	7952	7956	7967	7976	7993	7999
8003	8013	8023	8040	8046	8050	8061	8070	8087	8093	8097	8121	8164
8175												
3706#	4683	4686										
3706#	4700	4703										
3706#	3712	4455	4456	4457	4458	4459	4460	4461	4462	4463	4464	4465
4467	4469	4470	4471	4472	4473	4474	4475	4476	4477	4478	4479	4480
4481	4482	4483	4484	4485	4486	4487	4488	4493	4514	4523	4652	4673
4686	4703	4719	4737	4744	4755	4756	4762	4770	4790	4802	4807	4816
4821	4822	4830	4842	4848	4851	4852	4867	4877	4878	4885	4886	4888
4896	4906	4907	4914	4916	4924	4934	4935	4942	4944	4951	4964	4970
4973	4974	4988	5000	5004	5014	5019	5020	5028	5040	5044	5055	5060
5061	5069	5080	5087	5094	5099	5100	5108	5120	5121	5129	5130	5131
5144	5158	5160	5168	5185	5189	5204	5209	5210	5218	5234	5238	5253
5258	5259	5267	5283	5287	5302	5307	5308	5316	5332	5336	5351	5356
5357	5365	5385	5390	5409	5415	5416	5424	5445	5450	5470	5476	5477
5485	5501	5505	5520	5525	5526	5534	5550	5554	5569	5574	5575	5583
5599	5603	5618	5623	5624	5632	5648	5652	5667	5672	5673	5681	5697
5701	5716	5721	5722	5730	5746	5750	5765	5770	5771	5779	5795	5799
5814	5819	5820	5828	5844	5848	5863	5868	5869	5877	5901	5906	5919
5925	5926	5934	5950	5954	5970	5977	5978	5986	5991	6009	6013	6034

F\$CLEA= 000007  
F\$DU = 000016  
F\$END = 000041



	6039	6044	6045	6053	6078	6083	6099	6104	6105	6112	6131	6138	6156
	6164	6193	6201	6231	6238	6262	6263	6266	6273	6296	6297	6300	6307
	6329	6330	6333	6341	6383	6395	6427	6436	6472	6480	6504	6512	6539
	6553	6557	6568	6590	6591	6592	6605	6631	6636	6637	6641	6651	6677
	6682	6683	6687	6697	6723	6728	6729	6733	6743	6769	6774	6775	6779
	6789	6815	6820	6821	6825	6835	6861	6866	6867	6871	6881	6907	6912
	6913	6917	6927	6953	6958	6959	6963	6973	6999	7004	7005	7010	7021
	7047	7052	7053	7057	7068	7095	7100	7101	7106	7117	7143	7148	7149
	7153	7164	7190	7195	7196	7200	7211	7237	7242	7243	7247	7258	7284
	7289	7290	7294	7306	7332	7337	7338	7342	7353	7379	7384	7385	7389
	7402	7428	7433	7434	7438	7449	7475	7480	7481	7485	7496	7522	7527
	7528	7532	7543	7569	7574	7575	7579	7590	7616	7621	7622	7626	7637
	7663	7668	7669	7673	7684	7710	7715	7716	7720	7731	7757	7762	7763
	7767	7778	7804	7809	7810	7814	7826	7852	7857	7858	7862	7873	7899
	7904	7905	7909	7920	7946	7951	7952	7956	7967	7993	7998	7999	8003
	8013	8040	8045	8046	8050	8061	8087	8092	8093	8097	8132	8167	8175
F\$HARD= 000004	3706#	8121	8132										
F\$HW = 000013	3706#	3793	3808										
F\$INIT= 000006	3706#	4537	4652										
F\$JMP = 000050	3706#	4514	6263	6297	6330	6553	6637	6683	6729	6775	6821	6867	6913
		6959	7005	7053	7101	7149	7196	7243	7290	7338	7385	7434	7481
		7575	7622	7669	7716	7763	7810	7858	7905	7952	7999	8046	8093
F\$MOD = 000000	3706#	3712	8175										
F\$MESS = 000011	3706#	4455	4456	4457	4458	4459	4460	4461	4462	4463	4464	4465	4467
		4469	4470	4471	4472	4473	4474	4475	4476	4477	4478	4479	4481
		4482	4483	4484	4485	4486	4487	4488	4490	4493			
F\$PROT= 000021	3706#	3756	3760										
F\$PWR = 000017	3706#												
F\$RPT = 000012	3706#	4506	4523										
F\$SEG = 000003	3706#	4795	4807	4810	4821	4834	4851	4869	4878	4879	4886	4898	4907
		4908	4914	4926	4935	4936	4942	4955	4973	4993	5004	5006	5019
		5044	5046	5060	5073	5087	5088	5099	5112	5121	5123	5130	5174
		5192	5209	5223	5238	5241	5258	5272	5287	5290	5307	5321	5336
		5356	5370	5390	5393	5415	5429	5450	5453	5476	5490	5505	5508
		5539	5554	5557	5574	5588	5603	5606	5623	5637	5652	5655	5672
		5701	5704	5721	5735	5750	5753	5770	5784	5799	5802	5819	5833
		5851	5868	5882	5906	5909	5925	5939	5954	5957	5977	5992	6013
		6039	6058	6083	6086	6104	6575	6591	6614	6636	6660	6682	6706
		6752	6774	6798	6820	6844	6866	6890	6912	6936	6958	6982	7004
		7052	7078	7100	7126	7148	7173	7195	7220	7242	7267	7289	7315
		7362	7384	7411	7433	7458	7480	7505	7527	7552	7574	7599	7621
		7668	7693	7715	7740	7762	7787	7809	7835	7857	7882	7904	7929
		7976	7998	8023	8045	8070	8092						7951
F\$SOFT= 000005	3706#	8164	8167										
F\$SRV = 000010	3706#												
F\$SUB = 000002	3706#	5991	6044										
F\$SW = 000014	3706#	3822	3825										
F\$TEST= 000001	3706#	4737	4756	4762	4770	4790	4822	4830	4852	4867	4888	4896	4916
		4924	4944	4951	4974	4988	5020	5028	5061	5069	5100	5108	5131
		5160	5168	5210	5218	5259	5267	5308	5316	5357	5365	5416	5424
		5485	5526	5534	5575	5583	5624	5632	5673	5681	5722	5730	5771
		5820	5828	5869	5877	5926	5934	5978	5986	6045	6053	6105	6112
		6138	6156	6164	6193	6201	6231	6238	6266	6273	6300	6307	6333
		6383	6395	6427	6436	6472	6480	6504	6512	6557	6568	6592	6605
		6651	6687	6697	6733	6743	6779	6789	6825	6835	6871	6881	6917
		6963	6973	7010	7021	7057	7068	7106	7117	7153	7164	7200	7211

	7258	7294	7306	7342	7353	7389	7402	7438	7449	7485	7496	7532	7543
	7579	7590	7626	7637	7673	7684	7720	7731	7767	7778	7814	7826	7862
	7873	7909	7920	7956	7967	8003	8013	8050	8061	8097			
GETPRM 010712	4562	4570#	4575										
G\$CNT0= 000200	3706#												
G\$DELM= 000372	3706#												
G\$DISP= 000003	3706#												
G\$EXCP= 000400	3706#												
G\$HILI= 000002	3706#												
G\$LOLI= 000001	3706#												
G\$NO = 000000	3706#												
G\$OFFS= 000400	3706#	8123	8124	8125	8126								
G\$OF SI= 000376	3706#	8123	8124	8125	8126								
G\$PRMA= 000001	3706#	8124	8125										
G\$PRMD= 000002	3706#	8123	8126										
G\$PRML= 000000	3706#												
G\$RADA= 000140	3706#												
G\$RADB= 000000	3706#												
G\$RADD= 000040	3706#												
G\$RADL= 000120	3706#												
G\$RADO= 000020	3706#	8123	8124	8125	8126								
G\$XFER= 000004	3706#												
G\$YES = 000010	3706#	8123	8124	8125	8126								
HELP = 000000	3693#	3739	3750	3773	4022	4508	4516						
HOE = 100000 G	3852#												
IBE = 010000 G	3852#												
IDU = 000040 G	3852#												
IER = 020000 G	3852#												
INIFLG 002674	3947#												
INSTU 003536	4207	4217#											
ISR = 000100 G	3852#												
IXE = 004000 G	3852#												
I\$AU = 000041	3706#	4718#	4719#										
I\$AUTO= 000041	3706#	4655#	4673#										
I\$CLN = 000041	3706#	4683#	4686#										
I\$DU = 000041	3706#	4700#	4703#										
I\$HRD = 000041	8121#	8132#											
I\$INIT= 000041	3706#	4537#	4652#										
I\$MOD = 000041	3706#	3712#	8175#										
I\$MSG = 000041	3706#	4455#	4456#	4457#	4458#	4459#	4460#	4461#	4462#	4463#	4464#	4465#	4467#
	4469#	4470#	4471#	4472#	4473#	4474#	4475#	4476#	4477#	4478#	4479#	4480#	4481#
	4482#	4483#	4484#	4485#	4486#	4487#	4488#	4490#	4493#				
	3706#	3756#											
I\$PROT= 000040	3706#												
I\$PTAB= 000041	3706#												
I\$PWR = 000041	3706#												
I\$RPT = 000041	3706#	4506#	4523#										
I\$SEG = 000041	3706#	4737	4762	4790	4795#	4802	4807#	4810#	4816	4821#	4830	4834#	4842
	4848	4851#	4867	4869#	4877	4878#	4879#	4885	4886#	4896	4898#	4906	4907#
	4908#	4914#	4924	4926#	4934	4935#	4936#	4942#	4951	4955#	4964	4970	4973#
	4988	4993#	5000	5004#	5006#	5014	5019#	5028	5033#	5040	5044#	5046#	5055
	5060#	5069	5073#	5080	5087#	5088#	5094	5099#	5108	5112#	5120	5121#	5123#
	5129	5130#	5144	5168	5174#	5185	5189#	5192#	5204	5209#	5218	5223#	5234
	5238#	5241#	5253	5258#	5267	5272#	5283	5287#	5290#	5302	5307#	5316	5321#
	5332	5336#	5339#	5351	5356#	5365	5370#	5385	5390#	5393#	5409	5415#	5424
	5429#	5445	5450#	5453#	5470	5476#	5485	5490#	5501	5505#	5508#	5520	5525#
	5534	5539#	5550	5554#	5557#	5569	5574#	5583	5588#	5599	5603#	5606#	5618



CZDMPCO M8207 STATIC DIAG #1  
CZDMPC.P11 13-JUL-81 15:46

MACY11 30A(1052) 13-JUL-81 16:06 PAGE 60-8  
CROSS REFERENCE TABLE -- USER SYMBOLS

SEQ 0210

KMRVEC	002706	3979#	4227*	4592*				
KMTLVL	002714	3982#	4230*	4600*	4601*			
KMTVEC	002712	3981#	4228*	4597*	4598*			
LNUNIT	035126	8139#						
LOCK	002442	3888#						
LOE =	040000 G	3852#						
LOGDEV	002552	3902#	4565*	4571*	4572	4574	4669	
LOKFLG	002676	3949#						
LOOPBK	035323	8142#						
LOT =	000010 G	3852#						
LTN.ED=	000114	8184#						
L\$ACP	002110 G	3747#						
L\$APT	002036 G	3747#						
L\$AU	011364 G	3747	4718#					
L\$AUT	002070 G	3747#						
L\$AUTO	011256 G	3747	4655#					
L\$CCP	002106 G	3747#						
L\$CLEA	011354 G	3747	4683#					
L\$CO	002032 G	3747#						
L\$DEPO	002011 G	3747#						
L\$DESC	002414 G	3747	3882#					
L\$DESP	002076 G	3747#						
L\$DEVP	002060 G	3747#						
L\$DISP	002132 G	3747	3770#					
L\$DLY	002116 G	3747#						
L\$DTP	002040 G	3747#						
L\$DTYP	002034 G	3747#						
L\$DU	011360 G	3747	4700#					
L\$DUT	002072 G	3747#						
L\$DVTY	003130 G	3747	4015#					
L\$EF	002052 G	3747#						
L\$ENVI	002044 G	3747#						
L\$ETP	002102 G	3747#						
L\$EXP1	002046 G	3747#						
L\$EXP4	002064 G	3747#						
L\$EXP5	002066 G	3747#						
L\$HARD	034640 G	3747	8121#					
L\$HIME	002120 G	3747#						
L\$HPCP	002016 G	3747#						
L\$HPTP	002022 G	3747#						
L\$HW	002364 G	3747	3793#					
L\$ICP	002104 G	3747#						
L\$INIT	010570 G	3747	4537#					
L\$LADP	002026 G	3747#						
L\$LAST	040004 G	3747	8183#					
L\$LOAD	002100 G	3747#						
L\$LUN	002074 G	3747#						
L\$MREV	002050 G	3747#						
L\$NAME	002000 G	3747#						
L\$PRIO	002042 G	3747#						
L\$PROT	002122 G	3747	3756#					
L\$PRT	002112 G	3747#						
L\$REPP	002062 G	3747#						
L\$REV	002010 G	3747#						
L\$RPT	010562 G	4506#						
L\$SOFT	035404 G	8164#						

CZDMPCO M8207 STATIC DIAG #1  
CZDMPC.P11 13-JUL-81 15:46

MACY11 30A(1052) 13-JUL-81 16:06 PAGE 60-9  
CROSS REFERENCE TABLE -- USER SYMBOLS

SEQ 0211

L\$SPC	002056	G	3747#		
L\$SPCP	002020	G	3747#		
L\$SPTP	002024	G	3747#		
L\$STA	002030	G	3747#		
L\$SW	002414	G	3822#		
L\$TEST	002114	G	3747#		
L\$TIML	002014	G	3747#		
L\$UNIT	002012	G	3747#	4572	
L10001	002412		3793	3808#	
L10002	002414		3822	3825#	
L10003	006130		4455#		
L10004	006206		4456#		
L10005	006264		4457#		
L10006	006346		4458#		
L10007	006430		4459#		
L10010	006512		4460#		
L10011	006574		4461#		
L10012	006656		4462#		
L10013	006734		4463#		
L10014	007012		4464#		
L10015	007040		4465#		
L10016	007116		4467#		
L10017	007174		4469#		
L10020	007222		4470#		
L10021	007250		4471#		
L10022	007326		4472#		
L10023	007354		4473#		
L10024	007402		4474#		
L10025	007460		4475#		
L10026	007506		4476#		
L10027	007564		4477#		
L10030	007642		4478#		
L10031	007724		4479#		
L10032	010002		4480#		
L10033	010064		4481#		
L10034	010142		4482#		
L10035	010170		4483#		
L10036	010216		4484#		
L10037	010274		4485#		
L10040	010352		4486#		
L10041	010430		4487#		
L10042	010506		4488#		
L10043	010560		4493#		
L10044	010566		4514	4523#	
L10045	011254		4652#		
L10046	011352		4673#		
L10047	011356		4686#		
L10050	011362		4703#		
L10051	011364		4719#		
L10052	011512		4744	4755	4756#
L10053	011556		4770#		
L10054	011744		4822#		
L10055	012110		4852#		
L10056	012244		4888#		
L10057	012374		4916#		
L10060	012524		4944#		

CZDMPCO M8207 STATIC DIAG #1  
CZDMPC.P11 13-JUL-81 15:46

MACY11 30A(1052) 13-JUL-81 16:06 PAGE 60-10  
CROSS REFERENCE TABLE -- USER SYMBOLS

G 1

SEQ 0212

L10061	012666	4974#		
L10062	013052	5020#		
L10063	013236	5061#		
L10064	013424	5100#		
L10065	013574	5131#		
L10066	013702	5158	5160#	
L10067	014132	5210#		
L10070	014362	5259#		
L10071	014612	5308#		
L10072	015042	5357#		
L10073	015336	5416#		
L10074	015632	5477#		
L10075	016062	5526#		
L10076	016312	5575#		
L10077	016542	5624#		
L10100	016772	5673#		
L10101	017222	5722#		
L10102	017452	5771#		
L10103	017702	5820#		
L10104	020132	5869#		
L10105	020430	5926#		
L10106	020660	5978#		
L10107	021224	6034	6045#	
L10110	021222	6044#		
L10111	021536	6105#		
L10112	021700	6131#		
L10113	022042	6156#		
L10114	022216	6193#		
L10115	022422	6231#		
L10116	022566	6262	6263	6266#
L10117	022736	6296	6297	6300#
L10120	023102	6329	6330	6333#
L10121	023270	6383#		
L10122	023504	6427#		
L10123	023722	6472#		
L10124	024054	6504#		
L10125	024272	6539	6553	6557#
L10126	024422	6592#		
L10127	024636	6637	6641#	
L10130	025042	6683	6687#	
L10131	025246	6729	6733#	
L10132	025452	6775	6779#	
L10133	025656	6821	6825#	
L10134	026062	6867	6871#	
L10135	026266	6913	6917#	
L10136	026472	6959	6963#	
L10137	026700	7005	7010#	
L10140	027104	7053	7057#	
L10141	027310	7101	7106#	
L10142	027514	7149	7153#	
L10143	027720	7196	7200#	
L10144	030124	7243	7247#	
L10145	030330	7290	7294#	
L10146	030534	7338	7342#	
L10147	030740	7385	7389#	
L10150	031144	7434	7438#	



PRI02 = 000100 G	3852#													
PRI03 = 000140 G	3852#													
PRI04 = 000200 G	3852#													
PRI05 = 000240 G	3852#													
PRI06 = 000300 G	3852#													
PRI07 = 000340 G	3852#	6120	6145											
PSTACK 002554	3903#	4542*												
QV.FLG 002677	3950#													
RAMDAT 003370	4172#													
REGADR 002730	3991#													
RETADR 002562	3906#													
RUN 002622	3923#													
SAVACT 002614	3920#													
SAVE4 002650	3934#	4545*	4548	4671	4753	6426								
SAVE6 002652	3935#	4546*	4549	4672	4754	6425								
SAVNUM 002616	3921#													
SAVPC 002576	3912#													
SAVSP 002574	3911#													
SETBRO 003320	4137#													
SETBR1 003330	4143#													
SETBR4 003340	4150#													
SETBR7 003350	4157#													
SETC 004076	4320#	7363	7412	7459	7506	7553	7600	7647	7694	7741	7788	7836	7883	
	7930	7977	8024	8071										
SETVEC 003552	4224#	6116	6141	6176	6214									
SETZ 003360	4165#													
SFPTBL 002414 G	3822#													
SPDAT 002664	3941#	6613	6659	6705	6751	6797	6843	6889	6935	6981	7029	7077	7125	
	7172	7219	7266	7314	7361	7410	7457	7504	7551	7598	7645	7692	7739	
	7786	7834	7881	7928	7975	8022	8069							
SPLD 004012	4292#	6573	6612	6658	6704	6750	6796	6842	6888	6934	6980	7028	7076	
	7124	7171	7218	7265	7313	7360	7409	7456	7503	7550	7597	7644	7691	
	7738	7785	7833	7880	7927	7974	8021	8068						
SSTACK 003130	3995#	4540												
STAT 002566	3908#													
STAT1 002700	3972#	4603*	4605*	4609*	4620*	4624*	4627*	6169	6206					
STAT2 002702	3973#	4630*	4632*											
STAT3 002704	3974#													
STOP 023302	6398#													
STRTSW 002564	3907#													
SUBRPC 002556	3904#													
SVCGBL= 000000	3706#	3712	3720#	3747	3756	3770	3793	3822	3882	4015	4455	4456	4457	
	4458	4459	4460	4461	4462	4463	4464	4465	4467	4469	4470	4471	4472	
	4473	4474	4475	4476	4477	4478	4479	4480	4481	4482	4483	4484	4485	
	4486	4487	4488	4490	4506	4537	4655	4683	4700	4718	8121	8164	8183#	
SVCINS= 000000	3706#	3717#	3747	3770	3793	3822	3882	4015	4282	4455	4456	4457	4458	
	4459	4460	4461	4462	4463	4464	4465	4467	4469	4470	4471	4472	4473	
	4474	4475	4476	4477	4478	4479	4480	4481	4482	4483	4484	4485	4486	
	4487	4488	4491	4492	4493	4514	4523	4551	4552	4554	4555	4557	4558	
	4561	4562	4574	4575	4652	4669	4673	4684	4686	4702	4703	4719	4744	
	4751	4755	4756	4768	4770	4795	4801	4802	4807	4810	4815	4816	4821	
	4822	4834	4841	4842	4847	4848	4851	4852	4869	4876	4877	4878	4879	
	4884	4885	4886	4888	4898	4905	4906	4907	4908	4913	4914	4916	4926	
	4933	4934	4935	4936	4941	4942	4944	4955	4963	4964	4969	4970	4973	
	4974	4993	4999	5000	5004	5006	5013	5014	5019	5020	5033	5039	5040	
	5044	5046	5054	5055	5060	5061	5073	5079	5080	5087	5088	5093	5094	



5099	5100	5112	5119	5120	5121	5123	5128	5129	5130	5131	5156	5158
5160	5174	5184	5185	5139	5192	5203	5204	5209	5210	5223	5233	5234
5238	5241	5252	5253	5258	5259	5272	5282	5283	5287	5290	5301	5302
5307	5308	5321	5331	5332	5336	5339	5350	5351	5356	5357	5370	5384
5385	5390	5393	5408	5409	5415	5416	5429	5443	5445	5450	5453	5469
5470	5476	5477	5490	5500	5501	5505	5508	5519	5520	5525	5526	5539
5549	5550	5554	5557	5568	5569	5574	5575	5588	5598	5599	5603	5606
5617	5618	5623	5624	5637	5647	5648	5652	5655	5666	5667	5672	5673
5686	5696	5697	5701	5704	5715	5716	5721	5722	5735	5745	5746	5750
5753	5764	5765	5770	5771	5784	5794	5795	5799	5802	5813	5814	5819
5820	5833	5843	5844	5848	5851	5862	5863	5868	5869	5882	5900	5901
5906	5909	5918	5919	5925	5926	5939	5949	5950	5954	5957	5969	5970
5977	5978	5991	5992	6008	6009	6013	6015	6033	6034	6039	6044	6045
6058	6077	6078	6083	6086	6098	6099	6104	6105	6114	6120	6124	6126
6128	6131	6145	6149	6151	6153	6156	6168	6183	6189	6190	6193	6205
6221	6223	6227	6231	6239	6261	6262	6263	6266	6295	6296	6297	6300
6328	6329	6330	6333	6381	6383	6422	6427	6459	6469	6472	6502	6504
6538	6539	6553	6557	6575	6589	6590	6591	6592	6614	6630	6631	6636
6637	6641	6660	6676	6677	6682	6683	6687	6706	6722	6723	6728	6729
6733	6752	6768	6769	6774	6775	6779	6798	6814	6815	6820	6821	6825
6844	6860	6861	6866	6867	6871	6890	6906	6907	6912	6913	6917	6936
6952	6953	6958	6959	6963	6982	6998	6999	7004	7005	7010	7030	7046
7047	7052	7053	7057	7078	7094	7095	7100	7101	7106	7126	7142	7143
7148	7149	7153	7173	7189	7190	7195	7196	7200	7220	7236	7237	7242
7243	7247	7267	7283	7284	7289	7290	7294	7315	7331	7332	7337	7338
7342	7362	7378	7379	7384	7385	7389	7411	7427	7428	7433	7434	7438
7458	7474	7475	7480	7481	7485	7505	7521	7522	7527	7528	7532	7552
7568	7569	7574	7575	7579	7599	7615	7616	7621	7622	7626	7646	7662
7663	7668	7669	7673	7693	7709	7710	7715	7716	7720	7740	7756	7757
7762	7763	7767	7787	7803	7804	7809	7810	7814	7835	7851	7852	7857
7858	7862	7882	7898	7899	7904	7905	7909	7929	7945	7946	7951	7952
7956	7976	7992	7993	7998	7999	8003	8023	8039	8040	8045	8046	8050
8070	8086	8087	8092	8093	8097	8121	8123	8124	8125	8126	8132	8164
8167	8183											
3706#	3719#	5991										
3706#	3721#	3808	3825	4455	4456	4457	4458	4459	4460	4461	4462	4463
4464	4465	4467	4469	4470	4471	4472	4473	4474	4475	4476	4477	4478
4479	4480	4481	4482	4483	4484	4485	4486	4487	4488	4493	4523	4652
4673	4686	4703	4719	4756	4770	4807	4821	4822	4851	4852	4878	4886
4888	4907	4914	4916	4935	4942	4944	4973	4974	5004	5019	5020	5044
5060	5061	5087	5099	5100	5121	5130	5131	5160	5189	5209	5210	5238
5258	5259	5287	5307	5308	5336	5356	5357	5390	5415	5416	5450	5476
5477	5505	5525	5526	5554	5574	5575	5603	5623	5624	5652	5672	5673
5701	5721	5722	5750	5770	5771	5799	5819	5820	5848	5868	5869	5906
5925	5926	5954	5977	5978	6013	6039	6044	6045	6083	6104	6105	6131
6156	6193	6231	6266	6300	6333	6383	6427	6472	6504	6557	6591	6592
6636	6641	6682	6687	6728	6733	6774	6779	6820	6825	6866	6871	6912
6917	6958	6963	7004	7010	7052	7057	7100	7106	7148	7153	7195	7200
7242	7247	7289	7294	7337	7342	7384	7389	7433	7438	7480	7485	7527
7532	7574	7579	7621	7626	7668	7673	7715	7720	7762	7767	7809	7814
7857	7862	7904	7909	7951	7956	7998	8003	8045	8050	8092	8097	8132
8167												
3706#	3718#	4737	4762	4790	4830	4867	4896	4924	4951	4988	5028	5069
5108	5144	5168	5218	5267	5316	5365	5424	5485	5534	5583	5632	5681
5730	5779	5828	5877	5934	5986	6053	6112	6138	6164	6201	6238	6273
6307	6341	6395	6436	6480	6512	6568	6605	6651	6697	6743	6789	6835

SVCSUB= 000000  
 SVCTAG= 000000

SVCTST= 000000



T\$GMAN= 000000  
T\$HILI= 000007  
T\$LAST= 000001  
T\$LOLI= 000004  
T\$LSYM= 010000

3706#														
8123#	8124#	8125#	8126#											
3706#	8183#													
8123#	8124#	8125#	8126#											
3706#	3808	3825	4455	4456	4457	4458	4459	4460	4461	4462	4463	4464		
4465	4467	4469	4470	4471	4472	4473	4474	4475	4476	4477	4478	4479		
4480	4481	4482	4483	4484	4485	4486	4487	4488	4493	4523	4652	4673		
4686	4703	4719	4756	4770	4822	4852	4888	4916	4944	4974	5020	5061		
5100	5131	5160	5210	5259	5308	5357	5416	5477	5526	5575	5624	5673		
5722	5771	5820	5869	5926	5978	6044	6045	6105	6131	6156	6193	6231		
6266	6300	6333	6383	6427	6472	6504	6557	6592	6641	6687	6733	6779		
6825	6871	6917	6963	7010	7057	7106	7153	7200	7247	7294	7342	7389		
7438	7485	7532	7579	7626	7673	7720	7767	7814	7862	7909	7956	8003		
8050	8097	8132	8167											

T\$LTNC= 000114  
T\$NEST= 177777

8183#														
3706#	3712#	3756#	3760#	3793#	3808#	3822#	3825#	4455#	4456#	4457#	4458#	4459#		
4460#	4461#	4462#	4463#	4464#	4465#	4467#	4469#	4470#	4471#	4472#	4473#	4474#		
4475#	4476#	4477#	4478#	4479#	4480#	4481#	4482#	4483#	4484#	4485#	4486#	4487#		
4488#	4490#	4493#	4506#	4523#	4537#	4652#	4655#	4673#	4683#	4686#	4700#	4703#		
4718#	4719#	4737#	4756#	4762#	4770#	4790#	4795#	4807#	4810#	4821#	4822#	4830#		
4834#	4851#	4852#	4867#	4869#	4878#	4879#	4886#	4888#	4896#	4898#	4907#	4908#		
4914#	4916#	4924#	4926#	4935#	4936#	4942#	4944#	4951#	4955#	4973#	4974#	4988#		
4993#	5004#	5006#	5019#	5020#	5028#	5033#	5044#	5046#	5060#	5061#	5069#	5073#		
5087#	5088#	5099#	5100#	5108#	5112#	5121#	5123#	5130#	5131#	5144#	5160#	5168#		
5174#	5189#	5192#	5209#	5210#	5218#	5223#	5238#	5241#	5258#	5259#	5272#	5272#		
5287#	5290#	5307#	5308#	5316#	5321#	5336#	5339#	5356#	5357#	5365#	5370#	5390#		
5393#	5415#	5416#	5424#	5429#	5450#	5453#	5476#	5477#	5485#	5490#	5505#	5508#		
5525#	5526#	5534#	5539#	5554#	5557#	5574#	5575#	5583#	5588#	5603#	5606#	5623#		
5624#	5632#	5637#	5652#	5655#	5672#	5673#	5681#	5686#	5701#	5704#	5721#	5722#		
5730#	5735#	5750#	5753#	5770#	5771#	5779#	5784#	5799#	5802#	5819#	5820#	5828#		
5833#	5848#	5851#	5868#	5869#	5877#	5882#	5906#	5909#	5925#	5926#	5934#	5939#		
5954#	5957#	5977#	5978#	5986#	5991#	5992#	6013#	6015#	6039#	6044#	6045#	6053#		
6058#	6083#	6086#	6104#	6105#	6112#	6131#	6138#	6156#	6164#	6193#	6201#	6231#		
6238#	6266#	6273#	6300#	6307#	6333#	6341#	6383#	6395#	6427#	6436#	6472#	6480#		
6504#	6512#	6557#	6568#	6575#	6591#	6592#	6605#	6614#	6636#	6641#	6651#	6660#		
6682#	6687#	6697#	6706#	6728#	6733#	6743#	6752#	6774#	6779#	6789#	6798#	6820#		
6825#	6835#	6844#	6866#	6871#	6881#	6890#	6912#	6917#	6927#	6936#	6958#	6963#		
6973#	6982#	7004#	7010#	7021#	7030#	7052#	7057#	7068#	7078#	7100#	7106#	7117#		
7126#	7148#	7153#	7164#	7173#	7195#	7200#	7211#	7220#	7242#	7247#	7258#	7267#		
7289#	7294#	7306#	7315#	7337#	7342#	7353#	7362#	7384#	7389#	7402#	7411#	7433#		
7438#	7449#	7458#	7480#	7485#	7496#	7505#	7527#	7532#	7543#	7552#	7574#	7579#		
7590#	7599#	7621#	7626#	7637#	7646#	7668#	7673#	7684#	7693#	7715#	7720#	7731#		
7740#	7762#	7767#	7778#	7787#	7809#	7814#	7826#	7835#	7857#	7862#	7873#	7882#		
7904#	7909#	7920#	7929#	7951#	7956#	7967#	7976#	7998#	8003#	8013#	8023#	8045#		
8050#	8061#	8070#	8092#	8097#	8121#	8132#	8164#	8167#	8175#					

T\$NSO = 000000  
T\$NS1 = 000005

3712#	8175													
3756#	3760	3793#	3808	3822#	3825	4455#	4456#	4457#	4458#	4459#	4460#	4461#		
4462#	4463#	4464#	4465#	4467#	4469#	4470#	4471#	4472#	4473#	4474#	4475#	4476#		
4477#	4478#	4479#	4480#	4481#	4482#	4483#	4484#	4485#	4486#	4487#	4488#	4490#		
4493	4506#	4523	4537#	4652	4655#	4673	4683#	4686	4700#	4703	4718#	4719		
4737#	4756	4762#	4770	4790#	4822	4830#	4852	4867#	4888	4896#	4916	4924#		
4944	4951#	4974	4988#	5020	5028#	5061	5069#	5100	5108#	5131	5144#	5160		
5168#	5210	5218#	5259	5267#	5308	5316#	5357	5365#	5416	5424#	5477	5485#		
5526	5534#	5575	5583#	5624	5632#	5673	5681#	5722	5730#	5771	5779#	5820		
5828#	5869	5877#	5926	5934#	5978	5986#	6045	6053#	6105	6112#	6131	6138#		
6156	6164#	6193	6201#	6231	6238#	6266	6273#	6300	6307#	6333	6341#	6383		

T\$NS2 = 000003

T\$NS3 = 000003  
T\$PTNU= 000000  
T\$SAVL= 177777  
T\$SEGL= 177777

T\$SEKO= 010000

6395#	6427	6436#	6472	6480#	6504	6512#	6557	6568#	6592	6605#	6641	6651#
6687	6697#	6733	6743#	6779	6789#	6825	6835#	6871	6881#	6917	6927#	6963
6973#	7010	7021#	7057	7068#	7106	7117#	7153	7164#	7200	7211#	7247	7258#
7294	7306#	7342	7353#	7389	7402#	7438	7449#	7485	7496#	7532	7543#	7579
7590#	7626	7637#	7673	7684#	7720	7731#	7767	7778#	7814	7826#	7862	7873#
7909	7920#	7956	7967#	8003	8013#	8050	8061#	8097	8121#	8132	8164#	8167
4795#	4807	4810#	4821	4834#	4851	4869#	4878	4879#	4886	4898#	4907	4908#
4914	4926#	4935	4936#	4942	4955#	4973	4993#	5004	5006#	5019	5033#	5044
5046#	5060	5073#	5087	5088#	5099	5112#	5121	5123#	5130	5174#	5189	5192#
5209	5223#	5238	5241#	5258	5272#	5287	5290#	5307	5321#	5336	5339#	5356
5370#	5390	5393#	5415	5429#	5450	5453#	5476	5490#	5505	5508#	5525	5539#
5554	5557#	5574	5588#	5603	5606#	5623	5637#	5652	5655#	5672	5686#	5701
5704#	5721	5735#	5750	5753#	5770	5784#	5799	5802#	5819	5833#	5848	5851#
5868	5882#	5906	5909#	5925	5939#	5954	5957#	5977	5991#	6044	6058#	6083
6086#	6104	6575#	6591	6614#	6636	6660#	6682	6706#	6728	6752#	6774	6798#
6820	6844#	6866	6890#	6912	6936#	6958	6982#	7004	7030#	7052	7078#	7100
7126#	7148	7173#	7195	7220#	7242	7267#	7289	7315#	7337	7362#	7384	7411#
7433	7458#	7480	7505#	7527	7552#	7574	7599#	7621	7646#	7668	7693#	7715
7740#	7762	7787#	7809	7835#	7857	7882#	7904	7929#	7951	7976#	7998	8023#
8045	8070#	8092										
5992#	6013	6015#	6039									
3706#												
3706#												
3706#	4795#	4802	4807#	4810#	4816	4821#	4834#	4842	4848	4851#	4869#	4877
4878#	4879#	4885	4886#	4898#	4906	4907#	4908#	4914#	4926#	4934	4935#	4936#
4942#	4955#	4964	4970	4973#	4993#	5000	5004#	5006#	5014	5019#	5033#	5040
5044#	5046#	5055	5060#	5073#	5080	5087#	5088#	5094	5099#	5112#	5120	5121#
5123#	5129	5130#	5174#	5185	5189#	5192#	5204	5209#	5223#	5234	5238#	5241#
5253	5258#	5272#	5283	5287#	5290#	5302	5307#	5321#	5332	5336#	5339#	5351
5356#	5370#	5385	5390#	5393#	5409	5415#	5429#	5445	5450#	5453#	5470	5476#
5490#	5501	5505#	5508#	5520	5525#	5539#	5550	5554#	5557#	5569	5574#	5588#
5599	5603#	5606#	5618	5623#	5637#	5648	5652#	5655#	5667	5672#	5686#	5697
5701#	5704#	5716	5721#	5735#	5746	5750#	5753#	5765	5770#	5784#	5795	5799#
5802#	5814	5819#	5833#	5844	5848#	5851#	5863	5868#	5882#	5901	5906#	5909#
5919	5925#	5939#	5950	5954#	5957#	5970	5977#	5992#	6009	6013#	6015#	6039#
6058#	6078	6083#	6086#	6099	6104#	6575#	6590	6591#	6614#	6631	6636#	6660#
6677	6682#	6706#	6723	6728#	6752#	6769	6774#	6798#	6815	6820#	6844#	6861
6866#	6890#	6907	6912#	6936#	6953	6958#	6982#	6999	7004#	7030#	7047	7052#
7078#	7095	7100#	7126#	7143	7148#	7173#	7190	7195#	7220#	7237	7242#	7267#
7284	7289#	7315#	7332	7337#	7362#	7379	7384#	7411#	7428	7433#	7458#	7475
7480#	7505#	7522	7527#	7552#	7569	7574#	7599#	7616	7621#	7646#	7663	7668#
7693#	7710	7715#	7740#	7757	7762#	7787#	7804	7809#	7835#	7852	7857#	7882#
7899	7904#	7929#	7946	7951#	7976#	7993	7998#	8023#	8040	8045#	8070#	8087
8092#												
4795#	4802	4807	4810#	4816	4821	4834#	4842	4848	4851	4869#	4877	4878
4879#	4885	4886	4898#	4906	4907	4908#	4914	4926#	4934	4935#	4936#	4942
4955#	4964	4970	4973#	4993#	5000	5004#	5006#	5014	5019#	5033#	5040	5044
5046#	5055	5060	5073#	5080	5087#	5088#	5094	5099#	5112#	5120	5121#	5123#
5129	5130#	5174#	5185	5189#	5192#	5204	5209#	5223#	5234	5238#	5241#	5253
5258	5272#	5283	5287#	5290#	5302	5307#	5321#	5332	5336#	5339#	5351	5356
5370#	5385	5390	5393#	5409	5415#	5429#	5445	5450#	5453#	5470	5476	5490#
5501	5505	5508#	5520	5525#	5539#	5550	5554#	5557#	5569	5574#	5588#	5599
5603	5606#	5618	5623#	5637#	5648	5652#	5655#	5667	5672#	5686#	5697	5701
5704#	5716	5721	5735#	5746	5750#	5753#	5765	5770#	5784#	5795	5799#	5802#
5814	5819	5833#	5844	5848#	5851#	5863	5868#	5882#	5901	5906#	5909#	5919
5925	5939#	5950	5954	5957#	5970	5977#	5992#	6009	6013#	6015#	6039#	6058#

T\$SUBN= 000000

T\$TAGL= 177777  
T\$TAGN= 010171

T\$TEMP= 000000

T\$TEST= 000114

6078	6083	6086#	6099	6104	6575#	6590	6591	6614#	6631	6636	6660#	6677
6682	6706#	6723	6728	6752#	6769	6774	6798#	6815	6820	6844#	6861	6866
6890#	6907	6912	6936#	6953	6958	6982#	6999	7004	7030#	7047	7052	7078#
7095	7100	7126#	7143	7148	7173#	7190	7195	7220#	7237	7242	7267#	7284
7289	7315#	7332	7337	7362#	7379	7384	7411#	7428	7433	7458#	7475	7480
7505#	7522	7527	7552#	7569	7574	7599#	7616	7621	7646#	7663	7668	7693#
7710	7715	7740#	7757	7762	7787#	7804	7809	7835#	7852	7857	7882#	7899
7904	7929#	7946	7951	7976#	7993	7998	8023#	8040	8045	8070#	8087	8092
3706#	4737#	4762#	4790#	4830#	4867#	4896#	4924#	4951#	4988#	5028#	5069#	5108#
5144#	5168#	5218#	5267#	5316#	5365#	5424#	5485#	5534#	5583#	5632#	5681#	5730#
5779#	5828#	5877#	5934#	5986#	5991#	6053#	6112#	6138#	6164#	6201#	6238#	6273#
6307#	6341#	6395#	6436#	6480#	6512#	6568#	6605#	6651#	6697#	6743#	6789#	6835#
6881#	6927#	6973#	7021#	7068#	7117#	7164#	7211#	7258#	7306#	7353#	7402#	7449#
7496#	7543#	7590#	7637#	7684#	7731#	7778#	7826#	7873#	7920#	7967#	8013#	8061#
3706#	3756#	3793#	3822#	4455#	4456#	4457#	4458#	4459#	4460#	4461#	4462#	4463#
4464#	4465#	4467#	4469#	4470#	4471#	4472#	4473#	4474#	4475#	4476#	4477#	4478#
4479#	4480#	4481#	4482#	4483#	4484#	4485#	4486#	4487#	4488#	4490#	4506#	4537#
4655#	4683#	4700#	4718#	4737#	4762#	4790#	4830#	4867#	4896#	4924#	4951#	4988#
5028#	5069#	5108#	5144#	5168#	5218#	5267#	5316#	5365#	5424#	5485#	5534#	5583#
5632#	5681#	5730#	5779#	5828#	5877#	5934#	5986#	5991#	6053#	6112#	6138#	6164#
6201#	6238#	6273#	6307#	6341#	6395#	6436#	6480#	6512#	6568#	6605#	6651#	6697#
6743#	6789#	6835#	6881#	6927#	6973#	7021#	7068#	7117#	7164#	7211#	7258#	7306#
7353#	7402#	7449#	7496#	7543#	7590#	7637#	7684#	7731#	7778#	7826#	7873#	7920#
7967#	8013#	8061#	8121#	8164#	4456#	4457#	4458#	4459#	4460#	4461#	4462#	4463#
3760#	3770#	3808#	3825#	4455#	4471#	4472#	4473#	4474#	4475#	4476#	4477#	4478#
4464#	4465#	4467#	4469#	4470#	4484#	4485#	4486#	4487#	4488#	4493#	4514#	4523#
4479#	4480#	4481#	4482#	4483#	4719#	4744#	4755#	4756#	4770#	4802#	4807#	4816#
4652#	4673#	4686#	4703#	4719#	4744#	4755#	4756#	4770#	4802#	4807#	4816#	4821#
4822#	4842#	4848#	4851#	4852#	4877#	4878#	4885#	4886#	4888#	4906#	4907#	4914#
4916#	4934#	4935#	4942#	4944#	4964#	4970#	4973#	4974#	5000#	5004#	5014#	5019#
5020#	5040#	5044#	5055#	5060#	5061#	5080#	5087#	5094#	5099#	5100#	5120#	5121#
5129#	5130#	5131#	5158#	5160#	5185#	5189#	5204#	5209#	5210#	5234#	5238#	5253#
5258#	5259#	5283#	5287#	5302#	5307#	5308#	5332#	5336#	5351#	5356#	5357#	5385#
5390#	5409#	5415#	5416#	5445#	5450#	5476#	5477#	5501#	5505#	5520#	5525#	5525#
5526#	5550#	5554#	5569#	5574#	5575#	5599#	5603#	5618#	5623#	5624#	5648#	5652#
5667#	5672#	5673#	5697#	5701#	5716#	5721#	5722#	5746#	5750#	5765#	5770#	5771#
5795#	5799#	5814#	5819#	5820#	5844#	5848#	5863#	5868#	5869#	5901#	5906#	5919#
5925#	5926#	5950#	5954#	5970#	5977#	5978#	6009#	6013#	6034#	6039#	6044#	6045#
6078#	6083#	6099#	6104#	6105#	6131#	6156#	6193#	6231#	6262#	6263#	6266#	6296#
6297#	6300#	6329#	6330#	6333#	6383#	6427#	6472#	6504#	6539#	6553#	6557#	6590#
6591#	6592#	6631#	6636#	6637#	6641#	6677#	6682#	6683#	6687#	6723#	6728#	6729#
6733#	6769#	6774#	6775#	6779#	6815#	6820#	6821#	6825#	6861#	6866#	6867#	6871#
6907#	6912#	6913#	6917#	6953#	6958#	6959#	6963#	6999#	7004#	7005#	7010#	7047#
7052#	7053#	7057#	7095#	7100#	7101#	7106#	7143#	7148#	7149#	7153#	7190#	7195#
7196#	7200#	7237#	7242#	7243#	7247#	7284#	7289#	7290#	7294#	7332#	7337#	7338#
7342#	7379#	7384#	7385#	7389#	7428#	7433#	7434#	7438#	7475#	7480#	7481#	7485#
7522#	7527#	7528#	7532#	7569#	7574#	7575#	7579#	7616#	7621#	7622#	7626#	7663#
7668#	7669#	7673#	7710#	7715#	7716#	7720#	7757#	7762#	7763#	7767#	7804#	7809#
7810#	7814#	7852#	7857#	7858#	7862#	7899#	7904#	7905#	7909#	7946#	7951#	7952#
7956#	7993#	7998#	7999#	8003#	8040#	8045#	8046#	8050#	8087#	8092#	8093#	8097#
8123#	8124#	8125#	8126#	8132#	8167#	8175#	4772	4788	4790#	4824	4828	4830#
3706#	4732	4735	4737#	4758	4760	4762#	4922	4924#	4946	4949	4951#	4981
4861	4865	4867#	4890	4894	4896#	4918	5069#	5102	5106	5108#	5136	5142
4985	4988#	5022	5026	5028#	5063	5067	5261	5265	5267#	5310	5314	5316#
5144#	5162	5166	5168#	5212	5216	5218#						

5359	5363	5365#	5418	5422	5424#	5479	5483	5485#	5528	5532	5534#	5577
5581	5583#	5626	5630	5632#	5675	5679	5681#	5724	5728	5730#	5773	5777
5779#	5822	5826	5828#	5871	5875	5877#	5928	5932	5934#	5980	5984	5986#
5991	6047	6051	6053#	6107	6110	6112#	6133	6136	6138#	6158	6162	6164#
6195	6199	6201#	6233	6236	6238#	6268	6271	6273#	6302	6305	6307#	6335
6339	6341#	6385	6393	6395#	6429	6434	6436#	6474	6478	6480#	6506	6510
6512#	6563	6566	6568#	6597	6603	6605#	6643	6649	6651#	6689	6695	6697#
6735	6741	6743#	6781	6787	6789#	6827	6833	6835#	6873	6879	6881#	6919
6925	6927#	6965	6971	6973#	7013	7019	7021#	7060	7066	7068#	7109	7115
7117#	7156	7162	7164#	7203	7209	7211#	7250	7256	7258#	7297	7304	7306#
7345	7351	7353#	7392	7398	7402#	7441	7447	7449#	7488	7494	7496#	7535
7541	7543#	7582	7589	7590#	7629	7635	7637#	7676	7682	7684#	7723	7729
7731#	7770	7776	7778#	7817	7823	7826#	7865	7871	7873#	7912	7918	7920#
7959	7965	7967#	8005	8011	8013#	8053	8059	8061#	8183	8184		
3706#	4282	4455	4456	4457	4458	4459	4460	4461	4462	4463	4464	4465
4467	4469	4470	4471	4472	4473	4474	4475	4476	4477	4478	4479	4480
4481	4482	4483	4484	4485	4486	4487	4488	4491	4492	4493	4523	4551
4554	4557	4561	4574	4652	4669	4673	4684	4686	4702	4703	4719	4744
4751	4755	4756	4768	4770	4795	4801	4802	4807	4810	4815	4816	4821
4822	4834	4841	4842	4847	4848	4851	4852	4869	4876	4877	4878	4879
4884	4885	4886	4888	4898	4905	4906	4907	4908	4913	4914	4916	4926
4933	4934	4935	4936	4941	4942	4944	4955	4963	4964	4969	4970	4973
4974	4993	4999	5000	5004	5006	5013	5014	5019	5020	5033	5039	5040
5044	5046	5054	5055	5060	5061	5073	5079	5080	5087	5088	5093	5094
5099	5100	5112	5119	5120	5121	5123	5128	5129	5130	5131	5156	5158
5160	5174	5184	5185	5189	5192	5203	5204	5209	5210	5223	5233	5234
5238	5241	5252	5253	5258	5259	5272	5282	5283	5287	5290	5301	5302
5307	5308	5321	5331	5332	5336	5339	5350	5351	5356	5357	5370	5384
5385	5390	5393	5408	5409	5415	5416	5429	5443	5445	5450	5453	5469
5470	5476	5477	5490	5500	5501	5505	5508	5519	5520	5525	5526	5539
5549	5550	5554	5557	5568	5569	5574	5575	5588	5598	5599	5603	5606
5617	5618	5623	5624	5637	5647	5648	5652	5655	5666	5667	5672	5673
5686	5696	5697	5701	5704	5715	5716	5721	5722	5735	5745	5746	5750
5753	5764	5765	5770	5771	5784	5794	5795	5799	5802	5813	5814	5819
5820	5833	5843	5844	5848	5851	5862	5863	5868	5869	5882	5900	5901
5906	5909	5918	5919	5925	5926	5939	5949	5950	5954	5957	5969	5970
5977	5978	5991	5992	6008	6009	6013	6015	6033	6034	6039	6044	6045
6058	6077	6078	6083	6086	6098	6099	6104	6105	6114	6120	6124	6126
6128	6131	6145	6149	6151	6153	6156	6168	6183	6189	6190	6193	6205
6221	6223	6227	6231	6239	6261	6262	6263	6266	6295	6296	6297	6300
6328	6329	6330	6333	6381	6383	6422	6427	6459	6469	6472	6502	6504
6538	6539	6553	6557	6575	6589	6590	6591	6592	6614	6630	6631	6636
6637	6641	6660	6676	6677	6682	6683	6687	6706	6722	6723	6728	6729
6733	6752	6768	6769	6774	6775	6779	6798	6814	6815	6820	6821	6825
6844	6860	6861	6866	6867	6871	6890	6906	6907	6912	6913	6917	6936
6952	6953	6958	6959	6963	6982	6998	6999	7004	7005	7010	7030	7046
7047	7052	7053	7057	7078	7094	7095	7100	7101	7106	7126	7142	7143
7148	7149	7153	7173	7189	7190	7195	7196	7200	7220	7236	7237	7242
7243	7247	7267	7283	7284	7289	7290	7294	7315	7331	7332	7337	7338
7342	7362	7378	7379	7384	7385	7389	7411	7427	7428	7433	7434	7438
7458	7474	7475	7480	7481	7485	7505	7521	7522	7527	7528	7532	7552
7568	7569	7574	7575	7579	7599	7615	7616	7621	7622	7626	7646	7662
7663	7668	7669	7673	7693	7709	7710	7715	7716	7720	7740	7756	7757
7762	7763	7767	7787	7803	7804	7809	7810	7814	7835	7851	7852	7857
7858	7862	7882	7898	7899	7904	7905	7909	7929	7945	7946	7951	7952
7956	7976	7992	7993	7998	7999	8003	8023	8039	8040	8045	8046	8050

TSSTIM= 177777









\$LSTIN= 000000  
\$LSTTA= 000000  
\$TMPO 002550  
= 040004

.MSTCL 003156

.ROMCL 003244

5745*	5764*	5794*	5813*	5843*	5862*	5900*	5918*	5949*	5969*	6004*	6006	6008*
6029*	6031	6033*	6073*	6075	6077*	6094*	6096	6098*	6126*	6128*	6151*	6153*
6175*	6190*	6223*	6227*	6257*	6259	6287*	6293	6324*	6326	6359*	6379	6418*
6419*	6420	6454*	6457	6465*	6497*	6500	6534*	6536	6585*	6587	6626*	6628
6672*	6674	6718*	6720	6764*	6766	6810*	6812	6856*	6858	6902*	6904	6948*
6950	6994*	6996	7042*	7044	7090*	7092	7138*	7140	7185*	7187	7232*	7234
7279*	7281	7327*	7329	7374*	7376	7423*	7425	7470*	7472	7517*	7519	7564*
7566	7611*	7613	7658*	7660	7705*	7707	7752*	7754	7799*	7801	7847*	7849
7894*	7896	7941*	7943	7988*	7990	8035*	8037	8082*	8084			
3715#												
3716#												
3901#	4256*	4259	4274									
3698#	3894#	3896#	3918#	3919#	3920#	3921#	3948#	3994#	4015#	4111#	4514	4744
4755	4802	4816	4842	4848	4877	4885	4906	4934	4964	4970	5000	5014
5040	5055	5080	5094	5120	5129	5158	5185	5204	5234	5253	5283	5302
5332	5351	5385	5409	5445	5470	5501	5520	5550	5569	5599	5618	5648
5667	5697	5716	5746	5765	5795	5814	5844	5863	5901	5919	5950	5970
6009	6034	6078	6099	6262	6263	6296	6297	6329	6330	6522	6539	6553
6590	6631	6637	6677	6683	6723	6729	6769	6775	6815	6821	6861	6867
6907	6913	6953	6959	6999	7005	7047	7053	7095	7101	7143	7149	7190
7196	7237	7243	7284	7290	7332	7338	7379	7385	7428	7434	7475	7481
7522	7528	7569	7575	7616	7622	7663	7669	7710	7716	7757	7763	7804
7810	7852	7858	7899	7905	7946	7952	7993	7999	8040	8046	8087	8093
8181#												
4105#	4793	4831	4868	4897	4925	4952	4990	5030	5071	5110	5146	5169
5219	5268	5317	5366	5425	5486	5535	5584	5633	5682	5731	5780	5829
5878	5936	5988	6054	6140	6166	6192	6203	6230	6275	6309	6342	6397
6438	6482	6514	6570	6607	6653	6699	6745	6791	6837	6883	6929	6975
7023	7071	7119	7166	7213	7260	7308	7355	7404	7451	7498	7545	7592
7639	7686	7733	7780	7829	7875	7922	7969	8016	8063			
4120#	4129	4131	4133	4135	4146	4153	4160	4168	4182	4243	4261	4263
4266	4271	4275	4302	4313	4315	4323	4325	5177	5179	5196	5198	5226
5228	5245	5247	5275	5277	5294	5296	5324	5326	5343	5345	5374	5376
5398	5400	5433	5435	5458	5460	5493	5495	5512	5514	5542	5544	5561
5563	5591	5593	5610	5612	5640	5642	5659	5661	5689	5691	5708	5710
5738	5740	5757	5759	5787	5789	5806	5808	5836	5838	5855	5857	5887
5895	5913	5942	5944	5961	5963	5996	6000	6002	6021	6025	6027	6063
6068	6071	6090	6092	6122	6147	6181	6219	6251	6254	6284	6288	6290
6318	6321	6352	6374	6376	6413	6415	6446	6449	6452	6463	6489	6492
6495	6531	6577	6579	6581	6583	6618	6622	6624	6664	6668	6670	6710
6714	6716	6756	6760	6762	6802	6806	6808	6848	6852	6854	6894	6898
6900	6940	6944	6946	6986	6990	6992	7034	7038	7040	7082	7086	7088
7130	7134	7136	7177	7181	7183	7224	7228	7230	7271	7275	7277	7319
7323	7325	7366	7370	7372	7415	7419	7421	7462	7466	7468	7509	7513
7515	7556	7560	7562	7603	7607	7609	7650	7654	7656	7697	7701	7703
7744	7748	7750	7791	7795	7797	7839	7843	7845	7886	7890	7892	7933
7937	7939	7980	7984	7986	8027	8031	8033	8074	8078	8080		





	6469	6502	6538	6589	6630	6676	6722	6768	6814	6860	6906	6952	6998	7046	7094
	7142	7189	7236	7283	7331	7378	7427	7474	7521	7568	7615	7662	7709	7756	7803
ERRHRD	7851	7898	7945	7992	8039	8086									
ERROR	718#	3706#													
	722#	3706#	4046#	4282	4751	4768	4801	4815	4841	4847	4876	4884	4905	4913	4933
	4941	4963	4969	4999	5013	5039	5054	5079	5093	5119	5128	5156	6126	6128	6151
	6153	6190	6223	6227	6261	6295	6328	6381	6422	6459	6469	6502	6538	6589	6630
	6676	6722	6768	6814	6860	6906	6952	6998	7046	7094	7142	7189	7236	7283	7331
	7378	7427	7474	7521	7568	7615	7662	7709	7756	7803	7851	7898	7945	7992	8039
	8086														
ERRSF	726#	3706#													
ERRSOF	730#	3706#													
ERRTBL	734#	3706#													
ESCAPE	744#	3706#	4744	4755	4802	4816	4842	4848	4877	4885	4906	4934	4964	4970	5000
	5014	5040	5055	5080	5094	5120	5129	5158	5185	5204	5234	5253	5283	5302	5332
	5351	5385	5409	5445	5470	5501	5520	5550	5569	5599	5618	5648	5667	5697	5716
	5746	5765	5795	5814	5844	5863	5901	5919	5950	5970	6009	6034	6078	6099	6262
	6296	6329	6539	6590	6631	6677	6723	6769	6815	6861	6907	6953	6999	7047	7095
	7143	7190	7237	7284	7332	7379	7428	7475	7522	7569	7616	7663	7710	7757	7804
	7852	7899	7946	7993	8040	8087									
EXIT	771#	3706#	4514	6263	6297	6330	6553	6637	6683	6729	6775	6821	6867	6913	6959
	7005	7053	7101	7149	7196	7243	7290	7338	7385	7434	7481	7528	7575	7622	7669
	7716	7763	7810	7858	7905	7952	7999	8046	8093						
FEQUAL	810#	3706#													
GETBYT	824#	3706#													
GETPRI	834#	3706#													
GETWOR	829#	3706#													
GMANIA	839#	3706#													
GMANID	848#	3706#													
GMANIL	859#	3706#													
GPHARD	868#	3706#	4574												
GPRMA	874#	3706#	8124	8125											
GPRMD	903#	3706#	8123	8126											
GPRML	934#	3706#													
HEADER	954#	3706#	3747												
INLOOP	962#	3706#													
IOSETU	966#	3706#													
IOSTAR	974#	3706#													
KT11	982#	3706#													
K4ONLY	4078#														
LASTAD	1147#	3706#	8183												
MANUAL	1162#	3706#													
MDTO	4419#	4465	4470	4471	4473	4474	4476	4483	4484						
MDT1	4422#	4458	4459	4460	4461	4462									
MDT2	4426#	4455	4456	4457	4463	4464	4467	4472	4477	4478	4480	4482	4485	4486	4487
	4488														
MDT27	4435#	4479	4481												
MDT5	4431#	4469	4475												
MEMORY	1166#	3706#													
MSTCLR	4099#	4793	4831	4868	4897	4925	4952	4990	5030	5071	5110	5146	5169	5219	5268
	5317	5366	5425	5486	5535	5584	5633	5682	5731	5780	5829	5878	5936	5988	6054
	6140	6166	6192	6203	6230	6275	6309	6342	6397	6438	6482	6514	6570	6607	6653
	6699	6745	6791	6837	6883	6929	6975	7023	7071	7119	7166	7213	7260	7308	7355
	7404	7451	7498	7545	7592	7639	7686	7733	7780	7828	7875	7922	7969	8016	8063
MYINT	4087#	4763	4791	5070	5111	5145	5173	5222	5271	5320	5369	5428	5489	5538	5587
	5636	5685	5734	5783	5832	5881	5938	5987	6057	6113	6139	6165	6202	6241	6274

	6308	6343	6396	6437	6481	6513	6569	6606	6652	6698	6744	6790	6836	6882	6928
	6974	7022	7069	7118	7165	7212	7259	7307	7354	7403	7450	7497	7544	7591	7638
	7685	7732	7779	7827	7874	7921	7968	8015	8062						
M\$BYTE	2000#	3706#	3747#												
M\$CHEC	2118#	3706#	4514#	6263#	6297#	6330#	6553#	6637#	6683#	6729#	6775#	6821#	6867#	6913#	6959#
	7005#	7053#	7101#	7149#	7196#	7243#	7290#	7338#	7385#	7434#	7481#	7528#	7575#	7622#	7669#
	7716#	7763#	7810#	7858#	7905#	7952#	7999#	8046#	8093#						
M\$CNTO	2182#	3706#	8123#	8124#	8125#	8126#									
M\$COUN	2066#	3706#	4455#	4456#	4457#	4458#	4459#	4460#	4461#	4462#	4463#	4464#	4465#	4467#	4469#
	4470#	4471#	4472#	4473#	4474#	4475#	4476#	4477#	4478#	4479#	4480#	4481#	4482#	4483#	4484#
	4485#	4486#	4487#	4488#	4491#	4492#									
M\$DATA	1867#	3706#	3747#	3882#	4015#										
M\$DECR	2029#	3706#	3760#	3808#	3825#	4455#	4456#	4457#	4458#	4459#	4460#	4461#	4462#	4463#	4464#
	4465#	4467#	4469#	4470#	4471#	4472#	4473#	4474#	4475#	4476#	4477#	4478#	4479#	4480#	4481#
	4482#	4483#	4484#	4485#	4486#	4487#	4488#	4493#	4523#	4652#	4673#	4686#	4703#	4719#	4756#
	4770#	4807#	4821#	4822#	4851#	4852#	4878#	4886#	4888#	4907#	4914#	4916#	4935#	4942#	4944#
	4973#	4974#	5004#	5019#	5020#	5044#	5060#	5061#	5087#	5099#	5100#	5121#	5130#	5131#	5160#
	5189#	5209#	5210#	5238#	5258#	5259#	5287#	5307#	5308#	5336#	5356#	5357#	5390#	5415#	5416#
	5450#	5476#	5477#	5505#	5525#	5526#	5554#	5574#	5575#	5603#	5623#	5624#	5652#	5672#	5673#
	5701#	5721#	5722#	5750#	5770#	5771#	5799#	5819#	5820#	5848#	5868#	5869#	5906#	5925#	5926#
	5954#	5977#	5978#	6013#	6039#	6044#	6045#	6083#	6104#	6105#	6131#	6156#	6193#	6231#	6266#
	6300#	6333#	6383#	6427#	6472#	6504#	6557#	6591#	6592#	6636#	6641#	6682#	6687#	6728#	6733#
	6774#	6779#	6820#	6825#	6866#	6871#	6912#	6917#	6958#	6963#	7004#	7010#	7052#	7057#	7100#
	7106#	7148#	7153#	7195#	7200#	7242#	7247#	7289#	7294#	7337#	7342#	7384#	7389#	7433#	7438#
	7480#	7485#	7527#	7532#	7574#	7579#	7621#	7626#	7668#	7673#	7715#	7720#	7762#	7767#	7809#
	7814#	7857#	7862#	7904#	7909#	7951#	7956#	7998#	8003#	8045#	8050#	8092#	8097#	8132#	8167#
	8175#														
M\$DEFA	2170#	3706#	8123#	8124#	8125#	8126#									
M\$ENDE	2074#	3706#	3808#	3825#	4455#	4456#	4457#	4458#	4459#	4460#	4461#	4462#	4463#	4464#	4465#
	4467#	4469#	4470#	4471#	4472#	4473#	4474#	4475#	4476#	4477#	4478#	4479#	4480#	4481#	4482#
	4483#	4484#	4485#	4486#	4487#	4488#	4493#	4523#	4652#	4673#	4686#	4703#	4719#	4756#	4770#
	4807#	4821#	4822#	4851#	4852#	4878#	4886#	4888#	4907#	4914#	4916#	4935#	4942#	4944#	4973#
	4974#	5004#	5019#	5020#	5044#	5060#	5061#	5087#	5099#	5100#	5121#	5130#	5131#	5160#	5189#
	5209#	5210#	5238#	5258#	5259#	5287#	5307#	5308#	5336#	5356#	5357#	5390#	5415#	5416#	5450#
	5476#	5477#	5505#	5525#	5526#	5554#	5574#	5575#	5603#	5623#	5624#	5652#	5672#	5673#	5701#
	5721#	5722#	5750#	5770#	5771#	5799#	5819#	5820#	5848#	5868#	5869#	5906#	5925#	5926#	5954#
	5977#	5978#	6013#	6039#	6044#	6045#	6083#	6104#	6105#	6131#	6156#	6193#	6231#	6266#	6300#
	6333#	6383#	6427#	6472#	6504#	6557#	6591#	6592#	6636#	6641#	6682#	6687#	6728#	6733#	6774#
	6779#	6820#	6825#	6866#	6871#	6912#	6917#	6958#	6963#	7004#	7010#	7052#	7057#	7100#	7106#
	7148#	7153#	7195#	7200#	7242#	7247#	7289#	7294#	7337#	7342#	7384#	7389#	7433#	7438#	7480#
	7485#	7527#	7532#	7574#	7579#	7621#	7626#	7668#	7673#	7715#	7720#	7762#	7767#	7809#	7814#
	7857#	7862#	7904#	7909#	7951#	7956#	7998#	8003#	8045#	8050#	8092#	8097#	8132#	8167#	8175#
M\$ERRI	1649#	3706#	4282#	4751#	4768#	4801#	4815#	4841#	4847#	4876#	4884#	4905#	4913#	4933#	4941#
	4963#	4969#	4999#	5013#	5039#	5054#	5079#	5093#	5119#	5128#	5156#	5184#	5203#	5233#	5252#
	5282#	5301#	5331#	5350#	5384#	5408#	5443#	5469#	5500#	5519#	5549#	5568#	5598#	5617#	5647#
	5666#	5696#	5715#	5745#	5764#	5794#	5813#	5843#	5862#	5900#	5918#	5949#	5969#	6008#	6033#
	6077#	6098#	6126#	6128#	6151#	6153#	6190#	6223#	6227#	6261#	6295#	6328#	6381#	6422#	6459#
	6469#	6502#	6538#	6589#	6630#	6676#	6722#	6768#	6814#	6860#	6906#	6952#	6998#	7046#	7094#
	7142#	7189#	7236#	7283#	7331#	7378#	7427#	7474#	7521#	7568#	7615#	7662#	7709#	7756#	7803#
	7851#	7898#	7945#	7992#	8039#	8086#									
M\$ESCA	2006#	3706#	4744#	4755#	4802#	4816#	4842#	4848#	4877#	4885#	4906#	4934#	4964#	4970#	5000#
	5014#	5040#	5055#	5080#	5094#	5120#	5129#	5158#	5185#	5204#	5234#	5253#	5283#	5302#	5332#
	5351#	5385#	5409#	5445#	5470#	5501#	5520#	5550#	5569#	5599#	5618#	5648#	5667#	5697#	5716#
	5746#	5765#	5795#	5814#	5844#	5863#	5901#	5919#	5950#	5970#	6009#	6034#	6078#	6099#	6262#
	6296#	6329#	6539#	6590#	6631#	6677#	6723#	6769#	6815#	6861#	6907#	6953#	6999#	7047#	7095#
	7143#	7190#	7237#	7284#	7332#	7379#	7428#	7475#	7522#	7569#	7616#	7663#	7710#	7757#	7804#







M\$GNLS	1913#	3706#	4807#	4821#	4851#	4878#	4886#	4907#	4914#	4935#	4942#	4973#	5004#	5019#	5044#
	5060#	5087#	5099#	5121#	5130#	5189#	5209#	5238#	5258#	5287#	5307#	5336#	5356#	5390#	5415#
	5457#	5476#	5505#	5525#	5554#	5574#	5603#	5623#	5652#	5672#	5701#	5721#	5750#	5770#	5799#
	5819#	5848#	5868#	5906#	5925#	5954#	5977#	6013#	6039#	6083#	6104#	6591#	6636#	6682#	6728#
	6774#	6820#	6866#	6912#	6958#	7004#	7052#	7100#	7148#	7195#	7242#	7289#	7337#	7384#	7433#
	7480#	7527#	7574#	7621#	7668#	7715#	7762#	7809#	7857#	7904#	7951#	7998#	8045#	8092#	
M\$GNSU	1898#	3706#	5991#												
M\$GNIA	1890#	3706#	3808#	3825#	4455#	4456#	4457#	4458#	4459#	4460#	4461#	4462#	4463#	4464#	4465#
	4467#	4469#	4470#	4471#	4472#	4473#	4474#	4475#	4476#	4477#	4478#	4479#	4480#	4481#	4482#
	4483#	4484#	4485#	4486#	4487#	4488#	4493#	4523#	4652#	4673#	4686#	4703#	4719#	4756#	4770#
	4822#	4852#	4888#	4916#	4944#	4974#	5020#	5061#	5100#	5131#	5160#	5210#	5259#	5308#	5357#
	5416#	5477#	5526#	5575#	5624#	5673#	5722#	5771#	5820#	5869#	5926#	5978#	6044#	6045#	6105#
	6131#	6156#	6193#	6231#	6266#	6300#	6333#	6383#	6427#	6472#	6504#	6557#	6592#	6641#	6687#
	6733#	6779#	6825#	6871#	6917#	6963#	7010#	7057#	7106#	7153#	7200#	7247#	7294#	7342#	7389#
	7438#	7485#	7532#	7579#	7626#	7673#	7720#	7767#	7814#	7862#	7909#	7956#	8003#	8050#	8097#
	8132#	8167#													
M\$GNTE	1894#	3706#	4737#	4762#	4790#	4830#	4867#	4896#	4924#	4951#	4988#	5028#	5069#	5108#	5144#
	5168#	5218#	5267#	5316#	5365#	5424#	5485#	5534#	5583#	5632#	5681#	5730#	5779#	5828#	5877#
	5934#	5986#	6053#	6112#	6138#	6164#	6201#	6238#	6273#	6307#	6341#	6395#	6436#	6480#	6512#
	6568#	6605#	6651#	6697#	6743#	6789#	6835#	6881#	6927#	6973#	7021#	7068#	7117#	7164#	7211#
	7258#	7306#	7353#	7402#	7449#	7496#	7543#	7590#	7637#	7684#	7731#	7778#	7826#	7873#	7920#
	7967#	8013#	8061#												
M\$HAPT	1739#	3706#	3747#												
M\$HNAP	1824#	3706#	3747#												
M\$INCR	2026#	3706#	3712#	3756#	3793#	3822#	4282#	4455#	4456#	4457#	4458#	4459#	4460#	4461#	4462#
	4463#	4464#	4465#	4467#	4469#	4470#	4471#	4472#	4473#	4474#	4475#	4476#	4477#	4478#	4479#
	4480#	4481#	4482#	4483#	4484#	4485#	4486#	4487#	4488#	4490#	4491#	4492#	4493#	4506#	4523#
	4537#	4551#	4554#	4557#	4561#	4574#	4652#	4655#	4669#	4673#	4683#	4684#	4686#	4700#	4702#
	4703#	4718#	4719#	4737#	4744#	4751#	4755#	4756#	4762#	4768#	4770#	4790#	4795#	4801#	4802#
	4807#	4810#	4815#	4816#	4821#	4822#	4830#	4834#	4841#	4842#	4847#	4848#	4851#	4852#	4867#
	4869#	4876#	4877#	4878#	4879#	4884#	4885#	4886#	4888#	4896#	4898#	4905#	4906#	4907#	4908#
	4913#	4914#	4916#	4924#	4926#	4933#	4934#	4935#	4936#	4941#	4942#	4944#	4951#	4955#	4963#
	4964#	4969#	4970#	4973#	4974#	4988#	4993#	4999#	5000#	5004#	5006#	5013#	5014#	5019#	5020#
	5028#	5033#	5039#	5040#	5044#	5046#	5054#	5055#	5060#	5061#	5069#	5073#	5079#	5080#	5087#
	5088#	5093#	5094#	5099#	5100#	5108#	5112#	5119#	5120#	5121#	5123#	5128#	5129#	5130#	5131#
	5144#	5156#	5158#	5160#	5168#	5174#	5184#	5185#	5189#	5192#	5203#	5204#	5209#	5210#	5218#
	5223#	5233#	5234#	5238#	5241#	5252#	5253#	5258#	5259#	5267#	5272#	5282#	5283#	5287#	5290#
	5301#	5302#	5307#	5308#	5316#	5321#	5331#	5332#	5336#	5339#	5350#	5351#	5356#	5357#	5365#
	5370#	5384#	5385#	5390#	5393#	5408#	5409#	5415#	5416#	5424#	5429#	5443#	5445#	5450#	5453#
	5469#	5470#	5476#	5477#	5485#	5490#	5500#	5501#	5505#	5508#	5519#	5520#	5525#	5526#	5534#
	5539#	5549#	5550#	5554#	5557#	5568#	5569#	5574#	5575#	5583#	5588#	5598#	5599#	5603#	5606#
	5617#	5618#	5623#	5624#	5632#	5637#	5647#	5648#	5652#	5655#	5666#	5667#	5672#	5673#	5681#
	5686#	5696#	5697#	5701#	5704#	5715#	5716#	5721#	5722#	5730#	5735#	5745#	5746#	5750#	5753#
	5764#	5765#	5770#	5771#	5779#	5784#	5794#	5795#	5799#	5802#	5813#	5814#	5819#	5820#	5828#
	5833#	5843#	5844#	5848#	5851#	5862#	5863#	5868#	5869#	5877#	5882#	5900#	5901#	5906#	5909#
	5918#	5919#	5925#	5926#	5934#	5939#	5949#	5950#	5954#	5957#	5969#	5970#	5977#	5978#	5986#
	5991#	5992#	6008#	6009#	6013#	6015#	6033#	6034#	6039#	6044#	6045#	6053#	6058#	6077#	6078#
	6083#	6086#	6098#	6099#	6104#	6105#	6112#	6114#	6120#	6124#	6126#	6128#	6131#	6138#	6145#
	6149#	6151#	6153#	6156#	6164#	6168#	6183#	6189#	6190#	6193#	6201#	6205#	6221#	6223#	6227#
	6231#	6238#	6239#	6261#	6262#	6263#	6266#	6273#	6295#	6296#	6297#	6300#	6307#	6328#	6329#
	6330#	6333#	6341#	6381#	6383#	6395#	6422#	6427#	6436#	6459#	6469#	6472#	6480#	6502#	6504#
	6512#	6538#	6539#	6553#	6557#	6568#	6575#	6589#	6590#	6591#	6592#	6605#	6614#	6630#	6631#
	6636#	6637#	6641#	6651#	6660#	6676#	6677#	6682#	6683#	6687#	6697#	6706#	6722#	6723#	6728#
	6729#	6733#	6743#	6752#	6768#	6769#	6774#	6775#	6779#	6789#	6798#	6814#	6815#	6820#	6821#
	6825#	6835#	6844#	6860#	6861#	6866#	6867#	6871#	6881#	6890#	6906#	6907#	6912#	6913#	6917#
	6927#	6936#	6952#	6953#	6958#	6959#	6963#	6973#	6982#	6998#	6999#	7004#	7005#	7010#	7021#

	7030#	7046#	7047#	7052#	7053#	7057#	7068#	7078#	7094#	7095#	7100#	7101#	7106#	7117#	7126#
	7142#	7143#	7148#	7149#	7153#	7164#	7173#	7189#	7190#	7195#	7196#	7200#	7211#	7220#	7236#
	7237#	7242#	7243#	7247#	7258#	7267#	7283#	7284#	7289#	7290#	7294#	7306#	7315#	7331#	7332#
	7337#	7338#	7342#	7353#	7362#	7378#	7379#	7384#	7385#	7389#	7402#	7411#	7427#	7428#	7433#
	7434#	7438#	7449#	7458#	7474#	7475#	7480#	7481#	7485#	7496#	7505#	7521#	7522#	7527#	7528#
	7532#	7543#	7552#	7568#	7569#	7574#	7575#	7579#	7590#	7599#	7615#	7616#	7621#	7622#	7626#
	7637#	7646#	7662#	7663#	7668#	7669#	7673#	7684#	7693#	7709#	7710#	7715#	7716#	7720#	7731#
	7740#	7756#	7757#	7762#	7763#	7767#	7778#	7787#	7803#	7804#	7809#	7810#	7814#	7826#	7835#
	7851#	7852#	7857#	7858#	7862#	7873#	7882#	7898#	7899#	7904#	7905#	7909#	7920#	7929#	7945#
	7946#	7951#	7952#	7956#	7967#	7976#	7992#	7993#	7998#	7999#	8003#	8013#	8023#	8039#	8040#
	8045#	8046#	8050#	8061#	8070#	8086#	8087#	8092#	8093#	8097#	8121#	8164#			
M\$IOSE	1700#	3706#													
M\$LDRO	1942#	3706#	4551#	4554#	4557#	4561#	4574#	4669#	6120#	6124#	6145#	6149#	6168#	6183#	6205#
	6221#														
M\$MASK	1671#	3706#													
M\$MCH?	4#	3706#													
M\$MCLO	1624#	3706#													
M\$MSK1	1677#	3706#													
M\$POP	1881#	3706#	3760#	3808#	3825#	4455#	4456#	4457#	4458#	4459#	4460#	4461#	4462#	4463#	4464#
	4465#	4467#	4469#	4470#	4471#	4472#	4473#	4474#	4475#	4476#	4477#	4478#	4479#	4480#	4481#
	4482#	4483#	4484#	4485#	4486#	4487#	4488#	4493#	4523#	4652#	4673#	4686#	4703#	4719#	4756#
	4770#	4807#	4821#	4822#	4851#	4852#	4878#	4886#	4888#	4907#	4914#	4916#	4935#	4942#	4944#
	4973#	4974#	5004#	5019#	5020#	5044#	5060#	5061#	5087#	5099#	5100#	5121#	5130#	5131#	5160#
	5189#	5209#	5210#	5238#	5258#	5259#	5287#	5307#	5308#	5336#	5356#	5357#	5390#	5415#	5416#
	5450#	5476#	5477#	5505#	5525#	5526#	5554#	5574#	5575#	5603#	5623#	5624#	5652#	5672#	5673#
	5701#	5721#	5722#	5750#	5770#	5771#	5799#	5819#	5820#	5848#	5868#	5869#	5906#	5925#	5926#
	5954#	5977#	5978#	6013#	6039#	6044#	6045#	6083#	6104#	6105#	6131#	6156#	6193#	6231#	6266#
	6300#	6333#	6383#	6427#	6472#	6504#	6557#	6591#	6592#	6636#	6641#	6682#	6687#	6728#	6733#
	6774#	6779#	6820#	6825#	6866#	6871#	6912#	6917#	6958#	6963#	7004#	7010#	7052#	7057#	7100#
	7106#	7148#	7153#	7195#	7200#	7242#	7247#	7289#	7294#	7337#	7342#	7384#	7389#	7433#	7438#
	7480#	7485#	7527#	7532#	7574#	7579#	7621#	7626#	7668#	7673#	7715#	7720#	7762#	7767#	7809#
	7814#	7857#	7862#	7904#	7909#	7951#	7956#	7998#	8003#	8045#	8050#	8092#	8097#	8132#	8167#
	8175#														
M\$PRIN	1636#	3706#	4455#	4456#	4457#	4458#	4459#	4460#	4461#	4462#	4463#	4464#	4465#	4467#	4469#
	4470#	4471#	4472#	4473#	4474#	4475#	4476#	4477#	4478#	4479#	4480#	4481#	4482#	4483#	4484#
	4485#	4486#	4487#	4488#	4491#	4492#									
M\$PUSH	1631#	3706#	3712#	3756#	3793#	3822#	4455#	4456#	4457#	4458#	4459#	4460#	4461#	4462#	4463#
	4464#	4465#	4467#	4469#	4470#	4471#	4472#	4473#	4474#	4475#	4476#	4477#	4478#	4479#	4480#
	4481#	4482#	4483#	4484#	4485#	4486#	4487#	4488#	4490#	4506#	4537#	4655#	4683#	4700#	4718#
	4737#	4762#	4790#	4795#	4810#	4830#	4834#	4867#	4869#	4879#	4896#	4898#	4908#	4924#	4926#
	4936#	4951#	4955#	4988#	4993#	5006#	5028#	5033#	5046#	5069#	5073#	5088#	5108#	5112#	5123#
	5144#	5168#	5174#	5192#	5218#	5223#	5241#	5267#	5272#	5290#	5316#	5321#	5339#	5365#	5370#
	5393#	5424#	5429#	5453#	5485#	5490#	5508#	5534#	5539#	5557#	5583#	5588#	5606#	5632#	5637#
	5655#	5681#	5686#	5704#	5730#	5735#	5753#	5779#	5784#	5802#	5828#	5833#	5851#	5877#	5882#
	5909#	5934#	5939#	5957#	5986#	5991#	5992#	6015#	6053#	6058#	6086#	6112#	6138#	6164#	6201#
	6238#	6273#	6307#	6341#	6395#	6436#	6480#	6512#	6568#	6575#	6605#	6614#	6651#	6660#	6697#
	6706#	6743#	6752#	6789#	6798#	6835#	6844#	6881#	6890#	6927#	6936#	6973#	6982#	7021#	7030#
	7068#	7078#	7117#	7126#	7164#	7173#	7211#	7220#	7258#	7267#	7306#	7315#	7353#	7362#	7402#
	7411#	7449#	7458#	7496#	7505#	7543#	7552#	7590#	7599#	7637#	7646#	7684#	7693#	7731#	7740#
	7778#	7787#	7826#	7835#	7873#	7882#	7920#	7929#	7967#	7976#	8013#	8023#	8061#	8070#	8121#
	8164#														
M\$PUT	1972#	3706#	4455#	4456#	4457#	4458#	4459#	4460#	4461#	4462#	4463#	4464#	4465#	4467#	4469#
	4470#	4471#	4472#	4473#	4474#	4475#	4476#	4477#	4478#	4479#	4480#	4481#	4482#	4483#	4484#
	4485#	4486#	4487#	4488#	4491#	4492#									
M\$PUT1	1981#	3706#	4455#	4456#	4457#	4458#	4459#	4460#	4461#	4462#	4463#	4464#	4465#	4467#	4469#
	4470#	4471#	4472#	4473#	4474#	4475#	4476#	4477#	4478#	4479#	4480#	4481#	4482#	4483#	4484#





	5869#	5882#	5900#	5901#	5906#	5909#	5918#	5919#	5925#	5926#	5939#	5949#	5950#	5954#	5957#
	5969#	5970#	5977#	5978#	5991#	5992#	6008#	6009#	6013#	6015#	6033#	6034#	6039#	6044#	6045#
	6058#	6077#	6078#	6083#	6086#	6098#	6099#	6104#	6105#	6114#	6120#	6124#	6126#	6128#	6131#
	6145#	6149#	6151#	6153#	6156#	6168#	6183#	6189#	6190#	6193#	6205#	6221#	6223#	6227#	6231#
	6239#	6261#	6262#	6263#	6266#	6295#	6296#	6297#	6300#	6328#	6329#	6330#	6333#	6381#	6383#
	6422#	6427#	6459#	6469#	6472#	6502#	6504#	6538#	6539#	6553#	6557#	6575#	6589#	6590#	6591#
	6592#	6614#	6630#	6631#	6636#	6637#	6641#	6660#	6676#	6677#	6682#	6683#	6687#	6706#	6722#
	6723#	6728#	6729#	6733#	6752#	6768#	6769#	6774#	6775#	6779#	6798#	6814#	6815#	6820#	6821#
	6825#	6844#	6860#	6861#	6866#	6867#	6871#	6890#	6906#	6907#	6912#	6913#	6917#	6936#	6952#
	6953#	6958#	6959#	6963#	6982#	6998#	6999#	7004#	7005#	7010#	7030#	7046#	7047#	7052#	7053#
	7057#	7078#	7094#	7095#	7100#	7101#	7106#	7126#	7142#	7143#	7148#	7149#	7153#	7173#	7189#
	7190#	7195#	7196#	7200#	7220#	7236#	7237#	7242#	7243#	7247#	7267#	7283#	7284#	7289#	7290#
	7294#	7315#	7331#	7332#	7337#	7338#	7342#	7362#	7378#	7379#	7384#	7385#	7389#	7411#	7427#
	7428#	7433#	7434#	7438#	7458#	7474#	7475#	7480#	7481#	7485#	7505#	7521#	7522#	7527#	7528#
	7532#	7552#	7568#	7569#	7574#	7575#	7579#	7599#	7615#	7616#	7621#	7622#	7626#	7646#	7662#
	7663#	7668#	7669#	7673#	7693#	7709#	7710#	7715#	7716#	7720#	7740#	7756#	7757#	7762#	7763#
	7767#	7787#	7803#	7804#	7809#	7810#	7814#	7835#	7851#	7852#	7857#	7858#	7862#	7882#	7898#
	7899#	7904#	7905#	7909#	7929#	7945#	7946#	7951#	7952#	7956#	7976#	7992#	7993#	7998#	7999#
	8003#	8023#	8039#	8040#	8045#	8046#	8050#	8070#	8086#	8087#	8092#	8093#	8097#		
MSWORD	1994#	3706#	3747#	3770#	4282#	4514#	4751#	4768#	4801#	4815#	4841#	4847#	4876#	4884#	4905#
	4913#	4933#	4941#	4963#	4969#	4999#	5013#	5039#	5054#	5079#	5093#	5119#	5128#	5156#	5184#
	5203#	5233#	5252#	5282#	5301#	5331#	5350#	5384#	5408#	5443#	5469#	5500#	5519#	5549#	5568#
	5598#	5617#	5647#	5666#	5696#	5715#	5745#	5764#	5794#	5813#	5843#	5862#	5900#	5918#	5949#
	5969#	6008#	6033#	6077#	6098#	6126#	6128#	6151#	6153#	6190#	6223#	6227#	6261#	6263#	6295#
	6297#	6328#	6330#	6381#	6422#	6459#	6469#	6502#	6538#	6553#	6589#	6630#	6637#	6676#	6683#
	6722#	6729#	6768#	6775#	6814#	6821#	6860#	6867#	6906#	6913#	6952#	6959#	6998#	7005#	7046#
	7053#	7094#	7101#	7142#	7149#	7189#	7196#	7236#	7243#	7283#	7290#	7331#	7338#	7378#	7385#
	7427#	7434#	7474#	7481#	7521#	7528#	7568#	7575#	7615#	7622#	7662#	7669#	7709#	7716#	7756#
	7763#	7803#	7810#	7851#	7858#	7898#	7905#	7945#	7952#	7992#	7999#	8039#	8046#	8086#	8093#
	8123#	8124#	8125#	8126#	8183										
MSXFER	1682#	3706#													
OPEN	1171#	3706#													
POINTE	1176#	3706#	3737												
PRINTB	1239#	3706#	4455	4456	4457	4458	4459	4460	4461	4462	4463	4464	4465	4467	4469
	4470	4471	4472	4473	4474	4475	4476	4477	4478	4479	4480	4481	4482	4483	4484
	4485	4486	4487	4488											
PRINTF	1279#	3706#	4491	4492											
PRINTS	1319#	3706#													
PRINTX	1359#	3706#													
READBU	1399#	3706#													
READEF	1403#	3706#	4551	4554	4557	4561									
RERROR	4054#	6008	6033	6077	6098										
RFLAGS	1408#	3706#													
ROMCLK	4093#	4129	4131	4133	4139	4146	4153	4160	4168	4182	4243	4261	4263	4266	4271
	4275	4302	4313	4315	4323	4325	5177	5179	5196	5198	5226	5228	5245	5247	5275
	5277	5294	5296	5324	5326	5343	5345	5374	5376	5398	5400	5433	5435	5458	5460
	5493	5495	5512	5514	5542	5544	5561	5563	5591	5593	5610	5612	5640	5642	5659
	5661	5689	5691	5708	5710	5738	5740	5757	5759	5787	5789	5806	5808	5836	5838
	5855	5857	5887	5895	5913	5942	5944	5961	5963	5996	6000	6002	6021	6025	6027
	6063	6068	6071	6090	6092	6122	6147	6181	6219	6251	6254	6284	6288	6290	6318
	6321	6352	6374	6376	6413	6415	6446	6449	6452	6463	6489	6492	6495	6531	6577
	6579	6581	6583	6618	6622	6624	6664	6668	6670	6710	6714	6716	6756	6760	6762
	6802	6806	6808	6848	6852	6854	6894	6898	6900	6940	6944	6946	6986	6990	6992
	7034	7038	7040	7082	7086	7088	7130	7134	7136	7177	7181	7183	7224	7228	7230
	7271	7275	7277	7319	7323	7325	7366	7370	7372	7415	7419	7421	7462	7466	7468
	7509	7513	7515	7556	7560	7562	7603	7607	7609	7650	7654	7656	7697	7701	7703

	7744	7748	7750	7791	7795	7797	7839	7843	7845	7886	7890	7892	7933	7937	7939
	7980	7984	7986	8027	8031	8033	8074	8078	8080						
SETPRI	1413#	3706#	6120	6124	6145	6149	6168	6183	6205	6221					
SETVEC	1418#	3706#													
SLASH	1424#	3706#													
STARS	1438#	3706#													
SVC	1452#	3705#	3706												
XFER	1612#	3706#	4514#	6263#	6297#	6330#	6553#	6637#	6683#	6729#	6775#	6821#	6867#	6913#	6959#
	7005#	7053#	7101#	7149#	7196#	7243#	7290#	7338#	7385#	7434#	7481#	7528#	7575#	7622#	7669#
	7716#	7763#	7810#	7858#	7905#	7952#	7999#	8046#	8093#						
XFERF	1616#	3706#													
XFERT	1620#	3706#													
SMD	4439#	4455	4456	4457	4458	4459	4460	4461	4462	4463	4464	4465	4467	4469	4470
	4471	4472	4473	4474	4475	4476	4477	4478	4479	4480	4481	4482	4483	4484	4485
	4486	4487	4488												

. ABS. 040004 000

ERRORS DETECTED: 0

CZDMPC.BIC,CZDMPC.SEQ/CRF/DOC/NL:TOC=SVC34R.MLB,CZDMPC.P11

RUN-TIME: 46 55 6 SECONDS

RUN-TIME RATIO: 177/108=1.6

CORE USED: 21K (41 PAGES)

DOCUMENT PAGES: 236