

KD11-Z

11/24/44 UBI MAP  
CKKUAE0

AH-F629E-MC  
FICHE 1 OF 1

JUL 1982  
COPYRIGHT © 79-82  
MADE IN USA



A large grid of approximately 12 columns and 15 rows of small, illegible text blocks, likely representing a map or data table. The text is too small to read accurately but appears to be organized in a structured format.



1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38

.REM @

IDENTIFICATION

PRODUCT CODE:	AC-F627E-MC
PRODUCT NAME:	CKKUAEO 11/24/44 UBI MAP
DATE CREATED:	JANUARY, 1982
MAINTAINER:	DIAGNOSTIC ENGINEERING
AUTHOR:	DAN MILLEVILLE

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS MANUAL.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED TO THE PURCHASER UNDER A LICENSE FOR USE ON A SINGLE COMPUTER SYSTEM AND CAN BE COPIED (WITH INCLUSION OF DIGITAL'S COPYRIGHT NOTICE) ONLY FOR USE IN SUCH SYSTEM, EXCEPT AS MAY OTHERWISE BE PROVIDED IN WRITING BY DIGITAL.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1979, 1982 BY DIGITAL EQUIPMENT CORPORATION

39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55

HISTORY SECTION

CKKUAA0 WAS RELEASED OCTOBER, 1979 > INITIAL RELEASE  
 CKKUAB0 WAS RELEASED OCTOBER, 1980 > ADDITION OF UNIBUS MEMORY TEST  
 CKKUAC0 WAS RELEASED APRIL, 1981 > TESTING OF 11/24 MAP, 11/24 WITH UNIBUS  
 MEMORY ONLY, & POWER MONITOR BIT CHECK.  
 CKKUAD0 WAS RELEASED OCTOBER, 1981 > SETUP OF SOFTWARE/HARDWARE SWR ADDRESS  
 WAS ADDED TO STARTUP CODE.  
 > WHEN SELECTED, THE OPTIONAL CACHE TESTS  
 NOW RUN CORRECTLY.  
 CKKUAE0 WAS RELEASED JANUARY, 1982 > THE LMA TEST (11/24 ONLY) WAS MODIFIED TO  
 DO A MORE THOROUGH JOB OF CHECKING THE  
 ADDRESS LINES.

TABLE OF CONTENTS

56	
57	
58	1) ABSTRACT
59	
60	2) REQUIREMENTS
61	
62	2.1 EQUIPMENT
63	2.2 STORAGE
64	2.3 PRELIMINARY PROGRAMS
65	
66	3) LOADING PROCEDURE
67	
68	3.1 METHOD
69	
70	4) STARTING PROCEDURE
71	
72	4.1 STARTING ADDRESS
73	4.2 PROGRAM AND OPERATOR ACTION
74	4.3 SPECIAL STARTING PROCEDURE
75	
76	5) OPERATING PROCEDURE
77	
78	5.1 OPERATIONAL SWITCH SETTINGS
79	5.2 SUB-ROUTINE ABSTRACTS
80	5.3 RUNNING UNDER APT
81	
82	6) ERRORS
83	
84	6.1 ERROR HALTS AND DESCRIPTION
85	6.2 ERROR RECOVERY
86	6.3 SAMPLE ERROR MESSAGES
87	
88	7) RESTRICTIONS
89	
90	7.1 STARTING RESTRICTIONS
91	7.2 OPERATING RESTRICTIONS
92	
93	8) MISCELLANEOUS
94	
95	8.1 EXECUTION TIME
96	8.2 ADDRESS GENERATION IN THE PDP-11/44
97	
98	9) PROGRAM DESCRIPTION

99  
100  
101  
102  
103  
104  
105  
106  
107  
108  
109  
110  
111  
112  
113  
114  
115  
116  
117  
118  
119  
120  
121  
122  
123  
124  
125

1. ABSTRACT

THIS PROGRAM IS DESIGNED TO BE RUN ON A PDP 11/24 OR 11/44 ON WHICH THE CPU, CACHE (IF APPLICABLE), AND MEMORY MANAGEMENT DIAGNOSTIC PROGRAMS HAVE BEEN RUN. THE PROGRAM WILL DETECT ALL ERRORS THAT ORIGINATE WITH THE MAP BOX AND PROVIDE LOOPING CAPABILITIES SO THAT THE FIELD SERVICE ENGINEER CAN VERIFY THE FAILURES. THERE MAY BE SOME CASES, SUCH AS THE CACHE REGISTER DATA PATH, AND CACHE MEMORY DATA PATH, WHERE INTERACTION BETWEEN MODULES PROHIBITS CLOSE ISOLATION, BUT THE FAILING FUNCTION WILL BE CALLED OUT SO THE FIELD SERVICE ENGINEER CAN COMPLETE THE ISOLATION PROCESS.

IF THE PROGRAM CATCHES AN ERROR IN AN EARLY TEST AND IS ALLOWED TO CONTINUE RUNNING THROUGH THE LATER TESTS THE ERROR INDICATIONS FROM THOSE LATER TESTS MAY BE INVALID. THIS IS DUE TO THE STRUCTURE OF THE PROGRAM, WHICH ASSUMES THAT ALL AREAS TESTED PRIOR TO THE CURRENT TEST ARE FUNCTIONING PROPERLY.

THE ERROR TYPE OUTS WILL BE IN TABLE FORMAT, WITH A MESSAGE INDICATING

THE CLASS OF ERROR, A HEADER IDENTIFYING EACH COLUMN AND A REPORT OF ALL PERTINENT DATA. WHEN THE TEST CAN PRODUCE MORE THAN ONE ERROR CONDITION, A SUMMARY OF ERRORS WILL BE GIVEN AT THE END OF THAT TEST CONSISTING OF: THE LOGICAL 'AND' AND 'OR' OF THE DATA PREVIOUSLY REPORTED AND THE NUMBER OF ERRORS IN THIS TEST. (SEE SECTION 6.3 FOR AN EXAMPLE OF THE ERROR TYPEOUTS.)

126  
127  
128  
129  
130  
131  
132  
133  
134  
135  
136  
137  
138  
139  
140  
141  
142  
143  
144  
145

2. REQUIREMENTS

2.1 EQUIPMENT

THE BASIC PDP-11/24 OR 44 COMPUTER, INCLUDING THE CPU, CACHE (11/44 ONLY), MEMORY MANAGEMENT, AND AN LA-30 OR EQUIVALENT DEVICE FOR ERROR MESSAGES.

2.2 STORAGE

THIS PROGRAM WILL REQUIRE 8K TO LOAD BUT WILL UTILIZE ALL EXISTING CORE FOR A DUAL ADDRESSING TEST OF MEMORY FROM THE UNIBUS.

2.3 PRELIMINARY PROGRAMS

THE CPU, CACHE (IF APPLICABLE), AND MEMORY MANAGEMENT DIAGNOSTICS SHOULD BE RUN BEFORE THIS PROGRAM. THE MEMORY DIAGNOSTIC SHOULD AT LEAST MAKE A QUICK VERIFY OF THE AREA OF MEMORY THIS PROGRAM WILL LOAD AND RUN IN.

146  
147  
148  
149  
150  
151  
152

3. LOADING PROCEDURE

3.1 METHOD.

THIS PROGRAM CAN BE LOADED FROM ANY DEVICE THAT IS  
SUPPORTED BY XXDP AND SHOULD BE LOADED USING THE XXDP  
PROCEDURE FOR THAT DEVICE.

153 4. STARTING PROCEDURE  
154  
155 4.1 STARTING ADDRESS  
156 PROGRAM STARTS AT ADDRESS 200  
157  
158 4.2 PROGRAM AND/OR OPERATOR ACTION  
159  
160 THE PROGRAM WILL IDENTIFY ITSELF. IF CPU IS AN 11/44, PROGRAM  
161 WILL PROCEED WITH TESTING. IF CPU IS AN 11/24, AND LOCATION 176  
162 CONTAINS ZERO (SUCH AS JUST AFTER LOADING), PROGRAM WILL PROMPT  
163 FOR A SWITCH REGISTER INPUT. IF NONE IS REQUIRED, ENTER <CR>.  
164 IF YOU DO SO, PROGRAM WILL DEPOSIT A '1' IN LOCATION 176 (MEANINGLESS  
165 UNLESS BIT 8 IS ALSO SET) SO THAT SUBSEQUENT RUNNING OF THE PROGRAM  
166 WILL NOT RESULT IN THE SAME REQUEST. IF MANUFACTURING IS RUNNING  
167 THIS PROGRAM ON AN 11/24 WITH UNIBUS MEMORY ONLY (NO MAIN MEMORY),  
168 ENTER A NUMBER WITH AT LEAST BIT 11 SET (SWR=4000). THIS WILL KEY  
169 THE PROGRAM TO TEST THE 11/24 IN THAT CONFIGURATION.  
170  
171 4.3 SPECIAL STARTING PROCEDURE  
172  
173 IF IT APPEARS THAT THE CACHE IS CAUSING SOME TROUBLE AND  
174 YOU STILL WANT TO RUN THIS PROGRAM, IT IS POSSIBLE TO RUN  
175 WITH THE CACHE DISABLED. SIMPLY LOAD THE CACHE CONTROL  
176 REGISTER (17777746) WITH THE DESIRED NUMBER. THEN LOAD  
177 THE PC (17777707) WITH THE STARTING ADDRESS (200) AND  
178 PRESS 'CONTINUE'. THE PROGRAM WILL NOW RUN NORMALLY EXCEPT  
179 THAT CERTAIN TESTS WILL BE SKIPPED SINCE THE CACHE IS DISABLED.  
180 THIS FACT IS INDICATED IN THE ABSTRACT OF EACH TEST THAT  
181 CHECKS THE CACHE CONTROL REGISTER.  
182  
183 DEFINITION OF THE BITS IN THE CACHE CONTROL REGISTER:  
184 BIT00 -DISABLE TRAPS  
185 BIT02 -FORCE MISS ON READ,WHERE ADDRESS BIT 12 IS 0  
186 BIT03 -FORCE MISS ON READ,WHERE ADDRESS BIT 12 IS 1  
187 BIT09 -UNCONDITIONAL CACHE BYPASS  
188



189 5. OPERATING PROCEDURE  
 190  
 191 5.1 OPERATIONAL SWITCH SETTINGS  
 192  
 193 SW15 1= HALT ON ERROR  
 194 SW14 1= LOOP ON TEST  
 195 SW13 1= INHIBIT ERROR TYPEOUTS  
 196 SW12 1= INHIBIT TRACE TRAP  
 197 SW11 1= SET WHEN RUNNING AN 11/24 WITH NO MAIN MEMORY  
 198 AND ONLY UNIBUS MEMORY  
 199 SW10 1= BELL ON ERROR  
 200 SW09 1= LOOP ON ERROR  
 201 SW08 1= LOOP ON TEST IN SWR<05:00>  
 202 SW07 1= INHIBIT MULTIPLE ERROR TYPE OUTS  
 203 SW06 1= SELECT CACHE TESTS. THIS IS USED FOR  
 204 MFG. QUICK VERIFY STATION AND CAN BE SELECTED  
 205 BY APT SCRIPTING. THESE TESTS ASSUME THAT  
 206 ALL MODULES EXCEPT UBI MODULE ARE KNOWN GOOD.  
 207 SW05 1= SELECT UNIBUS MEMORY TESTS  
 208 SET WHEN A WINDOW EXISTS (SOME UBMAP JUMPERS CUT), AND  
 209 UNIBUS MEMORY OCCUPIES THE ENTIRE WINDOW ADDRESS AREA.  
 210  
 211 5.2 SUB-ROUTINE ABSTRACTS  
 212  
 213 ALL SUBROUTINE ABSTRACTS APPEAR IN THE CODE BEFORE THEIR  
 214 EXPANSION AND IN THE DOCUMENT THAT IMMEDIATELY FOLLOWS THIS.  
 215 BELOW IS A LIST OF THE SUBROUTINE TITLES.  
 216  
 217 5.2.1 MACRO LIBRARY SUBROUTINES (FOUND IN MOST PROGRAMS) (SOME IN THIS SOURCE)  
 218  
 219 SCOPE HANDLER ROUTINE  
 220 ERROR HANDLER ROUTINE  
 221 ERROR MESSAGE TYPE OUT ROUTINE  
 222 CONVERT 16-BIT VIRTUAL ADDRESSES TO 22-BIT PHYSICAL ADDRESSES  
 223 SAVE AND RESTORE R0-R5 ROUTINES  
 224 TYPE ROUTINE  
 225 BINARY TO OCTAL (ASCII) AND TYPE  
 226 CONVERT BINARY TO DECIMAL AND TYPE ROUTINE  
 227 TRAP DECODER  
 228 POWER DOWN AND UP ROUTINES  
 229 DOUBLE LENGTH BINARY TO OCTAL ASCII CONVERT ROUTINE  
 230 END OF PASS ROUTINE  
 231  
 232 5.2.2 SUBROUTINES UNIQUE TO THIS PROGRAM  
 233  
 234 SUBROUTINE TO TURN OFF AND SAVE T-BIT  
 235 SUBROUTINE TO RESTORE T-BIT TO ITS PREVIOUS CONDITION  
 236 SUBROUTINE TO CLEAR ALL OF THE MAP REGISTERS  
 237 SUBROUTINE TO EXTRACT MAP ADDRESS FROM PAR CONTENTS  
 238 SUBROUTINE TO DETERMINE 11/24 WITH UNIBUS MEM ONLY & CHECK LMA'S IF SO  
 239  
 240 5.2.3 TRAP AND ABORT HANDLER ROUTINES  
 241  
 242 CPU TRAP HANDLER ROUTINE  
 243 CACHE TRAPS AND ABORTS HANDLER ROUTINE  
 244 MEMORY MANAGEMENT TRAPS AND ABORTS HANDLER ROUTINE

5.3 RUNNING UNDER APT

THE EXECUTION TIMES PROVIDED IN THE APT SCRIPT THAT FOLLOWS ARE FOR EXECUTION WITH A 11/44 PROCESSOR, CACHE, 16K CORE MEMORY, AND 300 BAUD. THE FOLLOWING IS A PROGRAM LOAD FILE USED BY APT:

1. E TABLE 'A' IS USED FOR APT DUMP MODE.  
A. IN ADDITION TO NORMAL CPU DIAGNOSTIC TESTS, THIS TABLE WILL SELECT THE OPTIONAL CACHE TESTS, (\$SWREG=100).
2. E TABLE 'B' IS USED FOR APT QV MODE WHILE RUNNING ON A MANUFACTURING QV STATION. IT ACCOMPLISHES WHAT ETABLE 'A' DOES BUT ADDITIONALLY SUPPRESSES TYPEOUTS. (\$ENVM=240)
3. ETABLE 'C' IS USED FOR APT QV OR RUNTIME MODES WHILE RUNNING ON SYSTEMS OTHER THAN MFG. QV STATIONS. THIS TABLE DESELECTS THE OPTIONAL CACHE TESTS.
4. ETABLE 'D' IS USED BY MANUFACTURING TO RUN AN 11/24 UNDER APT WITH UNIBUS MEMORY AND NO MAIN MEMORY, AND BECAUSE OF NO CACHE IN AN 11/24, DESELECTS THE OPTIONAL CACHE TESTS.

1ST PASS	LONGEST	ADDITIONAL
RUN TIME	TEST TIME	RUN TIME
10	5	0

..... E TABLES .....

	A	B	C	D
E-MODE/S-MODE (\$ENVM/\$ENV)	000/000	240/001	240/001	240/001
SWITCH REGISTER 1 (\$SWREG)	000100	000100	000000	004000
SWITCH REGISTER 2	000000	000000	000000	000000
CPU TYPE/OPTIONS	00/0000	00/0000	00/0000	00/0000
MEMORY MAP CODE 1	000/0000	000/0000	000/0000	000/0000
MEMORY MAP CODE 2	000/0000	000/0000	000/0000	000/0000
MEMORY MAP CODE 3	000/0000	000/0000	000/0000	000/0000
MEMORY MAP CODE 4	000/0000	000/0000	000/0000	000/0000
BUS PRIORITY/INTERRUPT 1	0000	0000	0000	0000
BUS PRIORITY/INTERRUPT 2	0000	0000	0000	0000
BASE ADDRESS CODE	000000	000000	000000	000000
DEVICE MAP CODE	000000	000000	000000	000000
CTLR. SPECIFIC WORD 1	000000	000000	000000	000000
CTLR. SPECIFIC WORD 2	000000	000000	000000	000000
DEVICE DESCRIPTOR WORD 0	177777	177777	177777	177777
DEVICE DESCRIPTOR WORD 1	177777	177777	177777	177777
DEVICE DESCRIPTOR WORD 2	000000	000000	000000	000000
	THROUGH			
DEVICE DESCRIPTOR WORD 15	000000	000000	000000	000000

245  
246  
247  
248  
249  
250  
251  
252  
253  
254  
255  
256  
257  
258  
259  
260  
261  
262  
263  
264  
265  
266  
267  
268  
269  
270  
271  
272  
273  
274  
275  
276  
277  
278  
279  
280  
281  
282  
283  
284  
285  
286  
287  
288  
289  
290  
291  
292  
293  
294  
295  
296  
297

298  
299  
300  
301  
302  
303  
304  
305  
306  
307  
308  
309  
310  
311  
312  
313  
314  
315  
316  
317  
318  
319  
320  
321  
322  
323  
324  
325  
326  
327  
328  
329  
330  
331  
332  
333  
334

## 6. ERRORS

## 6.1 ERROR HALTS AND DESCRIPTION

WHEN AN ERROR IS DETECTED AN 'ERROR' (EMT) INSTRUCTION IS EXECUTED AND THE 'ERROR HANDLER ROUTINE' CHECKS THE SWITCH REGISTER FOR MODE SELECTED.

THE PROGRAM WILL:

HALT ON ERROR	IF SW15=1
INHIBIT ERROR TYPE OUT	IF SW13=1
RING BELL ON ERROR	IF SW10=1
LOOP ON ERROR	IF SW9=1

## 6.2 ERROR RECOVERY

IF SW09=1, THE PROGRAM WILL LOOP BACK TO THE POINT WHERE THE INSTRUCTION THAT CAUSED THE ERROR WAS EXECUTED, WITHOUT ALLOWING ANY OF THE CONDITIONS TO CHANGE. THIS WILL PROVIDE THE TIGHTEST POSSIBLE SCOPE LOOP.

IF SW09=0, EACH ERROR WILL BE REPORTED AND LOGGED AND, AT THE END OF EACH TEST, A SUMMARY OF ALL ERRORS OCCURRING IN THAT TEST WILL BE PROVIDED. THE SUMMARY CONSISTS OF THE LOGICAL AND AND OR OF THE ADDRESS AND/OR DATA THAT WAS WRONG.

IF THE POWER MONITOR BIT ERROR IS CALLED, YOU MUST CORRECT THE POWER SUPPLY OR CPU ERROR REGISTER PROBLEM BEFORE YOU CAN RELY ON THE RESULTS OF THIS DIAGNOSTIC. THE ERROR CAN BE CALLED AT 1 OF 2 PLACES - 1) IN THE SCOPE ROUTINE EXECUTED AT THE BEGINNING OF EACH TEST, AND 2) IN AN ERROR CALL IN CASE BIT BECOMES SET AFTER THE SCOPE. IF THE BIT IS CAUGHT IN THE ERROR ROUTINE, \*TWO\* ERRORS WILL CALL - 1) POWER MONITOR BIT ERROR WILL CALL FIRST TO ALERT YOU TO THE POSSIBILITY THE PROBLEM COULD BE CAUSED BY THE OUT-OF-SPEC POWER SUPPLY, AND THEN THE ERROR THAT WAS TO CALL.

6.3 SAMPLE ERROR TYPE OUTS  
SEE '\$ERRTB:' FOR SAMPLE ERROR TYPEOUTS.

335  
336  
337  
338  
339  
340  
341  
342  
343  
344  
345  
346  
347  
348  
349  
350  
351  
352  
353

6.3.1 MULTIPLE TYPE ERRORS: AN EXAMPLE:

THE FOLLOWING REGISTERS TIMED OUT WHEN REFERENCED

REG.ADR	TESTNO	ERRORPC
170210	000001	015226
170212	000001	015232
.	.	.
.	TO	.
.	.	.
170372	000001	015232
170374	000001	015232
170376	000001	015232

SUMMARY OF MAP REGISTERS THAT TIMED OUT ON READ

REGADRS	REGADRS	#ERRORS	TESTNO	ERRORPC
'OR'	'AND'			
170376	170210	32	000001	010530

354	7.	RESTRICTIONS
355		
356	7.1	STARTING RESTRICTIONS
357		
358		NONE
359		
360	7.2	OPERATING RESTRICTIONS
361		
362		NONE

363  
364  
365  
366  
367  
368  
369  
370  
371  
372  
373  
374  
375  
376  
377  
378  
379  
380  
381  
382  
383  
384  
385  
386  
387  
388  
389  
390  
391  
392  
393  
394  
395  
396  
397  
398  
399  
400  
401  
402  
403  
404  
405  
406  
407  
408  
409  
410  
411  
412  
413  
414  
415  
416

8. MISCELLANEOUS

8.1 EXECUTION TIME

THE RUN TIME FOR ANY PASS IS APPROXIMATELY 3 SECONDS.

8.2 ADDRESS GENERATION IN THE PDP-11/44

THE FOLLOWING IS AN EXAMPLE OF HOW A MEMORY ADDRESS IS GENERATED BY THE UNIBUS MAP. THIS ASSUMES THAT THE ADDRESS ORIGINATES IN THE CPU BUT THE PROCESS CAN APPLY TO ANY UNIBUS ADDRESS, STARTING AT LINE C2.

A. VIRTUAL ADDRESS	15 14 13 12 11 10 09 08 07 06 05 04 03 02 01 00
A1. P.A.R. PAGE NUMBER (0-7)	15 14 13
A2. OFFSET (FROM VIRTUAL ADDRESS)	12 11 10 09 08 07 06 05 04 03 02 01 00
B. P.A.R.[PAGE NO.] +	15 14 13 12 11 10 09 08 07 06 05 04 03 02 01 00
C. PHYS ADDRS (A2+B)	21 20 19 18 17 16 15 14 13 12 11 10 09 08 07 06 05 04 03 02 01 00
C1. 17XXXXXX=> U.B.ADR.	21 20 19 18
C2. MAPPING REG.NO.(0-36)	17 16 15 14 13
C3. OFFSET	12 11 10 09 08 07 06 05 04 03 02 01 00
D. MAP REG.[NO.] +	21 20 19 18 17 16 15 14 13 12 11 10 09 08 07 06 05 04 03 02 01
E. PHYS ADDR (C3+D)	21 20 19 18 17 16 15 14 13 12 11 10 09 08 07 06 05 04 03 02 01 00

DESCRIPTION OF LINES:

A: VIRTUAL ADDRESS (16 BITS)

A1: UPPER 3 BITS OF VIRTUAL ADDRESS, USED TO SELECT A PAGE ADDRESS REGISTER (PAR)

A2: LOWER 13 BITS OF VIRTUAL ADDRESS, ADDED TO SELECTED PAR

B: PAGE ADDRESS REGISTER (16 BITS), IN ADDITION PROCESS THIS GETS LEFT SHIFTED 6 BITS BEFORE ADDITION TO A2

C: PHYSICAL ADDRESS CREATED BY MEMORY MANAGEMENT, (22 BITS)

C1: IF UPPER 4 BITS ARE ALL ONES THEN BITS <17:00> GO OUT ON UNIBUS

C2: IF MAP RELOCATION IS ENABLED THEN BITS <17:13> SELECT ONE OF THE 36 (OCTAL) MAP REGISTERS.

C3: LOWER 13 BITS OF UNIBUS ADDRESS, ADDED TO SELECTED MAP REGISTER

D: MAP REGISTER (22 BITS), ADDED TO BITS <12:00> OF UNIBUS ADDRESS

E: PHYSICAL ADDRESS GENERATED BY UNIBUS MAP AND SENT TO THE CACHE.

417  
418  
419  
420  
421

9. PROGRAM DESCRIPTION

THE ASSEMBLED LISTING, CKKUAE.SEO, HAS A PARAGRAPH DESCRIBING EACH OF THE TESTS. THE PARAGRAPH WILL INDICATE IF THE TEST IS RUN CONDITIONALLY ON THE STATUS ON THE CACHE CONTROL REGISTER.ⓐ

1485

```

.TITLE CKKUAEO 11/24/44 UBI MAP
.*COPYRIGHT (C) JANUARY 1982
.*DIGITAL EQUIPMENT CORP.
.*MAYNARD, MASS. 01754
.*
.*PROGRAM BY DAN P. MILLEVILLE
.*
.*THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC
.*PACKAGE (MAINDEC-11-DZQAC-C5), JAN, 1981.

```

1486

```

.SBTTL OPERATIONAL SWITCH SETTINGS

```

SWITCH	USE
15	HALT ON ERROR
14	LOOP ON TEST
13	INHIBIT ERROR TYPEOUTS
12	INHIBIT TRACE TRAP
11	INHIBIT TRACE TRAP
10	BELL ON ERROR
9	LOOP ON ERROR
8	LOOP ON TEST IN SWR<4:0>
7	INHIBIT MULTIPLE ERROR TYPEOUTS
6	SELECT CACHE-CIS TESTS
5	SELECT MEMORY ON UNIBUS TEST

1487

1488



1489

```

.SBTTL BASIC DEFINITIONS
;*INITIAL ADDRESS OF THE STACK POINTER *** 1100 ***
001100 STACK= 1100 ;;FIRST ADDRESS OF THE STACK
001100 KERSTK= STACK ;;KERNEL STACK
000700 SUPSTK= STACK-200 ;;SUPERVISOR STACK
000600 USESTK= STACK-300 ;;USER STACK
104000 ERROR=EMT
000004 SCOPE=IOT
177776 PS= 177776 ;;PROCESSOR STATUS WORD
177776 PSW=PS
177774 STKLMT= 177774 ;;STACK LIMIT REGISTER
177772 PIRQ= 177772 ;;PROGRAM INTERRUPT REQUEST REGISTER
177570 DSWR= 177570 ;;HARDWARE SWITCH REGISTER
177570 DDISP= 177570 ;;HARDWARE DISPLAY REGISTER
177546 LKS= 177546 ;;LINE CLOCK (KW11-L) STATUS REGISTER
;*MISCELLANEOUS DEFINITIONS
000011 HT= 11 ;;CODE FOR HORIZONTAL TAB
000012 LF= 12 ;;CODE LINE FEED
000015 CR= 15 ;;CODE CARRIAGE RETURN
000200 CRLF= 200 ;;CODE FOR CARRIAGE RETURN-LINE FEED
;*GENERAL PURPOSE REGISTER DEFINITIONS
000000 R0= %0 ;;GENERAL REGISTER
000001 R1= %1 ;;GENERAL REGISTER
000002 R2= %2 ;;GENERAL REGISTER
000003 R3= %3 ;;GENERAL REGISTER
000004 R4= %4 ;;GENERAL REGISTER
000005 R5= %5 ;;GENERAL REGISTER
000006 R6= %6 ;;GENERAL REGISTER
000007 R7= %7 ;;GENERAL REGISTER
000000 R10=R0
000001 R11=R1
000002 R12=R2
000003 R13=R3
000004 R14=R4
000005 R15=R5
000006 SP= %6 ;;STACK POINTER
000006 KSP=SP
000006 SSP=SP
000006 USP=SP
000007 PC= %7 ;;PROGRAM COUNTER
;*PRIORITY LEVEL DEFINITIONS
000000 PR0= 0 ;;PRIORITY LEVEL 0
000040 PR1= 40 ;;PRIORITY LEVEL 1
000100 PR2= 100 ;;PRIORITY LEVEL 2
000140 PR3= 140 ;;PRIORITY LEVEL 3
000200 PR4= 200 ;;PRIORITY LEVEL 4
000240 PR5= 240 ;;PRIORITY LEVEL 5
000300 PR6= 300 ;;PRIORITY LEVEL 6
000340 PR7= 340 ;;PRIORITY LEVEL 7
;*SWITCH REGISTER SWITCH DEFINITIONS
100000 SW15= 100000
040000 SW14= 40000
020000 SW13= 20000
010000 SW12= 10000
004000 SW11= 4000
002000 SW10= 2000
001000 SW09= 1000
    
```

```
000400 SW08= 400
000200 SW07= 200
000100 SW06= 100
000040 SW05= 40
000020 SW04= 20
000010 SW03= 10
000004 SW02= 4
000002 SW01= 2
000001 SW00= 1
001000 SW9=SW09
000400 SW8=SW08
000200 SW7=SW07
000100 SW6=SW06
000040 SW5=SW05
000020 SW4=SW04
000010 SW3=SW03
000004 SW2=SW02
000002 SW1=SW01
000001 SW0=SW00
;*DATA BIT DEFINITIONS (BIT00 TO BIT15)
100000 BIT15= 100000
040000 BIT14= 40000
020000 BIT13= 20000
010000 BIT12= 10000
004000 BIT11= 4000
002000 BIT10= 2000
001000 BIT09= 1000
000400 BIT08= 400
000200 BIT07= 200
000100 BIT06= 100
000040 BIT05= 40
000020 BIT04= 20
000010 BIT03= 10
000004 BIT02= 4
000002 BIT01= 2
000001 BIT00= 1
001000 BIT9=BIT09
000400 BIT8=BIT08
000200 BIT7=BIT07
000100 BIT6=BIT06
000040 BIT5=BIT05
000020 BIT4=BIT04
000010 BIT3=BIT03
000004 BIT2=BIT02
000002 BIT1=BIT01
000001 BIT0=BIT00
;*BASIC "CPU" TRAP VECTOR ADDRESSES
000004 ERRVEC= 4 ;;TIME OUT AND OTHER ERRORS
000010 RESVEC= 10 ;;RESERVED AND ILLEGAL INSTRUCTIONS
000014 TBITVEC=14 ;;'T' BIT
000014 TRTVEC= 14 ;;TRACE TRAP
000014 BPTVEC= 14 ;;BREAKPOINT TRAP (BPT)
000020 IOTVEC= 20 ;;INPUT/OUTPUT TRAP (IOT) **SCOPE**
000024 PWRVEC= 24 ;;POWER FAIL
000030 EMTVEC= 30 ;;EMULATOR TRAP (EMT) **ERROR**
000034 TRAPVEC=34 ;;'TRAP' TRAP
000060 TKVEC= 60 ;;TTY KEYBOARD VECTOR
```

```

000064 TPVEC= 64          ;;TTY PRINTER VECTOR
000100 LKVEC= 100         ;;LINE CLOCK (KW11-L) VECTER
000114 CACHVEC=114      ;;CACHE ERROR INTERRUPT VECTOR
000240 PIQVEC=240      ;;PROGRAM INTERRUPT REQUEST VECTOR
000250 MMVEC= 250        ;;MEMORY MANAGEMENT VECTOR

.SBTTL CACHE REGISTER DEFINITIONS
177740 LOADRS = 177740 ;;LOWER 16 BITS OF ADDRESS THAT CAUSED ERROR
177742 HIADRS = 177742 ;;UPPER SIX BITS OF ADDRESS THAT CAUSED ERROR
177744 MEMERR = 177744 ;;CACHE ERROR REGISTER
177746 CONTRL = 177746 ;;MEMORY CONTROL REGISTER
177750 MAINT = 177750 ;;MEMORY MAINTENANCE REGISTER
177752 HITMIS = 177752 ;;HIT MISS REGISTER '1' IMPLIES HIT IN CACHE

.SBTTL CPU REGISTER DEFINITIONS
177760 SIZELO = 177760 ;;MEMORY SIZE REGISTER NUMBER TO PUT INTO A PAR
;;TO GET TO THE LAST 32 WORDS OF MEMORY
177762 SIZEHI = 177762 ;;HIGH SIZE REGISTER, RESERVED FOR FUTURE USE
;;CURRENTLY ALL ZERO
177764 SYSTID = 177764 ;;SYSTEM ID REGISTER
177766 CPUERR = 177766 ;;CPU ERROR REGISTER HOLDS CONDITION THAT CAUSED
;;THE TRAP TO ERRVEC (000004)

.SBTTL MEMORY MANAGEMENT DEFINITIONS
;*MEMORY MANAGEMENT STATUS REGISTER ADDRESSES
177572 MMR0= 177572
177574 MMR1= 177574
177576 MMR2= 177576
172516 MMR3= 172516
177572 SR0=MMR0
177574 SR1=MMR1
177576 SR2=MMR2
172516 SR3=MMR3

;*USER 'I' PAGE DESCRIPTOR REGISTERS
177600 UIPDR0= 177600
177602 UIPDR1= 177602
177604 UIPDR2= 177604
177606 UIPDR3= 177606
177610 UIPDR4= 177610
177612 UIPDR5= 177612
177614 UIPDR6= 177614
177616 UIPDR7= 177616

;*USER 'D' PAGE DESCRIPTOR REGISTORS
177620 UDPDR0= 177620
177622 UDPDR1= 177622
177624 UDPDR2= 177624
177626 UDPDR3= 177626
177630 UDPDR4= 177630
177632 UDPDR5= 177632
177634 UDPDR6= 177634
177636 UDPDR7= 177636

;*USER 'I' PAGE ADDRESS REGISTERS
177640 UIPAR0= 177640
177642 UIPAR1= 177642
177644 UIPAR2= 177644
177646 UIPAR3= 177646
177650 UIPAR4= 177650
177652 UIPAR5= 177652
177654 UIPAR6= 177654
177656 UIPAR7= 177656
    
```

```

177660      ;*USER 'D' PAGE ADDRESS REGISTERS
177662      UDPAR0= 177660
177664      UDPAR1= 177662
177666      UDPAR2= 177664
177670      UDPAR3= 177666
177672      UDPAR4= 177670
177674      UDPAR5= 177672
177676      UDPAR6= 177674
177676      UDPAR7= 177676
172200      ;*SUPERVISOR 'I' PAGE DESCRIPTOR REGISTERS
172202      SIPDR0= 172200
172204      SIPDR1= 172202
172206      SIPDR2= 172204
172210      SIPDR3= 172206
172212      SIPDR4= 172210
172214      SIPDR5= 172212
172216      SIPDR6= 172214
172216      SIPDR7= 172216
172220      ;*SUPERVISOR 'D' PAGE DESCRIPTOR REGISTERS
172222      SDPDR0= 172220
172224      SDPDR1= 172222
172226      SDPDR2= 172224
172230      SDPDR3= 172226
172232      SDPDR4= 172230
172234      SDPDR5= 172232
172236      SDPDR6= 172234
172236      SDPDR7= 172236
172240      ;*SUPERVISOR 'I' PAGE ADDRESS REGISTERS
172242      SIPAR0= 172240
172244      SIPAR1= 172242
172246      SIPAR2= 172244
172250      SIPAR3= 172246
172252      SIPAR4= 172250
172254      SIPAR5= 172252
172256      SIPAR6= 172254
172256      SIPAR7= 172256
172260      ;*SUPERVISOR 'D' PAGE ADDRESS REGISTERS
172262      SDPAR0= 172260
172264      SDPAR1= 172262
172266      SDPAR2= 172264
172270      SDPAR3= 172266
172272      SDPAR4= 172270
172274      SDPAR5= 172272
172276      SDPAR6= 172274
172276      SDPAR7= 172276
172300      ;*KERNEL 'I' PAGE DESCRIPTOR REGISTERS
172302      KIPDR0= 172300
172304      KIPDR1= 172302
172306      KIPDR2= 172304
172310      KIPDR3= 172306
172312      KIPDR4= 172310
172314      KIPDR5= 172312
172316      KIPDR6= 172314
172316      KIPDR7= 172316
172320      ;*KERNEL 'D' PAGE DESCRIPTOR REGISTERS
172322      KDPDR0= 172320
172322      KDPDR1= 172322
```

```
172324 KDPDR2= 172324
172326 KDPDR3= 172326
172330 KDPDR4= 172330
172332 KDPDR5= 172332
172334 KDPDR6= 172334
172336 KDPDR7= 172336
;*KERNEL 'I' PAGE ADDRESS REGISTERS
172340 KIPAR0= 172340
172342 KIPAR1= 172342
172344 KIPAR2= 172344
172346 KIPAR3= 172346
172350 KIPAR4= 172350
172352 KIPAR5= 172352
172354 KIPAR6= 172354
172356 KIPAR7= 172356
;*KERNEL 'D' PAGE ADDRESS REGISTERS
172360 KDPAR0= 172360
172362 KDPAR1= 172362
172364 KDPAR2= 172364
172366 KDPAR3= 172366
172370 KDPAR4= 172370
172372 KDPAR5= 172372
172374 KDPAR6= 172374
172376 KDPAR7= 172376
.SBTTL UNIBUS MAP REGISTER DEFINITIONS
;*THE LOWER 16 BITS OF THE MAP REGISTERS ARE LABELED 'MAPLXX'
;*THE UPPER 6 BITS OF THE MAP REGISTERS ARE LABELED 'MAPHXX'
170200 MAPL00 = 170200
170202 MAPH00 = 170202
170204 MAPL01 = 170204
170206 MAPH01 = 170206
170210 MAPL02 = 170210
170212 MAPH02 = 170212
170214 MAPL03 = 170214
170216 MAPH03 = 170216
170220 MAPL04 = 170220
170222 MAPH04 = 170222
170224 MAPL05 = 170224
170226 MAPH05 = 170226
170230 MAPL06 = 170230
170232 MAPH06 = 170232
170234 MAPL07 = 170234
170236 MAPH07 = 170236
170240 MAPL10 = 170240
170242 MAPH10 = 170242
170244 MAPL11 = 170244
170246 MAPH11 = 170246
170250 MAPL12 = 170250
170252 MAPH12 = 170252
170254 MAPL13 = 170254
170256 MAPH13 = 170256
170260 MAPL14 = 170260
170262 MAPH14 = 170262
170264 MAPL15 = 170264
170266 MAPH15 = 170266
170270 MAPL16 = 170270
170272 MAPH16 = 170272
```

170274	MAPL17 = 170274
170276	MAPH17 = 170276
170300	MAPL20 = 170300
170302	MAPH20 = 170302
170304	MAPL21 = 170304
170306	MAPH21 = 170306
170310	MAPL22 = 170310
170312	MAPH22 = 170312
170314	MAPL23 = 170314
170316	MAPH23 = 170316
170320	MAPL24 = 170320
170320	MAPH24 = 170320
170324	MAPL25 = 170324
170326	MAPH25 = 170326
170330	MAPL26 = 170330
170332	MAPH26 = 170332
170334	MAPL27 = 170334
170336	MAPH27 = 170336
170340	MAPL30 = 170340
170342	MAPH30 = 170342
170344	MAPL31 = 170344
170346	MAPH31 = 170346
170350	MAPL32 = 170350
170352	MAPH32 = 170352
170354	MAPL33 = 170354
170356	MAPH33 = 170356
170360	MAPL34 = 170360
170362	MAPH34 = 170362
170364	MAPL35 = 170364
170366	MAPH35 = 170366
170370	MAPL36 = 170370
170372	MAPH36 = 170372
170374	MAPL37 = 170374
170376	MAPH37 = 170376
170200	MAPL0=MAPL00
170202	MAPH0=MAPH00
170204	MAPL1=MAPL01
170206	MAPH1=MAPH01
170210	MAPL2=MAPL02
170212	MAPH2=MAPH02
170214	MAPL3=MAPL03
170216	MAPH3=MAPH03
170220	MAPL4=MAPL04
170222	MAPH4=MAPH04
170224	MAPL5=MAPL05
170226	MAPH5=MAPH05
170230	MAPL6=MAPL06
170232	MAPH6=MAPH06
170234	MAPL7=MAPL07
170236	MAPH7=MAPH07

.....

1492  
000000  
  
000174 000174  
000174 000000  
000176 000000  
  
000200 000137 010000

```
.SBTTL TRAP CATCHER
.=0
;*ALL UNUSED LOCATIONS FROM 4 - 776 CONTAIN A ".+2,HALT"
;*SEQUENCE TO CATCH ILLEGAL TRAPS AND INTERRUPTS
;*LOCATION 0 CONTAINS 0 TO CATCH IMPROPERLY LOADED VECTORS
.=174
DISPREG: .WORD 0          ;;SOFTWARE DISPLAY REGISTER
SWREG:   .WORD 0          ;;SOFTWARE SWITCH REGISTER
.SBTTL  STARTING ADDRESS(ES)
        JMP @#START ;;JUMP TO STARTING ADDRESS OF PROGRAM
```

1494

000204  
000046  
000046 022024  
000052 000052  
000052 000000  
000204

```
.SBTTL ACT11 HOOKS  
:*****  
:HOOKS REQUIRED BY ACT11  
    $SVPC=.           ;SAVE PC  
    .=46              ;:1)SET LOC.46 TO ADDRESS OF $ENDAD IN .$EOP  
    $ENDAD            ;:2)SET LOC.52 TO ZERO  
    .=52              ;: RESTORE PC  
    .WORD 0  
    .= $SVPC
```



1496

.SBTTL COMMON TAGS

\*\*\*\*\*  
\*THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIJNS  
\*USED IN THE PROGRAM.

Address	Value	Label	Format	Value	Description
001100	001100	\$CMTAG:			:: START OF COMMON TAGS
		:\$PASS:	.WORD	0	:: CONTAINS PASS COUNT ;DPM001
001100	000	\$TSTNM:	.BYTE	0	:: CONTAINS THE TEST NUMBER
001101	000	\$ERFLG:	.BYTE	0	:: CONTAINS ERROR FLAG
001102	000000	\$ICNT:	.WORD	0	:: CONTAINS SUBTEST ITERATION COUNT
001104	000000	\$LPADR:	.WORD	0	:: CONTAINS SCOPE LOOP ADDRESS
001106	000000	\$LPERR:	.WORD	0	:: CONTAINS SCOPE RETURN FOR ERRORS
001110	000000	\$ERTTL:	.WORD	0	:: CONTAINS TOTAL ERRORS DETECTED
001112	000	\$ITEMB:	.BYTE	0	:: CONTAINS ITEM CONTROL BYTE
001113	001	\$ERMAX:	.BYTE	1	:: CONTAINS MAX. ERRORS PER TEST
001114	000000	\$ERRPC:	.WORD	0	:: CONTAINS PC OF LAST ERROR INSTRUCTION
001116	000000	\$GDADR:	.WORD	0	:: CONTAINS ADDRESS OF 'GOOD' DATA
001120	000000	\$BDADR:	.WORD	0	:: CONTAINS ADDRESS OF 'BAD' DATA
001122	000000	\$GDDAT:	.WORD	0	:: CONTAINS 'GOOD' DATA
001124	000000	\$BDDAT:	.WORD	0	:: CONTAINS 'BAD' DATA
001126	000000		.WORD	0	:: RESERVED--NOT TO BE USED
001130	000000		.WORD	0	
001132	000	\$AUTOB:	.BYTE	0	:: AUTOMATIC MODE INDICATOR
001133	000	\$INTAG:	.BYTE	0	:: INTERRUPT MODE INDICATOR
001134	000000		.WORD	0	
001136	177570	\$SWR:	.WORD	DSWR	:: ADDRESS OF SWITCH REGISTER
001140	177570	\$DISPLAY:	.WORD	DDISP	:: ADDRESS OF DISPLAY REGISTER
001142	177560	\$TKS:	.WORD	177560	:: TTY KBD STATUS
001144	177562	\$TKB:	.WORD	177562	:: TTY KBD BUFFER
001146	177564	\$TPS:	.WORD	177564	:: TTY PRINTER STATUS REG. ADDRESS
001150	177566	\$TPB:	.WORD	177566	:: TTY PRINTER BUFFER REG. ADDRESS
001152	000	\$NULL:	.BYTE	0	:: CONTAINS NULL CHARACTER FOR FILLS
001153	002	\$FILLS:	.BYTE	2	:: CONTAINS # OF FILLER CHARACTERS REQUIRED
001154	012	\$FILLC:	.BYTE	12	:: INSERT FILL CHARS. AFTER A 'LINE FEED'
001155	000	\$TPFLG:	.BYTE	0	:: 'TERMINAL AVAILABLE' FLAG (BIT<07>=0=YES)
001156	000000	\$REGAD:	.WORD	0	:: CONTAINS THE ADDRESS FROM WHICH (\$REGO) WAS OBTAINED
	000006		.REPT	\$CM3	
001160	000000	\$REG0:	.WORD	0	:: CONTAINS ((\$REGAD)+0)
001162	000000	\$REG1:	.WORD	0	:: CONTAINS ((\$REGAD)+2)
001164	000000	\$REG2:	.WORD	0	:: CONTAINS ((\$REGAD)+4)
001166	000000	\$REG3:	.WORD	0	:: CONTAINS ((\$REGAD)+6)
001170	000000	\$REG4:	.WORD	0	:: CONTAINS ((\$REGAD)+10)
001172	000000	\$REG5:	.WORD	0	:: CONTAINS ((\$REGAD)+12)
	000007		.REPT	7	
001174	000000	\$TMP0:	.WORD	0	:: USER DEFINED
001176	000000	\$TMP1:	.WORD	0	:: USER DEFINED
001200	000000	\$TMP2:	.WORD	0	:: USER DEFINED
001202	000000	\$TMP3:	.WORD	0	:: USER DEFINED
001204	000000	\$TMP4:	.WORD	0	:: USER DEFINED
001206	000000	\$TMP5:	.WORD	0	:: USER DEFINED
001210	000000	\$TMP6:	.WORD	0	:: USER DEFINED
001212	000000	\$TIMES:	.WORD	0	:: MAX. NUMBER OF ITERATIONS
001214	000000	\$ESCAPE:	.WORD	0	:: ESCAPE ON ERROR ADDRESS
001216	207	\$BELL:	.ASCIZ	<207><377><377>	:: CODE FOR BELL

001222	077		\$QUES: .ASCII	/?/	:: QUESTION MARK
001223	015		\$CRLF: .ASCII	<15>	:: CARRIAGE RETURN
001224	012	000	\$LF: .ASCIZ	<12>	:: LINE FEED
:*****					
001226	000000		PADRSL: .WORD	0	:: HOLDS THE LOWER 16 BITS OF A 22 BIT ADDRESS : GENERATED FOR TYPE OUT.
001230	000000		PADRSR: .WORD	0	:: HOLDS THE UPPER 6 BITS OF A 22 BIT ADDRESS : GENERATED FOR TYPE OUT.
001232	000000	000077	ADRAND: .WORD	0,77	:: LOGICAL AND OF FAILING ADDRESSES
001236	000000	000077	ADDROR: .WORD	0,77	:: LOGICAL OR OF FAILING ADDRESSES
001242	000000	000077	DATAND: .WORD	0,77	:: LOGICAL AND OF BAD DATA
001246	000000	000077	DATAOR: .WORD	0,77	:: LOGICAL OR OF BAD DATA
001252	000000		PATAND: .WORD	0	:: LOGICAL AND OF PATTERN LOADED
001254	000000		PATOR: .WORD	0	:: LOGICAL OR OF PATTERN LOADED
001256	000000		LOWEST: .WORD	0	:: HOLDS NUMBER TO PUT IN PAR TO CAUSE THE : LOWEST USABLE MAP REGISTER TO RESPOND
001260	000000		HIGEST: .WORD	0	:: HOLDS NUMBER TO PUT IN PAR TO CAUSE THE : HIGHEST USABLE MAP REGISTER TO RESPOND
001262	000000		UBMLOW: .WORD	0	:: HOLDS NUMBER TO PUT IN PAR TO SIGNAL 1ST : ADDRESS OF UNIBUS MEMORY
001264	000000		UBMHI: .WORD	0	:: HOLDS NUMBER TO PUT IN PAR TO SIGNAL LAST : BLOCK OF 4K OF UNIBUS MEMORY
001266	000000		MMRLOW: .WORD	0	:: HOLDS LOWEST MAP REGISTER NUMBER FROM 'LOWEST:'
001270	000000		MMRHI: .WORD	0	:: HOLDS HIGHEST MAP REGISTER NUMBER FROM 'HIGEST:'
001272	000000		UBRLOW: .WORD	0	:: HOLDS LOWEST MAP REGISTER NUMBER FROM 'UBMLOW:'
001274	000000		UBRHI: .WORD	0	:: HOLDS HIGHEST MAP REGISTER NUMBER FROM 'UBMHI:'
001276	000000		BUPWIN: .WORD	0	:: HOLDS LOWEST USEABLE PAR OF UPPER WINDOW
001300	000000		LREGL: .WORD	0	:: HOLDS I/O PAGE ADDR OF LOW 16 BITS OF : THE LOWEST USABLE MAP REGISTER
001302	000000		LREGU: .WORD	0	:: HOLDS I/O PAGE ADDR OF HIGH 6 BITS OF : OF THE LOWEST USABLE MAP REGISTER
001304	000000		LMAH: .WORD	0	:: LOCATION TO HOLD LMA HIGH REGISTER CONTENTS
001306	000000		LMAL: .WORD	0	:: LOCATION TO HOLD LMA LOW REGISTER CONTENTS
001310	000000		UBM24L: .WORD	0	:: LOCATION USED TO HOLD LMA LOW EXPECTED VALUE
001312	000000		UBM24U: .WORD	0	:: LOCATION USED TO HOLD LMA HIGH EXPECTED VALUE
001314	000000		UBM24P: .WORD	0	:: LOCATION USED TO HOLD LMA LOW PRELOAD VALUE
001316	000000		NUMOFK: .WORD	0	:: LOCATION TO HOLD NUMBER OF K OF UB MEMORY
001320	000000		ERRCNT: .WORD	0	:: MULTIPLE ERROR ERROR COUNTER
001322	000000		CNTR: .WORD	0	:: AUXILIARY COUNTER
001324	000000		FLAG: .WORD	0	:: FLAG TO INDICATE TO LAST PROGRAM PASS N
001326	000000		CPUEXP: .WORD	0	:: HOLDS THE EXPECTED CPU ERROR CODE
001330	000000		PCPUER: .WORD	0	:: HOLDS RECEIVED CPU ERROR CONDITION
001332	000000		PPARER: .WORD	0	:: HOLDS RECEIVED PARITY ERROR CONDITION
001334	000000		PCONTR: .WORD	0	:: HOLDS CONTENTS OF CONTROL REGISTER
001336	000000		PMAINT: .WORD	0	:: HOLDS CONTENTS OF MAINTENANCE REGISTER
001340	000000		BADPC: .WORD	0	:: HOLDS PC OF INST THAT CAUSED TRAP
001342	000000		OLDPC: .WORD	0	:: HOLDS THE RETURN ADDRESS AFTER A TRAP
001344	000000		OLDPS: .WORD	0	:: HOLDS THE OLD PROCESSOR STATUS
001346	000000		OLDPSW: .WORD	0	:: HOLDS OLD PSW FOR TBITRESTORE
001350	000000		PMMR0: .WORD	0	:: HOLDS CONTENTS OF MMR0 AFTER TRAP
001352	000000		PMMR1: .WORD	0	:: HOLDS CONTENTS OF MMR1 AFTER TRAP
001354	000000		PMMR2: .WORD	0	:: HOLDS CONTENTS OF MMR2 AFTER TRAP
001356	000000		RSIZE: .WORD	0	:: WILL HOLD P.A.R. DATA FOR TOP OF MEMORY
001360	000000		RETRY: .WORD	0	:: RETRY FLAG IN CASE OF PARITY ABORTS
001362	000000		NXTTST: .WORD	0	:: LOCATION TO HOLD ESCAPE ADDRESS ON : PARITY ERRORS.
001364	000200		DATA: .WORD	200	:: PATTERN TO BE USED TO LOAD INTO MEMORY

.SBTTL ERROR POINTER TABLE

;\*THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.  
 ;\*THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN  
 ;\*LOCATION \$ITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.  
 ;\*NOTE1: IF \$ITEMB IS 0 THE ONLY PERTINENT DATA IS (\$ERRPC).  
 ;\*NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:

;\* EM ;:POINTS TO THE ERROR MESSAGE  
 ;\* DH ;:POINTS TO THE DATA HEADER  
 ;\* DT ;:POINTS TO THE DATA  
 ;\* DF ;:POINTS TO THE DATA FORMAT

1497	001366	024160	\$ERRTB:			
1498	001366	030121	:ITEM 1	.WORD	EM1	:NOT THE CORRECT CPU TRAP CONDITION THROUGH ERRVEC (#004)
1499	001370	032340		.WORD	DH1	:RECEIVD EXPECTD TESTNO PC AT ABORT
1500	001372	033641		.WORD	DT1	:PCPUER,CPUEXP,\$TESTN,BADPC,0
1501	001374			.WORD	DF1	: 0, 0, 0, 0
1502						
1503			:ITEM 2			
1504	001376	024245		.WORD	EM2	:UNEXPECTED CPU TRAP THROUGH ERRVEC (#004)
1505	001400	030160		.WORD	DH2	:RECEIVD TESTNO PC AT ABORT
1506	001402	032352		.WORD	DT2	:PCPUER,\$TESTN,BADPC,0
1507	001404	033641		.WORD	DF1	: 0, 0, 0
1508						
1509			:ITEM 3			
1510	001406	024317		.WORD	EM3	:MEMORY MANAGEMENT TRAP, MEMORY MANAGEMENT STATUS REGISTERS
1511	001410	030207		.WORD	DH3	:STATUS AUTOI/D VIRTADR
1512						:REGISTR REGISTR REGISTR TESTNO PC AT ABORT
1513	001412	032362		.WORD	DT3	:PMMR0,PMMR1,PMMR2,\$TESTN,BADPC,0
1514	001414	033641		.WORD	DF1	: 0, 0, 0, 0, 0
1515						
1516			:ITEM 4			
1517	001416	024425		.WORD	EM4	:SUMMARY OF MAP REGISTERS THAT TIMED OUT CN READ
1518	001420	030306		.WORD	DH4	:REGADRS REGADRS
1519						: 'OR' 'AND' #ERRORS TESTNO ERR PC
1520	001422	032376		.WORD	DT4	:ADDROR,ADRAND,ERRCNT,\$TESTN,\$ERRPC,0
1521	001424	033646		.WORD	DF4	: 2, 2, 1, 0, 0
1522						
1523			:ITEM 5			
1524	001426	024505		.WORD	EM5	:SUMMARY OF DUAL ADDRESSING ERRORS ON LOADING MAP REGISTERS
1525	001430	030403		.WORD	DH5	:REGLOAD REGLOAD REGDUAL REGDUAL
1526						: 'OR' 'AND' 'OR' 'AND' #ERRORS TESTNO
1527	001432	032412		.WORD	DT5	:ADDROR,ADRAND,DATAOR,DATAND,ERRCNT,\$TESTN,0
1528	001434	033653		.WORD	DF5	: 2, 2, 2, 2, 1, 0
1529						
1530			:ITEM 6			
1531	001436	024600		.WORD	EM6	:SUMMARY OF BIT PATTERN FAILURES IN LOWER 16 BITS OF MAP REGISTERS
1532	001440	030540		.WORD	DH6	:MAPREG MAPREG EXPECTD EXPECTD RECEIVD RECEIVD
1533						: 'OR' 'AND' 'OR' 'AND' 'OR' 'AND' #ERRORS TESTNO
1534	001442	032430		.WORD	DT6	:ADDROR,ADRAND,PATTOR,PATAND,DATAOR,DATAND,ERRCNT,\$TESTN,0
1535	001444	033661		.WORD	DF6	: 2, 2, 0, 0, 0, 0, 1, 0

1536			:ITEM 7					
1537	001446	024702		.WORD	EM7			:SUMMARY OF BIT PATTERN FAILURES IN UPPER 6 BITS OF MAP REGISTERS
1538	001450	030540		.WORD	DH6			:MAPREG MAPREG EXPECTD EXPECTD RECEIVD RECEIVD
1539								: 'OR' 'AND' 'OR' 'AND' 'OR' 'AND' #ERRORS TESTNO
1540	001452	032430		.WORD	DT6			:ADDROR,ADRAND,PATTOR,PATAND,DATAOR,DATAND,ERRCNT,\$TESTN,0
1541	001454	033661		.WORD	DF6			: 2, 2, 0, 0, 0, 0, 1, 0
1542								
1543			:ITEM 10					
1544	001456	025003		.WORD	EM10			:CAN'T GET TO MAIN MEMORY FROM UNIBUS WITH THE MAP OFF
1545								:SO JUMPING TO THE SIZE JUMPER TEST FOR VERIFICATION
1546	001460	030727		.WORD	DH10			:TESTNO ERR PC
1547	001462	032452		.WORD	DT10			: \$TESTN,\$ERRPC,0
1548	001464	033641		.WORD	DF1			:0, 0
1549								
1550			:ITEM 11					
1551	001466	025155		.WORD	EM11			:SUMMARY OF COUNT PATTERN FAILURES ON THE UNIBUS DATA PATH
1552	001470	030754		.WORD	DH11			:EXPECTD EXPECTD RECEIVD RECEIVD
1553								: 'OR' 'AND' 'OR' 'AND' #ERRORS TESTNO
1554	001472	032462		.WORD	DT11			:PATTOR,PATAND,DATAOR,DATAND,ERRCNT,\$TESTN,0
1555	001474	033671		.WORD	DF11			: 0, 0, 0, 0, 1, 0
1556								
1557			:ITEM 12					
1558	001476	025247		.WORD	EM12			:UNIBUS MAP IS RELOCATING WHEN NOT ENABLED
1559	001500	030727		.WORD	DH10			:TESTNO ERR PC
1560	001502	032452		.WORD	DT10			: \$TESTN,\$ERRPC,0
1561	001504	033641		.WORD	DF1			: 0, 0
1562								
1563			:ITEM 13					
1564	001506	025321		.WORD	EM13			:CANNOT USE ANY OF THE MAP REGISTERS OR PHYSICAL
1565								:ADDRESS BIT14 IS STUCK LOW, MUST RESTART PROGRAM
1566								:IF YOU DON'T LOOP ON THIS PROBLEM.
1567	001510	030727		.WORD	DH10			:TESTNO ERR PC
1568	001512	032452		.WORD	DT10			: \$TESTN,\$ERRPC,0
1569	001514	033641		.WORD	DF1			: 0, 0
1570								
1571			:ITEM 14					
1572	001516	025525		.WORD	EM14			:SUMMARY OF UNIBUS ADDRESS ERRORS, WITH MAP RELOCATION DISABLED
1573	001520	030754		.WORD	DH11			:EXPECTD EXPECTD RECEIVD RECEIVD
1574								: 'OR' 'AND' 'OR' 'AND' #ERRORS TESTNO
1575	001522	032500		.WORD	DT14			:ADDROR,ADRAND,DATAOR,DATAND,ERRCNT,\$TESTN,0
1576	001524	033677		.WORD	DF14			: 2, 2, 0, 0, 1, 0
1577								
1578			:ITEM 15					
1579	001526	025630		.WORD	EM15			:MAIN MEMORY TIME OUT OVER THE UNIBUS DID NOT OCCUR PROPERLY.
1580	001530	031111		.WORD	DH15			:CONDITN CONDITN
1581								:EXPECTD RECEIVD TESTNO ERR PC
1582	001532	032516		.WORD	DT15			:CPUEXP,PCPUER,\$TESTN,\$ERRPC,0
1583	001534	033641		.WORD	DF1			: 0, 0, 0, 0
1584								
1585			:ITEM 16					
1586	001536	025723		.WORD	EM16			:SUMMARY OF DUAL MAPPING ERRORS
1587	001540	030754		.WORD	DH11			:EXPECTD EXPECTD RECEIVD RECEIVD
1588								: 'OR' 'AND' 'OR' 'AND' #ERRORS TESTNO
1589	001542	032500		.WORD	DT14			:ADDROR,ADRAND,DATAOR,DATAND,\$ERRPC,\$TESTN,0
1590	001544	033653		.WORD	DF5			: 2, 2, 2, 2, 1, 0

1591			:ITEM 17		
1592	001546	026021	.WORD	EM17	:NO UNIBUS MEMORY EXISTS
1593	001550	030727	.WORD	DH10	:TESTNO ERR PC
1594	001552	032452	.WORD	DT10	:\$TESTN,\$ERRPC,0
1595	001554	033641	.WORD	DF1	: 0, 0
1596					
1597			:ITEM 20		
1598	001556	026051	.WORD	EM20	:INTERRUPT/ABORT LOGIC TESTS TRAP TO LOCATION 114 DID NOT OCCUR
1599	001560	030727	.WORD	DH10	:TESTNO ERR PC
1600	001562	032452	.WORD	DT10	:\$TESTN,\$ERRPC,0
1601	001564	033641	.WORD	DF1	: 0, 0
1602					
1603			:ITEM 21		
1604	001566	026150	.WORD	EM21	:INTERRUPT/ABORT TESTS R4 WAS OVERWRITTEN WITH
1605					:DATA INDICATING THAT INSTRUCTION WAS NOT ABORTED
1606	001570	030727	.WORD	DH10	:TESTNO ERR PC
1607	001572	032452	.WORD	DT10	:\$TESTN,\$ERRPC,0
1608	001574	033641	.WORD	DF1	: 0, 0
1609					
1610			:ITEM 22		
1611	001576	026226	.WORD	EM22	:INTERRUPT/ABORT TESTS TRAP DID NOT OCCUR DUE TO ABORT
1612	001600	030727	.WORD	DH10	:TESTNO ERR PC
1613	001602	032452	.WORD	DT10	:\$TESTN,\$ERRPC,0
1614	001604	033641	.WORD	DF1	: 0, 0
1615					
1616			:ITEM 23		
1617	001606	026314	.WORD	EM23	:LMA NOT LOADED PROPERLY
1618	001610	031170	.WORD	DH23	:TESTNO ERR PC LMAEXP LMARCV
1619	001612	032530	.WORD	DT23	:\$TESTN,\$ERRPC,EADRES,EADRS2,0
1620	001614	033705	.WORD	DF23	: 0, 0, 2, 2
1621					
1622			:ITEM 24		
1623	001616	026344	.WORD	EM24	:LMA FORCE JUMPER BIT NOT ZERO
1624	001620	031231	.WORD	DH24	:TESTNO ERR PC LMAEXP LMARCV
1625	001622	032542	.WORD	DT24	:\$TESTN,\$ERRPC,\$REG1,LMAHI,0
1626	001624	033641	.WORD	DF1	: 0, 0, 0, 0
1627					
1628			:ITEM 25		
1629	001626	026402	.WORD	EM25	:LMA FORCE JUMPER BIT NOT SET
1630	001630	031231	.WORD	DH24	:TESTNO ERR PC LMAEXP LMARCV
1631	001632	032542	.WORD	DT24	:\$TESTN,\$ERRPC,\$REG1,LMAHI,0
1632	001634	033641	.WORD	DF1	: 0, 0, 0, 0
1633					
1634			:ITEM 26		
1635	001636	026437	.WORD	EM26	:LMA CONTROL BITS INCORRECT
1636	001640	031231	.WORD	DH24	:TESTNO ERR PC LMAEXP LMARCV
1637	001642	032554	.WORD	DT26	:\$TESTN,\$ERRPC,\$TMP0,\$REG2,0
1638	001644	033641	.WORD	DF1	: 0, 0, 0, 0
1639					
1640			:ITEM 27		
1641	001646	026472	.WORD	EM27	:FORCE JUMPER BIT FAILS TO REVERT MAP REGISTER STATUS TO DEFAULT
1642	001650	031270	.WORD	DH27	:TESTNO ERR PC LMARCV KIPAR4
1643	001652	032566	.WORD	DT27	:\$TESTN,\$ERRPC,\$TMP0,KIPAR4,0
1644	001654	033641	.WORD	DF1	: 0, 0, 0

1645  
1646 001656 026572  
1647 001660 031327  
1648 001662 032600  
1649 001664 033641

;ITEM 30

.WORD EM30  
.WORD DH30  
.WORD DT30  
.WORD DF1

;KIPAR5 NOT LOADED PROPERLY  
:TESTNO ERR PC PR5EXP PR5RCV  
:\$TESTN,\$ERRPC,\$TMP5,KIPAR5,0  
: 0, 0, 0, 0

```

1650 001666
1651
1652
1653
1654
1655 001666 026625
1656 001670 031366
1657 001672 032612
1658 001674 033711
1659
1660
1661 001676 026701
1662 001700 031415
1663
1664 001702 032622
1665 001704 033661
1666
1667
1668 001706 026774
1669 001710 031524
1670 001712 032636
1671 001714 033711
1672
1673
1674 001716 027055
1675 001720 031605
1676 001722 032654
1677 001724 033717
1678
1679
1680 001726 027124
1681 001730 031656
1682
1683 001732 032670
1684 001734 033677
1685
1686
1687 001736 027206
1688 001740 031743
1689 001742 032702
1690 001744 033711
1691
1692
1693 001746 027237
1694 001750 032013
1695 001752 032716
1696 001754 033711
1697
1698
1699 001756 027346
1700 001760 032054
1701 001762 032730
1702 001764 033724

```

```

ER200: ;THIS IS THE STARTING POINT FOR ERROR MESSAGES
;201 THROJGH 377. THEY ARE USED FOR MULTIPLE
;ERROR MESSAGES.

;ITEM 201
      .WORD EM201 ;THE FOLLOWING REGISTERS TIMED OUT WHEN READ
      .WORD DH201 ;REGADRS TESTNO ERR PC
      .WORD DT201 ;EADRES,$TESTN,$ERRPC,0
      .WORD DF201 ; 2, 0, 0

;ITEM 202
      .WORD EM202 ;THE FOLLOWING ARE DUAL ADDRESSING ERRORS IN THE UNIBUS MAP
      .WORD DH202 ;MAPREG MAPREG NON-ZER
      .WORD DT202 ;TESTING DUALED CNTNTS TESTNO ERR PC
      .WORD DF6 ;EADRES,EADRS2,$TMP3,$TESTN,$ERRPC,0
      ; 2, 2, 0, 0, 0

;ITEM 203
      .WORD EM203 ;THE BIT PATTERN THROUGH THE MAP REGISTERS FAILED
      .WORD DH203 ;REGADRS PATRN EXPCTD RECEVD TESTNO ERR PC
      .WORD DT203 ;EADRS2,$TMP0,$REG4,$REG3,$TESTN,$ERRPC,0
      .WORD DF201 ; 2, 0, 0, 0, 0, 0

;ITEM 204
      .WORD EM204 ;UNIBUS DATA PATH COUNT PATTERN FAILURE
      .WORD DH204 ;EXPECTD RECEIVD ADDRLOAD TESTNO ERR PC
      .WORD DT204 ;$TMP0,$TMP1,$REG2,$TESTN,$ERRPC,0
      .WORD DF204 ;0, 0, 3, 0, 0

;ITEM 205
      .WORD EM205 ;UNIBUS ADDRESSING ERRORS, MAP RELOCATION DISABLED
      .WORD DH205 ;ADDRESS ADDRESS
      .WORD DT205 ;EXPECTD RECEIVD TESTNO ERR PC
      .WORD DF14 ;EADRES,EADRS2,$TESTN,$ERRPC,0
      ; 2, 2, 0, 0

;ITEM 206
      .WORD EM206 ;DATA PATTERN NOT CORRECT
      .WORD DH206 ;ADDRESS EXPCTD RECVD TESTNO ERR PC
      .WORD DT206 ;EADRES,$TMP4,$TMP5,$TESTN,$ERRPC,2
      .WORD DF201 ; 2, 0, 0, 0, 0

;ITEM 207
      .WORD EM207 ;REFERENCED MAP REGISTER 0 WITH ADDRESS ONE BIT DIFFERENT THAN 17770
      .WORD DH207 ;ADDRUSED BITDIFF TESTNO ERR PC
      .WORD DT207 ;EADRES,$REG0,$TESTN,$ERRPC,0
      .WORD DF201 ;2, 0, 0, 0

;ITEM 210
      .WORD EM210 ;MAP REGISTER UNDER TEST DID NOT RESPOND IN DUAL MAPPING TEST
      .WORD DH210 ;TESTNO ERR PC MAPREGADR
      .WORD DT210 ;$TESTN,$ERRPC,EADRES,0
      .WORD DF210 ; 0, 0, 2

```

1703					
1704	001766	027446			
1705					
1706	001770	032106			
1707					
1708	001772	032740			
1709	001774	033711			
1710					
1711					
1712	001776	027604			
1713					
1714	002000	032106			
1715					
1716	002002	032740			
1717	002004	033711			
1718					
1719					
1720	002006	027737			
1721	002010	032270			
1722	002012	032766			
1723	002014	033641			
1724					
1725					
1726	002016	030030			
1727	002020	032270			
1728	002022	032766			
1729	002024	033641			

			:ITEM 211		
			.WORD	EM211	:RELOCATION THROUGH THE MAP WAS NOT CORRECT, CARRY PROPAGATION
					:TEST BEING RUN OVER UNIBUS
			.WORD	DH211	:CORRECT EXPECTD RECEIVD
					:ADDRESS DATA FROM UB TESTNO ERR PC
			.WORD	DT211	:EADRES,\$REG3,\$REG2,\$TESTN,\$ERRPC,0
			.WORD	DF201	: 2, 0, 0, 0, 0
			:ITEM 212		
			.WORD	EM212	:MAIN MEMORY TIME OUT OVER THE UNIBUS DID NOT OCCUR PROPERLY.
					:TEST BEING RUN OVER UNIBUS
			.WORD	DH211	:CONDITN CONDITN
					:EXPECTD RECEIVD TESTNO ERR PC
			.WORD	DT211	:CPUEXP,PCPUER,\$TESTN,\$ERRPC,0
			.WORD	DF201	: 0, 0, 0, 0
			:ITEM 213		
			.WORD	EM213	:MAP REGISTER ENABLED WHEN DDW SAYS IT SHOULD BE DISABLED
			.WORD	DH213	:TESTNO ERR PC REG NO DDWDAT DDWADR
			.WORD	DT213	: \$TESTN,\$ERRPC,\$TMP0,\$TMP1,\$REG5,0
			.WORD	DF1	: 0, 0, 0, 0, 0
			:ITEM 214		
			.WORD	EM214	:MAP REGISTER DISABLED WHEN DDW SAYS IT SHOULD BE ENABLED
			.WORD	DH213	:TESTNO ERR PC REG NO DDWDAT DDWADR
			.WORD	DT213	: \$TESTN,\$ERRPC,\$TMP0,\$TMP1,\$REG5,0
			.WORD	DF1	: 0, 0, 0, 0, 0



1730  
1731 002026  
1732 000176  
1733 000176 000000  
1734 002026

.SBTTL SOFTWARE SWITCH REGISTER LOCATION  
      \$.Y=                   :SAVE ADDRESS LOCATION  
      .=176                 :ADDRESS TO SOFTWARE SWITCH REGISTER LOCATION  
\$SSWR: .WORD 0             :LOCATION FOR SOFTWARE SWITCH REGISTER  
      .=.Y                 :RETURN TO PREVIOUS ADDRESS LOCATION

1735  
 1736  
 1737  
 1738  
 1739  
 1740  
 1741  
 1742  
 1743  
 1744  
 1745  
 1746  
 1747  
 1748  
 1749  
 1750  
 1751  
 1752  
 1753  
 1754  
 1755  
 1756  
 1757  
 1758  
 1759  
 1760  
 1761  
 1762  
 1763  
 1764  
 1765  
 1766  
 1767  
 1768  
 1769  
 1770  
 1771  
 1772  
 1773  
 1774  
 1775  
 1776  
 1777  
 1778  
 1779  
 1780  
 1781  
 1782  
 1783  
 1784  
 1785  
 1786  
 1787  
 1788  
 1789  
 1790  
 1791

```

.SBTTL ERROR MESSAGE TYPE OUT ROUTINE
*****
*
* THIS SUBROUTINE IS CALLED BY THE ERROR HANDLER TO TYPE
* THE ERROR MESSAGES. IT PICKS UP THE ITEM BYTE ($ITEMB) NUMBER
* AND USES THAT TO INDEX THROUGH THE ERROR TABLE. THE ERROR
* TABLE STARTS AT '$ERRTB' AND HAS FOUR (4) POINTERS FOR EACH
* ENTRY, 'EM', 'DH', 'DT', 'DF'. THE 'EM' POINTS TO THE ERROR
* MESSAGE WHICH IS AN ASCIZ STRING. THE 'DH' POINTS TO THE DATA
* HEADER WHICH IS ANOTHER ASCIZ STRING. THE 'DT' POINTS TO THE
* DATA TABLE WHICH IS A GROUP OF WORDS CONTAINING THE ADDRESSES
* OF THE DATA TO BE TYPED. THE FORMAT OF THIS DATA IS
* CONTROLLED BY THE 'DF' WHICH IS THE POINTER TO THE DATA FORMAT.
* THE DATA FORMAT IS A GROUP OF BYTES WHICH CONTAIN NUMBERS
* THAT CORRESPOND TO DIFFERENT TYPING FORMATS.
*
* 0 -16 BIT OCTAL FORMAT
* 1 -DECIMAL FORMAT
* 2 -22 BIT OCTAL FORMAT. DATA IS LOWER 16 BITS OF THE
* PHYSICAL ADDRESS, UPPER 6 BITS ARE ADJACENT TO LOWER 16
* 3 -22 BIT OCTAL FORMAT. DATA IS THE 16 BIT VIRTUAL
* ADDRESS IN KERNEL I-SPACE.
* 4 -18 BIT OCTAL FORMAT. DATA IS A 16 BIT NUMBER THAT
* WILL BE CONVERTED INTO A UNIBUS ADDRESS BY LEFT
* SHIFTING IT 6 BITS.
* 5 -16 BIT OCTAL, SUPPRESS LEADING ZEROS
* 6 -16 BIT DECIMAL, SUPPRESS SPACES
*
* IF YOU SHOULD HAVE A NEED TO JUST TYPE A STRING OF
* NUMBERS, SET UP YOUR CODE THIS WAY:
*
* MOV #CONTINUE,-(SP) ;MOVE THE ADDRESS OF THE INSTRUCTION AFTER THE
* ;JUMP TO THE STACK
*
* MOV R0,-(SP) ;SAVE R0
* MOV R1,-(SP) ;AND R1 ON THE STACK
* MOV DTNAME,R0 ;MOVE THE ADDRESS OF THE DATA TABLE TO R0
* JMP TYPDAT ;SUBROUTINE IDENTIFIED IN CENTER OF THIS ROUTINE
*
* CONTINUE: NEXT INSTRUCTION
* AT A CONVENIENT SPOT, ALLOCATE THE FOLLOWING:
*
* *DTNAME: .WORD DTLIST,DFNAME ;IDENTIFY THE LIST NAME AND DATA FORMAT BELOW
* *DFNAME: .BYTE N,N,N,N,ETC. ;CONSTRUCT YOUR OWN DATA FORMAT LINE
*
* .EVEN
* *DTLIST: VAR1,VAR2,VAR3,VAR4,....,$CRLF,0 ;VARIABLES YOU WANT TYPED
*
*****
ERTYPE: MOV R0,-(KSP) ;SAVE R0 ON STACK
CLR R0 ;CLEAR R0
MOVB $ITEMB,R0 ;PUT ITEM NUMBER IN R0
BNE 1$ ;BRANCH IF IT IS NON-ZERO
MOV $ERRPC,-(KSP) ;PUT ERROR PC ON STACK FOR TYPING
TYPOC ;TYPE FAILING PC
BR 13$ ;GO TO RETURN
1$: CMPB #177,R0 ;SEE IF THIS IS THE PWR MON BIT ERROR ;DPM001
BNE 200$ ;BRANCH IF NOT TO CALL ERROR
MOV #PMBECW,R0 ;MOVE ADDRESS OF SPECIAL DATA HEADER TO R0
BR 210$ ;BRANCH TO CALL ERROR
200$: DEC R0 ;ADJUST ITEM NUMBER TO BE A POINTER
ASH #3,R0 ;LEFT SHIFT ITEM NO. 3 PLACES
BPL 22$ ;BRANCH IF ITEM NUMBER IS LESS THAN 200
CMP ERRCNT,#20 ;* SEE IF 20 (OCTAL) ERRORS HAVE PRINTED

```

1792	002102	002410			BLT	40\$	:: * BRANCH TO PRINT THE ERROR IF LESS
1793	002104	001404			BEQ	41\$	:: * BRANCH TO TYPE NO MORE DATA LINES IF EQUAL
1794	002106	062766	000004	000002	ADD	#4,2(KSP)	:: * CORRECT PC RETURN TO RETURN AFTER <CRLF> PRINT
1795	002114	000542			BR	13\$	:: * GO TO RETURN
1796	002116	104401	006421		41\$: TYPE	,NOMORE	:: * TYPE MESSAGE TO ANNOUNCE NO MORE PRINTING OF ERRORS
1797	002122	000537			BR	13\$	:: * GO TO RETURN
1798	002124	022737	000001	001320	40\$: CMP	#1,ERRCNT	:: * SEE IF THIS IS THE FIRST ERROR
1799	002132	001415			BEQ	21\$	:: * BRANCH IF IT WAS AND GO TYPE ERROR MESSAGE
1800	002134	032777	000200	176774	BIT	#SW7,@SWR	::SEE IF SWITCH 7 IS UP
1801	002142	001404			BEQ	20\$	::BRANCH IF SWITCH NOT UP AND TYPE DATA
1802	002144	062766	000004	000002	ADD	#4,2(KSP)	::SKIP 'TYPE', \$CRLF' IF SW 7 IS UP
1803							::INHIBIT MULTIPLE ERROR TYPEOUTS
1804	002152	000523			BR	13\$	::BRANCH TO EXIT
1805	002154	042700	177400		20\$: BIC	#177400,RO	::CLEAR UPPER BYTE OF RO
1806	002160	062700	001672		ADD	#ER200+4,RO	::POINT TO DATA TABLE ENTRY
1807	002164	000426			BR	5\$	::GO TYPE DATA TABLE
1808	002166	042700	177000		21\$: BIC	#177000,RO	::CLEAR UPPER BYTE OF RO
1809	002172	062700	000300		ADD	#<ER200-\$ERRTB>,RO	::ADD DIFFERENCE BETWEEN
1810							::ITEM 1 AND ITEM 201
1811							:::GET POINTER TO ERROR MESSAGE AND TYPE IT
1812							:::IF THE POINTER IS NOT ZERO
1813	002176	104401	001223		22\$: TYPE	,\$CRLF	:::TYPE A <CRLF>
1814	002202	062700	001366		ADD	#\$ERRTB,RO	:::ADD BASE OF ERROR TABLE
1815	002206	012037	002216		210\$: MOV	(RO)+,2\$	:::P M MESSAGE POINTER IN TYPE STATEMENT
1816	002212	001404			BEQ	3\$	:::BRANCH IF NO ERROR MESSAGE
1817	002214	104401			TYPE		:::TYPE ERROR MESSAGE
1818	002216	000000			2\$: .WORD	0	:::POINTER TO ERROR MESSAGE
1819	002220	104401	001223		TYPE	,\$CRLF	:::TYPE CRLF
1820							:::GET THE POINTER TO THE DATA HEADER AND
1821							:::TYPE IT IF THE POINTER IS NOT ZERO
1822	002224	012037	002234		3\$: MOV	(RO)+,4\$	:::PUT HEADER POINTER IN TYPE STATEMENT
1823	002230	001404			BEQ	5\$	:::BRANCH IF NO DATA HEADER
1824	002232	104401			TYPE		:::TYPE THE DATA HEADER
1825	002234	000000			4\$: .WORD	0	:::POINTER TO DATA HEADER
1826	002236	104401	001223		TYPE	,\$CRLF	:::TYPE CRLF
1827							:::THIS IS THE START OF THE DATA OUTPUT IF THE
1828							:::DATA POINTER IS NOT ZERO. RO POINTS TO THE
1829							:::DATA FORMAT, R1 POINTS TO THE ADDRESS OF
1830							:::THE DATA WORDS.
1831	002242	010146			5\$: MOV	R1,-(KSP)	:::SAVE R1 ON THE STACK
1832		002244			TYPDAT=.		
1833	002244	012001			MOV	(RO)+,R1	:::PUT DATA TABLE POINTER IN R1
1834	002246	001464			BEQ	12\$	:::BRANCH IF NO DATA TABLE
1835	002250	012000			MOV	(RO)+,RO	:::PICK UP DATA FORMAT POINTER
1836	002252	105710			6\$: TSTB	(RO)	:::IS THIS WORD OCTAL
1837	002254	001003			BNE	7\$	:::BRANCH IF NOT 16-BIT OCTAL
1838							:::WORD IS 16 BIT OCTAL FORMAT (DF = 0)
1839	00225	013146			MOV	@(R1)+,-(KSP)	:::PUSH NEXT 16-BIT WORD ON STACK
1840	002260	104402			TYPOC		:::TYPE THE WORD ON STACK AS 16 BIT OCTAL
1841	002262	000451			BR	11\$	:::GET READY FOR NEXT WORD
1842	002264	122710	000001		7\$: CMPB	#1,(RO)	:::IS THE WORD DECIMAL
1843	002270	001003			BNE	8\$	:::BRANCH IF NOT DECIMAL
1844							:::WORD IS DECIMAL FORMAT (DF = 1)
1845	002272	013146			MOV	@(R1)+,-(KSP)	:::PUSH NEXT 16-BIT WORD ON STACK
1846	002274	104405			TYPDS		:::TYPE THE WORD ON STACK AS DECIMAL
1847	002276	000443			BR	11\$	:::GET READY FOR NEXT WORD
1848	002300	122710	000002		8\$: CMPB	#2,(RO)	:::IS WORD 22-BIT PHYSICAL ADDRESS

```

1849 002304 001012          BNE      9$          ;BRANCH IF NOT 22-BIT PHYSICAL ADDR
1850                               ;:WORD IS 22-BIT PHYSICAL FORMAT (DF = 2)
1851 002306 012146          MOV      (R1)+,-(KSP) ;PUSH NEXT 16-BIT WORD ON STACK
1852 002310 004737 024040    JSR      PC,$DB20     ;CONVERT NUMBER TO OCTAL ASCIZ
1853 002314 062716 000003    ADD      #3,(KSP)     ;ONLY WANT 8 DIGITS
1854 002320 012637 002326    MOV      (KSP)+,30$   ;PUT POINTER AFTER 'TYPE' CALL
1855 002324 104401          TYPE     ;TYPE ASCIZ STRING
1856 002326 000000          .WORD   0            ;WORD HOLDS POINTER TO ASCIZ STRING
1857 002330 000426          BR       11$         ;GET READY FOR NEXT WORD
1858 002332 122710 000003    9$:     CMPB     #3,(R0) ;IS THIS A 16-BIT VIRTUAL ADDRESS
1859 002336 001004          BNE     10$         ;BRANCH IF NOT 16-BIT VIRT. ADDR.
1860                               ;:WORD IS 22-BIT VIRTUAL ADDRESS FORMAT
1861                               ;:KERNEL I-SPACE ASSUMED. (DF = 3)
1862 002340 013146          MOV      @(R1)+,-(KSP) ;PUSH NEXT 16-BIT WORD ON STACK
1863 002342 004737 002542    JSR      PC,TYPVAD    ;GO TYPE 22-BIT ADDRESS FROM 16-BIT V.A.
1864 002346 000417          BR       11$         ;GET READY FOR NEXT WORD
1865 002350 122710 000004    10$:    CMPB     #4,(R0)   ;IS THIS A 16 BIT NUMBER TO BE CONVERTED TO
1866                               ;AN 18 BIT UNIBUS ADDRESS LEFT SHIFTED 6?
1867 002354 001003          BNE     100$        ;SKIP OVER FORMAT 4 ROUTINE IF NOT
1868                               ;:WORD IS FORMAT 4. DATA WORD IS A UNIBUS
1869                               ;:ADDRESS OUTPUT WILL BE 18-BITS WORD LEFT SHIFTED 6.
1870
1871 002356 004737 002650    JSR      PC,UBADDR    ;CONVERT TO 18-BIT UNIBUS ADDR AND TYPE
1872 002362 000411          BR       11$         ;GET READY FOR NEXT WORD
1873 002364 122710 000005    100$:   CMPB     #5,(R0)   ;IS THIS A 16 BIT NUMBER TO BE PRINTED AS
1874                               ;OCTAL WITH LEADING ZEROS SUPPRESSED?
1875 002370 001004          BNE     110$        ;BRANCH TO DECIMAL LEADING SPACES SUPPRESS ROUTINE
1876                               ;:WORD IS FORMAT 5. DATA WORD IS TO BE
1877                               ;PRINTED IN OCTAL, LEADING ZEROS SUPPRESSED.
1878 002372 013146          MOV      @(R1)+,-(KSP) ;PUSH NEXT 16-BIT WORD ON STACK
1879 002374 104403          TYPOS   ;GO TYPE OCTAL SUPPRESS LEADING ZEROS
1880 002376          .BYTE   6            ;TYPE 6 DIGITS AND
1881 002377          .BYTE   0            ;SUPPRESS LEADING ZEROS
1882 002400 000402          BR       11$         ;GET READY FOR NEXT WORD
1883 002402          110$:          ;:WORD IS FORMAT 6. DATA WORD IS TO BE
1884                               ;PRINTED IN DECIMAL, LEADING SPACES SUPPRESSED.
1885 002402 013146          MOV      @(R1)+,-(KSP) ;PUSH NEXT 16-BIT WORD ON STACK
1886 002404 104405          TYPDS   ;POINT TO NEXT FORMAT BYTE
1887 002406 005200          11$:     INC      R0          ;TYPE TWO SPACES
1888 002410 104401 002426    TYPE    ,32$        ;IS THERE ANOTHER WORD?
1889 002414 005711          TST     (R1)        ;BRANCH IF NOT ALL DONE
1890 002416 001315          BNE     6$          ;RESTORE R1
1891 002420 012601          12$:    MOV      (KSP)+,R1 ;RESTORE R0
1892 002422 012600          13$:    MOV      (KSP)+,R0 ;RETURN TO ERROR ROUTINE
1893 002424 000207          RTS     PC          ;TWO SPACES
1894 002426          .ASCIZ  ? ?
1895          .EVEN
1896 002432 002442 002476 002526 PMBECW: .WORD   PMBECM,PMBECH,PMBECD,PMBECF ;4 WORDS POINTING TO BELOW
1897 002442          120          117          127 PMBECM: .ASCIZ  ?POWER MONITOR BIT FOUND SET?
1898 002476          124          105          123 PMBECH: .ASCIZ  ?TESTNO ERR PC CPUERR?
1899          .EVEN
1900 002526 020146 001114 020700 PMBECD: .WORD   $TESTN,$ERRPC,CPSAVE,0
1901 002536          000          000          000 PMBECF: .BYTE   0,0,0,0

```

1902  
 1903  
 1904  
 1905  
 1906  
 1907  
 1908  
 1909  
 1910  
 1911  
 1912  
 1913  
 1914 002542 104411  
 1915 002544 016601 000002  
 1916 002550 005000  
 1917 002552 073027 000003  
 1918 002556 006300  
 1919 002560 006001  
 1920 002562 006001  
 1921 002564 006001  
 1922 002566 062700 172340  
 1923 002572 011003  
 1924 002574 005002  
 1925 002576 073227 000006  
 1926 002602 060103  
 1927 002604 005502  
 1928 002606 010237 001230  
 1929 002612 010337 001226  
 1930 002616 012746 001226  
 1931 002622 004737 024040  
 1932 002626 062716 000003  
 1933 002632 012637 002640  
 1934 002636 104401  
 1935 002640 000000  
 1936  
 1937 002642 104412  
 1938 002644 012616  
 1939 002646 000207

.SBTTL CONVERT 16-BIT VIRTUAL ADDRESS TO 22-BIT PHYSICAL ADDRESS

\*\*\*\*\*  
 \*  
 \* THIS ROUTINE IS CALLED BY A 'JSR PC' AFTER THE VIRTUAL ADDRESS  
 \* IS PUSHED ON THE KERNEL STACK. THE V.A. IS THEN LOADED INTO  
 \* R1 AND THE UPPER 3 BITS ARE SHIFTED INTO R0 TO SELECT THE  
 \* CORRECT KERNEL I-SPACE PAR. THE LOWER 12 BITS OF THE VIRTUAL  
 \* ADDRESS ARE ADDED TO THE PAR AS THEY ARE BY MEMORY MANAGEMENT  
 \* AND THE PHYSICAL ADDRESS IS SAVED IN MEMORY TO BE CONVERTED  
 \* TO ASCIZ AND TYPED.  
 \*  
 \*\*\*\*\*

```
TYPVAD: SAVREG      ;SAVE ALL REGISTERS
MOV      2(KSP),R1  ;PUT VIRTUAL ADDR IN R1
CLR      R0         ;CLEAR R0 FOR CALCULATIONS
ASHC    #3,R0      ;LEFT SHIFT R0,R1 3 PLACES
ASL     R0         ;LEFT SHIFT R0 ONE MORE PLACE
ROR     R1         ;RIGHT SHIFT R1 SO OFFSET IS CORRECT
ROR     R1         ;RIGHT SHIFT R1
ROR     R1         ;RIGHT SHIFT R1
ADD     #KIPAR0,R0 ;FORM DESIRED PAR ADDR IN R0
MOV     (R0),R3    ;PUT CONTENTS OF PAR IN R3
CLR     R2         ;CLEAR R2 FOR PHYSICAL ADDR CALCULATIONS
ASHC    #6,R2      ;LEFT SHIFT <R2,R3> 6 PLACES
ADD     R1,R3      ;ADD OFFSET IN R1 TO BASE IN R3
ADC     R2         ;ADD ANY POSSIBLE CARRY TO UPPER 6 BITS
MOV     R2,PADRSH  ;PUT UPPER 6 BITS OF ADDR IN CORE
MOV     R3,PADRSL  ;PUT LOWER 16 BITS OF ADDR IN CORE
MOV     #PADRSL,-(KSP) ;PUT POINTER TO LOWER 16 BITS ON STACK
JSR     PC,$DB20   ;CONVERT NUMBER TO OCTAL ASCIZ
ADD     #3,(KSP)   ;ONLY TYPE 8 DIGITS
MOV     (KSP)+,3$  ;PUT POINTER AFTER TYPE INST
TYPE    ;TYPE THE 22-BIT VIRTUAL ADDRESS
3$:     .WORD      0 ;THIS WORD HOLDS THE POINTER TO
                           ;THE ASCIZ STRING
RESREG  ;RESTORE ALL THE REGISTERS
MOV     (KSP)+,(KSP) ;LEAVE ONLY RETURN ADDR ON STACK
RTS     PC        ;RETURN TO ERROR HANDLER
```

```

1940
1941
1942
1943
1944
1945
1946
1947 002650 104411
1948 002652 016601 000002
1949 002656 005000
1950 002660 073027 000006
1951 002664 010137 001226
1952 002670 010037 001230
1953 002674 012746 001226
1954 002700 004737 024040
1955 002704 062716 000005
1956 002710 012637 002716
1957 002714 104401
1958 002716 000000
1959 002720 104412
1960 002722 012616
1961 002724 000207
  
```

```

.SBTTL SUBROUTINE TO CONVERT WORD TO A UNIBUS ADDRESS AND TYPE
:*****
:THIS SUBROUTINE IS USED TO CONVERT THE A WORD PUSHED
:ON THE STACK INTO A UNIBUS ADDRESS AND TYPE IT AS A
:*6 DIGIT NUMBER. IT USES R1 & R0 AND LEAVES
:*ALL OTHER REGISTERS UNCHANGED.
:*****
UBADDR: SAVREG
MOV 2(KSP),R1 ;LOAD 16 BIT ADDRESS INTO R1
CLR R0 ;CLEAR R0 FOR CALCULATIONS
ASHC #6,R0 ;LEFT SHIFT <R0:R1> 6 PLACES
MOV R1,PADRSL ;PUT LOWER 16 BITS IN PADRSL
MOV R0,PADRSH ;PUT UPPER 6 BITS IN PADRSH
MOV #PADRSL,-(KSP) ;PUSH POINTER TO WORDS ON STACK
JSR PC,$DB20 ;JUMP TO CONVERT ROUTINE
ADD #5,(KSP) ;ONLY USE LOWER 6 CHARS.
MOV (KSP)+,3$ ;PUT POINTER AFTER TYPE CALL.
3$: .WORD 0 ;HOLDS POINTER TO FIRST CHAR.
RESREG
MOV (KSP)+,(KSP) ;LEAVE ONLY RETURN ADDRESS ON STACK
RTS PC ;RETURN TO ERROR TYPE ROUTINE.
  
```

1962  
1963  
1964  
1965  
1966  
1967  
1968  
1969  
1970  
1971  
1972  
1973  
1974  
1975  
1976  
1977  
1978 002726  
1979 002734  
1980 002736  
1981 002744  
1982 002752

000020  
032766 000020 000002  
001406  
016637 000002 001346  
042766 000020 000002  
000006

```

.SBTTL  TURN OFF AND SAVE T-BIT
*****
*****
**SUBROUTINES UNIQUE TO THIS PROGRAM**
*****
*****
THIS TRAP ROUTINE IS REACHED BY THE TRAP CALL 'TBITO'.  IT IS
USED TO TURN OFF THE T-BIT IF IT IS ON.  THE PROCESSOR STATUS
IS SAVED IN 'OLDPSW' SO THAT THE T-BIT CAN BE RESTORED TO ITS
PREVIOUS STATUS WHEN CONDITIONS WARRANT.
*****
TBIT=BIT4 ;T-BIT IS BIT04 IN PROC. STATUS
TBITOF: BIT #TBIT,2(KSP) ;IS THE T-BIT ON?
      BEQ 1$ ;BRANCH TO EXIT IF IT IS NOT ON
      MOV 2(KSP),OLDPSW ;SAVE OLD PSW FOR RESTORING T BIT
      BIC #TBIT,2(KSP) ;CLEAR T BIT
1$: RTT ;RETURN TO PROGRAM

```

```
1983 .SBTTL RESTORE T-BIT TO ITS PREVIOUS CONDITION
1984 :*****
1985 :*
1986 :* THIS TRAP ROUTINE CAN BE REACHED BY THE TRAP CALL 'TBITR'. IT IS
1987 :* USED TO RESTORE THE T-BIT AFTER A PARTICULAR TEST THAT CANNOT
1988 :* BE RUN WITH THE T-BIT ON. IT USES THE PROCESSOR STATUS STORED
1989 :* IN 'OLDPSW' BY 'TBITO', REPLACES THE PS ON THE STACK WITH IT
1,30 :* AND DOES AN 'RTT'.
1991 :*
1992 :*****
1993 002754 013766 001346 000002 TBITRE: MOV OLDPSW,2(KSP) ;PUT OLD PSW ON STACK
1994 002762 042737 000020 001346 BIC #TBIT,OLDPSW ;CLEAR T-BIT IN 'OLDPSW'
1995 ;SO THAT IT WON'T BE TURNED ON BY ACCIDENT
1996 002770 000006 RTT ;RETURN TO PROGRAM AND INHIBIT T-BIT TRAP AFTER THIS INSTRUCTION
```



1997  
1998  
1999  
2000  
2001  
2002  
2003  
2004  
2005  
2006  
2007  
2008 002772 012703 170200  
2009 002776 005023  
2010 003000 005023  
2011 003002 032737 000040 172516  
2012 003010 001402  
2013 003012 012723 020000  
2014 003016 005023  
2015 003020 022703 170400  
2016 003024 001374  
2017 003026 000207

```
.SBTTL SUBROUTINE TO CLEAR ALL OF THE MAP REGISTERS
*****
THIS SUBROUTINE CLEARS ALL OF THE MAP REGISTERS IF MAPPING IS
DISABLED BY LOADING THE ADDRESS OF MAPLO0 INTO R3 AND THEN
CLEARING THE REGISTER POINTED TO BY R3 UNTIL R3 POINTS ABOVE
MAPH37. IF MAPPING IS ENABLED, ALL REGISTERS EXCEPT MAPL1
IS CLEARED. THE LOWER WORD OF MAPL1 RECEIVES 20000. THIS IS
SO APT CAN PROPERLY MONITOR THE PROGRESS OF THE DIAGNOSTIC.
*****
CLRMAP: MOV #MAPLO,R3 ;PUT FIRST MAP ADDR IN R3
        CLR (R3)+ ;CLEAR MAPLO
        CLR (R3)+ ;CLEAR MAPLO+2
        BIT #BITS,MMR3 ;SEE IF MAPPING IS ENABLED
        BEQ 1$ ;BRANCH TO CLEAR ALL IF NOT ENABLED
        MOV #20000,(R3)+ ;LOAD 20000 INTO MAPL1 FOR POSSIBLE APT USE
1$: CLR (R3)+ ;CLEAR MAP REGISTERS
    CMP #MAPH37+2,R3 ;SEE IF LAST ADDR+2 IS IN R3
    BNE 1$ ;BRANCH IF NOT DONE YET
    RTS PC ;RETURN TO MAIN PROGRAM
```

```

2018 .SBTTL SUBROUTINE TO LOG AND REPORT TIMEOUTS OF MAP REGISTERS
2019 :*****
2020 :
2021 : THIS SUBROUTINE IS USED TO LOG AND REPORT THE FACT THAT A
2022 : REFERENCE TO A MAPPING REGISTER TIMED OUT ON THE UNIBUS. IT
2023 : KEEPS A 'LOGICAL AND' AND A 'LOGICAL OR' OF EACH ADDRESS THAT
2024 : TIMES OUT.
2025 :
2026 :*****
2027 003030 005227 TIMEOUT:INC (PC)+ :INCREMENT ONE TIME GATE
2028 003032 177777 TOFLAG: .WORD -1 :ONE TIME ENTANCE FLAG
2029 003034 001403 BEQ 10$ :BRANCH IF FLAG IS NOW ZERO
2030 003036 005237 020142 INC $MSGTY :INDICATE TO APT A FATAL ERROR OCCURED
2031 003042 000000 HALT :I HAVE ENTERED THIS ROUTINE BEFORE I FINISHED REPORTING THE FIRST ERROR.
2032 :THE SECOND ENTRY ADDRESS IS ON THE STACK AND THE
2033 :FIRST ERROR CONDITION IS PROBABLY STILL LOCKED UP.
2034 003044 012637 001342 10$: MOV (KSP)+,OLDPC :SAVE RETURN ADDRESS
2035 003050 012637 001344 MOV (KSP)+,OLDPS :SAVE OLD PSW
2036 003054 105737 007140 TSTB CPUTYP :SEE IF THIS IS AN 11/44
2037 003060 001406 BEQ 1$ :BRANCH TO CONTINUE IF IT IS
2038 003062 005237 001330 INC PCPUER :INCREMENT PCPUER TO SHOW A TIMEOUT OCCURED
2039 003066 005737 001326 TST CPUEXP :SEE IF THERE WAS AN EXPECTED ERROR
2040 003072 001435 BEQ 3$ :GO REPORT ERROR IF NONE EXPECTED
2041 003074 000442 BR 4$ :BRANCH TO EXIT IF TIMEOUT WAS EXPECTED
2042 003076 013737 177766 001330 1$: MOV CPUERR,PCPUER :SAVE CPU ERROR REGISTER
2043 003104 013737 001330 177766 MOV PCPUER,CPUERR :CLEAR CPU ERROR REGISTER
2044 003112 023737 001330 001326 CMP PCPUER,CPUEXP :SEE IF EXPECTED CONDITION CAME UP.
2045 003120 001405 BEQ 2$ :BRANCH IF IT WAS A TIMEOUT
2046 003122 012737 177777 003032 MOV #-1,TOFLAG :RESET ONE TIME GATE
2047 003130 104001 ERROR +1 :NOT THE CORRECT CPU TRAP THROUGH 4
2048 003132 000423 BR 4$ :BRANCH TO EXIT
2049 003134 105737 007140 2$: TSTB CPUTYP :IS THIS AN 11/24?
2050 003140 001403 BEQ 25$ :BRANCH IF NOT
2051 003142 005237 001320 INC ERRCNT :COUNT THIS AS A TIMEOUT
2052 003146 000415 BR 4$ :GO TO EXIT
2053 003150 022737 000020 001326 25$: CMP #TIMOUT,CPUEXP :SEE IF A TIMEOUT WAS EXPECTED
2054 003156 001411 BEQ 4$ :BRANCH TO EXIT THIS ROUTINE IF IT WAS
2055 003160 010046 MOV RO,-(SP) :PUT VIRTUAL ADDRESS ON STACK FOR ADREXT SUBROUTINE USE
2056 003162 013746 172356 MOV KIPAR7,-(SP) :PUT PAR ON STACK FOR ADREXT SUBROUTINE USE
2057 003166 004737 003674 JSR PC,ADREXT :GO SET DATA IN THE 4 WORDS OF ADDROR AND ADRAND
2058 003172 012737 177777 003032 MOV #-1,TOFLAG :RESET ONE TIME GATE
2059 003200 104201 ERROR +201 :THE FOLLOWING REGISTERS TIMED OUT WHEN READ
2060 003202 012737 177777 003032 4$: MOV #-1,TOFLAG :RESET ONE TIME GATE
2061 003210 013746 001344 MOV OLDPS,-(KSP) :RESTORE OLD PSW
2062 003214 013746 001342 MOV OLDPC,-(KSP) :PUSH RETURN ADDRESS BACK ON THE STACK
2063 003220 000006 RTT :RETURN TO THE TEST

```

2064  
2065  
2066  
2067  
2068  
2069  
2070  
2071  
2072  
2073  
2074  
2075  
2076  
2077  
2078  
2079  
2080  
2081  
2082  
2083  
2084  
2085  
2086  
2087  
2088  
2089  
2090  
2091  
2092  
2093  
2094  
2095  
2096  
2097  
2098  
2099  
2100  
2101  
2102  
2103  
2104  
2105  
2106  
2107  
2108  
2109  
2110  
2111

003222 005227  
003224 177777  
003226 001403  
003230 005237 020142  
003234 000000  
  
012637 001342  
012637 001344  
013737 177766 001330  
013737 001342 001340  
005737 001326  
001414  
105737 007140  
001016  
023737 001330 001326  
001417  
012737 177777 003224  
104001  
000412  
012737 177777 003224 1\$:  
104002  
000405  
005237 001320 2\$:  
013737 001326 001330  
012737 177777 003224 3\$:  
013737 001330 177766  
013746 001344  
013746 001342  
000006

```
.SBTTL CPU TRAP HANDLER ROUTINES
*****
**TRAP HANDLING ROUTINES**
*****

THIS SUBROUTINE WILL HANDLE ALL CPU TRAPS AND ABORTS, THROUGH
'ERRVEC' (000004). IF THIS SUBROUTINE IS ENTERED BY A SECOND
TRAP BEFORE THE FIRST HAS BEEN PROCESSED A HALT IS EXECUTED.
IF THE WORD 'CPUEXP' IS ZERO, NO TRAP WAS EXPECTED AND AN
UNEXPECTED ERROR MESSAGE IS GIVEN. IF THE WORD 'CPUEXP' IS
NOT ZERO THEN THE CPU ERROR REGISTER 'CPUERR' IS COMPARED WITH
'CPUEXP' TO SEE IF THE PROPER CONDITION OCCURRED. 'PCPUER' CAN
BE USED AS A FLAG TO INDICATE THAT A TRAP HAS OCCURRED SINCE IT
IS LOADED WITH THE ERROR REGISTER IF A TRAP VECTORS HERE
*****
CPUER: INC (PC)+ ;MAKE FLAG ZERO IF FIRST TIME
CPFLAG: .WORD -1 ;NEGATIVE ONE FOR A FLAG
        BEQ 10$ ;BRANCH IF FIRST TIME IN
        INC $MSGTY ;INDICATE TO APT A FATAL ERROR OCCURED
        HALT ;I HAVE ENTERED THIS ROUTINE BEFORE
;I FINISHED REPORTING THE FIRST ERROR. THE SECOND ENTRY ADDRESS IS ON
;THE STACK, AND THE FIRST ERROR CONDITION IS PROBABLY STILL LOCKED UP.
10$: MOV (KSP)+,OLDPC ;SAVE RETURN ADDRESS IN CASE OF LOOP
     MOV (KSP)+,OLDPS ;SAVE OLD PSW IN CASE OF LOOP
     MOV CPUERR,PCPUER ;SAVE CPU ERROR REGISTER
     MOV OLDPC,BAD^C ;SAVE PC+2 AT TIME OF ABORT
     TST CPUEXP ;SEE IF ANY CONDITION WAS EXPECTED
     BEQ 1$ ;BRANCH IF NO TRAP WAS EXPECTED
     TSTB CPUTYP ;SEE IF THIS WAS AN 11/44
     BNE 2$ ;BRANCH TO CONTINUE IF AN 11/24
     CMP PCPUER,CPUEXP ;SEE IF EXPECTED ERROR OCCURED
     BEQ 3$ ;BRANCH IF ERROR CODES MATCH
     MOV #-1,CPFLAG ;MAKE FLAG NEGATIVE ONE FOR NEXT TIME
     ERROR +1 ;NOT THE CORRECT CPU TRAP THROUGH 4
     BR 3$ ;SKIP NEXT INSTRUCTION
1$: MOV #-1,CPFLAG ;MAKE FLAG NEGATIVE ONE FOR NEXT TIME
     ERROR +2 ;UNEXPECTED CPU TRAP THROUGH 4
     BR 3$ ;SKIP NEXT INSTRUCTION
2$: INC ERRCNT ;INCREMENT ERRCNT TO SHOW AN ERROR FOR 11/24
     MOV CPUEXP,PCPUER ;PUT EXPECTED CONTENTS IN PCPUER
3$: MOV #-1,CPFLAG ;MAKE FLAG NEGATIVE ONE FOR NEXT TIME
     MOV PCPUER,PUERR ;CLEAR CPU ERROR REGISTER
     MOV OLDPS,-(KSP) ;PUSH OLD PSW BACK ON STACK
     MOV OLDPC,-(KSP) ;PUSH RETURN ADDRESS BACK ON STACK
     RTT ;RETURN FROM INTERRUPT OR ABORT
```

```
2112 .SBTTL MEMORY MANAGEMENT TRAPS AND ABORTS HANDLER ROUTINE
2113 :*****
2114 :*
2115 :* THIS ROUTINE WILL HANDLE ALL SPURIOUS MEMORY MANAGEMENT TRAPS
2116 :* AND ABORTS. IT WILL REPORT THE CONDITION OF ALL THE MEMORY
2117 :* MANAGEMENT STATUS REGISTERS, AND THEN RETURN TO THE TEST AND
2118 :* TRY TO CONTINUE RUNNING.
2119 :*
2120 :*****
2121 003372 005227 MMTRAP: INC (PC)+ ;MAKE FLAG ZERO IF FIRST TIME
2122 003374 177777 MMFLAG: .WORD -1 ;FLAG SHOULD BE NEG ONE
2123 003376 001403 BEQ 10$ ;BRANCH IF FIRST TIME INTO ROUTINE
2124 003400 005237 020142 INC $MSGTY ;INDICATE TO APT A FATAL ERROR OCCURED
2125 003404 000000 HALT ;I HAVE ENTERED THIS ROUTINE BEFORE I FINISHED REPORTING THE
2126 :FIRST ERROR. THE SECOND ENTRY ADDRESS IS ON THE STACK AND THE FIRST ERROR
2127 :CONDITION IS PROBABLY STILL LOCKED UP .
2128 003406 011637 001340 10$: MOV (KSP),BADPC ;SAVE PC AT TIME OF ABORT OR TRAP
2129 003412 012637 001342 MOV (KSP)+,OLDPC ;SAVE RETURN ADDRESS IN CASE OF LOOP
2130 003416 012637 001344 MOV (KSP)+,OLDPS ;SAVE OLD PSW IN CASE OF LOOP
2131 003422 013737 177572 001350 MOV MMR0,PMMR0 ;SAVE STATUS REGISTER
2132 003430 013737 177574 001352 MOV MMR1,PMMR1 ;SAVE AUTO INC/DEC REGISTER
2133 003436 013737 177576 001354 MOV MMR2,PMMR2 ;SAVE VIRTUAL ADDRESS REGISTER
2134 003444 104003 ERROR +3 ;UNEXPECTED M.M. ABORT OR TRAP
2135 003446 042737 177776 177572 1$: BIC #177776,MMR0 ;CLEAR ALL BITS EXCEPT 0
2136 003454 012737 177777 003374 MOV #-1,MMFLAG ;RESTORE A NEGATIVE ONE TO FLAG
2137 003462 013746 001344 MOV OLDPS,-(KSP) ;PUSH OLD PSW ONTO STACK
2138 003466 013746 001342 MOV OLDPC,-(KSP) ;PUSH RETURN ADDRESS ON STACK
2139 003472 000006 RTT ;RETURN TO MAIN PROGRAM
```

```

2140 .SBTTL SUBROUTINE TO TEST A LOCATION FOR WRITEABILITY
2141 :*****
2142 :
2143 : THIS SUBROUTINE CLEARS A TEST LOCATION, LOADS THE LOCATION USING
2144 : THE MAP REGISTER, AND DETERMINES IF THE LOCATION WAS LOADED. IF
2145 : IT WAS, RETURN IS NORMAL TO THE TEST. IF NOT, THE PC ON THE
2146 : STACK IS UPDATED BY 2 AND THEN A RETURN IS EXECUTED.
2147 :
2148 :*****
2149 003474 005237 001174 TSTLOC: INC $TMP0 ;INCREMENT REGISTER COUNTER
2150 003500 005737 005774 TST FLOATR ;SEE IF BIT 15 OF FLOATR IS SET
2151 003504 100011 BPL 1$ ;BRANCH IF STILL PLUS
2152 003506 022705 020230 CMP #DDW1,R5 ;SEE IF R5 IS POINTING TO UPPER .DW
2153 003512 001417 BEQ NEXT ;BRANCH IF SO - ALL DONE
2154 003514 012705 020230 MOV #DDW1,R5 ;MOVE ADDRESS OF DDW1 TO R5 AND
2155 003520 012737 000001 005774 MOV #BIT0,FLOATR ;RESET BIT 0 IN FLOATR
2156 003526 000411 BR NEXT ;BRANCH OVER ASL
2157 003530 005227 1$: INC (PC)+ ;INCREMENT NEXT LOCATION FOR FIRST TIME THROUGH CHECK
2158 003532 177777 FTTHRU: .WORD -1 ;FIRST TIME ENTRANCE FLAG
2159 003534 001004 BNE 1$ ;BRANCH IF NOT FIRST TIME
2160 003536 012737 000001 005774 MOV #BIT0,FLOATR ;MOVE BIT 0 TO LOCATION FLOATR
2161 003544 000402 BR NEXT ;BRANCH OVER THE ASL
2162 003546 006337 005774 1$: ASL FLOATR ;ROTATE THE TEST BIT TO THE LEFT
2163 003552 005037 037776 NEXT: CLR 37776 ;CLEAR TEST LOCATION
2164 003556 005037 001330 CLR PCPUER ;CLEAR ERROR LOCATION
2165 003562 010210 MOV R2,(R0) ;TRY TO LOAD TEST CELL THROUGH MAP
2166 003564 023702 037776 CMP 37776,R2 ;SEE IF TEST LOCATION WAS LOADED
2167 003570 001414 BEQ 2$ ;BRANCH IF IT WAS LOADED
2168 003572 004737 005076 JSR PC,CHKLMA ;GO SEE IF USER SAYS THIS IS AN 11/24 WITH UB MEMORY
2169 003576 177736 177734 .WORD LMAHI,LMALOW ;ADDRESSES OF LMA REGISTERS
2170 003602 000407 BR 2$ ;RETURN IS HERE IF OK
2171 003604 005737 001330 TST PCPUER ;SEE IF A TIMEOUT OCCURED
2172 003610 001402 BEQ 1$ ;BRANCH OVER SPECIAL STACK PUSH IF NOT
2173 003612 013743 001174 MOV $TMP0,-(R3) ;PUSH REGISTER NUMBER THAT TIMED OUT ON SPECIAL STACK
2174 003616 062716 000002 1$: ADD #2,(SP) ;CORRECT PC RETURN FOR LOAD FAILURE INDICATION
2175 003622 000207 2$: RTS PC ;RETURN FROM THIS SUBROUTINE
  
```

```
2176 .SBTTL SUBROUTINE TO LOAD DATAOR AND DATAND
2177 :*****
2178 :*
2179 :* THIS SUBROUTINE ASSUMES THE DATA TO BE ANDED AND ORED HAS BEEN PUT
2180 :* ON THE STACK BEFORE THIS SUBROUTINE WAS CALLED. IT BIT SETS THE
2181 :* DATA ONTO DATAOR, COMPLEMENTS THE DATA AND BIT CLEARS IT ONTO
2182 :* DATAND.
2183 :*
2184 :*****
2185 003624 056637 000002 001246 DATEXT: BIS 2(SP),DATAOR ;SET THE 'OR' PATTERN TO DATAOR
2186 003632 005166 000002 COM 2(SP) ;COMPLIMENT THE DATA
2187 003636 046637 000002 001242 BIC 2(SP),DATAND ;CLEAR THE 'AND' PATTERN TO DATAND
2188 003644 012616 MOV (SP)+,(SP) ;CLEAN THE STACK FOR THE RETURN
2189 003646 000207 RTS PC ;RETURN
```

2190  
2191  
2192  
2193  
2194  
2195  
2196  
2197  
2198  
2199 003650 056637 000002 001254  
2200 003656 005166 000002  
2201 003662 046637 000002 001252  
2202 003670 012616  
2203 003672 000207

```
.SBTTL SUBROUTINE TO LOAD PATAOR AND PATAND
:*****
:
: THIS SUBROUTINE ASSUMES THE DATA TO BE ANDED AND ORED HAS BEEN PUT
: ON THE STACK BEFORE THIS SUBROUTINE WAS CALLED. IT BIT SETS THE
: DATA ONTO PATTOR, COMPLEMENTS THE DATA AND BIT CLEARS IT ONTO
: PATAND.
:*****
PATEXT: BIS 2(SP),PATTOR ;SET THE 'OR' PATTERN TO PATTOR
COM 2(SP) ;COMPLIMENT THE PATTERN
BIC 2(SP),PATAND ;CLEAR THE 'AND' PATTERN TO PATAND
MOV (SP)+,(SP) ;CLEAN UP STACK FOR RETURN
RTS PC ;RETURN
```

```

2204 .SBTTL SUBROUTINE TO TAKE PAR AND LOAD 2 WORDS EACH OF ADDROR & ADRAND
2205 :*****
2206 :
2207 : THIS SUBROUTINE ASSUMES THE CONTENTS OF THE PAR, AND THE VIRTUAL
2208 : ADDRESS HAVE BEEN PUT ON THE STACK. IT TAKES THE PAR, SHIFTS IT
2209 : TO EXPOSE THE UPPER ADDRESS BITS, BIT SETS THEM TO ADDROR+2, COM-
2210 : PLIMENTS THE CONTENTS AND BIT CLEARS ADRAND+2. AFTER RELOADING
2211 : THE PAR IN R5, IT SHIFTS TO GET THE LOWER 16 BIT EQUIVALENT AND
2212 : ADDS THE VIRTUAL ADDRESS TO CREATE THE PHYSICAL LOWER 16 BITS.
2213 : THEN IT BIT SETS THEM TO ADDROR, COMPLIMENTS THE CONTENTS AND
2214 : BIT CLEARS ADRAND. ANOTHER COMPLIMENT BRINGS THE STATE BACK TO
2215 : ITS ORIGINAL STATE. THIS SUBROUTINE LEAVES WITH THE LOWER 16
2216 : BITS AND THE UPPER 6 BITS ON THE STACK, AND ARE TO BE REMOVED IN
2217 : THAT ORDER, AND MUST BE REMOVED AFTER RETURN.
2218 :
2219 :*****
2220 ADREXT: MOV R5, -(SP) ;SAVE R5
2221 MOV 4(SP), R5 ;MOVE PAR CONTENTS TO R5 FOR SHIFTING
2222 ASH #-10, R5 ;SHIFT R5 TO THE RIGHT 10 PLACES
2223 BIC #177700, R5 ;CLEAR BITS 15 TO 6
2224 CMP #74, R5 ;SEE IF I/O PAGE
2225 BNE 1$ ;BRANCH IF NOT
2226 MOV #77, R5 ;RESET R5 TO 77
2227 1$: MOV R5, $TMP5 ;MOVE OBTAINED UPPER 6 BITS TO $TMP5 FOR FUTURE TRANSFER
2228 BIS R5, ADDROR+2 ;SET THE 'OR' PATTERN OF UPPER 6 BITS TO ADDROR+2
2229 COM R5 ;COMPLIMENT R5
2230 BIC R5, ADRAND+2 ;CLEAR THE 'AND' PATTERN OF UPPER 6 BITS TO ADRAND+2
2231 MOV 4(SP), R5 ;PUT PAR CONTENTS BACK IN R5
2232 MOV $TMP5, 4(SP) ;MOVE UPPER 6 BITS OF PHYSICAL ADDRESS ON STACK
2233 CMP #74, $TMP5 ;SEE IF I/O PAGE
2234 BNE 2$ ;BRANCH IF NOT
2235 MOV #77, EADRES+2 ;SET 77 IN UPPER ERROR LOCATION
2236 MOV 6(SP), EADRES ;SET LOWER ADDRESS IN LOWER ERROR LOCATION
2237 BR 3$ ;BRANCH OVER PREP
2238 2$: BIC #176000, R5 ;STRIP OFF UPPER 6 BITS OF PAR CONTENTS
2239 ASH #6, R5 ;SHIFT REMAINING BITS 6 PLACES TO THE LEFT
2240 BIC #160000, 6(SP) ;STRIP OFF PAR PAGE BITS FROM ADDRESS TO FORM OFFSET
2241 ADD R5, 6(SP) ;FORM LOWER 16 BITS OF ADDRESS
2242 3$: MOV (SP)+, R5 ;RESTORE R5
2243 BIS 4(SP), ADDROR ;SET THE 'OR' PATTERN TO ADDROR
2244 COM 4(SP) ;COMPLIMENT THE ADDRESS
2245 BIC 4(SP), ADRAND ;CLEAR THE 'AND' PATTERN TO ADRAND
2246 COM 4(SP) ;RETURN ADDRESS TO ITS ORIGINAL STATE
2247 CMP #77, EADRES+2 ;SEE IF I/O PAGE IN UPPER LOCATION
2248 BEQ 4$ ;BRANCH TO EXIT IF SO
2249 MOV 4(SP), EADRES ;PUT LOWER 16 BITS IN ERROR STATUS LOCATION
2250 MOV 2(SP), EADRES+2 ;PUT UPPER 6 BITS IN ERROR STATUS LOCATION
2251 4$: MOV (SP)+, 2(SP) ;PUT RETURN ADDRESS WHERE IT BELONGS
2252 TST (SP)+ ;CLEAN STACK
2253 RTS PC ;RETURN

```



```

2254 .SBTTL SUBROUTINE TESTING RELOCATION ADDER
2255 :*****
2256 :* THE FOLLOWING SUBROUTINE IS USED IN TESTS 13 AND 16, AND USES THE DATA
2257 :* BANK FOLLOWING TO EXECUTE THE LOOPS IN THE TEST. R3 IS THE SPECIAL
2258 :* 'STACK' POINTER, INITIALIZED AT THE BEGINING TO THE R3STAK DATA BANK.
2259 :* THE STACK POINTER IS ADVANCED 3 WORDS FOR EACH PASS. CALL THIS SUB-
2260 :* ROUTINE IN THIS MANNER:
2261 :* CLR $TMP4 ;CLEAR $TMP4 - USED IN ERROR RETURN
2262 :*1$: JSR PC,MAPADD ;GO DO THE TEST
2263 :* ERROR +ERRORNUMBER ;RETURN IS HERE FOR ERROR
2264 :* BR 1$ ;BRANCH BACK TO CONTINUE TEST
2265 :*****
2266 004106 005737 004312 MAPADD: TST LOEFLG ;SEE IF THIS ENTRY WAS AN ERROR
2267 004112 001070 BNE 3$ ;GO CONTINUE TEST
2268 004114 011646 MOV (SP),-(SP) ;MOVE RETURN UP ONE NOTCH
2269 004116 062766 000004 000002 ADD #4,2(SP) ;CREATE ADDRESS ON STACK FOR FINAL RETURN
2270 004124 012703 004314 MOV #R3STAK,R3 ;SET THE SPECIAL STACK POINTER
2271 004130 012704 000013 MOV #13,R4 ;SET THE LOOP COUNTER
2272 004134 012737 004162 001106 MOV #2$,$LPERR ;SET LOOP ON ERROR POINTER TO 2$
2273 004142 005077 175134 CLR @LREGU ;CLEAR UPPER BITS OF MAPPING REG
2274 004146 012377 175126 1$: MOV (R3)+,@LREGL ;LOAD LOWER BITS OF MAPPING REG
2275 004152 013737 001256 172354 MOV LOWEST,KIPAR6 ;LOAD PAR6 WITH ADDR OF LOWEST MAP REG
2276 004160 012300 MOV (R3)+,R0 ;SELECT PAR6, OFFSET IS AUGEND
2277 004162 011001 2$: MOV (R0),R1 ;READ LOCATION DEFINED BY 4TH WORD IN TABLE
2278 004164 012337 001310 MOV (R3)+,UBM24L ;MOVE ANTICIPATED PHYSICAL ADDRESS TO UBM24L
2279 004170 020137 001310 CMP R1,UBM24L ;SEE IF THE MAP'S FETCH WAS CORRECT
2280 004174 001443 BEQ 4$ ;BRANCH IF FETCHED DATA MATCHES ADDRESS
2281 004176 004737 005076 JSR PC,CHKLMA ;GO SEE IF USER SAYS THIS IS AN 11/24 WITH UB MEMORY
2282 004202 177736 177734 .WORD LMAHI,LMALOW ;ADDRESSES OF LMA REGISTERS
2283 004206 000436 BR 4$ ;RETURN IS HERE IF OK
2284 004210 032777 004000 174720 BIT #BIT11,@SWR ;CHECK TO SEE IF 11/24 WITH UB MEMORY ONLY
2285 004216 001406 BEQ 25$ ;BRANCH IF NOT
2286 004220 017737 175064 001176 MOV @UBM24L,$TMP1 ;GET EXPECTED DATA FOR ERROR CALL
2287 004226 004737 005000 JSR PC,PTMP2 ;GO PREPARE $TMP2 FOR ERROR CALL
2288 004232 000404 BR 26$ ;GO CALL ERROR
2289 004234 011037 001176 25$: MOV (R0),$TMP1 ;GET EXPECTED DATA FOR ERROR CALL
2290 004240 010137 001200 MOV R1,$TMP2 ;GET DATA FROM R1 FOR ERROR CALL
2291 004244 162703 000002 26$: SUB #2,R3 ;ANTICIPATE ERROR LOOPING BY UNDOING AUTOINC
2292 004250 013737 001310 005764 MOV UBM24L,EADRES ;PUT ADDRESS IN EADRES FOR ERROR CALL
2293 004256 005037 005766 CLR EADRES+2 ;CLEAR UPPER LOCATION
2294 004262 011646 MOV (SP),-(SP) ;PUT AN EXTRA RETURN ON FOR POSSIBLE ERROR LOOPING
2295 004264 012737 000001 004312 MOV #1,LOEFLG ;SET FLAG SHOWING ERROR CALL WAS CALLED
2296 004272 000207 RTS PC ;EXIT TO ERROR CALL AT TEST
2297 004274 062703 000002 3$: ADD #2,R3 ;RESTORE AUTOINC, ERROR LOOPING NOT DONE
2298 004300 062706 000002 ADD #2,SP ;CLEAN EXTRA RETURN OFF STACK - LOOPING NOT DONE
2299 004304 077460 4$: SOB R4,1$ ;SUBTRACT 1 FROM R4 AND BRANCH IF NOT 0
2300 004306 005726 TST (SP)+ ;EXPOSE NEXT TEST RETURN ADDRESS
2301 004310 000207 RTS PC ;EXIT TO NEXT TEST
2302 004312 000000 LOEFLG. .WORD 0 ;LOOP ON ERROR FLAG LOCATION

```

2303  
 2304  
 2305  
 2306  
 2307  
 2308  
 2309 004314 060000 140000 060000  
 2310 004322 052524 145252 057776  
 2311 004330 045252 152524 057776  
 2312 004336 050420 150420 061040  
 2313 004344 054630 144210 061040  
 2314 004352 044210 154630 061040  
 2315 004360 056734 142104 061040  
 2316 004366 042104 156734 061040  
 2317 004374 057776 141042 061040  
 2318 004402 041042 157776 061040  
 2319 004410 057776 140002 060000

:DATA IN THE R3STAK DATA BANK BELOW IS ARRANGED IN THE FOLLOWING ORDER:  
 :>>>NOTE<<<: THE 'OFFSET' COLUMN IS NOT IN THE STACK DUE TO THE DELIMITER  
 (:) BETWEEN THE EXPECTED ADDRESS AND THE OFFSEI VALUES

	BASE	ADDRESS	ADDRESS	EXPCTD	OFFSET	R4 VALUE
R3STAK: .WORD	060000	140000	060000	060000	000000	R4=13
.WORD	052524	145252	057776	052524	005252	R4=12
.WORD	045252	152524	057776	012524	012524	R4=11
.WORD	050420	150420	061040	010420	010420	R4=10
.WORD	054630	144210	061040	004210	004210	R4=7
.WORD	044210	154630	061040	014630	014630	R4=6
.WORD	056734	142104	061040	002104	002104	R4=5
.WORD	042104	156734	061040	016734	016734	R4=4
.WORD	057776	141042	061040	001042	001042	R4=3
.WORD	041042	157776	061040	017776	017776	R4=2
.WORD	057776	140002	060000	000002	000002	R4=1

```

2320 .SBTTL SUBROUTINE TO TEST CARRY PROP OF MAP'S RELOC ADDER
2321
2322 :*****
2323 :* THIS SUBROUTINE IS USED BY TESTS 14 AND 17. CODE CALLING THIS SUB-
2324 :* ROUTINE IS AS FOLLOWS:
2325 :* CLR $TMP4 ;CLEAR $TMP4 - USED IN ERROR RETURN
2326 :*LAB: JSR PC,TCPMRA ;GO DO THE TEST
2327 :* ERROR +211 ;RETURN IS HERE IF AN ERROR
2328 :* BR LAB ;BRANCH BACK TO CONTINUE TEST
2329 :*****
2329 004416 005737 004312 TCPMRA: TST LOEFLG ;TEST ERROR FLAG TO SEE IF THIS ENTRY IS FROM ERROR
2330 004422 001132 BNE 4$ ;BRANCH TO CONTINUE TEST IF SO
2331 004424 011646 MOV (SP),-(SP) ;MOVE RETURN ADDRESS UP ONE NOTCH
2332 004426 062766 000004 000002 ADD #4,2(SP) ;CREATE CORRECT FINAL RETURN ADDRESS
2333 004434 012737 177777 004674 MOV #-1,35$ ;INITIALIZE FLAG AS NEGATIVE ONE
2334 004442 005077 174634 CLR @LREGU ;CLEAR UPPER 6 BITS OF MAP REG
2335 004446 012777 020000 174624 MOV #20000,@LREGL ;LOAD 4K BASE INTO MAP REGISTER
2336 004454 012701 100100 MOV #100100,R1 ;LOAD BITS TO SELECT PAR 4, OFFSET 100
2337 004460 012700 150000 MOV #150000,R0 ;LOAD BITS TO SELECT PAR 6, OFFSET 2K
2338 004464 012737 000277 172350 MOV #277,KIPAR4 ;START WITH PHYSICAL 6K
2339 004472 013737 001256 172354 MOV LOWEST,KIPAR6 ;LOAD PAR 6 WITH MAP REG'S ADDR
2340 004500 012737 004552 001106 MOV #2$, $LPERR ;SET LOOP ON ERROR POINTER TO 2$
2341 004506 005037 001330 1$: CLR PCPUER ;CLEAR TIME OUT FLAG
2342 004512 062737 010000 001310 ADD #10000,UBM24L ;FORM EXPECTED LMA FOR POSSIBLE USE
2343 004520 001002 BNE 15$ ;BRANCH AROUND UBM24U INCREMENT IF NOT ZERO
2344 004522 005237 001312 INC UBM24U ;INCREMENT UPPER LOCATION
2345 004526 012737 000020 001326 15$: MOV #20,CPUEXP ;EXPECTING A UNIBUS TIME OUT DURING TEST
2346 004534 013710 001364 MOV DATA,(R0) ;THIS LOAD WILL TIME OUT WHEN YOU HAVE REACHED THE TOP
2347 ;OF MEMORY IT SELECTS PAR 6 WHICH WILL PUT ADDR <XXX1>0000 ON THE UNIBUS. THE X'S WILL
2348 ;SELECT THE LOWEST USABLE MAPPING REGISTER. THE DEFAULT CASE IS 00010000, SELECTING
2349 ;MAP REGISTER 0.
2350 004540 005037 001326 CLR CPUEXP ;CLEAR CPUEXP - DON'T EXPECT TRAPS FOR A WHILE
2351 004544 005737 001330 TST PCPUER ;SEE IF THERE WAS MAIN MEMORY
2352 004550 001050 BNE 3$ ;BRANCH IF NO MAIN MEMORY FROM UNIBUS
2353 004552 012737 000040 001326 2$: MOV #NEXMEM,CPUEXP ;POSSIBLE CACHE NON-EXISTENT MEMORY
2354 004560 011103 MOV (R1),R3 ;READ TEST LOCATION VIA FASTBUS
2355 004562 005037 001326 CLR CPUEXP ;CLEAR CPUEXP - DON'T EXPECT TRAPS FOR A WHILE
2356 004566 022737 000040 001330 CMP #NEXMEM,PCPUER ;WAS THIS CACHE NON-EXISTENT MEMORY
2357 004574 001436 BEQ 3$ ;BRANCH IF NON-EXISTENT MEMORY
2358 004576 011002 MOV (R0),R2 ;READ TEST LOCATION VIA UNIBUS MAP
2359 004600 020203 CMP R2,R3 ;COMPARE TEST DATA R2=MAP DATA, R3=FASTBUS DATA
2360 004602 001433 BEQ 3$ ;BRANCH IF IT WAS THE SAME
2361 004604 004737 005076 JSR PC,CHKLMA ;GO CHECK FOR 11/24 WITH UB MEMORY
2362 004610 177736 177734 .WORD LMAHI,LMALOW ;ADDRESSES OF LMA REGISTERS
2363 004614 000426 BR 3$ ;RETURN IS HERE IF OK
2364 004616 032777 004000 174312 BIT #BIT11,@SWR ;SEE IF THIS IS AN 11/24 WITH UB MEMORY ONLY
2365 004624 001403 BEQ 25$ ;BRANCH IF NOT
2366 004626 004737 005000 JSR PC,PTMP2 ;GO PREPARE $TMP2 FOR ERROR CALL
2367 004632 000402 BR 26$ ;BRANCH TO CALL ERROR
2368 004634 011037 001200 25$: MOV (R0),$TMP2 ;GET RECEIVED DATA FOR ERROR CALL
2369 004640 010337 001176 26$: MOV R3,$TMP1 ;GET EXPECTED DATA FOR ERROR CALL
2370 004644 011646 MOV (SP),-(SP) ;PUT AN EXTRA RETURN ADDRESS ON STACK FOR POSSIBLE LOOP
2371 004646 013737 001310 005764 MOV UBM24L,EADRES ;LOAD LOWER 16 BITS OF ADDRESS FOR ERROR CALL
2372 004654 013737 001312 005766 MOV UBM24U,EADRES+2 ;LOAD UPPER 6 BITS OF ADDRESS FOR ERROR CALL
2373 004662 012737 000001 004312 MOV #1,LOEFLG ;SET FLAG SHOWING AN ERROR RETURN
2374 004670 000207 RTS PC ;RETURN TO THE ERROR
2375 004672 005227 3$: INC (PC)+ ;INCREMENT ONE TIME ENTRANCE FLAG
2376 004674 177777 35$: .WORD -1 ;FLAG

```

2377	004676	001006			BNE	5\$		:BRANCH IF I'VE BEEN HERE BEFORE
2378	004700	013737	172350	001356	MOV	KIPAR4,RSIZE		:SAVE UPPER LIMIT OF MEMORY
2379	004706	000402			BR	5\$		:BRANCH OVER ERROR LOOP CORRECTION
2380	004710	062706	000002		ADD	#2,SP		:POP EXCESS RETURN ADDRESS OFF STACK
2381	004714	062737	000100	001364	ADD	#100,DATA		:CHANGE PATTERN FOR NEXT LOAD
2382	004722	062737	000100	172350	ADD	#100,KIPAR4		:ADD 2K TO PAR4
2383	004730	062777	010000	174342	ADD	#10000,@LREGL		:ADD 2K TO MAP REGISTER
2384	004736	001263			BNE	1\$		:BRANCH IF MAP REGISTER NOT ZERO
2385	004740	005277	174336		INC	@LREGU		:ADD ONE TO UPPER 6 BITS OF MAP REG
2386	004744	022777	000073	174330	CMP	#73,@LREGU		:SEE IF TOP 128K BLOCK HAS BEEN PASSED
2387	004752	103255			BHIS	1\$		:BRANCH IF NOT PAST IT
2388	004754	005237	001364		INC	DATA		:CHANGE DATA PATTERN FOR NEXT PASS
2389	004760	042737	177700	001364	BIC	#177700,DATA		:CLEAR UPPER 10 BITS OF DATA PATTERN
2390	004766	052737	000300	001364	BIS	#300,DATA		:START WITH 3XX IN DATA PATTERN
2391	004774	005726			TST	(SP)+		:POP STACK EXPOSING FINAL RETURN ADDRESS
2392	004776	000207			RTS	PC		:EXIT

2393					.SBTTL	SUBROUTINE TO OBTAIN CONTENTS OF LMA CONTENTS LOCATION
2394	005000	013705	177734		PTMP2: MOV	LMALOW,R5 ;MOVE LMA LOW REGISTER CONTENTS TO R5 FOR SHIFTING
2395	005004	072527	177772		ASH	#-6,R5 ;SHIFT PHYSICAL UPPER 3 BITS TO THE RIGHT 6 PLACES
2396	005010	042705	176177		BIC	#176177,R5 ;CLEAR ALL BUT THE THREE SHIFTED BITS
2397	005014	010546			MOV	R5,-(SP) ;SAVE THIS NUMBER ON THE STACK
2398	005016	013705	177736		MOV	LMAHI,R5 ;MOVE LMA HIGH REGISTER CONTENTS TO R5 FOR SHIFTING
2399	005022	072527	000012		ASH	#10.,R5 ;SHIFT LOWER 6 BITS TO THE LEFT 10 PLACES
2400	005026	062605			ADD	(SP)+,R5 ;ADD PREVIOUSLY SHIFTED CONTENTS TO R5
2401	005030	013746	172346		MOV	KIPAR3,-(SP) ;SAVE PAR3 ON STACK
2402	005034	010537	172346		MOV	R5,KIPAR3 ;MOVE OBTAINED PAR VALUE TO PAR3
2403	005040	013737	177734	001200	MOV	LMALOW,\$TMP2 ;GET ADDRESS MAP CREATED
2404	005046	042737	100000	001200	BIC	#BIT15,\$TMP2 ;CLEAR BIT 15 AND
2405	005054	052737	060000	001200	BIS	#60000,\$TMP2 ;SET BITS 13 & 14 TO PUT PAR PAGE 3 IN \$TMP2
2406	005062	017737	174112	001200	MOV	@\$TMP2,\$TMP2 ;MOVE CONTENTS OF LOCATION TO \$TMP2
2407	005070	012637	172346		MOV	(SP)+,KIPAR3 ;RESTORE PAR3
2408	005074	000207			RTS	PC ;EXIT

2409  
 2410  
 2411  
 2412  
 2413  
 2414  
 2415  
 2416  
 2417  
 2418  
 2419  
 2420  
 2421  
 2422  
 2423  
 2424  
 2425  
 2426  
 2427  
 2428  
 2429  
 2430  
 2431  
 2432  
 2433  
 2434  
 2435  
 2436  
 2437  
 2438  
 2439  
 2440

005076 017637 000000 005134  
 005104 062716 000002  
 005110 017637 000000 005154  
 005116 062716 000002  
 005122 032777 004000 174006  
 005130 001413  
 005132 013746  
 005134 000000  
 005136 042716 177700  
 005142 023726 001312  
 005146 001004  
 005150 023737 001310  
 005154 000000  
 005156 001402  
 005160 062716 000002  
 005164 000207

```

.SBTTL SUBROUTINE TO CHECK FOR 11/24 WITH UBMEMORY
*****
*
* THIS SUBROUTINE CHECKS THE SWITCH REGISTER TO SEE IF USER STATES THAT
* THIS IS AN 11/24 CPU WITH UNIBUS MEMORY ONLY. IF NOT, AN EXIT IS
* EXECUTED WITH THE RETURN BEING UPDATED TO THE 2ND LOCATION AFTER THE
* JSR CALL. IF IT IS, THE LMA HIGH REGISTER IS CHECKED FOR BEING EQUAL
* TO THE CONTENTS OF UBM24U, (ASSUMED TO BE PRELOADED. THESE 6 BITS ARE
* THE UPPER 6 BITS OF THE MAPPED ADDRESS FORMED BY THE MAP REGISTER
* LOGIC). IF NOT, EXIT TO FUDGE RETURN. IF SO, THE LMA LOW REGISTER IS
* CHECKED. IT IS ASSUMED THAT LOCATION UBM24L CONTAINS THE EXPECTED
* PHYSICAL ADDRESS. IT COMPARES THE LMA LOW REGISTER WITH UBM24L, AND IF
* EQUAL, EXECUTES A RETURN WITHOUT THE FUDGING OF THE RETURN ADDRESS,
* OTHERWISE IT IS FUDGED.
*
*****
CHKLMA: MOV @0(SP),10$ :MOVE LMAHI ADDRESS TO ACCESS TO 10$
        ADD #2,(SP) :ADVANCE TO NEXT PARAMETER
        MOV @0(SP),11$ :MOVE LMALOW ADDRESS TO ACCESS TO 11$
        ADD #2,(SP) :CORRECT RETURN OVER PARAMETER
        BIT #BIT11,@SWR :SEE IF USER SAYS THIS IS AN 11/24 WITH UB MEMORY
        BEQ 1$ :BRANCH OUT IF NOT
        MOV @(PC)+,-(SP) :MOVE LMA HIGH REGISTER CONTENTS TO STACK
10$: .WORD 0 :LOCATION FOR ADDRESS TO ACCESS
        BIC #177700,(SP) :CLEAR ALL BUT LOWER 6 BITS (UPPER 6 BITS OF ADDRESS)
        CMP UBM24U,(SP)+ :SEE IF UPPER 6 BITS ARE AS EXPECTED
        BNE 1$ :BRANCH TO PREPARE FOR 2ND RETURN LOCATION IF NOT
        CMP UBM24L,@(PC)+ :SEE IF EXPECTED DATA WAS CLOCKED PROPERLY
11$: .WORD 0 :LOCATION FOR ADDRESS TO ACCESS
        BEQ 2$ :BRANCH AROUND STACK RETURN FUDGE IF OK
1$: ADD #2,(SP) :FUDGE RETURN OVER NON-ERROR BRANCH
2$: RTS PC :EXIT
  
```

2441  
2442  
2443 005166 011600  
2444 005170 012037 001362  
2445 005174 012037 001106  
2446 005200 012037 001100  
2447 005204 013777 001100 173726  
2448 005212 010016  
2449 005214 010037 001104  
2450 005220 012737 000001 001212  
2451 005226 000207

```
.SBTTL PRETEST DATA SETUP SUBROUTINE
:*****
PRETST: MOV (SP),R0 :MOVE RETURN ADDRESS TO R0
MOV (R0)+,NXTTST :SAVE STARTING ADDRESS OF NEXT TEST FOR ESCAPE ON PAR ERRORS
MOV (R0)+,$LPERR :SET LOOP ON ERROR POINTER TO 20$ IN TEST
MOV (R0)+,$STSTM :SETUP TEST NUMBER AND CLEAR THE ERROR FLAG
MOV $STSTM,@DISPLAY :DISPLAY TEST NUMBER FOR ALL TO SEE
MOV R0,(SP) :FUDGE RETURN OVER PARAMETERS
MOV R0,$LPADR :SET LOOP ON TEST POINTER TO START OF TEST
MOV #1,$TIMES :RESET ITERATIONS COUNTER TO 1
RTS PC :RETURN TO BEGIN TEST
```

```

2452
2453
2454
2455
2456
2457
2458
2459 005230 105737 020162
2460 005234 001411
2461 005236 105737 020163
2462 005242 100006
2463 005244 033715 005774
2464 005250 001403
2465 005252 011537 001176
2466 005256 000402
2467 005260 062716 000002
2468 005264 000207
  
```

```

.SBTTL  DISABLE CHECK SUBROUTINE
:*****
:*****
:
:
:  THIS SUBROUTINE CHECKS THE STATUS OF THE BIT POINTED TO IN FLOATR
:  IN THE LOCATION POINTED TO BY R5 (EITHER $DDW0 OR $DDW1), AND DETER-
:  MINES IF THE LOCATION SHOULD BE DISABLED.
DSABLD: TSTB  $ENV          ;TEST APT STATUS
        BEQ   1$           ;BRANCH IF NOT APT
        TSTB  $ENVM        ;DOES APT SAY TO SIZE
        BPL   1$           ;BRANCH TO EXIT IF NOT
        BIT   FLOATR,(R5)  ;TEST DISABLE STATUS
        BEQ   1$           ;BRANCH IF IT SHOULD BE DISABLED
        MOV   (R5),$TMP1   ;MOVE CONTENTS OF DEVICE DESCRIPTOR WORD TO $TMP1
        BR    2$           ;BRANCH OVER RETURN CORRECTION
1$:     ADD   #2,(SP)      ;CHOCOLATE FUDGE RETURN OVER ERROR CALL
2$:     RTS   PC          ;RETURN WITHOUT CORRECTING STACK SO ERROR WILL CALL
  
```



2469  
2470  
2471  
2472  
2473  
2474 005266 105737 020162  
2475 005272 001411  
2476 005274 105737 020163  
2477 005300 100006  
2478 005302 033715 005774  
2479 005306 001003  
2480 005310 011537 001176  
2481 005314 000402  
2482 005316 062716 000002  
2483 005322 000207

```
.SBTTL  ENABLE CHECK SUBROUTINE
:*****
:*      THIS SUBROUTINE CHECKS THE STATUS OF THE BIT POINTED TO IN FLOATR
:*      IN THE LOCATION POINTED TO BY R5 (EITHER $DDW0 OR $DDW1), AND DETER-
:*      MINES IF THE LOCATION SHOULD BE ENABLED.
ENABLD: TSTB  $ENV          ;TEST APT STATUS
        BEQ   1$          ;BRANCH IF NOT APT
        TSTB  $ENVM       ;DOES APT SAY TO SIZE
        BPL   1$          ;BRANCH TO EXIT IF NOT
        BIT   FLOATR,(R5) ;TEST DISABLE STATUS
        BNE   1$          ;BRANCH IF IT SHOULD BE ENABLED
        MOV   (R5), $TMP1 ;MOVE CONTENTS OF DEVICE DESCRIPTOR WORD TO $TMP1
        BR   2$          ;BRANCH OVER RETURN CORRECTION
1$:     ADD   #2,(SP)     ;VANILLA FUDGE RETURN OVER ERROR CALL
2$:     RTS   PC         ;RETURN WITHOUT CORRECTING STACK SO ERROR WILL CALL
```

```

2484          .SBTTL  CACHE TEST IN SUBROUTINE FORM
2485          ;;*****
2486          .ENABL  LSB
2487 005324 042737 000001 177572 CASHSR: BIC  #BIT00,MMRO ;TURN OFF RELOCATION
2488 005332 052737 000400 177746      BIS  #BIT08,CACHE ;FLUSH CACHE TO INVALIDATE ALL CACHE LOCATIONS
2489 005340 032737 010000 177746 1$:  BIT  #BIT12,CACHE ;WAIT TILL DONE
2490 005346 001374          BNE  1$
2491 005350 013702 000000          MOV  0,R2 ;SAVE ADDR. 0 CONTENTS
2492 005354 005037 000000          CLR  0 ;0'S TO MAIN MEMORY LOCATION 0.
2493 005360 005003          CLR  R3 ;CLEAR ERROR FLAG
2494 005362 012704 177777          MOV  #-1,R4 ;ALL 1'S TO R4
2495 005366 013700 000114          MOV  CTRAPV,R0 ;SAVE VECTORS
2496 005372 013701 000116          MOV  CTRAPS,R1
2497 005376 012737 005524 000114          MOV  #3$,CTRAPV ;SETUP FOR CACHE TRAP
2498 005404 012737 000340 000116          MOV  #340,CTRAPS
2499 005412 112737 000002 177750          MOVB #2,MAINT ;HODO ALLOWS CACHE UPDATES AND CLOCKING OF
2500          ;PARITY INFO TO INTERRUPT LOGIC ONLY DURING
2501          ;THE DESTINATION ACCESS OF AN INSTRUCTION.
2502 005420 012737 000015 177746          MOV  #15,CACHE ;NO UCB SO AS TO WRITE CACHE STORES
2503 005426 005737 040000          TST  40000 ;UPDATE CACHE LOCATION 0000 WITH CORRECT
2504          ;PARITY STORAGE
2505 005432 052737 000100 177746          BIS  #BIT06,CACHE ;ALLOW WRITE WRONG PARITY DATA TO LO & HI BYTE
2506          ;PARITY STORE.
2507 005440 005737 000000          TST  0 ;READ UPDATE TO CACHE LOCATION 0000;
2508          ;WRITE WRONG PARITY TO HI/LO BYTE PARITY STORES
2509 005444 042737 000100 177746          BIC  #BIT06,CACHE ;DISABLE WWP
2510 005452 005037 177744          CLR  CMPE ;CLEAR CMPE AND PARITY DETECT LOGIC
2511 005456 142737          BICB (PC)+,@(PC)+ ;ALLOW INT & ENABLE LOW CACHE (1ST ;DPM002
2512 005460 000000          CASH1: .WORD 0 ;LOCATION LOADED BY THE TEST ;DPM002
2513 005462 177746          .WORD CACHE ;ADDRESS OF CACHE LOCATION ;DPM002
2514 005464 122727          CMPB (PC)+,(PC)+ ;WHICH TEST ;DPM002
2515 005466 000002          .WORD 2 ;TEST 2 IS TESTED FOR ;DPM002
2516 005470 000000          CASH2: .WORD 0 ;THIS LOCATION LOADED BY THE TEST ;DPM002
2517 005472 001405          BEQ  2$
2518 005474 005737 000000          TST  0 ;GO TO 2ND TEST SECTION IF 2ND TEST EXECUTING
2519          ;READ HIT LO & HI BYTE PARITY CHECK GENERATORS
2520          ;WILL DETECT WRONG PARITY AND THE PARITY
2521          ;ERROR WILL BE CLOCKED TO INTERRUPT LOGIC
2521 005500 000240          NOP ;NEEDED FOR 11/44
2522 005502 005203          INC  R3 ;INDICATE THAT TRAP DID NOT OCCUR
2523 005504 000410          BR  4$ ;BRANCH OVER STACK CORRECTION AND 2ND TEST SECTION
2524 005506 052737 000200 177746 2$:  BIS  #BIT07,CACHE ;ALLOW FOR ABORT
2525 005514 011304          MOV  (R3),R4 ;READ HIT LO & HI BYTE PARITY CHECK GENERATORS WILL
2526          ;DETECT WRONG PARITY USING HODO AND SOURCE MODE FOR READING LOCATION 0 WILL
2527          ;INHIBIT PARITY ERROR FROM BEING CLOCKED TO INTERRUPT LOGIC. HOWEVER, THE PARITY
2528          ;ERROR SIGNAL WILL CAUSE THE ABORT SIGNAL TO BE ASSERTED. THE ABORT SIGNAL WILL
2529          ;BECAUSE CMPE<15> TO BE SET. THIS INSTRUCTION SHOULD BE ABORTED
2530          ;NEEDED IN AN 11/44 TO ALLOW 1 INSTRUCTION BEFORE ABORT
2530 005516 000240          NOP
2531 005520 005203          INC  R3 ;INDICATE NO TRAP OCCURED
2532 005522 000401          BR  4$ ;BRANCH OVER STACK CORRECTION
2533 005524 022626          3$:  CMP  (R6)+,(R6)+ ;READJUST STACK DUE TO INTERRUPT
2534 005526 005037 177744          4$:  CLR  CMPE ;CLEAR CMPE
2535 005532 012737 001015 177746          MOV  #1015,CACHE ;DISABLE CACHE
2536 005540 105037 177750          CLRB MAINT ;DISABLE MAINT. MODE
2537 005544 010237 000000          MOV  R2,0 ;RESTORE LOCATION 0
2538 005550 010037 000114          MOV  R0,CTRAPV ;RESTORE CACHE INTERRUPT VECTORS
2539 005554 010137 000116          MOV  R1,CTRAPS
2540 005560 052737 000400 177746          BIS  #BIT08,CACHE ;BEFORE LEAVING TEST FLUSH CACHE TO ELIMINATE EFFECTS OF WWP

```

```
2541 005566 032737 010000 177746 5$: BIT #BIT12,CACHE ;WAIT TILL DONE
2542 005574 001374 BNE 5$
2543 005576 000207 RTS PC ;EXIT
2544 .DSABL LSB
2545 .SBTTL SUBROUTINE TO PREPARE AND CHECK DATA PATTERN
2546 :*****
2547 005600 011504 CHKPAT: MOV (R5),R4 ;MOVE NEXT COUNT PATTERN TO R2
2548 005602 043704 005776 BIC MASK1,R4 ;USE MASK1 PRE-LOADED FOR PROPER LOADING
2549 005606 010410 MOV R4,(R0) ;LOAD MAP REGISTER WITH COUNT PATTERN
2550 005610 011504 MOV (R5),R4 ;RELOAD PATTERN
2551 005612 043704 006000 BIC MASK2,R4 ;USE THE 2ND MASK TO CONSTRUCT EXPECTED VALUE
2552 005616 020410 CMP R4,(R0) ;COMPARE EXPECTED WITH RECEIVED
2553 005620 001402 BEQ 1$ ;BRANCH IF DATA IS OK
2554 005622 062716 000002 ADD #2,(SP) ;FUDGE RETURN TO SHOW ERROR
2555 005626 000207 1$: RTS PC ;EXIT
```

```

2556                                     .SBTTL READ AN OCTAL NUMBER FROM THE TTY
2557                                     :*****
2558                                     :*THIS ROUTINE WILL READ AN OCTAL (ASCII) NUMBER FROM THE TTY, CHANGE IT TO
2559                                     :*BINARY AND PUT THE NUMBER ON THE STACK.
2560                                     :*CALL:
2561                                     :*   RDOCT          ;READ AN OCTAL NUMBER
2562                                     :*   MOV          (SP)+,LOCATION ;POP THE INPUTED NUMBER OFF STACK
2563                                     :*                                     ;HIGH ORDER BITS ARE IN $HIOCT
2564
2565 005630 011646 $RDOCT: MOV      (SP),-(SP) ;MAKE ROOM FOR THE
2566 005632 016666 000004 000002 MOV      4(SP),2(SP) ;OCTAL NUMBER
2567 005640 010046 MOV      R0,-(SP) ;SAVE R0
2568 005642 010146 MOV      R1,-(SP) ;SAVE R1
2569 005644 010246 MOV      R2,-(SP) ;SAVE R2
2570 005646 104407 1$: RDLIN   ;READ THE OCTAL NUMBER
2571 005650 012600 MOV      (SP)+,R0 ;GET ADDRESS OF 1ST CHARACTER
2572 005652 005001 CLR      R1 ;CLEAR R1
2573 005654 005002 CLR      R2 ;CLEAR R2
2574 005656 112046 2$: MOVVB  (R0)+,-(SP) ;MOVE CHARACTER TO STACK
2575 005660 001415 BEQ      3$ ;IF ZERO, EXIT
2576 005662 000241 CLC ;CLEAR THE CARRY BIT
2577 005664 006101 ROL      R1 ;SHIFT MSB TO THE CARRY BIT
2578 005666 006102 ROL      R2 ;SHIFT IT TO UPPER RECEIVER
2579 005670 000241 CLC ;CLEAR THE CARRY BIT
2580 005672 006101 ROL      R1 ;SHIFT MSB TO THE CARRY BIT
2581 005674 006102 ROL      R2 ;SHIFT IT TO UPPER RECEIVER
2582 005676 000241 CLC ;CLEAR THE CARRY BIT
2583 005700 006101 ROL      R1 ;SHIFT MSB TO THE CARRY BIT
2584 005702 006102 ROL      R2 ;SHIFT IT TO UPPER RECEIVER
2585 005704 042716 177770 BIC      #177770,(SP) ;STRIP ALL BUT BINARY EQUIVALENT
2586 005710 052601 BIS      (SP)+,R1 ;SET THE BINARY EQUIVALENT TO LOWER RECEIVER
2587 005712 000761 BR      2$ ;BRANCH BACK
2588 005714 005726 3$: TST      (SP)+ ;CLEAN TERMINATOR FROM STACK
2589 005716 010166 000012 MOV      R1,12(SP) ;SAVE THE RESULT
2590 005722 010237 005736 MOV      R2,$HIOCT
2591 005726 012602 MOV      (SP)+,R2 ;RESTORE R2
2592 005730 012601 MOV      (SP)+,R1 ;RESTORE R1
2593 005732 012600 MOV      (SP)+,R0 ;RESTORE R0
2594 005734 000002 RTI ;RETURN
2595 005736 000000 $HIOCT: .WORD 0 ;HIGH ORDER BITS GO HERE

```

2596					.SBTTL	DATA TABLES AND ASCII STRINGS USED IN THIS DIAGNOSTIC
2597	005740	005744	006120		DTMSG: .WORD	DTMSG,DFMSG ; POINTER TO DATA VARIABLE ADDRESSES
2598	005744	001266	001270	001272	DTMSG: .WORD	MMRLOW,MMRHI,UBRLOW,UBRHI,\$TESTN,0 ; DATA VARIABLES TO BE PRINTED
2599	005760	000000			CHARCT: .WORD	0 ; THIS LOCATION HOLDS CHARACTERS INPUTED DURING THE TYPE ROUTINE
2600	005762	000000			EXTOUT: .WORD	0 ; THIS LOCATION STORES THE OUTPUT OF THE EXTRACTION ROUTINE
2601	005764	000000	000077		EADRES: .WORD	0,77 ; LOCATIONS FOR STORING 22 BITS OF THE UBMAR REGISTER ADDRESS
2602	005770	000000	000077		EADRS2: .WORD	0,77 ; LOCATIONS FOR STORING ANOTHER UBMAR REGISTER ADDRESS
2603	005774	000000			FLOATR: .WORD	0 ; LOCATION TO HOLD BIT TO FLOAT TO TEST DDW'S STATUS
2604	005776	000000			MASK1: .WORD	0 ; PRE-LOADED BY THE TEST WITH THE 1ST BIT-MASK
2605	006000	000000			MASK2: .WORD	0 ; PRE-LOADED BY THE TEST WITH THE 2ND BIT-MASK
2606	006002				SPECST: .BLKW	40
2607		000002			.RADIX	2 ; SET RADIX TO BINARY REPRESENTATION
2608	006102	177777			PATRNS: .WORD	1111111111111111 ; ALL BITS SET
2609	006104	000000			.WORD	0000000000000000 ; ALL BITS CLEAR
2610	006106	125252			.WORD	1010101010101010 ; ODD BITS SET, EVEN BITS CLEAR
2611	006110	052525			.WORD	0101010101010101 ; EVEN BITS SET, ODD BITS CLEAR
2612	006112	031463			.WORD	0011001100110011 ; ALTERNATING PAIRS OF BITS SET
2613	006114	007417			.WORD	0000111100001111 ; ALTERNATING GROUPS OF 4 BITS SET
2614	006116	000377			.WORD	0000000011111111 ; LOWER BYTE SET, UPPER BYTE CLEAR
2615		000010			.RADIX	8 ; SET RADIX BACK TO OCTAL
2616	006120	000	000	000	DFMSG: .BYTE	0,0,0,0,0 ; ALL NUMBERS ARE TO BE PRINTED IN OCTAL
2617	006125	200	125	116	UBMAVA: .ASCIZ	<CRLF>?UNIBUS MEMORY AVAILABLE = ?
2618	006161	123	127	122	NEWSWR: .ASCIZ	?SWR INPUT ?
2619	006174	040	113	200	UBMEND: .ASCIZ	? K?<CRLF>



```

2636          .SBTTL  PRE-TESTING SETUP
2637          :*****
2638          :START OF TEST CODE
2639          :*****
2640
2641          010000          .=10000          ;START TEST CODE AT ADDRESS 10000 (2K)
2642 010000 012737 000340 177776 START: MOV #340,PS          ;LOCK OUT ALL INTERRUPTS
2643 010006 012700 001100          MOV #SCMTAG,R0          ;FIRST LOCATION TO BE CLEARED
2644 010017 012701 000021          MOV #<STKS-SCMTAG>/2,R1;MOVE LOOP COUNTER TO R1
2645 010016 005020          11$: CLR (R0)+          ;CLEAR MEMORY LOCATION
2646 010020 077102          SOB R1,11$          ;SUBTRACT 1 AND BRANCH IF NOT DONE YET
2647 010022 005037 020150          CLR $PASS          ;INITIALIZE PASS COUNT
2648 010026 012706 001100          MOV #STACK,SP          ;INITIALIZE STACK
2649 010032 012700 010054          MOV #13$,R0          ;MOVE ADDRESS OF VECTORS TO R0
2650 010036 012701 000005          MOV #5,R1          ;DO 5 LOADS
2651 010042 012030          12$: MOV (R0)+,@(R0)+          ;MOVE VECTOR TO LOCATION
2652 010044 012730 000340          MOV #340,@(R0)+          ;MOVE PRIORITY 7 TO NEXT LOCATION
2653 010050 077104          SOB R1,12$          ;BRANCH BACK IF NOT DONE YET
2654 010052 000417          BR 14$          ;BRANCH OVER DATA WORDS
2655 010054 020266 000020 000022 13$: .WORD $SCOPE,IOTVEC,IOTVEC+2,$ERROR,EMTVEC,EMTVEC+2,$TRAP,TRAPVE
2656 010074 000036 023610 000024          .WORD TRAPVE+2,$PWRDN,PWRVEC,PWRVEC+2,$RTRN,TBITVE,TBITVE+2
2657 010112 013737 021644 021636 14$: MOV $ENDCT,$EOPCT          ;SETUP END-OF-PROGRAM COUNTER
2658 010120 005037 001214          CLR $ESCAPE          ;CLEAR THE ESCAPE ON ERROR ADDRESS
2659 010124 112737 000001 001113          MOV #1,$ERMAX          ;ALLOW ONE ERROR PER TEST
2660 010132 012737 000002 022070          MOV #RTI,$RTRN          ;SET $RTRN TO AN RTI
2661 010140 012737 010166 000010          MOV #16$,RESVEC          ;MOVE 16$ (FAILURE) TO RESVEC
2662 010146 012746 000340          MOV #340,-(SP)          ;MOVE PRIORITY 7 TO STACK
2663 010152 012746 010160          MOV #15$,-(SP)          ;MOVE 15$ (SUCCESS) TO THE STACK
2664 010156 000006          RTT          ;TRY TO DO AN RTT
2665 010160 012737 000006 022070 15$: MOV #RTI,$RTRN          ;RTT IS LEGAL--SET $RTRN TO AN RTT
2666 010166 012706 001100          16$: MOV #STACK,SP          ;RESET STACK IF NECESSARY
2667 010172 012737 000012 000010          MOV #RESVEC+2,RESVEC;RESET TRAP CATCHER
2668 010200 005037 022076          CLR $TBIT          ;CLEAR 'T' BIT SWITCH
2669 010204 012737 010700 001104          MOV #TST1+2,$LPADR          ;SETUP $LPADR
2670 010212 012737 010700 001106          MOV #TST1+2,$LPERR          ;SETUP $LPERR
2671 010220 005227 177777          INC #-1          ;FIRST TIME?
2672 010224 001017          BNE 18$          ;BRANCH IF NOT
2673 010226 104401 010234          TYPE ,17$          ;TYPE THE TEST TITLE
2674 010232 000414          BR 18$          ;BRANCH OVER ASCIZ
2675 010234          103          113          113 17$: .ASCIZ 'CKKUAEO 11/24/44 UBI MAP'
2676          .EVEN
2677 010264 005737 020150          18$: TST $PASS          ;IS THIS THE FIRST PASS?
2678 010270 001140          BNE 8$          ;BRANCH IF NOT
2679 010272 013746 000004          MOV 4,-(SP)          ;SAVE TIMEOUT VECTOR
2680 010276 012737 010470 000004          MOV #2$,4          ;TIMEOUTS TO 104$
2681 010304 013746 000006          MOV 6,-(SP)          ;SAVE PS VECTOR
2682 010310 012737 000340 000006          MOV #340,6          ;PRIORITY 7
2683 010316 000007          MFPT          ;DETERMINE PROCESSOR TYPE
2684 010320 110037 007140          MOV #R0,CPUTYP          ;MOVE THE CPU NUMBER TO CPUTYP
2685 010324 105337 007140          DECB CPUTYP          ;MAKE THE 11/44 VALUE ZERO
2686 010330 001021          BNE 1$          ;BRANCH TO NEXT TEST IF NOT AN 11/44
2687 010332 022737 177777 177570          CMP #-1,177570          ;SEE IF SSWR IS TO BE USED :DPM002
2688 010340 001004          BNE 1000$          ;BRANCH TO SETUP FOR HARDWARE SWR :DPM002
2689 010342 012737 000176 001136          MOV #176,SWR          ;SET UP FOR SSWR :DPM002
2690 010350 000403          BR 1010$          ;BRANCH :DPM002
2691 010352 012737 177570 001136 1000$: MOV #177570,SWR          ;SET UP FOR HARDWARE SWITCH REGISTER :DPM002
2692 010360 112737 000064 006255 1010$: MOV #4,CPUMSG+55          ;MOVE ASCII 4 TO LOCATION IN MESSAGE TO PRINT

```

2693	010366	104401	006200		TYPE	,CPUMSG	:TYPE THE CPU TYPE HEADER	
2694	010372	000446			BR	6\$	:CONTINUE	
2695	010374	122737	000002	007140	1\$:	CMPB	#2,CPUTYP	:SEE IF THIS IS AN 11/24
2696	010402	001034			BNE	3\$	:BRANCH TO FATAL ERROR MESSAGE PRINTING IF NOT	
2697	010404	012737	000176	001136	MOV	#\$SSWR,SWR	:SETUP SOFTWARE SWITCH REGISTER ;DPM002	
2698	010412	112737	000062	006255	MOV	#'2,CPUMSG+55	:MOVE ASCII 2 TO LOCATION IN MESSAGE TO PRINT	
2699	010420	104401	006200		TYPE	,CPUMSG	:TYPE THE CPU TYPE HEADER	
2700	010424	105737	020163		TSTB	\$ENVM	:IS APT SIZING	
2701	010430	100427			BMI	6\$	:BRANCH IF NO	
2702	010432	012737	000176	001136	MOV	#\$SSWR,SWR	:SETUP SOFTWARE SWITCH REGISTER	
2703	010440	005737	000176		TST	\$SSWR	:SEE IF SWR IS NON-ZERO	
2704	010444	001021			BNE	6\$	:BRANCH IF SO	
2705	010446	104401	006161		TYPE	,NEWSWR	:TYPE: 'SWR INPUT'	
2706	010452	104410			RDOCT		:GO READ USER OCTAL INPUT	
2707	010454	012637	000176		MOV	(SP)+,\$SSWR	:MOVE NEW CONTENTS TO THE SOFTWARE SWR LOCATION	
2708	010460	001013			BNE	6\$	:BRANCH IF NON-ZERO	
2709	010462	005237	000176		INC	\$SSWR	:MAKE SWR NON-ZERO FOR POSSIBLE NEXT RUN	
2710	010466	000410			BR	6\$	:CONTINUE	
2711	010470	062706	000004		2\$:	ADD	#4,SP	:CLEAN STACK AFTER TIMEOUT
2712	010474	005237	020142		3\$:	INC	\$MSGTY	:TELL APT THIS IS A FATAL ERROR
2713	010500	104401	006607		4\$:	TYPE	,BADCPU	:TYPE THE BAD CPU MESSAGE
2714	010504	000000			HALT		:FATAL ERROR - THIS DIAGNOSTIC IS WRITTEN	
2715							:FOR 11/24 AND 11/44 PROCESSORS ONLY	
2716	010506	000774			BR	4\$	:DON'T ALLOW CONTINUE	
2717	010510	012637	000006		6\$:	MOV	(SP)+,6	:RESTORE TIMEOUT PS
2718	010514	012637	000004		MOV	(SP)+,4	:RESTORE TIMEOUT VECTOR	
2719	010520	013746	172346		MOV	KIPAR3,-(SP)	:SAVE PAR3	
2720	010524	012737	000400	172346	MOV	#400,KIPAR3	:START WITH ADDRESS 40000	
2721	010532	012704	060000		MOV	#60000,R4	:ADDRESS PAR3. OFFSET=0	
2722	010536	012705	040222		MOV	#40222,R5	:DATA TO LOAD TO 40000	
2723	010542	010514			7\$:	MOV	R5,(R4)	:MOVE DATA TO LOCATION
2724	010544	062705	010000		ADD	#10000,R5	:MOVE DATA UP 10000	
2725	010550	062737	000100	172346	ADD	#100,KIPAR3	:MOVE ADDRESS UP 10000	
2726	010556	022737	007600	172346	CMP	#7600,KIPAR3	:SEE IF ALL DONE YET	
2727	010564	001366			BNE	7\$	:BRANCH BACK IF NOT	
2728	010566	012637	172346		MOV	(SP)+,KIPAR3	:RESTORE PAR3	
2729	010572	105737	020163		8\$:	TSTB	\$ENVM	:IS APT SIZING
2730	010576	100003			BPL	LOOP	:BRANCH IF NOT	
2731	010600	012737	020164	001136	MOV	#\$SWREG,SWR	:USE APT SWITCH REGISTER	
2732	010606	012737	00337?	000250	LOOP:	MOV	##MTRAP,MMVEC	:LOAD MEMORY MANAGEMENT TRAP SERVICE ROUTINE ADDRESS
2733	010614	012737	000340	000252	MOV	#340,MMVEC+2	:SET PRIORITY SEVEN	
2734	010622	012737	003222	000004	MOV	#CPUER,ERRVEC	:LOAD CPU TRAP SERVICE ROUTINE ADDR	
2735	010630	012737	000340	000006	MOV	#340,ERRVEC+2	:SET PRIORITY SEVEN	
2736	010636	005037	001326		CLR	CPUEXP	:NOT EXPECTING ANY CPU ERRORS	
2737	010642	005037	177572		CLR	MMR0	:START IN 16 BIT MAPPING	
2738	010646	005037	172516		CLR	MMR3	:DISABLE MAP AND 22-BIT MAPPING	
2739	010652	012700	177777		MOV	#-1,R0	:NEGATIVE ONE USED TO INITIALIZE FLAGS	
2740	010656	010037	003224		MOV	R0,CPFLAG	:INITIALIZE FLAGS	
2741	010662	010037	003032		MOV	R0,TOFLAG	:INITIALIZE FLAGS	
2742	010666	010037	003374		MOV	R0,MMFLAG	:INITIALIZE FLAGS	
2743	010672	010037	177766		MOV	R0,CPUEER	:CLEAR CPU ERROR REGISTER	



2753

.SBTTL TEST # 1 - MAP REGISTER RESPONSE TEST

\*\*\*\*\*

\*TEST 1 MAP REGISTER RESPONSE TEST

\*

\* THIS TEST IS USED TO ENSURE THAT ALL THE UNIBUS MAP REGISTERS  
 \* CAN BE REFERENCED UNDER PROGRAM CONTROL, WITHOUT TIMING OUT.  
 \* THE ADDRESSES OF ANY MAP REGISTERS THAT TIME OUT WILL BE REPORTED  
 \* AND, AT THE END OF THE TEST, A SUMMARY OF THOSE REGISTERS WILL  
 \* BE GIVEN.

\*

\*\*\*\*\*

TST1:

010676	010676	000004			SCOPE		
010700	010700	004737	005166		JSR	PC,PRETST	:GO SET UP PRETEST DATA
010704	010704	011122	011042	000001	.WORD	TST2,20\$,1	:DATA USED BY PRETST
2754	010712	012737	003030	000004	MOV	#TIMEOUT,ERRVEC	:LOAD ERRVEC WITH ROUTINE ADDRESS
2755	010720	105737	007140		TSTB	CPUTYP	:TEST TO SEE WHICH CPU IS RUNNING THIS DIAGNOSTIC
2756	010724	001435			BEQ	3\$	:BRANCH AROUND MAP REGISTER EXISTENCE CHECK IF 11/44
2757	010726	005037	001320		CLR	ERRCNT	:CLEAR THE ERROR COUNTER
2758	010732	013702	170200		1\$: MOV	MAPLO,R2	:READ FIRST MAP REGISTER TO R2
2759	010736	005737	001320		TST	ERRCNT	:SEE IF THERE WERE ANY ERRORS
2760	010742	001426			BEQ	3\$	:BRANCH TO CHECK THEM ALL IF NONE, THEY ARE IN THIS 11/24
2761	010744	105737	020162		TSTB	\$ENV	:ARE WE RUNNING UNDER APT
2762	010750	100004			BPL	2\$	:BRANCH IF NOT
2763	010752	005237	020142		INC	\$MSGTY	:TELL APT THIS IS A FATAL ERROR
2764	010756	000000			HALT		:HALT - FATAL ERROR
2765	010760	000764			BR	1\$	:TRY AGAIN - RESTART REQUESTED
2766	010762	104401	006754		2\$: TYPE	,MRQUES	:ASK USER IF THERE ARE MAP REGISTERS IN THIS 11/24
2767	010766	104406			RDCHR		:GO READ USER INPUT
2768	010770	112637	007043		MOVB	(SP)+,GMRMD1	:MOVE THE CHARACTER TO THE PRINTING LOCATION
2769	010774	104401	007043		TYPE	,GMRMD1	:TYPE THE CHARACTER
2770	011000	122737	000131	007043	CMPB	#'Y',GMRMD1	:SEE IF THIS WAS A 'Y'
2771	011006	001404			BEQ	3\$	:BRANCH AROUND FATAL MESSAGE IF EQUAL TO A 'Y'
2772	011010	104401	007046		TYPE	,GMRMOD	:TYPE: 'DIAGNOSTIC CHECKS THIS MODULE - INSERT : 'BEFORE RE-RUNNING'
2773							:FATAL ERROR - WAIT FOR USER ACTION
2774	011014	000000			HALT		:TRY AGAIN - RESTART REQUESTED
2775	011016	000745			BR	1\$	:PUT FIRST MAP REGISTER ADDR IN R0
2776	011020	012700	170200		3\$: MOV	#MAPLO,R0	:TEST ALL MAP REGISTERS
2777	011024	012703	000100		MOV	#100,R3	:CLEAR THE ERROR COUNTER
2778	011030	005037	001320		CLR	ERRCNT	:MAKE SURE \$LPERR IS POINTING AT 20\$
2779	011034	012737	011042	001106	MOV	#20\$, \$LPERR	:READ MAP REGISTERS TO R2
2780	011042	011002			20\$: MOV	(R0),R2	:SEE IF LOOP ON ERROR IS SET
2781	011044	032777	001000	170064	BIT	#BIT09,@SWR	:BRANCH AROUND SETUP IF NOT
2782	011052	001403			BEQ	4\$	:SEE IF AN ERROR OCCURED
2783	011054	005737	001320		TST	ERRCNT	:BRANCH BACK IF SO
2784	011060	001370			BNE	20\$	:INCREMENT R0 TO NEXT REGISTER LOCATION
2785	011062	005720			4\$: TST	(R0)+	:DO ALL OF THEM
2786	011064	077312			SOB	R3,20\$	:RESTORE CPU TRAP SERVICE ROUTINE ADDRESS TO ERRVEC
2787	011066	012737	003222	000004	MOV	#CPUER,ERRVEC	:MOVE 3\$ TO LOOP ON ERROR FOR ERROR +4 BELOW
2788	011074	012737	011020	001106	MOV	#3\$, \$LPERR	:SEE IF THERE WERE ANY ERRORS
2789	011102	005737	001320		TST	ERRCNT	:GO TO NEXT TEST IF NO ERRORS
2790	011106	001405			BEQ	TST2	:DON'T COUNT SUMMARY AS AN ADDITIONAL ERROR
2791	011110	005337	001110		DEC	\$ERTTL	:DECREMENT ERRCNT FOR SAME REASON
2792	011114	005337	001320		DEC	ERRCNT	:SUMMARY OF MAP REGISTERS THAT TIMED OUT ON READ
2793	011120	104004			ERROR	+4	



2846	011340	022700	170402			CMP	#MAPH37+4,RO	:SEE IF THIS PASS WAS UPPER 6 BITS
2847	011344	001402				BEQ	8\$	:GO SERVICE UPPER 6 BITS ERROR IF SO
2848	011346	104006				ERROR	+6	:SUMMARY OF BIT PATTERN FAILURES, LOWER 16 BITS
2849	011350	000405				BR	10\$	:GO SET UP DATA FOR TESTING UPPER 6 BITS
2850	011352	104007			8\$:	ERROR	+7	:SUMMARY OF BIT PATTERN FAILURES, UPPER 6 BITS
2851	011354	000433				BR	TST3	:GO TO NEXT TEST - LOWER 16 BITS ALREADY TESTED
2852	011356	022700	*70402		9\$:	CMP	#MAPH37+4,RO	:SEE IF THIS PASS WAS FOR THE UPPER 6 BITS
2853	011362	001430				BEQ	TST3	:GO TO NEXT TEST IF IT WAS
2854	011364	012737	011254	001106	10\$:	MOV	#20\$,SLPERR	:RESET LOOP ON ERROR TO 20\$
2855	011372	012700	170202			MOV	#MAPH00,RO	:MOVE STARTING ADDRESS OF UPPER 6 BITS REGISTER TO RO
2856	011376	012737	177700	005776		MOV	#177700,MASK1	:MOVE 1ST MASK TO MASK1
2857	011404	012737	177700	006000		MOV	#177700,MASK2	:MOVE 2ND MASK TO MASK2
2858	011412	005037	001254			CLR	PATTOR	:CLEAR PATTOR FOR NEXT PASS
2859	011416	005037	001246			CLR	DATAOR	:CLEAR DATAOR FOR NEXT PASS
2860	011422	012737	177777	001252		MOV	#-1,PATAND	:MOVE -1 TO PATAND FOR NEXT PASS
2861	011430	012737	177777	001242		MOV	#-1,DATAND	:MOVE -1 TO DATAND FOR NEXT PASS
2862	011436	005037	001320			CLR	ERRCNT	:CLEAR ERROR COUNT FOR NEXT PASS
2863	011442	000651				BR	2\$	:GO REACCOMPLISH TEST FOR UPPER 6 BITS

2876

.SBTTL TEST # 3 - DUAL ADDRESS LOADS & READS MAP REG'S

\*\*\*\*\*

\*TEST 3 DUAL ADDRESS LOADS & READS MAP REG'S

\*

THIS TEST ENSURES THAT ONLY ONE UNIBUS MAP REGISTER IS LOADED DURING A 'MOV #DATA,MAPREG' INSTRUCTION. ALL MAP REGISTERS ARE CLEARED AND ONE REGISTER AT A TIME, STARTING WITH MAPL00, IS LOADED WITH A -1. THEN, ALL MAP REGISTERS ARE READ, STARTING WITH MAPH37, AND VERIFIED TO BE ZERO. ANY REGISTER THAT IS NOT ZERO AND WHOSE UNIBUS ADDRESS DOES NOT MATCH THAT OF THE REGISTER UNDER TEST IS REPORTED TO BE IN ERROR. AT THE END OF THE TEST A SUMMARY OF ALL DUALED REGISTERS IS GIVEN.

\*

\*\*\*\*\*

TST3:

Address	Hex	Dec	Hex	Dec	Label	Instruction	Comment
011444	000004					JSR	PC,PRETST ;GO SET UP PRETEST DATA
011444	004737	005166				.WORD	TST4,20\$,3 ;DATA USED BY PRETST
011452	011762	011616	000003			BIC	#1,MMR0 ;TURN OFF MEMORY MANAGEMENT
2877	011460	042737	000001	177572		MOV	#MAPL00,R0 ;LOAD ADDRESS OF MAPL00 IN R0
2878	011466	012700	170200			MOV	#177700,R2 ;SET UP XOR DATA
2879	011472	012702	177700			MOV	#MAPH37+2,R1 ;PUT ADDRESS OF MAPH37+2 IN R1
2880	011476	012701	170400		1\$:	MOV	#77,\$TMP0 ;SET UP TEST PATTERN IN \$TMP0
2881	011502	012737	000077	001174		JSR	PC,CLRMAP ;CLEAR ALL MAP REGISTERS FOR TEST
2882	011510	004737	002772			MOV	#100,R3 ;SET UP LOOP COUNTER FOR TESTING 40 REGISTERS, 2 WORDS EACH
2883	011514	012703	000100			CLR	MMR3 ;CLEAR MMR3
2884	011520	005037	172516		2\$:	MOV	#100,R4 ;SET UP LOOP COUNTER FOR CHECKING 40 REGISTERS, 2 WORDS EACH
2885	011524	012704	000100			XOR	R2,\$TMP0 ;REVERSE BIT STATES OF \$TMP0 IN BITS 7 TO 15
2886	011530	074237	001174			MOV	\$TMP0,(R0) ;LOAD MAP REGISTER UNDER TEST
2887	011534	013710	001174			MOV	#MAPH37+2,R1 ;PUT ADDRESS OF MAPH37+2 IN R1
2888	011540	012701	170400		3\$:	TST	-(R1) ;SEE IF MAP REGISTER IS ZERO
2889	011544	005741				BEQ	7\$ ;GO SEE IF MORE REGISTERS TO TEST IF = 0
2890	011546	001435				CLR	(R1) ;CLEAR THE FAILED LOCATION
2891	011550	005011				CMR	R1,R0 ;SEE IF NON-ZERO REGISTER ADDRESS MATCHES ADDRESS LOADED
2892	011552	020100				BEQ	7\$ ;GO SEE IF MORE REGISTERS TO TEST IF SO
2893	011554	001432				MOV	(R1)+,\$TMP3 ;MOVE FAULTY DATA TO \$TMP3 & PREPARE R1 FOR POSSIBLE LOOP
2894	011556	012137	001202			MOV	\$TMP3,-(SP) ;MOVE FAULTY DATA TO STACK FOR SUBROUTINE USE
2895	011562	013746	001202			MOV	KIPAR4,-(SP) ;MOVE PAR4 TO STACK FOR SUBROUTINE USE
2896	011566	013746	172350			JSR	PC,ADREXT ;GO SET DATA IN THE 4 WORDS OF ADDROR AND ADRAND
2897	011572	004737	003674				AND FORM A PHYSICAL 22-BIT ADDRESS
2898						MOV	KIPAR7,-(SP) ;PUT PAR ON STACK FOR DATEXT SUBROUTINE USE
2899	011576	013746	172356			MOV	R1,-(SP) ;PUT VIRTUAL ADDRESS ON STACK FOR DATEXT SUBROUTINE USE
2900	011602	010146				JSR	PC,DATEXT ;SUBROUTINE TO LOAD DATAOR AND DATAND
2901	011604	004737	003624			MOV	R0,EADRS2 ;MOVE ADDRESS IN R0 TO EADRS2 FOR ERROR CALL
2902	011610	010037	005770			BR	5\$ ;BRANCH OVER LOOP ON ERROR SECTION
2903	011614	000405				MOV	\$TMP0,(R0) ;LOAD MAP REGISTER UNDER TEST
2904	011616	013710	001174		20\$:	TST	(R1) ;SEE IF MAP REGISTER IS ZERO
2905	011622	005711				BEQ	6\$ ;GO SEE IF LOOP ON ERROR IS STILL SET IF ZERO
2906	011624	001402				CLR	(R1) ;CLEAR THE FAILED LOCATION
2907	011626	005011			5\$:	ERROR	+202 ;DUAL ADDRESSING ERROR IN THE UNIBUS MAP
2908	011630	104202			6\$:	BIT	#BIT09,@SWR ;SEE IF LOOP ON ERROR IS SET
2909	011632	032777	001000	167276		BNE	20\$ ;BRANCH BACK IF SO
2910	011640	001366			7\$:	SOB	R4,3\$ ;BRANCH IF MORE REGISTERS TO CHECK
2911	011642	077440				CLR	(R0)+ ;CLEAR THE REGISTER JUST TESTED AND POINT TO NEXT REGISTER
2912	011644	005020				DEC	R3 ;DECREMENT LOOP COUNTER AND
2913	011646	005303				BNE	2\$ ;BRANCH IF MORE REGISTERS TO TEST
2914	011650	001325				TST	ERRCNT ;SEE IF THERE WERE ANY ERRORS
2915	011652	005737	001320				

2916 011656 001405  
2917 011660 005337 001110  
2918 011664 005337 001320  
2919 011670 104005

BEQ      RELC22  
DEC      \$ERTTL  
DEC      ERRCNT  
ERROR    +5

:GO TO NEXT SECTION IF NO ERRORS  
:DON'T COUNT ERROR +5 AS ANOTHER ERROR  
:SAME AS ABOVE  
:SUMMARY OF DUAL ADDRESSING ERRORS ON LOADING MAP REGISTERS

```

2920 011672 104414          RELC22: TBITR          ;RESTORE THE T BIT TO ITS CONDITION
2921                                ;BEFORE THE LAST TEST
2922 011674 012700 077406    MOV          #77406,R0          ;MAKE THE KERNEL I-SPACE PAGES ALL
2923                                ;4K, UPWARD EXPANDABLE, READ/WRITE
2924 011700 012701 172300    MOV          #KIPDR0,R1        ;MOVE ADDRESS OF KIPDR0 TO R1
2925 011704 012702 000010    MOV          #8.,R2           ;LOAD 8 PDR'S
2926 011710 010021          1$: MOV        R0,(R1)+         ;KERNEL I-SPACE PAGE X KIPDRX
2927 011712 077202          SOB          R2,1$           ;SUBTRACT 1 AND BRANCH BACK IF NOT DONE
2928 011714 005000          CLR          R0             ;CLEAR R0
2929 011716 012701 172340    MOV          #KIPAR0,R1        ;MOVE ADDRESS OF KIPAR0 TO R1
2930 011722 012702 000006    MOV          #6,R2           ;LOAD FIRST 6 PAR'S
2931 011726 010021          2$: MOV        R0,(R1)+         ;MAP KIPARX TO NEXT PHYSICAL PAGE
2932 011730 062700 000200    ADD          #200,R0          ;MAP R0 TO NEXT PAGE
2933 011734 077204          SOB          R2,2$           ;SUBTRACT 1 AND BRANCH BACK IF NOT DONE
2934 011736 012721 170000    MOV          #170000,(R1)+     ;MAP KIPAR6 TO UNIBUS
2935 011742 012721 177600    MOV          #177600,(R1)+     ;MAP KIPAR7 TO I/O PAGE
2936 011746 012737 000001 177572    MOV          #BIT0,MMR0        ;ENABLE FULL 18-BIT MAPPING
2937 011754 012737 000020 172516    MOV          #BIT4,MMR3        ;ENABLE 22-BIT MAPPING
2938                                ;* AT THIS POINT 22-BIT RELOCATION FROM MEMORY MANAGEMENT
2939                                ;* IS ENABLED, WITH THE KIPAR'S MAPPED TO PHYSICAL 0-24K.
2940                                ;* KIPAR6 IS MAPPED TO THE UNIBUS (170000) AND
2941                                ;* KIPAR7 IS MAPPED TO THE I/O PAGE (177600).

```



2994	012222	012600		MOV	(SP)+,R0	:RESTORE R0
2995	012224	074037	172354	XOR	R0,KIPAR6	:RESTORE BIT TO ORIGINAL STATUS
2996	012230	006200		ASR	R0	:RIGHT SHIFT ONE PLACE
2997	012232	001277		BNE	1\$	:GO CONTINUE TEST IF BIT NOT SHIFTED OUT YET
2998	012234	013737	001200 172354 6\$:	MOV	\$TMP2,KIPAR6	:RESTORE KIPAR6



3011

```
.SBTTL TEST # 5 - DATA PATH, UNIBUS TO MAIN MEMORY
*****
*TEST 5 DATA PATH, UNIBUS TO MAIN MEMORY
*
* THIS TEST RUNS A COUNT PATTERN THROUGH A MEMORY LOCATION VIA
* THE UNIBUS. THE UNIBUS MAP IS LEFT OFF DURING THIS TEST SO
* THAT THE ADDRESS IS NOT RELOCATED. THE TEST TRIES TO LOAD THE
* PATTERN INTO ADDRESS 040000 (8K) BUT IF THE MAP JUMPERS ARE
* SET NOT TO RESPOND TO THAT ADDRESS THE NEXT 4K IS TRIED UNTIL
* THE TEST GETS TO MAIN MEMORY FROM THE UNIBUS. IF THIS TEST
* DETERMINES THAT IT CANNOT GET TO MAIN MEMORY FROM THE UNIBUS
* IT REPORTS THE FACT AND SKIPS THE NEXT TEST FOR VERIFICATION.
*****
```

```
TST5:
SCOPE
JSR PC,PRETST ;GO SET UP PRETEST DATA
.WORD TST6,20$,5 ;DATA USED BY PRETST
JSR PC,CLRMAP ;CLEAR ALL MAP REGISTERS
20$: MOV #35,R4 ;DO 35 ACCESSES
MOV #170400,KIPAR6 ;START WITH ADDRESS 8K FROM UNIBUS
MOV #170400,$TMP6 ;MOVE IT TO $TMP6 ALSO
2$: CLR PCPUER ;CLEAR ERROR CONDITION LOCATION
MOV #TIMOUT,CPUEXP ;TIMEOUTS MIGHT OCCUR IN THIS TEST.
MOV 140000,R0 ;TRY TO READ ADDRESS POINTED TO BY PAR6
CLR CPUEXP ;CLEAR CPUEXP - NO TIMEOUTS FOR A WHILE
TST PCPUER ;SEE IF READ OF ADDRESS TIMED OUT
BEQ 4$ ;BRANCH IF REFERENCE WAS GOOD
3$: ADD #200,KIPAR6 ;TRY NEXT 4K BLOCK OF MEMORY
ADD #200,$TMP6 ;ADD 200 TO $TMP6 ALSO
SOB R4,2$ ;SUBTRACT 1 FROM R4 AND BRANCH IF NOT DONE
ERROR +10 ;NO UNIBUS ADDRESSES RESPOND
BR SIZEJ0 ;BRANCH TO SIZE JUMPER SECTION
4$: MOV KIPAR6,KIPAR5 ;PUT PAR6 INTO PAR5
MOV $TMP6,$TMP5 ;DO SAME TRANSFER
BIC #170000,KIPAR5 ;MAKE PAR5 A NON UNIBUS ADDRESS
BIC #170000,$TMP5 ;CLEAR SAME BITS
MOV #173214,120000 ;PUT RANDOM NUMBER INTO TEST LOCATION BY FAST BUS
MOV #TIMOUT,CPUEXP ;TIMEOUTS MIGHT OCCUR IN THIS TEST.
MOV 140000,R1 ;READ TEST LOCATION BY UNIBUS
CLR CPUEXP ;CLEAR CPUEXP - NO TIMEOUTS FOR A WHILE
CMP #173214,R1 ;SEE IF DATA WAS READ PROPERLY
BEQ 5$ ;DATA OKAY NOW VERIFY DATA PATH
CMP R0,R1 ;SEE IF DATA CHANGED FROM FIRST READ
BNE 5$ ;BRANCH AROUND NEXT TRY IF SO
5$: ADD #200,KIPAR6 ;TRY NEXT 4K BLOCK OF MEMORY
SOB R4,2$ ;BRANCH BACK TO TRY NEXT 4K BLOCK
MOV #PATRNS,R1 ;LOAD ADDRESS OF BIT PATTERNS IN R1
MOV #140000,R2 ;LOAD VIRTUAL ADDRESS INTO R2
MOV #7,R3 ;DO 7 PATTERNS
MOV #TIMOUT,CPUEXP ;TIMEOUTS MIGHT OCCUR IN THIS TEST.
6$: MOV (R1),(R2) ;LOAD COUNT INTO TEST LOCATION VIA U.B.
CMP (R1),(R2) ;COMPARE COUNT WITH DATA READ
BEQ 10$ ;BRANCH IF DATA MATCHES
```

3048	012502	011137	001174			MOV	(R1), \$TMP0	:MOVE EXPECTED PATTERN TO \$TMP0
3049	012506	011237	001176			MOV	(R2), \$TMP1	:MOVE RECEIVED PATTERN TO \$TMP1
3050	012512	011246				MOV	(R2), -(SP)	:PUT DATA ON STACK FOR DATEXT SUBROUTINE USE
3051	012514	004737	003624			JSR	PC, DATEXT	:SUBROUTINE TO LOAD DATAOR AND DATAND
3052	012520	011146				MOV	(R1), -(SP)	:PUT PATTERN ON STACK FOR PATEXT SUBROUTINE USE
3053	012522	004737	003650			JSR	PC, PATEXT	:GO SET DATA INTO PATTOR AND PATAND
3054	012526	012737	012536	001106		MOV	#7\$, \$LPERR	:SET LOOP ON ERROR POINTER TO 61\$
3055	012534	000403				BR	8\$	:BRANCH OVER LOOP ON ERROR SECTION
3056	012536	011112			7\$:	MOV	(R1), (R2)	:LOAD COUNT INTO TEST LOCATION VIA U.B.
3057	012540	021112				CMP	(R1), (R2)	:COMPARE COUNT WITH DATA READ
3058	012542	001401				BEQ	9\$	:BRANCH IF OK NOW
3059	012544	104204			8\$:	ERROR	+204	:REPORT ERROR(S) ON UNIBUS DATA PATH
3060	012546	032777	001000	166362	9\$:	BIT	#BIT9, @SWR	:SEE IF LOOP ON ERROR IS SET
3061	012554	001370				BNE	7\$	:BRANCH BACK IF SO
3062	012556	062701	000002		10\$:	ADD	#2, R1	:MOVE TO NEXT PATTERN
3063	012562	077334				SOB	R3, 6\$	:DECREMENT LOOP COUNTER AND BRANCH IF NOT DONE
3064	012564	005037	001326			CLR	CPUEXP	:CLEAR CPUEXP - NO TIMEOUTS FOR A WHILE
3065	012570	005737	001320			TST	ERRCNT	:WERE THERE ANY ERRORS ON THIS TEST
3066	012574	001405				BEQ	11\$	:BRANCH IF NO ERRORS ON THIS TEST
3067	012576	005337	001110			DEC	\$ERTTL	:DON'T COUNT ERROR +11 AS ANOTHER ERROR
3068	012602	005337	001320			DEC	ERRCNT	:SAME AS ABOVE
3069	012606	104011				ERROR	+11	:SUMMARY OF ERRORS ON THE UNIBUS DATA PATH
3070	012610	023737	001206	172352	11\$:	CMP	\$TMP5, KIPAR5	:MAKE SURE PARS CONTAINS EXPECTED CONTENTS
3071	012616	001404				BEQ	TST6	:BRANCH IF OK
3072	012620	104030				ERROR	+30	:KIPAR5 NOT LOADED PROPERLY - SKIPPING NEXT TEST
3073	012622	013737	001206	172352		MOV	\$TMP5, KIPAR5	:RESET KIPAR5 FOR EXECUTION OF NEXT TEST

3087

```
.SBTTL TEST # 6 - MAP DOESN'T RELOCATE IF NOT ENABLED
:*****
:*TEST 6 MAP DOESN'T RELOCATE IF NOT ENABLED
:*
:* THIS TEST VERIFIES THAT THE UNIBUS MAP DOES NOT RELOCATE IF BITS
:* OF MMR3 IS NOT SET. THE TEST ASSUMES THAT THE PREVIOUS TEST HAS
:* RUN SUCCESSFULLY AND LEFT KIPAR6 POINTING TO THE FIRST UNIBUS
:* MAPPING REGISTER THAT THE UNIBUS MAP WILL RESPOND TO GREATER
:* THAN OR EQUAL TO MAPREG #2. KIPAR5 IS ALSO POINTING TO THE
:* SAME MEMORY BASE ADDRESS EXCEPT IT POINTS OVER THE FASTBUS.
:* THE TEST THEN SETS ONE BIT IN EACH A.L.U. OF THE UNIBUS MAP
:* AND TRIES TO REFERENCE MAIN MEMORY OVER THE UNIBUS. SINCE THE
:* MAP IS NOT ENABLED THE LOAD WILL GO TO MAIN MEMORY UNRELOCATED.
:*****
```

3088	012630	000004			TST6:	SCOPE		
3089	012632	004737	005166			JSR	PC,PRETST	:GO SET UP PRETEST DATA
3090	012636	012744	012710	000006		.WORD	SIZEJ0,20\$,6	:DATA USED BY PRETST
3091	012644	052737	000001	177572		BIS	#BIT0,MMR0	:TURN MEMORY MANAGEMENT BACK ON
3092	012652	013700	172354			MOV	KIPAR6,R0	:PUT UNIBUS ADDRESS OF MAP REGISTER IN R0
3093	012656	072027	177773			ASH	#-5,R0	:RIGHT SHIFT R0 5 PLACES
3094	012662	042700	177400			BIC	#177400,R0	:CLEAR UPPER BYTE
3095	012666	042737	177000	172352		BIC	#177000,KIPAR5	:MAKE KIPAR5 ACCESS THE FAST BUS
3096	012674	012720	021042			MOV	#021042,(R0)+	:SET BOTTOM BIT IN EACH ALU
3097	012700	012710	000042			MOV	#42,(R0)	:SET BOTTOM BIT IN EACH ALU
3098	012704	005037	120000			CLR	120000	:CLEAR TEST LOCATION VIA FAST BUS
3099	012710	012737	000020	001326	20\$:	MOV	#TIMOUT,CPUEXP	:TIMEOUTS MIGHT OCCUR IN THIS TEST.
3100	012716	012737	043207	140000		MOV	#43207,140000	:LOAD TEST LOCATION VIA UNIBUS THIS LOAD SHOULD NOT BE
3101	012724	005037	001326			CLR	CPUEXP	:RELOCATED BY THE UNIBUS MAP, SINCE BIT05 OF MMR3 IS CLEAR.
3102	012730	013703	120000			MOV	120000,R3	:CLEAR CPUEXP - NO TIMEOUTS FOR A WHILE
3103	012734	022703	043207			MOV	#43207,R3	:READ TEST LOCATION VIA FAST BUS
3104	012740	001401				CMP	SIZEJ0,R3	:SEE IF DATA MATCHES
3105	012742	104012				BEQ	SIZEJ0	:BRANCH IF DATA GOOD
						ERROR	+12	:MAP RELOCATED WHEN NOT ENABLED

```

3106
3107
3108
3109
3110
3111
3112
3113
3114
3115
3116
3117
3118 012744 012705 020226
3119 012750 012700 170200
3120 012754 012701 000040
3121 012760 012702 006002
3122 012764 012720 020000
3123 012770 005020
3124 012772 005022
3125 012774 077105
3126 012776 012703 006002
3127 013002 052737 000040 172516
3128 013010 052737 000001 177572
3129 013016 012700 117776
3130 013022 012737 170000 172350
3131 013030 012702 125252
3132 013034 012737 177777 001174
3133 013042 012737 177777 003532
3134 013050 012737 037776 001310
3135 013056 005037 001312
3136 013062 012737 013070 001106
3137 013070 012737 000020 001326
3138 013076 004737 003474
3139 013102 000417
3140 013104 005037 001326
3141 013110 004737 005230
3142 013114 104214
3143 013116 062737 000200 172350
3144 013124 022737 177400 172350
3145 013132 001356
3146 013134 104013
3147 013136 000137 010000
3148 013142 005037 001326
3149 013146 004737 005266
3150 013152 104213
  
```

.SBTTL DETERMINATION OF FIRST USEABLE MAP REGISTER

```

*****
*
* THIS TEST DETERMINES THE SETTING OF THE JUMPERS ON THE UNIBUS
* MAP WHICH ALLOW THE MAP TO RESPOND TO THOSE ADDRESSES BETWEEN
* THE JUMPER RANGE. THE DEFAULT SETTING ALLOWS THE MAP TO RESPOND
* TO ADDRESSES 000000 - 757776 ON THE UNIBUS. IF THE JUMPERS ARE
* NOT SET IN THEIR DEFAULT POSITION AN INFORMATIONAL MESSAGE IS GIVEN.
* >>>>>>>NOTE<<<<<<<<
* THIS IS THE FIRST TEST IN WHICH THE UNIBUS MAP IS TURNED ON.
*
*****
SIZEJO: MOV #SDDW0,R5 ;PUT ADDRESS OF SDDW0 IN R5
MOV #MAPLO,R0 ;LOAD ADDRESS OF FIRST MAP REGISTER IN R0
MOV #40,R1 ;DO ALL 40 REGISTERS
MOV #SPECST,R2 ;SET R2 TO BEGINING OF SPECIAL STACK
1$: MOV #20000,(R0)+ ;LOAD 4K INTO LOWER 16 BITS AND
CLR (R0)+ ;CLEAR THE UPPER 6 BITS
CLR (R2)+ ;CLEAR THE SPECIAL STACK LOCATION
SOB R1,1$ ;BRANCH IF THERE ARE MORE TO LOAD
MOV #SPECST,R3 ;RESET SPECIAL STACK POINTER
BIS #BIT5,MMR3 ;TURN ON MAP RELOCATION
BIS #BIT0,MMR0 ;MAKE SURE MEMORY MANAGEMENT IS ON
MOV #117776,R0 ;THIS WILL BE USED TO SELECT PAR 4, ADDRESS 17776
MOV #170000,KIPAR4 ;LOAD MAP REGISTER 0 -200 IN KIPAR4
MOV #125252,R2 ;CONSTANT TO LOAD INTO LOCATION 17776
MOV #-1,$TMP0 ;MOVE -1 TO MAP REGISTER POINTER
MOV #-1,$FTTHRU ;INITIALIZE ONE TIME ENTRANCE FLAG IN SUBROUTINE
MOV #37776,UBM24L ;MOVE TEST CELL ADDRESS TO LOCATION UBM24L
CLR UBM24U ;CLEAR UPPER LOCATION UBM24U
MOV #2$, $LPERR ;MOVE LOOP ON ERROR ADDRESS TO $LPERR
2$: MOV #TIMOUT,CPUEXP ;EXPECTING CPU TIME OUT ON UNIBUS
JSR PC,$TSTLOC ;GO TO SUBROUTINE TO SEE IF LOCATION RESPONDS
BR 3$ ;RETURN IS HERE IF LOWEST FOUND
CLR CPUEXP ;CLEAR CPUEXP - NO TIMEOUTS FOR A WHILE
JSR PC,$DSABLD ;GO SEE IF REGISTER SHOULD BE DISABLED
ERROR +214 ;MAP REGISTER DISABLED WHEN SHOULD BE ENABLED
ADD #200,KIPAR4 ;MAP TO NEXT REGISTER
CMP #177400,KIPAR4 ;SEE IF WE ARE POINTING JUST BELOW THE I/O PAGE
BNE 2$ ;GO TEST NEXT MAP REGISTER IF NOT
ERROR +13 ;FATAL ERROR, RESTARTING PROGRAM
JMP START ;JUMP TO RESTART PROGRAM
3$: CLR CPUEXP ;CLEAR CPUEXP - NO TIMEOUTS FOR A WHILE
JSR PC,$ENABLD ;GO CHECK TO SEE IF REGISTER SHOULD BE ENABLED
ERROR +213 ;MAP REGISTER ENABLED WHEN SHOULD BE DISABLED
  
```

```

3151 .SBTTL SECTION TO DETERMINE NUMBER OF USEABLE MAP REGISTERS
3152 *****
3153 THIS SECTION DETERMINES THE NUMBER OF USEABLE MAP REGISTERS BY ACCOM-
3154 PLISHING THE SAME LOCATION ACCESS TEST AS IN THE PREVIOUS SECTION.
3155 *****
3156
3157 013154 013737 001174 001266 SIZEJ1: MOV $TMP0,MMRLOW ;MOVE REGISTER NUMBER FOUND USEABLE TO MMRLOW
3158 013162 013737 172350 001256 MOV KIPAR4,LOWEST ;MOVE LOWEST USEABLE REGISTER TO LOWEST
3159 013170 022737 170000 001256 CMP #170000,LOWEST ;SEE IF LOWEST REGISTER FOUND WAS THE LOWEST
3160 013176 001427 BEQ 1$ ;BRANCH AROUND SETUP IF IT WAS
3161 013200 005037 001272 CLR UBRLOW ;MAP REGISTER 0 IS LOWEST FOR UNIBUS MEMORY
3162 013204 012737 170000 001262 MOV #170000,UBMLOW ;MOVE PAR VALUE OF UB MEMORY TO UBMLow
3163 013212 013737 001174 001274 MOV $TMP0,UBRHI ;MOVE REGISTER NUMBER FOUND USEABLE TO UBRHI
3164 013220 005337 001274 DEC UBRHI ;POINT IT AT HIGHEST UB MEMORY MAP REGISTER
3165 013224 013737 172350 001264 MOV KIPAR4,UBMHI ;MOVE KIPAR4 TO UNIBUS MAP HIGHEST AND
3166 013232 162737 000200 001264 SUB #200,UBMHI ;SUBTRACT 200 FROM IT TO POINT TO LAST USEABLE UBMEM PAGE
3167 013240 012737 177400 001260 MOV #177400,HIGEST ;MOVE HIGHEST REGISTER TO HIGEST AND
3168 013246 012737 000031 001270 MOV #31,MMRHI ;POINT TO LAST USEABLE MAP REGISTER
3169 013254 000532 BR YESMSG ;GO TYPE MESSAGE OF NON-DEFAULT INFORMATION
3170 013256 012737 013324 001106 1$: MOV #3$, $LPERR ;SET LOOP ON ERROR TO 3$
3171 013264 062737 000200 172350 ADD #200,KIPAR4 ;MAP TO NEXT REGISTER
3172 013272 000414 BR 3$ ;BRANCH OVER POST-TSTLOC CODE
3173 013274 005037 001326 2$: CLR CPUEXP ;CLEAR CPUEXP - DON'T EXPECT TRAPS FOR A WHILE
3174 013300 062737 000200 172350 ADD #200,KIPAR4 ;MAP TO NEXT REGISTER
3175 013306 022737 177400 172350 CMP #177400,KIPAR4 ;SEE IF ALL MAP REGISTERS HAVE BEEN TRIED
3176 013314 001416 BEQ 4$ ;BRANCH IF ALL ARE DONE
3177 013316 004737 C05266 JSR PC,ENABLD ;GO SEE IF MAP REGISTER SHOULD BE ENABLED
3178 013322 104213 ERROR +213 ;MAP REGISTER ENABLED WHEN SHOULD BE DISABLED
3179 013324 012737 000020 001326 3$: MOV #TIMOUT,CPUEXP ;TIMEOUTS MIGHT OCCUR IN THIS TEST.
3180 013332 004737 003474 JSR PC,TSTLOC ;GO TO SUBROUTINE TO SEE IF IT RESPONDS
3181 013336 000756 BR 2$ ;RETURN IS HERE IF IT WAS LOADED
3182 013340 005037 001326 CLR CPUEXP ;CLEAR CPUEXP - NO TIMEOUTS FOR A WHILE
3183 013344 004737 005230 JSR PC,DSABLD ;RETURN IS HERE IF NOT LOADED - GO SEE IF
3184 ;REGISTER SHOULD BE DISABLED
3185 013350 104214 ERROR +214 ;MAP REGISTER DISABLED WHEN SHOULD BE ENABLED
3186 013352 013737 001174 001270 4$: MOV $TMP0,MMRHI ;MOVE REGISTER FOUND TO MMRHI
3187 013360 005337 001270 DEC MMRHI ;DECREMENT THIS VALUE - IT IS ONE TOO MANY
3188 013364 013737 172350 001260 MOV KIPAR4,HIGEST ;MOVE FIRST UNUSABLE REGISTER TO HIGEST
3189 013372 023727 001260 177400 CMP HIGEST,#177400 ;SEE IF UPPER JUMPER IS DEFAULT.
3190 013400 001522 BEQ NOMSG ;BRANCH AROUND MESSAGE TYPEOUT IF IT IS DEFAULT

```

```

3191 .SBTTL DETERMINE UNUSEABLE MAP REGISTER WINDOW SIZE
3192 :*****
3193 :* THIS SECTION PERFORMS THE SAME LOCATION ACCESS TEST PREVIOUSLY DONE
3194 :* LOOKING FOR THE FIRST ACCESSIBLE REGISTER, OR THE UPPER LIMIT. ONCE
3195 :* FOUND, THE SIZE OF THE WINDOW HAS BEEN DETERMINED AND THE MESSAGE
3196 :* TELLING THE USER OF THE SIZE IS PRINTED.
3197 :*
3198 :*****
3199 013402 013737 001260 001262 SIZEJ2: MOV HIGEST,UBMLOW ;MOVE UPPER LIMIT TO UBMLOW LOCATION
3200 013410 062737 000200 001262 ADD #200,UBMLOW ;POINT UBMLOW TO FIRST USABLE UNIBUS MEM PAGE
3201 013416 013737 001174 001272 MOV $TMP0,UBRLOW ;MOVE REGISTER NUMBER TO UBRLOW
3202 013424 012737 013460 001106 MOV #2$,SLPERR ;SET LOOP ON ERROR TO 2$
3203 013432 000412 BR 2$ ;BRANCH OVER CHECK FOR NON-EXISTENT LOCATION
3204 013434 062737 000200 172350 1$: ADD #200,KIPAR4 ;MAP TO NEXT REGISTER
3205 013442 022737 177400 172350 CMP #177400,KIPAR4 ;SEE IF WE ARE POINTING JUST BELOW THE I/O PAGE
3206 013450 001414 BEQ 3$ ;GO INITIALIZE UBMHI IF WE ARE
3207 013452 004737 005230 JSR PC,DSABLD ;GO SEE IF LOCATION SHOULD BE DISABLED
3208 013456 104214 ERROR +214 ;MAP REGISTER DISABLED WHEN SHOULD BE ENABLED
3209 013460 012737 000020 001326 2$: MOV #TIMOUT,CPUEXP ;TIMEOUTS MIGHT OCCUR IN THIS TEST.
3210 013466 004737 003474 JSR PC,TSTLOC ;GO TO SUBROUTINE TO SEE IF IT DOESN'T RESPOND
3211 013472 000403 BR 3$ ;RETURN IS HERE IF IT WAS LOADED - GO INITIALIZE UBMHI
3212 013474 005037 001326 CLR CPUEXP ;CLEAR CPUEXP - NO TIMEOUTS FOR A WHILE
3213 013500 000755 BR 1$ ;RETURN IS HERE IF NOT - GO BACK FOR ANOTHER TRY
3214 :AT THIS POINT, KIPAR4 POINTS JUST ABOVE HIGHEST ADDRESS OF UNIBUS MEMORY
3215 013502 005037 001326 3$: CLR CPUEXP ;CLEAR CPUEXP - NO TIMEOUTS FOR A WHILE
3216 013506 004737 005266 JSR PC,ENABLD ;GO SEE IF MAP REGISTER SHOULD BE ENABLED
3217 013512 104213 ERROR +213 ;MAP REGISTER ENABLED WHEN SHOULD BE DISABLED
3218 013514 013737 172350 001276 MOV KIPAR4,BUPWIN ;MOVE THIS VALUE TO 'B'EGINING 'UP'PER 'WIN'DOW
3219 013522 013737 172350 001264 MOV KIPAR4,UBMHI ;MOVE THIS TO UBMHI ALSO
3220 013530 013737 001174 001274 MOV $TMP0,UBRHI ;MOVE MAP REGISTER POINTER TO UBRHI
3221 013536 005337 001274 DEC UBRHI ;DECREMENT THIS VALUE - IT IS ONE TOO MANY
    
```

```

3222          .SBTTL  ROUTINE TO PRINT THE WINDOW SIZE MESSAGE
3223          ;*****
YESMSG: TST    $PASS          ;SEE IF THIS IS FIRST PASS
        BNE    NOMSG        ;BRANCH TO NEXT SECTION IF NOT FIRST PASS
        TYPE   ,JMPMSG      ;TYPE SIZE JUMPERS NOT IN DEFAULT - FOR INFO ONLY
        MOV    #DTMS,R0     ;SET UP MESSAGE POINTER
        MOV    #1$,-(SP)    ;PUSH RETURN ON THE STACK
        MOV    R0,-(SP)     ;PUSH R0 ON THE STACK
        MOV    R1,-(SP)     ;PUSH R1 ON THE STACK
        JMP    TYPDAT      ;GO TYPE THE DATA
1$:      TYPE   , $CRLF      ;TYPE A <CRLF>
        TYPE   , $CRLF      ;TYPE ONE MORE <CRLF>
        CMP    #SPECST,R3   ;SEE IF ANY TIMEOUTS OCCURED
        BEQ    NOMSG        ;BRANCH TO NEXT SECTION IF NONE
        TYPE   ,TOMSG      ;TYPE THE TIMEOUTS MESSAGE
        MOV    #SPECST,R3   ;RESET R3
2$:      MOV    -(R3),-(SP)  ;PUSH THE REGISTER # ONTO THE STACK IN ORDER IT WAS PUSHED
3$:      TYPDS          ;TYPE THE NUMBER IN DECIMAL, LEADING ZEROS SUPPRESSED
        TYPE   , $CRLF      ;TYPE A <CRLF>
        TST    -(R3)        ;SEE IF THERE IS ANOTHER REGISTER NUMBER TO PRINT
        BEQ    4$          ;BRANCH AROUND SETUP IF NONE
        MOV    (R3),-(SP)   ;PUSH THIS NUMBER ON THE STACK
        BR     3$          ;BRANCH BACK TO PRINT IT
4$:      TYPE   , $CRLF      ;TYPE ONE MORE <CRLF>
3224 013542 005737 020150
3225 013546 001037
3226 013550 104401 033002
3227 013554 012700 005740
3228 013560 012746 013574
3229 013564 010046
3230 013566 010146
3231 013570 000137 002244
3232 013574 104401 001223
3233 013600 104401 001223
3234 013604 022703 006002
3235 013610 001416
3236 013612 104401 006261
3237 013616 012703 006002
3238 013622 014346
3239 013624 104405
3240 013626 104401 001223
3241 013632 005743
3242 013634 001402
3243 013636 011346
3244 013640 000771
3245 013642 104401 001223
  
```





3280

.SBTTL TEST # 7 - ENSURE THAT THERE IS NO DUAL MAPPING  
 \*\*\*\*\*  
 \*TEST 7 ENSURE THAT THERE IS NO DUAL MAPPING

THIS TEST VERIFIES THAT THERE IS NO DUAL MAPPING. IT CLEARS ALL THE MAP REGISTERS EXCEPT THE ONE UNDER TEST, AND LOADS THAT ONE WITH 00040000. IF MAP RELOCATION IS ENABLED (AND IN THIS TEST IT IS), SUBROUTINE CLRMAP CLEARS ALL BUT THE LOWER 16 BITS OF MAPL1, AND LOADS 20000 THERE. THIS IS SO THAT APT, IF CONTROLLING THIS DIAGNOSTIC, CAN STILL EXAMINE THE PROPER LOCATIONS. THE TEST THEN USES A VIRTUAL ADDRESS TO SELECT THAT MAP REGISTER AND ADD 17776, SO THAT IT SHOULD REFERENCE ADDRESS 00057776 (00037776 IF MAPL1 CONTAINS 20000 AS PER CONDITIONS DESCRIBED ABOVE). A REFERENCE IS MADE THROUGH EACH OF THE REGISTERS AND ANY THAT FETCH THE CORRECT DATA ARE CHECKED TO SEE THAT IT WAS THE MAP REGISTER UNDER TEST. IF NOT, BOTH THE MAP REGISTER UNDER TEST AND THE DUALED REGISTER ARE REPORTED.

TST7:

013712	000004				SCOPE	
013712	004737	005166			JSR	PC,PRETST ;GO SET UP PRETEST DATA
013714	014616	014260	000007		.WORD	TST10,20\$,7 ;DATA USED BY PRETST
3281 013720	005037	172516			CLR	MMR3 ;CLEAR MMR3
3282 013726	005037	001312			CLR	UBM24U ;CLEAR THE UPPER EXPECTED LMA LOCATION
3283 013732	052737	000060	172516		BIS	#60,MMR3 ;ENABLE 22-BIT ADDRESSING AND MAP RELOCATION
3284 013736	004737	002772			JSR	PC,CLRMAP ;CLEAR ALL MAP REGISTERS
3285 013744	042737	000001	177572		BIC	#1,MMR0 ;TURN OFF MEMORY MANAGEMENT
3286 013750	005037	001174			CLR	STMP0 ;STMP0 IS USED AS A FLAG IN THIS TEST
3287 013756	012703	117776			MOV	#117776,R3 ;SELECT P.A.R. 4 OFFSET OF 17776
3288 013762	013702	001300			MOV	LREGL,R2 ;PUT ADDRESS OF LOWEST USABLE MAP REGISTER IN R2
3289 013766	013700	001256			MOV	LOWEST,R0 ;LOAD PAR POINTING TO MAP REGISTER UNDER TEST IN R0
3290 013772	052737	000001	177572		BIS	#1,MMR0 ;MAKE SURE MEMORY MANAGEMENT IS ON
3291 014004	005037	001320			CLR	ERRCNT ;CLEAR THE ERROR COUNT FOR ERROR 202 BELOW
3292 014010	013737	001256	172350	100\$:	MOV	LOWEST,KIPAR4 ;PAR OF LOWEST USEABLE MAP REGISTER IS LOADED IN KIPAR4
3293 014016	022702	170204			CMP	#MAPL01,R2 ;SEE IF WE ARE POINTING AT MAPL1
3294 014022	001003				BNE	1\$ ;BRANCH IF NOT
3295 014024	022712	020000			CMP	#20000,(R2) ;SEE IF IT CONTAINS 20000 (FOR APT USE)
3296 014030	001410				BEQ	2\$ ;BRANCH IF SO
3297 014032	012712	040000		1\$:	MOV	#40000,(R2) ;LOAD MAP REGISTER UNDER TEST WITH 8K BASE
3298 014036	010237	057776			MOV	R2,57776 ;LOAD TEST LOCATION WITH THE ADDRESS
3299						;OF THE MAP REGISTER UNDER TEST
3300 014042	012737	057776	001314		MOV	#57776,UBM24P ;MOVE ANTICIPATED ADDRESS TO LOCATION UBM24P
3301 014050	000405				BR	3\$ ;BRANCH OVER LOCATION SETUP
3302 014052	010237	037776		2\$:	MOV	R2,37776 ;LOAD TEST LOCATION WITH THE ADDRESS
3303						;OF THE MAP REGISTER UNDER TEST
3304 014056	012737	037776	001314		MOV	#37776,UBM24P ;MOVE ANTICIPATED ADDRESS TO LOCATION
3305 014064	162737	000200	172350	3\$:	SUB	#200,KIPAR4 ;PREPARE KIPAR4 FOR FIRST 'ADD 200'
3306 014072	062737	000200	172350	4\$:	ADD	#200,KIPAR4 ;TRY NEXT MAP REGISTER
3307 014100	005037	001330		41\$:	CLR	PCPUER ;CLEAR THE ERROR RECEIVER
3308 014104	012737	017776	001310		MOV	#17776,UBM24L ;MOVE DEFAULT LMA ADDRESS TO UBM24L
3309 014112	020037	172350			CMP	R0,KIPAR4 ;SEE IF REGISTER UNDER TEST IS POINTED TO BY KIPAR4
3310 014116	001003				BNE	45\$ ;BRANCH AROUND SETUP IF NOT
3311 014120	013737	001314	001310		MOV	UBM24P,UBM24L ;MOVE SPECIAL LMA ADDRESS TO LOCATION
3312 014126	012737	000020	001326	45\$:	MOV	#TIMOUT,CPUEXP ;POSSIBLE NON-EXISTENT MEMORY
3313 014134	011304				MOV	(R3),R4 ;READ THROUGH THE MAP REGISTER

3314	014136	005037	001326		CLR	CPUEXP	:NO MORE TIMEOUTS FOR AWHILE
3315	014142	005037	001320		CLR	ERRCNT	:CLEAR ERROR COUNT
3316	014146	005737	001330		TST	PCPUER	:SEE IF THERE WAS AN ERROR
3317	014152	001110			BNE	8\$	:BRANCH AROUND DATA TEST IF SO
3318	014154	020402			CMP	R4,R2	:SEE IF CORRECT DATA WAS FETCHED
3319	014156	001075			BNE	6\$	:BRANCH IF NO MATCH
3320	014160	032777	004000	164750	BIT	#BIT11,@SWR	:SEE IF THIS IS AN 11/24 WITH UB MEM ONLY
3321	014166	001406			BEQ	49\$	:BRANCH IF NOT
3322	014170	013737	177736	001304	MOV	LMAHI,LMAH	:SAVE LMA HIGH REG IN LMAH
3323	014176	013737	177734	001306	MOV	LMALOW,LMAL	:SAVE LMA LOW REG IN LMAL
3324	014204	020037	172350	49\$:	CMP	R0,KIPAR4	:SEE IF MAP REGISTERS ARE THE SAME
3325	014210	001455			BEQ	5\$	:BRANCH IF CORRECT MAP REGISTER WAS USED
3326	014212	004737	005076		JSR	PC,CHKLMA	:GO CHECK FOR 11/24 WITH UB MEMORY ONLY
3327	014216	001304	001306		.WORD	LMAH,LMAL	:ADDRESSES OF LOCATIONS CONTAINING LMA CONTENTS
3328	014222	000450			BR	5\$	:RETURN IS HERE IF MATCH ACHIEVED
3329	014224	011337	001202		MOV	(R3), \$TMP3	:SAVE CONTENTS FOR ERROR PRINTING
3330	014230	013746	001202		MOV	\$TMP3,-(SP)	:MOVE FAULTY DATA TO STACK FOR SUBROUTINE USE
3331	014234	013746	172350		MOV	KIPAR4,-(SP)	:MOVE PAR4 CONTENTS TO STACK FOR SUBROUTINE USE
3332	014240	004737	003674		JSR	PC,ADREXT	:GO SET DATA IN THE 4 WORDS OF ADDROR AND ADRAND
3333	014244	010246			MOV	R2,-(SP)	:PUT ADDRESS OF REGISTER ON STACK FOR DATEXT USE
3334	014246	013746	172356		MOV	KIPAR7,-(SP)	:MOVE PAR CONTENTS TO STACK FOR SUBROUTINE USE
3335	014252	004737	003624		JSR	PC,DATEXT	:GO SET DATA IN DATAOR AND DATAND
3336	014256	000424			BR	46\$	:BRANCH OVER LOOP ON ERROR SETUP
3337	014260	020402		20\$:	CMP	R4,R2	:SEE IF CORRECT DATA WAS FETCHED
3338	014262	001023			BNE	47\$	:BRANCH IF NO MATCH
3339	014264	032777	004000	164644	BIT	#BIT11,@SWR	:SEE IF THIS IS AN 11/24 WITH UB MEM ONLY
3340	014272	001406			BEQ	59\$	:BRANCH IF NOT
3341	014274	013737	177736	001304	MOV	LMAHI,LMAH	:SAVE LMA HIGH REG IN LMAH
3342	014302	013737	177734	001306	MOV	LMALOW,LMAL	:SAVE LMA LOW REG IN LMAL
3343	014310	020037	172350	59\$:	CMP	R0,KIPAR4	:SEE IF MAP REGISTERS ARE THE SAME
3344	014314	001406			BEQ	47\$	:BRANCH IF CORRECT MAP REGISTER WAS USED
3345	014316	004737	005076		JSR	PC,CHKLMA	:GO CHECK FOR 11/24 WITH UB MEMORY ONLY
3346	014322	001304	001306		.WORD	LMAH,LMAL	:ADDRESSES OF LOCATIONS CONTAINING LMA CONTENTS
3347	014326	000401			BR	47\$	:RETURN IS HERE IF MATCH ACHIEVED
3348	014330	104210		46\$:	ERROR	+210	:DUAL MAPPING ERROR IN THE UNIBUS MAP
3349	014332	032777	001000	164576	47\$:	BIT	#BIT9,@SWR
3350	014340	001347			BNE	20\$	:SEE IF LOOP ON ERROR IS SET
3351	014342	000414			BR	8\$	:BRANCH BACK IF SO
3352	014344	005237	001174	5\$:	INC	\$TMP0	:BRANCH AROUND ADDRESS MATCH SETTING
3353	014350	000411			BR	8\$	:SET FLAG WHEN ADDRESSES MATCH
3354	014352	004737	005076	6\$:	JSR	PC,CHKLMA	:BRANCH AROUND SUBROUTINE CHECK - NOT NEEDED
3355	014356	001304	001306		.WORD	LMAH,LMAL	:GO CHECK FOR 11/24 WITH UB MEMORY ONLY
3356	014362	000401			BR	7\$	:ADDRESSES OF LOCATIONS CONTAINING LMA CONTENTS
3357	014364	000403			BR	8\$	:RETURN IS HERE IF MATCH ACHIEVED
3358	014366	020037	172350	7\$:	CMP	R0,KIPAR4	:BRANCH OVER LMA SPECIFIC COMPARE CODE
3359	014372	001764			BEQ	5\$	:SEE IF MAP REGISTERS ARE THE SAME
3360	014374	022737	177400	172350	8\$:	CMP	#177400,KIPAR4
3361	014402	001420			BEQ	10\$	:BRANCH IF CORRECT MAP REGISTER WAS USED
3362	014404	023737	001260	172350	CMP	HIGEST,KIPAR4	:SEE IF LAST REGISTER HAS BEEN TRIED
3363	014412	001227			BNE	4\$	:BRANCH TO CONTINUE IF SO
3364	014414	062737	000200	172350	9\$:	ADD	#200,KIPAR4
3365	014422	022737	177400	172350	CMP	#177400,KIPAR4	:SEE IF ALL HAVE BEEN TRIED
3366	014430	001405			BEQ	10\$	:BRANCH IF STILL MORE TO TRY
3367	014432	023737	001276	172350	CMP	BUPWIN,KIPAR4	:MAP TO NEXT MAP REGISTER
3368	014440	001365			BNE	9\$	:SEE IF WE ARE AT THE TOP
3369	014442	000616			BR	41\$	:BRANCH TO CONTINUE IF SO
3370	014444	005737	001174	10\$:	TST	\$TMP0	:SEE IF WE ARE POINTING TO THE UPPER WINDOW START
							:BRANCH BACK FOR ANOTHER INCREMENTING SET IF NOT
							:GO BACK FOR A NEW TRY
							:SEE THAT THERE WAS A SUCCESSFUL MATCH

3371	014450	001006		BNE	11\$	:BRANCH IF THERE WAS
3372	014452	010246		MOV	R2,-(SP)	:PUT ADDRESS OF REGISTER ON STACK FOR ADREXT USE
3373	014454	013746	172356	MOV	KIPAR7,-(SP)	:PUT PAR ON STACK FOR SUBROUTINE ADREXT USE
3374	014460	004737	003674	JSR	PC,ADREXT	:GO SET DATA IN THE 4 WORDS OF ADDROR AND ADRAND
3375	014464	104210		ERROR	+210	:DUAL MAPPING ERROR IN THE UNIBUS MAP
3376	014466	005037	001174	11\$: CLR	\$TMP0	:CLEAR FLAG FOR NEXT REGISTER
3377	014472	022702	170204	CMP	#MAPL01,R2	:SEE IF R2 IS POINTING TO MAPL1
3378	014476	001006		BNE	12\$	:BRANCH IF NOT
3379	014500	022712	040000	CMP	#40000,(R2)	:DOES MAPL1 CONTAIN 40000?
3380	014504	001403		BEQ	12\$	:BRANCH IF IT DOES
3381	014506	005037	037776	CLR	37776	:CLEAR LOCATION 37776 ONLY - MAPL1 IS TO BE LEFT ALONE
3382	014512	000401		BR	13\$	:SKIP OVER REGISTER CLEAR STEP
3383	014514	005012		12\$: CLR	(R2)	:CLEAR MAP REGISTER JUST TESTED
3384	014516	062700	000200	13\$: ADD	#200,R0	:POINT TO NEXT MAP REGISTER UNDER TEST
3385	014522	062702	000004	ADD	#4,R2	:POINT TO NEXT MAP REGISTER TO LOAD
3386	014526	022700	177400	CMP	#177400,R0	:SEE IF LAST REGISTER HAS BEEN TRIED
3387	014532	001421		BEQ	15\$	:BRANCH TO NEXT SECTION IF SO
3388	014534	023700	001260	CMP	HIGEST,R0	:SEE IF ALL MAP REGS HAVE BEEN TESTED
3389	014540	001402		BEQ	14\$	:BRANCH IF NO MORE TO TEST
3390	014542	000137	014010	JMP	100\$	:JUMP TO BEGIN AGAIN
3391	014546	062700	000200	14\$: ADD	#200,R0	:POINT TO NEXT MAP REGISTER UNDER TEST
3392	014552	062702	000004	ADD	#4,R2	:POINT TO NEXT MAP REGISTER TO LOAD
3393	014556	022700	177400	CMP	#177400,R0	:SEE IF LAST REGISTER HAS BEEN TRIED
3394	014562	001405		BEQ	15\$	:BRANCH TO NEXT SECTION IF SO
3395	014564	020037	001276	CMP	R0,BUPWIN	:SEE IF WE ARE POINTING TO UPPER WINDOW START
3396	014570	001336		BNE	11\$	:BRANCH FOR ANOTHER INCREMENT SET IF NOT
3397	014572	000137	014072	JMP	4\$	:JUMP BACK FOR ANOTHER RUN
3398	014576	005737	001320	15\$: TST	ERRCNT	:SEE IF THERE WERE ANY ERRORS
3399	014602	001405		BEQ	TST10	:BRANCH TO NEXT TEST IF NO ERRORS
3400	014604	005337	001110	DEC	\$ERTTL	:DON'T COUNT ERROR +16 AS ANOTHER ERROR
3401	014610	005337	001320	DEC	ERRCNT	:SAME AS ABOVE
3402	014614	104016		ERROR	+16	:SUMMARY OF DUAL MAPPING ERRORS

3411

```
.SBTTL TEST # 10 - LOAD LOC'S 40000-77776 WITH THEIR ADRES'S
:*****
:*TEST 10      LOAD LOC'S 40000-77776 WITH THEIR ADRES'S
:*
:*      THIS TEST IS USED TO LOAD MAIN MEMORY FROM ADDRESS 00040000 TO
:*      ADDRESS 000077776 WITH ITS OWN ADDRESS.  IT THEN CHECKS THAT
:*      MEMORY OVER THE UNIBUS AND LOGS ANG REPORTS ANY ERRORS THAT
:*      IT FINDS.
:*****
```

```
014616
014616 000004
014620 004737 005166
014624 015072 015030 000010
3412 014632 042737 000040 172516
3413 014640 012737 000400 172350
3414 014646 012700 040000
3415 014652 012701 100000
3416 014656 012702 010000
3417 014662 010021
3418 014664 062700 000002
3419 014670 077204
3420 014672 062737 000200 172350
3421 014700 022737 001000 172350
3422 014706 101361
3423
3424
3425
3426 014710 022737 171000 172354
3427
3428 014716 101465
3429 014720 013700 172354
3430
3431 014724 072027 000006
3432 014730 012701 140000
3433 014734 012702 010000
3434 014740 011103
3435 014742 020003
3436 014744 001012
3437 014746 022120
3438 014750 077205
3439 014752 062737 000200 172354
3440 014760 022737 171000 172354
3441 014766 101360
3442 014770 000430
3443 014772 011146
3444 014774 013746 172354
3445 015000 004737 003674
3446 015004 010146
3447 015006 013746 172344
3448 015012 004737 003624
3449 015016 010337 005770
3450 015022 005037 005772
3451 015026 000403
3452 015030 011103
3453 015032 020003
3454 015034 001401
```

```
TST10:
SCOPE
JSR PC,PRETST ;GO SET UP PRETEST DATA
.WORD TST11,20$,10 ;DATA USED BY PRETST
BIC #BITS,MMR3 ;TURN OFF MAP RELOCATION
MOV #400,KIPAR4 ;MAP PAGE 4 TO 8K
MOV #40000,R0 ;STARTING ADDRESS FOR DATA PATTERN
1$: MOV #100000,R1 ;VIRTUAL ADDRESS
MOV #4096,R2 ;LOAD 4096 LOCATIONS AT A TIME
2$: MOV R0,(R1)+ ;LOAD PHY. ADDR. INTO EACH MEMORY LOC.
ADD #2,R0 ;POINT TO NEXT PHYSICAL ADDRESS
SOB R2,2$ ;BRANCH IF 4K OF MEMORY NOT LOADED
ADD #200,KIPAR4 ;POINT TO NEXT 4K BANK OF MEMORY
CMP #1000,KIPAR4 ;SEE IF 16K IS LOADED
BHI 1$ ;BRANCH IF MORE MEMORY TO LOAD

:*
:* MEMORY FROM 8K - 16K IS NOW LOADED WITH ITS OWN ADDRESS
:*
CMP #171000,KIPAR6 ;DID I USE ANY MAP REGISTER
;BELOW REGISTER 6 (UB. ADDR 100000)
BLOS TST11 ;BRANCH TO NEXT TEST IF NOT
MOV KIPAR6,R0 ;LOAD PAR6 INTO R0 TO GET
;THE STARTING DATA PATTERN
3$: ASH #6,R0 ;R0 NOW HOLDS THE STARTING DATA PATTERN
MOV #140000,R1 ;STARTING VIRTUAL ADDRESS
MOV #4096,R2 ;PREPARE TO READ 4K AT A TIME
4$: MOV (R1),R3 ;READ MAIN MEMORY THROUGH UNIBUS
CMP R0,R3 ;SEE IF THE ADDRESSES MATCH
BNE 6$ ;BRANCH IF ERROR
5$: CMP (R1)+,(R0)+ ;CHANGE VIRTUAL & PHYSICAL ADDRESSES
SOB R2,4$ ;BRANCH IF 4K OF MEMORY NOT READ
ADD #200,KIPAR6 ;POINT TO NEXT BANK OF 4K THROUGH UNIBUS
CMP #171000,KIPAR6 ;SEE IF THIS POINTS TO 16K PLUS 2
BHI 3$ ;BRANCH IF 16K OF MEMORY NOT CHECKED
BR 10$ ;TEST FINISHED, BRANCH TO EXIT
6$: MOV (R1),-(SP) ;PUT VIRTUAL ADDRESS ON STACK FOR ADREXT SUBROUTINE USE
MOV KIPAR6,-(SP) ;PUT PAR6 CONTENTS ON STACK FOR SUBROUTINE USE
JSR PC,ADREXT ;GO SET DATA IN THE 4 WORDS OF ADDROR AND ADRAND
MOV R1,-(SP) ;PUT DATA ON STACK FOR DATEXT SUBROUTINE
MOV KIPAR2,-(SP) ;MOVE PAR CONTENTS TO STACK FOR SUBROUTINE USE
JSR PC,DATEXT ;SUBROUTINE TO LOAD DATAOR AND DATAND
MOV R3,EADRS2 ;MOVE DATA IN R3 TO EADRS2 FOR ERROR CALL
CLR EADRS2+2 ;CLEAR UPPER 6 BITS TO PRINT
BR 7$ ;BRANCH OVER LOOP ON ERROR SETUP
20$: MOV (R1),R3 ;READ MAIN MEMORY THROUGH UNIBUS
CMP R0,R3 ;SEE IF THE ADDRESSES MATCH
BEQ 8$ ;BRANCH IF OK
```

3455	015036	104205		7\$:	ERROR	+205		:DIDN'T READ ADDRESSES CORRECTLY FROM UNIBUS
3456	015040	032777	001000	164070	8\$:	BIT	#BIT9,@SWR	:SEE IF LOOP ON ERROR IS SET
3457	015046	001370				BNE	20\$	:BRANCH BACK IF SO
3458	015050	000736				BR	5\$	:CONTINUE TESTING
3459	015052	005737	001320		10\$:	TST	ERRCNT	:WERE THERE ANY ERRORS ON THIS TEST?
3460	015056	001405				BEQ	TST11	:BRANCH IF NO ERRORS ON THIS TEST
3461	015060	005337	001110			DEC	\$ERTTL	:DON'T COUNT ERROR +14 AS ANOTHER ERROR
3462	015064	005337	001320			DEC	ERRCNT	:SAME AS ABOVE
3463	015070	104014				ERROR	+14	:SUMMARY OF UNIBUS ADDRESS FAILURES

3472

```
.SBTTL TEST # 11 - MAIN MEMORY TIMEOUT THROUGH MAP
:*****
:*TEST 11      MAIN MEMORY TIMEOUT THROUGH MAP
:*
:*      THIS TEST GENERATES A TIME OUT THROUGH THE UNIBUS MAP BY TRYING
:*      TO REFERENCE ADDRESS 17000000 IN MAIN MEMORY.  IT USES THE LOWEST
:*      USABLE MAP REGISTER, WHICH IN THE DEFAULT CASE IS MAP REGISTER
:*      ZERO.
:*****
```

```
015072
015072 000004
015074 004737 005166
015100 015140 015132 000011
3473 015106 052737 000040 172516
3474 015114 005037 004312
3475 015120 012737 000074 001312
3476 015126 005037 001310
3477 015132 004737 020014
3478 015136 104015
```

```
TST11:
SCOPE
JSR PC,PRETST ;GO SET UP PRETEST DATA
.WORD TST12,20$,11 ;DATA USED BY PRETST
BIS #BIT5,MMR3 ;TURN MAP RELOCATION BACK ON
CLR LOEFLG ;CLEAR LOEFLG FOR ERROR LOOP INDICATOR
MOV #74,UBM24U ;EXPECTING 74 IN UPPER POSITION OF 11/24 LMA
CLR UBM24L ;EXPECTING ZERO IN LOWER POSITION
20$: JSR PC,MMTOTM ;GO DO THE TEST
ERROR +15 ;RETURN HERE IF ERROR - UNIBUS DID NOT TIME OUT
```

3489

.SBTTL TEST # 12 - RELOC USING LOWEST USABLE MAP REG THRU UNIBUS

\*\*\*\*\*  
\*TEST 12 RELOC USING LOWEST USABLE MAP REG THRU UNIBUS

\*  
\* THIS TEST CHECKS OUT THE FULL ADDITION PROPERTIES OF THE UNIBUS  
\* MAP A.L.U.. IN THE DEFAULT CASE IT USES MAP REGISTER ZERO BUT  
\* IF THE MAP JUMPERS HAVE BEEN ALTERED TO DE-SELECT SOME MAP REGISTERS  
\* THIS TEST WILL USE THE LOWEST USABLE MAP REGISTER.  
\* IF AN ERROR OCCURS THE TEST WILL REPORT THE PHYSICAL ADDRESS  
\* THAT WAS DESIRED, AND THE DATA AT THE ADDRESS THAT WAS REFERENCED.  
\*

\*\*\*\*\*  
TST12:

015140  
015140 000004  
015142 004737 005166  
015146 015174 015154 000012  
3490 015154 005037 004312  
3491 015160 005037 001312  
3492 015164 004737 004106  
3493 015170 104211  
3494 015172 000774

SCOPE  
JSR PC,PRETST ;GO SET UP PRETEST DATA  
.WORD TST13,20\$,12 ;DATA USED BY PRETST  
20\$: CLR LOEFLG ;CLEAR LOEFLG - FLAG USED FOR ERROR RETURN  
CLR UBM24U ;CLEAR UPPER LOCATION  
1\$: JSR PC,MAPADD ;GO DO THE TEST  
ERROR +211 ;RETURN IS HERE FOR ERROR  
BR 1\$ ;GO BACK TO THE SUBROUTINE

3503

.SBTTL TEST # 13 - CARRY PROP OF MAP'S RELOC ADDER THRU UNIBUS  
 :\*\*\*\*\*  
 :\*TEST 13 CARRY PROP OF MAP'S RELOC ADDER THRU UNIBUS

\* EVERY ADDRESS OF THE FORM XXXX0000 IS GENERATED HERE STARTING  
 \* WITH 00030000 UP TO 17000000. THAT IS, THE FIRST OF EVERY 2K  
 \* WORDS IS ADDRESSED, TO INSURE THAT THE ADDER IN THE MAP IS  
 \* WORKING PROPERLY .

3504 015174 000004  
 3504 015176 004737 005166  
 3505  
 3506  
 3507  
 3508  
 3509 015202 015236 015210 000013  
 3510 000040  
 3511 015210 005037 004312  
 3512 015214 005037 001312  
 3513 015220 012737 020000 001310  
 3514 015226 004737 004416  
 3515 015232 104211  
 3516 015234 000774  
 3517 015236

:\*\*\*\*\*  
 :TST13: SCOPE  
 : JSR PC,PRETST ;GO SET UP PRETEST DATA  
 :\*\*\*\*\*  
 :\*\*IMPORTANT\*\* : IF THE POSITION OF THIS TEST IS CHANGED, CHANGE THE THIRD  
 : WORD BELOW TO THE NEW TEST NUMBER THIS TEST WILL OCCUPY.  
 :\*\*\*\*\*  
 : .WORD 2\$,20\$,13 ;DATA USED BY PRETST  
 : NEXMEM=BIT5 ;BIT05 IS NON-EXISTENT MEMORY BIT IN THE CPU ERROR REGISTER  
 : 20\$: CLR LOEFLG ;CLEAR LOEFLG - USED AS AN ERROR RETURN FLAG  
 : CLR UBM24U ;CLEAR UPPER LOCATION  
 : MOV #20000,UBM24L ;PUT 20000 IN LOWER LOCATION  
 : 1\$: JSR PC,TCMRA ;GO DO THE TEST  
 : ERROR +211 ;RETURN IS HERE IF AN ERROR  
 : BR 1\$ ;RETURN TO THE TEST  
 : 2\$:







3584

.SBTTL TEST # 15 - RELOC USING LOWEST USABLE MAP REG USING MAP REG

\*\*\*\*\*  
 \*TEST 15 RELOC USING LOWEST USABLE MAP REG USING MAP REG

\*  
 \* THIS TEST CHECKS OUT THE FULL ADDITION PROPERTIES OF THE UNIBUS  
 \* MAP A.L.U.. IN THE DEFAULT CASE IT USES MAP REGISTER ZERO BUT  
 \* IF THE MAP JUMPERS HAVE BEEN ALTERED TO DE-SELECT SOME MAP REGISTERS  
 \* THIS TEST WILL USE THE LOWEST USABLE MAP REGISTER.  
 \* IF AN ERROR OCCURS THE TEST WILL REPORT THE PHYSICAL ADDRESS  
 \* THAT WAS DESIRED, AND THE DATA AT THE ADDRESS THAT WAS REFERENCED.

\*  
 \* THIS TEST IS BEING RUN WITH ALL MEMORY REFERENCES GOING THROUGH  
 \* THE UNIBUS MAP.  
 \*

\*\*\*\*\*

TST15:

015362	000004				SCOPE		
015362	004737	005166			JSR	PC,PRETST	;GO SET UP PRETEST DATA
015364	015420	015404	000015		.WORD	TST16,20\$,15	;DATA USED BY PRETST
3585 015370	012737	060000	060000		MOV	#060000,060000	;MAKE SURE ADDRESS 060000 CONTAINS ITS OWN ADDRESS AS DATA
3586 015376	005037	004312		20\$:	CLR	LOEFLG	;CLEAR LOEFLG - USED IN ERROR RETURN
3587 015404	004737	004106		1\$:	JSR	PC,MAPADD	;GO DO THE TEST
3588 015410	104211				ERROR	+211	;RETURN IS HEPE FOR ERROR
3589 015414	000774				BR	1\$	;RETURN TO THE SUBROUTINE

3598

```
.SBTTL TEST # 16 - CARRY PROP OF MAP'S RELOC ADDER USING MAP REG
*****
*TEST 16 CARRY PROP OF MAP'S RELOC ADDER USING MAP REG
*
* EVERY ADDRESS OF THE FORM XXXX0000 IS GENERATED HERE STARTING
* WITH 00030000 UP TO 17000000. THAT IS THE FIRST OF EVERY 2K
* WORDS IS ADDRESSED, TO INSURE THAT THE ADDER IN THE MAP IS
* WORKING PROPERLY .
*****
```

```
015420
015420 000004
015422 004737 005166
015426 015450 015434 000016
3599 015434 005037 004312
3600 015440 004737 004416
3601 015444 104211
3602 015446 000774
```

```
TST16:
SCOPE
JSR PC,PRETST ;GO SET UP PRETEST DATA
.WORD TST17,20$,16 ;DATA USED BY PRETST
CLR LOEFLG ;CLEAR LOEFLG - USED AS ERROR RETURN FLAG
20$: JSR PC,TCPMRA ;GO DO THE TEST
1$: ERROR +211 ;RETURN IS HERE IF AN ERROR
BR 1$ ;RETURN TO THE TEST
```

3633

```

.SBTTL TEST # 17 - VERIFY TRAP DUE TO CACHE PARITY INTERRUPT
*****
TEST 17 VERIFY TRAP DUE TO CACHE PARITY INTERRUPT
*****
*****NOTE*****
THE MAP WILL BE SHUT OFF FOR THE REMAINDER OF THE DIAGNOSTIC
BEFORE ANY TEST CODE IS EXECUTED. IT IS NOT NEEDED.
*****
THIS TEST IS OPTIONAL AND IS SELECTED BY SETTING MFM HARDWARE
SWITCH REGISTER BIT 08 TO A 1 IN THE CASE OF STANDALONE OPERATION
OF THE DIAGNOSTIC. IN THE CASE OF MANUFACTURING APT RUNTIME MODE
THEN BIT 08 OF $$WREG IS SET TO 1 THROUGH APT SCRIPTING.

THE TEST VERIFIES THE SIGNAL GENERATED FROM THE CACHE
TO THE UBI MODULE WHICH INDICATES TO THE UBI THAT A CACHE INTERRUPT
IS BEING CALLED FOR(CACHE PE INTR L).

THIS TEST ASSUMES THAT ALL MODULES EXCEPT THE UBI MODULE ARE KNOWN
GOOD MODULES.

THIS TEST TOGETHER WITH OTHER CACHE TESTS,ALLOW MFG. TO ELIMINATE
HAVING TO RUN THE CACHE DIAGNOSTIC DURING QUICK
VERIFY TESTING OF THE UBI MODULE.

TEST DESCRIPTION:
VERIFY INTERRUPT LOGIC BY ASSURING THAT A TRAP OCCURS TO LOCATION
114 WHEN A LOCATION PREVIOUSLY WRITTEN
WITH WRONG HI/LO BYTE PARITY IS ACCESSED.
CONDITIONS: PEA=0
DCPI=0

```

```

015450
015450 000004
015452 004737 005166
015456 015610 015554 000017
3634 015464 005037 177572
3635 015470 005037 172516
3636 015474 005037 172340
3637 015500 012737 000200 172342
3638 015506 105737 007140
3639 015512 001403
3640 015514 105237 001100
3641 015520 000511
3642 015522 132737 000200 020163 1$:
3643 015530 001405
3644 015532 032737 000100 020164
3645 015540 001423
3646 015542 000404
3647 015544 032777 000100 163364 2$:
3648 015552 001416
3649 015554 012737 000005 005460 20$:
3650 015562 112737 000001 005470
3651 015570 004737 005324
3652 015574 012737 000000 177746
3653 015602 005703
3654 015604 001401

TST17:
SCOPE
JSR PC,PRETST ;GO SET UP PRETEST DATA
WORD TST20,20$,17 ;DATA USED BY PRETST
CLR MMR0 ;TURN OFF MEMORY MANAGEMENT
CLR MMR3 ;TURN OFF MAP RELOCATION
CLR KIPAR0 ;PUT PAR0 BACK WHERE IT SHOULD AND
MOV #200,KIPAR1 ;PUT PAR1 BACK WHERE IT SHOULD
TSTB CPUYIP ;IS THIS AN 11/24?
BEQ 1$ ;BRANCH OVER JUMP IF 11/44
INCB $TSTNM ;INCREMENT TEST NUMBER TO SIMULATE SKIPPING TEST
BR TST21 ;BRANCH OVER THIS AND NEXT TESTS
BITB #200,$ENVM ;IS APT SIZING?
BEQ 2$ ;NO;TRY HARDWARE SWITCH REGISTER
BIT #100,$SWREG ;YES APT IS SIZING;DOES APT SAY TO DO THIS TEST
BEQ TST20 ;:NO - SKIP TEST
BR 20$ ;YES,DO TEST
BIT #100,@SWR ;DOES HARDWARE SWITCH REGISTER SAY TO DO TEST?
BEQ TST20 ;:NO - SKIP TEST
MOV #5,CASH1 ;MOVE BYTE TO LOAD TO CACHE TO SUB ;DPM002
MOVB #1,CASH2 ;MOVE TEST 1 TO LOCATION IN SUBROUTINE ;DPM002
JSR PC,CASHSR ;GO DO THE CASH TEST
MOV #0,CACHE ;TURN CACHE ON
TST R3 ;DID TRAP OCCUR?
BEQ TST20 ;:BRANCH TO NEXT TEST IF YES

```

3655 015606 104020

ERROR +20

:INTERRUPT/ABORT LOGIC TESTS TRAP TO LOC 114 DID NOT OCCUR



3708	015722	104022				ERROR	+22
3709	015724	012737	000000	177746	2\$:	MOV	#0,CACHE
3710	015732	062737	000007	001100	21\$:	ADD	#7,\$STSNM
3711	015740	000137	017164			JMP	TST30

; INTERRUPT/ABORT TESTS TRAP DID NOT OCCUR DUE TO ABORT  
; TURN CACHE ON  
; ADD 7 TO \$STSNM TO COMPENSATE FOR 7 TESTS SKIPPED  
; JUMP OVER NEXT 7 TESTS - THEY ARE FOR AN 11/24 ONLY



3724

SBTTL TEST # 21 - LMA REGISTER PHYSICAL ADDRESS CHECK

\*\*\*\*\*

\*TEST 21 LMA REGISTER PHYSICAL ADDRESS CHECK

\*

THE NEXT 7 TESTS ARE EXECUTED ON THE 11/24 ONLY.

\*

THIS TEST IS TO CHECK OUT THE LMA (LAST MAPPED ADDRESS) REGISTER FOR PROPER CONTENTS. FIRST, THE PAR AND MAP REGISTERS ARE SET, THEN A PHYSICAL ADDRESS IS LOADED INTO AN EXPECTED DATA LOCATION. THEN THE MAP IS INSURED TO BE ON AND A MEMORY ACCESS IS DONE, USING THE MAP REGISTER SO THE LMA IS LOADED. THE LMA IS THEN CHECKED FOR CONTAINING THE PROPER CONTENTS, CALLING AN ERROR IF EXPECTED DATA DID NOT APPEAR.

\*

\*\*\*\*\*

TST21:

015744	000004				SCOPE		
015744	004737	005166			JSR	PC,PRETST	:GO SET UP PRETEST DATA
015746	016220	016104	000021		.WORD	TST22,20\$,21	:DATA USED BY PRETST
3725	015752				BR	10\$	:BRANCH OVER TEST PATTERN TABLE :DPM002
3726	000416				.RADIX	2	:SET RADIX TO BINARY REPRESENTATION :DPM002
3727	015760				100\$: .WORD	0100000000000000	:SELECT MAP REG 2, ALL BITS CLEAR :DPM002
3728	015762				.WORD	0101111111111110	:SELECT MAP REG 2, ALL BITS SET EXC 0 :DPM002
3729	015764				.WORD	0101010101010100	:SELECT MAP REG 2, EVEN BITS SET :DPM002
3730	015766				.WORD	0100101010101010	:SELECT MAP REG 2, ODD BITS SET :DPM002
3731	015770				.WORD	0100011001100110	:SELECT MAP REG 2, PAIRS OF BITS SET :DPM002
3732	015772				.WORD	0101111000011110	:SELECT MAP REG 2, 2 SETS OF 4 BITS SET :DPM002
3733	015774				.WORD	0100000111111110	:SELECT MAP REG 2, 8 BITS SET :DPM002
3734	040776				:EXPECTED RESULTS IN LMA LOW:		
3735	016000				.WORD	0000000000000000	:EXPECTED RESULT WITH ALL BITS CLEAR :DPM002
3736	016002				.WORD	0001111111111110	:EXPECTED RESULT WITH ALL BITS 1 EXC 0 :DPM002
3737	016004				.WORD	0001010101010100	:EXPECTED RESULT WITH EVEN BITS SET :DPM002
3738	016006				.WORD	0000101010101010	:EXPECTED RESULT WITH ODD BITS SET :DPM002
3739	016010				.WORD	0000011001100110	:EXPECTED RESULT WITH PAIRS OF BITS SET :DPM002
3740	016012				.WORD	0001111000011110	:EXPECTED RESULT WITH GRPS OF 4 BITS =1 :DPM002
3741	016014				.WORD	0000000111111110	:EXPECTED RESULT WITH 8 BITS SET :DPM002
3742	000010				.RADIX	8	:SET RADIX BACK TO OCTAL :DPM002
3743	016016	015762			10\$: MOV	#100\$,R1	:MOVE TABLE ADDRESS TO R1 :DPM002
3744	016022	000007			MOV	#7,R2	:DO 7 PATTERNS :DPM002
3745	016026	042737	000001	177572	BIC	#BIT0,MMR0	:TURN OFF MEMORY MANAGEMENT
3746	016034	042737	000060	172516	BIC	#60,MMR3	:TURN OFF 22-BIT AND MAP RELOCATION
3747	016042	013746	172344		MOV	KIPAR2,-(SP)	:SAVE KIPAR2
3748	016046	013737	001256	172344	MOV	LOWEST,KIPAR2	:PUT PAR VALUE IN PAR2 TO ACCESS LOWEST MAP REGISTER
3749	016054	052737	000060	172516	BIS	#60,MMR3	:TURN ON 22-BIT AND MAP RELOCATION
3750	016062	005037	172340		CLR	KIPAR0	:CLEAR PAR0 FOR PAGE ACCESSING THIS TEST
3751	016066	052737	000001	177572	BIS	#BIT0,MMR0	:TURN ON MEMORY MANAGEMENT
3752	016074	005077	163200		CLR	@LREGL	:CLEAR LOWEST USEABLE MAP REGISTER LOW WORD
3753	016100	005077	163176		CLR	@LREGU	:CLEAR LOWEST USEABLE MAP REGISTER HIGH WORD
3754	016104	017137	000000	001174	20\$: MOV	@0(R1),\$TMP0	:DO THE MAP REGISTER READ THRU THE MAP :DPM002
3755	016112	026137	000016	177734	CMP	16(R1),LMA LOW	:SEE IF LMA LWR 16 WERE LOADED PROPERLY :DPM002
3756	016120	001007			BNE	1\$	:BRANCH TO CALL ERROR IF NOT :DPM002
3757	016122	013737	177736	001174	MOV	LMAHI,\$TMP0	:MOVE HI 6 BITS TO \$TMP0 FOR PREPARATION
3758	016130	042737	177700	001174	BIC	#177700,\$TMP0	:CLEAR ALL BUT LOWER 6 BITS
3759	016136	001424			BEQ	2\$	:BRANCH AROUND ERROR IF OK
3760	016140	013737	177734	005770	1\$: MOV	LMA LOW,EADRS2	:MOVE LOWER 16 BITS OF RECEIVED DATA TO EADRS2 FOR ERROR
3761	016146	013737	177736	005772	MOV	LMAHI,EADRS2+2	:MOVE UPPER 6 BITS OF RECEIVED DATA TO EADRS2+2 FOR ERROR
3762	016154	016137	000016	005764	MOV	16(R1),EADRES	:MOVE EXPECTED DATA TO EADRES :DPM002
3763	016162	005037	005766		CLR	EADRES+2	:CLEAR THE UPPER LOCATION

3764	016166	011637	172344		MOV	(SP),KIPAR2	;RESTORE KIPAR2	
3765	016172	104023			ERROR	+23	;LMA NOT LOADED PROPERLY	
3766	016174	013737	001256	172344	MOV	LOWEST,KIPAR2	;RESET PAR2 TO PRE-ERROR SETUP	
3767	016202	012703	004000		MOV	#4000,R3	;MOVE 4000 TO WAIT LOOF COUNTER	
3768	016206	077301		15\$:	SOB	R3,15\$	;WAIT A LITTLE	
3769	016210	005721		2\$:	TST	(R1)+	;INCREMENT TO NEXT TABLE VALUE	;DPM002
3770	016212	077244			SOB	R2,20\$	;SUBTRACT 1 AND BRANCH IF NOT DONE YET	;DPM002
3771	016214	012637	172344	3\$:	MOV	(SP)+,KIPAR2	;RESTORE KIPAR2 FOR GOOD NOW	

3778

```
.SBTTL TEST # 22 - LMA FORCE JUMPER BIT TEST
*****
:TEST 22      LMA FORCE JUMPER BIT TEST
:
: THIS TEST DETERMINES THAT THE FORCE JUMPER BIT OF THE LMA IS ZERO AFTER
: A SYSTEM RESET.
:
*****
```

```
016220
016220 000004
016222 004737 005166
016226 016266 016234 000022
3779 000100
3780 016234 042737 000060 172516
3781 016242 000005
3782 016244 032737 000100 177736
3783 016252 001405
3784 016254 013701 177736
3785 016260 042701 000100
3786 016264 104024
```

```
TST22:
SCOPE
JSR PC,PRETST ;GO SET UP PRETEST DATA
.WORD TST23,20$,22 ;DATA USED BY PRETST
=100 ;FORCE JUMPER BIT IS BIT 6
FJBIT BIC #60,MMR3 ;TURN OFF 22-BIT AND MAP RELOCATION
20$: RESET ;RESET THE WORLD, CLEARING THE FJBIT
BIT #FJBIT,LMAHI ;CHECK THE BIT FOR BEING ZERO
BEQ TST23 ;BRANCH TO NEXT TEST IF OK
MOV LMAHI,R1 ;MOVE LMAHI TO R1 FOR ERROR CALL
BIC #FJBIT,R1 ;CLEAR THE BIT THAT SHOULD HAVE BEEN CLEAR
ERROR +24 ;LMA FORCE JUMPER BIT NOT ZERO
```

3796

.SBTTL TEST # 23 - SETTING LMA FORCE JUMPER BIT TEST

\*\*\*\*\*  
 \*TEST 23 SETTING LMA FORCE JUMPER BIT TEST

\* THIS TEST SETS THE FORCE JUMPER BIT AND TESTS ITS FUNCTIONALITY IF  
 \* THE JUMPERS ARE NOT IN THEIR DEFAULT STATE. IF NOT ('LOWEST' OR  
 \* 'HIGEST' DO NOT CONTAIN THE DEFAULT VALUES OF 170000 OR 177400  
 \* RESPECTIVELY), THIS TEST INSURES THAT THE PREVIOUSLY DISABLED MAP  
 \* REGISTERS ARE ENABLED WITH THE FJ BIT SET.  
 \*\*\*\*\*

TST23:

016266	016266	000004				SCOPE		
	016270	004737	005166			JSR	PC,PRETST	:GO SET UP PRETEST DATA
	016274	016474	016302	000023		.WORD	TST24,20\$,23	:DATA USED BY PRETST
3797	016302	052737	000100	177736	20\$:	BIS	#FJBIT,LMAHI	:SET THE BIT
3798	016310	032737	000100	177736		BIT	#FJBIT,LMAHI	:SEE IF IT WAS SET
3799	016316	001005				BNE	1\$	:BRANCH IF SET
3800	016320	013701	177736			MOV	LMAHI,R1	:MOVE LMAHI TO R1 FOR ERROR CALL
3801	016324	052701	000100			BIS	#FJBIT,R1	:SET THE BIT THAT SHOULD HAVE BEEN SET
3802	016330	104025				ERROR	+25	:LMA FORCE JUMPER BIT NOT SET
3803	016332	022737	170000	001256	1\$:	CMP	#170000,LOWEST	:SEE IF MAP REGISTER 0 IS LOWEST
3804	016340	001004				BNE	2\$	:BRANCH AROUND UPPER LIMIT CHECK IF NOT
3805	016342	022737	177400	001260		CMP	#177400,HIGEST	:SEE IF MAP REGISTER 31 IS HIGEST
3806	016350	001451				BEQ	TST24	:BRANCH TO NEXT TEST IF SO
3807	016352	052737	000060	172516	2\$:	BIS	#60,MMR3	:TURN ON 22-BIT AND MAP RELOCATION
3808	016360	012737	016440	001106		MOV	#6\$,SLPERR	:RESET LOOP ON ERROR TO 6\$
3809	016366	013746	172350			MOV	KIPAR4,-(SP)	:SAVE PAR4
3810	016372	013737	001262	172350		MOV	UBMLOW,KIPAR4	:MOVE LOWEST PAGE OF MEMORY WINDOW TO PAR4
3811	016400	012700	117776			MOV	#117776,R0	:THIS WILL BE USED TO SELECT PAR4, ADDRESS 17776
3812	016404	012702	125252			MOV	#125252,R2	:LOAD CONSTANT TO R2
3813	016410	000407				BR	5\$	:BRANCH OVER LOOP SETUP
3814	016412	062737	000200	172350	4\$:	ADD	#200,KIPAR4	:MAP TO NEXT REGISTER
3815	016420	023737	001264	172350		CMP	UBMHI,KIPAR4	:SEE IF HIGHEST HAS BEEN REACHED
3816	016426	001415				BEQ	9\$	:BRANCH TO RESTORE PAR4 AND LEAVE TEST IF SO
3817	016430	004737	003474		5\$:	JSR	PC,TSTLOC	:GO TEST LOCATION FOR WRITEABILITY
3818	016434	000766				BR	4\$	:BRANCH BACK FOR ANOTHER TEST IF LOCATION LOADED
3819	016436	000403				BR	7\$	:BRANCH AROUND LOOP ON ERROR SETUP
3820	016440	004737	003474		6\$:	JSR	PC,TSTLOC	:GO TEST LOCATION FOR WRITEABILITY
3821	016444	000401				BR	8\$	:GO TEST FOR LOOP ON ERROR IF OK NOW
3822	016446	104027			7\$:	ERROR	+27	:FORCE JUMPER BIT FAILS TO REVERT MAP REGISTER STATUS TO DEF
3823	016450	032777	001000	162460	8\$:	BIT	#BIT9,@SWR	:SEE IF LOOP ON ERROR IS STILL SET
3824	016456	001370				BNE	6\$	:BRANCH BACK TO LOOP SECTION IF SO
3825	016460	000754				BR	4\$	:BRANCH BACK FOR ANOTHER TEST
3826	016462	012637	172350		9\$:	MOV	(SP)+,KIPAR4	:RESTORE KIPAR4
3827	016466	042737	000060	172516		BIC	#60,MMR3	

3833

```
.SBTTL TEST # 24 - CLEARING THE FORCE JUMPER BIT
:*****
:*TEST 24            CLEARING THE FORCE JUMPER BIT
:*
:*            THIS TEST CLEARS THE FJ BIT AND INSURES THAT IT IS SUCCESSFULLY CLEARED.
:*
:*****
```

```
016474
016474 000004
016476 004737 005166
016502 016540 016510 000024
3834 016510 042737 000100 177736
3835 016516 032737 000100 177736
3836 016524 001405
3837 016526 013701 177736
3838 016532 042701 000100
3839 016536 104024
```

```
TST24:
SCOPE
JSR    PC,PRETST            ;GO SET UP PRETEST DATA
      .WORD    TST25,20$,24 ;DATA USED BY PRETST
BIC    #FJBIT,LMAHI        ;CLEAR THE BIT
BIT    #FJBIT,LMAHI        ;CHECK TO SEE THAT IT WAS CLEARED
BEQ    TST25                ;BRANCH IF CLEARED
MOV    LMAHI,R1            ;MOVE LMAHI TO R1 FOR ERROR CALL
BIC    #FJBIT,R1            ;CLEAR THE BIT THAT SHOULD HAVE BEEN CLEAR
ERROR +24                 ;LMA FORCE JUMPER BIT NOT ZERO
```

3846

```
.SBTTL TEST # 25 - LMA CONTROL BITS TEST - DATI  
:*****  
:TEST 25 LMA CONTROL BITS TEST - DATI  
:  
: THIS TEST INSURES THE CONTROL BITS 14 AND 15 LOAD PROPERLY DOING A  
: DATI.  
:  
:*****
```

TST25:

016540	000004				SCOPE		
016540	004737	005166			JSR	PC,PRETST	:GO SET UP PRETEST DATA
016542	016702	016644	000025		.WORD	TST26,20\$,25	:DATA USED BY PRETST
016546	013746	172344			MOV	KIPAR2,-(SP)	:SAVE KIPAR2
3847	016554	012737	170000	172344	MOV	#170000,KIPAR2	:LOAD KIPAR2
3848	016560	012737	000001	177572	MOV	#1,MMR0	:TURN ON MEMORY MANAGEMENT
3849	016566	012737	000020	172516	MOV	#20,MMR3	:TURN ON 22-BIT ADDRESSING
3850	016574	012700	056664		MOV	#1\$+BIT14,R0	:MOVE LOCATION ADDRESS +40000 (TO REF PAR2) TO R0
3851	016602	011001			MOV	(R0),R1	:DO A DATI
3852	016606	013737	177736	001174	MOV	LMAHI,\$TMP0	:MOVE LMAHI TO \$TMP0 FOR PREPARATION OF EXPECTED
3853	016610	013737	001174	001200	MOV	\$TMP0,\$TMP2	:MOVE IT TO \$TMP2 ALSO
3854	016616	042737	037777	001200	BIC	#37777,\$TMP2	:CLEAR ALL BUT THE CONTROL BITS
3855	016624	023737	001174	001200	CMP	\$TMP0,\$TMP2	:SEE IF EXPECTED DATA CAME UP
3856	016632	001416			BEQ	3\$	:BRANCH TO FINISH TEST IF ALL CLEAR
3857	016640	000410			BR	1\$	:BRANCH OVER LOOP ON ERROR SETUP
3858	016642	011001			MOV	(R0),R1	:DO A DATI
3859	016644	013737	177736	001174	MOV	LMAHI,\$TMP0	:MOVE LMAHI TO \$TMP0 FOR COMPARE
3860	016646	023737	001174	001200	CMP	\$TMP0,\$TMP2	:SEE IF EXPECTED DATA CAME UP
3861	016654	001401			BEQ	2\$	:BRANCH AROUND ERROR IF IT DID
3862	016662	104026			ERROR	+26	:LMA CONTROL BITS INCORRECT
3863	016664	032777	001000	162242	BIT	#BIT9,@SWR	:SEE IF LOOP ON ERROR IS SET
3864	016666	001363			BNE	20\$	:BRANCH BACK FOR ANOTHER TRY IF SET
3865	016674	012637	172344		MOV	(SP)+,KIPAR2	:RESTORE KIPAR2
3866	016676						

3873

```
.SBTTL TEST # 26 - LMA CONTROL BITS TEST - DATO
*****
:TEST 26      LMA CONTROL BITS TEST - DATO
:
:      THIS TEST INSURES THE CONTROL BITS 14 AND 15 LOAD PROPERLY DOING A
:      DATO.
:
:*****
```

```
016702
016702 000004
016704 004737 005166
016710 017036 017000 000026
3874    100000
3875 016716 013746 172344
3876 016722 012737 170000 172344
3877 016730 012700 057020
3878 016734 010110
3879 016736 013737 177736 001174
3880 016744 013737 001174 001200
3881 016752 052737 100000 001200
3882 016760 042737 040000 001174
3883 016766 023737 001174 001200
3884 016774 001416
3885 016776 000410
3886 017000 010110
3887 017002 013737 177736 001174
3888 017010 023737 001174 001200
3889 017016 001401
3890 017020 104026
3891 017022 032777 001000 162106
3892 017030 001363
3893 017032 012637 172344
```

```
TST26:
SCOPE
JSR PC,PRETST ;GO SET UP PRETEST DATA
.WORD TST27,20$,26 ;DATA USED BY PRETST
=100000
DATO
MOV KIPAR2,-(SP) ;SAVE KIPAR2
MOV #170000,KIPAR2 ;LOAD KIPAR2
MOV #1$+BIT14,R0 ;MOVE LOCATION ADDRESS +40000 (TO REF PAR2) TO R0
MOV R1,(R0) ;DO A DATO
MOV LMAHI,$TMP0 ;MOVE LMAHI TO $TMP0 FOR CONTROL BIT ANALYSIS
MOV $TMP0,$TMP2 ;MOVE IT IT $TMP2 ALSO
BIS #DATO,$TMP2 ;SET AND CLEAR THE CONTROL BITS EXPECTED TO BE SET
BIC #BIT14,$TMP0 ;AND CLEAR SO $TMP2 WILL CONTAIN THE EXPECTED
CMP $TMP0,$TMP2 ;SEE IF BIT 15 IS SET AND 14 IS CLEAR
BEQ 3$ ;BRANCH IF OK
BR 1$ ;GO CALL ERROR
20$: MOV R1,(R0) ;DO A DATO
MOV LMAHI,$TMP0 ;MOVE LMA HIGH REGISTER CONTENTS TO $TMP0 FOR COMPARE
CMP $TMP0,$TMP2 ;SEE IF EXPECTED CAME UP
BEQ 2$ ;BRANCH AROUND ERROR IF IT DID
1$: ERROR +26 ;LMA CONTROL BITS INCORRECT
2$: BIT #BIT9,@SWR ;SEE IF LOOP ON ERROR IS SET
BNE 20$ ;BRANCH BACK FOR ANOTHER TRY IF SET
3$: MOV (SP)+,KIPAR2 ;RESTORE KIPAR2
```

3900

.SBTTL TEST # 27 - LMA CONTROL BITS TEST - DATOB

\*\*\*\*\*

\*TEST 27 LMA CONTROL BITS TEST - DATOB

\*

THIS TEST INSURES THE CONTROL BITS 14 AND 15 LOAD PROPERLY DOING A  
DATOB.

\*

\*\*\*\*\*

TST27:

017036	000004				SCOPE		
017036	004737	005166			JSR	PC,PRETST	:GO SET UP PRETEST DATA
017040	017164	017126	000027		.WORD	TST30,20\$,27	:DATA USED BY PRETST
3901	140000			DATOB	=140000		:DATOB CONTROL BITS STATUS=140000
3902	017052	013746	172344		MOV	KIPAR2,-(SP)	:SAVE KIPAR2
3903	017056	012737	170000	172344	MOV	#170000,KIPAR2	:LOAD KIPAR2
3904	017064	012700	057146		MOV	#1\$+BIT14,R0	:MOVE LOCATION ADDRESS +40000 (TO REF PAR2) TO R0
3905	017070	110110			MOVB	R1,(R0)	:DO A DATOB
3906	017072	013737	177736	001174	MOV	LMAHI,\$TMP0	:MOVE LMAHI TO \$TMP0 FOR CONTROL BIT CHECK
3907	017100	013737	001174	001200	MOV	\$TMP0,\$TMP2	:MOVE TO \$TMP2 ALSO
3908	017106	052737	140000	001200	BIS	#DATOB,\$TMP2	:SET THE EXPECTED DATA BITS INTO \$TMP0
3909	017114	023737	001174	001200	CMP	\$TMP0,\$TMP2	:SEE IF EXPECTED DATA CAME UP
3910	017122	001416			BEQ	3\$	:BRANCH IF OK
3911	017124	000410			BR	1\$	:BRANCH TO CALL ERROR
3912	017126	110110			20\$:	MOVB R1,(R0)	:DO A DATOB
3913	017130	013737	177736	001174	MOV	LMAHI,\$TMP0	:MOVE LMA HIGH REGISTER CONTENTS TO \$TMP0 FOR COMPARE
3914	017136	023737	001174	001200	CMP	\$TMP0,\$TMP2	:SEE IF EXPECTED DATA CAME UP
3915	017144	001401			BEQ	2\$	:BRANCH IF OK
3916	017146	104026			1\$:	ERROR +26	:LMA CONTROL BITS INCORRECT
3917	017150	032777	001000	161760	2\$:	BIT #BIT9,@SWR	:SEE IF LOOP ON ERROR IS SET
3918	017156	001363			BNE	20\$	:BRANCH BACK FOR ANOTHER TRY IF SET
3919	017160	012637	172344		3\$:	MOV (SP)+,KIPAR2	:RESTORE KIPAR2

\*\*\*\*\*

\*

>>NOTE<<: 'DATIP' CANNOT BE CHECKED IN THE 11/24 BECAUSE THE LMA IS  
WRITTEN TWICE WHEN A 'DATIP' IS EXECUTED, DESTROYING THE  
'DATIP' STATE THAT WAS WRITTEN FIRST.

\*

\*\*\*\*\*


3920  
3921  
3922  
3923  
3924  
3925  
3926



.SBTTL MEMORY ON UNIBUS TESTS HEADER

THE NEXT TWO TESTS WILL EXECUTE IF A '1' IN BIT 5 OF THE SWITCH REGISTER IS FOUND SET. IF IT HAS, IT THEN DETERMINES IF THERE IS ANY UNIBUS MEMORY - AN ERROR RESULTS IF THERE IS NONE. IF THERE IS MEMORY, IT THEN SIZES THE AMOUNT OF MEMORY ON THE UNIBUS, INFORMS THE USER HOW MUCH MEMORY IT FOUND ON THE FIRST PASS, THEN SETS AND CLEARS ALL BITS OF ALL LOCATIONS IN THE UNIBUS MEMORY FOUND USING THE 'MARCH' ALGORITHM.

M7098 FOR THE 11/44, M7134 FOR THE 11/24  
JUMPER SETTINGS FOR THE MAP REGISTERS



\*W3-W7 AND W8-W12 ARE THE BINARY-CODED PAGE NUMBER LIMIT (UPPER OR LOWER).  
 \*A JUMPER IN CORRESPONDS TO A LOGIC '0'; A JUMPER OUT TO A LOGIC '1'. TO  
 \*SET THE JUMPERS, DETERMINE WHICH UNIBUS PAGE THE MEMORY RESIDES IN (0 TO 31)  
 \*BY CHECKING WHICH OF THE 5 ADDRESS BITS BA17-BA13 ARE ASSERTED. ALL ZEROS  
 \*IS PAGE 0, 10000 IS PAGE 1, 01000 IS PAGE 2, 11000 IS PAGE 3, ETC. UP TO  
 \*PAGE 31 (11111). FOR THE MEMORY TO BE DETECTED, IT MUST LIE AT OR ABOVE  
 \*THE LOWER LIMIT JUMPER SETTING AND BELOW THE UPPER LIMIT JUMPER SETTING.  
 \*THUS TO HAVE UNIBUS MEMORY IN PAGES 5-9, ONE WOULD SET THE LOWER LIMIT TO  
 \*PAGE 5 (10100) OR W10 AND W12 OUT, AND W8, W9 AND W11 IN, AND THE UPPER LIMIT  
 \*TO PAGE 10 (01010) OR W4 AND W6 OUT, AND W3, W5 AND W7 IN. UNIBUS MEMORY  
 \*MUST BE CONTIGUOUS SINCE NO GAPS ARE PERMITTED.

3928  
3929  
3930  
3931  
3932  
3933  
3934  
3935  
3936  
3937  
3938  
3939  
3940  
3941  
3942  
3943  
3944  
3945  
3946  
3947  
3948  
3949  
3950  
3951  
3952  
3953  
3954  
3955  
3956  
3957  
3958  
3959  
3960

3972

SBTTL TEST # 30 - MEMORY ON UNIBUS TEST

\*\*\*\*\*  
 \*TEST 30 MEMORY ON UNIBUS TEST  
 \*\*\*\*\*

THIS TEST FIRST CHECKS TO SEE IF THE UNIBUS MEMORY TESTS HAVE BEEN  
 SELECTED. IF NOT, THE EOP IS EXECUTED. IT THEN CHECKS FOR UNIBUS  
 MEMORY EXISTENCE BY CHECKING THAT THE CONTENTS OF LOWEST OR HIGHEST  
 LOCATIONS IS NOT IN ITS DEFAULT STATE. IF BOTH ARE, AN ERROR IS  
 CALLED AND THE EOP IS EXECUTED. IF EITHER ARE NOT, THE NEXT SECTION  
 IS EXECUTED THAT DETERMINES THE SIZE OF THE UB MEMORY AND TELLS  
 USER OF THE RESULTS ON THE FIRST PASS ONLY.

\*\*\*\*\*  
 TST30:

017164				
017164	000004			
017166	004737	005166		
017172	017412	017200	000030	
3973	017200	042737	000001	177572
3974	017206	032777	000040	161722
3975	017214	001425		
3976	017216	012737	021576	001362
3977	017224	022737	170000	001256
3978	017232	001020		
3979	017234	022737	177400	001260
3980	017242	001014		
3981	017244	012737	012744	001106
3982	017252	112737	000007	001100
3983	017260	112737	000007	020146
3984	017266	104017		
3985	017270	000137	021576	
3986	017274	005037	001320	
3987	017300	005037	001330	
3988	017304	005037	172516	
3989	017310	052737	000020	172516
3990	017316	005037	172340	
3991	017322	012737	000200	172342
3992	017330	013700	001274	
3993	017334	163700	001272	
3994	017340	005200		
3995	017342	010037	001316	
3996	017346	005046		
3997	017350	012746	000200	
3998	017354	013746	001262	
3999	017360	012746	000002	
4000	017364	005737	020150	
4001	017370	001010		
4002	017372	010046		
4003	017374	006316		
4004	017376	006316		
4005	017400	104401	006125	
4006	017404	104405		
4007	017406	104401	006174	
4008		021576		

SCOPE				
JSR	PL,PRETST			:GO SET UP PRETEST DATA
.WORD	TST31,20\$,30			:DATA USED BY PRETST
BIC	#1,MMRO			:TURN OFF MEMORY MANAGEMENT
BIT	#BITS,@SWR			:SEE IF THIS TEST HAS BEEN SELECTED
BEQ	2\$			:BRANCH TO JUMP IF TEST NOT SELECTED
MOV	#SEOP,NXTTST			:POINT TO ESCAPE VECTOR
CMP	#170000,LOWEST			:SEE IF LOWEST IS LOWEST
BNE	3\$			:GO DO TEST IF IT ISN'T - UNIBUS MEMORY EXISTS
CMP	#177400,HIGEST			:SEE IF HIGEST IS HIGEST
BNE	3\$			:GO DO TEST IF IT ISN'T - UNIBUS MEMORY EXISTS
MOV	#SIZEJO,\$LPERR			:MOVE SIZE JUMPER ROUTINE TO LOOP ON ERROR
MOVB	#7,\$TSTNM			:EXECUTING AFTER TEST 7 ON LOOPBACK
MOVB	#7,\$TESTN			:EXECUTING AFTER TEST 7 ON LOOPBACK
ERROR	+17			:NO UNIBUS MEMORY EXISTS
JMP	SEOP			:JUMP TO END OF PASS
CLR	ERRCNT			:CLEAR THE ERROR COUNT INDICATOR
CLR	PCPUER			:CLEAR THE ERROR REGISTER RECEIVER
CLR	MMR3			:CLEAR MEMORY MANAGEMENT REGISTER MMR3
BIS	#20,MMR5			:TURN ON 22-BIT MAPPING
CLR	KIPAR0			:MAP PAR0 TO 0-4K
MOV	#200,KIPAR1			:MAP PAR1 TO 4-8K
MOV	UBRH,RO			:MOVE UBRHI TO RO
SUB	UBRLOW,RO			:SUBTRACT UBRLOW FROM IT, AND
INC	RO			:ADD LAST BLOCK OF 4K TO LOOP COUNTER
MOV	RO,NUMOFK			:SAVE RO IN NUMOFK
CLR	-(SP)			:CLEAR THE MAJOR LOOP INDICATOR ON STACK
MOV	#200, -(SP)			:MOVE PAR CHANGE TO STACK
MOV	UBRLOW, -(SP)			:MOVE STARTING PAR VALUE TO STACK
MOV	#2, -(SP)			:MOVE INCREMENT VALUE TO STACK
TST	\$PASS			:SEE IF THIS IS FIRST PASS
BNE	TST31			:BRANCH TO NEXT TEST IF NOT
MOV	RO, -(SP)			:MOVE LOOP COUNTER TO THE STACK AND
ASL	(SP)			:ROTATE THIS TO THE LEFT 2 PLACES
ASL	(SP)			:TO INDICATE NUMBER OF K IN OCTAL
TYPE	,UBMAVA			:GO TYPE THE UNI-BUS MEMORY AVAILABLE MESSAGE
TYPDS				:GO TYPE THE NUMBER IN DECIMAL
TYPE	,UBMEND			:TYPE A " K" AND <CRLF>
TST32=\$EOP				



4061 017664 012716 177776  
4062 017670 000662

MOV    #-2,(SP)  
BR     1\$

;MOVE DECREMENT VALUE TO STACK  
;BRANCH BACK FOR SECOND PASS

```
4063      020000      . =20000      ;THE APT TABLES NEED TO START AT 20000 - THIS STATEMENT DOES THAT
4064
4065      177777      ADDW0= 177777
4066      177777      ADDW1= 177777
4067
.SBTTL  APT PARAMETER BLOCK
:*****
:SET LOCATIONS 24 AND 44 AS REQUIRED FOR APT
:*****
      020000      .SX=      ;;SAVE CURRENT LOCATION
000024    000024      =24      ;;SET POWER FAIL TO POINT TO START OF PROGRAM
      000200      200      ;;FOR APT START UP
000044    000044      =44      ;;POINT TO APT INDIRECT ADDRESS PNTR.
      020000      $APTHDR ;;POINT TO APT HEADER BLOCK
      020000      .=.SX    ;;RESET LOCATION COUNTER
:*****
:SETUP APT PARAMETER BLOCK AS DEFINED IN THE APT-PDP11 DIAGNOSTIC
:INTERFACE SPEC.
$APTHD:
020000    000000    $HIBTS: .WORD 0      ;;TWO HIGH BITS OF 18 BIT MAILBOX ADDR.
020002    020142    $MBADR: .WORD $MAIL    ;;ADDRESS OF APT MAILBOX (BITS 0-15)
020004    000005    $STMT:  .WORD 5      ;;RUN TIM OF LONGEST TEST
020006    000010    $PASTM: .WORD 10     ;;RUN TIME IN SECS. OF 1ST PASS ON 1 UNIT (QUICK VERIFY)
020010    000000    $UNITM: .WORD 0      ;;ADDITIONAL RUN TIME (SECS) OF A PASS FOR EACH ADDITIONAL UNIT
020012    000052    .WORD $ETEND-$MAIL/2 ;;LENGTH MAILBOX-ETABLE(WORDS)
```

```

4069                                     .SBTTL SUBROUTINE TO TEST TIMEOUT THROUGH UNIBUS MAP
4070                                     :*****
4071 020014 005737 004312 MMTOTM: TST L0EFLG ;SEE IF THIS ENTRY IS FROM ERROR LOOPING
4072 020020 001402 BEQ 1$ ;BRANCH IF NOT
4073 020022 062706 000002 ADD #2,SP ;CLEAN EXTRA RETURN OFF STACK
4074 020026 005037 001320 1$: CLR ERRCNT ;CLEAR ERRCNT FOR THIS TEST
4075 020032 013737 001256 172350 MOV LOWEST,KIPAR4 ;LOAD PAR 4 WITH LOWEST USABLE MAP REG
4076 020040 012777 000074 161234 MOV #74,@LREGU ;LOAD UPPER 6 BITS OF LOWEST MAP REG
4077 020046 005077 161226 CLR @LREGL ;LOAD LOWER 16 BITS OF LOWEST MAP REG
4078 020052 032777 004000 161056 BIT #BIT11,@SWR ;SEE IF AN 11/24 WITH JB MEMORY ONLY
4079 020060 001403 BEQ 20$ ;BRANCH IF NOT
4080 020062 012737 177600 172350 MOV #177600,KIPAR4 ;RESET KIPAR4 SO A TIMEOUT THROUGH MAP CAN BE EXPECTED
4081 020070 005037 001330 20$: CLR PCPUER ;CPU ERROR REGISTER LOCATION
4082 020074 012737 000020 001326 MOV #TIMOUT,CPUEXP ;EXPECTING TIMEOUT IN THIS TEST
4083 020102 013703 100000 MOV 100000,R3 ;TRY TO READ THROUGH PAGE 4 THIS REFERENCE WILL GO OUT
4084                                     :ON THE UNIBUS TO SELECT THE LOWEST USABLE MAP REGISTER (DEFAULT MAP REG. 0). PHYSICAL
4085                                     :ADDRESS 1770000 IS THEN GENERATED, WHICH SHOULD TIME OUT SINCE IT IS THE FIRST
4086                                     :NON-EXISTENT LOCATION.
4087 020106 005037 001326 CLR CPUEXP ;CLEAR LOCATION - NO MORE TIMEOUTS FOR A WHILE
4088 020112 022737 000020 001330 CMP #TIMOUT,PCPUER ;THE UNIBUS SHOULD HAVE TIMED OUT
4089 020120 001405 BEQ 3$ ;BRANCH IF CONDITION WAS CORRECT
4090 020122 011646 000001 004312 2$: MOV (SP),-(SP) ;PUSH ANOTHER RETURN ONTO THE STACK FOR POSSIBLE ERROR LOOP
4091 020124 012737 000001 004312 MOV #1,L0EFLG ;SET ERROR LOOP FLAG
4092 020132 000402 BR 4$ ;EXIT
4093 020134 062716 000002 3$: ADD #2,(SP) ;CORRECT RETURN PC OVER ERROR CALL
4094 020140 000207 4$: RTS PC ;EXIT

```

4095

```
.SBTTL APT MAILBOX-ETABLE
*****
.EVEN
020142 $MAIL:          ;; APT MAILBOX
020142 000000 $MSGTY: .WORD  AMSGTY ;; MESSAGE TYPE CODE
020144 000000 $FATAL: .WORD  AFATAL ;; FATAL ERROR NUMBER
020146 000000 $TESTN: .WORD  ATESTN ;; TEST NUMBER
020150 000000 $PASS:  .WORD  APASS   ;; PASS COUNT
020152 000000 $DEVCT: .WORD  ADEVCT ;; DEVICE COUNT
020154 000000 $UNIT:  .WORD  AUNIT   ;; I/O UNIT NUMBER
020156 000000 $MSGAD: .WORD  AMSGAD ;; MESSAGE ADDRESS
020160 000000 $MSGLG: .WORD  AMSGLG ;; MESSAGE LENGTH
020162 $ETABLE:      ;; APT ENVIRONMENT TABLE
020162 000 $ENV:   .BYTE  AENV   ;; ENVIRONMENT BYTE
020163 000 $ENVM:  .BYTE  AENVM  ;; ENVIRONMENT MODE BITS
020164 000000 $SWREG: .WORD  ASWREG ;; APT SWITCH REGISTER
020166 000000 $USWR:  .WORD  AUSWR   ;; USER SWITCHES
020170 000000 $CPUOP: .WORD  ACPUOP  ;; CPU TYPE, OPTIONS
*
* BIT 15-11=CPU TYPE
* 11/04=01,11/05=02,11/20=03,11/40=04,11/45=05
* 11/70=06,PDQ=07,Q=10
*
* BIT 10=REAL TIME CLOCK
* BIT 9=FLOATING POINT PROCESSOR
* BIT 8=MEMORY MANAGEMENT
020172 000 $MAMS1: .BYTE  AMAMS1 ;; HIGH ADDRESS,M.S. BYTE
020173 000 $MTYP1: .BYTE  AMTYP1 ;; MEM. TYPE,BLK#1
*
* MEM.TYPE BYTE -- (HIGH BYTE)
* 900 NSEC CORE=001
* 300 NSEC BIPOLAR=002
* 500 NSEC MOS=003
020174 000000 $MADR1: .WORD  AMADR1 ;; HIGH ADDRESS,BLK#1
*
* MEM.LAST ADDR.=3 BYTES,THIS WORD AND LOW OF 'TYPE' ABOVE
020176 000 $MAMS2: .BYTE  AMAMS2 ;; HIGH ADDRESS,M.S. BYTE
020177 000 $MTYP2: .BYTE  AMTYP2 ;; MEM. TYPE,BLK#2
020200 000000 $MADR2: .WORD  AMADR2 ;; MEM.LAST ADDRESS,BLK#2
020202 000 $MAMS3: .BYTE  AMAMS3 ;; HIGH ADDRESS,M.S.BYTE
020203 000 $MTYP3: .BYTE  AMTYP3 ;; MEM. TYPE,BLK#3
020204 000000 $MADR3: .WORD  AMADR3 ;; MEM.LAST ADDRESS,BLK#3
020206 000 $MAMS4: .BYTE  AMAMS4 ;; HIGH ADDRESS,M.S.BYTE
020207 000 $MTYP4: .BYTE  AMTYP4 ;; MEM. TYPE,BLK#4
020210 000000 $MADR4: .WORD  AMADR4 ;; MEM.LAST ADDRESS,BLK#4
020212 000000 $VECT1: .WORD  AVECT1 ;; INTERRUPT VECTOR#1,BUS PRIORITY#1
020214 000000 $VECT2: .WORD  AVECT2 ;; INTERRUPT VECTOR#2BUS PRIORITY#2
020216 000000 $BASE:  .WORD  ABASE   ;; BASE ADDRESS OF EQUIPMENT UNDER TEST
020220 000000 $DEVN:  .WORD  ADEVN   ;; DEVICE MAP
020222 000000 $CDW1:  .WORD  ACDW1   ;; CONTROLLER DESCRIPTION WORD#1
020224 000000 $CDW2:  .WORD  ACDW2   ;; CONTROLLER DESCRIPTION WORD#2
020226 177777 $DDW0:  .WORD  ADDW0   ;; DEVICE DESCRIPTOR WORD#0
020230 177777 $DDW1:  .WORD  ADDW1   ;; DEVICE DESCRIPTOR WORD#1
020232 000000 $DDW2:  .WORD  ADDW2   ;; DEVICE DESCRIPTOR WORD#2
020234 000000 $DDW3:  .WORD  ADDW3   ;; DEVICE DESCRIPTOR WORD#3
020236 000000 $DDW4:  .WORD  ADDW4   ;; DEVICE DESCRIPTOR WORD#4
020240 000000 $DDW5:  .WORD  ADDW5   ;; DEVICE DESCRIPTOR WORD#5
020242 000000 $DDW6:  .WORD  ADDW6   ;; DEVICE DESCRIPTOR WORD#6
020244 000000 $DDW7:  .WORD  ADDW7   ;; DEVICE DESCRIPTOR WORD#7
020246 000000 $DDW8:  .WORD  ADDW8   ;; DEVICE DESCRIPTOR WORD#8
020250 000000 $DDW9:  .WORD  ADDW9   ;; DEVICE DESCRIPTOR WORD#9
```

020252 000000  
020254 000000  
020256 000000  
020260 000000  
020262 000000  
020264 000000  
020266

\$DDW10: .WORD ADDW10 ;;DEVICE DESCRIPTOR WORD#10  
\$DDW11: .WORD ADDW11 ;;DEVICE DESCRIPTOR WORD#11  
\$DDW12: .WORD ADDW12 ;;DEVICE DESCRIPTOR WORD#12  
\$DDW13: .WORD ADDW13 ;;DEVICE DESCRIPTOR WORD#13  
\$DDW14: .WORD ADDW14 ;;DEVICE DESCRIPTOR WORD#14  
\$DDW15: .WORD ADDW15 ;;DEVICE DESCRIPTOR WORD#15  
\$ETEND:



4097

.SBTTL SCOPE HANDLER ROUTINE

```

*****
*THIS ROUTINE CONTROLS THE LOOPING OF SUBTESTS. IT WILL INCREMENT
*AND LOAD THE TEST NUMBER($TSTNM) INTO THE DISPLAY REG.(DISPLAY<7:0>)
*AND LOAD THE ERROR FLAG ($ERFLG) INTO DISPLAY<15:08>
*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
*SW14=1      LOOP ON TEST
*SW11=1      INHIBIT ITERATIONS
*SW09=1      LOOP ON ERROR
*SW08=1      LOOP ON TEST IN SWR<4:0>
*CALL
*          SCOPE          ;;SCOPE=IOT
    
```

```

020266          005037 001360          $SCOPE:
020266          005037 001320          CLR      RETRY          ;CLEAR RETRY FLAG AN THE START OF EACH TEST
020272          005037 001320          CLR      ERRCNT        ;CLEAR THE MULTIPLE ERROR COUNTER
020276          005037 001246          CLR      DATAOR       ;LOCATION FOR LOGICAL OR OF BAD DATA
020302          005037 001236          CLR      ADDROR        ;LOCATION FOR LOGICAL OR OF ADDRESS
020306          005037 001240          CLR      ADDROR+2      ;LOCATION FOR UPPER 6 BITS OF LOGICAL OR OF ADDRESS
020312          005037 001254          CLR      PATTOR        ;LOCATION FOR LOGICAL OR OF PATTERN LOADED
020316          012737 177777 001242  MOV      #-1,DATAND    ;LOCATION FOR LOGICAL AND OF BAD DATA
020324          012737 177777 001232  MOV      #-1,ADRAND    ;LOCATION FOR LOGICAL AND OF ADDRESS
020332          012737 000077 001234  MOV      #77,ADRAND+2 ;LOCATION FOR UPPER 6 BITS OF LOGICAL AND OF ADDRESS
020340          012737 177777 001252  MOV      #-1,PATAND    ;LOCATION FOR LOGICAL AND OF PATTERN LOADED
020346          012737 000077 005766  MOV      #77,EADRES+2 ;RESTORE UPPER 6 BIT LOCATION OF EADRES+2
020354          012737 000077 005772  MOV      #77,EADRS2+2 ;RESTORE UPPER 6 BIT LOCATION OF EADRS2+2
020362          032777 040000 160546  1$:     BIT      #BIT14,@SWR  ;;LOOP ON PRESENT TEST?
020370          001134          BNE      $OVER         ;;YES IF SW14=1
          ;#####START OF CODE FOR THE XOR TESTER#####
020372          000416          $XTSTR: BR      6$          ;;IF RUNNING ON THE 'XOR' TESTER CHANGE
          ;THIS INSTRUCTION TO A 'NOP' (NOP=240)
020374          013746 000004          MOV      @ERRVEC,-(SP)  ;;SAVE THE CONTENTS OF THE ERROR VECTOR
020400          012737 020420 000004  MOV      #5$,@ERRVEC  ;;SET FOR TIMEOUT
020406          005737 177060          TST      @#177060     ;;TIME OUT ON XOR?
020412          012637 000004          MOV      (SP)+,@ERRVEC ;RESTORE THE ERROR VECTOR
020416          000503          BR      $SVLAD        ;GO TO THE NEXT TEST
020420          022626          5$:     CMP      (SP)+,(SP)+  ;CLEAR THE STACK AFTER A TIME OUT
020422          012637 000004          MOV      (SP)+,@ERRVEC ;RESTORE THE ERROR VECTOR
020426          000443          BR      7$          ;LOOP ON THE PRESENT TEST
020430          6$:;#####END OF CODE FOR THE XOR TESTER#####
020430          032777 000400 160500  BIT      #BIT08,@SWR  ;;LOOP ON SPEC. TEST?
020436          001407          BEQ      2$          ;BR IF NO
020440          017746 160472          MOV      @SWR,-(SP)   ;SET DESIRED TEST NUM. FROM SWR
020444          042716 000340          BIC      #$$SWRMK,(SP) ;STRIP AWAY UNDESIRED BITS
020450          122637 001100          CMPB    (SP)+,$TSTNM  ;ON THE RIGHT TEST?
020454          001502          BEQ      $OVER       ;BR IF YES
020456          013737 177766 020700  2$:     MOV      177766,CPSAVE ;MOVE CPU ERR REG VALUE TO LOC FOR TST ;DPM001
020464          032737 000001 020700  BIT      #BIT00,CPSAVE ;SEE IF THE POWER MONITOR BIT IS ON ;DPM001
020472          001406          BEQ      2000$       ;BRANCH TO CONTINUE ROUTINE IF CLEAR ;DPM001
020474          042737 000001 177766  BIC      #BIT00,177766 ;CLEAR THE BIT FOUND TO BE SET ;DPM001
020502          104177          EMT      +177        ;CALL SPECIAL POWER FAIL BIT ERROR CALL ;DPM001
020504          105037 001101          CLRB    $ERFLG       ;CLEAR THE ERROR FLAG ;DPM001
020510          105737 001101          2000$: TSTB    $ERFLG      ;HAS AN ERROR OCCURRED?
020514          001421          BEQ      3$          ;BR IF NO
020516          123737 001113 001101  CMPB    $ERMAX,$ERFLG ;MAX. ERRORS FOR THIS TEST OCCURRED?
020524          101015          BHI     3$          ;BR IF NO
    
```

```

020526 032777 001000 160402      BIT      #BIT09,@SWR      ;;LOOP ON ERROR?
020534 001404      BEQ      4$              ;;BR IF NO
020536 013737 001106 001104 7$:  MOV      $LPERR,$LPADR  ;;SET LOOP ADDRESS TO LAST SCOPE
020544 000446      BR              $OVER
020546 105037 001101      CLR      SERFLG        ;;ZERO THE ERROR FLAG
020552 005037 001212      CLR      $TIMES        ;;CLEAR THE NUMBER OF ITERATIONS TO MAKE
020556 000415      BR              1$      ;;ESCAPE TO THE NEXT TEST
020560 032777 004000 160350 3$:  BIT      #BIT11,@SWR    ;;INHIBIT ITERATIONS?
020566 001011      BNE      1$           ;;BR IF YES
020570 005737 020150      TST      $PASS         ;;IF FIRST PASS OF PROGRAM
020574 001406      BEQ      1$           ;;      INHIBIT ITERATIONS
020576 005237 001102      INC      $ICNT         ;;INCREMENT ITERATION COUNT
020602 023737 001212 001102      CMP      $TIMES,$ICNT  ;;CHECK THE NUMBER OF ITERATIONS MADE
020610 002024      BGE      $OVER        ;;BR IF MORE ITERATION REQUIRED
020612 012737 000001 001102 1$:  MOV      #1,$ICNT      ;;REINITIALIZE THE ITERATION COUNTER
020620 013737 020676 001212      MOV      $MXCNT,$TIMES ;;SET NUMBER OF ITERATIONS TO DO
020626 105237 001100      $SVLAD: INCB     $TSTNM  ;;COUNT TEST NUMBERS
020632 113737 001100 020146      MOVB    $TSTNM,$TESTN  ;;SET TEST NUMBER IN APT MAILBOX
020640 011637 001104      MOV      (SP),$LPADR   ;;SAVE SCOPE LOOP ADDRESS
020644 011637 001106      MOV      (SP),$LPERR   ;;SAVE ERROR LOOP ADDRESS
020650 005037 001214      CLR      $ESCAPE      ;;CLEAR THE ESCAPE FROM ERROR ADDRESS
020654 112737 000001 001113      MOVB    #1,$ERMAX     ;;ONLY ALLOW ONE(1) ERROR ON NEXT TEST
020662 013777 001100 160250 $OVER:  MOV      $TSTNM,@DISPLAY ;;DISPLAY TEST NUMBER
020670 013716 001104      MOV      $LPADR,(SP)  ;;FUDGE RETURN ADDRESS
020674 000002      RTI
020676 000002      $MXCNT: 2.          ;;FIXES PS
020700 000000      CPSAVE: .WORD      0  ;;MAX. NUMBER OF ITERATIONS
                                ;;LOCATION TO SAVE CPU ERR REG CONTENTS ;DPM001

```

4099

.SBTTL ERROR HANDLER ROUTINE

```

*****
*THIS ROUTINE WILL INCREMENT THE ERROR FLAG AND THE ERROR COUNT,
*SAVE THE ERROR ITEM NUMBER AND THE ADDRESS OF THE ERROR CALL
*AND GO TO ERTYPE ON ERROR
*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
*SW15=1      HALT ON ERROR
*SW13=1      INHIBIT ERROR TYPEOUTS
*SW10=1      BELL ON ERROR
*SW09=1      LOOP ON ERROR
*CALL
*          ERROR  N      ;;ERROR=EMT AND N=ERROR ITEM NUMBER
    
```

```

020702 000000          IBSAVE: .WORD 0          ;LOC'N TO HOLD $ITEMB DURING DUAL ERR ;DPM001
020704 105037 020702 $ERROR: CLRB IBSAVE          ;CLEAR THE ITEM BYTE SAVE LOCATION ;DPM001
020710 113737 001100 020146 MOVB $TSTNM,$TESTN ;SAVE TEST NUMBER FOR ERROR TYPE OUT
020716 005237 001320 INC ERRCNT ;COUNT ALL MULTIPLE ERRORS
020722 010037 001160 MOV R0,$REG0 ;SAVE R0 FOR POSSIBLE TYPE OUT
020726 010137 001162 MOV R1,$REG1 ;SAVE R1 FOR POSSIBLE TYPE OUT
020732 010237 001164 MOV R2,$REG2 ;SAVE R2 FOR POSSIBLE TYPE OUT
020736 010337 001166 MOV R3,$REG3 ;SAVE R3 FOR POSSIBLE TYPE OUT
020742 010437 001170 MOV R4,$REG4 ;SAVE R4 FOR POSSIBLE TYPE OUT
020746 010537 001172 MOV R5,$REG5 ;SAVE R5 FOR POSSIBLE TYPE OUT
020752 105237 001101 7$: INCB $ERFLG ;SET THE ERROR FLAG
020756 001775 BEQ 7$ ;DON'T LET THE FLAG GO TO ZERO
020760 013777 001100 160152 MOV $TSTNM,@DISPLAY ;DISPLAY TEST NUMBER AND ERROR FLAG
020766 032777 002000 160142 BIT #BIT10,@SWR ;BELL ON ERROR?
020774 001402 BEQ 1$ ;NO - SKIP
020776 104401 001216 TYPE ,SBELL ;RING BELL
021002 005237 001110 1$: INC $ERTTL ;COUNT THE NUMBER OF ERRORS
021006 011637 001114 MOV (SP),$ERRPC ;GET ADDRESS OF ERROR INSTRUCTION
021012 162737 000002 001114 SUB #2,$ERRPC
021020 117737 160070 001112 MOVB @ $ERRPC,$ITEMB ;STRIP AND SAVE THE ERROR ITEM CODE
021026 122737 000177 001112 CMPB #177,$ITEMB ;SEE IF THIS IS THE POWER FAIL CALL ;DPM001
021034 001426 BEQ 2001$ ;BRANCH AROUND ROUTINE IF IT IS ;DPM001
021036 105737 020702 TSTB IBSAVE ;SEE IF THIS IS THE 2ND ERROR CALL ;DPM001
021042 001021 BNE 2000$ ;BRANCH IF SO ;DPM001
021044 013737 177766 020700 MOV 177766,CPSAVE ;MOVE CPU ERR REG TO CPSAVE FOR TEST ;DPM001
021052 032737 000001 020700 BIT #BIT00,CPSAVE ;SEE IF POWER MONITOR BIT IS SET ;DPM001
021060 001414 BEQ 2001$ ;BRANCH IF OK ;DPM001
021062 042737 000001 177766 BIC #BIT00,177766 ;CLEAR THE BIT FOUND SET ;DPM001
021070 113737 001112 020702 MOVB $ITEMB,IBSAVE ;MAKE IBSAVE NON-ZERO FOR DUAL CALL ;DPM001
021076 112737 000177 001112 MOVB #177,$ITEMB ;SET $ITEMB TO SPECIAL POWER FAIL PNTR ;DPM001
021104 000402 BR 2001$ ;BRANCH OVER IBSAVE CLEARING ;DPM001
021106 105037 020702 2000$: CLRB IBSAVE ;CLEAR IBSAVE SO AFTER 2ND ERROR, EXIT ;DPM001
021112 2001$:
021112 032777 020000 160016 BIT #BIT13,@SWR ;SKIP TYPEOUT IF SET
021120 001004 BNE 20$ ;SKIP TYPEOUTS
021122 004737 002026 JSR PC,ERTYPE ;GO TO USER ERROR ROUTINE
021126 104401 001223 TYPE ,$CRLF
021132 20$:
021132 122737 000001 020162 CMPB #APTENV,$ENV ;RUNNING IN APT MODE
021140 001007 BNE 2$ ;NO,SKIP APT ERROR REPORT
021142 113737 001112 021154 MOVB $ITEMB,21$ ;SET ITEM NUMBER AS ERROR NUMBER
021150 004737 021346 JSR PC,$ATY4 ;REPORT FATAL ERROR TO AP?
021154 000 21$: .BYTE 0
    
```

```

021155      000
021156 000777      22$: BR      22$      ;;APT ERROR LOOP
021160 105737 020702 2$: TSTB  IBSAVE  ;;SEE IF POWER FAIL ERROR CALL ;DPM001
021164 001004      BNE     3$      ;;BRANCH IF NOT - HALT NOT ALLOWED ;DPM001
021166 005777 157744 TST   @SWR      ;;HALT ON ERROR
021172 100001      BPL     3$      ;;SKIP IF CONTINUE
021174 000000      HALT                    ;;HALT ON ERROR!
021176 032777 001000 157732 3$: BIT   #BIT09,@SWR  ;;LOOP ON ERROR SWITCH SET?
021204 001405      BEQ     4$      ;;BR IF NO
021206 105737 020702 TSTB  IBSAVE  ;;SEE IF THIS IS THE PWR MNTR BIT ERROR ;DPM001
021212 001257      BNE     7$      ;;BRANCH BACK IF SO - FUDGING NOT ALLOWED;DPM001
021214 013716 001106 MOV   $PERR,(SP) ;;FUDGE RETURN FOR LOOPING
021220 005737 001214 4$: TST   $ESCAPE ;;CHECK FOR AN ESCAPE ADDRESS
021224 001405      BEQ     5$      ;;BR IF NONE
021226 105737 020702 TSTB  IBSAVE  ;;SEE IF THIS IS THE PWR MNTR BIT ERROR ;DPM001
021232 001247      BNE     7$      ;;BRANCH BACK IF SO - FUDGING NOT ALLOWED;DPM001
021234 013716 001214 MOV   $ESCAPE,(SP) ;;FUDGE RETURN ADDRESS FOR ESCAPE
021240
021240 022737 022024 000042 5$: CMP   #SENDAD,@#42 ;;ACT-11 AUTO-ACCEPT?
021246 001001      BNE     6$      ;;BRANCH IF NO
021250 000000      HALT                    ;;YES
021252
021252 105737 020702 6$: TSTB  IBSAVE  ;;SEE IF THIS IS THE PWR FAIL ERROR CALL ;DPM001
021256 001235      BNE     7$      ;;BRANCH BACK TO CALL ORIGINAL ERR IF SO ;DPM001
021260 032777 001000 157650 BIT   #SW9,@SWR  ;;ARE WE LOOPING ON THIS ERROR?
021266 001417      BEQ     1000$     ;;BRANCH IF NOT
021270 012737 177777 177766 MOV   #-1,CPUERR ;;CLEAR CPU ERROR REGISTER
021276 042737 177776 177572 BIC   #177776,MMRO ;;CLEAR MEMORY MANAGEMENT STATUS REGISTER
021304 012737 177777 003032 MOV   #-1,TOFLAG ;;INITIALIZE TRAP FLAG
021312 012737 177777 003224 MOV   #-1,CPFLAG ;;INITIALIZE CP TRAP FLAG
021320 012737 177777 003374 MOV   #-1,MMFLAG ;;INITIALIZE MEMORY MANAGEMENT TRAP FLAG
021326 000002      1000$: RTI      ;;RETURN TO TEST
  
```

4101

```

.SBTTL APT COMMUNICATIONS ROUTINE
*****
021330 112737 000001 021574 $ATY1:  MOVB  #1,$FFLG      ;;TO REPORT FATAL ERROR
021336 112737 000001 021572 $ATY3:  MOVB  #1,$MFLG      ;;TO TYPE A MESSAGE
021344 000403                                     BR      $ATYC
021346 112737 000001 021574 $ATY4:  MOVB  #1,$FFLG      ;;TO ONLY REPORT FATAL ERROR
021354 $ATYC:
021354 010046                                     MOV    R0,-(SP)      ;;PUSH R0 ON STACK
021356 010146                                     MOV    R1,-(SP)      ;;PUSH R1 ON STACK
021360 105737 021572                                     TSTB  $MFLG          ;;SHOULD TYPE A MESSAGE?
021364 001450                                     BEQ   5$              ;;IF NOT: BR
021366 122737 000001 020162 CMPB  #APTENV,$ENV    ;;OPERATING UNDER APT?
021374 001031                                     BNE   3$              ;;IF NOT: BR
021376 132737 000100 020163 BITB  #APTPOOL,$ENVM  ;;SHOULD SPOOL MESSAGES?
021404 001425                                     BEQ   3$              ;;IF NOT: BR
021406 017600 000004                                     MOV    @4(SP),R0     ;;GET MESSAGE ADDR.
021412 062766 000002 000004 ADD   #2,4(SP)        ;;BUMP RETURN ADDR.
021420 005737 020142 1$:  TST   $MSGTYPE       ;;SEE IF DONE W/ LAST XMISSION?
021424 001375                                     BNE   1$              ;;IF NOT: WAIT
021426 010037 020156                                     MOV    R0,$MSGAD     ;;PUT ADDR IN MAILBOX
021432 105720 2$:  TSTB  (R0)+          ;;FIND END OF MESSAGE
021434 001376                                     BNE   2$
021436 163700 020156 SUB   $MSGAD,R0       ;;SUB START OF MESSAGE
021442 006200                                     ASR   R0              ;;GET MESSAGE LGTH IN WORDS
021444 010037 020160                                     MOV    R0,$MSGLG     ;;PUT LENGTH IN MAILBOX
021450 012737 000004 020142 MOV   #4,$MSGTYPE    ;;TELL APT TO TAKE MSG.
021456 000413                                     BR    5$
021460 017637 000004 021504 3$:  MOV   @4(SP),4$       ;;PUT MSG ADDR IN JSR LINKAGE
021466 062766 000002 000004 ADD   #2,4(SP)        ;;BUMP RETURN ADDRESS
021474 013746 177776 MOV   177776,-(SP)   ;;PUSH 177776 ON STACK
021500 004737 022200 JSR   PC,$TYPE       ;;CALL TYPE MACRO
021504 000000 4$:  .WORD  0
021506 5$:
021506 105737 021574 10$:  TSTB  $FFLG          ;;SHOULD REPORT FATAL ERROR?
021512 001416                                     BEQ   12$            ;;IF NOT: BR
021514 005737 020162 TST   $ENV           ;;RUNNING UNDER APT?
021520 001413                                     BEQ   12$            ;;IF NOT: BR
021522 005737 020142 11$:  TST   $MSGTYPE       ;;FINISHED LAST MESSAGE?
021526 001375                                     BNE   11$           ;;IF NOT: WAIT
021530 017637 000004 020144 MOV   @4(SP),$FATAL  ;;GET ERROR #
021536 062766 000002 000004 ADD   #2,4(SP)        ;;BUMP RETURN ADDR.
021544 005237 020142 INC   $MSGTYPE       ;;TELL APT TO TAKE ERROR
021550 105037 021574 12$:  CLRB  $FFLG          ;;CLEAR FATAL FLAG
021554 105037 021573 CLRB  $LFLG          ;;CLEAR LOG FLAG
021560 105037 021572 CLRB  $MFLG          ;;CLEAR MESSAGE FLAG
021564 012601                                     MOV   (SP)+,R1       ;;POP STACK INTO R1
021566 012600                                     MOV   (SP)+,R0       ;;POP STACK INTO R0
021570 000207 RTS   PC              ;;RETURN
021572 000                                     $MFLG: .BYTE 0       ;;MESSG. FLAG
021573 000                                     $LFLG: .BYTE 0       ;;LOG FLAG
021574 000                                     $FFLG: .BYTE 0       ;;FATAL FLAG
                                     .EVEN
APT SIZE=200
APT ENV=001
APT SPOOL=100
APT CSUP=040

```

000200  
000001  
000100  
000040

4103

.SBTTL END OF PASS ROUTINE

```

:*****
:*INCREMENT THE PASS NUMBER ($PASS)
:*INDICATE END-OF-PROGRAM AFTER 1 PASSES THRU THE PROGRAM
:*TYPE 'END PASS #XXXXX TOTAL NUMBER OF ERRORS SINCE LAST REPORT YYYYY'
:*WHERE XXXXX AND YYYYY ARE DECIMAL NUMBERS
:*IF SW12=1 INHIBIT TRACE TRAP
:*IF THERES A MONITOR GO TO IT
:*IF THERE ISN'T JUMP TO LOOP
    
```

```

021576          $EOP:
021576 000004          SCOPE          ;LOOP ON LAST TEST
021600 005037 177572  CLR          MMR0          ;TURN OFF FULL RELOCATION
021604 005037 172516  CLR          MMR3          ;DISABLE THE UNIBUS MAP
021610 104414          TBITR         ;RESTORE THE T BIT IF IT WAS ON
021612 005037 001100  CLR          $TSTNM        ;ZERO THE TEST NUMBER
021616 005037 001212  CLR          $TIMES        ;ZERO THE NUMBER OF ITERATIONS
021622 005237 020150  INC          $PASS          ;INCREMENT THE PASS NUMBER
021626 042737 100000  BIC          #100000,$PASS ;DON'T ALLOW A NEG. NUMBER
021634 005327          DEC          (PC)+      ;LOOP?
021636 000001          $EOPCT: .WORD    1
021640 003075          BGT          $DOAGN        ;YES
021642 012737          MOV          (PC)+,@(PC)+ ;RESTORE COUNTER
021644 000001          $ENDCT: .WORD    1
021646 021636          $EOPCT
021650 104401 021656  TYPE          ,65$          ;:TYPE ASCIZ STRING
021654 000407          BR          64$          ;:GET OVER THE ASCIZ
;:65$: .ASCIZ <12><15>/END PASS #/
021674          64$:
021674 013746 020150  MOV          $PASS,-(SP) ;:SAVE $PASS FOR TYPEOUT
;:TYPE PASS NUMBER
;:GO TYPE--DECIMAL ASCII WITH SIGN
021700 104405          TYPDS
021702 005737 001110  TST          $ERTTL        ;SEE IF THERE ARE ANY ERRORS TO REPORT ;DPM001
021706 001427          BEQ          1000$       ;BRANCH AROUND MESSAGE PRINT IF NOT ;DPM001
021710 104401 021716  TYPE          ,67$          ;:TYPE ASCIZ STRING
021714 000421          BR          66$          ;:GET OVER THE ASCIZ
;:67$: .ASCIZ / TOTAL ERRORS SINCE LAST REPORT /
021760          66$:
021760 013746 001110  MOV          $ERTTL,-(SP) ;:SAVE $ERTTL FOR TYPEOUT
;:TOTAL NUMBER OF ERRORS
;:GO TYPE--DECIMAL ASCII WITH SIGN
021764 104405          TYPDS
021766 104401 001223  1000$: TYPE          , $CR LF ;:TYPE CARRIAGE RETURN, LINE FEED
021772 005037 001110  CLR          $ERTTL        ;:CLEAR ERROR TOTAL
021776 013700 000042  $GET42: MOV          @#42,R0 ;:GET MONITOR ADDRESS
022002 001414          BEQ          $DOAGN        ;:BRANCH IF NO MONITOR
022004 005046          CLR          -(SP)         ;:INSURE THE 'T' BIT IS CLEAR
022006 012746 022014  MOV          #$CLR.T,-(SP) ;:SETUP FOR AN RTI OR RTT
022012 000426          BR          $RTRN        ;:GO DO AN RTI OR RTT TO LOAD THE PSW
;:WITH A CLEARED 'T' BIT
022014          $CLR.T:
022014 013700 000042  MOV          @#42,R0 ;:INSURE R0 CONTAINS THE MONITORS
022020 001405          BEQ          $DOAGN        ;:RETURN ADDRESS
022022 000005          RESET ;:CLEAR THE WORLD
022024 004710          $ENDAD: JSR         PC,(R0) ;:GO TO MONITOR
022026 000240          NOP ;:SAVE ROOM
022030 000240          NOP ;:FOR
    
```

```
022032 000240          NOP          ;;ACT11
022034          SDOAGN: TRAP          ;;PUSH OLD PSW AND PC ON STACK
022036 104400          BIC          #20,(SP)          ;;CLEAR THE 'T' BIT
022036 042716 000020    157066      BIT          #BIT12,@SWR          ;;RUN WITH TRACE TRAP?
022042 032777 010000    BNE          1$          ;;BR IF NO
022050 001005          COM          $TBIT          ;;IS IT TIME FOR TRACE TRAP
022052 005137 022076    BMI          1$          ;;BR IF NO
022056 100402          BJS          #20,(SP)          ;;SET TRACE TRAP
022060 052716 000020    1$:      MOV          #SLOOP,-(SP)          ;;JUMP TO START OF TEST
022064 012746 022072    SRTN:   RTI          ;;RETURN--THIS IS CHANGED TO
022070 000002          ;;AN 'RTT' IF 'RTT' IS A LEGAL
          ;;INSTRUCTION

022072          SLOOP:      JMP          @(PC)+          ;;RETURN
022072 000137          SRTNAD: .WORD      LOOP
022074 010606          $TBIT:  .WORD      0          ;;'T' BIT STATE INDICATOR
022076 000000          $ENULL: .BYTE      -1,-1,0          ;;NULL CHARACTER STRING
022100          .EVEN
```

4105

```

.SBTTL SAVE AND RESTORE R0-R5 ROUTINES
*****
*SAVE R0-R5
*CALL:
* SAVREG
*UPON RETURN FROM $SAVREG THE STACK WILL LOOK LIKE:
*
*TOP---(+16)
* +2---(+18)
* +4---R5
* +6---R4
* +8---R3
*+10---R2
*+12---R1
*+14---R0
$SAVREG:
MOV R0,-(SP) ;;PUSH R0 ON STACK
MOV R1,-(SP) ;;PUSH R1 ON STACK
MOV R2,-(SP) ;;PUSH R2 ON STACK
MOV R3,-(SP) ;;PUSH R3 ON STACK
MOV R4,-(SP) ;;PUSH R4 ON STACK
MOV R5,-(SP) ;;PUSH R5 ON STACK
MOV 22(SP),-(SP) ;;SAVE PS OF MAIN FLOW
MOV 22(SP),-(SP) ;;SAVE PC OF MAIN FLOW
MOV 22(SP),-(SP) ;;SAVE PS OF CALL
MOV 22(SP),-(SP) ;;SAVE PC OF CALL
RTI

*RESTORE R0-R5
*CALL:
* RESREG
$RESREG:
MOV (SP)+,22(SP) ;;RESTORE PC OF CALL
MOV (SP)+,22(SP) ;;RESTORE PS OF CALL
MOV (SP)+,22(SP) ;;RESTORE PC OF MAIN FLOW
MOV (SP)+,22(SP) ;;RESTORE PS OF MAIN FLOW
MOV (SP)+,R5 ;;POP STACK INTO R5
MOV (SP)+,R4 ;;POP STACK INTO R4
MOV (SP)+,R3 ;;POP STACK INTO R3
MOV (SP)+,R2 ;;POP STACK INTO R2
MOV (SP)+,R1 ;;POP STACK INTO R1
MOV (SP)+,R0 ;;POP STACK INTO R0
RTI

```

```

022104
022104 010046
022106 010146
022110 010246
022112 010346
022114 010446
022116 010546
022120 016646 000022
022124 016646 000022
022130 016646 000022
022134 016646 000022
022140 000002

```

```

022142
022142 012666 000022
022146 012666 000022
022152 012666 000022
022156 012666 000022
022162 012605
022164 012604
022166 012603
022170 012602
022172 012601
022174 012600
022176 000002

```



4107

.SBTTL TYPE ROUTINE

```

*****
*ROUTINE TO TYPE ASCIZ MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
*THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
*NOTE1: $NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
*NOTE2: $FILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
*NOTE3: $FILLC CONTAINS THE CHARACTER TO FILL AFTER.

```

```

*CALL:
*1) USING A TRAP INSTRUCTION
* TYPE ,MESADR ;:MESADR IS FIRST ADDRESS OF AN ASCIZ STRING

```

```

*OR
* TYPE
* MESADR

```

022200	105737	001155	\$TYPE:	TSTB	\$TFPLG	:: IS THERE A TERMINAL?
022204	100002			BPL	1\$	:: BR IF YES
022206	000000			HALT		:: HALT HERE IF NO TERMINAL
022210	000430			BR	3\$	:: LEAVE
022212	010046		1\$:	MOV	RO,-(SP)	:: SAVE RO
022214	017600	000002		MOV	@2(SP),RO	:: GET ADDRESS OF ASCIZ STRING
022220	122737	000001	020162	CMPB	#APTENV,\$ENV	:: RUNNING IN APT MODE
022226	001011			BNE	62\$	:: NO,GO CHECK FOR APT CONSOLE
022230	132737	000100	020163	BITB	#APTPOOL,\$ENVM	:: SPOOL MESSAGE TO APT
022236	001405			BEQ	62\$	:: NO,GO CHECK FOR CONSOLE
022240	010037	022250		MOV	RO,61\$	:: SETUP MESSAGE ADDRESS FOR APT
022244	004737	021336		JSR	PC,\$ATY3	:: SPOOL MESSAGE TO APT
022250	000000		61\$:	.WORD	0	:: MESSAGE ADDRESS
022252	132737	000040	020163	62\$:	BITB	#APTCSUP,\$ENVM
022260	001003			BNE	60\$	:: APT CONSOLE SUPPRESSED
022262	112046		2\$:	MOVB	(RO)+,-(SP)	:: YES,SKIP TYPE OUT
022264	001005			BNE	4\$	:: PUSH CHARACTER TO BE TYPED ONTO STACK
022266	005726			TST	(SP)+	:: BR IF IT ISN'T THE TERMINATOR
022270	012600		60\$:	MOV	(SP)+,RO	:: IF TERMINATOR POP IT OFF THE STACK
022272	062716	000002	3\$:	ADD	#2,(SP)	:: RESTORE RO
022276	000002			RTI		:: ADJUST RETURN PC
022300	122716	000011	4\$:	CMPB	#HT,(SP)	:: RETURN
022304	001430			BEQ	8\$	:: BRANCH IF <HT>
022306	122716	000200		CMPB	#CRLF,(SP)	:: BRANCH IF NOT <CRLF>
022312	001006			BNE	5\$	
022314	005726			TST	(SP)+	:: POP <CR><LF> EQUIV
022316	104401			TYPE		:: TYPE A CR AND LF
022320	001223			\$CRLF		
022322	105037	022540		CLRB	\$CHARCNT	:: CLEAR CHARACTER COUNT
022326	000755			BR	2\$	:: GET NEXT CHARACTER
022330	004737	022412	5\$:	JSR	PC,\$TYPEC	:: GO TYPE THIS CHARACTER
022334	123726	001154	6\$:	CMPB	\$FILLC,(SP)+	:: IS IT TIME FOR FILLER CHARS.?
022340	001350			BNE	2\$	:: IF NO GO GET NEXT CHAR.
022342	013746	001152		MOV	\$NULL,-(SP)	:: GET # OF FILLER CHARS. NEEDED
						:: AND THE NULL CHAR.
022346	105366	000001	7\$:	DECB	1(SP)	:: DOES A NULL NEED TO BE TYPED?
022352	002770			BLT	6\$	:: BR IF NO--GO POP THE NULL OFF OF STACK
022354	004737	022412		JSR	PC,\$TYPEC	:: GO TYPE A NULL
022360	105337	022540		DECB	\$CHARCNT	:: DO NOT COUNT AS A COUNT
022364	000770			BR	7\$	:: LOOP
022366	112716	000040	8\$:	MOVB	#' ,(SP)	:: REPLACE TAB WITH SPACE

```

;HORIZONTAL TAB PROCESSOR

```

```

022372 004737 022412          9$: JSR PC,$TYPEC      ;;TYPE A SPACE
022376 132737 000007 022540 BITB #7,$CHARCNT  ;;BRANCH IF NOT AT
022404 001372          BNE 9$          ;;TAB STOP
022406 005726          TST (SP)+      ;;POP SPACE OFF STACK
022410 000724          BR 2$          ;;GET NEXT CHARACTER
022412          $TYPEC:
022412 105777 156524          TSTB @STKS     ;;CHAR IN KYBD BUFFER?
022416 100022          BPL 10$        ;;BR IF NOT
022420 017746 156520          MOV @STKB,-(SP) ;;GET CHAR
022424 042716 177600          BIC #177600,(SP) ;;STRIP EXTRANEIOUS BITS
022430 122716 000023          CMPB #$XOFF,(SP) ;;WAS CHAR XOFF
022434 001012          BNE 102$       ;;BR IF NOT
022436          101$:
022436 105777 156500          TSTB @STKS     ;;WAIT FOR CHAR
022442 100375          BPL 101$       ;;
022444 117716 156474          MOVB @STKB,(SP) ;;GET CHAR
022450 042716 177600          BIC #177600,(SP) ;;STRIP IT
022454 122716 000021          CMPB #$XON,(SP) ;;WAS IT XON?
022460 001366          BNE 101$       ;;BR IF NOT
022462          102$:
022462 005726          TST (SP)+      ;;FIX STACK
022464          10$:
022464 105777 156456          TSTB @STPS     ;;WAIT UNTIL PRINTER IS READY
022470 100375          BPL 10$          ;;
022472 126627 000002 000021  CMPB 2(SP),#$XON ;;IS CHARACTER A RANDOM XON?
022500 001420          BEQ $TYPEX     ;;BRANCH IF YES
022502 116677 000002 156440  MOVB 2(SP),@STPB ;;LOAD CHAR TO BE TYPED INTO DATA REG.
022510 122766 000015 000002  CMPB #CR,2(SP)  ;;IS CHARACTER A CARRIAGE RETURN?
022516 001003          BNE 1$          ;;BRANCH IF NO
022520 105037 022540          CLRB $CHARCNT  ;;YES--CLEAR CHARACTER COUNT
022524 000406          BR $TYPEX     ;;EXIT
022526 122766 000012 000002  1$: CMPB #LF,2(SP) ;;IS CHARACTER A LINE FEED?
022534 001402          BEQ $TYPEX     ;;BRANCH IF YES
022536 105227          INCB (PC)+  ;;COUNT THE CHARACTER
022540 000000          $CHARCNT: .WORD 0 ;;CHARACTER COUNT STORAGE
022542 000207          $TYPEX: RTS PC

```

4109

```

.SBTTL BINARY TO OCTAL (ASCII) AND TYPE
*****
*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT
*OCTAL (ASCII) NUMBER AND TYPE IT.
*$TYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE
*CALL:
*   MOV      NUM,-(SP)      ;;NUMBER TO BE TYPED
*   TYPOS    ;;CALL FOR TYPEOUT
*   .BYTE   N              ;;N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE
*   .BYTE   M              ;;M=1 OR 0
*                               ;;1=TYPE LEADING ZEROS
*                               ;;0=SUPPRESS LEADING ZEROS
*$TYPON---ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST
*$TYPOS OR $TYPOC
*CALL:
*   MOV      NUM,-(SP)      ;;NUMBER TO BE TYPED
*   TYPON    ;;CALL FOR TYPEOUT
*$TYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER
*CALL:
*   MOV      NUM,-(SP)      ;;NUMBER TO BE TYPED
*   TYPOC    ;;CALL FOR TYPEOUT
022544 017646 000000 022767 $TYPOS: MOV @ (SP),-(SP) ;;PICKUP THE MODE
022550 116637 000001 022767 MOV 1(SP), $OFILL ;;LOAD ZERO FILL SWITCH
022556 112637 022771 MOV  (SP)+, $OMODE+1 ;;NUMBER OF DIGITS TO TYPE
022562 062716 000002 ADD #2, (SP) ;;ADJUST RETURN ADDRESS
022566 000406 BR $TYPON
022570 112737 000001 022767 $TYPOC: MOV #1, $OFILL ;;SET THE ZERO FILL SWITCH
022576 112737 000006 022771 MOV #6, $OMODE+1 ;;SET FOR SIX(6) DIGITS
022604 112737 000005 022766 $TYPON: MOV #5, $OCNT ;;SET THE ITERATION COUNT
022612 010346 MOV R3, -(SP) ;;SAVE R3
022614 010446 MOV R4, -(SP) ;;SAVE R4
022618 010546 MOV R5, -(SP) ;;SAVE R5
022620 113704 022771 MOV $OMODE+1, R4 ;;GET THE NUMBER OF DIGITS TO TYPE
022624 005404 NEG R4
022626 062704 000006 ADD #6, R4 ;;SUBTRACT IT FOR MAX. ALLOWED
022632 110437 022770 MOV R4, $OMODE ;;SAVE IT FOR USE
022636 113704 022767 MOV $OFILL, R4 ;;GET THE ZERO FILL SWITCH
022642 016605 000012 MOV 12(SP), R5 ;;PICKUP THE INPUT NUMBER
022646 005003 CLR R3 ;;CLEAR THE OUTPUT WORD
022650 006105 1$: ROL R5 ;;ROTATE MSB INTO 'C'
022652 000404 BR 3$ ;;GO DO MSB
022654 006105 2$: ROL R5 ;;FORM THIS DIGIT
022656 006105 ROL R5
022660 006105 ROL R5
022662 010503 MOV R5, R3
022664 006103 3$: ROL R3 ;;GET LSB OF THIS DIGIT
022666 105337 022770 DECB $OMODE ;;TYPE THIS DIGIT?
022672 100016 BPL 7$ ;;BR IF NO
022674 042703 177770 BIC #177770, R3 ;;GET RID OF JUNK
022700 001002 BNE 4$ ;;TEST FOR 0
022702 005704 TST R4 ;;SUPPRESS THIS 0?
022704 001403 BEQ 5$ ;;BR IF YES
022706 005204 4$: INC R4 ;;DON'T SUPPRESS ANYMORE 0'S
022710 052703 000060 BIS #0, R3 ;;MAKE THIS DIGIT ASCII
022714 052703 000040 5$: BIS #' ,R3 ;;MAKE ASCII IF NOT ALREADY

```

```

022720 110337 022764      MOVB   R3,8$      ;;SAVE FOR TYPING
022724 104401 022764      TYPE   8$        ;;GO TYPE THIS DIGIT
022730 105337 022766      7$:   DECB   $OCNT  ;;COUNT BY 1
022734 003347           BGT    2$        ;;BR IF MORE TO DO
022736 002402           BLT    6$        ;;BR IF DONE
022740 005204           INC    R4        ;;INSURE LAST DIGIT ISN'T A BLANK
022742 000744           BR     2$        ;;GO DO THE LAST DIGIT
022744 012605           6$:   MOV    (SP)+,R5  ;;RESTORE R5
022746 012604           MOV    (SP)+,R4  ;;RESTORE R4
022750 012603           MOV    (SP)+,R3  ;;RESTORE R3
022752 016666 000002 000004  MOV    2(SP),4(SP) ;;SET THE STACK FOR RETURNING
022760 012616           MOV    (SP)+,(SP)
022762 000002           RTI                    ;;RETURN
022764 000           8$:   .BYTE  0      ;;STORAGE FOR ASCII DIGIT
022765 000           .BYTE  0      ;;TERMINATOR FOR TYPE ROUTINE
022766 000           $OCNT: .BYTE  0  ;;OCTAL DIGIT COUNTER
022767 000           $OFILL: .BYTE  0 ;;ZERO FILL SWITCH
022770 000000           $OMODE: .WORD  0  ;;NUMBER OF DIGITS TO TYPE
  
```

4111

```

.SBTTL CONVERT BINARY TO DECIMAL AND TYPE ROUTINE
:*****
:*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 5-DIGIT
:*SIGNED DECIMAL (ASCII) NUMBER AND TYPE IT. DEPENDING ON WHETHER THE
:*NUMBER IS POSITIVE OR NEGATIVE A SPACE OR A MINUS SIGN WILL BE TYPED
:*BEFORE THE FIRST DIGIT OF THE NUMBER. LEADING ZEROS WILL ALWAYS BE
:*REPLACED WITH SPACES.
:*CALL:
:*
*   MOV     NUM,-(SP)           ;;PUT THE BINARY NUMBER ON THE STACK
*   TYPDS   ;;GO TO THE ROUTINE
$TYPDS:
MOV     R0,-(SP)           ;;PUSH R0 ON STACK
MOV     R1,-(SP)           ;;PUSH R1 ON STACK
MOV     R2,-(SP)           ;;PUSH R2 ON STACK
MOV     R3,-(SP)           ;;PUSH R3 ON STACK
MOV     R5,-(SP)           ;;PUSH R5 ON STACK
MOV     #20200,-(SP)       ;;SET BLANK SWITCH AND SIGN
MOV     20(SP),R5          ;;GET THE INPUT NUMBER
BPL     1$                 ;;BR IF INPUT IS POS.
NEG     R5                 ;;MAKE THE BINARY NUMBER POS.
MOVB   #'-,1(SP)          ;;MAKE THE ASCII NUMBER NEG.
1$:    CLR     R0           ;;ZERO THE CONSTANTS INDEX
MOV     #$DBLK,R3         ;;SETUP THE OUTPUT POINTER
MOVB   #' ,(R3)+          ;;SET THE FIRST CHARACTER TO A BLANK
2$:    CLR     R2           ;;CLEAR THE BCD NUMBER
MOV     $DTBL(R0),R1      ;;GET THE CONSTANT
3$:    SUB     R1,R5        ;;FORM THIS BCD DIGIT
BLT     4$                 ;;BR IF DONE
INC     R2                 ;;INCREASE THE BCD DIGIT BY 1
BR      3$
4$:    ADD     R1,R5        ;;ADD BACK THE CONSTANT
TST     R2                 ;;CHECK IF BCD DIGIT=0
BNE     5$                 ;;FALL THROUGH IF 0
TSTB   (SP)               ;;STILL DOING LEADING 0'S?
BMI     7$                 ;;BR IF YES
5$:    ASLB   (SP)          ;;MSD?
BCC     6$                 ;;BR IF NO
MOVB   1(SP),-1(R3)       ;;YES--SET THE SIGN
6$:    BIS     #'0,R2       ;;MAKE THE BCD DIGIT ASCII
7$:    BIS     #' ,R2       ;;MAKE IT A SPACE IF NOT ALREADY A DIGIT
MOVB   R2,(R3)+          ;;PUT THIS CHARACTER IN THE OUTPUT BUFFER
TST     (R0)+             ;;JUST INCREMENTING
CMP     R0,#10            ;;CHECK THE TABLE INDEX
BLT     2$                 ;;GO DO THE NEXT DIGIT
BGT     8$                 ;;GO TO EXIT
MOV     R5,R2             ;;GET THE LSD
BR      6$                 ;;GO CHANGE TO ASCII
8$:    TSTB   (SP)+         ;;WAS THE LSD THE FIRST NON-ZERO?
BPL     9$                 ;;BR IF NO
MOVB   -1(SP),-2(R3)     ;;YES--SET THE SIGN FOR TYPING
9$:    CLRB   (R3)         ;;SET THE TERMINATOR
MOV     (SP)+,R5         ;;POP STACK INTO R5
MOV     (SP)+,R3         ;;POP STACK INTO R3
MOV     (SP)+,R2         ;;POP STACK INTO R2
MOV     (SP)+,R1         ;;POP STACK INTO R1
MOV     (SP)+,R0         ;;POP STACK INTO R0
TYPE   , $DBLK           ;;NOW TYPE THE NUMBER

```

```

022772
022772 010046
022774 010146
022776 010246
023000 010346
023002 010546
023004 012746 020200
023010 016605 000020
023014 100004
023016 005405
023020 112766 000055 000001
023026 005000 1$:
023030 012703 023206
023034 112723 000040
023040 005002 2$:
023042 016001 023176
023046 160105 3$:
023050 002402
023052 005202
023054 000774
023056 060105 4$:
023060 005702
023062 001002
023064 105716
023066 100407
023070 106316 5$:
023072 103003
023074 116663 000001 177777
023102 052702 000060 6$:
023106 052702 000040 7$:
023112 110223
023114 005720
023116 020027 000010
023122 002746
023124 003002
023126 010502
023130 000764
023132 105726 8$:
023134 100003
023136 116663 177777 177776
023144 105013 9$:
023146 012605
023150 012603
023152 012602
023154 012601
023156 012600
023160 104401 023206

```

023164	016666	000002	000004	MOV	2(SP),4(SP)	::ADJUST THE STACK
023172	012616			MOV	(SP)+,(SP)	
023174	000002			RTI		::RETURN TO USER
023176	023420	\$DTBL:	10000.			
023200	001750		1000.			
023202	000144		100.			
023204	000012		10.			
023206		\$DBLK:	.BLKW 4			

4113

```

.SBTTL TTY INPUT ROUTINE
:*****
:ENABL LSB
:DSABL LSB
:*****
:THIS ROUTINE WILL INPUT A SINGLE CHARACTER FROM THE TTY
:CALL:
:*
* RDCHR                                ::INPUT A SINGLE CHARACTER FROM THE TTY
* RETURN HERE                          ::CHARACTER IS ON THE STACK
*                                       ::WITH PARITY BIT STRIPPED OFF
:*****
023216 011646          $RDCHR: MOV      (SP),-(SP)      ::PUSH DOWN THE PC
023220 016666 000004 000002  MOV      4(SP),2(SP)      ::SAVE THE PS
023226 105777 155710 1$:  TSTB     @STKS          ::WAIT FOR
023232 100375          BPL      1$              ::A CHARACTER
023234 117766 155704 000004  MOVB     @STKB,4(SP)      ::READ THE TTY
023242 042766 177600 000004  BIC     #^C<177>,4(SP)  ::GET RID OF JUNK IF ANY
023250 026627 000004 000023  CMP     4(SP),#2$      ::IS IT A CONTROL-S?
023256 001013          BNE     3$              ::BRANCH IF NO
023260 105777 155656 2$:  TSTB     @STKS          ::WAIT FOR A CHARACTER
023264 100375          BPL      2$              ::LOOP UNTIL ITS THERE
023266 117746 155652  MOVB     @STKB,-(SP)     ::GET CHARACTER
023272 042716 177600  BIC     #^C177,(SP)    ::MAKE IT 7-BIT ASCII
023276 022627 000021  CMP     (SP)+,#21      ::IS IT A CONTROL-Q?
023302 001366          BNE     2$              ::IF NOT DISCARD IT
023304 000750          BR       1$              ::YES, RESUME
023306 026627 000004 000021 3$:  CMP     4(SP),#$XON    ::IS IT A RANDOM XON?
023314 001744          BEQ     1$              ::BRANCH IF YES
023316 026627 000004 000140  CMP     4(SP),#140     ::IS IT UPPER CASE?
023324 002407          BLT     4$              ::BRANCH IF YES
023326 026627 000004 000175  CMP     4(SP),#175     ::IS IT A SPECIAL CHAR?
023334 003003          BGT     4$              ::BRANCH IF YES
023336 042766 000040 000004  BIC     #40,4(SP)     ::MAKE IT UPPER CASE
023344 000002 4$:  RTI      ::GO BACK TO USER
:*****
:THIS ROUTINE WILL INPUT A STRING FROM THE TTY
:CALL:
:*
* RDLIN                                ::INPUT A STRING FROM THE TTY
* RETURN HERE                          ::ADDRESS OF FIRST CHARACTER WILL BE ON THE STACK
*                                       ::TERMINATOR WILL BE A BYTE OF ALL 0'S
:*****
023346 010346          $RDLIN: MOV      R3,-(SP)      ::SAVE R3
023350 012703 023454 1$:  MOV     #STTYIN,R3    ::GET ADDRESS
023354 022703 023464 2$:  CMP     #STTYIN+8.,R3  ::BUFFER FULL?
023360 101405          BLOS    4$              ::BR IF YES
023362 104406          RDCHR   ::GO READ ONE CHARACTER FROM THE TTY
023364 112613          MOVB     (SP)+,(R3)     ::GET CHARACTER
023366 122713 000177 10$:  CMPB    #177,(R3)     ::IS IT A RUBOUT
023372 001003          BNE     3$              ::SKIP IF NOT
023374 104401 001222 4$:  TYPE    ,SQUES       ::TYPE A '?'
023400 000763          BR       1$              ::CLEAR THE BUFFER AND LOOP
023402 111337 023452 3$:  MOVB     (R3),9$      ::ECHO THE CHARACTER
023406 104401 023452  TYPE    ,9$
023412 122723 000015  CMPB    #15,(R3)+     ::CHECK FOR RETURN
023416 001356          BNE     2$              ::LOOP IF NOT RETURN
023420 105063 177777  CLRB    -1(R3)        ::CLEAR RETURN (THE 15)
023424 104401 001224  TYPE    ,SLF         ::TYPE A LINE FEED
023430 012603          MOV     (SP)+,R3     ::RESTORE R3

```

```
023432 011646          MOV      (SP),-(SP)      ;;ADJUST THE STACK AND PUT ADDRESS OF THE
023434 016666 000004 000002  MOV      4(SP),2(SP)      ;;      FIRST ASCII CHARACTER ON IT
023442 012766 023454 000004  MOV      #$TTYIN,4(SP)
023450 000002          RTI              ;;RETURN
023452          000          9$: .BYTE 0          ;;STORAGE FOR ASCII CHAR. TO TYPE
023453          000          .BYTE 0          ;;TERMINATOR
023454          .BLKB 8.      ;;RESERVE 8 BYTES FOR TTY INPUT
023464          136          125          015  $CNTLU: .ASCIZ /^U/<15><12>  ;;CONTROL 'U'
023471          136          107          015  $CNTLG: .ASCIZ /^G/<15><12>  ;;CONTROL 'G'
023476          015          012          123  $MSWR: .ASCIZ <15><12>/SWR = /
023507          040          040          116  $MNEW: .ASCIZ / NEW = /
```



4115

.SBTTL TRAP DECODER

\*\*\*\*\*  
\*THIS ROUTINE WILL PICKUP THE LOWER BYTE OF THE "TRAP" INSTRUCTION  
\*AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDRESS  
\*OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED IT WILL  
\*GO TO THAT ROUTINE.

023520 010046  
023522 016600 000002  
023526 005740  
023530 111000  
023532 006300  
023534 016000 023554  
023540 000200

\$TRAP: MOV R0,-(SP) ;;SAVE R0  
MOV 2(SP),R0 ;;GET TRAP ADDRESS  
TST -(R0) ;;BACKUP BY 2  
MOVB (R0),R0 ;;GET RIGHT BYTE OF TRAP  
ASL R0 ;;POSITION FOR INDEXING  
MOV \$TRPAD(R0),R0 ;;INDEX TO TABLE  
RTS R0 ;;GO TO ROUTINE

;;THIS IS USE TO HANDLE THE "GETPRI" MACRO

023542 011646  
023544 016666 000004 000002  
023552 000002

\$TRAP2: MOV (SP),-(SP) ;;MOVE THE PC DOWN  
MOV 4(SP),2(SP) ;;MOVE THE PSW DOWN  
RTI ;;RESTORE THE PSW

.SBTTL TRAP TABLE

\*THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED  
\*BY THE "TRAP" INSTRUCTION.  
ROUTINE

023554 023542  
023556 022200  
023560 022570  
023562 022544  
023564 022604  
023566 022772  
023570 023216  
023572 023346  
023574 005630  
023576 022104  
023600 022142  
4116 023602 002726  
4117 023604 002754  
4118 023606 005630

\$TRPAD: .WORD \$TRAP2  
\$TYPE ;;CALL=TYPE TRAP+1(104401) TTY TYPEOUT ROUTINE  
\$TYPOC ;;CALL=TYPOC TRAP+2(104402) TYPE OCTAL NUMBER (WITH LEADING ZEROS)  
\$TYPOS ;;CALL=TYPOS TRAP+3(104403) TYPE OCTAL NUMBER (NO LEADING ZEROS)  
\$TYPON ;;CALL=TYPON TRAP+4(104404) TYPE OCTAL NUMBER (AS PER LAST CALL)  
\$TYPDS ;;CALL=TYPDS TRAP+5(104405) TYPE DECIMAL NUMBER (WITH SIGN)  
\$RDCHR ;;CALL=RDCHR TRAP+6(104406) TTY TYPEIN CHARACTER ROUTINE  
\$RDLIN ;;CALL=RDLIN TRAP+7(104407) TTY TYPEIN STRING ROUTINE  
\$RDOCT ;;CALL=RDOCT TRAP+10(104410) READ AN OCTAL NUMBER FROM TTY  
\$SAVREG ;;CALL=SAVREG TRAP+11(104411) SAVE R0-R5 ROUTINE  
\$RESREG ;;CALL=RESREG TRAP+12(104412) RESTORE R0-R5 ROUTINE  
\$TBITOF ;;CALL=TBITO TRAP+13(104413) THIS WILL TURN OFF T BIT TRAPPING  
\$TBITRE ;;CALL=TBITR TRAP+14(104414) THIS WILL RETURN THE T BIT TO PREVIOUS CONDI  
\$RDOCT ;;CALL=RDOCT TRAP+15(104415) READ OCTAL NUMBER

4120

.SBTTL POWER DOWN AND UP ROUTINES  
:\*\*\*\*\*

```

:POWER DOWN ROUTINE
023610 012737 023766 000024 $PWRDN: MOV    $SILLUP,@#PWRVEC  ;;SET FOR FAST UP
023616 012737 000340 000026      MOV    #340,@#PWRVEC+2  ;;PRIO:7
      MOV    R0,-(SP)      ;;PUSH R0 ON STACK
023624 010046      MOV    R1,-(SP)      ;;PUSH R1 ON STACK
023626 010146      MOV    R2,-(SP)      ;;PUSH R2 ON STACK
023630 010246      MOV    R3,-(SP)      ;;PUSH R3 ON STACK
023632 010346      MOV    R4,-(SP)      ;;PUSH R4 ON STACK
023634 010446      MOV    R5,-(SP)      ;;PUSH R5 ON STACK
023636 010546      MOV    @SWR,-(SP)     ;;PUSH @SWR ON STACK
023640 017746 155272      MOV    SP,$SAVR6     ;;SAVE SP
023644 010637 023772      MOV    #PWRUP,@#PWRVEC ;;SET UP VECTOR
023650 012737 023662 000024      HALT
023656 000000      BR     .-2          ;;HANG UP
023660 000776

:*****
:POWER UP ROUTINE
023662 012737 023766 000024 $PWRUP: MOV    $SILLUP,@#PWRVEC  ;;SET FOR FAST DOWN
023670 013706 023772      MOV    $SAVR6,SP     ;;GET SP
023674 005037 023772      CLR    $SAVR6       ;;WAIT LOOP FOR THE TTY
023700 005237 023772 1$:    INC    $SAVR6       ;;WAIT FOR THE INC
023704 001375      BNE   1$           ;;OF WORD
023706 012677 155224      MOV    (SP)+,@SWR    ;;POP STACK INTO @SWR
023712 012605      MOV    (SP)+,R5     ;;POP STACK INTO R5
023714 012604      MOV    (SP)+,R4     ;;POP STACK INTO R4
023716 012603      MOV    (SP)+,R3     ;;POP STACK INTO R3
023720 012602      MOV    (SP)+,R2     ;;POP STACK INTO R2
023722 012601      MOV    (SP)+,R1     ;;POP STACK INTO R1
023724 012600      MOV    (SP)+,R0     ;;POP STACK INTO R0
023726 012737 023610 000024      MOV    #PWRDN,@#PWRVEC ;;SET UP THE POWER DOWN VECTOR
023734 012737 000340 000026      MOV    #340,@#PWRVEC+2 ;;PRIO:7
023742 104401      TYPE   PWRMSG       ;;REPORT THE POWER FAILURE
023744 023774      SPWRMG: .WORD  PWRMSG ;;POWER FAIL MESSAGE POINTER
023746 012716      MOV    (PC)+,(SP)   ;;RESTART AT START
023750 010000      SPWRAD: .WORD  START ;;RESTART ADDRESS
023752 042766 000020 000002      BIC   #20,2(SP)    ;;CLEAR 'T' BIT
023760 005037 022076      CLR   $TBIT        ;;CLEAR THE 'T' BIT FLAG
023764 000002      RTI
023766 000000      $ILLUP: HALT      ;;THE POWER UP SEQUENCE WAS STARTED
023770 000776      BR     .-2          ;; BEFORE THE POWER DOWN WAS COMPLETE
023772 000000      $SAVR6: 0          ;;PUT THE SP HERE
4121 023774 012 015 120 PWRMSG: .ASCIZ <12><15>?POWER FAILURE, RESTARTING PROGRAM?
4122      .EVEN

```

4124

```

024040 104411
024042 016601 000002
024046 012705 024157
024052 012704 000014
024056 012703 177770
024062 012100
024064 012101
024066 005002
024070 110245
024072 010002
024074 005304
024076 003007
024100 001405
024102 005205
024104 010566 000002
024110 104412
024112 000207
024114 006203
024116 006001
024120 006000
024122 006001
024124 006000
024126 006001
024130 006000
024132 040302
024134 062702 000060
024140 000753
024142
    
```

```

.SBTTL DOUBLE LENGTH BINARY TO OCTAL ASCII CONVERT ROUTINE
*****
*THIS ROUTINE WILL CONVERT A 32-BIT UNSIGNED BINARY NUMBER TO AN
*UNSIGNED OCTAL ASCII NUMBER.
*CALL
*
*   MOV    #PNTR, -(SP)      ;; POINTER TO LOW WORD OF BINARY NUMBER
*   JSR    PC, @#$DB20      ;; CALL THE ROUTINE
*   RETURN                                ;; THE ADDRESS OF THE FIRST ASCII CHAR. IS ON THE STACK
$DB20: SAVREG                ;; SAVE ALL REGISTERS
*   MOV    2(SP), R1         ;; PICKUP THE POINTER TO LOW WORD
*   MOV    #SOCTVL+13., R5   ;; POINTER TO DATA TABLE
*   MOV    #12., R4          ;; DO ELEVEN CHARACTERS
*   MOV    #^C7, R3         ;; MASK
*   MOV    (R1)+, R0         ;; LOWER WORD
*   MOV    (R1)+, R1         ;; HIGH WORD
*   CLR    R2                ;; TERMINATOR
1$:   MOVB  R2, -(R5)        ;; PUT CHARACTER IN DATA TABLE
*   MOV    R0, R2            ;; GET THIS DIGIT
*   DEC    R4                ;; COUNT THIS CHARACTER
*   BGT    3$                ;; BR IF NOT THE LAST DIGIT
*   BEQ    2$                ;; BR IF IT IS THE LAST DIGIT
*   INC    R5                ;; ALL DIGITS DONE-ADJUST POINTER FOR FIRST
*   MOV    R5, 2(SP)        ;; ASCII CHAR. & PUT IT ON THE STACK
*   RESREG                    ;; RESTORE ALL REGISTERS
*   RTS    PC                ;; RETURN TO USER
2$:   ASR    R3                ;; POSITION THE MASK FOR THE LAST DIGIT
3$:   ROR    R1                ;; POSITION THE BINARY NUMBER FOR
*   ROR    R0                ;; THE NEXT OCTAL DIGIT
*   ROR    R1
*   ROR    R0
*   ROR    R1
*   ROR    R0
*   BIC    R3, R2            ;; MASK OUT ALL JUNK
*   ADD    #0, R2           ;; MAKE THIS CHAR. ASCII
*   BR     1$                ;; GO PUT IT IN THE DATA TABLE
SOCTVL: .BLKB 14.          ;; RESERVE DATA TABLE
    
```

				.SBTTL	ERROR MESSAGES
4126					
4127	024160	116	117	124	EM1: .ASCIZ ?NOT THE CORRECT TRAP CONDITION THROUGH ERREVC (#004)?
4128	024245	125	116	105	EM2: .ASCIZ ?UNEXPECTED CPU TRAP THROUGH ERREVC (#004)?
4129	024317	125	116	105	EM3: .ASCIZ ?UNEXPECTED MEMORY MANAGEMENT TRAP, MEMORY MANAGEMENT STATUS REGISTERS?
4130	024425	123	125	115	EM4: .ASCIZ ?SUMMARY OF MAP REGISTERS THAT TIMED OUT ON READ?
4131	024505	123	125	115	EM5: .ASCIZ ?SUMMARY OF DUAL ADDRESSING ERRORS ON LOADING MAP REGISTERS?
4132	024600	123	125	115	EM6: .ASCIZ ?SUMMARY OF BIT PATTERN FAILURES IN LOWER 16 BITS OF MAP REGISTERS?
4133	024702	123	125	115	EM7: .ASCIZ ?SUMMARY OF BIT PATTERN FAILURES IN UPPER 6 BITS OF MAP REGISTERS?
4134	025003	103	101	116	EM10: .ASCII ?CAN'T GET TO MAIN MEMORY FROM UNIBUS WITH THE MAP OFF?<CRLF>
4135	025071	123	117	040	.ASCIZ ?SO JUMPING TO THE SIZE JUMPER TEST FOR VERIFICATION?
4136	025155	123	125	115	EM11: .ASCIZ ?SUMMARY OF COUNT PATTERN FAILURES ON THE UNIBUS DATA PATH?
4137	025247	125	116	111	EM12: .ASCIZ ?UNIBUS MAP IS RELOCATING WHEN NOT ENABLED?
4138	025321	103	101	116	EM13: .ASCII ?CANNOT USE ANY OF THE MAP REGISTERS OR PHYSICAL?<CRLF>
4139	025401	101	104	104	.ASCII ?ADDRESS BIT14 IS STUCK LOW, MUST RESTART PROGRAM?<CRLF>
4140	025462	111	106	040	.ASCIZ ?IF YOU DON'T LOOP ON THIS PROBLEM.?
4141	025525	123	125	115	EM14: .ASCIZ ?SUMMARY OF UNIBUS ADDRESS ERRORS, WITH THE MAP RELOCATION DISABLED.
4142	025630	115	101	111	EM15: .ASCIZ ?MAIN MEMORY TIMEOUT OVER THE UNIBUS DID NOT OCCUR PROPERLY?
4143	025723	122	105	114	EM16: .ASCIZ ?RELOCATION THROUGH THE MAP WAS NOT CORRECT, CARRY PROPAGATION?
4144	026021	116	117	040	EM17: .ASCIZ ?NO UNIBUS MEMORY EXISTS?
4145	026051	111	116	124	EM20: .ASCIZ ?INTERRUPT/ABORT LOGIC TESTS TRAP TO LOCATION 114 DID NOT OCCUR?
4146	026150	111	116	124	EM21: .ASCIZ ?INTERRUPT/ABORT TESTS R4 WAS OVERWRITTEN WITH?
4147	026226	111	116	124	EM22: .ASCIZ ?INTERRUPT/ABORT TESTS TRAP DID NOT OCCUR DUE TO ABORT?
4148	026314	114	115	101	EM23: .ASCIZ ?LMA NOT LOADED PROPERLY?
4149	026344	114	115	101	EM24: .ASCIZ ?LMA FORCE JUMPER BIT NOT ZERO?
4150	026402	114	115	101	EM25: .ASCIZ ?LMA FORCE JUMPER BIT NOT SET?
4151	026437	114	115	101	EM26: .ASCIZ ?LMA CONTROL BITS INCORRECT?
4152	026472	106	117	122	EM27: .ASCIZ ?FORCE JUMPER BIT FAILS TO REVERT MAP REGISTER STATUS TO DEFAULT?
4153	026572	113	111	120	EM30: .ASCIZ ?KIPARS NOT LOADED PROPERLY?
4154	026625	124	110	105	EM201: .ASCIZ ?THE FOLLOWING REGISTERS TIMED OUT WHEN READ?
4155	026701	124	110	105	EM202: .ASCIZ ?THE FOLLOWING ARE DUAL ADDRESSING ERRORS IN THE UNIBUS MAP?
4156	026774	124	110	105	EM203: .ASCIZ ?THE BIT PATTERN THROUGH THE MAP REGISTERS FAILED?
4157	027055	125	116	111	EM204: .ASCIZ ?UNIBUS DATA PATH COUNT PATTERN FAILURE?
4158	027124	125	116	111	EM205: .ASCIZ ?UNIBUS ADDRESSING ERRORS, MAP RELOCATION DISABLED?
4159	027206	104	101	124	EM206: .ASCIZ ?DATA PATTERN NOT CORRECT?
4160	027237	122	105	106	EM207: .ASCIZ ?REFERENCED MAP REGISTER 0 WITH ADDRESS ONE BIT DIFFERENT THAN 17770200?
4161	027346	115	101	120	EM210: .ASCIZ ?MAP REGISTER(S) UNDER TEST DID NOT RESPOND IN DUAL MAPPING TEST?
4162	027446	122	105	114	EM211: .ASCII ?RELOCATION THROUGH THE MAP WAS NOT CORRECT, CARRY PROPAGATION?<CRLF>
4163	027544	124	105	123	.ASCIZ ?TEST CODE BEING RUN OVER UNIBUS?
4164	027604	115	101	111	EM212: .ASCII ?MAIN MEMORY TIMEOUT OVER THE UNIBUS DID NOT OCCUR PROPERLY?<CRLF>
4165	027677	124	105	123	.ASCIZ ?TEST CODE BEING RUN OVER UNIBUS?
4166	027737	115	101	120	EM213: .ASCIZ ?MAP REGISTER ENABLED WHEN DDW SAYS IT SHOULD BE DISABLED?
4167	030030	115	101	120	EM214: .ASCIZ ?MAP REGISTER DISABLED WHEN DDW SAYS IT SHOULD BE ENABLED?



					.SBTTL	DATA TABLES
4204						
4205	032340	001330	001326	020146	DT1:	.WORD PCPUER,CPUEXP,\$TESTN,BADPC,0
4206	032352	001330	020146	001340	DT2:	.WORD PCPUER,\$TESTN,BADPC,0
4207	032362	001350	001352	001354	DT3:	.WORD PMMR0,PMR1,PMR2,\$TESTN,BADPC,0
4208	032376	001236	001232	001320	DT4:	.WORD ADDROR,ADRAND,ERRCNT,\$TESTN,\$ERRPC,0
4209	032412	001236	001232	001246	DT5:	.WORD ADDROR,ADRAND,DATAOR,DATAND,ERRCNT,\$TESTN,0
4210	032430	001236	001232	001254	DT6:	.WORD ADDROR,ADRAND,PATTOR,PATAND,DATAOR,DATAND,ERRCNT,\$TESTN,0
4211	032452	020146	001114	172516	DT10:	.WORD \$TESTN,\$ERRPC,MMR3,0
4212	032462	001254	001252	001246	DT11:	.WORD PATTOR,PATAND,DATAOR,DATAND,ERRCNT,\$TESTN,0
4213	032500	001236	001232	001246	DT14:	.WORD ADDROR,ADRAND,DATAOR,DATAND,ERRCNT,\$TESTN,0
4214	032516	001326	001330	020146	DT15:	.WORD CPUEXP,PCPUER,\$TESTN,\$ERRPC,0
4215	032530	020146	001114	005764	DT23:	.WORD \$TESTN,\$ERRPC,EADRES,EADRS2,0
4216	032542	020146	001114	001162	DT24:	.WORD \$TESTN,\$ERRPC,\$REG1,LMAHI,0
4217	032554	020146	001114	001174	DT26:	.WORD \$TESTN,\$ERRPC,\$TMP0,\$REG2,0
4218	032566	020146	001114	001174	DT27:	.WORD \$TESTN,\$ERRPC,\$TMP0,KIPAR4,0
4219	032600	020146	001114	001206	DT30:	.WORD \$TESTN,\$ERRPC,\$TMP5,KIPAR5,0
4220	032612	005764	020146	001114	DT201:	.WORD EADRES,\$TESTN,\$ERRPC,0
4221	032622	005770	005764	001202	DT202:	.WORD EADRS2,EADRES,\$TMP3,\$TESTN,\$ERRPC,0
4222	032636	005770	001174	001170	DT203:	.WORD EADRS2,\$TMP0,\$REG4,\$REG3,\$TESTN,\$ERRPC,0
4223	032654	001174	001176	001164	DT204:	.WORD \$TMP0,\$TMP1,\$REG2,\$TESTN,\$ERRPC,0
4224	032670	005764	005770	020146	DT205:	.WORD EADRES,EADRS2,\$TESTN,\$ERRPC,0
4225	032702	005764	001204	001206	DT206:	.WORD EADRES,\$TMP4,\$TMP5,\$TESTN,\$ERRPC,0
4226	032716	005764	001160	020146	DT207:	.WORD EADRES,\$REG0,\$TESTN,\$ERRPC,0
4227	032730	020146	001114	005764	DT210:	.WORD \$TESTN,\$ERRPC,EADRES,0
4228	032740	005764	001166	001164	DT211:	.WORD EADRES,\$REG3,\$REG2,\$TESTN,\$ERRPC,0
4229	032754	001326	001330	020146	DT212:	.WORD CPUEXP,PCPUER,\$TESTN,\$ERRPC,0
4230	032766	020146	001114	001174	DT213:	.WORD \$TESTN,\$ERRPC,\$TMP0,\$TMP1,\$REG5,0

4231					.SBTTL	NON-DEFAULT UNIBUS MAP JUMPER MESSAGE
4232	033002	200	123	111	JMPMSG: .ASCII	<CRLF>?SIZE JUMPERS ON UNIBUS MAP ARE NOT IN THEIR DEFAULT?<CRLF>
4233	033067	120	117	123	.ASCII	?POSITION. MAP REGISTERS BETWEEN THE LOWEST AND HIGHEST?<CRLF>
4234	033157	125	123	105	.ASCII	?USEABLE, AND ABOVE THE UNIBUS END NUMBER WILL BE TESTED.?<CRLF>
4235	033250	125	116	111	.ASCII	?UNIBUS MEMORY WILL BE ASSUMED TO BE BETWEEN UNIBUS BEGIN?<CRLF>
4236	033341	101	116	104	.ASCII	?AND END REGISTER NUMBERS IF BIT <5> IS SET IN THE SWR,?<CRLF>
4237	033430	105	116	101	.ASCII	?ENABLING TEST #23 TO EXECUTE.?<CRLF><CRLF>
4238	033467	040	040	114	.ASCII	? LOWEST HIGEST UNIBUS UNIBUS?<CRLF>
4239	033530	040	040	125	.ASCII	? USABLE USABLE BEGIN END?<CRLF>
4240	033567	040	040	040	.ASCIIZ	? REG# REG # REG # REG # TEST #?<CRLF>

					.SBTTL	DATA FIELDS
4241						
4242	033641	000	000	000	DF1:	.BYTE 0.0.0.0.0
4243	033646	002	002	001	DF4:	.BYTE 2.2.1.0.0
4244	033653	002	002	002	DF5:	.BYTE 2.2.2.2.1.0
4245	033661	002	002	000	DF6:	.BYTE 2.2.0.0.0.0.1.0
4246	033671	000	000	000	DF11:	.BYTE 0.0.0.0.1.0
4247	033677	002	002	000	DF14:	.BYTE 2.2.0.0.1.0
4248	033705	000	000	002	DF23:	.BYTE 0.0.2.2
4249	033711	002	000	000	DF201:	.BYTE 2.0.0.0.0.0
4250	033717	000	000	003	DF204:	.BYTE 0.0.3.0.0
4251	033724	000	000	002	DF210:	.BYTE 0.0.2
4252		000001				.END



ABASE = 000000  
ACDW1 = 000000  
ACDW2 = 000000  
ACPUOP = 000000  
ADDROR = 001236  
ADDW0 = 177777  
ADDW1 = 177777  
ADDW10 = 000000  
ADDW11 = 000000  
ADDW12 = 000000  
ADDW13 = 000000  
ADDW14 = 000000  
ADDW15 = 000000  
ADDW2 = 000000  
ADDW3 = 000000  
ADDW4 = 000000  
ADDW5 = 000000  
ADDW6 = 000000  
ADDW7 = 000000  
ADDW8 = 000000  
ADDW9 = 000000  
ADEVCT = 000000  
ADEVM = 000000  
ADRAND = 001232  
ADREXT = 003674  
AENV = 000000  
AENVM = 000000  
AFATAL = 000000  
AMADR1 = 000000  
AMADR2 = 000000  
AMADR3 = 000000  
AMADR4 = 000000  
AMAMS1 = 000000  
AMAMS2 = 000000  
AMAMS3 = 000000  
AMAMS4 = 000000  
AMSGAD = 000000  
AMSGLG = 000000  
AMSGTY = 000000  
AMTYP1 = 000000  
AMTYP2 = 000000  
AMTYP3 = 000000  
AMTYP4 = 000000  
APASS = 000000  
APRIOR = 000000  
APTCSU = 000040  
APTENV = 000001  
APTSIZ = 000200  
APTSPO = 000100  
ASWREG = 000000  
ATESTN = 000000  
AUNIT = 000000  
AUSWR = 000000  
AVECT1 = 000000  
AVECT2 = 000000  
BADCPU = 006607  
BADPC = 001340

BIT0 = 000001  
BIT00 = 000001  
BIT01 = 000002  
BIT02 = 000004  
BIT03 = 000010  
BIT04 = 000020  
BIT05 = 000040  
BIT06 = 000100  
BIT07 = 000200  
BIT08 = 000400  
BIT09 = 001000  
BIT1 = 000002  
BIT10 = 002000  
BIT11 = 004000  
BIT12 = 010000  
BIT13 = 020000  
BIT14 = 040000  
BIT15 = 100000  
BIT2 = 000004  
BIT3 = 000010  
BIT4 = 000020  
BIT5 = 000040  
BIT6 = 000100  
BIT7 = 000200  
BIT8 = 000400  
BIT9 = 001000  
BPTVEC = 000014  
BUFWIN = 001276  
CACHE = 177746  
CACHVE = 000114  
CASHSR = 005324  
CASH1 = 005460  
CASH2 = 005470  
CHARCT = 005760  
CHKLMA = 005076  
CHKPAT = 005600  
CLRMAP = 002772  
CMPE = 177744  
CNTR = 001322  
CONTRL = 177746  
CPFLAG = 003224  
CPSAVE = 020700  
CPUER = 003222  
CPUERR = 177766  
CPUEXP = 001326  
CPUMSG = 006770  
CPUTYP = 0000  
CR = 000015  
CRLF = 000200  
CTRAPS = 000116  
CTRAPV = 000114  
DATA = 001364  
DATAND = 001242  
DATAOR = 001246  
DATEXT = 003624  
DATO = 100000  
DATOB = 140000

DDISP = 177570  
DFMSG = 006120  
DF1 = 033641  
DF11 = 033671  
DF14 = 033677  
DF201 = 033711  
DF204 = 033717  
DF210 = 033724  
DF23 = 033705  
DF4 = 033646  
DF5 = 033653  
DF6 = 033661  
DH1 = 030121  
DH10 = 030727  
DH11 = 030754  
DH15 = 031111  
DH2 = 030160  
DH201 = 031366  
DH202 = 031415  
DH203 = 031524  
DH204 = 031605  
DH205 = 031656  
DH206 = 031743  
DH207 = 032013  
DH210 = 032054  
DH211 = 032106  
DH212 = 032211  
DH213 = 032270  
DH23 = 031170  
DH24 = 031231  
DH27 = 031270  
DH3 = 030207  
DH30 = 031327  
DH4 = 030306  
DH5 = 030403  
DH6 = 030540  
DISPLA = 001140  
DISPRE = 000174  
DSABLD = 005230  
DSWR = 177570  
DTMS = 005740  
DTMSG = 005744  
DT1 = 032340  
DT10 = 032452  
DT11 = 032462  
DT14 = 032500  
DT15 = 032516  
DT2 = 032352  
DT201 = 032612  
DT202 = 032622  
DT203 = 032636  
DT204 = 032654  
DT205 = 032670  
DT206 = 032702  
DT207 = 032716  
DT210 = 032730  
DT211 = 032740

DT212 = 032754  
DT213 = 032766  
DT23 = 032530  
DT24 = 032542  
DT26 = 032554  
DT27 = 032566  
DT3 = 032362  
DT30 = 032600  
DT4 = 032376  
DT5 = 032412  
DT6 = 032430  
EADRES = 005764  
EADRS2 = 005770  
EMTVEC = 000030  
EM1 = 024160  
EM10 = 025003  
EM11 = 025155  
EM12 = 025247  
EM13 = 025321  
EM14 = 025525  
EM15 = 025630  
EM16 = 025723  
EM17 = 026021  
EM2 = 024245  
EM20 = 026051  
EM201 = 026625  
EM202 = 026701  
EM203 = 026774  
EM204 = 027055  
EM205 = 027124  
EM206 = 027206  
EM207 = 027237  
EM21 = 026150  
EM210 = 027346  
EM211 = 027446  
EM212 = 027604  
EM213 = 027737  
EM214 = 030030  
EM22 = 026226  
EM23 = 026314  
EM24 = 026344  
EM25 = 026402  
EM26 = 026437  
EM27 = 026472  
EM3 = 024317  
EM30 = 026572  
EM4 = 024425  
EM5 = 024505  
EM6 = 024600  
EM7 = 024702  
ENABLD = 005266  
ERRCNT = 001320  
ERROR = 104000  
ERRVEC = 000004  
ERTYPE = 002026  
ER200 = 001666  
EXTOUT = 005762

FJBIT = 000100  
FLAG = 001324  
FLOATR = 005774  
FTTHRU = 003532  
GMRMD1 = 007043  
GMRMOD = 007046  
HIADRS = 177742  
HIGEST = 001260  
HITMIS = 177752  
HT = 000011  
IBSAVE = 020702  
IOTVEC = 000020  
JMPMSG = 033002  
KDPAR0 = 172360  
KDPAR1 = 172362  
KDPAR2 = 172364  
KDPAR3 = 172366  
KDPAR4 = 172370  
KDPAR5 = 172372  
KDPAR6 = 172374  
KDPAR7 = 172376  
KDPDR0 = 172320  
KDPDR1 = 172322  
KDPDR2 = 172324  
KDPDR3 = 172326  
KDPDR4 = 172330  
KDPDR5 = 172332  
KDPDR6 = 172334  
KDPDR7 = 172336  
KERSTK = 001100  
KIPAR0 = 172340  
KIPAR1 = 172342  
KIPAR2 = 172344  
KIPAR3 = 172346  
KIPAR4 = 172350  
KIPAR5 = 172352  
KIPAR6 = 172354  
KIPAR7 = 172356  
KIPDR0 = 172300  
KIPDR1 = 172302  
KIPDR2 = 172304  
KIPDR3 = 172306  
KIPDR4 = 172310  
KIPDR5 = 172312  
KIPDR6 = 172314  
KIPDR7 = 172316  
KSP = 000006  
LF = 000012  
LKS = 177546  
LKVEC = 000100  
LMAH = 001304  
LMAHI = 177736  
LMAL = 001306  
LMALOW = 177734  
LOADRS = 177740  
LOEFLG = 004312  
LOOP = 010606

LOWEST	001256	MAPL12=	170250	PATEXT	003650	SDPAR7=	172276	SW13	=	020000	
LREGL	001300	MAPL13=	170254	PATRNS	006102	SDPDR0=	172220	SW14	=	040000	
LREGU	001302	MAPL14=	170260	PATTOR	001254	SDPDR1=	172222	SW15	=	100000	
MAINT	=	MAPL15=	170264	PCONTR	001334	SDPDR2=	172224	SW2	=	000004	
MAPADD	004106	MAPL16=	170270	PCPUER	001330	SDPDR3=	172226	SW3	=	000010	
MAPHO	=	MAPL17=	170274	PIRQ	=	177772	SDPDR4=	172230	SW4	=	000020
MAPHO0=	170202	MAPL2	=	PIRQVE=	000240	SDPDR5=	172232	SW5	=	000040	
MAPHO1=	170206	MAPL20=	170300	PMAINT	001336	SDPDR6=	172234	SW6	=	000100	
MAPHO2=	170212	MAPL21=	170304	PMBECD	002526	SDPDR7=	172236	SW7	=	000200	
MAPHO3=	170216	MAPL22=	170310	PMBECF	002536	SIPAR0=	172240	SW8	=	000400	
MAPHO4=	170222	MAPL23=	170314	PMBECH	002476	SIPAR1=	172242	SW9	=	001000	
MAPHO5=	170226	MAPL24=	170320	PMBECM	002442	SIPAR2=	172244	SYSTID=	177764		
MAPHO6=	170232	MAPL25=	170324	PMBECW	002432	SIPAR3=	172246	TBIT	=	000020	
MAPHO7=	170236	MAPL26=	170330	PMMR0	001350	SIPAR4=	172250	TBITO	=	104413	
MAPH1	=	MAPL27=	170334	PMMR1	001352	SIPAR5=	172252	TBITOF	002726		
MAPH10=	170242	MAPL3	=	PMMR2	001354	SIPAR6=	172254	TBITR	=	104414	
MAPH11=	170246	MAPL30=	170340	PPARER	001332	SIPAR7=	172256	TBITRE	002754		
MAPH12=	170252	MAPL31=	170344	PRETST	005166	SIPDR0=	172200	TBITVE=	000014		
MAPH13=	170256	MAPL32=	170350	PRO	=	000000	SIPDR1=	172202	TCMRA	004416	
MAPH14=	170262	MAPL33=	170354	PR1	=	000040	SIPDR2=	172204	TIMEOU	003030	
MAPH15=	170266	MAPL34=	170360	PR2	=	000100	SIPDR3=	172206	TIMOUT=	000020	
MAPH16=	170272	MAPL35=	170364	PR3	=	000140	SIPDR4=	172210	TKVEC	=	000060
MAPH17=	170276	MAPL36=	170370	PR4	=	000200	SIPDR5=	172212	TOFLAG	003032	
MAPH2	=	MAPL37=	170374	PR5	=	000240	SIPDR6=	172214	TOMSG	006261	
MAPH20=	170302	MAPL4	=	PR6	=	000300	SIPDR7=	172216	TPVEC	=	000064
MAPH21=	170306	MAPL5	=	PR7	=	000340	SIZEH1=	177762	TRAPVE=	000034	
MAPH22=	170312	MAPL6	=	PS	=	177776	SIZEJ0	012744	TRTVEC=	000014	
MAPH23=	170316	MAPL7	=	PSW	=	177776	SIZEJ1	013154	TSTLOC	003474	
MAPH24=	170320	MASK1	005776	PTMP2	005000	SIZEJ2	013402	TST1	010676		
MAPH25=	170326	MASK2	006000	PWRMSG	023774	SIZELO=	177760	TST10	014616		
MAPH26=	170332	MEMERR=	177744	PWRVEC=	000024	SPECST	006002	TST11	015072		
MAPH27=	170336	MFPT	=	RDCHR	=	104406	SR0	=	177572		
MAPH3	=	MMFLAG	003374	RDLIN	=	104407	SR1	=	177574		
MAPH30=	170342	MMRHI	001270	RDOCT	=	104415	SR2	=	177576		
MAPH31=	170346	MMRLOW	001266	RELC22	011672	SR3	=	172516			
MAPH32=	170352	MMR0	=	RESREG=	104412	SSP	=	0000006			
MAPH33=	170356	MMR1	=	RESVEC=	000010	STACK	=	001100			
MAPH34=	170362	MMR2	=	RETRY	001360	START	010000	TST2	011122		
MAPH35=	170366	MMR3	=	RSIZE	001356	STKLMT=	177774	TST20	015610		
MAPH36=	170372	MMTOTM	020014	R10	=	0000000	SUPSTK=	000700	TST21	015744	
MAPH37=	170376	MMTRAP	003372	R11	=	0000001	SWR	001136	TST22	016220	
MAPH4	=	MMVEC	=	R12	=	0000002	SWREG	000176	TST23	016266	
MAPH5	=	MRQUES	006754	R13	=	0000003	SW0	=	000001		
MAPH6	=	NEWSWR	006161	R14	=	0000004	SW00	=	000001		
MAPH7	=	NEXMEM=	000040	R15	=	0000005	SW01	=	000002		
MAPL0	=	NEXT	003552	R3STAK	004314	SW02	=	000004			
MAPL00=	170200	NOMORE	006421	R6	=	0000006	SW03	=	000010		
MAPL01=	170204	NOMSG	013646	R7	=	0000007	SW04	=	000020		
MAPL02=	170210	NUMOFK	001316	SAVREG=	104411	SW05	=	000040			
MAPL03=	170214	NXTTST	001362	SCOPE	=	000004	SW06	=	000100		
MAPL04=	170220	OLDPC	001342	SDPAR0=	172260	SW07	=	000200			
MAPL05=	170224	OLDPS	001344	SDPAR1=	172262	SW08	=	000400			
MAPL06=	170230	OLDPSW	001346	SDPAR2=	172264	SW09	=	001000			
MAPL07=	170234	PADRSR	001230	SDPAR3=	172266	SW1	=	000002			
MAPL1	=	PADRSL	001226	SDPAR4=	172270	SW10	=	002000			
MAPL10=	170240	PATAND	001252	SDPAR5=	172272	SW11	=	004000			
MAPL11=	170244	PATCH	007142	SDPAR6=	172274	SW12	=	010000			

TYPOC = 104402	USESTK= 000600	\$DOAGN 022034	\$MBADR 020002	\$SVPC = 000204
TYPON = 104404	USP = %000006	\$DTBL 023176	\$MFLG 021572	\$SWR = 177400
TYPOS = 104403	YESMSG 013542	\$ENDAD 022024	\$MNEW 023507	\$SWREG 020164
TYPVAD 002542	\$APTHD 020000	\$ENDCT 021644	\$MSGAD 020156	\$SWRMK= 000340
UBADDR 002650	\$ATYC 021354	\$ENULL 022100	\$MSGLG 020160	\$TBIT 022076
UBMAVA 006125	\$ATY1 021330	\$ENV 020162	\$MSGTY 020142	\$TESTN 020146
UBMEND 006174	\$ATY3 021336	\$ENVM 020163	\$MSWR 023476	\$TIMES 001212
UBMHI 001264	\$ATY4 021346	\$EOP 021576	\$MTYP1 020173	\$TKB 001144
UBMLOW 001262	\$AUTOB 001132	\$EOPCT 021636	\$MTYP2 020177	\$TKS 001142
UBMSU 015236	\$BASE 020216	\$ERFLG 001101	\$MTYP3 020203	\$TMP0 001174
UBM24L 001310	\$BDADR 001120	\$ERMAX 001113	\$MTYP4 020207	\$TMP1 001176
UBM24P 001314	\$BDDAT 001124	\$ERROR 020704	\$MXCNT 020676	\$TMP2 001200
UBM24U 001312	\$BELL 001216	\$ERRPC 001114	\$NULL 001152	\$TMP3 001202
UBRHI 001274	\$CDW1 020222	\$ERRTB 001366	\$NWTST= 000001	\$TMP4 001204
UBRLOW 001272	\$CDW2 020224	\$ERTTL 001110	\$OCNT 022766	\$TMP5 001206
UDPAR0= 177660	\$CHARC 022540	\$ESCAP 001214	\$OCTVL 024142	\$TMP6 001210
UDPAR1= 177662	\$CLR.T 022014	\$ETABL 020162	\$OMODF 022770	\$TN = 000032
UDPAR2= 177664	\$CMTAG 001100	\$ETEND 020266	\$OVER 020662	\$TPB 001150
UDPAR3= 177666	\$CM1 = 000006	\$FATAL 020144	\$PASS 020150	\$TPFLG 001155
UDPAR4= 177670	\$CM2 = 000014	\$FFLG 021574	\$PASTM 020006	\$TPS 001146
UDPAR5= 177672	\$CM3 = 000006	\$FILLC 001154	\$PWAD 023750	\$TRAP 023520
UDPAR6= 177674	\$CM4 = 000007	\$FILLS 001153	\$PWADN 023610	\$TRAP2 023542
UDPAR7= 177676	\$CNTLG 023471	\$GDADR 001116	\$PWRMG 023744	\$TRP = 000016
UDPDR0= 177620	\$CNTLU 023464	\$GDDAT 001122	\$PWRUP 023662	\$TRPAD 023554
UDPDR1= 177622	\$CPUOP 020170	\$GET42 021776	\$QUES 001222	\$TSTM 020004
UDPDR2= 177624	\$CRLF 001223	\$HD = 000000	\$RDCHR 023216	\$TSTM 001100
UDPDR3= 177626	\$DBLK 023206	\$HIBTS 020000	\$RDLIN 023346	\$TTYIN 023454
UDPDR4= 177630	\$DB20 024040	\$HIOCT 005736	\$RDOCT 005630	\$TYPDS 022772
UDPDR5= 177632	\$DDW0 020226	\$ICNT 001102	\$RDSZ = 000010	\$TYPE 022200
UDPDR6= 177634	\$DDW1 020230	\$ILLUP 023766	\$REGAD 001156	\$TYPEC 022412
UDPDR7= 177636	\$DDW10 020252	\$INTAG 001133	\$REG0 001160	\$TYPEX 022542
UIPAR0= 177640	\$DDW11 020254	\$ITEMB 001112	\$REG1 001162	\$TYPOC 022570
UIPAR1= 177642	\$DDW12 020256	\$LF 001224	\$REG2 001164	\$TYPON 022604
UIPAR2= 177644	\$DDW13 020260	\$LFLG 021573	\$REG3 001166	\$TYPOS 022544
UIPAR3= 177646	\$DDW14 020262	\$LOOP 022072	\$REG4 001170	\$UNIT 020154
UIPAR4= 177650	\$DDW15 020264	\$LPADR 001104	\$REG5 001172	\$UNITM 020010
UIPAR5= 177652	\$DDW2 020232	\$LPERR 001106	\$RESRE 022142	\$USWR 020166
UIPAR6= 177654	\$DDW3 020234	\$MADR1 020174	\$RTNAD 022074	\$VECT1 020212
UIPAR7= 177656	\$DDW4 020236	\$MADR2 020200	\$RTRN 022070	\$VECT2 020214
UIPDR0= 177600	\$DDW5 020240	\$MADR3 020204	\$SAVRE 022104	\$XOFF = 000023
UIPDR1= 177602	\$DDW6 020242	\$MADR4 020210	\$SAVR6 023772	\$XON = 000021
UIPDR2= 177604	\$DDW7 020244	\$MAIL 020142	\$SCOPE 020266	\$XTSTR 020372
UIPDR3= 177606	\$DDW8 020246	\$MAMS1 020172	\$SETUP= 000037	\$SET4= 000001
UIPDR4= 177610	\$DDW9 020250	\$MAMS2 020176	\$SSWR 000176	\$OFILL 022767
UIPDR5= 177612	\$DEVCT 020152	\$MAMS3 020202	\$STUP - 177777	.\$X = 020000
UIPDR6= 177614	\$DEVN 020220	\$MAMS4 020206	\$SVLAD 020626	.\$Y = 002026
UIPDR7= 177616				

. ABS. 033727 000  
000000 001  
ERRORS DETECTED: 0

VIRTUAL MEMORY USED: 56440 WORDS ( 221 PAGES)  
DYNAMIC MEMORY: 20034 WORDS ( 77 PAGES)  
ELAPSED TIME: 00:10:24  
CKKUAE.BIN,CKKUAE/CR/-SP/NL:TOC=CKKUAE.MLB/ML,CKKUAE.P11

SYMBOL	CROSS REFERENCE	REFERENCES							
SYMBOL	VALUE								
ABASE	= 000000	91-4095	91-4095						
ACDW1	= 000000	91-4095	91-4095						
ACDW2	= 000000	91-4095	91-4095						
ACPUOP	= 000000	91-4095	91-4095						
ADDROR	= 001236	#21-1496	*41-2228	*41-2243	*92-4097	*92-4097	106-4208	106-4209	106-4210 106-4213
ADDW0	= 177777	#89-4065	91-4095	91-4095					
ADDW1	= 177777	#89-4066	91-4095	91-4095					
ADDW10	= 000000	91-4095	91-4095						
ADDW11	= 000000	91-4095	91-4095						
ADDW12	= 000000	91-4095	91-4095						
ADDW13	= 000000	91-4095	91-4095						
ADDW14	= 000000	91-4095	91-4095						
ADDW15	= 000000	91-4095	91-4095						
ADDW2	= 000000	91-4095	91-4095						
ADDW3	= 000000	91-4095	91-4095						
ADDW4	= 000000	91-4095	91-4095						
ADDW5	= 000000	91-4095	91-4095						
ADDW6	= 000000	91-4095	91-4095						
ADDW7	= 000000	91-4095	91-4095						
ADDW8	= 000000	91-4095	91-4095						
ADDW9	= 000000	91-4095	91-4095						
ADEVCT	= 000000	91-4095	91-4095						
ADEVN	= 000000	91-4095	91-4095						
ADRAND	= 001232	#21-1496	*41-2230	*41-2245	*92-4097	*92-4097	106-4208	106-4209	106-4210 106-4213
ADREXT	= 003674	35-2057	#41-2220	56-2828	57-2897	59-2975	68-3332	68-3374	69-3445
AENV	= 000000	91-4095	91-4095						
AENVN	= 000000	91-4095	91-4095						
AFATAL	= 000000	91-4095	91-4095						
AMADR1	= 000000	91-4095	91-4095						
AMADR2	= 000000	91-4095	91-4095						
AMADR3	= 000000	91-4095	91-4095						
AMADR4	= 000000	91-4095	91-4095						
AMAMS1	= 000000	91-4095	91-4095						
AMAMS2	= 000000	91-4095	91-4095						
AMAMS3	= 000000	91-4095	91-4095						
AMAMS4	= 000000	91-4095	91-4095						
AMSGAD	= 000000	91-4095	91-4095						
AMSGLG	= 000000	91-4095	91-4095						
AMSGTY	= 000000	91-4095	91-4095						
AMTYP1	= 000000	91-4095	91-4095						
AMTYP2	= 000000	91-4095	91-4095						
AMTYP3	= 000000	91-4095	91-4095						
AMTYP4	= 000000	91-4095	91-4095						
APASS	= 000000	91-4095	91-4095						
APRIOR	= 000000	91-4095							
APTCSU	= 000040	#94-4101	97-4107						
APTENV	= 000001	93-4099	94-4101	#94-4101	97-4107				
APTSIZ	= 000200	#94-4101							
APTSP0	= 000100	94-4101	#94-4101	97-4107					
ASWREG	= 000000	91-4095	91-4095						
ATESTN	= 000000	91-4095	91-4095						
AUNIT	= 000000	91-4095	91-4095						

SYMBOL CROSS REFERENCE		REFERENCES									
SYMBOL	VALUE										
AUSWR	= 000000	91-4095	91-4095								
AVECT1	= 000000	91-4095	91-4095								
AVECT2	= 000000	91-4095	91-4095								
BADCPU	006607	#53-2625	54-2713								
B/DPC	001340	#21-1496	*36-2092	*37-2128	106-4205	106-4206	106-4207				
BIT0	= 000001	#17-1489	38-2155	38-2160	58-2936	62-3090	63-3128	79-3745	79-3751		
BIT00	= 000001	#17-1489	17-1489	50-2487	92-4097	92-4097	93-4099	93-4099			
BIT01	= 000002	#17-1489	17-1489								
BIT02	= 000004	#17-1489	17-1489								
BIT03	= 000010	#17-1489	17-1489								
BIT04	= 000020	#17-1489	17-1489								
BIT05	= 000040	#17-1489	17-1489								
BIT06	= 000100	#17-1489	17-1489	50-2505	50-2509						
BIT07	= 000200	#17-1489	17-1489	50-2524							
BIT08	= 000400	#17-1489	17-1489	50-2488	50-2540	92-4097					
BIT09	= 001000	#17-1489	17-1489	55-2781	57-2909	59-2988	92-4097	93-4099			
BIT1	= 000002	#17-1489									
BIT10	= 002000	#17-1489	93-4099								
BIT11	= 004000	#17-1489	42-2284	44-2364	46-2429	59-2957	68-3320	68-3339	73-3526	90-4078	
			92-4097								
BIT12	= 010000	#17-1489	50-2489	50-2541	95-4103						
BIT13	= 020000	#17-1489	93-4099								
BIT14	= 040000	#17-1489	83-3851	84-3877	84-3882	85-3904	92-4097				
BIT15	= 100000	#17-1489	45-2404								
BIT2	= 000004	#17-1489									
BIT3	= 000010	#17-1489									
BIT4	= 000020	16-1460	#17-1489	32-1977	58-2937						
BIT5	= 000040	#17-1489	34-2011	63-3127	69-3412	70-3473	72-3510	87-3974			
BIT6	= 000100	#17-1489	78-3690								
BIT7	= 000200	#17-1489									
BIT8	= 000400	#17-1489									
BIT9	= 001000	#17-1489	56-2834	61-3060	68-3349	69-3456	81-3823	83-3864	84-3891	85-3917	
BPTVEC	= 000014	#17-1489									
BUPWIN	001276	#21-1496	*65-3218	68-3367	68-3395						
CACHE	= 177746	#16-1464	*50-2488	50-2489	*50-2502	*50-2505	*50-2509	50-2513	*50-2524	*50-2535	
		*50-2540	50-2541	*77-3652	*78-3709						
CACHVE	= 000114	#17-1489									
CASHSR	005324	#50-2487	77-3651	78-3701							
CASH1	005460	#50-2512	*77-3649	*78-3699							
CASH2	005470	#50-2516	*77-3650	*78-3700							
CHARCT	005760	#52-2599									
CHKLMA	005076	38-2168	42-2281	44-2361	#46-2425	68-3326	68-3345	68-3354			
CHKPAT	005600	#50-2547	56-2817	56-2831							
CLRMAR	002772	#34-2008	57-2882	60-3012	68-3284						
CMPE	= 177744	#16-1465	*50-2510	*50-2534							
CNTR	001322	#21-1496									
CONTRL	= 177746	#17-1489									
CPFLAG	003224	#36-2083	*36-2099	*36-2102	*36-2107	*54-2740	*93-4099				
CPSAVE	020700	29-1900	*92-4097	92-4097	#92-4097	*93-4099	93-4099				
CPUER	003222	#36-2082	54-2734	55-2787							
CPUERR	= 177766	#17-1489	35-2042	*35-2043	36-2091	*36-2108	*54-2743	*93-4099			
CPUEXP	001326	#21-1496	35-2039	35-2044	35-2053	36-2093	36-2097	36-2106	*44-2345	*44-2350	

SYMBOL CROSS REFERENCE		REFERENCES								
SYMBOL	VALUE									
		*44-2353	*44-2355	*54-2736	*59-2962	*59-2964	*59-2967	*59-2969	*59-2977	*59-2979
		*59-2990	*59-2992	*60-3017	*60-3019	*60-3032	*60-3034	*60-3044	*61-3064	*62-3098
		*62-3101	*63-3137	*63-3140	*63-3148	*64-3173	*64-3179	*64-3182	*65-3209	*65-3212
		*65-3215	*68-3312	*68-3314	*90-4082	*90-4087	106-4205	106-4214	106-4229	
CPUMSG	006200	#53-2620	*54-2692	54-2693	*54-2698	54-2699				
CPUTYP	007140	35-2036	35-2049	36-2095	#53-2630	*54-2684	*54-2685	54-2695	55-2755	77-3638
CR	= 000015	#17-1489	97-4107	97-4107						
CRLF	= 000200	#17-1489	52-2617	52-2619	53-2620	53-2620	53-2621	53-2622	53-2623	53-2624
		53-2625	53-2626	53-2628	53-2629	97-4107	97-4107	104-4134	104-4138	104-4139
		104-4162	104-4164	105-4171	105-4173	105-4175	105-4177	105-4180	105-4182	105-4189
		105-4193	105-4198	105-4200	107-4232	107-4232	107-4233	107-4234	107-4235	107-4236
		107-4237	107-4237	107-4238	107-4239	107-4240				
CTRAPS	= 000116	#16-1468	50-2496	*50-2498	*50-2539					
CTRAPV	= 000114	#16-1467	50-2495	*50-2497	*50-2538					
DATA	001364	#21-1496	44-2346	*44-2381	*44-2388	*44-2389	*44-2390			
DATAAND	001242	#21-1496	*39-2187	*56-2861	*92-4097	106-4209	106-4210	106-4212	106-4213	
DATAOR	001246	#21-1496	*39-2185	*56-2859	*92-4097	106-4209	106-4210	106-4212	106-4213	
DATEXT	003624	#39-2185	56-2824	57-2901	61-3051	68-3335	69-3448			
DATO	= 100000	#84-3874	84-3881							
DATOB	= 140000	#85-3901	85-3908							
DDISP	= 177570	#17-1489	21-1496							
DFMSG	006120	52-2597	#52-2616							
DF1	033641	22-1501	22-1507	22-1514	23-1548	23-1561	23-1569	23-1583	24-1595	24-1601
		24-1608	24-1614	24-1626	24-1632	24-1638	24-1644	25-1649	27-1723	27-1729
		#108-4242								
DF11	033671	23-1555	#108-4246							
DF14	033677	23-1576	26-1684	#108-4247						
DF201	033711	26-1658	26-1671	26-1690	26-1696	27-1709	27-1717	#108-4249		
DF204	033717	26-1677	#108-4250							
DF210	033724	26-1702	#108-4251							
DF23	033705	24-1620	#108-4248							
DF4	033646	22-1521	#108-4243							
DF5	033653	22-1528	23-1590	#108-4244						
DF6	033661	22-1535	23-1541	26-1665	#108-4245					
DH1	030121	22-1499	#105-4169							
DH10	030727	23-1546	23-1559	23-1567	24-1593	24-1599	24-1606	24-1612	#105-4179	
DH11	030754	23-1552	23-1573	23-1587	#105-4180					
DH15	031111	23-1580	#105-4182							
DH2	030160	22-1505	#105-4170							
DH201	031366	26-1656	#105-4188							
DH202	031415	26-1662	#105-4189							
DH203	031524	26-1669	#105-4191							
DH204	031605	26-1675	#105-4192							
DH205	031656	26-1681	#105-4193							
DH206	031743	26-1688	#105-4195							
DH207	032013	26-1694	#105-4196							
DH210	032054	26-1700	#105-4197							
DH211	032106	27-1706	27-1714	#105-4198						
DH212	032211	#105-4200								
DH213	032270	27-1721	27-1727	#105-4202						
DH23	031170	24-1618	#105-4184							
DH24	031231	24-1624	24-1630	24-1636	#105-4185					

SYMBOL	CROSS REFERENCE	VALUE	REFERENCES
DH27		031270	24-1642 #105-4186
DH3		030207	22-1511 #105-4171
DH30		031327	25-1647 #105-4187
DH4		030306	22-1518 #105-4173
DH5		030403	22-1525 #105-4175
DH6		030540	22-1532 23-1538 #105-4177
DISPLA		001140	#21-1496 47-2447 92-4097 93-4099
DISPRE		000174	#18-1492
DSABLD		005230	#48-2459 63-3141 64-3183 65-3207
DSWR	=	177570	#17-1489 21-1492
DTMS		005740	#52-2597 66-3227
DTMSG		005744	52-2597 #52-2598
DT1		032340	22-1500 #106-4205
DT10		032452	23-1547 23-1560 23-1568 24-1594 24-1600 24-1607 24-1613 #106-4211
DT11		032462	23-1554 #106-4212
DT14		032500	23-1575 23-1589 #106-4213
DT15		032516	23-1582 #106-4214
DT2		032352	22-1506 #106-4206
DT201		032612	26-1657 #106-4220
DT202		032622	26-1664 #106-4221
DT203		032636	26-1670 #106-4222
DT204		032654	26-1676 #106-4223
DT205		032670	26-1683 #106-4224
DT206		032702	26-1689 #106-4225
DT207		032716	26-1695 #106-4226
DT210		032730	26-1701 #106-4227
DT211		032740	27-1708 27-1716 #106-4228
DT212		032754	#106-4229
DT213		032766	27-1722 27-1728 #106-4230
DT23		032530	24-1619 #106-4215
DT24		032542	24-1625 24-1631 #106-4216
DT26		032554	24-1637 #106-4217
DT27		032566	24-1643 #106-4218
DT3		032362	22-1513 #106-4207
DT30		032600	25-1648 #106-4219
DT4		032376	22-1520 #106-4208
DT5		032412	22-1527 #106-4209
DT6		032430	22-1534 23-1540 #106-4210
EADRES		005764	*41-2235 *41-2236 41-2247 *41-2249 *41-2250 *42-2292 *42-2293 *44-2371 *44-2372 #52-2601 *59-2987 *79-3762 *79-3763 *88-4045 *92-4097 106-4215 106-4220 106-4221 106-4224 106-4225 106-4226 106-4227 106-4228
EADRS2		005770	#52-2602 *57-2902 *69-3449 *69-3450 *79-3760 *79-3761 *92-4097 106-4215 106-4221 106-4222 106-4224 54-2655
EMTVEC	=	000030	#17-1489
EM1		024160	22-1498 #104-4127
EM10		025003	23-1544 #104-4134
EM11		025155	23-1551 #104-4136
EM12		025247	23-1558 #104-4137
EM13		025321	23-1564 #104-4138
EM14		025525	23-1572 #104-4141
EM15		025630	23-1579 #104-4142
EM16		025723	23-1586 #104-4143

SYMBOL	CROSS REFERENCE	VALUE	REFERENCES
EM17		026021	24-1592 #104-4144
EM2		024245	22-1504 #104-4128
EM20		026051	24-1598 #104-4145
EM201		026625	26-1655 #104-4154
EM202		026701	26-1661 #104-4155
EM203		026774	26-1668 #104-4156
EM204		027055	26-1674 #104-4157
EM205		027124	26-1680 #104-4158
EM206		027206	26-1687 #104-4159
EM207		027237	26-1693 #104-4160
EM21		026150	24-1604 #104-4146
EM210		027346	26-1699 #104-4161
EM211		027446	27-1704 #104-4162
EM212		027604	27-1712 #104-4164
EM213		027737	27-1720 #104-4166
EM214		030030	27-1726 #104-4167
EM22		026226	24-1611 #104-4147
EM23		026314	24-1617 #104-4148
EM24		026344	24-1623 #104-4149
EM25		026402	24-1629 #104-4150
EM26		026437	24-1635 #104-4151
EM27		026472	24-1641 #104-4152
EM3		024317	22-1510 #104-4129
EM30		026572	25-1646 #104-4153
EM4		024425	22-1517 #104-4130
EM5		024505	22-1524 #104-4131
EM6		024600	22-1531 #104-4132
EM7		024702	23-1537 #104-4133
ENABLD		005266	#49-2474 63-3149 64-3177 65-3216
ERRCNT		001320	#21-1496 29-1791 29-1798 *35-2051 *36-2105 *55-2757 55-2759 *55-2778 55-2783
			55-2789 *55-2792 *56-2809 56-2841 *56-2845 *56-2862 57-2915 *57-2918 61-3065
			*61-3068 *68-3291 *68-3315 68-3398 *68-3401 69-3459 *69-3462 *87-3986 *90-4074
			*92-4097 *93-4099 106-4208 106-4209 106-4210 106-4212 106-4213
ERROR	=	104000	#16-1473 #17-1489 35-2047 35-2059 36-2100 36-2103 37-2134 55-2793 56-2833
			56-2848 56-2850 57-2908 57-2919 59-2986 60-3025 61-3059 61-3069 61-3072
			62-3105 63-3142 63-3146 63-3150 64-3178 64-3185 65-3208 65-3217 68-3348
			68-3375 68-3402 69-3455 69-3463 70-3478 71-3493 72-3515 74-3570 75-3588
			76-3601 77-3655 78-3704 78-3708 79-3765 80-3786 81-3802 81-3822 82-3839
			83-3863 84-3890 85-3916 87-3984 88-4046
ERRVEC	=	000004	#17-1489 *54-2734 *54-2735 *55-2754 *55-2787 92-4097 *92-4097 *92-4097 *92-4097
ERTYPE		002026	#29-1777 93-4099
ER200		001666	#26-1650 29-1806 29-1809
EXTOUT		005762	#52-2600
FJBIT	=	000100	#80-3779 80-3782 80-3785 81-3797 81-3798 81-3801 82-3834 82-3835 82-3838
FLAG		001324	#21-1496
FLOATR		005774	38-2150 *38-2155 *38-2160 *38-2162 48-2463 49-2478 #52-2603
FTTHRU		003532	#38-2158 *63-3133
GMRMD1		007043	#53-2628 *55-2768 55-2769 55-2770
GMRMOD		007046	#53-2629 55-2772
GNS	=	*****	18-1492 18-1492 95-4103 95-4103 101-4115 101-4115 101-4115 101-4115 101-4115
			101-4115 101-4115 101-4115 101-4115 101-4115 101-4115 101-4115 101-4115 101-4115
			101-4115 101-4115 101-4115 101-4115 101-4115 101-4116 101-4116 101-4117



SYMBOL	CROSS REFERENCE VALUE	REFERENCES	101-4117	101-4118	101-4118						
HIADRS	= 177742	#17-1489									
HIGEST	= 001260	#21-1496	*64-3167	*64-3188	64-3189	65-3199	68-3362	68-3388	81-3805	87-3979	
HITMIS	= 177752	#17-1489									
HT	= 000011	#17-1489	97-4107	97-4107							
IBSAVE	= 020702	#93-4099	*93-4099	93-4099	*93-4099	*93-4099	93-4099	93-4099	93-4099	93-4099	
IOTVEC	= 000020	#17-1489	54-2655	54-2655							
JMPMSG	= 033002	66-3226	#107-4232								
KDPARC	= 172360	#17-1489									
KDPAR1	= 172362	#17-1489									
KDPAR2	= 172364	#17-1489									
KDPAR3	= 172366	#17-1489									
KDPAR4	= 172370	#17-1489									
KDPAR5	= 172372	#17-1489									
KDPAR6	= 172374	#17-1489									
KDPAR7	= 172376	#17-1489									
KDPDR0	= 172320	#17-1489									
KDPDR1	= 172322	#17-1489									
KDPDR2	= 172324	#17-1489									
KDPDR3	= 172326	#17-1489									
KDPDR4	= 172330	#17-1489									
KDPDR5	= 172332	#17-1489									
KDPDR6	= 172334	#17-1489									
KDPDR7	= 172336	#17-1489									
KERSTK	= 001100	#17-1489									
KIPAR0	= 172340	#17-1489	30-1922	58-2929	*73-3555	*77-3636	*79-3750	*87-3990			
KIPAR1	= 172342	#17-1489	*73-3553	*77-3637	*87-3991						
KIPAR2	= 172344	#17-1489	69-3447	79-3747	*79-3748	*79-3764	*79-3766	*79-3771	83-3847	*83-3848	
		*83-3866	84-3875	*84-3876	*84-3893	85-3902	*85-3903	*85-3919			
KIPAR3	= 172346	#17-1489	45-2401	*45-2402	*45-2407	54-2719	*54-2720	*54-2725	54-2726	*54-2728	
KIPAR4	= 172350	#17-1489	*44-2338	44-2378	*44-2382	57-2896	*63-3130	*63-3143	63-3144	64-3158	
		64-3165	*64-3171	*64-3174	64-3175	64-3188	*65-3204	65-3205	65-3218	65-3219	
		*68-3292	*68-3305	*68-3306	68-3309	68-3324	68-3331	68-3343	68-3358	68-3360	
		68-3362	*68-3364	68-3365	68-3367	*69-3413	*69-3420	69-3421	81-3809	*81-3810	
		*81-3814	81-3815	*81-3826	*90-4075	*90-4080	106-4218				
KIPAR5	= 172352	#17-1489	*60-3027	*60-3029	61-3070	*61-3073	*62-3094	106-4219			
KIPAR6	= 172354	#17-1489	*42-2275	*44-2339	59-2953	*59-2954	*59-2959	59-2961	59-2974	*59-2993	
		*59-2995	*59-2998	*60-3014	*60-3022	60-3027	*60-3039	62-3091	69-3426	69-3429	
		*69-3439	69-3440	69-3444	*88-4018	*88-4025	*88-4027	*88-4052			
KIPAR7	= 172356	#17-1489	35-2056	56-2827	57-2899	68-3334	68-3373				
KIPDR0	= 172300	#17-1489	58-2924								
KIPDR1	= 172302	#17-1489									
KIPDR2	= 172304	#17-1489									
KIPDR3	= 172306	#17-1489									
KIPDR4	= 172310	#17-1489									
KIPDR5	= 172312	#17-1489									
KIPDR6	= 172314	#17-1489									
KIPDR7	= 172316	#17-1489									
KSP	=Z000006	#17-1489	*29-1777	*29-1781	29-1794	29-1802	*29-1831	*29-1839	*29-1845	*29-1851	
		29-1853	*29-1854	*29-1862	*29-1878	*29-1885	*29-1891	*29-1892	30-1915	*30-1930	
		30-1932	*30-1933	*30-1938	30-1938	31-1948	*31-1953	31-1955	*31-1956	*31-1960	
		31-1960	32-1978	32-1980	32-1981	33-1993	*35-2034	*35-2035	*35-2061	*35-2062	



SYMBOL	CROSS REFERENCE	VALUE	REFERENCES
MAPH32	=	170352	#17-1489
MAPH33	=	170356	#17-1489
MAPH34	=	170362	#17-1489
MAPH35	=	170366	#17-1489
MAPH36	=	170372	#17-1489
MAPH37	=	170376	#17-1489 34-2015 56-2846 56-2852 57-2880 57-2888
MAPH4	=	170222	#17-1489
MAPH5	=	170226	#17-1489
MAPH6	=	170232	#17-1489
MAPH7	=	170236	#17-1489
MAPLO	=	170200	#17-1489 34-2008 55-2758 55-2776 *59-2956 59-2970 *59-2972 59-2983 *59-2985 63-3119
MAPLO0	=	170200	#17-1489 17-1489 56-2811 57-2878
MAPLO1	=	170204	#17-1489 17-1489 68-3293 68-3377
MAPLO2	=	170210	#17-1489 17-1489
MAPLO3	=	170214	#17-1489 17-1489
MAPLO4	=	170220	#17-1489 17-1489
MAPLO5	=	170224	#17-1489 17-1489
MAPLO6	=	170230	#17-1489 17-1489
MAPLO7	=	170234	#17-1489 17-1489
MAPL1	=	170204	#17-1489
MAPL10	=	170240	#17-1489
MAPL11	=	170244	#17-1489
MAPL12	=	170250	#17-1489
MAPL13	=	170254	#17-1489
MAPL14	=	170260	#17-1489
MAPL15	=	170264	#17-1489
MAPL16	=	170270	#17-1489
MAPL17	=	170274	#17-1489
MAPL2	=	170210	#17-1489
MAPL20	=	170300	#17-1489
MAPL21	=	170304	#17-1489
MAPL22	=	170310	#17-1489
MAPL23	=	170314	#17-1489
MAPL24	=	170320	#17-1489
MAPL25	=	170324	#17-1489
MAPL26	=	170330	#17-1489
MAPL27	=	170334	#17-1489
MAPL3	=	170214	#17-1489
MAPL30	=	170340	#17-1489
MAPL31	=	170344	#17-1489
MAPL32	=	170350	#17-1489
MAPL33	=	170354	#17-1489
MAPL34	=	170360	#17-1489
MAPL35	=	170364	#17-1489
MAPL36	=	170370	#17-1489
MAPL37	=	170374	#17-1489
MAPL4	=	170220	#17-1489
MAPL5	=	170224	#17-1489
MAPL6	=	170230	#17-1489
MAPL7	=	170234	#17-1489
MASK1	=	005776	50-2548 #52-2604 *56-2812 56-2825 *56-2856

SYMBOL	CROSS REFERENCE	VALUE	REFERENCES
MASK2	=	006000	50-2551 #52-2605 *56-2813 *56-2857
MEMERR	=	177744	#17-1489
MFPT	=	000007	#16-1472 54-2683
MMFLAG		003374	#37-2122 *37-2136 *54-2742 *93-4099
MMRHI		001270	#21-1496 52-2598 *64-3168 *64-3186 *64-3187
MMRLOW		001256	#21-1496 52-2598 *64-3157
MMRO	=	177572	#17-1489 17-1489 37-2131 *37-2135 *50-2487 *54-2737 *57-2877 *58-2936 *62-3090 *63-3128 *68-3285 *68-3290 *77-3634 *79-3745 *79-3751 *83-3849 *87-3973 *88-4020 *93-4099 *95-4103
MMR1	=	177574	#17-1489 17-1489 37-2132
MMR2	=	177576	#17-1489 17-1489 37-2133
MMR3	=	172516	#17-1489 17-1489 34-2011 *54-2738 *57-2884 *58-2937 *63-3127 *68-3281 *68-3283 *69-3412 *70-3473 *77-3635 *79-3746 *79-3749 *80-3780 *81-3807 *81-3827 *83-3850 *87-3988 *87-3989 *95-4103 106-4211
MMTOTM		020014	70-3477 74-3569 #90-4071
MMTRAP		003372	#37-2121 54-2732
MMVEC	=	000250	#17-1489 *54-2732 *54-2733
MRQUES		006754	#53-2627 55-2766
NEWSWR		006161	#52-2618 54-2705
NEXMEM	=	000040	44-2353 44-2356 #72-3510
NEXT		003552	38-2153 38-2156 38-2161 #38-2163
NOMORE		006421	29-1796 #53-2623
NOMSG		013646	64-3190 66-3225 66-3235 #67-3253
NUMOFK		001316	#21-1496 *87-3995 88-4019
NXTTST		001362	#21-1496 *47-2444 *87-3976
OLDPC		001342	#21-1496 *35-2034 35-2062 *36-2089 36-2092 36-2110 *37-2129 37-2138
OLDPS		001344	#21-1496 *35-2035 35-2061 *36-2090 36-2109 *37-2130 37-2137
OLDPSW		001346	#21-1496 *32-1980 33-1993 *33-1994
PADRSR		001230	#21-1496 *30-1928 *31-1952
PADRSL		001226	#21-1496 *30-1929 30-1930 *31-1951 31-1953
PATAND		001252	#21-1496 *40-2201 *56-2860 *92-4097 106-4210 106-4212
PATCH		007142	#53-2634
PATEXT		003650	#40-2199 56-2822 61-3053
PATRS		006102	#52-2608 56-2816 60-3041
PATTOR		001254	#21-1496 *40-2199 *56-2858 *92-4097 106-4210 106-4212
PCONTR		001334	#21-1496
PCPUER		001330	#21-1496 *35-2038 *35-2042 35-2043 35-2044 *36-2091 36-2097 *36-2106 36-2108 *38-2164 38-2171 *44-2341 44-2351 44-2356 *60-3016 60-3020 *68-3307 68-3316 *87-3987 88-4043 *88-4049 *90-4081 90-4088 106-4205 106-4206 106-4214 106-4229
PIRQ	=	177772	#17-1489
PIRQVE	=	000240	#17-1489
PMAINT		001336	#21-1496
PMBECD		002526	29-1896 #29-1900
PMBECF		002536	29-1896 #29-1901
PMBECH		002476	29-1896 #29-1898
PMBECM		002442	29-1896 #29-1897
PMBECW		002432	29-1786 #29-1896
PMRO		001350	#21-1496 *37-2131 106-4207
PMR1		001352	#21-1496 *37-2132 106-4207
PMR2		001354	#21-1496 *37-2133 106-4207
PPARER		001332	#21-1496
PRETST		005166	#47-2443 55-2753 56-2808 57-2876 59-2952 60-3011 62-3088 68-3280 69-3411



SYMBOL	CROSS REFERENCE	VALUE	REFERENCES
SDPDR7	=	172236	#17-1489
SIPAR0	=	172240	#17-1489
SIPAR1	=	172242	#17-1489
SIPAR2	=	172244	#17-1489
SIPAR3	=	172246	#17-1489
SIPAR4	=	172250	#17-1489
SIPAR5	=	172252	#17-1489
SIPAR6	=	172254	#17-1489
SIPAR7	=	172256	#17-1489
SIPDR0	=	172200	#17-1489
SIPDR1	=	172202	#17-1489
SIPDR2	=	172204	#17-1489
SIPDR3	=	172206	#17-1489
SIPDR4	=	172210	#17-1489
SIPDR5	=	172212	#17-1489
SIPDR6	=	172214	#17-1489
SIPDR7	=	172216	#17-1489
SIZEH1	=	177762	#17-1489
SIZEJ0	=	012744	60-3026    62-3089    62-3104    #63-3118    87-3981
SIZEJ1	=	013154	#64-3157
SIZEJ2	=	013402	#65-3199
SIZELO	=	177760	#17-1489
SPECST	=	006002	#52-2606    63-3121    63-3126    66-3234    66-3237
SRO	=	177572	#17-1489
SR1	=	177574	#17-1489
SR2	=	177576	#17-1489
SR3	=	172516	#17-1489
SSP	=	%000006	#17-1489
STACK	=	001100	#17-1489    17-1489    17-1489    17-1489    54-2648    54-2666
START	=	010000	18-1492    #54-2642    63-3147    102-4120
STKLMT	=	177774	#17-1489
SUPSTK	=	000700	#17-1489
SWR	=	001136	#21-1496    29-1800    42-2284    44-2364    46-2429    *54-2689    *54-2691    *54-2697    *54-2702
			*54-2731    55-2781    56-2834    57-2909    59-2988    61-3060    68-3320    68-3339    68-3349
			69-3456    73-3526    77-3647    78-3690    78-3697    81-3823    83-3864    84-3891    85-3917
			87-3974    90-4078    92-4097    92-4097    92-4097    92-4097    92-4097    93-4099    93-4099
			93-4099    93-4099    93-4099    95-4103    102-4120    102-4120
SWREG	=	000176	#18-1492
SW0	=	000001	#17-1489
SW00	=	000001	#17-1489    17-1489
SW01	=	000002	#17-1489    17-1489
SW02	=	000004	#17-1489    17-1489
SW03	=	000010	#17-1489    17-1489
SW04	=	000020	#17-1489    17-1489
SW05	=	000040	#17-1489    17-1489
SW06	=	000100	#17-1489    17-1489
SW07	=	000200	#17-1489    17-1489
SW08	=	000400	#17-1489    17-1489
SW09	=	001000	#17-1489    17-1489
SW1	=	000002	#17-1489
SW10	=	002000	#17-1489
SW11	=	004000	#17-1489









SYMBOL	CROSS REFERENCE VALUE	REFERENCES
SDDW2	020232	#91-4095
SDDW3	020234	#91-4095
SDDW4	020236	#91-4095
SDDW5	020240	#91-4095
SDDW6	020242	#91-4095
SDDW7	020244	#91-4095
SDDW8	020246	#91-4095
SDDW9	020250	#91-4095
SDEVCT	020152	#91-4095
SDEVN	020220	#91-4095
SDOAGN	022034	95-4103 95-4103 #95-4103
SDTBL	023176	99-4111 #99-4111
SENDAD	022024	19-1494 93-4099 #95-4103
SENDCT	021644	54-2657 #95-4103
SENULL	022100	#95-4103
SENV	020162	48-2459 49-2474 55-2761 #91-4095 93-4099 94-4101 94-4101 97-4107
SENVN	020163	48-2461 49-2476 54-2700 54-2729 77-3642 78-3692 #91-4095 94-4101 97-4107
SEOP	021576	87-3976 87-3985 87-4008 88-4057 #95-4103
SEOPCT	021636	*54-2657 #95-4103 95-4103
SERFLG	001101	#21-1496 92-4097 *92-4097 92-4097 92-4097 *92-4097 92-4097 92-4097 *93-4099
SERMAX	001113	#21-1496 *54-2659 92-4097 *92-4097 92-4097 92-4097
SERROR	020704	54-2655 #93-4099
SERRPC	001114	#21-1496 29-1781 29-1900 *93-4099 *93-4099 93-4099 93-4099 93-4099 106-4208
		106-4211 106-4214 106-4215 106-4216 106-4217 106-4218 106-4219 106-4220 106-4221
		106-4222 106-4223 106-4224 106-4225 106-4226 106-4227 106-4228 106-4229 106-4230
SERRTB	001366	#22-1496 29-1809 29-1814
SERTTL	001110	#21-1496 *55-2791 *56-2844 *57-2917 *61-3067 *68-3400 *69-3461 *88-4048 *93-4099
		93-4099 93-4099 95-4103 95-4103 *95-4103
SESCAP	001214	#21-1496 *54-2658 *92-4097 93-4099 93-4099 93-4099
SETABL	020162	#91-4095
SETEND	020266	89-4067 #91-4095
SFATAL	020144	#91-4095 *94-4101
SFFLG	021574	*94-4101 *94-4101 94-4101 *94-4101 #94-4101
SFILLC	001154	#21-1496 97-4107 97-4107 97-4107
SFILLS	001153	#21-1496 97-4107 97-4107
SGADR	001116	#21-1496
SGDDAT	001122	#21-1496
SGET42	021776	#95-4103
SGTSWR	= *****	101-4115
SHD	= 000000	16-1485 16-1485 16-1485
SHIBTS	020000	#89-4067
SHIOCT	005736	*51-2590 #51-2595
SICNT	001102	#21-1496 *92-4097 92-4097 *92-4097 92-4097 92-4097
SILLUP	023766	102-4120 102-4120 #102-4120
SINTAG	001133	#21-1496
SITEMB	001112	#21-1496 29-1779 *93-4099 93-4099 93-4099 *93-4099 93-4099 93-4099 93-4099
SLF	001224	#21-1496 93-4099 93-4099 97-4107 97-4107 100-4113 100-4113 100-4113
SLFLG	021573	*94-4101 #94-4101
SLOOP	022072	95-4103 #95-4103
SLPADR	001104	#21-1496 *47-2449 *54-2669 *92-4097 *92-4097 92-4097 92-4097 92-4097





SYMBOL	CROSS REFERENCE	REFERENCES	REFERENCES	REFERENCES	REFERENCES	REFERENCES	REFERENCES	REFERENCES	REFERENCES	REFERENCES
SYMBOL	VALUE									
\$TMP1	001176	#21-1496	*42-2286	*42-2289	*44-2369	*48-2465	*49-2480	*61-3049	106-4223	106-4230
\$TMP2	001200	#21-1496	*42-2290	*44-2368	*45-2403	*45-2404	*45-2405	45-2406	*45-2406	*59-2953
		59-2998	*83-3854	*83-3855	83-3856	83-3861	*84-3880	*84-3881	84-3883	84-3888
		*85-3907	*85-3908	85-3909	85-3914					
\$TMP3	001202	#21-1496	*57-2894	57-2895	*68-3329	68-3330	106-4221			
\$TMP4	001204	#21-1496	*88-4036	*88-4041	106-4225					
\$TMP5	001206	#21-1496	*41-2227	41-2232	41-2233	*60-3028	*60-3030	61-3070	61-3073	*88-4042
		106-4219	106-4225							
\$TMP6	001210	#21-1496	*60-3015	*60-3023	60-3028					
\$TN	= 000032	#16-1471	16-1485	54-2753	55-2753	55-2753	55-2753	#55-2753	55-2790	55-2808
		56-2808	56-2808	56-2808	#56-2808	56-2851	56-2853	56-2876	57-2876	57-2876
		57-2876	#57-2876	58-2952	59-2952	59-2952	59-2952	#59-2952	59-3011	60-3011
		60-3011	60-3011	#60-3011	61-3071	61-3087	62-3087	#62-3087	67-3280	68-3280
		68-3280	68-3280	#68-3280	68-3399	68-3411	69-3411	69-3411	69-3411	#69-3411
		69-3428	69-3460	69-3472	70-3472	70-3472	70-3472	#70-3472	70-3489	71-3489
		71-3489	71-3489	#71-3489	71-3503	72-3503	#72-3503	73-3567	74-3567	74-3567
		74-3567	#74-3567	74-3584	75-3584	75-3584	75-3584	#75-3584	75-3598	76-3598
		76-3598	76-3598	#76-3598	76-3633	77-3633	77-3633	77-3633	#77-3633	77-3645
		77-3648	77-3654	77-3689	78-3689	78-3689	78-3689	#78-3689	78-3711	78-3724
		79-3724	79-3724	79-3724	#79-3724	79-3778	80-3778	80-3778	80-3778	#80-3778
		80-3783	80-3796	81-3796	81-3796	81-3796	#81-3796	81-3806	81-3833	82-3833
		82-3833	82-3833	#82-3833	82-3836	82-3846	83-3846	83-3846	83-3846	#83-3846
		83-3873	84-3873	84-3873	84-3873	#84-3873	84-3900	85-3900	85-3900	85-3900
		#85-3900	86-3972	87-3972	87-3972	87-3972	#87-3972	87-4001	87-4015	88-4015
		88-4015	88-4015	#88-4015						
\$TPB	001150	#21-1496	97-4107	97-4107	97-4107					
\$TPFLG	001155	#21-1496	97-4107	97-4107	97-4107					
\$TPS	001146	#21-1496	97-4107	97-4107	97-4107					
\$TRAP	023520	54-2655	#101-4115							
\$TRAP2	023542	#101-4115	101-4115							
\$TRP	= 000016	#101-4115	101-4115	101-4115	101-4115	101-4115	#101-4115	101-4115	101-4115	101-4115
		101-4115	#101-4115	101-4115	101-4115	101-4115	101-4115	#101-4115	101-4115	101-4115
		101-4115	101-4115	#101-4115	101-4115	101-4115	101-4115	101-4115	#101-4115	101-4115
		101-4115	101-4115	101-4115	#101-4115	101-4115	101-4115	101-4115	101-4115	#101-4115
		101-4115	101-4115	101-4115	101-4115	#101-4115	101-4115	101-4115	101-4115	101-4115
		#101-4115	101-4115	101-4115	101-4115	101-4115	#101-4115	101-4115	101-4115	101-4115
		101-4116	#101-4116	101-4117	101-4117	101-4117	101-4117	#101-4117	101-4118	101-4118
		101-4118	101-4118	#101-4118						
\$TRPAD	023554	101-4115	#101-4115							
\$STSM	020004	#89-4067								
\$STSNM	001100	#21-1496	*47-2446	47-2447	*73-3524	*73-3528	*77-3640	*78-3710	*87-3982	92-4097
		92-4097	*92-4097	92-4097	92-4097	92-4097	92-4097	93-4099	93-4099	93-4099
		93-4099	*95-4103							
\$TTYIN	023454	100-4113	100-4113	100-4113	#100-4113					
\$TYPBN	= *****	101-4115								
\$TYPDS	022772	#99-4111	101-4115	101-4115						
\$TYPE	022200	94-4101	#97-4107	101-4115	101-4115					
\$TYPEC	022412	97-4107	97-4107	97-4107	#97-4107					
\$TYPEX	022542	97-4107	97-4107	97-4107	#97-4107					
\$TYPOC	022570	#98-4109	101-4115	101-4115						
\$TYPON	022604	98-4109	#98-4109	101-4115						
\$TYPOS	022544	#98-4109	101-4115							

SYMBOL CROSS REFERENCE		REFERENCES			
SYMBOL	VALUE				
\$UNIT	020154	#91-4095			
\$UNITM	020010	#89-4067			
\$USWR	020166	#91-4095			
\$VECT1	020212	#91-4095			
\$VECT2	020214	#91-4095			
\$XOFF	= 000023	97-4107	97-4107		
\$XON	= 000021	97-4107	97-4107	97-4107	100-4113
\$XTSTR	020372	#92-4097			
\$SGET4	= 000001	#95-4103	#95-4103	95-4103	
\$OFILL	022767	*98-4109	*98-4109	98-4109	#98-4109
\$4OCAT	= *****	92-4097	93-4099		
.\$ASTA	= *****	94-4101	94-4101		
.\$X	= 020000	#89-4067	89-4067		
.\$Y	= 002026	#28-1731	28-1734		

MACRO CROSS REFERENCE

MACRO NAME REFERENCES

COMEN	#17-1489									
DONE	#16-1346	95-4103								
ENDCOM	#17-1489									
ESCAPE	#17-1489									
GETPRI	#17-1489	#95-4103								
GETSWR	#17-1489									
MSG	#80-3787	#81-3796	#81-3828	#82-3833	#82-3840	#83-3846	#83-3867	#84-3873	#84-3894	#85-3900
	#87-4009	#88-4015								
MSG1	#54-2744	55-2753								
MSG11	#67-3262	68-3280								
MSG12	#68-3403	#69-3411								
MSG13	#69-3464	70-3472								
MSG14	#70-3479	71-3489								
MSG15	#71-3495	#72-3503								
MSG16	#73-3556	#74-3567								
MSG17	#74-3571	75-3584								
MSG2	#55-2794	#56-2808								
MSG20	#75-3590	76-3598								
MSG21	#76-3603	#77-3633								
MSG22	#77-3656	78-3689								
MSG220	#78-3712	79-3724								
MSG221	#79-3772	80-3778								
MSG23	#86-3961	#87-3972								
MSG4	#56-2864	#57-2876								
MSG5	#58-2942	#59-2952								
MSG6	#59-2999	#60-3011								
MSG7	#61-3074	#62-3087								
MULT	#17-1489									
NEWTST	#16-1462	#17-1489	#54-2753	#55-2808	#56-2876	#58-2952	#59-3011	#61-3087	#67-3280	#68-3411
	#69-3472	#70-3489	#71-3503	#73-3567	#74-3584	#75-3598	#76-3633	#77-3689	#78-3724	#79-3778
	#80-3796	#81-3833	#82-3846	#83-3873	#84-3900	#86-3972	#87-4015			
POP	#17-1489	#94-4101	#94-4101	#96-4105	#99-4111	#102-4120	#102-4120			
PUSH	#17-1489	94-4101	94-4101	94-4101	96-4105	99-4111	102-4120	102-4120		
REPORT	#17-1489									
SAVTST	#16-1384	#93-4099								
SETPRI	#17-1489									
SETTRA	#101-4115	101-4115	101-4115	101-4115	101-4115	101-4115	101-4115	101-4115	101-4115	101-4115
	101-4115	101-4116	101-4117	101-4118						
SETUP	#17-1489									
SKIP	#17-1489	#55-2790	#56-2851	#56-2853	#61-3071	#68-3399	#69-3428	#69-3460	#77-3645	#77-3648
	#77-3654	#80-3783	#81-3806	#82-3836	#87-4001					
SKIPJ	#16-1337	78-3711								
SLASH	#17-1489									
SPACE	#16-1343	#17-1489								
SSCOPE	#16-1362	#92-4097								
STARS	#17-1489	19-1494	21-1496	21-1496	29-1736	29-1776	30-1903	30-1913	31-1941	31-1946
	32-1963	32-1964	32-1966	32-1967	32-1969	32-1976	33-1984	33-1992	34-1998	34-2007
	35-2019	35-2026	36-2065	36-2067	36-2069	36-2081	37-2113	37-2120	38-2141	38-2148
	39-2177	39-2184	40-2191	40-2198	41-2205	41-2219	42-2255	42-2265	44-2321	44-2328
	46-2410	46-2424	47-2442	48-2453	48-2454	49-2470	50-2485	50-2546	51-2557	55-2753
	55-2753	56-2808	56-2808	57-2876	57-2876	59-2952	59-2952	60-3011	60-3011	62-3087
	62-3087	63-3107	63-3117	64-3152	64-3156	65-3192	65-3198	66-3223	67-3247	67-3252





MACRO CROSS REFERENCE

MACRO NAME	REFERENCES
.SEOP	#16-475 95-4103
.SERRO	#16-863 #93-4099
.SPOWE	#16-1462 #102-4120
.SREAD	#16-1461 100-4113
.SSAVE	#16-1461 96-4105
.SSCOP	#16-1042 92-4097
.STRAP	#16-1462 #101-4115
.STYPD	#16-1461 #99-4111
.STYPE	#16-1461 97-4107
.STYPO	#16-1461 98-4109
.1170	#16-1459 17-1489