

Instrument Security Procedures

Models:

Fluke 8842A

Product Name:

Digital Multimeter

Instrument Description:

High performance 5-1/2 digit multimeter.

Memory Description:

Mainframe

There are three devices, with one form or another of memory, in the 8842A.

- 8-bit microcomputer, w/4k bytes of ROM and 144 bytes of RAM
 - EPROM, 4k bytes
 - EEPROM, 512 bytes
1. The ROM memory in the microcomputer is an “on-chip mask-programmed” ROM and is not alterable by the user of the 8842A. The RAM memory is cleared each time the instrument is turned off.
 2. The EPROM is pre-programmed memory and is not alterable by the user.
 3. The EEPROM stores the calibration constants and a user-defined string of up to 16 ASCII characters.

Option -05, IEEE – 488 Interfaces

There is one device with memory in the IEEE – 488 Interface option.

- 8-bit microcomputer, w/4k bytes of ROM and 144 bytes of RAM
1. The ROM memory in the microcomputer is an “on-chip mask-programmed” ROM and is not alterable by the user of the 8842A. The RAM memory is cleared each time the instrument is turned off.

Option -09, RMS AC converter

There are no memory devices in this option.

Memory Cleaning Instructions:

Access to the user-defined string is available ONLY over the IEEE-488 bus [option -05]. Use the GET COMMAND, G3 to retrieve the contents of the user defined message. To clear the message, set the instrument in the calibration mode [by pressing the CAL ENABLE switch on the front panel] and use the PUT COMMAND, P3 and send 16 <spaces>

To clear the entire calibration memory, set the instrument in the calibration mode [by pressing the CAL ENABLE switch on the front panel] and use the CALIBRATION COMMANDS, C3 and C0. This will clear the entire calibration memory, leaving you a 'brain-dead' 8842A – requiring a complete calibration to be useful again.