## 7.1.3 Display and error messages

To ease the ScopeMeter operation display messages are generated. If you operate the ScopeMeter incorrectly, it will display error messages. Each error message is displayed for 5 seconds.

The following table describes the display messages and error messages and the possible solutions. If no specific model number is stated, the message and solution apply to all ScopeMeter models.

The specific mean remaining the state of the	
MESSAGE	CAUSE
<b>Key not possible in this ScopeMeter mode.</b> (SCOPE/METER mode)	You have pressed an incorrect key. For example: you have pressed the trigger key, while in meter mode.
Solution: Press a correct key.	
Not executed: at least one trace on LCD (SCOPE mode)	You have attempted to switch off the only displayed trace in the CHAN AB menu or WAVEFORM menu (Model 97).
Solution: Turn on another channel.	
Not executed: already max. traces on LCD (SCOPE mode)	(Model 97) You have attempted to turn on more than four traces simultaneously in the CHAN AB menu and the WAVEFORM menu.
Solution: Turn off another trace.	
Chosen function changed other settings. (SCOPE mode)	Sometimes some functions, for example events and n-cycle, can adapt (change) other ScopeMeter settings automatically.
Solution: Switch off the chosen function and check the settings.	
Time base limit reached for present mode	The s TIME ns key has been pressed, forcing

(SCOPE mode)

The s TIME ns key has been pressed, forcing the timebase to exceed the limit. For example, if the limit of 100 ns in single trigger mode is exceeded.

Solution: Select RECURRENT trigger mode.

**ScopeMeter auto shut down in 5 minutes!** (SCOPE/METER mode)

No new key has been activated in the last 10 minutes. To save battery power, the ScopeMeter shuts down.

Solution: Press a key.

ScopeMeter model 9x; Vx.xx; yy-yy-yy (SCOPE/METER mode)

ScopeMeter "model number; software version; software date". Both softkeys 1 (left) and 5 (right) have been pressed at the same time.

Solution: -