


HP 9000 Series 200/300 Computers



**Pascal 3.2  
Documentation Guide  
and Master Index**



# **Pascal 3.2 Documentation Guide and Master Index**

**HP 9000 Series 200/300 Computers**

HP Part Number 98615-90017



**Hewlett-Packard Company**

3404 East Harmony Road, Fort Collins, Colorado 80525

## NOTICE

The information contained in this document is subject to change without notice.

HEWLETT-PACKARD MAKES NO WARRANTY OF ANY KIND WITH REGARD TO THIS MANUAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. Hewlett-Packard shall not be liable for errors contained herein or direct, indirect, special, incidental or consequential damages in connection with the furnishing, performance, or use of this material.

## WARRANTY

A copy of the specific warranty terms applicable to your Hewlett-Packard product and replacement parts can be obtained from your local Sales and Service Office.

Copyright © Hewlett-Packard Company 1987

This document contains information which is protected by copyright. All rights are reserved. Reproduction, adaptation, or translation without prior written permission is prohibited, except as allowed under the copyright laws.

### Restricted Rights Legend

Use, duplication or disclosure by the U.S. Government Department of Defense is subject to restrictions as set forth in paragraph (b)(3)(ii) of the Rights in Technical Data and Software clause in FAR 52.227-7013.

Use of this manual and flexible disc(s) or tape cartridge(s) supplied for this pack is restricted to this product only. Additional copies of the programs can be made for security and back-up purposes only. Resale of the programs in their present form or with alterations, is expressly prohibited.

Copyright © AT&T, Inc. 1980, 1984

Copyright © The Regents of the University of California 1979, 1980, 1983

This software and documentation is based in part on the Fourth Berkeley Software Distribution under license from the Regents of the University of California.

# Printing History

---

The manual printing date and part number indicate its current edition. The printing date will change when a new edition is printed. Minor changes may be made at reprint without changing the printing date. The manual part number will change when extensive changes are made.

Manual updates may be issued between editions to correct errors or document product changes. To ensure that you receive these updates or new editions, you should subscribe to the appropriate product support service. See your HP sales representative for details.

July 1987...Edition 1



# Pascal 3.2 Documentation Guide

---

## Introduction

This guide takes you on “sight-seeing tours” of the Pascal 3.2 manuals. Here is what it contains:

- A list of the manuals in this set.
- A “tour” of each manual.
- A Master Index for the manual set.

## List of Pascal 3.2 Manuals

Here are the manuals provided with the Pascal 3.2 Workstation system:

- *Pascal 3.2 User's Guide* (HP Part Number 98615-90042)
- *An Introduction to Programming and Problem Solving with Pascal* (HP Part Number 09826-90072)
- *Pascal 3.2 Workstation System* (HP Part Number 98615-90023, two volumes)
  - *Volume 1: Main Command Level and Subsystems*
  - *Volume 2: Programming and Configuration Topics*
- *Pascal 3.2 Procedure Library* (HP Part Number 98615-90032)
- *Pascal 3.2 Graphics Techniques* (HP Part Number 98615-90037)
- *HP Pascal Language Reference* (HP Part Number 98615-90052)
- *MC68000 User's Manual* (HP Part Number 09826-90073)
- *MC68020 User's Manual*<sup>1</sup> (HP Part Number is 98615-90606)
- *MC68881 User's Manual*<sup>1</sup> (HP Part Number is 98615-90607)

---

<sup>1</sup> This manual is available through the Direct Marketing Division (DMK). To order this manual, call 1-800-538-8787.

---

## Individual Manual “Tours”

The following paragraphs describe the purpose and contents of each manual.

---

### Note

You are highly encouraged to pick up and leaf through each manual as you read through its description. This exercise will help you to quickly familiarize yourself with their content and organization.

---

### ***Installation Guide (for your model of computer)***

An installation manual is shipped with your computer (*not* with the Pascal System). It describes the tasks of setting up the computer and then attaching the keyboard and monitor. It also describes how you can verify that your computer is operating properly. However, the tasks of installing and verifying peripheral devices, such as disc drives and printers, is described in the following manual.

### ***Series 200/300 Peripheral Installation Guide***

This manual describes the tasks of configuring and installing peripherals that you can use with your Series 200/300 computer. Here are some peripherals included:

- Memory and interface cards
- Discs
- Printers
- Plotters and other graphics devices

The manual also covers the task of configuring the Pascal system software to “talk to” these devices (i.e. adding device drivers).

---

# Pascal 3.2 User's Guide

## (HP Part Number 98615-90042)

This guide begins where the *Peripheral Installation Guide* left off. It describes how to load the Pascal System and get it “up and running.” It also takes you on a tour of the system and its subsystems, as well as shows you how to enter and run a short Pascal program. This manual is also a task-oriented manual.

- Chapter 1: “Vital Information” discusses a “little-known secret to success.” (If you don’t read the chapter, it will still be “little-known.”)
- Chapter 2: “Loading Pascal” shows you how to load the Pascal system.
- Chapter 3: “A Few Preliminaries” shows you how to prepare blank discs for use and how to make back-up copies of the system discs.
- Chapter 4: “Using Keyboard and Display” describes using the keyboard and display. You need only read the section that describes your computer’s keyboard.
- Chapter 5: “The Main Command Level” shows you how to begin using commands.
- Chapter 6: “The Editor” introduces you to the task of entering text using the Pascal Editor.
- Chapter 7: “The Filer” introduces you to the tasks of managing and storing files using the Pascal Filer.
- Chapter 8: “The Compiler” describes using the Compiler, which you will be using to transform a source program into a form that the computer can execute.
- Chapter 9: “Other Subsystems” briefly discusses the Assembler, Librarian, and Debugger subsystems.
- Chapter 10: “Setting Up Your Environment” is devoted to helping you set up your programming “environment.”
- In Chapter 11: “Program Development Section,” you will be entering, storing, compiling, and running a short Pascal program.
- The Task Reference briefly summarizes the steps for common procedures.
- There is also a subject index at the back of this manual.

---

# An Introduction to Programming and Problem Solving with Pascal

## (HP Part Number 09826-90072)

This is a textbook that will teach you the Pascal programming language. It is useful for those who have never programmed using the Pascal language. It is a combination of task-oriented information (such as discussions of how to solve particular programming problems) and object-oriented information (such as descriptions of reserved words and standard procedures).

- The STYLE CLINICS section lists the programming style tips given throughout the book.
- Chapter 1: “An Introduction to Computer Programming” describes the steps involved in developing programs in any computer language.
- Chapter 2: “Algorithms” takes a closer look at developing algorithms. A thorough understanding and *application* of these principles will help you to become a good programmer as quickly as possible. You should memorize and follow the maxim:

***“Think First, Code Later.”***

- Chapters 3 through 10 present advice and examples of Pascal programming. The titles for these chapters are as follows:
  - Chapter 3: “Basic Pascal Data Types and Declarations”
  - Chapter 4: “Elementary Pascal Programming”
  - Chapter 5: “The Flow of Control”
  - Chapter 6: “Running, Debugging, and Testing Programs”
  - Chapter 7: “Structured Data Types – Arrays”
  - Chapter 8: “Functions and Procedures”
  - Chapter 9: “More Structured Data Types – Records and Sets”
  - Chapter 10: “More Structured Data Types – Files and Pointers”
- Chapter 11: “Program Design Methods” presents a well organized summary of the “program design methods” that have been taught in the book.
- Appendices include the following: syntax diagrams, a list of standard identifiers, character sets, bibliography, selected answers to exercises, and subject index.

---

# Pascal 3.2 Workstation System, Volume 1: Main Command Level and Subsystems

## (HP Part Number 98615-90023)

This manual describes the HP Series 200/300 Pascal Workstation system. By reading it, you will learn how to use individual commands as well as how to use the subsystems (Editor, Filer, etc.). The chapters that describe the subsystems first take a task-oriented approach at introducing you to using the subsystem, and then provide an object-oriented discussion of each command at the end of the chapter.

- Chapter 1: “Manual Overview” contains an overview of the manual.
- Chapter 2: “The Main Command Level” provides a quick reference and detailed descriptions of Main Level commands.
- Chapter 3: “The File System” describes the File System of the Pascal Workstation System.
- Chapters 4 through 9 describe the subsystems of the Workstation system: Editor, Filer, Pascal Compiler, Assembler, Librarian, and Debugger. The first part of each chapter describes using the subsystem, while the latter part describes each command. Pay special attention to the concept of *modules*, because the system itself is composed of modules. An understanding of these structures will greatly increase your ability to use the system to its fullest extent.

The titles for Chapters 4 through 9 are as follows:

- Chapter 4: “The Editor”
  - Chapter 5: “The Filer”
  - Chapter 6: “Pascal Compiler”
  - Chapter 7: “The Assembler”
  - Chapter 8: “The Librarian”
  - Chapter 9: “The Debugger”
- A list of errors and subject index are also included at the end of this manual.

---

# Pascal 3.2 Workstation System, Volume 2: Programming and Configuration Topics

## (HP Part Number 98615-90023)

This manual describes using the Workstation-specific language features of this system. For instance, it describes programming with features of HP Pascal that are not contained in the “standard” Pascal language of most other computers. Some chapters also provide some handy techniques for making common computations with “standard” Pascal features. The last two chapters provide more task-oriented discussions of standard and special configurations and “non-disc” mass storage devices. Here are the chapters and topics therein:

- Chapter 10: “Overview of Workstation Software Features” provides an overview of the Pascal language and software libraries provided with this system. It shows that the language consists of the “ANSI/ISO Pascal” standard, *plus* several additional enhancements.
- Chapters 11 through 17 describe using Workstation extensions of standard Pascal features. The titles for these chapters are as follows:
  - Chapter 11: “Data Structures”
  - Chapter 12: “Program Flow”
  - Chapter 13: “Numeric Computation”
  - Chapter 14: “String Manipulation”
  - Chapter 15: “Programming with Files”
  - Chapter 16: “Dynamic Variables and Heap Management”
  - Chapter 17: “Error Trapping and Simulation”
- Chapter 18: “Special Configurations” first describes how the system boots itself and then describes how you can alter this “standard” configuration.

- Chapter 19: “Non-Disc Mass Storage” describes using “non-disc” mass storage devices: EPROM and Magnetic Bubble Memory cards, and cartridge tape drives.
- Chapter 20: “Backup Utilities” describes how to “port” programs written for Series 200 computers to Series 300 computers. It first describes the hardware differences between Series 300 and 200 machines, and then discusses several considerations to make when determining how to port a particular program.
- Chapter 21: “HFS Setup and Utilities” describes how to install and maintain the HFS file system on a hard disc.
  
- Chapter 22: “Porting to Series 300” explains how to make Pascal programs written for Series 200 computers run on Series 300 computers.
- Appendices discuss these topics: System History, file interchange between Series 200/300 BASIC and Pascal language systems, physical and software memory maps, command summaries, glossary, error messages, and subject index.

---

# Pascal 3.2 Procedure Library

## (HP Part Number 98615-90032)

This manual describes the library of procedures and functions provided with the Workstation Pascal System. It begins with an overview of modules and the mechanics of using them. The I/O Procedure Library is then covered in detail using a task-oriented approach. Several general and specific examples are provided. The last section of the book provides an object-oriented discussion of each procedure and function in the Procedure Library.

- Chapter 1: “Overview” provides an overview of using the procedures and functions provided in the Procedure Library. You **must** read this chapter (or be familiar with the concepts) if you want to painlessly use the rest of the manual.
- Chapters 2 through 9 describe general I/O programming techniques. The chapter titles are as follows:
  - Chapter 2: “Interfacing Concepts”
  - Chapter 3: “The I/O Procedure Library”
  - Chapter 4: “Directing Data Flow”
  - Chapter 5: “Outputting Data”
  - Chapter 6: “Inputting Data”
  - Chapter 7: “Registers”
  - Chapter 8: “Errors and Timeouts”
  - Chapter 9: “Advanced Transfer Techniques”
- Chapters 10 through 13 describe specific techniques for using the HP-IB, Datacomm, Serial, and GPIO interfaces. The chapter titles are as follows:
  - Chapter 10: “HP-IB Interface”
  - Chapter 11: “Datacomm Interface”
  - Chapter 12: “RS-232 Serial Interface”
  - Chapter 13: “GPIO Interface”

- Chapter 14: “System Devices” is an *advanced* programmer’s tutorial on using the “system devices” such as the beeper, softkeys, clock, timers, and other built-in hardware features.
- Chapter 15: “Segmentation Procedures” is also an *advanced* programmer’s tutorial on how to segment large programs into smaller ones at run time (to decrease memory requirements).
- The Procedure Library Reference section describes individual procedures and functions provided by the Procedure Library.
- There is also a glossary and subject index at the end of the manual.

---

## Pascal 3.2 Graphics Techniques

### (HP Part Number 98615-90037)

This manual describes graphics concepts and then graphics programming techniques. It is mostly a task-oriented manual, although it does contain a concept-oriented Graphics Procedures Reference appendix which describes the procedures and functions provided by the GRAPHICS modules.

- Chapter 1: “Introduction to Graphics” describes some fundamental graphics concepts and programming techniques.
- Chapter 2: “Miscellaneous Graphics Concepts” continues with additional concepts and techniques.
- Chapter 3: “External Graphics Displays and Plotters” describes color graphics and interactive graphics programming techniques.
- Chapter 4: “Interactive Graphics” explains how to design an interactive graphics interface for communicating with the computer.
- Chapter 5: “Color Graphics” provides a detailed explanation of color graphics as used with the Device independent Graphics Library (DGL). Some of the topics covered are:
  - The DGL Color System
  - Models for Color Specification
  - Color Spaces
  - Frame Buffers
  - Series 200/300 Color Graphics System
  - Resolution and Color Models
  - Writing Modes and Color
  - Effective Use of Color
  - Reproducing Color Graphics
- Appendix A provides several program listings.

- Appendix B provides descriptions of GRAPHICS procedures and functions provided in the Procedure Library (these descriptions are *exact* copies of descriptions found in the Reference section of the *Pascal Procedure Library* manual).
- This manual also has a subject index.

---

# HP Pascal Language Reference

## (HP Part Number 98615-90052)

This manual describes HP Pascal reserved words, standard identifiers, procedures, functions, and terms. It is entirely a concept-oriented manual.

- The Keyword Dictionary section describes these topics: manual organization; symbols, identifiers, reserved words, operators, statements, procedures, and other features of the HP Standard Pascal language.
- The HP-UX Implementation section describes the specific features of the Series 200/300 HP-UX Pascal Compiler (which is irrelevant *unless* you also have a Series 200/300 HP-UX system).
- The Workstation Implementation section describes these specific features of the Series 200/300 Pascal Workstation System: Compiler options, implementation restrictions, UCSD Pascal extensions, Series 200 system programming extensions, Series 200/300 Pascal Workstation File System, heap management, and error messages.

---

# MC68000 User's Manual

## (HP Part Number 09826-90073)

This manual describes the hardware operation, assembly language<sup>1</sup>, and machine language of the Motorola MC68000 and MC68010 microprocessors. (Note that only 68000 and 68010 processors, not 68008 processors, are used in Series 200 machines; MC68010 and MC68020 are used in Series 300 computers.) You will only need to read it if you are going to be programming in assembly language. It is mostly a concept-oriented manual.

- Section 1 describes MC68000 and MC68010 hardware architecture.
- Section 2 describes addressing modes and data organization.
- Section 3 details the instruction set.
- Section 4 describes how “exceptions” are processed.
- Appendix A discusses condition codes in detail.
- Appendix B provides an alphabetical reference of the Assembler language instructions, and Appendix C summarizes the format of these instructions.
- Appendices D, E, and F show how to determine the time required to execute instructions for different processors in the MC68000 family.
- Appendix G discusses the looping instructions available with the MC 68010 processor.

---

<sup>1</sup> Extensions to and deviations from this assembly language are described in the “Assembler” chapter in Volume 1 of the *Pascal Workstation System* manual.

---

## **MC68020 User's Manual**

**(HP Part Number 98615-90606)**

This manual contains hardware specifications and assembly language instruction syntax<sup>1</sup> for the MC68020 microprocessor.<sup>2</sup>

---

## **MC68881 User's Manual**

**(HP Part Number 98615-90607)**

This manual contains hardware specifications and assembly language instruction syntax<sup>1</sup> for the MC68881 floating-point math co-processor.<sup>2</sup>

---

<sup>1</sup> Extensions to and deviations from this assembly language are described in the "Assembler" chapter in Volume 1 of the *Pascal Workstation System* manual.

<sup>2</sup> This manual is not shipped with any Pascal systems. It must be order separately from the Direct Marketing Division (DMK). To order this manual, call 1-800-538-8787.

---

# The Master Index

The Master Index is a merger of the indexes in the individual manuals in this set. This section describes the notation used in the index.

## Referencing Scheme

Since the Master Index references more than one book, it must indicate which book the referenced subject exists in. Here is the notation used to specify where the subject is covered.

- UG:**    *Pascal 3.2 User's Guide*
- WS 1:**  *Pascal 3.2 Workstation System*  
          *Volume 1: Main Command Level and Subsystems*
- WS 2:**  *Pascal 3.2 Workstation System*  
          *Volume 2: Programming and Configuration Topics*
- PL:**    *Pascal 3.2 Procedure Library*
- GT:**    *Pascal 3.2 Graphics Techniques*

Here is a sample of index entries:

Access command (Filer) ..... **WS 1:** 126  
Access rights (SRM) ..... **WS 1:** 46,110, **WS 2:** 120  
Accuracy ..... **WS 2:** 34  
Active controller (HP-IB) ..... **PL:** 78,83

Note the following characteristics of this notation:

- An acronym that identifies the manual (such as **WS 1:** or **PL:**) *always* precedes all page numbers for a given topic.
- When a topic is found in more than one manual (such as the second example above), the list may contain several acronyms. In this case, the page numbers between the first and second acronyms are in the manual indicated by the first acronym; the pages between the second and third acronyms are in the manual indicated by the second acronym; and so forth.

## Manuals Not Referenced

Note that the following manuals are **not** referenced in the Master Index:

- *An Introduction to Programming and Problem Solving with Pascal*
- *HP Pascal Language Reference*
- *MC68000 User's Manual*
- *MC68020 User's Manual*
- *MC68881 User's Manual*

The Pascal programming text has its own index. The language reference does not need an index, since topics are listed in alphabetical order. The 68000, 68020, and 68881 manuals have no index.

# Master Index

---

## a

Abort (HP-IB) .....	<b>PL:</b> 10-10
Aborting prompts .....	<b>UG:</b> 45
Absolute addressing (of variables) .....	<b>WS 2:</b> 11-6
Absolute locator .....	<b>GT:</b> B-1, B-3, B-30, B-62, B-64, B-68, B-84, B-109
Acceleration, pen .....	<b>GT:</b> 3-6
Access command (Filer) .....	<b>WS 1:</b> 5-26
Access rights:	
HFS .....	<b>WS 1:</b> 5-8
SRM .....	<b>WS1:</b> 3-8, <b>WS 2:</b> 15-38
Active controller (HP-IB) .....	<b>PL:</b> 10-2, 10-7
Address (HP-IB) .....	<b>PL:</b> 10-7
Addressed to listen state (HP-IB) .....	<b>PL:</b> 10-13
Addressed to talk state (HP-IB) .....	<b>PL:</b> 10-13
Addresses (HP-IB) .....	<b>PL:</b> 10-2
Addresses:	
I/O .....	<b>WS 2:</b> B-18
Memory .....	<b>WS 2:</b> B-17
RAM .....	<b>WS 2:</b> B-17
ROM .....	<b>WS 2:</b> B-18
System .....	<b>WS 2:</b> B-20
Adjust command (Editor) .....	<b>WS 1:</b> 4-28
Advanced bus management (HP-IB) .....	<b>PL:</b> 10-18
ALIAS (Compiler option) .....	<b>WS 1:</b> 6-22
ALLOCATE module .....	<b>PL:</b> 1-17
ALLOW_PACKED (Compiler option) .....	<b>WS 1:</b> 6-23
ALPHA key .....	<b>UG:</b> 75, 89, 111
Alphabetical directory listing .....	<b>UG:</b> 149
Alternate DAMs .....	<b>WS 2:</b> 18-21, 18-64
Anisotropic scaling .....	<b>GT:</b> 1-10

---

**UG:** *Pascal 3.2 User's Guide*

**WS 1:** *Pascal 3.2 Workstation System, Volume 1*

**WS 2:** *Pascal 3.2 Workstation System, Volume 2*

**PL:** *Pascal 3.2 Procedure Library*

**GT:** *Pascal 3.2 Graphics Techniques*

ANSI (Compiler option) .....	<b>WS 1:6-24</b>
ANY C key .....	<b>UG: 102</b>
ANY CHAR key .....	<b>UG: 89</b>
ANYCHAR key .....	<b>UG: 74</b>
ANYPTR type .....	<b>WS 2:12-3</b>
ANYVAR type .....	<b>WS 2:12-2</b>
APPEND (files) .....	<b>WS 2: 15-23, 15-24, 15-33</b>
Arrow keys .....	<b>UG: 82, 96, 107</b>
Aspect ratio .....	<b>GT: 2-2, 4-13, 2-28</b>
Aspect Ratio, setting .....	<b>GT: 1-11</b>
Assembler pseudo ops:	
COM .....	<b>WS 1: 7-30</b>
DC .....	<b>WS 1: 7-31</b>
DECIMAL .....	<b>WS 1: 7-32</b>
DEF .....	<b>WS 1: 7-32</b>
DS .....	<b>WS 1: 7-32</b>
END .....	<b>WS 1: 7-33</b>
EQU .....	<b>WS 1: 7-33</b>
INCLUDE .....	<b>WS 1: 7-34</b>
LIST .....	<b>WS 1: 7-34</b>
LLEN .....	<b>WS 1: 7-34</b>
LMODE .....	<b>WS 1: 7-35</b>
LPRINT .....	<b>WS 1: 7-35</b>
MNAME .....	<b>WS 1: 7-35</b>
NOLIST .....	<b>WS 1: 7-35</b>
NOOBJ .....	<b>WS 1: 7-36</b>
NOSYMS .....	<b>WS 1: 7-36</b>
ORG .....	<b>WS 1: 7-36</b>
PAGE .....	<b>WS 1: 7-36</b>
REFA .....	<b>WS 1: 7-37</b>
REFR .....	<b>WS 1: 7-37</b>
RMODE .....	<b>WS 1: 7-38</b>
RORG .....	<b>WS 1: 7-38</b>
SMODE .....	<b>WS 1: 7-39</b>
SPC .....	<b>WS 1: 7-39</b>
SPRINT .....	<b>WS 1: 7-39</b>
SRC .....	<b>WS 1: 7-40</b>
START .....	<b>WS 1: 7-40</b>
TTL .....	<b>WS 1: 7-40</b>

Assembler subsystem .....	<b>UG: 169, 216, 275</b>
Assembler:	
Addressing modes .....	<b>WS 1: 7-26</b>
Declaring global variables .....	<b>WS 1: 7-9</b>
Declaring module name .....	<b>WS 1: 7-8</b>
DEF table .....	<b>WS 1: 7-7</b>
Error recovery .....	<b>WS 1: 7-13</b>
Errors .....	<b>WS 2: A-13</b>
Example modules .....	<b>WS 1: 7-41</b>
Exception coding .....	<b>WS 1: 7-15</b>
Expressions .....	<b>WS 1: 7-24</b>
EXT Table .....	<b>WS 1: 7-8</b>
EXTERNAL procedures .....	<b>WS 1: 7-16</b>
IMPORT text .....	<b>WS 1: 7-6</b>
Instruction format .....	<b>WS 1: 7-17</b>
Introduction .....	<b>WS 1: 7-1</b>
Invoking .....	<b>WS 1: 7-2</b>
Listing .....	<b>WS 1: 7-2</b>
Local variables .....	<b>WS 1: 7-11</b>
Module initialization .....	<b>WS 1: 7-13</b>
Modules .....	<b>WS 1: 7-5</b>
Object file .....	<b>WS 1: 7-3</b>
Opcode size suffix .....	<b>WS 1: 7-20</b>
Opcodes .....	<b>WS 1: 7-19</b>
Passing Parameters .....	<b>WS 1: 7-8</b>
Pseudo ops .....	<b>WS 1: 7-30</b>
Source file .....	<b>WS 1: 7-2</b>
Symbols .....	<b>WS 1: 7-22</b>
Use of the stack .....	<b>WS 1: 7-15</b>
Asterisk (system volume) .....	<b>UG: 118</b>
Asynchronous protocol (Datacomm) .....	<b>PL: 11-2, 11-13</b>
Attention line (HP-IB) .....	<b>PL: 10-15</b>
Attention message (HP-IB) .....	<b>PL: 10-4</b>
Attributes, color .....	<b>GT: 5-1</b>

---

**UG:** *Pascal 3.2 User's Guide*

**WS 1:** *Pascal 3.2 Workstation System, Volume 1*

**WS 2:** *Pascal 3.2 Workstation System, Volume 2*

**PL:** *Pascal 3.2 Procedure Library*

**GT:** *Pascal 3.2 Graphics Techniques*

Auto-Configuration:	
Introduction .....	WS 2: 18-1
Process .....	WS 2: 18-7
Standard .....	WS 2: 18-7
TABLE program .....	WS 2: 18-6
Verifying modifications .....	WS 2: 18-68
Auto-dialing (Datacomm) .....	PL: 11-20
Auto-poll (Datacomm) .....	PL: 11-25
AUTOKEYS files .....	WS 2: 18-6, 18-37
AUTOSTART files .....	WS 2: 18-6, 18-37
Autostart files:	
Booting with .....	UG: 189
Changing .....	UG: 209
Confirming .....	UG: 190
Creating .....	UG: 184, 243
Description of .....	UG: 184
Modifying for Winchester disc .....	UG: 187
Storing .....	UG: 188
Auxiliary command register (HP-IB) .....	PL: 10-33
Available global space .....	UG: 122
AWAIT_LOCATOR procedure .....	GT: 4-9, B-1, B-3
Axes .....	GT: 1-20, 2-30
Axes, labelling .....	GT: 1-25
Axes, logarithmic .....	GT: 2-32
AxesGrid program .....	GT: 2-30, A-2

## b

BACK SPACE key .....	UG: 96, 107
Background value .....	GT: 5-24
Backing up a program .....	UG: 205
Backing up the Pascal system .....	UG: 51, 234, 333
Backing up volumes .....	WS 1: 5-12
Backplane .....	PL: 2-2
Backspace key .....	UG: 82
BACKUP:	
Full .....	WS 2: 20-3
Incremental .....	WS 2: 20-4
Limitations .....	WS 2: 20-8
Restore .....	WS 2: 20-5

Table-of-Contents .....	<b>WS 2: 20-7</b>
Utility .....	<b>WS 2: 20-2</b>
Verification .....	<b>WS 2: 20-10</b>
Bad sector command (Filer) .....	<b>WS 1: 5-29</b>
BAR_KNOB program .....	<b>GT: 4-1, 4-4, A-9</b>
BAR_KNOB2 program .....	<b>GT: A-12</b>
Battery features (System devices) .....	<b>PL: 14-75</b>
Baud rate (Datacomm) .....	<b>PL: 11-7, 11-14</b>
Baud rate (Serial) .....	<b>PL: 12-3, 12-6</b>
Beeper (System devices) .....	<b>PL: 14-9</b>
Bit .....	<b>PL: 2-7</b>
Block size (Datacomm) .....	<b>PL: 11-19</b>
Blocked and Unblocked Units .....	<b>WS 1: 3-3</b>
Blocked devices .....	<b>WS 2: 18-9</b>
Bold labels .....	<b>GT: 1-19</b>
Boot files (Renaming) .....	<b>WS 2: 18-35</b>
Boot ROM .....	<b>WS 2: 18-3</b>
Boot volume .....	<b>UG: 18, 20</b>
Boot volume (defined) .....	<b>WS 2: 18-5</b>
Boot-time errors .....	<b>WS 2: A-2</b>
Booting from EPROM .....	<b>WS 2: 19-20</b>
Booting process .....	<b>WS 2: 18-3</b>
Booting the Pascal system .....	<b>GT: 1-7</b>
Booting:	
From flexible disc .....	<b>UG: 18, 213</b>
From Winchester (hard) disc .....	<b>UG: 177</b>
Problems .....	<b>UG: 20</b>
Break key .....	<b>UG: 80</b>
Break messages (Serial) .....	<b>PL: 12-11</b>
Break timing (Datacomm) .....	<b>PL: 11-17</b>
Breakpoints (Debugger) .....	<b>WS 1: 9-13</b>
BRSTUFF module (CTABLE) .....	<b>WS 2: 18-62</b>
Bubble memory .....	<b>UG: 46</b>

---

**UG:** *Pascal 3.2 User's Guide*

**WS 1:** *Pascal 3.2 Workstation System, Volume 1*

**WS 2:** *Pascal 3.2 Workstation System, Volume 2*

**PL:** *Pascal 3.2 Procedure Library*

**GT:** *Pascal 3.2 Graphics Techniques*

Bubble memory:	
Configuration .....	<b>WS 2:</b> 19-3
Driver module .....	<b>WS 2:</b> 19-5
Error correction .....	<b>WS 2:</b> 19-10
File System access of .....	<b>WS 2:</b> 19-10
Hardware device .....	<b>WS 2:</b> 19-11
Initializing .....	<b>WS 2:</b> 19-11
Interrupts .....	<b>WS 2:</b> 19-11
Introduction .....	<b>WS 2:</b> 19-1
Using .....	<b>WS 2:</b> 19-3, 18-19
Buffer, editing .....	<b>UG:</b> 135
Buffer, type ahead .....	<b>UG:</b> 87
Buffer, type-ahead .....	<b>UG:</b> 100, 112
Buffer:	
type-ahead .....	<b>UG:</b> 63
Buffers:	
BUF_INFO_TYPE .....	<b>PL:</b> 9-1
Control of .....	<b>PL:</b> 9-2
END condition transfers .....	<b>PL:</b> 9-8
Feeding of .....	<b>PL:</b> 9-3
General .....	<b>PL:</b> 9-1
Match character transfers .....	<b>PL:</b> 9-8
Overlap transfers .....	<b>PL:</b> 9-6
Reading data from .....	<b>PL:</b> 9-2
Serial transfers .....	<b>PL:</b> 9-4
Special transfers .....	<b>PL:</b> 9-8
Terminating transfers .....	<b>PL:</b> 9-6
Word transfers .....	<b>PL:</b> 9-8
Writing data to .....	<b>PL:</b> 9-3
BUF_INFO_TYPE .....	<b>PL:</b> 9-1
Bus .....	<b>PL:</b> 2-2
Bus address .....	<b>PL:</b> 4-2
Bus line states (HP-IB) .....	<b>PL:</b> 10-16
Bus sequences (HP-IB) .....	<b>PL:</b> 10-5
Byte .....	<b>PL:</b> 2-7

## C

C I/O key .....	UG: 107
Cable options (Datacomm) .....	PL: 11-27
Cable options (Serial) .....	PL: 12-23
CALL .....	WS 2: 12-4
CALLABS (Compiler option) .....	WS 1: 6-25
CAPS key .....	UG: 108
Caps key .....	UG: 83
CAPS LOCK key .....	UG: 97
CARD_ID .....	PL: 3-7, 3-8, 3-9
CARD_TYPE .....	PL: 3-7, 3-8, 3-9
Cartesian coordinates .....	GT: 1-6
Cartridge tape drives .....	WS 2: 19-35
Cell, character .....	GT: 2-11
Centering labels .....	GT: 1-17
Change command .....	UG: 152, 259, 260
Change command (Filer) .....	WS 1: 5-18, 5-30
Changing memory contents (Debugger) .....	WS 1: 9-22
Chapter previews .....	WS 1: 1-2, 1-4
Character cell .....	GT: 2-11
Character format (Datacomm) .....	PL: 11-17
Character format (Serial) .....	PL: 12-2, 12-4, 12-7
Character length (Datacomm) .....	PL: 11-7
Character set, Roman 8 .....	UG: 84
Character sets .....	WS 2: C-1
Character size, setting .....	GT: 2-13, 1-16
Characters (internal representation of) .....	PL: 2-9
CharCell program .....	GT: 2-11, A-17
CHARSIZE procedure .....	GT: 2-14, 2-18
Choosing the graphics display device .....	GT: 1-6
Clear (HP-IB) .....	PL: 10-10
Clear line key .....	UG: 86
CLEAR_DISPLAY procedure .....	GT: B-10, 2-23

---

**UG:** *Pascal 3.2 User's Guide*

**WS 1:** *Pascal 3.2 Workstation System, Volume 1*

**WS 2:** *Pascal 3.2 Workstation System, Volume 2*

**PL:** *Pascal 3.2 Procedure Library*

**GT:** *Pascal 3.2 Graphics Techniques*

Clearing workfiles .....	<b>UG:</b> 250
CLIPDRAW procedure .....	<b>GT:</b> 1-25, 2-30, 1-32
Clipping lines .....	<b>GT:</b> 1-23
Clock .....	<b>WS 2:</b> 22-4
Clock, setting the .....	<b>UG:</b> 26, 214
Clock (System devices) .....	<b>PL:</b> 14-11
CLOSE (files) .....	<b>WS 2:</b> 15-24
Closed loop system .....	<b>GT:</b> 4-1
CLR I/O key .....	<b>UG:</b> 95
CLR L key .....	<b>UG:</b> 109
CLR LN key .....	<b>UG:</b> 99
Coalescing hard-disc volumes .....	<b>WS 2:</b> 18-14, 18-26
CODE (Compiler option) .....	<b>WS 1:</b> 6-26
Code file specification .....	<b>WS 1:</b> 9-6
CODE files .....	<b>UG:</b> 115, 164
CODE_OFFSETS (Compiler option) .....	<b>WS 1:</b> 6-27
Colon (default volume) .....	<b>UG:</b> 118
Color displays, external .....	<b>GT:</b> 3-4
COLOR program .....	<b>GT:</b> 5-9, A-18
Color:	
Additional colors .....	<b>GT:</b> 5-20, 5-24, 5-25
Business .....	<b>GT:</b> 5-2
CMY Color Cube .....	<b>GT:</b> 5-13
Dithered colors .....	<b>GT:</b> 5-21, 5-24
Effective use of .....	<b>GT:</b> 5-36
Gamuts .....	<b>GT:</b> 5-40
Graphics .....	<b>GT:</b> 5-1
Hardcopy .....	<b>GT:</b> 5-40
HSL Color Cylinder .....	<b>GT:</b> 5-14
HSL model .....	<b>GT:</b> 5-5, 5-9
Hue .....	<b>GT:</b> 5-5
Luminosity .....	<b>GT:</b> 5-5
Map .....	<b>GT:</b> 5-25
Mixing .....	<b>GT:</b> 5-37
Model resolution .....	<b>GT:</b> 5-29
Models .....	<b>GT:</b> 5-4, 5-9
Objective use of .....	<b>GT:</b> 5-38
Primary .....	<b>GT:</b> 5-2
References .....	<b>GT:</b> 5-42
RGB Color Cube .....	<b>GT:</b> 5-12
RGB model .....	<b>GT:</b> 5-4, 5-9

Saturation .....	<b>GT: 5-5</b>
Seeing .....	<b>GT: 5-36</b>
Spaces .....	<b>GT: 5-11</b>
Subjective use of .....	<b>GT: 5-38</b>
Table .....	<b>GT: 5-2</b>
Vector .....	<b>GT: 5-21</b>
Command Interpreter .....	<b>WS 2: 18-6</b>
Command lines .....	<b>UG: 40, 61</b>
Command reference:	
Debugger .....	<b>WS 1: 9-34</b>
Librarian .....	<b>WS 1: 8-24</b>
Command summary:	
Debugger .....	<b>WS 1: 9-31, WS 2: D-8</b>
Editor .....	<b>WS 2: D-2</b>
Filer .....	<b>WS 2: D-4</b>
Librarian .....	<b>WS 2: D-6</b>
Main Command Level .....	<b>WS 2: D-1</b>
Commands table (HP-IB) .....	<b>PL: 10-20</b>
Commands:	
eXecute (Main level) .....	<b>WS 1: 2-5</b>
Exiting .....	<b>UG: 220</b>
Initialize (Main Level) .....	<b>WS 1: 2-6</b>
Invoking .....	<b>UG: 219</b>
Main Level .....	<b>WS 1: 2-3, 2-4</b>
Memory volume (Main Level) .....	<b>WS 1: 2-7</b>
New sysvol (Main Level) .....	<b>WS 1: 2-9</b>
Permanent (Main Level) .....	<b>WS 1: 2-10</b>
Run (Main Level) .....	<b>WS 1: 2-11</b>
Stream (Main Level) .....	<b>WS 1: 2-12</b>
Syntax diagram .....	<b>WS 1: 2-4</b>
User restart (Main Level) .....	<b>WS 1: 2-15</b>
Version (Main Level) .....	<b>WS 1: 2-16</b>
What (Main Level) .....	<b>WS 1: 2-18</b>
Compacting volume space .....	<b>UG: 156, 263</b>
Compatibility hardware .....	<b>WS 2: 22-10</b>

---

**UG:** *Pascal 3.2 User's Guide*

**WS 1:** *Pascal 3.2 Workstation System, Volume 1*

**WS 2:** *Pascal 3.2 Workstation System, Volume 2*

**PL:** *Pascal 3.2 Procedure Library*

**GT:** *Pascal 3.2 Graphics Techniques*

Compatibility (of interfaces) .....	<b>PL: 2-4</b>
Compile strategy (for modules) .....	<b>PL: 1-6</b>
Compiler errors .....	<b>WS 2: A-9</b>
Compiler intrinsics .....	<b>PL: 1-13</b>
Compiler option:	
ALIAS .....	<b>WS 1: 6-22</b>
ALLOW_PACKED .....	<b>WS 1: 6-23</b>
ANSI .....	<b>WS 1: 6-24</b>
CALLABS .....	<b>WS 1: 6-25</b>
CODE .....	<b>WS 1: 6-26</b>
CODE_OFFSETS .....	<b>WS 1: 6-27</b>
COPYRIGHT .....	<b>WS 1: 6-28</b>
DEBUG .....	<b>WS 1: 6-29</b>
DEBUG ON .....	<b>WS 1: 6-54</b>
DEF .....	<b>WS 1: 6-30</b>
FLOAT_HDW .....	<b>WS 1: 6-31</b>
General .....	<b>WS 1: 6-21</b>
HEAP_DISPOSE .....	<b>WS 1: 6-32</b>
IF .....	<b>WS 1: 6-33</b>
INCLUDE .....	<b>WS 1: 6-34</b>
IOCHECK .....	<b>WS 1: 6-35</b>
LINENUM .....	<b>WS 1: 6-36</b>
LINES .....	<b>WS 1: 6-37</b>
LIST .....	<b>WS 1: 6-38</b>
OVFLCHECK .....	<b>WS 1: 6-39</b>
PAGE .....	<b>WS 1: 6-40</b>
PAGEWIDTH .....	<b>WS 1: 6-41</b>
PARTIAL_EVAL .....	<b>WS 1: 6-42</b>
RANGE .....	<b>WS 1: 6-43</b>
REF .....	<b>WS 1: 6-44</b>
SAVE_CONST .....	<b>WS 1: 6-45</b>
SEARCH .....	<b>WS 1: 6-46</b>
SEARCH_SIZE .....	<b>WS 1: 6-47</b>
STACKCHECK .....	<b>WS 1: 6-48</b>
STACKCHECK_ON .....	<b>WS 1: 6-55</b>
SWITCH_STRPOS .....	<b>WS 1: 6-49</b>
SYSPROG .....	<b>WS 1: 6-50, WS 2: 17-1</b>
TABLES .....	<b>WS 1: 6-51</b>
UCSD .....	<b>WS 1: 6-52</b>
WARN .....	<b>WS 1: 6-53</b>

FLOAT_HDW .....	<b>PL: 1-15</b>
HEAP_DISPOSE .....	<b>PL: 1-13</b>
RANGE ON .....	<b>PL: 3-7</b>
SEARCH .....	<b>PL: 1-6</b>
SYSPROG .....	<b>PL: 8-2</b>
Compiler:	
Absolute address (of variables) .....	<b>WS 2: 11-6</b>
Absolute addressing (of variables) .....	<b>WS 2: 11-6</b>
ANYPTR type .....	<b>WS 2: 11-6</b>
CALL .....	<b>WS 2: 12-4</b>
Compiling workfiles .....	<b>UG: 166, 194</b>
Description of .....	<b>UG: 114, 161</b>
Entering .....	<b>UG: 162, 216, 264</b>
Error trapping and simulation .....	<b>WS 2: 17-1</b>
Errors .....	<b>WS 1: 6-19</b>
Function calls .....	<b>WS 1: 6-57</b>
Function results .....	<b>WS 1: 6-58</b>
Global variables .....	<b>WS 1: 6-55</b>
INCLUDE files .....	<b>WS 1: 6-18</b>
Introduction .....	<b>WS 1: 6-1</b>
Invoking .....	<b>WS 1: 6-3</b>
IOCHECK .....	<b>WS 2: 17-3</b>
IORESULT function .....	<b>WS 2: 17-2</b>
Listing .....	<b>WS 1: 6-5</b>
Memory requirements .....	<b>UG: 275</b>
Mixing DISPOSE and RELEASE .....	<b>WS 2: 16-4</b>
Modules .....	<b>WS 1: 6-7</b>
Output (CODE) files .....	<b>UG: 164, 264</b>
Parameter passing .....	<b>WS 1: 6-57</b>
Printer (program) listings .....	<b>UG: 163, 264</b>
Procedure calls .....	<b>WS 1: 6-55</b>
Relaxed typechecking .....	<b>WS 2: 12-2</b>
Running the program .....	<b>WS 1: 6-5</b>
SEARCH option .....	<b>WS 1: 6-14</b>
Separate module compilation .....	<b>WS 1: 6-13</b>

---

**UG:** *Pascal 3.2 User's Guide*

**WS 1:** *Pascal 3.2 Workstation System, Volume 1*

**WS 2:** *Pascal 3.2 Workstation System, Volume 2*

**PL:** *Pascal 3.2 Procedure Library*

**GT:** *Pascal 3.2 Graphics Techniques*

Compiler: (continued)	
Stack usage .....	<b>WS 1:6-54</b>
Static links .....	<b>WS 1:6-58</b>
Strategy for compiling modules .....	<b>WS 1:8-5</b>
UCSD options .....	<b>WS 1:6-52</b>
Using .....	<b>UG:163, 194, 197, 200, 203, 264</b>
Variable size .....	<b>WS 2:11-5</b>
Workfile .....	<b>WS 1:6-6</b>
Compiling a program .....	<b>UG:163, 264</b>
Compiling demonstration programs .....	<b>GT:1-4</b>
Compiling modules .....	<b>WS 1:8-5</b>
Compiling programs .....	<b>UG:197</b>
Complementing lines .....	<b>GT:2-23, 5-31</b>
Computer (block diagram) .....	<b>PL:2-2</b>
Computer resource .....	<b>PL:2-1</b>
CONFIG disc .....	<b>UG:66</b>
Configuration:	
Example of SRM .....	<b>WS 2:18-71</b>
Interfaces .....	<b>WS 2:18-16</b>
Modifying the standard .....	<b>WS 2:18-26</b>
Multi-disc SRM .....	<b>WS 2:18-82</b>
Verifying changes to .....	<b>WS 2:18-68</b>
CONSOLE volume .....	<b>UG:156</b>
CONT key .....	<b>UG:74, 102</b>
CONTINUE key .....	<b>UG:90</b>
Continuous degrees of freedom .....	<b>GT:4-7</b>
Control blocks (Datacomm) .....	<b>PL:11-4, 11-13, 11-18</b>
Control characters (System devices) .....	<b>PL:14-28</b>
Control value (DISPLAY_INIT) .....	<b>GT:1-7</b>
ControlWord variable .....	<b>GT:1-7</b>
Conversion between coordinate systems .....	<b>GT:2-8</b>
ConvertVirtualToWorld program .....	<b>GT:2-9</b>
ConvertWorldToVirtual program .....	<b>GT:2-10</b>
CONVERT_WTODMM procedure .....	<b>GT:B-11, 1-24</b>
CONVERT_WTOLMM procedure .....	<b>GT:B-12</b>
Coordinate systems, conversion between .....	<b>GT:2-8</b>
Coordinates:	
Cartesian .....	<b>GT:1-6</b>
Rectangular .....	<b>GT:1-6</b>
Virtual .....	<b>GT:1-13</b>
World .....	<b>GT:1-13, B-11, B-12</b>

Copy command .....	UG: 134
Copy command (Editor) .....	WS 1: 4-30
Copying discs .....	WS 1: 5-12
Copying files .....	UG: 151, 205, 251, WS 1: 5-15
Copying files (to SRM) .....	WS 2: 18-77
Copying Pascal system to hard disc .....	UG: 172, 236
Copying system files .....	WS 2: 18-34
Copying Volumes .....	UG: 254
COPYRIGHT (Compiler option) .....	WS 1: 6-28
Cpy command .....	UG: 134
Creating a file .....	UG: 129, 244
Creating an HFS directory .....	WS 1: 5-14
Creating an SRM directory .....	WS 1: 5-14
CRT drawing modes .....	GT: 2-23, 5-30
CRT, graphics .....	GT: 1-6
CRT highlight characters .....	WS 2: C-12
CRT information .....	PL: 14-30
CRT interface (select code 1) .....	PL: 4-1
CrtAddr variable .....	GT: 3-1, 1-7
Crunch command .....	UG: 154, 263
CS80 discs (configuration) .....	WS 2: 18-26
CsizeProg program .....	GT: A-25
CTABLE program:	
BRSTUFF module .....	WS 2: 18-62
Commentary .....	WS 2: 18-50
Compiling .....	WS 2: 18-68
CTR module .....	WS 2: 18-61
Device address vectors .....	WS 2: 18-53
Editing .....	WS 2: 18-67
Flexible disc units .....	WS 2: 18-52
Local printers .....	WS 2: 18-52
Modifying .....	WS 2: 18-49
Modifying for Bubble cards .....	WS 2: 19-8
OPTIONS module .....	WS 2: 18-51
Running .....	WS 2: 18-68

---

**UG:** *Pascal 3.2 User's Guide*

**WS 1:** *Pascal 3.2 Workstation System, Volume 1*

**WS 2:** *Pascal 3.2 Workstation System, Volume 2*

**PL:** *Pascal 3.2 Procedure Library*

**GT:** *Pascal 3.2 Graphics Techniques*

CTABLE program: (continued)	
SCANSTUFF module .....	<b>WS 2:</b> 18-62
Secondary DAMs .....	<b>WS 2:</b> 18-51
CTR module (CTABLE) .....	<b>WS 2:</b> 18-61
CTRL key .....	<b>UG:</b> 79, 93, 105
Cube, Color .....	<b>GT:</b> 5-12
Cursor .....	<b>UG:</b> 70
Cursor control (System devices) .....	<b>PL:</b> 14-32
Cursor tracking .....	<b>GT:</b> 4-1
Cursor wheel .....	<b>WS 1:</b> 4-8, 4-21
Customizing demo programs for your system .....	<b>GT:</b> 1-6
Cylinder, Color .....	<b>GT:</b> 5-14

## d

DAMs (Directory access methods) .....	<b>WS 1:</b> 2-7, <b>WS 2:</b> 18-23, 18-51
Data compatibility .....	<b>PL:</b> 2-4
Data flow, directing .....	<b>PL:</b> 4-1
Data input:	
Datacomm .....	<b>PL:</b> 11-4
General .....	<b>PL:</b> 6-1
GPIO .....	<b>PL:</b> 13-15
HP-IB .....	<b>PL:</b> 10-3
Serial .....	<b>PL:</b> 12-9
Data link connections (Datacomm) .....	<b>PL:</b> 11-20
Data link options (Datacomm) .....	<b>PL:</b> 11-17
Data link protocol (Datacomm) .....	<b>PL:</b> 11-3
Data messages (Datacomm) .....	<b>PL:</b> 11-6
Data messages (HP-IB) .....	<b>PL:</b> 10-5
Data output:	
Datacomm .....	<b>PL:</b> 11-4
General .....	<b>PL:</b> 5-1
GPIO .....	<b>PL:</b> 13-15
HP-IB .....	<b>PL:</b> 10-3
Serial .....	<b>PL:</b> 12-8
Data representations:	
Bits and bytes .....	<b>PL:</b> 2-7
Characters .....	<b>PL:</b> 2-9
GPIO .....	<b>PL:</b> 13-15
Numbers .....	<b>PL:</b> 2-8
Real numbers .....	<b>PL:</b> 2-11
Signed integers .....	<b>PL:</b> 2-9

Data types:	
ANYPTR .....	<b>WS 2:</b> 12-3
ANYVAR .....	<b>WS 2:</b> 12-2
I/O .....	<b>PL:</b> 3-6, 3-7, 3-8, 3-9, 3-10
Supported for input .....	<b>PL:</b> 6-1
Supported for output .....	<b>PL:</b> 5-1
Data-Cartridge tape drives .....	<b>WS 2:</b> 19-35
Data-driven plotting .....	<b>GT:</b> 2-39
Datacomm:	
Asynchronous .....	<b>PL:</b> 11-13
Asynchronous protocol .....	<b>PL:</b> 11-2
Auto-dialing .....	<b>PL:</b> 11-20
Auto-poll .....	<b>PL:</b> 11-25
Baud rate .....	<b>PL:</b> 11-7, 11-14
Block size .....	<b>PL:</b> 11-19
Break timing .....	<b>PL:</b> 11-17
Cable adapter options .....	<b>PL:</b> 11-27
Character format .....	<b>PL:</b> 11-17
Character length .....	<b>PL:</b> 11-7
Connecting to the line .....	<b>PL:</b> 11-19
Connection procedures .....	<b>PL:</b> 11-20
Control blocks .....	<b>PL:</b> 11-4, 11-13, 11-18
Data Communication Basics (98046-90005) .....	<b>PL:</b> 11-1
Data link connections .....	<b>PL:</b> 11-20
Data link options .....	<b>PL:</b> 11-17
Data link protocol .....	<b>PL:</b> 11-3
Data messages .....	<b>PL:</b> 11-6
DCE and DTE cable options .....	<b>PL:</b> 11-27
Defaults .....	<b>PL:</b> 11-11
Dialing procedures .....	<b>PL:</b> 11-20
Direct connection links .....	<b>PL:</b> 11-19
Driver/receiver circuits .....	<b>PL:</b> 11-28
End-of-line recognition .....	<b>PL:</b> 11-16
Errors and recovery .....	<b>PL:</b> 11-22
Establishing the connection .....	<b>PL:</b> 11-10

---

**UG:** *Pascal 3.2 User's Guide*  
**WS 1:** *Pascal 3.2 Workstation System, Volume 1*  
**WS 2:** *Pascal 3.2 Workstation System, Volume 2*  
**PL:** *Pascal 3.2 Procedure Library*  
**GT:** *Pascal 3.2 Graphics Techniques*

Datacomm: (continued)	
Example terminal emulator .....	<b>PL: 11-8</b>
Half-duplex .....	<b>PL: 11-26</b>
Handshake .....	<b>PL: 11-15, 11-18</b>
Handshake characters .....	<b>PL: 11-16</b>
Initiating connection .....	<b>PL: 11-21</b>
Introduction .....	<b>PL: 11-1</b>
IOSTATUS and IOCONTROL registers .....	<b>PL: 11-29</b>
Line timeouts .....	<b>PL: 11-14</b>
Non-data characters .....	<b>PL: 11-16</b>
Operating parameters .....	<b>PL: 11-10</b>
Overview of programming .....	<b>PL: 11-7</b>
Parity .....	<b>PL: 11-2, 11-7, 11-19</b>
Preventing data loss .....	<b>PL: 11-24</b>
Private links .....	<b>PL: 11-19</b>
Programming helps .....	<b>PL: 11-24</b>
Prompt recognition .....	<b>PL: 11-16</b>
Protocol .....	<b>PL: 11-2, 11-12</b>
Reset .....	<b>PL: 11-12</b>
RS-232C cable signals .....	<b>PL: 11-27</b>
Secondary channel .....	<b>PL: 11-26</b>
Start bit .....	<b>PL: 11-2</b>
Stop bits .....	<b>PL: 11-2, 11-7</b>
Telephone links .....	<b>PL: 11-19</b>
Terminal identification .....	<b>PL: 11-18</b>
Terminal prompt messages .....	<b>PL: 11-24</b>
Datapoint function .....	<b>GT: 1-6</b>
DataPoint program .....	<b>GT: A-26</b>
Date and time (System devices) .....	<b>PL: 14-11</b>
Date, setting system .....	<b>UG: 25, 214</b>
DCE and DTE cables (Datacomm) .....	<b>PL: 11-27</b>
DCE cable (Serial) .....	<b>PL: 12-24</b>
DEBUG (Compiler option) .....	<b>WS 1: 6-29</b>
DEBUG ON (Compiler option) .....	<b>WS 1: 9-2, 6-54</b>
Debugger commands:	
B .....	<b>WS 1: 9-36</b>
BA .....	<b>WS 1: 9-36</b>
BC .....	<b>WS 1: 9-37</b>
BD .....	<b>WS 1: 9-37</b>
BS .....	<b>WS 1: 9-38</b>
CALL .....	<b>WS 1: 9-39</b>

D	WS 1:9-40
DA	WS 1:9-42
DG	WS 1:9-42
EC	WS 1:9-43
ET	WS 1:9-43
ETC	WS 1:9-44
ETN	WS 1:9-44
FB	WS 1:9-45
FH	WS 1:9-45
FI	WS 1:9-45
FO	WS 1:9-45
FU	WS 1:9-45
G	WS 1:9-46
GF	WS 1:9-46
GT	WS 1:9-47
GTF	WS 1:9-47
IF, ELSE, END	WS 1:9-48
OL,OW,OB	WS 1:9-50
PN	WS 1:9-51
PX	WS 1:9-51
Q	WS 1:9-52
QE	WS 1:9-52
QS	WS 1:9-52
Register operations	WS 1:9-53
sb (system boot)	WS 1:9-55
Softkey commands	WS 1:9-54
T	WS 1:9-55
TD	WS 1:9-55
TQ	WS 1:9-56
TT	WS 1:9-56
WD	WS 1:9-57
WR	WS 1:9-57
WS	WS 1:9-57

---

**UG:** *Pascal 3.2 User's Guide*  
**WS 1:** *Pascal 3.2 Workstation System, Volume 1*  
**WS 2:** *Pascal 3.2 Workstation System, Volume 2*  
**PL:** *Pascal 3.2 Procedure Library*  
**GT:** *Pascal 3.2 Graphics Techniques*

Debugger subsystem .....	<b>UG: 170</b>
Debugger window (System devices) .....	<b>PL: 14-37</b>
Debugger:	
Breakpoint Table .....	<b>WS 1: 9-15</b>
Breakpoints .....	<b>WS 1: 9-13</b>
Changing memory contents .....	<b>WS 1: 9-22</b>
Clearing Breakpoints .....	<b>WS 1: 9-14</b>
Code file specification .....	<b>WS 1: 9-6</b>
Command reference .....	<b>WS 1: 9-34</b>
Command screen .....	<b>WS 1: 9-7</b>
Command summary .....	<b>WS 1: 9-31, WS 2: D-8</b>
DEBUG Compiler option .....	<b>WS 1: 9-2</b>
Default display formats .....	<b>WS 1: 9-12</b>
Display formats .....	<b>WS 1: 9-10</b>
Displaying data .....	<b>WS 1: 9-9</b>
Errors .....	<b>WS 2: A-14</b>
Examining consecutive memory .....	<b>WS 1: 9-20</b>
Examining variables .....	<b>WS 1: 9-18</b>
Example program .....	<b>WS 1: 9-2</b>
Exception trapping .....	<b>WS 1: 9-24</b>
Executing a number of statements .....	<b>WS 1: 9-16</b>
Expressions .....	<b>WS 1: 9-34</b>
Formats for structured variables .....	<b>WS 1: 9-21</b>
Generating Escapes .....	<b>WS 1: 9-25</b>
Input formats .....	<b>WS 1: 9-12</b>
Introduction .....	<b>WS 1: 9-1</b>
Invoking .....	<b>WS 1: 9-6</b>
Is it installed? .....	<b>WS 1: 9-5, 9-28</b>
Key notation .....	<b>WS 1: 9-5</b>
Keyboard .....	<b>WS 1: 9-27</b>
Loading .....	<b>WS 1: 9-1, 9-4</b>
Pause function .....	<b>WS 1: 9-16</b>
Prompt .....	<b>WS 1: 9-7</b>
Queue .....	<b>WS 1: 9-9</b>
Sample session .....	<b>WS 1: 9-2</b>
Screen dumps .....	<b>WS 1: 9-8</b>
Single-stepping .....	<b>WS 1: 9-7</b>
Slow program execution .....	<b>WS 1: 9-7</b>
Stack frame .....	<b>WS 1: 9-17</b>
Static and dynamic links .....	<b>WS 1: 9-23</b>
Tracing program flow .....	<b>WS 1: 9-17</b>

DEF (Compiler option) .....	<b>WS 1:</b> 6-30
DEF table .....	<b>WS 1:</b> 7-7, 8-27
DEF table command (Librarian) .....	<b>WS 1:</b> 8-19
Default display formats (Debugger) .....	<b>WS 1:</b> 9-12
Default values (in prompts) .....	<b>UG:</b> 45, 222
Default volume .....	<b>UG:</b> 120, 155, 183, <b>WS 1:</b> 2-18, 3-4, 5-3
Defaults:	
Datacomm .....	<b>PL:</b> 11-11
GPIO .....	<b>PL:</b> 13-3, 13-4
HP-IB .....	<b>PL:</b> 10-2
Serial .....	<b>PL:</b> 12-3, 12-4
Define Source .....	<b>WS 1:</b> 8-28
Defining a viewport .....	<b>GT:</b> 1-13
Degrees of freedom:	
Continuous .....	<b>GT:</b> 4-7
Non-separable .....	<b>GT:</b> 4-7
Number of .....	<b>GT:</b> 4-3
Quality of .....	<b>GT:</b> 4-3
Quantizable .....	<b>GT:</b> 4-8
Separability of .....	<b>GT:</b> 4-7
DEL C key .....	<b>UG:</b> 109
DEL CHR key .....	<b>UG:</b> 99
DEL key .....	<b>UG:</b> 86
DEL L key .....	<b>UG:</b> 108
DEL LN key .....	<b>UG:</b> 99
Delete char key .....	<b>UG:</b> 86
Delete command .....	<b>UG:</b> 131
Delete command (Editor) .....	<b>WS 1:</b> 4-32
Delete line key .....	<b>UG:</b> 86
Deleting a file .....	<b>UG:</b> 153, 256
Deleting files .....	<b>WS 1:</b> 5-19
Demonstration programs .....	<b>GT:</b> 1-4, 1-6
Dependency of modules (table) .....	<b>PL:</b> 1-20
Destination (of I/O operations) .....	<b>PL:</b> 2-2
Device address vectors (CTABLE) .....	<b>WS 2:</b> 18-53

---

**UG:** *Pascal 3.2 User's Guide*  
**WS 1:** *Pascal 3.2 Workstation System, Volume 1*  
**WS 2:** *Pascal 3.2 Workstation System, Volume 2*  
**PL:** *Pascal 3.2 Procedure Library*  
**GT:** *Pascal 3.2 Graphics Techniques*

Device classes (TABLE program) .....	<b>WS 2:</b> 18-9
Device drivers .....	<b>WS 2:</b> 18-38
Device priority (while booting) .....	<b>WS 2:</b> 18-10
Device selector (DISPLAY_INIT) .....	<b>GT:</b> 1-6
Device selectors:	
General .....	<b>PL:</b> 4-1, 4-2, 3-6
HP-IB .....	<b>PL:</b> 10-3
Device-driver modules .....	<b>WS 2:</b> 18-7
Device-independent Graphics (DGL) .....	<b>PL:</b> 1-16
DGLPRG disc .....	<b>GT:</b> 1-1
Dialing procedures (Datacomm) .....	<b>PL:</b> 11-20
Direct access files .....	<b>WS 2:</b> 15-27
Direct connection links (Datacomm) .....	<b>PL:</b> 11-19
Directing data flow .....	<b>PL:</b> 4-1
Direction, label .....	<b>GT:</b> 2-16
Direction of labels, setting .....	<b>GT:</b> 1-17
Directory access methods (DAMs) .....	<b>WS 1:</b> 2-7, 3-10, <b>WS 2:</b> 18-21
Directory path syntax .....	<b>WS 1:</b> 3-6
Directory:	
Description of .....	<b>UG:</b> 35
Listing alphabetically .....	<b>UG:</b> 149
Listing files in .....	<b>UG:</b> 148, 261
Disassembly of a module .....	<b>WS 1:</b> 7-43
Disc drives .....	<b>WS 1:</b> 3-2
Disc, flexible:	
Formatting .....	<b>UG:</b> 22, 28
Handling .....	<b>UG:</b> 10
Initialization .....	<b>UG:</b> 28, 223
Insertion .....	<b>UG:</b> 12
Removing .....	<b>UG:</b> 13
Disc interleave .....	<b>WS 2:</b> 15-40
Disc performance .....	<b>WS 2:</b> 18-18
Disc, Winchester (hard):	
Autostart file .....	<b>UG:</b> 187
Booting from .....	<b>UG:</b> 177
Copying Pascal system .....	<b>UG:</b> 172, 236
Formatting .....	<b>UG:</b> 28, 225
Initialization .....	<b>UG:</b> 28, 225
Disc:	
Unit number assignments .....	<b>UG:</b> 46, 229, 230
Write-protection .....	<b>UG:</b> 15

Discs (general) .....	<b>WS 1:</b> 3-1
Discs (system) .....	<b>WS 2:</b> 18-4
Display control characters (System devices) .....	<b>PL:</b> 14-28
Display design .....	<b>GT:</b> 5-37
Display formats (Debugger) .....	<b>WS 1:</b> 9-10
Display limits, setting .....	<b>GT:</b> 2-1
Display organization .....	<b>UG:</b> 61
DISPLAY_FINIT procedure .....	<b>GT:</b> B-13
Displaying data (with Debugger) .....	<b>WS 1:</b> 9-9
DISPLAY_INIT procedure .....	<b>GT:</b> 1-6, 3-1, 3-4, B-17
Displays, external color .....	<b>GT:</b> 3-4
Displays (Series 200/300) .....	<b>WS 2:</b> 22-2
Displays, turning on and off .....	<b>GT:</b> 2-7
DISPLAY_TERM procedure .....	<b>GT:</b> B-23
DISPOSE .....	<b>WS 2:</b> 16-3
DISPOSE (procedure) .....	<b>PL:</b> 1-13
Dithered colors .....	<b>GT:</b> 5-24
Dithering .....	<b>GT:</b> 2-43, 5-20, 5-26
Delete command .....	<b>UG:</b> 131
DMA card (configuration) .....	<b>WS 2:</b> 18-2
DMP A key .....	<b>UG:</b> 74
DMP G key .....	<b>UG:</b> 74
Document editing environment .....	<b>UG:</b> 137
Dollar sign wildcard .....	<b>UG:</b> 152, 175, 206, 251
Dominant lines, drawing .....	<b>GT:</b> 2-23, 5-31
Drawing lines .....	<b>GT:</b> 1-7
Drawing modes, CRT .....	<b>GT:</b> 2-23, 5-30
DrawMdPrg program .....	<b>GT:</b> 2-24, A-26
Drive numbers .....	<b>WS 1:</b> 3-3
Driver/receiver circuits (Datacomm) .....	<b>PL:</b> 11-28
DTE cable (Serial) .....	<b>PL:</b> 12-23
DUMP ALPHA key .....	<b>UG:</b> 90, 111
DUMP GRAPHICS key .....	<b>UG:</b> 90, 111
Dumping raster images .....	<b>GT:</b> 3-2
Duplicate command (Filer) .....	<b>WS 1:</b> 5-32

---

**UG:** *Pascal 3.2 User's Guide*  
**WS 1:** *Pascal 3.2 Workstation System, Volume 1*  
**WS 2:** *Pascal 3.2 Workstation System, Volume 2*  
**PL:** *Pascal 3.2 Procedure Library*  
**GT:** *Pascal 3.2 Graphics Techniques*

## e

Echoes .....	GT: B-5
Echoes:	
Built-in .....	GT: 4-9
Rubber .....	GT: 4-12
EDIT key .....	UG: 89
Editor command:	
Adjust .....	WS 1: 4-28
Copy .....	WS 1: 4-30
Delete .....	WS 1: 4-32
Equals (=) .....	WS 1: 4-34
Exchange .....	WS 1: 4-53
Find .....	WS 1: 4-35
Insert .....	WS 1: 4-37
Jump .....	WS 1: 4-40
Margin .....	WS 1: 4-41
Page .....	WS 1: 4-42
Quit .....	WS 1: 4-43
Replace .....	WS 1: 4-45
Set .....	WS 1: 4-48
Verify .....	WS 1: 4-52
Zap .....	WS 1: 4-55
Editor:	
Anchor .....	WS 1: 4-21
Backing up your file .....	WS 1: 4-20
Changing text .....	WS 1: 4-11
Command summary .....	WS 2: D-2
Confirming or aborting commands .....	WS 1: 4-7
Copying text from other files .....	WS 1: 4-6
Cpy command .....	UG: 134
Creating a text file .....	WS 1: 4-3
Creating text .....	WS 1: 4-4
Cursor .....	WS 1: 4-21
Deleting text .....	WS 1: 4-9
Description of .....	UG: 114, 127
Dlete command .....	UG: 131
Duplicating text .....	WS 1: 4-11
Editing characteristics .....	UG: 136
Entering .....	UG: 58, 127, 216
Entering the .....	WS 1: 4-2

Exiting .....	UG:59, 140
Exiting the Editor .....	WS 1: 4-19
File size .....	WS 1: 4-22
Finding text patterns .....	WS 1: 4-11
Formatting text .....	WS 1: 4-16
Insrt command .....	UG:129
Introduction .....	WS 1: 4-1
I/O errors .....	WS 1: 4-24
Margin command .....	UG:137
Margining text .....	WS 1: 4-16
Memory requirements .....	UG:275
Moving text .....	WS 1: 4-11
Moving the cursor .....	WS 1: 4-8
Quitting .....	UG:59
Recovering deleted text .....	WS 1: 4-11
Set environment command .....	UG:136
Setting the environment .....	WS 1: 4-19
Storing an edited file .....	UG:140, 192
Storing your file .....	WS 1: 4-5, 4-19
Stream files .....	WS 1: 4-24
Text file structure .....	WS 1: 4-23
Using workfiles .....	WS 1: 4-24
Window .....	WS 1: 4-21
Xchg command .....	UG:133
Electrical compatibility .....	PL: 2-4
END condition transfers .....	PL: 9-8
End or Identify (HP-IB) .....	PL: 10-15
End-of-line recognition (Datacomm) .....	PL: 11-16
ENTER key .....	UG: 91, 103
Enter key .....	UG: 78
Environment, programming .....	UG: 171
Environments, editing .....	UG: 137
EPROM card .....	UG: 46

---

**UG:** *Pascal 3.2 User's Guide*  
**WS 1:** *Pascal 3.2 Workstation System, Volume 1*  
**WS 2:** *Pascal 3.2 Workstation System, Volume 2*  
**PL:** *Pascal 3.2 Procedure Library*  
**GT:** *Pascal 3.2 Graphics Techniques*

## EPROM memory:

As the system volume .....	<b>WS 2:</b> 19-20
Blank check .....	<b>WS 2:</b> 19-27
Burn failure .....	<b>WS 2:</b> 19-29
Burn rate .....	<b>WS 2:</b> 19-25
Check failure .....	<b>WS 2:</b> 19-29
Configuration changes .....	<b>WS 2:</b> 19-13
Configuration modifications .....	<b>WS 2:</b> 19-32
Driver module .....	<b>WS 2:</b> 19-30
Driver modules .....	<b>WS 2:</b> 19-13
Empty sockets .....	<b>WS 2:</b> 19-26
File system access .....	<b>WS 2:</b> 19-34
Headers .....	<b>WS 2:</b> 19-20
Introduction .....	<b>WS 2:</b> 19-1
Memory addresses .....	<b>WS 2:</b> 19-17
Memory card installation .....	<b>WS 2:</b> 19-16
Overview of using .....	<b>WS 2:</b> 19-12
Programmer card installation .....	<b>WS 2:</b> 19-14
Programmer card select code .....	<b>WS 2:</b> 19-14, 19-25
Programming utility .....	<b>WS 2:</b> 19-19
Transfer utility .....	<b>WS 2:</b> 19-23
Transferring files .....	<b>WS 2:</b> 19-21
Transferring volumes .....	<b>WS 2:</b> 19-20, 19-28
Using .....	<b>WS 2:</b> 19-12, 18-19
Equal sign wildcard .....	<b>UG:</b> 175, 253
Equals (=) command (Editor) .....	<b>WS 1:</b> 4-34
Erasing lines .....	<b>GT:</b> 2-23, 5-31
<b>Errors:</b>	
Assembler .....	<b>WS 2:</b> A-13
Boot-time .....	<b>WS 2:</b> A-2
Booting .....	<b>UG:</b> 20
Compiler .....	<b>WS 2:</b> A-9
Debugger .....	<b>WS 2:</b> A-14
Graphics errors .....	<b>WS 2:</b> A-7
I/O library .....	<b>WS 2:</b> A-6
I/O system .....	<b>WS 2:</b> A-4
Loader/Segmenter .....	<b>WS 2:</b> A-8
Messages .....	<b>WS 2:</b> A-1
Recovery .....	<b>WS 1:</b> 7-13
Run-time .....	<b>UG:</b> 201, <b>WS 2:</b> A-3
Syntax .....	<b>UG:</b> 199, <b>WS 1:</b> 6-4

Trapping and simulation .....	<b>WS 2:</b> 17-1
Datacomm .....	<b>PL:</b> 11-22
General .....	<b>PL:</b> 8-1
I/O .....	<b>PL:</b> 8-3
I/O (table) .....	<b>PL:</b> 8-7
Segmentation .....	<b>PL:</b> 15-10
Serial (Serial) .....	<b>PL:</b> 12-9
ESC key .....	<b>UG:</b> 62, 79
ESCAPE .....	<b>PL:</b> 8-3
ESCAPECODE .....	<b>PL:</b> 8-3
Establishing the connection (Datacomm) .....	<b>PL:</b> 11-10
Events (errors and timeouts) .....	<b>PL:</b> 8-1
Examining consecutive memory (Debugger) .....	<b>WS 1:</b> 9-20
Examining variables (Debugger) .....	<b>WS 1:</b> 9-18
Example modules .....	<b>PL:</b> 1-3
Example terminal emulator (Datacomm) .....	<b>PL:</b> 11-8
Exception coding .....	<b>WS 1:</b> 7-15
Exception trapping (Debugger) .....	<b>WS 1:</b> 9-24
Exchange command .....	<b>UG:</b> 133
eXchange command (Editor) .....	<b>WS 1:</b> 4-53
EXEC key .....	<b>UG:</b> 104
eXecute command .....	<b>UG:</b> 28, 42, 115, 266
eXecute Command (Main Level) .....	<b>WS 1:</b> 2-5
EXECUTE key .....	<b>UG:</b> 92
Exiting .....	<b>UG:</b> 4
Exiting commands .....	<b>UG:</b> 220
Exiting subsystems .....	<b>UG:</b> 218
Explicit commands (HP-IB) .....	<b>PL:</b> 10-22
EXPORT .....	<b>WS 1:</b> 8-29
Expressions (Debugger) .....	<b>WS 1:</b> 9-34
EXT Table .....	<b>WS 1:</b> 7-8, 8-28
EXT table command (Librarian) .....	<b>WS 1:</b> 8-18
Extend char key .....	<b>UG:</b> 84
Extended character set .....	<b>UG:</b> 84

---

**UG:** *Pascal 3.2 User's Guide*  
**WS 1:** *Pascal 3.2 Workstation System, Volume 1*  
**WS 2:** *Pascal 3.2 Workstation System, Volume 2*  
**PL:** *Pascal 3.2 Procedure Library*  
**GT:** *Pascal 3.2 Graphics Techniques*

Extended directory command (Filer) .....	<b>WS 1:</b> 5-7, 5-34
Extensions (to Pascal) .....	<b>WS 2:</b> 10-10
External color displays .....	<b>GT:</b> 3-4
External plotter control .....	<b>GT:</b> 3-5
EXTERNAL procedures .....	<b>WS 1:</b> 7-16

## f

f1 through f8 keys .....	<b>UG:</b> 71
Failure of TABLE program .....	<b>WS 2:</b> 18-13
Fast drawing procedures .....	<b>GT:</b> 2-24
Feedback .....	<b>GT:</b> 4-1
FGRAPHICS modules .....	<b>PL:</b> 1-15
File directory .....	<b>WS 1:</b> 8-2
File specification .....	<b>WS 1:</b> 3-6
File system .....	<b>UG:</b> 35
File System (Introduction) .....	<b>WS 1:</b> 3-1
File types .....	<b>WS 1:</b> 3-13
File:	
Autostart files .....	<b>UG:</b> 184, 209
Changing a file name .....	<b>UG:</b> 152, 259, 260
CODE .....	<b>UG:</b> 164
Copying into Editor .....	<b>UG:</b> 134
Creation .....	<b>UG:</b> 128, 244
Data files .....	<b>UG:</b> 192
Deleting .....	<b>UG:</b> 153, 256
Description of .....	<b>UG:</b> 35
Location of .....	<b>UG:</b> 42, 227
Name .....	<b>UG:</b> 35, 42, 227
Printing .....	<b>UG:</b> 157, 267
Removing .....	<b>UG:</b> 153, 256
Specifying .....	<b>UG:</b> 42, 227
Storing .....	<b>UG:</b> 245, 249
Suffix suppression .....	<b>UG:</b> 115
Filecopy command .....	<b>UG:</b> 54, 151, 175, 206, 234, 236, 251
Filecopy command (Filer) .....	<b>WS 1:</b> 5-12, 5-15, 5-37
Filer:	
Access command .....	<b>WS 1:</b> 5-26
Bad sector command .....	<b>WS 1:</b> 5-29
Change command .....	<b>UG:</b> 152, 258, <b>WS 1:</b> 5-18, 5-30
Command summary .....	<b>WS 2:</b> D-4

Confirming or aborting commands .....	<b>WS 1:5-2</b>
Creating a directory (HFS) .....	<b>WS 1:5-14</b>
Creating a directory (SRM) .....	<b>WS 1:5-14</b>
Deleting files .....	<b>WS 1:5-19</b>
Description of .....	<b>UG:114, 143</b>
Duplicate command .....	<b>WS 1:5-32</b>
Duplicate_link .....	<b>WS 2:18-77</b>
Entering .....	<b>UG:60, 143, 216</b>
Entering the Filer .....	<b>WS 1:5-2</b>
Exiting .....	<b>UG:60, 160</b>
Extended directory command .....	<b>WS 1:5-7, 5-34</b>
Filecopy command ....	<b>UG:51, 151, 175, 206, 234, 236, 251, WS 1:5-12, 5-15, 5-37</b>
Get command .....	<b>WS 1:5-40, UG:146</b>
HFS access rights .....	<b>WS 1:5-8</b>
Hfs command .....	<b>WS 1:5-41</b>
Introduction .....	<b>WS 1:5-1</b>
Krunch command .....	<b>UG:154, 263, WS 1:5-44</b>
Ldir command .....	<b>UG:148, 261</b>
Leaving the Filer .....	<b>WS 1:5-20</b>
List-directory command .....	<b>WS 1:5-6, 5-46</b>
Make command .....	<b>WS 1:5-48</b>
Memory requirements .....	<b>UG:275</b>
New command .....	<b>UG:157, WS 1:5-50</b>
Prefix command .....	<b>WS 1:3-5, 5-51</b>
Prefix-vol command .....	<b>UG:155, 183</b>
Prompt .....	<b>WS 1:5-2</b>
Quit command .....	<b>WS 1:5-53</b>
Quitting .....	<b>UG:60</b>
Remove command .....	<b>UG:153, 256, WS 1:5-54</b>
Removing files .....	<b>WS 1:5-19</b>
Save command .....	<b>UG:147, WS 1:5-56</b>
SRM access rights .....	<b>WS 1:5-8</b>
Stream command .....	<b>WS 1:2-12</b>
Translate command .....	<b>UG:157, 267, WS 1:3-15, 5-10, 5-57</b>
Unit directory command .....	<b>WS 1:5-60</b>
Vols (Volumes) command .....	<b>UG:46, 48, 156, 262</b>

---

**UG:** *Pascal 3.2 User's Guide*  
**WS 1:** *Pascal 3.2 Workstation System, Volume 1*  
**WS 2:** *Pascal 3.2 Workstation System, Volume 2*  
**PL:** *Pascal 3.2 Procedure Library*  
**GT:** *Pascal 3.2 Graphics Techniques*

Filer: (continued)

Volume back-up .....	WS 1:5-12
Volumes command .....	WS 1:3-2, 5-61
What command .....	WS 1:5-62
What devices are accessible? .....	WS 1:5-3
Wildcards .....	WS 1:5-9
Workfile .....	WS 1:5-20
Zero command .....	UG:33, WS 1:5-63

Files:

APPEND .....	WS 2:15-23, 15-24, 15-33
Buffer Variable .....	WS 2:15-21
CLOSE .....	WS 2:15-24
Creating a text file .....	WS 1:4-3
Current component .....	WS 2:15-21
Debugging .....	WS 2:15-39
Declaring a TEXT file .....	WS 2:15-29
Deleting .....	WS 1:5-19
Disposing of .....	WS 2:15-24
F^ .....	WS 2:15-21
File buffer .....	WS 2:15-21
File modes .....	WS 2:15-21
File position .....	WS 2:15-21
File specification (syntax) .....	WS 1:5-24
File variable .....	WS 2:15-6
Formatted I/O .....	WS 2:15-32
General discussion .....	WS 1:3-5
GET .....	WS 2:15-26
HFS names .....	WS 1:3-12
HFS permissions .....	WS 2:15-39
Interchange between BASIC and Pascal .....	WS 2:B-16
LIF file names .....	WS 1:3-10
Lookahead mode .....	WS 2:15-22
MAXPOS .....	WS 2:15-29
Names to avoid .....	WS 1:3-9
Naming conventions .....	WS 1:3-6
Object (definition of) .....	WS 1:8-2
Object modules .....	WS 1:6-1
OPEN .....	WS 2:15-23, 15-24, 15-33
Opening existing .....	WS 2:15-24
Pascal operations .....	WS 2:15-19
POSITION .....	WS 2:15-29

Programming with .....	<b>WS 2:</b> 15-1
PUT .....	<b>WS 2:</b> 15-26
READ .....	<b>WS 2:</b> 15-25
Read mode .....	<b>WS 2:</b> 15-21
READDIR .....	<b>WS 2:</b> 15-27
Removing .....	<b>WS 1:</b> 5-19
Renaming .....	<b>WS 1:</b> 5-18
RESET .....	<b>WS 2:</b> 15-24, 15-33
REWRITE .....	<b>WS 2:</b> 15-5, 15-23, 15-25, 15-33
SEEK .....	<b>WS 2:</b> 15-28
Sequential operations .....	<b>WS 2:</b> 15-25
Size specification .....	<b>WS 1:</b> 3-12, <b>WS 2:</b> 15-20
Specification .....	<b>WS 1:</b> 3-6
SRM concurrent file access .....	<b>WS 1:</b> 3-24, <b>WS 2:</b> 15-36
SRM names .....	<b>WS 1:</b> 3-11
Stream files .....	<b>WS 1:</b> 2-12, 4-24
Structure of text files .....	<b>WS 1:</b> 4-23
Suffixes .....	<b>WS 1:</b> 3-13
Suppressing the suffix .....	<b>WS 1:</b> 3-15
Syntax of name .....	<b>WS 1:</b> 3-6
System .....	<b>WS 2:</b> 18-3, 18-5
Temporary .....	<b>WS 2:</b> 15-20
Text file representation .....	<b>WS 2:</b> 15-30
Textfile I/O .....	<b>WS 2:</b> 15-29
Translating between data types .....	<b>WS 1:</b> 3-15
Types .....	<b>WS 1:</b> 3-10, 3-13, <b>WS 2:</b> 15-4
Wildcards .....	<b>WS 1:</b> 5-9, 3-16
Workfile .....	<b>WS 1:</b> 4-24, 5-20, 6-6
WRITE .....	<b>WS 2:</b> 15-26
Write mode .....	<b>WS 2:</b> 15-22
WRITEDIR .....	<b>WS 2:</b> 15-28
WS1.0 file names .....	<b>WS 1:</b> 3-18
FillGraph program .....	<b>GT:</b> 2-46, A-30
Filling, polygon .....	<b>GT:</b> 2-43

---

**UG:** *Pascal 3.2 User's Guide*  
**WS 1:** *Pascal 3.2 Workstation System, Volume 1*  
**WS 2:** *Pascal 3.2 Workstation System, Volume 2*  
**PL:** *Pascal 3.2 Procedure Library*  
**GT:** *Pascal 3.2 Graphics Techniques*

Flexible disc:	
FillProg program	<b>GT: 2-44, A-29</b>
Find command (Editor)	<b>WS 1: 4-35</b>
Flags	<b>WS 1: 8-29</b>
Formatting	<b>UG: 28, 223</b>
Handling	<b>UG: 10</b>
Initialization	<b>UG: 28, 223</b>
Insertion	<b>UG: 12</b>
Removing	<b>UG: 13</b>
Selection	<b>UG: 41</b>
unit number assignments	<b>UG: 46, 229</b>
Write-protection	<b>UG: 15</b>
Flexible discs (CTABLE)	<b>WS 2: 18-52</b>
FLOAT_HDW (Compiler option)	<b>PL: 1-15, WS 1: 6-31</b>
Floating-point math card (HP 98635)	<b>PL: 1-15</b>
Floppy drives (in the Unit Table)	<b>WS 2: 18-10</b>
Force, pen	<b>GT: 3-6</b>
Formats for structured variables (Debugger)	<b>WS 1: 9-21</b>
Formatted input	<b>PL: 6-6</b>
Formatted I/O (files)	<b>WS 2: 15-32</b>
Formatted output	<b>PL: 5-6, 5-7</b>
Formatting option	<b>UG: 30, 224</b>
Formatting:	
Flexible discs	<b>UG: 28, 223</b>
Winchester (hard) discs	<b>UG: 28, 225</b>
Frame buffer	<b>GT: 5-17, 5-24, 5-32</b>
Frame, window	<b>GT: 2-5</b>
Free-field input	<b>PL: 6-2, 6-3, 6-4, 6-5</b>
Free-field output	<b>PL: 5-1, 5-2, 5-3, 5-4, 5-5, 5-6</b>
Freedom, degrees of	<b>GT: 4-4</b>
Full backup	<b>WS 2: 20-3</b>
Full-mode handshakes (GPIO)	<b>PL: 13-5</b>
Function calls	<b>WS 1: 6-58</b>
Function results	<b>WS 1: 6-58</b>

## g

Gamuts, color	<b>GT: 5-40</b>
General bus management (HP-IB)	<b>PL: 10-8</b>
GENERAL modules	<b>PL: 3-2, 3-5</b>
General Value or Address Record (GVR)	<b>WS 1: 8-30</b>
Generating Escapes (Debugger)	<b>WS 1: 9-25</b>

Get command	UG: 146
Get command (Filer)	WS 1: 5-40
GET (files)	WS 2: 15-26
GLOAD procedure	GT: 2-36
Global base	WS 1: 6-55
Global space	WS 1: 2-16
Global variables	WS 1: 2-10, 2-15, 6-55, 7-9
Glossary	WS 2: E-1
Glossary (Librarian)	WS 1: 8-27
Go to local (HP-IB)	PL: 10-9
GPIO interface (select code 12)	PL: 4-2, 2-6
GPIO:	
Configuration	PL: 13-3
Data input	PL: 13-15
Data output	PL: 13-15
Data representations	PL: 13-15
Description	PL: 13-2
Examples of I/O	PL: 13-16, 13-17
Full-mode handshakes	PL: 13-5
Handshake lines	PL: 13-4
Handshakes	PL: 13-3
Interface reset	PL: 13-14
Interrupt priority	PL: 13-3
Introduction	PL: 13-1
IOREAD_BYTE and IOWRITE_BYTE registers	PL: 13-21
IOSTATUS and IOCONTROL registers	PL: 13-20
Logic sense	PL: 13-3
Peripheral status line	PL: 13-4
Pulse-mode handshakes	PL: 13-7
Select code	PL: 13-3
Special purpose lines	PL: 13-18

---

**UG:** *Pascal 3.2 User's Guide*  
**WS 1:** *Pascal 3.2 Workstation System, Volume 1*  
**WS 2:** *Pascal 3.2 Workstation System, Volume 2*  
**PL:** *Pascal 3.2 Procedure Library*  
**GT:** *Pascal 3.2 Graphics Techniques*

GRAPH key .....	UG: 74
Graphics display device, selecting .....	GT: 1-6
Graphics dump .....	GT: 3-2
Graphics errors .....	WS 2: A-7
Graphics input and output .....	WS 2: 18-17
Graphics, interactive .....	GT: 4-1
GRAPHICS key .....	GT: 2-7, UG: 89
Graphics key .....	UG: 111
GRAPHICS Library, using .....	GT: 1-4
Graphics memory address .....	GT: 2-37
Graphics memory size .....	GT: 2-37
GRAPHICS modules .....	PL: 1-15
Graphics procedure quick reference .....	GT: B-1
Graphics programming .....	PL: 1-15
Graphics tablet .....	GT: 4-13
GRAPHICSERROR procedure .....	GT: B-24
GRAPHICS_INIT procedure .....	GT: 1-9, B-26
GRAPHICS_TERM procedure .....	GT: 1-9, B-27
GRID procedure .....	GT: 2-32
Grids .....	GT: 2-30
GSTORE procedure .....	GT: 2-36, 3-3
GstorProg program .....	GT: A-31
GTEXT procedure .....	GT: 1-15, 1-25, 1-32, 2-18, B-28

## h

Half-duplex (Datacomm) .....	PL: 11-26
Half-toning .....	GT: 5-20
Handling flexible discs .....	UG: 10
Handshake characters (Datacomm) .....	PL: 11-16
Handshake:	
Datacomm .....	PL: 11-15, 11-18
General .....	PL: 2-4
GPIO .....	PL: 13-3
HP-IB .....	PL: 10-5, 10-14
Serial .....	PL: 12-4, 12-12
Hard disc:	
Autostart file .....	UG: 187
Booting from .....	UG: 177
Copying Pascal system .....	UG: 172, 236
Formatting .....	UG: 28, 225
Initialization .....	UG: 28, 225

Partitioning .....	<b>WS 2:</b> 18-11, 18-14, 18-54
Unit number assignments .....	<b>UG:</b> 48, 230
Unit Numbers .....	<b>WS 2:</b> 18-10
Volumes .....	<b>WS 2:</b> 18-14, 18-26
Hardcopy, color .....	<b>GT:</b> 5-40
Hardware .....	<b>PL:</b> 2-1
Heap Management:	
DISPOSE .....	<b>WS 2:</b> 16-3
MARK .....	<b>WS 2:</b> 16-2
RELEASE .....	<b>WS 2:</b> 16-2
HEAP_DISPOSE (Compiler option) .....	<b>PL:</b> 1-13
HEAP_DISPOSE (compiler option) .....	<b>WS 1:</b> 6-32
Hfs command (Filer) .....	<b>WS 1:</b> 5-41
HFS:	
Access rights .....	<b>WS 1:</b> 5-8
Creating a directory .....	<b>WS 1:</b> 5-14
File names .....	<b>WS 1:</b> 3-18
File permissions .....	<b>WS 2:</b> 15-39
HFCK .....	<b>UG:</b> 326
HFCK utility .....	<b>WS 2:</b> 21-10
Initialization .....	<b>UG:</b> 306
Installing driver modules .....	<b>WS 2:</b> 18-23
Introduction .....	<b>WS 1:</b> 3-25
MKHFS .....	<b>UG:</b> 308
MKHFS utility .....	<b>WS 2:</b> 21-2
OSINSTALL utility .....	<b>WS 2:</b> 21-5
Overview .....	<b>WS 2:</b> 21-1
Setup .....	<b>WS 2:</b> 21-1
System volume .....	<b>WS 2:</b> 18-67
Unit number assignments .....	<b>UG:</b> 233
HFCK utility (HFS) .....	<b>WS 2:</b> 21-10
Hierarchical directories (HFS) .....	<b>WS 1:</b> 3-25
Hierarchical directories (SRM) .....	<b>WS 1:</b> 3-20
High-speed disc interface (configuration) .....	<b>WS 2:</b> 18-18
Highlight Characters .....	<b>WS 2:</b> C-12, C-13

---

**UG:** *Pascal 3.2 User's Guide*  
**WS 1:** *Pascal 3.2 Workstation System, Volume 1*  
**WS 2:** *Pascal 3.2 Workstation System, Volume 2*  
**PL:** *Pascal 3.2 Procedure Library*  
**GT:** *Pascal 3.2 Graphics Techniques*

Highlighting data curves .....	<b>GT:</b> 2-47
History of the system .....	<b>WS 2:</b> B-1
HP 98627A RGB interface .....	<b>GT:</b> 3-4
HP 98635 Floating-point math card .....	<b>PL:</b> 1-15
HP 98644 differences (Serial) .....	<b>PL:</b> 12-27
HP-HIL .....	<b>GT:</b> B-1
HP-HIL absolute locator .....	<b>GT:</b> B-3, B-30, B-62, B-64, B-68, B-84, B-109
HP-HIL devices .....	<b>UG:</b> 65
HP-HIL digitizing .....	<b>GT:</b> 4-1
HP-HIL port .....	<b>GT:</b> B-1
HP-HIL relative locator .....	<b>GT:</b> B-2, B-7, B-33, B-63, B-70, B-85, B-111
HP-HIL relative locator .....	<b>PL:</b> 14-18, 14-22, 14-47, 15-8
HP-IB address .....	<b>PL:</b> 4-2
HP-IB interface, built-in (select code 7) .....	<b>PL:</b> 4-1
HP-IB interface description .....	<b>PL:</b> 2-5
HP-IB interface, optional (select code 8) .....	<b>PL:</b> 4-2
HP-IB:	
Abort .....	<b>PL:</b> 10-10
Active controller .....	<b>PL:</b> 10-4, 10-7
Address of interface .....	<b>PL:</b> 10-2, 10-7
Addressed to listen state .....	<b>PL:</b> 10-13
Addressed to talk state .....	<b>PL:</b> 10-13
Addressing to listen .....	<b>PL:</b> 10-5, 10-6
Addressing to talk .....	<b>PL:</b> 10-5
Advanced bus management .....	<b>PL:</b> 10-18
Attention line .....	<b>PL:</b> 10-15
Attention message .....	<b>PL:</b> 10-4
Auxiliary command register .....	<b>PL:</b> 10-33
Bus line states .....	<b>PL:</b> 10-16
Clear .....	<b>PL:</b> 10-10
Commands (table) .....	<b>PL:</b> 10-20
Control thru Pascal .....	<b>PL:</b> 10-7
Data messages .....	<b>PL:</b> 10-5
Device selectors .....	<b>PL:</b> 10-3
End or Identify .....	<b>PL:</b> 10-15
Example bus sequences .....	<b>PL:</b> 10-5
Explicit commands .....	<b>PL:</b> 10-22
General bus management .....	<b>PL:</b> 10-8
General I/O operations .....	<b>PL:</b> 10-3
General rules .....	<b>PL:</b> 10-3
Go to local .....	<b>PL:</b> 10-9

Handshake .....	<b>PL: 10-5</b>
Handshake lines .....	<b>PL: 10-14</b>
Installation .....	<b>PL: 10-2</b>
Interface clear .....	<b>PL: 10-15</b>
Interface conditions .....	<b>PL: 10-13</b>
Introduction .....	<b>PL: 10-1</b>
IOCONTROL and IOSTATUS registers .....	<b>PL: 10-23</b>
IOREAD_BYTE and IOWRITE_BYTE registers .....	<b>PL: 10-27</b>
Listen and talk messages .....	<b>PL: 10-5</b>
Local lockout .....	<b>PL: 10-9</b>
Local lockout state .....	<b>PL: 10-13</b>
Messages .....	<b>PL: 10-18</b>
Multiple listeners .....	<b>PL: 10-6</b>
Non-active controller .....	<b>PL: 10-6</b>
Pass control .....	<b>PL: 10-11</b>
Polling .....	<b>PL: 10-11</b>
Remote enable .....	<b>PL: 10-15</b>
Remote message .....	<b>PL: 10-8</b>
Remote state .....	<b>PL: 10-13</b>
Secondary addresses .....	<b>PL: 10-8</b>
Send command .....	<b>PL: 10-22</b>
Service request .....	<b>PL: 10-16</b>
Service requested state .....	<b>PL: 10-13</b>
Status .....	<b>PL: 10-7</b>
Summary of bus sequences .....	<b>PL: 10-37</b>
System controller .....	<b>PL: 10-4, 10-7</b>
System controller jumper/switch .....	<b>PL: 10-2</b>
Triggering .....	<b>PL: 10-10</b>
Unlisten and untalk messages .....	<b>PL: 10-7</b>
HP98542 display .....	<b>GT: 5-18</b>
HP98543 display .....	<b>GT: 5-18</b>
HP98544 display .....	<b>GT: 5-18</b>
HP98545 display .....	<b>GT: 5-18</b>
HP98546A .....	<b>GT: 1-12</b>

---

**UG:** *Pascal 3.2 User's Guide*  
**WS 1:** *Pascal 3.2 Workstation System, Volume 1*  
**WS 2:** *Pascal 3.2 Workstation System, Volume 2*  
**PL:** *Pascal 3.2 Procedure Library*  
**GT:** *Pascal 3.2 Graphics Techniques*

HP98547A display .....	<b>GT: 5-18</b>
HP98549 display .....	<b>GT: 5-18</b>
HP98700 display .....	<b>GT: 5-18</b>
HPIB modules .....	<b>PL: 3-2, 3-5</b>
HPM module .....	<b>PL: 1-13</b>
HSL color model .....	<b>GT: 5-5, 5-9, 5-29</b>
Hue .....	<b>GT: 5-5</b>

## i

ID PROM .....	<b>WS 2: 22-7</b>
Identifying flexible disc drives .....	<b>UG: 46</b>
Identifying Winchester (hard) discs .....	<b>UG: 48</b>
IF (Compiler option) .....	<b>WS 1: 6-33</b>
Images, dumping .....	<b>GT: 3-2</b>
Images, storing and retrieving .....	<b>GT: 2-36</b>
IMPLEMENT .....	<b>WS 1: 8-30</b>
IMPORT .....	<b>WS 1: 8-30</b>
IMPORT text .....	<b>WS 1: 7-6</b>
IMPORT text command (Librarian) .....	<b>WS 1: 8-18</b>
INCLUDE (Compiler option) .....	<b>WS 1: 6-34</b>
INCLUDE files .....	<b>GT: 1-5, 1-7</b>
INCLUDE files (Compiler) .....	<b>WS 1: 6-18</b>
Incremental backup .....	<b>WS 2: 20-4</b>
Indicator:	
status .....	<b>UG: 63</b>
Initialization (I/O) .....	<b>PL: 3-3</b>
Initialization Library file .....	<b>WS 2: 18-4</b>
Initialize Command (Main Level) .....	<b>WS 1: 2-6</b>
Initializing discs .....	<b>WS 2: 18-27, 15-41</b>
Initializing modules .....	<b>WS 1: 7-13</b>
Initializing:	
Winchester (hard) discs .....	<b>UG: 28, 225, 306</b>
Flexible discs .....	<b>UG: 28, 223</b>
Initiating connection:	
Datacomm .....	<b>PL: 11-21</b>
Serial .....	<b>PL: 12-6</b>
INITLIB file:	
Adding modules for SRM .....	<b>WS 2: 18-79</b>
adding modules to .....	<b>WS 2: 18-38</b>
Introduction .....	<b>WS 2: 18-4</b>
Library .....	<b>WS 2: 18-7</b>

module descriptions	WS 2: 18-38
renaming	WS 2: 18-35
required order of modules	WS 2: 18-38
INITLIB modules	PL: 1-7
Input (defined)	PL: 2-2
Input device selection	GT: 4-4
Input formats (Debugger)	WS 1: 9-12
Input pixel	GT: B-2
Input:	
Characters	PL: 6-4
Formatted	PL: 6-6
Free-field	PL: 6-2, 6-3, 6-4, 6-5
Real numbers	PL: 6-2
Skipping data	PL: 6-5
Strings	PL: 6-3
Termination	PL: 6-2
Words	PL: 6-4
INPUT_ESC procedure	GT: B-1, B-30
INQ_COLOR_TABLE procedure	GT: B-34
INQ_PGN_TABLE procedure	GT: B-36
INQ_WS procedure	GT: 1-13, 2-2, 2-5, 2-19, B-38
INS C key	UG: 109
INS CHR key	UG: 99
INS L key	UG: 109
INS LN key	UG: 99
Insert char key	UG: 86
Insert command	UG: 129
Insert command (Editor)	WS 1: 4-37
Insert line key	UG: 86
Inserting flexible discs	UG: 12
Insrt command	UG: 129
Integer number range	WS 2: 13-1

---

**UG:** *Pascal 3.2 User's Guide*  
**WS 1:** *Pascal 3.2 Workstation System, Volume 1*  
**WS 2:** *Pascal 3.2 Workstation System, Volume 2*  
**PL:** *Pascal 3.2 Procedure Library*  
**GT:** *Pascal 3.2 Graphics Techniques*

Integers (internal representation of) .....	<b>PL: 2-9</b>
Interactive graphics .....	<b>GT: 4-1</b>
Interchange of files .....	<b>WS 2: B-16</b>
Interface clear (HP-IB) .....	<b>PL: 10-15</b>
Interface conditions (HP-IB) .....	<b>PL: 10-13</b>
INTERFACE modules .....	<b>PL: 1-14</b>
Interface reset:	
Datacomm .....	<b>PL: 11-12</b>
GPIO .....	<b>PL: 13-14</b>
HP-IB .....	<b>PL: 10-23</b>
Serial .....	<b>PL: 12-6</b>
Interface text .....	<b>PL: 1-14, WS 1: 7-5, 7-6</b>
Interface:	
Drivers .....	<b>WS 2: 18-40</b>
HP 98546 Display .....	<b>WS 2: 22-10</b>
HP 98620 DMA .....	<b>WS 2: 18-16</b>
HP 98622 GPIO .....	<b>WS 2: 18-16</b>
HP 98624 HP-IB .....	<b>WS 2: 18-16</b>
HP 98625 (configuration) .....	<b>WS 2: 18-2</b>
HP 98625 High-speed disc (HP-IB) .....	<b>WS 2: 18-16, 18-18</b>
HP 98626 RS-232 serial .....	<b>WS 2: 18-16</b>
HP 98627 Color output .....	<b>WS 2: 18-16</b>
HP 98628 Datacomm .....	<b>WS 2: 18-16</b>
HP 98629 SRM .....	<b>WS 2: 18-17</b>
HP 98630 Breadboard .....	<b>WS 2: 18-17</b>
HP 98635 Floating-point math .....	<b>WS 2: 18-17</b>
HP 98644 RS232 serial .....	<b>WS 2: 18-17</b>
HP-Human Interface Link (HP-HIL) .....	<b>WS 2: 18-43</b>
Additional functions .....	<b>PL: 2-4</b>
Datacomm .....	<b>PL: 11-1</b>
Functional diagram .....	<b>PL: 2-3</b>
GPIO .....	<b>PL: 2-6</b>
Interfaces:	
HP-IB .....	<b>PL: 2-5, 10-1</b>
Overview .....	<b>PL: 2-5</b>
Registers .....	<b>PL: 7-1</b>
Select codes .....	<b>PL: 3-6, 4-1</b>
Serial .....	<b>PL: 2-6</b>
Why needed? .....	<b>PL: 2-3</b>

Interfacing concepts .....	<b>PL: 2-1</b>
Interleave, discs .....	<b>WS 2: 15-40</b>
Interleave factor .....	<b>UG: 30, 224, 226</b>
Interrupt priority (GPIO) .....	<b>PL: 13-3</b>
Interrupt processing overview (System devices) .....	<b>PL: 14-5</b>
INT_LINE procedure .....	<b>GT: 2-24, B-45</b>
INT_MOVE procedure .....	<b>GT: 2-24, B-47</b>
INT_POLYGON procedure .....	<b>GT: B-49</b>
INT_POLYGON_DD procedure .....	<b>GT: B-52</b>
INT_POLYLINE procedure .....	<b>GT: B-56</b>
Invoking commands .....	<b>UG: 219</b>
IO data types .....	<b>PL: 3-6, 3-7, 3-8, 3-9, 3-10</b>
I/O (definition of) .....	<b>PL: 2-2</b>
I/O error handling .....	<b>PL: 8-3</b>
I/O errors .....	<b>PL: 8-1</b>
I/O events (errors and timeouts) .....	<b>PL: 8-1</b>
IO modules .....	<b>PL: 1-14</b>
I/O Procedure Library:	
GENERAL modules .....	<b>PL: 3-2, 3-4</b>
HPIB modules .....	<b>PL: 3-2, 3-5</b>
Initialization .....	<b>PL: 3-3</b>
Introduction .....	<b>PL: 3-1</b>
IODECLARATIONS module .....	<b>PL: 3-6</b>
Organization .....	<b>PL: 3-2</b>
SERIAL modules .....	<b>PL: 3-3, 3-6</b>
I/O terminology .....	<b>PL: 2-1</b>
I/O timeouts .....	<b>PL: 8-1, 8-5</b>
I/O:	
Addresses .....	<b>WS 2: B-18</b>
Library errors .....	<b>WS 2: A-6</b>
Memory map .....	<b>WS 2: B-18</b>
System errors .....	<b>WS 2: A-4</b>

---

**UG:** *Pascal 3.2 User's Guide*  
**WS 1:** *Pascal 3.2 Workstation System, Volume 1*  
**WS 2:** *Pascal 3.2 Workstation System, Volume 2*  
**PL:** *Pascal 3.2 Procedure Library*  
**GT:** *Pascal 3.2 Graphics Techniques*

IOCHECK (Compiler option) .....	<b>WS 1:</b> 6-35
IODECLARATIONS modules .....	<b>PL:</b> 3-6
IOE_ISC .....	<b>PL:</b> 8-4
IOE_RESULT .....	<b>PL:</b> 8-3
IOERROR_MESSAGE .....	<b>PL:</b> 8-4
IOESCAPECODE .....	<b>PL:</b> 8-3
IOREAD_BYTE and IOWRITE_BYTE registers:	
General .....	<b>PL:</b> 7-1
GPIO .....	<b>PL:</b> 13-21
HP-IB .....	<b>PL:</b> 10-27
Serial .....	<b>PL:</b> 12-14, 12-19
IORESULT function .....	<b>WS 2:</b> 17-2, 17-3
IOSTATUS and IOCONTROL registers:	
Datacomm .....	<b>PL:</b> 11-29
General .....	<b>PL:</b> 7-1
GPIO .....	<b>PL:</b> 13-20
HP-IB .....	<b>PL:</b> 10-23
Serial .....	<b>PL:</b> 12-15
ISC_TABLE .....	<b>PL:</b> 3-7
IsoProg program .....	<b>GT:</b> 2-28, A-40
Isotropic scaling .....	<b>GT:</b> 1-10, 2-27

## j

JSR instruction (68000) .....	<b>WS 1:</b> 6-55
Jump command (Editor) .....	<b>WS 1:</b> 4-40
Justifying labels .....	<b>GT:</b> 2-18
JustProg program .....	<b>GT:</b> 2-21, A-46

## k

Katakana display characters .....	<b>WS 2:</b> C-10
Kernel (operating system) .....	<b>WS 2:</b> 18-4
Key buffer (System devices) .....	<b>PL:</b> 14-48
Key codes (System devices) .....	<b>PL:</b> 14-59
Key correspondence table .....	<b>UG:</b> 2, 7
Key labels .....	<b>UG:</b> 71
Key notations (Debugger) .....	<b>WS 1:</b> 9-5, 9-27
Key notations in text .....	<b>WS 1:</b> 2-2
KEYBOARD file .....	<b>GT:</b> 4-4
Keyboard interface (select code 2) .....	<b>PL:</b> 4-1

Keyboard label .....	<b>UG:110</b>
Keyboard (System devices) .....	<b>PL:14-42</b>
Keyboards .....	<b>WS 2:22-6</b>
Keyboards:	
HP 46020A .....	<b>UG:2, 70</b>
HP 46021A .....	<b>UG:2, 70</b>
HP 98203A .....	<b>UG:3, 101</b>
HP 98203B .....	<b>UG:3, 88</b>
HP 98203C .....	<b>UG:3</b>
Model 226/236 .....	<b>UG:3, 88</b>
Keypad, numeric .....	<b>UG:85, 98</b>
Knob .....	<b>UG:96, 107, WS 1:4-8, 4-26</b>
Knob (System devices) .....	<b>PL:14-56</b>
Krunch command .....	<b>UG:154, 263</b>
Krunch command (Filer) .....	<b>WS 1:5-44</b>

**I**

Label direction, setting .....	<b>GT:2-16</b>
LABELJUSTIFY procedure .....	<b>GT:2-18</b>
Labelling a plot .....	<b>GT:2-11</b>
Labelling Axes .....	<b>GT:1-25</b>
Labels, justifying .....	<b>GT:2-18</b>
Labels:	
Bold .....	<b>GT:1-19</b>
Centering .....	<b>GT:1-17</b>
Direction of .....	<b>GT:1-17</b>
Language extensions .....	<b>WS 2:10-10</b>
Ldir command .....	<b>UG:148, 261</b>
LdirProg program .....	<b>GT:2-17, A-50</b>
LEM programs .....	<b>GT:2-41, 2-44</b>
Length of strings .....	<b>WS 2:14-1</b>
LIBRARIAN file .....	<b>WS 1:8-31</b>
Librarian subsystem .....	<b>UG:169, 216, 275</b>

---

**UG:** *Pascal 3.2 User's Guide*  
**WS 1:** *Pascal 3.2 Workstation System, Volume 1*  
**WS 2:** *Pascal 3.2 Workstation System, Volume 2*  
**PL:** *Pascal 3.2 Procedure Library*  
**GT:** *Pascal 3.2 Graphics Techniques*

Librarian:

Adding modules to System Library .....	<b>WS 1: 8-10</b>
Command summary .....	<b>WS 2: D-6</b>
Creating a boot file .....	<b>WS 1: 8-23</b>
Creating libraries .....	<b>WS 1: 8-12</b>
DEF table .....	<b>WS 1: 8-27</b>
DEF table command .....	<b>WS 1: 8-19</b>
Define Source .....	<b>WS 1: 8-28</b>
Detailed file information .....	<b>WS 1: 8-17</b>
EXPORT .....	<b>WS 1: 8-29</b>
EXT table .....	<b>WS 1: 8-28</b>
EXT table command .....	<b>WS 1: 8-18</b>
Flags .....	<b>WS 1: 8-29</b>
General Value or Address Record (GVR) .....	<b>WS 1: 8-30</b>
Glossary .....	<b>WS 1: 8-27</b>
IMPLEMENT .....	<b>WS 1: 8-30</b>
IMPORT .....	<b>WS 1: 8-30</b>
IMPORT text command .....	<b>WS 1: 8-18</b>
Introduction .....	<b>WS 1: 8-1</b>
Invoking .....	<b>WS 1: 8-10</b>
Libraries .....	<b>WS 1: 8-2</b>
Linking object files together .....	<b>WS 1: 8-14</b>
Mass storage requirements .....	<b>WS 2: 18-44</b>
Mass storage setup .....	<b>WS 1: 8-9</b>
Object file .....	<b>WS 1: 8-31</b>
Object module .....	<b>WS 1: 8-31</b>
REF tables .....	<b>WS 1: 8-32</b>
Reference Pointer .....	<b>WS 1: 8-32</b>
Text Record .....	<b>WS 1: 8-33</b>
Unassemble commands .....	<b>WS 1: 8-19, 8-21</b>
What it does .....	<b>WS 1: 8-3</b>
Main prompt .....	<b>PL: 1-9</b>
Purpose of .....	<b>PL: 1-3</b>
Using .....	<b>PL: 1-9</b>

Libraries .....	<b>WS 2: 18-7</b>
Libraries:	
Creating .....	<b>PL: 1-8</b>
Overview .....	<b>PL: 1-3</b>
LIBRARY .....	<b>PL: 1-6, 1-9</b>
LIBRARY file .....	<b>WS 1: 8-1, 8-31</b>
LIBRARY modules .....	<b>PL: 1-12</b>
Library overview .....	<b>PL: 1-3</b>
Library:	
Definition of .....	<b>WS 1: 8-31</b>
Overview .....	<b>WS 1: 8-2</b>
System .....	<b>WS 1: 8-33</b>
LIF file names .....	<b>WS 1: 3-10</b>
Limits, display .....	<b>GT: 2-1</b>
LINE .....	<b>GT: B-58</b>
Line drawing .....	<b>GT: 1-7</b>
LINE procedure .....	<b>GT: 1-8, 1-32</b>
Line Styles, selecting .....	<b>GT: 2-25</b>
Line timeouts (Datacomm) .....	<b>PL: 11-14</b>
Line value .....	<b>GT: 5-24</b>
LINENUM (Compiler option) .....	<b>WS 1: 6-36</b>
Lines, clipping .....	<b>GT: 1-23</b>
LINES (Compiler option) .....	<b>WS 1: 6-37</b>
LINK instruction (68000) .....	<b>WS 1: 6-55, 7-11</b>
Linking object files .....	<b>WS 1: 8-14</b>
LIST (Compiler option) .....	<b>WS 1: 6-38</b>
List-directory command (Filer) .....	<b>WS 1: 5-6, 5-46</b>
Listen addresses (HP-IB) .....	<b>PL: 10-5, 10-6</b>
Listing a directory .....	<b>UG: 148, 261</b>
Listing of files .....	<b>WS 1: 5-11</b>
Loader/Segmenter errors .....	<b>WS 2: A-8</b>
Loading a system .....	<b>WS 2: 18-3</b>

---

**UG:** *Pascal 3.2 User's Guide*  
**WS 1:** *Pascal 3.2 Workstation System, Volume 1*  
**WS 2:** *Pascal 3.2 Workstation System, Volume 2*  
**PL:** *Pascal 3.2 Procedure Library*  
**GT:** *Pascal 3.2 Graphics Techniques*

Loading Pascal system .....	<b>GT: 1-7</b>
Loading subsystems .....	<b>UG: 216</b>
Loading the Pascal system .....	<b>UG: 18</b>
Local lockout (HP-IB) .....	<b>PL: 10-9</b>
Local lockout state (HP-IB) .....	<b>PL: 10-13</b>
Local printers (CTABLE) .....	<b>WS 2: 18-52</b>
Local variables .....	<b>WS 1: 7-11</b>
Locator .....	<b>GT: B-1</b>
LOCATOR program .....	<b>GT: 4-9, A-51</b>
LOCATOR_INIT procedure .....	<b>GT: B-1, B-59</b>
Locators .....	<b>GT: B-3, B-7</b>
LOCATOR_TERM procedure .....	<b>GT: B-1, B-64</b>
LOCKABLE files .....	<b>WS 2: 15-33</b>
LOCKMODULE .....	<b>PL: 1-13</b>
Logarithmic plotting .....	<b>GT: 2-32</b>
Logic sense (GPIO) .....	<b>PL: 13-3</b>
Logical unit numbers .....	<b>WS 2: 18-7</b>
Logical units .....	<b>WS 1: 3-3</b>
Logical volumes (hard discs) .....	<b>WS 2: 18-11, 18-14</b>
LogPlot program .....	<b>GT: 2-34, A-54</b>
Loopback (Serial) .....	<b>PL: 12-13</b>
LT instruction .....	<b>GT: 2-25</b>
Luminosity .....	<b>GT: 5-5</b>

## m

Main Command Level .....	<b>WS 1: 2-1, 2-4</b>
Main Command Level:	
Compiler command .....	<b>UG: 114</b>
Description of .....	<b>UG: 114</b>
Editor command .....	<b>UG: 114</b>
eXecute command .....	<b>UG: 28, 42, 115, 266</b>
Filer command .....	<b>UG: 114</b>
Memvol command .....	<b>UG: 123, 180, 195, 239</b>
Newsysvol command .....	<b>UG: 118, 125, 145, 196</b>
Permanent command .....	<b>UG: 120, 178, 238</b>
User restart command .....	<b>UG: 40, 120</b>
Version command .....	<b>UG: 122</b>
What command .....	<b>UG: 117, 181, 240</b>
Main Command Prompt .....	<b>WS 1: 2-1</b>
Main Level Command summary .....	<b>WS 2: D-1</b>

Main Level commands .....	<b>WS 1: 2-3, 2-4</b>
Make command (Filer) .....	<b>WS 1: 5-48</b>
MAKE_PIC_CURRENT procedure .....	<b>GT: B-65</b>
Manual organization .....	<b>PL: 1-1</b>
Manual overview .....	<b>WS 1: 1-1, 1-4</b>
Map, color .....	<b>GT: 5-25</b>
Margin command .....	<b>UG: 138</b>
Margin command (Editor) .....	<b>WS 1: 4-41</b>
MARK and RELEASE .....	<b>WS 2: 16-2</b>
MARK (procedure) .....	<b>PL: 1-13</b>
MARKER procedure .....	<b>GT: 2-47, B-66</b>
MarkrProg program .....	<b>GT: 2-48, A-56</b>
Mass storage .....	<b>PL: 1-8</b>
Mass storage:	
Comparison of .....	<b>WS 2: 19-2</b>
Configuration .....	<b>WS 2: 18-17</b>
Introduction .....	<b>WS 1: 3-1</b>
Volumes .....	<b>WS 1: 3-2</b>
Match character transfers .....	<b>PL: 9-8</b>
MAXPOS (files) .....	<b>WS 2: 15-29</b>
MEDIAINIT program .....	<b>UG: 28, 223, 225, 306, WS 2: 15-41, 18-27</b>
Memory address, graphics .....	<b>GT: 2-37</b>
Memory map:	
RAM .....	<b>WS 2: B-17</b>
ROM .....	<b>WS 2: B-18</b>
Software .....	<b>WS 2: B-20</b>
Memory requirements, subsystem .....	<b>UG: 275</b>
Memory size, graphics .....	<b>GT: 2-37</b>
Memory volume command (Main Level) .....	<b>WS 1: 2-7</b>
Memory volumes .....	<b>UG: 123, 180, 195, 239, WS 2: 18-44</b>
Memory-mapped I/O .....	<b>WS 2: B-18</b>

---

**UG:** *Pascal 3.2 User's Guide*  
**WS 1:** *Pascal 3.2 Workstation System, Volume 1*  
**WS 2:** *Pascal 3.2 Workstation System, Volume 2*  
**PL:** *Pascal 3.2 Procedure Library*  
**GT:** *Pascal 3.2 Graphics Techniques*

Memory:	
Bubble .....	<b>WS 2:</b> 18-19
Characteristics .....	<b>WS 1:</b> 3-1
EPROM .....	<b>WS 2:</b> 18-19
RAM .....	<b>WS 1:</b> 3-1
Memvol command .....	<b>UG:</b> 123, 180, 195, 239
Menu key .....	<b>UG:</b> 71
Menus (System devices) .....	<b>PL:</b> 14-34
Messages (HP-IB) .....	<b>PL:</b> 10-18
Micro disc:	
Formatting .....	<b>UG:</b> 28
Initialization .....	<b>UG:</b> 28
Insertion .....	<b>UG:</b> 12
Removing .....	<b>UG:</b> 13
Write-protection .....	<b>UG:</b> 15
Mini disc:	
Formatting .....	<b>UG:</b> 28
Initialization .....	<b>UG:</b> 28
Insertion .....	<b>UG:</b> 14
Removing .....	<b>UG:</b> 14
Write-protection .....	<b>UG:</b> 17
Mixing DISPOSE and RELEASE .....	<b>WS 2:</b> 16-4
MKHFS .....	<b>UG:</b> 308
MKHFS utility .....	<b>WS 2:</b> 21-2
Models 216 and 217 differences (Serial) .....	<b>PL:</b> 12-30
Models, color .....	<b>GT:</b> 5-4, 5-9
Modem handshake (Serial) .....	<b>PL:</b> 12-7
Modem line control (Serial) .....	<b>PL:</b> 12-12
Modem status and control (Serial) .....	<b>PL:</b> 12-3
Modem-line handshakes (Serial) .....	<b>PL:</b> 12-12
Modes, drawing .....	<b>GT:</b> 2-23
Module Dependency Table .....	<b>GT:</b> B-131
Modules:	
Assembler .....	<b>WS 1:</b> 7-5
Developing and testing .....	<b>WS 1:</b> 6-10
Device drivers .....	<b>WS 2:</b> 18-4
Examples of .....	<b>WS 1:</b> 6-9, 6-10, 7-41, 7-42, 8-3
How the Compiler finds them .....	<b>WS 1:</b> 8-5
How the loader finds them .....	<b>WS 1:</b> 8-6
Importing .....	<b>WS 1:</b> 8-5, 8-6

Initialization .....	<b>WS 1:7-13</b>
INITLIB .....	<b>WS 2:18-4</b>
INITLIB module descriptions .....	<b>WS 2:18-40</b>
LAST (in INITLIB) .....	<b>WS 2:18-5</b>
Names used by operating system .....	<b>WS 2:B-16</b>
Object (definition of) .....	<b>WS 1:8-31</b>
Pascal .....	<b>WS 1:8-32</b>
PRINTER .....	<b>WS 2:18-17</b>
Required order in INITLIB .....	<b>WS 2:18-38</b>
Separate compilation .....	<b>WS 1:6-13</b>
Strategy for compiling .....	<b>WS 1:6-14</b>
Structure of .....	<b>WS 1:6-7</b>
Adding to the System Library .....	<b>PL:1-9</b>
ALLOCATE .....	<b>PL:1-17</b>
Compiling .....	<b>PL:1-6</b>
Dependency table .....	<b>PL:1-20</b>
Directory .....	<b>PL:1-3</b>
Examples (on DOC disc) .....	<b>PL:1-3</b>
FGRAPHICS .....	<b>PL:1-15</b>
File sizes .....	<b>PL:1-8</b>
GENERAL .....	<b>PL:3-2, 3-4</b>
GRAPHICS .....	<b>PL:1-15</b>
How the Compiler finds them .....	<b>PL:1-6</b>
How the loader finds them .....	<b>PL:1-7</b>
HPIB .....	<b>PL:3-2, 3-5</b>
HPM .....	<b>PL:1-13</b>
Importing .....	<b>PL:1-4</b>
INTERFACE .....	<b>PL:1-14</b>
IO .....	<b>PL:1-14, 3-2</b>
IODECLARATIONS .....	<b>PL:3-6</b>
LIBRARY .....	<b>PL:1-12</b>
LOCKMODULE .....	<b>PL:1-13</b>
Making them accessible .....	<b>PL:1-6, 1-7, 1-18, 1-19</b>

---

**UG:** *Pascal 3.2 User's Guide*  
**WS 1:** *Pascal 3.2 Workstation System, Volume 1*  
**WS 2:** *Pascal 3.2 Workstation System, Volume 2*  
**PL:** *Pascal 3.2 Procedure Library*  
**GT:** *Pascal 3.2 Graphics Techniques*

Modules: (continued)

Overview .....	<b>PL: 1-3</b>
RND .....	<b>PL: 1-12</b>
SEGMENTER .....	<b>PL: 1-17</b>
SERIAL .....	<b>PL: 3-3, 3-6</b>
Standard .....	<b>PL: 1-12</b>
SYSDEVS .....	<b>PL: 14-3</b>
SYSGLOBALS .....	<b>PL: 14-3</b>
UIO .....	<b>PL: 1-13</b>
Monochromatic defaults in color table .....	<b>GT: 5-3</b>
Mouse .....	<b>UG: 66, 77, 78, 82</b>
Mouse input device .....	<b>WS 1: 4-8, 4-26, WS 2: 18-43</b>
MOVE procedure .....	<b>GT: 1-8, 1-32, B-67</b>
Moving files .....	<b>WS 1: 5-15</b>
Multi-line objects .....	<b>GT: 2-40</b>
Multiple listeners (HP-IB) .....	<b>PL: 10-6</b>
Multiple on-line systems .....	<b>WS 2: 18-15</b>

**n**

New command .....	<b>UG: 157</b>
New command (Filer) .....	<b>WS 1: 5-50</b>
NEW (procedure) .....	<b>PL: 1-13</b>
New sysvol Command (Main Level) .....	<b>WS 1: 2-9</b>
Newsysvol command .....	<b>UG: 118, 125, 145, 196</b>
No room on volume .....	<b>UG: 154</b>
Non-active controller (HP-IB) .....	<b>PL: 10-6</b>
Non-data characters (Datacomm) .....	<b>PL: 11-16</b>
Non-disc mass storage (introduction) .....	<b>WS 2: 19-1</b>
Non-separable degrees of freedom .....	<b>GT: 4-7</b>
Non-square pixels .....	<b>GT: 5-19</b>
Numbers (internal representation of) .....	<b>PL: 2-8</b>
Numeric keypad .....	<b>UG: 85, 98</b>

**o**

Object file .....	<b>PL: 1-3, 1-7, WS 1: 8-31</b>
Object module .....	<b>WS 1: 8-2, 8-31</b>
On-Line devices .....	<b>WS 1: 2-6</b>
Opcodes (Assembler) .....	<b>WS 1: 7-19</b>

OPEN (files) .....	<b>WS 2:</b> 15-5, 15-23, 15-24, 15-33
Operating parameters (Datacomm) .....	<b>PL:</b> 11-10
Operating system kernel .....	<b>WS 2:</b> 18-4
OPTIONS module (CTABLE) .....	<b>WS 2:</b> 18-51
OSINSTALL .....	<b>UG:</b> 331
OSINSTALL utility (HFS) .....	<b>WS 2:</b> 21-5
Other manuals .....	<b>WS 1:</b> 1-1, 1-2
Output:	
Characters .....	<b>PL:</b> 5-4
Data types supported .....	<b>PL:</b> 5-1
Definition of .....	<b>PL:</b> 2-2
Formatted .....	<b>PL:</b> 5-6, 5-7
Free-field .....	<b>PL:</b> 5-1, 5-2, 5-3, 5-4, 5-5, 5-6
General .....	<b>PL:</b> 5-1
Real numbers .....	<b>PL:</b> 5-2
Strings .....	<b>PL:</b> 5-3
Words .....	<b>PL:</b> 5-4
OUTPUT_ESC procedure .....	<b>GT:</b> 2-7, 2-23, 3-2, 3-5, B-1, B-68
Overlap transfers .....	<b>PL:</b> 9-6
Overview .....	<b>WS 1:</b> 1-1
Overview of manual .....	<b>PL:</b> 1-1
Overwriting files .....	<b>UG:</b> 148
OVFLCHECK (Compiler option) .....	<b>WS 1:</b> 6-39

## p

P-load (modules) .....	<b>PL:</b> 1-7
Page command (Editor) .....	<b>WS 1:</b> 4-42
PAGE (Compiler option) .....	<b>WS 1:</b> 6-40
PAGEWIDTH (Compiler option) .....	<b>WS 1:</b> 6-41
Parameter passing .....	<b>WS 1:</b> 6-57
Parity (Datacomm) .....	<b>PL:</b> 11-2, 11-7, 11-19
Parity (Serial) .....	<b>PL:</b> 12-2, 12-4, 12-7
PARTIAL_EVAL (Compiler option) .....	<b>WS 1:</b> 6-42

---

**UG:** *Pascal 3.2 User's Guide*  
**WS 1:** *Pascal 3.2 Workstation System, Volume 1*  
**WS 2:** *Pascal 3.2 Workstation System, Volume 2*  
**PL:** *Pascal 3.2 Procedure Library*  
**GT:** *Pascal 3.2 Graphics Techniques*

Partitioning hard discs:	
Algorithm .....	<b>WS 2: 18-11</b>
Designing your own .....	<b>WS 2: 18-58</b>
Example .....	<b>WS 2: 18-27</b>
Modifying .....	<b>WS 2: 18-14, 18-54</b>
Recommendations .....	<b>WS 2: 18-57</b>
Pascal file system .....	<b>UG: 35</b>
Pascal Graphics Techniques manual .....	<b>PL: 1-15</b>
Pascal system backup .....	<b>UG: 51, 234</b>
Pascal system, loading .....	<b>GT: 1-7</b>
Pascal:	
1.0 (description) .....	<b>WS 2: B-1</b>
2.0 (description) .....	<b>WS 2: B-2</b>
2.1 (description) .....	<b>WS 2: B-2</b>
3.0 (description) .....	<b>WS 2: B-5</b>
3.01 (description) .....	<b>WS 2: B-9</b>
3.1 (description) .....	<b>WS 2: B-10</b>
3.12 (description) .....	<b>WS 2: B-14</b>
3.2 (description) .....	<b>WS 2: B-14</b>
Extensions .....	<b>WS 2: 10-10</b>
File operations .....	<b>WS 2: 15-22</b>
Modules .....	<b>WS 1: 8-32</b>
Program development .....	<b>WS 1: 6-2</b>
System history .....	<b>WS 2: B-1</b>
Volumes .....	<b>WS 1: 3-2</b>
Pass control (HP-IB) .....	<b>PL: 10-11</b>
Passing parameters .....	<b>WS 1: 7-8</b>
Passwords (SRM) .....	<b>WS 1: 3-8</b>
PAUSE key .....	<b>UG: 90</b>
Pen acceleration, controlling .....	<b>GT: 3-6</b>
Pen force, controlling .....	<b>GT: 3-6</b>
Pen speed, controlling .....	<b>GT: 3-5</b>
Peripheral drivers .....	<b>WS 2: 18-40</b>
Peripheral status line (GPIO) .....	<b>PL: 13-4</b>
Peripherals supported (by 3.0 system) .....	<b>WS 2: B-7</b>
Permanent command .....	<b>GT: 1-4, UG: 120, 178, 238</b>
Permanent Command (Main Level) .....	<b>WS 1: 2-10</b>
Permanently loading subsystems .....	<b>UG: 120, 178, 238</b>
Permissions (HFS) .....	<b>WS 2: 15-39</b>
Photographing the CRT .....	<b>GT: 5-41</b>

Physical memory map .....	<b>WS 2:</b> B-17
Pixel .....	<b>GT:</b> 1-11, 2-43
Pixel pairs .....	<b>GT:</b> 5-19
PLineProg program .....	<b>GT:</b> 2-39, A-57
Plot Labelling .....	<b>GT:</b> 2-11
Plotter control .....	<b>GT:</b> 3-5
Plotter, selecting a .....	<b>GT:</b> 3-1
Plotters .....	<b>GT:</b> 5-16
Plotting and the CRT .....	<b>GT:</b> 5-41
Polling (HP-IB) .....	<b>PL:</b> 10-11
Polygon filling .....	<b>GT:</b> 2-43
Polygon interiors .....	<b>GT:</b> 5-24
POLYGON procedure .....	<b>GT:</b> 2-40, 2-42, B-75
POLYGON_DEV_DEP procedure .....	<b>GT:</b> 2-42, B-78
Polygons .....	<b>GT:</b> 5-35
POLYLINE procedure .....	<b>GT:</b> 2-39, B-82
PolyProg program .....	<b>GT:</b> 2-41, A-58
Porting software .....	<b>WS 2:</b> 22-1
POSITION (files) .....	<b>WS 2:</b> 15-29
Powerfail (System devices) .....	<b>PL:</b> 14-75
Prefix command (Filer) .....	<b>WS 1:</b> 3-5, 5-51
Prefix volume .....	<b>WS 1:</b> 3-4, <b>UG:</b> 155
Prefix-vol command .....	<b>UG:</b> 155, 183
Preventing data loss (Datacomm) .....	<b>PL:</b> 11-24
Primary DAMs .....	<b>WS 2:</b> 18-21
Printer listings .....	<b>UG:</b> 163, 200, 264
PRINTER volume .....	<b>UG:</b> 156
Printers:	
Changing the System Printer .....	<b>WS 2:</b> 18-18
Modules .....	<b>WS 2:</b> 18-17
Serial devices .....	<b>WS 2:</b> 18-19

---

**UG:** *Pascal 3.2 User's Guide*  
**WS 1:** *Pascal 3.2 Workstation System, Volume 1*  
**WS 2:** *Pascal 3.2 Workstation System, Volume 2*  
**PL:** *Pascal 3.2 Procedure Library*  
**GT:** *Pascal 3.2 Graphics Techniques*

Printing a file .....	<b>UG:157, 267</b>
Private links (Datacomm) .....	<b>PL:11-19</b>
Problems:	
Compiler .....	<b>WS 1:6-19</b>
Debugging programs that use files .....	<b>WS 2:15-39</b>
File names to avoid .....	<b>WS 1:3-9</b>
Insufficient global space .....	<b>WS 1:6-20</b>
No room on volume .....	<b>WS 1:3-19</b>
Not Enough Memory .....	<b>WS 1:6-20</b>
Syntax errors .....	<b>WS 1:6-4</b>
TABLE program .....	<b>WS 2:18-13</b>
Procedure calls (effects on stack) .....	<b>WS 1:6-55</b>
Procedure Library .....	<b>PL:1-12</b>
Procedures (EXTERNAL) .....	<b>WS 1:7-16</b>
Processor boards .....	<b>WS 2:22-3</b>
Program development .....	<b>WS 1:6-2</b>
Programming helps (Datacomm) .....	<b>PL:11-24</b>
Programming system .....	<b>WS 1:7-5</b>
Programming techniques .....	<b>PL:12-5</b>
Programs:	
Backing up .....	<b>UG:207</b>
Creation .....	<b>UG:129, 161, 193</b>
Editing environment .....	<b>UG:136</b>
Listings .....	<b>UG:163, 200, 264</b>
Permanently loading .....	<b>UG:120, 238</b>
Running .....	<b>UG:119, 166, 201, 203, 266</b>
Prompt recognition (Datacomm) .....	<b>PL:11-16</b>
Prompts:	
Value range type .....	<b>UG:45</b>
Aborting .....	<b>UG:45, 222</b>
Compiler .....	<b>WS 1:6-3</b>
Date .....	<b>WS 1:2-17</b>
Debugger .....	<b>WS 1:9-7</b>
Default values .....	<b>UG:45, 222</b>
Editor .....	<b>WS 1:4-3</b>
Filer .....	<b>WS 1:5-2</b>
Librarian .....	<b>WS 1:8-8</b>
Main Level .....	<b>WS 1:2-1</b>

Responding to .....	<b>UG:</b> 44, 222
Straight question type .....	<b>UG:</b> 44, 222
Time .....	<b>WS 1:</b> 2-17
Value range type .....	<b>UG:</b> 222
Yes/No type .....	<b>UG:</b> 44, 222
Protocol (Datacomm) .....	<b>PL:</b> 11-2, 11-12
Protocol (Serial) .....	<b>PL:</b> 12-4
PSE key .....	<b>UG:</b> 102
Pulse-mode handshakes (GPIO) .....	<b>PL:</b> 13-7
PUT (files) .....	<b>WS 2:</b> 15-26

## q

Quantizable degrees of freedom .....	<b>GT:</b> 4-8
Question mark wildcard .....	<b>UG:</b> 175, 252
Questions (prompts) .....	<b>UG:</b> 44, 222
Queue (Debugger) .....	<b>WS 1:</b> 9-9
Quick reference for graphics procedures .....	<b>GT:</b> B-1
Quit command .....	<b>UG:</b> 218
Quit command:	
Editor .....	<b>WS 1:</b> 4-43
Filer .....	<b>WS 1:</b> 5-53
Librarian .....	<b>WS 1:</b> 8-8

## r

RAM volumes .....	<b>UG:</b> 123, 180, 195, 239
RAM:	
Addresses .....	<b>WS 2:</b> B-17
Introduction .....	<b>WS 1:</b> 3-1
Memory map .....	<b>WS 2:</b> B-17
RAND (function) .....	<b>PL:</b> 1-12

---

**UG:** *Pascal 3.2 User's Guide*  
**WS 1:** *Pascal 3.2 Workstation System, Volume 1*  
**WS 2:** *Pascal 3.2 Workstation System, Volume 2*  
**PL:** *Pascal 3.2 Procedure Library*  
**GT:** *Pascal 3.2 Graphics Techniques*

Random access files .....	<b>WS 2: 15-27</b>
RANDOM (procedure) .....	<b>PL: 1-12</b>
RANGE (Compiler option) .....	<b>WS 1: 6-43</b>
Range of addresses .....	<b>WS 2: B-18</b>
Range of device selectors .....	<b>PL: 3-7</b>
Range of numbers .....	<b>WS 2: 13-1</b>
Range of select codes .....	<b>PL: 3-6</b>
Raster images, dumping .....	<b>GT: 3-2</b>
Ratio, aspect .....	<b>GT: 2-2, 2-28, 4-13</b>
RCL key .....	<b>UG: 105</b>
READ (files) .....	<b>WS 2: 15-25</b>
READDIR (files) .....	<b>WS 2: 15-27</b>
Reading buffers .....	<b>PL: 9-2</b>
Real number range .....	<b>WS 2: 13-1</b>
Real numbers (internal representation of) .....	<b>PL: 2-9</b>
RECALL key .....	<b>UG: 74, 95</b>
RECOVER .....	<b>PL: 8-2</b>
Rectangular coordinates .....	<b>GT: 1-6</b>
REF (Compiler option) .....	<b>WS 1: 6-44</b>
REF tables .....	<b>WS 1: 8-32</b>
Reference Pointer .....	<b>WS 1: 8-32</b>
References, color .....	<b>GT: 5-42</b>
Registers:	
Common definitions .....	<b>PL: 7-2</b>
Datacomm .....	<b>PL: 11-29</b>
General .....	<b>PL: 7-1</b>
GPIO .....	<b>PL: 13-20</b>
Hardware vs. I/O System .....	<b>PL: 7-1</b>
HP-IB .....	<b>PL: 10-23</b>
Serial .....	<b>PL: 12-15</b>
Relative locator .....	<b>GT: B-3, B-7, B-33, B-63, B-70, B-85, B-111</b>
Relaxed typechecking (Compiler) .....	<b>WS 2: 12-2</b>
RELEASE and MARK .....	<b>WS 2: 16-2</b>
RELEASE (procedure) .....	<b>PL: 1-13</b>
Remote enable (HP-IB) .....	<b>PL: 10-15</b>
Remote message (HP-IB) .....	<b>PL: 10-8</b>
Remote state (HP-IB) .....	<b>PL: 10-13</b>
Remove command .....	<b>UG: 153, 256</b>
Remove command (Filer) .....	<b>WS 1: 5-54</b>

Removing a file .....	<b>UG:</b> 153, 256
Removing files .....	<b>WS 1:</b> 5-19
Removing flexible discs .....	<b>UG:</b> 13
Renaming a file or volume .....	<b>UG:</b> 152, 259, 260
Renaming:	
Boot files .....	<b>WS 2:</b> 18-35
Files .....	<b>WS 1:</b> 5-18
Volumes .....	<b>WS 1:</b> 5-18
Replace command (Editor) .....	<b>WS 1:</b> 4-45
RESET (files) .....	<b>WS 2:</b> 15-5, 15-24, 15-33
RESET key .....	<b>UG:</b> 93
Reset key .....	<b>UG:</b> 79
Reset:	
Datacomm .....	<b>PL:</b> 11-12
GPIO .....	<b>PL:</b> 13-14
HP-IB .....	<b>PL:</b> 10-23
Serial .....	<b>PL:</b> 12-6
Resolution of color models .....	<b>GT:</b> 5-29
Resource .....	<b>PL:</b> 4-1
Responding to prompts .....	<b>UG:</b> 44, 222
Restore (BACKUP) .....	<b>WS 2:</b> 20-5
Retrieving and storing images .....	<b>GT:</b> 2-36
Return key .....	<b>UG:</b> 77
REWRITE (files) .....	<b>WS 2:</b> 15-5, 15-23, 15-25, 15-33
RGB color model .....	<b>GT:</b> 5-4, 5-9, 5-29
RGB interface .....	<b>GT:</b> 3-4
RND module .....	<b>PL:</b> 1-12
ROM memory map .....	<b>WS 2:</b> B-18
ROM:	
Boot ROM .....	<b>WS 2:</b> 18-3
Roman 8 character set .....	<b>UG:</b> 84
Rotation, label .....	<b>GT:</b> 2-16

---

**UG:** *Pascal 3.2 User's Guide*  
**WS 1:** *Pascal 3.2 Workstation System, Volume 1*  
**WS 2:** *Pascal 3.2 Workstation System, Volume 2*  
**PL:** *Pascal 3.2 Procedure Library*  
**GT:** *Pascal 3.2 Graphics Techniques*

Rotation of labels .....	<b>GT: 1-17</b>
RS-232 Serial:	
98626 interface .....	<b>PL: 12-1</b>
98644 interface .....	<b>PL: 12-1, 12-27</b>
Built-in (Models 216 and 217) .....	<b>PL: 12-30</b>
Introduction .....	<b>PL: 12-1</b>
UART .....	<b>PL: 12-1</b>
RS-232C cable signals (Datacomm) .....	<b>PL: 11-27</b>
RST key .....	<b>UG: 105</b>
Rubber echoes .....	<b>GT: 4-12</b>
Run command .....	<b>UG: 266</b>
Run Command (Main Level) .....	<b>WS 1: 2-11</b>
RUN key .....	<b>UG: 90, 102</b>
Run light (System devices) .....	<b>PL: 14-36</b>
Run-time errors .....	<b>UG: 203, WS 2: A-3</b>
Running demonstration programs .....	<b>GT: 1-4</b>
Running programs .....	<b>UG: 203, 205</b>
Running stored programs .....	<b>UG: 119, 166, 266</b>

## S

SAMPLE_LOCATOR procedure .....	<b>GT: B-1, B-84</b>
Saturation .....	<b>GT: 5-5</b>
Save command .....	<b>UG: 147</b>
Save Command (Filer) .....	<b>WS 1: 5-56</b>
SAVE_CONST (Compiler option) .....	<b>WS 1: 6-45</b>
Scaling .....	<b>GT: 1-9</b>
Scaling, isotropic .....	<b>GT: 2-27</b>
SCANSTUFF module (CTABLE) .....	<b>WS 2: 18-62</b>
Screen dump .....	<b>GT: 3-2</b>
Screen dumps (Debugger) .....	<b>WS 1: 9-8</b>
Screen organization .....	<b>UG: 61</b>
SEARCH Compiler option .....	<b>PL: 1-6</b>
SEARCH (Compiler option) .....	<b>WS 1: 6-46</b>
SEARCH_SIZE (Compiler option) .....	<b>WS 1: 6-47</b>
Secondary addresses (HP-IB) .....	<b>PL: 10-8</b>
Secondary channel (Datacomm) .....	<b>PL: 11-26</b>
Secondary DAMs .....	<b>WS 2: 18-21</b>
SEEK (files) .....	<b>WS 2: 15-28</b>

Segmentation:	
Calling a procedure .....	<b>PL: 15-5</b>
Calling a program .....	<b>PL: 15-3</b>
Checking a procedure variable .....	<b>PL: 15-6</b>
Errors .....	<b>PL: 15-10</b>
Free space .....	<b>PL: 15-3</b>
Initialization .....	<b>PL: 15-3</b>
Introduction .....	<b>PL: 15-1</b>
Searching for a procedure name .....	<b>PL: 15-6</b>
Unloading segments .....	<b>PL: 15-9</b>
Using the explicit code area .....	<b>PL: 15-7</b>
Using the heap .....	<b>PL: 15-8</b>
Using the stack .....	<b>PL: 15-3</b>
WARNING - You're on your own .....	<b>PL: 15-3</b>
SEGMENTER module .....	<b>PL: 1-17</b>
Select codes .....	<b>PL: 3-6, 4-1</b>
Select key .....	<b>UG: 62, 78</b>
Selecting graphics display device .....	<b>GT: 1-6</b>
Self test (during boot) .....	<b>WS 2: 18-3</b>
Self-test (Serial) .....	<b>PL: 12-13</b>
Send command (HP-IB) .....	<b>PL: 10-22</b>
Separability (degrees of freedom) .....	<b>GT: 4-7</b>
Separable degrees of freedom .....	<b>GT: 4-7</b>
Serial interfaces .....	<b>PL: 2-6, 4-2</b>
SERIAL modules .....	<b>PL: 3-3, 3-6</b>
Serial printer .....	<b>UG: 46</b>
Serial printers .....	<b>WS 2: 18-19</b>
Serial transfers .....	<b>PL: 9-4</b>
Serial:	
98626 interface .....	<b>PL: 12-1</b>
98644 interface .....	<b>PL: 12-1, 12-27</b>
Baud rate .....	<b>PL: 12-3, 12-6</b>
Break messages .....	<b>PL: 12-11</b>
Built-in (Models 216 and 217) .....	<b>PL: 12-30</b>
Cable options .....	<b>PL: 12-23</b>

---

**UG:** *Pascal 3.2 User's Guide*  
**WS 1:** *Pascal 3.2 Workstation System, Volume 1*  
**WS 2:** *Pascal 3.2 Workstation System, Volume 2*  
**PL:** *Pascal 3.2 Procedure Library*  
**GT:** *Pascal 3.2 Graphics Techniques*

Serial: (continued)

Character format .....	<b>PL:</b> 12-2, 12-4, 12-7
Data input .....	<b>PL:</b> 12-9
Data output .....	<b>PL:</b> 12-8
DCE cable .....	<b>PL:</b> 12-24
DTE cable .....	<b>PL:</b> 12-23
Error handling .....	<b>PL:</b> 12-9
Handshake .....	<b>PL:</b> 12-4, 12-12
HP 98644 differences .....	<b>PL:</b> 12-27
Initializing the connection .....	<b>PL:</b> 12-6
Interface reset .....	<b>PL:</b> 12-6
Introduction .....	<b>PL:</b> 12-1
IOREAD_BYTE and IOWRITE_BYTE registers .....	<b>PL:</b> 12-14, 12-19
IOSTATUS and IOCONTROL registers .....	<b>PL:</b> 12-15
Loopback .....	<b>PL:</b> 12-13
Models 216 and 217 differences .....	<b>PL:</b> 12-30
Modem handshake .....	<b>PL:</b> 12-7
Modem line control .....	<b>PL:</b> 12-12
Modem status and control .....	<b>PL:</b> 12-3
Modem-line handshakes .....	<b>PL:</b> 12-12
Parity .....	<b>PL:</b> 12-4, 12-7
Parity bit .....	<b>PL:</b> 12-2
Programming techniques .....	<b>PL:</b> 12-5
Self-test .....	<b>PL:</b> 12-13
Signal functions .....	<b>PL:</b> 12-23
Software handshake .....	<b>PL:</b> 12-4, 12-7, 12-11
Special applications .....	<b>PL:</b> 12-11
Special characters .....	<b>PL:</b> 12-11
Start bit .....	<b>PL:</b> 12-2
Status-Line Disconnect switches .....	<b>PL:</b> 12-3
Stop bits .....	<b>PL:</b> 12-2
Transferring data .....	<b>PL:</b> 12-8
Service request (HP-IB) .....	<b>PL:</b> 10-16
Service requested state (HP-IB) .....	<b>PL:</b> 10-13
Set command (Editor) .....	<b>WS</b> 1: 4-48
Set environment command .....	<b>UG:</b> 136
SET_ASPECT procedure .....	<b>GT:</b> 1-11, 1-14, 2-1, B-86
SET_CHAR_SIZE procedure .....	<b>GT:</b> 1-16, 2-12, 2-14, 2-18, B-88
SET_COLOR procedure .....	<b>GT:</b> 5-1, 5-16, B-89
SET_COLOR_MODEL procedure .....	<b>GT:</b> 5-3, B-92
SET_COLOR_TABLE procedure .....	<b>GT:</b> 2-23, 5-3, 5-16, B-94

SET_DISPLAY_LIM procedure	GT: 1-24, 2-1, B-98
SET_ECHO procedure	GT: 4-13
SET_ECHO_POS procedure	GT: B-102
SET_LINE_STYLE procedure	GT: 2-25, B-104
SET_LINE_WIDTH procedure	GT: B-108
SET_LOCATOR_LIM procedure	GT: 4-13, B-1, B-109
SET_PGN_COLOR procedure	GT: 5-1, 5-16, B-113
SET_PGN_LS procedure	GT: B-116
SET_PGN_STYLE procedure	GT: 2-43, B-120
SET_PGN_TABLE procedure	GT: B-121
SET_TEXT_ROT procedure	GT: 1-17, 2-16, B-124
SET_TIMING procedure	GT: B-125
Setting system, setting	UG: 25
SET_VIEWPORT procedure	GT: 1-14, 2-2, 2-5, B-127
SET_WINDOW procedure	GT: 1-9, 1-14, 2-2, 2-3, 2-15, 2-27, B-129
Shading graphs	GT: 2-46
SHIFT key	UG: 97, 108
Shift key	UG: 83
Signal functions:	
Datacomm	PL: 11-27
Serial	PL: 12-23
SinAspect program	GT: 1-12, A-59
SinAxes1 program	GT: 1-22, A-60
SinAxes2 program	GT: 1-26, A-64
SinClip program	GT: 1-24, A-69
Single stepping a program	WS 1: 9-7
SinLabel1 program	GT: 1-15, A-73
SinLabel2 program	GT: 1-16, 1-18, A-74
SinLabel3 program	GT: 1-19, A-75
SinLine program	GT: 1-8, A-76
SinViewpt program	GT: A-76
SinWindow program	GT: 1-10, A-77
Skipping data (during input)	PL: 6-5
Slow program execution	WS 1: 9-7

---

**UG:** *Pascal 3.2 User's Guide*

**WS 1:** *Pascal 3.2 Workstation System, Volume 1*

**WS 2:** *Pascal 3.2 Workstation System, Volume 2*

**PL:** *Pascal 3.2 Procedure Library*

**GT:** *Pascal 3.2 Graphics Techniques*

Software .....	<b>PL: 2-1</b>
Software handshake:	
Datacomm .....	<b>PL: 11-15</b>
Serial .....	<b>PL: 12-4, 12-7, 12-11</b>
Software memory map .....	<b>WS 2: B-20</b>
Software porting .....	<b>WS 2: 22-1</b>
Solution vector .....	<b>GT: 5-21</b>
Source file .....	<b>PL: 1-3</b>
Source (of I/O operations) .....	<b>PL: 2-2</b>
Source program .....	<b>WS 1: 6-2</b>
Source text .....	<b>PL: 1-6</b>
Special configurations:	
Definition of .....	<b>WS 2: 18-1</b>
Example changes .....	<b>WS 2: 18-1</b>
Examples of .....	<b>WS 2: 18-14</b>
Special purpose lines (GPIO) .....	<b>PL: 13-18</b>
Special transfers .....	<b>PL: 9-8</b>
Specification:	
file .....	<b>UG: 42, 227</b>
Specifying files .....	<b>UG: 42, 227</b>
Speed, pen .....	<b>GT: 3-6</b>
SRM:	
Access Rights .....	<b>UG: 286</b>
Access rights .....	<b>WS 1: 3-8, WS 2: 15-38</b>
Concurrent file access .....	<b>WS 1: 3-24, WS 2: 15-36</b>
Configuration requirements .....	<b>WS 2: 18-21</b>
Creating a directory .....	<b>WS 1: 5-14</b>
Current working volume .....	<b>WS 1: 3-22</b>
Default volume .....	<b>WS 1: 3-22</b>
Directory configuration .....	<b>WS 2: 18-74</b>
Directory structure .....	<b>WS 1: 3-20</b>
Example configuration .....	<b>WS 2: 18-71</b>
File names .....	<b>WS 1: 3-18</b>
File notation .....	<b>WS 1: 3-21</b>
Hardware setup .....	<b>WS 2: 18-72</b>
Installing driver modules .....	<b>WS 2: 18-73</b>
LOCKABLE files .....	<b>WS 2: 15-33</b>
Multi-disc .....	<b>WS 2: 18-82</b>
Multiple unit numbers .....	<b>WS 2: 18-64</b>
Overview of installation .....	<b>WS 2: 18-72</b>

Passwords .....	<b>UG: 298, WS 1: 3-8</b>
Unit number assignments .....	<b>UG: 232</b>
Unit numbers .....	<b>WS 1: 3-22</b>
Volumes .....	<b>WS 1: 3-22</b>
Stack frame (Debugger) .....	<b>WS 1: 9-17</b>
Stack (How Pascal uses it) .....	<b>WS 1: 6-54</b>
STACKCHECK (Compiler option) .....	<b>WS 1: 6-48</b>
STACKCHECK_ON (Compiler option) .....	<b>WS 1: 6-55</b>
Standard configurations (definition of) .....	<b>WS 2: 18-1</b>
Standard modules .....	<b>PL: 1-12</b>
Standard partitioning, hard discs .....	<b>WS 2: 18-56</b>
Start bit:	
Datacomm .....	<b>PL: 11-2</b>
Serial .....	<b>PL: 12-2</b>
STARTUP file .....	<b>WS 2: 18-6</b>
STARTUP file, renaming .....	<b>WS 2: 18-35</b>
Static and dynamic links (Debugger) .....	<b>WS 1: 9-23</b>
Static links .....	<b>WS 1: 6-58</b>
Status (HP-IB) .....	<b>PL: 10-7</b>
Status indicator .....	<b>UG: 63</b>
Status-Line Disconnect switches (Serial) .....	<b>PL: 12-3</b>
STEP key .....	<b>UG: 74, 91, 103</b>
Stop bits:	
Datacomm .....	<b>PL: 11-7</b>
Serial .....	<b>PL: 12-2</b>
STOP key .....	<b>UG: 94, 106</b>
Stop key .....	<b>UG: 4, 61, 80</b>
Stopping .....	<b>UG: 4</b>
Storage-order directory listing .....	<b>UG: 149</b>
Storing a workfile .....	<b>UG: 147</b>
Storing and retrieving images .....	<b>GT: 2-36</b>
Straight question prompts .....	<b>UG: 44, 222</b>

---

**UG:** *Pascal 3.2 User's Guide*  
**WS 1:** *Pascal 3.2 Workstation System, Volume 1*  
**WS 2:** *Pascal 3.2 Workstation System, Volume 2*  
**PL:** *Pascal 3.2 Procedure Library*  
**GT:** *Pascal 3.2 Graphics Techniques*

Stream Command (Main Level) .....	<b>WS 1: 2-12</b>
Stream files .....	<b>WS 1: 4-24, WS 2: 18-6, 18-37</b>
String length .....	<b>WS 2: 14-1</b>
Strings and textfiles .....	<b>WS 2: 15-33</b>
STRLEN procedure .....	<b>GT: 1-17</b>
STRWRITE procedure .....	<b>GT: 1-25</b>
Subsystems .....	<b>WS 1: 2-1</b>
Subsystems:	
Definition .....	<b>UG: 57</b>
Exiting .....	<b>UG: 218</b>
Loading .....	<b>UG: 216</b>
Permanently loading .....	<b>UG: 120, 178, 238</b>
Suffix Suppression .....	<b>WS 1: 3-15</b>
Suffix suppression .....	<b>UG: 115</b>
Suffixes .....	<b>WS 1: 3-13</b>
Summary of bus sequences (HP-IB) .....	<b>PL: 10-37</b>
Summary:	
Debugger commands .....	<b>WS 1: 9-31</b>
Editor commands .....	<b>WS 1: 4-25</b>
Filer Commands .....	<b>WS 1: 5-21</b>
Librarian commands .....	<b>WS 1: 8-24</b>
Supported features (System devices) .....	<b>PL: 14-2</b>
Suppressing file suffixes .....	<b>UG: 115</b>
SWITCH_STRPOS (Compiler option) .....	<b>WS 1: 6-49</b>
Symbols (Assembler) .....	<b>WS 1: 7-22</b>
Syntax diagrams (introduction) .....	<b>WS 1: 2-4</b>
Syntax errors .....	<b>UG: 199</b>
SYSGLOBALS .....	<b>PL: 14-3</b>
SYSPROG (Compiler option) .....	<b>PL: 8-2, WS 1: 6-50, WS 2: 17-1</b>
System addresses .....	<b>WS 2: B-20</b>
System Boot file (SYSTEM_P) .....	<b>WS 2: 18-4</b>
System Boot files (naming) .....	<b>WS 2: 18-15</b>
System Boot files (renaming) .....	<b>WS 2: 18-35</b>
System controller (HP-IB) .....	<b>PL: 10-2, 10-7</b>
System date, setting .....	<b>UG: 214</b>
System devices:	
Battery commands .....	<b>PL: 14-78</b>
Battery features .....	<b>PL: 14-75</b>
Beeper .....	<b>PL: 14-9</b>
Bit-mapped display parameters .....	<b>PL: 14-31</b>

Changing display parameters .....	<b>PL: 14-31</b>
Clock .....	<b>PL: 14-11</b>
Cursor control .....	<b>PL: 14-32</b>
Date and time .....	<b>PL: 14-11</b>
Debugger window .....	<b>PL: 14-37</b>
Direct clock access .....	<b>PL: 14-16</b>
Display .....	<b>PL: 14-28</b>
Display control characters .....	<b>PL: 14-28</b>
Display parameters .....	<b>PL: 14-30</b>
Display status area .....	<b>PL: 14-35</b>
Display types .....	<b>PL: 14-28</b>
Dumping the display .....	<b>PL: 14-32</b>
Example programs .....	<b>PL: 14-3</b>
Hooks .....	<b>PL: 14-5</b>
Interrupt masks .....	<b>PL: 14-7</b>
Interrupt processing overview .....	<b>PL: 14-5</b>
Interrupts (enabling) .....	<b>PL: 14-7</b>
Introduction .....	<b>PL: 14-1</b>
ISR .....	<b>PL: 14-6</b>
Key actions .....	<b>PL: 14-62</b>
Key buffer .....	<b>PL: 14-48</b>
Key buffer I/O hooks .....	<b>PL: 14-49</b>
Key codes .....	<b>PL: 14-59</b>
Key translation hook .....	<b>PL: 14-51</b>
Keyboard .....	<b>PL: 14-42</b>
Keyboard ISR hook .....	<b>PL: 14-45</b>
Keyboard poll hook .....	<b>PL: 14-46</b>
Keyboard request hook .....	<b>PL: 14-43</b>
Keyboard types .....	<b>PL: 14-42</b>
Keyboards .....	<b>PL: 14-58</b>
Knob .....	<b>PL: 14-56</b>
Language table .....	<b>PL: 14-54</b>
Language types .....	<b>PL: 14-42</b>
Last line of display .....	<b>PL: 14-32</b>

---

**UG:** *Pascal 3.2 User's Guide*  
**WS 1:** *Pascal 3.2 Workstation System, Volume 1*  
**WS 2:** *Pascal 3.2 Workstation System, Volume 2*  
**PL:** *Pascal 3.2 Procedure Library*  
**GT:** *Pascal 3.2 Graphics Techniques*

System devices: (continued)

Menus .....	PL: 14-34
Missed timer interrupts .....	PL: 14-22
Module .....	PL: 14-3
Periodic timer .....	PL: 14-24
Powerfail .....	PL: 14-75
Run light .....	PL: 14-36
Simplified debugger window .....	PL: 14-41
Supported features .....	PL: 14-2
SYSDEVS source listing .....	PL: 14-81
System timer example .....	PL: 14-26
Timer ISR .....	PL: 14-21
Timer operations .....	PL: 14-19
Timers .....	PL: 14-18
Toggle alpha/graphics .....	PL: 14-29
Tone generator .....	PL: 14-9
Typing aids program .....	PL: 14-66
WARNING-You're on your own .....	PL: 14-1
System discs .....	WS 2: 18-4
System files:	
Copying .....	WS 2: 18-34
New sysvol command .....	WS 1: 2-9
What command .....	WS 1: 2-18
System history .....	WS 2: B-1
System key .....	UG: 71
System Library .....	WS 1: 1-4, 2-5, 2-9, 2-10, 2-18, 8-1
System Library:	
Adding modules to it .....	PL: 1-9
Building your own .....	PL: 1-18
Defined .....	PL: 1-6
Volume size considerations .....	PL: 1-8, 1-18
When used by Compiler .....	PL: 1-6
When used by loader .....	PL: 1-7
System programming (extensions) .....	WS 2: 17-1
System time, setting .....	UG: 26, 214
System version .....	WS 1: 2-16
System volume .....	UG: 118, 125, 145, 181, 196, 240
System volume:	
Bubble cards as .....	WS 2: 19-8
Definition .....	WS 1: 3-4

EPROMs as .....	<b>WS 2:</b> 19-20
New sysvol command .....	<b>WS 1:</b> 2-9
Search algorithm .....	<b>WS 2:</b> 18-60
SRM .....	<b>WS 2:</b> 18-79
TABLE selection .....	<b>WS 2:</b> 18-13
Volume listing .....	<b>WS 1:</b> 5-3
What command .....	<b>WS 1:</b> 2-18
SYSTEM_P file .....	<b>WS 2:</b> 18-4, 18-35
systems:	
Memory requirements .....	<b>UG:</b> 275
SYSTEM volume .....	<b>UG:</b> 156
System files .....	<b>WS 2:</b> 18-3

## t

TAB key .....	<b>UG:</b> 97, 108
Tab key .....	<b>UG:</b> 83
TABLE program:	
Auto-configuration .....	<b>WS 2:</b> 18-6
CTABLE source file .....	<b>WS 2:</b> 18-50
Failures .....	<b>WS 2:</b> 18-13
Initialize command .....	<b>WS 1:</b> 2-6
Modifying (CTABLE) .....	<b>WS 2:</b> 18-49
Renaming .....	<b>WS 2:</b> 18-35
Table-of-contents (BACKUP) .....	<b>WS 2:</b> 20-7
TABLES (Compiler option) .....	<b>WS 1:</b> 6-51
Tablets .....	<b>GT:</b> B-1
Talk addresses (HP-IB) .....	<b>PL:</b> 10-5
Tape backup utility .....	<b>WS 2:</b> 20-1, 20-9
Tape drives:	
Access methods .....	<b>WS 2:</b> 19-35
Backup utility .....	<b>WS 2:</b> 20-1
Certify .....	<b>WS 2:</b> 20-13
File System access .....	<b>WS 2:</b> 20-13
Introduction .....	<b>WS 2:</b> 19-35

---

**UG:** *Pascal 3.2 User's Guide*  
**WS 1:** *Pascal 3.2 Workstation System, Volume 1*  
**WS 2:** *Pascal 3.2 Workstation System, Volume 2*  
**PL:** *Pascal 3.2 Procedure Library*  
**GT:** *Pascal 3.2 Graphics Techniques*

Tape drives: (continued)	
List of supported devices .....	<b>WS 2:</b> 19-35
Media-copy .....	<b>WS 2:</b> 20-11
Selective backup .....	<b>WS 2:</b> 20-15
Terminology .....	<b>WS 2:</b> 20-9
Verify .....	<b>WS 2:</b> 20-12
Volume backup .....	<b>WS 2:</b> 20-15
Target vector .....	<b>GT:</b> 5-21
Technical Reference .....	<b>WS 2:</b> B-1
Telephone links (Datacomm) .....	<b>PL:</b> 11-19
Terminal identification (Datacomm) .....	<b>PL:</b> 11-18
Terminal prompt messages (Datacomm) .....	<b>PL:</b> 11-24
Terminating transfers .....	<b>PL:</b> 9-6
Terminology .....	<b>PL:</b> 2-1
Test program .....	<b>GT:</b> 4-4, 4-9
Text .....	<b>GT:</b> 5-35
Text files:	
Creating .....	<b>WS 1:</b> 4-3, 4-4
Declaration .....	<b>WS 2:</b> 15-29
I/O .....	<b>WS 2:</b> 15-29
Representation .....	<b>WS 2:</b> 15-30
Strings .....	<b>WS 2:</b> 15-33
Structure of .....	<b>WS 1:</b> 4-23
Text Record .....	<b>WS 1:</b> 8-33
Text, writing on graphics screen .....	<b>GT:</b> 1-15
Tick marks .....	<b>GT:</b> 1-20, 2-30
Time, setting system .....	<b>UG:</b> 26, 214
Time zone .....	<b>UG:</b> 23
time zone .....	<b>UG:</b> 186
Timeouts .....	<b>PL:</b> 8-1, 8-5
Timeouts (Datacomm) .....	<b>PL:</b> 11-14
Timers (System devices) .....	<b>PL:</b> 14-18
Timing compatibility .....	<b>PL:</b> 2-4
Tone generator (System devices) .....	<b>PL:</b> 14-9
Total available memory .....	<b>UG:</b> 122
Touchscreen .....	<b>GT:</b> B-1, B-2
Tracking the stylus .....	<b>GT:</b> 4-1
Transfers:	
END condition .....	<b>PL:</b> 9-8
Introduction .....	<b>PL:</b> 9-1
Match character .....	<b>PL:</b> 9-8

Overlap .....	<b>PL: 9-6</b>
Serial .....	<b>PL: 9-4</b>
Special .....	<b>PL: 9-8</b>
Termination of .....	<b>PL: 9-6</b>
Word .....	<b>PL: 9-8</b>
Translate command .....	<b>UG: 157, 267</b>
Translate command (Filer) .....	<b>WS 1: 3-15, 5-10, 5-57</b>
TRAP instruction (68000) .....	<b>WS 1: 6-55, 7-11</b>
Triggering (HP-IB) .....	<b>PL: 10-10</b>
TRY .....	<b>PL: 8-2</b>
TRY/RECOVER .....	<b>WS 2: 17-1</b>
TRY/RECOVER blocks .....	<b>PL: 8-1, 8-2, 8-3</b>
Type-ahead buffer .....	<b>UG: 63, 87, 100, 112</b>
Typing aids program (System devices) .....	<b>PL: 14-66</b>

## U

UART (RS-232 interface) .....	<b>PL: 12-1</b>
UCSD (Compiler option) .....	<b>WS 1: 6-52</b>
UCSD Unit I/O operations .....	<b>PL: 1-13</b>
UIO module .....	<b>PL: 1-13</b>
Unassemble commands (Librarian) .....	<b>WS 1: 8-19, 8-21</b>
Unblocked devices .....	<b>WS 2: 18-9</b>
Unit directory command (Filer) .....	<b>WS 1: 5-60</b>
Unit I/O operations .....	<b>PL: 1-13</b>
Unit number assignments .....	<b>UG: 46, 229</b>
Unit numbers:	
How assigned .....	<b>WS 2: 18-8</b>
Initialize command .....	<b>WS 1: 2-6</b>
Logical units .....	<b>WS 1: 3-3</b>
Memory volume command .....	<b>WS 1: 2-7</b>
New sysvol command .....	<b>WS 1: 2-9</b>
Standard assignments .....	<b>WS 2: 18-8</b>
Unit table .....	<b>WS 2: 18-7</b>

---

**UG:** *Pascal 3.2 User's Guide*  
**WS 1:** *Pascal 3.2 Workstation System, Volume 1*  
**WS 2:** *Pascal 3.2 Workstation System, Volume 2*  
**PL:** *Pascal 3.2 Procedure Library*  
**GT:** *Pascal 3.2 Graphics Techniques*

Unit Table .....	<b>WS 1:2-6, 2-9, 3-7</b>
Unit:	
Default unit number .....	<b>UG: 155</b>
Description of .....	<b>UG: 36</b>
Flexible disc drives .....	<b>UG: 46</b>
Prefixing to a unit number .....	<b>UG: 155</b>
Relationship to Volumes .....	<b>UG: 36</b>
Unit Number .....	<b>UG: 42, 227</b>
Unit number .....	<b>UG: 36, 46</b>
Winchester (hard) discs .....	<b>UG: 48</b>
UNITBUSY (function) .....	<b>PL: 1-13</b>
UNITCLEAR (procedure) .....	<b>PL: 1-13</b>
UNITREAD (procedure) .....	<b>PL: 1-13</b>
Units, Blocked and Unblocked .....	<b>WS 1:3-3</b>
UNITWAIT (procedure) .....	<b>PL: 1-13</b>
UNITWRITE (procedure) .....	<b>PL: 1-13</b>
Unlisten and untalk messages (HP-IB) .....	<b>PL: 10-7</b>
UNLK instruction (68000) .....	<b>WS 1:6-56</b>
U.S. ASCII characters .....	<b>WS 2:C-2</b>
User key .....	<b>UG: 71</b>
User restart command .....	<b>UG: 40, 120</b>
User restart Command (Main Level) .....	<b>WS 1:2-15</b>
User-defined keys .....	<b>UG: 76</b>
U.S./European display characters .....	<b>WS 2:C-4</b>
Using the stack .....	<b>WS 1:7-15</b>

## V

Value range prompts .....	<b>UG: 45, 222</b>
Variables, (size of) .....	<b>WS 2:11-5</b>
Variables:	
Global .....	<b>WS 1:2-10, 2-15, 2-17</b>
Zeroing .....	<b>WS 1:2-10, 2-15</b>
Vector, color .....	<b>GT: 5-21</b>
Verification (BACKUP) .....	<b>WS 2:20-10</b>
Verify command (Editor) .....	<b>WS 1:4-52</b>
Version command .....	<b>UG: 122</b>
Version Command (Main Level) .....	<b>WS 1:2-16</b>
Video compatibility hardware .....	<b>WS 2:22-10</b>
Viewport, Defining .....	<b>GT: 1-13</b>

Viewport, defining .....	<b>GT: 2-2</b>
Virtual coordinates .....	<b>GT: 1-13</b>
Vision, color .....	<b>GT: 5-36</b>
Vols command .....	<b>UG: 46, 48, 156, 262</b>
Volume ID .....	<b>UG: 36, WS 1: 3-7</b>
Volume:	
Changing a volume name .....	<b>UG: 152, 259, 260</b>
Compacting free space .....	<b>UG: 154, 263</b>
CONSOLE .....	<b>UG: 156</b>
Contents of system volumes .....	<b>UG: 276</b>
Copying Entire .....	<b>UG: 254</b>
Default volume .....	<b>UG: 118, 155, 183, 241</b>
Description of .....	<b>UG: 35</b>
Directory .....	<b>UG: 35</b>
Listing on-line volumes .....	<b>UG: 156, 262</b>
Memory .....	<b>UG: 123, 180, 239</b>
On-line .....	<b>UG: 156, 262</b>
Prefix volume .....	<b>UG: 155</b>
PRINTER .....	<b>UG: 156</b>
RAM .....	<b>UG: 123, 180, 239</b>
Relationship to Units .....	<b>UG: 36</b>
Removable .....	<b>UG: 36</b>
System volume .....	<b>UG: 118, 125, 145, 181, 240</b>
SYSTEM .....	<b>UG: 156</b>
Volume ID .....	<b>UG: 35, 42, 46, 227</b>
Zeroing .....	<b>UG: 33</b>
Volumes .....	<b>PL: 1-8</b>
Volumes command .....	<b>UG: 46, 48, 156, 262</b>
Volumes command (Filer) .....	<b>WS 1: 3-2, 5-3, 5-61</b>
Volumes on-line, listing .....	<b>UG: 156, 262</b>

---

**UG:** *Pascal 3.2 User's Guide*  
**WS 1:** *Pascal 3.2 Workstation System, Volume 1*  
**WS 2:** *Pascal 3.2 Workstation System, Volume 2*  
**PL:** *Pascal 3.2 Procedure Library*  
**GT:** *Pascal 3.2 Graphics Techniques*

## Volumes:

Auto-configuration .....	<b>WS 2:</b> 18-7
Backing up .....	<b>WS 1:</b> 5-12
Default volume .....	<b>WS 1:</b> 3-4
General .....	<b>WS 1:</b> 3-2
Pascal .....	<b>WS 1:</b> 3-2
Prefix volume .....	<b>WS 1:</b> 3-4
PRINTER .....	<b>WS 2:</b> 18-18
Renaming .....	<b>WS 1:</b> 5-18
Specification (syntax) .....	<b>WS 1:</b> 5-25
Syntax of identifier .....	<b>WS 1:</b> 3-7
System volume .....	<b>WS 1:</b> 3-4

## W

WARN (Compiler option) .....	<b>WS 1:</b> 6-53
What command .....	<b>GT:</b> 1-4, <b>PL:</b> 1-6, 1-9, <b>UG:</b> 117, 181, 240
What command (Filer) .....	<b>WS 1:</b> 5-62
What command (Main Level) .....	<b>WS 1:</b> 2-18
Wildcards .....	<b>UG:</b> 152, 175, 206, 251, 257, <b>WS 1:</b> 3-16, 5-9
Winchester disc:	
Autostart file .....	<b>UG:</b> 187
Booting from .....	<b>UG:</b> 177
Copying Pascal system .....	<b>UG:</b> 172, 236
Formatting .....	<b>UG:</b> 28, 225
Initialization .....	<b>UG:</b> 28, 225
Unit number assignments .....	<b>UG:</b> 48, 230
Window frame, drawing .....	<b>GT:</b> 2-5
Window limits, calculating .....	<b>GT:</b> 2-3
Word .....	<b>PL:</b> 2-7
Word transfers .....	<b>PL:</b> 9-8
Words .....	<b>PL:</b> 5-4
Workfile .....	<b>WS 1:</b> 4-24, 5-20, 6-6
Workfile:	
Clearing .....	<b>UG:</b> 157, 250
Compiling .....	<b>UG:</b> 166, 194, 200, 203
Creation .....	<b>UG:</b> 140, 147, 247, 248
Decision to use .....	<b>UG:</b> 192, 193
Deleting .....	<b>UG:</b> 157
Description of .....	<b>UG:</b> 144

Running a program .....	UG: 119, 201, 203
Saving .....	UG: 147, 193, 204, 245, 249
Updating in Editor .....	UG: 140
World coordinates .....	GT: 1-13, B-11, B-12
WRITE (files) .....	WS 2: 15-26
Write-protection (flexible discs) .....	UG: 15
WRITEDIR (files) .....	WS 2: 15-28
WRITELN procedure .....	GT: 1-25
Writing data .....	PL: 5-1
Writing modes .....	GT: 5-30
Writing text on graphics screen .....	GT: 1-15
Writing to buffers .....	PL: 9-3
WS1.0 file names .....	WS 1: 3-18

## X

Xchg command .....	UG: 133
--------------------	---------

## Y

Yes/No prompts .....	UG: 44, 222
----------------------	-------------

## Z

Zap command (Editor) .....	WS 1: 4-55
Zero command .....	UG: 33
Zero command (Filer) .....	WS 1: 5-63
Zeroing a volume .....	UG: 33

---

**UG:** *Pascal 3.2 User's Guide*  
**WS 1:** *Pascal 3.2 Workstation System, Volume 1*  
**WS 2:** *Pascal 3.2 Workstation System, Volume 2*  
**PL:** *Pascal 3.2 Procedure Library*  
**GT:** *Pascal 3.2 Graphics Techniques*





**HP Part Number  
98615-90017**

Microfiche No. 98615-99017  
Printed in U.S.A. 7/87



**98615-90623**

For Internal Use Only