



Agilent E3668B

Feedthru Panel Kit

For:

E7590A— 1.3 meter Instrument Rack

E3661B— 1.6 meter Instrument Rack

E3662B— 2.0 meter Instrument Rack

Installation Guide



Agilent Technologies

November 2001
Printed in U.S.A. E1101



E3668-90002

Errata

Agilent References in this manual

NOTICE: This document contains references to Agilent Technologies. Agilent's former Test and Measurement business has become Keysight Technologies. For more information, go to:

www.keysight.com

About this manual

We've added this manual to the Keysight website in an effort to help you support your product. This manual provides the best information we could find. It may be incomplete or contain dated information.

Support for your product

You can find information about technical and professional services, product support, and equipment repair and service on the web:

www.keysight.com

Select your country from the drop-down menu at the top. Under *Electronic Test and Measurement*, click on *Services*. The web page that appears next has contact information specific to your country.

For more detailed product information, go to: www.keysight.com/find/ <product model>
i.e., for the M9514A, use: www.keysight.com/find/M9514A

Hypertext links to documents on agilent.com are no longer active. Use this substitution to access PDF files:

Broken links have the form: <http://cp.literature.agilent.com/litweb/pdf/> < literature_part_number >

Substitute links with this form: <http://literature.cdn.keysight.com/litweb/pdf/> < literature_part_number >

Where < literature_part_number > has the form: M9300-90001.pdf

For service notes, use: www.keysight.com/find/servicenotes

Notice

The information contained in this document is subject to change without notice.

AGILENT TECHNOLOGIES MAKES NO WARRANTY OF ANY KIND WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

Agilent Technologies shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this material. This document contains proprietary information, which is protected by copyright. All rights are reserved. No part of this document may be photocopied, reproduced, or translated into another language without the prior written consent of Agilent Technologies.

Copyright © 1998, 2001 Agilent Technologies, Inc.

Contents

The E3668B Feedthru Panel Kit contains the following items.

Item	Quantity	Description	Part Number
1	1	Feedthru Panel	E3668-60002
2	2	Sheet Metal Nuts (10-32)	0590-0804
3	2	Screw, special, 10-32 x 0.5"	0570-1366
4	1	Installation Instruction Sheet	E3668-90002

Tools Required

To install the Feedthru Panel Kit, you will need a Phillips screwdriver

Installation Procedure

Refer to the illustration on page 4. The feedthru panel occupies 1 EIA unit (44 mm). The panel is designed to attach to the center hole within the EIA envelope.

1. Locate the appropriate holes on the front columns of the rack.
2. Position the two sheet metal nuts over the appropriate holes in the front columns.
3. Attach the feedthru panel to the front columns of the rack using two screws.
4. Route the cables through the openings in the feedthru panel.

This completes installation of the Feedthru Panel Kit.

Place this *Note* with your rack documentation.

