

EMERGING COMMUNICATIONS TECHNOLOGY INSTITUTE UNIVERSITY OF TORONTO

SiO2 etch on Phantom etcher

Document Number: Document Owner: ECTI Approved by: Created : Revision #: Revision date: July 4, 2008

Summary:

This document is a basic recipe for etching thin films of SiO using the Trion Phantom etcher.

Table of content

1	Associated Documents & References	1
2	Equipment Used	1
3	Verifications Prior to Processing	1
4	Recipe description	2
5	Technical Data	2
6	Measurements & Statistical Process Control	2
	6.1 Measurements	Fout! Bladwijzer niet gedefinieerd.
7	Record of Revisions	2

1 Associated Documents & References

MSDS if chemicals or gas involved. Phantom etcher standard operating procedure Rules and procedures of cleanroom

2 Equipment Used

Phantom Etcher (www.triontech.com) in Bahen Cleanroom. This equipment has to be reserved through the online resource scheduler. If you need to be assisted by the technician, check availability with him before reserving the equipment. Users have to go through regular training before using this equipment alone.

3 Verifications Prior to Processing

Chamber clean. No air leaks into etcher.



EMERGING COMMUNICATIONS TECHNOLOGY INSTITUTE UNIVERSITY OF TORONTO

4 Recipe description

1. Set up Phantom etcher with the following parameters

Pump chamber for 10 minutes with no gas flowing, no RF power and pressure set to 0 mTorr.

pressure 150 mTorr, RIE 100 watts, CHF3 45 sccm O2 5 sccm He backside cooling 2 Torr. Enter an etch time based on an etch rate of approximately 180 nm per minute.

Add a pumpdown (no gas, no RF) and cooling step at the end of the etch of 10 minutes.

- 2. Load the empty carrier into the chamber
- 3. Ensure the chamber walls are clean and vacuum any loose particulates.

4 Do a "conditioning" run with the above steps. This aids in cleaning the walls, degassing/conditioning the walls and warming up the chamber in preparation for the sample etch.

5. Check the reflected power is low (less than 10 watts). A high reflected power indicates poor plasma conditions or circuit tuning is not working.

6. Check the color of the plasma during the "conditioning" . If there is any residual air or water vapor the color will be off.

7. Quickly load sample onto carrier minimize absorption of air and water vapor on the walls and close the lid.

- 6. Run etch recipe.
- 7. Check the reflected power and color of the plasma during etching.

Allow a cooldown period of 10 minutes before retrieving the sample.

5 Technical Data

Etch rate, selectivity and profile depends on the size of the feature, the depth of the feature and how much open area and density the pattern occupies. The parameters in the recipe will have to be varied in order to find the optimum etch conditions for the sample.

6 Measurements & Statistical Process Control

7 Record of Revisions

Rev. 0

First Edition