

Users Guide

HP 81533B Optical Head Interface Module, HP 81520A, HP 81521B, HP 81524A, and HP 81525A Optical Heads

SERIAL NUMBERS

This manual applies to all instruments listed above, and also to the HP 81533A Optical Head Interface Module.



**HP Part No. 81533-90014
Printed in Germany**

**Fifth Edition
E0598**

Notices

This document contains proprietary information that is protected by copyright. All rights are reserved.

No part of this document may be photocopied, reproduced, or translated to another language without the prior written consent of Hewlett-Packard GmbH.

© Copyright 1997 by:
Hewlett-Packard GmbH
Herrenberger Str. 130
71034 Boeblingen
Germany

Subject Matter

The information in this document is subject to change without notice.

Hewlett-Packard makes no warranty of any kind with regard to this printed material, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose.

Hewlett-Packard shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this material.

Printing History

New editions are complete revisions of the guide reflecting alterations in the functionality of the instrument. Updates are occasionally made to the guide between editions. The date on the title page changes when an updated guide is published. To find out the current revision of the guide, or to purchase an updated guide, contact your Hewlett-Packard representative.

Warranty

This Hewlett-Packard instrument product is warranted against defects in material and workmanship for a period of one year from date of shipment. During the warranty period, HP will, at its option, either repair or replace products that prove to be defective.

For warranty service or repair, this product must be returned to a service facility designated by HP. Buyer shall prepay shipping charges to HP and HP shall pay shipping charges to return the product to Buyer. However, Buyer shall pay all shipping charges, duties, and taxes for products returned to HP from another country.

HP warrants that its software and firmware designated by HP for use with an instrument will execute its programming instructions when properly installed on that instrument. HP does not warrant that the operation of the instrument, software, or firmware will be uninterrupted or error free.

Limitation of Warranty

The foregoing warranty shall not apply to defects resulting from improper or inadequate maintenance by Buyer, Buyer-supplied software or interfacing, unauthorized modification or misuse, operation outside of the environmental specifications for the product, or improper site preparation or maintenance.

No other warranty is expressed or implied. Hewlett-Packard specifically disclaims the implied warranties of Merchantability and Fitness for a Particular Purpose.

Exclusive Remedies

The remedies provided herein are Buyer's sole and exclusive remedies. Hewlett-Packard shall not be liable for any direct, indirect, special, incidental, or consequential damages whether based on contract, tort, or any other legal theory.

Assistance

Product maintenance agreements and other customer assistance agreements are available for Hewlett-Packard products. For any assistance contact your nearest Hewlett-Packard Sales and Service Office.

Certification

Hewlett-Packard Company certifies that this product met its published specifications at the time of shipment from the factory.

Hewlett-Packard further certifies that its calibration measurements are traceable to the United States National Institute of Standards and Technology, NIST (formerly the United States National Bureau of Standards, NBS) to the extent allowed by the Institutes's calibration facility, and to the calibration facilities of other International Standards Organization members.

ISO 9001 Certification

Produced to ISO 9001 international quality system standard as part of our objective of continually increasing customer satisfaction through improved process control.

Control Serial Number: Edition 3 applies directly to all instruments.

Edition 1 : 1st May 1990 : 81533-90011 : E0590 ; 1st December 1990 : 81533-90011 : E1290

Edition 2 : 1st December 1991 : 81533-90012 : E1291

Edition 3 : 1st March 1993 : 81533-90013 : E0393

Edition 4 : 1st May 1994 : 81533-90014 : E0594; 1st December 1994 : 81533-90014 : E1294

1st July 1996 : 81533-90014 : E0796; 1st May 1997 : 81553-90014 : E0597

Edition 5 : 1st May 1998 : 81533-90014 : E0598

Safety Considerations

Before operation, review the instrument and manual, including the red safety page, for safety markings and instructions. You must follow these to ensure safe operation and to maintain the instrument in safe condition.

Initial Inspection

Inspect the shipping container for damage. If there is damage to the container or cushioning, keep it until you have checked the contents of the shipment for completeness and verified the module both mechanically and electrically.

The Performance Tests give procedures for checking the operation of the module. If the contents are incomplete, mechanical damage or defect is apparent, or if a module does not pass the operator's checks, notify the nearest Hewlett-Packard office.

Warning



To avoid hazardous electrical shock, do not perform electrical tests when there are signs of shipping damage to any portion of the outer enclosure (covers, panels, etc.).

Power Requirements

The HP 81533B operates when installed into the HP 8153A Optical Multimeter mainframe.

Operating Environment

The HP 8153A safety information summarizes the HP 81533B operating environment ranges. In order for the HP 81533B to meet specifications, the operating environment must be within the limits specified in this section.

Input/Output Signals

Caution

A maximum of 15V can be applied as an external voltage to any BNC connectors.

Storage and Shipment

The module can be stored or shipped at temperatures between -40°C and $+70^{\circ}\text{C}$. Protect the module from temperature extremes that may cause condensation within it.

Contents

C. HP 81533B, HP 81520A, HP 81521B, HP 81524A, and HP 81525A Specifications	
Supplementary Performance Characteristics	C-3
HP 81050AL Lens	C-4
HP 81010BL and HP 81050BL Lens	C-4
Optical Connections	C-4
Compensating for Lens Loss	C-6
D. HP 81533B and Optical Heads Performance Tests	
Introduction	D-1
Test Record	D-1
Test Failure	D-1
Instrument Specification	D-2
Module Function Tests	D-3
Equipment Required	D-3
Function Test	D-3
Static and Dynamic Tests	D-3
Gain/Range Calibration Accuracy Test	D-6
HP 81520A, HP 81521B, HP 81524A, and HP 81525A Performance Tests	D-12
Equipment Required	D-12
HP 81520A	D-12
HP 81521B	D-13
HP 81524A or HP 81525A	D-14
Performance Test	D-14
Accuracy and Linearity Tests	D-15
I. Accuracy Test	D-15
II. Linearity Test	D-16

E. Cleaning Procedures

How to clean instruments with a recessed lens interface	E-1
Light dirt	E-1
Heavy dirt	E-1

Index

Figures

C-1. Optical Connections	C-5
C-2. Optical Connections	C-6
D-1. Accuracy Test Set-Up	D-15
D-2. HP 81525A Linearity Test Test Set-Up	D-17
D-3. Addition of results (example)	D-20

HP 81533B, HP 81520A, HP 81521B, HP 81524A, and HP 81525A Specifications

Specifications describe the instrument's warranted performance. Supplementary performance characteristics describe the instrument's non-warranted typical performance.

Because of the modular nature of the instrument, these performance specifications apply only to this module. You should insert these pages into the appropriate section of the manual.

C

HP 81533B Specifications

	HP 81533B with HP 81520A Optical Head	HP 81533B with HP 81521B Optical Head	HP 81533B with HP 81524A Optical Head	HP 81533B with HP 81525A Optical Head
Sensor Element	Si, 5mm	Ge, 5mm	InGaAs, 5mm	
Wavelength range	450-1020nm	900-1700nm	800-1650nm	
Power range	+ 10 to -100dBm	+ 3 to -80dBm	+ 3 to -90dBm	+ 27 to -70dBm (1250 to 1650nm) + 23 to -70dBm (800 to 1650nm)
Display resolution	0.001dB/dBm (0.0001dB/dBm on printout), 0.01pW to 10pW (depending on power range)			
Applicable fiber type	parallel beam, 9/125 μ m - 100/140 μ m, NA \leq 0.3			
Uncertainty (Accuracy) at reference conditions^[1]	\pm 2.2% (600-1020nm)	\pm 2.2% (1000-1650nm)	\pm 2.2% (1000-1600nm)	\pm 3% (900-1600nm)
Total Uncertainty^[2]	\pm 4% \pm 0.5pW (600-1020nm)	\pm 4% \pm 50pW (1000-1650nm)	\pm 4% \pm 5pW (1000-1600nm)	\pm 5% \pm 500pW ^[3] (900-1600nm)
Linearity 18°C to 28°C const. temp Operating temp. range const. temp	(+ 3 to -80dBm) \pm 0.04dB \pm 0.5pW \pm 0.15dB \pm 0.5pW	(0 to -60dBm) \pm 0.04dB \pm 50pW \pm 0.15dB \pm 50pW	(+ 3 to -70dBm) \pm 0.04dB \pm 5pW \pm 0.15dB \pm 5pW	(+ 10 to -50dBm) ^[3] \pm 0.04dB \pm 500pW \pm 0.15dB \pm 500pW
Noise peak-peak, avg. time 1sec	<0.5pW (700-900nm)	<50pW (1200-1600nm)	<5pW (1000-1600nm)	<500pW (900-1600nm)
Operating Temperature	0°C to +40°C			0°C to +35°C ^[4]
Dimensions				
Module	75mm H, 32mm W, 335mm D (2.8" \times 1.3" \times 13.2")			
Head	37.5mm Diameter, 140mm Long (1.5" \times 5.5")			
Weight				
Module	net 0.6kg (1.3lbs), shipping 1kg (2.2lbs)			
Head	net 0.45kg (1lbs), shipping 1kg (2.2lbs)			
Recalibration period	2 years			
Warmup time	20 min.			
The display may vary by \pm 1 count.				

Information on the traceability of power meters is available on request

[1] at the following reference conditions:

- Power level 10 μ W (-20dBm), Continuous Wave (CW).
- Parallel beam, 3mm spot diameter on detector.
- Ambient temperature 23°C \pm 5K
- At day of calibration. (add 0.3% for aging over one year, add 0.6% over two years).
- Spectral width of source <10nm

C-2 HP 81533B, HP 81520A, HP 81521B, HP 81524A, and HP 81525A Specifications

[2] at the following operating conditions:

- Parallel beam, 3mm spot diameter on detector, or connectorized fiber with $NA \leq 0.2$
- Ambient temperature 0 to 40°C, non-condensating.
- Within 1 year after calibration, add 0.3% for the second year.

[3] Add 0.008dB/10mW between 10 and 27dBm.

- Lens required (for example for SM 81010BL, for MM 81050BL) or parallel beam, 3mm spot diameter on detector.
- Wavelength range 950-1650 nm.

[4] 30°C for >20dBm input power.

Supplementary Performance Characteristics

Add 1% to total uncertainty for the full wavelength range (except HP 81525A: see footnote 3).

Outside the specified wavelength range, the noise increases by up to 5 times the value shown above.


For fiber applications with NA between 0.2 and 0.3 use specific lenses and add 0.5% total uncertainty for the 850±50nm, 1300±50nm, and 1550±50nm range.

Analog output	
bandwidth	$\geq DC, \leq 300$ to 1000Hz depending on range and optical head
output voltage	0 to 2V into open
output impedance	600Ω typ.
max. input voltage	±10V

HP 81050AL Lens

Attenuation at 850 nm (AL-type) is printed on each lens. This value must be entered into the power meter using the CAL parameter, for precise measurements.


Typical attenuation over wavelength for the 81050AL, exactly measured at 850 nm:



HP 81010BL and HP 81050BL Lens

Attenuation at 1300/1550 nm (BL-type) is printed on each lens. This value must be entered into the power meter using the CAL parameter, for precise measurements.

Typical attenuation over wavelength for the 81010BL and 81050BL, exactly measured at 1300 nm and 1550 nm:



Optical Connections

For the optical head, various accessories can be ordered that aid measurement, as well as connection to bare or terminated fibers. Depending on which accessories you ordered, Figure C-1 shows the sequence in which you attach them to the HP 81520A. Figure C-2 shows the sequence in which you attach them to the HP 81521B and the HP 81524A.

C-4 HP 81533B, HP 81520A, HP 81521B, HP 81524A, and HP 81525A Specifications




Figure C-1. Optical Connections




Figure C-2. Optical Connections

Compensating for Lens Loss. If you are using one of the optical heads with a lens, the attenuation loss has been individually measured at the factory. This measured value is marked on the lens casing as a “CAL” factor, for example CAL -.19dB.

You should enter this CAL factor, together with any other known losses for your measurement system, to compensate for the non-ideal nature of the measuring equipment.

HP 81533B and Optical Heads Performance Tests

Introduction

The procedures in this section test the electrical performance of the instrument. The complete specifications to which the HP 81533B, with an optical head, is tested are given in Appendix C. All tests can be performed without access to the interior of the instrument. The test equipment given corresponds to tests carried out with Diamond HMS-10/HP connectors.

Test Record

Results of the performance test may be tabulated on the Test Record provided after the test procedures. It is recommended that you fill out the Test Record and refer to it while doing the test. Since the test limits and setup information are printed on the Test Record for easy reference, the record can also be used as an abbreviated test procedure (if you are already familiar with the test procedures). The Test Record can also be used as a permanent record and may be reproduced without written permission from Hewlett-Packard.

Test Failure

If the HP 81533B or the optical head fails any performance test, return it to the nearest Hewlett-Packard Sales/Service Office for repair.

D

Instrument Specification

Specifications are the performance characteristics of the instrument that are certified. These specifications, listed in Appendix C, are the performance standards or limits against which to test. Appendix C also lists some supplemental characteristics. Supplemental characteristics should be considered as additional information.

Any changes in the specifications due to manufacturing changes, design, or traceability to the National Bureau of Standards, are covered in a manual change supplement, or revised manual. Such specifications supersede any that were previously published.

Module Function Tests

Equipment Required

Equipment required for the function test is listed in the table below. Any equipment that satisfies the critical specifications of the equipment given in the table, may be substituted for the recommended models.

Instrument/Accessory	Recommended Model
Multimeter Mainframe	HP 8153A
Optical Head	HP 81520A, HP 81521B, HP 81524A, or HP 81525A
Digital Multimeter	HP 3466A, with test leads.
BNC to BNC cable	HP 10102A
BNC(m) to dual Banana plug	HP 10110B
Test/Cal Box	P/N 08152-63201
Head Recognition Adapter	P/N 08152-63211
Test Cable	P/N 08153-61610
BNC(f) to dual Banana plug	P/N 1251-2277
DC Standard	with adapter cables
Oscilloscope	

Function Test

The function test given in this section is using the HP 8153A with the HP 81533B Optical Head Adapter Module and the 08152- 63201 Test/Cal Box to check voltages and signals to and from the HP 81520A/21B Optical Heads. Perform each step in the tests in the order given, using the corresponding equipment.

Static and Dynamic Tests

1. Insert the HP 81533B into the mainframe channel A position and connect the test/cal box to its input.
2. Make sure that the head recognition adapter is connected to the test/cal box.
3. Turn power on and check that all display segments are lit for approximately 2 seconds and check that the HP 8153A then displays the error message E3200 HEAD-DAT SELFTEST.
4. To test the constant voltages:

D

- a. Using the test cable check the following DC levels at test/cal box receptacles

Receptacle Expected Value

+15V +15±0.8V

-15V -15±0.8V

P.CTRL 0V

STATUS 0V

5. To test the ranging:

- a. The states of RANGE 0 and RANGE 1 depend on the respective HP 8153A range settings.
- b. Press **Auto** to make sure that autoranging is OFF.
- c. Select the following ranges with **Up** and **Down**. In each case, check the status of the range selection signal on the RANGE 0 and RANGE 1 receptacle on the test/cal box.

dBm Range	RANGE 0	RANGE 1
0	H	H
-10	H	H
-20	H	L
-30	H	L
-40	H	L
-50	L	L

6. To test the +5V:

- a. Set the oscilloscope as follows:
- Input to 2V/DIV, DC Coupled, 1MΩ.
 - Timebase to 0.005s/DIV.
 - Sweep mode to AUTO.

Note

When performing this test and the following tests, each time, after pressing the switch on the head recognition adapter, the message ER 3200 HEAD-DAT appears. To continue the tests or to repeat a test, the error state must be overwritten by pressing any key on the HP 8153A front panel.

D

- b. Use the test cable to connect the +5V receptacle to the oscilloscope.
 - c. Check that, when you press the switch on the head recognition adapter, the +5V output switches from 0V to +5V and then back to 0V after approximately 2 seconds.
7. To test the data clock (see also the note to step 6):
- a. Use the test cable to connect the CLOCK receptacle to the oscilloscope.
 - b. Check that, when you press the switch on the head recognition adapter, the CLOCK outputs clock pulses for approximately 4 seconds, going from +5V to 0V.
8. To test the \overline{OE} (see also the note to step 6):
- a. Use the test cable to connect the \overline{OE} receptacle to the oscilloscope.
 - b. Check that, when you press the switch on the head recognition adapter, the \overline{OE} output switches from +5V to 0V and then back to +5V after approximately 2 seconds.
9. To test the ON/OFF (see also the note to step 6):
- a. Use the test cable to connect the ON/OFF receptacle to the oscilloscope.
 - b. Check that the ON/OFF output is at +15V while you are pressing the switch on the head recognition adapter, and at +5V when you release the switch.
10. To test the Peltier Control:
- a. Change the input sensitivity of the oscilloscope to 0.05V/DIV and connect the test cable from the P.CTRL receptacle to the oscilloscope.
 - b. Watch the DC level displayed on the oscilloscope and connect instead of the head recognition adapter the HP 81520A, HP 81521B, HP 81524A, or HP 81525A Optical Head.
 - c. After a few seconds, the P.CTRL voltage should change from approximately 130mV to approximately 30mV (HP 81520A), from

D

approximately 150mV to approximately 40mV (HP 81521B)) or from approximately 130mV to approximately 50mV (HP 81524A, or HP 81525A).

Gain/Range Calibration Accuracy Test

Note



These measurements are very dependent on the condition of the test setup. Before beginning these tests, check the equipment for possible ground loops and shielding problems and make sure that the line supply is free of disturbances.

11. To test the gain/range calibration accuracy:
 - a. Connect the DC standard to the BNC connector marked “8152A IN” on the test/cal box. Make sure that the DC standard is set to 0 volts.
 - b. Make sure the instrument is in MEASure mode, and press **(dBm/W)** to make sure that the display is in Watts.
 - c. Press **(Param)** to select the CAL parameter. Reset the calibration to 0 by holding **(Param)** down for 3 seconds.
 - d. Press **(Zero)** to zero the instrument. Select the -20dBm range with **(Up)** and **(Down)**.
 - e. Check that, at the DC standard settings, and Range settings given in the table, you get the readings indicated.

Range	DC Standard Setting	Reading
-20	0.0000V	0.00 μ W
-20	+7.6000V	19.000 μ W(\pm 40 counts)
-20	+0.7600V	1.900 μ W(\pm 4 counts)
-30	+0.7600V	1900.0nW(\pm 40 counts)
-30	+0.0760V	190.0nW(\pm 4 counts)
-40	+0.0760V	190.00nW(\pm 40 counts)
-40	+0.0076V	19.00nW(\pm 4 counts)

D



Function Test for the HP 81533B

Page 1 of 4

D

Test Facility:

_____	Report No.	_____
_____	Date	_____
_____	Customer	_____
_____	Tested By	_____

Model HP 81533B Optical Head Interface Module

Serial No. _____ Ambient temperature _____ °C

Options _____ Relative humidity _____ %

Firmware Rev. _____ Line frequency _____ Hz

Special Notes:

Performance Test for the HP 81533B

D 

Test Equipment Used:

Description	Model No.	Trace No.	Cal. Due Date
1. Lightwave Multimeter (Std.)	HP 8153A	_____	_____
2 Opt. Head Interface Module	HP 81533B	_____	_____
3a. Optical Head 850nm	HP 81520A	_____	_____
3b. Optical Head 1310, 1550nm	HP 81521B	_____	_____
3c. Optical Head 1310, 1550nm	HP 81524A	_____	_____
3d. Optical Head 1310, 1550nm	HP 81525A	_____	_____
4. BNC to BNC Cable	HP 10102A		
5. BNC(m) to dual banana plug	HP 10110B		
6. Test/Cal Box	08152-63201		
7. Head Recognition Adapter	08152-63211		
8. Test Cable	08153-61610		
9. BNC(f) to dual banana plug	1251-2277		
10. DC Standard with Adapter Cables	_____	_____	_____
11. Oscilloscope	_____	_____	_____
12. _____	_____	_____	_____
13. _____	_____	_____	_____

Function Test for the HP 81533B

D

Model HP 81533B Opt. Head Int. Module No. _____ Date _____

Test Description		Pass	Fail
Static and Dynamic Test			
Parameter	Expected Value		
+15V	+15±0.8V	—	—
-15V	-15±0.8V	—	—
P.CTRL	0V	—	—
STATUS	0V	—	—
RANGE 0	High in the 0dBm to -40dBm ranges Low in the -50dBm range	—	—
RANGE 1	High in the 0dBm to -10dBm ranges Low in the -20dBm to -50dBm ranges	—	—
+5V	0V→+5V→0V	—	—
MODE 0	0V→+5V→0V	—	—
MODE 1	0V→+5V→0V	—	—
CLOCK	Pulses from +5V to 0V	—	—
\overline{OE}	+5V→0V→+5V	—	—
ON/OFF	+5V→+15V→+5V	—	—
P.CTRL	Peltier Regulation	—	—

Function Test for the HP 81533B

D 

Model HP 81533B Opt. Head Int. Module No. _____ Date _____

Test Description		Result		
Gain/Range Accuracy Test				
Range	DC Standard Setting	Minimum	Actual	Maximum
-20dBm	0.0000V	0.000 μ W	_____	0.000 μ W
-20dBm	+7.6000V	18.960 μ W	_____	19.040 μ W
-20dBm	+0.7600V	1.896 μ W	_____	1.904 μ W
-30dBm	+0.7600V	1896.0nW	_____	1904.0nW
-30dBm	+0.0760V	189.6nW	_____	190.4nW
-40dBm	+0.0760V	189.60nW	_____	190.40nW
-40dBm	+0.0076V	18.96nW	_____	19.04nW

D

HP 81520A, HP 81521B, HP 81524A, and HP 81525A Performance Tests

Equipment Required

Equipment required for the performance test is listed below. Any equipment that satisfies the critical specifications of the equipment given in the table, may be substituted for the recommended models.

HP 81520A

Instrument/Accessory	Rec. Model	Required Characteristic
Power Meter Standard #C01	HP 8153A Lightwave Multimeter Mainframe with HP 81533B Optical Head Interface Module with HP 81520A Optical Head.	Uncertainty $\pm 1.5\%$
CW Laser Source	HP 8153A Lightwave Multimeter Mainframe with HP 81551MM 850nm Laser Source Module.	Wavelength Uncertainty $\pm 2\text{nm}$
Optical Attenuator	HP 8158B Option 001/011*	
Lens Adapter	HP 81050AL	
Connector Adapter	HP 81000AA	
Plastic Cap	5040-9361 ($\times 2$)	

* or equivalent:

Attenuation range	0 to 30dB
Resolution	0.01dB
Return Loss	$>27\text{dB}$

HP 81521B

Instrument/Accessory	Rec. Model	Required Characteristic
Power Meter Standard #C01	HP 8153A Lightwave Multimeter Mainframe with HP 81533B Optical Head Interface Module with HP 81521B Optical Head	Uncertainty $\pm 1.5\%$
CW Laser Source	HP 8153A Lightwave Multimeter Mainframe with HP 81552SM 1310nm Laser Source Module and HP 81553SM 1550nm Laser Source Module	Wavelength Uncertainty $\pm 1.5\text{nm}$
	<i>OR</i>	
	HP 8153A Lightwave Multimeter Mainframe with HP 81554SM 1310/1550nm Laser Source Module.	Wavelength Uncertainty $\pm 1.5\text{nm}$
Optical Attenuator	HP 8156A Option 101	
Connector Interface	HP 81000AI ($\times 2$)	
Singlemode Fiber	HP 81101AC ($\times 2$)	
Lens Adapter	HP 81010BL	
Connector Adapter	HP 81000AA	
Plastic Cap	5040-9361 ($\times 2$)	

D

D

HP 81524A or HP 81525A

Instrument/Accessory	Rec. Model	Required Characteristic
Power Meter Standard #C01	HP 8153A Lightwave Multimeter Mainframe with HP 81533B Optical Head Interface Module with HP 81524A Optical Head	Uncertainty $\pm 1.5\%$
CW Laser Source	HP 8153A Lightwave Multimeter Mainframe with HP 81552SM 1310nm Laser Source Module and HP 81553SM 1550nm Laser Source Module	Wavelength Uncertainty $\pm 1.5\text{nm}$
<i>OR</i>		
	HP 8153A Lightwave Multimeter Mainframe with HP 81554SM 1310/1550nm Laser Source Module.	Wavelength Uncertainty $\pm 1.5\text{nm}$
Optical Attenuator	HP 8156A Option 101	
Connector Interface	HP 81000AI ($\times 2$)	
Singlemode Fiber	HP 81101AC ($\times 2$)	
Lens Adapter	HP 81010BL	
Connector Adapter	HP 81000AA	
Plastic Cap	5040-9361 ($\times 2$)	

Performance Test

The performance tests given in this section are separated into Accuracy Test and Linearity Test. Perform each step in the tests in the order given, using the corresponding test equipment.

Note



Make sure that all optical connections of the test setups given in the procedure are dry and clean. **DO NOT USE INDEX MATCHING OIL** (see cleaning procedure).

The Optical Cables from the Laser Source to and from the HP 8156A Attenuator to the Power Meter must be fixed on the table to ensure minimum cable movement during the tests.

D [Redacted]

Accuracy and Linearity Tests

Specifications: HP 81520A

Uncertainty: $\pm 2.5\%$ (600-1020 nm) including aging.
Linearity: $\pm 0.04\text{dB} \pm 0.5\text{pW}$ rel. to -20dBm

Specifications: HP 81521B

Uncertainty: $\pm 2.5\%$ (1000-1650 nm) including aging.
Linearity: $\pm 0.04\text{dB} \pm 50\text{pW}$ rel. to -20dBm

Specifications: HP 81524A

Uncertainty: $\pm 2.5\%$ (1000-1600 nm) including aging.
Linearity: $\pm 0.04\text{dB} \pm 5\text{pW}$ rel. to -20dBm

Specifications: HP 81525A

Uncertainty: $\pm 3.3\%$ (900-1600 nm) including aging.
Linearity: $\pm 0.04\text{dB} \pm 500\text{pW}$ rel. to -20dBm

I. Accuracy Test

The following gives the procedure for performing the accuracy test for the HP 81520A, HP 81521B, HP 81524A, or the HP 81525A with the HP 8153A and the HP 81533B:




Figure D-1. Accuracy Test Set-Up

D

1. Make sure that the cable connectors, lenses and detector windows are clean. Refer to the cleaning procedure.
2. Connect the equipment as shown in Figure D-1. Ensure that the cables to and from the Attenuator are fixed on the table and both optical heads are close together so that minimum cable movement is achieved when connecting the cable to the Standard or to the DUT Head.
3. Turn the instruments on, enable the laser source, and allow the instruments to warm up for at least 20 minutes.
4. ZERO the power meters with the head connector adapters covered with plastic caps (P/N 5040-9361 or 5040-9351).
5. Set the CAL factor of both instruments to zero.
6. Set the WAVELENGTH of both instruments to the actual wavelength of the Laser Source and note the wavelength in the Test Record.
7. Set both instruments to MEASure, (display in μW), switch AUTOrange off and select the -20dBm range.
8. Enable the HP 8156A output, and change the HP 8156A attenuation until the Power Meter Standard displays 10.00 μW .
9. Connect the attenuator output cable, with the same lens and adapter, to the DUT and check that the DUT display is between 9.75 μW and 10.25 μW . Note the result in the Test Record.
10. For the HP 81521B, HP 81524A, or HP 81525A, repeat steps 8 and 9 at the second wavelength.

II. Linearity Test

1. Make sure that the HP 8156A output is disabled. ZERO the DUT.
2. Enable the HP 8156A output.
3. On the DUT, switch off autoranging and select the -20dBm range. Set the display to show results in dBm.
4. Alter the attenuation until the DUT displays -17.4dBm.
5. Press **(Disp→Ref)**, then **(dB)**.
6. Press **(Up)** to select the -10dBm range.
7. Note the deviation, displayed in dB, as R1 on the test record.

- a. In the -10dBm range. Set the display to show results in dBm.
 - b. Alter the attenuation until the DUT displays -7.4dBm.
 - c. Press **(Disp→Ref)**, then **(dB)**.
 - d. Select the 0dBm range.
 - e. Note the deviation, displayed in dB, as R2 on the test record.
8. Repeat the steps a to e at the all the range and level settings shown in the test record.

Note



- For the HP 81520A, HP 81524A, or HP 81525A, it might be necessary to use the attenuation of the laser source itself, as well as the attenuator, to set the power to -67.2dBm in the -60dBm range.
- For the HP 81525A in the +10, +20, and +30dBm ranges.
 - a. Connect the laser source to the DUT Head as shown in Figure D-2.




Figure D-2. HP 81525A Linearity Test Test Set-Up

- b. Use the attenuation of the laser source itself to set the power to 0dBm for the 0dBm range before selecting the +10dBm range. You do not need to alter this attenuation of the source before selecting the +20dBm and +30dBm ranges.
9. Calculate the non-linearity using the formulae in the test record. An example calculation follows here.

D

**Example Results for the Linearity test (for an HP 81525A
Optical Head)**

Test No.	Test Description	Min. Spec.	Result	Max. Spec.	Measurement Uncertainty
II.	Linearity Test		dB		
	Range Power (dBm)				
	-20dBm -17.4 Disp→Ref		0.01 = R1		
	-10dBm				
	-10dBm -7.4 Disp→Ref		-0.02 = R2		
	0dBm				
	-20dBm -27.4 Disp→Ref		-0.02 = R3		
	-30dBm				
	-30dBm -37.4 Disp→Ref		-0.01 = R4		
	-40dBm				
	0dBm 0 Disp→Ref		0.03 = R11		
	+10dBm				
	0dBm 0 Disp→Ref		-0.02 = R21		
	+20dBm				
	0dBm 0 Disp→Ref		0.03 = R31		
	+30dBm				

Example Calculated Results for the Linearity Test (for an HP 81525A Optical Head)

D 

Test No.	Test Description	Min. Spec.	Result	Max. Spec.	Measurement Uncertainty
	Non-Linearity				
	Range Formula				
	+30dBm R1 + R2 + R31	-0.1dB	0.01dB	+0.01B	¹
	+20dBm R1 + R2 + R21	-0.1dB	-0.03dB	+0.1dB	¹
	+10dBm R1 + R2 + R11	-0.04dB	0.02dB	+0.04dB	±0.018dB
	0dBm R1 + R2	-0.04dB	-0.01dB	+0.04dB	±0.017dB
	-10dBm R1	-0.04dB	0.01dB	+0.04dB	±0.010dB
	-20dBm		0.000dB		±0.000dB
	-30dBm R3	-0.04dB	-0.02dB	+0.04dB	±0.010dB
	-40dBm R3 + R4	-0.04dB	-0.03dB	+0.04dB	±0.014dB

¹ Functional test only (insufficient power).

Shown graphically, these results look add as shown in the following figure:



D




Figure D-3. Addition of results (example)

Performance Test for the HP 81520A

D 

Test Facility:

_____	Report No.	_____
_____	Date	_____
_____	Customer	_____
_____	Tested By	_____

Model HP 81520A Optical Head

Serial No. _____ Ambient temperature _____ °C

Options _____ Relative humidity _____ %

Firmware Rev. _____ Line frequency _____ Hz

Special Notes:

Performance Test for the HP 81520A

D

Test Equipment Used:

Description	Model No.	Trace No.	Cal. Due Date
1. Lightwave Multimeter (Std.)	HP 8153A	_____	_____
2a. Opt. Head Interface Module	HP 81533B	_____	_____
2b. Optical Head 850nm	HP 81520A	_____	_____
3. Laser Module	HP 81551MM	_____	_____
4. Lens Adapter	HP 81050AL		
5. Connector Adapter	HP 81000AA		
6. Optical Attenuator	HP 8158B		
7. Multimode Fiber (x2)	Opt.001/011 HP 81501AC		
8. Lightwave Multimeter (DUT)	HP 8153A		
9. Opt. Head Interface Module (DUT)	HP 81533B		
10. _____	_____	_____	_____
11. _____	_____	_____	_____
12. _____	_____	_____	_____
13. _____	_____	_____	_____
14. _____	_____	_____	_____
15. _____	_____	_____	_____

Performance Test for the HP 81520A

D 

Model HP 81520A Optical Head No. _____ Date _____

Test No.	Test Description	Min. Spec.	Result	Max. Spec.	Measurement Uncertainty
I.	Accuracy Test		μW		
	measured at _____ nm Output Power	9.75 μW	_____	10.25 μW	$\pm 2.00\%$
II.	Linearity Test		dB		
	Range Power (dBm)				
	-20dBm -17.4 Disp→Ref		_____ = R1		
	-10dBm				
	-10dBm -7.4 Disp→Ref		_____ = R2		
	0dBm				
	-20dBm -27.4 Disp→Ref		_____ = R3		
	-30dBm				
	-30dBm -37.4 Disp→Ref		_____ = R4		
	-40dBm				
	-40dBm -47.4 Disp→Ref		_____ = R5		
	-50dBm				
	-50dBm -57.4 Disp→Ref		_____ = R6		
	-60dBm				

Performance Test for the HP 81520A

Model HP 81520A Optical Head No. _____ Date _____

Test No.	Test Description	Min. Spec.	Result	Max. Spec.	Measurement Uncertainty
	Non-Linearity				
	Range Formula				
	0dBm R1 + R2	-0.04dB	_____dB	+ 0.04dB	±0.017dB
	-10dBm R1	-0.04dB	_____dB	+ 0.04dB	±0.010dB
	-20dBm		0.000dB		±0.000dB
	-30dBm R3	-0.04dB	_____dB	+ 0.04dB	±0.010dB
	-40dBm R3 + R4	-0.04dB	_____dB	+ 0.04dB	±0.014dB
	-50dBm R3 + R4 + R5	-0.04dB	_____dB	+ 0.04dB	±0.017dB
	-60dBm R3 + R4 + R5 + R6	-0.04dB	_____dB	+ 0.04dB	±0.022dB

Performance Test for the HP 81521B

D 

Test Facility:

_____	Report No.	_____
_____	Date	_____
_____	Customer	_____
_____	Tested By	_____

Model HP 81521B Optical Head

Serial No. _____ Ambient temperature _____ °C

Options _____ Relative humidity _____ %

Firmware Rev. _____ Line frequency _____ Hz

Special Notes:

Performance Test for the HP 81521B

D

Test Equipment Used:

Description	Model No.	Trace No.	Cal. Due Date
1. Lightwave Multimeter (Std.)	HP 8153A	_____	_____
2a. Opt. Head Interface Module	HP 81533B	_____	_____
2b. Optical Head 1310, 1550nm	HP 81521B	_____	_____
3a1. Laser Module	HP 81552SM	_____	_____
3a2. Laser Module	HP 81553SM	_____	_____
3b. Laser Module	HP 81554SM	_____	_____
4. Lens Adapter	HP 81010BL		
5. Connector Adapter	HP 81000AA		
6. Optical Attenuator	HP 8156A Opt.101		
7. Connector Interface (×2)	HP 81000AI		
8. Singlemode Fiber (×2)	HP 81101AC		
9. Lightwave Multimeter (DUT)	HP 8153A		
10. Opt. Head Interface Module (DUT)	HP 81533B		
11. _____	_____	_____	_____
12. _____	_____	_____	_____
13. _____	_____	_____	_____
14. _____	_____	_____	_____
14. _____	_____	_____	_____

Performance Test for the HP 81521B

D

Model HP 81521B Optical Head		No. _____	Date _____		
Test No.	Test Description	Min. Spec.	Result	Max. Spec.	Measurement Uncertainty
I.	Accuracy Test		μW		
	measured at 13_____nm Output Power	9.75 μW	_____	10.25 μW	$\pm 2.00\%$
	measured at 15_____nm Output Power	9.75 μW	_____	10.25 μW	$\pm 2.00\%$
II.	Linearity Test		dB		
	Range Power (dBm)				
	-20dBm -17.4 Disp→Ref				
	-10dBm		_____ = R1		
	-10dBm -7.4 Disp→Ref				
	0dBm		_____ = R2		
	-20dBm -27.4 Disp→Ref				
	-30dBm		_____ = R3		
	-30dBm -37.4 Disp→Ref				
	-40dBm		_____ = R4		
	-40dBm -47.4 Disp→Ref				
	-50dBm		_____ = R5		

Performance Test for the HP 81521B

D

Model HP 81521B Optical Head No. _____ Date _____

Test No.	Test Description	Min. Spec.	Result	Max. Spec.	Measurement Uncertainty
	Non-Linearity				
	Range Formula				
	0dBm R1 + R2	-0.04dB	_____dB	+ 0.04dB	±0.017dB
	-10dBm R1	-0.04dB	_____dB	+ 0.04dB	±0.010dB
	-20dBm		0.000dB		±0.000dB
	-30dBm R3	-0.04dB	_____dB	+ 0.04dB	±0.010dB
	-40dBm R3 + R4	-0.04dB	_____dB	+ 0.04dB	±0.014dB
	-50dBm R3 + R4 + R5	-0.051dB	_____dB	+ 0.051dB	±0.017dB

Performance Test for the HP 81524A

D 

Test Facility:

_____	Report No.	_____
_____	Date	_____
_____	Customer	_____
_____	Tested By	_____

Model HP 81524A Optical Head

Serial No. _____ Ambient temperature _____ °C

Options _____ Relative humidity _____ %

Firmware Rev. _____ Line frequency _____ Hz

Special Notes:

Performance Test for the HP 81524A

D

Test Equipment Used:

Description	Model No.	Trace No.	Cal. Due Date
1. Lightwave Multimeter (Std.)	HP 8153A	_____	_____
2a. Opt. Head Interface Module	HP 81533B	_____	_____
2b. Optical Head 1310, 1550nm	HP 81524A	_____	_____
3a1. Laser Module	HP 81552SM	_____	_____
3a2. Laser Module	HP 81553SM	_____	_____
3b. Laser Module	HP 81554SM	_____	_____
4. Lens Adapter	HP 81010BL		
5. Connector Adapter	HP 81000AA		
6. Optical Attenuator	HP 8156A Opt.101		
7. Connector Interface (×2)	HP 81000AI		
8. Singlemode Fiber (×2)	HP 81101AC		
9. Lightwave Multimeter (DUT)	HP 8153A		
10. Opt. Head Interface Module (DUT)	HP 81533B		
11. _____	_____	_____	_____
12. _____	_____	_____	_____
13. _____	_____	_____	_____
14. _____	_____	_____	_____

Performance Test for the HP 81524A

D 

Model HP 81524A Optical Head		No. _____	Date _____		
Test No.	Test Description	Min. Spec.	Result	Max. Spec.	Measurement Uncertainty
I.	Accuracy Test		μW		
	measured at 13_____nm Output Power	9.75 μW	_____	10.25 μW	$\pm 2.00\%$
	measured at 15_____nm Output Power	9.75 μW	_____	10.25 μW	$\pm 2.00\%$
II.	Linearity Test		dB		
	Range Power (dBm)				
	-20dBm -17.4 Disp→Ref				
	-10dBm		_____ = R1		
	-10dBm -7.4 Disp→Ref				
	0dBm		_____ = R2		
	-20dBm -27.4 Disp→Ref				
	-30dBm		_____ = R3		
	-30dBm -37.4 Disp→Ref				
	-40dBm		_____ = R4		
	-40dBm -47.4 Disp→Ref				
	-50dBm		_____ = R5		
	-50dBm -57.4 Disp→Ref				
	-60dBm		_____ = R6		

Performance Test for the HP 81524A

D

Model HP 81524A Optical Head No. _____ Date _____

Test No.	Test Description	Min. Spec.	Result	Max. Spec.	Measurement Uncertainty
	Non-Linearity				
	Range Formula				
	0dBm R1 + R2	-0.04dB	_____dB	+ 0.04dB	±0.017dB
	-10dBm R1	-0.04dB	_____dB	+ 0.04dB	±0.010dB
	-20dBm		0.000dB		±0.000dB
	-30dBm R3	-0.04dB	_____dB	+ 0.04dB	±0.010dB
	-40dBm R3 + R4	-0.04dB	_____dB	+ 0.04dB	±0.014dB
	-50dBm R3 + R4 + R5	-0.04dB	_____dB	+ 0.04dB	±0.017dB
	-60dBm R3 + R4 + R5 + R6	-0.04dB	_____dB	+ 0.04dB	±0.022dB

Performance Test for the HP 81525A



Test Facility:

_____	Report No.	_____
_____	Date	_____
_____	Customer	_____
_____	Tested By	_____

Model HP 81525A Optical Head

Serial No. _____ Ambient temperature _____ °C

Options _____ Relative humidity _____ %

Firmware Rev. _____ Line frequency _____ Hz

Special Notes:

Performance Test for the HP 81525A

D

Test Equipment Used:

Description	Model No.	Trace No.	Cal. Due Date
1. Lightwave Multimeter (Std.)	HP 8153A	_____	_____
2a. Opt. Head Interface Module	HP 81533B	_____	_____
2b. Optical Head 1310, 1550nm	HP 81524A	_____	_____
3a1. Laser Module	HP 81552SM	_____	_____
3a2. Laser Module	HP 81553SM	_____	_____
3b. Laser Module	HP 81554SM	_____	_____
4. Lens Adapter	HP 81010BL		
5. Connector Adapter	HP 81000AA		
6. Optical Attenuator	HP 8156A Opt.101		
7. Connector Interface (×2)	HP 81000AI		
8. Singlemode Fiber (×2)	HP 81101AC		
9. Lightwave Multimeter (DUT)	HP 8153A		
10. Opt. Head Interface Module (DUT)	HP 81533B		
11. _____	_____	_____	_____
12. _____	_____	_____	_____
13. _____	_____	_____	_____
14. _____	_____	_____	_____

Performance Test for the HP 81525A

D 

Model HP 81525A Optical Head No. _____ Date _____

Test No.	Test Description	Min. Spec.	Result	Max. Spec.	Measurement Uncertainty
I.	Accuracy Test		μW		
	measured at 13_____ nm Output Power	9.75 μW	_____	10.25 μW	$\pm 2.00\%$
	measured at 15_____ nm Output Power	9.75 μW	_____	10.25 μW	$\pm 2.00\%$
II.	Linearity Test		dB		
	Range Power (dBm)				
	-20dBm -17.4 Disp→Ref				
	-10dBm		_____ = R1		
	-10dBm -7.4 Disp→Ref				
	0dBm		_____ = R2		
	-20dBm -27.4 Disp→Ref				
	-30dBm		_____ = R3		
	-30dBm -37.4 Disp→Ref				
	-40dBm		_____ = R4		
	0dBm 0 Disp→Ref				
	+ 10dBm		_____ = R11		
	0dBm 0 Disp→Ref				
	+ 20dBm		_____ = R21		
	0dBm 0 Disp→Ref				
	+ 30dBm		_____ = R31		

Performance Test for the HP 81525A

D

Model HP 81525A Optical Head No. _____ Date _____

Test No.	Test Description	Min. Spec.	Result	Max. Spec.	Measurement Uncertainty
Non-Linearity					
	Range Formula				
	+ 30dBm R1 + R2 + R31	-0.2dB	_____dB	+0.2dB	¹
	+ 20dBm R1 + R2 + R21	-0.2dB	_____dB	+0.2dB	¹
	+ 10dBm R1 + R2 + R11	-0.04dB	_____dB	+0.04dB	0.018dB
	0dBm R1 + R2	-0.04dB	_____dB	+0.04dB	±0.017dB
	-10dBm R1	-0.04dB	_____dB	+0.04dB	±0.010dB
	-20dBm		0.000dB		±0.000dB
	-30dBm R3	-0.04dB	_____dB	+0.04dB	±0.010dB
	-40dBm R3 + R4	-0.04dB	_____dB	+0.04dB	±0.014dB

¹ Functional test only (insufficient power).

Cleaning Procedures

How to clean instruments with a recessed lens interface

Light dirt

If you find any particles of dirt on the fixed connector interface, or on the input of the optical block, clean them with compressed air.

This cleaning method is gentle to your optical device and is an ideal approach if there is no fat on the surface of your device.

Heavy dirt

Using compressed air, blow away larger particles of dirt. Clean the recessed lens interface with a dry cotton swab by rubbing gently over its surface. Then blow away any remaining filaments left by the swab.

Isopropyl alcohol should only be used if there is fat on the lens. In this case, choose a new swab and moisten it with alcohol. Remove the dirt by gently rotating the swab using light pressure. Then select a fresh, dry swab to wipe away the alcohol. Blow away any remaining filament with compressed air.

Caution



Do not press the swabs too hard onto the optical surface of your device, as this may produce scratches and your recessed lens could be misaligned.

Alcohol will dissolve some types of dirt. If this then forms a deposit on the edge of the optical input it cannot be removed. You should therefore only use alcohol if absolutely necessary.

Other solvents, like Acetone, should also not be used, as they may damage your optical device and reduce its performance.

Index

P

Power requirements, v

S

Safety considerations, v

