

# Agilent Signal Studio for TD-SCDMA (TSM) E4438C ESG Vector Signal Generator

Option 411 Technical Overview


Signal Studio for TD-SCDMA (TSM) is a powerful software tool for creating TD-SCDMA (TSM) I/Q waveforms for use with the Agilent E4438C ESG vector signal generator.

# **Main features**

- Intuitive user interface
- Quickly create TD-SCDMA (TSM) frames
- Seventeen fully-coded transport channel types for BER/BLER, including BCCH-T, TCH/T-EFS, and TCH/T9.6
- Configure channels in each timeslot
- Select from predefined PN sequences, fixed bit patterns, or user files
- Configure DwPTS and UpPTS
- Selectable baseband filtering
- 10B/T LAN or GPIB connectivity

# Try before you buy!

Go to www.agilent.com/find/signalstudio and download Signal Studio for TD-SCDMA (TSM) to your PC to evaluate the signal configuration capabilities of the software. A license key is required to generate the waveform. The license key can be ordered through your sales engineer or the nearest sales office, which can be found at: www.agilent.com/find/assist.



# **Benefits**

### **Component test**

- Determine performance characteristics of TD-SCDMA (TSM) components
- Modify signal parameters to meet your customized test needs
- Generate statistically correct signals to properly stress components

### **Receiver test**

- Fully-coded channels enable BER/BLER testing
- Customize channel configurations in each timeslot to verify demodulation capability and sensitivity of mobile handsets and base transceiver stations

# I/Q waveform generation

Signal Studio for TD-SCDMA (TSM) software is an intuitive Windows®-based utility that simplifies the creation of TD-SCDMA (TSM) I/Q waveforms. It is intended for use with the E4438C ESG vector signal generator equipped with a baseband generator operating in the real-time mode.

Signal Studio requires a PC running Windows 2000 or Windows XP and a LAN or GPIB interface. The configured signal parameters are downloaded to the ESG, which automatically begins generating the modulated RF signal. Waveform configurations can be stored on the PC.



### TD-SCDMA (TSM) Signal Studio software features<sup>1</sup>

Specification version	CWTS TSM 05.02 V3.0.0 (2002-08)
	CWTS TSM 05.03 V3.0.0 (2002-08)
	CWTS TSM 05.04 V3.0.0 (2002-08)
Scramble code	0 to 127
Midamble base	0 to 127
Max users	2, 4, 6, 8, 10, 12, 14, or 16
Baseband filtering	Root Nyquist and Nyquist with adjustable
	filter alpha, Gaussian, or rectangle
Filter optimization	ACP or EVM
IQ phase	Normal or inverted
Number of uplink slots (switch point)	1 to 6
Chip clock	Internal or external
Chip rate	320 kcps to 1.408 Mcps
Graphic displays	Frame timeslot structure
Pilot signal configuration	
DwPTS (downlink pilot timeslot physical o	channel)
	0, 01

# Downlink SYNC code0 to 31Power0 to -40 dBPhase patternS1, S2, or noneUpPTS (uplink pilot timeslot physical channel)Uplink SYNCH code0 to 255UpPTS power0 to -40 dBTime offset-5 to 5 chips

### Resource unit (RU) configuration (uplink and downlink)

Physical channel type	DPCH
Number of channels	Up to 16 channels per timeslot
Slot number	0 to 6
Spread factor	1, 2, 4, 8, or 16
Channelization code	0 to 15
User number	1 to 16
Data type	Fixed 4-bit pattern, PN9, PN15
Time offset	-5 to 5 chips
Power level	0 to -60 dB

### Transport layer coding (uplink and downlink)

allocated to any timeslot
unocated to any timesion
8 or 16
0 to 15
Uncoded, TCH-T/EFS, TCH-T/F9.6M,
TCH-T/F9.6, TCH-T/HS, TCH-T/F14.4M,
TCH-T/F14.4, FACCH-T/F, FACCH-T/H,
BCCH-T, PCH-T, AGCH-T, NCH-T, CBCH-T,
RACH-T, FACH-T, HOACH-T, FNICH-T
Fixed 4-bit pattern, PN9, PN15, user file
BLER, BER, or none for either data field
1 to 16
-5 to 5 chips (uplink)
0 to -60 dB

### **Recommended configuration**

E4438C ESG with the following options:		
E4438C-001*	8 Msample baseband	
	generator	
E4438C-411*	Signal Studio for	
	TD-SCDMA (TSM)	
E4438C-503	3-GHz frequency range	
E4438C-1E5	High stability timebase	

\*Required option. The baseband generator with 8 Msamples (E4438C-001) is the minimum requirement. The baseband generator with 32 Msamples (E4438C-002) should be ordered if the ESG will be used for extensive arbitrary waveform generation.

### Upgrade kits

If you currently own an E4438C ESG vector signal generator equipped with a baseband generator, and want an upgrade kit (license key), order E4438CK-411.



### www.agilent.com/find/emailupdates Get the latest information on the products and applications you select.

Windows® is a U.S. registered trademark of Microsoft Corporation.

#### By internet, phone, or fax, get assistance with all your test & measurement needs Online Assistance: www.agilent.com/find/assist

Phone or Fax	Korea:
United States:	(tel) (82 2) 2004 5004
(tel) 800 452 4844	(fax) (82 2) 2004 5115
Canada:	Latin America:
(tel) 877 894 4414	(tel) (305) 269 7500
(fax) 905 282 6495	(fax) (305) 269 7599
China:	Taiwan:
(tel) 800 810 0189	(tel) 0800 047 866
(fax) 800 820 2816	(fax) 0800 286 331
Europe:	Other Asia Pacific
(tel) (31 20) 547 2323	Countries:
(fax) (31 20) 547 2390	(tel) (65) 6375 8100
Japan:	(fax) (65) 6836 0252
(tel) (81) 426 56 7832	Email:
(fax) (81) 426 56 7840	tm_asia@agilent.com

Product specifications and descriptions in this document subject to change without notice.

© Agilent Technologies, Inc. 2002, 2003 Printed in USA, January 15, 2003 5988-6552EN

1. Features subject to change.

2. Applies to data field #1, data field #2, power control field, synchronization shift field, and stealing flag field.

