

Installation Note

**HP 8719D, HP 8720D, and HP 8722D Network Analyzers
Firmware Upgrade Kit Revision 7.14 and Above
Kit Number 08720-60262**



HP Part Number 08720-90385 Supersedes May 1998
Printed in USA November 1998

Notice.

The information contained in this document is subject to change without notice.

Hewlett-Packard makes no warranty of any kind with regard to this material, including but not limited to, the implied warranties of merchantability and fitness for a particular purpose. Hewlett-Packard shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this material.

HP 8719D/8720D/8722D Firmware Upgrade Kit

Products Affected:	HP 8719D, HP 8720D, HP 8722D
Serial Numbers:	All
Compatibilities:	This upgrade applies only to those instruments with a fast CPU board, (Firmware Rev. 7.12 and above).
To Be Performed By:	HP Service Center, Personnel Qualified by HP, or Customer
Estimated Installation Time:	5 minutes

Purpose

This note contains the information required to update the firmware in the HP 8719D/8720D/8722D network analyzer.

Items Included in the Kit

Table 1 describes the parts included in this firmware upgrade kit. Check the contents of the kit against this table.

Table 1 Parts Kit 08720-60262

Quantity	Description	HP Part Number
1	Installation note	08720-90385
1	Firmware disk	08720-10008

Firmware Installation Procedure

CAUTION

Loading firmware will clear all internal memory. Perform the following steps to save any instrument states that are stored in internal memory to a floppy disk:

1. Press **Save/Recall** **SELECT DISK** **INTERNAL MEMORY** **RETURN** .
 2. Select an instrument state and press **RECALL STATE** .
 3. Press **SELECT DISK** **INTERNAL DISK** **RETURN** **SAVE STATE** .
 4. If the instrument state file was not saved to disk with the same name that it had while in internal memory, you may wish to rename the file.
Press **FILE UTILITIES** **RENAME FILE** , enter the desired name, and press **DONE** .
 5. Repeat steps 1 through 4 for each instrument state that you wish to save.
-

Loading Firmware into an Existing CPU

The network analyzer must be in proper working condition prior to installing this firmware upgrade. Any necessary repairs must be made before proceeding with this installation.

1. Turn off the network analyzer.
2. Insert the firmware disk into the instrument's disk drive.
3. Turn the instrument on. The firmware will load automatically during power-up. The front panel LEDs should step through a sequence for approximately one minute as the firmware is loaded. The display will be blank during this time.
4. After the firmware successfully loads, the LEDs for Channel 1 and Port 1 will remain on and the display will indicate the version of firmware loaded.

In Case of Difficulty

If the firmware did not load successfully, LED patterns on the front panel can help you isolate the problem.

- ☐ If the following LED pattern is present on the instrument's front panel, the firmware disk is not for use with your instrument model.

Front Panel LED Pattern					
CH 1	CH 2	R	L	T	S
•	•				

- ☐ If any of the following LED patterns are present on the instrument's front panel, the firmware disk may be defective.

Front Panel LED Pattern					
CH 1	CH 2	R	L	T	S
		•			
	•	•			
•		•			
•	•	•			
			•		
	•		•		
•			•		
•	•		•		
		•	•		
	•	•	•		
•		•	•		
		•			•
	•	•			•

- ☐ If any other LED pattern is present, the CPU board is defective.

Hewlett-Packard Sales and Service Offices

Table 3 Sales and Service Offices

UNITED STATES		
Instrument Support Center Hewlett-Packard Company (800) 403-0801		
EUROPEAN FIELD OPERATIONS		
Headquarters Hewlett-Packard S.A. 150, Route du Nant-d'Avril 1217 Meyrin 2/ Geneva Switzerland (41 22) 780.8111	France Hewlett-Packard France 1 Avenue Du Canada Zone D'Activite De Courtaboeuf F-91947 Les Ulis Cedex France (33 1) 69 82 60 60	Germany Hewlett-Packard GmbH Hewlett-Packard Strasse 61352 Bad Homburg v.d.H Germany (49 6172) 16-0
Great Britain Hewlett-Packard Ltd. Eskdale Road, Winnersh Triangle Wokingham, Berkshire RG41 5DZ England (44 734) 696622		
INTERCON FIELD OPERATIONS		
Headquarters Hewlett-Packard Company 3495 Deer Creek Rd. Palo Alto, CA 94304-1316 USA (415) 857-5027	Australia Hewlett-Packard Australia Ltd. 31-41 Joseph Street Blackburn, Victoria 3130 (61 3) 895-2895	Canada Hewlett-Packard (Canada) Ltd. 17500 South Service Road Trans-Canada Highway Kirkland, Quebec H9J 2X8 Canada (514) 697-4232
Japan Hewlett-Packard Japan, Ltd. 9-1 Takakura-Cho, Hachioji Tokyo 192, Japan (81 426) 60-2111	Singapore Hewlett-Packard Singapore (Pte.) Ltd. 150 Beach Road #29-00 Gateway West Singapore 0718 (65) 291-9088	Taiwan Hewlett-Packard Taiwan 8th Floor, H-P Building 337 Fu Hsing North Road Taipei, Taiwan (886 2) 712-0404
China China Hewlett-Packard Co. 38 Bei San Huan X1 Road Shuang Yu Shu Hai Dian District Beijing, China (86 1) 256-6888		