

# *D-STAR System Introduction*



# Five Examples of Having Fun with D-STAR

Have you ever thought about if you could access the Internet from ham radios?  
Or have you ever thought if you could communicate with a friend in another city or country using a simple handy radio?  
Or want to send a simple text message, or know the call sign of whom is on the air right now?  
The D-STAR system is such a magical system; you can easily realize these functions without using a tricky gadget or complicated facilities.

## Application 1

### Digital voice (DV mode)

Analog audio is modulated to a digital signal and transmitted in the digital mode signal by the D-STAR radio.



## Internet connection\*

The Internet gateway allows linking of D-STAR repeater sites over the Internet. You can uplink to your local repeater and downlink from a remote repeater, even from a foreign country!

## Application 5

### IP camera (DD mode)

You can transmit live images in DD mode and watch real-time images from a remote location.



## Application 2

### Short data message (DV mode)



## GPS satellite

## Application 3


### GPS tracking (DV mode)

With a GPS receiver, you can send your current position information to another radio.


## Application 4

### Internet access (DD mode)\*

In DD mode operation, you can access to the Internet via a D-STAR Internet gateway. Connect a PC with the ID-1 and you can browse web sites or check e-mail.



\* Some restrictions may apply depending on specific countries' regulations.



## D-STAR repeater

### ID-RP2C: Repeater controller

One unit is required for each repeater station and connects up to 4 RF modules. Transfers the received signal to the specified RF module or the Internet gateway server.



### ID-RP2D: 1.2GHz DD mode RF module

The ID-RP2D is the DD mode RF module for 1.2GHz. It provides 128kbps high speed data communication.



Photo shows ID-RP2V.

### ID-RP2V: 1.2GHz DV mode RF module ID-RP2000V: 144MHz DV mode RF module ID-RP4000V: 430(440)MHz DV mode RF module

These are DV (digital voice) mode RF modules for the respective bands. With a combination of these RF modules, cross band operation with 144/430 (440)/1200MHz bands is available.



### RS-RP2C: Internet gateway software

The Internet gateway (GW) connects the D-STAR repeater station to the Internet and links multiple D-STAR repeater stations via the Internet.



## Frequently Asked Questions About D-STAR

### Q What does "D-STAR" stand for?

**A** The "D-STAR" stands for Digital Smart Technologies for Amateur Radio. It is an open standard digital communication protocol established by JARL\*. Please refer to <http://www.jarl.com/d-star/shogen.pdf> for technical details. \* Japan Amateur Radio League

### Q What can I do with the D-STAR radio?

**A** 4.8kbps digital voice (DV) mode and 128kbps data\* (DD) mode communications are available. When using DD mode with a PC and the D-STAR radio, high speed data communication is possible. \* DD mode is available with ID-1 only.

### Q Can I send data with a voice transmission? DV mode only

**A** Yes, you can. In DV mode operation, you can simultaneously send up to 950bps of data, such as call sign, short data message or GPS position with a voice transmission.

### Q Can I use the D-STAR repeater without connecting to the Internet?

**A** Yes, you can use a D-STAR repeater as a local repeater. You can also communicate with other D-STAR radios directly.

### Q Can I make a call with foreign countries?

**A** Yes, you can\*. The Internet gateway allows you to relay your call to a remote D-STAR repeater over the Internet. The D-STAR repeater call sign and IP address must be registered to the gateway server. \* Some restrictions may apply depending on specific countries' regulations.

### Q Can I receive a call only when the call is intended for me?

**A** Yes, you can. The call sign squelch function opens the squelch only when your call sign is received.

### Q How do I set a repeater call sign when I make a call to a desired station using a D-STAR repeater?

**A** When you communicate with other D-STAR stations using a D-STAR repeater, it is necessary to set the repeater's call sign in RPT1/RPT2 as well as the desired station call sign and your own call sign.

For example, when you make a call in the same zone (without using the Internet gateway), set the uplink repeater call sign in RPT1 and the downlink repeater call sign in RPT2. Set "CQCQCQ" for the desired station call sign, when you make a CQ call.

When you make a call in another zone using the Internet gateway, set the uplink repeater call sign in RPT1 and the gateway call sign in RPT2. The gateway repeater has "G" setting for the 8th-digit. Set "/" plus downlink repeater call sign at the desired station call sign, when you make a CQ call.

Call type	UR (Your call sign)	RPT1 (Uplink repeater)	RPT2 (Downlink or gateway)	MY
Desired station in the same zone	Receiver's call sign	Uplink repeater's call sign	Downlink repeater's call sign	Own call sign
Desired station in another zone	Receiver's call sign	Uplink repeater's call sign	Gateway repeater's call sign plus "G"	Own call sign
CQ call in the same zone	CQCQCQ	Uplink repeater's call sign	Downlink repeater's call sign	Own call sign
CQ call in another zone	"/" plus downlink repeater call sign	Uplink repeater's call sign	Gateway repeater's call sign plus "G"	Own call sign

# Icom's D-STAR Compatible Transceiver Line-up



1.2GHz Transceiver

10W

**ID-1**

- Both DV and DD modes available
- PC remote control software included
- Separate remote controller and speaker



144/430(440MHz) Dual Band Transceivers

50W

**IC-2820H + UT-123**

**IC-E2820 + UT-123**

- 50W output power (VHF/UHF)
- Wideband receiver with V/V, U/U dualwatch capability
- D-STAR + GPS receiver capability (UT-123 required)



144/430(440MHz) Dual Band Transceiver

55/50W

**ID-800H**

- 55/50W output power (VHF/UHF)
- Wideband receiver
- Detachable front panel



UT-121

144/430(440MHz)  
Dual Band Transceivers

5W

**IC-91AD**

**IC-91A + UT-121**

**IC-E91 + UT-121**

- 5W (typ.) output power (VHF/UHF)
- V/V, U/U dualwatch receive capability
- Optional PC remote control software



UT-118

144MHz FM Transceiver

7W

**IC-V82 + UT-118**

430(440)MHz FM Transceiver

5W

**IC-U82 + UT-118**

- 7W output power (IC-V82)
- 5W output power (IC-U82)
- 200 memory channels



UT-118

144MHz FM Transceiver

65W

**IC-2200H + UT-118**

- 65W output power
- 207 memory channels
- Simple operation

## Repeater compatibility chart with ICOM digital transceivers

	ID-1	IC-2820H + UT-123 or IC-E2820 + UT-123	ID-800H	IC-91AD, IC-91A + UT-121 or IC-E91 + UT-121	IC-V82 + UT-118	IC-U82 + UT-118	IC-2200H + UT-118
<b>ID-RP2000V</b>	—	✓	✓	✓	✓	—	✓
<b>ID-RP4000V</b>	—	✓	✓	✓	—	✓	—
<b>ID-RP2V/ID-RP2D</b>	✓	—	—	—	—	—	—

\*Repeater access using radio frequency. Cross band operation between ID-RP2000V/RP4000V/RP2V is also possible.

**Icom Inc.**

1-1-32, Kami-minami, Hirano-ku, Osaka 547-0003, Japan Phone: +81 (06) 6793 5302 Fax: +81 (06) 6793 0013

URL: <http://www.icom.co.jp/world/index.html>

**Count on us!**

**Icom America Inc.**

2380 116th Avenue NE,  
Bellevue, WA 98004, U.S.A.  
Phone: +1 (604) 952-4266  
Fax: +1 (425) 454-1509  
E-mail: [sales@icomamerica.com](mailto:sales@icomamerica.com)  
URL: <http://www.icomamerica.com>

**Icom New Zealand**

146A Harris Road, East Tamaki,  
Auckland, New Zealand  
Phone: +64 (09) 274 4062  
Fax: +64 (09) 274 4708  
E-mail: [inquiries@icom.co.nz](mailto:inquiries@icom.co.nz)  
URL: <http://www.icom.co.nz>

**Icom (UK) Ltd.**

Unit 9, Sea St., Herne Bay,  
Kent, CT6 8LD, U.K.  
Phone: +44 (01227) 741741  
Fax: +44 (01227) 741742  
E-mail: [info@icomuk.co.uk](mailto:info@icomuk.co.uk)  
URL: <http://www.icomuk.co.uk>

**Asia Icom Inc.**

6F No. 68, Sec. 1 Cheng-Teh Road,  
Taipei, Taiwan, R.O.C.  
Phone: +886 (02) 2559 1899  
Fax: +886 (02) 2559 1874  
E-mail: [sales@asia-icom.com](mailto:sales@asia-icom.com)  
URL: <http://www.asia-icom.com>

**Icom Canada**

Glenwood Centre #150-6165 Highway 17,  
Delta, B.C., V4K 5B8, Canada  
Phone: +1 (604) 952-4266  
Fax: +1 (604) 952-0090  
E-mail: [info@icomcanada.com](mailto:info@icomcanada.com)  
URL: <http://www.icomcanada.com>

**Icom (Europe) GmbH**

Communication Equipment  
Himmelgeister Str. 100,  
D-40225 Düsseldorf, Germany  
Phone: +49 (0211) 346047  
Fax: +49 (0211) 333639  
E-mail: [info@icomeurope.com](mailto:info@icomeurope.com)  
URL: <http://www.icomeurope.com>

**Icom France s.a.s.**

Zac de la Plaine,  
1 Rue Brindejonc des Moulinais, BP 45804,  
31505 Toulouse Cedex 5, France  
Phone: +33 (5) 61 36 03 03  
Fax: +33 (5) 61 36 03 00  
E-mail: [icom@icom-france.com](mailto:icom@icom-france.com)  
URL: <http://www.icom-france.com>

**Beijing Icom Ltd.**

10C07, Long Silver Mansion, No.88, Yong Ding  
Road, Haidian District, Beijing, 100039, China  
Phone: +86 (010) 5889 5391/5392/5393  
Fax: +86 (010) 5889 5395  
E-mail: [bjicom@bjicom.com](mailto:bjicom@bjicom.com)  
URL: <http://www.bjicom.com>

**Icom (Australia) Pty. Ltd.**

Unit 1 / 103 Garden Road,  
Clayton, VIC 3168 Australia  
Phone: +61 (03) 9549 7500  
Fax: +61 (03) 9549 7505  
E-mail: [sales@icom.net.au](mailto:sales@icom.net.au)  
URL: <http://www.icom.net.au>

**Icom Spain S.L.**

Ctra. Rubi, No. 88 "Edificio Can Castanyer"  
08190, Sant Cugat del Valles, Barcelona, Spain  
Phone: +34 (93) 590 26 70  
Fax: +34 (93) 589 04 46  
E-mail: [icom@icomspain.com](mailto:icom@icomspain.com)  
URL: <http://www.icomspain.com>

**Icom Polska**

Sopot, 3 maja 54, Poland  
Phone: +48 (58) 550 7135  
Fax: +48 (58) 551 0484  
E-mail: [icompolaska@icompolaska.com.pl](mailto:icompolaska@icompolaska.com.pl)  
URL: <http://www.icompolaska.com.pl>

Your local distributor/dealer: