KENWOOD SPECTRUM 470/570AV

CONGRATULATIONS!


This guide will show you how to connect all of the different parts of your Spectrum 470/570AV System. Simply perform the following steps (on both sides) to build your new system.

For more detailed connection information, and to learn how to assemble the rack and operate all of the system's components, please read the manuals that come with the rack and the components.

STEP 1 - Stacking The Components In The Rack

To make sure that they're properly ventilated and stable, stack the components according to the diagram on the right. If you're using a turntable, place it on top of the rack.


IMPORTANT: Do not plug the receiver's power cord into an AC outlet until you have properly made all of the connections listed in steps 3 through 7.



STEP 2 - Placing The Speakers

Place the speakers as shown in the diagram on the right. While you're setting the speakers up, keep these points in mind:

- Since the left, right, and center speakers are magnetically-shielded, you can place them near the TV without picture discoloration. The center speaker can be placed right on top of the TV.
- You can hang the surround speakers on the wall using heavy-duty picture hangers.
- Placing the left and right speakers next to a wall produces more deep bass output than placing them away from a wall. Placing the speakers in corners produces the deepest bass output overall, but may cause the sound to become "muddy" or "heavy."




SYSTEM QUICK-CONNECT GUIDE


STEP 3 - Connecting The Speakers

Connect the speakers as shown in the diagram on the right, using the wires supplied with the speakers. To make it easier, we've removed the insulation from the ends of the wires.

- Be sure to connect the (+) terminals on the receiver to the (+) terminals on the speakers, and the (-) terminals on the receiver to the (-) terminals on the speakers. Connecting (+) to (-) can cause poor sound quality.
- Never allow the (+) and (-) speaker wires to touch each other. Touching wires can cause a short circuit, which could damage the receiver.



STEP 4 - Connecting The Audio Components




KENWOOD SPECTRUM 470/570AV


STEP 5 - Connecting the System Control Cables

Connect the System Control cable between the receiver and CD player as shown in the diagram on the right. Be sure to push the plugs all the way in.

NOTE: Make sure that the SL16/XS8 switch is in the SL16 position.



STEP 6 - Connecting Video Components



SYSTEM QUICK-CONNECT GUIDE

STEP 7 - Connecting a DVD Player

Connect a DVD player with 6-channel analog outputs VR-206 RECEIVER to the receiver as shown in the diagram on the right. If the DVD player does not have a 6-channel analog output, connect its 2-channel analog output to the video 2 input, as shown in the diagram in STEP 6 -Connecting Video Components. 6CH, INPUT CENTER **VOOFE** CONNECTING A STEREO RCA CABLE DVD 6CH, INPUT VIDEO IN LEFT = WHITE RIGHT = RED VIDEO = YELLOW SURROUND FRONT DVD PLAYER (6-CHANNEL ANALOG AUDIO OUTPUTS)

QUESTIONS ABOUT YOUR NEW SYSTEM?

If you have any questions about your new system, please contact our Stage 3 Customer Service Department on any business day at:

(310) 639-5300 from 8:30 A.M. to 5:00 P.M.,
Pacific Time

Or visit out website anytime at:

www.kenwoodusa.com

OUT