



# Connecting to a computer

If you are using a computer running Windows, make sure that you install Nikon View 5 before connecting your camera to the computer for the first time. After installing Nikon View 5, turn the camera on and connect it to the computer, or insert the memory card into a card reader or a card slot.


For more information about connecting your camera to a computer, see the *Guide to Digital Photography* provided with your camera.



D1/ D1x/D1H series (IEEE 1394/Firewire interface)



COOLPIX series (USB interface)



D100 (USB interface)

## ✓ Using a Reliable Power Source

When transferring data from the camera to the computer use the EH-21 AC adapter/battery charger or EH-53 AC adapter (available separately). If you decide to transfer images to the computer using a camera running on a battery, be sure that the battery is fully charged. If in doubt, recharge the battery before beginning transfer. If battery power runs out during transfer transfer will be interrupted and data may be lost.




## Using a card slot


When inserted in a PC-card adapter (available separately), the camera memory card functions as a Type II PCMCIA ATA card, allowing images to be read from the card.

## Inserting a memory card

Remove the memory card from the camera and insert it in the adapter.



Insert the adapter into a PCMCIA TYPE II ATA card slot on your computer. For more information on inserting the adapter, see the documentation provided with your computer.



Depending on your computer's operating environment, you may need to install drivers, register the card adapter, or adjust OS settings when the adapter is inserted into the card slot. For more information, refer to the instruction manual for your operating system.

## Using a Card Reader

Images on the memory card can also be viewed using a card reader.

## Inserting a Memory Card

After removing the memory card from the camera, insert it in the card reader and connect the reader to the computer. See the documentation provided with the card reader for more information on connecting it to a computer.

