


Install Software

Step 1: Select the software you wish to use



Select the programs you want to install from the list in the **Software** tab. Click **Install**. If you have chosen more than one program, the programs are installed in the order of display.

PanoramaMaker

Select this check box to install Panorama Maker.

Nikon View 5

Select this check box to install Nikon View 5.

FotoStation Easy

Select this check box to install FotoStation Easy.


QuickTime 5.0.2

Select this check box to install Apple Computer's QuickTime 5.0.2.


Step 2 : Install the selected software

2.1 — Install PanoramaMaker

The license agreement shown below will appear. Read the agreement carefully and click **Accept** if you wish to continue the installation.



When you accept the agreement the dialog below is displayed.



Click **Install**, and follow the on-screen instructions.




Panorama Maker

You can use Panorama Maker to combine separate images into a Panorama. This software is particularly useful if your COOLPIX camera has a Panorama Assist mode.



When the installation is complete, the dialog shown below appears. Click **OK**.




2.2 — Install Nikon View 5

The license agreement shown below appears, showing that you are now installing the selected software.

2.2.1 — Accept the license agreement

When you start installation of Nikon View 5, the license agreement is displayed. Read the agreement carefully, and click **Accept** if you wish to continue installation.




When you accept the agreement, the **ReadMe** window is displayed.

Take a few moments to view this file, which may contain important information that could not be included in this manual.

Click **Continue**.



Installing Nikon View 5 under Mac OS X




When installing Nikon View under Mac OS X, the **Authenticate** dialog box will appear. Enter your administrator name and password.




2.2.2 — Choose a location for Nikon View 5

Select **Easy Install** from the pull-down menu in the top left corner of the **Nikon View 5 Installer** dialog box.



2.2.3 — Confirm the install destination

The disk and folder to which Nikon View 5 will be installed are shown in the **Install Location** area.




2.2.4 — Start installation

To install Nikon View 5 to the selected location, click **Install** in the **Nikon View 5 Installer** dialog box. A progress meter will be displayed during installation.



The dialog box shown below will appear when the installation of files is complete. Click **OK** to create an alias, which will allow you to start Nikon View 5 directly from an icon on the desktop.



Existing versions of Nikon View


If an older version of Nikon View 5 is installed on your computer, it must be uninstalled before installing Nikon View 5.




2.2.5— Complete the installation

The dialog box shown below will appear indicating that the installation is complete.

Click **Quit** to complete the installation of Nikon View 5.




If the dialog box shown below appears, click **Restart** to restart your computer.




2.3 — Install FotoStation Easy


The splashscreen below appears, showing that you are now installing FotoStation Easy. Click **Continue** and follow the rest of the on-screen instructions to complete the installation.



The dialog box below will appear indicating that the installation is complete. Click **OK** to complete the installation.



Add to Dock (Mac OS X only)



When installing Nikon View 5 under Mac OS X, the dialog box shown left will appear asking if you want to add Nikon View 5 to the Dock. Click **OK**. The Nikon View 5 icon will then appear in the Dock, allowing you to start the program by clicking the icon.



2.4 — Installing QuickTime 5.0.2


The **Welcome to QuickTime** dialog box appears, showing that you are now installing QuickTime 5. Click **Continue**.



The QuickTime 5 license will appear. Read the license carefully. If you accept the terms of the license and wish to continue with the installation, click **Agree**.



The **Choose Installation Type** dialog box will be displayed. Select **Recommended** and click **Continue**.



The Registration dialog box will be displayed. Leave the entry fields blank and click **Continue**.



When the installation is complete the dialog box shown below will be displayed. Click **Restart** to end the installation and restart your computer. When your computer restarts, the Quick Time settings dialog box will be displayed. For information on Quick Time settings, refer to the instructions provided with the software.

