


Panorama Maker 3.0

A series of pictures taken at a setting of Panorama Assist can be combined into a seamless Panorama using ArcSoft's Panorama Maker.


Step 1

Select a series of images taken with Panorama Assist. Select Edit using other program from the File menu. Select PanoramaMaker 3.0 from the list which appears. If Panorama Maker is not listed, use Add/Remove Editing program to register Panorama maker.



Step 2

Panorama Maker 3.0 will start. The software will automatically detect the direction of the panorama. The example below shows a horizontal panorama. Click **Next**.




For further information on how to create a panorama using Panorama Maker 3.0, click the **Help** button and refer to the Help file.



Step 3

The software will automatically detect the order of the images in the panorama. The software will start to create the panorama when you click **Next**.




Images used to make panorama

Step 4


A preview of the completed panorama is displayed. Use the **Fine Tune** tool to digitally adjust the “join” between the individual images in the panorama.

Click **Finish** to display the completed panorama.



Step 5


Click **Save** to save the panorama.



Step 6

In the **Save As** dialog box, enter the desired file name for the newly created panorama.

Under **Save in:** choose where you would like to save the image.



Viewing panorama images in Nikon Browser

When a panorama image is viewed in Nikon Browser, a generic file icon may be displayed instead of the actual image thumbnail. If a generic icon is displayed, click **Recreate thumbnails from the actual image data** in the Thumbnail tab of the Preferences dialog box . The generic icon will then be replaced by the thumbnail. Note that the time taken to display thumbnails in the thumbnail area will increase.

