



**NOKIA**  
Nseries

# Additional applications

Nokia N95-1

#### ABOUT ADD-ON APPLICATIONS FOR YOUR NOKIA N95

In the memory of your device and on the CD-ROM supplied with the device you will find additional applications from Nokia and third-party developers.

#### NO WARRANTY

The third-party applications provided with your device may have been created and may be owned by persons or entities not affiliated with or related to Nokia. Nokia does not own the copyrights or intellectual property rights to the third-party applications. As such, Nokia does not take any responsibility for end-user support, functionality of the applications, or the information in the applications or these materials. Nokia does not provide any warranty for the third-party applications. BY USING THE APPLICATIONS YOU ACKNOWLEDGE THAT THE APPLICATIONS ARE PROVIDED AS IS WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW. YOU FURTHER ACKNOWLEDGE THAT NEITHER NOKIA NOR ITS AFFILIATES MAKE ANY REPRESENTATIONS OR WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO WARRANTIES OF TITLE, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OR THAT THE APPLICATIONS WILL NOT INFRINGE ANY THIRD-PARTY PATENTS, COPYRIGHTS, TRADEMARKS, OR OTHER RIGHTS.

© 2006 Nokia. All rights reserved.

Nokia, Nokia Connecting People, Nseries, and N95 are trademarks or registered trademarks of Nokia Corporation. Other product and company names mentioned herein may be trademarks or tradenames of their respective owners.

Nokia operates a policy of ongoing development. Nokia reserves the right to make changes and improvements to any of the products described in this document without prior notice.

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, UNDER NO CIRCUMSTANCES SHALL NOKIA OR ANY OF ITS LICENSORS BE RESPONSIBLE FOR ANY LOSS OF DATA OR INCOME OR ANY SPECIAL, INCIDENTAL, CONSEQUENTIAL OR INDIRECT DAMAGES HOWSOEVER CAUSED.

THE CONTENTS OF THIS DOCUMENT ARE PROVIDED "AS IS". EXCEPT AS REQUIRED BY APPLICABLE LAW, NO WARRANTIES OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE MADE IN

RELATION TO THE ACCURACY, RELIABILITY OR CONTENTS OF THIS DOCUMENT. NOKIA RESERVES THE RIGHT TO REVISE THIS DOCUMENT OR WITHDRAW IT AT ANY TIME WITHOUT PRIOR NOTICE.

The availability of particular products and applications and services for these products may vary by region. Please check with your Nokia dealer for details, and availability of language options.

Some operations and features are SIM card and/or network dependent, MMS dependent, or dependent on the compatibility of devices and the content formats supported. Some services are subject to a separate charge.

# Contents

<b>Introduction .....</b>	<b>4</b>
Network services.....	4
Support.....	5
<b>Gallery.....</b>	<b>6</b>
Print online.....	6
Online share.....	7
<b>Mobile Search .....</b>	<b>10</b>
Use Mobile Search .....	10
More information.....	10
<b>Download!.....</b>	<b>11</b>
Download! .....	11

<b>Tools.....</b>	<b>13</b>
Push to talk .....	13
Settings wizard .....	17
<b>Applications.....</b>	<b>19</b>
Games .....	19
<b>For your PC.....</b>	<b>20</b>
Home Media Server .....	20
Nokia PC Suite .....	21

# Introduction



Model number: Nokia N95-1

Hereinafter referred to as Nokia N95.

Your Nokia N95 is a powerful, intelligent multimedia device. There are various applications provided by Nokia and different third-party software developers to help you do more with your Nokia N95.

Some of the applications provided are in the device memory, and some are on the CD-ROM supplied with the device.

To use some applications, you must accept the applicable license terms.

Throughout this document, icons indicate if the application is available in the device memory () or on the CD-ROM (.

Refer to the user guide for other important information about your device.

You must install the applications on the CD-ROM to a compatible PC before using them.

Copyright protections may prevent some images, music (including ringing tones), and other content from being copied, modified, transferred, or forwarded.

Your device may have preinstalled bookmarks and links for third-party internet sites. You may also access other third-party sites through your device. Third-party sites are not affiliated with Nokia, and Nokia does not endorse or assume liability for them. If you choose to access such sites, you should take precautions for security or content.

## Network services

To use the phone you must have service from a wireless service provider. Many of the features require special network features. These features are not available on all networks; other networks may require that you make specific arrangements with your service provider before you can use the network services. Your service provider can give you instructions and explain what charges will apply. Some networks may have limitations that affect how you can use network services. For instance, some networks may not support all language-dependent characters and services.

Your service provider may have requested that certain features be disabled or not activated in your device. If so, these features will not appear on your device menu. Your device may also have a special configuration such as

changes in menu names, menu order, and icons. Contact your service provider for more information.

## Support

Applications provided by third-party software developers are supported by these developers. If you experience problems with an application, obtain support from the relevant website. See the web links at the end of each application in this guide.

# Gallery

## Print online

With [Print online](#), you can order prints of your images online directly to your home or to a store where you can pick them up. You can also order different products with the selected image, such as mugs or mouse pads. The available products depend on the service provider.

In order to use [Print online](#), you must have at least one printing service configuration file installed. The files can be obtained from printing service providers that support [Print online](#).

## Order prints

You can only print images that are in .jpeg format.

Press , and select [Gallery](#) > [Images & video](#).

- 1 Select an image or images and [Options](#) > [Print](#) > [Order prints](#).
- 2 Select a service provider from the list.
- 3 Select [Options](#) and from the following:  
[Open](#)—to start the connection to the service provider  
[Info](#)—to view information about the service provider, for example, the address of a store, contact details,

and web links to more information on the service provider

- [Remove](#)—to remove the service provider from the list  
[Log](#)—to view the details of the previous orders
- 4 If the service provided is a single shop service, you are connected to the service provider, and the images preview view displays the images you selected in [Gallery](#). Select [Options](#) and from the following:  
[Preview](#)—to view the image before ordering a print. Scroll up or down to view the images.  
[Order now](#)—to submit your order  
[Change product order](#)—to adjust the product details and number of copies for the selected image. In the product order view, you can select the product and the type you want to order. The available options and products vary by the service provider. Scroll left or right to view and change the image details of the other images.  
[Change customer info](#)—to change the customer and order information  
[Add image](#)—to add more images to the order  
[Remove image](#)—to remove images from the order
  - 5 If the service offered is a retailer group service, you are connected to the service provider, and need to select a store from where you want to collect your prints. The

images preview view displays the images you selected in **Gallery**. Depending on the service provider, you may have options for browsing and searching for stores with different search criteria.

To check details, such as opening hours of the selected store, select **Options > Info** (if provided by the service provider).

Scroll to the desired retail pick up point, and press the scroll key. You can preview the images before ordering, change image details or customer information, or add or remove images from the order. To order the prints, select **Options > Order now**.

## Online share

With **Online share**, you can share your images and video clips in compatible online albums, weblogs, or other compatible online sharing services on the web. You can upload content, save unfinished posts as drafts and continue later, and view the content of the albums. The supported content types may vary depending on the service provider.


## Get started

To use **Online share**, you must subscribe to the service with an online image sharing service provider. You can usually subscribe to the service on the web page of the

service provider. Contact your service provider for details on subscribing to the service. For more information on compatible service providers, see [www.nokia.com/support](http://www.nokia.com/support).

When you open the service for the first time in the Online share application, you are prompted to create a new account and define the user name and password for it. To access the account settings later, select **Online share > Options > Settings**. See 'Online share settings', p. 8.

## Upload files

Press , and select **Gallery > Images & video**, the files you want to upload, and **Options > Send > Web upload**. You can also access **Online share** from the main camera.

**Select service** opens. To create a new account for a service, select **Options > Add new account** or the service icon with **Create new** in the services list. If you have created a new account offline or modified an account or service settings through a web browser on a compatible PC, to update the services list in your device, select **Options > Retrieve services**. To select a service, press the scroll key.

When you select the service, the selected images and videos are shown in the edit state. You can open and view the files, reorganize them, add text to them, or add new files.

To cancel the web upload process and save the created post as a draft, select **Back** > **Save as draft**. If the upload has already begun, select **Cancel** > **Save as draft**.

To connect to the service and upload the files to the web, select **Options** > **Upload**, or press **⌘** .

## Open online service

To view uploaded images and videos in the online service and draft and sent entries in your device, select **Images & video** > **Options** > **Open online service**. If you create a new account offline or modify an account or service settings through a web browser on a compatible PC, select **Options** > **Retrieve services** to update the services list in your device. Select a service from the list.

After you open a service, select from the following:

**Open in Web browser**—to connect to the selected service and view the uploaded and draft albums in the web browser. The view may vary depending on the service provider.

**Drafts**—to view and edit the draft entries and upload them to the web

**Sent**—to view the 20 latest entries created through your device

**New post**—to create a new entry

The available options may vary depending on the service provider.

## Online share settings

To edit the Online share settings, in **Online share**, select **Options** > **Settings**.

## My accounts

In **My accounts**, you can create new accounts or edit existing accounts. To create a new account, select **Options** > **Add new account**. To edit an existing account, select an account and **Options** > **Edit**. Select from the following:

**Account name**—to enter the desired name for the account

**Service provider**—to select the service provider you want to use. You cannot change the service provider for an existing account; you must create a new account for the new service provider. If you delete an account in **My accounts**, the services related to the account are also deleted from your device, including the sent items for the service.

**User name** and **Password**—to enter the user name and password you created for your account when you registered to the online service

**Upload image size**—to select the size in which the images are uploaded to the service



## Application settings

**Display image size**—to select the size in which the image is shown on the display of your device. This setting does not affect the upload image size.

**Display text size**—to select the font size used to display text in draft and sent entries or when you add or edit text to a new entry

### Advanced

**Service providers**—To view or edit service provider settings, add a new service provider, or view details of a service provider. If you change the service provider, all My accounts information for the previous service provider is lost. You cannot change the settings of predefined service providers.


**Default access point**—To change the access point used to connect to the online service, select the access point you want.



## Mobile Search

Use Mobile Search to get access to search engines, and find and connect to local services, websites, images, and mobile content. You can use the application to find and call local restaurants and shops, and use the advanced mapping technology to assist you in finding their location.

### Use Mobile Search

Press  , and select **Search**.

When you open Mobile Search, a list of categories is displayed. Select a category (for example, images), and enter your text into the search field. Select **Search**. The search results are displayed on the screen.

### More information

For additional help and instructions on the application, select **Options > Help**.


For more information on the application, visit also [www.mobilesearch.nokia.com/](http://www.mobilesearch.nokia.com/).

# Download!



## Download!

With **Download!** you can discover; preview; buy; download; and upgrade content, services, and applications that work with your Nokia N95. Games, ringing tones, wallpapers, applications, and much more are easily accessible. The items are categorized under catalogs and folders provided by different service providers. The available content depends on your service provider.

Press , and select **Download!**.

**Download!** uses your network services to access the most up-to-date content. For information on additional items available through **Download!**, contact your service provider, or the supplier or manufacturer of the item.

**Download!** receives ongoing updates, and provides you with the latest content your service provider offers for your device. To update the content in **Download!** manually, select **Options > Refresh list**.

To hide a folder or a catalog from the list, for example, to view only the items you use frequently, select **Options > Hide**. To make all the hidden items visible again, select **Options > Show all**.

To buy the selected item in the main view, a folder, or a catalog, select **Options > Buy**. A submenu opens where you can select the version of the item and view price information. The available options depend on the service provider.

To download an item that is free of charge, select **Options > Get**.

## Settings for Download!

The application updates your device with the most recent content available from your service provider and other available channels. To change the settings, select **Options > Settings** and from the following:

**Access point**—to select which access point is used to connect to the service provider's server and whether to have the device to ask for the access point every time you use it

**Automatic open**—To automatically open the content or application after downloading, select **Yes**.

**Preview confirmation**—To automatically download a preview of the content or application, select **No**. To be

asked separately each time before downloading a preview, select **Yes**.

**Buy confirmation**—To be asked for confirmation before buying content or an application, select **Yes**. To start the buying process immediately after you select **Buy**, select **No**.

After you complete the settings, select **Back**.



# Tools



## Push to talk

Push to talk (PTT) (network service) is a real-time voice over IP service implemented over a GSM/GPRS network. PTT provides direct voice communication connected with the push of a key. Use PTT to have a conversation with one person or with a group of people.

Before you can use PTT, you must define the PTT access point and settings. You may receive the settings in a special text message from the service provider that offers the PTT service. You can also use the settings wizard application for configuration, if supported by your service provider. See 'Settings wizard', p. 17.

Press , and select **Tools > Push to talk**.

In PTT communication, one person talks while the others listen through the built-in loudspeaker. Speakers take turns responding to each other. Because only one group member can talk at any time, the maximum length of time that one person can talk is limited, usually to 30 seconds. For details about the length of talk time for your network, contact your service provider.



**Warning:** Do not hold the device near your ear when the loudspeaker is in use, because the volume may be extremely loud.

Phone calls always take priority over PTT activities.

## Define a PTT access point

Many service providers require you to use an internet access point (IAP) for your default access point. Other service providers allow you to use a WAP access point. Contact your service provider for more information.

If you do not have a WAP connection, you may need to contact your service provider for assistance with the first-time connection or visit [www.nokia.com/phonesettings](http://www.nokia.com/phonesettings).

## PTT settings

Press , and select **Tools > Push to talk > Options > PTT settings**.

Select **User settings**, and enter the following information:

**Accepted list calls**—Select **Notify** if you want to see a notification of incoming calls. Select **Auto-accept** if you

want PTT calls to be answered automatically. Select **Not allowed** if you want PTT calls to be rejected automatically.

**PTT call alert tone**—Select **Set by profile** if you want the incoming call alert setting for PTT to be the same as the incoming call alert tone defined in the prevailing active profile.

**Callback request tone**—Select a tone for callback requests.

**Application start-up**—Select if you want to log in to the PTT service when you switch on your device.

**Default nickname**—Enter your default nickname that is displayed to other users. Your service provider may have disabled the editing of this option in your device.

**Show my PTT address**—Select **In 1 to 1 calls**, **In group calls**, **In all calls**, or **Never**. Your service provider may have disabled some of these options in your device.

**Show my login status**—Select **Yes** if you want your status to be shown or **No** if you want your status to be hidden.

Select **Connection settings**, and enter the following information:

**Domain**—Enter the domain name obtained from your service provider.


**Access point name**—Enter the PTT access point name. The access point name is needed to establish a connection to the GSM/GPRS network.

**Server address**—Enter the IP address or domain name of the PTT server obtained from your service provider.

**User name**—Enter your user name obtained from your service provider.


**PTT password**—Enter a password, if required, to make a data connection. The password is usually provided by the service provider and is often case-sensitive.


## Log in to PTT

Press , and select **Tools > Push to talk**. PTT automatically logs in to the service when started.

When login is successful, PTT automatically connects to channels that were active when the application was last closed. If the connection is lost, the device automatically tries to log back in until you choose to exit PTT.

## Exit PTT



Press , and select **Tools > Push to talk > Options > Exit. Log out from PTT after exiting application?** is displayed. To log out and close the service, select **Yes**. To keep the application active on the background, select **No**.



If several applications are open and you want to switch from one application to another, press and hold .


## Make a one-to-one call

Select **Options** > **Contacts**.



Select the contact to whom you want to talk from the list, and select **Options** > **Talk 1 to 1**.


Press and hold  the entire time you are talking. When you have finished talking, release .

To talk to the contact in other views in PTT (for example, the contacts view), press and hold . To make a new phone call, end the one-to-one call. Select **Disconnect**, or press .

 **Tip!** Remember to hold the device in front of you during a PTT call so you can see the display. Speak towards the microphone, and do not cover the loudspeaker with your hands.

## Answer a one-to-one call

To start a one-to-one call, press . To dismiss the call, press .

 **Tip!** To make a one-to-one or group call from contacts, select **Options** > **PTT options** > **Talk 1 to 1** or **Talk to many**.

## Make a group call

To call a group, select **Options** > **Contacts**, mark the contacts you want to call, and select **Options** > **Talk to many**.

## Subscribe to login status of others

To subscribe or unsubscribe to the PTT login status of others, select **Options** > **Contacts**, the contact, and **Options** > **Show login status** or **Hide login status**.

## Send a callback request

In **Contacts**, scroll to the desired name, and select **Options** > **Send callback request**.

## Respond to a callback request

When someone sends you a callback request, **1 new callback request** is displayed in standby mode. Select **Show** > **Callback inbox**. To start a one-to-one call, select a contact and **Options** > **Talk 1 to 1**.

## Channels

You can join public preconfigured channels. Public channels are open to anyone who knows the URL for the channel.

When you are connected to a channel and talk, all members joined to the channel hear you talking. Up to five channels can be active at the same time. When more than one channel is active, use **Swap** to change the channel you want to talk to.

Select **Options > PTT channels**.

To connect to a public preconfigured channel for the first time, select **Options > New channel > Add existing**.

When you join a preconfigured channel, you must fill in an URL for the channel.

## Create your own channels

To create a new preconfigured channel select **Options > New channel > Create new**.

You can create your own public channels, choose your own channel name, and invite members. Those members can invite more members to the public channel.

You may also set up private channels. Only users invited by the host are allowed to join and use private channels.

For each channel, define **Channel name**, **Channel privacy**, **Nickname**, and **Thumbnail** (optional).

When you have successfully created a channel, you are asked if you want to send channel invitations. Channel invitations are text messages.

## Talk to a channel

To talk to a channel after you log in to the PTT service, press **⌘**. You hear a tone indicating that access is granted.

Continue to press and hold **⌘** the entire time you are talking. When you finish talking, release **⌘**.

If you try to respond to a channel by pressing **⌘** while another member is talking, **Wait** is displayed. Release **⌘**, wait for the other person to finish talking, and press **⌘** again when the speaker has finished. Alternatively, keep **⌘** pressed and wait for **Talk** to be displayed.

When you are talking in a channel, the first person to press **⌘** when someone stops talking talks next.

When you have finished the PTT call, select **Disconnect** or press **⌘**.

To view currently active members of a channel when you have an active call to the channel, select **Options > Active members**.

To invite new members to a channel when you are connected to it, select **Options > Send invitation** to open the invitation view. You can only invite new members when you are the host of a private channel, or when the channel is a public channel. Channel invitations are text messages.



## Respond to a channel invitation

To save a received channel invitation, select **Options** > **Save channel**. The channel is added to your PTT contacts, channels view.

After you save the channel invitation, you are asked if you want to connect to the channel. To open the PTT sessions view, select **Yes**. Your device logs in to the service, if you are not logged in already.

If you reject or clear the invitation, the invitation is stored in your messaging inbox. To join the channel later, open the invitation message, and save the invitation. To connect to the channel, select **Yes** from the dialog.

## View the PTT log

Press **Ⓜ**, and select **Tools** > **Push to talk** > **Options** > **PTT log** > **Missed PTT**, **Received PTT**, and **Created PTT**.

To initiate a one-to-one call from **PTT log**, press **Ⓜ**.



## Settings wizard

Press **Ⓜ**, and select **Tools** > **Sett. wizard**.

**Settings wizard** configures your device for operator, e-mail, PTT, and video sharing settings based on your service provider information.

The availability of different settings in **Settings wizard** depends on the features of your device, SIM card, operator, and availability of the data in the settings wizard database in the device memory.

To use these services, you may have to contact your service provider to activate a data connection or other services.

When you use the application for the first time, you are guided through the settings configuration. To start the wizard, select **Start**. To cancel the operation, select **Exit**.

If you do not have a SIM card inserted, you are asked to select the home country of your operator and your operator (wireless service provider). If the country or operator suggested by the wizard is not the correct one, select one from the list.

To access the main view of **Settings wizard** after the settings configuration, select **OK**. If the settings configuration is interrupted, the settings are not defined. After closing the wizard you can start to use the configured applications in their own menu locations.

## E-mail

When you choose to configure your e-mail settings, **Settings wizard** asks you to enter the e-mail address, mailbox name, user name, and password.

If the e-mail service provider you enter is unknown, the wizard asks you to define the mailbox type and incoming and outgoing mail servers. Contact your service provider for more information.

To start using the new mailbox after entering the required information, select **Yes**, or select **No** to return to the **Settings wizard** main view.

## Operator

When you choose to configure your operator (wireless service provider) settings, **Settings wizard** asks you to select from the available settings, then **OK**.

## Push to talk

This option is available only if you have the application installed in your device, and you have subscribed to the service.

When you choose to configure your push-to-talk (PTT) (network service) settings, **Settings wizard** asks you to define the PTT nickname, user name, and password.

## Video sharing

This option is available only if you have the application installed in your device and you have subscribed to the service.

To be able to make a video call, you must have a USIM card and be in coverage of a UMTS network.

When you choose to configure your video sharing (network service) settings, **Settings wizard** asks you to enter the video sharing address, user name, password, video sharing proxy user name, and password; and select **OK**.

After creating video sharing settings, **Settings wizard** asks if you want to add the video sharing address to a contact. Select **Yes** or **No**.

## More information

If you experience any problems with **Settings wizard**, visit the Nokia phone settings website at [www.nokia.com/phonesettings](http://www.nokia.com/phonesettings).

# Applications




## Games

Press **⌘G**, and select **Applications > Games** and a game.  
For instructions on how to play the game, select **Options > Help**.

# For your PC

## Home Media Server

 **Important:** Always enable one of the available encryption methods to increase the security of your wireless LAN connection. Using encryption reduces the risk of unauthorized access to your data.

Home Media Server uses UPnP architecture to connect to compatible devices through wireless LAN. UPnP architecture uses the security settings of the wireless LAN connection.

With Home Media Server you can easily catalog music, pictures, and video files on your compatible PC. You can create custom music playlists, photo albums, and movie collections. You can transfer compatible media files to your device and back up files from your device to your PC. You can use your device as a remote control, and show media files from the device or PC to a UPnP compatible networked home media player such as a PC, television, or stereo system.

## Install Home Media Server on a PC

Install the Home Media Server application to your compatible PC from the CD-ROM supplied with your

device. Home Media Server requires Microsoft Windows 2000 or Windows XP operating system. If you have a firewall to protect your PC, you may need to change settings to allow the PC to work with your Nokia N95. Follow the on-screen installation instructions.

## Manage your media files

To keep track of your songs, digital photos, and video clips, locate the files on your compatible PC and add the files or entire folders to Home Media Server.

You can designate folders where you keep compatible media files on your PC as watch folders. When you place new media files in watch folders, Home Media Server adds them to your library and keeps them updated automatically.

## Transfer files from PC to your device

- 1 Using your Nokia N95, connect to the Home Media Server on your compatible PC.  
On your compatible PC, using the Home Media Server application, select your Nokia N95 in the devices menu.
- 2 Select a media file library you want to transfer.
- 3 Select a single media file.

- 4 Select the option to transfer the file to the Nokia N95.

## Transfer files from your device to PC

- 1 Using your Nokia N95, connect to the Home Media Server on your compatible PC; or on your compatible PC, using the Home Media Server application, select your Nokia N95 in the devices menu.
- 2 Select the file you want to transfer.
- 3 Select the option to transfer the file to the Home Media Server on your compatible PC.

## Show files from PC in other devices

You can use your Nokia N95 as a remote control to show compatible media files from Home Media Server on your compatible PC in other UPnP compatible devices of your home network. For example, you can use your Nokia N95 to control playback of compatible music files stored on your PC through your UPnP compatible home audio system using a UPnP compatible multimedia receiver.

## Control media files with your Nokia N95

- 1 Using your Nokia N95, connect to the Home Media Server on your compatible PC.
- 2 Select the media library containing the file you want to control.
- 3 Select a media file.

- 4 Select the compatible device on which the file is shown.

## More information

For more information on Home Media Server, visit [www.simplecenter.net/nokia](http://www.simplecenter.net/nokia) or press **F1** in the Home Media Server application to open Help.



## Nokia PC Suite

Nokia PC Suite is a set of PC applications developed for use with your Nokia N95.

To install and use Nokia PC Suite, you need a PC that runs on Microsoft Windows 2000 or XP and is compatible with a USB data cable, Bluetooth connectivity, or infrared. Before using Nokia PC Suite, you need to install it on your PC. See the CD-ROM supplied with your device for more information.

A full user guide for Nokia PC Suite is available in electronic format on the CD-ROM. For further information, and to download the most recent version of Nokia PC Suite, visit [www.nokia.com/pcsuite](http://www.nokia.com/pcsuite).

Some useful applications in Nokia PC Suite are as follows:

**Get Connected**—to connect your device to a compatible PC for the first time

**Synchronize**—to synchronize contacts, calendar, to-do, and note items, and e-mails between your device and a compatible PC personal information manager (PIM) with Nokia PC Sync

**Backup**—to back up data from your device or restore saved data from the compatible PC to the device with Content Copier

**Store images**—to store images and videos from your device to a compatible PC with Image Store

**File manager**—to manage the contents of your device folders through Microsoft Windows Explorer with Nokia Phone Browser

**Transfer music**—to create and organize digital music files on a compatible PC and transfer them to a compatible device with Nokia Music Manager

**Connect to the Internet**—to establish a network connection with One Touch Access using your device as a modem

**View multimedia**—to view images and videos, and convert video and audio files with Nokia Multimedia Player

## More information

For further information, and to download the most recent version of Nokia PC Suite, visit [www.nokia.com/pcsuite](http://www.nokia.com/pcsuite).