

TX-W28R4 Service Manual

Safety

Specifications

Parts List

Service Information

Adjustments

Self Check

Service Hints

Mechanical View

Disassembly

Location of Controls

Waveforms

Block Diagrams

Schematic Diagrams

PCB Views

Service Support

Service and repair of this product is supported by Panasonic's LUCI interface.

This interface provides a link between the TV and a standard PC to allow a number of diagnostic and control functions to be performed.

For more details contact your local Panasonic company.



BACK

EXIT

Audio

Control

Power supply

Video



BACK

E - PCB

M - PCB

E - Schematic

H - Schematic

Y - PCB

M - Schematic

Y - Schematic



BACK



BACK

Service Manual



Colour Television

TX-W28R4

EURO4 Chassis

SPECIFICATIONS

Power Source:	220-240V AC, 50Hz	AV3 IN	S-Video IN (4-pin) Audio (RCAx2)	Y: 1V p-p 75Ω C: 0,3V p-p 75Ω 500mV rms 10kΩ
Power Consumption:	100W		Video (RCAx1)	1V p-p 75Ω
Aerial Impedance:	75Ω unbalanced, Coaxial Type			
Stand-by Power Consumption:	1,8W	High Voltage:	30,5kV ±1kV	
Receiving System:	PAL I, PAL 525/60 M.NTSC NTSC (AV only)	Picture Tube:	W66EHK51X35	66cm
Receiving Channels:	UHF E21-E69	Audio Output:	2 x 20W (Music Power) 8Ω Impedance	
Intermediate Frequency:		Headphones:	8Ω Impedance 3,5 mm	
Video	39,5MHz	Accessories supplied :	Remote Control 2 x R6 (UM3) Batteries	
Audio	33,5MHz, 32,95MHz			
Colour	35,07MHz	Dimensions:	Height: Width: Depth:	518 mm 760 mm 496,8 mm
Video/Audio Terminals:				
AV1 IN	Video (21 pin) Audio (21 pin) RGB (21 pin)	1V p-p 75Ω 500mV rms 10kΩ	Net weight:	35,5kg
AV1 OUT	Video (21 pin) Audio (21 pin)	1V p-p 75Ω 500mV rms 1kΩ	Specifications are subject to change without notice. Weights and dimensions shown are approximate.	
AV2 IN	Video (21 pin) Audio (21 pin) S-Video IN (21 pin)	1V p-p 75Ω 500mV rms 10kΩ Y: 1V p-p 75Ω C: 0.3V p-p 75Ω	NOTE: This Service Manual should be used in conjunction with the EURO4 Technical Guide.	
AV2 OUT	Video (21 pin) Audio (21 pin) Selectable Output (21 pin)	1V p-p 75Ω 500mV rms 1kΩ		

Panasonic

Panasonic CS (U.K.) Ltd.
WILLOUGHBY ROAD,
BRACKNELL,
BERKS.,
RG12 8FT.

CONTENTS

SAFETY PRECAUTIONS.....	2
SERVICE HINTS.....	3
SERVICE POSITION.....	4
ADJUSTMENT PROCEDURE.....	5
ADJUSTMENT PROCEDURE AND SELF-CHECK	6
WAVEFORM PATTERN TABLE	7
ALIGNMENT SETTINGS.....	8
BLOCK DIAGRAMS	9
PARTS LOCATION	13
REPLACEMENT PARTS LIST	14
SCHEMATIC DIAGRAMS	23
CONDUCTOR VIEWS.....	28

SAFETY PRECAUTIONS

GENERAL GUIDE LINES

1. It is advisable to insert an isolation transformer in the AC supply before servicing a hot chassis.
2. When servicing, observe the original lead dress in the high voltage circuits. If a short circuit is found, replace all parts that have been overheated or damaged by the short circuit.
3. After servicing, see that all the protective devices such as insulation barriers, insulation papers, shields and isolation R-C combinations are correctly installed.
4. When the receiver is not being used for a long period of time, unplug the power cord from the AC outlet.
5. Potentials as high as 31,5kV are present when this receiver is in operation. Operation of the receiver without the rear cover involves the danger of a shock hazard from the receiver power supply. Servicing should not be attempted by anyone who is not familiar with the precautions necessary when working on high voltage equipment. Always discharge the anode of the tube.
6. After servicing make the following leakage current checks to prevent the customer from being exposed to shock hazard.

LEAKAGE CURRENT COLD CHECK

1. Unplug the AC cord and connect a jumper between the two prongs of the plug.
2. Turn on the receiver's power switch.
3. Measure the resistance value with an ohmmeter, between the jumpered AC plug and each exposed metallic cabinet part on the receiver, such as screw heads, aerials, connectors, control shafts etc. When the exposed metallic part has a return path to the chassis, the reading should be between 4M ohm and 20M ohm. When the exposed metal does not have a return path to the chassis, the reading must be infinite.

LEAKAGE CURRENT HOT CHECK

1. Plug the AC cord directly into the AC outlet. Do not use an isolation transformer for this check.
2. Connect a $2\text{k}\Omega$ 10W resistor in series with an exposed metallic part on the receiver and an earth, such as a water pipe.
3. Use an AC voltmeter with high impedance to measure the potential across the resistor.
4. Check each exposed metallic part and check the voltage at each point.

5. Reverse the AC plug at the outlet and repeat each of the above measurements.
6. The potential at any point should not exceed 1,4 Vrms. In case a measurement is outside the limits specified, there is a possibility of a shock hazard, and the receiver should be repaired and rechecked before it is returned to the customer.

HOT CHECK CIRCUIT




Fig. 1.

X-RADIATION WARNING

1. The potential sources of X-Radiation in TV sets are the high voltage section and the picture tube.
2. When using a picture tube test jig for service, ensure that the jig is capable of handling 30,5kV without causing X-Radiation.


NOTE: It is important to use an accurate periodically calibrated high voltage meter.

1. Set the brightness to minimum.
2. Measure the high voltage. The meter should indicate $\sim 30,5\text{kV} \pm 1\text{kV}$. If the meter indication is out of tolerance, immediate service and correction is required to prevent the possibility of premature component failure.
3. To prevent any X-Radiation possibility, it is essential to use the specified tube.

SERVICE HINTS

How to remove the rear cover

1. Remove the 9 screws as shown in Fig.2.



LOCATION OF CONTROLS




Fig.3.

HOW TO MOVE THE CHASSIS INTO SERVICE POSITION

1. Remove the bead clamper from the mains lead and screw, using back cover screw, into top right-hand cabinet rib (A), shown in **Fig.4**.
2. Hold and lift the rear of the E-PCB chassis and gently pull the chassis toward you, as shown in **Fig.4**.
3. Release the respective wiring clips and rotate the chassis vertically through 90°, anti-clockwise.
4. Locate the base of the chassis frame into the hole (B), shown in **Fig.6**.
5. Clip the chassis frame onto the bead clamper, as shown in **Fig.5**.
6. After servicing replace the bead clamper and ensure all wiring is returned to its original position before returning the receiver to the customer.




Fig.4.



Fig.5.




Fig.6.

(B)

ADJUSTMENT PROCEDURE

The remote control is used for entering and storing adjustments, with the exception of Cut-off adjustments, which must always be done prior to service adjustment. Perform adjustments in accordance with screen display. The display on the screen also specifies the software version as well as the approx. setting values. The adjustment sequence for the service mode is indicated below.

1. Set the Bass to maximum position, set the Treble to minimum position, press the F button followed by the volume down button on the customer controls at the front of the TV and at the same time press the "INDEX" button on the remote control, this will place the TV into the Service Mode.
2. Press the **RED / GREEN** buttons to step up / down through the functions.
3. Press the **YELLOW / BLUE** buttons to alter the function values.
4. Press the **STR** button after each adjustment has been made to store the required values.
5. To exit the Service Mode, turn the TV off at the power button.

NOTE: This TV also has the option of using a Memory Pack which enables you to copy the preset TV channels into the Memory Pack and then download them onto this or any other EURO-4 TV set.

TV to Memory Pack process

1. Plug the memory pack into the AV1 21 pin terminal at the back of the TV and switch the TV on.
2. Enter Service Mode as explained above.
The screen will show :-

Program
External>>TV

3. Press the **BLUE** button on the remote control.
The screen will show :-

Program
TV>>External

4. Press the **STR** button on the TV.
The screen will show :-

Please Wait

5. All the tuning information stored inside the TV will now be transferred to the Memory Pack. This process will take 2-3 minutes to complete and when finished the screen will show :-

Complete

Memory Pack to TV process

1. Plug the memory pack into the AV1 21 pin terminal at the back of the TV and switch the TV on.
2. Enter Service Mode as explained above.
The screen will show :-

Program
External>>TV

3. Press the **STR** button on the TV.
The screen will show :-

Please Wait

4. All the tuning information stored inside the Memory Pack will now be transferred to the TV. This process will take 2-3 minutes to complete and when finished the screen will show :-

Complete

5. The tuning information from the Memory Pack has now been copied into the TV.
6. To exit the Service Mode turn the TV off at the power button.
7. The process has now been completed and the Memory Pack can now be removed.

ERRORS

If an error occurs while using the Memory Pack the TV will detect this and the screen will show :-

Error !!

If this happens then press the "**N**" button and repeat the process that was being used. If the errors continue to occur then check the connectors between the TV and the memory pack and check the 9V battery inside the memory pack.

ADJUSTMENT PROCEDURE

Item / Preparation	Adjustments																																										
+B SET-UP <ol style="list-style-type: none"> Receive a Greyscale signal. Set the controls :- <table> <tr><td>Brightness</td><td>Minimum</td><td>B9</td><td>5 ± 0,25V</td><td>B10</td><td>5 ± 0,25V</td></tr> <tr><td>Contrast</td><td>Minimum</td><td>B5</td><td>12 ± 0,5V</td><td>B11</td><td>33 ± 1,5V</td></tr> <tr><td>Volume</td><td>Minimum</td><td>B4</td><td>16 ± 1V</td><td>B7</td><td>8 ± 0,5V</td></tr> </table> 	Brightness	Minimum	B9	5 ± 0,25V	B10	5 ± 0,25V	Contrast	Minimum	B5	12 ± 0,5V	B11	33 ± 1,5V	Volume	Minimum	B4	16 ± 1V	B7	8 ± 0,5V	<ol style="list-style-type: none"> Set the +B voltage up as follows:- Adjust R811 so that B2 shows $148V \pm 1V$. Confirm the following voltages. <table> <tr><td>B9</td><td>5 ± 0,25V</td><td>B10</td><td>5 ± 0,25V</td></tr> <tr><td>B5</td><td>12 ± 0,5V</td><td>B11</td><td>33 ± 1,5V</td></tr> <tr><td>B4</td><td>16 ± 1V</td><td>B7</td><td>8 ± 0,5V</td></tr> <tr><td>B12</td><td>26 ± 1V</td><td>B8</td><td>5,5 ± 0,5V</td></tr> <tr><td>B3</td><td>41 ± 1,5V</td><td>B13</td><td>15 ± 1V</td></tr> <tr><td>B1</td><td>200 ± 10V</td><td>B14</td><td>-15 ± 1V</td></tr> </table> 	B9	5 ± 0,25V	B10	5 ± 0,25V	B5	12 ± 0,5V	B11	33 ± 1,5V	B4	16 ± 1V	B7	8 ± 0,5V	B12	26 ± 1V	B8	5,5 ± 0,5V	B3	41 ± 1,5V	B13	15 ± 1V	B1	200 ± 10V	B14	-15 ± 1V
Brightness	Minimum	B9	5 ± 0,25V	B10	5 ± 0,25V																																						
Contrast	Minimum	B5	12 ± 0,5V	B11	33 ± 1,5V																																						
Volume	Minimum	B4	16 ± 1V	B7	8 ± 0,5V																																						
B9	5 ± 0,25V	B10	5 ± 0,25V																																								
B5	12 ± 0,5V	B11	33 ± 1,5V																																								
B4	16 ± 1V	B7	8 ± 0,5V																																								
B12	26 ± 1V	B8	5,5 ± 0,5V																																								
B3	41 ± 1,5V	B13	15 ± 1V																																								
B1	200 ± 10V	B14	-15 ± 1V																																								
CUT OFF / Ug2 Test <ol style="list-style-type: none"> Receive a Greyscale signal. Degauss the tube externally. Set the TV into Service Mode 1. Select Cut off mode. 	<p>To adjust Cutoff connect an oscilloscope to the Blue cathode, adjust "cutoff" value using the "Yellow" and "Blue" buttons until the black level is $160V \pm 5V$ press "STR" to store the value. Remove the oscilloscope.</p> <p>Select Ug2 adjustment and adjust the screen VR until the display shows "O.K."</p>																																										

FACTORY SETTINGS

To return customer settings to factory settings and clear owner ID of all information input by the customer, enter Self-Check mode. Press the down (-/v) button on the customer controls at the front of the TV set, at the same time pressing the **STATUS** button  on the remote control. To exit Self Check, switch off the TV set at the power button.

NOTE: Self Check should only be used when refurbishing the TV set and not during normal repair work.

VDP	O.K.	PCB	O.K.
TUN	O.K.	Cab	O.K.
E2	O.K.	Sum	Factory use only
MSP	O.K.		
DPL	--		
OPTION 1	00		
OPTION 2	11		
OPTION 3	02		
OPTION 4	00		
OPTION 5	B1		
OPTION 6	A9		

Self Check is also used to automatically check the bus lines and hexadecimal code of the TV set. If the CCU ports have been checked and found to be incorrect or not located then " -- " will appear in place of "O.K.". For more in-depth TV diagnostics use the **LUCI** interface as listed below.

Service Aids

To aid in the service of our current chassis there are a number of Service Aids which have been made available.

- **LUCI** interface kit (**Linked Utility Computer Interface**)

Part number: TZS6EZ002

This contains interface and cables for connecting TV service connector and a PC as well as diagnostic software. As new models are introduced upgrade software will become available.

- **VICI** (**Visual Interactive Computer Information**)

These C.D.'s contain multimedia documentation providing quick access to service information.


















Part No. TZS7EZ006 & TZS7EZ005

1. Service Manuals
2. Instruction Books
3. Technical Information

- **TASMIN** (**Technically Advanced System for Multimedia Interactive Notes**)


As well as providing a first step towards more interactive training this product also achieves quick access to Technical Information.

WAVEFORM PATTERN TABLE




ALIGNMENT SETTINGS

(The figures below are nominal and used for representative purposes only.)

Alignment Function		Settings / Special features
Horizontal Position	H-Pos 061	Optimum setting.
Vertical Position	V-Pos 005	Optimum setting.
Horizontal Amplitude	H-Amp 055	Optimum setting.
Vert. Amplitude	V-Amp 054	Optimum setting.
EW-amplitude	E/W-Amp1 -128	Optimum setting.
EW-amplitude	E/W-Amp2 006	Optimum setting.
Trapezium-comp	Trapez-1 047	Optimum setting.
Trapezium-comp	Trapez-2 -128	Optimum setting.
Vertical Linearity	V-Lin 006	Optimum setting.
Vertical Symmetry	V-Sym 002	Optimum setting.
DVCO	DVCO -005	Receive a PAL Colour Bar Pattern. For DVCO alignment press "Blue" button, wait until the colours are changing slowly and press "STR".
Cut-off DC	Cut-off 0171	To adjust Cutoff connect an oscilloscope to the blue cathode, adjust "cutoff" value using the "Yellow" and "Blue" buttons until the black level is $160V \pm 5V$ press "STR" to store the value. Remove the oscilloscope. Select Ug2 adjustment and adjust the screen VR until the display shows "O.K."
Ug2 Test	Ug2 055 O.K.	
Highlight Lowlight	High 0902 0777 0864 Low 0117 0132 0112	Optimum setting.
Sub-Brightness	Sub-Brightness 255	Optimum setting.


VIDEO BLOCK DIAGRAM

6




AUDIO BLOCK DIAGRAM


01



CONTROL BLOCK DIAGRAM




POWER SUPPLY BLOCK DIAGRAM



PARTS LOCATION

NOTE:

The numbers on the exploded view below refer to the mechanical section of the Replacement Parts List.



REPLACEMENT PARTS LIST

Important Safety Notice

Components Identified by  mark have special characteristics important for safety.
 * When replacing any of these components, use only manufacturers specified parts.
 In case of ordering these spare parts, please always add the complete Model-Type number to your order.

Cct Ref	Parts Number	Description
MECHANICAL PARTS		
1	EAGG1218J2	SPEAKER
2	ENG27506G	TUNER
3	EUR511210	REMOTE CONTROL
4	TBM8E1728	PANASONIC BADGE
5	TBX8E049	POWER BUTTON
6	THT1062	CRT FIXING SCREW
7	TKK8E026	SPEAKER REFLECTOR
8	TKP8E1141	DOOR LID
9	TKP8E1142	PANEL RIGHT
10	TKP8E1143	PANEL LEFT
11	TKP8E1152	SPEAKER NET
12	TKP8E1254	AV PANEL
13	TKU8E00300	BACK COVER
14	TKY8E120	CABINET
15	TMW8E024-3	CONTROL BRACKET
16	TMX8E031	CHASSIS FRAME
17	TNP8EE009BS	E P.C.B.
18	TNP8EH002AB	H P.C.B.
19	TNP8EM013AB	M P.C.B.
20	TNP8EY012AG	Y P.C.B.
21	TQF8E2692	MODEL LABEL
22	TSX8E0025	POWER CORD
23	TXFLK01DAG	DEGAUSS COIL
24	UR51EC904A	BATTERY COVER (REMOTE)
25	W66EHK51X35	C.R.T.
MISCELLANEOUS COMPONENTS		
	31221212478	FIX CLIP
	832AG11D-ESL	I.C. SOCKET
F9-4-220		RELAY
PCS-084A-1		84 PIN SOCKET
TBM8E1532-2		PRESET PANEL
TBM8E1886		REAR AV LABEL
TEK6940		LID CATCH
TMW8E017		LED HOLDER
TPC8E4676		OUTER CARTON
TPD8E623		TOP CUSHION
TPD8E624		BOTTOM CUSHION
TZS9EV277		TOP BOARD
TZS9EV278		VIDEO SHELF
TZS9EV279		BASE PANEL
TZS9EV280		GLASS DOOR
TZS9EV281		INNER SIDE PANEL
TZS9EV282		CORNER PANEL
TZS9EV283		OUTER SIDE PANEL
TZS9EV284		ALLEN KEY
TZS9EV285		CHIPBOARD SCREEN
TZS9EV286		CASTOR
TZS9EV287		DOWEL
TZS9EV288		HINGE BUSH
TZS9EV289		LATCH SCREW
TZS9EV290		MAGNETIC LATCH

Cct Ref	Parts Number	Description
INSTRUCTION BOOKS		
	TQB8E2583	ENGLISH
I.C.s		
IC251	LA4282	AUDIO OUTPUT
IC351	TDA6103Q-N3	R.G.B. OUTPUT
IC451	LA7845N	VERTICAL OUTPUT
IC601	VDP3120BPPB1	VIDEO PROCESSOR
IC701	TEA2031A	E/W CORRECTION
IC801	STRF6654LF51	POWER SUPPLY
IC850	SE140N	ERROR AMPLIFER
IC851	L78M12MRB	12V REGULATOR
IC853	AN78L08TA	8V REGULATOR
IC1061	RPM-637CBRS1	LED RECEIVER
IC1101	SDA5450C48	MICRO PROCESSOR
IC1102	27C2001-F18	EPROM *
IC1103	XGL2-01LA	EAROM *
IC1104	MN1381-R(TA)	RESET
IC1105	MN1381-T(TA)	RESET
IC2101	MSP3410DPOB4	AUDIO PROCESSOR
IC3401	TEA2114	VIDEO SWITCHING
DIODES		
D251	MA2180TP	DIODE
D253	MA700TA5	DIODE
D254	MA700TA5	DIODE
D354	1SR124-4AT82	DIODE
D355	1SR124-4AT82	DIODE
D356	1SR124-4AT82	DIODE
D357	MA165TA5	DIODE
D358	MA165TA5	DIODE
D359	MA165TA5	DIODE
D360	MTZJT-7715A	DIODE
D361	MA165TA5	DIODE
D362	MA165TA5	DIODE
D363	MA165TA5	DIODE
D364	MA165TA5	DIODE
D453	MA165TA5	DIODE
D454	ERA15-02V3	DIODE
D456	MTZJT-775.6C	DIODE
D457	MA165TA5	DIODE
D501	MA165TA5	DIODE
D502	1SR124-4AT82	DIODE
D511	MA4047	DIODE

Cct Ref	Parts Number	Description
D551	ERD07-15L7	DIODE
D552	RU3LFA1	DIODE
D553	1SR124-4AT82	DIODE
D554	1SR124-4AT82	DIODE
D556	MA165TA5	DIODE
D557	EU02	DIODE
D558	1SR124-4AT82	DIODE
D601	DAN217T146	DIODE
D603	DAN217T146	DIODE
D605	DAN212KT146	DIODE
D606	MA165TA5	DIODE
D607	MA4051	DIODE
D609	1SR124-4AT82	DIODE
D615	STZ6.2NT146	DIODE
D616	STZ6.2NT146	DIODE
D701	MA165TA5	DIODE
D702	MTZJT-775.6C	DIODE
D704	MA29TA5	DIODE
D705	MTZJT-775.6B	DIODE
D801	RBV-608LF-B	DIODE
D803	1SR124-4AT82	DIODE
D804	1SR124-4AT82	DIODE
D805	TLP621GR-LF2	PHOTO COUPLER
D806	1SR124-4AT82	DIODE
D850	RU4BLF-L1	DIODE
D851	MTZJT776.2B	DIODE
D852	MA165TA5	DIODE
D853	MA2180BLFS	DIODE
D854	TVSRU2AMLFA5	DIODE
D855	FML22SLF610	DIODE
D856	RU4AMLF-M1	DIODE
D857	MTZJT-775.1C	DIODE
D858	MA165TA5	DIODE
D859	MA165TA5	DIODE
D861	MA165TA5	DIODE
D862	MTZJT-7736A	DIODE
D863	MA165TA5	DIODE
D865	MA165TA5	DIODE
D866	MA165TA5	DIODE
D867	EK06-V0	DIODE
D868	1N4150T-77	DIODE
D869	1N4150T-77	DIODE
D870	MA165TA5	DIODE
D871	1N4150T-77	DIODE
D873	MTZJT-775.6C	DIODE
D874	1SR124-4AT82	DIODE
D875	BZX79A75A26A	DIODE
D901	MA165TA5	DIODE
D902	MA165TA5	DIODE
D904	MA165TA5	DIODE
D905	MA165TA5	DIODE
D906	RLS72TE-11	DIODE
D1061	LN81RPHL	DIODE
D1101	MA165TA5	DIODE
D1102	MA165TA5	DIODE
D2101	MA723TA5	DIODE
D2102	MA723TA5	DIODE
D2103	MA723TA5	DIODE
D2104	MA723TA5	DIODE
D2105	MTZJT-778.2C	DIODE
D3201	MTZJT-778.2C	DIODE
D3202	MTZJT-778.2C	DIODE
TRANSISTORS		
Q101	BC847B	TRANSISTOR
Q102	BC847B	TRANSISTOR
Q104	BC847B	TRANSISTOR

Cct Ref	Parts Number	Description
Q105	BC847B	TRANSISTOR
Q251	2SD1328STX	TRANSISTOR
Q252	2SD1328STX	TRANSISTOR
Q253	BC847B	TRANSISTOR
Q254	BC847B	TRANSISTOR
Q301	BC847B	TRANSISTOR
Q302	FMY4T148	TRANSISTOR
Q303	BC847B	TRANSISTOR
Q304	FMY4T148	TRANSISTOR
Q305	BC847B	TRANSISTOR
Q306	FMY4T148	TRANSISTOR
Q351	2SA1767	TRANSISTOR
Q352	2SA1767	TRANSISTOR
Q353	2SA1767	TRANSISTOR
Q354	BC857B	TRANSISTOR
Q451	BC857B	TRANSISTOR
Q503	2SD2398-M2	TRANSISTOR
Q551	BU2508AXLB	TRANSISTOR
Q552	2SC1473-RN	TRANSISTOR
Q701	BC857B	TRANSISTOR
Q850	2SD1273PLB	TRANSISTOR
Q851	BC857B	TRANSISTOR
Q852	2SC1383-S	TRANSISTOR
Q853	BC847B	TRANSISTOR
Q854	BC847B	TRANSISTOR
Q855	BC847B	TRANSISTOR
Q856	BC847B	TRANSISTOR
Q857	2SA1018QTA	TRANSISTOR
Q905	BC847B	TRANSISTOR
Q906	BC847B	TRANSISTOR
Q907	BC857B	TRANSISTOR
Q908	2SA1535ARLB	TRANSISTOR
Q909	2SC3944ARLB	TRANSISTOR
Q950	BC847B	TRANSISTOR
Q951	FMY4T148	TRANSISTOR
Q1051	BC847B	TRANSISTOR
Q1062	BC847B	TRANSISTOR
Q1101	BC847B	TRANSISTOR
Q1104	BC847B	TRANSISTOR
Q1105	BC847B	TRANSISTOR
Q1106	BC847B	TRANSISTOR
Q1107	BC847B	TRANSISTOR
Q1108	BC847B	TRANSISTOR
Q2101	BC857B	TRANSISTOR
Q2102	BC857B	TRANSISTOR
Q2103	BC857B	TRANSISTOR
Q2302	BC857B	TRANSISTOR
Q2304	BC857B	TRANSISTOR
Q3001	BC847B	TRANSISTOR
Q3006	BC847B	TRANSISTOR
Q3007	BC847B	TRANSISTOR
Q3201	BC847B	TRANSISTOR
Q3202	BC847B	TRANSISTOR
Q3203	BC857B	TRANSISTOR
Q3204	BC857B	TRANSISTOR
Q3205	BC847B	TRANSISTOR
Q3206	BC847B	TRANSISTOR
Q3207	BC847B	TRANSISTOR
Q3208	BC847B	TRANSISTOR
Q3209	BC847B	TRANSISTOR
Q3401	BC847B	TRANSISTOR
Q3402	BC847B	TRANSISTOR
Q3601	BC847B	TRANSISTOR
TRANSFORMERS		
T501	ETH19Y173AY	TRANSFORMER
T551	ZTFM05002A	F.B.T.

Cct Ref	Parts Number	Description	
T801	ETS42AE226AD	TRANSFORMER	▲
T802	ETP35KAN619U	TRANSFORMER	▲
COILS			
J164	TLT331K991R	COIL	
L104	EXCELSA35T	COIL	
L106	TLTACT100K	COIL	
L107	TLTACT6R8K	COIL	
L301	TLTACT4R7K	COIL	
L302	TLTACT4R7K	COIL	
L451	EXCELSA35T	COIL	
L501	EXCELSA35T	COIL	
L552	ELH5L6110	COIL	
L553	ELC08D682E	COIL	
L554	ELC18B102L	COIL	
L601	TLTACT4R7K	COIL	
L602	TLTACT4R7K	COIL	
L603	TLTACT4R7K	COIL	
L604	TLTACT4R7K	COIL	
L606	TLTACT4R7K	COIL	
L607	ELJFC2R2KF	COIL	
L701	ELC10D822E	COIL	
L850	EXCELSA35T	COIL	
L851	EXCELSA35T	COIL	
L852	ELEIN470KA	COIL	
L853	EXCELSA35T	COIL	
L854	EXCELSA35T	COIL	
L855	EXCELSA35T	COIL	
L856	EXCELSA39V	COIL	
L901	EXCELSA24T	COIL	
L902	EXCELSA24T	COIL	
L1061	TLT331K991R	COIL	
L1103	TLTACT100K	COIL	
L1104	EXCELSA35T	COIL	
L1105	ELJFC2R2KF	COIL	
L2101	TLTACT100K	COIL	
L2103	EXCELSA35T	COIL	
L2104	TLTACT4R7K	COIL	
L3001	ELEMV1R5MA	COIL	
L3002	ELEMV1R5MA	COIL	
L3003	ELEMV1R5MA	COIL	
L3004	ELEMV1R5MA	COIL	
L3005	ELEBR2R2KA	COIL	
L3006	ELEBR2R2KA	COIL	
L3007	TLTACT2R2K	COIL	
L3201	ELEBR6R8KA	COIL	
L3202	ELEBR6R8KA	COIL	
L3203	TLT390K991R	COIL	
L3401	ELESN2R2KA	COIL	
L3402	ELESN2R2KA	COIL	
FILTERS			
L804	ELF18N010A	LINE FILTER	
CRYSTALS			
X601	4730007267	CRYSTAL	
X1101	TSSA121	CRYSTAL	
X2101	4730007158	CRYSTAL	
RESISTORS			
	ERC12GK825	SOLID	0.5W 10% 8M2 □
C101	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA44	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA45	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA46	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA47	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA48	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA49	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA50	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA51	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA52	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA53	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA54	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA55	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA56	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA57	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA58	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA59	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA60	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA61	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA62	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA63	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA64	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA65	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA66	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA67	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA68	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA69	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA70	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA71	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA72	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA73	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA74	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA75	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA76	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA77	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA78	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA79	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA80	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA81	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA82	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA83	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA84	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA85	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA86	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA87	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA88	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA89	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA90	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA91	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA92	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA93	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA94	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA95	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA96	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA97	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA98	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA99	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA100	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA101	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA102	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA103	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA104	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA105	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA106	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA107	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA108	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA109	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA110	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA111	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA112	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA113	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA114	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA115	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □

Cct Ref	Parts Number	Description	
JA15	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA26	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA22	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA40	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA39	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA38	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA37	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA16	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA12	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA25	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA58	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA3	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA27	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA2	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JSE10	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JSM7	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JSE4	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JSE35	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JSE33	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JSE3	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JSE26	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JSE22	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA11	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JSE12	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA52	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA9	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA60	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA10	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA49	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA57	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA28	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA55	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA54	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JSE18	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
JA1	ERJ8GEY0R00	S.M.CARB	.125W 5% 0 □
JA2	ERJ8GEY0R00	S.M.CARB	.125W 5% 0 □
JA21	ERJ8GEY0R00	S.M.CARB	.125W 5% 0 □
JA29	ERJ8GEY0R00	S.M.CARB	.125W 5% 0 □
JA30	ERJ8GEY0R00	S.M.CARB	.125W 5% 0 □
JA31	ERJ8GEY0R00	S.M.CARB	.125W 5% 0 □
JA32	ERJ8GEY0R00	S.M.CARB	.125W 5% 0 □
JA33	ERJ8GEY0R00	S.M.CARB	.125W 5% 0 □
JA34	ERJ8GEY0R00	S.M.CARB	.125W 5% 0 □
JA35	ERJ8GEY0R00	S.M.CARB	.125W 5% 0 □
JA43	ERJ8GEY0R00	S.M.CARB	.125W 5% 0 □
JA46	ERJ8GEY0R00	S.M.CARB	.125W 5% 0 □
JA50	ERJ8GEY0R00	S.M.CARB	.125W 5% 0 □
JA51	ERJ8GEY0R00	S.M.CARB	.125W 5% 0 □
JA56	ERJ8GEY0R00	S.M.CARB	.125W 5% 0 □
JA59	ERJ8GEY0R00	S.M.CARB	.125W 5% 0 □
JA68	ERJ8GEY0R00	S.M.CARB	.125W 5% 0 □
JA5	ERJ8GEY0R00	S.M.CARB	.125W 5% 0 □
JA23	ERJ8GEY0R00	S.M.CARB	.125W 5% 0 □
J116	ERDS1TJ220	CARBON	0.5W 5% 22 □
R101	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
R102	ERJ6GEYJ103	S.M.CARB	0.1W 5% 10K □
R103	ERJ6GEYJ222	S.M.CARB	0.1W 5% 2K2 □
R104	ERJ6GEYJ332	S.M.CARB	0.1W 5% 3K3 □
R105	ERJ6GEYJ101	S.M.CARB	0.1W 5% 100 □
R106	ERJ6GEYJ681	S.M.CARB	0.1W 5% 680 □
R107	ERJ6GEYJ102	S.M.CARB	0.1W 5% 1K □
R111	ERJ6GEY0R00	S.M.CARB	0.1W 5% 0 □
R112	ERJ6GEYJ101	S.M.CARB	0.1W 5% 100 □
R113	ERJ6GEYJ223	S.M.CARB	0.1W 5% 22K □
R114	ERJ6GEYJ331	S.M.CARB	0.1W 5% 330 □
R115	ERJ6GEYJ331	S.M.CARB	0.1W 5% 330 □

Cct Ref	Parts Number	Description					
R116	ERJ6GEYJ562	S.M.CARB	0.1W	5%	5K6 		
R117	ERJ6GEYJ222	S.M.CARB	0.1W	5%	2K2 		
R118	ERJ6GEYJ102	S.M.CARB	0.1W	5%	1K 		
R121	ERJ6GEYJ471	S.M.CARB	0.1W	5%	470 		
R251	ERJ6GEYJ101	S.M.CARB	0.1W	5%	100 		
R252	ERJ6GEYJ272	S.M.CARB	0.1W	5%	2K7 		
R253	ERJ6GEYJ103	S.M.CARB	0.1W	5%	10K 		
R254	ERJ6GEYJ101	S.M.CARB	0.1W	5%	100 		
R255	ERJ6GEYJ103	S.M.CARB	0.1W	5%	10K 		
R256	ERJ6GEYJ471	S.M.CARB	0.1W	5%	470 		
R257	ERJ6GEYJ100	S.M.CARB	0.1W	5%	10 		
R258	ERJ6GEYJ272	S.M.CARB	0.1W	5%	2K7 		
R259	ERJ6GEYJ100	S.M.CARB	0.1W	5%	10 		
R260	ERJ6GEYJ103	S.M.CARB	0.1W	5%	10K 		
R261	ERJ6GEYJ471	S.M.CARB	0.1W	5%	470 		
R262	ERJ6GEYJ103	S.M.CARB	0.1W	5%	10K 		
R263	ERJ6GEYJ473	S.M.CARB	0.1W	5%	47K 		
R264	ERJ6GEYJ103	S.M.CARB	0.1W	5%	10K 		
R265	ERD25TJ2R2	CARBON	0.25W	5%	2R2 		
R266	ERD25TJ2R2	CARBON	0.25W	5%	2R2 		
R267	ERF7ZK4R7	WOUND	7W	10%	4R7 		
R268	ERJ6GEYJ103	S.M.CARB	0.1W	5%	10K 		
R269	ERQ14AJ101	METAL	0.25W	5%	100 		
R271	ERJ6GEYJ103	S.M.CARB	0.1W	5%	10K 		
R272	ERF7ZK4R7	WOUND	7W	10%	4R7 		
R301	ERJ6GEYJ391	S.M.CARB	0.1W	5%	390 		
R302	ERJ6GEYJ102	S.M.CARB	0.1W	5%	1K 		
R303	ERJ6GEYJ750	S.M.CARB	0.1W	5%	75 		
R304	ERJ6GEYJ331	S.M.CARB	0.1W	5%	330 		
R305	ERJ6GEYJ391	S.M.CARB	0.1W	5%	390 		
R306	ERJ6GEYJ102	S.M.CARB	0.1W	5%	1K 		
R307	ERJ6GEYJ750	S.M.CARB	0.1W	5%	75 		
R308	ERJ6GEYJ331	S.M.CARB	0.1W	5%	330 		
R309	ERJ6GEYJ391	S.M.CARB	0.1W	5%	390 		
R310	ERJ6GEYJ102	S.M.CARB	0.1W	5%	1K 		
R311	ERJ6GEYJ750	S.M.CARB	0.1W	5%	75 		
R312	ERJ6GEYJ331	S.M.CARB	0.1W	5%	330 		
R351	ERJ6GEYJ302	S.M.CARB	0.1W	5%	3K 		
R352	ERJ6GEYJ302	S.M.CARB	0.1W	5%	3K 		
R353	ERJ6GEYJ302	S.M.CARB	0.1W	5%	3K 		
R354	ERJ6GEYJ102	S.M.CARB	0.1W	5%	1K 		
R355	ERJ6GEYJ102	S.M.CARB	0.1W	5%	1K 		
R356	ERJ6GEYJ102	S.M.CARB	0.1W	5%	1K 		
R357	ERDS1TJ114	CARBON	0.5W	5%	110K 		
R358	ERDS1TJ114	CARBON	0.5W	5%	110K 		
R359	ERDS1TJ114	CARBON	0.5W	5%	110K 		
R363	ERD25TJ103	CARBON	0.25W	5%	10K 		
R364	ERD25TJ103	CARBON	0.25W	5%	10K		
R365	ERD25TJ103	CARBON	0.25W	5%	10K		
R366	ERDS1TJ152	CARBON	0.5W	5%	1K5		
R367	ERDS1TJ152	CARBON	0.5W	5%	1K5		
R368	ERDS1TJ152	CARBON	0.5W	5%	1K5		
R369	ERD25TJ472	CARBON	0.25W	5%	4K7		
R370	ERJ6GEYJ102	S.M.CARB	0.1W	5%	1K		
R372	ERQ12AJ121	FUSIBLE	0.5W	5%	120		
R373	ERJ6GEYJ220	S.M.CARB	0.1W	5%	22		
R374	ERD25TJ274	CARBON	0.25W	5%	270K		
R375	ERJ6GEYJ684	S.M.CARB	0.1W	5%	680K		
R376	ERJ6GEYJ183	S.M.CARB	0.1W	5%	18K		
R377	ERQ12HKR22	FUSIBLE	0.5W	5%	R22		
R378	ERJ6GEY0R00	S.M.CARB	0.1W	5%	0		
R379	ERJ6GEY0R00	S.M.CARB	0.1W	5%	0		
R380	ERJ6GEY0R00	S.M.CARB	0.1W	5%	0		
R381	ERJ6GEYJ473	S.M.CARB	0.1W	5%	47K		
R451	ERJ6GEYJ223	S.M.CARB	0.1W	5%	22K		
R452	ERJ6GEY0R00	S.M.CARB	0.1W	5%	0		

Cct Ref	Parts Number	Description					
R453	ERJ6GEY0R00	S.M.CARB	0.1W	5%	0 		
R454	ERJ6GEYJ752	S.M.CARB	0.1W	5%	7K5 		
R455	ERJ6GEYJ222	S.M.CARB	0.1W	5%	2K2 		
R456	ERJ6GEYJ104	S.M.CARB	0.1W	5%	100K 		
R457	ERJ6GEYJ223	S.M.CARB	0.1W	5%	22K 		
R458	ERD25TJ1R5	CARBON	0.25W	5%	1R5 		
R459	ERJ6GEYJ101	S.M.CARB	0.1W	5%	100 		
R460	ERDS1TJ31	CARBON	0.5W	5%	330 		
R461	ERW2PK1R2	WOUND	2W	10%	1R2 		
R463	ERD25TJ222	CARBON	0.25W	5%	2K2 		
R464	ERJ6GEYJ182	S.M.CARB	0.1W	5%	1K8 		
R465	ERJ6GEYJ681	S.M.CARB	0.1W	5%	680 		
R502	ERJ6GEYJ511	S.M.CARB	0.1W	5%	510 		
R506	ERD25TJ560	CARBON	0.25W	5%	56 		
R507	ERG1FJ101P	METAL	1W	5%	100 		
R509	ERDS1TJ152	CARBON	0.5W	5%	1K5 		
R510	ERDS1FJ152	CARBON	0.5W	5%	1K5 		
R553	ERG1SJ152	METAL	1W	5%	1K5 		
R554	ERG1SJ101	METAL	1W	5%	100 		
R555	ERQ12HKR33	METAL	0.5W	5%	R33 		
R558	ERDS1TJ124	CARBON	0.5W	5%	120K 		
R559	ERQ12HKR33	METAL	0.5W	5%	R33 		
R560	ERJ6GEYJ274	S.M.CARB	0.1W	5%	270K 		
R561	ERJ6GEYJ273	S.M.CARB	0.1W	5%	27K 		
R563	ERJ6GEYJ684	S.M.CARB	0.1W	5%	680K 		
R564	ERJ6GEYJ623	S.M.CARB	0.1W	5%	62K 		
R566	ERJ6GEYJ563	S.M.CARB	0.1W	5%	56K 		
R567	ERF7ZK1R0	WOUND	7W	10%	1 		
R601	ERJ6GEYJ101	S.M.CARB	0.1W	5%	100 		
R602	ERJ6GEYJ821	S.M.CARB	0.1W	5%	820 		
R603	ERJ8GEYJ103	S.M.CARB	.125W	5%	10K 		
R604	ERJ6GEYJ101	S.M.CARB	0.1W	5%	100 		
R605	ERD25TJ331	CARBON	0.25W	5%	330 		
R606	ERD25TJ331	CARBON	0.25W	5%	330 		
R607	ERJ6GEYJ821	S.M.CARB	0.1W	5%	820 		
R608	ERJ6GEYJ271	S.M.CARB	0.1W	5%	270 		
R609	ERJ6GEYJ122	S.M.CARB	0.1W	5%	1K2 		
R610	ERJ6GEY0R00	S.M.CARB	0.1W	5%	0 		
R611	ERJ6GEYJ103	S.M.CARB	0.1W	5%	10K 		
R612	ERJ6GEYJ101	S.M.CARB	0.1W	5%	100 		
R613	ERJ6GEYJ152	S.M.CARB	0.1W	5%	1K5 		
R622	ERJ6GEY0R00	S.M.CARB	0.1W	5%	0 		
R636	ERJ6GEYJ750	S.M.CARB	0.1W	5%	75 		
R645	ERJ6GEYJ103	S.M.CARB	0.1W	5%	10K 		
R647	ERJ6GEYJ472	S.M.CARB	0.1W	5%	4K7 		
R648	ERJ6GEYJ152	S.M.CARB	0.1W	5%	1K5 		
R650	ERJ6GEYJ750	S.M.CARB	0.1W	5%	75 		
R651	ERJ6GEYJ750	S.M.CARB	0.1W	5%	75		
R652	ERJ6GEYJ102	S.M.CARB	0.1W	5%	1K		
R654	ERJ6GEYJ622	S.M.CARB	0.1W	5%	6K2		
R655	ERJ6GEYJ103	S.M.CARB	0.1W	5%	10K 		
R2107	ERJ6GEYJ101	S.M.CARB	0.1W	5%	100 		
R2108	ERJ6GEYJ101	S.M.CARB	0.1W	5%	100 		
R2109	ERJ6GEYJ183	S.M.CARB	0.1W	5%	18K 		
R2110	ERJ6GEY0R00	S.M.CARB	0.1W	5%	0 		
R2111	ERJ6GEYJ221	S.M.CARB	0.1W	5%	220 		
R2112	ERJ6GEYJ102	S.M.CARB	0.1W	5%	1K 		
R2113	ERJ6GEYJ562	S.M.CARB	0.1W	5%	5K6 		
R2114	ERJ6GEYJ101	S.M.CARB	0.1W	5%	100 		
R2115	ERJ6GEYJ222	S.M.CARB	0.1W	5%	2K2 		
R2116	ERJ6GEYJ101	S.M.CARB	0.1W	5%	100 		
R2117	ERJ6GEYJ101	S.M.CARB	0.1W	5%	100 		
R2118	ERJ6GEYJ222	S.M.CARB	0.1W	5%	2K2 		
R2119	ERJ6GEYJ101	S.M.CARB	0.1W	5%	100 		
R2120	ERJ6GEYJ222	S.M.CARB	0.1W	5%	2K2 		
R2305	ERJ6GEYJ102	S.M.CARB	0.1W	5%	1K 		
R2311	ERJ6GEYJ102	S.M.CARB	0.1W	5%	1K 		
R3001	ERJ6GEYJ101	S.M.CARB	0.1W	5%	100 		
R3002	ERJ6GEYJ471	S.M.CARB	0.1W	5%	470 		
R3003	ERJ6GEYJ101	S.M.CARB	0.1W	5%	100 		
R3004	ERJ6GEYJ153	S.M.CARB	0.1W	5%	15K 		
R3005	ERJ6GEYJ101	S.M.CARB	0.1W	5%	100 		
R3006	ERJ6GEYJ471	S.M.CARB	0.1W	5%	470 		
R3007	ERJ6GEYJ101	S.M.CARB	0.1W	5%	100 		
R3008	ERJ6GEYJ153	S.M.CARB	0.1W	5%	15K 		
R3009	ERJ6GEYJ750	S.M.CARB	0.1W	5%	75 		
R3010	ERJ6GEYJ750	S.M.CARB	0.1W	5%	75 		
R3011	ERJ6GEYJ750	S.M.CARB	0.1W	5%	75 		
R3012	ERJ6GEYJ750	S.M.CARB	0.1W	5%	75 		
R3013	ERJ6GEYJ101	S.M.CARB	0.1W	5%	100 		
R3014	ERJ6GEYJ471	S.M.CARB	0.1W	5%	470 		
R3015	ERJ6GEYJ101	S.M.CARB	0.1W	5%	100 		
R3016	ERJ6GEYJ153	S.M.CARB	0.1W	5%	15K 		
R3017	ERJ6GEYJ101	S.M.CARB	0.1W	5%	100 		
R3018	ERJ6GEYJ471	S.M.CARB	0.1W	5%	470 		
R3019	ERJ6GEYJ101	S.M.CARB	0.1W	5%	100 		
R3020	ERJ6GEYJ153	S.M.CARB	0.1W	5%	15K 		
R3021	ERJ6GEYJ750	S.M.CARB	0.1W	5%	75 		
R3022	ERJ6GEYJ102	S.M.CARB	0.1W	5%	1K 		
R3023	ERJ6GEYJ123	S.M.CARB	0.1W	5%	12K 		
R3024	ERJ6GEYJ472	S.M.CARB	0.1W	5%	4K7 		
R3025	ERJ6GEYJ750	S.M.CARB	0.1W	5%	75 		
R3026	ERJ6GEYJ750	S.M.CARB	0.1W	5%	75 		
R3044	ERJ6GEYJ750	S.M.CARB	0.1W	5%	75 		
R3046	ERJ6GEYJ101	S.M.CARB	0.1W	5%	100 		
R3047	ERJ6GEYJ101	S.M.CARB	0.1W	5%	100 		
R3048	ERJ6GEYJ103	S.M.CARB	0.1W	5%	10K 		
R3049	ERJ6GEYJ101	S.M.CARB	0.1W	5%	100		
R3050	ERJ6GEYJ103	S.M.CARB	0.1W	5%	10K		
R3057	ERJ6GEYJ750	S.M.CARB	0.1W	5%	75		
R3202	ERDS1TJ151	CARBON	0.5W	5%	150		
R3203	ERDS1TJ151	CARBON	0.5W	5%	150		
R3204	ERG2FJ221	METAL	2W	5%	220		
R3205	ERG2FJ221	METAL	2W	5%	220		
R3207	ERJ6GEYJ101	S.M.CARB	0.1W	5%	100		
R3208	ERJ6GEYJ153	S.M.CARB	0.1W	5%	15K		
R3209	ERJ6GEYJ101	S.M.CARB	0.1W	5%	100		
R3210	ERJ6GEYJ153	S.M.CARB	0.1W	5%	15K		
R3211	ERJ6GEYJ223	S.M.CARB	0.1W	5%	22K		
R3212	ERJ6GEYJ223	S.M.CARB	0.1W	5%	22K		
R3213	ERJ6GEYJ102	S.M.CARB	0.1W	5%	1K		
R3214	ERJ6GEYJ683	S.M.CARB	0.1W	5%	68K		
R3215	ERJ6GEYJ302	S.M.CARB	0.1W	5%	3K		
R3216	ERJ6GEYJ750	S.M.CARB	0.1W	5%	75		
R3217	ERJ6GEYJ223	S.M.CARB	0.1W	5%	22K		
R3218	ERJ6GEYJ223	S.M.CARB	0.1W	5%	22K		

Cct Ref	Parts Number	Description				
R3219	ERJ6GEYJ102	S.M.CARB	0.1W	5%	1K 	
R3220	ERJ6GEYJ683	S.M.CARB	0.1W	5%	68K 	
R3221	ERJ6GEYJ302	S.M.CARB	0.1W	5%	3K 	
R3222	ERJ6GEYJ223	S.M.CARB	0.1W	5%	22K 	
R3223	ERJ6GEYJ223	S.M.CARB	0.1W	5%	22K 	
R3224	ERJ6GEYJ102	S.M.CARB	0.1W	5%	1K 	
R3225	ERJ6GEYJ683	S.M.CARB	0.1W	5%	68K 	
R3226	ERJ6GEYJ302	S.M.CARB	0.1W	5%	3K 	
R3227	ERJ6GEYJ102	S.M.CARB	0.1W	5%	1K 	
R3228	ERJ6GEYJ273	S.M.CARB	0.1W	5%	27K 	
R3229	ERJ6GEYJ103	S.M.CARB	0.1W	5%	10K 	
R3230	ERJ6GEYJ302	S.M.CARB	0.1W	5%	3K 	
R3231	ERJ6GEYJ122	S.M.CARB	0.1W	5%	1K2 	
R3232	ERJ6GEYJ242	S.M.CARB	0.1W	5%	2K4 	
R3233	ERJ6GEYJ391	S.M.CARB	0.1W	5%	390 	
R3234	ERJ6GEYJ102	S.M.CARB	0.1W	5%	1K 	
R3402	ERJ6GEYJ750	S.M.CARB	0.1W	5%	75 	
R3403	ERJ6GEYJ101	S.M.CARB	0.1W	5%	100 	
R3404	ERJ6GEYJ242	S.M.CARB	0.1W	5%	2K4 	
R3405	ERJ6GEYJ104	S.M.CARB	0.1W	5%	100K 	
R3406	ERJ6GEYJ301	S.M.CARB	0.1W	5%	300 	
R3407	ERJ6GEYJ123	S.M.CARB	0.1W	5%	12K 	
R3408	ERJ6GEYJ472	S.M.CARB	0.1W	5%	4K7 	
R3409	ERJ6GEYJ750	S.M.CARB	0.1W	5%	75 	
R3601	ERJ6GEYJ101	S.M.CARB	0.1W	5%	100 	
R3602	ERJ6GEYJ101	S.M.CARB	0.1W	5%	100 	
R3603	ERJ6GEYJ101	S.M.CARB	0.1W	5%	100 	
R3604	ERJ6GEYJ101	S.M.CARB	0.1W	5%	100 	
R3605	ERJ6GEYJ101	S.M.CARB	0.1W	5%	100 	
R3606	ERJ6GEYJ101	S.M.CARB	0.1W	5%	100 	
R3607	ERJ6GEYJ472	S.M.CARB	0.1W	5%	4K7 	
R3608	ERJ6GEYJ752	S.M.CARB	0.1W	5%	7K5 	
R3609	ERJ6GEY0R00	S.M.CARB	0.1W	5%	0 	
R3610	ERJ6GEYJ102	S.M.CARB	0.1W	5%	1K 	
R3613	ERJ6GEYJ391	S.M.CARB	0.1W	5%	390 	
R3614	ERJ6GEYJ391	S.M.CARB	0.1W	5%	390 	
CAPACITORS						
C102	ECUV1H103ZFX	S.M.CAP	50V		10nF	
C103	ECJ2VF1H104Z	ELECT	350V		100nF	
C106	ECUV1H560JCX	S.M.CAP	50V		56pF	
C107	ECJ2VF1H104Z	ELECT	350V		100nF	
C108	ECA1CM100GB	ELECT	16V		10µF	
C109	ECUV1H102JCX	S.M.CAP	50V		1nF	
C110	ECUV1H103ZFX	S.M.CAP	50V		10nF	
C111	ECA1HMR33GB	ELECT	50V		10nF	
C117	ECUV1H103ZFX	S.M.CAP	50V		10nF	
C118	ECJ2VF1H104Z	ELECT	350V		100nF	
C119	ECA1CM221GB	ELECT	16V		220µF	
C120	ECA1CM221GB	ELECT	16V		220µF	
C121	ECUV1H561KBX	S.M.CAP	50V		560pF	
C124	ECUV1H220JCX	S.M.CAP	50V		22pF	
C125	ECUV1H100DCX	S.M.CAP	50V		10pF	
C251	ECA1HM220GB	ELECT	50V		22µF	
C252	ECUV1H223KBX	S.M.CAP	50V		22nF	
C253	ECA1HM4R7GB	ELECT	50V		4.7µF	
C254	ECQM1H184J	FILM	50V		4.7µF	
C255	ECA1EM101GB	ELECT	25V		100µF	
C256	ECUV1H223KBX	S.M.CAP	50V		22nF	
C257	ECA1HM4R7GB	ELECT	50V		4.7µF	
C258	ECA1HM220GB	ELECT	50V		22µF	
C259	ECQM1H184J	FILM	50V		22µF	

Cct Ref	Parts Number	Description		
C265	ECQM1H184J	FILM	50V	1nF
C266	ECA1HMR22GB	ELECT	50V	1nF
C267	ECJ2VB1H104K	ELECT	350V	100nF
C268	ECJ2VB1H104K	ELECT	350V	100nF
C270	ECJ2VB1H104K	ELECT	350V	100nF
C301	ECJ2VB1C104K	ELECT	350V	100nF
C302	ECJ2VB1C104K	ELECT	350V	100nF
C303	ECJ2VB1C104K	ELECT	350V	100nF
C304	ECA1CM100GB	ELECT	16V	10µF
C351	ECUV1H090DCN	S.M. CAP	50V	90pF
C352	ECUV1H090DCN	S.M. CAP	50V	90pF
C353	ECUV1H090DCN	S.M. CAP	50V	90pF
C354	ECQM2104KZ	FILM	250V	100nF
C355	ECUV1H471JCX	S.M. CAP	50V	470pF
C356	ECUV1H471JCX	S.M. CAP	50V	470pF
C357	ECUV1H471JCX	S.M. CAP	50V	470pF
C358	ECQM1H224J	FILM	50V	220nF
C360	ECKC3D152J	CERAMIC	2KV	1.5nF
C361	ECA1HMR47GB	ELECT	50V	1.5nF
C363	ECA1VM471GB	ELECT	35V	470µF
C364	ECJ2VF1H103Z	ELECT	350V	10nF
C366	ECA1CM100GB	ELECT	16V	10µF
C451	ECUV1H102JX	S.M. CAP	50V	1nF
C453	ECUV1H152KBX	S.M. CAP	50V	1.5pF
C454	ECUV1H223KBM	S.M. CAP	50V	22nF
C455	ECA1HM100GB	ELECT	50V	10µF
C456	ECA1HHG221B	ELECT	50V	220µF
C458	ECQB1222JF3	FILM	100V	2.2nF
C459	222236516154	FILM	160V	150nF
C461	ECCR2H270J	CERAMIC	500V	27pF
C508	ECQV1H105JZ	FILM	50V	1µF
C509	ECA1VM470B	ELECT	35V	47µF
C510	ECUV1H104KBX	S.M. CAP	50V	100nF
C511	ECQM2683JZ	FILM	250V	68nF
C551	ECKC3D152J	CERAMIC	2KV	1.5nF
C552	ECWH15H102JN	FILM	1500V	1nF
C554	ECWF2H514J	FILM	500V	510nF
C555	ECWH15H123JN	CAPACITO	1500V	12nF
C556	ECQF4273ZH	FILM	400V	27nF
C557	ECKC2H471J	CERAMIC	500V	470pF
C558	ECA1HHG471E	ELECT	50V	470µF
C559	ECWF2824JBB	FILM	200V	820nF
C560	ECA2VM010B	ELECT	63V	1µF
C561	ECA1EHG102B	ELECT	25V	1µF
C562	ECKC2H101J	CERAMIC	500V	100pF
C563	ECA2EHG220B	ELECT	250V	20µF
C564	ECEA2AU2R2	ELECT	100V	2.2µF
C565	ECQP1H273J	FILM	100V	2.2µF
C566	ECKC2H471J	CERAMIC	500V	470pF
C567	ECA1EHG102B	ELECT	25V	470pF
C568	ECKC2H471J	CERAMIC	500V	470pF
C569	ECKC2H102J	CERAMIC	500V	1nF
C601	ECUV1H104KBX	S.M. CAP	50V	100nF
C602	ECA1HM101GB	ELECT	50V	100µF
C603	ECUV1H102JCX	S.M. CAP	50V	1nF
C604	ECJ2VF1H223Z	ELECT	350V	22nF
C605	ECA1HM101GB	ELECT	50V	100µF
C606	ECA1HM3R3GB	ELECT	50V	3.3µF
C607	ECJ2VF1H104Z	ELECT	350V	100nF
C608	ECUV1H153KBX	S.M. CAP	50V	15nF
C609	ECUV1H153KBX	S.M. CAP	50V	15nF
C610	ECUV1H153KBX	S.M. CAP	50V	15nF
C611	ECUV1H153KBX	S.M. CAP	50V	15nF
C612	ECUV1H153KBX	S.M. CAP	50V	15nF
C613	ECUV1H153KBX	S.M. CAP	50V	15nF
C614	ECUV1H050CCX	S.M. CAP	50V	50pF

Cct Ref	Parts Number	Description		
C615	ECUV1H050CCX	S.M. CAP	50V	50pF
C616	ECA1HM101GB	ELECT	50V	100µF
C617	ECUV1H223KBX	S.M. CAP	50V	22nF
C618	ECA1CM221GB	ELECT	16V	220µF
C619	ECJ2VB1H473K	ELECT	350V	47nF
C620	ECA1HM101GB	ELECT	50V	100µF
C621	ECJ2VB1C104K	ELECT	350V	100nF
C622	ECUV1H683KBX	S.M. CAP	50V	68nF
C623	ECUV1H102JCX	S.M. CAP	50V	1nF
C624	ECJ3VB1C474K	ELECT	3.5KV	470nF
C625	ECJ3VB1C474K	ELECT	3.5KV	470nF
C626	ECJ3VB1C474K	ELECT	3.5KV	470nF
C627	ECA1CM100GB	ELECT	16V	10µF
C628	ECUV1H104KBX	S.M. CAP	50V	100nF
C629	ECUV1H100DCX	S.M. CAP	50V	10pF
C630	ECUV1H683ZFX	S.M. CAP	50V	68nF
C631	ECUV1H270JCX	S.M. CAP	50V	27pF
C632	ECUV1H271JCX	S.M. CAP	50V	270pF
C633	ECUV1H271JCX	S.M. CAP	50V	270pF
C634	ECUV1H271JCX	S.M. CAP	50V	270pF
C635	ECUV1H180JCX	S.M. CAP	50V	18pF
C636	ECUV1H271JCX	S.M. CAP	50V	270pF
C637	ECUV1H101JCX	S.M. CAP	50V	100pF
C638	ECUV1H471JCX	S.M. CAP	50V	470pF
C639	ECUV1H332KBM	S.M. CAP	50V	3.3nF
C701	ECA1HHG101B	ELECT	50V	100µF
C702	ECUV1H103KBX	S.M. CAP	50V	10nF
C703	ECEA1HGE100	ELECT	50V	10µF
C704	ECQB1H223K	FILM	50V	22nF
C705	ECQB1H152K	FILM	50V	1.5nF
C804	ECQE2A474MWB	FILM	100V	470nF
C806	ECKWNA101MBC	CERAMIC	400V	100µF
C807	ECKC2H472J	CERAMIC	500V	4.7nF
C808	ECKC2H472J	CERAMIC	500V	4.7nF
C809	ECKC2H472J	CERAMIC	500V	4.7nF
C810	ECKC2H472J	CERAMIC	500V	4.7nF
C811	ECOS2GA221CA	ELECT	400V	220µF
C814	ECKC3D102J	CERAMIC	2KV	1nF
C815	ECKC1H471J	CERAMIC	50V	470pF
C816	EEUFB1E820B	CERAMIC	25V	82pF
C817	ECQE6104K	FILM	600V	100nF
C818	ECKWNA332MEC	CERAMIC	250V	3.3nF
C819	ECQB1H182K	FILM	50V	1.8nF
C850	ECKC3D471JB	CERAMIC	2KV	470pF
C851	ECA2CM221E	ELECT	160V	220µF
C852	ECA2CHG101E	ELECT	160V	100µF
C853	ECKC2H471J	CERAMIC	500V	470pF
C854	ECA1EM102GB	ELECT	25V	100µF
C855	ECKC2H471J	CERAMIC	500V	470pF
C856	ECA1AHG222B	ELECT	10V	470pF
C857	ECKC2H471J	CERAMIC	500V	470pF
C858	ECEA1HGE102	ELECT	50V	470pF
C859	ECJ2VF1H104Z	ELECT	350V	100nF
C860	ECA1HM101GB	ELECT	50V	100µF
C862	ECJ2VF1H104Z	ELECT	350V	100nF
C863	ECA1HM101GB	ELECT	50V	100µF
C866	ECJ2VF1H104Z	ELECT	350V	100nF
C867	ECA1CM100GB	ELECT	16V	10µF
C868	ECA1CM100GB	ELECT	16V	10µF
C869	ECA1EM101GB	ELECT	25V	100µF
C870	ECA1EM471GB	ELECT	25V	470µF
C871	ECA1CM102B	ELECT	16V	470µF
C872	ECA1CM471GB	ELECT	16V	470µF
C873	ECA1CM100GB	ELECT	16V	10µF
C875	ECA2CM4R7B	ELECT	160V	10µF
C876	ECA1AHG471E	ELECT	10V	470pF

Cct Ref	Parts Number	Description		
C902	ECA1VM101GB	ELECT	35V	100µF
C903	ECUV1H472KBX	S.M. CAP	50V	4.7nF
C904	ECUV1H472KBX	S.M. CAP	50V	4.7nF
C906	ECUV1H471KBX	S.M. CAP	50V	470pF
C908	ECUV1H151JCX	S.M. CAP	50V	150pF
C909	ECKC2H472J	CERAMIC	500V	4.7nF 
C910	ECKC2H472J	CERAMIC	500V	4.7nF 
C911	ECUV1H151JCX	S.M. CAP	50V	150pF
C912	ECEA2CU100	ELECT	160V	10µF
C913	ECA1HM101GB	ELECT	50V	100µF
C914	ECA1HM101GB	ELECT	50V	100µF
C916	ECEA2CGE100	ELECT	160V	10µF
C950	ECJ2VB1C104K	ELECT	350V	100nF
C1061	ECUV1H103KBX	S.M. CAP	50V	10nF
C1062	ECA1HM101GB	ELECT	50V	100µF
C1063	ECUV1H331JCX	S.M. CAP	50V	330pF
C1101	ECJ2VF1H104Z	ELECT	350V	100nF
C1102	ECA0JM101G	ELECT	6.3V	100µF
C1103	ECUV1H220JCX	S.M. CAP	50V	22pF
C1104	ECUV1H220JCX	S.M. CAP	50V	22pF
C1105	ECUV1H101JCX	S.M. CAP	50V	100pF
C1108	ECJ2VB1H333K	ELECT	350V	33nF
C1111	ECA1CM100GB	ELECT	16V	10µF
C1112	ECUV1H103KBX	S.M. CAP	50V	10nF
C1115	ECJ3VB1C474K	ELECT	3.5KV	470nF
C1116	ECUV1H472KBX	S.M. CAP	50V	4.7nF
C1117	ECJ2VF1H104Z	ELECT	350V	100nF
C1118	ECUV1H103KBX	S.M. CAP	50V	10nF
C1119	ECUV1H221JCX	S.M. CAP	50V	220pF
C1120	ECJ2VF1H104Z	ELECT	350V	100nF
C1121	ECUV1H221JCX	S.M. CAP	50V	220pF
C1123	ECUV1H101JCX	S.M. CAP	50V	100pF
C1124	ECUV1H391JCX	S.M. CAP	50V	390pF
C1125	ECUV1H391JCX	S.M. CAP	50V	390pF
C1126	ECUV1H391JCX	S.M. CAP	50V	390pF
C1127	ECUV1H221JCX	S.M. CAP	50V	220pF
C1128	ECUV1H223KBX	S.M. CAP	50V	22nF
C1129	ECUV1H270JCX	S.M. CAP	50V	27pF
C2101	ECUV1H102JCX	S.M. CAP	50V	1nF
C2102	ECUV1H102JCX	S.M. CAP	50V	1nF
C2103	ECUV1H102JCX	S.M. CAP	50V	1nF
C2104	ECUV1H102JCX	S.M. CAP	50V	1nF
C2105	ECUV1H102JCX	S.M. CAP	50V	1nF
C2106	ECUV1H102JCX	S.M. CAP	50V	1nF
C2107	ECUV1H102JCX	S.M. CAP	50V	1nF
C2108	ECUV1H102JCX	S.M. CAP	50V	1nF
C2109	ECUV1H102JCX	S.M. CAP	50V	1nF
C2110	ECUV1H102JCX	S.M. CAP	50V	1nF
C2111	ECA1CM100GB	ELECT	16V	10µF
C2112	ECA1CM100GB	ELECT	16V	10µF
C2113	ECA1HM3R3GB	ELECT	50V	3.3µF
C2114	ECJ2VF1H104Z	ELECT	350V	100nF
C2115	ECUV1H221JCX	S.M. CAP	50V	220pF
C2116	ECUV1H221JCX	S.M. CAP	50V	220pF
C2117	ECUV1H221JCX	S.M. CAP	50V	220pF
C2118	ECUV1H221JCX	S.M. CAP	50V	220pF
C2119	ECUV1H221JCX	S.M. CAP	50V	220pF
C2120	ECUV1H221JCX	S.M. CAP	50V	220pF
C2121	ECA1CM100GB	ELECT	16V	10µF
C2122	ECJ2VF1H104Z	ELECT	350V	100nF
C2123	ECUV1H221JCX	S.M. CAP	50V	220pF
C2124	ECUV1H070DTX	S.M. CAP	50V	70pF
C2125	ECUV1H470JCX	S.M. CAP	50V	47pF
C2126	ECUV1H070DTX	S.M. CAP	50V	70pF
C2127	ECUV1H010CCX	S.M. CAP	50V	1pF
C2128	ECUV1H010CCX	S.M. CAP	50V	1pF

Cct Ref	Parts Number	Description		
C2129	ECA1CM102B	ELECT	16V	1pF
C2130	ECA1CM331B	ELECT	16V	330µF
C2131	ECUV1H103ZFX	S.M. CAP	50V	10nF
C2132	ECUV1H103ZFX	S.M. CAP	50V	10nF
C2134	ECUV1H103ZFX	S.M. CAP	50V	10nF
C2135	ECA1HM101GB	ELECT	50V	100µF
C2136	ECJ2VF1H104Z	ELECT	350V	100nF
C2137	ECA1CM100GB	ELECT	16V	10µF
C2138	ECUV1H471KBX	S.M. CAP	50V	470pF
C2139	ECUV1H221JCX	S.M. CAP	50V	220pF
C2140	ECA1HM101GB	ELECT	50V	100µF
C2141	ECUV1H152JCX	S.M. CAP	50V	1.5pF
C3001	ECUV1H222JCX	S.M. CAP	50V	2.2nF
C3002	ECUV1H222JCX	S.M. CAP	50V	2.2nF
C3003	ECA1CM470GB	ELECT	16V	47µF
C3005	ECUV1H561JCX	S.M. CAP	50V	560pF
C3006	ECJ3VB1C474K	ELECT	3.5KV	470nF
C3007	ECUV1H222JCX	S.M. CAP	50V	2.2nF
C3008	ECUV1H222JCX	S.M. CAP	50V	2.2nF
C3009	ECUV1H222JCX	S.M. CAP	50V	2.2nF
C3010	ECA1CM470GB	ELECT	16V	47µF
C3012	ECUV1H561JCX	S.M. CAP	50V	560pF
C3013	ECJ3VB1C474K	ELECT	3.5KV	470nF
C3014	ECUV1H222JCX	S.M. CAP	50V	2.2nF
C3015	ECUV1H222JCX	S.M. CAP	50V	2.2nF
C3016	ECUV1H222JCX	S.M. CAP	50V	2.2nF
C3017	ECA1CM470GB	ELECT	16V	47µF
C3019	ECUV1H561JCX	S.M. CAP	50V	560pF
C3020	ECJ3VB1C474K	ELECT	3.5KV	470nF
C3021	ECUV1H222JCX	S.M. CAP	50V	2.2nF
C3022	ECUV1H222JCX	S.M. CAP	50V	2.2nF
C3023	ECUV1H222JCX	S.M. CAP	50V	2.2nF
C3024	ECA1CM470GB	ELECT	16V	47µF
C3026	ECUV1H561JCX	S.M. CAP	50V	560pF
C3027	ECJ3VB1C474K	ELECT	3.5KV	470nF
C3028	ECUV1H222JCX	S.M. CAP	50V	2.2nF
C3029	ECA1HM101GB	ELECT	50V	100µF
C3032	ECUV1H271JCX	S.M. CAP	50V	270pF
C3033	ECUV1H271JCX	S.M. CAP	50V	270pF
C3034	ECUV1H271JCX	S.M. CAP	50V	270pF
C3035	ECUV1H271JCX	S.M. CAP	50V	270pF
C3101	ECUV1H104KBX	S.M. CAP	50V	100nF
C3102	ECUV1E104KBX	S.M. CAP	25V	100nF
C3111	ECUV1H391JCX	S.M. CAP	50V	390pF
C3112	ECUV1H271JCX	S.M. CAP	50V	270pF
C3201	ECUV1H103KBX	S.M. CAP	50V	10nF
C3202	ECUV1H103KBX	S.M. CAP	50V	10nF
C3203	ECUV1H561JCX	S.M. CAP	50V	560pF
C3204	ECUV1H561JCX	S.M. CAP	50V	560pF
C3205	ECA1HM470GB	ELECT	50V	47µF
C3206	ECUV1H561JCX	S.M. CAP	50V	560pF
C3207	ECUV1H561JCX	S.M. CAP	50V	560pF
C3208	ECA1HM470GB	ELECT	50V	47µF
C3209	ECUV1H103KBX	S.M. CAP	50V	10nF
C3210	ECJ2VB1C104K	ELECT	350V	100nF
C3211	ECUV1H103KBX	S.M. CAP	50V	10nF
C3212	ECUV1H103KBX	S.M. CAP	50V	10nF
C3213	ECUV1H103KBX	S.M. CAP	50V	10nF
C3214	ECJ2VB1C104K	ELECT	350V	100nF
C3215	ECUV1H103KBX	S.M. CAP	50V	10nF
C3216	ECA1CM330GB	ELECT	16V	33pF
C3217	ECJ2VB1C104K	ELECT	350V	100nF
C3221	ECA1HM4R7	ELECT	50V	4R7µF
C3401	ECQM1H224J	FILM	50V	220nF
C3402	ECUV1H101JCX	S.M. CAP	50V	100pF
C3403	ECA1HM101GB	ELECT	50V	100µF

Cct Ref	Parts Number	Description		
C3404	ECQM1H224J	FILM	50V	220nF
C3405	ECUV1H180JCX	S.M. CAP	50V	18pF
C3406	ECUV1H271JCX	S.M. CAP	50V	270pF
C3407	ECUV1H271JCX	S.M. CAP	50V	270pF
C3408	ECA1HM101GB	ELECT	50V	100μF
C3601	ECA1HM101GB	ELECT	50V	100μF
JSE28	ECUV1H104KBX	S.M. CAP	50V	100nF

TERMINALS AND LINKS

JK2301	JPJ841101320	RCA / HEADPHONE JACK
JK3201	TJB16656	A.V. TERMINAL

SWITCHES

S802	ESB92S11B	SWITCH
S1251	EVQ23405R	SWITCH
S1252	EVQ23405R	SWITCH
S1253	EVQ23405R	SWITCH
S1254	EVQ23405R	SWITCH
S1255	EVQ23405R	SWITCH

Cct Ref	Parts Number	Description

SCHEMATIC DIAGRAMS FOR MODEL

TX-W28R4

(EURO-4 CHASSIS)

IMPORTANT SAFETY NOTICE

Components identified by  mark have special characteristics important for safety. When replacing any of these components, use only manufacturer's specified parts.

NOTE

1. RESISTOR

All resistors are carbon $\frac{1}{4}W$ resistor, unless marked otherwise.
Unit of resistance is OHM (Ω) ($k=1,000$, $M=1,000,000$)


2. CAPACITORS

All capacitors are ceramic 50V unless marked otherwise.
Unit of capacitance is μF unless otherwise stated.

3. COIL

Unit of inductance is μH , unless otherwise stated.

4. TEST POINT



Test Point Position

5. EARTH SYMBOL



Chassis Earth (Cold)



Line Earth (Hot)

6. VOLTAGE MEASUREMENT

Voltage is measured by a DC voltmeter.

Measurement conditions are as follows:

Power source AC 220V-240V, 50Hz
Receiving Signal Colour Bar signal (RF)
All customer controls Maximum position

7.



Indicates the Video signal path



Indicates the Audio signal path

These schematic diagrams are the latest at time of printing and are subject to change without notice.


REMARKS

- a. Do not touch the hot part, or the hot and cold parts at the same time, as you are liable to a shock hazard.
- b. Do not short circuit the hot and cold circuits as electrical components may be damaged.
- c. Do not connect an instrument, such as an oscilloscope, to the hot and cold circuits simultaneously as this may cause fuse failure. Connect the earth of the instruments to the earth connection of the circuit being measured.
- d. Make sure to disconnect the power plug before removing the chassis.

NOTE

1. The Power Supply Circuit contains a circuit area, which uses a separate power supply to isolate the earth connection. The circuit is defined by HOT and COLD indications in the schematic diagram. All circuits, except the Power Circuit, are COLD.


Y BOARD !
TNP8EY012





E BOARD
TNP8EE009

CRT DRIVE


SERVICE/TEST








JK3201
TJB16656



CONDUCTOR VIEWS


E - BOARD TNP8EE009

TRAN'S	DIODES	
Q3601 L8	D3103 B7	D558 L4
Q3007 M9	D3101 B7	D557 M4
Q3001 N8	D3102 B7	D556 K1
Q3006 N10	D2161 G9	D555 N3
Q2304 I7	D2105 G10	D554 M4
Q2303 M6	D2104 F9	D552 J2
Q2301 I7	D2103 G10	D551 K3
Q2103 I8	D2102 G9	D511 M5
Q2102 H8	D1103 F8	D502 I2
Q2101 G10	D1102 F7	D501 I2
Q1108 F9	D1101 G7	D457 L5
Q1107 C7	D1051 A9	D456 L5
Q1106 C7	D875 J5	D454 L5
Q1105 C7	D874 J4	D453 F9
Q1104 C7	D873 B5	D254 C5
Q1101 F7	D871 A5	D253 C5
Q1052 A9	D870 871	D252 B5
Q1051 C8	D869 B4	D251 B4
Q951 J9	D668 B4	IC'S
Q950 J9	D867 A3	IC2101 H8
Q857 J4	D866 I9	IC1105 F7
Q856 F9	D865 I9	IC1104 C9
Q855 J5	D864 I10	IC1103 F8
Q854 B4	D863 G9	IC1102 D10
Q853 B4	D862 N10	IC1101 D8
Q852 B5	D861 J9	IC1051 A10
Q850 F5	D860 I10	IC852 H10
Q701 J5	D859 H5	IC851 G5
Q552 N3	D858 E5	IC850 H4
Q551 K1	D857 E5	IC801 G2
Q503 I2	D855 F4	IC701 K5
Q451 F8	D854 G4	IC601 L7
Q394 K9	D853 H3	IC451 L5
Q305 K9	D852 I4	IC251 D6
Q303 K9	D851 I4	TP'S
Q302 J9	D850 H4	TPE14 M5
Q301 K9	D806 G2	TPE13 M4
Q253 C4	D805 H2	TPE12 K4
Q252 C4	D804 H1	TPE11 N5
Q252 C4	D803 H1	TPE10 B5
Q251 D4	D802 G2	TPE9 E5
Q105 M8	D801 E1	TPE8 F5
Q104 M9	D705 J5	TPE7 I9
Q103 F10	D704 K5	TPE6 J10
Q102 G10	D703 K5	TPE5 G5
Q101 H10	D702 K5	TPE4 G5
	D701 K5	TPE3 E5
	D609 M5	TPE2 I5
	D607 L9	TPE1 M4



Y - BOARD TNP8EY012

TRANSISTORS
Q909 E1
Q908 C2
Q907 F4
Q906 G3
Q905 F5
Q354 A7
Q353 G6
Q352 F6
Q351 F6
DIODES
D906 F1
D905 G4
D904 D3
D902 G4
D901 G3
D364 C9
D363 C8
D362 B9
D361 B7
D360 D8
D359 G6
D358 E7
D357 F7
D356 G7
D355 F7
D354 G7
TEST POINTS
TPY6 B8
TPY5 D5
TPY4 E5
TPY3 F6
TPY2 E7
TPY1 G6
IC'S
IC351 E8



M - BOARD TNP8EM013


TRANSISTORS

Q1061	C2
Q1062	C2
Q3201	C8
Q3202	B9
Q3203	B8
Q3204	B9
Q3205	B9
Q3206	A9
Q3207	B10
Q3208	B9
Q3209	B10

DIODES

D1061	C1
D3201	B4
D3202	B4
D3203	B3
IC'S	

IC1601	D2
--------	----



NOTES