

Creating and playing play lists

Creating play lists

RAM

You can create play lists that are collections of your favorite scenes from pre-recorded programs. The location information of the beginning and the end of a scene is stored on the disc and played in the designated sequence. This means that play lists use up hardly any disc space because only the location (START and END points) of the play list are stored on the disc. The play list content is accessed from the program that it resides in.

Preparation

- Press [DVD].
- Insert a pre-recorded disc.

1 During stop:

Press [PLAY LIST].

2 Press [◀].

- This step is not necessary if play lists have not been created.

3 The “Create a new Play List?” message appears. Select “Yes” using [◀], and press [SELECT].

- The play list creation screen now appears, and play starts from the first of the recorded programs




4 Perform forward (or reverse) search, slow playback, etc. to locate the START point of the scene.



5 Once the START point has been located, press [SELECT].

- A thumbnail image and time of the START point are displayed.



6 Perform forward (or reverse) search, slow playback, etc. to locate the END point of the scene, and press [SELECT].

- A thumbnail image and time of the END point are displayed.

