



2. Off Timer

- 3** After performing steps 1 and 2 on p. 108, select “2 Off Timer” using [▲] and [▼], and press [SELECT].



- 4** Select the item to be set using [▲] and [▼], and press [SELECT].



1. 2hr

The unit's power is automatically turned off if no operation has been performed for about 2 hours or more.

2. 6hr (factory setting)

The unit's power is automatically turned off if no operation has been performed for about 6 hours or more.

3. Off


The automatic power-off function is cancelled.

3. Remote Control Code


Refer to p. 95-96.

4. FL Display

- 3** After performing steps 1 and 2 on p. 108, select “4 FL Display” using [▲] and [▼], and press [SELECT].



- 4** Select the item to be set using [▲] and [▼], and press [SELECT].



1. Dim during DVD/VCD Play (Auto)


When the power is on, the unit display window is dark only during DVD-RAM, DVD-Video discs or Video CDs. When the power is off, it is dim.

2. Bright (factory setting)

When the power is on, anything shown on the unit display window is bright at all times. When the power is off, it is dim.

3. Dim


Anything shown on the unit display window is dim at all times regardless of whether the power is on or off.




1 Set Up (continued)

5. Blue Background

- 3** After performing steps 1 and 2 on p. 108, select “5 Blue Background” using [▲] and [▼], and press [SELECT].



- 4** Select the item to be set using [▲] and [▼], and press [SELECT].



1. On (factory setting)


When a channel with no broadcasts is selected or when the signals are extremely weak, a blue screen appears and the sound is muted.

2. Off


When a channel with no broadcasts is selected or the signals are extremely weak, the blue screen does not appear.

6. Color Picture Recording

- 3** After performing steps 1 and 2 on p. 108: Select “6 Color Picture Recording” using [▲] and [▼], and press [SELECT].



- 4** Select the item to be set using [▲] and [▼], and press [SELECT].



1. On (factory setting)

- For recording in color.

2. Off (B&W)

- For recording in black and white.