


5 Entering a title for each play list


• Proceed after performing steps 1 to 3 on p. 82.

4 Select “Enter Title” using [▲] and [▼], and press [SELECT].

• The title input screen now appears.




5 Enter the title using [◀], [▲], [▶] and [▼] to select the characters and press [SELECT].



6 When the title has been entered:

Select “SET” using [◀], [▲], [▶] and [▼], and press [SELECT].




6 Displaying the play list information

• Proceed after performing steps 1 to 3 on p. 82.

4 Select “Properties” using [▲] and [▼], and press [SELECT].



• The name of the play list, if one has been entered, the play list numbers, creation date, total scene recording time and number of scenes will be displayed.



■ **Clearing the display**

Press [SELECT].

Entering titles

The titles and the names of programs and discs can be input using [DIRECT NAVIGATOR] while the names of play lists can be entered using the [PLAY LIST]. The title entry procedure is described in this section.

Preparation


- Press [DVD].
- Insert a pre-recorded disc.
- Using direct navigator, display the program title input screen (p. 71) or disc name input screen (p. 77).
- Using play list, display the scene name input screen on the left.

Title entry procedure

RAM

Entering characters

Select the desired alphanumeric or symbols using [◀], [▲], [▼] and [▶], and press [SELECT].



■ Entering spaces

Select “SPACE” using [◀], [▲], [▼] and [▶], and press [SELECT].

• A space equivalent to one character is now input.

■ When the wrong alphanumeric or symbol was input

Select “BACKSPACE” using [◀], [▲], [▼] and [▶], and press [SELECT].

• A character is deleted every time [SELECT] is pressed.

■ Deleting and adding characters already input

1. Select already input sentences using [▲].
2. Move the cursor “_” to one character behind the character to be deleted using [▼] and [▶].
3. Select “BACK SPACE” using [◀], [▲], [▼] and [▶], and press [SELECT].
4. Select characters to be input for correction using [◀], [▲], [▼] and [▶] and press [SELECT].

■ To complete the entry

Select “SET” using [◀], [▲], [▼] and [▶], and press [SELECT].