

Using the direct navigator

RAM

When a program is recorded using this unit, its details are automatically entered on the direct navigator program list. This list can be used to locate the programs that are to be viewed. The direct navigator program list is recorded on the disc that contains the program recordings.


Preparation

- Press [DVD].
- Insert a pre-recorded disc.

1 During playback or stop:

[Remote control]: Press [NAVIGATOR].

[Unit]: Press [DIRECT NAVIGATOR].




- The program numbers, recording dates, channels, start times and titles (only if titles have been entered; see p. 71) of the recorded programs are displayed.
- When [NAVIGATOR] has been pressed during stop, playback starts and this screen appears.

2 Select the program to be viewed using [▲] and [▼].

Example where program "2" has been selected

- If there are six or more programs, keep pressing [▼] to scroll down to the bottom half of the list.



3 Press [SELECT].

- The selected program can be viewed.
- It can also be viewed by pressing [NAVIGATOR], [RETURN] or [PLAY].

