



6 Clock Settings (continued)

2. Manual Clock Setting

- 3** After performing steps 1 and 2 on p. 108, select “6 Clock Settings” using [▲] and [▼], and press [SELECT].




- 4** Select “Manual Clock Setting” using [▲] and [▼], and press [SELECT].




- 5** Set the “MONTH” using [▲] and [▼].

- After setting the month, press [▶] to advance to “DAY.”




- 6** Set the “DAY” using [▲] and [▼].

- After setting the day, press [▶] to advance to “YEAR.”



- 7** Set the “YEAR” using [▲] and [▼].

- Any year from 1988 to 2087 can be set.
- After setting the year, press [▶] to advance to “HOUR.”



- 8** Set the “HOUR” using [▲] and [▼].

- The clock display is based on the 12-hour system.
- After setting the hour, press [▶] to advance to “MINUTE.”

