


# Connecting a cable TV box (adaptor)

A specially designed cable TV box (adaptor) may be required to watch CATV broadcasts.

- Before proceeding with the connections, turn off the power of the components and make sure that your hands are dry.
- Read the operating instructions of the TV set and home terminal as well. (For further details, consult the CATV company.)

Connect the components correctly in the order below.



## Notes:

- VCR Plus+ programming is not possible unless the guide channels of each broadcast station have been set. For details on setting the reception channels, refer to p. 19.
- Switch the unit's input when pay-per-view broadcasts are to be received. The pay-per-view broadcasts received by this unit's tuner will not be reproduced clearly. Switch to the external input that the cable TV box is connected (external input "L1" in the connections example shown above). (For further details, consult the CATV company.)
- When both composite video (yellow) and S-video cables are connected to the same input connectors (L1 or L2 or L3), the S-video connector has higher priority. (To view the composite video signal, unplug the S-video cable.)