

Virtual Surround Sound (V.S.S.)

Enjoying V.S.S. through the front speakers

RAM DVD-V

Provided that the DVD disc being played is recorded with the Dolby Digital 2 channel system or higher, you can enjoy surround sound through the front speakers (L/R) alone.

Preparation

- Press [DVD].

1 During playback:

Press [DISPLAY] twice to show the menu bar (unit information screen).

Example using DVD-Video disc



2 Select "V.S.S. mode" using [◀] and [▶].



3 Select "⌘" (speaker mode) using [▲] and [▼].



4 Press [▶] then [▲] or [▼] to select the level.

- Each time this button is pressed, the V.S.S. effect is changed in the following sequence: 1 (level 1) ↔ 2 (level 2) ↔ OFF ↔
- The effect can also be selected by pressing [V.S.S.].
- The V.S.S. button's lamp on the unit is illuminated.
- The display in the unit display window changes in the following sequence: SPEAKERS 1 ↔ SPEAKERS 2 ↔ SPEAKERS OFF ↔

