

INPUT CONDITION							OUTPUT RESULT						
POWER	AV2 SELECT	TV/ VTR	EE/ VV	OSD ON(H)	INPUT CH	AV2 PB(H)	AV1 OUT	AV2 OUT	AV1 PB(H)	RGB SW	VCR IN	VCR OUT	
P.ON	EXT	TV	EE	L	NORMAL TUN	---	VTR OUT	VTR OUT	L	OFF	TUN	TUN	
					C+ TUNER	---	VTR OUT	VTR OUT	L	OFF	TUN	TUN	
					AV1	---	VTR OUT	VTR OUT	L	OFF	AV1	AV1	
					AV2	---	VTR OUT	VTR OUT	L	ON	AV2	AV2	
					AV3	---	VTR OUT	VTR OUT	L	OFF	AV3	AV3	
					SAT.NOR TUN	---	VTR OUT	VTR OUT	L	OFF	SAT.TUN	SAT.TUN	
					SAT.C+ TUN	---	VTR OUT	VTR OUT	L	OFF	SAT.TUN	SAT.TUN	
				H	NORMAL TUN	---	VTR OUT	VTR OUT	H	OFF	TUN	TUN	
					C+ TUNER	---	VTR OUT	VTR OUT	H	OFF	TUN	TUN	
					AV1	---	VTR OUT	VTR OUT	H	OFF	AV1	AV1	
					AV2	---	VTR OUT	VTR OUT	H	ON	AV2	AV2	
					AV3	---	VTR OUT	VTR OUT	H	OFF	AV3	AV3	
					SAT.NOR TUN	---	VTR OUT	VTR OUT	H	OFF	SAT.TUN	SAT.TUN	
					SAT.C+ TUN	---	VTR OUT	VTR OUT	H	OFF	SAT.TUN	SAT.TUN	
		VTR	EE	L	NORMAL TUN	---	VTR OUT	VTR OUT	H	OFF	TUN	TUN	
					C+ TUNER	---	VTR OUT	VTR OUT	H	OFF	TUN	TUN	
					AV1	---	VTR OUT	VTR OUT	H	OFF	AV1	AV1	
					AV2	---	VTR OUT	VTR OUT	H	ON	AV2	AV2	
					AV3	---	VTR OUT	VTR OUT	H	OFF	AV3	AV3	
					SAT.NOR TUN	---	VTR OUT	VTR OUT	H	OFF	SAT.TUN	SAT.TUN	
					SAT.C+ TUN	---	VTR OUT	VTR OUT	H	OFF	SAT.TUN	SAT.TUN	
				H	NORMAL TUN	---	VTR OUT	VTR OUT	H	OFF	TUN	TUN	
					C+ TUNER	---	VTR OUT	VTR OUT	H	OFF	TUN	TUN	
					AV1	---	VTR OUT	VTR OUT	H	OFF	AV1	AV1	
					AV2	---	VTR OUT	VTR OUT	H	ON	AV2	AV2	
					AV3	---	VTR OUT	VTR OUT	H	OFF	AV3	AV3	
					SAT.NOR TUN	---	VTR OUT	VTR OUT	H	OFF	SAT.TUN	SAT.TUN	
					SAT.C+ TUN	---	VTR OUT	VTR OUT	H	OFF	SAT.TUN	SAT.TUN	
		VV	---	NORMAL TUN	---	VTR OUT	VTR OUT	H	OFF	TUN	PB		
				C+ TUNER	---	VTR OUT	VTR OUT	H	OFF	TUN	PB		
				AV1	---	VTR OUT	VTR OUT	H	OFF	AV1	PB		
				AV2	---	VTR OUT	VTR OUT	H	OFF	AV2	PB		
				AV3	---	VTR OUT	VTR OUT	H	OFF	AV3	PB		
				SAT.NOR TUN	---	VTR OUT	VTR OUT	H	OFF	SAT.TUN	PB		
				SAT.C+ TUN	---	VTR OUT	VTR OUT	H	OFF	SAT.TUN	PB		
	DECODER	TV	EE	L	NORMAL TUN	L	VTR OUT	AV1 IN	L	OFF	TUN	TUN	
						H	AV2 IN	AV1 IN	H	ON	TUN	TUN	
					C+ TUNER	L	VTR OUT	TUN IN	L	OFF	TUN	TUN	
						H	VTR OUT	TUN IN	L	OFF	AV2	AV2	
					AV1	L	VTR OUT	AV1 IN	L	OFF	AV1	AV1	
						H	AV2 IN	AV1 IN	H	ON	AV2	AV2	
					AV2	L	VTR OUT	AV1 IN	L	ON	AV2	AV2	
						H	AV2 IN	AV1 IN	H	ON	AV2	AV2	
					AV3	L	VTR OUT	AV1 IN	L	OFF	AV3	AV3	
						H	AV2 IN	AV1 IN	H	ON	AV3	AV3	
					SAT.NOR TUN	L	VTR OUT	AV1 IN	L	OFF	SAT.TUN	SAT.TUN	
						H	AV2 IN	AV1 IN	H	ON	SAT.TUN	SAT.TUN	
				SAT.C+ TUN	L	VTR OUT	SAT IN	L	OFF	SAT.TUN	SAT.TUN		
					H	VTR OUT	SAT IN	L	OFF	AV2	AV2		
				H	NORMAL TUN	L	VTR OUT	AV1 IN	H	OFF	TUN	TUN	
						H	VTR OUT	AV1 IN	H	OFF	TUN	TUN	
					C+ TUNER	L	VTR OUT	TUN IN	H	OFF	TUN	TUN	
						H	VTR OUT	TUN IN	H	ON	AV2	AV2	
					AV1	L	VTR OUT	AV1 IN	H	OFF	AV1	AV1	
						H	VTR OUT	AV1 IN	H	ON	AV2	AV2	
					AV2	L	VTR OUT	AV1 IN	H	ON	AV2	AV2	
						H	VTR OUT	AV1 IN	H	ON	AV2	AV2	