

- (R) :TO POWER SUPPLY/RF SECTION
(S) :TO SYSTEM CONTROL & SERVO SECTION
(A) :TO HI-FI AUDIO SECTION
(I) :TO INPUT/OUTPUT SECTION
(T) :TO TIMER SECTION

VIDEO MAIN SIGNAL PATH IN REC MODE

VIDEO MAIN SIGNAL PATH IN PLAYBACK MODE

AUDIO MAIN SIGNAL PATH IN REC MODE

AUDIO MAIN SIGNAL PATH IN PLAYBACK MODE

P4003 (TO A/C HEAD)	
AUDIO ERASE IN	1
GND	2
A HEAD (R)	3
A HEAD (W)	4
CTL HEAD (-)	5
CTL HEAD (+)	6

(S) CTL HEAD (+)	
(S) CTL HEAD (-)	
(S) SHORT DET (I)	
(S) BIAS (T)	

P4002 (TO FULL ERASE HEAD)	
FULL ERASE OUT	1
FULL ERASE IN	2

(S) HEAD SW	A1
(S) H AMP SW	A2
(S) ENV SELECT	A3
(S) TRACKING ENV.	A4
(S) D REC (H)	A5
(S) CURR EMPH (H)	A6
(R) TUNER AUDIO (N)	A7
(T) P FAIL MUTE	A8
(A) AUDIO OUT (N)	A9
(S) MUTE (H)	A10
(A) AUDIO IN (N)	A11

P3502 (TO CYLINDER UNIT)	
LP R	1
LP COM	2
LP L	3
SP R	4
SP COM	5
SP L	6
GND	7
AUDIO HEAD L	8
AUDIO HEAD COM	9
AUDIO HEAD R	10

(A) AUDIO HEAD R	
(A) AUDIO HEAD COM	
(A) AUDIO HEAD L	

(S) D.AREC (H)	
(S) PAL EP (H)	

(R) BIAS 5V	
(R) VIDEO 5V	
(R) GND	

