





← VIDEO MAIN SIGNAL PATH IN REC MODE

← AUDIO MAIN SIGNAL PATH IN REC MODE



TO LUMINANCE & CHROMINANCE/  
AUDIO SECTION PP4001(E-1)

PS4801	1
IR	1
N.SW 5V	2
FRONT AUDIO (R)	3
GND	4
A3	5
A2	6
GND	7
FRONT VIDEO	8
GND	9
FRONT AUDIO (L)	10

NOTE:DO NOT USE ANY PART NUMBER SHOWN ON THIS SCHEMATIC DIAGRAM FOR ORDERING.WHEN YOU ORDER A PART,PLEASE REFER TO PARTS LIST.

NV-FJ730A/EA/BD/BDX,FJ735AM  
FRONT PACK SCHEMATIC DIAGRAM